




# HEIDENHAIN



## TNC 640

### Conversational Programming User's Manual

NC Software

340590-07

340591-07

340595-07





English (en)

9/2016



### Controls of the TNC

#### Keys






##### Keys on visual display unit

Key	Function
	Selecting the screen layout
	Toggle the display between machining and programming modes
	Soft keys for selecting functions on screen
	Shifting between soft-key rows



##### Alphanumeric keyboard

Key	Function
	File names, comments
	DIN/ISO programming












##### Machine operating modes

Key	Function
	Manual operation
	Electronic handwheel
	Positioning with manual data input
	Program run, single block
	Program run, full sequence



##### Programming modes

Key	Function
	Programming
	Test run

##### Entering and editing coordinate axes and numbers








Key	Function
	Select coordinate axes or enter them in a program
	Numbers
	Decimal point / Reverse algebraic sign
	Polar coordinate entry / Incremental values
	Q parameter programming / Q parameter status
	Capture actual position
	Skip dialog questions, delete words
	Confirm entry and resume dialog
	Conclude block and exit entry
	Clear entries or TNC error message
	Abort dialog, delete program section

##### Tool functions











Key	Function
	Define tool data in the program
	Call tool data









## Manage programs and files, TNC functions

Key	Function
	Select or delete programs and files, external data transfer
	Define program call, select datum and point tables
	Select MOD functions
	Display help text for NC error messages, call TNCguide
	Display all current error messages
	Show calculator
	Show special functions










## Navigation keys

Key	Function
 	Position the cursor
	Go directly to blocks, cycles and parameter functions
	Navigate to the program start or table start
	Navigate to the program end or end of a table line
	Navigate up one page
	Navigate down one page
	Select the next tab in forms
 	Up/down one dialog box or button

## Cycles, subprograms and program section repeats

Key	Function
	Define touch probe cycles
 	Define and call cycles
 	Enter and call labels for subprogramming and program section repeats
	Enter program stop in a program

## Programming path movements

Key	Function
	Approach/depart contour
	FK free contour programming
	Straight line
	Circle center/pole for polar coordinates
	Circular arc with center
	Circle with radius
	Circular arc with tangential connection
 	Chamfer/rounding arc

## Potentiometer for feed rate and spindle speed

Feed rate	Spindle speed
	



**Fundamentals**

#### About this manual

The symbols used in this manual are described below.



This symbol indicates that important information about the function described must be considered.



This symbol indicates that there is one or more of the following risks when using the described function:

- Danger to workpiece
- Danger to fixtures
- Danger to tool
- Danger to machine
- Danger to operator



This symbol indicates a possibly dangerous situation that may cause injuries if not avoided.



This symbol indicates that the described function must be adapted by the machine tool builder. The function described may therefore vary depending on the machine.



This symbol indicates that you can find detailed information about a function in another manual.

#### Would you like any changes, or have you found any errors?

We are continuously striving to improve our documentation for you. Please help us by sending your requests to the following e-mail address:

**tnc-userdoc@heidenhain.de**

## TNC model, software and features

This manual describes functions and features provided by controls as of the following NC software numbers.

TNC model	NC software number
TNC 640	340590-07
TNC 640 E	340591-07
TNC 640 Programming Station	340595-07

The suffix E indicates the export version of the TNC. The following software options are not available in the export version:

- Advanced Function Set 2 (option 9)
- KinematicsComp (option 52)
- 3D-ToolComp (option 92)

The machine manufacturer adapts the usable features of the TNC to his machine by the setting machine parameters. Some of the functions described in this manual may therefore not be among the features provided by the TNC on your machine.

TNC functions that may not be available on your machine include:

- Tool measurement with the TT

In order to find out about the actual features of your machine, please contact the machine manufacturer.

Many machine manufacturers, including HEIDENHAIN, offer programming courses for the TNCs. Participation in one of these courses is recommended to familiarize yourself thoroughly with the TNC functions.



### Cycle Programming User's Manual:

All of the cycle functions (touch probe cycles and fixed cycles) are described in the Cycle Programming User's Manual. If you need this user's manual, please contact HEIDENHAIN if required. ID: 892905-xx



### Software options

The TNC 640 features various software options that can be enabled by your machine tool builder. Each option is to be enabled separately and contains the following respective functions:

#### Additional Axis (options 0 to 7)

---

<b>Additional axis</b>	Additional control loops 1 to 8
------------------------	---------------------------------

#### Advanced Function Set 1 (option 8)

---

<b>Expanded functions Group 1</b>	<b>Machining with rotary tables</b>
-----------------------------------	-------------------------------------

- Cylindrical contours as if in two axes
- Feed rate in distance per minute

##### Coordinate conversions:

Tilting the working plane

#### Advanced Function Set 2 (option 9)

---

<b>Expanded functions Group 2</b>	<b>3-D machining:</b>
-----------------------------------	-----------------------

Export license required

- Motion control with minimum jerk
- 3-D tool compensation through surface normal vectors
- Using the electronic handwheel to change the angle of the swivel head during program run without affecting the position of the tool point. (TCPM = Tool Center Point Management)
- Keeping the tool normal to the contour
- Tool radius compensation perpendicular to traversing direction and tool direction

##### Interpolation:

Linear in 6 axes

#### HEIDENHAIN DNC (option 18)

---

Communication with external PC applications over COM component

#### Display Step (option 23)

---

<b>Display step</b>	<b>Input resolution:</b>
---------------------	--------------------------

- Linear axes down to 0.01 µm
- Rotary axes to 0.00001°

#### Dynamic Collision Monitoring – DCM (option 40)

---

<b>Dynamic Collision Monitoring</b>	<ul style="list-style-type: none"><li>■ The machine manufacturer defines objects to be monitored</li><li>■ Warning in Manual operation</li><li>■ Program interrupt in Automatic operation</li><li>■ Includes monitoring of 5-axis movements</li></ul>
-------------------------------------	---

#### DXF Converter (option 42)

---

<b>DXF converter</b>	<ul style="list-style-type: none"><li>■ Supported DXF format: AC1009 (AutoCAD R12)</li><li>■ Adoption of contours and point patterns</li><li>■ Simple and convenient specification of reference points</li><li>■ Selecting graphical features of contour sections from conversational programs</li></ul>
----------------------	--

## Adaptive Feed Control – AFC (option 45)

### Adaptive Feed Control

- Recording the actual spindle power by means of a teach-in cut
- Defining the limits of automatic feed rate control
- Fully automatic feed control during program run

## KinematicsOpt (option 48)

### Optimizing the machine kinematics

- Backup/restore active kinematics
- Test active kinematics
- Optimize active kinematics

## Mill-Turning (option 50)

### Milling and turning modes

#### Functions:

- Switching between Milling/Turning mode of operation
- Constant surface speed
- Tool-tip radius compensation
- Turning cycles
- Cycle 880: Gear hobbing (option 50 and option 131)

## KinematicsComp (option 52)

### Three-dimensional compensation

Compensation of position and component errors

Export license required

## 3D-ToolComp (option 92)

### 3-D tool radius compensation depending on the tool's contact angle

- Compensate the deviation of the tool radius depending on the tool's contact angle
- Compensation values in a separate compensation value table
- Prerequisite: Working with **LN** blocks

Export license required

## Extended Tool Management (option 93)

### Extended tool management

Python-based

## Advanced Spindle Interpolation (option number 96)

### Interpolating spindle

#### Interpolation turning:

- Cycle 291: Interpolation turning, coupling
- Cycle 292: Interpolation turning, contour finishing

## Spindle Synchronism (option 131)

### Spindle synchronization

- Synchronization of milling spindle and turning spindle
- Cycle 880: Gear hobbing (option 50 and option 131)

## Remote Desktop Manager (option 133)

### Remote operation of external computer units

- Windows on a separate computer unit
- Incorporated in the TNC interface

## Synchronizing Functions (option 135)

### Synchronization functions

#### Real Time Coupling – RTC:

Coupling of axes

---

#### Visual Setup Control – VSC (option number 136)

- |   |  |
|---|--|
| <b>Camera-based monitoring of the setup situation</b> | <ul style="list-style-type: none"><li>■ Record the setup situation with a HEIDENHAIN camera system</li><li>■ Visual comparison of planned and actual status in the workspace</li></ul> |
|---|--|

---

#### Cross Talk Compensation – CTC (option number 141)

- |                                       |   |
|---------------------------------------|---|
| <b>Compensation of axis couplings</b> | <ul style="list-style-type: none"><li>■ Determination of dynamically caused position deviation through axis acceleration</li><li>■ Compensation of the TCP (<b>T</b>ool <b>C</b>enter <b>P</b>oint)</li></ul> |
|---------------------------------------|---|

---

#### Position Adaptive Control – PAC (option 142)

- |                                  |  |
|----------------------------------|--|
| <b>Adaptive position control</b> | <ul style="list-style-type: none"><li>■ Changing of the control parameters depending on the position of the axes in the working space</li><li>■ Changing of the control parameters depending on the speed or acceleration of an axis</li></ul> |
|----------------------------------|--|

---

#### Load Adaptive Control – LAC (option 143)

- |                              |  |
|------------------------------|--|
| <b>Adaptive load control</b> | <ul style="list-style-type: none"><li>■ Automatic determination of workpiece weight and frictional forces</li><li>■ Changing of control parameters depending on the actual mass of the workpiece</li></ul> |
|------------------------------|--|

---

#### Active Chatter Control – ACC (option number 145)

- |                               |   |
|-------------------------------|---|
| <b>Active chatter control</b> | Fully automatic function for chatter control during machining |
|-------------------------------|---|

---

#### Active Vibration Damping – AVD (option number 146)

- |                                 |  |
|---------------------------------|--|
| <b>Active vibration damping</b> | Damping of machine oscillations to improve the workpiece surface |
|---------------------------------|--|

### Feature Content Level (upgrade functions)

Along with software options, significant further improvements of the TNC software are managed via the **Feature Content Level** upgrade functions. If you install a software update on your TNC you do not automatically have the functions available as covered by the FCL.



All upgrade functions are available to you without surcharge when you receive a new machine.

Upgrade functions are identified in the manual as **FCL n**. The **n** signifies the serial number of the development status.

You can purchase a code number in order to permanently enable the FCL functions. For more information, contact your machine tool builder or HEIDENHAIN.

### Intended place of operation

The TNC complies with the limits for a Class A device in accordance with the specifications in EN 55022, and is intended for use primarily in industrially-zoned areas.

### Legal information

This product uses open source software. Further information is available on the control under:

- ▶ Operating mode **Programming**
- ▶ MOD function
- ▶ **LICENSE INFO** soft key

#### New functions

##### New functions 34059x-02

- DXF files can now be opened directly on the TNC in order to extract contours and point patterns, see "Data transfer from CAD files", page 293
- The active tool-axis direction can now be activated in manual mode and during handwheel superimposition as a virtual tool axis, see "Superimpose handwheel positioning during program run: M118 ", page 419
- The machine tool builder can now define any areas on the machine for collision monitoring, see "Dynamic Collision Monitoring (option 40)", page 431
- Writing and reading data in freely definable tables, see "Freely definable tables", page 471
- The function Adaptive Feed Control AFC has been introduced, see "Adaptive Feed Control AFC (option 45)", page 442
- New touch probe Cycle 484 for calibrating the wireless touch probe TT 449, see Cycle Programming User's Manual
- The new HR 520 and HR 550 FS handwheels are supported, see "Traverse with electronic handwheels", page 583
- New operating Cycle 225 Engraving, see Cycle Programming User's Manual
- New Active Chatter Control (ACC) software option, see "Active Chatter Control ACC (option 145)", page 455
- New manual probing cycle "Center line as datum", see "Setting a center line as datum ", page 634
- New function for rounding corners, see "Rounding corners: M197", page 426
- External access to the TNC can now be blocked with a MOD function, see "External access", page 701



### Changed functions 34059x-02

- The maximum number of characters for the NAME and DOC fields in the tool table has been increased from 16 to 32, see "Enter tool data into the table", page 206
- The columns AFC and ACC were added to the tool table, see "Enter tool data into the table", page 206
- Operation and positioning behavior of the manual probing cycles has been improved, see "Using a 3-D touch probe ", page 609
- Predefined values can now be entered into a cycle parameter with the PREDEF function in cycles, see Cycle Programming User's Manual
- The status display has been expanded with the AFC tab, see "Additional status displays", page 92
- The FUNCTION TURNDATA SPIN rotation function has been expanded with an input option for maximum speed, see "Program spindle speed", page 550
- With the KinematicsOpt cycles a new optimization algorithm is now used, see the Cycle Programming User's Manual
- With Cycle 257, CIRCULAR STUD, a parameter is now available with which you can determine the approach position on the stud, see User's Manual for Cycle Programming
- With Cycle 256 RECTANGULAR STUD, a parameter is now available with which you can determine the approach position on the stud, see Cycle Programming User's Manual
- With the manual "Basic Rotation" touch probe cycle, workpiece misalignment can now be compensated for with a table rotation, see "Compensation of workpiece misalignment by rotating the table", page 626

#### New functions 34059x-04

- New special operating mode RETRACT, see "Retraction after a power interruption", page 684
- New graphic simulation, see "Graphics ", page 660
- New MOD function "tool usage file" within the machine settings group, see "Tool usage file", page 704
- New MOD function "set system time" within the systems settings group, see "Set the system time", page 705
- New MOD group "graphic settings", see "Graphic settings", page 700
- With the new syntax for the adaptive feed control (AFC) you can start or end a teach-in cut, see "Recording a teach-in cut", page 447
- With the new cutting data calculator you can calculate the spindle speed and the feed rate, see "Cutting data calculator", page 182
- In the TURNDATA function, you can now define the effect of the tool compensation, see "Tool compensation in the program", page 558
- Now you can activate and deactivate the active chatter control (ACC) with a soft key, see "Activating/deactivating ACC", page 456
- With the jump commands new if/then decisions have been introduced, see "Programming if-then decisions", page 343
- The character set of machining Cycle 225 Engraving has been expanded to include more characters and the diameter sign, see Cycle Programming User's Manual
- New machining Cycle 275 Trochoidal Milling, see Cycle Programming User's Manual
- New machining Cycle 233 Face Milling, see Cycle Programming User's Manual
- In drilling Cycles 200, 203 and 205, the parameter Q395 DEPTH REFERENCE has been introduced in order to evaluate the T ANGLE, see Cycle Programming User's Manual
- Probing Cycle 4 MEASURING IN 3-D has been introduced, see Cycle Programming User's Manual

### Modified functions 34059x-04

- The column NAME has been added to the turning tool table, see "Tool data", page 559
- Up to 4 M functions are now allowed in an NC block, see "Fundamentals", page 406
- New soft keys for transferring values have been introduced in the pocket calculator, see "Operation", page 179
- The distance-to-go display can now also be displayed in the input system, see "Select the position display", page 706
- Several input parameters have been added to Cycle 241 SINGLE-LIP DEEP HOLE DRILLING, see Cycle Programming User's Manual
- Parameter Q305 NUMBER IN TABLE has been added to Cycle 404, see Cycle Programming User's Manual
- In the thread milling Cycles 26x, an approaching feed rate has been introduced, see Cycle Programming User's Manual
- In Cycle 205 Universal Deep Hole Drilling you can now use parameter Q208 to define a feed rate for retraction, see Cycle Programming User's Manual

#### New functions 34059x-05

- The column PITCH has been added to the tool management, see "Enter tool data into the table", page 206
- The columns YL and DYI have been added to the turning tool table, see "Tool data", page 559
- In the tool management, several lines can now be added at the end of the table, see "Editing tool management", page 233
- Any turning tool table can be selected for the program test, see "Test run", page 673
- Programs with .HU and .HC extensions can be selected and processed in all operating modes
- The functions **SELECT PROGRAM** and **CALL SELECTED PROGRAM** have been introduced, see "Calling any program as a subprogram", page 321
- New **FEED DWELL** function for programming repeating dwell times, see "Dwell time FUNCTION FEED", page 479
- The FN18 functions have been expanded, see "FN 18: SYSREAD – Reading system data", page 356
- The DCM function can be activated and deactivated from the NC program, see "Activating and deactivating collision monitoring", page 436
- USB data carriers can be locked with the SELinux security software, see "SELinux security software", page 105
- The machine parameter **posAfterContPocket** (no. 201007) that influences positioning after an SL cycle has been introduced, see "Machine-specific user parameters", page 730
- Protective zones can be defined in the MOD menu, see "Entering traverse limits", page 703
- Write protection is possible for single lines in the preset table, see "Saving the datums in the preset table", page 600
- New manual probing function for aligning a plane, see "Measuring 3-D basic rotation", page 627
- New function for aligning the machining plane without rotary axes, see "Tilt the working plane without rotary axes", page 508
- CAD files can be opened without option number 42, see "CAD viewer", page 295
- New software option number 96 Advanced Spindle Interpolation, see "Software options", page 8
- New software option number 131 Spindle Synchronism, see "Software options", page 8

### Modified functions 34059x-05

- FZ and FU feed rate input possible in the Tool Call block, see "Call tool data", page 220
- With tool selection the control displays the XL and ZL columns from the turning tool table in the pop-up window, see "Tool call", page 557
- The input range of the DOC column in the pocket table has been expanded to 32 characters, see "Pocket table for tool changer", page 217
- Commands FN 15, FN 31, FN 32, FT and FMAXT from predecessor controls no longer generate ERROR blocks during import. When simulating or running an NC program with these commands, the control interrupts the NC program with an error message that helps you to find an alternative implementation
- Miscellaneous functions M104, M105, M112, M114, M124, M134, M142, M150, M200 - M204 from predecessor controls no longer generate ERROR blocks during import. When simulating or running an NC program with these miscellaneous functions, the control interrupts the NC program with an error message that helps you to find an alternative implementation, see "Comparison: Miscellaneous functions", page 773
- The maximum file size of files output with FN 16: F-PRINT has been increased from 4 KB to 20 KB
- The Preset.PR preset table is write-protected in Programming operating mode, see "Saving the datums in the preset table", page 600
- The input range of the Q parameter list for defining the QPARA tab on the status display consists of 132 input positions, see "Displaying Q parameters (QPARA tab)", page 97
- Manual calibration of the touch probe with fewer pre-positioning movements, see "Calibrating 3-D touch probes", page 617
- The position display takes into account the DL oversizes programmed in the Tool Call block, selectable as an oversize of the workpiece or tool, see "Delta values for lengths and radii", page 205
- In single block mode the control executes each point individually with point pattern cycles and CYCL CALL PAT, see "Program run", page 678
- Rebooting the control is no longer possible with the **END** key but with the **RESTART** soft key, see "Switch-off", page 580
- The control displays the contouring feed rate in manual mode, see "Spindle speed S, feed rate F and miscellaneous function M", page 593
- Deactivate tilting in manual mode is only possible via the 3D-ROT menu, see "Activating manual tilting:", page 641
- Machine parameter **maxLineGeoSearch** (no. 105408) has been increased to max. 100000, see "Machine-specific user parameters", page 730
- The names of software options number 8, 9 and 21 have changed, see "Software options", page 8



#### New and modified cycle functions 34059x-05

- New cycle **880 GEAR HOBBING** (option 50, option 131)
- New cycle **292 CONTOUR.TURNG.INTRP.** (option 96)
- New cycle **291 COUPLG.TURNG.INTERP.** (option 96)
- New cycle **239 ASCERTAIN THE LOAD** for LAC (Load Adapt. Control) load-dependent adaptation of control parameters (option 143)
- Cycle **270 CONTOUR TRAIN DATA** has been added
- Cycle **39 CYL. SURFACE CONTOUR** has been added (option 1)
- The character set of Machining Cycle **225 ENGRAVING** has been expanded with the CE character, ß, the @ character and system time
- Cycles **252-254** have been expanded with the optional parameter Q439
- Cycle **22 ROUGH-OUT** has been expanded by the optional parameters Q401, Q404
- Cycle **484 CALIBRATE IR TT** has been expanded by the optional parameter Q536
- Cycles **841 SIMPLE REC. TURNG., RADIAL DIR., 842 ENH.REC.TURNNG, RAD., 851 SIMPLE REC TURNG, AX, 852 ENH.REC.TURNING, AX.** have been expanded by plunge feed rate Q488
- Eccentric turning with Cycle **800 ADJUST XZ SYSTEM** is possible with option 50

**Further information:** Cycle Programing User's Manual

### New functions 34059x-06

- Manual probe functions create a completely new line in the preset table, see "Writing measured values from the touch probe cycles to the preset table", page 616
- Manual probe functions can write in a password-protected line, see "Recording measured values from the touch probe cycles", page 614
- The column **AFC-LOAD** was added to the tool table. In this column you can set a tool-dependent standard reference power for the adaptive feed control AFC, which you establish once with a teach-in cut, see "Enter tool data into the table", page 206
- The column **KINEMATIC** has been added to the tool table, see "Enter tool data into the table", page 206
- When importing tool data the CSV file may contain additional table columns not recognized by the control. During import a message is displayed indicating the unrecognized columns and informing that these values will not be adopted, see "Import and export tool data", page 238
- New function **FUNCTION S-PULSE** for programming pulsing shaft speeds, see "Pulsing spindle speed FUNCTION S-PULSE", page 477
- It is possible to search quickly for a file in file management by entering the first letter, see "Selecting drives, directories and files", page 151
- With active structuring the structure block can be edited in the structure window, see "Definition and applications", page 177
- The FN18 functions have been expanded, see "FN 18: SYSREAD – Reading system data", page 356
- The control differentiates between interrupted or stopped NC programs. In the interrupted status, the control offers more intervention options, see "Interrupt, stop or abort machining", page 679
- The machine manufacturer can also configure the turning spindle (option number 50) as an optional axis on the handwheel, see "Selecting the axis to be moved", page 588
- Animated help can be selected with the tilt working plane function, see "Overview", page 486
- The software option number 42 DXF Converter now also produces CR circles, see "Basic settings", page 298
- New software option 136 Visual Setup Control (camera-based monitoring of the setup situation), see "Software options", page 8, see "Camera-based monitoring of the setup situation VSC (option number 136)", page 645.

#### Modified functions 34059x-06

- When editing the tool table or tool management, only the current table line is blocked, see "Editing the tool table", page 211
- When importing tool tables, nonexistent tool types are imported as type undefined, see "Importing tool tables", page 214
- You cannot delete the tool data of tools still stored in the pocket table, see "Editing the tool table", page 211
- In all manual probing functions, quicker selection of the start angle of holes and studs is possible with soft keys (paraxial probing directions), see "Functions in touch probe cycles", page 611
- When probing, after acceptance of the actual value of the 1st point for the 2nd point the soft key for the axis direction is shown
- In all manual probing functions, the direction of the reference axis is suggested as a default
- In manual probing cycles the hard keys **END** and **ADOPT ACTUAL POSITION** may be used
- The display of the machining feed rate has been changed in manual mode, see "Spindle speed S, feed rate F and miscellaneous function M", page 593
- In the file management, the programs or directories at the cursor position are also displayed in a separate field beneath the current path display
- Block editing no longer causes block marking to be canceled. If a block is edited with active block marking and another block is then selected via the syntax search, the marking is expanded to the newly selected block, see "Marking, copying, cutting and inserting program sections", page 143
- In the screen layout **PROGRAM + SECTS** it is possible to edit the structure in the structure window, "Definition and applications"
- The functions **APPR CT** and **DEP CT** allow approach to and departure from a helix. This movement is carried out as a helix with an even pitch, see "Overview: Types of paths for contour approach and departure", page 250
- The functions **APPR LT**, **APPR LCT**, **DEP LT** and **DEP LCT** position all three axes at on the auxiliary point at the same time, see "Approaching on a straight line with tangential connection: APPR LT", page 253, see "Approaching on a circular path with tangential connection from a straight line to the contour: APPR LCT", page 255
- The values entered for the traverse limits are checked for validity, see "Entering traverse limits", page 703
- When calculating the axis angle in the axes chosen with M138, the control sets the value to 0, see "Selecting tilting axes: M138", page 517
- The input range in columns SPA, SPB and SPC in the preset table has been expanded to 999,9999, see "Datum management with the preset table", page 599
- Tilting is permitted in combination with mirroring, see "The PLANE function: Tilting the working plane (software option 8)", page 485

- Even when the 3D-ROT dialog is active in Manual Operation mode, **PLANE RESET** still functions with active basic transformation, see "Activating manual tilting:", page 641
- The feed rate potentiometer only reduces the programmed feed rate and no longer the feed rate calculated by the control, see "Feed rate F", page 202
- The DXF converter displays **FUNCTION MODE TURN** or **FUNCTION MODE MILL** as a comment

### New and modified cycle functions 34059x-06

- New cycle 258 POLYGON STUD
- New cycles 600 and 601, touch probe cycles for monitoring with a camera (option 136)
- Cycle 291 INTERPOLATION TURNING, COUPLING (option 96) has been expanded by parameter Q561
- Cycles 421, 422 and 427 have been expanded to include parameters Q498 and Q531
- For cycle 247: SET DATUM, the datum number from the preset table can be selected with the corresponding parameter
- With cycle 200 and 203 the behavior of the dwell time at top has been adapted
- Cycle 205 performs deburring on the coordinate surface
- With SL cycles, M110 is now taken into account with circles compensated inwards if it is active during machining

**Further information:** Cycle Programming User's Manual

#### New functions 34059x-07

- New function **FUNCTION DWELL** for programming a dwell time, see "Dwell time FUNCTION DWELL", page 481
- New software option 3D-ToolComp (option 92), see "3-D radius compensation depending on the tool's contact angle (option 92)", page 531
- New column **DR2TABLE** in the tool table with selection dialog for the 3D-ToolComp tables, see "Enter tool data into the table", page 206
- The column **OVRTIME** has been added to the tool table, see "Enter tool data into the table", page 206
- New columns **AFC-OVLD1** and **AFC-OVLD2** in the tool table for tool wear monitoring and tool load monitoring, see "Tool wear monitoring", page 454, see "Tool load monitoring", page 454
- The measured compensation values **DXL** and **DZL** of a turning tool can be manually compensated in the tool management (option 93), see "Calculate the tool compensation", page 561
- An oversize for the recessing tool width can be defined via **FUNCTION TURNDATA CORR-TCS:Z/X DCW** or with an entry in the new column **DCW** of the turning tool table, see "Tools in turning mode (option 50)", page 557
- The tool length stored in the turning tool table column **ZL** is saved by the control in the Q parameter Q114, see "Tool data", page 559
- New function, 3-D calibrating of touch probe systems, see "3-D calibration with a calibration sphere (option 92)", page 623
- During a manual touch probe cycle, control can be transferred to the handwheel, see "Traverse movements with a handwheel with display", page 610
- Several handwheels can be connected to a control, see "Traverse with electronic handwheels", page 583
- In **Electronic handwheel** mode of operation, the handwheel axis for an HR 130 can be selected with the orange axis keys
- If the control is set to the INCH unit of measure, the control also includes movements traversed by the handwheel in INCHES, see "Traverse with electronic handwheels", page 583
- The FN18 functions have been expanded, see "FN 18: SYSREAD – Reading system data", page 356
- The FN16 functions have been expanded, see "FN16: F-PRINT – Formatted output of text and Q parameter values", page 351
- The file saved with **SAVE AS** is now also found in the file management under **LAST FILES**, see "Editing a program", page 140
- If you save files with **SAVE AS**, you can select the target directory with the **SWITCH** soft key, see "Editing a program", page 140
- File management displays vertical scrollbars and supports scrolling with the mouse, see "Calling the file manager", page 150
- The functions in the software option VSC (option 136) have been expanded and adapted for improved operation, see



"Camera-based monitoring of the setup situation VSC (option number136)", page 645

- New machine parameter for recreating **M7** and **M8**, see "Machine-specific user parameters", page 730
- New machine parameter for defining the minimum feed rate in turning cycles, see "Machine-specific user parameters", page 730
- New machine parameter for deactivating parallel axis programming, see "Working with the parallel axes U, V and W", page 457
- The function **STRLEN** checks whether a string parameter has been defined, see "Finding the length of a string parameter", page 389
- The function **SYSSTR** enables the NC software version to be read out, see "Reading system data", page 386
- The function **FN 38: SEND** can now be programmed without a code number
- Undefined Q parameters can now be transferred with the function **FN 0**
- For jumps with **FN 9**, QS parameters and texts are permitted as conditions, see "Programming if-then decisions", page 343
- Cylindrical workpiece blanks can now also be defined with a diameter instead of a radius, see "Define the blank: BLK FORM", page 133
- Programming of **TCPM AXIS SPAT** is possible with active Cycle 8 and Cycle 10
- It is now possible to program up to 6 axes in a straight line block, see "Three-dimensional movement", page 245
- The transitional elements **RND** and **CHF** can now also be executed between 3-D contours, i.e. with straight line blocks with three programmed coordinates or a helix
- The control now supports spatial arcs, i.e. circles in 3 axes vertical to the working plane, see "Circular path C around circle center CC", page 263
- Active kinematics is displayed in the 3D-ROT menu, see "Activating manual tilting:", page 641
- In operating modes **Program run, single block** and **Program run, full sequence** the screen layout **PROGRAM + SECTS** can be specified, see "Structuring programs", page 177
- In operating modes **Program run full sequence**, **Program run single block** and **Positioning with manl.data input**, the font size can be set to the same size as the **Programming** operating mode, see "Machine-specific user parameters", page 730
- The functions in the **Positioning with manl.data input** mode were expanded and adapted for improved operation, see "Positioning with Manual Data Input", page 653
- Active kinematics is displayed in the operating mode **RETRACT**, see "Retraction after a power interruption", page 684
- In **RETRACT** operating mode, feed-rate limitation can be deactivated with the soft key **CANCEL THE FEED RATE LIMITATION**, see "Retraction after a power interruption", page 684

### TNC model, software and features

- In **Test run** operating mode a tool usage file can also be created without simulation, see "Tool usage test", page 225
- In **Test run** operating mode the soft key **FMAX PATHS** hides the rapid traverse movements, see "3-D view in the Test Run operating mode", page 665
- In **Test run** operating mode the soft key **RESET THE VOLUME MODEL** resets the solid model, see "3-D view in the Test Run operating mode", page 665
- In **Test run** operating mode the soft key **RESET TOOL PATHS** resets the tool paths, see "3-D view in the Test Run operating mode", page 665
- In **Test run** operating mode the soft key **MEASURING** displays the coordinates if you position the mouse on the graphics, see "3-D view in the Test Run operating mode", page 665
- In **Test run** operating mode the soft key **STOP AT** simulates up to a predefined block, see "Test run up to a certain block ", page 677
- Active basic transformation is shown in the status display on the **POS** tab, see "Positions and coordinates (POS tab)", page 95
- The status display now also shows the path of the active main program, see "Overview", page 93, see "General program information (PGM tab)", page 93
- In the status display the **CYC** tab now also shows **T-Max** and **TA-Max**
- Mid-program startup can now be continued, see "Any entry into program: Mid-program startup", page 687
- With functions **NC/PLC Backup** and **NC/PLC Restore** you can save and restore single directories or the complete TNC drive, see "Backup and restore", page 108

### Modified functions 34059x-07

- Tool names can now also include the special characters % and ,, see "Tool number, tool name", page 204
- When importing tool tables the numerical values are adopted from the **R-OFFS** column, see "Importing tool tables", page 214
- In the **LIFTOFF** column of the tool table the default is now **N**, see "Enter tool data into the table", page 206
- The **L** and **R** columns of the tool table are empty when a new tool is created, see "Editing the tool table", page 211
- In the tool table for the **RT** and **KINEMATIC** columns, the **SELECT** soft key is now available, see "Enter tool data into the table", page 206
- The touch probe function Corner as preset has been expanded, see "Corner as datum ", page 630
- The arrangement of soft keys in the manual probing cycle **PROBING P** has been adapted, see "Corner as datum ", page 630
- The **FMAX** soft key in Program Run not only limits the machining feed rate during execution of the program but also the axis feed rate for manual axis movements, see "Feed rate limit F MAX", page 594
- Soft key allocations were adapted for incremental positioning
- When the preset table is opened the cursor is on the line of the active preset
- New help graphics with **PLANE RESET**, see "Specifying the positioning behavior of the PLANE function", page 501
- The behavior of **COORD ROT** and **TABLE ROT** in the 3D-ROT menu has been modified, see "Specifying the positioning behavior of the PLANE function", page 501
- The current structure block can be more clearly recognized in the structure window, see "Definition and applications", page 177
- DHCP Lease Time is now also valid following power interruption. When HeROS is shut down, the DHCP server is no longer informed that the IP address is vacant again, see "Configuring the TNC", page 715
- In the status display the fields for the LBL names have been expanded to 32 characters
- The **TT** status display now also shows values if the user changes to the **TT** tab later
- Status displays can now also be switched over with the **NEXT TAB** key, see "Additional status displays", page 92
- An active pallet table during program run can only be edited via the **EDIT PALLET** soft key, see "Processing pallet table", page 542
- If a subprogram called with **CALL PGM** ends with **M2** or **M30** the control outputs a warning
- **M124** no longer triggers an error message but only a warning. This enables NC programs with programmed **M124** to run through without interruption

### TNC model, software and features

- Upper and lower cases for a file name can be modified in the file management
- If a larger file is transferred to a USB device in the file management, the control displays a warning until file transfer is completed, see "USB devices on the TNC", page 171
- In the file management, the control also shows the momentary type filter with the path
- In the file management the **SHOW ALL** soft key is now displayed in all operating modes
- In the file management the function **SELECT DIRECTORY** was modified for copying files or directories. The soft keys **OK** and **CANCEL** are available on the first two positions
- The colors of the programming graphics were changed, see "Programming graphics", page 185
- In **Test run** and **Programming** operating modes the tool data is reset if a program is reselected or restarted with the **RESET + START** soft key
- In **Test run** operating mode the control displays the datum of the machine tool table as the reference point with **BLANK IN WORK SPACE**, see "Show the workpiece blank in the working space ", page 671
- The machine tool builder can configure the interaction of **M140** and **DCM** for each collision object, see "Collision monitoring in the Program Run operating modes", page 435
- The soft key of the turning tool table has changed, see "Tool data", page 559
- With the **FUNCTION MODE** function the soft key **SELECT KINEMATICS** has changed, see "Switching between milling/turning mode of operation", page 547
- If a limit is defined with **FUNCTION TURNDATA SPIN SMAX** and spindle speed limiting is effective, the display shows **SMAX** instead of **S**, see "Program spindle speed", page 550
- After modification of the active datum, resuming the program is only possible after **GOTO** or mid-program startup, see "Moving the machine axes during an interruption", page 682
- With mid-program startup an FK sequence can be entered, see "Any entry into program: Mid-program startup", page 687
- Mid-program startup operation and dialog guidance has been improved, also for pallet tables, see "Any entry into program: Mid-program startup", page 687

### New and modified cycle functions 34059x-07

- With Cycle 251 Rectangular pocket, **M110** is now taken into account with circles compensated inwards if it is active during machining
- New cycle 444 for 3-D probing of any coordinate (software option 17)
- Cycle 451 has been expanded with parameter Q406. With activated option #52 KinematicsComp this enables the measured angular position errors of the rotary axes to be compensated (software option 52)
- Cycle 460 has been expanded with parameter Q455. With activated option #92 3D-ToolComp this enables 3-D calibration data to be determined, saved and then used to compensate for any deviations. (Software option 92)
- In the protocol of the KinematicsOpt cycles 451 and 452 the position of the measured rotary axes can be output before and after optimization. (Software option 52)
- Cycle 225 has been expanded with parameters Q516, Q367 and Q574. This enables a datum for the specific text position to be defined or the text length and character height to be scaled
- Cycle 861 has been expanded with parameters Q510, Q511, Q462. This enables an overlap, feed rate factor and selectable retraction behavior to be programmed
- Cycle 862 has been expanded with parameters Q510, Q511, Q462. This enables an overlap, feed rate factor and selectable retraction behavior to be programmed
- Cycle 871 has been expanded with parameters Q510, Q511, Q462. This enables an overlap, feed rate factor and selectable retraction behavior to be programmed
- Cycle 872 has been expanded with parameters Q510, Q511, Q462. This enables an overlap, feed rate factor and selectable retraction behavior to be programmed
- Cycle 860 has been expanded with parameters Q510, Q511, Q462. This enables an overlap, feed rate factor and selectable retraction behavior to be programmed
- Cycle 870 has been expanded with parameters Q510, Q511, Q462. This enables an overlap, feed rate factor and selectable retraction behavior to be programmed
- In Cycle 810 the parameter Q499 was expanded with the input option "2". This adapts the tool position if the contour is executed inversely to the programmed direction
- In cycles 481 to 483 the parameter Q340 was expanded with the input option "2". This enables a tool control without making any change in the tool table
- Cycle 251 has been expanded by parameter Q439. The finishing strategy was also revised
- The finishing strategy was revised with cycle 252
- Cycle 275 has been expanded with parameters Q369 and Q439

**Further information:** Cycle Programming User's Manual



## Contents

1	First Steps with the TNC 640.....	63
2	Introduction.....	83
3	Fundamentals, file management.....	117
4	Programming aids.....	173
5	Tools.....	201
6	Programming contours.....	241
7	Data transfer from CAD files.....	293
8	Subprograms and program section repeats.....	313
9	Programming Q parameters.....	331
10	Miscellaneous functions.....	405
11	Special functions.....	427
12	Multiple axismachining.....	483
13	Pallet management.....	539
14	Turning.....	545
15	Manual Operation and Setup.....	577
16	Positioning with Manual Data Input.....	653
17	Test Run and Program Run.....	659
18	MOD Functions.....	697
19	Tables and Overviews.....	729





<b>1</b>	<b>First Steps with the TNC 640.....</b>	<b>63</b>
<b>1.1</b>	<b>Overview.....</b>	<b>64</b>
<b>1.2</b>	<b>Machine switch-on.....</b>	<b>64</b>
	Acknowledging the power interruption and moving to the reference points.....	64
<b>1.3</b>	<b>Programming the first part.....</b>	<b>65</b>
	Selecting the correct operating mode.....	65
	The most important TNC keys.....	65
	Opening a new program/file management.....	66
	Defining a workpiece blank.....	67
	Program layout.....	68
	Programming a simple contour.....	69
	Creating a cycle program.....	72
<b>1.4</b>	<b>Graphically testing the first part.....</b>	<b>74</b>
	Selecting the correct operating mode.....	74
	Selecting the tool table for the test run.....	74
	Choosing the program you want to test.....	75
	Selecting the screen layout and the view.....	75
	Starting the test run.....	76
<b>1.5</b>	<b>Setting up tools.....</b>	<b>77</b>
	Selecting the correct operating mode.....	77
	Preparing and measuring tools.....	77
	The tool table TOOL.T.....	78
	The pocket table TOOL_PTCH.....	79
<b>1.6</b>	<b>Workpiece setup.....</b>	<b>80</b>
	Selecting the correct operating mode.....	80
	Clamping the workpiece.....	80
	Datum setting with a 3-D touch probe.....	81
<b>1.7</b>	<b>Running the first program.....</b>	<b>82</b>
	Selecting the correct operating mode.....	82
	Choosing the program you want to run.....	82
	Start the program.....	82

<b>2</b>	<b>Introduction.....</b>	<b>83</b>
<b>2.1</b>	<b>The TNC 640.....</b>	<b>84</b>
	HEIDENHAIN Klartext and DIN/ISO.....	84
	Compatibility.....	84
<b>2.2</b>	<b>Visual display unit and operating panel.....</b>	<b>85</b>
	Display screen.....	85
	Set screen layout.....	85
	Control panel.....	86
<b>2.3</b>	<b>Modes of operation.....</b>	<b>87</b>
	Manual Operation and El. Handwheel.....	87
	Positioning with Manual Data Input.....	87
	Programming.....	88
	Test Run.....	88
	Program Run, Full Sequence and Program Run, Single Block.....	89
<b>2.4</b>	<b>Status displays.....</b>	<b>90</b>
	General status display.....	90
	Additional status displays.....	92
<b>2.5</b>	<b>Window manager.....</b>	<b>99</b>
	Overview of the task bar.....	100
	Portscan.....	102
	Remote Service.....	103
	SELinux security software.....	105
	VNC.....	106
	Backup and restore.....	108
<b>2.6</b>	<b>Remote Desktop Manager (option 133).....</b>	<b>110</b>
	Introduction.....	110
	Configuring connections – Windows Terminal Service.....	111
	Configuring the connection – VNC.....	113
	Starting and stopping the connection.....	114
<b>2.7</b>	<b>Accessories: HEIDENHAIN 3-D touch probes and electronic handwheels.....</b>	<b>115</b>
	3-D touch probes.....	115
	HR electronic handwheels.....	116

<b>3</b>	<b>Fundamentals, file management.....</b>	<b>117</b>
<b>3.1</b>	<b>Fundamentals.....</b>	<b>118</b>
	Position encoders and reference marks.....	118
	reference systems.....	119
	Designation of the axes on milling machines.....	129
	Polar coordinates.....	129
	Absolute and incremental workpiece positions.....	130
	Selecting the datum.....	131
<b>3.2</b>	<b>Opening programs and entering.....</b>	<b>132</b>
	Structure of an NC program in HEIDENHAIN Klartext.....	132
	Define the blank: BLK FORM.....	133
	Opening a new part program.....	136
	Programming tool movements in Klartext.....	137
	Actual position capture.....	139
	Editing a program.....	140
	The TNC search function.....	144
<b>3.3</b>	<b>File management: Basics.....</b>	<b>145</b>
	Files.....	145
	Displaying externally generated files on the TNC.....	147
	Data Backup.....	147

<b>3.4 Working with the file manager.....</b>	<b>148</b>
Directories.....	148
Paths.....	148
Overview: Functions of the file manager.....	149
Calling the file manager.....	150
Selecting drives, directories and files.....	151
Creating a new directory.....	153
Create new file.....	153
Copying a single file.....	153
Copying files into another directory.....	154
Copying a table.....	155
Copying a directory.....	156
Choose one of the last files selected.....	156
Deleting a file.....	157
Deleting a directory.....	157
Tag files.....	158
Renaming a file.....	158
Sort files.....	159
Additional functions.....	159
Additional tools for management of external file types.....	160
Additional tools for ITCs.....	167
Data transfer to or from an external data carrier.....	169
The TNC in a network.....	170
USB devices on the TNC.....	171

<b>4</b>	<b>Programming aids.....</b>	<b>173</b>
<b>4.1</b>	<b>Adding comments.....</b>	<b>174</b>
	Application.....	174
	Entering comments during programming.....	174
	Inserting comments after program entry.....	174
	Entering a comment in a separate block.....	174
	Functions for editing of the comment.....	175
<b>4.2</b>	<b>Display of NC programs.....</b>	<b>176</b>
	Syntax highlighting.....	176
	Scrollbar.....	176
<b>4.3</b>	<b>Structuring programs.....</b>	<b>177</b>
	Definition and applications.....	177
	Displaying the program structure window / Changing the active window.....	177
	Inserting a structure block in the program window.....	178
	Selecting blocks in the program structure window.....	178
<b>4.4</b>	<b>Calculator.....</b>	<b>179</b>
	Operation.....	179
<b>4.5</b>	<b>Cutting data calculator.....</b>	<b>182</b>
	Application.....	182
<b>4.6</b>	<b>Programming graphics.....</b>	<b>185</b>
	Generate/do not generate graphics during programming.....	185
	Generating a graphic for an existing program.....	186
	Block number display ON/OFF.....	187
	Erasing the graphic.....	187
	Showing grid lines.....	187
	Magnification or reduction of details.....	188

## **4.7 Error messages..... 189**

Display of errors.....	189
Open the error window.....	189
Closing the error window.....	189
Detailed error messages.....	190
Soft key: INTERNAL INFO.....	190
Soft key FILTER.....	190
Clearing errors.....	191
Error log.....	191
Keystroke log.....	192
Informational texts.....	193
Save service files.....	193
Calling the TNCguide help system.....	193

## **4.8 TNCguide context-sensitive help system..... 194**

Application.....	194
Working with TNCguide.....	195
Downloading current help files.....	198

<b>5 Tools.....</b>	<b>201</b>
<b>5.1 Entering tool-related data.....</b>	<b>202</b>
Feed rate F.....	202
Spindle speed S.....	203
<b>5.2 Tool data.....</b>	<b>204</b>
Requirements for tool compensation.....	204
Tool number, tool name.....	204
Tool length L.....	204
Tool radius R.....	204
Delta values for lengths and radii.....	205
Entering tool data into the program.....	205
Enter tool data into the table.....	206
Importing tool tables.....	214
Overwriting tool data from an external PC.....	216
Pocket table for tool changer.....	217
Call tool data.....	220
Tool change.....	222
Tool usage test.....	225
<b>5.3 Tool compensation.....</b>	<b>227</b>
Introduction.....	227
Tool length compensation.....	227
Tool radius compensation.....	228
<b>5.4 Tool management (option number 93).....</b>	<b>231</b>
Basics.....	231
Calling tool management.....	232
Editing tool management.....	233
Available tool types.....	236
Import and export tool data.....	238

<b>6</b>	<b>Programming contours.....</b>	<b>241</b>
<b>6.1</b>	<b>Tool movements.....</b>	<b>242</b>
	Path functions.....	242
	FK free contour programming.....	242
	Miscellaneous functions M.....	242
	Subprograms and program section repeats.....	243
	Programming with Q parameters.....	243
<b>6.2</b>	<b>Fundamentals of path functions.....</b>	<b>244</b>
	Programming tool movements for workpiece machining.....	244
<b>6.3</b>	<b>Approaching and departing a contour.....</b>	<b>248</b>
	"From" and "To" points.....	248
	Overview: Types of paths for contour approach and departure.....	250
	Important positions for approach and departure.....	251
	Approaching on a straight line with tangential connection: APPR LT.....	253
	Approaching on a straight line perpendicular to the first contour point: APPR LN.....	253
	Approaching on a circular path with tangential connection: APPR CT.....	254
	Approaching on a circular path with tangential connection from a straight line to the contour: APPR LCT.....	255
	Departing in a straight line with tangential connection: DEP LT.....	256
	Departing in a straight line perpendicular to the last contour point: DEP LN.....	256
	Departing on a circular path with tangential connection: DEP CT.....	257
	Departing on a circular arc tangentially connecting the contour and a straight line: DEP LCT.....	257
<b>6.4</b>	<b>Path contours — Cartesian coordinates.....</b>	<b>258</b>
	Overview of path functions.....	258
	Straight line L.....	259
	Inserting a chamfer between two straight lines.....	260
	Rounded corners RND.....	261
	Circle center CC.....	262
	Circular path C around circle center CC.....	263
	CircleCR with defined radius.....	264
	Circle CT with tangential connection.....	266
	Example: Linear movements and chamfers with Cartesian coordinates.....	267
	Example: Circular movements with Cartesian coordinates.....	268
	Example: Full circle with Cartesian coordinates.....	269



## **6.5 Path contours – Polar coordinates..... 270**

Overview.....	270
Zero point for polar coordinates: pole CC.....	271
Straight line LP.....	271
Circular path CP around pole CC.....	272
Circle CTP with tangential connection.....	272
Helix.....	273
Example: Linear movement with polar coordinates.....	275
Example: Helix.....	276

## **6.6 Path contours – FK free contour programming..... 277**

Fundamentals.....	277
FK programming graphics.....	279
Initiating the FK dialog.....	280
Pole for FK programming.....	280
Free straight line programming.....	281
Free circular path programming.....	282
Input possibilities.....	283
Auxiliary points.....	286
Relative data.....	287
Example: FK programming 1.....	289
Example: FK programming 2.....	290
Example: FK programming 3.....	291

<b>7</b>	<b>Data transfer from CAD files.....</b>	<b>293</b>
<b>7.1</b>	<b>CAD viewer and DXF converter screen layout.....</b>	<b>294</b>
	Fundamentals of the CAD viewer and DXF converter.....	294
<b>7.2</b>	<b>CAD viewer.....</b>	<b>295</b>
	Application.....	295
<b>7.3</b>	<b>DXF converter (option 42).....</b>	<b>296</b>
	Application.....	296
	Working with the DXF converter.....	297
	Opening a DXF file.....	297
	Basic settings.....	298
	Setting layers.....	300
	Setting a datum.....	301
	Selecting and saving a contour.....	303
	Selecting and saving machining positions.....	307

<b>8</b>	<b>Subprograms and program section repeats.....</b>	<b>313</b>
<b>8.1</b>	<b>Labeling subprograms and program section repeats.....</b>	<b>314</b>
	Label.....	314
<b>8.2</b>	<b>Subprograms.....</b>	<b>315</b>
	Operating sequence.....	315
	Programming notes.....	315
	Program the subprogram.....	316
	Calling a subprogram.....	316
<b>8.3</b>	<b>Program-section repeats.....</b>	<b>317</b>
	Label.....	317
	Operating sequence.....	317
	Programming notes.....	317
	Programming a program section repeat.....	318
	Calling a program section repeat.....	318
<b>8.4</b>	<b>Any desired program as subprogram.....</b>	<b>319</b>
	Overview of the soft keys.....	319
	Operating sequence.....	320
	Programming notes.....	320
	Calling any program as a subprogram.....	321
<b>8.5</b>	<b>Nesting.....</b>	<b>323</b>
	Types of nesting.....	323
	Nesting depth.....	323
	Subprogram within a subprogram.....	324
	Repeating program section repeats.....	325
	Repeating a subprogram.....	326
<b>8.6</b>	<b>Programming examples.....</b>	<b>327</b>
	Example: Milling a contour in several infeeds.....	327
	Example: Groups of holes.....	328
	Example: Group of holes with several tools.....	329

<b>9</b>	<b>Programming Q parameters.....</b>	<b>331</b>
<b>9.1</b>	<b>Principle and overview of functions.....</b>	<b>332</b>
	Programming notes.....	334
	Calling Q parameter functions.....	335
<b>9.2</b>	<b>Part families—Q parameters in place of numerical values.....</b>	<b>336</b>
	Application.....	336
<b>9.3</b>	<b>Describing contours with mathematical functions.....</b>	<b>337</b>
	Application.....	337
	Overview.....	337
	Programming fundamental operations.....	338
<b>9.4</b>	<b>Angle functions.....</b>	<b>340</b>
	Definitions.....	340
	Programming trigonometric functions.....	340
<b>9.5</b>	<b>Calculation of circles.....</b>	<b>341</b>
	Application.....	341
<b>9.6</b>	<b>If-then decisions with Q parameters.....</b>	<b>342</b>
	Application.....	342
	Unconditional jumps.....	342
	Abbreviations used:.....	342
	Programming if-then decisions.....	343
<b>9.7</b>	<b>Checking and changing Q parameters.....</b>	<b>344</b>
	Procedure.....	344
<b>9.8</b>	<b>Additional functions.....</b>	<b>346</b>
	Overview.....	346
	FN 14: ERROR: Displaying error messages.....	347
	FN16: F-PRINT – Formatted output of text and Q parameter values.....	351
	FN 18: SYSREAD – Reading system data.....	356
	FN 19: PLC – Transfer values to the PLC.....	365
	FN 20: WAIT FOR – NC and PLC synchronization.....	365
	FN 29: PLC – Transfer values to the PLC.....	366
	FN 37: EXPORT.....	366
	FN 38: SEND – Send information from NC program.....	366

## **9.9 Accessing tables with SQL commands..... 367**

Introduction.....	367
A transaction.....	368
Programming SQL commands.....	370
Overview of the soft keys.....	371
SQL BIND.....	372
SQL SELECT.....	373
SQL FETCH.....	375
SQL UPDATE.....	376
SQL INSERT.....	376
SQL COMMIT.....	377
SQL ROLLBACK.....	377

## **9.10 Entering formulas directly..... 378**

Entering formulas.....	378
Rules for formulas.....	380
Example of entry.....	381

## **9.11 String parameters..... 382**

String processing functions.....	382
Assign string parameters.....	383
Chain-linking string parameters.....	383
Converting a numerical value to a string parameter.....	384
Copying a substring from a string parameter.....	385
Reading system data.....	386
Converting a string parameter to a numerical value.....	387
Testing a string parameter.....	388
Finding the length of a string parameter.....	389
Compare alphabetic priority.....	390
Reading out machine parameters.....	391

## 9.12 Preassigned Q parameters..... 394

Values from the PLC: Q100 to Q107.....	394
Active tool radius: Q108.....	394
Tool axis: Q109.....	394
Spindle status: Q110.....	395
Coolant on/off: Q111.....	395
Overlap factor: Q112.....	395
Unit of measurement for dimensions in the program: Q113.....	395
Tool length: Q114.....	395
Coordinates after probing during program run.....	396
Deviation between actual value and nominal value during automatic tool measurement with the TT 130.....	396
Tilting the working plane with mathematical angles: rotary axis coordinates calculated by the TNC.....	396
Measurement results from touch probe cycles.....	397
Checking the setup situation: Q601.....	398

## 9.13 Programming examples..... 399

Example: Ellipse.....	399
Example: Concave cylinder machined with spherical cutter.....	401
Example: Convex sphere machined with end mill.....	403

<b>10 Miscellaneous functions.....</b>	<b>405</b>
<b>10.1 Enter miscellaneous functions M and STOP.....</b>	<b>406</b>
Fundamentals.....	406
<b>10.2 Miscellaneous functions for program run inspection, spindle and coolant.....</b>	<b>408</b>
Overview.....	408
<b>10.3 Miscellaneous functions for coordinate entries.....</b>	<b>409</b>
Programming machine-referenced coordinates: M91/M92.....	409
Moving to positions in a non-tilted coordinate system with a tilted working plane: M130.....	411
<b>10.4 Miscellaneous functions for path behavior.....</b>	<b>412</b>
Machining small contour steps: M97.....	412
Machining open contour corners: M98.....	413
Feed rate factor for plunging movements: M103.....	414
Feed rate in millimeters per spindle revolution: M136.....	415
Feed rate for circular arcs: M109/M110/M111.....	416
Calculating the radius-compensated path in advance (LOOK AHEAD): M120.....	417
Superimpose handwheel positioning during program run: M118.....	419
Retraction from the contour in the tool-axis direction: M140.....	421
Suppressing touch probe monitoring: M141.....	423
Deleting basic rotation: M143.....	424
Automatically retract tool from the contour at an NC stop: M148.....	425
Rounding corners: M197.....	426

<b>11 Special functions.....</b>	<b>427</b>
<b>11.1 Overview of special functions.....</b>	<b>428</b>
Main menu for SPEC FCT special functions.....	428
Program defaults menu.....	429
Functions for contour and point machining menu.....	429
Menu of various conversational functions.....	430
<b>11.2 Dynamic Collision Monitoring (option 40).....</b>	<b>431</b>
Function.....	431
Graphic display of the collision objects.....	432
Collision monitoring in the manual operating modes.....	434
Collision monitoring in the Program Run operating modes.....	435
Activating and deactivating collision monitoring.....	436
<b>11.3 Tool carrier management.....</b>	<b>438</b>
Fundamentals.....	438
Save tool carrier templates.....	438
Assign input parameters to tool carriers.....	439
Allocate parameterized tool carriers.....	441
<b>11.4 Adaptive Feed Control AFC (option 45).....</b>	<b>442</b>
Application.....	442
Defining the AFC basic settings.....	444
Recording a teach-in cut.....	447
Activating/deactivating AFC.....	452
Log file.....	453
Tool wear monitoring.....	454
Tool load monitoring.....	454
<b>11.5 Active Chatter Control ACC (option 145).....</b>	<b>455</b>
Application.....	455
Activating/deactivating ACC.....	456



## **11.6 Working with the parallel axes U, V and W..... 457**

Overview.....	457
FUNCTION PARAXCOMP DISPLAY.....	458
FUNCTION PARAXCOMP MOVE.....	458
Deactivating FUNCTION PARAXCOMP.....	459
FUNCTION PARAXMODE.....	460
Deactivating FUNCTION PARAXMODE.....	461
Example: Drilling in the W axis.....	462

## **11.7 File functions..... 463**

Application.....	463
Defining file functions.....	463

## **11.8 Definition of a datum shift..... 464**

Overview.....	464
TRANS DATUM AXIS.....	464
TRANS DATUM TABLE.....	465
TRANS DATUM RESET.....	466

## **11.9 Creating text files..... 467**

Application.....	467
Opening and exiting a text file.....	467
Editing texts.....	468
Deleting and re-inserting characters, words and lines.....	468
Editing text blocks.....	469
Finding text sections.....	470

## **11.10 Freely definable tables..... 471**

Fundamentals.....	471
Creating a freely definable table.....	471
Editing the table format.....	472
Switching between table and form view.....	473
FN 26: TABOPEN – Open a freely definable table.....	474
FN 27: TABWRITE – Write to a freely definable table.....	475
FN 28: TABREAD – Read from a freely definable table.....	476
Customize table view.....	476

<b>11.11 Pulsing spindle speed FUNCTION S-PULSE.....</b>	<b>477</b>
Program pulsing spindle speed.....	477
Reset pulsing spindle speed.....	478
<b>11.12 Dwell time FUNCTION FEED.....</b>	<b>479</b>
Programming dwell time.....	479
Resetting dwell time.....	480
<b>11.13 Dwell time FUNCTION DWELL.....</b>	<b>481</b>
Programming dwell time.....	481

<b>12 Multiple axis machining.....</b>	<b>483</b>
<b>12.1 Functions for multiple axis machining.....</b>	<b>484</b>
<b>12.2 The PLANE function: Tilting the working plane (software option 8).....</b>	<b>485</b>
Introduction.....	485
Overview.....	486
Defining the PLANE function.....	487
Position display.....	487
Resetting PLANE function.....	488
Defining the working plane with the spatial angle: PLANE SPATIAL.....	489
Defining the working plane with the projection angle: PLANE PROJECTED.....	490
Defining the working plane with the Euler angle: PLANE EULER.....	492
Defining the working plane with two vectors: PLANE VECTOR.....	494
Defining the working plane via three points: PLANE POINTS.....	496
Defining the working plane via a single incremental spatial angle: PLANE RELATIV.....	498
Tilting the working plane through axis angle: PLANE AXIAL.....	499
Specifying the positioning behavior of the PLANE function.....	501
Tilt the working plane without rotary axes.....	508
<b>12.3 Inclined-tool machining in a tilted plane (option 9).....</b>	<b>509</b>
Function.....	509
Inclined-tool machining via incremental traverse of a rotary axis.....	509
Inclined-tool machining via normal vectors.....	510
<b>12.4 Miscellaneous functions for rotary axes.....</b>	<b>511</b>
Feed rate in mm/min on rotary axes A, B, C: M116 (option 8).....	511
Shortest-path traverse of rotary axes: M126.....	512
Reducing display of a rotary axis to a value less than 360°: M94.....	513
Maintaining the position of the tool tip when positioning with tilted axes (TCPM): M128 (option 9)....	514
Selecting tilting axes: M138.....	517
Compensating the machine kinematics in ACTUAL/NOMINAL positions at end of block: M144 (option 9).....	518

## **12.5 FUNCTION TCPM (option 9)..... 519**

Function.....	519
Defining the TCPM FUNCTION.....	519
Mode of action of the programmed feed rate.....	520
Interpretation of the programmed rotary axis coordinates.....	520
Type of interpolation between the starting and end position.....	521
Resetting the TCPM FUNCTION.....	522

## **12.6 Three-dimensional tool compensation (option 9)..... 523**

Introduction.....	523
Suppressing error messages with positive tool oversize: M107.....	524
Definition of a normalized vector.....	525
Permissible tool shapes.....	526
Using other tools: Delta values.....	526
3-D compensation without TCPM.....	527
Face milling: 3-D compensation with TCPM.....	528
Peripheral milling: 3-D radius compensation with TCPM and radius compensation (RL/RR).....	529
3-D radius compensation depending on the tool's contact angle (option 92).....	531

## **12.7 Running CAM programs..... 533**

From 3-D model to NC program.....	533
Consider with processor configuration.....	534
Please note the following for CAM programming.....	536
Possibilities for intervention on the control.....	538
ADP motion control.....	538

**13 Pallet management..... 539**

**13.1 Pallet management..... 540**

Application.....	540
Selecting pallet table.....	542
Exit pallet table.....	542
Processing pallet table.....	542

<b>14 Turning.....</b>	<b>545</b>
<b>14.1 Turning operations on milling machines (option 50).....</b>	<b>546</b>
Introduction.....	546
<b>14.2 Basic functions (option 50).....</b>	<b>547</b>
Switching between milling/turning mode of operation.....	547
Graphic display of turning operations.....	549
Program spindle speed.....	550
Feed rate.....	552
<b>14.3 Unbalance functions (option 50).....</b>	<b>553</b>
Unbalance while turning.....	553
Measure Unbalance cycle.....	555
Calibrate unbalance cycle.....	556
<b>14.4 Tools in turning mode (option 50).....</b>	<b>557</b>
Tool call.....	557
Tool compensation in the program.....	558
Tool data.....	559
Tool tip radius compensation TRC.....	566
<b>14.5 Turning program functions (option 50).....</b>	<b>567</b>
Recessing and undercutting.....	567
Blank form update TURNDATA BLANK.....	573
Inclined turning.....	574

<b>15 Manual Operation and Setup.....</b>	<b>577</b>
<b>15.1 Switch-on, switch-off.....</b>	<b>578</b>
Switch-on.....	578
Switch-off.....	580
<b>15.2 Moving the machine axes.....</b>	<b>581</b>
Note.....	581
Moving the axis with the axis direction keys.....	581
Incremental jog positioning.....	582
Traverse with electronic handwheels.....	583
<b>15.3 Spindle speed S, feed rate F and miscellaneous function M.....</b>	<b>593</b>
Application.....	593
Entering values.....	593
Adjusting spindle speed and feed rate.....	594
Feed rate limit F MAX.....	594
<b>15.4 Optional safety concept (functional safety FS).....</b>	<b>595</b>
Miscellaneous.....	595
Explanation of terms.....	596
Checking the axis positions.....	597
Activating feed-rate limitation.....	598
Additional status displays.....	598
<b>15.5 Datum management with the preset table.....</b>	<b>599</b>
Note.....	599
Saving the datums in the preset table.....	600
Activating the datum.....	606
<b>15.6 Datum setting without a 3-D touch probe.....</b>	<b>607</b>
Note.....	607
Preparation.....	607
Datum setting with an end mill.....	607
Using touch probe functions with mechanical probes or measuring dials.....	608

<b>15.7 Using a 3-D touch probe.....</b>	<b>609</b>
Overview.....	609
Functions in touch probe cycles.....	611
Selecting the probing cycle.....	613
Recording measured values from the touch probe cycles.....	614
Writing measured values from the touch probe cycles to a datum table.....	615
Writing measured values from the touch probe cycles to the preset table.....	616
<b>15.8 Calibrating 3-D touch probes.....</b>	<b>617</b>
Introduction.....	617
Calibrating the effective length.....	618
Calibrating the effective radius and compensating center misalignment.....	619
Displaying calibration values.....	624
<b>15.9 Compensating workpiece misalignment with 3-D touch probe.....</b>	<b>625</b>
Introduction.....	625
Identifying basic rotation.....	626
Saving a basic rotation in the preset table.....	626
Compensation of workpiece misalignment by rotating the table.....	626
Displaying a basic rotation.....	627
Canceling a basic rotation.....	627
Measuring 3-D basic rotation.....	627
<b>15.10 Datum setting with a 3-D touch probe.....</b>	<b>629</b>
Overview.....	629
Datum setting on any axis.....	629
Corner as datum.....	630
Circle center as datum.....	631
Setting a center line as datum.....	634
Measuring workpieces with a 3-D touch probe.....	635
<b>15.11 Tilting the working plane (option 8).....</b>	<b>638</b>
Application, function.....	638
Traversing datums in tilted axes.....	640
Position display in a tilted system.....	640
Limitations on working with the tilting function.....	640
Activating manual tilting:.....	641
Setting the tool-axis direction as the active machining direction.....	643
Setting a datum in a tilted coordinate system.....	644



**15.12 Camera-based monitoring of the setup situation VSC (option number 136)..... 645**

Basics.....	645
Overview.....	647
Produce live image.....	648
Manage monitoring data.....	649
Configuration.....	650
Results of the image evaluation.....	651

**16 Positioning with Manual Data Input..... 653**

**16.1 Programming and executing simple machining operations.....654**

    Positioning with manual data input (MDI)..... 655

    Protecting programs in \$MDI..... 657

## **17 Test Run and Program Run..... 659**

### **17.1 Graphics.....660**

Application.....	660
Speed of the setting test runs.....	661
Overview: Display modes.....	662
3-D view.....	663
Plan view.....	667
Projection in three planes.....	667
Repeating graphic simulation.....	669
Tool display.....	669
Measurement of machining time.....	670

### **17.2 Show the workpiece blank in the working space..... 671**

Application.....	671
------------------	-----

### **17.3 Functions for program display..... 672**

Overview.....	672
---------------	-----

### **17.4 Test run..... 673**

Application.....	673
Execute test run.....	675
Test run up to a certain block.....	677

### **17.5 Program run..... 678**

Application.....	678
Running a part program.....	678
Interrupt, stop or abort machining.....	679
Moving the machine axes during an interruption.....	682
Resuming program run after an interruption.....	683
Retraction after a power interruption.....	684
Any entry into program: Mid-program startup.....	687
Returning to the contour.....	692

### **17.6 Automatic program start..... 693**

Application.....	693
------------------	-----

<b>17.7</b>	<b>Optional block skip.....</b>	<b>694</b>
	Application.....	694
	Inserting the "/" character.....	694
	Erasing the "/" character.....	694
<b>17.8</b>	<b>Optional program-run interruption.....</b>	<b>695</b>
	Application.....	695

<b>18 MOD Functions.....</b>	<b>697</b>
<b>18.1 MOD function.....</b>	<b>698</b>
Selecting MOD functions.....	698
Changing the settings.....	698
Exiting MOD functions.....	698
Overview of MOD functions.....	699
<b>18.2 Graphic settings.....</b>	<b>700</b>
<b>18.3 Machine settings.....</b>	<b>701</b>
External access.....	701
Entering traverse limits.....	703
Tool usage file.....	704
Select kinematics.....	704
<b>18.4 System settings.....</b>	<b>705</b>
Set the system time.....	705
<b>18.5 Select the position display.....</b>	<b>706</b>
Application.....	706
<b>18.6 Setting the unit of measure.....</b>	<b>707</b>
Application.....	707
<b>18.7 Displaying operating times.....</b>	<b>707</b>
Application.....	707
<b>18.8 Software numbers.....</b>	<b>708</b>
Application.....	708
<b>18.9 Enter the code number.....</b>	<b>708</b>
Application.....	708

<b>18.10 Setting up data interfaces.....</b>	<b>709</b>
Serial interfaces on the TNC 640.....	709
Application.....	709
Setting the RS-232 interface.....	709
Set BAUD RATE (baud rate no. 106701).....	709
Set protocol (protocol no. 106702).....	710
Set data bits (dataBits no. 106703).....	710
Check parity (parity no. 106704).....	710
Set stop bits (stopBits no. 106705).....	710
Set handshake (flowControl no. 106706).....	711
File system for file operation (fileSystem no. 106707).....	711
Block check character (bccAvoidCtrlChar no. 106708).....	711
Condition of RTS line (rtsLow no. 106709).....	711
Define behavior after receipt of ETX (noEotAfterEtx no. 106710).....	712
Settings for the transmission of data using PC software TNCserver.....	712
Setting the operating mode of the external device (fileSystem).....	713
Software for data transfer.....	713
<b>18.11 Ethernet interface.....</b>	<b>715</b>
Introduction.....	715
Connection possibility.....	715
Configuring the TNC.....	715
<b>18.12 Firewall.....</b>	<b>721</b>
Application.....	721
<b>18.13 Configuring the HR 550FS wireless handwheel.....</b>	<b>724</b>
Application.....	724
Assigning the handwheel to a specific handwheel holder.....	724
Setting the transmission channel.....	725
Selecting the transmitter power.....	725
Statistical data.....	726
<b>18.14 Load machine configuration.....</b>	<b>727</b>
Application.....	727

<b>19 Tables and Overviews.....</b>	<b>729</b>
<b>19.1 Machine-specific user parameters.....</b>	<b>730</b>
Application.....	730
<b>19.2 Connector pin layout and connection cables for data interfaces.....</b>	<b>743</b>
RS-232-C/V.24 interface for HEIDENHAIN devices.....	743
Non-HEIDENHAIN devices.....	745
Ethernet interface RJ45 socket.....	746
<b>19.3 Technical Information.....</b>	<b>747</b>
User functions.....	749
Software options.....	752
Accessories.....	755
<b>19.4 Overview tables.....</b>	<b>756</b>
Fixed cycles.....	756
Miscellaneous functions.....	758
<b>19.5 Functions of the TNC 640 and the iTNC 530 compared.....</b>	<b>760</b>
Comparison: Specifications.....	760
Comparison: Data interfaces.....	760
Comparison: Accessories.....	761
Comparison: PC software.....	761
Comparison: Machine-specific functions.....	762
Comparison: User functions.....	762
Comparator: Cycles.....	770
Comparison: Miscellaneous functions.....	773
Comparison: Touch probe cycles in the Manual operation and Electronic handwheel modes of operationElectronic handwheel.....	775
Comparison: Probing system cycles for automatic workpiece control.....	776
Comparison: Differences in programming.....	777
Comparison: Differences in Test Run, functionality.....	782
Comparison: Differences in Test Run, operation.....	782
Comparison: Differences in Manual Operation, functionality.....	783
Comparison: Differences in Manual Operation, operation.....	784
Comparison: Differences in Program Run, operation.....	784
Comparison: Differences in Program Run, traverse movements.....	785
Comparison: Differences in MDI operation.....	790
Comparison: Differences in programming station.....	790





# 1

**First Steps with  
the TNC 640**

# 1 First Steps with the TNC 640

## 1.1 Overview

### 1.1 Overview

This chapter is intended to help TNC beginners quickly learn to handle the most important procedures. For more information on a respective topic, see the section referred to in the text.

The following topics are included in this chapter:

- Machine switch-on
- Programming the first part
- Graphically testing the first part
- Setting up tools
- Workpiece setup
- Running the first program

### 1.2 Machine switch-on

#### Acknowledging the power interruption and moving to the reference points



Refer to your machine manual.

Danger exists for the operator when the machine is started up. Read the safety information before switching on the machine.



Switch-on and crossing over the reference points can vary depending on the machine tool. Refer to your machine manual.

- ▶ Switch on the power supply for control and machine. The TNC starts the operating system. This process may take several minutes. Then the TNC will display the "Power interrupted" message in the screen header.

**CE**


- ▶ Press the **CE** key: The TNC compiles the PLC program



- ▶ Switch on the control voltage: The TNC checks operation of the emergency stop circuit and goes into Reference Run mode



- ▶ Cross the datums manually in the prescribed sequence: For each axis press the **START** key. If you have absolute linear and angle encoders on your machine there is no need for a reference run



The TNC is now ready for operation in the **Manual operation** mode.

#### Further information on this topic

- Approaching datums  
**Further Information:** "Switch-on", page 578
- Operating modes  
**Further Information:** "Programming", page 88

## 1.3 Programming the first part

### Selecting the correct operating mode

You can write programs only in **Programming** mode:








- Press the Programming operating mode key for the TNC to switch to **Programming**

#### Further information on this topic

- Operating modes  
**Further Information:** "Programming", page 88

### The most important TNC keys

Key	Functions for conversational guidance
	Confirm entry and activate the next dialog prompt
	Ignore the dialog question
	End the dialog immediately
	Abort dialog, discard entries
	Soft keys on the screen with which you select functions appropriate to the active operating state

#### Further information on this topic

- Writing and editing programs  
**Further Information:** "Editing a program", page 140
- Overview of keys  
**Further Information:** "Controls of the TNC", page 2

# 1 First Steps with the TNC 640

## 1.3 Programming the first part

### Opening a new program/file management

PGM  
MGT

- ▶ Press the **PGM MGT** key: The TNC opens the file manager. The file management of the TNC is arranged much like the file management on a PC with the Windows Explorer. The file management enables you to manage data on the internal memory of the TNC.


- ▶ Use the arrow keys to select the folder in which you want to open the new file.
- ▶ Enter any desired file name with the extension **.H**.

ENT

- ▶ Confirm with the **ENT** key: The control asks you for the unit of measurement for the new program.

MM

- ▶ Select the unit of measure: Press the **MM** or **INCH** soft key.



The TNC automatically generates the first and last blocks of the program. Afterwards you can no longer change these blocks.

### Further information on this topic



- File management  
**Further Information:** "Working with the file manager", page 148
- Creating a new program  
**Further Information:** "Opening programs and entering", page 132

## Defining a workpiece blank

After you have created a new program you can define a workpiece blank. For example, define a cuboid by entering the MIN and MAX points, each with reference to the selected reference point.

After you have selected the desired blank form via soft key, the TNC automatically initiates the workpiece blank definition and asks for the required data:

- ▶ **Working plane in graphic: XY?:** Enter the active spindle axis. Z is saved as default setting. Accept with the **ENT** key
- ▶ **Workpiece blank def.: Minimum X:** Enter the smallest X coordinate of the workpiece blank with respect to the reference point, e.g. 0, confirm with the **ENT** key
- ▶ **Workpiece blank def.: Minimum Y:** Smallest Y coordinate of the workpiece blank with respect to the reference point, e.g. 0. Confirm with the **ENT** key
- ▶ **Workpiece blank def.: Minimum Z:** Smallest Z coordinate of the workpiece blank with respect to the reference point, e.g. -40, confirm with the **ENT** key
- ▶ **Workpiece blank def.: Maximum X:** Enter the largest X coordinate of the workpiece blank with respect to the reference point, e.g. 100, confirm with the **ENT** key
- ▶ **Workpiece blank def.: Maximum Y:** Enter the largest Y coordinate of the workpiece blank with respect to the reference point, e.g. 100. Confirm with the **ENT** key
- ▶ **Workpiece blank def.: Maximum Z:** Enter the largest Z coordinate of the workpiece blank with respect to the reference point, e.g. 0. Confirm with the **ENT** key. The TNC concludes the dialog



### Example NC blocks

```
0 BEGIN PGM NEW MM
```

```
1 BLK FORM 0.1 Z X+0 Y+0 Z-40
```

```
2 BLK FORM 0.2 X+100 Y+100 Z+0
```

```
3 END PGM NEW MM
```

### Further information on this topic

- Define workpiece blank  
**Further Information:** "Opening a new part program", page 136

## First Steps with the TNC 640

### 1.3 Programming the first part

#### Program layout

NC programs should be arranged consistently in a similar manner. This makes it easier to find your place, accelerates programming and reduces errors.

#### Recommended program layout for simple, conventional contour machining

- 1 Call tool, define tool axis
- 2 Retract the tool
- 3 Pre-position the tool in the working plane near the contour starting point
- 4 In the tool axis, position the tool above the workpiece, or preposition immediately to workpiece depth. If required, switch on the spindle/coolant
- 5 Contour approach
- 6 Contour machining
- 7 Contour departure
- 8 Retract the tool, end program

#### Further information on this topic

- Contour programming  
**Further Information:** "Programming tool movements for workpiece machining", page 244

#### Recommended program layout for simple cycle programs

- 1 Call tool, define tool axis
- 2 Retract the tool
- 3 Define the machining positions
- 4 Define the fixed cycle
- 5 Call the cycle, switch on the spindle/coolant
- 6 Retract the tool, end program

#### Further information on this topic

- Cycle programming  
**Further information:** Cycle Programming User's Manual

#### Layout of contour machining programs

```

0 BEGIN PGM BSPCONT MM
1 BLK FORM 0.1 Z X... Y... Z...
2 BLK FORM 0.2 X... Y... Z...
3 TOOL CALL 5 Z S5000
4 L Z+250 R0 FMAX
5 L X... Y... R0 FMAX
6 L Z+10 R0 F3000 M13
7 APPR ... X... Y...RL F500
...
16 DEP ... X... Y... F3000 M9
17 L Z+250 R0 FMAX M2
18 END PGM BSPCONT MM

```

#### Cycle program layout

```

0 BEGIN PGM BSBCYC MM
1 BLK FORM 0.1 Z X... Y... Z...
2 BLK FORM 0.2 X... Y... Z...
3 TOOL CALL 5 Z S5000
4 L Z+250 R0 FMAX
5 PATTERN DEF POS1( X... Y...
  Z... ) ...
6 CYCL DEF...
7 CYCL CALL PAT FMAX M13
8 L Z+250 R0 FMAX M2
9 END PGM BSBCYC MM

```

## Programming a simple contour

The contour shown to the right is to be milled once to a depth of 5 mm. You have already defined the workpiece blank. After you have initiated a dialog through a function key, enter all the data requested by the TNC in the screen header.



- Call the tool: Enter the tool data. Confirm the entry in each case with the **ENT** key, and do not forget the **Z** tool axis




- Retracting tool: Press the orange axis key **Z** and enter the value for the position to be approached, e.g. 250. Press the **ENT** key
- **Tool radius comp: RL/RR/no comp?** confirm with the **ENT** key: Do not activate radius compensation
- **Vorschub F=?** confirm with the **ENT** key: Rapid traverse (**FMAX**)
- Enter **Miscellaneous function M?** and confirm with the **END** key: The TNC saves the input positioning block



- Preposition the tool in the working plane: Press the orange **X** axis key and enter the value for the position to be approached, e.g. -20
- Press the orange axis key **Y** and enter the value for the position to be approached, e.g. -20. Press the **ENT** key
- **Tool radius comp: RL/RR/no comp?** confirm with the **ENT** key: Do not activate radius compensation
- **Vorschub F=?** confirm with the **ENT** key: Rapid traverse (**FMAX**)




- Confirm **Miscellaneous function M?** with the **END** key: The TNC saves the input positioning block
- Move tool to working depth: Press the orange axis key **Z** and enter the value for the position to be approached, e.g. -5. Press the **ENT** key
- **Tool radius comp: RL/RR/no comp?** confirm with the **ENT** key: Do not activate radius compensation
- **Feed rate F=?** Enter the positioning feed rate, e.g. 3000 mm/min, confirm with the **ENT** key
- **Miscellaneous function M?** Switch on the spindle and coolant, e.g. **M13**, confirm with the **END** key: The TNC saves the entered positioning block
- Move to the contour: Press the **APPR/DEP** key: The TNC shows a soft-key row with approach and departure functions



# First Steps with the TNC 640

## 1.3 Programming the first part



- ▶ Press the approach function soft key **APPR CT**: Enter the coordinates of the contour starting point **1** in X and Y, e.g. 5/5, confirm with the **ENT** key
- ▶ **Center angle?** Enter the approach angle, e.g. 90°, confirm with the **ENT** key
- ▶ **Circle radius?** Enter the circular radius, e.g. 8 mm, confirm with the **ENT** key
- ▶ Confirm the **Tool radius comp: RL/RR/no comp?** with the **RL** soft key: Activate the radius compensation to the left of the programmed contour
- ▶ **Feed rate F=?** Enter the machining feed rate, e.g. 700 mm/min, save your entry with the **END** key



- ▶ Machine the contour and move to contour point **2**: You only need to enter the information that changes. In other words, enter the Y coordinate 95 and save your entry with the **END** key



- ▶ Move to contour point **3**: Enter the X coordinate 95 and save your entry with the **END** key



- ▶ Define the chamfer at contour point **3**: Enter the chamfer width 10 mm and save with the **END** key



- ▶ Move to contour point **4**: Enter the Y coordinate 5 and save your entry with the **END** key



- ▶ Define the chamfer at contour point **4**: Enter the chamfer width 20 mm and save with the **END** key



- ▶ Move to contour point **1**: Enter the X coordinate 5 and save your entry with the **END** key



- ▶ Depart contour: Press the APPR DEP key



- ▶ Departure function: Press the **DEP CT** soft key
- ▶ **Center angle?** Enter the departure angle, e.g. 90°, confirm with the **ENT** key
- ▶ **Circle radius?** Enter the departure radius, e.g. 8 mm, confirm with the **ENT** key
- ▶ **Feed rate F=?** Enter the positioning feed rate, e.g. 3000 mm/min, confirm with the **ENT** key
- ▶ **Miscellaneous function M?** Switch on the coolant, e.g. **M9**, confirm with the **END** key: The TNC saves the entered positioning block



- ▶ Retracting tool: Press the orange axis key **Z** and enter the value for the position to be approached, e.g. 250. Press the **ENT** key
- ▶ **Tool radius comp: RL/RR/no comp?** confirm with the **ENT** key: Do not activate radius compensation
- ▶ **Vorschub F=?** confirm with the **ENT** key: Rapid traverse (**FMAX**)
- ▶ **MISCELLANEOUS FUNCTION M?** Enter **M2** to end the program and confirm with the **END** key: The TNC saves the entered positioning block



**Further information on this topic**






- **Complete example with NC blocks**  
**Further Information:** "Example: Linear movements and chamfers with Cartesian coordinates", page 267
- Creating a new program  
**Further Information:** "Opening programs and entering", page 132
- Approaching/departing contours  
**Further Information:** "Approaching and departing a contour", page 248
- Programming contours  
**Further Information:** "Overview of path functions", page 258
- Programmable feed rates  
**Further Information:** "Possible feed rate input", page 138
- Tool radius compensation  
**Further Information:** "Tool radius compensation ", page 228
- Miscellaneous functions M  
**Further Information:** "Miscellaneous functions for program run inspection, spindle and coolant ", page 408

# First Steps with the TNC 640



## 1.3 Programming the first part

### Creating a cycle program

The holes (depth of 20 mm) shown in the figure at right are to be drilled with a standard drilling cycle. You have already defined the workpiece blank.



- ▶ Call the tool: Enter the tool data. Confirm the entry in each case with the **ENT** key, do not forget the tool axis
- ▶ Retract tool: Press the orange axis key **Z** and enter the value for the position to be approached, e.g. 250. Press the **ENT** key
- ▶ Confirm **Radius comp.: RL/RR/no comp.?** by pressing the **ENT** key: Do not activate radius compensation
- ▶ Confirm **Feed rate F=?** with the **ENT** key: Move at rapid traverse (**FMAX**)
- ▶ **Miscellaneous function M?** Confirm with the **END** key: The TNC saves the entered positioning block
- ▶ Call the cycle menu: Press the CYCL DEF key
- ▶ Display the drilling cycles
- ▶ Select the standard drilling cycle 200: The TNC starts the dialog for cycle definition. Enter all parameters requested by the TNC step by step and conclude each entry with the **ENT** key. In the screen to the right, the TNC also displays a graphic showing the respective cycle parameter
- ▶ Call the menu for special functions: Press the SPEC FCT key
- ▶ Display the functions for point machining
- ▶ Select the pattern definition
- ▶ Select point entry: Enter the coordinates of the 4 points and confirm each with the **ENT** key. After entering the fourth point, save the block with the **END** key
- ▶ Display the menu for defining the cycle call: Press the CYCL CALL key
- ▶ Run the drilling cycle on the defined pattern:
- ▶ Confirm **Feed rate F=?** with the **ENT** key: Move at rapid traverse (**FMAX**)
- ▶ **Miscellaneous function M?** Switch on the spindle and coolant, e.g. **M13**. Confirm with the **END** key: The TNC saves the entered positioning block





- ▶ Enter Retract tool: Press the orange axis key **Z** and enter the value for the position to be approached, e.g. 250. Press the **ENT** key
- ▶ Confirm **Radius comp.: RL/RR/no comp.?** by pressing the **ENT** key: Do not activate radius compensation
- ▶ Confirm **Feed rate F=?** with the **ENT** key: Move at rapid traverse (**FMAX**)
- ▶ **Miscellaneous function M?** Enter **M2** to end the program and confirm with the **END** key: The TNC saves the entered positioning block

#### Example NC blocks

0 BEGIN PGM C200 MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-40	Definition of workpiece blank
2 BLK FORM 0.2 X+100 Y+100 Z+0	
3 TOOL CALL 5 Z S4500	Tool call
4 L Z+250 R0 FMAX	Retract the tool
5 PATTERN DEF POS1 (X+10 Y+10 Z+0) POS2 (X+10 Y+90 Z+0) POS3 (X+90 Y+90 Z+0) POS4 (X+90 Y+10 Z+0)	Define the machining positions
6 CYCL DEF 200 DRILLING	Define the cycle
Q200=2 ;SET-UP CLEARANCE	
Q201=-20 ;DEPTH	
Q206=250 ;FEED RATE FOR PLNGNG	
Q202=5 ;PLUNGING DEPTH	
Q210=0 ;DWELL TIME AT TOP	
Q203=-10 ;SURFACE COORDINATE	
Q204=20 ;2ND SET-UP CLEARANCE	
Q211=0.2 ;DWELL TIME AT DEPTH	
Q395=0 ;DEPTH REFERENCE	
7 CYCL CALL PAT FMAX M13	Spindle and coolant on, call the cycle
8 L Z+250 R0 FMAX M2	Retract the tool, end program
9 END PGM C200 MM	

#### Further information on this topic

- Creating a new program  
**Further Information:** "Opening programs and entering", page 132
- Cycle programming  
**Further information:** Cycle Programming User's Manual

# First Steps with the TNC 640

## 1.4 Graphically testing the first part

### 1.4 Graphically testing the first part

#### Selecting the correct operating mode


You can test programs in the **Test run** mode:



- ▶ Press the operating mode key for the TNC to switch to **Test Run** operating mode

#### Further information on this topic

- Operating modes of the TNC  
**Further Information:** "Modes of operation", page 87
- Testing programs  
**Further Information:** "Test run", page 673



#### Selecting the tool table for the test run

If you have not yet activated a tool table in **Test run** mode, then you must carry out this step.



- ▶ Press the **PGM MGT** key: The TNC opens the file manager



- ▶ Press the **SELECT TYPE** soft key: The TNC shows a soft-key menu for selection of the file type to be displayed



- ▶ Press the **DEFAULT** soft key: The TNC shows all saved files in the right-hand window



- ▶ Move the cursor to the left onto the directories



- ▶ Move the cursor to the **TNC:\table** directory



- ▶ Move the cursor to the right onto the files



- ▶ Move the cursor onto the file **TOOL.T** (active tool table), confirm with the **ENT** key: **TOOL.T** contains the status **S** and is therefore active for the test run



- ▶ Press the **END** key: Exit the file manager


#### Further information on this topic

- Tool management  
**Further Information:** "Enter tool data into the table", page 206
- Testing programs  
**Further Information:** "Test run", page 673

## Choosing the program you want to test



- ▶ Press the **PGM MGT** key: The TNC opens the file manager



- ▶ Press the **LAST FILES** soft key: The TNC opens a pop-up window with the most recently selected files
- ▶ Use the arrow keys to select the program that you want to test. Load with the **ENT** key

### Further information on this topic

- Program number  
**Further Information:** "Working with the file manager", page 148

## Selecting the screen layout and the view






- ▶ Press the key for selecting the screen layout. The TNC shows all available alternatives in the soft-key row



- ▶ Press the **PROGRAM + GRAPHICS** soft key: In the left half of the screen the TNC shows the program; in the right half it shows the workpiece blank

The TNC features the following views:

Soft keys	Function
	Volume view
	Volume view and tool paths
	Tool paths

### Further information on this topic

- Graphic functions  
**Further Information:** "Graphics ", page 660
- Performing a test run  
**Further Information:** "Test run", page 673

## First Steps with the TNC 640

### 1.4 Graphically testing the first part

#### Starting the test run



- ▶ Press the **RESET + START** soft key
- > The control resets the previously active tool data
- > The control simulates the active program up to a programmed break or to the program end
- ▶ While the simulation is running, you can use the soft keys to change views



- ▶ Press the **STOP** soft key
- > The TNC interrupts the test run



- ▶ Press the **START** soft key
- > The control resumes the test run after a break

#### Further information on this topic

- Performing a test run  
**Further Information:** "Test run", page 673
- Graphic functions  
**Further Information:** "Graphics ", page 660
- Adjusting the simulation speed  
**Further Information:** "Speed of the setting test runs", page 661

## 1.5 Setting up tools

### Selecting the correct operating mode


Tools are set up in the **Manual operation** mode:



- ▶ Press the operating mode key for the TNC to switch to **Manual operation** operating mode

#### Further information on this topic

- Operating modes of the TNC  
**Further Information:** "Modes of operation", page 87



### Preparing and measuring tools

- ▶ Clamp the required tools in their tool holders
- ▶ When measuring with an external tool presetter: Measure the tools, note down the length and radius, or transfer them directly to the machine through a transfer program
- ▶ When measuring on the machine: store the tools in the tool changer

**Further Information:** "The pocket table TOOL\_PTCH", page 79


# 1 First Steps with the TNC 640

## 1.5 Setting up tools

### The tool table TOOL.T

In the tool table TOOL.T (permanently saved under **TNC:\table\**), save the tool data such as length and radius, but also further tool-specific information that the TNC needs to perform its functions.

To enter tool data in the tool table TOOL.T, proceed as follows:



- ▶ Display the tool table: The TNC shows the tool table
- ▶ Edit the tool table: Set the **EDIT** soft key to **ON**
- ▶ With the upward or downward arrow keys you can select the tool number that you want to edit
- ▶ With the rightward or leftward arrow keys you can select the tool data that you want to edit
- ▶ To exit the tool table, press the **END** key

T	NAME	L	R	R2	DL	DR
0	SMALL WERKZEUGE	0	0	0	0	0
1	100	20	1	0	0	0
2	204	40	2	0	0	0
3	306	50	3	0	0	0
4	408	50	4	0	0	0
5	5010	60	5	0	0	0
6	6012	60	6	0	0	0
7	7014	70	7	0	0	0
8	8016	80	8	0	0	0
9	9018	80	9	0	0	0
10	10020	90	10	0	0	0
11	11022	90	11	0	0	0
12	12024	90	12	0	0	0
13	13026	90	13	0	0	0
14	14028	100	14	0	0	0
15	15030	100	15	0	0	0
16	16032	100	16	0	0	0
17	17034	100	17	0	0	0
18	18036	100	18	0	0	0
19	19038	100	19	0	0	0
20	20040	100	20	0	0	0
21	21042	100	5	5	0	0
22	22044	120	22	0	0	0
23	23046	120	23	0	0	0
24	24048	120	24	0	0	0
25	25050	120	25	0	0	0
26	26052	120	26	0	0	0

### Further information on this topic

- Operating modes of the TNC  
**Further Information:** "Modes of operation", page 87
- Working with the tool table  
**Further Information:** "Enter tool data into the table", page 206



## The pocket table TOOL\_PTCH



The function of the pocket table depends on the machine. Refer to your machine manual.

In the pocket table TOOL\_PTCH (permanently saved under **TNC:\table\**) you specify which tools your tool magazine contains. To enter data in the pocket table TOOL\_PTCH, proceed as follows:



- Display the tool table: The TNC shows the tool table



- Display the pocket table: The TNC shows the pocket table
- Edit the pocket table: Set the **EDIT** soft key to **ON**
- With the upward or downward arrow keys you can select the pocket number that you want to edit
- With the rightward or leftward arrow keys you can select the data that you want to edit
- To leave the pocket table, press the **END** key

P	T	TNAME	RSV	ST	F	L	DOC
0.0	5.010						
1.1	1.02						
1.2	2.04						
1.3	3.06						
1.4	4.08						
1.5	5.010						
1.6	6.012						
1.7	7.014						
1.8	8.016						
1.9	9.018						
1.10	10.020						
1.11	11.022						
1.12	12.024						
1.13	13.026						
1.14	14.028						
1.15	15.030						
1.16	16.032						
1.17	17.034						
1.18	18.036						
1.19	19.038						
1.20	20.040						
1.21	21.042						
1.22	22.044						
1.23	23.046						
1.24	24.048						
1.25	25.050						
1.26	26.052						

### Further information on this topic

- Operating modes of the TNC  
**Further Information:** "Modes of operation", page 87
- Working with the pocket table  
**Further Information:** "Pocket table for tool changer", page 217

## First Steps with the TNC 640

### 1.6 Workpiece setup

### 1.6 Workpiece setup

#### Selecting the correct operating mode

Workpieces are set up in the **Manual operation** or **Electronic handwheel** mode



- ▶ Press the operating mode key for the TNC to switch to **Manual operation** operating mode **Manual operation**

#### Further information on this topic

- The operating mode **Manual operation**  
**Further Information:** "Moving the machine axes", page 581

#### Clamping the workpiece

Mount the workpiece with a fixture on the machine table. If you have a 3-D touch probe on your machine, then you do not need to clamp the workpiece parallel to the axes.

If you do not have a 3-D touch probe available, you have to align the workpiece so that it is fixed with its edges parallel to the machine axes.

#### Further information on this topic

- Setting datums with a 3-D touch probe  
**Further Information:** "Datum setting with a 3-D touch probe ", page 629
- Setting datums without 3-D touch probe  
**Further Information:** "Datum setting without a 3-D touch probe", page 607

## Datum setting with a 3-D touch probe

- Insert a 3-D touch probe: In the **Positioning with manl.data input** mode, run a **TOOL CALL** block containing the tool axis and then return to the **Manual operation** mode



- Press the probing function soft key: The TNC displays all available functions in the soft key row



- Set the datum at a workpiece corner, for example
- Position the touch probe near the first touch point on the first workpiece edge
- Select the probing direction via soft key
- Press **NC START**: The touch probe moves in the defined direction until it contacts the workpiece and then automatically returns to its starting point
- Use the axis-direction keys to pre-position the touch probe to a position near the second touch point on the first workpiece edge
- Press NC start: The touch probe moves in the defined direction until it contacts the workpiece and then automatically returns to its starting point
- Use the axis-direction keys to pre-position the touch probe to a position near the first touch point on the second workpiece edge
- Select the probing direction via soft key
- Press NC start: The touch probe moves in the defined direction until it contacts the workpiece and then automatically returns to its starting point
- Use the axis-direction keys to pre-position the touch probe to a position near the second touch point on the second workpiece edge
- Press NC start: The touch probe moves in the defined direction until it contacts the workpiece and then automatically returns to its starting point
- Then the TNC shows the coordinates of the measured corner point



- To set to 0: Press the **SET DATUM** soft key
- Press the **END** soft key to close the menu

### Further information on this topic

- Setting datums  
**Further Information:** "Datum setting with a 3-D touch probe ", page 629

# First Steps with the TNC 640

## 1.7 Running the first program

### 1.7 Running the first program

#### Selecting the correct operating mode


You can run programs either in the **Program run, single block** or the **Program run, full sequence** mode:



- ▶ Press the operating mode key: The TNC changes to operating mode **Program run, single block**, and the TNC executes the NC program block by block. You have to confirm each block with the **NC START KEY**



- ▶ Press the operating mode key: The TNC changes to operating mode **Program run, full sequence**, and the TNC runs the program after NC start-up to a program interruption or to the end of the program




#### Further information on this topic

- Operating modes of the TNC  
**Further Information:** "Modes of operation", page 87
- Executing a program  
**Further Information:** "Program run", page 678

#### Choosing the program you want to run



- ▶ Press the **PGM MGT** key: The TNC opens the file manager



- ▶ Press the **LAST FILES** soft key: The TNC opens a pop-up window with the most recently selected files
- ▶ Use the arrow keys if required to select the program you want to run. Load with the **ENT** key

#### Further information on this topic

- File management  
**Further Information:** "Working with the file manager", page 148

#### Start the program



- ▶ Press the **NC START** key: The TNC runs the active program

#### Further information on this topic

- Executing a program  
**Further Information:** "Program run", page 678

# 2

## **Introduction**

## Introduction

### 2.1 The TNC 640

#### 2.1 The TNC 640

HEIDENHAIN TNC controls are workshop-oriented contouring controls that enable you to program conventional milling and drilling operations right at the machine in easy-to-use Klartext conversational language. They are designed for milling, drilling and boring machines, as well as machining centers, with up to 18 axes. You can also change the angular position of the spindle under program control.

An integrated hard disk provides storage for as many programs as you like, even if they were created off-line. For quick calculations you can call up the on-screen pocket calculator at any time.

Keyboard and screen layout are clearly arranged in such a way that the functions are fast and easy to use.



#### HEIDENHAIN Klartext and DIN/ISO

HEIDENHAIN Klartext, the dialog-guided TNC programming language for workshops, is an especially easy method of writing programs. Programming graphics illustrate the individual machining steps for programming the contour. If no NC-dimensioned drawing is available, then the FK free contour programming will help. Workpiece machining can be graphically simulated either during a test run or during a program run.

It is also possible to program in ISO format or DNC mode.

You can also enter and test one program while the control is running another.

#### Compatibility

Machining programs created on HEIDENHAIN contouring controls (starting from the TNC 150 B) may not always run on the TNC 640. If the NC blocks contain invalid elements, the TNC will mark these as ERROR blocks or with error messages when the file is opened.



Please also note the detailed description of the differences between the iTNC 530 and the TNC 640.  
**Further Information:** "Functions of the TNC 640 and the iTNC 530 compared", page 760.

## 2.2 Visual display unit and operating panel

### Display screen

The TNC is shipped with a 19-inch TFT flat-panel display.

#### 1 Header

When the TNC is on, the screen displays the selected operating modes in the header: The machining mode at the left and the programming mode at right. The currently active mode is displayed in the larger field of the header, where the dialog prompts and TNC messages also appear (exception: If the TNC only displays graphics).

#### 2 Soft keys

In the footer the TNC indicates additional functions in a soft-key row. You can select these functions by pressing the keys immediately below them. The thin bars immediately above the soft-key row indicate the number of soft-key rows that can be called with the keys to the right and left that are used to switch the soft keys. The bar representing the active soft-key row is highlighted.

#### 3 Soft-key selection keys


#### 4 Keys for switching the soft keys

#### 5 Setting the screen layout

#### 6 Shift key for switchover between machining and programming modes

#### 7 Soft-key selection keys for machine tool builders

#### 8 Keys for switching the soft keys for machine tool builders



### Set screen layout


You select the screen layout yourself: In the **Programming** mode, for example, you can have the TNC show program blocks in the left window while the right window displays programming graphics. You could also display the program structure in the right window instead, or display only program blocks in one large window. The available screen windows depend on the selected operating mode.

Set up screen layout:



- ▶ Press the screen switchover key: The soft key row shows the available layout options

**Further Information:** "Modes of operation", page 87



- ▶ Select the desired screen layout with a soft key


## Introduction

### 2.2 Visual display unit and operating panel

#### Control panel

The TNC 640 is delivered with an integrated operating panel. The figure to the right shows the operating elements of the operating panel:

- 1 Alphabetic keyboard for entering texts and file names, as well as for ISO programming
- 2
  - File management
  - Calculator
  - MOD function
  - HELP function
- 3 Programming modes
- 4 Machine operating modes
- 5 Initiating programming dialogs
- 6 Navigation keys and **GOTO** jump command
- 7 Numerical input and axis selection
- 8 Touchpad
- 9 Mouse buttons
- 10 USB connection



Some machine tool builders do not use the standard HEIDENHAIN operating panel. Refer to your machine manual.

External keys, e.g. **NC START** or **NC STOP**, are described in your machine manual.



## 2.3 Modes of operation


### Manual Operation and El. Handwheel

The **Manual operation** mode is required for setting up the machine tool. In this mode of operation, you can position the machine axes manually or by increments, set the datums and tilt the working plane.

The **Electronic handwheel** mode of operation allows you to move the machine axes manually with the HR electronic handwheel.

#### Soft keys for the screen layout (select as described above)

Soft key	Window
<b>POSITION</b>	Positions
<b>POSITION + STATUS</b>	Left: positions, right: status display
<b>POSITION + KINEMATICS</b>	Left: positions, right: collision object




### Positioning with Manual Data Input

This mode of operation is used for programming simple traversing movements, such as for face milling or prepositioning.

#### Soft keys for selecting the screen layout

Soft key	Window
<b>PGM</b>	Program
<b>PROGRAM + STATUS</b>	Left: program, right: status display
<b>POSITION + KINEMATICS</b>	Left: program, right: collision object




## Programming

In this operating mode you can write your machining programs. The FK free programming feature, the various cycles and the Q parameter functions help you with programming and add necessary information. If desired, you can have the programming graphics show the programmed paths of traverse.

### Soft keys for selecting the screen layout

Soft key	Window
PGM	Program
PROGRAM + SECTS	Left: program, right: program structure
PROGRAM + GRAPHICS	Left: program blocks, right: programming graphics




## Test Run

In the **Test run** mode of operation, the TNC checks programs and program sections for errors, such as geometrical incompatibilities, missing or incorrect data within the program or violations of the working space. This simulation is supported graphically in different display modes.

### Soft keys for selecting the screen layout

Soft key	Window
PGM	Program
PROGRAM + STATUS	Left: program, right: status display
PROGRAM + GRAPHICS	Left: program, right: graphics
GRAPHICS	Graphic



## Program Run, Full Sequence and Program Run, Single Block

In the **Program run full sequence** mode, the TNC executes a program continuously to its end or to a manual or programmed stop. You can resume program run after an interruption.


In the **Program run single block** mode, you execute each block separately by pressing the **NC START** key. With point pattern cycles and **CYCL CALL PAT** the controls stops after each point.

### Soft keys for selecting the screen layout

Soft key	Window
<b>PGM</b>	Program
<b>PROGRAM + SECTS</b>	Left: program, right: structure
<b>PROGRAM + STATUS</b>	Left: program, right: status display
<b>PROGRAM + GRAPHICS</b>	Left: program, right: graphics
<b>GRAPHICS</b>	Graphic
<b>POSITION + KINEMATICS</b>	Left: program, right: collision object
<b>KINEMATICS</b>	Collision body

### Soft keys for screen layout with pallet tables

Soft key	Window
<b>PALLET</b>	Pallet table
<b>PROGRAM + PALLET</b>	Left: program, right: pallet table
<b>PALLET + STATUS</b>	Left: pallet table, right: status display
<b>PALLET + GRAPHICS</b>	Left: pallet table, right: graphics



## 2.4 Status displays

### General status display

The general status display in the lower part of the screen informs you of the current state of the machine.

It is displayed automatically in the following operating modes:

- Program run, single block
- Program run, full sequence
- Positioning with manl.data input













If the **GRAPHICS** screen layout is selected the status display is not shown.

In the **Manual operation** and **Electronic handwheel** modes the status display appears in the large window.

### Information in the status display

Icon	Meaning
<b>ACTL.</b>	Position display: Actual, nominal or distance-to-go coordinates mode
<b>XYZ</b>	Machine axes; the TNC displays auxiliary axes in lower-case letters. The sequence and quantity of displayed axes is determined by the machine tool builder. Refer to your machine manual for more information
	Number of the active presets from the preset table. If the datum was set manually, the TNC displays the text <b>MAN</b> behind the symbol
<b>F S M</b>	The displayed feed rate in inches corresponds to one tenth of the effective value. Spindle speed S, feed rate F and active M functions
	Axis is clamped
	Axis can be moved with the handwheel
	Axes are moving under a basic rotation
	Axes are moving under a 3-D basic rotation
	Axes are moving in a tilted working plane
<b>TC PM</b>	The <b>M128</b> function or <b>FUNCTION TCPM</b> is active



Icon	Meaning
	<p>No program selected, program reselected, program aborted via internal stop or program terminated</p> <p>In this condition the control has no modally effective program information (i.e. the contextual reference), so that all handling is possible, e.g. cursor movements or modification of Q parameters.</p>
	<p>Program started, execution runs</p> <p>For safety reasons, the control permits no handling in this condition</p>
	<p>Program stopped, e.g. in operating mode</p> <p><b>Program run, full sequence</b> after pressing the <b>NC STOP</b> key</p> <p>For safety reasons, the control permits no handling in this condition</p>
	<p>Program interrupted, e.g. in operating mode</p> <p><b>Positioning with manl.data input</b> following the error-free execution of an NC block</p> <p>In this condition the control permits various handling, e.g. cursor movements or the modification of Q parameters. With this handling the control may lose the modally effective program information (i.e. the contextual reference). Loss of this contextual reference may cause undesired tool positions!</p> <p><b>Further Information:</b> "Programming and executing simple machining operations", page 654 and "Program-controlled interruptions", page 680</p>
	Program aborted or terminated
	Turning mode is active
	The Dynamic Collision Monitoring function (DCM) is active (Option #40)
	The Adaptive Feed Function (AFC) is active (Option #45)
<b>ACC</b>	The Active Chatter Control (ACC) function is active (option number 145)
<b>CTC</b>	The CTC function is active (Option #141)
S % 	Pulsing spindle speed function is active

### Additional status displays

The additional status displays contain detailed information on the program run. This can be called in all operating modes except for the **Programming** mode.

#### To switch on the additional status display



- ▶ Call the soft key row for screen layout



- ▶ Select the screen layout with additional status display: In the right half of the screen, the TNC shows the **OVERVIEW** status form

#### To select an additional status display



- ▶ Toggle through the soft key rows until the **STATUS** soft keys appear



- ▶ Either select the additional status display directly with the soft key, e.g. positions and coordinates; or



- ▶ use the switch-over soft keys to select the desired view

Select the status displays described below as follows:

- directly with the corresponding soft key
- via the switchover soft keys
- or by using the **NEXT TAB** key



Please note that some of the status information described below is not available unless the associated software option is enabled on your TNC.



## Overview

The **Overview** status form is displayed by the TNC following TNC switch-on if you selected the screen layout **PROGRAM + STATUS** (or **POSITION + STATUS**). The overview form contains a summary of the most important status information, which you can also find on the various detail forms.

Soft key	Meaning
<b>STATUS</b>	Position display
<b>OVERVIEW</b>	
	Tool information
	Active M functions
	Active coordinate transformations
	Active subprogram
	Active program section repeat
	Program called with <b>PGM CALL</b>
	Current machining time
	Name and path of the active main program

## General program information (PGM tab)

Soft key	Meaning
No direct selection possible	Name and path of the active main program
	Circle center CC (pole)
	Dwell time counter
	Machining time when the program was completely simulated in the <b>Test run</b> operating mode
	Current machining time in percent
	Current time
	Active programs




## Introduction

### 2.4 Status displays


#### Program section repeat/Subprograms (LBL tab)

Soft key	Meaning
No direct selection possible	Active program section repeats with block number, label number, and number of programmed repeats/repeats yet to be run
	Active subprograms with block number in which the subprogram was called and the label number that was called



#### Information on standard cycles (CYC tab)

Soft key	Meaning
No direct selection possible	Active fixed cycle
	Active values of Cycle 32 Tolerance






## Status displays 2.4


### Active miscellaneous functions M (M tab)

Soft key	Meaning
No direct selection possible	List of the active M functions with fixed meaning
	List of the active M functions that are adapted by your machine manufacturer



### Positions and coordinates (POS tab)

Soft key	Meaning
<b>STATUS</b> <b>POS.</b>	Type of position display, e.g. actual position
	Tilt angle of the working plane
	Angle of basic transformations
	Active kinematics




# 2 Introduction

## 2.4 Status displays

### Information on tools (TOOL tab)

Soft key	Meaning
<b>TOOL STATUS</b>	Display of active tool: <ul style="list-style-type: none"> <li>■ T: Tool number and tool name</li> <li>■ RT: Number and name of a replacement tool</li> </ul>
	Tool axis
	Tool length and tool radii
	Oversizes (delta values) from the tool table (TAB) and the <b>TOOL CALL</b> (PGM)
	Tool life, maximum tool life (TIME 1) and maximum tool life for <b>TOOL CALL</b> (TIME 2)
	Display of programmed tool and replacement tool




### Tool measurement (TT tab)




The TNC displays the TT tab only if the function is active on your machine.

Soft key	Meaning
No direct selection possible	Active tool
	Measured values from tool measurement



## Coordinate transformations (TRANS tab)

Soft key	Meaning
<b>STATUS</b> <b>COORD.</b> <b>TRANSF.</b>	Name of the active datum table
	Active datum number (#), comment from the active line of the active datum number (DOC) from Cycle 7
	Active datum shift (Cycle 7); The TNC displays an active datum shift in up to 8 axes
	Mirrored axes (Cycle 8)
	Active rotation angle (Cycle 10)
	Active scaling factor/factors (Cycles 11 / 26); The TNC displays an active scaling factor in up to 6 axes
	Scaling datum



**Further information:** Cycle Programming User's Manual


## Displaying Q parameters (QPARA tab)

Soft key	Meaning
<b>STATUS OF</b> <b>Q PARAM.</b>	Display the current values of the defined Q parameters
	Display the character strings of the defined string parameters



Press the **Q PARAMETER LIST** soft key. The TNC opens a pop-up window. For each parameter type (Q, QL, QR, QS) define the parameter numbers you wish to control. Separate single Q parameters with a comma, and connect sequential Q parameters with a hyphen, e.g. 1,3,200-208. The input range per parameter type is 132 characters.

The display in the **QPARA** tab always contains eight decimal places. The result of  $Q1 = \cos 89.999$  is shown by the control as 0.00001745, for example. Very large and very small values are displayed by the control in exponential notation. The result of  $Q1 = \cos 89.999 * 0.001$  is shown by the control as +1.74532925e-08, whereby e-08 corresponds to the factor of  $10^{-8}$ .




## Adaptive Feed Control (AFC tab, Option #45)



The TNC displays the AFC tab only if the function is active on your machine.

Soft key	Meaning
No direct selection possible	Active tool (number and name)
	Cut number
	Current factor of the feed potentiometer in %
	Active spindle load in percent
	Reference load of the spindle
	Current spindle speed
	Current deviation of the speed
	Current machining time
	Line diagram, in which the current spindle load and the value commanded by the TNC for the feed rate override are shown



## 2.5 Window manager



The machine tool builder determines the scope of function and behavior of the window manager. Refer to your machine manual.

The TNC features the Xfce window manager. Xfce is a standard application for UNIX-based operating systems, and is used to manage graphical user interfaces. The following functions are possible with the window manager:

- Display a task bar for switching between various applications (user interfaces)
- Manage an additional desktop, on which special applications from your machine manufacturer can run
- Control the focus between NC software applications and those of the machine manufacturer
- You can change the size and position of pop-up windows. It is also possible to close, minimize and restore pop-up windows



The TNC shows a star in the upper left of the screen if an application of the window manager or the window manager itself has caused an error. In this case, switch to the window manager and correct the problem. If required, refer to your machine manual.

### Overview of the task bar

In the task bar you can choose different workspaces by mouse click.

The control provides the following workspaces:

- Workspace 1: Active operating mode
- Workspace 2: Active programming mode
- Workspace 3: CAD viewer, DXF converter or applications of the machine tool builder (optionally available)
- Workspace 4: Display and remote control of external computer units (option 133) or applications of the machine tool builder (optionally available)

In addition, you can also select other applications from the task bar which you have started in parallel to the control software, e.g. the **TNCguide**.




You can randomly move all open applications to the right of the green HEIDENHAIN symbol between the workspaces by pressing and holding the left mouse button.

Click the green HEIDENHAIN symbol to open a menu in which you can get information, make settings or start applications.

The following functions are available:

- **About HEROS:** Open information about the operating system of the control
- **NC Control:** Start and stop the control software (for diagnostic purposes only)
- **Web Browser:** Start the web browser
- **Remote Desktop Manager** (option 133): Display and remote control external computer units  
**Further Information:** "Remote Desktop Manager (option 133)", page 110
- **Diagnostic:** Diagnostic applications
  - **GSmartControl:** Available only to authorized specialists
  - **HE Logging:** Define settings for internal diagnostic files
  - **HE Menu:** Available only to authorized specialists
  - **perf2:** Check processor load and process load
  - **Portscan:** Test active connections  
**Further Information:** "Portscan", page 102
  - **Portscan OEM:** Available only to authorized specialists
  - **RemoteService:** Start and stop remote maintenance  
**Further Information:** "Remote Service", page 103
  - **Terminal:** Enter and execute console commands
- **Settings:** Operating system settings
  - **Date/Time:** Set date and time
  - **Language/Keyboards:** Select system dialog language and keyboard version—the control overwrites the setting of the system dialog language when starting with the language setting of the machine parameter **CfgDisplayLanguage** (no. 101300)
  - **Network:** Define network settings



- **Printer:** Configure and manage printer
- **Screensaver:** Define screensaver
- **SELinux:** Define safety software for Linux-based operating systems
- **Shares:** Connect and manage external network drives
- **VNC:** Define the setting for external software accessing the control for e.g. maintenance work (**V**irtual **N**etwork **C**omputing)  
**Further Information:** "VNC", page 106
- **WindowManagerConfig:** Available only to authorized specialists
- **Firewall:** Configure the firewall  
**Further Information:** "Firewall", page 721
- **HePacketManager:** Available only to authorized specialists
- **HePacketManager Custom:** Available only to authorized specialists
- **Tools:** File applications
  - **Document Viewer:** Display files, e.g. PDF files
  - **File Manager:** Available only to authorized specialists
  - **Geeqie:** Open and manage graphics
  - **Gnumeric:** Open and edit tables
  - **Leafpad:** Open and edit text files
  - **NC/PLC Backup:** Create backup file  
**Further Information:** "Backup and restore", page 108
  - **NC/PLC Restore:** Restore backup file  
**Further Information:** "Backup and restore", page 108
  - **Ristretto:** Open graphics
  - **Screenshot:** Create screenshots
  - **TNCguide:** Call up help system
  - **Xarchiver:** Extract or compress directories
  - **Applications:** Supplementary applications
    - **Orage Calender:** Open calendar
    - **Real VNC viewer:** Define the setting for external software accessing the control for e.g. maintenance work (Virtual Network Computing)



The applications available under tools can be started directly by selecting the corresponding file type in the file management of the control

**Further Information:** "Additional tools for management of external file types", page 160

### Portscan

The PortScan function enables the cyclic or manual searching for all open, incoming TCP and UDP list ports on the system. All ports found are compared with whitelists. If the control finds a non-listed port it shows a corresponding pop-up window.

The HeROS **Diagnostic** menu contains the **Portscan** and **Portscan OEM** applications for this purpose. **Portscan OEM** is only executable after entering the machine manufacturer password.

The **Portscan** function searches for all open, incoming TCP and UDP ports on the system and compares them to four whitelists stored in the system:

- System-internal whitelists **/etc/sysconfig/portscan-whitelist.cfg** and **/mnt/sys/etc/sysconfig/portscan-whitelist.cfg**
- Whitelist for ports with machine manufacturer-specific functions, e.g. for Python and DNC applications: **/mnt/plc/etc/sysconfig/portscan-whitelist.cfg**
- Whitelist for ports with customer-specific functions: **/mnt/tnc/etc/sysconfig/portscan-whitelist.cfg**

For each entry the whitelist contains the type of port (TCP/UDP), the port number, the offering program and optional comments. If the automatic port scan function is active, only ports listed in the whitelists can be open. Non-listed ports trigger a notification window.

The result of the scan is saved to a log file (LOG:/portscan/scanlog and LOG:/portscan/scanlogevil), and if new ports are found that are not listed in one of the whitelists these are displayed.

#### Manually starting Portscan

Proceed as follows to manually start the Portscan:

- ▶ Open the task bar at the bottom edge of the screen  
**Further Information:** "Window manager", page 99
- ▶ Press the green HEIDENHAIN button to open the JH menu
- ▶ Select the **Diagnostic** menu item
- ▶ Select the **Portscan** menu item
- > The control opens the **HeRos Portscan** pop-up window.
- ▶ Press the **Start** key

#### Cyclically starting Portscan

Proceed as follows to automatically start the Portscan cyclically:

- ▶ Open the task bar at the bottom edge of the screen  
**Further Information:** "Window manager", page 99
- ▶ Press the green HEIDENHAIN button to open the JH menu
- ▶ Select the **Diagnostic** menu item
- ▶ Select the **Portscan** menu item
- > The control opens the **HeRos Portscan** pop-up window.
- ▶ Press the **Automatic update on** key
- ▶ Set the time interval with the slider



## Remote Service

Together with the Remote Service Setup Tool, the TeleService from HEIDENHAIN enables encrypted end-to-end connections to be established between a service computer and the machine tool.

To enable the HEIDENHAIN control to communicate with the HEIDENHAIN server it must be connected to the internet.

**Further Information:** "Configuring the TNC", page 715

In its basic state the firewall of the control blocks all incoming and outgoing connections. For this reason the firewall must be deactivated for the duration of the service session.


### Setting up the control

To set up the control, proceed as follows:

- ▶ Open the task bar at the bottom edge of the screen  
**Further Information:** "Window manager", page 99
- ▶ Press the green HEIDENHAIN button to open the JH menu
- ▶ Select the **Settings** menu item
- ▶ Select the **Firewall** menu item
- ▶ The control displays the **Firewall/SSH settings** dialog
- ▶ Deactivate the firewall by removing the **Active** option in the **Firewall** tab.
- ▶ Press the **Apply** key to save the settings
- ▶ Press the **OK** button
- ▶ The firewall is disabled.



Do not forget to activate the firewall again after the end of the service session.



### Automatic installation of a session certificate

With an NC software installation a temporary certificate is automatically installed on the control. An installation, also in the form of an update, may only be carried out by a service technician from the machine tool builder.

### Manual installation of a session certificate

A new certificate must be installed if no valid session certificate is installed on the control. Clarify which certificate is needed with your service employee. He will then provide you with a valid certificate file if necessary.


To install the certificate on the control proceed as follows:

- ▶ Open the task bar at the bottom edge of the screen  
**Further Information:** "Window manager", page 99
- ▶ Press the green HEIDENHAIN button to open the JH menu
- ▶ Select the **Settings** menu item
- ▶ Select the **Network** menu item
- > The control displays the **Network settings** dialog
- ▶ Select the **Internet** tab. The settings in the **Remote maintenance** field are configured by the machine tool builder.
- ▶ Press the **Add** key and select the file from the selection menu
- ▶ Press the **Open** key
- > The certificate is opened.
- ▶ Press the **OK** soft key
- ▶ It may be necessary to restart the control to load the settings

### Launching the service session

Proceed as follows to start the service session:

- ▶ Open the task bar at the bottom edge of the screen
- ▶ Press the green HEIDENHAIN button to open the JH menu
- ▶ Select the **Diagnostic** menu item
- ▶ Select the **RemoteService** menu item
- ▶ Enter the **Session key** of the machine tool builder



## SELinux security software

**SELinux** is an extension for Linux-based operating systems. SELinux is an additional security software package based on Mandatory Access Control (MAC) and protects the system against the running of unauthorized processes or functions and therefore protects against viruses and other malware.

MAC means that each action must be specifically permitted otherwise the TNC will not run it. The software is intended as protection in addition to the normal access restriction in Linux. Certain processes and actions can only be executed if the standard functions and access control of SELinux permit it.



The SELinux installation of the TNC is prepared to permit running of only those programs installed with the HEIDENHAIN NC software. Other programs cannot be run with the standard installation.

The access control of SELinux under HEROS 5 is regulated as follows:

- The TNC runs only those applications installed with the HEIDENHAIN NC software
- Files in connection with the security of the software (SELinux system files, HEROS 5 boot files, etc.) may only be changed by programs that are selected explicitly
- New files generated by other programs must never be executed
- USB data carriers cannot be deselected
- There are only two processes that are permitted to execute new files:
  - Starting a software update: A software update from HEIDENHAIN can replace or change system files
  - Starting the SELinux configuration: The configuration of SELinux is usually password-protected by your machine manufacturer; refer here to the relevant machine manual



HEIDENHAIN recommends activating SELinux because it provides additional protection against attacks from outside.

## VNC

Use the **VNC** function to configure the behavior of the various VNC clients. This includes, for example, operation via soft keys, mouse and the ASCII keyboard.

The control provides the following options:


- List of permitted clients (IP address or name)
- Password for the connection
- Additional server options
- Additional settings for assigning the focus



For multiple clients or operating units, the focus assignment procedure depends on the design and the operating situation of the machine.

This function must be adapted to the TNC by your machine manufacturer.

Refer to your machine manual.



### Opening the VNC settings

Proceed as follows to open the VNC settings:




- ▶ Open the task bar at the bottom edge of the screen
  - Further Information:** "Window manager", page 99
- ▶ Press the green HEIDENHAIN button to open the JH menu
- ▶ Select the **Settings** menu item
- ▶ Select the **VNC** menu item
- ▶ The control opens the **VNC Settings** pop-up window.

The control provides the following options:

- Add: Add new VNC viewer/client
- Remove: Deletes the selected client Only possible with manually entered clients.
- Edit: Edit the configuration of the selected client
- Update: Updates the display. Required with connection attempts during which the dialog is open.

### VNC settings

Dialog	Option	Meaning
VNC participant settings	<b>Computer name:</b>	IP address or computer name
	<b>VNC:</b>	Connection of the client to the VNC viewer
	<b>VNC Focus</b>	The client participates in the focus assignment
	<b>Model</b>	<ul style="list-style-type: none"> <li>■ Manual Manually entered client</li> <li>■ Denied This client is not permitted to connect</li> <li>■ TeleService/IPC 61xx Client via TeleService connection</li> <li>■ DHCP Other computer that obtains an IP address from this computer</li> </ul>

Dialog	Option	Meaning
Firewall warning		Warnings and information about if the VNC protocol has not been authorized for all VNC clients due to firewall settings on the control. <b>Further Information:</b> "Firewall", page 721.
Global settings	<b>Enabling TeleService/IPC 61xx</b>	Connection via TeleService/IPC 61xx is always permitted
	<b>Password verification</b>	The client must enter a password for verification. If this option is active, the password must be entered when the connection is established.
Enabling other VNC	<b>Deny</b>	Access generally denied to all other VNC clients.
	<b>Inquire</b>	During connection attempts a corresponding dialog is opened.
	<b>Permitted</b>	Access is generally granted to all other VNC clients.
VNC Focus Settings	<b>Enabling VNC focus</b>	Enable focus assignment for this system. Otherwise there is no central focus assignment. In the default setting, the focus is actively reassigned by the owner of the focus by clicking the focus symbol. This means that the owner of the focus must first release the focus by clicking the focus symbol before any other client can retrieve the focus.
	<b>Enabling concurrency VNC focus</b>	In the default setting, the focus is actively reassigned by the owner of the focus by clicking the focus symbol. This means that the owner of the focus must first release the focus by clicking the focus symbol before any other client can retrieve the focus. If concurrency focus is selected, any client can retrieve the focus at any time without having to wait for the current owner of the focus to release it.
	<b>Timeout Concurrency VNC Focus</b>	Time period within which the current owner of the focus can object to the focus being withdrawn or can prevent the reassignment of the focus. If a client requests the focus, a dialog in which the reassignment of focus can be refused appears on all clients' screens.
Focus symbol		Current status of VNC focus on the respective client: Focus is owned by other client. Mouse and keyboard are disabled.
		Current status of VNC focus on respective client: Focus is owned by current client. Entries can be made.
		Current status of VNC focus on the respective client: Request by the owner of the focus to give the focus to another client. Mouse and keyboard are disabled until the focus is assigned unambiguously.

If **Enable concurrency VNC focus** is selected, a pop-up window appears. This dialog makes it possible to refuse that the focus be given to the requesting client. If this does not occur, the focus changes to the requesting client after the set time limit.

### Backup and restore

With functions **NC/PLC Backup** and **NC/PLC Restore** you can save and restore single directories or the complete TNC drive. You can save the backup files locally on a network drive or to USB data carriers.

The backup program generates a **\*. tncbck** file that can also be processed by the PC tool TNCbackup (part of TNCremo). The restore program can restore these files as well as those from existing TNCbackup programs. If a **\*. tncbck** file is selected in the file manager of the control, the program **NC/PLC Restore** is automatically launched.

Backup and restore is subdivided into several steps. Navigate between these steps with the **FORWARD** and **BACK** soft keys. Specific actions for steps are selectively displayed as soft keys.

#### Open NC/PLC Backup or NC/PLC Restore

Proceed as follows to open the functions:

- ▶ Open the task bar at the bottom edge of the screen  
**Further Information:** "Window manager", page 99
- ▶ Press the green HEIDENHAIN button to open the JH menu
- ▶ Select the **Tools** menu item
- ▶ Open the **NC/PLC Backup** or **NC/PLC Restore** menu item
- > The control opens the pop-up window.

#### Backing up data

To backup data from the control, proceed as follows:

- ▶ Select **NC/PLC Backup**
- ▶ Select the type
  - Back up the **TNC** partition
  - Back up the directory tree: Select the directory for backup in the file management
  - Backup machine configuration (for machine tool builders only)
  - Complete backup (for machine tool builders only)
  - Comment: Freely configurable comment for the backup
- ▶ Select the next step with the **FORWARD** soft key
- ▶ Stop the control if required with the **STOP NC SOFTWARE** soft key
- ▶ Define the exclusion rules
  - User preset rules
  - Write own rules to the table
- ▶ Select the next step with the **FORWARD** soft key
- > The control generates a list of files for backing up.
- ▶ Check the list. Deselect files if necessary.
- ▶ Select the next step with the **FORWARD** soft key
- ▶ Enter the name of the backup file
- ▶ Select the storage path
- ▶ Select the next step with the **FORWARD** soft key
- > The control generates the backup file.
- ▶ Confirm with the **OK** soft key
- > The control concludes the backup process and restarts the NC software.

## Restore data



### Caution: Data may be lost!

The control overwrites existing files without a confirmation prompt.

To restore the data proceed as follows:

- ▶ Select **NC/PLC Restore**
- ▶ Select the archive to be restored
- ▶ Select the next step with the **FORWARD** soft key
- > The control generates a list of files for restoring.
- ▶ Check the list. Deselect files if necessary.
- ▶ Select the next step with the **FORWARD** soft key
- ▶ Stop the control if required with the **STOP NC SOFTWARE** soft key
- ▶ Extract the archive
- > The control restores the files.
- ▶ Confirm with the **OK** soft key
- > The control restarts the NC software.

## 2.6 Remote Desktop Manager (option 133)

### 2.6 Remote Desktop Manager (option 133)

#### Introduction

The Remote Desktop Manager enables you to display external computer units on the TNC screen that are connected via Ethernet and to operate them over the TNC. You can also start programs specifically under HeROS or display web pages of an external server.

The following connection options are available:

- **Windows Terminal Server (RDP):** Displays the desktop of a remote Windows computer on the control
- **Windows Terminal Server (RemoteFX):** Displays the desktop of a remote Windows computer on the control
- **VNC:** Connection to an external computer (e.g. HEIDENHAIN-IPC). Displays the desktop of a remote Windows or Unix computer on the control
- **Switch-off/restart of a computer:** Available only to authorized specialists
- **World Wide Web:** Available only to authorized specialists
- **SSH:** Available only to authorized specialists
- **XDMCP:** Available only to authorized specialists
- **User-defined connection:** Available only to authorized specialists



HEIDENHAIN assures a functioning connection between HeROS 5 and the IPC 6341. HEIDENHAIN cannot guarantee the correct function of any other combinations or connections to external devices.



## Configuring connections – Windows Terminal Service

### Configuring an external computer



You do not need additional software for your external computer for connecting to the Windows Terminal Service.

Proceed as follows to configure the external computer, e.g. in the Windows 7 operating system:

- ▶ After pressing the Windows start button select the menu item **System control** via the task bar
- ▶ Select the **System** menu item
- ▶ Select the **Advanced system settings** menu item
- ▶ Select the **Remote** tab
- ▶ In the **Remote support** area, activate the function **Permit remote support connection with this computer**
- ▶ In the **Remote desktop** area, activate the function **Permit connections from computers on which any version of remote desktop is installed**
- ▶ Confirm the settings via the **OK** button

### Configuring the TNC



Depending on the operating system of your external computer and the protocol used in accordance with this, select either **Windows Terminal Service (RDP)** or **Windows Terminal Service (RemoteFX)**.

Configure the TNC as follows:

- ▶ After pressing the green HEIDENHAIN button, select the menu item **Remote Desktop Manager** via the task bar
- ▶ Press the **New connection** button in the **Remote Desktop Manager** window
- ▶ Select the menu item **Windows Terminal Service (RDP)** or **Windows Terminal Service (RemoteFX)**
- ▶ Specify the required connection information in the **Edit the connection** window

## 2.6 Remote Desktop Manager (option 133)

Setting	Meaning	Input
<b>Connection name</b>	Name of the connection in the Remote Desktop Manager	Required
<b>Restarting after end of connection</b>	Behavior with terminated connection: <ul style="list-style-type: none"> <li>■ Always restart</li> <li>■ Never restart</li> <li>■ Always after an error</li> <li>■ Ask after an error</li> </ul>	Required
<b>Automatic starting upon login</b>	Connection automatically established during control power-up	Required
<b>Add to favorites</b>	Connection icon in the task bar: <ul style="list-style-type: none"> <li>■ Double click with left mouse button: The control starts the connection</li> <li>■ Single click with left mouse button: The control changes to the desktop of the connection</li> <li>■ Single click with right mouse button: The control displays the connection menu</li> </ul>	Required
<b>Move to the following workspace</b>	Number of desktop for the connection, whereby desktops 0 and 1 are reserved for the NC software	Required
<b>Release USB mass memory</b>	Enable access to connected USB mass memory	Required
<b>Computer</b>	Host name or IP address of the external computer	Required
<b>User name</b>	Name of the user	Required
<b>Password</b>	User password	Required
<b>Windows domain</b>	Domain of the external computer	Required
<b>Full screen mode or user-defined window size</b>	Size of the connection window	Required
Entries in the <b>Advanced options</b> area	Available only to authorized specialists	Optional

## Configuring the connection – VNC

### Configuring an external computer



You do not need an additional VNC server for your external computer for connecting to VNC.  
Install and configure the VNC server, e.g. the TightVNC server, before configuring the TNC.

### Configuring the TNC

Configure the TNC as follows:

- ▶ Select the **Remote Desktop Manager** menu item via the task bar
- ▶ Press the **New connection** button in the **Remote Desktop Manager** window
- ▶ Select the **VNC** menu item
- ▶ Specify the required connection information in the **Edit the connection** window

Setting	Meaning	Input
<b>Connection name:</b>	Name of the connection in the Remote Desktop Manager	Required
<b>Restarting after end of connection:</b>	Behavior with terminated connection: <ul style="list-style-type: none"> <li>■ Always restart</li> <li>■ Never restart</li> <li>■ Always after an error</li> <li>■ Ask after an error</li> </ul>	Required
<b>Automatic starting upon login</b>	Connection automatically established during control power-up	Required
<b>Add to favorites</b>	Connection icon in the task bar: <ul style="list-style-type: none"> <li>■ Double click with left mouse button: The control starts the connection</li> <li>■ Single click with left mouse button: The control changes to the desktop of the connection</li> <li>■ Single click with right mouse button: The control displays the connection menu</li> </ul>	Required
<b>Move to the following workspace</b>	Number of desktop for the connection, whereby desktops 0 and 1 are reserved for the NC software	Required
<b>Release USB mass memory</b>	Permit access to connected USB mass memory	Required
<b>Calculator</b>	Host name or IP address of the external computer	Required
<b>Password</b>	Password for connecting to the VNC server	Required

## 2.6 Remote Desktop Manager (option 133)

Setting	Meaning	Input
<b>Full-screen mode or User-defined window size:</b>	Size of the connection window	Required
<b>Permit further connections (share)</b>	Enable access to the VNC server also by other VNC connections	Required
<b>View only</b>	The external computer cannot be operated in display mode	Required
Entries in the <b>Advanced options</b> area	Available only to authorized specialists	Optional

**Starting and stopping the connection**

Once a connection has been configured, it is shown as an icon in the Remote Desktop Manager window. Click the connection icon with the right mouse key to open a menu in which the display can be started and stopped.

Use the right DIADUR key on the keyboard to change to Desktop 3 and back to the TNC interface. You can also use the task bar to get to this desktop.

If the desktop of the external connection or the external computer is active, all inputs from the mouse and the keyboard are transmitted there.

All connections are canceled automatically when the HEROS 5 operating system is shut down. Please note, however, that only the connection is canceled, whereas the external computer or the external system is not shut down automatically.

## 2.7 Accessories: HEIDENHAIN 3-D touch probes and electronic handwheels

### 3-D touch probes

The various HEIDENHAIN 3-D touch probes enable you to:

- Automatically align workpieces
- Quickly and precisely set datums
- Measure the workpiece during program run
- Measure and inspect tools



All of the cycle functions (touch probe cycles and fixed cycles) are described in the Cycle Programming User's Manual. If you need this user's manual, please contact HEIDENHAIN if required. ID: 892905-xx

#### The triggering touch probes TS 220, TS 440, TS 444, TS 640 and TS 740

These touch probes are particularly effective for automatic workpiece alignment, datum setting and workpiece measurements. The TS 220 transfers the trigger signal via a cable and is also a cost-effective alternative if you have to carry out digitizing occasionally.

The TS 640 and the smaller TS 440 feature wireless infrared transmission of the triggering signals to the TNC. This makes them highly convenient for use on machines with automatic tool changers.

Principle of operation: HEIDENHAIN triggering touch probes feature a wear resisting optical switch that generates an electrical signal as soon as the stylus is deflected. The signal produced is transmitted to the control, which stores the current position of the touch probe as the actual value.

#### TT 140 tool touch probe for tool measurement

The TT 140 is a triggering 3-D touch probe for tool measurement and inspection. The TNC provides three cycles for this touch probe with which you can measure the tool length and radius either with the spindle rotating or stationary. The TT 140 features a particularly rugged design and a high degree of protection, which make it insensitive to coolants and swarf. The triggering signal is generated by a wear-resistant and highly reliable optical switch.



## Introduction

### 2.7 Accessories: HEIDENHAIN 3-D touch probes and electronic handwheels

#### HR electronic handwheels

Electronic handwheels facilitate moving the axis slides precisely by hand. A wide range of traverses per handwheel revolution is available. Apart from the HR130 and HR150 integral handwheels, HEIDENHAIN also offers the HR 410, HR 520 and HR 550FS portable handwheels.



Several electronic handwheels can also be connected simultaneously and used alternatively on controls with the (**HSCI**: HEIDENHAIN Serial Controller Interface) serial interface for control components.

Configuration is performed via the machine tool builder.



# 3

**Fundamentals, file  
management**

## 3 Fundamentals, file management

### 3.1 Fundamentals

#### 3.1 Fundamentals


##### Position encoders and reference marks

The machine axes are equipped with position encoders that register the positions of the machine table or tool. Linear axes are usually equipped with linear encoders, rotary tables and tilting axes with angle encoders.

When a machine axis moves, the corresponding position encoder generates an electrical signal. The TNC evaluates this signal and calculates the precise actual position of the machine axis.

If there is a power interruption, the calculated position will no longer correspond to the actual position of the machine slide. To recover this association, incremental position encoders are provided with reference marks. The scales of the position encoders contain one or more reference marks that transmit a signal to the TNC when they are crossed over. From that signal the TNC can re-establish the assignment of displayed positions to machine positions. For linear encoders with distance-coded reference marks, the machine axes need to move by no more than 20 mm, for angle encoders by no more than 20°.

With absolute encoders, an absolute position value is transmitted to the control immediately upon switch-on. In this way the assignment of the actual position to the machine slide position is re-established directly after switch-on.





## reference systems

For the control to traverse an axis according to a defined path it requires a **reference system**.

A paraxially mounted linear encoder on a machine tool serves as a simple reference system for linear axes. The linear encoder represents a **number ray**, a unidimensional coordinate system.

To approach a point on the **plane**, the control requires two axes and therefore a reference system with two dimensions.

To approach a point in the **space**, the control requires three axes and therefore a reference system with three dimensions. If these three axes are configured perpendicular to each other this creates a so-called **three-dimensional Cartesian coordinate system**.



According to the right-hand rule the fingertips point in the positive directions of the three main axes.

For a point to be uniquely determined in space, a **coordinate origin** is needed in addition to the configuration of the three dimensions. The common intersection serves as the coordinate origin in a 3-D coordinate system. This intersection has the coordinates **X+0, Y+0** and **Z+0**.

The control must differentiate between various reference systems for it to always perform a tool change at the same position for example, or carry out a machining operation always related to the current workpiece position.




The control differentiates between the following reference systems:

- Machine coordinate system M-CS:  
**M**achine **C**oordinate **S**ystem
- Basic coordinate system B-CS:  
**B**asic **C**oordinate **S**ystem
- Workpiece coordinate system W-CS:  
**W**orkpiece **C**oordinate **S**ystem
- Working plane coordinate system WPL-CS:  
**W**orking **P**lane **C**oordinate **S**ystem
- Input coordinate system I-CS:  
**I**nternal **C**oordinate **S**ystem
- Tool coordinate system T-CS:  
**T**ool **C**oordinate **S**ystem



All reference systems build up on each other. They are subject to the kinematic chain of the specific machine tool.

The machine coordinate system is the reference system.



## 3 Fundamentals, file management

### 3.1 Fundamentals

#### Machine coordinate system M-CS


The machine coordinate system corresponds to the description of kinematics and therefore to the actual mechanical design of the machine tool.

Because the mechanics of a machine tool never precisely correspond to a Cartesian coordinate system, the machine coordinate system consists of several one-dimensional coordinate systems. These one-dimensional coordinate systems correspond to the physical machine axes that are not obligatorily perpendicular to each other.

The position and orientation of the one-dimensional coordinate systems are defined with the aid of translations and rotations based on the spindle tip in the description of kinematics.

The position of the coordinate origin, the so-called machine datum, is defined by the machine manufacturer during machine configuration. The values in the machine configuration define the zero positions of the encoders and the corresponding machine axes. The machine zero point is not obligatorily located in the theoretical intersection of the physical axes. It can therefore also be located outside of the traverse range.



Because the machine configuration values cannot be modified by the user, the machine coordinate system is used for determining constant positions, e.g. the tool change point.



Machine zero point MZP:  
**Machine Zero Point**

- ▶ In the **Positioning with manl.data input** operating mode, run an NC block with **L IY+10**
- ▶ The control determines the required axis nominal values from the defined values.
- ▶ During positioning the control moves the **Y and Z** machine axes.
- ▶ The **RFACTL** and **REF NOML** displays show movements of the Y axis and Z axis in the machine coordinate system.
- ▶ The **ACTL.** and **NOML.** displays only show one movement of the Y axis in the input coordinate system.
- ▶ In the **Positioning with manl.data input** operating mode run an NC block with **L IY-10 M91**
- ▶ The control determines the required axis nominal values from the defined values.
- ▶ During positioning the control only moves the **Y** machine axis.
- ▶ The **RFACTL** and **REF NOML** displays only show one movement of the Y axis in the machine coordinate system.
- ▶ The **ACTL.** and **NOML.** displays show movements of the Y axis and Z axis in the input coordinate system.

Soft key	Application
----------	-------------



**Manual operation**

Manual operation

	NO	4	DOO	A_OFFSET	B_OFFSET	C_OFFSET	U_OFFSET	V_OFFSET	W_OFFSET
1	0	0	0	0	0	0	0	0	
2	0	0	0	0	0	0	0	0	
3	0	0	0	0	0	0	0	0	
4	0	0	0	0	0	0	0	0	
5	0	0	0	0	0	0	0	0	
6	0	0	0	0	0	0	0	0	
7	0	0	0	0	0	0	0	0	
8	0	0	0	0	0	0	0	0	
9	0	0	0	0	0	0	0	0	

Text width 16 TMC: /table/preset.pr

1% X [Nm] P1 -T1

1% Y [Nm] S1 LIMIT ?

X +0.000 A +0.000

Y +0.000 C +0.000

Z +100.000

Mode: NC/M T 23 S 3800 F Resin Int 100% M 1/3

CHANGE PRESET BASIC TRANSFORM JOINTS ACTIVATE PRESET

# 3 Fundamentals, file management

## 3.1 Fundamentals

### Basic coordinate system B-CS


The basic coordinate system is a 3-D Cartesian coordinate system. Its coordinate origin is the end of the kinematics model.

The orientation of the basic coordinate system in most cases corresponds to that of the machine coordinate system. There may be exceptions to this if a machine manufacturer uses additional kinematic transformations.

The kinematic model and thus the position of the coordinate origin for the basic coordinate system is defined by the machine manufacturer in the machine configuration. The user cannot modify the machine configuration values.

The basic coordinate system serves to determine the position and orientation of the workpiece coordinate system.



Soft key	Application
----------	-------------



The user determines the position and orientation of the workpiece coordinate system by using a 3-D touch probe for example. The control saves the values determined related to the basic coordinate system as **BASE TRANSFORM.** values in the preset table.



The machine manufacturer configures the **BASE TRANSFORM.** columns of the preset table in accordance with the machine.




**Further Information:** "Datum management with the preset table", page 599

### Workpiece coordinate system W-CS

The workpiece coordinate system is a 3-D Cartesian coordinate system. Its coordinate origin is the active reference point.

The position and orientation of the workpiece coordinate system depend on the **BASE TRANSFORM.** values of the active preset line.

#### Soft key Application



The user determines the position and orientation of the workpiece coordinate system by using a 3-D touch probe for example. The control saves the values determined related to the basic coordinate system as **BASE TRANSFORM.** values in the preset table.

**Further Information:** "Datum management with the preset table", page 599

In the workpiece coordinate system the user defines the position and orientation of the working plane coordinate system with use of transformations.

Transformations in the workpiece coordinate system:

- **3D ROT** functions
  - **PLANE** functions
  - Cycle 19 **WORKING PLANE**
- Cycle 7 **DATUM SHIFT**  
(shifting **before** tilting the working plane)
- Cycle 8 **MIRRORING**  
(mirroring **before** tilting the working plane)






The result of transformations built up on each other depends on the programming sequence.



Without active transformations in the workpiece coordinate system, the position and orientation of the working plane coordinate system and workpiece coordinate system are identical.

There are no transformations in the workpiece coordinate system on 3-axis machine tools or with pure 3-axis machining. The **BASE TRANSFORM.** values of the active preset line are directly effective on the working plane coordinate system with this assumption.

Other transformations are of course possible in the working plane coordinate system. **Further Information:** "Working plane coordinate system WPL-CS", page 124



## 3 Fundamentals, file management

### 3.1 Fundamentals

#### Working plane coordinate system WPL-CS

The working plane coordinate system is a 3-D Cartesian coordinate system.

The position and orientation of the working plane coordinate system depend on the active transformations in the workpiece coordinate system.






Without active transformations in the workpiece coordinate system, the position and orientation of the working plane coordinate system and workpiece coordinate system are identical.

There are no transformations in the workpiece coordinate system on 3-axis machine tools or with pure 3-axis machining. The **BASE TRANSFORM.** values of the active preset line are directly affective on the working plane coordinate system with this assumption.

In the working plane coordinate system the user defines the position and orientation of the input coordinate system with use of transformations.

Transformations in the working plane coordinate system:

- Cycle 7 **DATUM SHIFT**
- Cycle 8 **MIRRORING**
- Cycle 10 **ROTATION**
- Cycle 11 **SCALING FACTOR**
- Cycle 26 **AXIS-SPECIFIC SCALING**
- **PLANE RELATIVE**





As a **PLANE** function, the **PLANE RELATIVE** is effective in the workpiece coordinate system and aligns the working plane coordinate system.  
The values of additive tilting always relate to the current working plane coordinate system.



The result of transformations built up on each other depends on the programming sequence.



Without active transformations in the working plane coordinate system, the position and orientation of the input coordinate system and working plane coordinate system are identical.  
There are also no transformations in the workpiece coordinate system on 3-axis machine tools or with pure 3-axis machining. The **BASE TRANSFORM.** values of the active preset line are directly affective on the input coordinate system with this assumption.

## 3 Fundamentals, file management

### 3.1 Fundamentals

#### Input coordinate system I-CS

The input coordinate system is a 3-D Cartesian coordinate system. The position and orientation of the input coordinate system depend on the active transformations in the working plane coordinate system.



Without active transformations in the working plane coordinate system, the position and orientation of the input coordinate system and working plane coordinate system are identical.

There are also no transformations in the workpiece coordinate system on 3-axis machine tools or with pure 3-axis machining. The **BASE TRANSFORM.** values of the active preset line are directly affective on the input coordinate system with this assumption.

With the aid of positioning blocks in the input coordinate system, the user defines the position of the tool and therefore the position of the tool coordinate system.

Positioning blocks in input coordinate system:

- Paraxial positioning blocks
- Positioning blocks with Cartesian or polar coordinates
- Positioning blocks with Cartesian coordinates and surface normal vectors

**7 X+48 R+**

**7 L X+48 Y+102 Z-1.5 R0**

**7 LN X+48 Y+102 Z-1.5 NX-0.04658107 NY0.00045007  
NZ0.8848844 R0**






The position of the tool coordinate system is determined by the Cartesian coordinates X, Y and Z also for positioning blocks with surface normal vectors.

In conjunction with 3-D tool compensation, the position of the tool coordinate system can be shifted along the surface normal vectors.



Orientation of the tool coordinate system can be performed in various reference systems.

**Further Information:** "Tool coordinate system T-CS", page 127



A contour referencing the input coordinate system origin can be simply transformed at random.



### Tool coordinate system T-CS

The tool coordinate system is a 3-D Cartesian coordinate system. Its coordinate origin is the tool reference point. The values of the tool table, **L** and **R** with milling tools and **ZL**, **XL** and **YL** with turning tools, reference this point.

**Further Information:** "Enter tool data into the table", page 206 and "Tool data", page 559



For dynamic collision monitoring (option 40) to correctly monitor the tool, the values in the tool table must correspond to the actual dimensions of the tool.

In accordance with the values from the tool table, the coordinate origin of the tool coordinate system is shifted to the tool center point TCP. TCP stands for **T**ool **C**enter **P**oint.

If the NC program does not reference the tool tip, the tool center point must be shifted. The required shift is implemented in the NC program using the delta values during a tool call.



The position of the TCP as shown in the diagram is obligatory in conjunction with the 3-D tool compensation.



With the aid of positioning blocks in the input coordinate system, the user defines the position of the tool and therefore the position of the tool coordinate system.

With active **TCPM** function or active miscellaneous function **M128** the orientation of the tool coordinate system depends on the current tool angle of inclination.

The user defines the tool's angle of inclination either in the machine coordinate system or in the working plane coordinate system.

Tool angle of inclination in the machine coordinate system:

```
7 L X+10 Y+45 A+10 C+5 R0 M128
```




Tool angle of inclination in the working plane coordinate system:

```
6 FUNCTION TCPM F TCP AXIS SPAT PATHCTRL AXIS
```

```
7 L A+0 B+45 C+0 R0 F2500
```

```
7 LN X+48 Y+102 Z-1.5 NX-0.04658107 NY0.00045007
  NZ0.8848844 TX-0.08076201 TY-0.34090025 TZ0.93600126
  R0 M128
```

```
7 LN X+48 Y+102 Z-1.5 NX-0.04658107 NY0.00045007
  NZ0.8848844 R0 M128
```



## 3 Fundamentals, file management


### 3.1 Fundamentals



With the shown positioning blocks with vectors, 3-D tool compensation is possible with compensation values **DL**, **DR** and **DR2** from the **TOOL CALL** block. The methods of function of the compensation values depend on the type of tool.

The control detects the various tool types with the columns **L**, **R** and **R2** of the tool table:

- $R2_{TAB} + DR2_{TAB} + DR2_{PROG} = 0$   
→ end mill
- $R2_{TAB} + DR2_{TAB} + DR2_{PROG} = R_{TAB} + DR_{TAB} + DR_{PROG}$   
→ radius cutter or ball cutter
- $0 < R2_{TAB} + DR2_{TAB} + DR2_{PROG} < R_{TAB} + DR_{TAB} + DR_{PROG}$   
→ toroid cutter or toroidal cutter



Without the **TCPM** function or miscellaneous function **M128**, orientation of the tool coordinate system and input coordinate system is identical.

## Designation of the axes on milling machines

The X, Y and Z axes on your milling machine are also referred to as tool axis, principal axis (1st axis) and secondary axis (2nd axis). The assignment of the tool axis is decisive for the assignment of the principal and secondary axes.


Tool axis	Principal axis	Secondary axis
X	Y	Z
Y	Z	X
Z	X	Y

## Polar coordinates

If the production drawing is dimensioned in Cartesian coordinates, you also write the NC program using Cartesian coordinates. For parts containing circular arcs or angles it is often simpler to give the dimensions in polar coordinates.

While the Cartesian coordinates X, Y and Z are three-dimensional and can describe points in space, polar coordinates are two-dimensional and describe points in a plane. Polar coordinates have their datum at a circle center (CC), or pole. A position in a plane can be clearly defined by the:


- Polar Radius, the distance from the circle center CC to the position, and the
- Polar Angle, the value of the angle between the angle reference axis and the line that connects the circle center CC with the position.



## Setting the pole and the angle reference axis

The pole is set by entering two Cartesian coordinates in one of the three planes. These coordinates also set the reference axis for the polar angle PA.

Coordinates of the pole (plane)	Reference axis of the angle
X/Y	+X
Y/Z	+Y
Z/X	+Z



# 3 Fundamentals, file management

## 3.1 Fundamentals


### Absolute and incremental workpiece positions

#### Absolute workpiece positions

Absolute coordinates are position coordinates that are referenced to the datum of the coordinate system (origin). Each position on the workpiece is unambiguously defined by its absolute coordinates.

Example 1: Holes dimensioned in absolute coordinates

Hole 1	Hole 2	Hole 3
X = 10 mm	X = 30 mm	X = 50 mm
Y = 10 mm	Y = 20 mm	Y = 30 mm



#### Incremental workpiece positions

Incremental coordinates are referenced to the last programmed nominal position of the tool, which serves as the relative (imaginary) datum. When you write an NC program in incremental coordinates, you thus program the tool to move by the distance between the previous and the subsequent nominal positions. This is why they are also referred to as chain dimensions.

To program a position in incremental coordinates, enter the function "I" before the axis.

Example 2: Holes dimensioned in incremental coordinates

#### Absolute coordinates of hole 4

X = 10 mm

Y = 10 mm

#### Hole 5, with respect to 4


X = 20 mm

Y = 10 mm

#### Hole 6, with respect to 5

X = 20 mm


Y = 10 mm



#### Absolute and incremental polar coordinates

Absolute coordinates always refer to the pole and the angle reference axis.

Incremental polar coordinates always refer to the last programmed nominal position of the tool.



## Selecting the datum

A production drawing identifies a certain form element of the workpiece, usually a corner, as the absolute datum. When setting the datum, you first align the workpiece along the machine axes, and then move the tool in each axis to a defined position relative to the workpiece. Set the display of the TNC either to zero or to a known position value for each position. This establishes the reference system for the workpiece, which will be used for the TNC display or your machining program.

If the production drawing is dimensioned in relative datums, simply use the coordinate transformation cycles.

**Further information:** Cycle Programming User's Manual



If the production drawing is not dimensioned for NC, set the datum at a position or corner on the workpiece from which the dimensions of the remaining workpiece positions can be measured.

The fastest, easiest and most accurate way of setting the datum is by using a 3-D touch probe from HEIDENHAIN.

**Further Information:** "Datum setting with a 3-D touch probe ", page 629

### Example

The workpiece drawing shows holes (1 to 4), whose dimensions are shown with respect to an absolute datum with the coordinates  $X=0$   $Y=0$ . The coordinates of holes 5 to 7 refer to the relative datum with the absolute coordinates  $X=450$   $Y=750$ . By using the **ZERO POINT DISPL.** cycle you can shift the datum temporarily to the position  $X=450$ ,  $Y=750$  and program the holes (5 to 7) without further calculations.



## 3 Fundamentals, file management

### 3.2 Opening programs and entering

### 3.2 Opening programs and entering

#### Structure of an NC program in HEIDENHAIN Klartext

A machining program consists of a series of NC blocks. The illustration on the right shows the elements of a block.

The TNC numbers the blocks of a part program in ascending sequence.

The first block of a program is identified by **BEGIN PGM**, the program name and the active unit of measure.

The subsequent blocks contain information on:


- The workpiece blank
- Tool calls
- Approaching a safe position
- Feed rates and spindle speeds, as well as
- Path contours, cycles and other functions

The last block of a program is identified by **END PGM**, the program name and the active unit of measure.



After each tool call, HEIDENHAIN recommends always traversing to a safe position from which the TNC can position the tool for machining without causing a collision!

#### Block






## Define the blank: BLK FORM

Immediately after initiating a new program, you define a cuboid, unmachined workpiece blank. If you wish to define the blank at a later stage, press the **SPEC FCT** key, the **PROGRAM DEFAULTS** soft key, and then the **BLK FORM** soft key. The TNC needs this definition for graphic simulation.



You only need to define the workpiece blank if you wish to run a graphic test for the program!

The TNC can depict various types of blank forms.

Soft key	Function
	Define a rectangular blank
	Define a cylindrical blank
	Define a rotationally symmetric blank of any shape

### Rectangular blank

The sides of the cuboid lie parallel to the X, Y and Z axes. This blank is defined by two of its corner points:

- MIN point: the smallest X, Y and Z coordinates of the blank form, entered as absolute values.
- MAX point: the largest X, Y and Z coordinates of the blank form, entered as absolute or incremental values

### Example: Display the BLK FORM in the NC program


<b>0 BEGIN PGM NEW MM</b>	Program begin, name, unit of measure
<b>1 BLK FORM 0.1 Z X+0 Y+0 Z-40</b>	Spindle axis, MIN point coordinates
<b>2 BLK FORM 0.2 X+100 Y+100 Z+0</b>	MAX point coordinates
<b>3 END PGM NEW MM</b>	Program end, name, unit of measure

## 3.2 Opening programs and entering

### Cylindrical blank

The cylindrical blank form is defined by the dimensions of the cylinder:

- X, Y or Z: Rotation axis
- D, R: Diameter or radius of the cylinder (with positive algebraic sign)
- L: Length of the cylinder (with positive algebraic sign)
- DIST: Shifting along the rotational axis
- DI, RI: Inside diameter or inside radius for a hollow cylinder



The parameters **DIST** and **RI** or **DI** are optional and need not be programmed.

### Example: Display the BLK FORM CYLINDER in the NC program

0 BEGIN PGM NEW MM	Program begin, name, unit of measure
1 BLK FORM CYLINDER Z R50 L105 DIST+5 RI10	Spindle axis, radius, length, distance, inside radius
2 END PGM NEW MM	Program end, name, unit of measure

### Rotationally symmetric blank of any shape


You define the contour of the rotationally symmetric blank in a subprogram. Use X, Y or Z as the rotation axis.

In the workpiece blank definition you refer to the contour description:


- DIM\_D, DIM-R: Diameter or radius of the rotationally symmetrical blank form
- LBL: Subprogram with the contour description

The contour description may contain negative values in the rotation axis but only positive values in the reference axis. The contour must be closed, i.e. the contour beginning corresponds to the contour end.

If you define a rotationally symmetric blank with incremental coordinates, the dimensions are then independent of the diameter programming.



The subprogram can be designated with a number, an alphanumeric name, or a QS parameter.





## Opening programs and entering 3.2

### Example: Display the BLK FORM ROTATION in the NC program

<b>0 BEGIN PGM NEW MM</b>	Program begin, name, unit of measure
<b>1 BLK FORM ROTATION Z DIM_R LBL 1</b>	Spindle axis, manner of interpretation, subprogram number
<b>2 M30</b>	End of main program
<b>3 LBL 1</b>	Beginning of subprogram
<b>4 L X+0 Z+1</b>	Starting point of contour
<b>5 L X+50</b>	Programming in the positive direction of the principal axis
<b>6 L Z-20</b>	
<b>7 L X+70</b>	
<b>8 L Z-100</b>	
<b>9 L X+0</b>	
<b>10 L Z+1</b>	Contour end
<b>11 LBL 0</b>	End of subprogram
<b>12 END PGM NEW MM</b>	Program end, name, unit of measure

## 3 Fundamentals, file management

### 3.2 Opening programs and entering

#### Opening a new part program

You always enter a machining program in **Programming** mode. An example of program initiation:



- ▶ Operating mode: Press the **Programming** key



- ▶ To call the file manager, press the **PGM MGT** key.

Select the directory in which you wish to store the new program:

**FILE NAME = NEW.H**




- ▶ Enter the new program name and confirm your entry with the **ENT** key



- ▶ Select the unit of measure: Press the **MM** or **INCH** soft key. The TNC switches the screen layout and initiates the dialog for defining the **BLK FORM** (workpiece blank)



- ▶ Select a rectangular workpiece blank: Press the soft key for a rectangular blank form



#### WORKING PLANE IN GRAPHIC: XY



- ▶ Enter the spindle axis, e.g. **Z**

#### WORKPIECE BLANK DEF.: MINIMUM



- ▶ Enter in sequence the X, Y and Z coordinates of the MIN point and confirm each of your entries with the **ENT** key

#### WORKPIECE BLANK DEF.: MAXIMUM



- ▶ Enter in sequence the X, Y and Z coordinates of the MAX point and confirm each of your entries with the **ENT** key

#### Example: Display the BLK form in the NC program

0 BEGIN PGM NEW MM	Program begin, name, unit of measure
1 BLK FORM 0.1 Z X+0 Y+0 Z-40	Spindle axis, MIN point coordinates
2 BLK FORM 0.2 X+100 Y+100 Z+0	MAX point coordinates
3 END PGM NEW MM	Program end, name, unit of measure


The TNC automatically generates the block numbers as well as the **BEGIN** and **END** blocks.



If you do not wish to define a blank form, cancel the dialog at **Working plane in graphic: XY** using the **DEL** key.

## Programming tool movements in Klartext

To program a block, initiate the dialog by pressing a function key. In the screen headline, the TNC then asks you for all the information necessary to program the desired function.



### Example of a positioning block



- ▶ open the block

### COORDINATES ?



- ▶ **10** (enter the target coordinate for the X axis)



- ▶ **20** (enter the target coordinate for the Y axis)



- ▶ Go to the next question with **ENT**.

### RADIUS COMP.: RL/RR/NO COMP.?



- ▶ Enter **"No radius compensation"** and go to the next question with **ENT**

### FEED RATE F=? / F MAX = ENT

- ▶ **100** (enter a feed rate of 100 mm/min for this path contour)



- ▶ Go to the next question with **ENT**.

### MISCELLANEOUS FUNCTION M ?

- ▶ Enter **3** (miscellaneous function **M3** "Spindle ON").



- ▶ With the **END** key, the TNC ends this dialog.






The program-block window displays the following line:




**3 L X+10 Y+5 R0 F100 M3**

## 3 Fundamentals, file management

### 3.2 Opening programs and entering

#### Possible feed rate input

Soft key	Functions for setting the feed rate
	Rapid traverse, blockwise. Exception: If defined before an <b>APPR</b> block, <b>FMAX</b> also in effect for moving to an auxiliary point  <b>Further Information:</b> "Important positions for approach and departure", page 251
	Traverse feed rate automatically calculated in <b>TOOL CALL</b>
	Move at the programmed feed rate (unit of measure is mm/min or 1/10 inch/min). With rotary axes, the TNC interprets the feed rate in degrees/min, regardless of whether the program is written in mm or inches
	Define the feed per revolution (units in mm/1 or inch/1). Caution: In inch-programs, FU cannot be combined with M136
	Define the tooth feed (units in mm/tooth or inch/tooth). The number of teeth must be defined in the tool table in the <b>CUT</b> column.

Key	Functions for conversational guidance
	Ignore the dialog question
	End the dialog immediately
	Abort the dialog and erase the block

### Actual position capture

The TNC enables you to transfer the current tool position into the program, for example during


- Positioning-block programming
- Cycle programming

To transfer the correct position values, proceed as follows:

- Place the input box at the position in the block where you want to insert a position value



- Select the actual-position-capture function: In the soft-key row the TNC displays the axes whose positions can be transferred



- Select the axis: The TNC writes the current position of the selected axis into the active input box



In the working plane the TNC always captures the coordinates of the tool center, even though tool radius compensation is active.

In the tool axis the TNC always captures the coordinates of the tool tip and thus always takes the active tool length compensation into account.


The TNC keeps the soft-key row for axis selection active until you deactivate it by pressing the actual-position-capture key again. This behavior remains in effect even if you save the current block and open a new one with a path function key. If you select a block element in which you must choose an input alternative via soft key (e.g. for radius compensation), then the TNC also closes the soft-key row for axis selection.

The actual-position-capture function is not allowed if the tilted working plane function is active.

3.2








Opening programs and entering





Editing a program



You cannot edit a program while it is being run by the TNC in a machine operating mode.

While you are creating or editing a part program, you can select any desired line in the program or individual words in a block with the arrow keys or the soft keys:

Soft key/key	Function
	Change the position of the current block on the screen. Press this soft key to display additional NC blocks that are programmed before the current block
	Change the position of the current block on the screen. Press this soft key to display additional NC blocks that are programmed after the current block
	Move from one block to the next
	
	Select individual words in a block
	
	<p>To select a certain block, press the <b>GOTO</b> key, enter the desired block number, and confirm with the <b>ENT</b> key.</p> <p>Or: Press the <b>GOTO</b> key, enter the block number step and jump up or down the number of entered lines by pressing the <b>N LINES</b> soft key</p>

Soft key/key	Function
	<ul style="list-style-type: none"> <li>■ Set the selected word to zero</li> <li>■ Erase an incorrect number</li> <li>■ Delete the (clearable) error message</li> </ul>
	Delete the selected word
	<ul style="list-style-type: none"> <li>■ Delete the selected block</li> <li>■ Erase cycles and program sections</li> </ul>
	Insert the block that you last edited or deleted

### Inserting blocks at any desired location

- ▶ Select the block after which you want to insert a new block and initiate the dialog

### Save changes

The control normally saves changes automatically if you switch the operating mode or if you select the file manager. If you deliberately want to save changes to the program, proceed as follows:

- ▶ Select the soft-key row with the saving functions

- ▶ Press the **STORE** soft key for the TNC to save all changes made since the last time you saved the program

### Saving a program to a new file

You can save the contents of the currently active program under a different program name. Proceed as follows:

- ▶ Select the soft-key row with the saving functions

- ▶ Press the **SAVE AS** soft key: The TNC opens a window in which you can enter the directory and the new file name
- ▶ Select the target directory if required with the **SWITCH** soft key
- ▶ Enter the file name
- ▶ Confirm with the **OK** soft key or the **ENT** key, or press the **CANCEL** soft key to abort



The file saved with **SAVE AS** is now also found in the file management under **LAST FILES**.


## 3 Fundamentals, file management

### 3.2 Opening programs and entering

#### Undoing changes

You can undo all changes made since the last time you saved the program. Proceed as follows:

- ▶ Select the soft-key row with the saving functions



- ▶ Press the **CANCEL CHANGE** soft key: The TNC opens a window in which you can confirm or cancel this action
- ▶ Confirm with the **YES** key or cancel with the **ENT** key, or press the **NO** key to abort

#### Editing and inserting words

- ▶ Select a word in a block and overwrite it with the new one. The dialog is available while the word is highlighted
- ▶ To accept the change, press the **END** key

If you want to insert a word, press the horizontal arrow key repeatedly until the desired dialog appears. You can then enter the desired value.

#### Looking for the same words in different blocks



- ▶ Select a word in a block: Press the arrow key repeatedly until the desired word is highlighted



- ▶ Select a block with the arrow keys
  - Arrow down: search forwards
  - Arrow up: search backwards

The word that is highlighted in the new block is the same as the one you selected previously.




If you have started a search in a very long program, the TNC shows a progress display window. You then have the option of canceling the search via soft key.



### Marking, copying, cutting and inserting program sections

The TNC provides the following functions for copying program sections within an NC program or into another NC program:

Soft key	Function
<b>SELECT BLOCK</b>	Switch the marking function on
<b>CANCEL SELECTION</b>	Switch the marking function off
<b>CUT OUT BLOCK</b>	Cut the marked block
<b>INSERT BLOCK</b>	Insert the block that is stored in the buffer memory
<b>COPY BLOCK</b>	Copy the marked block



To copy a program section, proceed as follows:

- ▶ Select the soft key row containing the marking functions
- ▶ Select the first block of the section you wish to copy
- ▶ Mark the first block: Press the **SELECT BLOCK** soft key. The TNC highlights the block in color and displays the **CANCEL SELECTION** soft key
- ▶ Move the highlight to the last block of the program section you wish to copy or cut. The TNC shows the marked blocks in a different color. You can end the marking function at any time by pressing the **CANCEL SELECTION** soft key
- ▶ Copy the selected program section: Press the **COPY BLOCK** soft key. Cut the selected program section: Press the **CUT OUT BLOCK** soft key. The TNC stores the selected block
- ▶ Using the arrow keys, select the block after which you wish to insert the copied (cut) program section



To insert the section into another program, select the corresponding program using the file manager and then mark the block after which you wish to insert the program section.

- ▶ Insert the saved program section: Press the **INSERT BLOCK** soft key
- ▶ To end the marking function, press the **CANCEL SELECTION** soft key

## 3 Fundamentals, file management


### 3.2 Opening programs and entering

#### The TNC search function

The search function of the TNC enables you to search for any text within a program and replace it by a new text, if required.

##### Finding any text

- FIND
- ▶ Select the Search function: The TNC superimposes the search window and displays the available search functions in the soft-key row
  - ▶ Enter the text to be searched for, e.g.: **TOOL**
  - ▶ Select forwards search or backwards search
  - ▶ Start the search process: The TNC moves to the next block containing the text you are searching for
  - ▶ Repeat the search process: The TNC moves to the next block containing the text you are searching for
  - ▶ Terminate the search function: Press the END soft key
- FIND
- FIND
- END



##### Finding/Replacing any text



The find/replace function is not possible if

- a program is protected
- the program is currently being run by the TNC

When using the **REPLACE ALL** function, ensure that you do not accidentally replace text that you do not want to change. Once replaced, such text cannot be restored.

- ▶ Select the block containing the word you wish to find
  - ▶ Select the Search function: The TNC superimposes the search window and displays the available search functions in the soft-key row
  - ▶ Press the **CURRENT WORD** soft key: The TNC loads the first word of the current block. If required, press the info key again to load the desired word.
  - ▶ Start the search process: The TNC moves to the next occurrence of the text you are searching for
  - ▶ To replace the text and then move to the next occurrence of the text, press the **REPLACE** soft key. To replace all text occurrences, press the **REPLACE ALL** soft key. To skip the text and move to its next occurrence press the **FIND** soft key
  - ▶ Terminate the search function: Press the END soft key
- FIND
- FIND
- REPLACE
- END

### 3.3 File management: Basics

#### Files

Files in the TNC	Type
<b>Programs</b>	
in HEIDENHAIN format	.H
in DIN/ISO format	.I
<b>Compatible Programs</b>	
HEIDENHAIN Unit Programs	.HU
HEIDENHAIN Contour Programs	.HC
<b>Tables for</b>	
tools	.T
Tool changers	.TCH
Datums	.D
Points	.PNT
Reference points	.PR
Touch probes	.TP
Backup files	.BAK
Dependent data (e.g. Structure items)	.DEP
Freely definable tables	.TAB
Pallets	.P
Turning tools	.TRN
Tool compensation	.3DTC
<b>Text as</b>	
ASCII files	.A
Log files	.TXT
Help files	.CHM
<b>CAD files as</b>	
ASCII files	.DXF .IGES .STEP

When you write a part program on the TNC, you must first enter a program name. The TNC saves the program to the internal memory as a file with the same name. The TNC can also save texts and tables as files.

The TNC provides a special file management window in which you can easily find and manage your files. Here you can call, copy, rename and erase files.

You can manage an almost unlimited number of files with the TNC. The available memory is at least **21 GB**. A single NC program can be up to **2 GB** in size.



Depending on the setting, the TNC generates a backup file (\*.bak) after editing and saving of NC programs. This can reduce the memory space available to you.

3

Fundamentals, file management

3.3

File management: Basics

File names

When you store programs, tables and texts as files, the TNC adds an extension to the file name, separated by a point. This extension indicates the file type.

File name	File type
PROG20	.H

File names on the TNC must comply with this standard: The Open Group Base Specifications Issue 6 IEEE Std 1003.1, 2004 Edition (Posix-Standard). Accordingly, the file names may include the characters below:

A B C D E F G H I J K L M N O P Q R S T U V W X Y Z a b c d e f g  
h i j k l m n o p q r s t u v w x y z 0 1 2 3 4 5 6 7 8 9 . \_ -

You should not use any other characters in file names in order to prevent any file transfer problems. Table names must start with a letter.



The maximum permitted path length is 255 characters. All drive characters, directory and the file name, including the extension, must not exceed 255 characters.

**Further Information:** "Paths", page 148

## Displaying externally generated files on the TNC

The TNC features several additional tools which you can use to display the files shown in the table below. Some of the files can also be edited.

File types	Type
PDF files	pdf
Excel tables	xls csv
Internet files	html
Text files	txt ini
Graphics files	bmp gif jpg png

**Further Information:** "Additional tools for management of external file types", page 160

## Data Backup

We recommend saving newly written programs and files on a PC at regular intervals.

The **TNCremo** data transmission freeware from HEIDENHAIN is a simple and convenient method for backing up data stored on the TNC.

You can also backup files directly from the control. **Further Information:** "Backup and restore", page 108

You additionally need a data medium on which all machine-specific data, such as the PLC program, machine parameters, etc., are stored. Ask your machine manufacturer for assistance, if necessary.



Saving the contents of the internal memory can take up to several hours. In this case, it is a good idea to save the data outside of work hours, e.g. during the night.

Take the time occasionally to delete any unneeded files so that the TNC always has enough hard-disk space for system files (such as the tool table).



Depending on operating conditions (e.g. vibration load), hard disks generally have a higher failure rate after three to five years of service. HEIDENHAIN therefore recommends having the hard disk inspected after three to five years.

# 3 Fundamentals, file management

## 3.4 Working with the file manager


### 3.4 Working with the file manager

#### Directories

To ensure that you can easily find your programs and files, we recommend that you organize your internal memory into directories. You can divide a directory into further directories, which are called subdirectories. With the **-/+** key or **ENT** you can show or hide the subdirectories.

#### Paths

A path indicates the drive and all directories and subdirectories under which a file is saved. The individual names are separated by a backslash "\".




The maximum permitted path length is 255 characters. All drive characters, directory and the file name, including the extension, must not exceed 255 characters.

#### Example



















The directory AUFTR1 was created on the TNC drive. Then, in the AUFTR1 directory, the directory NCPROG was created and the part program PROG1.H was copied into it. The part program now has the following path:

**TNC:\AUFTR1\NCPROG\PROG1.H**

The chart at right illustrates an example of a directory display with different paths.



## Overview: Functions of the file manager

Soft key	Function	Page
	Copy a single file	153
	Display a specific file type	151
	Create new file	153
	Display the last 10 files that were selected	156
	Delete a file	157
	Tag a file	158
	Rename file	158
	Protect a file against editing and erasure	159
	Cancel file protection	159
	Import tool table of an iTNC 530	214
	Customize table view	476
	Manage network drives	170
	Select the editor	159
	Sort files by properties	159
	Copy a directory	156
	Delete directory with all its subdirectories	
	Refresh directory	
	Rename a directory	
	Create a new directory	

## Calling the file manager






- Press the **PGM MGT** key: The TNC displays the file management window (see figure for default setting. If the TNC displays a different screen layout, press the **WINDOW** soft key.)

The narrow window on the left shows the available drives and directories. Drives designate devices with which data are stored or transferred. A drive is the internal memory of the TNC. Other drives are the interfaces (RS232, Ethernet) to which you can connect a PC for example. A directory is always identified by a folder symbol to the left and the directory name to the right. Subdirectories are shown to the right of and below their parent directories. If there are subdirectories, you can show or hide them using the **-/+** key.

If the directory tree is longer than the screen, navigate using the scroll bar or a connected mouse.

The wide window on the right shows you all files that are stored in the selected directory. Each file is shown with additional information, illustrated in the table below.

Display	Meaning
File name	File name and file type
Bytes	File size in bytes
Status	File properties:
E	Program is selected in the <b>Programming</b> mode of operation
S	Program is selected in the <b>Test run</b> mode of operation
M	Program is selected in a Program Run mode of operation
+	Program has non-displayed dependent files with the extension DEP, e.g. with use of the tool usage test
	File is protected against erasing and editing
	File is protected against erasing and editing, because it is being run
Date	Date that the file was last edited
Time	Time that the file was last edited



 To display the dependent files, set the machine parameter **dependentFiles** (no. 122101) to **MANUAL**.



## Selecting drives, directories and files



- To call the file manager, press the **PGM MGT** key.

Navigate with a connected mouse or use the arrow keys or the soft keys to move the cursor to the desired position on the screen:



- Moves the cursor from the left to the right window, and vice versa



- Moves the cursor up and down within a window



- Moves the cursor one page up or down within a window



### Step 1: Select drive

- Move the highlight to the desired drive in the left window



- To select a drive, press the **SELECT** soft key, or



- Press the **ENT** key

# 3

## Fundamentals, file management

### 3.4 Working with the file manager

#### Step 2: Select a directory

- Move the highlight to the desired directory in the left-hand window—the right-hand window automatically shows all files stored in the highlighted directory

#### Step 3: Select a file



- Press the **SELECT TYPE** soft key



- Press the soft key for the desired file type, or



- Press the **SHOW ALL** soft key to display all files, or



- Use wildcards, e.g. **4\*.h**: Show all files of type .h starting with a 4

- Move the highlight to the desired file in the right window



- Press the **SELECT** soft key, or



- Press the **ENT** key

The TNC opens the selected file in the operating mode from which you called the file manager.




If you enter the first letter of the file you are looking for in file management, the cursor automatically jumps to the first program with the same letter.

### Creating a new directory

- ▶ Move the highlight in the left window to the directory in which you want to create a subdirectory



- ▶ Press the **NEW DIRECTORY** soft key
- ▶ Enter a directory name
- ▶ Press the **ENT** key



- ▶ Press the **OK** soft key to confirm or



- ▶ Press the **CANCEL** soft key to abort

### Create new file

- ▶ Select the directory in the left window in which you wish to create the new file
- ▶ Position the cursor in the right window




- ▶ Press the **NEW FILE** soft key
- ▶ Enter the file name with extension
- ▶ Press the **ENT** key



### Copying a single file

- ▶ Move the cursor to the file you wish to copy
- ▶ Press the **COPY** soft key to select the copying function. The TNC opens a pop-up window




#### Copying files into the current directory

- ▶ Enter the name of the destination file.
- ▶ Press the **ENT** key or **OK** soft key: The TNC copies the file into the current directory. The original file is retained.



#### Copying files into another directory



- ▶ Press the **TARGET DIRECTORY** soft key to select the target directory from a pop-up window
- ▶ Press the **ENT** key or **OK** soft key: The TNC copies the file with the same name into the chosen directory. The original file is retained.



When you start the copying process with **ENT** or the **OK** soft key, the TNC displays a pop-up window with a progress indicator.

## 3 Fundamentals, file management

### 3.4 Working with the file manager

#### Copying files into another directory

- ▶ Select a screen layout with two equally sized windows

In the right window

- ▶ Press the **SHOW TREE** soft key
- ▶ Move the cursor to the directory into which you wish to copy the files, and display the files in this directory with the **ENT** key

In the left window


- ▶ Press the **SHOW TREE** soft key
- ▶ Select the directory with the files to copy and press the **SHOW FILES** soft key to display them



- ▶ Press the Tag soft key: Call the file tagging functions



- ▶ Press the Tag soft key: Position the cursor on the file you wish to copy and tag. You can tag several files in this way, if desired



- ▶ Press the Copy soft key: Copy the tagged files into the target directory

**Further Information:** "Tag files", page 158

If you have tagged files in both the left and right windows, the TNC copies from the directory in which the cursor is located.

#### Overwriting files

If you copy files into a directory in which other files are stored under the same name, the TNC will ask whether the files in the target directory should be overwritten:

- ▶ Overwrite all files (**Existing files** field selected): Press the **OK** soft key, or
- ▶ To leave the files as they are, press the **CANCEL** soft key

If you want to overwrite a protected file, select the **Protected files** field or cancel the process.

## Copying a table

### Importing lines to a table

If you are copying a table into an existing table, you can overwrite individual lines with the **REPLACE FIELDS** soft key. Prerequisites:

- The target table must exist
- The file to be copied must only contain the lines you want to replace
- Both tables must have the same file extension



The **REPLACE FIELDS** function is used to overwrite lines in the target table. To avoid losing data, create a backup copy of the original table.

### Example

With a tool presetter you have measured the length and radius of ten new tools. The tool presetter then generates the TOOL\_Import.T tool table with 10 lines (for the 10 tools).

- ▶ Copy this table from the external data medium to any directory
- ▶ Copy the externally created table to the existing table TOOL.T using the TNC file manager. The TNC asks if you wish to overwrite the existing TOOL.T tool table:
- ▶ If you press the **REPLACE FIELDS** soft key, the TNC will completely overwrite the current TOOL.T tool table. After the copying process the new TOOL.T table consists of 10 lines.
- ▶ Or press the **REPLACE FIELDS** soft key for the TNC to overwrite the 10 lines in the TOOL.T file. The data of the other lines is not changed

### Extracting lines from a table

You can select one or more lines in a table and save them in a separate table.

- ▶ Open the table from which you want to copy lines
- ▶ Use the arrow keys to select the first line to be copied
- ▶ Press the **MORE FUNCTIONS** soft key
- ▶ Press the **TAG** soft key **TAG**
- ▶ Select additional lines, if required
- ▶ Press the **SAVE AS** soft key **SAVE AS**
- ▶ Enter a name for the table in which the selected lines are to be saved

# 3 Fundamentals, file management

## 3.4 Working with the file manager

### Copying a directory

- ▶ Move the highlight in the right window onto the directory you want to copy
- ▶ Press the **COPY** soft key: The TNC opens the window for selecting the target directory
- ▶ Select the target directory and confirm with **ENT** or the **OK** soft key: The TNC copies the selected directory and all its subdirectories to the selected target directory

### Choose one of the last files selected



- ▶ To call the file manager, press the **PGM MGT** key.




- ▶ To display the last ten files selected: press the **LAST FILES** soft key

Press the arrow keys to move the cursor to the file you wish to select:



- ▶ Moves the cursor up and down within a window




- ▶ To select the file, press the **OK** soft key, or



- ▶ Press the **ENT** key



The **COPY FIELD** soft key allows you to copy the path of a marked file. You can reuse the copied path later, e.g. when calling a program with the **PGM CALL** key.



## Deleting a file



### Caution: Data may be lost!

Once you delete files they cannot be restored!

- Move the cursor to the file you want to delete



- To select the erasing function, press the **DELETE** soft key. The TNC asks whether you really want to delete the file
- To confirm the deletion, press the **OK** soft key; or
- To cancel deletion, press the **CANCEL** soft key

## Deleting a directory



### Caution: Data may be lost!

Once you delete files they cannot be restored!

- Move the cursor to the directory you want to delete








- To select the erasing function, press the **DELETE** soft key. The TNC inquires whether you really intend to delete the directory and all its subdirectories and files
- To confirm the deletion, press the **OK** soft key; or
- To cancel deletion, press the **CANCEL** soft key

3

## Fundamentals, file management









### 3.4 Working with the file manager

#### Tag files

Soft key	Tagging function
	Tag a single file
	Tag all files in the directory
	Untag a single file
	Untag all files
	Copy all tagged files


Some functions, such as copying or erasing files, can not only be used for individual files, but also for several files at once. To tag several files, proceed as follows:

- ▶ Move the cursor to the first file

	▶ To display the tagging functions, press the <b>TAG</b> soft key
	▶ To tag the file, press the <b>TAG FILE</b> soft key
	▶ Move the cursor to other files
	
	▶ To select the next file, press the <b>TAG FILE</b> soft key. Repeat this process for all files you want to tag.
	▶ Copy the tagged files: Press the <b>COPY</b> soft key; or
	▶ Delete tagged files: leave active soft key row
	▶ Press the <b>DELETE</b> soft key to delete tagged files

#### Renaming a file

- ▶ Move the cursor to the file you wish to rename

	▶ To select the function for renaming press the <b>RENAME</b> soft key
	▶ Enter the new file name; the file type cannot be changed
	▶ To rename: Press the <b>OK</b> soft key or the <b>ENT</b> key



## Sort files


- ▶ Select the folder in which you wish to sort the files
  - ▶ Press the **SORT** soft key
  - ▶ Select the soft key with the corresponding display criterion



## Additional functions

### Protecting a file / Canceling file protection


- ▶ Move the cursor to the file you want to protect
  - ▶ To select the additional functions, press the **MORE FUNCTIONS** soft key
  - ▶ Enable file protection: Press the **PROTECT** soft key. The file is tagged with the "protected" symbol



- ▶ To cancel file protection, press the **UNPROTECT** soft key


### Selecting the editor

- ▶ Move the cursor in the right-hand window onto the file you want to open
  - ▶ To select the additional functions, press the **MORE FUNCTIONS** soft key.
  - ▶ To select the editor with which to open the selected file, press the **SELECT EDITOR** soft key
  - ▶ Mark the desired editor
  - ▶ Press the **OK** soft key to open the file



### Connecting/removing a USB device

- ▶ Move the cursor to the left-hand window
  - ▶ To select the additional functions, press the **MORE FUNCTIONS** soft key.
  - ▶ Shift the soft-key row
  - ▶ Search for a USB device
  - ▶ To remove the USB device, move the cursor to the USB device in the directory tree
  - ▶ Remove the USB device



**Further Information:** "USB devices on the TNC", page 171

## 3 Fundamentals, file management

### 3.4 Working with the file manager

#### Additional tools for management of external file types

The additional tools enable you to display or edit various externally created file types on the TNC.


File types	Description
PDF files (pdf)	page 161
Excel spreadsheets (xls, csv)	page 162
Internet files (htm, html)	page 163
ZIP archives (zip)	page 164
Text files (ASCII files, e.g. txt, ini)	page 165
Video files	page 165
Graphics files (bmp, jpg, gif, png)	page 166



If you transfer files from a PC to the control by means of TNCremo, you must have entered the file name extension pdf, xls, zip, bmp gif, jpg and png in the list of the file types for binary transmission (menu item **>Extras >Configuration >Mode** in TNCremo).

## Displaying PDF files

To open PDF files directly on the TNC, proceed as follows:


-  ▶ To call the file manager, press the **PGM MGT** key.
- ▶ Select the directory in which the PDF file is saved
- ▶ Move the cursor to the PDF file
- ▶ Press **ENT**: The TNC opens the PDF file in its own application using the **PDF viewer** additional tool



With the key combination ALT+TAB you can always return to the TNC user interface while leaving the PDF file open. Alternatively, you can also click the corresponding symbol in the task bar to switch back to the TNC interface.





If you position the mouse pointer over a button, a brief tool tip explaining the function of this button will be displayed. More information on how to use the **PDF viewer** is provided under **Help**.



Proceed as follows to exit the **PDF viewer**:

- ▶ Use the mouse to select the **File** menu item
- ▶ Select the menu item **Close**: The TNC returns to the file manager

If you are not using a mouse, proceed as follows to close the **PDF viewer**:

-  ▶ Press the key for switching the soft keys: The **PDF viewer** opens the **File** pull-down menu
-  ▶ Select the menu item **Close**: The TNC returns to the file manager and confirm with the **ENT** key: The TNC returns to the file manager



ENT

## 3 Fundamentals, file management

### 3.4 Working with the file manager

#### Displaying and editing Excel files

Proceed as follows to open and edit Excel files with the extension **xls**, **xlsx** or **csv** directly on the TNC:

- 
- ▶ To call the file manager, press the **PGM MGT** key.
  - ▶ Select the directory in which the Excel file is saved
  - ▶ Move the cursor to the Excel file
- 
- ▶ Press **ENT**: The TNC opens the Excel file in its own application using the **Gnumeric** additional tool



With the key combination ALT+TAB you can always return to the TNC user interface while leaving the Excel file open. Alternatively, you can also click the corresponding symbol in the task bar to switch back to the TNC interface.





If you position the mouse pointer over a button, a brief tool tip explaining the function of this button will be displayed. More information on how to use the **Gnumeric** function is provided under **Help**.

Proceed as follows to exit **Gnumeric**:

- ▶ Use the mouse to select the **File** menu item
- ▶ Select the menu item **Close**: The TNC returns to the file manager

If you are not using a mouse, proceed as follows to close the additional **Gnumeric** tool:

- 
- ▶ Press the key for switching the soft keys: The **Gnumeric** additional tool opens the **File** pull-down menu
- 
- ▶ Select the **Close** menu item and confirm with the **ENT** key: The TNC returns to the file manager

**ENT**

## Displaying Internet files

To open Internet files with the extension **htm** or **html** directly on the TNC, proceed as follows:

PGM  
MGT

- ▶ To call the file manager, press the **PGM MGT** key.
- ▶ Select the directory in which the Internet file is saved

ENT


- ▶ Move the cursor to the Internet file
- ▶ Press **ENT**: The TNC opens the Internet file in its own application using the additional **Web Browser** tool



With the key combination ALT+TAB you can always return to the TNC user interface while leaving the PDF file open. Alternatively, you can also click the corresponding symbol in the task bar to switch back to the TNC interface.



If you position the mouse pointer over a button, a brief tool tip explaining the function of this button will be displayed. More information on how to use **Web Browser** is available in **Help**.



Proceed as follows to exit the **Web Browser**:

- ▶ Use the mouse to select the **File** menu item
- ▶ Select the menu item **Quit**: The TNC returns to the file manager

If you are not using a mouse, proceed as follows to close the **Web Browser**:

▶

- ▶ Press the key for switching the soft keys: The **Web Browser** opens the **File** pull-down menu

↓

- ▶ Select the **Quit** menu item and confirm with the **ENT** key: The TNC returns to the file manager

ENT

# 3 Fundamentals, file management


## 3.4 Working with the file manager

### Working with ZIP archives


Proceed as follows to open ZIP archives with the extension **zip** directly on the TNC:

- PGM MGT


ENT
- ▶ To call the file manager, press the **PGM MGT** key.
  - ▶ Select the directory in which the archive file is saved
  - ▶ Move the cursor to the archive file
  - ▶ Press **ENT**: The TNC opens the archive file in its own application using the additional **Xarchiver** tool



With the key combination ALT+TAB you can always return to the TNC user interface while leaving the archive file open. Alternatively, you can also click the corresponding symbol in the task bar to switch back to the TNC interface.



If you position the mouse pointer over a button, a brief tool tip explaining the function of this button will be displayed. More information on how to use the **Xarchiver** function is provided under **Help**.



Please note that the TNC does not carry out any binary-to-ASCII conversion or vice versa when compressing or decompressing NC programs and NC tables. When such files are transferred to TNC controls using other software versions, the TNC may not be able to read them.

Proceed as follows to exit **Xarchiver**:


- ▶ Use the mouse to select the **ARCHIVE** menu item
- ▶ Select the menu item **Exit**: The TNC returns to the file manager

If you are not using a mouse, proceed as follows to close the **Xarchiver**:

- ▶

⬇

ENT
- ▶ Press the key for switching the soft keys: The **Xarchiver** opens the **ARCHIVE** pull-down menu**ARCHIVE**
  - ▶ Select the **Exit** menu item and confirm with the **ENT** key: The TNC returns to the file manager



## Working with the file manager 3.4

### Displaying and editing text files

Use the internal text editor to open and edit text files (ASCII files, e.g. with the extension **txt**). Proceed as follows:

PGM  
MGT

- ▶ To call the file manager, press the **PGM MGT** key.
- ▶ Select the drive and the directory in which the text file is saved
- ▶ Move the cursor to the text file
- ▶ Press the **ENT** key: The TNC opens the text file with the internal text editor


ENT



Alternatively, you can also open the ASCII files using the **Leafpad** additional tool. The shortcuts you are familiar with from Windows, which you can use to edit texts quickly (CTRL+C, CTRL+V,...), are available within **Leafpad**.



With the key combination ALT+TAB you can always return to the TNC user interface while leaving the text file open. Alternatively, you can also click the corresponding symbol in the task bar to switch back to the TNC interface.



Proceed as follows to open **Leafpad**:

- ▶ Use the mouse to select the **Menu HEIDENHAIN** icon from the task bar
- ▶ Select the **Tools** and **Leafpad** menu items in the pull-down menu

Proceed as follows to exit **Leafpad**:

- ▶ Use the mouse to select the **File** menu item
- ▶ Select the menu item **Exit**: The TNC returns to the file manager

### Displaying video files



Refer to your machine manual.  
This feature must be enabled and adapted by the machine tool builder.

Proceed as follows to open video files directly on the TNC:

PGM  
MGT

- ▶ To call the file manager, press the **PGM MGT** key.
- ▶ Select the directory in which the video file is saved
- ▶ Move the cursor to the video file
- ▶ Press **ENT**: The TNC opens the video file in its own application

ENT

# 3

## Fundamentals, file management

### 3.4 Working with the file manager

#### Displaying graphic files

Proceed as follows to open graphics files with the extension bmp, gif, jpg or png directly on the TNC:

PGM  
MGT

- ▶ To call the file manager, press the **PGM MGT** key.
- ▶ Select the directory in which the graphics file is saved
- ▶ Move the cursor to the graphics file
- ▶ Press the **ENT** key The TNC opens the graphics file in its own application using the additional **ristretto** tool

ENT



With the key combination ALT+TAB you can always return to the TNC user interface while leaving the graphics file open. Alternatively, you can also click the corresponding symbol in the task bar to switch back to the TNC interface.



More information on how to use the **ristretto** function is provided under **Help**.



Proceed as follows to exit **ristretto**:

- ▶ Use the mouse to select the **File** menu item
- ▶ Select the menu item **Exit**: The TNC returns to the file manager

If you are not using a mouse, proceed as follows to close the additional **ristretto** tool:

▶

- ▶ Press the key for switching the soft keys: The **ristretto** additional tool opens the **File** pull-down menu

↓

- ▶ Select the **Exit** menu item and confirm with the **ENT** key: The TNC returns to the file manager

ENT



## Additional tools for ITCs

The following additional tools allow you to apply various settings for the touch screens on connected ITCs.

ITCs are industrial PCs without their own memory media, and therefore they do not have their own operating system. This feature is what makes ITCs different from IPCs.

ITCs are frequently used with large machinery, e.g. as a clone of the actual control system.



The machine manufacturer defines and configures the display and function of the connected ITCs and IPCs.

Additional tool	Application
<b>ITC Calibration</b>	4-point calibration
<b>ITC Gestures</b>	Configuration of gesture control
<b>ITC touchscreen configuration</b>	Selection of touch sensitivity



The additional tools for the ITCs are only provided by the control in the taskbar with connected ITCs.

### ITC Calibration

Using the additional tool **ITC Calibration**, you align the position for the mouse cursor displayed with the actual movement position of your finger.

Calibration using the additional **ITC Calibration** tool is recommended in the following cases:

- After replacing the touchscreen
- When changing the touch screen position (parallel axis error due to amended viewing angle)

Calibration involves the following steps:

- ▶ Start the tool in control using the task bar
- > The ITC opens the calibration screen with four touch points in the corners of the screen
- ▶ Touch the four touch points shown one after the other
- > The ITC closes the calibration screen once calibration has been successfully completed

### ITC Gestures

Using the additional **ITC Gestures** tool, the machine manufacturer configures the gesture control on the touch screen.



This function may only be used with the permission of your machine manufacturer.

## 3 Fundamentals, file management

### 3.4 Working with the file manager

#### ITC touchscreen configuration

Using the additional **ITC Touchscreen Configuration** tool, you can select the touch sensitivity of the touch screen.

The ITC gives you the following options:

- **Normal Sensitivity (Cfg 0)**
- **High Sensitivity (Cfg 1)**
- **Low Sensitivity (Cfg 2)**

Use the **Normal Sensitivity (Cfg 0)** setting as standard. If you find it difficult to operate the equipment while wearing gloves in this setting, select the **High Sensitivity (Cfg 1)** setting.



If the ITC touch screen is not splash-proof, select the **Low Sensitivity (Cfg 2)** setting. This stops the ITC interpreting drops of water as touches.

Calibration involves the following steps:

- ▶ Start the tool in control using the task bar
- > The ITC opens a pop-up window with three options
- ▶ Select Touch Sensitivity
- ▶ Press the **OK** button
- > The ITC closes the pop-up window


## Data transfer to or from an external data carrier



Before you can transfer data to an external data medium, you must set up the data interface.

**Further Information:** "Setting up data interfaces", page 709

Depending on the data transfer software you use, problems can occur occasionally when you transmit data over a serial interface. They can be overcome by repeating the transmission.



- To call the file manager, press the **PGM MGT** key.



- Select the screen layout for data transfer: press the **WINDOW** soft key.

Use the arrow keys to move the cursor to the file you wish to transfer:



- Moves the cursor up and down within a window



- Moves the cursor from the right to the left window, and vice versa



If you wish to copy from the TNC to the external data medium, move the highlight in the left window to the file to be transferred.


If you wish to copy from the external data medium to the TNC, move the highlight in the right window to the file to be transferred.



- Select another drive or directory: Press the **SHOW TREE** soft key




- Use the arrow keys to select the desired directory
- Select the desired file: Press the **SHOW FILES** soft key



- Use the arrow keys to select the file
- Transfer a single file: Press the **COPY** soft key

- Confirm with the **OK** soft key or with the **ENT** key. A status window appears on the TNC, informing about the copying progress, or



- Stop transfer: Press the **WINDOW** soft key. The TNC displays the standard file manager window again

# 3 Fundamentals, file management

## 3.4 Working with the file manager

### The TNC in a network



You must connect the Ethernet card to the network.

**Further Information:** "Ethernet interface ", page 715

The TNC logs error messages during network operation.

**Further Information:** "Ethernet interface ", page 715

If the TNC is connected to a network, the left directory window displays additional drives. All the functions described above (selecting a drive, copying files, etc.) also apply to network drives, provided that you have been granted the corresponding rights.


#### Connecting and disconnecting a network drive

PGM  
MGT

- To call the file manager, press the **PGM MGT** key

NET

- Select network settings: Press the **NET** soft key (soft-key row 2)
- To manage the network drives: Press the **DEFINE NETWORK CONNECTN.** soft key. In a window the TNC shows the network drives available for access. With the soft keys described below you can define the connection for each drive.



Soft key	Function
<b>Connect</b>	Establish the network connection. If the connection is active, the TNC marks the <b>Mount</b> column.
<b>Separate</b>	End network connection
<b>Auto</b>	Automatically establish network connection whenever the TNC is switched on. The TNC marks the <b>Auto</b> column if the connection is established automatically
<b>Add</b>	Set up new network connection
<b>Remove</b>	Delete existing network connection
<b>Copy</b>	Copy network connection
<b>Edit</b>	Edit network connection
<b>Clear</b>	Delete the status window

## USB devices on the TNC



### Caution: Data may be lost!

Only use the USB interface for transferring and saving, not for processing or running programs.

Backing up data from or loading onto the TNC is especially easy with USB devices. The TNC supports the following USB block devices:

- Floppy disk drives with FAT/VFAT file system
- Memory sticks with the FAT/VFAT file system
- Hard disks with the FAT/VFAT file system
- CD-ROM drives with the Joliet (ISO 9660) file system

The TNC automatically detects these types of USB devices when connected. The TNC does not support USB devices with other file systems (such as NTFS). The TNC displays the **USB: TNC does not support device** error message when such a device is connected.



If an error message is displayed when connecting a USB data medium, check the setting in the SELinux security software.

**Further Information:** "SELinux security software", page 105

The TNC also displays the **USB: TNC does not support device** error message if you connect a USB hub. In this case, simply acknowledge the message with the **CE** key.

In theory, you should be able to connect all USB devices with the file systems mentioned above to the TNC. It may occur that a USB device is not correctly detected by the control. In such cases, use another USB device.

## Working with USB devices



Your machine tool builder can assign permanent names for USB devices. The machine manual provides further information.

The USB devices appear as separate drives in the directory tree, so you can use the file management functions described in the earlier chapters.









If a larger file is transferred to a USB device in the file management, the control displays a dialog **Write access on USB device** until file transfer is completed. The dialog is closed with the soft key **VERBERGEN** and file transfer is continued in the background. The control displays a warning until file transfer is completed.

## 3 Fundamentals, file management


### 3.4 Working with the file manager

#### Remove the USB device

Proceed as follows to remove a USB device:

-  ▶ To call the file manager, press the **PGM MGT** key
-  ▶ Select the left window with the arrow key
-  ▶ Use the arrow keys to select the USB device to be removed
-  ▶ Scroll through the soft-key row
-  ▶ Press the MORE FUNCTIONS soft key
-  ▶ Scroll through the soft-key row
-  ▶ Select the function for removing USB devices. The TNC removes the USB device from the directory tree and reports **The USB device can be removed now.**
- ▶ Remove the USB device
-  ▶ Quit the File Manager

In order to re-establish a connection with a USB device that has been removed, press the following soft key:

-  ▶ Select the function for reconnection of USB devices

# 4

**Programming aids**

## Programming aids

### 4.1 Adding comments

#### 4.1 Adding comments

##### Application


You can add comments to a part program to explain program steps or make general notes.



Depending on the machine parameter **lineBreak** (no. 105404), the TNC displays comments that can no longer be shown entirely on the screen, shows these in several lines or the character >> appears on the screen.

The last character in a comment block must not have any tilde(~).

You have the following possibilities for adding comments.



##### Entering comments during programming

- ▶ Enter the data for an NC block, then press the semicolon key ; on the alphabetic keyboard—the TNC displays the dialog prompt **Comment?**
- ▶ Enter your comment and conclude the block by pressing the **END** key

##### Inserting comments after program entry






- ▶ Select the block to which a comment is to be added
- ▶ Select the last word in the block with the right arrow key, then press the semicolon key (;): The TNC displays the dialog prompt **COMMENT?**
- ▶ Enter your comment and conclude the block by pressing the **END** key

##### Entering a comment in a separate block

- ▶ Select the block after which the comment is to be inserted
- ▶ Initiate the programming dialog with the semicolon key (;) on the alphabetic keyboard
- ▶ Enter your comment and conclude the block by pressing the **END** key



## Functions for editing of the comment

Soft key	Function
	Jump to beginning of comment
	Jump to end of comment
	Jump to the beginning of a word. Words must be separated by a space
	Jump to the end of a word. Words must be separated by a space
	Switch between paste and overwrite mode

## Programming aids

### 4.2 Display of NC programs

#### 4.2 Display of NC programs

##### Syntax highlighting


The TNC displays syntax elements with various colors according to their meaning. Programs are made more legible and clear with color-highlighting.

##### Color highlighting of syntax elements

Use	Color
Standard color	Black
Display of comments	Green
Display of numerical values	Blue
Block number	Violet

##### Scrollbar

Screen content can be shifted with the mouse using the scroll bar at the right edge of the program window. In addition, the size and position of the scrollbar indicates program length and cursor position.



## 4.3 Structuring programs

### Definition and applications

This TNC function enables you to comment part programs in structuring blocks. Structuring blocks are short texts with up to 252 characters and are used as comments or headlines for the subsequent program lines.

With the aid of appropriate structuring blocks, you can organize long and complex programs in a clear and comprehensible manner.

This function is particularly convenient if you want to change the program later. Structuring blocks can be inserted into the part program at any point.

Structure blocks can also be displayed in a separate window, and be edited or added to, as desired. Use the appropriate screen layout for this.

The inserted structure items are managed by the TNC in a separate file (extension: .SEC.DEF). This speeds navigation in the program structure window.

The **PROGRAM + SECTS** screen layout can be selected in the following operating modes:

- Program run, single block
- Program run, full sequence
- Programming


### Displaying the program structure window / Changing the active window



- ▶ Display structure window: For this screen layout press the **PROGRAM + STRUCTURE** soft key



- ▶ Change the active window: Press the **CHANGE WINDOW** soft key



## Programming aids

### 4.3 Structuring programs

#### Inserting a structure block in the program window

- ▶ Select the block after which the structuring block is to be inserted



- ▶ Press the **SPEC FCT** key



- ▶ Press the **PROGRAMMING AIDS** soft key



- ▶ Press the **INSERT SECTION** soft key

- ▶ Enter the structuring text



- ▶ If necessary, change the structure depth with the soft key



You can also insert structure blocks with the key combination **Shift + 8**.

#### Selecting blocks in the program structure window

If you are scrolling through the program structure window block by block, the TNC at the same time automatically moves the corresponding NC blocks in the program window. This way you can quickly skip large program sections.


## 4.4 Calculator

### Operation

The TNC features an integrated calculator with the basic mathematical functions.

- Use the **CALC** key to show and hide the on-line calculator
- Select the arithmetical functions: The calculator is operated with short commands via soft key or through the alphabetic keyboard.

Calculate function	Shortcut (soft key)
Addition	+
Subtraction	-
Multiplication	*
Division	/
Calculations in parentheses	( )
Arc cosine	ARC
Sine	SIN
Cosine	COS
Tangent	TAN
Powers of values	X^Y
Square root	SQRT
Inversion	1/x
pi (3.14159265359)	PI
Add value to buffer memory	M+
Save the value to buffer memory	MS
Recall from buffer memory	MR
Delete buffer memory contents	MC
Natural logarithm	LN
Logarithm	LOG
Exponential function	e^x
Check the algebraic sign	SGN
Form the absolute value	ABS



## Programming aids

### 4.4 Calculator

Calculate function	Shortcut (soft key)
Truncate decimal places	INT
Truncate integers	FRAC
Modulus operator	MOD
Select view	View
Delete value	CE
Unit of measure	MM or INCH
Show angle values in radians (standard: angle in degrees)	RAD
Select the display mode of the numerical value	DEC (decimal) or HEX (hexadecimal)







#### Transferring the calculated value into the program

- ▶ Use the arrow keys to select the word into which the calculated value is to be transferred
- ▶ Superimpose the on-line calculator by pressing the **CALC** key and perform the desired calculation
- ▶ Press the **CONFIRM VALUE** soft key for the TNC to transfer the value into the active input box and close the calculator



You can also transfer values from a program into the calculator. When you press the **GET CURRENT VALUE** soft key or the **GOTO** key, the TNC transfers the value from the active input field to the calculator. The calculator remains in effect even after a change in operating modes. Press the **END** soft key to close the calculator.

### Functions in the pocket calculator

Soft key	Function
	Load the nominal or reference value of the respective axis position into the calculator
	Load the numerical value from the active input field into the calculator
	Load the numerical value from the calculator field into the active input field
	Copy the numerical value from the calculator
	Insert the copied numerical value into the calculator
	Open the cutting data calculator



You can also shift the calculator with the arrow keys on your keyboard. If you have connected a mouse you can also position the calculator with this.

## Programming aids

### 4.5 Cutting data calculator


#### 4.5 Cutting data calculator

##### Application

With the cutting data calculator you can calculate the spindle speed and the feed rate for a machining process. Then you can load the calculated values into an opened feed rate or spindle speed dialog box in the NC program.



You cannot perform any cutting data calculation in turning mode with the cutting data calculator because the feed rate and spindle speed data are different in turning mode from milling mode. During turning, feed rates are usually defined in mm per revolution (mm/1) (**M136**), but the cutting data calculator always calculates in mm per minute (mm/min). In addition, the radius in the cutting data calculator relates to the tool, but turning operations require the tool diameter.



To open the cutting data calculator, press the **CUTTING DATA CALCULATOR** soft key. The TNC shows the soft key if you

- open the on-line calculator (press the **CALC** soft key)
- open the dialog field for spindle speed input in the TOOL CALL block
- open the dialog field for feed rate input in positioning blocks or cycles
- enter a feed rate in manual mode (press the **F** soft key)
- enter a spindle speed in manual mode (press the **S** soft key)

The cutting data calculator is displayed with different input fields depending on whether you calculate a spindle speed or a feed rate:

##### Window or spindle speed calculation:

Code letter	Meaning
R:	Tool radius (mm)
VC:	Cutting speed (m/min)
S=	Result for spindle speed (rev/min)











**Window for feed rate calculation:**

Code letter	Meaning
S:	Spindle speed (rpm)
Z:	Number of teeth on the tool (n)
FZ:	Feed per tooth (mm/tooth)
FU:	Feed rate per revolution (mm/1)
F=	Result for feed rate (mm/min)










You can also calculate the feed rate in the TOOL CALL block and automatically transfer it to the subsequent positioning blocks and cycles. For this purpose, with feed rate input in positioning blocks and cycles, press the **F AUTO** soft key. The TNC then uses the feed rate defined in the TOOL CALL block. If you have to change the feed rate later, you only need to adjust the feed-rate value in the TOOL CALL block.

**Functions in the cutting data calculator:**

Soft key	Function
	Load the spindle speed from the cutting data calculator form into an open dialog field.
	Load the feed rate from the cutting data calculator form into an open dialog field.
	Load the cutting speed from the cutting data calculator form into an open dialog field.
	Load the feed per tooth from the cutting data calculator form into an open dialog field.
	Load the feed per revolution from the cutting data calculator form into an open dialog field.
	Load the tool radius into the cutting data calculator form
	Load the spindle speed from the open dialog field into the cutting data calculator form
	Load the feed rate from the open dialog field into the cutting data calculator form

## Programming aids

### 4.5 Cutting data calculator


Soft key	Function
	Load the feed per revolution from the open dialog field into the cutting data calculator form
	Load the feed per tooth from the open dialog field into the cutting data calculator form
	Load the value from an open dialog field into the cutting data calculator form
	Switch to the pocket calculator
	Move the cutting data calculator in the direction of the arrow
	Use inch values in the cutting data calculator
	Close the cutting data calculator

## 4.6 Programming graphics

### Generate/do not generate graphics during programming

While you are writing the part program, you can have the TNC generate a 2-D pencil-trace graphic of the programmed contour.

- Switch the screen layout to displaying program blocks to the left and graphics to the right: Press the screen layout key and the **PROGRAM + GRAPHICS** soft key



- Set the **AUTO DRAW** soft key to **ON**. While you are entering the program lines, the TNC generates each programmed path contour in the graphics window in the right screen half

If you do not wish to have the TNC generate graphics during programming, set the **AUTO DRAW** soft key to **OFF**.



If **AUTO DRAW** is set to **ON**, with creation of 2-D line graphics the control does not consider:

- Program section repetitions
- Jump commands
- M functions, such as M2 or M30
- Cycle calls


Only use automatic drawing during contour programming.

The control resets the tool data if you reopen a program or press the **RESET + START** soft key.

The control uses various colors in the programming graphics:

- **blue**: uniquely specified contour element
- **violet**: not yet uniquely specified contour element, can still be modified by e.g. an RND
- **ocher**: tool midpoint path
- **red**: rapid traverse

**Further Information:** "FK programming graphics", page 279



## Programming aids

### 4.6 Programming graphics








#### Generating a graphic for an existing program

- Use the arrow keys to select the block up to which you want the graphic to be generated, or press **GOTO** and enter the desired block number



- Reset previously active tool data and generate graphics: Press the **RESET + START** soft key

#### Additional functions:

Soft key	Function
	Reset previously active tool data. Generate programming graphics
	Generate programming graphic blockwise
	Generate a complete graphic or complete it after <b>RESET + START</b>
	Stop the programming graphics. This soft key only appears while the TNC is generating the programming graphics
	Selecting views <ul style="list-style-type: none"> <li>■ Plan view</li> <li>■ Front view</li> <li>■ Page view</li> </ul>
	Display or hide tool paths
	Display or hide tool paths in rapid traverse

### Block number display ON/OFF



- ▶ Shift the soft-key row




- ▶ Display block numbers: **BLOCK NO.** soft keySet **BLOCK NO. SHOW OMIT** to **SHOW**
- ▶ Hide block numbers: **BLOCK NO.** soft keySet **BLOCK NO. SHOW OMIT** to **HIDE**

### Erasing the graphic



- ▶ Shift the soft-key row




- ▶ Erase the graphics: Press the **CLEAR GRAPHICS** soft key

### Showing grid lines



- ▶ Shift the soft-key row



- ▶ Show grid lines: Press the **SHOW GRID LINES** soft key

## Programming aids








### 4.6 Programming graphics

#### Magnification or reduction of details

You can select the graphics display

- Shift the soft-key row


The following functions are available:

Soft key	Function
 	Shift section
 	
	Reduce section
	Enlarge section
	Reset section

With the **RESET BLK FORM** soft key, you can restore the original section.

You can also use the mouse to change the graphic display. The following functions are available:

- To shift the model shown: Hold the center mouse button or mouse wheel down and move the mouse. If you simultaneously press the shift key, you can only shift the model horizontally or vertically
- To zoom in on a certain area: Mark a zoom area by holding the left mouse button down. After you release the left mouse button, the TNC zooms in on the defined area
- To rapidly magnify or reduce any area: Rotate the mouse wheel backwards or forwards



## 4.7 Error messages

### Display of errors

The TNC displays errors with e.g.:

- Incorrect data input
- Logical errors in the program
- Contour elements that are impossible to machine
- Incorrect use of touch probes

When an error occurs, it is displayed in red type in the header.



The control uses different colors for different dialogs:

- red for errors
- yellow for warnings
- green for notes
- blue for information

Long and multi-line error messages are displayed in abbreviated form. Complete information on all pending errors is shown in the error window.

If a rare "processor check error" should occur, the TNC automatically opens the error window. You cannot correct such an error. Shut down the system and restart the TNC.

The error message is displayed in the header until it is cleared or replaced by a higher-priority error.

An error message that contains an NC block number was caused by an error in the indicated block or in the preceding block.

### Open the error window

**ERR**

- ▶ Press the **ERR** key. The TNC opens the error window and displays all accumulated error messages.

### Closing the error window

**END**

- ▶ Press the **END** soft key; or

**ERR**

- ▶ Press the **ERR** key. The TNC closes the error window.

## Programming aids

### 4.7 Error messages


#### Detailed error messages

The TNC displays possible causes of the error and suggestions for solving the problem:

- ▶ Open the error window

MORE  
INFO

- ▶ Information on the error cause and corrective action: Position the cursor on the error message and press the **MORE INFO** soft key. The TNC opens a window with information on the error cause and corrective action.
- ▶ Leave Info: Press the **MORE INFO** soft key again



#### Soft key: INTERNAL INFO

The **INTERNAL INFO** soft key supplies information on the error message. This information is only required if servicing is needed.

- ▶ Open the error window

INTERNAL  
INFO

- ▶ Detailed information about the error message: Position the cursor on the error message and press the **INTERNAL INFO** soft key. The TNC opens a window with internal information about the error
- ▶ To exit Details, press the **INTERNAL INFO** soft key again

#### Soft key FILTER

The **FILTER** soft key enables you to filter identical warnings listed immediately in succession.

- ▶ Open the error window

MORE  
FUNCTIONS

- ▶ Press the **MORE FUNCTIONS** soft key

FILTER  
OFF ON

- ▶ Press the **FILTER** soft key The control filters the identical warnings




- ▶ Leave Filter: Press the **GO BACK** soft key



## Clearing errors

### Clearing errors outside of the error window



- ▶  Clear the errors/messages in the header: Press the **CE** key



In certain situations you cannot use the **CE** key for deleting the errors because the key is used for other functions.

### Deleting errors

- ▶ Open the error window

- ▶  Clear individual errors: Position the cursor on the error message and press the **DELETE** soft key.
- ▶  Delete all error messages: Press the **DELETE ALL** soft key.







If the cause of the error has not been corrected for that error it cannot be deleted. In this case, the error message remains in the window.

## Error log

The TNC stores errors occurred and important events (e.g. system start) in an error log. The capacity of the error log is limited. If the log is full, the TNC uses a second file. If this is also full, the first error log is deleted and newly written etc. If required, switch from **CURRENT FILE** to **PREVIOUS FILE** to view the history.

- ▶ Open the error window.

- ▶  Press the **LOG FILES** soft key.
- ▶  Open the error log file: Press the **ERROR LOG** soft key.
- ▶  Set the previous error log if required: Press the **PREVIOUS FILE** soft key.
- ▶  Set the current error log if required: Press the **CURRENT FILE** soft key.





The oldest entry is at the beginning of the log file, and the most recent entry is at the end.

## Programming aids

### 4.7 Error messages









#### Keystroke log

The TNC stores each key pressed and important events (e.g. system start) in a keystroke log. The capacity of the keystroke log is limited. If the keystroke log is full, the control switches to a second keystroke log. If this is also full, the first keystroke log is deleted and newly written etc. If required, switch from **CURRENT FILE** to **PREVIOUS FILE** to view the history of the inputs.

	► Press the <b>LOG FILES</b> soft key
	► Open the keystroke log file: Press the <b>KEYSTROKE LOG</b> soft key
	► Set the previous keystroke log if required: Press the <b>PREVIOUS FILE</b> soft key
	► Set the current keystroke log if required: Press the <b>CURRENT FILE</b> soft key

The TNC saves each key pressed during operation in a keystroke log. The oldest entry is at the beginning, and the most recent entry is at the end of the file.

#### Overview of the keys and soft keys for viewing the log

Soft key/ Keys	Function
	Go to beginning of keystroke log
	Go to end of keystroke log
	Find text
	Current keystroke log
	Previous keystroke log
	Up/down one line
	
	Return to main menu

## Informational texts

With an operating error, e.g. pressing an impermissible key or entering a value outside of a validity range, the TNC notifies you of this with an information text in the header of the operating error. The TNC deletes this information text with the next valid entry.


## Save service files

If necessary, you can save the "Current status of the TNC," and make it available to a service technician for evaluation. A group of service files is saved (error and keystroke logs, as well as other files that contain information about the current status of the machine and the machining operation).

If you repeat the **Save service files** function with the same file name, the previously saved group of service data files is overwritten. To avoid this, use another file name when you repeat the function.

### Saving service files


- Open the error window.



- Press the **LOG FILES** soft key



- Press the **SAVE SERVICE FILES** soft key: The TNC opens a pop-up window in which you can enter a file name or a complete path for the service file




- Save the service files: Press the **OK** soft key

## Calling the TNCguide help system

You can call the TNC's help system via soft key. Immediately the help system shows you the same error explanation that you receive by pressing the **HELP** soft key.



If your machine manufacturer also provides a help system, the TNC shows an additional **MACHINE MANUFACTURER (OEM)** soft key with which you can call this separate help system. There you will find further, more detailed information on the error message concerned.



- Call the help for HEIDENHAIN error messages



- Call the help for HEIDENHAIN machine-specific error messages, if available

## Programming aids

### 4.8 TNCguide context-sensitive help system

#### 4.8 TNCguide context-sensitive help system

##### Application



Before you can use the TNCguide, you need to download the help files from the HEIDENHAIN home page.

**Further Information:** "Downloading current help files", page 198

The **TNCguide** context-sensitive help system contains the user documentation in HTML format. The TNCguide is called with the **HELP** key, and the TNC sometimes immediately displays the information specific to the situation from which the help was called (context-sensitive call). Even if you are editing an NC block and press the **HELP** key, you are usually brought to the exact place in the documentation that describes the corresponding function.



The TNC always tries to start TNCguide in the language that you have selected as the conversational language on your TNC. If the files with this language are not yet available on your TNC, it automatically opens the English version.


The following user documentation is available in TNCguide:

- Conversational Programming User's Manual (**BHBKlartext.chm**)
- ISO User's Manual (**BHBIso.chm**)
- Cycle Programming User's Manual (**BHBtchprobe.chm**)
- List of All Error Messages (**errors.chm**)

In addition, the **main.chm** "book" file is available, with the contents of all existing .chm files.



As an option, your machine tool builder can embed machine-specific documentation in the **TNCguide**. These documents then appear as a separate book in the **main.chm** file.



## Working with TNCguide

### Call TNCguide

There are several ways to start the TNCguide:

- ▶ Press the **HELP** key.
- ▶ Click the help symbol at the lower right of the screen beforehand, then click the appropriate soft keys
- ▶ Open a help file (CHM file) via the file management. The TNC can open any .chm file, even if it is not saved on the TNC's internal memory




When the help system is called on the programming station, the TNC starts the internally defined standard browser.

For many soft keys there is a context-sensitive call through which you can go directly to the description of the soft key's function. This functionality requires using a mouse. Proceed as follows:

- ▶ Select the soft-key row containing the desired soft key
- ▶ Click with the mouse on the help symbol that the TNC displays just above the soft-key row: The mouse pointer turns into a question mark
- ▶ Move the question mark to the soft key for which you want an explanation, and click: The TNC opens TNCguide. If there is no entry point for the selected soft key, then the TNC opens the book file **main.chm**. You can search for the desired explanation using full text search or by using the navigation

Even if you are editing an NC block, context-sensitive help is available:

- ▶ Select any NC block
- ▶ Select the desired word
- ▶ Press the **HELP** button: The TNC opens the Help system and shows the description of the active function. This does not apply for miscellaneous functions or cycles from your machine manufacturer



## Programming aids













### 4.8 TNCguide context-sensitive help system





#### Navigating in the TNCguide

It's easiest to use the mouse to navigate in TNCguide. A table of contents appears on the left side of the screen. By clicking the rightward pointing triangle you open subordinate sections, and by clicking the respective entry you open the individual pages. It is operated in the same manner as the Windows Explorer.

Linked text positions (cross references) are shown underlined and in blue. Clicking the link opens the associated page.

Of course you can also operate TNCguide through keys and soft keys. The following table contains an overview of the corresponding key functions.

Soft key	Function
	<ul style="list-style-type: none"> <li>If the table of contents at left is active: Select the entry above it or below it</li> </ul>
	<ul style="list-style-type: none"> <li>If the text window on the right is active: Move the page downward or upward if texts or graphics are not shown completely</li> </ul>
	<ul style="list-style-type: none"> <li>If the table of contents at left is active: Open up the table of contents</li> <li>If the text window at right is active: No function</li> </ul>
	<ul style="list-style-type: none"> <li>If the table of contents at left is active: Close the table of contents</li> <li>If the text window at right is active: No function</li> </ul>
	<ul style="list-style-type: none"> <li>If the table of contents at left is active: Use the cursor key to show the selected page</li> <li>If the text window at right is active: If the cursor is on a link, jump to the linked page</li> </ul>
	<ul style="list-style-type: none"> <li>If the table of contents at left is active: Switch the tab between the display of the table of contents, display of the subject index, and the full-text search function and switching to the screen half at right</li> <li>If the text window at right is active: Jump back to the window at left</li> </ul>
	<ul style="list-style-type: none"> <li>If the table of contents at left is active: Select the entry above it or below it</li> </ul>
	<ul style="list-style-type: none"> <li>If the text window at right is active: Jump to next link</li> </ul>
	Select the page last shown
	Page forward if you have used the "Select page last shown" function
	Move up by one page
	Move down by one page

Soft key	Function
	Display or hide table of contents
	Switch between full-screen display and reduced display. With the reduced display you can see some of the rest of the TNC window
	The focus is switched internally to the TNC application so that you can operate the control when the TNCguide is open. If the full screen is active, the TNC reduces the window size automatically before the change of focus
	Exit TNCguide


## Subject index

The most important subjects in the Manual are listed in the subject index (**Index** tab). You can select them directly by mouse or with the arrow keys.

The left side is active.



- ▶ Select the **Index** tab
- ▶ Activate the **Keyword** entry field
- ▶ Enter the search word and the TNC synchronizes the subject index and creates a list in which you can find the subject more easily; or
- ▶ Use the arrow key to highlight the desired keyword
- ▶ Use the **ENT** key to call the information on the selected keyword



## Full-text search

In the **Find** tab you can search all of TNCguide for a specific word.

The left side is active.



- ▶ Select the **Find** tab
- ▶ Activate the **Find:** entry field
- ▶ Enter the desired word and confirm with the **ENT** key: The TNC lists all sources containing the word
- ▶ Use the arrow key to highlight the desired source
- ▶ Press the **ENT** key to go to the selected source



The full-text search only works for single words. If you activate the **Search only in titles** function (by mouse or by using the cursor and the space key), the TNC searches only through headings and ignores the body text.

## Programming aids

### 4.8 TNCguide context-sensitive help system

#### Downloading current help files

You'll find the help files for your TNC software on the HEIDENHAIN homepage:

**[http://content.heidenhain.de/doku/tnc\\_guide/html/en/index.html](http://content.heidenhain.de/doku/tnc_guide/html/en/index.html)**

Navigate to the suitable help file as follows:

- ▶ TNC Controls
- ▶ Series, e.g. TNC 600
- ▶ Desired NC software number, e.g. TNC 640 (34059x-07)
- ▶ Select the desired language version from the **TNCguide online help** table
- ▶ Download the ZIP file and unpack it
- ▶ Move the unzipped CHM files to the TNC in the **TNC:\tncguide-\en** directory or to the respective language subdirectory



If you want to use TNCremo to transfer the CHM files to the TNC, then in the **Extras > Configuration > Mode > Transfer in binary format** menu item you have to enter the extension **.CHM**.



Language	TNC directory
German	TNC:\tncguide\de
English	TNC:\tncguide\en
Czech	TNC:\tncguide\cs
French	TNC:\tncguide\fr
Italian	TNC:\tncguide\it
Spanish	TNC:\tncguide\es
Portuguese	TNC:\tncguide\pt
Swedish	TNC:\tncguide\sv
Danish	TNC:\tncguide\da
Finnish	TNC:\tncguide\fi
Dutch	TNC:\tncguide\nl
Polish	TNC:\tncguide\pl
Hungarian	TNC:\tncguide\hu
Russian	TNC:\tncguide\ru
Chinese (simplified)	TNC:\tncguide\zh
Chinese (traditional)	TNC:\tncguide\zh-tw
Slovenian	TNC:\tncguide\sl
Norwegian	TNC:\tncguide\no
Slovak	TNC:\tncguide\sk
Korean	TNC:\tncguide\kr
Turkish	TNC:\tncguide\tr
Romanian	TNC:\tncguide\ro



# 5

**Tools**


# 5 Tools

## 5.1 Entering tool-related data

### 5.1 Entering tool-related data

#### Feed rate F

The feed rate **F** is the speed at which the tool center point moves. The maximum feed rates can be different for the individual axes and are set in machine parameters.



#### Input

You can enter the feed rate in the **TOOL CALL** block and in every positioning block.

**Further Information:** "Creating the NC blocks with the path function keys", page 246

You enter the feed rate **F** in mm/min in millimeter programs, and in 1/10 inch/min in inch-programs, for resolution reasons. Alternatively, with the corresponding soft keys, you can also define the feed rate in mm per revolution (mm/1) **FU** or in mm per tooth (mm/tooth) **FZ**.

#### Rapid traverse

If you wish to program rapid traverse, enter **F MAX**. To enter **F MAX**, press the **ENT** key or the **F MAX** soft key when the dialog question **FEED RATE F = ?** appears on the control's screen.



To move your machine at rapid traverse, you can also program the corresponding numerical value, e.g. **F30000**. Unlike **F MAX**, this rapid traverse remains in effect not only in the individual block but in all blocks until you program a new feed rate.

#### Duration of effect

A feed rate entered as a numerical value remains in effect until a block with a different feed rate is reached. **F MAX** is only effective in the block in which it is programmed. After the block with **F MAX** is executed, the feed rate will return to the last feed rate entered as a numerical value.

#### Changing during program run

You can adjust the feed rate during the program run with the feed rate potentiometer **F**.

The feed rate potentiometer lowers the programmed feed rate, not the feed rate calculated by the control.

## Spindle speed S

The spindle speed S is entered in revolutions per minute (rpm) in a **TOOL CALL** block (tool call). Instead, you can also define the cutting speed Vc in meters per minute (m/min).

### Programmed change

In the part program, you can change the spindle speed in a **TOOL CALL** block by entering the new spindle speed only:



- ▶ Program a tool call: Press the **TOOL CALL** key
- ▶ Ignore the dialog question for **Tool number ?** with the **NO ENT** key
- ▶ Ignore the dialog question for **Working spindle axis X/Y/Z ?** with the **NO ENT** key
- ▶ Enter the new spindle speed for the dialog question **Spindle speed S= ?**, and confirm with **END**, or switch via the **VC** soft key to entry of the cutting speed.

### Changing during program run


You can adjust the spindle speed during program run with the spindle speed potentiometer S.

## 5.2 Tool data

### Requirements for tool compensation

You usually program the coordinates of path contours as they are dimensioned in the workpiece drawing. To allow the TNC to calculate the tool center path i.e. the tool compensation you must also enter the length and radius of each tool you are using.

Tool data can be entered either directly in the part program with **TOOL DEF** or separately in a tool table. In a tool table, you can also enter additional data for the specific tool. The TNC will consider all the data entered for the tool when executing the part program.



### Tool number, tool name

Each tool is identified by a number between 0 and 32767. If you are working with tool tables, you can also enter a tool name for each tool. Tool names can have up to 32 characters.



**Permitted special characters:** # \$ % & , - \_ . 0 1 2 3 4 5 6 7 8 9 @ A B C D E F G H I J K L M N O P Q R S T U V W X Y Z


The control automatically replaces lowercase letters with corresponding uppercase letters during saving.

**Impermissible characters:** <Leerzeichen> ! " ' ( ) \* + ; < = > ? [ / ] ^ ` { } ~

The tool number 0 is automatically defined as the zero tool with the length  $L=0$  and the radius  $R=0$ . In tool tables, tool T0 should also be defined with  $L=0$  and  $R=0$ .

### Tool length L

You should always enter the tool length  $L$  as an absolute value based on the tool reference point. The entire tool length is essential for the TNC in order to perform numerous functions involving multi-axis machining.



### Tool radius R

You can enter the tool radius  $R$  directly.

## Delta values for lengths and radii

Delta values are offsets in the length and radius of a tool.

A positive delta value describes a tool oversize (**DL**, **DR**>0). If you are programming the machining data with an allowance, enter the oversize value in the **TOOL CALL**.

A negative delta value describes a tool undersize (**DL**, **DR**<0). An undersize is entered in the tool table for wear.

Delta values are usually entered as numerical values. In a **TOOL CALL** block, you can also assign the values to Q parameters.


Input range: You can enter a delta value with up to  $\pm 99.999$  mm.



Delta values from the tool table influence the graphical representation of the clearing simulation. Delta values from the **TOOL CALL** block do not change the represented size of the **tool** during the simulation. However, the programmed delta values move the **tool** by the defined value in the simulation.



Delta values from the **TOOL CALL** block influence the position display depending on the optional machine parameter **progToolCallIDL** (no. 124501).



## Entering tool data into the program



The machine tool builder determines the scope of function of the **TOOL DEF** function. Refer to your machine manual.

The number, length and radius of a specific tool is defined in the **TOOL DEF** block of the part program:

- Select the tool definition: Press the **TOOL DEF** key



- **Tool number**: Each tool is uniquely identified by its tool number
- **Tool length**: Compensation value for the tool length
- **Tool radius**: Compensation value for the tool radius



In the programming dialog, you can transfer the value for tool length and tool radius directly into the input line by pressing the desired axis soft key.

### Example

```
4 TOOL DEF 5 L+10 R+5
```

### Enter tool data into the table

You can define and store up to 767 tools and their tool data in a tool table. Also see the editing functions later in this chapter. In order to be able to assign various compensation data to a tool(indexing the tool number), insert a line and extend the tool number by a dot and a number from 1 to 9 (e.g. **T 5.2**).

You must use tool tables if:

- you wish to use indexed tools such as stepped drills with more than one length compensation value
- your machine tool has an automatic tool changer
- If you want to work with the machining cycle 22,  
**Further information:** Cycle Programming User's Manual
- If you want to work with machining Cycles 251 to 254,  
**Further information:** Cycle Programming User's Manual



if you create or manage further tool tables, the file name has to start with a letter.

You can select either list view or form view for tables via the "Screen layout" key.

when you open the tool table you can also change its layout



Tool table: Standard tool data

Abbr.	Inputs	Dialog
<b>T</b>	Number by which the tool is called in the program (e.g. 5, indexed: 5.2).	-
<b>NAME</b>	Name by which the tool is called in the program (max. 32characters, all capitals, no spaces)	<b>Tool name?</b>
<b>L</b>	Compensation value for tool length L	<b>Tool length?</b>
<b>R</b>	Compensation value for the tool radius R	<b>Tool radius?</b>
<b>R2</b>	Tool radius R2 for toroid cutters (only for 3-D radius compensation or graphical representation of a machining operation with spherical or toroid cutters)	<b>Tool radius 2?</b>
<b>DL</b>	Delta value for tool length L	<b>Tool length oversize?</b>
<b>DR</b>	Delta value for tool radius R	<b>Tool radius oversize?</b>
<b>DR2</b>	Delta value for tool radius R2	<b>Tool radius oversize 2?</b>
<b>TL</b>	Set tool lock ( <b>TL</b> for <b>T</b> ool <b>L</b> ocked)	<b>Tool locked? Yes=ENT/ No=NOENT</b>
<b>RT</b>	Number of a replacement tool – if available – asreplacement tool ( <b>RT</b> : for <b>R</b> eplacement <b>T</b> ool) An empty field or input <b>0</b> means no replacement tool has been defined.	<b>Replacement tool?</b>
<b>TIME1</b>	Maximum tool life in minutes. This function can vary depending on the individual machine tool. Your machine manual provides more information	<b>Maximum tool age?</b>
<b>TIME2</b>	Maximum tool life in minutes during a tool call: If the current tool age reaches or exceeds this value, the TNC inserts the replacement tool during the next <b>TOOL CALL</b>	<b>Max. tool age for TOOL CALL?</b>
<b>CUR_TIME</b>	Current age of the tool in minutes: The TNC automatically counts the current tool life ( <b>CUR_TIME</b> : For <b>CUR</b> rent <b>TIME</b> ) A starting value can be entered for used tools	<b>Current tool age?</b>
<b>TYPE</b>	Tool type: Press the ENT key to edit the field; the GOTO key opens a window in which you can select the tool type. You can assign tool types to specify the display filter settings such that only the selected type is visible in the table	<b>Tool type?</b>
<b>DOC</b>	Comment on tool (max. 32 characters)	<b>Tool description</b>
<b>PLC</b>	Information on this tool that is to be sent to the PLC	<b>PLC status?</b>
<b>LCUTS</b>	Tooth length of the tool for Cycle 22	<b>Tooth length in the tool axis?</b>
<b>ANGLE</b>	Maximum plunge angle of the tool for reciprocating plunge-cut in Cycles 22 and 208	<b>Maximum plunge angle?</b>
<b>NMAX</b>	Limit the spindle speed for this tool. The programmed value is monitored (error message) as well as an increase in the shaft speed via the potentiometer. Function inactive: Enter -. <b>Input range:</b> 0 to +999, if function not active: enter -	<b>Maximum speed [rpm]</b>

Abbr.	Inputs	Dialog
LIFTOFF	<p>Definition of whether the TNC should retract the tool in the direction of the positive tool axis at an NC stop in order to avoid leaving dwell marks on the contour. If <b>Y</b> is defined, the TNC retracts the tool from the contour, provided M148 has been activated.</p> <p><b>Further Information:</b> "Automatically retract tool from the contour at an NC stop: M148", page 425</p>	Retract allowed? Yes=ENT/ No=NOENT
TP_NO	Reference to the number of the touch probe in the touch-probe table	Number of the touch probe
T-ANGLE	Point angle of the tool. Is used by the Centering cycle (Cycle 240) in order to calculate the centering depth from the diameter entry	Point angle
PITCH	Thread pitch of the tool. Used by tapping cycles (Cycle 206, Cycle 207 and Cycle 209). A positive algebraic sign means a right-hand thread.	Tool thread pitch?
AFC	<p>Control setting for the adaptive feed control from the <b>AFC.TAB</b>. In the tool table open the selection with the <b>SELECT</b> soft key and accept with <b>OK</b>. In the tool management open the selection with the <b>GOTO</b> soft key and accept with the <b>SELECT</b> soft key.</p> <p><b>Input range:</b> max. 10 characters</p>	Feedback-control strategy
AFC-LOAD	<p>Tool-dependent standard reference power for adaptive feed control AFC.</p> <p>The input in percent refers to the rated spindle power. The control immediately uses the value given for regulation, meaning a teach-in cut is dropped. The value should be previously determined with a teach-in cut.</p> <p><b>Further Information:</b> "Recording a teach-in cut", page 447</p>	Reference power for AFC [%]
AFC-OVLD1	<p>Cut-related tool wear monitoring for the adaptive feed control.</p> <p>The input in percent refers to the standard reference power. The value 0 deactivates the monitoring function. An empty field has no effect.</p> <p><b>Further Information:</b> "Tool wear monitoring", page 454</p>	AFC overload warning level [%]
AFC-OVLD2	<p>Cut-related tool load monitoring (tool breakage control) for the adaptive feed control.</p> <p>The input in percent refers to the standard reference power. The value 0 deactivates the monitoring function. An empty field has no effect.</p> <p><b>Further Information:</b> "Tool load monitoring", page 454</p>	AFC overload switch-off level [%]
LAST_USE	Date and time that the tool was last inserted via <b>TOOL CALL</b>	Date/time of last tool call
PTYP	<p>Tool type for evaluation in the pocket table</p> <p>Function is defined by the machine manufacturer. Refer to your machine manual.</p>	Tool type for pocket table?
ACC	<p>Activate or deactivate active chatter control for the respective tool (page 455).</p> <p><b>Input range:</b> N (inactive) and Y (active)</p>	ACC active? Yes=ENT/ No=NOENT

Abbr.	Inputs	Dialog
KINEMATIC	<p>Display tool carrier kinematics using the <b>SELECT</b> softkey and confirm file name and path with the <b>OK</b> (in tool management, display using the <b>GOTO</b> key and confirm with the <b>SELECT</b> soft key).</p> <p><b>Further Information:</b> "Allocate parameterized tool carriers", page 441</p>	Tool-carrier kinematics
DR2TABLE	<p>Display list of error compensation tables using the <b>SELECT</b> soft key and select error compensation table (without extension and path).</p> <p>The error compensation tables are saved under TNC: \system\3D-ToolComp.</p> <p><b>Further Information:</b> "3-D radius compensation depending on the tool's contact angle (option 92)", page 531</p>	Compensation val. table for DR2
OVRTIME	<p>Time for exceeding the tool life in minutes</p> <p><b>Further Information:</b> "Overtime for tool life", page 224</p> <p>Function is defined by the machine manufacturer. Refer to your machine manual.</p>	Tool life expired

Tool table: Tool data required for automatic tool measurement



For a description of the cycles governing automatic tool measurement,

**Further information:** Cycle Programming User's Manual

Abbr.	Inputs	Dialog
CUT	Number of teeth (99 teeth maximum)	Number of teeth?
LTOL	Permissible deviation from tool length L for wear detection. If the entered value is exceeded, the TNC locks the tool (status <b>L</b> ). Input range: 0 to 0.9999 mm	Wear tolerance: length?
RTOL	Permissible deviation from tool radius R for wear detection. If the entered value is exceeded, the TNC locks the tool (status <b>L</b> ). Input range: 0 to 0.9999 mm	Wear tolerance: radius?
R2TOL	Permissible deviation from tool radius R2 for wear detection. If the entered value is exceeded, the TNC locks the tool (status <b>L</b> ). Input range: 0 to 0.9999 mm	Wear tolerance: Radius 2?
DIRECT	Cutting direction of the tool for measuring the tool during rotation	Cutting direction? M4=ENT/ M3=NOENT
R-OFFS	Tool length measurement: Tool offset between stylus center and tool center. Default setting: No value entered (offset = tool radius)	Tool offset: radius?
L-OFFS	Tool radius measurement: tool offset in addition to <b>offsetToolAxis</b> between upper surface of stylus and lower surface of tool. Default: 0	Tool offset: length?
LBREAK	Permissible deviation from tool length <b>L</b> for breakage detection. If the entered value is exceeded, the TNC locks the tool (status <b>L</b> ). Input range: 0 to 3.2767 mm	Breakage tolerance: length?
RBREAK	Permissible deviation from tool radius R for breakage detection. If the entered value is exceeded, the TNC locks the tool (status <b>L</b> ). Input range: 0 to 0.9999 mm	Breakage tolerance: radius?



### Editing the tool table

The tool table that is active during execution of the part program is designated TOOL.T and must be saved in the **TNC:\table** directory.

Other tool tables that are to be archived or used for test runs are given different file names with the extension .T. By default, for the **Test run** and **Programming** modes the TNC also uses the TOOL.T tool table. In the **Test run** mode, press the **TOOL TABLE** soft key to edit it.

To open the tool table TOOL.T:

- ▶ Select any machine operating mode
  - ▶ Select the tool table: Press the **TOOL TABLE** soft key
- ▶ Set the **EDIT** soft key to **ON**



If you edit the tool table, the selected tool is locked. If this tool is required in the NC program being used, the TNC shows the message: **Tool table locked**.

If a new tool is created the length and radius columns remain empty until you enter values. If it is attempted to insert such a newly created tool, the control aborts with an error message. This means you cannot insert a tool for which no data has been entered.

### Displaying only specific tool types (filter setting)

- ▶ Press the **TABLE FILTER** soft key
- ▶ Select the tool type by pressing a soft key: The TNC only shows tools of the type selected
- ▶ Cancel the filter: Press the **SHOW ALL** soft key



The machine tool builder adapts the features of the filter function to the requirements of your machine. Refer to your machine manual.

## 5.2 Tool data

**Hiding or sorting the tool table columns**

You can adapt the layout of the tool table to your needs. Columns that are not to be displayed can be simply hidden:

- ▶ Press the **HIDE/ SORT/ COLUMNS** soft key
- ▶ Select the appropriate column name with the arrow key
- ▶ Press the **HIDE COLUMN** soft key to remove this column from the table view

You can also modify the sequence of columns in the table:

- ▶ You can also modify the sequence of columns in the table with the **Move before:** dialog. The entry highlighted in **Displayed columns:** is moved in front of this column

You can use a connected mouse or the TNC keyboard to navigate in the form. Navigation using the TNC keyboard:



- ▶ Press the navigation keys to go to the input fields. Use the arrow keys to navigate within an input field. To open pop-down menus, press the **GOTO** key.



The function **freeze number of columns** enables you to determine how many columns (0-3) the control will freeze to the left border of the screen. These columns are also displayed if you navigate in the table to the right.







**Opening any other tool table**













- ▶ Select the **Programming** operating mode



- ▶ To call the file manager, press the PGM MGT key
- ▶ Select a file or enter a new file name. Confirm your entry with the **ENT** key or the soft key **SELECT**

When you have opened the tool table, you can edit the tool data by moving the cursor to the desired position in the table with the arrow keys or the soft keys. You can overwrite the stored values, or enter new values at any position. Additional functions are illustrated in the table below.

Soft key	Editing functions for tool tables
	Select the table start
	Select the table end
	Select the previous page in the table
	Select the next page in the table
	Find the text or number
	Move to beginning of line

Soft key	Editing functions for tool tables
	Move to end of line
	Copy highlighted field
	Insert copied field
	Add the entered number of lines (tools) at the end of the table
	Adding a row with tool number for entering
	Delete the current line (tool)
	Sort the tools according to the content of a column
	Select possible entries from a pop-up window
	Show all drills in the tool table
	Show all cutters in the tool table
	Show all taps/thread cutters in the tool table
	Show all touch probes in the tool table

### Exiting any other tool table

- Call the file manager and select a file of a different type, such as a part program

### Tool table for turning tools

When managing turning tools, different geometric descriptions to those for milling or drilling tools are considered. To be able to execute tool radius compensation, for example, you have to define the tool radius. The TNC provides special tool management for turning tools to support this definition process.

**Further Information:** "Tool data", page 559

## 5.2 Tool data

## Importing tool tables



Refer to your machine manual. The machine manufacturer can adapt the **IMPORT TABLE** function.

If you export a tool table from an iTNC 530 and import it into a TNC 640, you have to adapt its format and content before you can use the tool table. On the TNC 640, you can adapt the tool table conveniently with the **IMPORT TABLE** function. The TNC converts the contents of the imported tool table to a format valid for the TNC 640 and saves the changes to the selected file.

Follow this procedure:

- ▶ Save the tool table of the iTNC 530 to the **TNC:\table** directory




- ▶ Select the operating mode: Press the **Programming** key



- ▶ Call the file manager: Press the **PGM MGT** key



- ▶ Move the cursor to the tool table you want to import



- ▶ Press the **MORE FUNCTIONS** soft key



- ▶ Shift the soft key row



- ▶ Press the **IMPORT TABLE** soft key: The TNC inquires whether you really want to overwrite the selected tool table

- ▶ Do not overwrite the file: Press the **CANCEL** soft key; or
- ▶ Overwrite the file: Press the **OK** soft key
- ▶ Open the converted table and check its contents
- ▶ New columns in the tool table are highlighted green
- ▶ Press the **REMOVE UPDATE INFORMATION** soft key: The green columns are displayed in white again





The following characters are permitted in the **Name** column of the tool table: # \$ % & , - . 0 1 2 3 4 5 6 7 8 9 @ A B C D E F G H I J K L M N O P Q R S T U V W X Y Z \_

The TNC changes a comma in the tool name to a period during import.

The TNC overwrites the selected tool table when running the **IMPORT TABLE** function. To avoid losing data, be sure to make a backup copy of your original tool table before importing it!

The procedure for copying tool tables using the TNC file manager is described in the section on file management.

**Further Information:** "Copying a table", page 155

When tool tables are imported from an iTNC 530, all existing tools are imported along with their corresponding tool type. Tool types not present are imported as type **Undefined**. Check the tool table after the import.

### Overwriting tool data from an external PC

#### Application

The HEIDENHAIN data transfer software TNCremo provides an especially convenient way to use an external PC to overwrite tool data.

**Further Information:** "Software for data transfer", page 713

This application case occurs e.g. if you wish to determine tool data on an external tool presetter and then transfer this to the TNC.

#### Requirements

In addition to option 18 HEIDENHAIN DNC, TNCremo (from version 3.1) is required with TNCremoPlus functions.

#### Procedure

- ▶ Copy the tool table TOOL.T to the TNC, for example to TST.T
- ▶ Start the data transfer software TNCremo on the PC
- ▶ Establish a connection with the TNC
- ▶ Transfer the copied tool table TST.T to the PC
- ▶ Use any text editor to reduce TST.T to the lines and columns to be changed (see figure). Make sure that the header is not changed and the data is always flush in the column. The tool number (column T) need not be consecutive
- ▶ In TNCremo, select the menu item <Extras> and <TNCcmd>: This starts TNCcmd.
- ▶ To transfer TST.T to the TNC, enter the following command and confirm with the return key (see figure): put tst.t tool.t /m



During transfer, only the tool data defined in the subfile (e.g. TST.T) is overwritten. All other tool data of the table TOOL.T remains unchanged.

The procedure for copying tool tables using the TNC file manager is described in the file management.

**Further Information:** "Copying a table", page 155

BEGIN TST	.T MM		
T	NAME	L	R
1		+12.5	+9
3		+23.15	+3.5
[END]			

```

TNC640(340594) - TNCcmd
TNCcmdPlus - WIN32 Command Line Client for HEIDENHAIN Controls - Version: 5.92
Connecting with TNC640(340594) (192.168.56.101)
Connection established with TNC640, NC Software 340595 0T Dev
TNC:\nc_prog\> put tst.t tool.t /m
  
```

## Pocket table for tool changer



Refer to your machine manual. The machine tool builder adapts the features of the pocket table to the requirements of your machine.


For automatic tool changing you need the a pocket table. You manage the assignment of your tool changer in the pocket table. The pocket table is in the **TNC:\TABLE** directory. The machine manufacturer can amend the name, path and content of the pocket table. If you wish, you can select different views using the soft keys in the **TABLE FILTER** menu.

P	T	TNAME	RSV	ST	F	L	DOC
0.0	5.010						
1.1	1.02						
1.2	2.04						
1.3	3.06						
1.4	4.08						
1.5	5.010						
1.6	6.012						
1.7	7.014						
1.8	8.016						
1.9	9.018						
1.10	10.020						
1.11	11.022						
1.12	12.024						
1.13	13.026						
1.14	14.028						
1.15	15.030						
1.16	16.032						
1.17	17.034						
1.18	18.036						
1.19	19.038						
1.20	20.040						
1.21	21.042						
1.22	22.044						
1.23	23.046						
1.24	24.048						
1.25	25.050						
1.26	26.052						

### Editing a pocket table in a Program Run operating mode



- Select the tool table: Press the **TOOL TABLE** soft key



- Select the pocket table: Press the **POCKET TABLE** soft key















- Set the **EDIT** soft key to **ON**. On your machine this might not be necessary or even possible. Refer to your machine manual

### Selecting a pocket table in Programming mode



- To call the file manager, press the **PGM MGT** key.
- Display the file types: Press the **SHOW ALL** soft key
- Select a file or enter a new file name. Confirm your entry with the **ENT** key or the soft key **SELECT**

Abbr.	Inputs	Dialog
<b>P</b>	Pocket number of the tool in the tool magazine	-
<b>T</b>	Tool number	<b>Tool number?</b>
<b>RSV</b>	Pocket reservation for box magazines	<b>Pocket reserv.: Yes = ENT / No = NO ENT</b>
<b>ST</b>	Special tool ( <b>ST</b> ); If your special tool blocks pockets in front of and behind its actual pocket, these additional pockets need to be locked in column L (status L).	<b>Special tool?</b>
<b>F</b>	The tool is always returned to the same pocket in the tool magazine	<b>Fixed pocket? Yes = ENT / No = NO ENT</b>
<b>L</b>	Locked pocket ( <b>L</b> : for <b>L</b> ocked)	<b>Pocket locked Yes = ENT / No = NO ENT</b>
<b>DOC</b>	Display of the comment to the tool from TOOL.T	-
<b>PLC</b>	Information on this tool pocket that is to be sent to the PLC	<b>PLC status?</b>
<b>P1 ... P5</b>	Function is defined by the machine tool builder. The machine tool documentation provides further information	<b>Value?</b>
<b>PTYP</b>	Tool type. Function is defined by the machine tool builder. The machine tool documentation provides further information	<b>Tool type for pocket table?</b>
<b>LOCKED_ABOVE</b>	Box magazine: Lock the pocket above	<b>Lock the pocket above?</b>
<b>LOCKED_BELOW</b>	Box magazine: Lock the pocket below	<b>Lock the pocket below?</b>
<b>LOCKED_LEFT</b>	Box magazine: Lock the pocket at left	<b>Lock the pocket at left?</b>
<b>LOCKED_RIGHT</b>	Box magazine: Lock the pocket at right	<b>Lock the pocket at right?</b>

Soft key	Editing functions for pocket tables
	Select the table start
	Select the table end
	Select the previous page in the table
	Select the next page in the table
	Reset pocket table
	Reset tool number T column
	Go to beginning of the line
	Go to end of the line
	Simulate a tool change
	Select a tool from the tool table: The TNC shows the contents of the tool table. Use the arrow keys to select a tool, press <b>OK</b> to transfer it to the pocket table
	Edit the current field
	Sort the view



The machine manufacturer defines the features, properties and designations of the various display filters. Refer to your machine manual.

### Call tool data

A **TOOL CALL** in the part program is defined with the following data:

- ▶ Select the tool call function with the **TOOL CALL** key

TOOL  
CALL

- ▶ **Tool number**: Enter the number or name of the tool. The tool must already be defined in a **TOOL DEF** block or in the tool table. With the **TOOL NAME** soft key you can enter a name. With the **QS** soft key you enter a string parameter. The TNC automatically places the tool name in quotation marks. You have to assign a tool name to a string parameter first. Names always refer to an entry in the active tool table TOOL .T. If you wish to call a tool with other compensation values, also enter the index you defined in the tool table after the decimal point. There is a **SELECT** soft key for calling a window from which you can select a tool defined in the tool table TOOL.T directly without having to enter the number or name
- ▶ **Working spindle axis X/Y/Z**: Enter the tool axis
- ▶ **Spindle speed S**: Enter the spindle speed S in revolutions per minute (rpm). Instead, you can define the cutting speed Vc in meters per minute (m/min). Press the **VC** soft key
- ▶ **Feed rate F**: Enter feed rate **F** in millimeters per minute (mm/min). Alternatively, you can define the feed rate in millimeters per revolution, (mm/1) **FU** or in millimeters per tooth (mm/tooth) **FZ**. The feed rate is effective until you program a new feed rate in a positioning block or in a **TOOL CALL** block
- ▶ **Tool length oversize DL**: Enter the delta value for the tool length
- ▶ **Tool radius oversize DR**: Enter the delta value for the tool radius
- ▶ **Tool radius oversize DR2**: Enter the delta value for tool radius 2



If you open a pop-up window for tool selection, the TNC marks all tools available in the tool magazine green.

You can also search for a tool in the pop-up window. To do so, press the **GOTO** or **FIND** soft key and enter the tool number or tool name. With the **OK** soft key you can load the tool into the dialog box.

### Example: Tool call

Call tool number 5 in the tool axis Z with a spindle speed 2500 rpm and a feed rate of 350 mm/min. The tool length and tool radius 2 are to be programmed with an oversize of 0.2 and 0.05 mm, the tool radius with an undersize of 1 mm.

```
20 TOOL CALL 5.2 Z S2500 F350 DL+0.2 DR-1 DR2+0.05
```

The character **D** preceding **L**, **R** and **R2** designates delta values.

### Preselection of tools



The preselection of tools with **TOOL DEF** can vary depending on the individual machine. Refer to your machine manual.

If you are working with tool tables, use a **TOOL DEF** block to preselect the next tool. Simply enter the tool number or a corresponding Q parameter, or type the tool name in quotation marks.

## 5.2 Tool data

### Tool change

#### Automatic tool change



The tool change function can vary depending on the individual machine tool. Refer to your machine manual.

If your machine tool has automatic tool changing capability, the program run is not interrupted. When the TNC reaches a tool call with **TOOL CALL**, it replaces the inserted tool by another from the tool magazine.

#### Automatic tool change if the tool life expires: M101



The function of **M101** can vary depending on the individual machine tool. Refer to your machine manual.

When the specified tool life has expired, the TNC can automatically insert a replacement tool and continue machining with it. Activate the miscellaneous function **M101** for this. **M101** is reset with **M102**.

Enter the respective tool life after which machining is to be continued with a replacement tool in the **TIME2** column of the tool table. In the **CUR\_TIME** column the TNC enters the current tool life. If the current tool life is higher than the value entered in the **TIME2** column, a replacement tool will be inserted at the next possible point in the program no later than one minute after expiration of the tool life. The change is made only after the NC block has been completed.

The TNC performs the automatic tool change at a suitable point in the program. The automatic tool change is not performed:

- During execution of machining cycles
- While radius compensation (**RR/RL**) is active
- Directly after an approach function **APPR**
- Directly before a departure function **DEP**
- Directly before and after **CHF** and **RND**
- During execution of macros
- During execution of a tool change
- Directly after a **TOOL CALL** or **TOOL DEF**
- During execution of SL cycles





**Caution: Danger to the workpiece and tool!**

Switch off the automatic tool change with **M102** if you are working with special tools (e.g. side mill cutter) because the TNC at first always moves the tool away from the workpiece in tool axis direction.

Depending on the NC program, the machining time can increase as a result of the tool life verification and calculation of the automatic tool change. You can influence this with the optional entry element **BT** (block tolerance).

If you enter the **M101** function, the TNC continues the dialog by requesting the **BT**. Here you define the number of NC blocks (1 - 100) by which the automatic tool change may be delayed. The resulting time period by which the tool change is delayed depends on the content of the NC blocks (e.g. feed rate, path). If you do not define **BT**, the TNC uses the value 1 or, if applicable, a default value defined by the machine manufacturer.



The more you increase the value of **BT**, the smaller will be the effect of an extended program duration through **M101**. Please note that this will delay the automatic tool change!

Use the formula **BT = 10: Average machining time of an NC block in seconds** to calculate a suitable starting value for **BT**. Round up to the next odd integer. If the calculated result is greater than 100, use the maximum input value of 100.

If you want to reset the current age of a tool (e.g. after changing the indexable inserts), enter the value 0 in the CUR\_TIME column.

The **M101** function is not available for turning tools and in turning mode.

## 5.2 Tool data

### Overtime for tool life



Refer to your machine manual.

This feature must be enabled and adapted by the machine tool builder.

The tool condition at the end of planned tool life depends on e.g. the tool type, machining method and workpiece material. In the **OVRTIME** column of the tool table, enter the time in minutes for which the tool is permitted to be used beyond the tool life.

The machine manufacturer specifies whether this column is enabled and how it is used during tool search.

### Prerequisites for NC blocks with surface-normal vectors and 3-D compensation

The active radius (**R + DR**) of the replacement tool must not deviate from the radius of the original tool. You can enter the delta values (**DR**) either in the tool table or in the **TOOL CALL** block. With deviations, the TNC displays an error message and does not replace the tool. You can suppress this message with the M function **M107**, and reactivate it with **M108**.

**Further Information:** "Three-dimensional tool compensation (option 9)", page 523

## Tool usage test

### Requirements



The tool usage test function must be enabled by your machine manufacturer.  
Refer to your machine manual.



The tool usage test function is not available for turning tools.

To conduct a tool usage test, you must activate **Create tool usage files** in the MOD menu.

**Further Information:** "Tool usage file", page 704

### Generate a tool usage file

Depending on the setting in the MOD menu, you have the following options for generating the tool usage file:

- Completely simulate the NC program in the **Test run** operating mode
- Completely run the NC program in the **Program Run, Full Sequence/Single Block** operating modes
- In the **Test run** operating mode press the **GENERATE TOOL USAGE FILE** soft key (also possible without simulation)

The tool usage file generated is in the same directory as the NC program. It contains the following information:

Column	Meaning
<b>TOKEN</b>	<ul style="list-style-type: none"> <li>■ <b>TOOL</b>: Tool usage time per tool call. The entries are listed in chronological order.</li> <li>■ <b>TTOTAL</b>: Total usage time of a tool</li> <li>■ <b>STOTAL</b>: Call of a subprogram. The entries are listed in chronological order.</li> <li>■ <b>TIMETOTAL</b>: The total machining time of the NC program is entered in the <b>WTIME</b> column. In the <b>PATH</b> column the TNC saves the path name of the corresponding NC programs. The <b>TIME</b> column shows the sum of all <b>TIME</b> entries (feed time without rapid traverse movements). The TNC sets all other columns to 0</li> <li>■ <b>TOOLFILE</b>: In the <b>PATH</b> column, the TNC saves the path name of the tool table with which you conducted the test run. This enables the TNC during the actual tool usage test to detect whether you performed the test run with the TOOL.T</li> </ul>
<b>TNR</b>	Tool number (-1: Tool not inserted yet)
<b>IDX</b>	Tool index
<b>NAME</b>	Tool name from the tool table

## Tools

### 5.2 Tool data

Column	Meaning
<b>TIME</b>	Tool usage time in seconds (feed time without rapid traverse movements)
<b>WTIME</b>	Tool-usage time in seconds (total usage time between tool changes)
<b>RAD</b>	<b>Tool radius R + Oversize of tool radius DR</b> from the tool table. (in mm)
<b>BLOCK</b>	Block number in which the <b>TOOL CALL</b> block was programmed
<b>PATH</b>	<ul style="list-style-type: none"> <li>■ <b>TOKEN = TOOL</b>: Path name of the active main program or subprogram</li> <li>■ <b>TOKEN = STOTAL</b>: Path name of the subprogram</li> </ul>
<b>T</b>	Tool number with tool index
<b>OVRMAX</b>	Maximum feed rate override that occurred during machining. The TNC enters the value 100 (%) during the test run
<b>OVRMIN</b>	Minimum feed rate override that occurred during machining. During Test Run the TNC enters the value -1
<b>NAMEPROG</b>	<ul style="list-style-type: none"> <li>■ 0: The tool number is programmed</li> <li>■ 1: The tool name is programmed</li> </ul>

The TNC saves the tool usage times in a separate file with the extension **pgmname.H.T.DEP**. This file is not visible unless the machine parameter **dependentFiles** (no. 122101) is set to **MANUAL**

There are two ways to run a tool usage test for a pallet file:


- The highlight in the pallet file is on a pallet entry: The TNC runs the tool usage test for the entire pallet
- The highlight in the pallet file is on a pallet entry: The TNC runs the tool usage test for the entire pallet

#### Using a tool usage test

Before starting a program in the **Program Run, Full Sequence/Single Block** operating modes, you can use the **TOOL USAGE** and **TOOL USAGE TEST** soft keys to check whether the tools being used in the selected program are available and have sufficient remaining service life. The TNC then compares the actual service-life values in the tool table with the nominal values from the tool usage file.

After you have pressed the **TOOL USAGE TEST** soft key, the TNC displays the result of the tool usage test in a pop-up window. To close the pop-up window, press the **ENT** key.

You can query the tool usage test with the **FN18 ID975 NR1** function.




## 5.3 Tool compensation

### Introduction

The TNC adjusts the tool path by the compensation value for the tool length in the spindle axis. In the machining plane, it compensates the tool radius.

If you are writing the part program directly on the TNC, the tool radius compensation is effective only in the working plane.

The TNC accounts for the compensation value in up to six axes including the rotary axes.



### Tool length compensation

Length compensation becomes effective automatically as soon as a tool is called. To cancel length compensation, call a tool with the length  $L=0$  (e.g. **TOOL CALL 0**).



#### **Danger of collision!**

If you cancel a positive length compensation with **TOOL CALL 0** the distance between tool and workpiece will be reduced.

After **TOOL CALL** the path of the tool in the spindle axis, as entered in the part program, is adjusted by the difference between the length of the previous tool and that of the new one.

For tool length compensation, the control takes the delta values from both the **TOOL CALL** block and the tool table into account:

Compensation value =  $L + DL_{\text{TOOL CALL}} + DL_{\text{TAB}}$  with

**L**: Tool length **L** from **TOOL DEF** block or tool table

**DL<sub>TOOL CALL</sub>**: Oversize for length **DL** in the **TOOL CALL** block

**DL<sub>TAB</sub>**: Oversize for length **DL** in the tool table

### 5.3 Tool compensation

#### Tool radius compensation

The block for programming a tool movement contains:

- **RL** or **RR** for radius compensation
- **R0**, if there is no radius compensation

The radius compensation is effective as soon as a tool is called and traversed with a straight line block in the working plane with **RL** or **RR**.



The TNC automatically cancels radius compensation if you:

- program a straight line block with **R0**
- depart the contour with the **DEP** function
- Select a new program with **PGM MGT**

For radius compensation, the TNC takes the delta values from both the **TOOL CALL** block and the tool table into account:

Compensation value = **R** + **DR<sub>TOOL CALL</sub>** + **DR<sub>TAB</sub>** with

**R:** Tool radius **R** from **TOOL DEF** block or tool table



**DR<sub>TOOL CALL</sub>:** Oversize for radius **DR** in the **TOOL CALL** block

**DR<sub>TAB</sub>:** Oversize for radius **DR** in the tool table

#### Contouring without radius compensation: **R0**

The tool center moves on the machining plane along the programmed path onto the programmed coordinates.

Applications: Drilling and boring, pre-positioning



### Contouring with radius compensation: RR and RL

**RR:** The tool moves to the right of the programmed contour

**RL:** The tool moves to the left of the programmed contour


The tool center moves along the contour at a distance equal to the radius. "Right" or "left" are to be understood as based on the direction of tool movement along the workpiece contour.



Between two program blocks with different radius compensations **RR** and **RL** you must program at least one traversing block in the working plane without radius compensation (that is, with **R0**).

The TNC does not put radius compensation into effect until the end of the block in which it is first programmed.

In the first block in which radius compensation is activated with **RR/RL** or canceled with **R0** the TNC always positions the tool perpendicular to the programmed starting or end position. Position the tool at a sufficient distance from the first or last contour point to prevent the possibility of damaging the contour.



### Entering radius compensation

Radius compensation is entered in an **L** block. Enter the coordinates of the target point and confirm your entry with the **ENT** key.

#### RADIUS COMP.: RL/RR/NO COMP.?

- |          |   |
|----------|---|
| RL       | ▶ Select tool movement to the left of the contour:<br>Press the <b>RL</b> soft key, or                        |
| RR       | ▶ Select tool movement to the right of the contour:<br>Press the <b>RR</b> soft key, or                       |
| ENT      | ▶ Select tool movement without radius compensation or cancel radius compensation:<br>Press the <b>ENT</b> key |
| END<br>□ | ▶ Terminate the block: Press the <b>END</b> key   |

### 5.3 Tool compensation



#### Radius compensation: Machining corners

- Outside corners:  
If you program radius compensation, the TNC moves the tool around outside corners on a transitional arc. If necessary, the TNC reduces the feed rate at outside corners to reduce machine stress, for example at very great changes of direction.
- Inside corners:  
The TNC calculates the intersection of the tool center paths at inside corners under radius compensation. From this point it then starts the next contour element. This prevents damage to the workpiece at the inside corners. The permissible tool radius is therefore limited by the geometry of the programmed contour



#### **Danger of collision!**

To prevent the tool from damaging the contour, be careful not to program the starting or end position for machining inside corners at a corner of the contour.





## 5.4 Tool management (option number 93)

### Basics



Refer to your machine manual. Tool management is a machine-dependent function, which may be partly or completely deactivated. The machine tool builder defines the exact range of functions.

In tool management, your machine manufacturer can provide a wide range of functions for tool handling. Examples:

- Easily readable and, if you desired, adaptable representation of the tool data in fillable forms
- Any description of the individual tool data in the new table view
- Mixed representation of data from the tool table and the pocket table
- Fast sorting of all tool data by mouse
- Use of graphic aids, e.g. color coding of tool or magazine status
- Program-specific list of all available tools
- Program-specific usage sequence of all tools
- Copying and pasting of all tool data pertaining to a tool
- Graphic depiction of tool type in the table view and in the detail view for a better overview of the available tool types



If you edit a tool in tool management, the selected tool is locked. If this tool is required in the NC program being used, the TNC shows the message:  
**Tool table locked.**

The screenshot shows the 'Expanded tool management' window with a table of tool data. The table has columns for 'TYP', 'NAME', 'P/F', 'T/L', 'POCKET', 'MAGAZINE', 'TOOL LIFE', and 'REMAINING LIFE'. The data is organized into rows, with some rows highlighted in green and others in blue. The interface also includes a 'Programming' tab and various control buttons at the bottom.

TYP	NAME	P/F	T/L	POCKET	MAGAZINE	TOOL LIFE	REMAINING LIFE
1	D2	0	0	0	0	Not monitored	0
2	D4	0	0	0	0	Not monitored	0
3	D6	0	0	0	0	Not monitored	0
4	D8	0	0	0	0	Not monitored	0
5	D10	0	0	0	0	Not monitored	0
6	D12	0	0	0	0	Not monitored	0
7	D14	0	0	0	0	Not monitored	0
8	D16	0	0	0	0	Not monitored	0
9	D18	0	0	0	0	Not monitored	0
10	D20	0	0	0	0	Not monitored	0
11	D22	0	0	0	0	Not monitored	0
12	D24	0	0	0	0	Not monitored	0
13	D26	0	0	0	0	Not monitored	0
14	D28	0	0	0	0	Not monitored	0
15	D30	0	0	0	0	Not monitored	0
16	D32	0	0	0	0	Not monitored	0
17	D34	0	0	0	0	Not monitored	0
18	D36	0	0	0	0	Not monitored	0
19	D38	0	0	0	0	Not monitored	0
20	D40	0	0	0	0	Not monitored	0
21	D42	0	0	0	0	Not monitored	0
22	D44	0	0	0	0	Not monitored	0
23	D46	0	0	0	0	Not monitored	0
24	D48	0	0	0	0	Not monitored	0
25	D50	0	0	0	0	Not monitored	0
26	D52	0	0	0	0	Not monitored	0
27	D54	0	0	0	0	Not monitored	0
28	D56	0	0	0	0	Not monitored	0
29	D58	0	0	0	0	Not monitored	0
30	D60	0	0	0	0	Not monitored	0
31	D62	0	0	0	0	Not monitored	0
32	D64	0	0	0	0	Not monitored	0
33	D66	0	0	0	0	Not monitored	0
34	D68	0	0	0	0	Not monitored	0
35	D70	0	0	0	0	Not monitored	0
36	D72	0	0	0	0	Not monitored	0
37	D74	0	0	0	0	Not monitored	0
38	D76	0	0	0	0	Not monitored	0
39	D78	0	0	0	0	Not monitored	0
40	D80	0	0	0	0	Not monitored	0
41	D82	0	0	0	0	Not monitored	0
42	D84	0	0	0	0	Not monitored	0
43	D86	0	0	0	0	Not monitored	0
44	D88	0	0	0	0	Not monitored	0
45	D90	0	0	0	0	Not monitored	0
46	D92	0	0	0	0	Not monitored	0
47	D94	0	0	0	0	Not monitored	0
48	D96	0	0	0	0	Not monitored	0
49	D98	0	0	0	0	Not monitored	0
50	D100	0	0	0	0	Not monitored	0

## 5.4 Tool management (option number 93)

### Calling tool management



The tool management call can differ as described below. Refer to your machine manual.



- ▶ Select tool table: Press the **TOOL TABLE** soft key



- ▶ Scroll through the soft-key row



- ▶ Select the **TOOL MANAGEMENT** soft key: The TNC moves to the new table view

Expanded tool management

Tool	NAME	TYPE	TL	POCKET	MAGAZINE	Tool life	REMAINING LIFE
1	02	0	0	0	0	Not monitored	0
2	04	0	0	0	0	Not monitored	0
3	06	0	0	0	0	Not monitored	0
4	08	0	0	0	0	Not monitored	0
5	10	0	0	0	0	Not monitored	0
6	12	0	0	0	0	Not monitored	0
7	14	0	0	0	0	Not monitored	0
8	16	0	0	0	0	Not monitored	0
9	18	0	0	0	0	Not monitored	0
10	20	0	0	0	0	Not monitored	0
11	22	0	0	0	0	Not monitored	0
12	24	0	0	0	0	Not monitored	0
13	26	0	0	0	0	Not monitored	0
14	28	0	0	0	0	Not monitored	0
15	30	0	0	0	0	Not monitored	0
16	32	0	0	0	0	Not monitored	0
17	34	0	0	0	0	Not monitored	0
18	36	0	0	0	0	Not monitored	0
19	38	0	0	0	0	Not monitored	0
20	40	0	0	0	0	Not monitored	0
21	42	0	0	0	0	Not monitored	0
22	44	0	0	0	0	Not monitored	0
23	46	0	0	0	0	Not monitored	0
24	48	0	0	0	0	Not monitored	0
25	50	0	0	0	0	Not monitored	0
26	52	0	0	0	0	Not monitored	0
27	54	0	0	0	0	Not monitored	0
28	56	0	0	0	0	Not monitored	0
29	58	0	0	0	0	Not monitored	0
30	60	0	0	0	0	Not monitored	0
31	62	0	0	0	0	Not monitored	0
32	64	0	0	0	0	Not monitored	0

Buttons: BEGIN, END, PAGE, PAGE, MAGAZINE MANAGEMENT, FORM FOR TOOL, END
















### Tool management view


In the new view, the TNC presents all tool information in the following four tabs:

- **Tools:** Tool specific information
- **pockets:** Pocket-specific information
- **Assembly list:** List of all tools in the NC program that is selected in the Program Run mode (only if you have already created a tool usage file)  
**Further Information:** "Tool usage test", page 225
- **T usage sequence:** List of the sequence of all tools that are inserted in the program selected in the Program Run mode (only if you have already created a tool usage file)  
**Further Information:** "Tool usage test", page 225

## Editing tool management

The tool management can be operated by mouse or with the keys and soft keys:

Soft key	Editing functions for tool management
	Select the table start
	Select the table end
	Select the previous page in the table
	Select the next page in the table
	Call the form view of the marked tool. Alternative function: Press the <b>ENT</b> key
	Changing tab: <b>Tools, Pockets, Assembly list, T usage sequence</b>
	Search function: Here you can select the column to be searched and then the search term either from a list or by entering it
	Import tools
	Export tools
	Delete marked tools
	Add several lines at end of table
	Update table view
	Show the programmed tools column (if the <b>Pockets</b> tab is active)
	Define the settings: <ul style="list-style-type: none"> <li>■ <b>SORT COLUMN</b> active: Click the column header to sort the content of the column</li> <li>■ <b>SHIFT COLUMN</b> active: The column can be moved by drag and drop</li> </ul>
	Reset the manually changed settings (move columns) to the original condition



## 5.4 Tool management (option number 93)



You can edit the tool data only in the form view, which you can activate by pressing the **FORM FOR TOOL** soft key or the **ENT** key for the currently highlighted tool.

If you use the tool management without a mouse, then you can activate and deactivate functions with the "-/+" key.











In the tool management, use the **GOTO** soft key to search for the tool number or pocket number.

In addition, you can perform the following functions by mouse:

- Sorting function. You can sort the data in ascending or descending order (depending on the active setting) by clicking a column of the table head.
- Arrange columns. You can arrange the columns in any sequence you want by clicking a column of the table head and then moving it with the mouse key pressed down. The TNC does not save the current column sequence when you exit the tool management (depending on the active setting).
- Show miscellaneous information in the form view: The TNC displays tool tips when you leave the mouse pointer on an active entry field for more than a second and when you have set the **EDIT ON/OFF** soft key to **ON**

### Editing with active form view

If the form view is active, the following functions are available to you:

Soft key	Editing functions, form view
	Select the tool data of the previous tool
	Select the tool data of the next tool
	Select previous tool index (only active if indexing is enabled)
	Select the next tool index (only active if indexing is enabled)
	Discard all changes made since the form was called
	Calculate the measured values of tool compensation
	Add tool index
	Delete tool index
	Copy the tool data of the selected tool
	Insert the copied tool data in the selected tool

### Deleting marked tool data

Using this function you can simply delete tool data that you no longer need.

Follow the steps outlined below for deleting:

- ▶ In the tool management you use the arrow keys or mouse to mark the tool data that you wish to delete
- ▶ Select the **DELETE MARKED TOOLS** soft key and the TNC shows a pop-up window listing the tool data to be deleted
- ▶ Press the **START** soft key to start the delete process: The TNC shows the status of the delete process in a pop-up window
- ▶ Terminate the delete process by pressing the **END** key or soft key














- The TNC deletes all the data of all the tools selected. Make sure that you really no longer need the tool data, because there is no Undo function available.
- You cannot delete the tool data of tools still stored in the pocket table. First remove the tool from the magazine.







## 5.4 Tool management (option number 93)

## Available tool types

The tool management displays the various tool types with an icon. The following tool types are available:

Icon	Tool type	Tool type number
	Undefined,****	99
	Milling cutter,MILL	0
	Drill,DRILL	1
	Tap,TAP	2
	Center drill,CENT	4
	Turning Tool,TURN	29
	Touch probe,TCHP	21
	Ream,REAM	3
	Countersink,CSINK	5
	Piloted counterbore(TSINK),TSINK	6
	Boring tool,BOR	7
	Back boring tool,BCKBOR	8
	Thread mill,GF	15
	Thread mill w/ countersink,GSF	16
	Thread mill w/ single thread,EP	17
	Thread mill w/ indxbi insert,WSP	18
	Thread milling drill,BGF	19
	Circular thread mill,ZBGF	20

## Tool management (option number 93) 5.4

Icon	Tool type	Tool type number
	Roughing cutter (MILL_R),MILL_R	9
	Finishing cutter (MILL_F),MILL_F	10
	Rough/finish cutter,MILL_RF	11
	Floor finisher(MILL_FD),MILL_FD	12
	Side finisher (MILL_FS),MILL_FS	13
	Face milling cutter,MILL_FACE	14

## 5.4 Tool management (option number 93)

### Import and export tool data

#### Importing tool data

Using this function you can simply import tool data that you have measured externally on a presetting device, for example. The file to be imported must have the CSV format (**c**omma **s**eparated **v**alue). The **CSV** file format describes the structure of a text file for exchanging simply structured data. Accordingly, the import file must have the following structure:

- **Row 1:** In the first line you define the column names in which the data defined in the subsequent lines is to be placed. The column names are separated with a comma.
- **Other lines:** All the other lines contain the data that you wish to import into the tool table. The order of the data must match the order of the column names in Line 1. The data is separated by commas, decimal numbers are to be defined with a decimal point.

Follow the steps outlined below for importing:

- ▶ Copy the tool table to be imported to the hard disk of the TNC in the **TNC:\systems\tooltab** directory
- ▶ Start expanded tool management
- ▶ Select the **TOOL IMPORT** soft key in the tool management: The TNC shows a pop-up window with the CSV files stored in the **TNC:\system\tooltab** directory
- ▶ Use the arrow keys or mouse to select the file to be imported and confirm with the **ENT** key: The TNC shows the content of the CSV file in a pop-up window
- ▶ Start import procedure with **START** soft key





- The CSV file to be imported must be stored in the **TNC:\system\tooltab** directory.
- If you import the tool data of tools whose numbers are in the pocket table, the TNC issues an error message. You can then decide whether you want to skip this data record or insert a new tool. The TNC inserts a new tool into the first empty line of the tool table.
- If the imported CSV file includes additional table columns unknown to the control, a message is displayed during import specifying these unknown columns and indicating that these values will not be adopted.
- Make sure that the column designations have been specified correctly.  
**Further Information:** "Enter tool data into the table", page 206
- You can import any tool data, the associated data record does not have to contain all the columns (or data) of the tool table.
- The column names can be in any order, the data must be defined in the corresponding order.

#### Sample import file:

T,L,R,DL,DR	Line 1 with column names
4,125.995,7.995,0,0	Line 2 with tool data
9,25.06,12.01,0,0	Line 3 with tool data
28,196.981,35,0,0	Line 4 with tool data

## 5.4 Tool management (option number 93)

### Exporting tool data

Using this function you can simply export tool data to read it into the tool database of your CAM system, for example. The TNC stores the exported file in the CSV format (**c**omma **s**eparated **v**alue). The **CSV** file format describes the structure of a text file for exchanging simply structured data. The export file has the following structure:

- **Line 1:** In the first line the TNC stores the column names of all the relevant tool data to be defined. The column names are separated from each other by commas.
- **Further lines:** All the other lines contain the data of the tools that you have exported. The order of the data matches the order of the column names in Line 1. The data is separated by commas, the TNC outputs decimal numbers with a decimal point.

Follow the steps outlined below for exporting:

- ▶ In the tool management you use the arrow keys or mouse to mark the tool data that you wish to export
- ▶ Press the **EXPORT TOOL** soft key, the TNC shows a pop-up window: specify the name for the CSV file, confirm with the **ENT** key
- ▶ Press the **START** soft key to start the export process: The TNC shows the status of the delete export process in a pop-up window
- ▶ Terminate the export process by pressing the **END** key or soft key



The TNC always stores the exported CSV file in the **TNC:\system\tooltab** directory.

# 6

**Programming  
contours**


## Programming contours

### 6.1 Tool movements

#### 6.1 Tool movements

##### Path functions


A workpiece contour is usually composed of several contour elements such as straight lines and circular arcs. With the path functions, you can program the tool movements for **straight lines** and **circular arcs**.



##### FK free contour programming

If a production drawing is not dimensioned for NC and the dimensions given are not sufficient for creating a part program, you can program the workpiece contour with the FK free contour programming. The TNC calculates the missing data.

With FK programming, you also program tool movements for **straight lines** and **circular arcs**.



##### Miscellaneous functions M

With the TNC's miscellaneous functions you can affect

- the program run, e.g., a program interruption
- the machine functions, such as switching spindle rotation and coolant supply on and off
- the path behavior of the tool

### Subprograms and program section repeats

If a machining sequence occurs several times in a program, you can save time and reduce the chance of programming errors by entering the sequence once and then defining it as a subprogram or program section repeat. If you wish to execute a specific program section only under certain conditions, you also define this machining sequence as a subprogram. In addition, you can have a part program call a separate program for execution.

**Further Information:** "Subprograms and program section repeats", page 313

### Programming with Q parameters

Instead of programming numerical values in a machining program, you enter markers called Q parameters. You assign the values to the Q parameters separately with the Q parameter functions. You can use the Q parameters for programming mathematical functions that control program execution or describe a contour.

In addition, programming with Q parameters enables you to measure with the 3-D touch probe during the program run.

**Further Information:** "Programming Q parameters", page 331

## Programming contours

### 6.2 Fundamentals of path functions

#### 6.2 Fundamentals of path functions

##### Programming tool movements for workpiece machining

You create a machining program by programming the path functions for the individual contour elements in sequence. You do this by entering the coordinates of the end points of the contour elements given in the production drawing. The TNC calculates the actual path of the tool from these coordinates, and from the tool data and radius compensation.

The TNC moves all machine axes programmed in the NC block of a path function simultaneously.

##### Movement parallel to the machine axes

The NC block contains only one coordinate. The TNC thus moves the tool parallel to the programmed machine axis.

Depending on the individual machine tool, the part program is executed by movement of either the tool or the machine table on which the workpiece is clamped. Path contours are programmed as if the tool were moving.

##### Example:

```
50 L X+100
```

**50**            Block number  
**L**            Path function "straight line"  
**X+100**        Coordinate of the end point

The tool retains the Y and Z coordinates and moves to the position X=100.



##### Movement in the main planes

The NC block contains two coordinates. The TNC thus moves the tool on the programmed plane.

##### Example

```
L X+70 Y+50
```

The tool retains the Z coordinate and moves on the XY plane to the position X=70, Y=50.



### Three-dimensional movement

The NC block contains three coordinates. The TNC thus moves the tool spatially to the programmed position.


#### Example

```
L X+80 Y+0 Z-10
```

You can program up to six axes in a straight line block according to the kinematics of your machine.

#### Example

```
L X+80 Y+0 Z-10 A+15 B+0 C-45
```




### Circles and circular arcs

The TNC moves two axes simultaneously on a circular path relative to the workpiece. You can define a circular movement by entering the circle center **CC**.

When you program a circle, the control assigns it to one of the main planes. This main plane for a **TOOL CALL** must be defined when the spindle axis is set:

Spindle axis	Main plane
Z	XY, also UV, XV, UY
Y	ZX, also WU, ZU, WX
X	YZ, also VW, YW, VZ



You can program circles that do not lie parallel to a main plane by using the function for **Tilt working plane** or with Q parameters.

**Further Information:** "The PLANE function: Tilting the working plane (software option 8)", page 485


**Further Information:** "Principle and overview of functions", page 332

### Direction of rotation DR for circular movements

When a circular path has no tangential transition to another contour element, enter the direction of rotation as follows:

Clockwise direction of rotation: **DR-**

Counterclockwise direction of rotation: **DR+**



## Programming contours

### 6.2 Fundamentals of path functions

#### Radius compensation

The radius compensation must be in the block in which you move to the first contour element. You cannot activate radius compensation in a circle block. It must be activated beforehand in a straight-line block.

**Further Information:** "Path contours Cartesian coordinates", page 258

**Further Information:** "Approaching and departing a contour", page 248

#### Pre-position




#### Danger of collision!

Before running a machining program, always pre-position the tool to prevent the possibility of damaging it or the workpiece.

#### Creating the NC blocks with the path function keys

The gray path function keys initiate the dialog. The TNC asks you successively for all the necessary information and inserts the program block into the part program.





**Example – programming a straight line**

- ▶ Initiate the programming dialog, e.g. for a straight line

**COORDINATES?**

- ▶ Enter the coordinates of the straight-line end point, e.g. -20 in X

**COORDINATES?**

- ▶ Enter the coordinates of the straight-line end point, e.g. 30 in Y, and confirm with the **ENT** key

**Radius comp.: RL/RR/no comp.?**

- ▶ Select the radius compensation (here, press the **R0** soft key—the tool moves without compensation)

**Feed rate F=? / F MAX = ENT**

- ▶ Enter **100** (feed rate e.g. 100 mm/min; for programming in inches: an input of 100 corresponds to a feed rate of 10 inches/min.) and confirm with the **ENT** key; or



- ▶ Move at rapid traverse: Press the **FMAX** soft key; or



- ▶ Traverse at the feed rate defined in the **TOOL CALL** block: Press the **F AUTO** soft key.

**MISCELLANEOUS FUNCTION M?**

- ▶ Enter **3** (miscellaneous function e.g. M3), and terminate the dialog with **END**.

**The part program now contains the following line:**

```
L X-20 Y+30 R0 FMAX M3
```

## Programming contours

### 6.3 Approaching and departing a contour

#### 6.3 Approaching and departing a contour


##### "From" and "To" points

The tool approaches the first contour point from the starting point. The starting point must be:

- Programmed without radius compensation
- Approachable without danger of collision
- Close to the first contour point


Example in the figure on the right:

If you set the starting point in the dark gray area, the contour will be damaged when the first contour element is approached.



##### First contour point

You need to program a radius compensation for the tool movement to the first contour point.




##### Approaching the starting point in the spindle axis

When the starting point is approached, the tool must be moved to the working depth in the spindle axis. If danger of collision exists, approach the starting point in the spindle axis separately.

##### NC blocks

```
30 L Z-10 R0 FMAX
```

```
31 L X+20 Y+30 RL F350
```



## Approaching and departing a contour 6.3

### End point

The end point should be selected so that it is:

- Approachable without danger of collision
- Near to the last contour point
- In order to make sure the contour will not be damaged, the optimal ending point should lie on the extended tool path for machining the last contour element

Example in the figure on the right:

If you set the end point in the dark gray area, the contour will be damaged when the end point is approached.



Departing the end point in the spindle axis:

Program the departure from the end point in the spindle axis separately.

### NC blocks

```
50 L X+60 Y+70 R0 F700
```

```
51 L Z+250 R0 FMAX
```




### Common starting and end points

Do not program any radius compensation if the starting point and end point are the same.

In order to make sure the contour will not be damaged, the optimal starting point should lie between the extended tool paths for machining the first and last contour elements.

Example in the figure on the right:

If you set the end point in the dark gray area, the contour will be damaged when the contour is approached/departed.












## Programming contours

### 6.3 Approaching and departing a contour

#### Overview: Types of paths for contour approach and departure

The functions for contour approach **APPR** and departure **DEP** are activated with the **APPR/DEP** key. You can then select the following path forms with the corresponding soft keys:

Approach	Departure	Function
		Straight line with tangential connection
		Straight line perpendicular to a contour point
		Circular arc with tangential connection
		Circular arc with tangential connection to the contour. Approach and departure to an auxiliary point outside the contour on a tangentially connecting line




#### Approaching and departing a helix

The tool approaches and departs a helix on its extension by moving in a circular arc that connects tangentially to the contour. You program helical approach and departure with the **APPR CT** and **DEP CT** functions.

### Important positions for approach and departure

- Starting point  $P_S$   
You program this position in the block before the APPR block.  $P_S$  lies outside the contour and is approached without radius compensation (R0).
- Auxiliary point  $P_H$   
Some of the paths for approach and departure go through an auxiliary point  $P_H$  that the TNC calculates from your input in the APPR or DEP block. The TNC moves from the current position to the auxiliary point  $P_H$  at the feed rate last programmed. If you have programmed **FMAX** (positioning at rapid traverse) in the last positioning block before the approach function, the TNC also approaches the auxiliary point  $P_H$  at rapid traverse.
- First contour point  $P_A$  and last contour point  $P_E$   
You program the first contour point  $P_A$  in the APPR block. The last contour point  $P_E$  can be programmed with any path function. If the APPR block also includes the Z coordinate, then the TNC moves the tool simultaneously to the first contour point  $P_A$ .
- End point  $P_N$

The position  $P_N$  lies outside of the contour and results from your input in the DEP block. If the DEP block also includes the Z coordinate, then the TNC moves the tool simultaneously to the end point  $P_N$ .



Abbreviation	Meaning
APPR	Approach
DEP	Departure
L	Line
C	Circle
T	Tangential (smooth connection)
N	Normal (perpendicular)



When moving from the actual position to the auxiliary point  $P_H$  the TNC does not check whether the programmed contour will be damaged. Use the test graphics to check.

With the **APPR LT**, **APPR LN** and **APPR CT** functions, the TNC moves the tool from the actual position to the auxiliary point  $P_H$  at the feed rate/rapid traverse that was last programmed. With the **APPR LCT** function, the TNC moves to the auxiliary point  $P_H$  at the feed rate programmed with the APPR block. If no feed rate is programmed before the approach block, the TNC generates an error message.

## Programming contours

### 6.3 Approaching and departing a contour

#### Polar coordinates

You can also program the contour points for the following approach/departure functions over polar coordinates:

- APPR LT becomes APPR PLT
- APPR LN becomes APPR PLN
- APPR CT becomes APPR PCT
- APPR LCT becomes APPR PLCT
- DEP LCT becomes DEP PLCT

Select an approach or departure function with the soft key, then press the orange **P** key.

#### Radius compensation

The tool radius compensation is programmed together with the first contour point  $P_A$  in the APPR block. The DEP blocks automatically discard the tool radius compensation.





If you program **APPR LN** or **APPR CT** with **R0**, the control stops the machining/simulation with an error message.

This method of function differs from the iTNC 530 control!

### Approaching on a straight line with tangential connection: APPR LT

The tool moves on a straight line from the starting point  $P_S$  to an auxiliary point  $P_H$ . It then moves to the first contour point  $P_A$  on a straight line that connects tangentially to the contour. The auxiliary point  $P_H$  is separated from the first contour point  $P_A$  by the distance **LEN**.

- ▶ Use any path function to approach the starting point  $P_S$
- ▶ Initiate the dialog with the **APPR DEP** key and **APPR LT** soft key
  - ▶ Coordinates of the first contour point  $P_A$
  - ▶ **LEN**: Distance from the auxiliary point  $P_H$  to the first contour point  $P_A$
  - ▶ Radius compensation **RR/RL** for machining




#### Example NC blocks

7 L X+40 Y+10 R0 FMAX M3	$P_S$ without radius compensation
8 APPR LT X+20 Y+20 Z-10 LEN15 RR F100	$P_A$ with radius comp. RR, distance $P_H$ zu $P_A$ : LEN=15
9 L X+35 Y+35	End point of the first contour element
10 L ...	Next contour element

### Approaching on a straight line perpendicular to the first contour point: APPR LN

- ▶ Use any path function to approach the starting point  $P_S$ .
- ▶ Initiate the dialog with the **APPR DEP** key and **APPR LN** soft key:
  - ▶ Coordinates of the first contour point  $P_A$
  - ▶ Length: Distance to the auxiliary point  $P_H$ . Always enter **LEN** as a positive value
  - ▶ Radius compensation **RR/RL** for machining



#### Example NC blocks

7 L X+40 Y+10 R0 FMAX M3	Approach $P_S$ without radius compensation
8 APPR LN X+10 Y+20 Z-10 LEN15 RR F100	$P_A$ with radius comp. RR
9 L X+20 Y+35	End point of the first contour element
10 L ...	Next contour element

## Programming contours



### 6.3 Approaching and departing a contour

#### Approaching on a circular path with tangential connection: APPR CT

The tool moves on a straight line from the starting point  $P_S$  to an auxiliary point  $P_H$ . It then moves from  $P_H$  to the first contour point  $P_A$  following a circular arc that is tangential to the first contour element.

The arc from  $P_H$  to  $P_A$  is determined through the radius  $R$  and the center angle **CCA**. The direction of rotation of the circular arc is automatically derived from the tool path for the first contour element.

- ▶ Use any path function to approach the starting point  $P_S$ .
- ▶ Initiate the dialog with the **APPR DEP** key and **APPR CT** soft key
  - ▶ Coordinates of the first contour point  $P_A$
  - ▶ Radius  $R$  of the circular arc
    - If the tool should approach the workpiece in the direction defined by the radius compensation: Enter  $R$  as a positive value
    - If the tool should approach the workpiece opposite to the radius compensation: Enter  $R$  as a negative value.
  - ▶ Center angle **CCA** of the arc
    - CCA can be entered only as a positive value.
    - Maximum input value  $360^\circ$
  - ▶ Radius compensation **RR/RL** for machining



#### Example NC blocks

7 L X+40 Y+10 R0 FMAX M3	Approach $P_S$ without radius compensation
8 APPR CT X+10 Y+20 Z-10 CCA180 R+10 RR F100	$P_A$ with radius compensation $RR$ , radius $R=10$
9 L X+20 Y+35	End point of the first contour element
10 L ...	Next contour element



### Approaching on a circular path with tangential connection from a straight line to the contour: APPR LCT

The tool moves on a straight line from the starting point  $P_S$  to an auxiliary point  $P_H$ . It then moves to the first contour point  $P_A$  on a circular arc. The feed rate programmed in the APPR block is effective for the entire path that the TNC traversed in the approach block (path  $P_S$  to  $P_A$ ).

If you have programmed the coordinates of all three principal axes X, Y and Z in the approach block, the TNC moves the tool from the position defined before the APPR block to the auxiliary point  $P_H$  on all three axes simultaneously. Then the TNC goes from  $P_H$  to  $P_A$  only on the working plane.


The arc is connected tangentially both to the line  $P_S - P_H$  as well as to the first contour element. Once these lines are known, the radius then suffices to completely define the tool path.



Please note that earlier programs may need to be adapted.

The arc is connected tangentially both to the line  $P_S - P_H$  as well as to the first contour element. Once these lines are known, the radius then suffices to completely define the tool path.


- Use any path function to approach the starting point  $P_S$ .
- Initiate the dialog with the **APPR DEP** key and **APPR LCT** soft key:



- Coordinates of the first contour point  $P_A$
- Radius R of the circular arc. Enter R as a positive value
- Radius compensation **RR/RL** for machining

#### Example NC blocks

7 L X+40 Y+10 R0 FMAX M3	Approach PS without radius compensation
8 APPR LCT X+10 Y+20 Z-10 R10 RR F100	PA with radius compensation RR, radius R=10
9 L X+20 Y+35	End point of the first contour element
10 L ...	Next contour element



## Programming contours

### 6.3 Approaching and departing a contour


#### Departing in a straight line with tangential connection: DEP LT

The tool moves on a straight line from the last contour point  $P_E$  to the end point  $P_N$ . The line lies on the extension of the last contour element.  $P_N$  is separated from  $P_E$  by the distance **LEN**.

- ▶ Program the last contour element with the end point  $P_E$  and radius compensation
- ▶ Initiate the dialog with the **APPR DEP** key and **DEP LT** soft key



- ▶ **LEN**: Enter the distance from the last contour element  $P_E$  to the end point  $P_N$ .



#### Example NC blocks

23 L Y+20 RR F100	Last contour element: PE with radius compensation
24 DEP LT LEN12.5 F100	Depart contour by LEN=12.5 mm
25 L Z+100 FMAX M2	Retract in Z, return to block 1, end program


#### Departing in a straight line perpendicular to the last contour point: DEP LN

The tool moves on a straight line from the last contour point  $P_E$  to the end point  $P_N$ . The line departs on a perpendicular path from the last contour point  $P_E$ .  $P_N$  is separated from  $P_E$  by the distance **LEN** plus the tool radius.

- ▶ Program the last contour element with the end point  $P_E$  and radius compensation
- ▶ Initiate the dialog with the **APPR DEP** key and **DEP LN** soft key



- ▶ **LEN**: Enter the distance from the last contour element to  $P_N$ . Important: Enter a positive value in **LEN**





#### Example NC blocks

23 L Y+20 RR F100	Last contour element: PE with radius compensation
24 DEP LN LEN+20 F100	Depart perpendicular to contour by LEN=20 mm
25 L Z+100 FMAX M2	Retract in Z, return to block 1, end program

### Departing on a circular path with tangential connection: DEP CT

The tool moves on a circular arc from the last contour point  $P_E$  to the end point  $P_N$ . The circular arc connects tangentially to the last contour element.

- ▶ Program the last contour element with the end point  $P_E$  and radius compensation
- ▶ Initiate the dialog with the **APPR DEP** key and **DEP CT** soft key
  - ▶ Center angle **CCA** of the arc
  - ▶ Radius **R** of the circular arc
    - If the tool should depart the workpiece in the direction opposite to the radius compensation: Enter **R** as a positive value.
    - If the tool should depart the workpiece in the direction **opposite** to the radius compensation: Enter **R** as a negative value.





#### Example NC blocks

23 L Y+20 RR F100	Last contour element: PE with radius compensation
24 DEP CT CCA 180 R+8 F100	Center angle=180°, arc radius=8 mm
25 L Z+100 FMAX M2	Retract in Z, return to block 1, end program

### Departing on a circular arc tangentially connecting the contour and a straight line: DEP LCT

The tool moves on a circular arc from the last contour point  $P_E$  to an auxiliary point  $P_H$ . It then moves on a straight line to the end point  $P_N$ . The arc is tangentially connected both to the last contour element and to the line from  $P_H$  to  $P_N$ . Once these lines are known, the radius **R** suffices to unambiguously define the tool path.

- ▶ Program the last contour element with the end point  $P_E$  and radius compensation
- ▶ Initiate the dialog with the **APPR/DEP** key and **DEP LCT** soft key
  - ▶ Enter the coordinates of the end point  $P_N$
  - ▶ Radius **R** of the circular arc. Enter **R** as a positive value



#### Example NC blocks









23 L Y+20 RR F100	Last contour element: PE with radius compensation
24 DEP LCT X+10 Y+12 R+8 F100	Coordinates PN, arc radius=8 mm
25 L Z+100 FMAX M2	Retract in Z, return to block 1, end program

## Programming contours

### 6.4 Path contours — Cartesian coordinates

#### 6.4 Path contours — Cartesian coordinates

##### Overview of path functions


Path function key	Function	Tool movement	Required input	Page
	Straight line <b>L</b>	Straight line	Coordinates of the end point of the straight line	259
	Chamfer: <b>CHF</b>	Chamfer between two straight lines	Chamfer side length	260
	Circle center <b>CC</b>	None	Coordinates of the circle center or pole	262
	Circular arc <b>C</b>	Circular arc around a circle center CC to an arc end point	Coordinates of the arc end point, direction of rotation	263
	Circular arc <b>CR</b>	Circular arc with a certain radius	Coordinates of the arc end point, arc radius, direction of rotation	264
	Circular arc <b>CT</b>	Circular arc with tangential connection to the preceding and subsequent contour elements	Coordinates of the arc end point	266
	Corner rounding <b>RND</b>	Circular arc with tangential connection to the preceding and subsequent contour elements	Rounding radius R	261
	<b>FK</b> free contour programming	Straight line or circular path with any connection to the preceding contour element	"Path contours – FK free contour programming", page 277	280

## Straight line L

The TNC moves the tool in a straight line from its current position to the straight-line end point. The starting point is the end point of the preceding block.



- ▶ Press the **L** key to open a program block for a linear movement
- ▶ **Coordinates** of the end point of the straight line, if necessary
- ▶ **Radius compensation** RL/RR/R0
- ▶ **Feed rate** F
- ▶ **Miscellaneous function** M



### Example NC blocks

```
7 L X+10 Y+40 RL F200 M3
```

```
8 L IX+20 IY-15
```

```
9 L X+60 IY-10
```

### Capture actual position

You can also generate a straight line block (**L** block) by using the **ACTUAL-POSITION-CAPTURE** key:

- ▶ In the Manual Operation mode, move the tool to the position you want to capture
- ▶ Switch the screen display to programming.
- ▶ Select the NC block after which you want to insert the straight line block



- ▶ Press the **ACTUAL-POSITION-CAPTURE** key: The TNC generates a straight line block with the actual position coordinates.

## Programming contours

### 6.4 Path contours — Cartesian coordinates


#### Inserting a chamfer between two straight lines

The chamfer enables you to cut off corners at the intersection of two straight lines.

- The line blocks before and after the **CHF** block must be in the same working plane as the chamfer.
- The radius compensation before and after the **CHF** block must be the same
- The chamfer must be machinable with the current tool



- ▶ **Chamfer side length:** Length of the chamfer, and if necessary:
- ▶ **Feed rate F** (effective only in **CHF** block)



#### Example NC blocks

```
7 L X+0 Y+30 RL F300 M3
```

```
8 L X+40 IY+5
```

```
9 CHF 12 F250
```

```
10 L IX+5 Y+0
```



You cannot start a contour with a **CHF** block.  
A chamfer is possible only in the working plane.  
The corner point is cut off by the chamfer and is not part of the contour.  
A feed rate programmed in the **CHF** block is effective only in that CHF block. After the **CHF** block, the previous feed rate becomes effective again.

### Rounded corners RND

The **RND** function rounds off contour corners.

The tool moves on an arc that is tangentially connected to both the preceding and subsequent contour elements.

The rounding arc must be machinable with the called tool.



- ▶ **Rounding radius:** Enter the radius, and if necessary:
- ▶ **Feed F** (effective only in the **RND** block)


#### Example NC blocks

```
5 L X+10 Y+40 RL F300 M3
```

```
6 L X+40 Y+25
```

```
7 RND R5 F100
```

```
8 L X+10 Y+5
```



In the preceding and subsequent contour elements, both coordinates must lie in the plane of the rounding arc. If you machine the contour without tool-radius compensation, you must program both coordinates in the plane.

The corner point is cut off by the rounding arc and is not part of the contour.

A feed rate programmed in the **RND** block is effective only in that **RND** block. After the **RND** block, the previous feed rate becomes effective again.

You can also use an **RND** block for a tangential contour approach.

## Programming contours

### 6.4 Path contours — Cartesian coordinates


#### Circle center CC

You can define a circle center for circles that you have programmed with the C key (circular path C) . This is done in the following ways:

- Entering the Cartesian coordinates of the circle center in the working plane, or
- Using the circle center defined in an earlier block, or
- Capturing the coordinates with the **ACTUAL-POSITION CAPTURE** key



- ▶ Enter coordinates for the circle center or, if you want to use the last programmed position, enter no coordinates



#### Example NC blocks

```
5 CC X+25 Y+25
```

or

```
10 L X+25 Y+25
```

```
11 CC
```

The program lines 10 and 11 do not refer to the illustration.

#### Validity

The circle center definition remains in effect until a new circle center is programmed.

#### Entering the circle center incrementally

If you enter the circle center with incremental coordinates, you have programmed it relative to the last programmed position of the tool.



The only effect of **CC** is to define a position as circle center: The tool does not move to this position. The circle center is also the pole for polar coordinates.



### Circular path C around circle center CC

Before programming a circular arc, you must first enter the circle center **CC**. The last programmed tool position will be the starting point of the arc.

- Move the tool to the circle starting point



- **Enter the coordinates** of the circle center



- Enter the **coordinates** of the arc end point, and if necessary:
- **Direction of rotation DR**
- **Feed F**
- **Miscellaneous function M**





The TNC normally makes circular movements in the active working plane. If you program circular arcs that do not lie in the active working plane, e.g. **C Z... X...** **DR+** with a tool axis Z, and at the same time rotate this movement, then the TNC moves the tool in a spatial arc, which means a circular arc in 3 axes.

#### Example NC blocks

```
5 CC X+25 Y+25
```

```
6 L X+45 Y+25 RR F200 M3
```

```
7 C X+45 Y+25 DR+
```



#### Full circle

For the end point, enter the same point that you used for the starting point.



The starting and end points of the arc must lie on the circle.

The maximum value for input tolerance is 0.016 mm. Set the input tolerance in the machine parameter **circleDeviation** (no. 200901).

Smallest possible circle that the TNC can traverse: 0.0016 µm.

## Programming contours


### 6.4 Path contours — Cartesian coordinates

#### CircleCR with defined radius

The tool moves on a circular path with the radius  $R$ .



- ▶ **Coordinates** of the arc end point
- ▶ **Radius  $R$**  (the algebraic sign determines the size of the arc)
- ▶ **Direction of rotation  $DR$**  Note: The algebraic sign determines whether the arc is concave or convex.
- ▶ **Miscellaneous function  $M$**
- ▶ **Feed  $F$**



#### Full circle

For a full circle, program two blocks in succession:

The end point of the first semicircle is the starting point of the second. The end point of the second semicircle is the starting point of the first.

#### Central angle CCA and arc radius R

The starting and end points on the contour can be connected with four arcs of the same radius:

Smaller arc:  $CCA < 180^\circ$

Enter the radius with a positive sign  $R > 0$


Larger arc:  $CCA > 180^\circ$

Enter the radius with a negative sign  $R < 0$

The direction of rotation determines whether the arc is curving outward (convex) or curving inward (concave):

Convex: Direction of rotation **DR-** (with radius compensation **RL**)

Concave: Direction of rotation **DR+** (with radius compensation **RL**)



The distance from the starting and end points of the arc diameter cannot be greater than the diameter of the arc.

The maximum radius is 99.9999 m.

You can also enter rotary axes A, B and C.

The TNC normally makes circular movements in the active working plane. If you program circular arcs that do not lie in the active working plane, and at the same time rotate this movement, then the TNC moves the tool in a spatial arc, which means a circular arc in 3 axes.

**Example NC blocks**

```
10 L X+40 Y+40 RL F200 M3
```

```
11 CR X+70 Y+40 R+20 DR- (ARC 1)
```

or


```
11 CR X+70 Y+40 R+20 DR+ (ARC 2)
```

or

```
11 CR X+70 Y+40 R-20 DR- (ARC 3)
```

or

```
11 CR X+70 Y+40 R-20 DR+ (ARC 4)
```



## Programming contours

### 6.4 Path contours — Cartesian coordinates

#### Circle CT with tangential connection

The tool moves on an arc that starts tangentially to the previously programmed contour element.

A transition between two contour elements is called tangential when there is no kink or corner at the intersection between the two contours—the transition is smooth.

The contour element to which the tangential arc connects must be programmed immediately before the **CT** block. This requires at least two positioning blocks.



- ▶ **Coordinates** of the arc end point, and if necessary:
- ▶ **Feed F**
- ▶ **Miscellaneous function M**


#### Example NC blocks

```
7 L X+0 Y+25 RL F300 M3
```

```
8 L X+25 Y+30
```


```
9 CT X+45 Y+20
```

```
10 L Y+0
```



A tangential arc is a two-dimensional operation: the coordinates in the **CT** block and in the contour element preceding it must be in the same plane of the arc!

### Example: Linear movements and chamfers with Cartesian coordinates




<b>0 BEGIN PGM LINEAR MM</b>	
<b>1 BLK FORM 0.1 Z X+0 Y+0 Z-20</b>	Define the workpiece blank for graphic workpiece simulation
<b>2 BLK FORM 0.2 X+100 Y+100 Z+0</b>	
<b>3 TOOL CALL 1 Z S4000</b>	Call the tool in the spindle axis and with spindle speed
<b>4 L Z+250 R0 FMAX</b>	Retract the tool in the spindle axis at rapid traverse FMAX
<b>5 L X-10 Y-10 R0 FMAX</b>	Pre-position the tool
<b>6 L Z-5 R0 F1000 M3</b>	Move to working depth at feed rate F = 1000 mm/min
<b>7 APPR LT X+5 Y+5 LEN10 RL F300</b>	Approach the contour at point 1 on a straight line with tangential connection
<b>8 L Y+95</b>	Move to point 2
<b>9 L X+95</b>	Point 3: first straight line for corner 3
<b>10 CHF 10</b>	Program a chamfer with length 10 mm
<b>11 L Y+5</b>	Point 4: 2nd straight line for corner 3, 1st straight line for corner 4
<b>12 CHF 20</b>	Program a chamfer with length 20 mm
<b>13 L X+5</b>	Move to last contour point 1, second straight line for corner 4
<b>14 DEP LT LEN10 F1000</b>	Depart the contour on a straight line with tangential connection
<b>15 L Z+250 R0 FMAX M2</b>	Retract the tool, end program
<b>16 END PGM LINEAR MM</b>	


## Programming contours

### 6.4 Path contours — Cartesian coordinates

#### Example: Circular movements with Cartesian coordinates



<b>0 BEGIN PGM CIRCULAR MM</b>	
<b>1 BLK FORM 0.1 Z X+0 Y+0 Z-20</b>	Define the workpiece blank for graphic workpiece simulation
<b>2 BLK FORM 0.2 X+100 Y+100 Z+0</b>	
<b>3 TOOL CALL 1 Z S4000</b>	Call the tool in the spindle axis and with spindle speed
<b>4 L Z+250 R0 FMAX</b>	Retract the tool in the spindle axis at rapid traverse FMAX
<b>5 L X-10 Y-10 R0 FMAX</b>	Pre-position the tool
<b>6 L Z-5 R0 F1000 M3</b>	Move to working depth at feed rate F = 1000 mm/min
<b>7 APPR LCT X+5 Y+5 R5 RL F300</b>	Approach the contour at point 1 on a circular arc with tangential connection
<b>8 L X+5 Y+85</b>	Point 2: First straight line for corner 2
<b>9 RND R10 F150</b>	Insert radius with R = 10 mm, feed rate: 150 mm/min
<b>10 L X+30 Y+85</b>	Move to point 3: Starting point of the arc with CR
<b>11 CR X+70 Y+95 R+30 DR-</b>	Move to point 4: End point of the arc with CR, radius 30 mm
<b>12 L X+95</b>	Move to point 5
<b>13 L X+95 Y+40</b>	Move to point 6
<b>14 CT X+40 Y+5</b>	Move to point 7: End point of the arc, circular arc with tangential connection to point 6, TNC automatically calculates the radius
<b>15 L X+5</b>	Move to last contour point 1
<b>16 DEP LCT X-20 Y-20 R5 F1000</b>	Depart the contour on a circular arc with tangential connection
<b>17 L Z+250 R0 FMAX M2</b>	Retract the tool, end program
<b>18 END PGM CIRCULAR MM</b>	

**Example: Full circle with Cartesian coordinates**

<b>0 BEGIN PGM C-CC MM</b>	
<b>1 BLK FORM 0.1 Z X+0 Y+0 Z-20</b>	Definition of workpiece blank
<b>2 BLK FORM 0.2 X+100 Y+100 Z+0</b>	
<b>3 TOOL CALL 1 Z S3150</b>	Tool call
<b>4 CC X+50 Y+50</b>	Define the circle center
<b>5 L Z+250 R0 FMAX</b>	Retract the tool
<b>6 L X-40 Y+50 R0 FMAX</b>	Pre-position the tool
<b>7 L Z-5 R0 F1000 M3</b>	Move to working depth
<b>8 APPR LCT X+0 Y+50 R5 RL F300</b>	Approach the starting point of the circle on a circular arc with tangential connection
<b>9 C X+0 DR-</b>	Move to the circle end point (= circle starting point)
<b>10 DEP LCT X-40 Y+50 R5 F1000</b>	Depart the contour on a circular arc with tangential connection
<b>11 L Z+250 R0 FMAX M2</b>	Retract the tool, end program
<b>12 END PGM C-CC MM</b>	

## Programming contours

### 6.5 Path contours – Polar coordinates

#### 6.5 Path contours – Polar coordinates









##### Overview

With polar coordinates you can define a position in terms of its angle **PA** and its distance **PR** relative to a previously defined pole **CC**.

Polar coordinates are useful with:

- Positions on circular arcs
- Workpiece drawing dimensions in degrees, e.g. bolt hole circles

##### Overview of path functions with polar coordinates

Path function key	Tool movement	Required input	Page
 + 	Straight line	Polar radius, polar angle of the straight-line end point	271
 + 	Circular path around circle center/pole to arc end point	Polar angle of the arc end point, direction of rotation	272
 + 	Circular arc with tangential connection to the preceding contour element	Polar radius, polar angle of the arc end point	272
 + 	Combination of a circular and a linear movement	Polar radius, polar angle of the arc end point, coordinate of the end point in the tool axis	273



### Zero point for polar coordinates: pole CC


You can set the pole CC at any point in the machining program, before indicating points in polar coordinates. Set the pole in the same way as you would program the circle center.



- **Coordinates:** Enter Cartesian coordinates for the pole or, if you want to use the last programmed position, do not enter any coordinates. Before programming polar coordinates, define the pole. You can only define the pole in Cartesian coordinates. The pole remains in effect until you define a new pole.

### Example NC blocks

```
12 CC X+45 Y+25
```



### Straight line LP

The tool moves in a straight line from its current position to the straight-line end point. The starting point is the end point of the preceding block.



- **Polar coordinate radius PR:** Enter the distance from the pole CC to the straight-line end point.
- **Polar coordinate angle PA:** Angular position of the straight-line end point between  $-360^\circ$  and  $+360^\circ$



The sign of **PA** depends on the angle reference axis:

- If the angle from the angle reference axis to **PR** is counterclockwise: **PA**>0
- If the angle from the angle reference axis to **PR** is clockwise: **PA**<0

### Example NC blocks


```
12 CC X+45 Y+25
```

```
13 LP PR+30 PA+0 RR F300 M3
```

```
14 LP PA+60
```

```
15 LP IPA+60
```

```
16 LP PA+180
```



## Programming contours

### 6.5 Path contours – Polar coordinates

#### Circular path CP around pole CC

The polar coordinate radius **PR** is also the radius of the arc. **PR** is defined by the distance from the starting point to the pole **CC**. The last programmed tool position will be the starting point of the arc.



- ▶ **Polar coordinate angle PA:** Angular position of the arc end point between  $-99999.9999^\circ$  and  $+99999.9999^\circ$



- ▶ **Direction of rotation DR**

#### Example NC blocks

```
18 CC X+25 Y+25
```


```
19 LP PR+20 PA+0 RR F250 M3
```

```
20 CP PA+180 DR+
```



With incremental inputs you must enter DR and PA with the same sign.

Consider this behavior when importing programs from earlier controls. Adapt the program if required.



#### Circle CTP with tangential connection


The tool moves on a circular path, starting tangentially from a preceding contour element.



- ▶ **Polar coordinate radius PR:** Distance between the arc end point and the pole **CC**
- ▶ **Polar coordinate angle PA:** Angular position of the arc end point.



The pole is **not** the center of the contour arc!



#### Example NC blocks

```
12 CC X+40 Y+35
```

```
13 L X+0 Y+35 RL F250 M3
```

```
14 LP PR+25 PA+120
```


```
15 CTP PR+30 PA+30
```

```
16 L Y+0
```

## Helix

A helix is a combination of a circular movement in a main plane and a linear movement perpendicular to this plane. You program the circular path in a main plane.

A helix is programmed only in polar coordinates.



### Application

- Large-diameter internal and external threads
- Lubrication grooves

### Calculating the helix

To program a helix, you must enter the total angle through which the tool is to move on the helix in incremental dimensions, and the total height of the helix.

Thread revolutions n:	Thread revolutions + overrun at start and end of thread
Total height h:	Thread pitch P times thread revolutions n
Incremental total angle IPA:	Thread revolutions x 360° + angle for beginning of thread + angle for thread overrun
Starting coordinate Z:	Pitch P times (thread revolutions + thread overrun at start of thread)

### Shape of the helix

The table below illustrates in which way the shape of the helix is determined by the work direction, direction of rotation and radius compensation.

Internal thread	Work direction	Direction of rotation	Radius compensation
Right-hand	Z+	DR+	RL
Left-hand	Z+	DR-	RR
Right-hand	Z-	DR-	RR
Left-hand	Z-	DR+	RL
External thread			
Right-hand	Z+	DR+	RR
Left-hand	Z+	DR-	RL
Right-hand	Z-	DR-	RL
Left-hand	Z-	DR+	RR

## Programming contours

### 6.5 Path contours – Polar coordinates

#### Programming a helix




Always enter the same algebraic sign for the direction of rotation and the incremental total angle **IPA**. The tool may otherwise move in a wrong path and damage the contour.

For the total angle **IPA** you can enter a value of  $-99\,999.9999^\circ$  to  $+99\,999.9999^\circ$ .



- ▶ **Polar coordinates angle:** Enter the total angle of tool traverse along the helix in incremental dimensions. **After entering the angle, specify the tool axis with an axis selection key.**
- ▶ **Coordinate:** Enter the coordinate for the height of the helix in incremental dimensions
- ▶ **Direction of rotation DR**  
Clockwise helix: DR–  
Counterclockwise helix: DR+
- ▶ **Enter the radius compensation** according to the table




#### Example NC blocks: Thread M6 x 1 mm with 5 revolutions

12 CC X+40 Y+25

13 L Z+0 F100 M3

14 LP PR+3 PA+270 RL F50

15 CP IPA-1800 IZ+5 DR-


**Example: Linear movement with polar coordinates**

<b>0 BEGIN PGM LINEARPO MM</b>	
<b>1 BLK FORM 0.1 Z X+0 Y+0 Z-20</b>	Definition of workpiece blank
<b>2 BLK FORM 0.2 X+100 Y+100 Z+0</b>	
<b>3 TOOL CALL 1 Z S4000</b>	Tool call
<b>4 CC X+50 Y+50</b>	Define the datum for polar coordinates
<b>5 L Z+250 R0 FMAX</b>	Retract the tool
<b>6 LP PR+60 PA+180 R0 FMAX</b>	Pre-position the tool
<b>7 L Z-5 R0 F1000 M3</b>	Move to working depth
<b>8 APPR PLCT PR+45 PA+180 R5 RL F250</b>	Approach the contour at point 1 on a circular arc with tangential connection
<b>9 LP PA+120</b>	Move to point 2
<b>10 LP PA+60</b>	Move to point 3
<b>11 LP PA+0</b>	Move to point 4
<b>12 LP PA-60</b>	Move to point 5
<b>13 LP PA-120</b>	Move to point 6
<b>14 LP PA+180</b>	Move to point 1
<b>15 DEP PLCT PR+60 PA+180 R5 F1000</b>	Depart the contour on a circular arc with tangential connection
<b>16 L Z+250 R0 FMAX M2</b>	Retract the tool, end program
<b>17 END PGM LINEARPO MM</b>	

## Programming contours

### 6.5 Path contours – Polar coordinates

#### Example: Helix



<b>0 BEGIN PGM HELIX MM</b>	
<b>1 BLK FORM 0.1 Z X+0 Y+0 Z-20</b>	Definition of workpiece blank
<b>2 BLK FORM 0.2 X+100 Y+100 Z+0</b>	
<b>3 TOOL CALL 1 Z S1400</b>	Tool call
<b>4 L Z+250 R0 FMAX</b>	Retract the tool
<b>5 L X+50 Y+50 R0 FMAX</b>	Pre-position the tool
<b>6 CC</b>	Transfer the last programmed position as the pole
<b>7 L Z-12.75 R0 F1000 M3</b>	Move to working depth
<b>8 APPR PCT PR+32 PA-182 CCA180 R+2 RL F100</b>	Approach the contour on a circular arc with tangential connection
<b>9 CP IPA+3240 IZ+13.5 DR+ F200</b>	Helical interpolation
<b>10 DEP CT CCA180 R+2</b>	Depart the contour on a circular arc with tangential connection
<b>11 L Z+250 R0 FMAX M2</b>	Retract the tool, end program
<b>12 END PGM HELIX MM</b>	

## 6.6 Path contours – FK free contour programming


### Fundamentals

Workpiece drawings that are not dimensioned for NC often contain unconventional coordinate data that cannot be entered with the gray dialog keys.

You can enter such dimensional data directly by using the free contour programming function FK, e.g.

- If there are known coordinates on or in the proximity of the contour element
- If coordinate data refers to another contour element
- If directional data and data regarding the course of the contour are known

The TNC derives the contour from the known coordinate data and supports the programming dialog with the interactive FK programming graphics. The upper right figure shows a workpiece drawing for which FK programming is the most convenient programming method.





**The following prerequisites for FK programming must be observed:**

The FK free contour programming feature can only be used for programming contour elements that lie in the working plane.

The working plane for FK programming is defined according to the following hierarchy:

- 1. Using the plane defined in an **FPOL** block
- 2. In the Z/X plane if the FK sequence is run in turning mode
- 3. Using the working plane defined in the **TOOL CALL** (e.g. **TOOL CALL 1 TOOL CALLZ = X/Y plane**)
- 4. The standard X/Y plane is active if none of these applies

The display of the FK soft keys depends on the spindle axis in the workpiece blank definition. If for example you enter spindle axis **Z** in the workpiece blank definition, the TNC only shows FK soft keys for the X/Y plane.

You must enter all available data for every contour element. Even the data that does not change must be entered in every block—otherwise it will not be recognized.

Q parameters are permissible in all FK elements, except in elements with relative references (e.g. **RX** or **RAN**), or in elements that are referenced to other NC blocks.

If both FK blocks and conventional blocks are entered in a program, the FK contour must be fully defined before you can return to conventional programming.

The TNC needs a fixed point from which it can calculate the contour elements. Use the gray path function keys to program a position that contains both coordinates of the working plane immediately before programming the FK contour. Do not enter any Q parameters in this block.

If the first block of an FK contour is an **FCT** or **FLT** block, you must program at least two NC blocks with the gray path function keys to fully define the direction of contour approach.

Do not program an FK contour immediately after an **LBL** command.



## FK programming graphics



If you wish to use graphic support during FK programming, select the **PROGRAM + GRAPHICS** screen layout.

**Further Information:** "Programming", page 88

Incomplete coordinate data often is not sufficient to fully define a workpiece contour. In this case, the TNC indicates the possible solutions in the FK graphic. You can then select the contour that matches the drawing.

The control uses various colors in the FK graphics:

- **blue:** uniquely specified contour element  
The last FK element is only shown in blue after the departure movement.
- **violet:** not yet uniquely specified contour element
- **ocher:** tool midpoint path
- **red:** rapid traverse
- **green:** more than one solution is possible

If the data permit several possible solutions and the contour element is displayed in green, select the correct contour element as follows:

SHOW  
SOLUTION

- Press the **SHOW SOLUTION** soft key repeatedly until the correct contour element is displayed. Use the zoom function if you cannot distinguish possible solutions in the standard setting


SELECT  
SOLUTION

- If the displayed contour element matches the drawing, select the contour element with **SELECT SOLUTION**

If you do not yet wish to select a green contour element, press the **START SINGLE** soft key to continue the FK dialog.



Select the green contour elements as soon as possible with the **SELECT SOLUTION** soft key. This way you can reduce the ambiguity of subsequent elements.



### Showing block numbers in the graphic window

To show a block number in the graphic window:

BLOCK NO.  
SHOW  
OMIT

- Set the **SHOW OMIT BLOCK NR.** soft key to **SHOW** (soft-key row 3)






## Programming contours

### 6.6 Path contours – FK free contour programming



#### Initiating the FK dialog

If you press the gray FK button, the TNC displays the soft keys you can use to initiate an FK dialog. Press the **FK** button a second time to deselect the soft keys.

If you initiate the FK dialog with one of these soft keys, the TNC shows additional soft-key rows that you can use for entering known coordinates, directional data and data regarding the course of the contour.

Soft key	FK element
	Straight line with tangential connection
	Straight line without tangential connection
	Circular arc with tangential connection
	Circular arc without tangential connection
	Pole for FK programming

#### Pole for FK programming

- 
  - ▶ To display the soft keys for free contour programming, press the **FK** key
- 
  - ▶ To initiate the dialog for defining the pole, press the **FPOL** soft key. The TNC then displays the axis soft keys of the active working plane
  - ▶ Enter the pole coordinates using these soft keys




The pole for FK programming remains active until you define a new one using FPOL.

## Free straight line programming

### Straight line without tangential connection



- ▶ To display the soft keys for free contour programming, press the **FK** key



- ▶ To initiate the dialog for free programming of straight lines, press the **FL** soft key. The TNC displays additional soft keys
- ▶ Enter all known data in the block by using these soft keys. The FK graphic displays the programmed contour element in violet until sufficient data is entered. If the entered data describes several solutions, the graphic will display the contour element in green.


**Further Information:** "FK programming graphics", page 279

### Straight line with tangential connection

If the straight line connects tangentially to another contour element, initiate the dialog with the **FLT** soft key:



- ▶ To display the soft keys for free contour programming, press the **FK** key



- ▶ To initiate the dialog, press the **FLT** soft key
- ▶ Enter all known data in the block by using the soft keys

## Programming contours


### 6.6 Path contours – FK free contour programming

#### Free circular path programming

##### Circular arc without tangential connection



- ▶ To display the soft keys for free contour programming, press the **FK** key



- ▶ To initiate the dialog for free programming of circular arcs, press the **FC** soft key. The TNC displays soft keys with which you can directly enter data on the circular arc or the circle center
- ▶ Enter all known data in the block by using these soft keys. The FK graphic displays the programmed contour element in violet until sufficient data is entered. If the entered data describes several solutions, the graphic will display the contour element in green.


**Further Information:** "FK programming graphics", page 279

##### Circular arc with tangential connection

If the circular arc connects tangentially to another contour element, initiate the dialog with the **FCT** soft key:







- ▶ To display the soft keys for free contour programming, press the **FK** key



- ▶ To initiate the dialog, press the **FCT** soft key
- ▶ Enter all known data in the block by using the soft keys

## Input possibilities

### End point coordinates


Soft keys	Known data
 	Cartesian coordinates X and Y
 	Polar coordinates referenced to FPOL

### Example NC blocks






7 FPOL X+20 Y+30

8 FL IX+10 Y+20 RR F100

9 FCT PR+15 IPA+30 DR+ R15





### Direction and length of contour elements

Soft keys	Known data
	Length of a straight line
	Gradient angle of a straight line
	Chord length LEN of an arc
	Gradient angle AN of an entry tangent
	Center angle of an arc



### Caution: Danger to the workpiece and tool!

Gradient angles you defined incrementally (**IAN**) are referenced by the TNC to the direction of the last traversing block. Programs that contain incremental gradient angles and that were created on an iTNC 530 or on earlier TNCs are not compatible.



### Example NC blocks

27 FLT X+25 LEN 12.5 AN+35 RL F200

28 FC DR+ R6 LEN 10 AN-45

29 FCT DR- R15 LEN 15

## Programming contours

### 6.6 Path contours – FK free contour programming


#### Circle center CC, radius and direction of rotation in the FC/FCT block

The TNC calculates a circle center for free-programmed arcs from the data you enter. This makes it possible to program full circles in an FK program block.

If you wish to define the circle center in polar coordinates you must use FPOL, not **CC**, to define the pole. FPOL is entered in Cartesian coordinates and remains in effect until the control encounters a block in which another **FPOL** is defined.





A circle center that was calculated or programmed conventionally is then no longer valid as a pole or circle center for the new FK contour: If you enter conventional polar coordinates that refer to a pole from a CC block you have defined previously, then you must enter the pole again in a CC block after the FK contour.





#### Soft keys

#### Known data



Circle center in Cartesian coordinates



Center point in polar coordinates



Rotational direction of the arc



Radius of an arc

#### Example NC blocks

```
10 FC CCX+20 CCY+15 DR+ R15
```

```
11 FPOL X+20 Y+15
```


```
12 FL AN+40
```

```
13 FC DR+ R15 CCPR+35 CCPA+40
```

### Closed contours

You can identify the beginning and end of a closed contour with the **CLSD** soft key. This reduces the number of possible solutions for the last contour element.

Enter **CLSD** as an addition to another contour data entry in the first and last blocks of an FK section.



Beginning of contour: CLSD+  
End of contour: CLSD-


### Example NC blocks

```
12 L X+5 Y+35 RL F500 M3
```

```
13 FC DR- R15 CLSD+ CCX+20 CCY+35
```

```
...
```

```
17 FC DR- R+15 CLSD-
```



## Programming contours











### 6.6 Path contours – FK free contour programming

#### Auxiliary points







For both free-programmed straight lines and free-programmed circular arcs, you can enter the coordinates of auxiliary points that are located on the contour or in its proximity.

#### Auxiliary points on a contour

The auxiliary points are located on the straight line, the extension of the straight line, or on the circular arc.

Soft keys	Known data
 	X coordinate of an auxiliary point P1 or P2 of a straight line
 	Y coordinate of an auxiliary point P1 or P2 of a straight line
  	X coordinate of an auxiliary point P1, P2 or P3 of a circular path
  	Y coordinate of an auxiliary point P1, P2 or P3 of a circular path


#### Auxiliary points near a contour

Soft keys	Known data
 	X and Y coordinates of the auxiliary point near a straight line
	Distance of auxiliary point to straight line
 	X and Y coordinates of an auxiliary point near a circular arc
	Distance of auxiliary point to circular arc

#### Example NC blocks

```
13 FC DR- R10 P1X+42.929 P1Y+60.071
```

```
14 FLT AN-70 PDX+50 PDY+53 D10
```





## Relative data


Relative data are values based on another contour element. The soft keys and program words for relative entries begin with the letter **R**. The figure on the right shows the dimensional data that should be programmed as relative data.



The coordinates and angles for relative data are always programmed in incremental dimensions. You must also enter the block number of the contour element on which the data are based.

The block number of the contour element on which the relative data are based can only be located up to 64 positioning blocks before the block in which you program the reference.



If you delete a block on which relative data are based, the TNC will display an error message. Change the program first before you delete the block.





### Data relative to block N: End point coordinates

#### Soft keys

#### Known data



Cartesian coordinates relative to block N



Polar coordinates relative to block N

### Example NC blocks

12 FPOL X+10 Y+10

13 FL PR+20 PA+20

14 FL AN+45




15 FCT IX+20 DR- R20 CCA+90 RX 13

16 FL IPR+35 PA+0 RPR 13

## Programming contours

### 6.6 Path contours – FK free contour programming

**Data relative to block N: Direction and distance of the contour element**


Soft key	Known data
 RAN [N...]	Angle between a straight line and another element or between the entry tangent of the arc and another element
 PAR [N...]	Straight line parallel to another contour element
 DP	Distance from a straight line to a parallel contour element

#### Example NC blocks





```

17 FL LEN 20 AN+15
18 FL AN+105 LEN 12.5
19 FL PAR 17 DP 12.5
20 FSELECT 2
21 FL LEN 20 IAN+95
22 FL IAN+220 RAN 18

```



**Data relative to block N: Circle center CC**


Soft key	Known data
 RCCX [N...]	Cartesian coordinates of the circle center relative to block N
 RCCY [N...]	
 RCCPR [N...]	Polar coordinates of the circle center relative to block N
 RCCPA [N...]	

#### Example NC blocks


```

12 FL X+10 Y+10 RL
13 FL ...
14 FL X+18 Y+35
15 FL ...
16 FL ...
17 FC DR- R10 CCA+0 ICCX+20 ICCY-15 RCCX12 RCCY14

```



## Example: FK programming 1




0 BEGIN PGM FK1 MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-20	Definition of workpiece blank
2 BLK FORM 0.2 X+100 Y+100 Z+0	
3 TOOL CALL 1 Z S500	Tool call
4 L Z+250 R0 FMAX	Retract the tool
5 L X-20 Y+30 R0 FMAX	Pre-position the tool
6 L Z-10 R0 F1000 M3	Move to working depth
7 APPR CT X+2 Y+30 CCA90 R+5 RL F250	Approach the contour on a circular arc with tangential connection
8 FC DR- R18 CLSD+ CCX+20 CCY+30	FK contour section:
9 FLT	Program all known data for each contour element
10 FCT DR- R15 CCX+50 CCY+75	
11 FLT	
12 FCT DR- R15 CCX+75 CCY+20	
13 FLT	
14 FCT DR- R18 CLSD- CCX+20 CCY+30	
15 DEP CT CCA90 R+5 F1000	Depart the contour on a circular arc with tangential connection
16 L X-30 Y+0 R0 FMAX	
17 L Z+250 R0 FMAX M2	Retract the tool, end program
18 END PGM FK1 MM	

## Programming contours


### 6.6 Path contours – FK free contour programming

#### Example: FK programming 2



0 BEGIN PGM FK2 MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-20	Definition of workpiece blank
2 BLK FORM 0.2 X+100 Y+100 Z+0	
3 TOOL CALL 1 Z S4000	Tool call
4 L Z+250 R0 FMAX	Retract the tool
5 L X+30 Y+30 R0 FMAX	Pre-position the tool
6 L Z+5 R0 FMAX M3	Pre-position the tool
7 L Z-5 R0 F100	Move to working depth
8 APPR LCT X+0 Y+30 R5 RR F350	Approach the contour on a circular arc with tangential connection
9 FPOL X+30 Y+30	FK contour section:
10 FC DR- R30 CCX+30 CCY+30	Program all known data for each contour element
11 FL AN+60 PDX+30 PDY+30 D10	
12 FSELECT 3	
13 FC DR- R20 CCPR+55 CCPA+60	
14 FSELECT 2	
15 FL AN-120 PDX+30 PDY+30 D10	
16 FSELECT 3	
17 FC X+0 DR- R30 CCX+30 CCY+30	
18 FSELECT 2	
19 DEP LCT X+30 Y+30 R5	Depart the contour on a circular arc with tangential connection
20 L Z+250 R0 FMAX M2	Retract the tool, end program
21 END PGM FK2 MM	

## Example: FK programming 3



0 BEGIN PGM FK3 MM	
1 BLK FORM 0.1 Z X-45 Y-45 Z-20	Definition of workpiece blank
2 BLK FORM 0.2 X+120 Y+70 Z+0	
3 TOOL CALL 1 Z S4500	Tool call
4 L Z+250 R0 FMAX	Retract the tool
5 L X-70 Y+0 R0 FMAX	Pre-position the tool
6 L Z-5 R0 F1000 M3	Move to working depth
7 APPR CT X-40 Y+0 CCA90 R+5 RL F250	Approach the contour on a circular arc with tangential connection
8 FC DR- R40 CCX+0 CCY+0	FK contour section:
9 FLT	Program all known data for each contour element
10 FCT DR- R10 CCX+0 CCY+50	
11 FLT	
12 FCT DR+ R6 CCX+0 CCY+0	
13 FCT DR+ R24	
14 FCT DR+ R6 CCX+12 CCY+0	
15 FSELECT 2	
16 FCT DR- R1.5	
17 FCT DR- R36 CCX+44 CCY-10	
18 FSELECT 2	
19 FCT DR+ R5	
20 FLT X+110 Y+15 AN+0	
21 FL AN-90	
22 FL X+65 AN+180 PAR21 DP30	
23 RND R5	
24 FL X+65 Y-25 AN-90	
25 FC DR+ R50 CCX+65 CCY-75	
26 FCT DR- R65	
27 FSELECT 1	
28 FCT Y+0 DR- R40 CCX+0 CCY+0	
29 FSELECT 4	
30 DEP CT CCA90 R+5 F1000	Depart the contour on a circular arc with tangential connection

## Programming contours

### 6.6 Path contours – FK free contour programming

31 L X-70 R0 FMAX	
32 L Z+250 R0 FMAX M2	Retract the tool, end program
33 END PGM FK3 MM	

# 7

**Data transfer from  
CAD files**

## Data transfer from CAD files


### 7.1 CAD viewer and DXF converter screen layout

#### 7.1 CAD viewer and DXF converter screen layout

##### Fundamentals of the CAD viewer and DXF converter

##### Screen display

If you open the CAD viewer or DXF converter, the following screen layout is displayed:



- 1 Menu bar
- 2 Graphics window
- 3 List View window
- 4 Window element information
- 5 Status bar

##### File formats

The CAD viewer and DXF converter allow you to open standardized CAD data formats directly on the TNC.

The TNC displays the following file formats:

File	Type	Format
Step	.STP and .STEP	■ AP 203
		■ AP 214
IGES	.IGS and .IGES	■ Version 5.3
DXF	.DXF	■ R10
		■ R12
		■ R13
		■ 2000
		■ 2002













## 7.2 CAD viewer

### Application

The file can simply be selected via the file manager of the TNC, just like NC programs. This allows you to view models quickly and easily.

The datum can be positioned anywhere in the model. Starting from this datum, element information such as centers of circles can be shown.

The following icons are available:

Icon	Setting
	Show or hide the Window List view to expand the Graphics window
	Display of the various layers
	Set the datum or delete set datum
	
	Set the zoom to the largest possible view of the complete graphics
	Change the background color (black or white)
	Set resolution: The resolution specifies how many decimal places the TNC will use when generating the contour program. Default setting: 4 decimal places with <b>mm</b> and 5 decimal places with <b>inch</b>
	Switch between various views of the model e.g. <b>Top</b>
	Activate wire frame or shadowing
	

# 7

## Data transfer from CAD files

### 7.3 DXF converter (option 42)

### 7.3 DXF converter (option 42)

#### Application

DXF files can be opened directly by the TNC, in order to extract contours or machining positions, and save them as conversational programs or as point files. Conversational programs acquired in this manner can also be run by older TNC controls, since these contour programs contain only **L** and **CC/C** blocks.

If you process DXF files in **Programming** mode, the TNC generates contour programs with the file extension **.H** and point files with the extension **.PNT** by default. You can choose the desired file type in the save dialog. To add a selected contour or a selected machining position directly in an NC program, use the TNC clipboard.




The file to be processed must be stored on the hard disk of your TNC.

Before loading the file to the TNC, ensure that the name of the file does not contain any blank spaces or impermissible special characters.

**Further Information:** "File names", page 146

The TNC does not support binary DXF format. When generating the DXF file from a CAD or drawing program, make sure that you save the file in ASCII format.



The TNC supports the following types of file formats:

**Further Information:** "Fig. X", page

## Working with the DXF converter



You cannot use the DXF converter without a mouse or touch pad. All operating modes and functions as well as contours and machining positions can only be selected with the mouse or touch pad.

The DXF converter runs as a separate application on the third desktop of the TNC. This enables you to use the screen switchover key to switch between the machine operating modes, the programming modes and the DXF converter as desired. This is particularly useful if you want to add contours or machining positions by copying using the clipboard in a conversational program.

## Opening a DXF file



- ▶ Operating mode: Press the **Programming** key



- ▶ To call the file manager, press the **PGM MGT** key



- ▶ In order to see the soft key menu for selecting the file types to be displayed, press the **SELECT TYPE** soft key



- ▶ In order to show all CAD files, press the **SHOW CAD** soft key
















- ▶ Select the directory in which the CAD file is saved
- ▶ Select the desired CAD file
- ▶ Load it with the **ENT** key. The TNC starts the DXF converter and shows the contents of the file on the screen. In the List View window, the TNC shows the layers (planes) and it shows the drawing in the Graphics window


## Data transfer from CAD files

### 7.3 DXF converter (option 42)





#### Basic settings

The basic settings specified below are selected using the icons in the toolbar.

Icon	Setting
	Show or hide the Window List view to expand the Graphics window
	Display of the various layers
	Select the contour
	Select hole positions
	Set datum
	Set the zoom to the largest possible view of the complete graphics
	Change the background color (black or white)
	Switch between 2-D and 3-D mode. The active mode is color-highlighted
	Set the unit of measure, <b>mm</b> or <b>inch</b> , for the file. The TNC then outputs the contour program and the machining positions in this unit of measure. The active unit of measure is highlighted in red
	Set resolution: The resolution specifies how many decimal places the TNC will use when generating the contour program. Default setting: 4 decimal places with <b>mm</b> and 5 decimal places with <b>inch</b>
	Switch between various views of the model e.g. <b>Top</b>
	Select a contour for a turning operation. The active machining is color-highlighted (option 50)
	Activate 3-D drawing wire model



The following icons are displayed by the TNC only in certain modes.

Icon	Setting
	<p>Contour assumption mode:</p> <p>The tolerance specifies how far apart neighboring contour elements may be from each other. You can use the tolerance to compensate for inaccuracies that occurred when the drawing was made. The default setting is 0.001 mm</p>
	<p>Point assumption mode:</p> <p>Specify whether the TNC should display the tool path as a dashed straight line during selection of machining positions</p>
	<p>Path optimization mode:</p> <p>The TNC optimizes the tool traverse movement to give the shortest traverse movements between the machining positions. Optimization is reset with repeated actuations</p>
	<p>Arc mode:</p> <p>Arc mode determines whether circles should be produced in C format or CR format, e.g. for cylinder coat interpolations in the NC program.</p>



Please note that you must set the correct unit of measurement, since the DXF file does not contain any such information.

If you want to generate programs for older TNC controls, you must limit the resolution to three decimal places. In addition, you must remove the comments that the DXF converter inserts into the contour program.

The TNC displays the active basic settings in the footer of the screen.

# 7

## Data transfer from CAD files

### 7.3 DXF converter (option 42)

#### Setting layers


DXF files usually contain several layers. The designer uses these layers to create groups of various types of elements, e.g. the actual workpiece contour, dimensions, auxiliary and design lines, shadings, and texts.

So that little unnecessary information appears on the screen during selection of the contours, you can hide all excessive layers contained in the DXF file.



The DXF file to be processed must contain at least one layer. Elements not assigned to a layer are automatically moved by the TNC to the anonymous layer.

You can even select a contour if the designer has saved it on different layers.



- ▶ Select the mode for the layer settings: In the List View window the TNC shows all layers contained in the active DXF file
- ▶ Hide a layer: Select the layer with the left mouse button, and click its check box to hide it. Alternatively, use the space key
- ▶ Show a layer: Select the layer with the left mouse button, and click on its check box to show it. Alternatively, use the space key

## Setting a datum

The datum of the drawing for the DXF file is not always located in a manner that lets you use it directly as a datum for the workpiece. Therefore, the TNC has a function with which you can shift the drawing datum to a suitable location by clicking an element.


You can define a datum at the following locations:

- By directly inputting numerical values into the List View window
- At the beginning, end or center of a straight line
- At the beginning, center or end of a circular arc
- At the transition between quadrants or at the center of a complete circle
- At the intersection between:
  - A straight line and a straight line, even if the intersection is actually on the extension of one of the lines
  - Straight line – circular arc
  - Straight line – full circle
  - Circle – circle (regardless of whether a circular arc or a full circle)



You must use the touchpad or a connected mouse in order to specify a reference point.

You can also change the reference point once you have already selected the contour. The TNC does not calculate the actual contour data until you save the selected contour in a contour program.



## Selecting a datum on a single element



- ▶ Select the mode for specifying the datum
- ▶ Click the desired element with the mouse: The TNC indicates possible locations for datums on the selected element with stars
- ▶ Click the star you want to select as reference point. The TNC sets the reference-point symbol to the selected location. If the selected element is too small, then use the zoom function.

# 7

## Data transfer from CAD files

### 7.3 DXF converter (option 42)

#### Selecting a datum on the intersection of two elements




- ▶ Select the mode for specifying the datum
- ▶ Click the first element (straight line, complete circle or circular arc) with the left mouse button. The TNC indicates possible locations for datums on the selected element with stars. The element is color-highlighted
- ▶ Click on the second element (straight line, complete circle or circular arc) with the left mouse button. The TNC sets the datum symbol on the intersection



The TNC calculates the intersection of two elements even if it is on the extension of one of these elements.

If the TNC calculates multiple intersections, it selects the intersection nearest the mouse-click on the second element.


If the TNC cannot calculate an intersection, it rescinds the marking of the element.

If a datum is set, the color of the icon changes  Setting a datum.

Delete a datum by clicking on the  icon.

#### Element Information

In the Element Information window, the TNC shows how far the datum you haven chosen is located from the drawing datum.





## Selecting and saving a contour




You must use the touchpad on the TNC keyboard or a mouse attached via the USB port in order to select a contour.

Specify the direction of rotation during contour selection so that it matches the desired machining direction.

Select the first contour element such that approach without collision is possible.

If the contour elements are very close to one another, use the zoom function.



The following DXF elements are selectable as contours:

- LINE (straight line)
- CIRCLE (complete circle)
- ARC (circular arc)
- POLYLINE

Ellipses and splines can be used for intersections but cannot be selected. If you select ellipses or splines, these are displayed in red.

### Element information

In the Element Information window the TNC displays a range of information about the last contour element that you highlighted in the List View window or in the Graphics window.

- **Layer:** Indicates the layer you are currently on
- **Type:** Indicates the current element type, e.g. line
- **Coordinates:** Shows the starting point and end point of an element, and circle center and radius where appropriate

# 7

## Data transfer from CAD files

### 7.3 DXF converter (option 42)



- ▶ Select the mode for selecting a contour: The Graphics window is active for contour selection
- ▶ To select a contour element: Click the desired element with the mouse. The TNC displays the machining sequence as a dashed straight line. Position the mouse on the other side of the center point of an element to modify the machining sequence. Select the element with the left mouse button. The selected contour element turns blue. If further contour elements in the selected machining sequence are selectable, these elements turn green
- ▶ If further contour elements in the selected machining sequence are selectable, the TNC highlights these elements in green. With divergences, the element with the lowest angle distance is selected. Click on the last green element to assume all elements into the contour program
- ▶ The TNC shows all selected contour elements in the List View window. The TNC displays elements that are still green in the **NC** column without a check mark. The TNC does not save these elements to the contour program. You can also confirm the highlighted elements in the contour program by clicking in the List View window



- ▶ If necessary you can also deselect elements that you already selected by clicking the element in the graphic window again, but this time while pressing the **CTRL** key. You can deselect all selected elements by clicking the icon



- ▶ Save the selected contour elements to the clipboard of the TNC so that you can then insert the contour in a conversational program; or



- ▶ To save the selected contour elements in a conversational program, enter any file name, the file type and target directory in the pop-up window displayed by the TNC.



- ▶ Confirm the entry: The TNC saves the contour program to the selected directory



- ▶ If you want to select more contours, press the Cancel Selected Elements soft key and select the next contour as described above



The TNC also transfers two workpiece-blank definitions (**BLK FORM**) to the contour program. The first definition contains the dimensions of the entire DFX file. The second one, which is the active one, contains only the selected contour elements, so that an optimized size of the workpiece blank results.


The TNC only saves elements that have actually been selected (blue elements), which means that they have been given a check mark in the List View window.

### Dividing, extending and shortening contour elements

Proceed as follows to modify contour elements:



- ▶ The Graphics window is active for the contour selection
- ▶ To select the starting point: Select an element or the intersection between two elements (using the shift key). A red star is displayed as the starting point.
- ▶ To select the next contour element: Click the desired element with the mouse. The TNC displays the machining sequence as a dashed straight line. When the element is selected the TNC displays it in blue. If the elements cannot be connected the TNC displays the selected element in gray.
- ▶ If further contour elements in the selected machining sequence are selectable, the TNC highlights these elements in green. With divergences, the element with the lowest angle distance is selected. Click on the last green element to assume all elements into the contour program



You select the machining sequence of the contour with the first contour element.

If the contour element to be extended or shortened is a straight line, then the TNC extends/shortens the contour element along the same line. If the contour element to be extended or shortened is a circular arc, then the TNC extends/shortens the contour element along the same arc.

# 7

## Data transfer from CAD files

### 7.3 DXF converter (option 42)

#### Select a contour for a turning operation

You can also use the DXF converter (option #50) to select contours for turning. The icon is grayed out if option 50 is not enabled.


Before you enter a turning contour, you must set the datum onto the rotary axis. If you select a turning contour, it is saved with Z and X coordinates. In addition, all X coordinate values in turning contours are transferred as diameter values, i.e. the drawing dimensions for the X axis are doubled. All contour elements below the rotary axis cannot be selected and are highlighted gray.



- ▶ Select the mode for choosing a turning contour: The TNC shows only the selectable elements above the rotation center
- ▶ Select the desired contour elements with the left mouse button: The TNC displays the selected contour elements in blue and shows the selected elements with a symbol (circular or straight) in the List View window



The icons specified above have identical functions for both milling and turning. Icons not available for turning are disabled.



You can also use the mouse to change the turning graphic display. The following functions are available:

- ▶ To shift the model shown: Hold the center mouse button or the wheel button down and move the mouse.
- ▶ To zoom in on a certain area: Mark a zoom area by holding the left mouse button down. After you release the left mouse button, the TNC zooms in on the defined area
- ▶ To rapidly magnify or reduce any area: Rotate the mouse wheel backwards or forwards
- ▶ To return to the standard display: Double-click with the right mouse key

## Selecting and saving machining positions




You must use the touchpad on the TNC keyboard or a mouse attached via the USB port in order to select a machining position.

If the positions to be selected are very close to one another, use the zoom function.

If required, configure the basic settings so that the TNC shows the tool paths.

**Further Information:** "Basic settings", page 298



Three possibilities are available in the pattern generator for defining machining positions:

- Single selection: You select the desired machining position through individual mouse clicks.  
**Further Information:** "Single selection", page 308
- Rapid selection of hole positions with the mouse area: By dragging the mouse to define an area, you can select all the hole positions within this area.  
**Further Information:** "Rapid selection of hole positions with the mouse area", page 309
- Quick selection of hole positions via an icon: Click on the icon and the TNC then displays all existing hole diameters.  
**Further Information:** "Rapid selection of hole positions via icon", page 310

### Select the file type

The following file types are available:

- Point table (.PNT)
- Klartext conversational language program (.H)

If you save the machining positions to a plain-language program, the TNC creates a separate linear block with cycle call for every machining position (**L X... Y... M99**). You can also transfer this program to old TNC controls and run it there.



The point tables (.PNT) of the TNC 640 and iTNC 530 are not compatible. Transferring and processing on the other control type in each case may lead to problems and unforeseen performance.

# 7


## Data transfer from CAD files

### 7.3 DXF converter (option 42)

#### Single selection



- ▶ Select the mode for choosing a machining position. The Graphics window becomes active for position selection
- ▶ To select a machining position: Click the desired element with the mouse and the TNC displays the element in orange. If the shift key is pressed at the same time, the TNC indicates possible machining positions on the element with stars. If you click a circle, the TNC loads the circle center as machining position. If the shift key is pressed at the same time, the TNC indicates possible machining positions with stars. The TNC loads the selected position into the List View window (displays a point symbol).



- ▶ If necessary you can also deselect elements that you already selected by clicking the element in the graphic window again, but this time while pressing the **CTRL** key. Alternatively, select the element in the List View window and press **DEL**. You can deselect all selected elements by clicking the icon
- ▶ If you want to specify the machining position at the intersection of two elements, click the first element with the left mouse button: the TNC displays stars at the selectable machining positions.
- ▶ Click on the second element (straight line, complete circle or circular arc) with the left mouse button. The TNC loads the intersection of the elements into the List View window (displays a point symbol). If there are several intersections, the TNC takes the intersection nearest to the mouse.



- ▶ Save the selected machining positions to the clipboard of the TNC so that you can then insert them as a positioning block with cycle call in a Klartext conversational language program, or



- ▶ To save the selected machining positions in a point file: The TNC displays a pop-up window for you to enter any file name, the file type and target directory.



- ▶ Confirm the entry: The TNC saves the contour program to the selected directory



- ▶ If you want to select more machining positions, press the Cancel Selected Elements icon and select as described above

### Rapid selection of hole positions with the mouse area



- ▶ Select the mode for choosing a machining position: The Graphics window is active for position selection
- ▶ To select machining positions, press the shift key and define an area with the left mouse button. The TNC assumes all complete circles that are completely within the area as hole positions: The TNC opens a window in which you can filter the holes by size
- ▶ Configure the filter settings and click the **OK** button to confirm: The TNC loads the selected positions into the List View window (displays a point symbol).

**Further Information:** "Filter settings", page 311

- ▶ If necessary you can also deselect elements that you already selected by clicking the element in the graphic window again, but this time while pressing the **CTRL** key. Alternatively, select the element in the List View window and press **DEL**. If necessary you can also deselect elements that you already selected, by dragging an area open again, but this time while pressing the **CTRL** key



- ▶ Save the selected machining positions to the clipboard of the TNC so that you can then insert them as a positioning block with cycle call in a Klartext conversational language program, or




- ▶ To save the selected machining positions in a point file: The TNC displays a pop-up window for you to enter any file name, the file type and target directory.



- ▶ Confirm the entry: The TNC saves the contour program to the selected directory



- ▶ If you want to select more machining positions, press the Cancel Selected Elements icon and select as described above



# 7

## Data transfer from CAD files

### 7.3 DXF converter (option 42)

#### Rapid selection of hole positions via icon



- ▶ Select the mode for choosing a machining position: The Graphics window is active for position selection



- ▶ Select the icon: The TNC opens a window in which you can filter the holes by size
- ▶ Configure the filter settings if required and click the **OK** button to confirm: The TNC loads the selected positions into the List View window (displays a point symbol).

**Further Information:** "Filter settings", page 311



- ▶ If necessary you can also deselect elements that you already selected by clicking the element in the graphic window again, but this time while pressing the **CTRL** key. Alternatively, select the element in the List View window and press **DEL**. You can deselect all selected elements by clicking the icon



- ▶ Save the selected machining positions to the clipboard of the TNC so that you can then insert them as a positioning block with cycle call in a plain-language program, or




- ▶ To save the selected machining positions in a point file: The TNC displays a pop-up window for you to enter any file name, the file type and target directory.



- ▶ Confirm the entry: The TNC saves the contour program to the selected directory



- ▶ If you want to select more machining positions, press the Cancel Selected Elements icon and select as described above





### Filter settings


After you have used the quick selection function to mark hole positions, a pop-up window appears in which the smallest diameter found is to the left and the largest diameter to the right. With the buttons just below the diameter display you can adjust the diameter so that you can load the hole diameters that you want.

The following buttons are available:

Icon	Filter setting of smallest diameter
	Display the smallest diameter found (default setting)
	Display the next smaller diameter found
	Display the next larger diameter found
	Display the largest diameter found. The TNC sets the filter for the smallest diameter to the value set for the largest diameter
Icon	Filter setting of largest diameter
	Display the smallest diameter found. The TNC sets the filter for the largest diameter to the value set for the smallest diameter
	Display the next smaller diameter found
	Display the next larger diameter found
	Display the largest diameter found (default setting)

You can have the tool paths displayed by clicking the **SHOW TOOL PATH** icon.

**Further Information:** "Basic settings", page 298



# 7

## Data transfer from CAD files


### 7.3 DXF converter (option 42)

#### Element information

In the Element Information window, the TNC displays the coordinates of the machining position that you last selected in the List View window or Graphics window by clicking on the mouse.

You can also use the mouse to change the graphic display. The following functions are available:

- ▶ In order to rotate the model shown in three dimensions: Hold down the right mouse button down and move the mouse
- ▶ To shift the model shown: Hold the center mouse button or the wheel button down and move the mouse.
- ▶ To zoom in on a certain area: Mark a zoom area by holding the left mouse button down. After you release the left mouse button, the TNC zooms in on the defined area
- ▶ To rapidly magnify and reduce any area: Rotate the mouse wheel backwards or forwards
- ▶ To return to the standard display: Press the shift key and simultaneously double-click with the right mouse key. The rotation angle is maintained if you only double-click with the right mouse key



# 8

**Subprograms and  
program section  
repeats**

## Subprograms and program section repeats

### 8.1 Labeling subprograms and program section repeats

#### 8.1 Labeling subprograms and program section repeats

Subprograms and program section repeats enable you to program a machining sequence once and then run it as often as necessary.

##### Label

The beginnings of subprograms and program section repeats are marked in a part program by labels (**LBL**).

A LABEL is identified by a number between 1 and 65535 or by a name you define. Each LABEL number or LABEL name can be set only once in the program with the **LABEL SET** key. The number of label names you can enter is only limited by the internal memory.




Do not use a label number or label name more than once!

Label 0 (**LBL 0**) is used exclusively to mark the end of a subprogram and can therefore be used as often as desired.

## 8.2 Subprograms

### Operating sequence

- 1 The TNC executes the part program up to calling a subprogram, **CALL LBL**.
- 2 The subprogram is then executed from beginning to end, **LBL 0**.
- 3 The TNC then resumes the part program from the block after the subprogram call **CALL LBL**.



### Programming notes

- A main program can contain any number of subprograms
- You can call subprograms in any sequence and as often as desired
- A subprogram cannot call itself
- Write subprograms after the block with M2 or M30
- If subprograms are located before the block with M2 or M30 in the part program, they will be executed at least once even if they are not called

## Subprograms and program section repeats

### 8.2 Subprograms

#### Program the subprogram

LBL  
SET

- ▶ To mark the beginning: Press the **LBL SET** key
- ▶ Enter the subprogram number. If you want to use a label name, press the **LBL NAME** soft key to switch to text entry.
- ▶ Enter the text
- ▶ Mark the end: Press the **LBL SET** key and enter the label number **0**

#### Calling a subprogram

LBL  
CALL

- ▶ Call a subprogram: Press the **LBL CALL** key
- ▶ Enter the subprogram number of the subprogram you wish to call. If you want to use a label name, press the **LBL NAME** soft key to switch to text entry.
- ▶ If you want to enter the number of a string parameter as target address: Press the **QS** soft key; the TNC will then jump to the label name that is specified in the string parameter defined.
- ▶ Ignore repeats **REP** by pressing the **NO ENT** key. Repeat **REP** is used only for program section repeats




**CALL LBL 0** is not permitted (Label 0 is only used to mark the end of a subprogram).

## 8.3 Program-section repeats

### Label

The beginning of a program section repeat is marked by the label **LBL**. The end of a program section repeat is identified by **CALL LBL n REPn**.



### Operating sequence

- 1 The TNC executes the part program up to the end of the program section (**CALL LBL n REPn**)
- 2 Then the program section between the called LABEL and the label call **CALL LBL n REPn** is repeated the number of times entered after **REP**
- 3 The TNC resumes the part program after the last repetition

### Programming notes

- You can repeat a program section up to 65 534 times in succession
- The total number of times the program section is executed is always one more than the programmed number of repeats, because the first repeat starts after the first machining process.

## Subprograms and program section repeats

### 8.3 Program-section repeats

#### Programming a program section repeat

LBL  
SET

- ▶ To mark the beginning, press the **LBL SET** key and enter a LABEL NUMBER for the program section you wish to repeat. If you want to use a label name, press the **LBL NAME** soft key to switch to text entry.
- ▶ Enter the program section

#### Calling a program section repeat

LBL  
CALL

- ▶ Call a program section: Press the **LBL CALL** key
- ▶ Enter the program section number of the program section to be repeated. If you want to use a LABEL name, press the **LBL NAME** soft key to switch to text entry
- ▶ Enter the number of repeats **REP** and confirm with the **ENT** key.



## 8.4 Any desired program as subprogram

### Overview of the soft keys

If the **PGM CALL** key is pressed, the TNC displays the following soft keys:

Soft key	Function
CALL PROGRAM	Call a program with <b>PGM CALL</b>
SELECT DATUM TABLE	Select a datum table with <b>SEL TABLE</b>
SELECT POINT TABLE	Select a point table with <b>SEL PATTERN</b>
SELECT CONTOUR	Select a contour program with <b>SEL CONTOUR</b>
SELECT PROGRAM	Select a program with <b>SEL PGM</b>
CALL SELECTED PROGRAM	Select last selected file with <b>CALL SELECTED PGM</b>

## Subprograms and program section repeats


### 8.4 Any desired program as subprogram

#### Operating sequence

- 1 The TNC executes the part program up to the block in which another program is called with **CALL PGM**
- 2 Then the other part program is run from beginning to end
- 3 The TNC then resumes the first part program (i.e. the calling program) with the block after the program call



If you want to program variable program calls in connection with string parameters, use the **SEL PGM** function.



#### Programming notes

- The TNC does not need any labels to call any part program
- The called program must not contain the miscellaneous functions **M2** or **M30**. If you have defined subprograms with labels in the called part program, you then need to replace M2 or M30 with the **FN 9: IF +0 EQU +0 GOTO LBL 99** jump function to force a jump over this program section
- The called part program must not contain a **CALL PGM** call into the calling part program, otherwise an infinite loop will result

## Calling any program as a subprogram



### Danger of collision!

Coordinate transformations that you define in the called program also remain in effect for the calling program too, unless you reset them.



If the program you want to call is located in the same directory as the program you are calling it from, then you only need to enter the program name.

If the program called is not located in the same directory as the program you are calling it from, you must enter the complete path, for example **TNC: \ZW35\SCHRUPP\PGM1.H**

If you want to call a DIN/ISO program, enter the file type .I after the program name.

You can also call a program with Cycle **12 PGM CALL**.

As a rule, Q parameters are effective globally with a **PGM CALL**. So please note that changes to Q parameters in the called program also influence the calling program.

## Call a program with PGM CALL

The **PGM CALL** function calls any program as a subprogram. The control runs the called program from the position where it was called in the program.

PGM  
CALL

- ▶ To select the functions for program call, press the **PGM CALL** key

CALL  
PROGRAM

- ▶ Press the **CALL PROGRAM** soft key: The TNC starts the dialog for defining the program to be called. Enter the path name with the keyboard

or

SELECT  
FILE

- ▶ Press the **SELECT FILE** soft key: The TNC displays a selection window in which you can select the program to be called; confirm with the **ENT** key

## Subprograms and program section repeats

### 8.4 Any desired program as subprogram

#### Call with **SEL PGM** and **CALL SELECTED PGM**

Use the function **SEL PGM** to select any program as a subprogram and call it at another position in the program. The control runs the called program from the position where it was called in the program with **CALL SELECTED PGM**.

The **SEL PGM** function is also permitted with string parameters, so that you can dynamically control program calls.

To select the program, proceed as follows:

- |  |  |
|--|--|
| <div style="border: 1px solid black; padding: 2px; width: fit-content;">PGM<br/>CALL</div>       | ▶ To select the functions for program call, press the <b>PGM CALL</b> key  |
| <div style="border: 1px solid black; padding: 2px; width: fit-content;">SELECT<br/>PROGRAM</div> | ▶ Press the <b>SELECT PROGRAM</b> soft key: The TNC starts the dialog for defining the program to be called  |
| <div style="border: 1px solid black; padding: 2px; width: fit-content;">SELECT<br/>FILE</div>    | ▶ Press the <b>SELECT FILE</b> soft key: The TNC displays a selection window in which you can select the program to be called; confirm with the <b>ENT</b> key |

To call the selected program, proceed as follows:

- |   |  |
|---|--|
| <div style="border: 1px solid black; padding: 2px; width: fit-content;">PGM<br/>CALL</div>                  | ▶ To select the functions for program call, press the <b>PGM CALL</b> key  |
| <div style="border: 1px solid black; padding: 2px; width: fit-content;">CALL<br/>SELECTED<br/>PROGRAM</div> | ▶ Press the <b>CALL SELECTED PROGRAM</b> soft key: The TNC calls the last program selected with <b>CALL SELECTED PGM</b> |

## 8.5 Nesting

### Types of nesting

- Subprogram calls in subprograms
- Program-section repeats within a program-section repeat
- Subprogram calls in program section repeats
- Program-section repeats in subprograms

### Nesting depth

The nesting depth is the number of successive levels in which program sections or subprograms can call further program sections or subprograms.

- Maximum nesting depth for subprograms: 19
- Maximum nesting depth for main program calls: 19, where a **CYCL CALL** acts like a main program call
- You can nest program section repeats as often as desired

## Subprograms and program section repeats

### 8.5 Nesting

#### Subprogram within a subprogram

##### Example NC blocks

0 BEGIN PGM UPGMS MM	
...	
17 CALL LBL "UP1"	Call the subprogram marked with LBL SP1
...	
35 L Z+100 R0 FMAX M2	Last program block of the main program with M2
36 LBL "UP1"	Beginning of subprogram SP1
...	
39 CALL LBL 2	Call the subprogram marked with LBL 2
...	
45 LBL 0	End of subprogram 1
46 LBL 2	Beginning of subprogram 2
...	
62 LBL 0	End of subprogram 2
63 END PGM SUBPGMS MM	

##### Program execution

- 1 Main program UPGMS is executed up to block 17.
- 2 Subprogram SP1 is called, and executed up to block 39.
- 3 Subprogram 2 is called, and executed up to block 62. End of subprogram 2 and return jump to the subprogram from which it was called.
- 4 Subprogram 1 is called, and executed from block 40 up to block 45. End of subprogram 1 and return jump to the main program UPGMS.
- 5 Main program UPGMS is executed from block 18 up to block 35. Return jump to block 1 and end of program.

## Repeating program section repeats

### Example NC blocks

0 BEGIN PGM REPS MM	
...	
15 LBL 1	Beginning of program section repeat 1
...	
20 LBL 2	Beginning of program section repeat 2
...	
27 CALL LBL 2 REP 2	Program section call with two repeats
...	
35 CALL LBL 1 REP 1	The program section between this block and LBL 1
...	(block 15) is repeated once
50 END PGM REPS MM	

### Program execution

- 1 Main program REPS is executed up to block 27.
- 2 Program section between block 27 and block 20 is repeated twice.
- 3 Main program REPS is executed from block 28 to block 35.
- 4 Program section between block 35 and block 15 is repeated once (including the program section repeat between 20 and block 27).
- 5 Main program REPS is executed from block 36 to block 50.  
Return jump to block 1 and end of program.

## Subprograms and program section repeats

### 8.5 Nesting

#### Repeating a subprogram

##### Example NC blocks

0 BEGIN PGM UPGREP MM	
...	
10 LBL 1	Beginning of program section repeat 1
11 CALL LBL 2	Subprogram call
12 CALL LBL 1 REP 2	Program section call with two repeats
...	
19 L Z+100 R0 FMAX M2	Last block of the main program with M2
20 LBL 2	Beginning of subprogram
...	
28 LBL 0	End of subprogram
29 END PGM UPGREP MM	

##### Program execution

- 1 Main program UPGREP is executed up to block 11.
- 2 Subprogram 2 is called and executed.
- 3 Program section between block 12 and block 10 is repeated twice. This means that subprogram 2 is repeated twice.
- 4 Main program UPGREP is executed from block 13 up to block 19. Return jump to block 1 and end of program.




## 8.6 Programming examples

### Example: Milling a contour in several infeeds

Program run:

- Pre-position the tool to the workpiece surface
- Enter the infeed depth in incremental values
- Contour milling
- Repeat infeed and contour-milling



0 BEGIN PGM PGMWDH MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-40	
2 BLK FORM 0.2 X+100 Y+100 Z+0	
3 TOOL CALL 1 Z S500	Tool call
4 L Z+250 R0 FMAX	Retract the tool
5 L X-20 Y+30 R0 FMAX	Pre-position in the working plane
6 L Z+0 R0 FMAX M3	Pre-position to the workpiece surface
7 LBL 1	Set label for program section repeat
8 L IZ-4 R0 FMAX	Infeed depth in incremental values (in space)
9 APPR CT X+2 Y+30 CCA90 R+5 RL F250	Contour approach
10 FC DR- R18 CLSD+ CCX+20 CCY+30	Contour
11 FLT	
12 FCT DR- R15 CCX+50 CCY+75	
13 FLT	
14 FCT DR- R15 CCX+75 CCY+20	
15 FLT	
16 FCT DR- R18 CLSD- CCX+20 CCY+30	
17 DEP CT CCA90 R+5 F1000	Contour departure
18 L X-20 Y+0 R0 FMAX	Retract tool
19 CALL LBL 1 REP 4	Return jump to LBL 1; section is repeated a total of 4 times
20 L Z+250 R0 FMAX M2	Retract the tool, end program
21 END PGM PGMWDH MM	


## Subprograms and program section repeats

### 8.6 Programming examples

#### Example: Groups of holes

Program run:


- Approach the groups of holes in the main program
- Call the group of holes (subprogram 1) in the main program
- Program the group of holes only once in subprogram 1



0 BEGIN PGM UP1 MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-20	
2 BLK FORM 0.2 X+100 Y+100 Z+0	
3 TOOL CALL 1 Z S5000	Tool call
4 L Z+250 R0 FMAX	Retract the tool
5 CYCL DEF 200 DRILLING	Cycle definition: drilling
Q200=2 ;SET-UP CLEARANCE	
Q201=-10 ;DEPTH	
Q206=250 ;FEED RATE FOR PLNGNG	
Q202=5 ;PLUNGING DEPTH	
Q210=0 ;DWELL TIME AT TOP	
Q203=+0 ;SURFACE COORDINATE	
Q204=10 ;2ND SET-UP CLEARANCE	
Q211=0.25 ;DWELL TIME AT DEPTH	
Q395=0 ;DEPTH REFERENCE	
6 L X+15 Y+10 R0 FMAX M3	Move to starting point for group 1
7 CALL LBL 1	Call the subprogram for the group
8 L X+45 Y+60 R0 FMAX	Move to starting point for group 2
9 CALL LBL 1	Call the subprogram for the group
10 L X+75 Y+10 R0 FMAX	Move to starting point for group 3
11 CALL LBL 1	Call the subprogram for the group
12 L Z+250 R0 FMAX M2	End of main program
13 LBL 1	Beginning of subprogram 1: Group of holes
14 CYCL CALL	Hole 1
15 L IX+20 R0 FMAX M99	Move to 2nd hole, call cycle
16 L IY+20 R0 FMAX M99	Move to 3rd hole, call cycle
17 L IX-20 R0 FMAX M99	Move to 4th hole, call cycle
18 LBL 0	End of subprogram 1
19 END PGM UP1 MM	

Program run:

- Program the fixed cycles in the main program
- Call the complete hole pattern (subprogram 1) in the main program
- Approach the groups of holes (subprogram 2) in subprogram 1
- Program the group of holes only once in subprogram 2



0 BEGIN PGM UP2 MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-20	
2 BLK FORM 0.2 X+100 Y+100 Z+0	
3 TOOL CALL 1 Z S5000	Centering drill tool call
4 L Z+250 R0 FMAX	Retract the tool
5 CYCL DEF 200 DRILLING	Cycle definition: CENTERING
Q200=2 ;SET-UP CLEARANCE	
Q201=-3 ;DEPTH	
Q206=250 ;FEED RATE FOR PLNGNG.	
Q202=3 ;PLUNGING DEPTH	
Q210=0 ;DWELL TIME AT TOP	
Q203=+0 ;SURFACE COORDINATE	
Q204=10 ;2ND SET-UP CLEARANCE	
Q211=0.25 ;DWELL TIME AT DEPTH	
Q395=0 ;DEPTH REFERENCE	
6 CALL LBL 1	Call subprogram 1 for the entire hole pattern
7 L Z+250 R0 FMAX	
8 TOOL CALL 2 Z S4000	Drill tool call
9 FN 0: Q201 = -25	New depth for drilling
10 FN 0: Q202 = +5	New plunging depth for drilling
11 CALL LBL 1	Call subprogram 1 for the entire hole pattern
12 L Z+250 R0 FMAX	
13 TOOL CALL 3 Z S500	Reamer tool call

## Subprograms and program section repeats

### 8.6 Programming examples

14 CYCL DEF 201 REAMING	Cycle definition: REAMING
Q200=2 ;SET-UP CLEARANCE	
Q201=-15 ;DEPTH	
Q206=250 ;FEED RATE FOR PLNGNG.	
Q211=0.5 ;DWELL TIME AT DEPTH	
Q208=400 ;RETRACTION FEED RATE	
Q203=+0 ;SURFACE COORDINATE	
Q204=10 ;2ND SET-UP CLEARANCE	
15 CALL LBL 1	Call subprogram 1 for the entire hole pattern
16 L Z+250 R0 FMAX M2	End of main program
17 LBL 1	Beginning of subprogram 1: Entire hole pattern
18 L X+15 Y+10 R0 FMAX M3	Move to starting point for hole group 1
19 CALL LBL 2	Call subprogram 2 for the hole group
20 L X+45 Y+60 R0 FMAX	Move to starting point for hole group 2
21 CALL LBL 2	Call subprogram 2 for the hole group
22 L X+75 Y+10 R0 FMAX	Move to starting point for hole group 3
23 CALL LBL 2	Call subprogram 2 for the hole group
24 LBL 0	End of subprogram 1
25 LBL 2	Beginning of subprogram 2: Group of holes
26 CYCL CALL	1st hole with active fixed cycle
27 L IX+20 R0 FMAX M99	Move to 2nd hole, call cycle
28 L IY+20 R0 FMAX M99	Move to 3rd hole, call cycle
29 L IX-20 R0 FMAX M99	Move to 4th hole, call cycle
30 LBL 0	End of subprogram 2
31 END PGM SP2 MM	

# 9

**Programming Q  
parameters**

## Programming Q parameters

### 9.1 Principle and overview of functions

#### 9.1 Principle and overview of functions

With Q parameters you can program entire families of parts in a single NC program by programming variable Q parameters instead of fixed numerical values.

Use Q parameters for e.g.:


- Coordinate values
- Feed rates
- Spindle speeds
- Cycle data

With Q parameters you can also:

- Program contours that are defined through mathematical functions
- Make execution of machining steps depend on certain logical conditions
- Variably design FK programs

Q parameters are always identified with letters and numbers. The letters determine the type of Q parameter and the numbers the Q parameter range.

For more information, see the table below:



Q parameter type	Q parameter range	Meaning
<b>Q parameters:</b>		
	0 – 99	Parameters effect all NC programs in the TNC memory
	100 – 199	Parameters for the <b>user</b> , if there are no overlaps with the HEIDENHAIN-SL cycles
	200 – 1199	Parameters for system information on the TNC that can be read by the NC programs of the user or by cycles
	1200 – 1399	Parameters primarily used for HEIDENHAIN cycles
	1400 – 1599	Parameters that are primarily used with manufacturer cycles when values are given back to the user program
	1600 – 1999	Parameters primarily used as input parameters for manufacturer cycles
	1600 – 1999	Parameters for <b>users</b>
<b>QL parameters:</b>		
	0 – 499	Parameters only effective locally within an NC program
	0 – 499	Parameters for <b>users</b>
<b>QR parameters:</b>		
	0 – 499	Parameters that are nonvolatile on all NC programs in the TNC memory, i.e. they remain in effect even after a power interruption
	0 – 499	Parameters for <b>users</b>

**QS** parameters (the **S** stands for string) are also available on the TNC and enable you to process texts.

<b>Q parameter type</b>	<b>Q parameter range</b>	<b>Meaning</b>
<b>QS parameters:</b>		<b>Parameters effect all NC programs in the TNC memory</b>
	0 – 99	Parameters for the <b>user</b> , where no overlaps with the HEIDENHAIN SL cycles are present
	100 – 199	Parameters for diverse functions on the TNC that can be read by the NC programs of the user or by cycles
	200 – 1199	Parameters primarily used for HEIDENHAIN cycles
	1200 – 1399	Parameters that are primarily used with manufacturer cycles when values are given back to the user program
	1400 – 1599	Parameters primarily used as input parameters for manufacturer cycles
	1600 – 1999	Parameters for <b>users</b>



You gain maximum safety for your applications by using only Q parameter ranges recommended for the user in your NC programs.

Please note that the specified use of the Q parameter ranges is recommended by HEIDENHAIN but cannot be ensured.

Machine manufacturer or third-party functions may still cause overlaps with the user's NC program. Please refer to the machine manual and third-party documentation for this.

## Programming Q parameters

### 9.1 Principle and overview of functions

#### Programming notes

You can mix Q parameters and numerical values within an NC program.

Q parameters can be assigned numerical values between -999,999,999 and +999,999,999. The input range is limited to 16 digits, of which 9 may be before the decimal point. Internally the TNC calculates numbers up to a value of  $10^{10}$ .

You can assign a maximum of 255 characters to **QS**QS parameters.



The TNC automatically assigns some Q and QS parameters the same data, e.g. the Q parameter **Q108** is automatically assigned the current tool radius.

**Further Information:** " Preassigned Q parameters", page 394








The TNC saves numerical values internally in a binary number format (standard IEEE 754). Due to this standardized format some decimal numbers do not have an exact binary representation (round-off error). Keep this in mind especially when you use calculated Q-parameter contents for jump commands or positioning movements.

You can reset Q parameters to the status **UNDEFINED**. If a position is programmed with a Q parameter that is undefined, the control ignores this movement.



## Calling Q parameter functions

When you are writing a part program, press the **Q** key (in the numeric keypad for numerical input and axis selection, below the +/- key). The TNC then displays the following soft keys:

Soft key	Function group	Page
	Basic arithmetic (assign, add, subtract, multiply, divide, square root)	337
	Trigonometric functions	340
	Function for calculating circles	341
	If/then conditions, jumps	342
	Other functions	346
	Entering formulas directly	378
	Function for machining complex contours	See Cycle Programming User's Manual



The TNC shows the soft keys Q, QL and QR when you are defining or assigning a Q parameter. First press one of these soft keys to select the desired type of parameter, and then enter the parameter number.

If you have a USB keyboard connected, you can press the **Q** key to open the dialog for entering a formula.

## Programming Q parameters

### 9.2 Part families—Q parameters in place of numerical values

#### 9.2 Part families—Q parameters in place of numerical values

##### Application

The Q parameter function **FN 0: ASSIGN** assigns numerical values to Q parameters. This enables you to use variables in the program instead of fixed numerical values.

##### Example NC blocks


<b>15 FN 0: Q10=25</b>	Assign
...	Q10 is assigned the value 25
<b>25 L X +Q10</b>	Means L X +25

You need write only one program for a whole family of parts, entering the characteristic dimensions as Q parameters.

To program a particular part, you then assign the appropriate values to the individual Q parameters.

##### Example: Cylinder with Q parameters

Cylinder radius:	$R = Q1$
Cylinder height:	$H = Q2$
Cylinder Z1:	$Q1 = +30$ $Q2 = +10$
Cylinder Z2:	$Q1 = +10$ $Q2 = +50$



## 9.3 Describing contours with mathematical functions

### Application

The Q parameters listed below enable you to program basic mathematical functions in a machining program:

- Select a Q parameter function: Press the **Q** key (in the numerical keypad on the right). The Q parameter functions are displayed in a soft key row
- To select the mathematical functions, press the **BASIC ARITHM.** soft key. The TNC then displays the following soft keys:

### Overview

Soft key	Function
<div>FN0</div> <div>X = Y</div>	<b>FN 0: ASSIGN</b> e. g. <b>FN 0: Q5 = +60</b> Directly assign value Reset Q parameter value
<div>FN1</div> <div>X + Y</div>	<b>FN 1: ADDITION</b> e.g. <b>FN 1: Q1 = -Q2 + -5</b> Form and assign sum from two values
<div>FN2</div> <div>X - Y</div>	<b>FN 2: SUBTRACTION</b> e. g. <b>FN 2: Q1 = +10 - +5</b> Form and assign difference between two values
<div>FN3</div> <div>X * Y</div>	<b>FN 3: MULTIPLICATION</b> e. g. <b>FN 3: Q2 = +3 * +3</b> Form and assign the product of two values
<div>FN4</div> <div>X / Y</div>	<b>FN 4: DIVISION</b> e.g. <b>FN 4: Q4 = +8 DIV +Q2</b> Form and assign the quotient of two values <b>Not permitted:</b> Division by 0
<div>FN5</div> <div>SQRT</div>	<b>FN 5: SQUARE ROOT</b> e.g. <b>FN 5: Q20 = SQRT 4</b> Form and assign the square root of a value <b>Not permitted:</b> Square root from negative value

To the right of the "=" character you can enter the following:

- Two numbers
- Two Q parameters
- A number and a Q parameter

The Q parameters and numerical values in the equations can be entered with positive or negative signs.

## Programming Q parameters


### 9.3 Describing contours with mathematical functions

#### Programming fundamental operations


##### Example 1



- ▶ Select the Q parameter function: Press the **Q** key



- ▶ To select the mathematical functions, press the **BASIC ARITHM.** soft key.



- ▶ Select the ASSIGN Q parameter function: Press the **FN0 X = Y** soft key

##### NC sets in the TNC

16 FN 0: Q5 = +10

17 FN 3: Q12 = +Q5 \* +7

##### PARAMETER NUMBER FOR RESULT?



- ▶ Enter **12** (the number of the Q parameter) and confirm with the **ENT** key

##### FIRST VALUE / PARAMETER?




- ▶ Enter **10**: Assign the numerical value 10 to Q5 and confirm with the **ENT** soft key


##### Example 2



- ▶ Select the Q parameter function: Press the **Q** key



- ▶ To select the mathematical functions, press the **BASIC ARITHM.** soft key.



- ▶ To select the MULTIPLICATION Q parameter function, press the **FN3 X \* Y** soft key

##### PARAMETER NUMBER FOR RESULT?



- ▶ Enter **12** (the number of the Q parameter) and confirm with the **ENT** key

**FIRST VALUE / PARAMETER?**


- ▶ Enter **Q5** as the first value and confirm with the **ENT** key.

**SECOND VALUE / PARAMETER?**


- ▶ Enter **7** as the second value and confirm with the **ENT** key.

**Example 3 – Reset Q parameters**

- ▶ Select the Q parameter function: Press the **Q** key




- ▶ To select the mathematical functions, press the **BASIC ARITHM.** soft key.



- ▶ To select the ASSIGN Q parameter function, press the **FN0 X = Y** soft key

**PARAMETER NUMBER FOR RESULT?**

- ▶ Enter **12** (the number of the Q parameter) and confirm with the **ENT** key

**1. VALUE OR PARAMETER?**

- ▶ Press **SET UNDEFINED**



The **FN 0** function also supports transfer of the value **Undefined**. If you wish to transfer the undefined Q parameter without **FN 0**, the control shows the error message **Invalid value**.

**NC sets in the TNC**

16 FN 0: Q5 SET UNDEFINED

16 FN 0: Q1 = Q5

# Programming Q parameters

## 9.4 Angle functions

### 9.4 Angle functions

#### Definitions


- Sine:**  $\sin \alpha = a / c$
- Cosine:**  $\cos \alpha = b / c$
- Tangent:**  $\tan \alpha = a / b = \sin \alpha / \cos \alpha$

where

- c is the side opposite the right angle
- a is the side opposite the angle  $\alpha$
- b is the third side.

The TNC can find the angle from the tangent:

$$\alpha = \arctan (a / b) = \arctan (\sin \alpha / \cos \alpha)$$



#### Example:

a = 25 mm  
b = 50 mm  
 $\alpha = \arctan (a / b) = \arctan 0.5 = 26.57^\circ$   
Furthermore:  
 $a^2 + b^2 = c^2$  (where  $a^2 = a \times a$ )  
 $c = \sqrt{(a^2 + b^2)}$

#### Programming trigonometric functions

Press the **TRIGONOMETRY** soft key to call the trigonometric functions. The TNC then displays the soft keys that are listed in the table below.


Soft key	Function
<div>FN6</div> <div>SIN(X)</div>	<b>FN 6: SINUS</b> e. g. <b>FN 6: Q20 = SIN-Q5</b> Define and assign the sine of an angle in degrees (°)
<div>D7</div> <div>COS(X)</div>	<b>FN 7: COSINUS</b> e. g. <b>FN 7: Q21 = COS-Q5</b> Define and assign the cosine of an angle in degrees (°)
<div>FN8</div> <div>X LEN Y</div>	<b>FN 8: ROOT SUM OF SQUARES</b> e. g. <b>FN 8: Q10 = +5 LEN +4</b> Form and assign length from two values
<div>FN13</div> <div>X ANG Y</div>	<b>FN 13: ANGLE</b> e. g. <b>FN 13: Q20 = +25 ANG-Q1</b> Calculate the angle from the arc tangent of the opposite and adjacent sides or from the sine and cosine of the angle (0 < angle < 360°) and assign it to a parameter

## 9.5 Calculation of circles

### Application


The TNC can use the functions for calculating circles to calculate the circle center and the circle radius from three or four given points on the circle. The calculation is more accurate if four points are used.

Application: These functions can be used if you wish to determine the location and size of a hole or a pitch circle using the programmable probing function.

Soft key	Function
	FN 23: Determining the CIRCLE DATA from three points e. g. <b>FN 23: Q20 = CDATA Q30</b>

The coordinate pairs of three points on a circle must be saved in Q30 and the following five parameters—in this case, up to Q35.

The TNC then saves the circle center in the reference axis (X if spindle axis is Z) in parameter Q20, the circle center in the minor axis (Y if spindle axis is Z) in parameter Q21, and the circle radius in parameter Q22.

Soft key	Function
	FN 24: Determining the CIRCLE DATA from four points e. g. <b>FN 24: Q20 = CDATA Q30</b>

The coordinate pairs of four points on a circle must be saved in Q30 and the following seven parameters—in this case, up to Q37.

The TNC then saves the circle center in the reference axis (X if spindle axis is Z) in parameter Q20, the circle center in the minor axis (Y if spindle axis is Z) in parameter Q21, and the circle radius in parameter Q22.



Note that **FN 23** and **FN 24** automatically overwrite the resulting parameter and the two following parameters.

## Programming Q parameters

### 9.6 If-then decisions with Q parameters

#### 9.6 If-then decisions with Q parameters

##### Application

The TNC can make logical if-then decisions by comparing a Q parameter with another Q parameter or with a numerical value. If the condition is fulfilled, the TNC continues the program at the label that is programmed after the condition.

**Further Information:** "Labeling subprograms and program section repeats", page 314

If it is not fulfilled, the TNC continues with the next block.

To call another program as a subprogram, enter a **PGM CALL** program call after the block with the label.

##### Unconditional jumps

An unconditional jump is programmed by entering a conditional jump whose condition is always true. Example:

**FN 9: IF+10 EQU+10 GOTO LBL1**

##### Abbreviations used:

<b>IF</b>	:	If
<b>EQU</b>	:	Equal to
<b>NE</b>	:	Not equal to
<b>GT</b>	:	Greater than
<b>LT</b>	:	Less than
<b>GOTO</b>	:	Go to
<b>UNDEFINED</b>	:	Undefined
<b>DEFINED</b>	:	Defined



## Programming if-then decisions

### Possibilities for jump inputs

The following inputs are possible for the condition **IF**:

- Numbers
- Texts
- Q, QL, QR
- **QS** (string parameter)

You have three possibilities for entering the jump address **GOTO**:

- **LBL NAME**
- **LBL NUMBER**
- **QS**

Press the **JUMP** soft key to call the if-then conditions. The TNC then displays the following soft keys:

Soft key	Function
<div>FN9 IF X EQ Y GOTO</div>	<b>FN 9: IF EQUAL, JUMP</b> e. g. <b>FN 9: IF +Q1 EQU +Q3 GOTO LBL "UPCAN25"</b>
<div>EQU</div>	If both values or parameters are equal, jump to specified label
<div>FN9 IF X EQ Y GOTO</div>	<b>FN 9: IF UNDEFINED, JUMP</b> e. g. <b>FN 9: IF +Q1 IS UNDEFINED GOTO LBL "UPCAN25"</b>
<div>IS UNDEFINED</div>	If the given parameter is undefined, jump to the specified label
<div>FN9 IF X EQ Y GOTO</div>	<b>FN 9: IF DEFINED, JUMP</b> e. g. <b>FN 9: IF +Q1 IS DEFINED GOTO LBL "UPCAN25"</b>
<div>IS DEFINED</div>	If the given parameter is defined, jump to the specified label
<div>FN10 IF X NE Y GOTO</div>	<b>FN 10: IF UNEQUAL, JUMP</b> e. g. <b>FN 10: IF +10 NE -Q5 GOTO LBL 10</b> If both values or parameters are unequal, jump to specified label
<div>FN11 IF X GT Y GOTO</div>	<b>FN 11: IF GREATER, JUMP</b> g. g. <b>FN 11: IF+Q1 GT+10 GOTO LBL QS5</b> If the first value or parameter is greater than the second value or parameter, jump to specified label
<div>FN12 IF X LT Y GOTO</div>	<b>FN 12: IF LESS, JUMP</b> e. g. <b>FN 12: IF+Q5 LT+0 GOTO LBL "ANYNAME"</b> If the first value or parameter is smaller than the second value or parameter, jump to specified label

## Programming Q parameters

### 9.7 Checking and changing Q parameters

#### 9.7 Checking and changing Q parameters


##### Procedure

You can check Q parameters in all operating modes, and also edit them.

- ▶ If you are in a program run, interrupt it if required (e.g. by pressing the **NC STOP** key and the **INTERNAL STOP** soft key) or stop the test run

Q  
INFO

- ▶ To call the Q parameter functions, press the **Q** **INFO** soft key or the **Q** key
- ▶ The TNC lists all parameters and their current values. Use the arrow keys or the **GOTO** key to select the desired parameter.
- ▶ If you would like to change the value, press the **EDIT CURRENT FIELD** soft key. Enter a new file name and confirm with **ENT**
- ▶ To leave the value unchanged, press the **PRESENT VALUE** soft key or end the dialog with the **END** key



The parameters used by the TNC internally or in cycles are provided with comments.

If you want to check or edit local, global or string parameters, press the **SHOW PARAMETERS Q QL QR QS** soft key. The TNC then displays the specific parameter type. The functions previously described also apply.

## Checking and changing Q parameters 9.7

You can have Q parameters also displayed in the additional status display in all operating modes (except **Programming** mode).


- ▶ If you are in a program run, interrupt it if required (e.g. by pressing the **NC STOP** key and the **INTERNAL STOP** soft key), or stop the test run



- ▶ Call the soft key row for screen layout




- ▶ Select the screen layout with additional status display: In the right half of the screen, the TNC shows the **Overview** status form



- ▶ Press the **STATUS OF Q PARAM.** soft key **STATUS OF Q PARAM.**



- ▶ Press the **Q PARAMETER LIST** soft key: The TNC opens a pop-up window
- ▶ For each parameter type (Q, QL, QR, QS), define the parameter numbers you wish to control. Separate single Q parameters with a comma, and connect sequential Q parameters with a hyphen, e.g. 1,3,200-208. The input range per parameter type is 132 characters



The display in the **QPARA** tab always contains eight decimal places. The result of  $Q1 = \cos 89.999$  is shown by the control as 0.00001745, for example. Very large or very small values are displayed by the control in exponential notation. The result of  $Q1 = \cos 89.999 \cdot 0.001$  is shown by the control as +1.74532925e-08, whereby e-08 corresponds to the factor of  $10^{-8}$ .

## Programming Q parameters

### 9.8 Additional functions

### 9.8 Additional functions

#### Overview

Press the **DIVERSE FUNCTION** soft key to call the additional functions. The TNC then displays the following soft keys:

Soft key	Function	Page
FN14 ERROR=	<b>FN 14: ERROR</b> Display error messages	347
FN16 F-PRINT	<b>FN 16: F-PRINT</b> Formatted output of texts or Q parameter values	351
FN18 SYS-DATUM READ	<b>FN 18: SYSREAD</b> Read system data	356
FN19 PLC=	<b>FN 19: PLC</b> Transfer values to the PLC	365
FN20 WAIT FOR	<b>FN 20: WAIT FOR</b> NC and PLC synchronization	365
FN26 OPEN TABLE	<b>FN 26: TABOPEN</b> Open a freely definable table	474
FN27 WRITE TO TABLE	<b>FN 27: TABWRITE</b> Write to a freely definable table	475
FN28 READ FROM TABLE	<b>FN 28: TABREAD</b> Read from a freely definable table	476
FN29 PLC LIST=	<b>FN 29: PLC</b> Transfer up to eight values to the PLC	366
FN37 EXPORT	<b>FN 37: EXPORT</b> Export local Q parameters or QS parameters into a calling program	366
FN38 SEND	<b>FN 38: SEND</b> Send information from the NC program	366

## FN 14: ERROR: Displaying error messages

With the **FN 14: ERROR** function you can call messages under program control. The messages are predefined by the machine manufacturer or by HEIDENHAIN. Whenever the TNC comes to a block with **FN 14: ERROR** in the Program Run or Test Run mode, it interrupts the program run and displays a message. The program must then be restarted.

Error numbers area	Standard dialog
0 ... 999	Machine-dependent dialog
1000 ... 1199	Internal error messages

### Example NC block

The TNC is to display the message stored under error number 1000.

```
180 FN 14: ERROR = 1000
```

### Error message predefined by HEIDENHAIN

Error number	Text
1000	Spindle?
1001	Tool axis is missing
1002	Tool radius too small
1003	Tool radius too large
1004	Range exceeded
1005	Start position incorrect
1006	ROTATION not permitted
1007	SCALING FACTOR not permitted
1008	MIRROR IMAGE not permitted
1009	Datum shift not permitted
1010	Feed rate is missing
1011	Input value incorrect
1012	Incorrect sign
1013	Entered angle not permitted
1014	Touch point inaccessible
1015	Too many points
1016	Contradictory input
1017	CYCL incomplete
1018	Plane wrongly defined
1019	Wrong axis programmed
1020	Wrong rpm
1021	Radius comp. undefined

**9.8 Additional functions**

Error number	Text
1022	Rounding-off undefined
1023	Rounding radius too large
1024	Program start undefined
1025	Excessive nesting
1026	Angle reference missing
1027	No fixed cycle defined
1028	Slot width too small
1029	Pocket too small
1030	Q202 not defined
1031	Q205 not defined
1032	Q218 must be greater than Q219
1033	CYCL 210 not permitted
1034	CYCL 211 not permitted
1035	Q220 too large
1036	Q222 must be greater than Q223
1037	Q244 must be greater than 0
1038	Q245 must not equal Q246
1039	Angle range must be under 360°
1040	Q223 must be greater than Q222
1041	Q214: 0 not permitted
1042	Traverse direction not defined
1043	No datum table active
1044	Position error: center in axis 1
1045	Position error: center in axis 2
1046	Hole diameter too small
1047	Hole diameter too large
1048	Stud diameter too small
1049	Stud diameter too large
1050	Pocket too small: rework axis 1
1051	Pocket too small: rework axis 2
1052	Pocket too large: scrap axis 1
1053	Pocket too large: scrap axis 2
1054	Stud too small: scrap axis 1
1055	Stud too small: scrap axis 2
1056	Stud too large: rework axis 1
1057	Stud too large: rework axis 2

Error number	Text
1058	TCHPROBE 425: length exceeds max
1059	TCHPROBE 425: length below min
1060	TCHPROBE 426: length exceeds max
1061	TCHPROBE 426: length below min
1062	TCHPROBE 430: diameter too large
1063	TCHPROBE 430: diameter too small
1064	No measuring axis defined
1065	Tool breakage tolerance exceeded
1066	Enter Q247 unequal to 0
1067	Enter Q247 greater than 5
1068	Datum table?
1069	Enter Q351 unequal to 0
1070	Thread depth too large
1071	Missing calibration data
1072	Tolerance exceeded
1073	Block scan active
1074	ORIENTATION not permitted
1075	3-D ROT not permitted
1076	Activate 3-D ROT
1077	Enter depth as negative
1078	Q303 in meas. cycle undefined!
1079	Tool axis not allowed
1080	Calculated values incorrect
1081	Contradictory meas. points
1082	Incorrect clearance height
1083	Contradictory plunge type
1084	This fixed cycle not allowed
1085	Line is write-protected
1086	Oversize greater than depth
1087	No point angle defined
1088	Contradictory data
1089	Slot position 0 not allowed
1090	Enter an infeed not equal to 0
1091	Switchover of Q399 not allowed
1092	Tool not defined
1093	Tool number not permitted

## 9.8 Additional functions

Error number	Text
1094	Tool name not permitted
1095	Software option not active
1096	Kinematics cannot be restored
1097	Function not permitted
1098	Contradictory workpc. blank dim.
1099	Measuring position not allowed
1100	Kinematic access not possible
1101	Meas. pos. not in traverse range
1102	Preset compensation not possible
1103	Tool radius too large
1104	Plunging type is not possible
1105	Plunge angle incorrectly defined
1106	Angular length is undefined
1107	Slot width is too large
1108	Scaling factors not equal
1109	Tool data inconsistent



## FN16: F-PRINT – Formatted output of text and Q parameter values



With **FN16: F-PRINT**, you can also output to the screen any messages from the NC program. Such messages are displayed by the TNC in a pop-up window.

The function **FN16: F-PRINT** transfers Q parameter values and texts in a selectable format. If you send the values, the TNC saves the data in the file that you defined in the **FN16** block. The maximum size of the output file is 20 kilobytes.

To be able to use the function **FN16: F-PRINT**, first program a text file that defines the output format.

### Available functions

When you create a text file, use the following formatting functions:

Special characters	Function
"....."	Define output format for texts and variables between the quotation marks
<b>%9.3F</b>	Format for Q parameter: <ul style="list-style-type: none"> <li>■ Define %: format</li> <li>■ 9.3: 9 total characters (incl. decimal point), of which 3 are places after the decimal point</li> <li>■ F: Floating (decimal number), format for Q, QL, QR</li> </ul>
<b>%+7.3F</b>	Format for Q parameter: <ul style="list-style-type: none"> <li>■ Define %: format</li> <li>■ +: number right-aligned</li> <li>■ 7.3: 7 total characters (incl. decimal point), of which 3 are places after the decimal point</li> <li>■ F: Floating (decimal number), format for Q, QL, QR</li> </ul>
<b>%S</b>	Format for text variable QS
<b>%D or %I</b>	Format for integer
,	Separation character between output format and parameter
;	End of block character
\n	Line break
+	Q parameter value, right-aligned
-	Q parameter value, left-aligned

**9.8 Additional functions**

The following functions allow you to include the following additional information in the protocol log file:

<b>Keyword</b>	<b>Function</b>
CALL_PATH	Indicates the path for the NC program where you will find the FN16 function. Example: "Measuring program: %S",CALL_PATH;
M_CLOSE	Closes the file to which you are writing with FN16. Example: M_CLOSE;
M_APPEND	Upon renewed output, appends the log to the existing log. Example: M_APPEND;
M_APPEND_MAX	Upon renewed output, appends the log to the existing log until the maximum specified file size in kilobytes is exceeded. Example: M_APPEND_MAX20;
M_TRUNCATE	Overwrites the log upon renewed output. Example: M_TRUNCATE;
L_ENGLISH	Outputs text only for English conversational language
L_GERMAN	Outputs text only for German conversational language
L_CZECH	Outputs text only for Czech conversational language
L_FRENCH	Outputs text only for French conversational language
L_ITALIAN	Outputs text only for Italian conversational language
L_SPANISH	Outputs text only for Spanish conversational language
L_PORTUGUE	Outputs text only for Portuguese conversational language
L_SWEDISH	Outputs text only for Swedish conversational language
L_DANISH	Outputs text only for Danish conversational language
L_FINNISH	Outputs text only for Finnish conversational language
L_DUTCH	Outputs text only for Dutch conversational language
L_POLISH	Outputs text only for Polish conversational language
L_HUNGARIA	Outputs text only for Hungarian conversational language
L_CHINESE	Outputs text only for Chinese conversational language
L_CHINESE_TRAD	Outputs text only for Chinese (traditional) conversational language

Keyword	Function
L_SLOVENIAN	Outputs text only for Slovenian conversational language
L_NORWEGIAN	Outputs text only for Norwegian conversational language
L_ROMANIAN	Outputs text only for Rumanian conversational language
L_SLOVAK	Outputs text only for Slovak conversational language
L_TURKISH	Outputs text only for Turkish conversational language
L_ALL	Display text independently of the conversational language
HOUR	Number of hours from the real-time clock
MIN	Number of minutes from the real-time clock
SEC	Number of seconds from the real-time clock
DAY	Day from the real-time clock
MONTH	Month as a number from the real-time clock
STR_MONTH	Month as a string abbreviation from the real-time clock
YEAR2	Two-digit year from the real-time clock
YEAR4	Four-digit year from the real-time clock

### Creating a text file

To output the formatted texts and Q-parameter values, create a text file with the TNC's text editor. In this file you then define the output format and Q parameters you want to output. Create this file with the extension **.A**.

Example of a text file to define the output format:

**"MEASURING LOG OF IMPELLER CENTER OF GRAVITY";**

**"DATUM: %02d.%02d.%04d",DAY,MONTH,YEAR4;**

**"TIME: %02d:%02d:%02d",HOUR,MIN,SEC;**

**"NO. OF MEASURED VALUES: = 1";**

**"X1 = %9.3F", Q31;**

**"Y1 = %9.3F", Q32;**

**"Z1 = %9.3F", Q33;**

## Programming Q parameters

### 9.8 Additional functions

In the part program, program **FN 16: F-PRINT** to activate the output:

```
96 FN 16: F-PRINT TNC:\MASK\MASK1.A/ TNC:\PROT1.TXT
```

The TNC then creates the file PROT1.TXT:

**MEASURING LOG OF IMPELLER CENTER OF GRAVITY**

**DATE: July 15, 2015**

**TIME: 8:56:34 AM**

**NO. OF MEASURED VALUES : = 1**

**X1 = 149.360**

**Y1 = 25.509**

**Z1 = 37.000**



If you output the same file more than once in the program, the TNC appends all texts to the end of the texts already output within the target file.

If you use **FN16** more than once in the program, the TNC saves all texts in the file that you defined in the **FN16** function. The file is not output until the TNC reads the **END PGM** block, or you press the **NC STOP** key, or you close the file with **M\_CLOSE**.

In the **FN16** block, program the format file and the log file with their respective file type extensions

If you enter only the file name for the path of the log file, the TNC saves the log file in the directory in which the NC program with the **FN16** function is located.

In machine parameters **fn16DefaultPath** (no. 102202) and **fn16DefaultPathSim** (no. 102203) you can define a default path for outputting log files. If you use **FN16** the file must not be UTF8-encoded.

### Displaying messages on the TNC screen

You can also use the function **FN16: F-PRINT** to display any messages from the NC program in a pop-up window on the TNC screen. This makes it easy to display explanatory texts, including long texts, at any point in the program in a way that the operator has to react to them. You can also display Q-parameter contents if the protocol description file contains such instructions.

For the message to appear on the TNC screen, you need only enter **SCREEN:** as the name of the protocol file.

**96 FN 16: F-PRINT TNC:\MASK\MASK1.A/SCREEN:**

If the message has more lines than fit in the pop-up window, you can use the arrow keys to page in the window.

To close the pop-up window, press the **CE** key. To have the program close the window, program the following NC block:

**96 FN 16: F-PRINT TNC:\MASK\MASK1.A/SCLR:**



If you output the same file more than once in the program, the TNC appends all texts to the end of the texts already output within the target file.

### Exporting messages

The **FN 16** function also enables you to save the log files externally.

Enter the complete target path in the **FN 16** function:

**96 FN 16: F-PRINT TNC:\MSK\MSK1.A / PC325:\LOG\PRO1.TXT**




If you output the same file more than once in the program, the TNC appends all texts to the end of the texts already output within the target file.

## 9.8 Additional functions

### FN 18: SYSREAD – Reading system data

With the **FN 18: SYSREAD** function you can read system data and store them in Q parameters. You select the system data through a group name (ID number), and additionally through a number and an index.



Values read from the function **FN 18: SYSREAD** are always output in metric units.

Group name, ID no.	Number	Index	Meaning
Program information, 10	3	-	Number of the active fixed cycle
	103	Q parameter-number	Relevant within NC cycles; for inquiry as to whether the Q parameter given under IDX was explicitly stated in the associated CYCLE DEF.
System jump addresses, 13	1	-	Label jumped to during M2/M30 instead of ending the current program Value = 0: M2/M30 functions normally
	2	-	Label jumped to in the event of FN14: ERROR with the NC CANCEL reaction instead of aborting the program with an error message. The error number programmed in the FN14 command can be read under ID992 NR14. Value = 0: FN14 has the normal effect.
	3	-	Label jumped to in the event of an internal server error (SQL, PLC, CFG) instead of aborting the program with an error message. Value = 0: Server error has the normal effect.
Machine status, 20	1	-	Active tool number (without index)
	2	-	Prepared tool number (without index)
	3	-	Active tool axis 0=X, 1=Y, 2=Z, 6=U, 7=V, 8=W
	4	-	Programmed spindle speed
	5	-	Active spindle condition: -1=not defined, 0=M3 active, 1=M4 active, 2=M5 after M3, 3=M5 after M4
	7	-	Gear range
	8	-	Coolant status: 0=off, 1=on
	9	-	Active feed rate
	10	-	Index of prepared tool
	11	-	Index of active tool
Channel data, 25	1	-	Channel number
Cycle parameter, 30	1	-	Set-up clearance of active fixed cycle
	2	-	Drilling depth or milling depth in active fixed cycle

Group name, ID no.	Number	Index	Meaning
	3	-	Plunging depth of active machining cycle
	4	-	Feed rate for pecking in active fixed cycle
	5	-	1st side length for rectangular pocket cycle
	6	-	2nd side length for rectangular pocket cycle
	7	-	1st side length for slot cycle
	8	-	2nd side length for slot cycle
	9	-	Radius for circular pocket cycle
	10	-	Feed rate for milling in active fixed cycle
	11	-	Direction of rotation for active fixed cycle
	12	-	Dwell time for active fixed cycle
	13	-	Thread pitch for Cycles 17, 18
	14	-	Finishing allowance for active fixed cycle
	15	-	Direction angle for rough out in active fixed cycle
	21	-	Probing angle
	22	-	Probing path
	23	-	Probing feed rate
Modal condition, 35	1	-	Dimensions: 0 = absolute (G90) 1 = incremental (G91)
Data for SQL tables, 40	1	-	Result code for the last SQL command
Data from the tool table, 50	1	Tool no.	Tool length
	2	Tool no.	Tool radius
	3	Tool no.	Tool radius R2
	4	Tool no.	Oversize for tool length DL
	5	Tool no.	Tool radius oversize DR
	6	Tool no.	Tool radius oversize DR2
	7	Tool no.	Tool locked (0 or 1)
	8	Tool no.	Number of the replacement tool
	9	Tool no.	Maximum tool age TIME1
	10	Tool no.	Maximum tool age TIME2
	11	Tool no.	Current tool age CUR. TIME
	12	Tool no.	PLC status
	13	Tool no.	Maximum tooth length LCUTS
	14	Tool no.	Maximum plunge angle ANGLE
	15	Tool no.	TT: Number of tool teeth CUT
	16	Tool no.	TT: Wear tolerance for length, LTOL
	17	Tool no.	TT: Wear tolerance for radius, RTOL
	18	Tool no.	TT: Rotational direction DIRECT (0=positive/-1=negative)
	19	Tool no.	TT: Offset in plane R-OFFS

## Programming Q parameters

### 9.8 Additional functions

Group name, ID no.	Number	Index	Meaning
	20	Tool no.	TT: Offset in length L-OFFS
	21	Tool no.	TT: Breakage tolerance for length, LBREAK
	22	Tool no.	TT: Breakage tolerance for radius, RBREAK
	23	Tool no.	PLC value
	25	Tool no.	Probe center offset in minor axis CAL_OF2
	26	Tool no.	Spindle angle during calibration CAL-ANG
	27	Tool no.	Tool type for pocket table
	28	Tool no.	Maximum rpm NMAX
	32	Tool no.	Point angle TANGLE
	34	Tool no.	LIFTOFF allowed (0= No, 1= Yes)
	35	Tool no.	Wear tolerance for radius R2TOL
	37	Tool no.	Corresponding line in the touch-probe table
	38	Tool no.	Timestamp of last use
Pocket table data, 51	1	Pocket number	Tool number
	2	Pocket number	Special tool: 0=No, 1=Yes
	3	Pocket number	Fixed pocket: 0=No, 1=Yes
	4	Pocket number	Locked pocket: 0=No, 1=Yes
	5	Pocket number	PLC status
Tool location, 52	1	Tool no.	Pocket number P
	2	Tool no.	Magazine number
File information, 56	1	-	Number of lines of the selected tool table
	2	-	Number of lines of the selected datum table
	4	-	Number of lines in the open, freely definable table Value -1: No table open
Values programmed immediately after tool call, 60	1	-	Tool number T
	2	-	Active tool axis 0 = X 6 = U 1 = Y 7 = V 2 = Z 8 = W
	3	-	Spindle speed S
	4	-	Oversize for tool length DL
	5	-	Tool radius oversize DR
	6	-	Automatic TOOL CALL 0 = Yes, 1 = No
	7	-	Tool radius oversize DR2
	8	-	Tool index
	9	-	Active feed rate



Group name, ID no.	Number	Index	Meaning
Values programmed immediately after tool definition TOOL DEF, 61	1	-	Tool number T
	2	-	Length
	3	-	Radius
	4	-	Index
	5	-	Tool data programmed in TOOL DEF 1 = Yes, 0 = No
Active tool compensation, 200	1	1 = without oversize 2 = with oversize 3 = with oversize and Oversize from TOOL CALL	Active radius
	2	1 = without oversize 2 = with oversize 3 = with oversize and Oversize from TOOL CALL	Active length
	3	1 = without oversize 2 = with oversize 3 = with oversize and Oversize from TOOL CALL	Rounding radius R2
Active transformations, 210	1	-	Basic rotation manual operating mode
	2	-	Programmed rotation with Cycle 10
	3	-	Active mirrored axis
			0: Mirroring not active
			+1: X axis mirrored
			+2: Y axis mirrored
			+4: Z axis mirrored
			+64: U axis mirrored
			+128: V axis mirrored
			+256: W axis mirrored
			Combinations = Sum of individual axes
	4	1	Active scaling factor in X axis
	4	2	Active scaling factor in Y axis
	4	3	Active scaling factor in Z axis

## 9.8 Additional functions

Group name, ID no.	Number	Index	Meaning
	4	7	Active scaling factor in U axis
	4	8	Active scaling factor in V axis
	4	9	Active scaling factor in W axis
	5	1	3-D ROT A axis
	5	2	3-D ROT B axis
	5	3	3-D ROT C axis
	6	-	Tilted working plane active / inactive (-1/0) in a Program Run operating mode
	7	-	Tilted working plane active / inactive (-1/0) in a Manual operating mode
Active datum shift, 220	2	1	X axis
		2	Y axis
		3	Z axis
		4	A axis
		5	B axis
		6	C axis
		7	U axis
		8	V axis
		9	W axis
	3	1 to 9	Difference between reference point and datum in axes 1 to 9
Traverse range, 230	2	1 to 9	Negative software limit switch or traverse range limit in axes 1 to 9
	3	1 to 9	Positive software limit switch or traverse range limit in axes 1 to 9
	5	-	Software limit switch on or off: 0 = on, 1 = off
Nominal position in the machine coordinate system, 240	1	1	X axis
		2	Y axis
		3	Z axis
		4	A axis
		5	B axis
		6	C axis
		7	U axis
		8	V axis
		9	W axis
Current position in the active coordinate system, 270	1	1	X axis
		2	Y axis
		3	Z axis

Group name, ID no.	Number	Index	Meaning
		4	A axis
		5	B axis
		6	C axis
		7	U axis
		8	V axis
		9	W axis
Interpretation of coordinates in turning operation, 310	20	1 to 3 (X, Y, Z)	Coordinates are give with respect to: 0 = diameter, -1 = radius
Machining time, 320	3	-	Momentary machining time of the active NC program in minutes
TS triggering touch probe, 350	50	1	Type of touch probe
		2	Line in the touch-probe table
	51	-	Effective length
	52	1	Effective ball radius
		2	Rounding radius
	53	1	Center offset (reference axis)
		2	Center offset (minor axis)
	54	-	Spindle-orientation angle in degrees (center offset)
	55	1	Rapid traverse
		2	Measuring feed rate
	56	1	Maximum measuring range
		2	Safety clearance
	57	1	Spindle orientation possible: 0=No, 1=Yes
		2	Spindle-orientation angle
TT tool touch probe	70	1	Type of touch probe
		2	Line in the touch-probe table
	71	1	Center point in reference axis (REF system)
		2	Center point in minor axis (REF system)
		3	Center point in tool axis (REF system)
	72	-	Plate radius
	75	1	Rapid traverse
		2	Measuring feed rate for stationary spindle
		3	Measuring feed rate for rotating spindle
	76	1	Maximum measuring range
		2	Safety clearance for linear measurement
		3	Safety clearance for radial measurement
	77	-	Spindle speed
	78	-	Probing direction

## 9.8 Additional functions

Group name, ID no.	Number	Index	Meaning
Reference point from touch probe cycle, 360	1	1 to 9 (X, Y, Z, A, B, C, U, V, W)	Last reference point of a manual touch probe cycle, or last touch point from Cycle 0 without probe length compensation but with probe radius compensation (workpiece coordinate system)
	2	1 to 9 (X, Y, Z, A, B, C, U, V, W)	Last reference point of a manual touch probe cycle, or last touch point from Cycle 0 without probe length or probe radius compensation (machine coordinate system)
	3	1 to 9 (X, Y, Z, A, B, C, U, V, W)	Result of measurement of the touch probe cycles 0 and 1 without probe radius or probe length compensation
	4	1 to 9 (X, Y, Z, A, B, C, U, V, W)	Last reference point of a manual touch probe cycle, or last touch point from Cycle 0 without probe length or probe radius compensation (workpiece coordinate system)
	10	-	Oriented spindle stop
	11	-	Error status for suppressed error message 0 = Probe process successful -1 = Touch point not reached
Value from the active datum table in the active coordinate system, 500	Line	Column	Read values
Basic transformation, 507	Line	1 to 6 (X, Y, Z, SPA, SPB, SPC)	Read the basic transformation of a preset
Axis offset, 508	Line	1 to 9 (X_OFFS, Y_OFFS, Z_OFFS, A_OFFS, B_OFFS, C_OFFS, U_OFFS, V_OFFS, W_OFFS)	Read the axis offset of a preset
Active preset, 530	1	-	Read the number of the active preset
SIK, 630	2	-	Read SIK ID
Read data of the current tool, 950	1	-	Tool length L
	2	-	Tool radius R
	3	-	Tool radius R2
	4	-	Oversize for tool length DL
	5	-	Tool radius oversize DR
	6	-	Tool radius oversize DR2
	7	-	Tool locked TL 0 = not locked, 1 = locked
	8	-	Number of the replacement tool RT

Group name, ID no.	Number	Index	Meaning
	9	-	Maximum tool age TIME1
	10	-	Maximum tool age TIME2
	11	-	Current tool age CUR. TIME
	12	-	PLC status
	13	-	Maximum tooth length LCUTS
	14	-	Maximum plunge angle ANGLE
	15	-	TT: Number of tool teeth CUT
	16	-	TT: Wear tolerance for length, LTOL
	17	-	TT: Wear tolerance for radius, RTOL
	18	-	TT: Direction of rotation DIRECT 0 = Positive, -1 = Negative
	19	-	TT: Offset in plane R-OFFS
	20	-	TT: Offset in length L-OFFS
	21	-	TT: Breakage tolerance for length, LBREAK
	22	-	TT: Breakage tolerance for radius, RBREAK
	23	-	PLC value
	24	-	Tool type TYP 0 = Milling cutter, 21 = Touch probe
	27	-	Corresponding line in the touch-probe table
	32	-	Tip angle
	34	-	Lift off
Read data of the current turning tool, 951	1	-	Tool number
	2	-	Tool length XL
	4	-	Tool length ZL
	5	-	Tool length oversize DXL
	7	-	Tool length oversize DZL
	8	-	Cutting-edge radius (RS)
	9	-	Tool orientation TO
	10	-	Angle of spindle orientation (ORI)
	11	-	Tool angle
	12	-	Point angle
	13	-	Recessing width
	14	-	Tool type
	1	-	Tool usage test of the current NC program -2= no test possible, deactivated by the machine manufacturer -1 = no test possible, no tool usage file 0 = test OK, all tools available 1 = test not OK, no tool or tool is locked

# 9 Programming Q parameters

## 9.8 Additional functions

Group name, ID no.	Number	Index	Meaning
Touch probe cycles, 990	1	-	Approach behaviour: 0 = Standard behavior 1 = Effective radius, Safety clearance zero
	2	-	0 = Pushbutton monitoring off 1 = Pushbutton monitoring on
	4	-	0 = Stylus not deflected 1 = Stylus deflected
	8	-	Current spindle angle
Tool number, 990	10	Q parameter-number	Tool number associated with the tool name of the Q parameter IDX -1 = name is not available or tool is locked
Execution status, 992	10	-	Mid-program startup active 1 = Yes, 0 = No
	11	-	Search phase
	14	-	Number of the last FN14 error
	16	-	Real execution active 1 = execution , 0 = simulation
	31	-	Radius compensation in MDI mode with paraxial positioning blocks permitted 0 = Not permitted, 1 = Permitted

**Example: Assign the value of the active scaling factor for the Z axis to Q25.**

```
55 FN 18: SYSREAD Q25 = ID210 NR4 IDX3
```

## FN 19: PLC – Transfer values to the PLC



This function may only be used with the permission of your machine tool builder.

The **FN 19: PLC** function transfers up to two numerical values or Q parameters to the PLC.

## FN 20: WAIT FOR – NC and PLC synchronization



This function may only be used with the permission of your machine tool builder.

With the **FN 20: WAIT FOR** function you can synchronize the NC and PLC during a program run. The NC stops machining until the condition that you have programmed in the **FN 20: WAIT FOR** block is fulfilled.

**SYNC** is used whenever you read, for example, system data via **FN18: SYSREAD** that require synchronization with real time. The TNC stops the look-ahead calculation and executes the subsequent NC block only when the NC program has actually reached that block.

**Example: Pause internal look-ahead calculation, read current position in the X axis**

```
32 FN 20: WAIT FOR SYNC
```

```
33 FN 18: SYSREAD Q1 = ID270 NR1 IDX1
```

## Programming Q parameters

### 9.8 Additional functions

#### FN 29: PLC – Transfer values to the PLC



This function may only be used with the permission of your machine tool builder.

The **FN 29: PLC** function transfers up to eight numerical values or Q parameters to the PLC.

#### FN 37: EXPORT



This function may only be used with the permission of your machine tool builder.

You need the **FN 37: EXPORT** function if you want to create your own cycles and integrate them in the TNC.

#### FN 38: SEND – Send information from NC program

The function **FN 38: SEND** enables you to write texts and Q parameter values to the log from the NC program and send to a DNC application.

Data transmission is through a standard TCP/IP computer network.



For more detailed information, consult the Remo Tools SDK manual.

#### Example

Document values from Q1 and Q23 in the log.

```
FN 38: SEND /"Q PARAMETER Q1: %F Q23: %F" / +Q1 / +Q23
```



## 9.9 Accessing tables with SQL commands

### Introduction

Accessing of tables is programmed on the TNC with SQL commands in **transactions**. A transaction consists of multiple SQL commands that guarantee an orderly execution of the table entries.



Tables are configured by the machine manufacturer. Names and designations required as parameters for SQL commands are also specified.

The following **terms** are used:

- **Table:** A table consists of x columns and y rows. It is saved as a file in the File Manager of the TNC, and is addressed with the path and file name (= table name). Synonyms can also be used for addressing, as an alternative to the path and file name
- **Columns:** The number and names of the columns are specified when configuring the table. The column name is used for addressing in various SQL commands
- **Rows:** The number of rows is variable. You can insert new rows. There are no row numbers or other designators. You can however select rows according to their column content. Rows can only be deleted in the table editor and not via the NC program.
- **Cell:** The column in a row
- **Table entry:** Content of a cell
- **Result set:** During a transaction, the selected columns and rows are managed in the result set. You can view the result set as a sort of "intermediate memory," which temporarily assumes the set of selected columns and rows. Result set
- **Synonym:** This term defines a name used for a table instead of its path and file name. Synonyms are specified by the machine manufacturer in the configuration data

## Programming Q parameters

### 9.9 Accessing tables with SQL commands

#### A transaction

In principle, a transaction consists of the following actions:

- Address the table (file), select rows and transfer them to the result set
- Read rows from the result set, change rows or insert new rows
- Conclude transaction. If changes/insertions were made, the rows from the result set are transferred to the table (file)


Other actions are also necessary so that table entries can be edited in an NC program and to ensure that other changes are not made to copies of the same table rows at the same time. This results in the following **transaction sequence**:

- 1 A Q parameter is specified for each column to be edited. The Q parameter is assigned to a column—it is "bound" (**SQL BIND...**)
- 2 Address the table (file), select rows and transfer them to the result set. In addition, you define which columns are transferred to the result set (**SQL SELECT...**). You can lock the selected rows. Other processes can then read these rows, but cannot change the table entries. You should always lock the selected rows when you are going to make changes (**SQL SELECT ... FOR UPDATE**)
- 3 Read, change and/or add new lines in the results set: – Copy a line from the results set into the Q parameter of your NC program (**SQL FETCH...**) – Prepare changes in the Q parameters and transfer one row from the result set (**SQL UPDATE...**) – Prepare new table row in the Q parameters and transfer into the result set as a new row (**SQL INSERT...**)
- 4 Conclude transaction. – If changes/insertions have been made, the data from the result set is placed in the table (file). The data is now saved in the file. Any locks are canceled, and the result set is released (**SQL COMMIT...**). – If table entries have **not** been changed or inserted (read-only access), any locks are canceled and the result set is released (**SQL ROLLBACK... WITHOUT INDEX**)

Multiple transactions can be edited at the same time.



You must conclude a transaction, even if it consists solely of read accesses. This is to ensure that modifications/enhancements are not lost, locks not canceled or the result set enabled.



### Result set

The selected rows are numbered in ascending order within the result set, starting from 0. This numbering is referred to as the **index**. The index is used for read and write accesses, enabling a row of the result set to be specifically addressed.

It can often be advantageous to sort the rows in the result set. Do this by specifying the table column containing the sorting criteria. Also select ascending or descending order (**SQL SELECT ... ORDER BY ...**).

The selected rows that were transferred to the result set are addressed with the **HANDLE**. All following SQL commands use the handle to refer to this "set of selected columns and rows."

When concluding a transaction, the handle is released (**SQL COMMIT...** or **SQL ROLLBACK...**). It is then no longer valid.


You can edit more than one result set at the same time. The SQL server assigns a new handle for each "Select" command.

### "Binding" Q parameters to columns

The NC program does not have direct access to the table entries in the result set. The data must be transferred in Q parameters. In the other direction, the data is first prepared in the Q parameters and then transferred to the result set.

Specify with **SQL BIND ...** which table columns are mapped to which Q parameters. The Q parameters are "bound" (assigned) to the columns. Columns that are not bound to Q parameters are not included in the read-/write-processes.

If a new table row is generated with **SQL INSERT...**, the columns not linked to Q parameters are filled with default values.



## Programming Q parameters

### 9.9 Accessing tables with SQL commands

#### Programming SQL commands



This function can only be programmed if you have entered the code number 555343.

Program SQL commands in the **Programming** mode:

SPEC  
FCT

- ▶ Press the **SPEC FCT** key

PROGRAM  
FUNCTIONS

- ▶ Press the **PROGRAM FUNCTIONS** soft key



- ▶ Shift the soft-key row

SQL

- ▶ To select the MOD functions, press **SQL**
- ▶ Select an SQL command using a soft key or press the **SQL EXECUTE** soft key and program the SQL command



If a table is read from or written to with SQL commands, metric units are always output.

## Overview of the soft keys

Soft key	Function
SQL BIND	<b>SQL BIND</b> Bind a Q parameter to a table column
SQL SELECT	<b>SQL SELECT</b> Select table rows
SQL EXECUTE	<b>SQL EXECUTE</b> Program a Select command
SQL FETCH	<b>SQL FETCH</b> Read table rows from the result set and save them in Q parameters
SQL ROLLBACK	<b>SQL ROLLBACK</b> <ul style="list-style-type: none"> <li>■ If <b>INDEX</b> is not programmed: Discard any changes/insertions and conclude the transaction</li> <li>■ If <b>INDEX</b> is programmed: The indexed row remains in the result set – all other rows are deleted from the result set The transaction is <b>not</b> concluded</li> </ul>
SQL COMMIT	<b>SQL COMMIT</b> Transfer table rows from the result set into the table and conclude the transaction.
SQL UPDATE	<b>SQL UPDATE</b> Save data from the Q parameters in an existing table row in the result set
SQL INSERT	<b>SQL INSERT</b> Save data from the Q parameters in a new table row in the result set


# Programming Q parameters

## 9.9 Accessing tables with SQL commands

### SQL BIND

**SQL BIND** links a Q parameter to a table column. The SQL commands "Fetch," "Update" and "Insert" evaluate this binding (assignment) during data transfer between the result set and the NC program.

An **SQL BIND** command without a table or column name cancels the link. The link is terminated at the end of the NC program or subprogram, if not before.



- You can program any number of bindings. Read and write processes only take into account the columns that were entered in the "Select" command.
- **SQL BIND...** must be programmed **before** "Fetch," "Update" or "Insert" commands are programmed. You can program a "Select" command without a preceding "Bind" command.
- If in the "Select" command you include columns for which no link has been programmed, an error occurs during read/write processes (program interrupt).

SQL  
BIND

- ▶ **Parameter no. for result:** Q parameter that is linked (assigned) to the table column
- ▶ **Database: column name:** Enter the table name and column description – separated by . a **table name:** synonym or path and file name of this table. The synonym is entered directly – path and file name are entered in single speech marks **Column description:** description of the table column set in the configuration data

### Link Q parameters to table columns

11	SQL BIND Q881	"TAB_EXAMPLE.MEAS_NO"
12	SQL BIND Q882	"TAB_EXAMPLE.MEAS_X"
13	SQL BIND Q883	"TAB_EXAMPLE.MEAS_Y"
14	SQL BIND Q884	"TAB_EXAMPLE.MEAS_Z"

### Cancel binding

91	SQL BIND Q881
92	SQL BIND Q882
93	SQL BIND Q883
94	SQL BIND Q884

## SQL SELECT

**SQL SELECT** selects table rows and transfers them to the result set.

The SQL server places the data in the result set row-by-row. The rows are numbered in ascending order, starting from 0. This row number, called the **INDEX**, is used in the SQL commands "Fetch" and "Update".

Enter the selection criteria in the **SQL SELECT...WHERE...** function. This lets you restrict the number of rows to be transferred. If you do not use this option all rows in the table are loaded.

Enter the sorting criteria in the **SQL SELECT...ORDER BY...** function. This consists of the column designation and the keyword for ascending/descending order. If you do not use this option, the rows are placed in random order.

Lock out the selected rows for other applications with the **SQL SELECT...FOR UPDATE** function. Other applications can continue to read these rows, but cannot change them. We strongly recommend using this option if you are making changes to the table entries.

**Empty result set:** If no rows match the selection criteria, the SQL server returns a valid handle but no table entries.

SQL  
EXECUTE

- ▶ **Parameter no. for result:** Q parameter for the handle. The SQL server returns the handle for the group of columns and rows selected with the current "Select" command.  
In the event of an error (selection could not be executed) the SQL server returns a 1. Code 0 identifies an invalid handle.
- ▶ **Data bank: SQL command text:** with the following elements:
  - **SELECT** (keyword):  
Name of the SQL command, names of the table columns to be transferred. Separate column names with a , (comma). Q parameters must be linked to all columns entered here
  - **FROM** table name:  
Synonym or path and file name of this table. The synonym is entered directly: The path name and table name are entered in single quotation marks in the SQL command; names of the table columns to be transferred – separate several columns with a comma. Q parameters must be bound to all columns entered here.

### Select all table rows

```
11SQL BIND Q881
   "TAB_EXAMPLE.MEAS_NO"
```

```
12SQL BIND Q882
   "TAB_EXAMPLE.MEAS_X"
```

```
13SQL BIND Q883
   "TAB_EXAMPLE.MEAS_Y"
```

```
14SQL BIND Q884
   "TAB_EXAMPLE.MEAS_Z"
```

...

```
20SQL Q5 "SELECT
   MEAS_NO,MEAS_X,MEAS_Y,
   MEAS_Z FROM TAB_EXAMPLE"
```

### Selection of table rows with the WHERE function

...

```
20SQL Q5 "SELECT
   MEAS_NO,MEAS_X,MEAS_Y,
   MEAS_Z FROM TAB_EXAMPLE
   WHERE MEAS_NO<20"
```

### Selection of table rows with the WHERE function and Q parameters

...

```
20SQL Q5 "SELECT
   MEAS_NO,MEAS_X,MEAS_Y,
   MEAS_Z FROM TAB_EXAMPLE
   WHERE MEAS_NO==:'Q11'"
```

### Table name defined with path and file name

...

```
20SQL Q5 "SELECT
   MEAS_NO,MEAS_X,MEAS_Y,
   MEAS_Z FROM 'V:\TABLE
   \TAB_EXAMPLE' WHERE
   MEAS_NO<20"
```

9.9

Accessing tables with SQL commands

- Optional:  
**WHERE** selection criteria: A selection criterion consists of a column name, condition and comparator. Link several selection criteria with logical AND or OR. Program the comparative value directly or with a Q parameter. A Q parameter is introduced with a colon and placed in single quotation marks
- Optional:  
**ORDER BY** column name **ASC** for ascending sorting, or **ORDER BY** column name **DESC** for descending sorting. If you program neither **ASC** nor **DESC**, ascending sorting is executed by default. The TNC places the selected rows in the indicated column.
- Optional:  
**FOR UPDATE** (keyword): The selected rows are locked against write-accesses from other processes.

Condition	Programming
Equal to	= ==
Not equal to	!= <>
Less than	<
Less than or equal to	<=
Greater than	>
Greater than or equal to	>=
<b>Linking multiple conditions:</b>	
Logical AND	AND
Logical OR	OR



### SQL FETCH

**SQL FETCH** reads the row addressed with **INDEX** from the result set, and places the table entries in the linked (assigned) Q parameters. The result set is addressed with the **HANDLE**.

**SQL FETCH** takes into account all columns entered in the "Select" command.



- ▶ **Parameter no. for result:** Q parameter in which the SQL server reports the result:  
0: No error  
1: Error occurred (incorrect handle or index too large)
- ▶ **Database: SQL access ID:** Q parameter with the **handle** for identifying the result set  
**Further Information:** "SQL SELECT", page 373
- ▶ **Database: Index for SQL result:** Row number within the result set. The table entries of this row are read and are transferred into the bound Q parameters. If you do not specify the index, the first row (n=0) is read.  
Either enter the row number directly or program the Q parameter containing the index

#### Row number is transferred to a Q parameter

```
11SQL BIND Q881  
"TAB_EXAMPLE.MEAS_NO"
```

```
12SQL BIND Q882  
"TAB_EXAMPLE.MEAS_X"
```

```
13SQL BIND Q883  
"TAB_EXAMPLE.MEAS_Y"
```

```
14SQL BIND Q884  
"TAB_EXAMPLE.MEAS_Z"
```

...

```
20SQL Q5 "SELECT  
MEAS_NO,MEAS_X,MEAS_Y,  
MEAS_Z FROM TAB_EXAMPLE"
```

...

```
30 SQL FETCH Q1HANDLE Q5 INDEX  
+Q2
```

#### Row number is programmed directly

...

```
30 SQL FETCH Q1HANDLE Q5 INDEX5
```

## Programming Q parameters

### 9.9 Accessing tables with SQL commands

#### SQL UPDATE

**SQL UPDATE** transfers the data prepared in the Q parameters to the row of the result set addressed with **INDEX**. The existing row in the result set is completely overwritten.

**SQL UPDATE** takes into account all columns entered in the "Select" command.

SQL  
UPDATE

- ▶ **Parameter no. for result:** Q parameter in which the SQL server reports the result:  
0: No error  
1: Error occurred (incorrect handle, index too large, value range exceeded/fallen below or wrong data format)
- ▶ **Database: SQL access ID:** Q parameter with the **handle** for identifying the result set  
**Further Information:** "SQL SELECT", page 373
- ▶ **Database: Index for SQL result:** Row number within the result set. The table entries prepared in the Q parameters are written to this row. If you do not specify the index, the first row (n=0) is written to.  
Either enter the row number directly or program the Q parameter containing the index

#### Row number is programmed directly

```
...
40 SQL UPDATEQ1 HANDLE Q5 INDEX5
```

#### SQL INSERT

**SQL INSERT** generates a new row in the result set and transfers the data prepared in the Q parameters into the new row.

**SQL INSERT** takes into account all columns entered in the "Select" command. Table columns not entered in the "Select" command are filled with default values.

SQL  
INSERT

- ▶ **Parameter no. for result:** Q parameter in which the SQL server reports the result:  
0: No error  
1: Error occurred (incorrect handle, value range exceeded/fallen below or wrong data format)
- ▶ **Database: SQL access ID:** Q parameter with the **handle** for identifying the result set  
**Further Information:** "SQL SELECT", page 373

#### Row number is transferred to a Q parameter

```
11SQL BIND Q881
   "TAB_EXAMPLE.MEAS_NO"
12SQL BIND Q882
   "TAB_EXAMPLE.MEAS_X"
13SQL BIND Q883
   "TAB_EXAMPLE.MEAS_Y"
14SQL BIND Q884
   "TAB_EXAMPLE.MEAS_Z"
...
20SQL Q5 "SELECT
   MEAS_NO,MEAS_X,MEAS_Y,
   MEAS_Z FROM TAB_EXAMPLE"
...
40 SQL INSERTQ1 HANDLE Q5
```

## SQL COMMIT

**SQL COMMIT** transfers all rows in the result set back to the table. A lock set with **SELECT...FOR UPDATE** is canceled.

The handle given in the **SQL SELECT** command loses its validity.

SQL  
COMMIT

- ▶ **Parameter no. for result:** Q parameter in which the SQL server reports the result:  
0: No error  
1: Error occurred (incorrect handle or same entry in columns, in which unambiguous entries are required)
- ▶ **Database: SQL access ID:** Q parameter with the **handle** for identifying the result set  
**Further Information:** "SQL SELECT", page 373

```
11SQL BIND Q881
   "TAB_EXAMPLE.MEAS_NO"
12SQL BIND Q882
   "TAB_EXAMPLE.MEAS_X"
13SQL BIND Q883
   "TAB_EXAMPLE.MEAS_Y"
14SQL BIND Q884
   "TAB_EXAMPLE.MEAS_Z"
...
20SQL Q5 "SELECT
   MEAS_NO,MEAS_X,MEAS_Y,
   MEAS_Z FROM TAB_EXAMPLE"
...
30 SQL FETCH Q1HANDLE Q5 INDEX
   +Q2
...
40 SQL UPDATEQ1 HANDLE Q5 INDEX
   +Q2
...
50 SQL COMMITQ1 HANDLE Q5
```

## SQL ROLLBACK

How **SQL ROLLBACK** is executed depends on whether **INDEX** is programmed:

- If **INDEX** is not programmed: The result set is **not** written back to the table (any changes/insertions are discarded). The transaction is closed and the handle given in the **SQL SELECT** command loses its validity. Typical application: Ending a transaction with read-access only
- If **INDEX** is programmed: The indexed row remains. All other rows are deleted from the result set. The transaction is **not** concluded. A lock set with **SELECT...FOR UPDATE** remains for the indexed row; for all other rows it is reset

SQL  
ROLLBACK

- ▶ **Parameter no. for result:** Q parameter in which the SQL server reports the result:  
0: No error  
1: Error occurred (incorrect handle)
- ▶ **Database: SQL access ID:** Q parameter with the **handle** for identifying the result set  
**Further Information:** "SQL SELECT", page 373
- ▶ **Database: Index for SQL result:** Row that is to remain in the result set. Either enter the row number directly or program the Q parameter containing the index

```
11SQL BIND Q881
   "TAB_EXAMPLE.MEAS_NO"
12SQL BIND Q882
   "TAB_EXAMPLE.MEAS_X"
13SQL BIND Q883
   "TAB_EXAMPLE.MEAS_Y"
14SQL BIND Q884
   "TAB_EXAMPLE.MEAS_Z"
...
20SQL Q5 "SELECT
   MEAS_NO,MEAS_X,MEAS_Y,
   MEAS_Z FROM TAB_EXAMPLE"
...
30 SQL FETCH Q1HANDLE Q5 INDEX
   +Q2
...
50 SQL ROLLBACKQ1 HANDLE Q5
```

## Programming Q parameters














### 9.10 Entering formulas directly

#### 9.10 Entering formulas directly

##### Entering formulas

You can enter mathematical formulas that include several operations directly into the part program by soft key.

Press the **FORMULA** soft key to call the mathematical functions. The TNC displays the following soft keys in several soft-key rows:

Soft key	Linking function
	<b>Addition</b> e. g. $Q10 = Q1 + Q5$
	<b>Subtraction</b> e. g. $Q25 = Q7 - Q108$
	<b>Multiplication</b> e. g. $Q12 = 5 * Q5$
	<b>Division</b> e. g. $Q25 = Q1 / Q2$
	<b>Opening parenthesis</b> e. g. $Q12 = Q1 * (Q2 + Q3)$
	<b>Closing parenthesis</b> e. g. $Q12 = Q1 * (Q2 + Q3)$
	<b>Square the value</b> e.g. $Q15 = SQ\ 5$
	<b>Square root</b> e.g. $Q22 = SQRT\ 25$
	<b>Sine of an angle</b> e. g. $Q44 = SIN\ 45$
	<b>Cosine of an angle</b> e. g. $Q45 = COS\ 45$
	<b>Tangent of an angle</b> e. g. $Q46 = TAN\ 45$
	<b>Arc sine</b> Inverse function of the sine; determine the angle from the ratio of the opposite side to the hypotenuse e.g. $Q10 = ASIN\ 0.75$
	<b>Arc cosine</b> Inverse function of the cosine; determine the angle from the ratio of the adjacent side to the hypotenuse e. g. $Q11 = ACOS\ Q40$

Soft key	Linking function
ATAN	<b>Arc tangent</b> Inverse function of the tangent; determine the angle from the ratio of the opposite side to the adjacent side e.g. <b>Q12 = ATAN Q50</b>
^	<b>Powers of values</b> e.g. <b>Q15 = 3^3</b>
PI	<b>Constant PI (3.14159)</b> e.g. <b>Q15 = PI</b>
LN	<b>Logarithmus Naturalis (LN) of a row</b> Base 2.7183 e.g. <b>Q15 = LN Q11</b>
LOG	<b>Logarithm of a number, Base 10</b> e. g. <b>Q33 = LOG Q22</b>
EXP	<b>Exponential function, 2.7183 to the power of n</b> e. g. <b>Q1 = EXP Q12</b>
NEG	<b>Negate values (multiply by -1)</b> e.g. <b>Q2 = NEG Q1</b>
INT	<b>Truncate digits after the decimal point</b>  Form an integer e.g. <b>Q3 = INT Q42</b>
ABS	<b>Absolute value of a number</b> e. g. <b>Q4 = ABS Q22</b>
FRAC	<b>Truncate digits before the decimal point</b> Form a fraction e.g. <b>Q5 = FRAC Q23</b>
SGN	<b>Check algebraic sign of a number</b> e.g. <b>Q12 = SGN Q50</b> When return value Q12 = 1, then Q50 >= 0 When return value Q12 = -1, then Q50 < 0
%	<b>Calculate modulo value (division remainder)</b> e. g. <b>Q12 = 400 % 360</b> Result: Q12 = 40

## Programming Q parameters

### 9.10 Entering formulas directly

#### Rules for formulas

Mathematical formulas are programmed according to the following rules:

#### Higher-level operations are performed first

**12 Q1 = 5 \* 3 + 2 \* 10 = 35**

- 1 Calculation  $5 * 3 = 15$
- 2 Calculation  $2 * 10 = 20$
- 3 Calculation  $15 + 20 = 35$

**or**

**13 Q2 = SQ 10 - 3^3 = 73**

- 1 Calculation step 10 squared = 100
- 2 Calculation step 3 to the third power = 27
- 3 Calculation  $100 - 27 = 73$

#### Distributive law


Law of distribution with parentheses calculation

$$a * (b + c) = a * b + a * c$$

### Example of entry

Calculate an angle with the arc tangent from the opposite side (Q12) and adjacent side (Q13); then store in Q25.

- ▶ Select the formula entry function: Press the **Q** key and the **FORMULA** soft key, or use the shortcut
- ▶ Press the **Q** key on the ASCII keyboard



### PARAMETER NUMBER FOR RESULT?

- ▶ Enter **25** (parameter number) and press the **ENT** key
- ▶ Shift the soft-key row and select the arc tangent function
- ▶ Shift the soft-key row and open the parentheses
- ▶ Enter **12** (Q parameter number)
- ▶ Select division
- ▶ Enter **13** (Q parameter number)
- ▶ Close parentheses and conclude formula entry

### Example NC block

```
37 Q25 = ATAN (Q12/Q13)
```

9.11

String parameters

9.11

String parameters

String processing functions

You can use the **QS** parameters to create variable character strings. You can output such character strings for example through the **FN 16:F-PRINT** function to create variable logs.

You can assign a linear sequence of characters (letters, numbers, special characters and spaces) up to a length of 255 characters to a string parameter. You can also check and process the assigned or imported values using the functions described below. As in Q parameter programming, you can use a total of 2000 QS parameters.

**Further Information:** "Principle and overview of functions", page 332

The **STRING FORMULA** and **FORMULA** Q parameter functions contain various functions for processing the string parameters.

Soft key	Functions of the STRING FORMULA	Page
<div>STRING</div>	Assigning string parameters	383
<div>CFGREAD</div>	Read out machine parameter	391
	Chain-linking string parameters	383
<div>TOCHAR</div>	Converting a numerical value to a string parameter	384
<div>SUBSTR</div>	Copy a substring from a string parameter	385
<div>SYSSTR</div>	Read out system parameter	386
Soft key	FORMULA string functions	Page
<div>TONUMB</div>	Converting a string parameter to a numerical value	387
<div>INSTR</div>	Checking a string parameter	388
<div>STRLEN</div>	Finding the length of a string parameter	389
<div>STRCOMP</div>	Compare alphabetic priority	390







When you use the **STRING FORMULA** function, the result of the arithmetic operation is always a string. When you use the **FORMULA** function, the result of the arithmetic operation is always a numeric value.



## Assign string parameters

You have to assign a string variable before you use it. Use the **DECLARE STRING** command to do so.





-  ▶ Show the soft-key row with special functions
-  ▶ Open the function menu
-  ▶ Press the String functions soft key
-  ▶ Press the **DECLARE STRING** soft key

### Example NC block

```
37 DECLARE STRING QS10 = "WORKPIECE"
```

## Chain-linking string parameters

With the concatenation operator (string parameter || string parameter) you can make a chain of two or more string parameters.

-  ▶ Show the soft-key row with special functions
-  ▶ Open the function menu
-  ▶ Press the String functions soft key
- 
  - ▶ Press the **STRING FORMULA** soft key
  - ▶ Enter the number of the string parameter in which the TNC is to save the concatenated string. Confirm with the **ENT** key
  - ▶ Enter the number of the string parameter in which the **first** substring is saved. Confirm with the **ENT** key: The TNC displays the concatenation symbol ||
  - ▶ Press the **ENT** key
  - ▶ Enter the number of the string parameter in which the **second** substring is saved. Confirm with the **ENT** key
  - ▶ Repeat the process until you have selected all the required substrings. Conclude with the **END** key

### Example: QS10 is to include the complete text of QS12, QS13 and QS14

```
37 QS10 = QS12 || QS13 || QS14
```

Parameter contents:

- QS12: Workpiece
- QS13: Status:
- QS14: Scrap
- QS10: Workpiece Status: Scrap

## Programming Q parameters

### 9.11 String parameters

#### Converting a numerical value to a string parameter

With the **TOCHAR** function, the TNC converts a numerical value to a string parameter. This enables you to chain numerical values with string variables.

SPEC  
FCT

- Show the soft-key row with special functions

PROGRAM  
FUNCTIONS

- Open the function menu

STRING  
FUNCTIONS

- Press the String functions soft key

STRING  
FORMULA

- Press the **STRING FORMULA** soft key

TOCHAR

- Select the function for converting a numerical value to a string parameter
- Enter the number or the desired Q parameter to be converted, and confirm with the **ENT** key
- If desired, enter the number of decimal places that the TNC should convert, and confirm with the **ENT** key
- Close the parenthetical expression with the **ENT** key and confirm your entry with the **END** key

**Example: Convert parameter Q50 to string parameter QS11, use 3 decimal places**

```
37 QS11 = TOCHAR ( DAT+Q50 DECIMALS3 )
```

## Copying a substring from a string parameter

The **SUBSTR** function copies a definable range from a string parameter.

- |   |  |
|---|--|
| <div style="border: 1px solid black; padding: 2px; width: fit-content; margin-bottom: 10px;">SPEC<br/>FCT</div> <div style="border: 1px solid black; padding: 2px; width: fit-content; margin-bottom: 10px;">PROGRAM<br/>FUNCTIONS</div> <div style="border: 1px solid black; padding: 2px; width: fit-content; margin-bottom: 10px;">STRING<br/>FUNCTIONS</div> <div style="border: 1px solid black; padding: 2px; width: fit-content; margin-bottom: 10px;">STRING<br/>FORMULA</div> <div style="border: 1px solid black; padding: 2px; width: fit-content;">SUBSTR</div> | <ul style="list-style-type: none"> <li>▶ Show the soft-key row with special functions</li> <br/> <li>▶ Open the function menu</li> <br/> <li>▶ Press the String functions soft key</li> <br/> <li>▶ Press the <b>STRING FORMULA</b> soft key</li> <li>▶ Enter the number of the string parameter in which the TNC is to save the copied string. Confirm with the <b>ENT</b> key</li> <br/> <li>▶ Select the function for cutting out a substring</li> <li>▶ Enter the number of the QS parameter from which the substring is to be copied. Confirm with the <b>ENT</b> key</li> <br/> <li>▶ Enter the number of the place starting from which to copy the substring, and confirm with the <b>ENT</b> key</li> <br/> <li>▶ Enter the number of characters to be copied, and confirm with the <b>ENT</b> key</li> <br/> <li>▶ Close the parenthetical expression with the <b>ENT</b> key and confirm your entry with the <b>END</b> key</li> </ul> |
|---|--|



Remember that the first character of a text sequence starts internally with the zeroth place.

**Example: A four-character substring (LEN4) is read from the string parameter QS10 beginning with the third character (BEG2)**

```
37 QS13 = SUBSTR ( SRC_QS10 BEG2 LEN4 )
```

## 9 Programming Q parameters

### 9.11 String parameters

#### Reading system data

With the function **SYSTR** you can read system data and store them in string parameters. You select the system data through a group number (ID) and a number.

Entering **IDX** and **DAT** is not required.

Group name, ID no.	Number	Meaning
Program information, 10010	1	Path of the current main program
	3	Path of the cycle selected with <b>CYCL DEF 12 PGM CALL</b>
	10	Path of the program selected with <b>SEL PGM</b>
Channel data, 10025	1	Channel name
Values programmed in the tool call, 10060	1	Tool name
Kinematics, 10290	10	Kinematics programmed in the last <b>FUNCTION MODE</b> block
Touch-probe data, 10350	50	Probe type of the active touch probe TS
	70	Probe type of the active touch probe TT
	73	Key name of the active touch probe TT from MP <b>activeTT</b>
Data for pallet machining, 10510	1	Pallet name
	2	Path of the selected pallet table
NC software version, 10630	10	Version identifier of the NC software version
Information for unbalance cycle, 10855	1	Path of the unbalance calibration table belonging to the active kinematics
Tool data, 10950	1	Tool name
	2	DOC entry of the tool
	3	AFC control setting
	4	Tool-carrier kinematics

## Converting a string parameter to a numerical value

The **TONUMB** function converts a string parameter to a numerical value. The value to be converted should be only numerical.



The QS parameter must contain only one numerical value. Otherwise the TNC will output an error message.

**Q**

- ▶ Select Q-parameter functions

**FORMULA**

- ▶ Press the **FORMULA** soft key
- ▶ Enter the number of the parameter in which the TNC is to save the numerical value. Confirm with the **ENT** key



- ▶ Shift the soft-key row

**TONUMB**

- ▶ Select the function for converting a string parameter to a numerical value
- ▶ Enter the number of the QS parameter to be converted, and confirm with the **ENT** key
- ▶ Close the parenthetical expression with the **ENT** key and confirm your entry with the **END** key

**Example: Convert string parameter QS11 to a numerical parameter Q82**










```
37 Q82 = TONUMB ( SRC_QS11 )
```

## Programming Q parameters

### 9.11 String parameters

#### Testing a string parameter

The **INSTR** function checks whether a string parameter is contained in another string parameter.

-  ▶ Select Q-parameter functions
-  ▶ Press the **FORMULA** soft key
-  ▶ Enter the number of the Q parameter for the result and confirm with the **ENT** key. The TNC saves in the parameter the position at which the sought-after text begins.
-  ▶ Shift the soft-key row
-  ▶ Select the function for checking a string parameter
-  ▶ Enter the number of the QS parameter in which the text to be searched for is saved. Confirm with the **ENT** key
-  ▶ Enter the number of the QS parameter to be searched, and confirm with the **ENT** key
-  ▶ Enter the number of the place starting from which the TNC is to search the substring, and confirm with the **ENT** key
-  ▶ Close the parenthetical expression with the **ENT** key and confirm your entry with the **END** key



Remember that the first character of a text sequence starts internally with the zeroth place.

If the TNC cannot find the required substring, it will save the total length of the string to be searched (counting starts at 1) in the result parameter.








If the substring is found in more than one place, the TNC returns the first place at which it finds the substring.

**Example: Search through QS10 for the text saved in parameter QS13. Begin the search at the third place.**

```
37 Q50 = INSTR ( SRC_QS10 SEA_QS13 BEG2 )
```

## Finding the length of a string parameter

The **STRLEN** function returns the length of the text saved in a selectable string parameter.

-  ▶ Select Q parameter function
-  ▶ Press the **FORMULA** soft key
-  ▶ Enter the number of the Q parameter in which the TNC is to save the ascertained string length. Confirm with the **ENT** key
-  ▶ Shift the soft-key row
-  ▶ Select the function for finding the text length of a string parameter
-  ▶ Enter the number of the QS parameter whose length the TNC is to ascertain, and confirm with the **ENT** key
-  ▶ Close the parenthetical expression with the **ENT** key and confirm your entry with the **END** key

### Example: Find the length of QS15

```
37 Q52 = STRLEN ( SRC_QS15 )
```








If the selected string parameter is not defined the control returns the result **-1**.

## Programming Q parameters

### 9.11 String parameters

#### Compare alphabetic priority

The **STRCOMP** function compares string parameters for alphabetic priority.

-  ▶ Select Q parameter function
-  ▶ Press the **FORMULA** soft key
-  ▶ Enter the number of the Q parameter in which the TNC is to save the result of comparison. Confirm with the **ENT** key
-  ▶ Shift the soft-key row
- 
  - ▶ Select the function for comparing string parameters
  - ▶ Enter the number of the first QS parameter to be compared, and confirm with the **ENT** key
  - ▶ Enter the number of the second QS parameter to be compared, and confirm with the **ENT** key
  - ▶ Close the parenthetical expression with the **ENT** key and confirm your entry with the **END** key



The TNC returns the following results:

- **0**: The compared QS parameters are identical
- **-1**: The first QS parameter **precedes** the second QS parameter alphabetically
- **+1**: The first QS parameter **follows** the second QS parameter alphabetically

**Example: QS12 and QS14 are compared for alphabetic priority**





```
37 Q52 = STRCOMP ( SRC_QS12 SEA_QS14 )
```



## Reading out machine parameters

Use the **CFGREAD** function to read out TNC machine parameters as numerical values or as strings. The read values are always output in metric units.

In order to read out a machine parameter, you must use the TNC's configuration editor to determine the parameter name, parameter object, and, if they have been assigned, the group name and index:

Icon	Type	Meaning	Example
	<b>Key</b>	Group name of the machine parameter (if available)	CH_NC
	<b>Entity</b>	Parameter object (name begins with "Cfg...")	CfgGeoCycle
	<b>Attribute</b>	Name of the machine parameter	displaySpindleErr
	<b>Index</b>	List index of a machine parameter (if available)	[0]



If you are in the configuration editor for the user parameters, you can change the display of the existing parameters. In the default setting, the parameters are displayed with short, explanatory texts. To display the actual system names of the parameters, press the key for the screen layout key and then the **SHOW SYSTEM NAME** soft key. Follow the same procedure to return to the standard display.

Each time you want to interrogate a machine parameter with the **CFGREAD** function, you must first define a QS parameter with attribute, entity and key.

The following parameters are read in the CFGREAD function's dialog:

- **KEY\_QS**: Group name (key) of the machine parameter
- **TAG\_QS**: Object name (entity) of the machine parameter
- **ATR\_QS**: Name (attribute) of the machine parameter
- **IDX**: Index of the machine parameter

# Programming Q parameters

## 9.11 String parameters

### Reading a string of a machine parameter

In order to store the content of a machine parameter as a string in a QS parameter:

- Q
- STRING  
FORMULA
- ▶ Press the **Q** key.
  - ▶ Press the **STRING FORMULA** soft key
  - ▶ Enter the number of the string parameter in which the TNC is to save the machine parameter. Confirm with the **ENT** key
  - ▶ Select the **CFGREAD** function
  - ▶ Enter the numbers of the string parameters for the key, entity and attribute, then confirm with the **ENT** key
  - ▶ Enter the number for the index, or skip the dialog with **NNO ENT**, whichever applies
  - ▶ Close the parenthetical expression with the **ENT** key and confirm your entry with the **END** key

**Example: Read as a string the axis designation of the fourth axis**

#### Parameter settings in the configuration editor

DisplaySettings  
CfgDisplayData  
axisDisplayOrder  
[0] to [5]

14 QS11 = ""	Assign string parameter for key
15 QS12 = "CFGDISPLAYDATA"	Assign string parameter for entity
16 QS13 = "AXISDISPLAY"	Assign string parameter for parameter name
17 QS1 = CFGREAD( KEY_QS11 TAG_QS12 ATR_QS13 IDX3 )	Read out machine parameter

### Reading a numerical value of a machine parameter

Store the value of a machine parameter as a numerical value in a Q parameter:

- Q

  - ▶ Select Q parameter function
- FORMULA

  - ▶ Press the **FORMULA** soft key
  - ▶ Enter the number of the Q parameter in which the TNC is to save the machine parameter. Confirm with the **ENT** key
  - ▶ Select the **CFGREAD** function
  - ▶ Enter the numbers of the string parameters for the key, entity and attribute, then confirm with the **ENT** key
  - ▶ Enter the number for the index, or skip the dialog with **NNO ENT**, whichever applies
  - ▶ Close the parenthetical expression with the **ENT** key and confirm your entry with the **END** key

### Example: Read overlap factor as Q parameter

#### Parameter settings in the configuration editor

```
ChannelSettings
CH_NC
    CfgGeoCycle
        pocketOverlap
```

14 QS11 = "CH_NC"	Assign string parameter for key
15 QS12 = "CFGGEOCYCLE"	Assign string parameter for entity
16 QS13 = "POCKETOVERLAP"	Assign string parameter for parameter name
17 Q50 = CFGREAD( KEY_QS11 TAG_QS12 ATR_QS13 )	Read out machine parameter

## Programming Q parameters

### 9.12 Preassigned Q parameters

#### 9.12 Preassigned Q parameters

The Q parameters Q100 to Q199 are assigned values by the TNC. The following types of information are assigned to Q parameters:

- Values from the PLC
- Tool and spindle data
- Data on operating status
- Results of measurements from touch probe cycles etc.

The TNC saves the values for the preassigned Q parameters Q108, Q114 and Q115 to Q117 in the unit of measure used by the active program.



Preassigned Q parameters (QS parameters) between **Q100** and **Q199** (**QS100** and **QS199**) must not be used in NC programs as calculation parameters. Otherwise you might receive undesired results.

#### Values from the PLC: Q100 to Q107

The TNC uses the parameters Q100 to Q107 to transfer values from the PLC to an NC program.

#### Active tool radius: Q108

The active value of the tool radius is assigned to Q108. Q108 is calculated from:

- Tool radius R (tool table or **TOOL DEF** block)
- Delta value DR from the tool table
- Delta value DR from the **TOOL CALL** block



The TNC remembers the current tool radius even if the power is interrupted.

#### Tool axis: Q109

The value of Q109 depends on the current tool axis:

Tool axis	Parameter value
No tool axis defined	Q109 = -1
X axis	Q109 = 0
Y axis	Q109 = 1
Z axis	Q109 = 2
U axis	Q109 = 6
V axis	Q109 = 7
W axis	Q109 = 8

**Spindle status: Q110**

The value of the parameter Q110 depends on the M function last programmed for the spindle.

M function	Parameter value
No spindle status defined	Q110 = -1
M3: Spindle ON, clockwise	Q110 = 0
M4: Spindle ON, counterclockwise	Q110 = 1
M5 after M3	Q110 = 2
M5 after M4	Q110 = 3

**Coolant on/off: Q111**

M function	Parameter value
M8: Coolant ON	Q111 = 1
M9: Coolant OFF	Q111 = 0

**Overlap factor: Q112**

The overlap factor for pocket milling is assigned to Q112.

**Unit of measurement for dimensions in the program: Q113**

During nesting the **PGM CALL**, the value of the parameter Q113 depends on the dimensional data of the program from which the other programs are called.

Dimensional data of the main program	Parameter value
Metric system (mm)	Q113 = 0
Imperial system (inch)	Q113 = 1

**Tool length: Q114**

The current value for the tool length is assigned to Q114.



The TNC remembers the current tool length even if the power is interrupted.

## Programming Q parameters

### 9.12 Preassigned Q parameters

#### Coordinates after probing during program run

The parameters Q115 to Q119 contain the coordinates of the spindle position at the moment of contact during programmed measurement with the 3-D touch probe. The coordinates refer to the datum point that is active in the **Manual operation** mode.

The length of the stylus and the radius of the ball tip are not compensated in these coordinates.

Coordinate axis	Parameter value
X axis	Q115
Y axis	Q116
Z axis	Q117
4th axis Machine-dependent	Q118
5th axis Machine-dependent	Q119

#### Deviation between actual value and nominal value during automatic tool measurement with the TT 130

Deviation of actual from nominal value	Parameter value
Tool length	Q115
Tool radius	Q116

#### Tilting the working plane with mathematical angles: rotary axis coordinates calculated by the TNC

Coordinates	Parameter value
A axis	Q120
B axis	Q121
C axis	Q122

## Measurement results from touch probe cycles

**Further information:** Cycle Programming User's Manual

Measured actual values	Parameter value
Angle of a straight line	Q150
Center in reference axis	Q151
Center in minor axis	Q152
Diameter	Q153
Pocket length	Q154
Pocket width	Q155
Length of the axis selected in the cycle	Q156
Position of the centerline	Q157
Angle in the A axis	Q158
Angle in the B axis	Q159
Coordinate of the axis selected in the cycle	Q160
Measured deviation	Parameter value
Center in reference axis	Q161
Center in minor axis	Q162
Diameter	Q163
Pocket length	Q164
Pocket width	Q165
Measured length	Q166
Position of the centerline	Q167
Determined space angle	Parameter value
Rotation about the A axis	Q170
Rotation about the B axis	Q171
Rotation about the C axis	Q172
Workpiece status	Parameter value
Good	Q180
Rework	Q181
Scrap	Q182

# 9

## Programming Q parameters

### 9.12 Preassigned Q parameters

Tool measurement with the BLUM laser	Parameter value
Reserved	Q190
Reserved	Q191
Reserved	Q192
Reserved	Q193
Reserved for internal use	Parameter value
Marker for cycles	Q195
Marker for cycles	Q196
Marker for cycles (machining patterns)	Q197
Number of the last active measuring cycle	Q198
Status of tool measurement with TT	Parameter value
Tool within tolerance	Q199 = 0.0
Tool is worn (LTOL/RTOL is exceeded)	Q199 = 1.0
Tool is broken (LBREAK/RBREAK is exceeded)	Q199 = 2.0

#### Checking the setup situation: Q601

The value of the parameter Q601 indicates the status of the camera-based monitoring of the VSC setup situation.

Status	Parameter value
No error	Q601 = 1
Error	Q601 = 2
No monitoring area defined or not enough reference images	Q601 = 3
Internal errs (no signal, camera fault, etc)	Q601 = 10




## 9.13 Programming examples

### Example: Ellipse

Program run

- The contour of the ellipse is approximated by many short lines (defined in Q7). The more calculation steps you define for the lines, the smoother the curve becomes.
- The milling direction is determined with the starting angle and end angle in the plane:  
Machining direction is clockwise:  
Starting angle > end angle  
Machining direction is counterclockwise:  
Starting angle < end angle
- The tool radius is not taken into account



<b>0 BEGIN PGM ELLIPSE MM</b>	
<b>1 FN 0: Q1 = +50</b>	Center in X axis
<b>2 FN 0: Q2 = +50</b>	Center in Y axis
<b>3 FN 0: Q3 = +50</b>	Semixaxis in X
<b>4 FN 0: Q4 = +30</b>	Semixaxis in Y
<b>5 FN 0: Q5 = +0</b>	Starting angle in the plane
<b>6 FN 0: Q6 = +360</b>	End angle in the plane
<b>7 FN 0: Q7 = +40</b>	Number of calculation steps
<b>8 FN 0: Q8 = +0</b>	Rotational position of the ellipse
<b>9 FN 0: Q9 = +5</b>	Milling depth
<b>10 FN 0: Q10 = +100</b>	Feed rate for plunging
<b>11 FN 0: Q11 = +350</b>	Feed rate for milling
<b>12 FN 0: Q12 = +2</b>	Set-up clearance for pre-positioning
<b>13 BLK FORM 0.1 Z X+0 Y+0 Z-20</b>	Workpiece blank definition
<b>14 BLK FORM 0.2 X+100 Y100 Z+0</b>	
<b>15 TOOL CALL 1 Z S4000</b>	Tool call
<b>16 L Z+250 R0 FMAX</b>	Retract the tool
<b>17 CALL LBL 10</b>	Call machining operation
<b>18 L Z+100 R0 FMAX M2</b>	Retract the tool, end program
<b>19 LBL 10</b>	Subprogram 10: Machining operation
<b>20 CYCL DEF 7.0 DATUM SHIFT</b>	Shift datum to center of ellipse
<b>21 CYCL DEF 7.1 X+Q1</b>	
<b>22 CYCL DEF 7.2 Y+Q2</b>	
<b>23 CYCL DEF 10.0 ROTATION</b>	Account for rotational position in the plane
<b>24 CYCL DEF 10.1 ROT+Q8</b>	
<b>25 Q35 = (Q6 -Q5) / Q7</b>	Calculate angle increment
<b>26 Q36 = Q5</b>	Copy starting angle

# 9

## Programming Q parameters


### 9.13 Programming examples

27 Q37 = 0	Set counter
28 Q21 = Q3 *COS Q36	Calculate X coordinate for starting point
29 Q22 = Q4 *SIN Q36	Calculate Y coordinate for starting point
30 L X+Q21 Y+Q22 R0 FMAX M3	Move to starting point in the plane
31 L Z+Q12 R0 FMAX	Pre-position in spindle axis to set-up clearance
32 L Z-Q9 R0 FQ10	Move to working depth
33 LBL1	
34 Q36 = Q36 +Q35	Update the angle
35 Q37 = Q37 +1	Update the counter
36 Q21 = Q3 *COS Q36	Calculate the current X coordinate
37 Q22 = Q4 *SIN Q36	Calculate the current Y coordinate
38 L X+Q21 Y+Q22 R0 FQ11	Move to next point
39 FN 12: IF +Q37 LT +Q7 GOTO LBL 1	Unfinished? If not finished, return to LBL 1
40 CYCL DEF 10.0 ROTATION	Reset the rotation
41 CYCL DEF 10.1 ROT+0	
42 CYCL DEF 7.0 DATUM SHIFT	Reset the datum shift
43 CYCL DEF 7.1 X+0	
44 CYCL DEF 7.2 Y+0	
45 L Z+Q12 R0 FMAX	Move to set-up clearance
46 LBL 0	End of subprogram
47 END PGM ELLIPSE MM	

### Example: Concave cylinder machined with spherical cutter

#### Program run

- This program functions only with a spherical cutter.  
The tool length refers to the sphere center.
- The contour of the cylinder is approximated by many short line segments (defined in Q13). The more line segments you define, the smoother the curve becomes.
- The cylinder is milled in longitudinal cuts (here: parallel to the Y axis).
- The milling direction is determined with the starting angle and end angle in space:  
Machining direction clockwise:  
Starting angle > end angle  
Machining direction counterclockwise:  
Starting angle < end angle
- The tool radius is compensated automatically



<b>0 BEGIN PGM CYLIN MM</b>	
<b>1 FN 0: Q1 = +50</b>	Center in X axis
<b>2 FN 0: Q2 = +0</b>	Center in Y axis
<b>3 FN 0: Q3 = +0</b>	Center in Z axis
<b>4 FN 0: Q4 = +90</b>	Starting angle in space (Z/X plane)
<b>5 FN 0: Q5 = +270</b>	End angle in space (Z/X plane)
<b>6 FN 0: Q6 = +40</b>	Cylinder radius
<b>7 FN 0: Q7 = +100</b>	Length of the cylinder
<b>8 FN 0: Q8 = +0</b>	Rotational position in the X/Y plane
<b>9 FN 0: Q10 = +5</b>	Allowance for cylinder radius
<b>10 FN 0: Q11 = +250</b>	Feed rate for plunging
<b>11 FN 0: Q12 = +400</b>	Feed rate for milling
<b>12 FN 0: Q13 = +90</b>	Number of cuts
<b>13 BLK FORM 0.1 Z X+0 Y+0 Z-50</b>	Definition of workpiece blank
<b>14 BLK FORM 0.2 X+100 Y+100 Z+0</b>	
<b>15 TOOL CALL 1 Z S4000</b>	Tool call
<b>16 L Z+250 R0 FMAX</b>	Retract the tool
<b>17 CALL LBL 10</b>	Call machining operation
<b>18 FN 0: Q10 = +0</b>	Reset allowance
<b>19 CALL LBL 10</b>	Call machining operation
<b>20 L Z+100 R0 FMAX M2</b>	Retract the tool, end program

## Programming Q parameters


### 9.13 Programming examples

21 LBL 10	Subprogram 10: Machining operation
22 Q16 = Q6 -Q10 - Q108	Account for allowance and tool, based on the cylinder radius
23 FN 0: Q20 = +1	Set counter
24 FN 0: Q24 = +Q4	Copy starting angle in space (Z/X plane)
25 Q25 = (Q5 -Q4) / Q13	Calculate angle increment
26 CYCL DEF 7.0 DATUM SHIFT	Shift datum to center of cylinder (X axis)
27 CYCL DEF 7.1 X+Q1	
28 CYCL DEF 7.2 Y+Q2	
29 CYCL DEF 7.3 Z+Q3	
30 CYCL DEF 10.0 ROTATION	Account for rotational position in the plane
31 CYCL DEF 10.1 ROT+Q8	
32 L X+0 Y+0 R0 FMAX	Pre-position in the plane to the cylinder center
33 L Z+5 R0 F1000 M3	Pre-position in the spindle axis
34 LBL 1	
35 CC Z+0 X+0	Set pole in the Z/X plane
36 LP PR+Q16 PA+Q24 FQ11	Move to starting position on cylinder, plunge-cutting obliquely into the material
37 L Y+Q7 R0 FQ12	Longitudinal cut in Y+ direction
38 FN 1: Q20 = +Q20 + +1	Update the counter
39 FN 1: Q24 = +Q24 + +Q25	Update solid angle
40 FN 11: IF +Q20 GT +Q13 GOTO LBL 99	Finished? If finished, jump to end
41 LP PR+Q16 PA+Q24 FQ11	Move in an approximated "arc" for the next longitudinal cut
42 L Y+0 R0 FQ12	Longitudinal cut in Y– direction
43 FN 1: Q20 = +Q20 + +1	Update the counter
44 FN 1: Q24 = +Q24 + +Q25	Update solid angle
45 FN 12: IF +Q20 LT +Q13 GOTO LBL 1	Unfinished? If not finished, return to LBL 1
46 LBL 99	
47 CYCL DEF 10.0 ROTATION	Reset the rotation
48 CYCL DEF 10.1 ROT+0	
49 CYCL DEF 7.0 DATUM SHIFT	Reset the datum shift
50 CYCL DEF 7.1 X+0	
51 CYCL DEF 7.2 Y+0	
52 CYCL DEF 7.3 Z+0	
53 LBL 0	End of subprogram
54 END PGM CYLIN	

### Example: Convex sphere machined with end mill

Program run

- This program requires an end mill.
- The contour of the sphere is approximated by many short lines (in the Z/X plane, defined in Q14). The smaller you define the angle increment, the smoother the curve becomes.
- You can determine the number of contour cuts through the angle increment in the plane (defined in Q18).
- The tool moves upward in three-dimensional cuts.
- The tool radius is compensated automatically



<b>0 BEGIN PGM SPHERE MM</b>	
<b>1 FN 0: Q1 = +50</b>	Center in X axis
<b>2 FN 0: Q2 = +50</b>	Center in Y axis
<b>3 FN 0: Q4 = +90</b>	Starting angle in space (Z/X plane)
<b>4 FN 0: Q5 = +0</b>	End angle in space (Z/X plane)
<b>5 FN 0: Q14 = +5</b>	Angle increment in space
<b>6 FN 0: Q6 = +45</b>	Sphere radius
<b>7 FN 0: Q8 = +0</b>	Starting angle of rotational position in the X/Y plane
<b>8 FN 0: Q9 = +360</b>	End angle of rotational position in the X/Y plane
<b>9 FN 0: Q18 = +10</b>	Angle increment in the X/Y plane for roughing
<b>10 FN 0: Q10 = +5</b>	Allowance in sphere radius for roughing
<b>11 FN 0: Q11 = +2</b>	Set-up clearance for pre-positioning in the spindle axis
<b>12 FN 0: Q12 = +350</b>	Feed rate for milling
<b>13 BLK FORM 0.1 Z X+0 Y+0 Z-50</b>	Workpiece blank definition
<b>14 BLK FORM 0.2 X+100 Y+100 Z+0</b>	
<b>15 TOOL CALL 1 Z S4000</b>	Tool call
<b>16 L Z+250 R0 FMAX</b>	Retract the tool
<b>17 CALL LBL 10</b>	Call machining operation
<b>18 FN 0: Q10 = +0</b>	Reset allowance
<b>19 FN 0: Q18 = +5</b>	Angle increment in the X/Y plane for finishing
<b>20 CALL LBL 10</b>	Call machining operation
<b>21 L Z+100 R0 FMAX M2</b>	Retract the tool, end program
<b>22 LBL 10</b>	Subprogram 10: Machining operation
<b>23 FN 1: Q23 = +Q11 + +Q6</b>	Calculate Z coordinate for pre-positioning
<b>24 FN 0: Q24 = +Q4</b>	Copy starting angle in space (Z/X plane)
<b>25 FN 1: Q26 = +Q6 + +Q108</b>	Compensate sphere radius for pre-positioning
<b>26 FN 0: Q28 = +Q8</b>	Copy rotational position in the plane
<b>27 FN 1: Q16 = +Q6 + -Q10</b>	Account for allowance in the sphere radius
<b>28 CYCL DEF 7.0 DATUM SHIFT</b>	Shift datum to center of sphere
<b>29 CYCL DEF 7.1 X+Q1</b>	
<b>30 CYCL DEF 7.2 Y+Q2</b>	
<b>31 CYCL DEF 7.3 Z-Q16</b>	

## Programming Q parameters

### 9.13 Programming examples

32 CYCL DEF 10.0 ROTATION	Account for starting angle of rotational position in the plane
33 CYCL DEF 10.1 ROT+Q8	
34 LBL 1	Pre-position in the spindle axis
35 CC X+0 Y+0	Set pole in the X/Y plane for pre-positioning
36 LP PR+Q26 PA+Q8 R0 FQ12	Pre-position in the plane
37 CC Z+0 X+Q108	Set pole in the Z/X plane, offset by the tool radius
38 L Y+0 Z+0 FQ12	Move to working depth
39 LBL 2	
40 LP PR+Q6 PA+Q24 FQ12	Move upward in an approximated "arc"
41 FN 2: Q24 = +Q24 - +Q14	Update solid angle
42 FN 11: IF +Q24 GT +Q5 GOTO LBL 2	Inquire whether an arc is finished. If not finished, return to LBL 2
43 LP PR+Q6 PA+Q5	Move to the end angle in space
44 L Z+Q23 R0 F1000	Retract in the spindle axis
45 L X+Q26 R0 FMAX	Pre-position for next arc
46 FN 1: Q28 = +Q28 + +Q18	Update rotational position in the plane
47 FN 0: Q24 = +Q4	Reset solid angle
48 CYCL DEF 10.0 ROTATION	Activate new rotational position
49 CYCL DEF 10.0 ROT+Q28	
50 FN 12: IF +Q28 LT +Q9 GOTO LBL 1	
51 FN 9: IF +Q28 EQU +Q9 GOTO LBL 1	Unfinished? If not finished, return to LBL 1
52 CYCL DEF 10.0 ROTATION	Reset the rotation
53 CYCL DEF 10.1 ROT+0	
54 CYCL DEF 7.0 DATUM SHIFT	Reset the datum shift
55 CYCL DEF 7.1 X+0	
56 CYCL DEF 7.2 Y+0	
57 CYCL DEF 7.3 Z+0	
58 LBL 0	End of subprogram
59 END PGM SPHERE MM	

# 10

**Miscellaneous  
functions**

## Miscellaneous functions

### 10.1 Enter miscellaneous functions M and STOP

#### 10.1 Enter miscellaneous functions M and STOP

##### Fundamentals

With the TNC's miscellaneous functions—also called M functions—you can affect

- the program run, e.g. a program interruption
- the machine functions, such as switching spindle rotation and coolant supply on and off
- the path behavior of the tool

You can enter up to four M (miscellaneous) functions at the end of a positioning block or in a separate block. The TNC displays the following dialog question: **Miscellaneous function M?**

You usually enter only the number of the miscellaneous function in the programming dialog. Some miscellaneous functions can be programmed with additional parameters. In this case, the dialog is continued for the parameter input.

In the **Manual operation** and **Electronic handwheel** operating modes, the M functions are entered with the **M** soft key.



### Effectiveness of miscellaneous functions

Please note that some M functions become effective at the start of a positioning block, and others at the end, regardless of their position in the NC block.

M functions come into effect in the block in which they are called. Some M functions are effective only in the block in which they are programmed. Unless the miscellaneous function is only effective blockwise, either you must cancel it in a subsequent block with a separate M function, or it is automatically canceled by the TNC at the end of the program.



If several M functions are programmed in one NC block, then the execution sequence is as follows:

- M functions taking effect at the start of the block are executed before those taking effect at the end of the block
- If all M functions take effect at the start or end of block, execution take place in the sequence programmed

### Entering a miscellaneous function in a STOP block

If you program a **STOP** block, the program run or test run is interrupted at the block, e.g. for a tool inspection. You can also enter an M (miscellaneous) function in a **STOP** block:

STOP

- ▶ To program an interruption of program run, press the **STOP** key
- ▶ Enter a miscellaneous function **M**

### Example NC blocks

87 STOP M6

## Miscellaneous functions

### 10.2 Miscellaneous functions for program run inspection, spindle and coolant

### 10.2 Miscellaneous functions for program run inspection, spindle and coolant

#### Overview



The machine tool builder can influence the behavior of the miscellaneous functions described below. Refer to your machine manual.


M	Effect	Effective at block	Start	End
<b>M0</b>	Program STOP Spindle STOP			■
<b>M1</b>	Optional program STOP Spindle STOP if necessary Coolant OFF if necessary (function defined by the machine tool builder)			■
<b>M2</b>	STOP program run Spindle STOP Coolant off Return jump to block 1 Clear status display Functional scope depends on machine parameter <b>clearMode</b> (no. 100901)			■
<b>M3</b>	Spindle ON clockwise	■		
<b>M4</b>	Spindle ON counterclockwise	■		
<b>M5</b>	Spindle STOP			■
<b>M6</b>	Tool change Spindle STOP Program STOP			■
<b>M8</b>	Coolant ON	■		
<b>M9</b>	Coolant OFF			■
<b>M13</b>	Spindle ON clockwise Coolant ON	■		
<b>M14</b>	Spindle ON counterclockwise Coolant ON	■		
<b>M30</b>	Same as M2			■

## 10.3 Miscellaneous functions for coordinate entries

### Programming machine-referenced coordinates: M91/M92

#### Scale datum

On the scale, a reference mark indicates the position of the scale datum.



#### Machine datum

The machine datum is required for the following tasks:

- Define the axis traverse limits (software limit switches)
- Approach machine-referenced positions (e.g. tool change positions)
- Set a workpiece datum

The distance in each axis from the scale datum to the machine datum is defined by the machine manufacturer in a machine parameter.

#### Standard behavior

The TNC references coordinates to the workpiece datum.

**Further Information:** "Datum setting without a 3-D touch probe", page 607

#### Behavior with M91 – Machine datum

If you want the coordinates in a positioning block to be referenced to the machine datum, end the block with M91.



If you program incremental coordinates in an M91 block, enter them with respect to the last programmed M91 position. If no M91 position is programmed in the active NC block, then enter the coordinates with respect to the current tool position.

The coordinate values on the TNC screen are referenced to the machine datum. Switch the display of coordinates in the status display to REF.

**Further Information:** "Status displays", page 90

## Miscellaneous functions

### 10.3 Miscellaneous functions for coordinate entries

#### Behavior with M92 – Additional machine datum



In addition to the machine datum, the machine tool builder can also define an additional machine-based position as a reference point.

For each axis, the machine tool builder defines the distance between the machine datum and this additional machine datum. Refer to your machine manual.

If you want the coordinates in positioning blocks to be based on the additional machine datum, end these block with M92.



Radius compensation remains the same in blocks that are programmed with M91 or M92. The tool length is **not** included.

#### Effect

M91 and M92 are effective only in the blocks in which M91 and M92 have been programmed.


M91 and M92 take effect at the start of block.

#### Workpiece datum

If you want the coordinates to always be referenced to the machine datum, you can block datum setting for one or more axes.

If datum setting is inhibited for all axes, the TNC no longer displays the **DATUM SET** in the **Manual operation** mode.

The figure shows coordinate systems with the machine and workpiece datum.



#### M91/M92 in the Test Run mode

In order to be able to graphically simulate M91/M92 movements, you need to activate working space monitoring and display the workpiece blank referenced to the set datum.

**Further Information:** "Show the workpiece blank in the working space ", page 671

## Moving to positions in a non-tilted coordinate system with a tilted working plane: M130

### Standard behavior with a tilted working plane

The TNC references coordinates in the positioning blocks to the tilted working plane coordinate system.

### Behavior with M130

The TNC references coordinates in straight line blocks with an active tilted working plane to the untilted workpiece coordinate system.

The TNC then positions the tilted tool to the programmed coordinates of the untilted workpiece coordinate system.



#### **Danger of collision!**

Subsequent positioning blocks or fixed cycles are carried out in a tilted coordinate system. This can lead to problems in fixed cycles with absolute prepositioning.

The function M130 is allowed only if the tilted working plane function is active.

### Effect

M130 functions blockwise in straight-line blocks without tool radius compensation.

## Miscellaneous functions


### 10.4 Miscellaneous functions for path behavior

#### 10.4 Miscellaneous functions for path behavior

##### Machining small contour steps: M97

###### Standard behavior

The TNC inserts a transition arc at outside corners. If the contour steps are very small, however, the tool would damage the contour. In such cases the TNC interrupts program run and generates the error message "Tool radius too large."




###### Behavior with M97

The TNC calculates the intersection of the contour elements—as at inside corners—and moves the tool over this point.

Program M97 in the same block as the outside corner.



Instead of **M97** you should use the much more powerful function **M120 LA**. **Further Information:** "Calculating the radius-compensated path in advance (LOOK AHEAD): M120 ", page 417



###### Effect

M97 is effective only in the blocks in which it is programmed.



A corner machined with M97 will not be completely finished. You may wish to rework the contour with a smaller tool.


##### Example NC blocks

5 TOOL DEF L ... R+20	Large tool radius
...	
13 L X... Y... R... F... M97	Move to contour point 13
14 L IY-0.5 ... R... F...	Machine small contour step 13 to 14
15 L IX+100 ...	Move to contour point 15
16 L IY+0.5 ... R... F... M97	Machine small contour step 15 to 16
17 L X... Y...	Move to contour point 17

## Machining open contour corners: M98


### Standard behavior

The TNC calculates the intersections of the cutter paths at inside corners and moves the tool in the new direction at those points. If the contour is open at the corners, however, this will result in incomplete machining.



### Behavior with M98

With the miscellaneous function M98, the TNC temporarily suspends radius compensation to ensure that both corners are completely machined:



### Effect

M98 is effective only in the blocks in which it is programmed. M98 takes effect at the end of block.

### Example NC blocks

Move to the contour points 10, 11 and 12 in succession:

```
10 L X... Y... RL F
```

```
11 L X... Y... M98
```

```
12 L IX+ ...
```

## Miscellaneous functions

### 10.4 Miscellaneous functions for path behavior

#### Feed rate factor for plunging movements: M103

##### Standard behavior

The TNC moves the tool at the last programmed feed rate, regardless of the direction of traverse.

##### Behavior with M103

The TNC reduces the feed rate when the tool moves in the negative direction of the tool axis. The feed rate for plunging FZMAX is calculated from the last programmed feed rate FPROG and a factor F%:

$$FZMAX = FPROG \times F\%$$

##### Programming M103

If you enter M103 in a positioning block, the TNC continues the dialog by asking you the factor F.

##### Effect

M103 becomes effective at the start of block.

To cancel M103, program M103 once again without a factor.



M103 is also effective with an active tilted working plane. The feed rate reduction is then effective during traverse in the negative direction of the **tilted** tool axis.

#### Example NC blocks

The feed rate for plunging is to be 20% of the feed rate in the plane.

...	Actual contouring feed rate (mm/min):
17 L X+20 Y+20 RL F500 M103 F20	500
18 L Y+50	500
19 L IZ-2.5	100
20 L IY+5 IZ-5	141
21 L IX+50	500
22 L Z+5	500



## Feed rate in millimeters per spindle revolution: M136

### Standard behavior

The TNC moves the tool at the programmed feed rate F in mm/min

### Behavior with M136



In inch-programs, M136 is not permitted in combination with the new alternate feed rate FU. The spindle is not permitted to be controlled when M136 is active.

With M136, the TNC does not move the tool in mm/min, but rather at the programmed feed rate F in millimeters per spindle revolution. If you change the spindle speed by using the spindle override, the TNC changes the feed rate accordingly.

### Effect

M136 becomes effective at the start of block.

You can cancel M136 by programming M137.

## Miscellaneous functions

### 10.4 Miscellaneous functions for path behavior

#### Feed rate for circular arcs: M109/M110/M111

##### Standard behavior

The TNC applies the programmed feed rate to the path of the tool center.

##### Behavior at circular arcs with M109

The TNC adjusts the feed rate for circular arcs at inside and outside contours so that the feed rate at the tool cutting edge remains constant.



##### **Caution: Danger to the workpiece and tool!**

On very small outside corners the TNC may increase the feed rate so much that the tool or workpiece may be damaged. Avoid **M109** with small outside corners.

##### Behavior at circular arcs with M110

The TNC keeps the feed rate constant for circular arcs at inside contours only. Adjustment of the feed rate does not have any effect when machining the outside contours of circular arcs.



If you define M109 or M110 before calling a machining cycle with a number greater than 200, the adjusted feed rate is also effective for circular arcs within these machining cycles. The initial state is restored after finishing or canceling a machining cycle.

##### Effect

M109 and M110 become effective at the start of block. To cancel M109 or M110, enter M111.

## Calculating the radius-compensated path in advance (LOOK AHEAD): M120

### Standard behavior

If the tool radius is larger than the contour step that is to be machined with radius compensation, the TNC interrupts program run and generates an error message. M97" suppresses the error message, but it results in dwell marks and will also move the corner.

**Further Information:** "Machining small contour steps: M97", page 412


If the programmed contour contains undercut features, the tool may damage the contour.

### Behavior with M120

The TNC checks radius-compensated contours for undercuts and tool path intersections, and calculates the tool path in advance from the current block. Areas of the contour that might be damaged by the tool are not machined (dark areas in figure). You can also use M120 to calculate the tool radius compensation for digitized data or data created on an external programming system. This means that deviations from the theoretical tool radius can be compensated.

Use LA (**L**ook **A**head) behind M120 to define the number of blocks (maximum: 99) that you want the TNC to calculate in advance.

Note that the larger the number of blocks you choose, the higher the block processing time will be.



### Input

If you enter M120 in a positioning block, the TNC continues the dialog for this block by asking you the number of blocks LA that are to be calculated in advance.

### Effect

M120 must be located in an NC block that also contains radius compensation **RL** or **RR**. M120 is then effective from this block until

- radius compensation is canceled with **R0**
- M120 LA0 is programmed, or
- M120 is programmed without LA, or
- another program is called with **PGM CALL**
- the working plane is tilted with Cycle **19** or the PLANE function

M120 becomes effective at the start of the block.

## Miscellaneous functions

### 10.4 Miscellaneous functions for path behavior

#### Restrictions

- After an external or internal stop, you can only re-enter the contour with the function **RESTORE POS. AT N**. Before you start the block scan, you must cancel M120, otherwise the TNC will output an error message.
- If you want to approach the contour on a tangential path, you must use the function **APPR LCT**. The block with **APPR LCT** must contain only the coordinates of the working plane.
- If you want to depart the contour on a tangential path, you must use the function **DEP LCT**. The block with **DEP LCT** must contain only the coordinates of the working plane.
- Before using the functions listed below, you have to cancel M120 and the radius compensation:
  - Cycle **32** Tolerance
  - Cycle **19** Working plane
  - PLANE function
  - M114
  - M128
  - TCPM FUNCTION

## Superimpose handwheel positioning during program run: M118

### Standard behavior

In the program run modes, the TNC moves the tool as defined in the part program.

### Behavior with M118

M118 permits manual corrections by handwheel during program run. Just program M118 and enter an axis-specific value (linear or rotary axis) in millimeters.



The handwheel superimposing function with **M118** in combination with dynamic collision monitoring is only possible at a standstill.

**M118** is not possible in combination with dynamic collision monitoring and also functions **TCPM** or **M128**.

To be able to use M118 without restrictions, you have to deselect DCM either with a soft key in the menu, or activate a kinematics model without collision monitored objects (CMOs).



### Danger of collision!

If you modify the position of a rotary axis with the handwheel superimposition **M118** function and then run **M140**, the TNC ignores the superimposed values with the retraction movement.

This may cause undesired motion or collisions on machines with rotary axes in the head.

### Input

If you enter M118 in a positioning block, the TNC continues the dialog for this block by asking you the axis-specific values. The coordinates are entered with the orange axis direction buttons or the ASCII keyboard.

### Effect

Cancel handwheel positioning by programming M118 once again without coordinate input.

M118 becomes effective at the start of the block.

## Miscellaneous functions

### 10.4 Miscellaneous functions for path behavior

#### Example NC blocks

You want to be able to use the handwheel during program run to move the tool in the working plane X/Y by  $\pm 1$  mm and in the rotary axis B by  $\pm 5^\circ$  from the programmed value:

```
L X+0 Y+38.5 RL F125 M118 X1 Y1 B5
```



M118 is effective in a tilted coordinate system if you activate the tilted working plane function for the Manual Operation mode. If the tilted working plane function is not active for the Manual Operation mode, the untilted workpiece coordinate system is effective.

M118 is also effective in **Positioning with manl.data input** operating mode!

#### Virtual tool axis VT



Your machine tool builder must have prepared the TNC for this function. Refer to your machine manual.

With the virtual tool axis you can also traverse in the direction of a sloping tool with the handwheel on a machine with swivel heads. To traverse in a virtual tool axis direction, select the VT axis on the display of your handwheel.

**Further Information:** "Traverse with electronic handwheels", page 583

With an HR 5xx handwheel you can select the virtual axis directly with the orange VI axis key if required (refer to your machine manual).

You can also carry out handwheel superimposing in the currently active tool axis direction with the M118 function. For this purpose, you must at least define the spindle axis with the permitted traverse range (e.g. M118 Z5) in the M118 function and select the VT axis on the handwheel.

## Retraction from the contour in the tool-axis direction: M140

### Standard behavior

In the **Program run single block** and **Program run full sequence** modes, the TNC moves the tool as defined in the machining program.

### Behavior with M140

With M140 MB (move back) you can enter a path in the direction of the tool axis for departure from the contour.



#### **Danger of collision!**

In conjunction with dynamic collision monitoring **DCM** the machine manufacturer defines whether TNC might move the tool only until it detects a collision and, from there, complete the NC program without any error message. **This process takes place no matter whether collision monitoring is active or inactive.** This may cause movements that were not programmed as such!

Refer to your machine manual.

### Input

If you enter M140 in a positioning block, the TNC continues the dialog and asks for the desired path of tool departure from the contour. Enter the requested path that the tool should follow when departing the contour, or press the MB MAX soft key to move to the limit of the traverse range.

In addition, you can program the feed rate at which the tool traverses the entered path. If you do not enter a feed rate, the TNC moves the tool along the entered path at rapid traverse.

### Effect

M140 is effective only in the NC block in which M140 is programmed.

M140 becomes effective at the start of the block.

## Miscellaneous functions

### 10.4 Miscellaneous functions for path behavior

#### Example NC blocks

Block 250: Retract the tool 50 mm from the contour.

Block 251: Move the tool to the limit of the traverse range.

```
250 L X+0 Y+38.5 F125 M140 MB 50 F750
```

```
251 L X+0 Y+38.5 F125 M140 MB MAX
```



M140 is also effective if the tilted-working-plane function is active. For machines with swivel heads the TNC then moves the tool in the tilted system.

With **M140 MB MAX** you can only retract in the positive direction.

Always define a tool call with tool axis before **M140**, otherwise the traverse direction is not defined.



#### **Danger of collision!**

If you modify the position of a rotary axis with the handwheel superimposition **M118** function and then run **M140**, the TNC ignores the superimposed values with the retraction movement.

This may cause undesired motion or collisions on machines with rotary axes in the head.



## Suppressing touch probe monitoring: M141

### Standard behavior

When the stylus is deflected, the TNC outputs an error message as soon as you attempt to move a machine axis.

### Behavior with M141

The TNC moves the machine axes even if the touch probe is deflected. This function is required if you wish to write your own measuring cycle in connection with measuring cycle 3 in order to retract the stylus by means of a positioning block after it has been deflected.



#### **Danger of collision!**

If you use M141, make sure that you retract the touch probe in the correct direction.

M141 functions only for movements with straight-line blocks.

### Effect

M141 is effective only in the block in which it is programmed.

M141 becomes effective at the start of block.

## Miscellaneous functions

### 10.4 Miscellaneous functions for path behavior

#### Deleting basic rotation: M143

##### Standard behavior

The basic rotation remains in effect until it is reset or is overwritten with a new value.

##### Behavior with M143

The TNC erases a programmed basic rotation from the NC program.



The function **M143** is not permitted with mid-program startup.

##### Effect

M143 is effective only from the NC block in which M143 is programmed.

M143 becomes effective at the start of the block.



M143 deletes the entries in columns SPA, SPB and SPC in the preset table; re-activating the corresponding preset lines does not activate the deleted basic rotation.

## Automatically retract tool from the contour at an NC stop: M148

### Standard behavior

At an NC stop the TNC stops all traverse movements. The tool stops moving at the point of interruption.

### Behavior with M148



The M148 function must be enabled by the machine tool builder. The machine tool builder defines in a machine parameter the path that the TNC is to traverse for a **LIFTOFF** command.

Set the parameter **Y** in the **LIFTOFF** column of the tool table for the active tool. The TNC then retracts the tool from the contour by up to 2 mm in the direction of the tool axis.

**Further Information:** "Enter tool data into the table", page 206

**LIFTOFF** takes effect in the following situations:

- An NC stop triggered by you
- An NC stop triggered by the software, e.g. if an error occurred in the drive system
- When a power interruption occurs



### Danger of collision!

Remember that, especially on curved surfaces, the surface can be damaged during return to the contour. Retract the tool before returning to the contour!

In the **CfgLiftOff** (no. 201400) machine parameter, define the value by which the tool is to be retracted.

In the **CfgLiftOff** (no. 201400) machine parameter you can also switch the function off.

### Effect

M148 remains in effect until deactivated with M149.

M148 becomes effective at the start of the block, M149 at the end of the block.

## Miscellaneous functions

### 10.4 Miscellaneous functions for path behavior

#### Rounding corners: M197

##### Standard behavior

The TNC inserts a transition arc at outside corners with active radius compensation. This may lead to grinding of the edge.

##### Behavior with M197

With Function M197 the contour at the corner is tangentially extended and a smaller transition arc is then inserted. When you program Function M197 and then press the ENT key, the TNC opens the **DL** input field. In **DL** you define the length with which the TNC extends the contour elements. With M197 the corner radius is reduced, the corner grinds less and the traverse movement is still tangential.

##### Effect

The Function M197 is effective blockwise and is only effective on outside corners.

##### Example NC blocks

```
L X... Y... RL M197 DL0.876
```

# 11

**Special functions**

## Special functions

### 11.1 Overview of special functions


#### 11.1 Overview of special functions







The TNC provides the following powerful special functions for a large number of applications:

Function	Description
Dynamic Collision Monitoring with integrated fixture management (Option #40)	page 431
Adaptive Feed Control AFC (Option #45)	page 442
Active Chatter Control (Option #145)	page 455
Working with text files	page 467
Working with freely definable tables	page 471

Press the **SPEC FCT** and the corresponding soft keys to access further special functions of the TNC. The following tables give you an overview of which functions are available.

#### Main menu for SPEC FCT special functions

 ► Press the SPEC FCT key to select the special functions

Soft key	Function	Description
	Define program defaults	page 429
	Functions for contour and point machining	page 429
	Define the <b>PLANE</b> function	page 487
	Define different conversational functions	page 430
	Define turning functions	page 547
	Programming aids	page 173




After pressing the **SPEC FCT** key, you can open the **smartSelect** selection window with the **GOTO** key. The TNC displays a structure overview with all available functions. You can rapidly navigate with the cursor or mouse and select functions in the tree diagram. The TNC displays online help for the specific functions in the window on the right.

## Program defaults menu

PROGRAM  
DEFAULTS

- Press the Program Defaults soft key

Soft key	Function	Description
BLK FORM	Define workpiece blank	page 133
DATUM TABLE	Select datum table	See Cycle- Programming User's Manual
GLOBAL DEF	Define global cycle parameters	See Cycle- Programming User's Manual




## Functions for contour and point machining menu

CONTOUR  
+ POINT  
MACHINING

- Press the soft key for functions for contour and point machining

Soft key	Function	Description
DECLARE CONTOUR	Assign contour description	See Cycle- Programming User's Manual
CONTOUR DEF	Define a simple contour formula	See Cycle- Programming User's Manual
SEL CONTOUR	Select a contour definition	See Cycle- Programming User's Manual
CONTOUR FORMULA	Define a complex contour formula	See Cycle- Programming User's Manual
PATTERN DEF	Define regular machining pattern	See Cycle- Programming User's Manual
SEL PATTERN	Select the point file with machining positions	See Cycle- Programming User's Manual



## Special functions


### 11.1 Overview of special functions

#### Menu of various conversational functions

PROGRAM  
FUNCTIONS

- Press the soft key for defining various conversational functions

Soft key	Function	Description
FUNCTION TCPM	Define the positioning behavior for rotary axes	page 519
FUNCTION FILE	Define file functions	page 463
FUNCTION PARAX	Define the positioning behavior for parallel axes U, V, W	page 457
FUNCTION AFC	Define Adaptive Feed Control	page 442
TRANSFORM	Define coordinate transformations	page 464
STRING FUNCTIONS	Define string functions	page 382
FUNCTION SPINDLE	Define pulsing spindle speed	page 477
FUNCTION FEED	Define dwell time	page 479
FUNCTION DCM	Define Dynamic Collision Monitoring DCM	page 431
INSERT COMMENT	Add comments	page 174





## 11.2 Dynamic Collision Monitoring (option 40)

### Function



Dynamic collision monitoring **DCM** must be adapted by the machine manufacturer for the control and for the machine. Refer to your machine manual.

The machine manufacturer can define any objects that are monitored by the TNC during all machining operations. If two objects monitored for collision come within a defined distance of each other, the TNC outputs an error message and terminates the movement.


The TNC can display the defined collision objects graphically in all machine operating modes.

**Further Information:** "Graphic display of the collision objects", page 432

The TNC also monitors the active tool for collision and graphically displays it accordingly. The TNC always assumes cylindrical tools. The TNC likewise monitors stepped tools according to the definition in the tool table.

The control takes into account the following definitions from the tool table:

- Tool lengths
- Tool radii
- Tool dimensions
- Tool carrier kinematics



## Special functions

### 11.2 Dynamic Collision Monitoring (option 40)



#### Generally valid constraints:

- DCM helps to reduce the danger of collision. However, the TNC cannot consider all possible constellations in operation.
- Collisions between machine components and the tool and between the tool and the workpiece are not detected by the TNC.
- DCM can only protect those machine components from collision that your machine tool builder has correctly defined with regard to dimensions, orientation and position.
- The TNC can only monitor tools for which you have defined **positive tool radii** and **positive tool lengths** in the tool table.
- When a touch probe cycle starts, the TNC no longer monitors the stylus length and ball tip diameter so that you can also probe collision objects.
- For certain tools (such as face milling cutters), the radius that would cause a collision can be greater than the value defined in the tool table.
- The tool oversizes **DL** and **DR** from the tool table are taken into account by the TNC. Tool oversizes from the **TOOL CALL** block are not accounted for.

#### Graphic display of the collision objects

Activate the graphic display of the collision objects as follows:

- Select any machine operating mode
  - Press the screen switchover key




POSITION  
+  
KINEMATICS

PROGRAM  
+  
KINEMATICS

KINEMATICS

- Select the desired screen layout

You can also use the soft keys to change the display of the collision objects.







Modify the graphic display of the collision objects as follows:

- Shift the soft-key row if necessary



- Press the **KINEMATICS** soft key
- Modify the graphic display of the collision objects using the following functions

The following functions are available:

Soft key	Function
	Switch between wire-frame and solid-object view
	Switch between shadowed and transparent view
	Display/hide the coordinate systems that result from transformations in the kinematics description
	Functions for rotating, zooming and shifting

You can also use the mouse to change the display of the collision objects.

The following functions are available:

- In order to rotate the model shown in three dimensions you hold the right mouse button down and move the mouse. If you simultaneously press the shift key, you can only rotate the model horizontally or vertically.
- To shift the model shown: Hold the center mouse button or the wheel button down and move the mouse. If you simultaneously press the shift key, you can only shift the model horizontally or vertically.
- To zoom in on a certain area: Mark a zoom area by holding the left mouse button down. After you release the left mouse button, the TNC zooms in on the defined area.
- To rapidly magnify or reduce any area: Rotate the mouse wheel backwards or forwards.
- To return to the standard display: Press the shift key and simultaneously double-click with the right mouse key. The rotation angle is maintained if you only double-click with the right mouse key.

## Special functions

### 11.2 Dynamic Collision Monitoring (option 40)

#### Collision monitoring in the manual operating modes

In the **Manual operation** and **Electronic handwheel** operating modes, the TNC stops a motion if two objects monitored for collision approach each other within a distance of less than 2 mm. In this case, the TNC displays an error message naming the two objects causing collision.

Before the collision warning, the TNC dynamically reduces the feed of the movements to ensure that the axes stop in good time before a collision.

If you have selected a screen layout in which the collision objects are on the right, then the TNC additionally marks the colliding objects in red.



Once a collision warning is displayed, machine motions via the direction keys or handwheel are possible only if the motion increases the distance between the collision objects.

Motions that reduce the distance or leave it unchanged are not allowed as long as collision monitoring is active.

**Further Information:** "Activating and deactivating collision monitoring", page 436



Note the generally valid constraints.

**Further Information:** "Function", page 431

## Collision monitoring in the Program Run operating modes

In the **Positioning with manl.data input**, **Program run single block** and **Program run, full sequence** operating modes, the TNC stops the program run before an NC block in which two objects monitored for collision would approach each other within a distance of less than 5 mm is processed. In this case, the TNC displays an error message naming the two objects causing collision.

If you have selected a screen layout in which the collision objects are on the right, then the TNC additionally marks the colliding objects in red.



### Danger of collision!

Regarding the function **M140**, please note:

The machine manufacturer defines for each collision object whether the TNC might move the tool only until it detects a collision and, from there, complete the NC program without any error message. This process takes place no matter whether collision monitoring is active or inactive. This may cause movements that were not programmed as such!

Refer to your machine manual.



### Constraints with program run:

- For tapping with a floating tap holder only the basic setting of the floating tap holder is taken into account with collision monitoring.
- The handwheel superimpositioning function with **M118** in combination with active collision monitoring is only possible in stopped condition.
- Dynamic collision monitoring is not available with the following functions **M118** and also **TCPM** or **M128**.
- The TNC is not able to implement collision monitoring if functions or cycles require the coupling of several axes e.g. with eccentric turning.
- The TNC is not able to implement collision monitoring if at least one axis is referenced in lag tracking or not.

Also note the generally valid restrictions.

**Further Information:** "Function", page 431

## Special functions

### 11.2 Dynamic Collision Monitoring (option 40)

#### Activating and deactivating collision monitoring

In some cases it is necessary to temporarily deactivate collision monitoring:

- To reduce the distance between two objects monitored for collision
- To prevent stops during program runs



#### **Danger of collision!**

If you deactivate collision monitoring, the TNC does not output an error message with a pending collision.

Also, with inactive collision monitoring, the TNC does not prevent movements caused by collision.

#### Permanently manually activating and deactivating collision monitoring



- ▶ Operating mode: Press the **Manual operation** or **Electronic handwheel** key



- ▶ Shift the soft-key row if necessary



- ▶ Press the **COLLISION** soft key



- ▶ Select the operating modes for which the modification should apply:
  - **Program run: Positioning with manl.data input, Program run, single block and Program run, full sequence**
  - **Manual operation: Manual operation and Electronic handwheel**




- ▶ Press the **GO TO** soft key



- ▶ Select the condition for which the selected operating modes should apply:
  - **Inactive:** Deactivate collision monitoring
  - **Active:** Activate collision monitoring



- ▶ Press the **OK** soft key




### Temporarily activating and deactivating collision monitoring via program control

- Open the NC program in **Programming** mode
- Place the cursor at the desired position, e.g. before Cycle 800 to enable eccentric turning




- Press the **SPEC FCT** key




- Press the **PROGRAM FUNCTIONS** soft key




- Shift the soft-key row



- Press the **FUNCTION DCM** soft key.



- Select the condition with the corresponding soft key:



- **DCM OFF FUNCTION:** This NC command temporarily deactivates collision monitoring. The deactivation is effective only until the end of the program or until the next **DCM ON FUNCTION**. When another NC program is called, DCM is active again.
- **DCM ON FUNCTION:** This NC command cancels an existing **DCM OFF FUNCTION**.



The settings applied with the **DCM FUNCTION** are only effective in the active NC program.


After terminating the program run or selecting a new program, the settings made for **Program run** and **Manual operation** with the **COLLISION** soft key become effective again.

**Further Information:** "Permanently manually activating and deactivating collision monitoring", page 436

### Symbols

Symbols in the status display show the condition of collision monitoring:

Icon	Function
	Collision monitoring active
	Collision monitoring is not available
	Collision monitoring is not active



## Special functions

### 11.3 Tool carrier management

### 11.3 Tool carrier management

#### Fundamentals

You can create and manage tool carriers using the tool carrier management. The control factors the tool carriers into the calculations.

On machines with 3 axes, tool carriers for right-angled angled heads help processing on tool axes **X** and **Y**, as the control takes the dimensions of the angle heads into consideration.

Along with software option number 8, **Advanced Function Set 1**, you can tilt the working plane to the angle of the removable angled heads and thus keep working with the **Z** tool axis.

Along with software option number 40, **Dynamic Collision Monitoring**, you can monitor every tool carrier and thus prevent collisions.

You must carry out the following steps so that the control can factor the tool carriers into the calculations:

- Save tool carrier templates
- Assign input parameters to tool carriers
- Allocate parameterized tool carriers

#### Save tool carrier templates

Many tool carriers only differ from others in terms of their dimensions, but their geometric shape is identical. So that you don't have to design all your tool carriers yourself, HEIDENHAIN supplies a range of ready-made tool carrier templates. Tool carrier templates are 3-D models with fixed geometries but changeable dimensions.

The tool carrier templates must be saved in **TNC:\system\Toolkinematics** and have the extension **.cft**.



If the tool carrier templates are not available in your control, please download the data you require from:  
**<http://www.klartext-portal.com/nc-solutions/en>**



If you need further tool carrier templates, please contact your machine manufacturer or third-party vendor.



The tool carrier templates may consist of several sub-files. If the sub-files are incomplete, the control will display an error message.

**Do not use incomplete tool carrier templates!**












## Assign input parameters to tool carriers

Before the control can factor the tool carrier into the calculations, you must give the tool carrier template the actual dimensions. These parameters are entered in the additional **ToolHolderWizard** tool.

Save the parameterized tool carriers with the extension **.cfx** under **TNC:\system\Toolkinematics**.


The additional **ToolHolderWizard** tool is mainly operated with a mouse. Using the mouse, you can also set the desired screen layout by drawing a line between the areas **Parameter**, **Help graphics** and **3-D graphics** by holding down the left mouse button.

The following icons are available in the additional **ToolHolderWizard** tool:

Icon	Function
	Close tool
	Open file
	Switch between wire frame model and solid object view
	Switch between shaded and transparent view
	Display or hide transformation vectors
	Show or hide names of collision objects
	Display or hide test points
	Show or hide measurement points
	Return to starting view of the 3-D model



If the tool carrier template does not contain any transformation vectors, names, test points and measurement points, the additional **ToolHolderWizard** tool does not execute any function when the corresponding icons are activated.



## Special functions

### 11.3 Tool carrier management


Proceed as follows to parameterize tool carrier templates and save these parameters:



- ▶ Operating mode: Press the **MANUAL OPERATION** key



- ▶ Press the **TOOL TABLE** soft key




- ▶ Press the **EDIT** soft key



- ▶ Move the cursor to the **KINEMATIC** column



- ▶ Press the **SELECT** soft key



- ▶ Press the **TOOL HOLDER WIZARD** soft key
- > The control opens the additional **ToolHolderWizard** tool in a pop-up window



- ▶ Press the **OPEN FILE** icon
- > The control opens a pop-up window
- ▶ Select the desired tool carrier template using the preview screen
- ▶ Press the **OK** button
- > The control opens the selected tool carrier template
- > The cursor goes to the first parameterizable value
- ▶ Adjust values
- ▶ Enter the name for the parameterized tool holder in the **Output file** area
- ▶ Press the **GENERATE FILE** button
- ▶ If required, reply to the message on the control
- ▶ Press the **CLOSE** icon
- > The control closes the additional tool



## Allocate parameterized tool carriers

To allow the control to factor a parameterized tool carrier into calculations, you must allocate the tool carrier to a tool and **call the tool again**.



Parameterized tool carriers can consist of several sub-files. If the sub-files are incomplete, the control will display an error message.

**Only use fully parameterized tool carriers!**


Proceed as follows to allocate a parameterized tool carrier to a tool:



- ▶ Operating mode: Press the **MANUAL OPERATION** key



- ▶ Press the **TOOL TABLE** soft key




- ▶ Press the **EDIT** soft key



- ▶ Move the cursor to the **KINEMATIC** column of the required tool



- ▶ Press the **SELECT** soft key
- The control opens a pop-up window with parameterized tool carriers
- ▶ Select the desired tool carrier using the preview screen
- ▶ Press the **OK** soft key
- The control copies the name of the selected tool carrier to the **KINEMATIC** column
- ▶ Exit the tool table



## Special functions

### 11.4 Adaptive Feed Control AFC (option 45)

#### 11.4 Adaptive Feed Control AFC (option 45)

##### Application



Refer to your machine manual.


This feature must be enabled and adapted by the machine tool builder.

Your machine tool builder may also have specified whether the TNC uses the spindle power or any other value as the input value for the feed control.



Adaptive feed control is not intended for tools with diameters less than 5 mm. This limit diameter might also be greater if the spindle's rated power is very high.

Do not work with adaptive feed control in operations in which the feed rate and spindle speed must be adapted to each other, such as tapping.



In adaptive feed control the TNC automatically controls the feed rate during program run as a function of the current spindle power consumption. The spindle power required for each machining step is to be recorded in a teach-in cut and saved by the TNC in a file belonging to the machining program. When each machining step is started, which is normally when the spindle is switched on, the TNC controls the feed rate so that it remains within the limits that you have defined.



If the cutting conditions do not change, you can define a spindle power determined using a teach-in cut as a permanent tool-specific standard reference power. Use the **AFC-LOAD** column in the tool table to do this. If you enter a value manually in this column, the control does not execute any more teach-in cuts.

This makes it possible to avoid negative effects on the tool, the workpiece, and the machine that might be caused by changing cutting conditions. Cutting conditions are changed particularly by:

- Tool wear
- Fluctuating cutting depths that occur especially with cast parts
- Fluctuating hardness caused by material flaws

Adaptive feed control (AFC) offers the following benefits:

- Optimization of machining time

By regulating the feed rate, the TNC attempts to maintain the previously programmed maximum spindle power or the standard reference power indicated in the tool table (**AFC-LOAD** column) for the duration of the entire process. It shortens the machining time by increasing the feed rate in machining zones with little material removal.

- Tool monitoring

If the spindle power exceeds the programmed or prescribed maximum value (**AFC-LOAD** column in the tool table), the TNC decreases the feed rate until the reference spindle power is reattained. If the maximum spindle power is exceeded during machining and at the same time the feed rate falls below the minimum that you defined, the TNC reacts by shutting down. This helps to prevent further damage after a tool breaks or is worn out.

- Protection of the machine's mechanical elements

Timely feed rate reduction and shutdown responses help to avoid machine overload

## Special functions

### 11.4 Adaptive Feed Control AFC (option 45)

#### Defining the AFC basic settings

In the **AFC.TAB** table, which must be saved in the **TNC:\table** directory, you enter the control settings with which the TNC performs the feed rate control.

The data in this table are default values that were copied into a file belonging to the respective machining program during a teach-in cut. The values act as the basis for regulation.



If you define a tool-specific standard reference power using the **AFC-LOAD** column in the tool table, the control generates the associated file for the relevant processing program without a teach-in cut shortly before regulation.

The following data are to be defined in this table:

Column	Function
<b>NR</b>	Consecutive line number in the table (has no further functions)
<b>AFC</b>	Name of the control setting. You enter this name in the <b>AFC</b> column of the tool table. It specifies the assignment of control parameters to the tool.
<b>FMIN</b>	Feed rate at which the TNC is to conduct a shutdown response. Enter the value in percent with respect to the programmed feed rate. Input range: 50 to 100 %
<b>FMAX</b>	Maximum feed rate in the material up to which the TNC can automatically increase the feed rate. Enter the value in percent of the programmed feed rate.
<b>FIDL</b>	Feed rate at which the TNC is to traverse when the tool is not cutting (feed rate in the air). Enter the value in percent of the programmed feed rate.
<b>FENT</b>	Feed rate at which the TNC is to traverse when the tool enters or exits the material. Enter the value in percent with respect to the programmed feed rate. Maximum input value: 100%

Column	Function
OVLD	<p>Desired reaction of the TNC to overload:</p> <ul style="list-style-type: none"> <li>■ <b>M</b>: Execution of a macro defined by the machine tool builder</li> <li>■ <b>S</b>: Immediate NC stop</li> <li>■ <b>F</b>: NC stop if the tool has been retracted</li> <li>■ <b>E</b>: Just display an error message on the screen</li> <li>■ <b>L</b>: Disable active tool</li> <li>■ -: No overload reaction</li> </ul> <p>The TNC conducts the selected shutdown response if the maximum spindle power is exceeded for more than one second and at the same time the feed rate falls below the minimum you defined. Enter the desired function via the ASCII keyboard.</p> <p>In conjunction with the cut-related tool wear monitoring the control only evaluates the options <b>M</b> and <b>L</b>.</p> <p><b>Further Information:</b> "Tool wear monitoring", page 454</p>
POUT	<p>Spindle power at which the TNC is to detect the exit of the tool from the workpiece. Enter the value in percent of the learned reference load. Recommended input value: 8 %</p>
SENS	<p>Sensitivity (aggressiveness) of feedback control. A value between 50 and 200 can be entered. 50 is for slow control, 200 for a very aggressive control. An aggressive control reacts quickly and with strong changes to the values, but it tends to overshoot. Recommended value: 100</p>
PLC	<p>Value that the TNC is to transfer to the PLC at the beginning of a machining step. The machine manufacturer defines the function, so refer to your machine manual.</p>



In the **AFC.TAB** table you can define as many control settings (lines) as desired.

If there is no AFC.TAB table in the **TNC:\table** directory, the TNC uses permanently defined internal control settings for the teach-in cut, or predefined tool-dependent standard reference power for regulation. It is best, however, to work with the AFC.TAB table.

## Special functions

### 11.4 Adaptive Feed Control AFC (option 45)

Proceed as follows to create the AFC.TAB file (only necessary if the file does not yet exist):

- ▶ Select the **Programming** operating mode
- ▶ To call the file manager, press the **PGM MGT** key
- ▶ Select the **TNC:\** directory
- ▶ Create a new **AFC.TAB** file and confirm with the **ENT** key: The TNC shows a list of table formats
- ▶ Select the **AFC.TAB** table format and confirm with the **ENT** key: The TNC creates a table with the **Standard** control settings



## Recording a teach-in cut

The TNC provides several cycles that enable you to start and stop a teach-in step:

- **FUNCTION AFC CTRL:** The AFC CTRL function activates closed-loop mode starting with the place at which this block is run (even if the teach-in phase has not yet been completed)
- **FUNCTION AFC CUT BEGIN TIME1 DIST2 LOAD3:** The TNC starts a sequence of cuts with active AFC. The switch from the teach-in cut to closed-loop mode begins as soon as the reference load was determined in the teach-in phase, or once one of the conditions TIME, DIST or LOAD is fulfilled. With TIME you define the maximum duration in seconds of the teach-in phase. DIST defines the maximum distance for the teach-in cut. With LOAD you can set a reference load directly.
- **FUNCTION AFC CUT END:** The AFC CUT END function deactivates the AFC control



The defaults TIME, DIST and LOAD are modally effective. They can be reset with the entry 0.



If you enter a tool-dependent standard reference power using the **AFC-LOAD** column, the control stops executing teach-in cuts. The control immediately uses the value given for regulation. You specify the value for the tool-dependent standard reference once in advance with a teach-in cut. If the cut conditions change, e.g. if the workpiece material changes, carry out a new teach-in cut.



You can define a standard reference power with the **AFC LOAD** tool table column and the **LOAD** input in the NC program. Activate the value **AFC LOAD** via the tool call and the value **LOAD** with the function **FUNCTION AFC CUT BEGIN**.

The control uses the value programmed later in the NC program.

## Special functions

### 11.4 Adaptive Feed Control AFC (option 45)

#### Programming AFC

To program the AFC functions for starting and ending the teach in cut, proceed as follows:

- ▶ In the **Programming** operating mode press the **SPEC FCT** key
- ▶ Press the **PROGRAM FUNCTIONS** soft key
- ▶ Press the **FUNCTION AFC** soft key
- ▶ Select the function

With a teach-in cut the TNC firstly copies the basic settings defined in the AFC.TAB table into the file **<name>.H.AFC.DEP** for each machining step. **<name>** is the name of the NC program for which you have recorded the teach-in cut. In addition, the TNC measures the maximum spindle power consumed during the teach-in cut and saves this value in the table.

Each line in the **<name>.H.AFC.DEP** file stands for a machining section, that you start with **FUNCTION AFC CUT BEGIN** and complete with **FUNCTION AFC CUT END**. You can edit all data of the **<name>.H.AFC.DEP** file if you wish to optimize them. If have carried out optimization processes in comparison with the values entered in the AFC.TAB table, the TNC places a **\*** in front of the control settings in the AFC column.

**Further Information:** "Defining the AFC basic settings", page 444

As well as the data from the AFC.TAB table, the TNC also saves the following additional information in the file **<name>.H.AFC.DEP**:

Column	Function
<b>NR</b>	Number of the machining step
<b>TOOL</b>	Number or name of the tool with which the machining step was made (not editable)
<b>IDX</b>	Index of the tool with which the machining step was made (not editable)
<b>N</b>	Difference for tool call: <ul style="list-style-type: none"> <li>■ <b>0</b>: Tool was called by its tool number</li> <li>■ <b>1</b>: Tool was called by its tool name</li> </ul>
<b>PREF</b>	Reference load of the spindle. The TNC measures the value in percent with respect to the rated power of the spindle
<b>ST</b>	Status of the machining step: <ul style="list-style-type: none"> <li>■ <b>L</b>: In the next program run, a teach-in cut is recorded for this machining step. The TNC overwrites any existing values in this line</li> <li>■ <b>C</b>: The teach-in cut was successfully completed. The next program run can be conducted with automatic feed control</li> </ul>
<b>AFC</b>	Name of the control setting

Remember the following before you record a teach-in cut:

- If required, adapt the control settings in the AFC.TAB table
- Enter the desired control setting for all tools in the **AFC** column of the tool table TOOL.T
- Select the program for teach-in
- Activate the AFC with the soft key

**Further Information:** "Activating/deactivating AFC ", page 452



You can teach any number of machining steps for a tool. Your machine tool builder will either make a function available for this, or will integrate this possibility in the functions for switching on the spindle. Refer to your machine manual.

The functions for starting and ending a machining step are machine-dependent. Refer to your machine manual.

## 11.4 Adaptive Feed Control AFC (option 45)



When you are performing a teach-in cut, the TNC shows the spindle reference power determined until this time in a pop-up window.

You can reset the reference power at any time by pressing the **PREF RESET** soft key. The TNC then restarts the learning phase.

When you record a teach-in cut, the TNC internally sets the spindle override to 100%. Then you can no longer change the spindle speed.

During the teach-in cut, you can influence the measured reference load by using the feed rate override to make any changes to the contouring feed rate.

You do not have to run the entire machining step in learning mode. If the cutting conditions do not change significantly, you can switch to the control mode immediately. Press the **EXIT LEARNING** soft key, and the status changes from **L** to **C**.

You can repeat a teach-in cut as often as desired. Manually change the status from **ST** back to **L**. It may be necessary to repeat the teach-in cut if the programmed feed rate is far too fast, and forces you to sharply decrease the feed rate override during the machining step.

The TNC changes the status from teach-in (**L**) to controlling (**C**) only when the recorded reference load is greater than 2 %. Adaptive feed control is not possible for smaller values.

Proceed as follows to select and, if required, edit the **<name>.H.AFC.DEP** file:



- ▶ Operating mode: Press the **Program run, full sequence** soft key



- ▶ Shift the soft-key row



- ▶ Press the AFC Settings soft key
- ▶ Make optimizations if required



Note that the **<name>.H.AFC.DEP** file is locked against editing as long as the NC program **<name>.H** is running.

The TNC removes the editing lock if one of the following functions has been executed:

- **M02**
- **M30**
- **END PGM**

You can also change the **<name>.H.AFC.DEP** file in **Programming** mode. If necessary, you can even delete a machining step (entire line) there.



In order to edit the **<name>.H.AFC.DEP** file, you must first set the file manager so that all file types can be displayed (**SELECT TYPE** soft key).

**Further Information:** "Files", page 145

## Special functions

### 11.4 Adaptive Feed Control AFC (option 45)


#### Activating/deactivating AFC



- ▶ Operating mode: Press the **Program run, full sequence** soft key




- ▶ Shift the soft-key row



- ▶ To activate the adaptive feed control: Set the soft key to **ON** and the TNC displays the AFC symbol in the position display

**Further Information:** "Status displays", page 90



- ▶ To deactivate the adaptive feed control: Set the soft key to **OFF**



If adaptive feed control is active in **Control** mode, the control executes a switch-off reaction independent of the programmed shutdown response:

- If with the reference spindle load the minimum feed factor is fallen below
- If the programmed feed rate is fallen below by 30%

The adaptive feed control remains active until you deactivate it by soft key. The TNC remembers the setting of the soft key even if the power is interrupted.

If the adaptive feed control is active in the **Control** mode, the TNC internally sets the spindle override to 100%. Then you can no longer change the spindle speed.

If the adaptive feed control is active in the **Control** mode, the TNC takes over the feed rate override function:


- If you increase the feed rate override, it has no influence on the control.
- If you decrease the feed rate override by more than **10%** with respect to the maximum setting, the TNC switches the adaptive feed control off. In this case the TNC displays a window to inform you.


In NC blocks containing **FMAX**, the adaptive feed control is **not active**.

Mid-program startup is allowed during active feed control and the TNC takes the cut number of the startup point into account.

The TNC shows various pieces of information in the additional status display when adaptive feed control is active.

**Further Information:** "Additional status displays", page 92

In addition, the TNC shows the symbol  in the position display.



## Log file

The TNC stores various pieces of information for each machining step of a teach-in cut in the **<name>.H.AFC2.DEP** file. **<name>** is the name of the NC program for which you have recorded the teach-in cut. During control, the TNC updates the data and makes various evaluations. The following data are to be saved in this table:

Column	Function
<b>NR</b>	Number of the machining step
<b>TOOL</b>	Number or name of the tool with which the machining step was made
<b>IDX</b>	Index of the tool with which the machining step was made
<b>SNOM</b>	Nominal spindle speed [rpm]
<b>SDIFF</b>	Maximum difference of the spindle speed in % of the nominal speed
<b>CTIME</b>	Machining time (tool in effect)
<b>FAVG</b>	Average feed rate (tool in effect)
<b>FMIN</b>	Smallest occurring feed factor. The TNC shows the value as a percentage of the programmed feed rate
<b>PMAX</b>	Maximum recorded spindle power during machining. The TNC shows the value as a percent of the spindle's rated power.
<b>PREF</b>	Reference load of the spindle. The TNC shows the value as a percent of the spindle's rated power.
<b>OVLD</b>	Reaction by the TNC to overload: <ul style="list-style-type: none"> <li>■ <b>M</b>: A macro defined by the machine tool builder has been run</li> <li>■ <b>S</b>: Immediate NC stop was conducted</li> <li>■ <b>F</b>: NC stop was conducted after the tool was retracted</li> <li>■ <b>E</b>: An error message was displayed</li> <li>■ <b>L</b>: The current tool was locked</li> <li>■ <b>-</b>: There was no overload reaction</li> </ul>
<b>BLOCK</b>	Block number at which the machining step begins



During regulation, the control indicates the current machining time as well as the resulting time saving in percent. The control enters the results of the evaluation between the key words **total** and **saved** in the last line of the log file. Where the time balance is positive, the percentage value is also positive.

## Special functions

### 11.4 Adaptive Feed Control AFC (option 45)


Proceed as follows to select the **<name>.H.AFC2.DEP** file:




- ▶ Operating mode: Press the **Program run, full sequence** soft key



- ▶ Shift the soft-key row



- ▶ Press the AFC Settings soft key



- ▶ Show the log file

#### Tool wear monitoring

Activate cut-related tool wear monitoring by entering a value not equal to 0 in the **AFC-OVLD1** column in the tool table.

The shutdown response depends on the **AFC.TAB** column **OVLD**.

In conjunction with cut-related tool wear monitoring the control only evaluates the two options **M** and **L** in the **OVLD** column, whereby the following responses are possible:

- Pop-up window
- Lock current tool
- Insert replacement tool



If the **AFC.TAB** columns **FMIN** and **FMAX** each have a value of 100%, adaptive feed control is deactivated but cut-related tool wear monitoring remains active.

**Further Information:** "Enter tool data into the table", page 206 and page 444

#### Tool load monitoring

Activate cut-related tool load monitoring (tool breakage control) by entering a value not equal to 0 in the **AFC-OVLD2** column in the tool table.

As shutdown response, the control always executes a machining stop and locks the momentary tool.



If the **AFC.TAB** columns **FMIN** and **FMAX** each have a value of 100%, adaptive feed control is deactivated but cut-related tool load monitoring remains active.

**Further Information:** "Enter tool data into the table", page 206 and page 444



## 11.5 Active Chatter Control ACC (option 145)

### Application



Refer to your machine manual.

This feature must be enabled and adapted by the machine tool builder.

Strong forces come into play during roughing (power milling). Depending on the tool spindle speed, the resonances in the machine tool and the chip volume (metal-removal rate during milling), the tool can sometimes begin to "chatter." This chattering places heavy strain on the machine, and causes ugly marks on the workpiece surface. The tool, too, is subject to heavy and irregular wear from chattering. In extreme cases it can result in tool breakage.

To reduce the inclination to chattering, HEIDENHAIN now offers an effective antidote with **ACC (Active Chatter Control)**. The use of this control function is particularly advantageous during heavy cutting. ACC makes substantially higher metal removal rates possible. This enables you to increase your metal removal rate by up to 25 % and more, depending on the type of machine. You reduce the mechanical load on the machine and increase the life of your tools at the same time.



Please note that ACC was developed especially for heavy cutting and is particularly effective in this area. You need to conduct appropriate tests to ensure whether ACC is also advantageous during standard roughing.

When you use the ACC feature, you must enter the number of tool cuts **CUT** for the corresponding tool in the TOOL.T tool table.

## Special functions

### 11.5 Active Chatter Control ACC (option 145)

#### Activating/deactivating ACC

To activate ACC, you first need to set the **ACC** column to **Y** (**ENT** key = Y, **NO ENT** = N) for the respective tool in the tool table TOOL.T.


Activate/deactivate ACC for the machine mode:




- ▶ Operating mode: Press the **Program run, full sequence, Program run, single block** or **Positioning with manl.data input** key



- ▶ Shift the soft-key row



- ▶ Activate ACC: Set the soft key to **ON** and the TNC displays the ACC symbol in the position display  
**Further Information:** "Status displays", page 90



- ▶ To deactivate ACC: Set the soft key to **OFF**

If ACC is on, in the position display the TNC shows the symbol **ACC**.

# 11.6 Working with the parallel axes U, V and W

## Overview



Refer to your machine manual.  
Your machine must be configured by the machine manufacturer if you want to use parallel-axis functions.  
Depending on the configuration, the PARAXCOMP function may be activated as standard.

The axes U, V and W are secondary axes parallel to the principal axes X, Y and Z, respectively. Principal axes and parallel axes are permanently assigned to each other.


Principal axis	Parallel axis	Rotary axis
X	U	A
Y	V	B
Z	W	C

The TNC provides the following functions for machining with the parallel axes U, V and W:

Soft key	Function	Meaning	Page
FUNCTION PARAXCOMP	PARAXCOMP	Define the TNC's behavior when positioning parallel axes	459
FUNCTION PARAXMODE	PARAXMODE	Define the axes the TNC is to use for machining	460



After the TNC is started up, the standard configuration is always effective.  
You must deactivate the parallel-axis functions before switching the machine kinematics.  
You can deactivate the programming of parallel axes with the machine parameter **noParaxMode** (no. 105413).



## Special functions

### 11.6 Working with the parallel axes U, V and W

#### FUNCTION PARAXCOMP DISPLAY

Use the **PARAXCOMP DISPLAY** function to activate the display function for parallel axis movements. The TNC considers the traverse movements of the parallel axis in the position display of the associated principal axis (sum display). Therefore, the position display of the principal axis always displays the relative distance from the tool to the workpiece, regardless of whether you move the principal axis or the minor axis.

Proceed as follows for the definition:

- |   |  |
|---|--|
| <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">SPEC<br/>FCT</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">PROGRAM<br/>FUNCTIONS</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">FUNCTION<br/>PARAX</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">FUNCTION<br/>PARAXCOMP</div> <div style="border: 1px solid black; padding: 2px;">FUNCTION<br/>PARAXCOMP<br/>DISPLAY</div> | <ul style="list-style-type: none"> <li>▶ Show the soft-key row with special functions</li> <li>▶ Select the menu for defining various plain-language functions</li> <li>▶ Select <b>FUNCTION PARAX</b></li> <li>▶ Select <b>FUNCTION PARAXCOMP</b></li> <li>▶ Select <b>FUNCTION PARAXCOMP DISPLAY</b></li> <li>▶ Define the parallel axis whose movements the TNC is to take into account in the position display of the associated principal axis</li> </ul> |
|---|--|

#### NC block

##### 13 FUNCTION PARAXCOMP DISPLAY W

#### FUNCTION PARAXCOMP MOVE



The **PARAXCOMP MOVE** function can be used only in connection with straight-line blocks (**L**).

#### NC block

##### 13 FUNCTION PARAXCOMP MOVE W

The TNC uses the **PARAXCOMP MOVE** function to compensate for the movement of a parallel axis by performing a compensation movement in the associated principal axis.

For example, if a parallel axis moves in the negative W-axis direction, the principal axis Z simultaneously moves in the positive direction by the same value. The relative distance from the tool to the workpiece remains the same. Application in gantry-type milling machine: Retract the spindle sleeve to move the cross beam down simultaneously.

Proceed as follows for the definition:

- |  |  |
|--|--|
| <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">SPEC<br/>FCT</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">PROGRAM<br/>FUNCTIONS</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">FUNCTION<br/>PARAX</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">FUNCTION<br/>PARAXCOMP</div> <div style="border: 1px solid black; padding: 2px;">FUNCTION<br/>PARAXCOMP<br/>MOVE</div> | <ul style="list-style-type: none"> <li>▶ Show the soft-key row with special functions</li> <li>▶ Select the menu for defining various plain-language functions</li> <li>▶ Select <b>FUNCTION PARAX</b></li> <li>▶ Select <b>FUNCTION PARAXCOMP</b></li> <li>▶ Select <b>FUNCTION PARAXCOMP MOVE</b></li> <li>▶ Define the parallel axis</li> </ul> |
|--|--|

## Deactivating FUNCTION PARAXCOMP



After the TNC is started up, the standard configuration is always effective.

The parallel-axis function **PARAXCOMP** is automatically reset by the TNC with the following functions:

- Selection of a program
- **PARAXCOMP OFF**

You must deactivate the parallel-axis functions before switching the machine kinematics.

Use the **PARAXCOMP OFF** function to switch off the parallel-axis functions **PARAXCOMP DISPLAY** and **PARAXCOMP MOVE**. Proceed as follows for the definition:

SPEC  
FCT

- ▶ Show the soft-key row with special functions

PROGRAM  
FUNCTIONS

- ▶ Select the menu for defining various plain-language functions

FUNCTION  
PARAX

- ▶ Select **FUNCTION PARAX**

FUNCTION  
PARAXCOMP

- ▶ Select **FUNCTION PARAXCOMP**

FUNCTION  
PARAXCOMP  
OFF

- ▶ Select **FUNCTION PARAXCOMP OFF**. If you want to switch off the parallel-axis functions only for individual parallel axes, then the respective axis must be specifically indicated.

### NC blocks

13 FUNCTION PARAXCOMP OFF

13 FUNCTION PARAXCOMP OFF W

## Special functions

### 11.6 Working with the parallel axes U, V and W

#### FUNCTION PARAXMODE








To activate the **PARAXMODE** function, you must always define three axes.

If you combine the **PARAXMODE** and **PARAXCOMP** functions, the TNC deactivates the **PARAXCOMP** function for an axis that was defined in both functions. When you deactivate **PARAXMODE**, the **PARAXCOMP** function becomes active again.

Use the **PARAXMODE** function to define the axes the TNC is to use for machining. You program all traverse movements and contour descriptions in the principal axes X, Y and Z, independent of your machine.

Define the three axes in the **PARAXMODE** function (e.g. **FUNCTION PARAXMODE X Y W**), which the TNC is to use to execute the programmed traverse movements.

Proceed as follows for the definition:

-  ▶ Show the soft-key row with special functions
-  ▶ Select the menu for defining various plain-language functions
-  ▶ Select **FUNCTION PARAX**
-  ▶ Select **FUNCTION PARAXMODE**
-  ▶ Select **FUNCTION PARAXMODE**
- ▶ Define the axes for machining

#### Move the principal axis and the parallel axis simultaneously

If the **PARAXMODE** function is active, the TNC uses the axes defined in the function to execute the programmed traverse movements.

If the TNC is to traverse a parallel axis simultaneously with the associated principal axis, you can identify the respective axis by additionally entering the character "&". The axis with the & character then refers to the principal axis.



The syntax element "&" is only permitted in L blocks. Additional positioning of a principal axis with the "&" command is done in the REF system. If you have set the position display to "actual value", this movement will not be shown. If necessary, switch the position display to "REF value".

#### NC block

**13 FUNCTION PARAXMODE X Y W**

#### NC block

**13 FUNCTION PARAXMODE X Y W**

**14 L Z+100 &Z+150 R0 FMAX**

## Deactivating FUNCTION PARAXMODE



After the TNC is started up, the standard configuration is always effective.

The parallel-axis function **PARAXMODE OFF** is automatically reset by the TNC via the following functions:

- Selection of a program
- End of program
- M2 or M30
- **PARAXMODE OFF**

You must deactivate the parallel-axis functions before switching the machine kinematics.

### NC block

**13 FUNCTION PARAXMODE OFF**

Use the **PARAXMODE OFF** function to switch off the parallel-axis function. The TNC then uses the principal axes defined by the machine manufacturer. Proceed as follows for the definition:

- |   |   |
|---|---|
| <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">SPEC<br/>FCT</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">PROGRAM<br/>FUNCTIONS</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">FUNCTION<br/>PARAX</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">FUNCTION<br/>PARAXMODE</div> <div style="border: 1px solid black; padding: 2px;">FUNCTION<br/>PARAXMODE<br/>OFF</div> | <ul style="list-style-type: none"> <li>▶ Show the soft-key row with special functions</li> <li>▶ Select the menu for defining various plain-language functions</li> <li>▶ Select <b>FUNCTION PARAX</b></li> <li>▶ Select <b>FUNCTION PARAXMODE</b></li> <li>▶ Select <b>FUNCTION PARAXMODE OFF</b></li> </ul> |
|---|---|

## Special functions

### 11.6 Working with the parallel axes U, V and W

#### Example: Drilling in the W axis

0 BEGIN PGM PAR MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-20	
2 BLK FORM 0.2 X+100 Y+100 Z+0	
3 TOOL CALL 5 Z S2222	Call the tool in the spindle axis Z
4 L Z+0 W+0 R0 FMAX M91	Reset the principle axis and minor axis
5 L Z+100 R0 FMAX M3	Position the principal axis
6 CYCL DEF 200 DRILLING	
Q200=+2           ;SET-UP CLEARANCE	
Q201=-20         ;DEPTH	
Q206=+150        ;FEED RATE FOR PLNGNG	
Q202=+5          ;PLUNGING DEPTH	
Q210=+0          ;DWELL TIME AT TOP	
Q203=+0          ;SURFACE COORDINATE	
Q204=+50         ;2ND SET-UP CLEARANCE	
Q211=+0          ;DWELL TIME AT DEPTH	
Q395=+0          ;DEPTH REFERENCE	
7 FUNCTION PARAXCOMP DISPLAY Z W	Activate display compensation
8 FUNCTION PARAXMODE X Y W	Positive axis selection
9 L X+50 Y+50 R0 FMAX M99	Infeed runs minor axis W
10 FUNCTION PARAXMODE OFF	Restore standard axis configuration
11 L Z+0 W+0 R0 FMAX M91	Reset the principle axis and minor axis
12 L M30	
13 END PGM PAR MM	



## 11.7 File functions

### Application

The **FILE FUNCTION** features are used to copy, move and delete files from within the part program.



You must not use **FILE** functions on programs or files, to which you have previously made reference with functions such as **CALL PGM** or **CYCL DEF 12 PGM CALL**.

### Defining file functions

SPEC  
FCT

- Press the special functions key

PROGRAM  
FUNCTIONS

- Select the program functions

FUNCTION  
FILE

- Select the file functions: The TNC displays the available functions

Soft key	Function	Meaning
FILE COPY	<b>FILE COPY</b>	Copy file: Enter the name and path of the file to be copied, as well as the target path
FILE MOVE	<b>FILE MOVE</b>	Move file: Enter the name and path of the file to be moved, as well as the target path
FILE DELETE	<b>FILE DELETE</b>	Delete file: Enter the path and name of the file to be deleted

## Special functions

### 11.8 Definition of a datum shift






#### 11.8 Definition of a datum shift

##### Overview

As an alternative to the coordinate transformation cycle 7 **DATUM SHIFT**, you can also use the **TRANS DATUM** conversational function. Just as in Cycle 7, you can use **TRANS DATUM** to directly program shift values or activate a line from a selectable datum table. In addition, there is also the **TRANS DATUM RESET** function, which you can use to easily reset a datum shift.

##### TRANS DATUM AXIS

You can define a datum shift by entering values in the respective axis with the **TRANS DATUM AXIS** function. You can define up to nine coordinates in one block, and incremental entries are possible. Proceed as follows for the definition:

- |   |   |
|---|---|
|    | ► Show the soft-key row with special functions  |
|    | ► Select the menu for defining various conversational functions   |
|  | ► Select transformations  |
|  | ► Select datum shifting with <b>TRANS DATUM</b>   |
|  | ► Select the value input soft key<br>► Enter the datum shift in the affected axes, confirming with the <b>ENT</b> key each time |

##### NC block






```
13 TRANS DATUMAXIS X+10 Y+25 Z+42
```



Values entered as absolute values refer to the workpiece datum, which is specified either by datum setting or with a preset from the preset table. Incremental values always refer to the datum which was last valid (this may be a datum which has already been shifted).

## TRANS DATUM TABLE

You can define a datum shift by selecting a datum number from a datum table with the **TRANS DATUM TABLE** function. Proceed as follows for the definition:

- 
  - ▶ Show the soft-key row with special functions
- 
  - ▶ Select the menu for defining various plain-language functions
- 
  - ▶ Select transformations
- 
  - ▶ Select datum shifting with **TRANS DATUM**
- 
  - ▶ Select datum shifting with **TRANS DATUM TABLE**
  - ▶ Enter the line number to be activated by the TNC, and confirm with the **ENT** key
  - ▶ If desired, enter the name of the datum table from which you want to activate the datum number, and confirm with the **ENT** key. If you do not want to define a datum table, confirm with the **NO ENT** key



If you did not define a datum table in the **TRANS DATUM TABLE** block, then the TNC uses the datum table already selected in the NC program with **SEL TABLE**, or the datum table with status M selected in the **Program run, single block** or **Program run, full sequence** operating mode.

### NC block

13 TRANS DATUMTABLE TABLINE25

## Special functions

### 11.8 Definition of a datum shift

#### TRANS DATUM RESET

Use the **TRANS DATUM RESET** function to cancel a datum shift. How you previously defined the datum is irrelevant. Proceed as follows for the definition:

#### NC block

#### 13 TRANS DATUM RESET

- ▶ Show the soft-key row with special functions
- ▶ Select the menu for defining various conversational functions
- ▶ Select transformations
- ▶ Select datum shift **TRANS DATUM**
- ▶ Press the **RESET DATUM SHIFT** soft key

## 11.9 Creating text files

### Application

You can use the TNC's text editor to write and edit texts. Typical applications:







- Recording test results
- Documenting working procedures
- Creating formula collections

Text files have the extension .A (for ASCII files). If you want to edit other types of files, you must first convert them into type .A files.

### Opening and exiting a text file

- ▶ Operating mode: Press the **Programming** key
- ▶ To call the file manager, press the **PGM MGT** key.
- ▶ Display type .A files: Press the **SELECT TYPE** soft key and **SHOW ALL** soft key one after the other
- ▶ Select a file and open it with the **SELECT** soft key or **ENT** key, or create a new file by entering the new file name and confirming your entry with the **ENT** key

To leave the text editor, call the file manager and select a file of a different file type, for example a part program.

Soft key	Cursor movements
	Move cursor one word to the right
	Move cursor one word to the left
	Go to next screen page
	Go to previous screen page
	Cursor at beginning of file
	Cursor at end of file

## Special functions

### 11.9 Creating text files

#### Editing texts

Above the first line of the text editor, there is an information field showing the file name, location and line information:

**File:** Name of the text file

**Line:** Line in which the cursor is presently located

**Column:** Column in which the cursor is presently located

The text is inserted or overwritten at the location of the cursor.





You can move the cursor to any desired position in the text file by pressing the arrow keys.

You can insert a line break with the **RETURN** or **ENT** key.

#### Deleting and re-inserting characters, words and lines

With the text editor, you can erase words and even lines, and insert them at any desired location in the text.


- ▶ Move the cursor to the word or line that you wish to erase and insert at a different place in the text
- ▶ Press the **DELETE WORD** or **DELETE LINE** soft key: The text is deleted and stored temporarily.
- ▶ Move the cursor to the location where you wish insert the text, and press the **INSERT LINE / WORD** soft key.

Soft key	Function
	Delete and temporarily store a line
	Delete and temporarily store a word
	Delete and temporarily store a character
	Insert a line or word from temporary storage

## Editing text blocks



You can copy and erase text blocks of any size, and insert them at other locations. Before any of these actions, you must first select the desired text block:

- ▶ To select a text block: Move the cursor to the first character of the text you wish to select.




- ▶ Press the **SELECT BLOCK** soft key.
- ▶ Move the cursor to the last character of the text you wish to select. You can select whole lines by moving the cursor up or down directly with the arrow keys—the selected text is shown in a different color.

After selecting the desired text block, you can edit the text with the following soft keys:

Soft key	Function
	Delete the selected block and store temporarily
	Store the selected block temporarily without erasing (copy)

If desired, you can now insert the temporarily stored block at a different location:

- ▶ Move the cursor to the location where you want to insert the temporarily stored text block



- ▶ Press the **INSERT BLOCK** soft key the text block is inserted.

You can insert the temporarily stored text block as often as desired

## Transferring the selected block to a different file


- ▶ Select the text block as described previously



- ▶ Press the **APPEND TO FILE** soft key. The TNC displays the dialog prompt **Destination file =**
- ▶ Enter the path and name of the destination file. The TNC appends the selected text to the specified file. If no target file with the specified name is found, the TNC creates a new file with the selected text.

## Inserting another file at the cursor position

- ▶ Move the cursor to the location in the text where you wish to insert another file



- ▶ Press the **READ FILE** soft key. The TNC displays the dialog prompt **File name =**
- ▶ Enter the path and name of the file you want to insert

## Special functions

### 11.9 Creating text files

#### Finding text sections

With the text editor, you can search for words or character strings in a text. Two functions are available:

##### Finding the current text

The search function is used for finding the next occurrence of the word in which the cursor is presently located:

- ▶ Move the cursor to the desired word.
- ▶ To select the search function, press the **FIND** soft key.
- ▶ Press the **FIND CURRENT WORD** soft key.
- ▶ To find a word: press the **FIND** soft key.
- ▶ Exit the search function: Press the **END** soft key

##### Finding any text

- ▶ To select the search function, press the **FIND** soft key. The TNC displays the dialog prompt **Find text :**
- ▶ Enter the text that you wish to find
- ▶ To find text: press the **FIND** soft key.
- ▶ Exit the search function: Press the **END** soft key



## 11.10 Freely definable tables

### Fundamentals

In freely definable tables you can save and read any information from the NC program. The Q parameter functions **FN 26** to **FN 28** are provided for this purpose.

You can change the format of freely definable tables, i.e. the columns and their properties, by using the structure editor. They enable you to make tables that are exactly tailored to your application.

You can also toggle between a table view (standard setting) and form view.

NO	X	Y	Z	A	C	DOC
0	100.001	49.999	0			PAT 1
1	99.994	49.999	0			PAT 2
2	99.990	50.001	0			PAT 3
3	100.002	49.995	0			PAT 4
4	99.990	50.003				PAT 5
5						
6						
7						
8						
9						
10						

### Creating a freely definable table

- ▶ To call the file manager, press the **PGM MGT** key
- ▶ Enter any file name with the .TAB extension and confirm with the **ENT** key. The TNC displays a pop-up window with permanently saved table formats
- ▶ Use the arrow key to select a table template e.g. **EXAMPLE.TAB** and confirm with the **ENT** key: The TNC opens a new table in the predefined format
- ▶ To adapt the table to your requirements you have to edit the table format

**Further Information:** "Editing the table format", page 472



Machine tool builders may define their own table templates and save them in the TNC. When you create a new table, the TNC opens a pop-up window listing all available table templates.



You can also save your own table templates in the TNC. To do this, you create a new table, change the table format and save the table in the **TNC:\system\proto** directory. Then your template will also be available in the list box for table templates when you create a new table.

## Special functions

### 11.10 Freely definable tables

#### Editing the table format


- Press the soft key **EDIT FORMAT** (switch the soft-key row):  
The TNC opens the editor form showing the table structure.  
The meanings of the structure commands (header entries) are shown in the following table.

Structure command	Meaning
<b>Available columns:</b>	List of all columns contained in the table
<b>Move before:</b>	The entry highlighted in <b>Available columns</b> is moved in front of this column
<b>Name</b>	Column name: Is displayed in the header
<b>Column type</b>	<b>TEXT:</b> Text entry <b>SIGN:</b> + or - sign <b>BIN:</b> Binary number <b>DEC:</b> Decimal, positive, whole number (cardinal number) <b>HEX:</b> Hexadecimal number <b>INT:</b> Whole number <b>LENGTH:</b> Length (is converted in inch programs) <b>FEED:</b> Feed rate (mm/min or 0.1 inch/min) <b>IFEED:</b> Feed rate (mm/min or inch/min) <b>FLOAT:</b> Floating-point number <b>BOOL:</b> Logical value <b>INDEX:</b> Index <b>TSTAMP:</b> Fixed format for date and time <b>UPTXT:</b> Text entry in upper case <b>PATHNAME:</b> Path name
<b>Default value</b>	Default value for the fields in this column
<b>Width</b>	Width of the column (number of characters)
<b>Primary key</b>	First table column
<b>Language-sensitive column name</b>	Language-sensitive dialogs

You can use a connected mouse or the TNC keyboard to navigate in the form. Navigation using the TNC keyboard:



- Press the navigation keys to go to the entry fields.  
Use the arrow keys to navigate within an entry field. To open pop-down menus, press the **GOTO** key.





In a table that already contains lines you can not change the table properties **Name** and **Column type**. Once you have deleted all lines, you can change these properties. If required, create a backup copy of the table beforehand.

In a field of the **TSTAMP** column type you can reset an invalid value if you press the **CE** key and then the **ENT** key.

### Exiting the structure editor

- Press the **OK** soft key. The TNC closes the editor form and applies the changes. All changes are discarded by pressing the **CANCEL** soft key.

### Switching between table and form view

All tables with the **.TAB** extension can be opened in either list view or form view.




- Press the key for setting the screen layout. Select the respective soft key for list view or form view (form view: with or without dialog texts)

In the form view the TNC lists the line numbers with the contents of the first column in the left half of the screen.

In the right half you can change the data.

- Press the **ENT** key or the arrow key to move to the next entry field
- To select another line press the navigation key (folder symbol). This moves the cursor to the left window, and you can select the desired line with the arrow keys. Press the green navigation key to switch back to the input window.



## Special functions

### 11.10 Freely definable tables

#### FN 26: TABOPEN – Open a freely definable table

With the function **FN 26: TABOPEN** you open a freely definable table to be written to with **FN 27** or to be read from with **FN 28**.



Only one table can be opened in an NC program at any one time. A new block with **FN 26: TABOPEN** automatically closes the last opened table.

The table to be opened must have the extension **.TAB**.

**Example: Open the table TAB1.TAB, which is saved in the directory TNC:\DIR1.**

```
56 FN 26: TABOPEN TNC:\DIR1\TAB1.TAB
```

### FN 27: TABWRITE – Write to a freely definable table

With the **FN 27: TABWRITE** function you write to the table that you previously opened with **FN 26: TABOPEN**.

You can write several column names in a **TABWRITE** block. The column names must be written between quotation marks and separated by a comma. You define the values that the TNC is to write to the respective column with Q parameters.



Note that by default the **FN 27: TABWRITE** function also writes values to the currently open table in **Test run** mode. The **FN18 ID992 NR16** function enables you to query in which operating mode the program is to be run. If the **FN27** function is to be run only in the **Program run, single block** and **Program run, full sequence** operating modes, you can skip the respective program section by using a jump command.

**Further Information:** "If-then decisions with Q parameters", page 342

You can write only to numerical table fields.

If you wish to write to more than one column in a block, you must save the values under successive Q parameter numbers.

#### Example

You wish to write to the columns "Radius," "Depth" and "D" in line 5 of the presently opened table. The value to be written in the table must be saved in the Q parameters Q5, Q6 and Q7.

```
53 Q5 = 3.75
```

```
54 Q6 = -5
```

```
55 Q7 = 7.5
```

```
56 FN 27: TABWRITE 5/"RADIUS,DEPTH,D" = Q5
```

## Special functions

### 11.10 Freely definable tables

#### FN 28: TABREAD – Read from a freely definable table

With the **FN 28: TABREAD** function you read from the table previously opened with **FN 26: TABOPEN**.

You can define, i.e. read, several column names in a **TABREAD** block. The column names must be written between quotation marks and separated by a comma. In the **FN 28** block you can define the Q parameter number in which the TNC is to write the value that is first read.



You can read only numerical table fields.  
If you wish to read from more than one column in a block, the TNC will save the values under successive Q parameter numbers.

#### Example

You wish to read the values of the columns "Radius," "Depth" and "D" from line 6 of the presently opened table. Save the first value in Q parameter Q10 (second value in Q11, third value in Q12).

```
56 FN 28: TABREAD Q10 = 6/"RADIUS,DEPTH,D"
```

#### Customize table view



This function may only be used with the permission of your machine manufacturer.

#### Soft key

#### Function

ADAPT THE  
TABLE  
FORMAT

Adapt format of tables present after changing the control software version

## 11.11 Pulsing spindle speed FUNCTION S-PULSE

### Program pulsing spindle speed

#### Application



Refer to your machine manual.

The behavior of this function varies depending on the respective machine.

Using the **S-PULSE FUNCTION** you can program a pulsing spindle speed, e.g. to avoid natural oscillations of the machine when operating at a constant spindle speed.

You can define the duration of a vibration (period length) using the P-TIME input value or a speed change in percent using the the SCALE input value. The spindle speed changes in a sinusoidal form around the target value.

#### Procedure

Proceed as follows for the definition:

- |  |  |
|--|--|
| <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">SPEC<br/>FCT</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">PROGRAM<br/>FUNCTIONS</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">FUNCTION<br/>SPINDLE</div> <div style="border: 1px solid black; padding: 2px;">SPINDLE-<br/>PULSE</div> | <ul style="list-style-type: none"> <li>▶ Show the soft-key row with special functions</li> <li>▶ Select the menu for defining various conversational functions</li> <li>▶ Press the <b>FUNCTION SPINDLE</b> soft key</li> <li>▶ Press the <b>SPINDLE-PULSE</b> soft key</li> <li>▶ Define period length P-TIME</li> <li>▶ Define speed change SCALE</li> </ul> |
|--|--|



The control never exceeds a programmed speed limit. The spindle speed is maintained until the sinusoidal curve of the **S-PULSE FUNCTION** falls below the maximum speed once more.


#### Symbols

In the status bar the symbol indicates the condition of the pulsing shaft speed:

Icon	Function
	Pulsing spindle speed active

#### NC block

**13 FUNCTION S-PULSE P-TIME10  
SCALE5**



## Special functions

### 11.11 Pulsing spindle speed FUNCTION S-PULSE

#### Reset pulsing spindle speed

Use the **S-PULSE RESET** function to reset the pulsing spindle speed.

Proceed as follows for the definition:

- ▶ Show the soft-key row with special functions
- ▶ Select the menu for defining various plain-language functions
- ▶ Press the **FUNCTION SPINDLE** soft key
- ▶ Press the **RESET SPINDLE-PULSE** soft key.

#### NC block

**18 FUNCTION S-PULSE RESET**



## 11.12 Dwell time FUNCTION FEED

### Programming dwell time

#### Application



Refer to your machine manual.  
The behavior of this function varies depending on the respective machine.

The **FUNCTION FEED DWELL** function is used to program a recurring dwell time in seconds, e.g. to force chip breaking in a turning cycle. Program **FUNCTION FEED DWELL** immediately prior to the machining you wish to run with chip breaking.

The defined dwell time from **FUNCTION FEED DWELL** is effective in both milling and turning operations.





The **FUNCTION FEED DWELL** function is not effective with rapid traverse movements and probing motion.



Damage to the workplace!  
Do not use **FUNCTION FEED DWELL** for machining threads.

#### Procedure

Proceed as follows for the definition:

- ▶  Show the soft-key row with special functions
- ▶  Select the menu for defining various plain-language functions
- ▶  Press the **FUNCTION FEED** soft key
- ▶  Press the **FEED DWELL** soft key
- ▶ Define the interval duration for dwelling D-TIME
- ▶ Define the interval duration for cutting F-TIME

#### NC block

**13 FUNCTION FEED DWELL D-TIME0.5  
F-TIME5**

## Special functions

### 11.12 Dwell time FUNCTION FEED

#### Resetting dwell time



Reset to the dwell time immediately following the machining with chip breaking.

#### NC block

**18 FUNCTION FEED DWELL RESET**

Use **FUNCTION FEED DWELL RESET** to reset the recurring dwell time.

Proceed as follows for the definition:

SPEC  
FCT

- Show the soft-key row with special functions

PROGRAM  
FUNCTIONS

- Select the menu for defining various plain-language functions

FUNCTION  
FEED

- Press the **FUNCTION FEED** soft key

RESET  
FEED  
DWELL

- Press the **RESET FEED DWELL** soft key



You can also reset the dwell time by entering D-TIME 0.

The TNC automatically resets the **FUNCTION FEED DWELL** function at the end of a program.

## 11.13 Dwell time FUNCTION DWELL

### Programming dwell time

#### Application

The **FUNCTION DWELL** function enables you to program a dwell time in seconds or define the number of spindle revolutions for dwelling.

The defined dwell time from **FUNCTION DWELL** is effective in both milling and turning operations.

#### Procedure

Proceed as follows for the definition:

- ▶ Show the soft-key row with special functions
- ▶ Select the menu for defining various plain-language functions
- ▶ **FUNCTION DWELL** soft key
- ▶ Press the **DWELL TIME** soft key
- ▶ Define the duration in seconds
- ▶ Alternatively, press the **DWELL REVOLUTIONS** soft key
- ▶ Define the number of spindle revolutions

SPEC  
FCT

PROGRAM  
FUNCTIONS

FUNCTION  
DWELL

DWELL  
TIME

DWELL  
REVOLUTIONS

#### NC block

13 FUNCTION DWELL TIME10

#### NC block

23 FUNCTION DWELL REV5.8



# 12

**Multiple axis-  
machining**

## Multiple axis machining

### 12.1 Functions for multiple axis machining

#### 12.1 Functions for multiple axis machining

The TNC functions for multiple-axis machining are described in this chapter.

<b>TNC function</b>	<b>Description</b>	<b>Page</b>
<b>PLANE</b>	Define machining in the tilted working plane	485
<b>M116</b>	Feed rate of rotary axes	511
<b>PLANE/M128</b>	Inclined-tool machining	509
<b>FUNCTION TCPM</b>	Define the behavior of the TNC when positioning the rotary axes (improvement of M128)	519
<b>M126</b>	Shortest-path traverse of rotary axes	512
<b>M94</b>	Reduce display value of rotary axes	513
<b>M128</b>	Define the behavior of the TNC when positioning the rotary axes	514
<b>M138</b>	Selection of tilted axes	517
<b>M144</b>	Calculate machine kinematics	518
<b>LN blocks</b>	Three-dimensional tool compensation	523

## 12.2 The PLANE function: Tilting the working plane (software option 8)

### Introduction



The machine manufacturer must enable the functions for tilting the working plane!

You can only use the **PLANE** function completely on machines which have at least two rotary axes (head and/or table). Exception: **PLANE AXIAL** can also be used if only a single rotary axis is present or active on your machine.

The **PLANE** function is a powerful function for defining tilted working planes in various manners.

The parameter definition of the **PLANE** function is separated into two parts:

- The geometric definition of the plane, which is different for each of the available **PLANE** functions.
- The positioning behavior of the **PLANE** function, which is independent of the plane definition and is identical for all **PLANE** functions

**Further Information:** "Specifying the positioning behavior of the PLANE function", page 501



#### **Danger of collision!**

If you work with Cycle **8 MIRRORING** in a tilted system, please note the following:

If you program mirroring before the tilting of the working plane, the mirroring also effects the tilting. Exception: Tilting with Cycle 19 and **AXIAL PLANE**.

Mirroring a rotary axis with Cycle **8** only mirrors the motions of the axis, but not the angles defined in the **PLANE** functions. As a result, the positioning of the axes changes.



The actual-position-capture function is not possible with an active tilted working plane.

If you use the **PLANE** function when **M120** is active, the TNC automatically rescinds the radius compensation, which also rescinds the **M120** function.

Always use **PLANE RESET** to reset **PLANE** functions. Entering 0 in all **PLANE** parameters does not completely reset the function.

If you restrict the number of tilting axes with the **M138** function, your machine may provide only limited tilting possibilities. When calculating the axis angle in the selected axis, the control sets the value 0.









The TNC only supports tilting the working plane with spindle axis Z.

## Multiple axismachining

### 12.2 The PLANE function: Tilting the working plane (software option 8)



#### Overview

All **PLANE** functions available on the TNC describe the desired working plane independently of the rotary axes actually present on your machine. The following possibilities are available:

Soft key	Function	Required parameters	Page
	<b>SPATIAL</b>	Three spatial angles: <b>SPA</b> , <b>SPB</b> , and <b>SPC</b>	489
	<b>PROJECTED</b>	Two projection angles: <b>PROPR</b> and <b>PROMIN</b> and a rotation angle <b>ROT</b>	490
	<b>EULER</b>	Three Euler angles: precession ( <b>EULPR</b> ), nutation ( <b>EULNU</b> ) and rotation ( <b>EULROT</b> ),	492
	<b>VECTOR</b>	Normal vector for defining the plane and base vector for defining the direction of the tilted X axis	494
	<b>POINTS</b>	Coordinates of any three points in the plane to be tilted	496
	<b>RELATIVE</b>	Single, incrementally effective spatial angle	498
	<b>AXIAL</b>	Up to three absolute or incremental axis angles <b>A,B,C</b>	499
	<b>RESET</b>	Resetting the PLANE function	488

#### Running an animation

In order to make the differences between each definition possibility more clear even before selecting the function, you can start an animated sequence via soft key. The control turns the soft key blue and shows an animated portrayal of the selected PLANE function.

Soft key	Function
	Switch on animation
	Animation mode activated



## The PLANE function: Tilting the working plane (software option 8) 12.2


### Defining the PLANE function

SPEC  
FCT

- Show the soft-key row with special functions

TILT  
MACHINING  
PLANE

- Select the **PLANE** function: Press the **TILT MACHINING PLANE** soft key: The TNC displays the available definition possibilities in the soft-key row



### Selecting functions

- Select the desired function by soft key. The control continues the dialog and requests the required parameters


### Selecting the function while animation is active

- Select the function using the soft key: Control shows the animation
- To confirm the currently active function: Press the function's soft key again or press the **ENT** key

### Position display

As soon as a **PLANE** function except **PLANE AXIAL** is active, the TNC shows the calculated spatial angle in the additional status display.

In the Distance-To-Go mode (**ACTDST** and **REFDST**) the TNC shows during tilting (**MOVE** or **TURN** mode) in the rotary axis the distance to go (or calculated distance) to the final position of the rotary axis.



## Multiple axismachining

### 12.2 The PLANE function: Tilting the working plane (software option 8)

#### Resetting PLANE function




- Show the soft-key row with special functions



- Select the PLANE function: Press the **TILT MACHINING PLANE** soft key: The TNC displays the available definition possibilities in the soft-key row



- Select function to be reset: This resets the **PLANE** function internally



- Specify whether the TNC automatically moves the rotary axes to the default setting (**MOVE** or **TURN**) or not (**STAY**)

**Further Information:** "Automatic positioning: MOVE/TURN/STAY (entry is mandatory)", page 501



- Terminate the entry: Press the **END** key

#### NC block

**25 PLANE RESET MOVE DIST50 F1000**



The **PLANE RESET** function resets the active **PLANE** function—or an active cycle **19**—completely (angles = 0 and function is inactive). It does not need to be defined more than once.

Deactivate tilting in the **Manual operation** operating mode in the **3D ROT** menu.

**Further Information:** "Activating manual tilting:", page 641

## The PLANE function: Tilting the working plane (software option 8) 12.2

### Defining the working plane with the spatial angle: PLANE SPATIAL

#### Application

Spatial angles define a working plane using up to three rotations of the workpiece coordinate system; two perspectives that have always the same result are available for this purpose.

- **Rotations about the untilted coordinate system:** The sequence of the rotations is first around the machine axis A, then around the machine axis B, and then around the machine axis C.
- **Rotations about the respectively tilted coordinate system:** The sequence of rotations is first around the machine axis C, then around the rotated axis B, and then around the rotated axis A. This perspective is usually easier to understand.




#### Before programming, note the following

You must always define the three spatial angles **SPA**, **SPB**, and **SPC**, even if one of them = 0.


This operation corresponds to **19** if the entries in Cycle **19** are defined as spatial angles on the machine side.

Parameter description for the positioning behavior.


**Further Information:** "Specifying the positioning behavior of the PLANE function", page 501



#### Input parameters



- ▶ **Spatial angle A?:** Rotation angle **SPA** around the machine-referenced axis X. Entry range from  $-359.9999^\circ$  to  $+359.9999^\circ$
- ▶ **Spatial angle B?:** Rotation angle **SPB** around the machine-referenced axis X. Entry range from  $-359.9999^\circ$  to  $+359.9999^\circ$
- ▶ **Spatial angle C?:** Rotation angle **SPC** around the machine-referenced axis X. Entry range from  $-359.9999^\circ$  to  $+359.9999^\circ$
- ▶ Continue with the positioning properties  
**Further Information:** "Specifying the positioning behavior of the PLANE function", page 501




## Multiple axis machining

### 12.2 The PLANE function: Tilting the working plane (software option 8)

#### Abbreviations used

Abbreviation	Meaning
SPATIAL	In space
SPA	<b>S</b> patial <b>A</b> : Rotation around the X axis
SPB	<b>S</b> patial <b>B</b> : Rotation around the Y axis
SPC	<b>S</b> patial <b>C</b> : Rotation around the Z axis



#### NC block

```
5 PLANE SPATIAL SPA+27 SPB+0 SPC
+45 .....
```

#### Defining the working plane with the projection angle: PLANE PROJECTED

##### Application

Projection angles define a working plane by specifying two angles that you can communicate by projection of the 1st coordinate plane (Z/X on tool axis Z) and 2nd coordinate plane (Y/Z on tool axis Z) to the working levels to be defined.




#### Before programming, note the following

You can only use projection angles if the angle definitions are given with respect to a rectangular cuboid. Otherwise there will be deformations on the workpiece.


Parameter description for the positioning behavior.

**Further Information:** "Specifying the positioning behavior of the PLANE function", page 501





## The PLANE function: Tilting the working plane (software option 8) 12.2

### Input parameters



- ▶ **Projection angle on 1st Coordinate plane?:** Projected angle of the tilted machining plane in the 1st coordinate plane of the untilted coordinate system (Z/X for tool axis Z). Input range: from  $-89.9999^\circ$  to  $+89.9999^\circ$ . The  $0^\circ$  axis is the principal axis of the active working plane (X for tool axis Z, positive direction)
- ▶ **Proj. angle on 2nd Coordinate plane?:** Projected angle in the 2nd coordinate plane of the untilted coordinate system (Y/Z for tool axis Z). Input range: from  $-89.9999^\circ$  to  $+89.9999^\circ$ . The  $0^\circ$  axis is the minor axis of the active machining plane (Y for tool axis Z)
- ▶ **ROT angle of tilted plane?:** Rotation of the tilted coordinate system around the tilted tool axis (corresponds to a rotation with Cycle 10 ROTATION). The rotation angle is used to simply specify the direction of the principal axis of the working plane (X for tool axis Z, Z for tool axis Y). Input range:  $-360^\circ$  to  $+360^\circ$
- ▶ Continue with the positioning properties  
**Further Information:** "Specifying the positioning behavior of the PLANE function", page 501



### NC block

```
5 PLANE PROJECTED PROPR+24 PROMIN+24 ROT+30 .....
```

Abbreviations used:

<b>PROJECTED</b>	Projected
<b>PROPR</b>	Principle plane
<b>PROMIN</b>	Minor plane
<b>ROT</b>	Rotation

## 12.2 The PLANE function: Tilting the working plane (software option 8)

### Defining the working plane with the Euler angle: PLANE EULER

#### Application


Euler angles define a machining plane through up to three **rotations about the respectively tilted coordinate system**. The Swiss mathematician Leonhard Euler defined these angles.




#### Before programming, note the following

Parameter description for the positioning behavior.


**Further Information:** "Specifying the positioning behavior of the PLANE function", page 501



#### Input parameters



- ▶ **Rot. angle Main coordinate plane?:** Rotary angle **EULPR** around the Z axis. Please note:
  - Input range: -180.0000° to 180.0000°
  - The 0° axis is the X axis
- ▶ **Tilting angle tool axis?:** Tilting angle **EULNUT** of the coordinate system around the X axis shifted by the precession angle. Please note:
  - Input range: 0° to 180.0000°
  - The 0° axis is the Z axis
- ▶ **ROT angle of tilted plane?:** Rotation **EULROT** of the tilted coordinate system around the tilted Z axis (corresponds to a rotation with Cycle 10 ROTATION). Use the rotation angle to simply define the direction of the X axis on the tilted working plane. Please note:
  - Input range: 0° to 360.0000°
  - The 0° axis is the X axis
- ▶ Continue with the positioning properties  
**Further Information:** "Specifying the positioning behavior of the PLANE function", page 501





#### NC block

```
5 PLANE EULER EULPR45 EULNU20 EULROT22 .....
```

## The PLANE function: Tilting the working plane (software option 8) 12.2

### Abbreviations used

Abbreviation	Meaning
EULER	Swiss mathematician who defined these angles
EULPR	<b>P</b> recession angle: angle describing the rotation of the coordinate system around the Z axis
EULNU	<b>N</b> utation angle: angle describing the rotation of the coordinate system around the X axis shifted by the precession angle
EULROT	<b>R</b> otation angle: angle describing the rotation of the tilted machining plane around the tilted Z axis



## 12.2 The PLANE function: Tilting the working plane (software option 8)

### Defining the working plane with two vectors: PLANE VECTOR

#### Application

You can use the definition of a working plane via **two vectors** if your CAD system can calculate the base vector and normal vector of the tilted machining plane. A normalized input is not necessary. The TNC calculates the normal, so you can enter values between -9.999999 and +9.999999.

The base vector required for the definition of the machining plane is defined by the components **BX, BY** and **BZ**. The normal vector is defined by the components **NX, NY** and **NZ**.



#### Before programming, note the following

The TNC calculates standardized vectors from the values you enter.

Parameter description for the positioning behavior.


**Further Information:** "Specifying the positioning behavior of the PLANE function", page 501



The base vector defines the direction of the principal axis in the tilted machining plane, and the normal vector determines the orientation of the tilted machining plane, and at the same time is perpendicular to it.

Depending on the setting of the machine tool builder, the control either outputs an error message if the vectors are not perpendicular, or it automatically compensates the vectors.


Refer to your machine manual.








## The PLANE function: Tilting the working plane (software option 8) 12.2

### Input parameters



- ▶ **X component of base vector?:** X component **BX** of the base vector B; input range: from -9.9999999 to +9.9999999
  - ▶ **Y component of base vector?:** Y component **BY** of the base vector B; input range: from -9.9999999 to +9.9999999
  - ▶ **Z component of base vector?:** Z component **BZ** of the base vector B; input range: from -9.9999999 to +9.9999999
  - ▶ **X component of normal vector?:** X component **NX** of the normal vector N; input range: from -9.9999999 to +9.9999999
  - ▶ **Y component of normal vector?:** Y component **NY** of the normal vector N; input range: from -9.9999999 to +9.9999999
  - ▶ **Z component of normal vector?:** Z component **NZ** of the normal vector N; input range: from -9.9999999 to +9.9999999
  - ▶ Continue with the positioning properties
- Further Information:** "Specifying the positioning behavior of the PLANE function", page 501



### NC block

```
5 PLANE VECTOR BX0.8 BY-0.4 BZ-0.42 NX0.2 NY0.2 NZ0.92 ..
```

### Abbreviations used

Abbreviation	Meaning
VECTOR	Vector
BX, BY, BZ	Basis vector: <b>X</b> , <b>Y</b> and <b>Z</b> components
NX, NY, NZ	Normal vector: <b>X</b> , <b>Y</b> and <b>Z</b> components

## 12.2 The PLANE function: Tilting the working plane (software option 8)

## Defining the working plane via three points: PLANE POINTS

## Application

A working plane can be uniquely defined by entering **any three points P1 to P3 in this plane**. This possibility is realized in the **PLANE POINTS** function.

**Before programming, note the following**


The connection from Point 1 to Point 2 determines the direction of the tilted main axis (X for tool axis Z).

The direction of the tilted tool axis is determined by the position of Point 3 relative to the connecting line between Point 1 and Point 2. Use the right-hand rule (thumb = X axis, index finger = Y axis, middle finger = Z axis) to remember: thumb (X axis) points from Point 1 to Point 2, index finger (Y axis) points parallel to the tilted Y axis in the direction of Point 3. Then the middle finger points in the direction of the tilted tool axis.

The three points define the slope of the plane. The position of the active datum is not changed by the TNC.


Parameter description for the positioning behavior.

**Further Information:** "Specifying the positioning behavior of the PLANE function", page 501






## The PLANE function: Tilting the working plane (software option 8) 12.2

### Input parameters



- ▶ **X coordinate of 1st plane point?:** X coordinate **P1X** of the 1st plane point
- ▶ **Y coordinate of 1st plane point?:** Y coordinate **P1Y** of the 1st plane point
- ▶ **Z coordinate of 1st plane point:** Z coordinate **P1Z** of the 1st plane point
- ▶ **X coordinate of 2nd plane point?:** X coordinate **P2X** of the 2nd. plane point
- ▶ **Y coordinate of 2nd plane point?:** Y coordinate **P2Y** of the 2nd plane point
- ▶ **Z coordinate of 2nd plane point?:** Z coordinate **P2Z** of the 2nd plane point
- ▶ **X coordinate of 3rd plane point?:** X coordinate **P3X** of the 3rd plane point
- ▶ **Y coordinate of 3rd plane point?:** Y coordinate **P3Y** of the 3rd plane point
- ▶ **Z coordinate of 3rd plane point?:** Z coordinate **P3Z** of the 3rd plane point
- ▶ Continue with the positioning properties  
**Further Information:** "Specifying the positioning behavior of the PLANE function", page 501



### NC block

```
5 PLANE POINTS P1X+0 P1Y+0 P1Z+20 P2X+30 P2Y+31 P2Z+20 P3X
+0 P3Y+41 P3Z+32.5 .....
```

### Abbreviations used

Abbreviation	Meaning
--------------	---------

POINTS	Points
--------	--------

## Multiple axis machining

### 12.2 The PLANE function: Tilting the working plane (software option 8)

#### Defining the working plane via a single incremental spatial angle: PLANE RELATIV

##### Application

Use a relative spatial angle when an already active tilted working plane is to be tilted by **another rotation**. Example: machining a 45° chamfer on a tilted plane.



##### Before programming, note the following

The defined angle is always in effect in respect to the active working plane, regardless of the function you have used to activate it.


You can program any number of **PLANE RELATIV** functions in a row.

If you want to return to the working plane that was active before the **PLANE RELATIV** function, define the same **PLANE RELATIV** function again but with the opposite algebraic sign.


If you use the **PLANE RELATIV** function in a non-tilted working plane, then you simply rotate the non-tilted plane about the spatial angle defined in the **PLANE** function.

Parameter description for the positioning behavior.

**Further Information:** "Specifying the positioning behavior of the PLANE function", page 501




##### Input parameters



- ▶ **Incremental angle?:** Spatial angle by which the active machining plane is to be rotated. Use a soft key to select the axis to be rotated around. Input range: -359.9999° to +359.9999°
- ▶ Continue with the positioning properties  
**Further Information:** "Specifying the positioning behavior of the PLANE function", page 501

##### Abbreviations used

Abbreviation	Meaning
RELATIV	Relative to



##### NC block

```
5 PLANE RELATIV SPB-45 .....
```

## The PLANE function: Tilting the working plane (software option 8) 12.2

### Tilting the working plane through axis angle: PLANE AXIAL

#### Application

The **PLANE AXIAL** function defines both the position of the working plane and the nominal coordinates of the rotary axes. This function is particularly easy to use on machines with Cartesian coordinates and with kinematics structures in which only one rotary axis is active.



**PLANE AXIAL** can also be used if you have only one rotary axis active on your machine.

You can use the **PLANE RELATIVE** function after **PLANE AXIAL** if your machine allows spatial angle definitions. Refer to your machine manual.



#### Before programming, note the following

Enter only axis angles that actually exist on your machine. Otherwise the TNC generates an error message.


Rotary axis coordinates defined with **PLANE AXIAL** are modally effective. Successive definitions therefore build on each other. Incremental input is allowed.

Use **PLANE RESET** to reset the **PLANE AXIAL** function. Resetting by entering 0 does not deactivate **PLANE AXIAL**.

**SEQ**, **TABLE ROT** and **COORD ROT** have no function in conjunction with **PLANE AXIAL**.

Parameter description for the positioning behavior.

**Further Information:** "Specifying the positioning behavior of the PLANE function", page 501




## Multiple axis machining

### 12.2 The PLANE function: Tilting the working plane (software option 8)

#### Input parameters



- ▶ **Axis angle A?**: Axis angle **to which** the A axis is to be tilted. If entered incrementally, it is the angle **by which** the A axis is to be tilted from its current position. Input range:  $-99999.9999^\circ$  to  $+99999.9999^\circ$
  - ▶ **Axis angle B?**: Axis angle **to which** the B axis is to be tilted. If entered incrementally, it is the angle **by which** the B axis is to be tilted from its current position. Input range:  $-99999.9999^\circ$  to  $+99999.9999^\circ$
  - ▶ **Axis angle C?**: Axis angle **to which** the C axis is to be tilted. If entered incrementally, it is the angle **by which** the C axis is to be tilted from its current position. Input range:  $-99999.9999^\circ$  to  $+99999.9999^\circ$
  - ▶ Continue with the positioning properties
- Further Information:** "Specifying the positioning behavior of the PLANE function", page 501



#### NC block

5 PLANE AXIAL B-45 .....

#### Abbreviations used

Abbreviation	Meaning
AXIAL	In the axial direction



## The PLANE function: Tilting the working plane (software option 8) 12.2

### Specifying the positioning behavior of the PLANE function

#### Overview

Independently of which PLANE function you use to define the tilted machining plane, the following functions are always available for the positioning behavior:

- Automatic positioning
- Selection of alternate tilting possibilities (not with **PLANE AXIAL**)
- Selection of the type of transformation (not with **PLANE AXIAL**)



#### Danger of collision!

If you work with Cycle **8 MIRRORING** in a tilted system, please note the following:

If you program mirroring before the tilting of the working plane, the mirroring also effects the tilting. Exception: Tilting with Cycle 19 and **AXIAL PLANE**.

Mirroring a rotary axis with Cycle **8** only mirrors the motions of the axis, but not the angles defined in the PLANE functions. As a result, the positioning of the axes changes.

#### Automatic positioning: MOVE/TURN/STAY (entry is mandatory)


After you have entered all parameters for the plane definition, you must specify how the rotary axes will be positioned to the calculated axis values:

- |  |   |
|--|---|
| <div style="border: 1px solid black; padding: 2px; text-align: center; width: fit-content;">MOVE</div> | <ul style="list-style-type: none"> <li>▶ The PLANE function is to automatically position the rotary axes to the calculated position values. The position of the tool relative to the workpiece is to remain the same. The TNC carries out a compensation movement in the linear axes</li> </ul> |
| <div style="border: 1px solid black; padding: 2px; text-align: center; width: fit-content;">TURN</div> | <ul style="list-style-type: none"> <li>▶ The PLANE function is to automatically position the rotary axes to the calculated position values, but only the rotary axes are positioned. The TNC does <b>not</b> carry out a compensation movement on the linear axes</li> </ul>                    |
| <div style="border: 1px solid black; padding: 2px; text-align: center; width: fit-content;">STAY</div> | <ul style="list-style-type: none"> <li>▶ You will position the rotary axes later in a separate positioning block</li> </ul>   |

If you have selected the **MOVE** option (PLANE function is to position the axes automatically), the following two parameters must still be defined: **Dist. tool tip - center of rot.** and **Feed rate? F =**.

If you have selected the option **TURN** (PLANE function is to position the axes automatically), the following parameter must still be defined **Feed rate? F =**.

As an alternative to defining a feed rate **F** directly by numerical value, you can also position with **FMAX** (rapid traverse) or **FAUTO** (feed rate from the **TOOL CALLT** block).



If you use **PLANE** together with **STAY**, you have to position the rotary axes in a separate block after the **PLANE** function.




## 12.2 The PLANE function: Tilting the working plane (software option 8)

- **Dist. tool tip - center of rot.** (incremental): The TNC tilts the tool (or table) relative to the tool tip. The **DIST** parameter shifts the center of rotation of the positioning movement relative to the current position of the tool tip.

**Note:**

- If the tool is already at the given distance to the workpiece before positioning, then relatively speaking the tool is at the same position after positioning (see figure at center right, **1** = DIST)
- If the tool is not at the given distance to the workpiece before positioning, then relatively speaking the tool is offset from the original position after positioning (see figure at bottom right, **1** = DIST)

- **Feed rate? F=:** Contour speed at which the tool should be positioned
- **Retraction length in the tool axis?:** Retraction path **MB** is effective incrementally from the current tool position in the active tool axis direction that the TNC approaches **before tilting**. **MB MAX** positions the tool just before the software limit switch.





## The PLANE function: Tilting the working plane (software option 8) 12.2

### Positioning the rotary axes in a separate block

Proceed as follows if you want to position the rotary axes in a separate positioning block (option **STAY** selected):



#### **Danger of collision!**

Pre-position the tool to a position where there is no danger of collision with the workpiece (clamping devices) during positioning.

Do not program mirroring of the rotary axis between the PLANE function and the positioning, otherwise the control positions to the mirrored values but the PLANE function calculates without mirroring.

- ▶ Select any **PLANE** function, and define automatic positioning with the **STAY** option. During program execution the TNC calculates the position values of the rotary axes present on the machine, and stores them in the system parameters Q120 (A axis), Q121 (B axis) and Q122 (C axis)
- ▶ Define the positioning block with the angular values calculated by the TNC

### NC example blocks: Position a machine with a rotary table C and a tilting table A to a space angle of B+45°

...	
12 L Z+250 R0 FMAX	Position at clearance height
13 PLANE SPATIAL SPA+0 SPB+45 SPC+0 STAY	Define and activate the PLANE function
14 L A+Q120 C+Q122 F2000	Position the rotary axis with the values calculated by the TNC
...	Define machining in the tilted working plane

## Multiple axismachining

### 12.2 The PLANE function: Tilting the working plane (software option 8)

#### Selection of alternate tilting possibilities: SEQ +/- (entry optional)

The position you define for the working plane is used by the TNC to calculate the appropriate positioning of the rotary axes present on the machine. In general there are always two solution possibilities.

Use the **SEQ** switch to specify which possibility the TNC should use:

- **SEQ+** positions the master axis so that it assumes a positive angle. The master axis is the first rotary axis going out from the tool or the last rotary axis going out from the table (depending on the machine configuration)
- **SEQ-** positions the master axis so that it assumes a negative angle.


If the solution you chose with **SEQ** is not within the machine's range of traverse, the TNC displays the **Entered angle not permitted** error message.



When the **PLANE AXIAL** function is used, the **SEQ** switch is nonfunctional.

If you do not define **SEQ**, the TNC determines the solution as follows:

- 1 The TNC first checks whether both solution possibilities are within the traverse range of the rotary axes.
- 2 If they are, then the TNC selects the shortest possible solution based on the current position of the rotary axes.
- 3 If only one solution is within the traverse range, the TNC selects this solution
- 4 If neither solution is within the traverse range, the TNC displays the **Entered angle not permitted** error message.



## The PLANE function: Tilting the working plane (software option 8) 12.2

**Example for a machine with a rotary table C and a tilting table**

**A. Programmed function: PLANE SPATIAL SPA+0 SPB+45 SPC+0**

Limit switch	Starting position	SEQ	Resulting axis position
None	A+0, C+0	not prog.	A+45, C+90
None	A+0, C+0	+	A+45, C+90
None	A+0, C+0	–	A–45, C–90
None	A+0, C–105	not prog.	A–45, C–90
None	A+0, C–105	+	A+45, C+90
None	A+0, C–105	–	A–45, C–90
$-90 < A < +10$	A+0, C+0	not prog.	A–45, C–90
$-90 < A < +10$	A+0, C+0	+	Error message
None	A+0, C–135	+	A+45, C+90

### Selecting the type of transformation (entry optional)

The transformation types **COORD ROT** and **TABLE ROT** influence the orientation of the working plane coordinate system through the axis position of a so-called free rotary axis.


Any rotary axis becomes a free rotary axis with the following constellation:

- the rotary axis has no effect on the tool angle of inclination because the rotation axis and tool axis are parallel in the tilting situation
- the rotary axis is the first rotary axis in the kinematic chain starting from the workpiece

The effect of the transformation types **COORD ROT** and **TABLE ROT** therefore depends on the programmed spatial angles and the machine kinematics.



- If no free rotary axis is created in a tilting situation, the **COORD ROT** and **TABLE ROT** transformation types have no effect
- With the **PLANE AXIAL** function the **COORD ROT** and **TABLE ROT** transformation types have no effect



## 12.2 The PLANE function: Tilting the working plane (software option 8)


## Effect with a free rotary axis



- For the positioning behaviour with the **COORD ROT** and **TABLE ROT** transformation types, it does not matter if the free rotary axis is in the table or the head
- The resulting axis position of the free rotary axis depends on an active basic rotation among other factors
- The orientation of the working plane coordinate system also depends on a programmed rotation, for example with Cycle 10 **ROTATION**

## Soft key

## Effect

**COORD ROT:**

- > The control positions the free rotary axis to 0
- > The control aligns the working plane coordinate system according to the programmed spatial angle

**TABLE ROT** with:

- SPA and SPB equal to 0
- SPC equal or unequal to 0
- > The control aligns the free rotary axis according to the programmed spatial angle
- > The control aligns the working plane coordinate system according to the basic coordinate system

**TABLE ROT** with:

- At least SPA or SPB unequal to 0
- SPC equal or unequal to 0
- > The control does not position the free rotary axis. The position before tilting the working plane is maintained
- > Because the workpiece was not positioned, the control aligns the working plane coordinate system according to the programmed spatial angle



If no transformation type was specified, the control uses **COORD ROT** transformation for the PLANE functions

## The PLANE function: Tilting the working plane (software option 8) 12.2

### Example with a free axis


The example below shows the effect of the **TABLE ROT** transformation type in conjunction with a free rotary axis.

...	
<b>6 L B+45 R0 FMAX</b>	Pre-position rotary axis
<b>7 PLANE SPATIAL SPA-90 SPB+20 SPC+0 TURN F5000 TABLE ROT</b>	Tilt working plane
...	

Origin

A = 0, B = 45

A = -90, B = 45



- > The control positions the B axis to the axis angle B+45
- > With the programmed tilting situation with SPA-90, the B axis becomes the free rotary axis
- > The control does not position the free rotary axis. The position of the B axis before tilting the working plane is maintained
- > Because the workpiece was not positioned, the control aligns the working plane coordinate system according to the programmed spatial angle SPB+20

## 12.2 The PLANE function: Tilting the working plane (software option 8)

## Tilt the working plane without rotary axes



Refer to your machine manual. This feature must be enabled and adapted by the machine tool builder.

The machine tool builder must take into account e.g. the precise angle of a mounted angular head in the kinematics description.

You can also align the programmed working plane perpendicular to the tool without rotary axes, e.g. for adapting the working plane for a mounted angular head.

Use the **PLANE SPATIAL** function and the **STAY** positioning behavior to swivel the working plane to the angle specified by the machine tool builder.

Example of mounted angular head with permanent tool direction Y:

## NC syntax

```
TOOL CALL 5 Z S4500
```

```
PLANE SPATIAL SPA+0 SPB-90 SPC+0 STAY
```



The swivel angle must be precisely adapted to the tool angle, otherwise the TNC outputs an error message.

## 12.3 Inclined-tool machining in a tilted plane (option 9)

### Function


In combination with **M128** and the new **PLANE** functions, **inclined-tool machining** on a tilted machining plane is now possible. Two possibilities are available for definition:

- Inclined-tool machining via incremental traverse of a rotary axis
- Inclined-tool machining via normal vectors



Inclined-tool machining in a tilted machining plane only functions with spherical cutters. With 45° swivel heads and tilting tables you can also define the incline angle as a spatial angle. Use the **TCPM FUNCTION**.

**Further Information:** "FUNCTION TCPM (option 9)", page 519



### Inclined-tool machining via incremental traverse of a rotary axis

- ▶ Retract the tool
- ▶ Define any PLANE function; consider the positioning behavior
- ▶ Activate M128
- ▶ Via a straight-line block, traverse to the desired incline angle in the appropriate axis incrementally

#### Example NC blocks

...	
12 L Z+50 R0 FMAX	Position at clearance height
13 PLANE SPATIAL SPA+0 SPB-45 SPC+0 MOVE DIST50 F1000	Define and activate the PLANE function
14 M128	Activate M128
15 L IB-17 F1000	Set the incline angle
...	Define machining in the tilted working plane

## Multiple axis machining

### 12.3 Inclined-tool machining in a tilted plane (option 9)

#### Inclined-tool machining via normal vectors



Only one directional vector can be defined in the **LN** block. This vector defines the incline angle (normal vector **NX**, **NY**, **NZ** or tool directional vector **TX**, **TY**, **TZ**).

- ▶ Retract the tool
- ▶ Define any PLANE function; consider the positioning behavior
- ▶ Activate M128
- ▶ Execute program with LN blocks in which the tool direction is defined by a vector

#### Example NC blocks

...	
12 L Z+50 R0 FMAX	Position at clearance height
13 PLANE SPATIAL SPA+0 SPB+45 SPC+0 MOVE DIST50 F1000	Define and activate the PLANE function
14 M128	Activate M128
15 LN X+31.737 Y+21,954 Z+33,165 NX+0,3 NY+0 NZ +0,9539 F1000 M3	Set the incline angle with the normal vector
...	Define machining in the tilted working plane



## 12.4 Miscellaneous functions for rotary axes

### Feed rate in mm/min on rotary axes A, B, C: M116 (option 8)

#### Standard behavior

The TNC interprets the programmed feed rate of a rotary axis in degrees/min (in mm programs and also in inch programs). The feed rate therefore depends on the distance from the tool center to the center of the rotary axis.

The larger this distance becomes, the greater the contouring feed rate.

#### Feed rate in mm/min on rotary axes with M116



The machine geometry must be specified by the machine tool builder in the description of kinematics.

M116 works only on rotary tables. M116 cannot be used with swivel heads. If your machine is equipped with a table/head combination, the TNC ignores the swivel-head rotary axes.

**M116** is also effective in an active tilted working plane and in combination with M128 if you used the **M138** function to select rotary axes.

**Further Information:** "Selecting tilting axes: M138", page 517

Then **M116** affects only those rotary axes that were selected with **M138**.

The TNC interprets the programmed feed rate of a rotary axis in mm/min (or 1/10 inch/min). In this case, the TNC calculates the feed for the block at the start of each block. With a rotary axis, the feed rate is not changed during execution of the block even if the tool moves toward the center of the rotary axis.

#### Effect

M116 is effective in the working plane. Reset M116 with M117. At the end of the program, M116 is also ineffective.

M116 becomes effective at the start of block.

## Multiple axis machining

### 12.4 Miscellaneous functions for rotary axes

#### Shortest-path traverse of rotary axes: M126

##### Standard behavior



The behavior of the TNC when positioning the rotary axes depends on the machine tool. Refer to your machine manual.

The standard behavior of the TNC while positioning rotary axes whose display has been reduced to values less than  $360^\circ$  is dependent on machine parameter **shortestDistance**(no. 300401). This machine parameter defines whether the TNC should consider the difference between nominal and actual position, or whether it should always (even without M126) choose the shortest path to the programmed position. Examples:

Actual position	Nominal position	Traverse
$350^\circ$	$10^\circ$	$-340^\circ$
$10^\circ$	$340^\circ$	$+330^\circ$

##### Behavior with M126

With M126, the TNC will move the axis on the shorter path of traverse for rotary axes whose display is reduced to values less than  $360^\circ$ . Examples:

Actual position	Nominal position	Traverse
$350^\circ$	$10^\circ$	$+20^\circ$
$10^\circ$	$340^\circ$	$-30^\circ$

##### Effect

M126 becomes effective at the start of block.

To cancel M126, enter M127. At the end of program, M126 is automatically canceled.

## Reducing display of a rotary axis to a value less than 360°: M94

### Standard behavior

The TNC moves the tool from the current angular value to the programmed angular value.

### Example:

Current angular value:	538°
Programmed angular value:	180°
Actual distance of traverse:	-358°

### Behavior with M94

At the start of block, the TNC first reduces the current angular value to a value less than 360° and then moves the tool to the programmed value. If several rotary axes are active, M94 will reduce the display of all rotary axes. As an alternative you can enter a rotary axis after M94. The TNC then reduces the display only of this axis.

### Example NC blocks

To reduce display of all active rotary axes:

```
L M94
```

To reduce display of the C axis only:

```
L M94 C
```

To reduce display of all active rotary axes and then move the tool in the C axis to the programmed value:

```
L C+180 FMAX M94
```

### Effect

M94 is effective only in the NC block in which it is programmed. M94 becomes effective at the start of block.

### Maintaining the position of the tool tip when positioning with tilted axes (TCPM): M128 (option 9)

#### Standard behavior

If the inclination angle of the tool changes this results in an offset of the tool tip compared to the nominal position. The control does not compensate this offset. If the operator does not take this deviation into account in the NC program, offset machining is executed.

#### Behavior with M128 (TCPM: Tool Center Point Management)

If the position of a controlled tilted axis changes in the program, the position of the tool tip in relation to the workpiece remains the same during the tilting process.



#### Caution: Danger to the workpiece!

For tilted axes with Hirth coupling: Do not change the position of the tilted axis until after retracting the tool. Otherwise you might damage the contour when disengaging from the coupling.

After **M128** you can program another feed rate, at which the TNC will carry out the compensation movements in the linear axes.

If you want to change the position of the tilting axis with the handwheel during the program run, use **M128** along with **M118**. Superimposing handwheel positioning is implemented with active **M128**, depending on the setting in the 3D-ROT menu of the **Manual operation** operating mode, in the active coordinate system or in the untilted coordinate system.



The functions **TCPM** or **M128** in conjunction with the dynamic collision monitoring **M118** are not available.




Before positioning with **M91** or **M92** and before a **TOOL CALL**, **RESET M128**.

To avoid contour gouging you must use only radius cutters with **M128**.

The tool length must refer to the spherical center of the tool tip.

If **M128** is active, the TNC shows the TCPM symbol in the status display.



**M128 on tilting tables**

If you program a tilting table movement while **M128** is active, the TNC rotates the coordinate system accordingly. If, for example, you rotate the C axis by 90° (through a positioning command or datum shift) and then program a movement in the X axis, the TNC executes the movement in the machine axis Y.

The TNC also transforms the set datum, which has been shifted by the movement of the rotary table.

**M128 with 3-D tool compensation**

If you carry out a three-dimensional tool compensation with active **M128** and active radius compensation **RL/RR**, the TNC will automatically position the rotary axes for certain machine geometrical configurations (peripheral milling).

**Further Information:** "Three-dimensional tool compensation (option 9)", page 523

**Effect**

**M128** becomes effective at the start of the block, **M129** at the end of the block. **M128** is also effective in the manual operating modes and remains active even after a change of mode. The feed rate for the compensation movement will be effective until you program a new feed rate or until you cancel **M128** with **M129**.

Enter **M129** to cancel **M128**. The TNC also cancels **M128** if you select a new program in a program run operating mode.

**Example NC blocks**

Feed rate of 1000 mm/min for compensation movements:

```
L X+0 Y+38.5 IB-15 RL F125 M128 F1000
```

## Multiple axis machining

### 12.4 Miscellaneous functions for rotary axes

#### Inclined machining with noncontrolled rotary axes

If you have noncontrolled rotary axes (counting axes) on your machine, then in combination with M128 you can also perform inclined machining operations with these axes.

- 1 Manually traverse the rotary axes to the desired positions.  
M128 must not be active!
- 2 Activate M128: The TNC reads the actual values of all rotary axes present, calculates from this the new position of the tool center point, and updates the position display
- 3 The TNC performs the necessary compensating movement in the next positioning block
- 4 Carry out the machining operation
- 5 At the end of the program, reset M128 with M129, and return the rotary axes to their initial positions

Proceed as follows:



As long as M128 is active, the TNC monitors the actual positions of the noncontrolled rotary axes. If the actual position deviates from the nominal position by a value greater than that defined by the machine manufacturer, the TNC outputs an error message and interrupts program run.

## Selecting tilting axes: M138

### Standard behavior

The TNC performs M128, TCPM, and tilts the working plane, only in those axes for which the machine tool builder has set the appropriate machine parameters.

### Behavior with M138

The TNC performs the above functions only in those tilting axes that you have defined using M138.



If you restrict the number of tilting axes with the **M138** function, your machine may provide only limited tilting possibilities. When calculating the axis angle in the selected axis, the control sets the value 0.

### Effect

M138 becomes effective at the start of the block.

You can reset M138 by reprogramming it without entering any axes.

### Example NC blocks

Perform the above-mentioned functions only in the tilting axis C:

```
L Z+100 R0 FMAX M138 C
```

## Multiple axis machining

### 12.4 Miscellaneous functions for rotary axes

#### Compensating the machine kinematics in ACTUAL/ NOMINAL positions at end of block: M144 (option 9)

##### Standard behavior

If the kinematics change, e.g. by inserting a spindle attachment or entering an inclination angle, the control does not compensate this modification. If the operator does not take this modification to the kinematics into account in the NC program, offset machining is executed.

##### Behavior with M144

The **M144** function enables the control to consider the modification to the machine kinematics in the position display and compensate the offset of the tool tip in relation to the workpiece.



Positioning blocks with M91/M92 are permitted if M144 is active.

The position display in the operating modes **Program run full sequence** and **Program run single block** does not change until the tilting axes have reached their final position

##### Effect

M144 becomes effective at the start of the block. M144 does not function in connection with M128 or a tilted working plane.

You can cancel M144 by programming M145.



The machine geometry must be specified by the machine tool builder in the description of kinematics.

The machine tool builder determines the behavior in the automatic and manual operating modes. Refer to your machine manual.



## 12.5 FUNCTION TCPM (option 9)

### Function



The machine geometry must be specified by the machine tool builder in the description of kinematics.

**TCPM FUNCTION** is an improvement on the **M128** function, with which you can define the behavior of the TNC when positioning the rotary axes. In contrast to **M128**, with **TCPM FUNCTION** you can define the mode of action of various functions:

- Mode of action of the programmed feed rate: **F TCP/F CONT**
- Interpretation of the rotary axis coordinates programmed in the NC program: **AXIS POS/AXIS SPAT**
- Type of interpolation between start and target position: **PATHCTRL AXIS / PATHCTRL VECTOR**

If **TCPM FUNCTION** is active, the TNC shows the symbol **TCPM** in the position display.




#### For tilted axes with Hirth coupling:

Only change the position of the tilted axis after retracting the tool. Otherwise you might damage the contour when disengaging from the coupling.



Before positioning with **M91** or **M92** and before a **TOOL CALL**: Reset **TCPM FUNCTION**.

To avoid contour gouging, use only radius cutters if possible. Pay attention to possible contour gouging if working with **FUNCTION TCPM** in conjunction with other tool shapes.



### Defining the TCPM FUNCTION

SPEC  
FCT

- ▶ Select the special functions

PROGRAM  
FUNCTIONS

- ▶ Select the programming aids

FUNCTION  
TCPM

- ▶ Select the **TCPM FUNCTION**

## Multiple axis machining

### 12.5 FUNCTION TCPM (option 9)

#### Mode of action of the programmed feed rate

The TNC provides two functions for defining the mode of action of the programmed feed rate:

- |              |  |
|--------------|--|
| F<br>TCP     | ▶ <b>F TCP</b> determines that the programmed feed rate is interpreted as the actual relative velocity between the tool tip ( <b>tool center point</b> ) and the workpiece |
| F<br>CONTOUR | ▶ <b>F CONT</b> determines that the programmed feed rate is interpreted as the contouring feed rate of the axis programmed in the respective NC block.                     |

#### Example NC blocks

...	
13 FUNCTION TCPM F TCP ...	Feed rate refers to the tool tip
14 FUNCTION TCPM F CONT ...	Feed rate is interpreted as the speed of the tool along the contour
...	

#### Interpretation of the programmed rotary axis coordinates

Up to now, machines with 45° swivel heads or 45° tilting tables could not easily set the angle of inclination or a tool orientation with respect to the currently active coordinate system (spatial angle). This function could only be realized through specially written programs with normal vectors (LN blocks).

The TNC now provides the following function:

- |                  |   |
|------------------|---|
| AXIS<br>POSITION | ▶ <b>AXIS POS</b> determines that the TNC interprets the programmed coordinates of rotary axes as the nominal position of the respective axis |
| AXIS<br>SPATIAL  | ▶ <b>AXIS SPAT</b> determines that the TNC interprets the programmed coordinates of rotary axes as the spatial angle                          |



**AXIS POS** should be used primarily if your machine is equipped with Cartesian rotary axes. You can also use **AXIS POS** with 45°-swivel heads/ tilting tables if it is ensured that the programmed rotary axis coordinates define the desired orientation of the working plane correctly (this can be accomplished with a CAM system, for example).

**AXIS SPAT**: The rotary axis coordinates entered in the positioning block are space angles that are given with respect to the currently active (perhaps tilted) coordinate system (incremental spatial angle). After you switch on **FUNCTION TCPM** with **AXIS SPAT**, in the first positioning block you should always program all three spatial angles in the inclination angle definition. This also applies if one or more spatial angles are 0°.

## Type of interpolation between the starting and end position

The TNC provides two functions for defining the type of interpolation between the starting and end position:

PATH  
CONTROL  
AXIS

- ▶ **PATHCTRL AXIS** determines that the tool tip between the starting and end position of the respective NC block moves on a straight line (**Face Milling**). The direction of the tool axis at the starting and end positions corresponds to the respective programmed values, but the tool circumference does not describe a defined path between the starting and end positions. The surface produced by milling with the tool circumference (**Peripheral Milling**) depends on the machine geometry

PATH  
CONTROL  
VECTOR

- ▶ **PATHCTRL VECTOR** determines that the tool tip between the starting and end position of the respective NC block moves on a straight line and also that the direction of the tool axis between starting and end position is interpolated so that a plane results from machining at the tool circumference (**Peripheral Milling**)



### With PATHCTRL VECTOR, remember:

Any defined tool orientation is generally accessible through two different tilting angle positions. The TNC uses the solution over the shortest available path—starting from the current position.

To attain the most continuous multi-axis movement possible, Cycle 32 should be defined with a **tolerance for rotary axes**.

**Further information:** Cycle Programming User's Manual

The tolerance of the rotary axes should be about the same as the tolerance of the contouring deviation that is also defined in Cycle 32. The greater the tolerance for the rotary axes is defined, the greater the contour deviations that occur during peripheral milling.

## Example NC blocks

...	
13 FUNCTION TCPM F TCP AXIS SPAT PATHCTRL AXIS	Tool tip moves along a straight line
14 FUNCTION TCPM F TCP AXIS POS PATHCTRL VECTOR	Tool tip and tool directional vector move in one plane
...	

## Multiple axismachining

### 12.5 FUNCTION TCPM (option 9)

#### Resetting the TCPM FUNCTION



- **FUNCTION RESET TCPM** is to be used if you want to purposely reset the function within a program.

The TNC automatically resets **TCPM FUNCTION** if you select a new program in a program run mode.  
 You can reset the **TCPM FUNCTION** only if the **PLANE** function is inactive. If required, run **PLANE RESET** before **FUNCTION RESET TCPM**.

#### Example NC blocks

...	
25 FUNCTION RESETTCPM	Reset TCPM FUNCTION
...	

## 12.6 Three-dimensional tool compensation (option 9)

### Introduction


The TNC can carry out a three-dimensional tool compensation (3-D compensation) for straight-line blocks. Apart from the X, Y and Z coordinates of the straight-line end point, these blocks must also contain the components NX, NY and NZ of the surface-normal vector.

**Further Information:** "Definition of a normalized vector", page 525

If you want to carry out a tool orientation, these blocks also require a normalized vector with the components TX, TY and TZ that determines the tool orientation,

**Further Information:** "Definition of a normalized vector", page 525

The straight-line end point, the components for the surface normals as well as those for the tool orientation must be calculated by a CAM system.



### Possible applications

- Use of tools with dimensions that do not correspond with the dimensions calculated by the CAM system (3-D compensation without definition of the tool orientation).
- Face milling: compensation of the cutter geometry in the direction of the surface-normal vector (3-D compensation with and without definition of the tool orientation). Cutting is usually with the end face of the tool.
- Peripheral milling: compensation of the cutter radius perpendicular to the direction of movement and perpendicular to the tool direction (3D radius compensation with definition of the tool orientation). Cutting is usually with the lateral surface of the tool.

## 12.6 Three-dimensional tool compensation (option 9)

**Suppressing error messages with positive tool  
oversize: M107****Standard behavior**

With positive tool compensation, programmed contours may be damaged. The control checks whether critical oversizes are created due to tool compensation, and if so, outputs an error message.

With Peripheral Milling the control triggers an error message in the following case:

- $DR_{Tab} + DR_{Prog} > 0$

With Face Milling the control triggers an error message in the following case:

- $DR_{Tab} + DR_{Prog} > 0$
- $R2 + DR2_{Tab} + DR2_{Prog} > R + DR_{Tab} + DR_{Prog}$
- $R2 + DR2_{Tab} + DR2_{Prog} < 0$
- $DR2_{Tab} + DR2_{Prog} > 0$

**Behavior with M107**

With M107 the control suppresses the error message.

**Effect**

M107 takes effect at the end of block.

You can reset M107 with M108.

### Definition of a normalized vector

A normalized vector is a mathematical quantity with a value of 1 and any direction. The TNC requires up to two normalized vectors for LN blocks, one to determine the direction of the surface-normal vector, and another (optional) to determine the tool orientation direction. The direction of a surface-normal vector is determined by the components NX, NY and NZ. With an end mill and radius cutter, this direction is perpendicular from the workpiece surface to be machined to the tool datum PT, and goes through PT' or PT in the case of a toroid cutter (see figure). The direction of tool orientation is determined by the components TX, TY and TZ.



The coordinates for the X, Y, Z positions and the surface-normal components NX, NY, NZ, as well as TX, TY, TZ must be in the same sequence in the NC block.

Always indicate all of the coordinates and all of the surface-normal vectors in an LN block, even if the values have not changed from the previous block.

TX, TY and TZ must always be defined with numerical values. You cannot use Q parameters.

Calculate the normal vectors as exactly as possible and output them with a sufficient number of decimal places, in order to avoid interruptions in the feed rate during machining.


3-D compensation with surface-normal vectors is only effective for coordinates in the main axes X, Y, Z.

If you insert a tool with an oversize (positive delta value), the TNC outputs an error message. You can suppress the error message with the M function **M107**.

**Further Information:** "Definition of a normalized vector", page 525

The TNC will not display an error message if an entered tool oversize would cause damage to the contour.

The **toolRefPoint** (no. 201302) machine parameter defines whether the CAM system has calculated the tool length compensation from the center of sphere PT or the south pole of the sphere PSP (see figure).



## 12.6 Three-dimensional tool compensation (option 9)

## Permissible tool shapes

You can describe the permissible tool shapes in the tool table via tool radii **R** and **R2**:

- Tool radius **R**: Distance from the tool center to the tool circumference
- Tool radius 2 **R2**: Radius of the curvature between the tool tip and tool circumference

The ratio of **R** to **R2** fundamentally determines the shape of the tool:

- **R2** = 0: End mill
- **R2** = **R**: Radius cutter
- $0 < \mathbf{R2} < \mathbf{R}$ : Toroid cutter

These data also provide the coordinates of the tool datum PT.

## Using other tools: Delta values

If you want to use tools that have different dimensions than the ones you originally programmed, you can enter the difference between the tool lengths and radii as delta values in the tool table or **TOOL CALL**:


- Positive delta value **DL**, **DR**: The tool is larger than the original tool (oversize)
- Negative delta value **DL**, **DR**: The tool is smaller than the original tool (undersize)

The TNC then compensates the tool position by the sum of the delta values from the tool table and the tool call.

With **DR 2** you modify the rounding radius of the tool and therefore also the tool shape.

If you work with **DR 2** the following applies:

- $R2 + DR2_{Tab} + DR2_{Prog} = \text{End mill}$
- $0 < R2 + DR2_{Tab} + DR2_{Prog} < R$ : Toroid cutter
- $R2 + DR2_{Tab} + DR2_{Prog} = R$ : Radius cutter






### 3-D compensation without TCPM

The TNC carries out a 3-D compensation for three-dimensional machining operations if the NC program contains surface-normal vectors. In this case, the **RL/RR** radius compensation and **TCPM** or **M128** must be inactive. The TNC displaces the tool in the direction of the surface-normal vectors by the sum of the delta values (tool table and **TOOL CALL**).

#### Example: Block format with surface-normal vectors

```
1 LN X+31.737 Y+21.954 Z+33.165NX+0.2637581 NY+0.0078922
  NZ-0.8764339 F1000 M3
```

<b>LN:</b>	Straight line with 3-D compensation
<b>X, Y, Z:</b>	Compensated coordinates of the straight-line end point
<b>NX, NY, NZ:</b>	Components of the surface-normal vector
<b>F:</b>	Feed rate
<b>M:</b>	Miscellaneous function



## 12.6 Three-dimensional tool compensation (option 9)


## Face milling: 3-D compensation with TCPM

Face milling is a machining operation carried out with the front face of the tool. If the NC program contains surface-normal vectors and **TCPM** or **M128** is active, 3-D compensation is executed with 5-axis machining. Radius compensation **RL/RR** must not be active in this case. The TNC displaces the tool in the direction of the surface-normal vectors by the sum of the delta values (tool table and **TOOL CALL**).

If tool orientation was not defined in the **LN** block, the control maintains the tool perpendicular to the workpiece contour with active **TCPM**.

**Further Information:** "Maintaining the position of the tool tip when positioning with tilted axes (TCPM): M128 (option 9)", page 514

If there is a tool orientation **T** defined in the **LN** block and **M128** (or **TCPM FUNCTION**) is active at the same time, then the TNC will position the rotary axes automatically so that the tool can reach the defined orientation. If you have not activated **M128** (or **TCPM FUNCTION**), then the TNC ignores the direction vector **T**, even if it is defined in the **LN** block.



The TNC is not able to automatically position the rotary axes on all machines. Refer to your machine manual.

**Danger of collision!**

On machines whose rotary axes only allow limited traverse, sometimes automatic positioning can require the table to be rotated by 180°. In this case, make sure that the tool head does not collide with the workpiece or the clamps.

**Example: Block format with surface normals without tool orientation**

```
LN X+31.737 Y+21.954 Z+33.165 NX+0.2637581 NY+0.0078922
  NZ-0.8764339 F1000 M128
```

**Example: Block format with surface normals and tool orientation**

```
LN X+31.737 Y+21.954 Z+33.165 NX+0.2637581 NY+0.0078922
  NZ-0.8764339 TX+0.0078922 TY-0.8764339 TZ+0.2590319
  F1000 M128
```

<b>LN:</b>	Straight line with 3-D compensation
<b>X, Y, Z:</b>	Compensated coordinates of the straight-line end point
<b>NX, NY, NZ:</b>	Components of the surface-normal vector
<b>TX, TY, TZ:</b>	Components of the normalized vector for workpiece orientation
<b>F:</b>	Feed rate
<b>M:</b>	Miscellaneous function


## Three-dimensional tool compensation (option 9) 12.6

### Peripheral milling: 3-D radius compensation with TCPM and radius compensation (RL/RR)

The TNC displaces the tool perpendicular to the direction of movement and perpendicular to the tool direction by the sum of the delta values **DR** (tool table and **TOOL CALL**). Determine the compensation direction with radius compensation **RL/RR** (see figure, direction of movement Y+). For the TNC to be able to reach the set tool orientation, you need to activate the **M128** function.

**Further Information:** "Maintaining the position of the tool tip when positioning with tilted axes (TCPM): M128 (option 9)", page 514

The TNC then positions the rotary axes automatically so that the tool can reach the defined orientation with the active compensation.



This function is possible only on machines for which you can define spatial angles for the tilting axis configuration. Refer to your machine manual.

The TNC is not able to automatically position the rotary axes on all machines.

Refer to your machine manual.

Note that the TNC makes a compensating movement by the defined **delta values**. The tool radius R defined in the tool table has no effect on the compensation.



#### **Danger of collision!**

On machines whose rotary axes only allow limited traverse, sometimes automatic positioning can require the table to be rotated by 180°. In this case, make sure that the tool head does not collide with the workpiece or the clamps.

There are two ways to define the tool orientation:

- In an LN block with the components TX, TY and TZ
- In an L block by indicating the coordinates of the rotary axes

## Multiple axismachining

### 12.6 Three-dimensional tool compensation (option 9)

#### Example: Block format with tool orientation

```
1 LN X+31.737 Y+21.954 Z+33.165 TX+0.0078922 TY-0.8764339
  TZ+0.2590319 RR F1000 M128
```

<b>LN:</b>	Straight line with 3-D compensation
<b>X, Y, Z:</b>	Compensated coordinates of the straight-line end point
<b>TX, TY, TZ:</b>	Components of the normalized vector for workpiece orientation
<b>RR:</b>	Tool radius compensation
<b>F:</b>	Feed rate
<b>M:</b>	Miscellaneous function

#### Example: Block format with rotary axes

```
1 L X+31.737 Y+21.954 Z+33.165 B+12.357 C+5.896 RL F1000
  M128
```

<b>L:</b>	Straight line
<b>X, Y, Z:</b>	Compensated coordinates of the straight-line end point
<b>B, C:</b>	Coordinates of the rotary axes for tool orientation
<b>RL:</b>	Radius Compensation
<b>F:</b>	Feed rate
<b>M:</b>	Miscellaneous function

### 3-D radius compensation depending on the tool's contact angle (option 92)

#### Application

The effective sphere radius of a radius cutter deviates from the ideal form owing to the production process. The maximum form inaccuracy is defined by the machine tool builder. Common deviations lie between 0.005 mm and 0.01 mm.

The form inaccuracy can be saved in the form of a compensation value table. This table contains angle values and the deviation from the nominal radius  $R2$  measured on the respective angle value.

The **3D-ToolComp** software option (option 92) enables the control to compensate the value defined in the compensation value table depending on the actual contact point of the tool.

3-D calibration of the touch probe can also be carried out with the **3D-ToolComp** software option. During this process the deviations determined during touch probe calibration are saved to the compensation value table.

**Further Information:** "3-D calibration with a calibration sphere (option 92)", page 623

#### Requirements

To be able to use the software option **3D-ToolComp** (option 92) the control requires the following preconditions:

- Option 9 is enabled
- Option 92 is enabled
- The **DR2TABLE** column in the TOOL.T tool table is enabled
- The name of the compensation value table (without its extension) is entered in the **DR2TABLE** column for the tool to be compensated
- 0 is entered in the **DR2** column
- NC program with surface normal vectors (LN blocks)

#### Compensation value table

If you create the compensation value table yourself, proceed as follows:

- PGM  
MGT


NEW  
FILE

- ▶ In the file manager open the path **TNC:\system\3D-ToolComp**
  - ▶ Press the **NEW FILE** soft key
  - ▶ Enter the file name with extension **.3DTC**
  - ▶ The control opens a table containing the required columns for a compensation value table.

The compensation value table contains three columns:

- **NR**: Consecutive line number
- **ANGLE**: Measured angle in degrees
- **DR2**: Radius deviation from the nominal value

The control evaluates a maximum of 100 lines in the compensation value table.



## 12.6 Three-dimensional tool compensation (option 9)

## Function

If you are executing a program with surface normal vectors and assigned a compensation value table (DR2TABLE column) to the active tool in the tool table (TOOL.T), the TNC uses the values from the compensation value table instead of the compensation value DR2 from TOOL.T.

In doing so, the control takes the compensation value from the compensation value table defined for the current contact point of the tool with workpiece into account. If the contact point is between two compensation points, the control interpolates the compensation value linearly between the two closest angles.


Angle value	Compensation value
40°	0.03 mm (measured)
50°	-0.02 mm (measured)
45° (contact point)	+0.005 mm (interpolated)



The control generates an error message if it cannot determine a compensation value through interpolation.

Programming of **M107** (suppress error message for positive compensation values) is not required even if the compensation value is positive.

The TNC uses either DR2 from TOOL.T or a compensation value from the compensation value table. If required, you can define additional offsets, such as a surface oversize, via DR2 in the **TOOL CALL** block.



## NC program

The software option **3D-ToolComp** (option 92) only functions with NC programs containing surface normal vectors.

Pay attention when creating the CAM program how you measure the tools:

- NC program output at the south pole of the sphere requires tools measured on the tool tip
- NC program output at the center of the sphere requires tools measured on the tool center


## 12.7 Running CAM programs

If you create NC programs externally using a CAM system, you should pay attention to the recommendations detailed below. This will enable you to optimally use the powerful path control of the TNC, and as a rule create better workpiece surfaces with shorter machining times. Despite high machining speeds, the TNC still achieves very high contour accuracy. The basis for this is the real-time operating system HeROS 5 in conjunction with the **ADP** (Advanced Dynamic Prediction) function of the TNC 640. This enables the TNC to also efficiently process NC programs with high point densities.

### From 3-D model to NC program

Here is a simplified description of the process for creating an NC program from a CAD model:

- ▶ **CAD: Model creation**  
Construction departments prepare a 3-D model of the workpiece to be machined. Ideally the 3-D model is designed for the center of tolerance.
- ▶ **CAM: Path generation, tool compensation**  
The CAM programmer specifies the machining strategies for the areas of the workpiece to be machined. The CAM system uses the surfaces of the CAD model to calculate the paths of the tool movements. These tool paths consist of individual points calculated by the CAM system so that each surface to be machined is approximated as nearly as possible while considering chord errors and tolerances. This way, a machine-neutral NC program is created, known as a CLDATA file (cutter location data). A post processor generates a machine- and control-specific NC program, which can be processed by the CNC control. The post processor is adapted according to the machine tool and the control. The post processor is the link between the CAM system and the CNC control.
- ▶ **TNC: Motion control, tolerance monitoring, velocity profile**  
The TNC uses the points defined in the NC program to calculate the motions of each machine axes as well as the required velocity profiles. Powerful filter functions then process and smooth the contour so that the TNC does not exceed the maximum permissible path deviation.
- ▶ **Mechatronics: Feed control, drive technology, machine tool**  
The motions and velocity profiles calculated by the TNC are realized as actual movements of the tool by the machine's drive system.



**Consider with processor configuration**

**Take the following points into account with post processor configuration:**

- Always set the data output for axis positions to at least four decimal places. This way you improve the quality of the NC data and avoid rounding errors, which can result in defects visible to the naked eye on the workpiece surface. Output to five decimal places (option 23) may achieve improved surface quality for optical components and components with very large radii (i.e. small curvatures), for example forms for the automotive industry.
- Always set the data output for the machining of surface normal vectors (LN blocks, only Klartext conversational programming) to exactly seven decimal places
- Set the tolerance in Cycle 32 so that in standard behavior it is at least twice as large as the chord error defined in the CAM system. Also note the information in the functional description for Cycle 32.
- If the chord error selected in the CAM program is too large, then, depending on the respective curvature of a contour, large distances between NC blocks can result, each with large changes of direction. During machining this leads to drops in the feed rate at the block transitions. Recurring and equal accelerations (i.e. force excitation), caused by feed-rate drops in the heterogeneous NC program, can lead to undesirable excitation of vibrations in the machine structure.
- You can also use arc blocks instead of linear blocks to connect the path points calculated by the CAM system. The TNC internally calculates circles more exactly than can be defined via the input format
- Do not output any intermediate points on exactly straight lines. Intermediate points that are not exactly on a straight line can result in defects visible to the naked eye on the workpiece surface
- There should be exactly one NC data point at curvature transitions (corners)
- Avoid sequences of many short block paths. Short paths between blocks are generated in the CAM system when there are large curvature transitions with very small chord errors in effect. Exactly straight lines do not require such short block paths, which are often forced by the continuous output of points from the CAM system
- Avoid a perfectly even distribution of points over surfaces with a uniform curvature, since this could result in patterns on the workpiece surface
- For 5-axis simultaneous programs: avoid the duplicated output of positions if they only differ in the tool's angle of inclination
- Avoid the output of the feed rate in every NC block. This would negatively influence the TNC's velocity profile



**Useful configurations for the machine tool operator:**

- In order to improve the structure of large NC programs, use the TNC's structuring function  
**Further Information:** "Structuring programs", page 177
- Use the TNC's commenting function in order to document NC programs  
**Further Information:** "Adding comments", page 174
- Use the comprehensive cycles of the TNC available for the machining of drill holes and simple pocket geometries: See the Cycle Programming User's Manual
- For fits, output the contours with **RL/RR** tool radius compensation. This makes it easy for the machine operator to make necessary compensations  
**Further Information:** "Tool compensation", page 227
- Separate feed rates for pre-positioning, machining, and downfeeds, and define them via Q parameters at the beginning of the program

**NC example blocks with variable feed-rate definitions**

1 Q50 = 7500 ; POSITION FEED RATE
2 Q51 = 750 ; FEED RATE FOR PLUNGING
3 Q52 = 1350 ; FEED RATE FOR MILLING
...
25 L Z+250 R0 FMAX
26 L X+235 Y-25 FQ50
27 L Z+35
28 L Z+33.2571 FQ51
29 L X+321.7562 Y-24.9573 Z+33.3978 FQ52
30 L X+320.8251 Y-24.4338 Z+33.8311
...

### Please note the following for CAM programming

#### Adapting chord errors



When defining finishing operations, make sure that the chord error defined in the CAM system is not set to greater than 5  $\mu\text{m}$ . In Cycle 32, use the appropriate tolerance factor **T** of 1.3 to 5.

When defining roughing operations, make sure that the sum of the chord error and the tolerance from Cycle 32 is less than the defined machining oversize. This ensures that no contour gouging will occur.

Adapt the chord error in the CAM program, depending on the machining:

#### ■ Roughing with preference for speed:

Use higher values for the chord error and the appropriate tolerance in Cycle 32. Both values depend on the oversize required on the contour. If a special cycle is available on your machine, use the roughing mode. In roughing mode the machine generally moves with high jerk values and high accelerations

- Normal tolerance in Cycle 32: Between 0.05 mm and 0.3 mm
- Normal chord error in the CAM system: Between 0.004 mm and 0.030 mm

#### ■ Finishing with preference for high accuracy:


Use smaller values for the chord error and an appropriately low tolerance in Cycle 32. The data density must be high enough for the TNC to detect transitions and corners exactly. If a special cycle is available on your machine, use the finishing mode. In finishing mode the machine generally moves with low jerk values and low accelerations

- Normal tolerance in Cycle 32: Between 0.002 mm and 0.006 mm
- Normal chord error in the CAM system: Between 0.001 mm and 0.004 mm

#### ■ Finishing with preference for high surface quality:

Use small values for the chord error and an appropriately larger tolerance in Cycle 32. The TNC then smooths the contour more exactly. If a special cycle is available on your machine, use the finishing mode. In finishing mode the machine generally moves with low jerk values and low accelerations

- Normal tolerance in Cycle 32: Between 0.010 mm and 0.020 mm
- Normal chord error in the CAM system: Smaller than 0.005 mm



### Further adaptations

Take the following points into account with CAM programming:

- For slow machining feed rates or contours with large radii, define the chord error to be only one-third to one-fifth of the tolerance **T** in Cycle 32. Additionally, define the maximum permissible point spacing to be between 0.25 mm and 0.5 mm. The geometry error or model error should also be specified to be very small (max. 1 µm).
- Even at higher machining feed rates, point spacings of greater than 2.5 mm are not recommended for curved contour areas
- For straight contour elements, one NC point at the beginning of a line and one NC point at the end suffice. Avoid the output of intermediate positions
- In programs with five axes moving simultaneously, avoid large changes in the ratio of path lengths in linear and rotational blocks. Otherwise large reductions in the feed rate could result at the tool reference point (TCP)
- The feed-rate limitation for compensating movements (e.g. via **M128 F...**) should be used only in exceptional cases. The feed-rate limitation for compensating movements can cause large reductions in the feed rate at the tool reference point (TCP).
- NC programs for 5-axis simultaneous machining with spherical cutters should preferably be output for the center of the sphere. The NC data are then generally more consistent. Additionally, in Cycle 32 you can set a higher rotational axis tolerance **TA** (e.g. between 1° and 3°) for an even more constant feed-rate curve at the tool reference point (TCP).
- For NC programs for 5-axis simultaneous machining with toroid cutters or radius cutters where the NC output is for the south pole of the sphere, choose a lower rotational axis tolerance. 0.1° is a typical value. However, the maximum permissible contour damage is the decisive factor for the rotational axis tolerance. This contour damage depends on the possible tool tilting, tool radius and contact depth of the tool.

With 5-axis gear hobbing with an end mill you can calculate the maximum possible contour damage **T** directly from the cutter contact length **L** and permissible contour tolerance **TA**:

$$T \sim K \times L \times TA \quad K = 0.0175 [1/^\circ]$$

Example:  $L = 10 \text{ mm}$ ,  $TA = 0.1^\circ$ :  $T = 0.0175 \text{ mm}$

## Multiple axismachining

### 12.7 Running CAM programs

#### Possibilities for intervention on the control

Cycle 32 **TOLERANCE** is available for the influencing of CAM programs directly on the TNC. Also note the information in the functional description for Cycle 32. Also note the interactions with the chord error defined in the CAM system.

**Further information:** Cycle Programing User's Manual



Refer to your machine manual.

Some machine tool builders provide an additional cycle for adapting the behavior of the machine to the respective machining operation, such as Cycle 332 Tuning. Cycle 332 can be used to modify filter settings, acceleration settings, and jerk settings.

#### NC example blocks, Cycle 32

```
34 CYCL DEF 32.0 TOLERANCE
```

```
35 CYCL DEF 32.1 T0.05
```

```
36 CYCL DEF 32.2 HSC MODE:1 TA3
```

#### ADP motion control



Refer to your machine manual.

This feature must be enabled and adapted by the machine tool builder.

An insufficient quality of data in NC programs created on CAM systems frequently causes inferior surface quality of the milled workpieces. The **ADP** (Advanced Dynamic Prediction) feature expands the conventional look-ahead of the permissible maximum feed rate profile and optimizes the motion control of the feed axes during milling. This enables clean surfaces with short machining times to be cut, even with a strongly fluctuating distribution of points in adjacent tool paths. This significantly reduces or eliminates the reworking complexity.

These are the most important benefits of ADP:

- Symmetrical feed-rate behavior on forward and backward paths with bidirectional milling
- Uniform feed rate curves with adjacent cutter paths
- Improved reaction to negative effects (e.g. short, step-like stages, coarse chord tolerances, heavily rounded block end-point coordinates) in NC programs generated by CAM system
- Precise compliance to dynamic characteristics even in difficult conditions

# 13

**Pallet management**

### 13.1 Pallet management

### 13.1 Pallet management

## Application



Pallet table management is a machine-dependent function. The standard functional range is described below.

Refer to your machine manual.

Pallet tables (**.P**) are mainly used in machining centers with pallet changers. The pallet tables call the different pallets with the corresponding machining programs and activate all defined datums and datum tables.


Without a pallet changer you can use pallet tables to process NC programs with different datums in sequence with just one press of **NC START**.




















If you want to create or manage pallet tables, the name of the file must begin with a letter.

Pallet tables contain the following information:

- **NR:** The control produces the entry automatically when new rows are added. The entry is required for the entry field **Line number** = of the **BLOCK SCAN** function.
- **TYPE:** Input is obligatory. The control differentiates between the entries Pallet **PAL**, fixture **FIX** or NC program **PGM**. Select the entries using the **ENT** key and arrow keys.
- **NAME:** Entry is obligatory. The machine tool builder specifies the names for pallets and fixtures (observe the machine manual), whereas you define program names. You must specify the complete paths if the files are not saved in the directory of the pallet table.
- **DATUM:** This entry is only required if datum tables are used. You must specify the complete paths if the files are not saved in the directory of the pallet table. You activate datums from the datum tables in the NC program using Cycle 7.
- **PRESET:** This entry is only required if different reference points are used. Enter the required preset numbers.
- **LOCATION:** Entry is obligatory. The entry "**MA**" indicates that the machine is loaded with a pallet or fixture that can be machined. The TNC only machines pallets or fixtures identified by "**MA**". Press the **ENT** key to enter **MA**. Press the **NO ENT** key to remove the entry.
- **LOCK:** This entry is optional. Using an **\*** you can exclude the row of the pallet table from processing. Press the **ENT** key to identify the row with the entry **\***. Press the **NO ENT** key to cancel the lock. You can lock the execution for individual programs, fixtures or entire pallets. Unlocked lines (e.g. PGM) in a locked pallet are also not executed.



Soft key	= Editing function
	Select the table start
	Select the table end
	Select the previous page in the table
	Select the next page in the table
	Insert as last line in the table
	Delete the last line in the table
	Add the number of lines that can be entered at the end of the table
	Copy the current value
	Insert the copied value
	Select start of row
	Select end of row
	Search for text or value
	Sort or hide table columns
	Edit the current field
	Sort by column content
	Miscellaneous functions, e.g. saving
	Open dialog for file path selection

## Pallet management

### 13.1 Pallet management

#### Selecting pallet table

- ▶ Select file manager in **Programming** mode or the Program Run operating modes: Press the **PGM MGT** key
- ▶ Display type .P files: Press the **SELECT TYPE** soft key and **SHOW ALL** soft key
- ▶ Select a pallet table with the arrow keys, or enter a new file name to create a new table
- ▶ Confirm your entry with the **ENT** key



Use the screen layout key to switch between table view and list view

#### Exit pallet table

- ▶ To call the file manager, press the **PGM MGT** key
- ▶ To select a different type of file, press the **SELECT TYPE** soft key and the soft key for the desired file type, e.g. **SHOW .H**
- ▶ Select the desired file

#### Processing pallet table



MP7683 defines whether the pallet table is to be executed blockwise or continuously.



- ▶ In the **Program run, full sequence** or **Program run, single block** operating mode, select the file manager: Press the **PGM MGT** key
- ▶ Display all type .P files: Press the **SELECT TYPE** and **SHOW .P** soft keys
- ▶ Select a pallet table with the arrow keys
- ▶ Press the **ENT** key
- ▶ Execute the pallet table: Press the **NC START** key



### Screen layout when working in the pallet table

If you want to see the program content and the content of the pallet table at the same time, select the screen layout **PALLET + PROGRAM**. During execution, the TNC then shows program blocks to the left and the pallet to the right. To check the program contents before execution, proceed as follows:

- ▶ Select pallet table
- ▶ With the arrow keys, choose the program you would like to check
- ▶ Press the **OPEN THE PROGRAM** soft key
- ▶ The TNC displays the selected program on the screen. You can now page through the program with the arrow keys
- ▶ Press the **END PGM PAL** soft key
- ▶ The control returns to the pallet table



### Editing pallet tables

If the pallet table is active in a program run operating mode, the soft keys for modifying the table in the **Programming** operating mode are inactive. You can modify this table with the **EDIT PALLET** soft key in the **Program run, single block** or **Program run, full sequence** operating mode.

### Block scan in a pallet table

With the pallet management you can also use the **BLOCK SCAN** function in conjunction with pallet tables.

If you interrupt the processing of pallet tables, the control always suggests the previously selected NC block of the interrupted NC program for the **BLOCK SCAN** function.

**Further Information:** "Block scan in pallet programs", page 691



# 14

**Turning**

## 14.1 Turning operations on milling machines (option 50)

### 14.1 Turning operations on milling machines (option 50)

#### Introduction

Special types of milling machines allow performing both milling and drilling operations. A workpiece can thus be machined completely on one machine without rechucking, even if complex milling and turning applications are required.

Turning operations are machining processes by which workpieces are rotated, thus implementing the cutting movements. A fixed tool carries out infeed and feed movements. Turning applications, depending on machining direction and task, are subdivided into various production processes, e.g. longitudinal turning, face turning, groove turning or thread turning.



The TNC offers you several cycles for each of the various production processes.

**Further information:** Cycle Programming User's Manual

On the TNC you can simply switch between Milling and Turning mode within the NC program. In Turning mode, the rotary table serves as turning spindle, whereas the milling spindle with the tool is fixed. This enables rotationally symmetric contours to be created. The preset must be in the center of the turning spindle.

With the management of turning tools, other geometric descriptions are considered than with milling or drilling tools. To be able to execute tool radius compensation, for example, you have to define the tool radius. The TNC provides special tool management for turning tools to support this definition process.



**Further Information:** "Tool data", page 559

Different cycles are available for machining. These can also be used with additional swivel axes.

**Further Information:** "Inclined turning", page 574

The assignment of the axes with turning is defined so that the X coordinates describe the diameter of the workpiece and the Z coordinates the longitudinal positions.

Programming is thus always done on the XZ coordinate plane. The machine axes to be used for the required movements depend on the respective machine kinematics and are determined by the machine manufacturer. This makes NC programs with turning functions largely exchangeable and independent of the machine model.



## 14.2 Basic functions (option 50)

### Switching between milling/turning mode of operation



Switching the machine kinematics is a machine-specific function.

The machine has to have been adapted by the machine manufacturer for turning operations and switching the mode of operation. Refer to your machine manual.

To switch between milling and turning operations you must switch to the specific mode.

You can switch these operating modes with the NC functions **FUNCTION MODE TURN** and **FUNCTION MODE MILL**.

The TNC shows a symbol in the status display when the turning mode is active

Icon	Mode of operation
	Turning mode active: <b>FUNCTION MODE TURN</b>
No symbol	Milling mode active: <b>FUNCTION MODE MILL</b>

When the operating modes are toggled the TNC executes a macro that defines the machine-specific settings for the specific operating mode. With the NC functions **FUNCTION MODE TURN** and **FUNCTION MODE MILL** you can activate a machine kinematic model that the machine manufacturer has defined and saved in the macro.



The preset must be in the center of the turning spindle in turning mode.

The position of the tool tip must be aligned to the center of the turning spindle. Position the Y coordinates in Turning mode to the center of the turning spindle.

Check the orientation of the tool spindle. The tool tip must be aligned to the center of the turning spindle for outside machining. For inside machining, the tool must be aligned opposite to the center of the turning spindle.

Check whether the rotation direction of the turning spindle is correct for the loaded tool.

If you process heavy workpieces with high speeds then high physical forces occur. Ensure that the workpiece is firmly clamped to avoid accidents or machine damage.

## 14.2 Basic functions (option 50)



In Turning mode, diameter values are displayed on the X axis position display. The TNC then shows a diameter symbol on the position display.

In turning mode, the spindle potentiometer is active for the turning spindle (rotary table).

You cannot switch over the machining mode if tilting of the machining plane or TCPM is active.

In Turning mode, no coordinate conversions are permitted except for the datum shift cycle.

You can also use all manual touch probe cycles, except the corner probing cycle and plane probing cycle, in Turning mode. Please note that in Turning mode all measured values in the X coordinate are calculated and displayed as diameter values.


You can also use the smartSelect function to define the turning functions.

**Further Information:** "Overview of special functions", page 428


Entering the operation mode:




- Show the soft-key row with special functions




- Press the **TURNING PROGRAM FUNCTIONS** soft key



- Press the **BASIC FUNCTIONS** soft key



- Press the **FUNCTION MODE** soft key



- Function for machining mode: Press the **TURNING** or **MILLING** soft key

If the machine tool builder has enabled kinematics selection, proceed as follows:



- Enter " quotation marks
- Press the **SELECT KINEMATICS** soft key

## NC syntax

11 FUNCTION MODE TURN "AC\_TABLE" ; ACTIVATE TURNING MODE

12 FUNCTION MODE TURN ; ACTIVATE TURNING MODE


13 FUNCTION MODE MILL "B\_HEAD" ; ACTIVATE MILLING MODE

### Graphic display of turning operations

You can simulate turning operations in **Test Run** mode. The requirement for this is a workpiece blank definition suitable for the turning process and option number 20.



The machining times shown for milling/turning operations in the simulation do not correspond to the actual machining times.




### Graphic display in the Programming mode of operation

You can graphically simulate turning processes with the line graphic in **Programming** mode. To display the traverse movements in turning mode in **Programming** mode, change the layout using the soft keys.

**Further Information:** "Generating a graphic for an existing program", page 186

The standard assignment of the axes with turning is defined so that the X coordinates describe the diameter of the workpiece and the Z coordinates the longitudinal positions.

Even when turning occurs in a 2D plane (X and Z coordinates), with a rectangular workpiece blank you must still program the Y values when defining the workpiece blank.



### NC syntax

<b>0 BEGIN PGM SHOULDER MM</b>	
<b>1 BLK FORM 0.1Y X+0 Y-1 Z-50</b>	Workpiece blank definition
<b>2 BLK FORM 0.2 X+87 Y+1 Z+2</b>	
<b>3 TOOL CALL 12</b>	Tool call
<b>4 M140 MB MAX</b>	Retract the tool
<b>5 FUNCTION MODE TURN</b>	Activate Turning mode

## 14.2 Basic functions (option 50)

### Program spindle speed



If you machine at constant cutting speed, the selected gear range limits the possible spindle speed range. The possible gear ranges (if applicable) depend on your machine.


With turning you can machine both at constant spindle speed and constant cutting speed.

If you machine at constant cutting speed **VCONST:ON**, the TNC modifies speed according to the distance of the tool tip to the center of the turning spindle. The TNC increases table speed with positioning in the direction of the turning center and reduces speed with movements away from the turning center.

For processing with constant spindle speed **VCONST:OFF**, speed is independent of the tool position.

Use **FUNCTION TURNDATA SPIN** to define the speed. The TNC provides the following entry parameters:

- VCONST: Constant cutting speed on/off (obligatory)
- VC: Cutting speed (optional)
- S: Nominal speed if no constant cutting speed is active (optional)
- S MAX: Maximum speed with constant cutting speed (optional). Reset with S MAX 0
- gearrange: Gear range for the turning spindle (optional)





Defining the speed:

- SPEC  
FCT

- ▶ Show the soft-key row with special functions
- TURNING  
PROGRAM  
FUNCTIONS

- ▶ Press the **TURNING PROGRAM FUNCTIONS** soft key
- FUNCTION  
TURNDATA

- ▶ Press the **FUNCTION TURNDATA** soft key
- TURNDATA  
SPIN

- ▶ Press the **TURNDATA SPIN** soft key.
- VCONST:  
ON

- ▶ Select the function for speed entry: Press the **VCONST:** soft key

➡

Cycle 800 limits maximum speed with eccentric turning. To reset, program **FUNCTION TURNDATA SPIN SMAX0**.

If the maximum speed is achieved the control displays **SMAX** instead of **S** in the status display.

NC syntax

3 FUNCTION TURNDATA SPIN VCONST:ON VC:100 GEARRANGE:2	Definition of a constant cutting speed in gear range 2
3 FUNCTION TURNDATA SPIN VCONST:OFF S550	Definition of a constant spindle speed
...	

## 14.2 Basic functions (option 50)

## Feed rate


With turning, feed rates are often specified in millimeters per revolution. The TNC moves the tool according to a defined value for each spindle revolution. The resulting contouring feed rate is thus dependent on the speed of the turning spindle. With high speeds the TNC increases the feed rate and with low speeds reduces the feed rate. With uniform cutting depth you can machine with constant cutting force to achieve a constant cut thickness.



The machine parameter **facMinFeedTurnSMAX** (no. 201009) enables you to enter a minimum feed rate maintained at maximum speed.

The programmed feed rate on a TNC is by default always interpreted in millimeters per minute (mm/min). If you wish to define feed rate in millimeters per revolution (mm/1), you must program **M136**. The TNC then interprets all subsequent feed rate specifications in mm/1 until **M136** is canceled.

**M136** is effective modally at the beginning of the block and can be canceled with **M137**.



## NC syntax

<b>10 L X+102 Z+2 R0 FMAX</b>	Movement at rapid traverse
...	
<b>15 L Z-10 F200</b>	Movement at a feed rate of 200 mm/min
...	
<b>19 M136</b>	Feed rate in millimeters per revolution
<b>20 L X+154 F0.2</b>	Movement at a feed rate of 0.2 mm/1
...	

## 14.3 Unbalance functions (option 50)


### Unbalance while turning

#### General information



The machine has to have been adapted by the machine manufacturer for monitoring and measuring unbalance. Unbalance functions are not required on all machine tool types. These functions may not be available on your machine. Refer to your machine manual.

The unbalance functions described here are basic functions that are set up and adapted to the machine by the machine manufacturer. The scope and effect of the described functions may therefore vary from machine to machine. The machine manufacturer may also provide different unbalance functions. Refer to your machine manual.



In a turning operation, the tool is in a fixed position, whereas the rotary table and the clamped workpiece rotate. Depending on the size of the workpiece, the mass that is set in rotation can be very large. As the workpiece rotates, it creates an outward centrifugal force.

The centrifugal force that occurs basically depends on the rotational speed, the mass and the unbalance of the workpiece. An imbalance occurs when a body whose mass is not evenly distributed in terms of a symmetrical rotation is brought into a circular motion. If the mass object is rotating, this creates outward-acting centrifugal forces. If the rotating mass is evenly distributed, the centrifugal forces cancel each other out.

The unbalance is significantly influenced by the structural shape of the workpiece (e.g. an asymmetric pump housing) and by the clamping devices. Because these conditions can often not be changed, compensate any existing unbalance by clamping a balancing weight. The TNC provides the **MEASURE UNBALANCE** cycle for this purpose. The cycle determines the existing unbalance and calculates the mass and position of the required balancing mass.

In the NC program, Cycle 892 **CHECK IMBALANCE** checks whether the entered parameters are exceeded.

### 14.3 Unbalance functions (option 50)



The rotation of the workpiece creates centrifugal forces that can cause vibration (resonance), depending on the unbalance. This vibration has a negative effect on the machining process and reduces the tool life. High centrifugal forces can damage the machine or push the workpiece out of the fixture.

Check the unbalance whenever you clamp a new workpiece. If required, use balancing weights to compensate any imbalance.

The removal of material during machining will change the mass distribution within the workpiece. This may also have an influence on workpiece unbalance. Therefore, unbalance checks should also be carried out between machining steps.

Keep in mind the mass and unbalance of the workpiece when choosing the speed. Do not use high speeds with heavy workpieces or high unbalance loads.

#### Unbalance Monitor function

The Unbalance Monitor function monitors the unbalance of a workpiece in Turning mode. If a maximum unbalance limit specified by the machine manufacturer is exceeded, the TNC issues an error message and initiates an emergency stop. In addition, you can further decrease the permissible unbalance limit by setting the optional machine parameter **limitUnbalanceUsr**(no. 120101). If this limit is exceeded, the TNC issues an error message. Table rotation is not interrupted in this case. The TNC automatically activates the Unbalance Monitor function when you switch to Turning mode. The unbalance monitor is effective until you switch back to Milling mode.



**Further information:** Cycle Programming User's Manual

## Measure Unbalance cycle



This cycle can only be run in turning mode. Activate **FUNCTION MODE TURN** beforehand.


To ensure maximum safety and minimum strain on the machine and workpiece during turning, you should check the unbalance of the clamped workpiece and compensate it with a balancing weight. The TNC provides the **MEASURE UNBALANCE** cycle for this purpose.

The **MEASURE UNBALANCE** cycle determines the unbalance of the workpiece and calculates the mass and position of a balancing mass.


Determine the unbalance:




- ▶ Shift the soft-key row in the Manual Operation mode




- ▶ Press the **MANUAL CYCLES** soft key



- ▶ Press the **TURNING** soft key



- ▶ Press the **MEASURE UNBALANCE** soft key
- ▶ Enter the speed for unbalance detection
- ▶ Press NC start
- ▶ The cycle starts rotating the table at a low speed and gradually increases the speed up to the defined value. The TNC displays a window that shows the calculated mass and radial position of the balancing mass.



If you wish to use a different radial position or mass for the balancing mass, you can overwrite one value and have the other value recalculated automatically.



Repeat the unbalance measurement after you have clamped a balancing weight.

In some cases, you may need to place two or more balancing weights at different positions in order to compensate unbalance.

# 14

## Turning

### 14.3 Unbalance functions (option 50)

#### Calibrate unbalance cycle



Only use the **CALIBRATE UNBALANCE** cycle if agreed with the machine tool builder.  
Refer to your machine manual.

The unbalance calibration is performed by the machine tool builder before shipping the machine. With unbalance calibration, the rotary table is operated at various speeds with a defined weight mounted at a defined radial position. The measurement is repeated with different weights.

## 14.4 Tools in turning mode (option 50)

### Tool call

Just as in Milling mode, turning tools are called with the **TOOL CALL** function. You merely have to enter the tool number or tool name in the **TOOL CALL** block.



You can call and insert a turning tool both in Milling mode and in Turning mode.

### Tool selection in the pop-up window

If you open a pop-up window for tool selection, the TNC marks all tools available in the tool magazine green.

In addition to the tool number and tool name, the control also shows the **ZL** and **XL** columns from the turning tool table.

### NC syntax

<b>1 FUNCTION MODE TURN</b>	Turning mode selection
<b>2TOOL CALL "TRN_ROUGH"</b>	Tool call
...	

## 14.4 Tools in turning mode (option 50)

### Tool compensation in the program

With **FUNCTION TURNDATA CORR** you can define additional compensation values for the active tool. In the **TURNDATA CORR FUNCTION** you can enter delta values for tool lengths in the X direction **DXL** and in the Z direction **DZL**. The compensation values have an additive effect on the compensation values from the turning tool table.

With recessing tools, use the **FUNCTION TURNDATA CORR-TCS** function to compensate the recessing width with **DCW**.

**FUNCTION TURNDATA CORR** is always effective for the active tool. A renewed **TOOL CALL** deactivates compensation again. When you exit the program (e.g. PGM MGT), the TNC automatically resets the compensation values.

When you enter the **TURNDATA CORR FUNCTION** you can specify the effect of the tool compensation with a soft key:

- **FUNCTION TURNDATA CORR-TCS**: The tool compensation is effective in the tool coordinate system
- **FUNCTION TURNDATA CORR-WPL**: The tool compensation is effective in the workpiece coordinate system



Tool compensation **FUNCTION TURNDATA CORR-TCS** is always effective in the tool coordinate system, even during inclined machining.

Define the tool compensation:

SPEC  
FCT

- ▶ Show the soft-key row with special functions

TURNING  
PROGRAM  
FUNCTIONS

- ▶ Press the **TURNING PROGRAM FUNCTIONS** soft key

FUNCTION  
TURNDATA

- ▶ Press the **FUNCTION TURNDATA** soft key

TURNDATA  
CORR

- ▶ Press the **TURNDATA CORR** soft key.

### NC syntax

```
21 FUNCTION TURNDATA CORR-TCS:Z/X DZL:0.1 DXL:0.05*
```

```
...
```



## Tools in turning mode (option 50) 14.4

## Tool data

You define turning-specific tool data in the turning tool table **TOOLTURN.TRN**.

The tool number saved in column **T** refers to the number of the turning tool in TOOL.T. Geometry values such as **L** and **R** from the TOOL.T are not effective with turning tools.

The tool length stored in the column **ZL** is saved by the control in the Q parameter Q114.

In addition you must identify turning tools in the tool table TOOL.T as turning tools. For this, in column TYP select the tool type **TURN** for the appropriate tool. If you require additional geometric data for a tool you can create further indexed tools for this.



The tool number in TOOLTURN.TRN must match the tool number of the turning tool in TOOL.T. If you enter or copy a new line you can then enter the corresponding number.

Below the table window the TNC displays dialog text, unit specification and entry area for the specific input field

T	NAME	ZL	XL	YL	DZL	DXL
S0		75	10	0	0	0
S1		75	10	0	0	0
S2		70	0	0	0	0
S3		120	10	0	0	0

You should give other tool tables that are to be archived or used for test runs different file names of your choice with the extension **.TRN**.

Proceed as follows to open the turning tool table:




- Select the machine operating mode, e.g. **Manual operation**



- Press the **TOOL TABLE** soft key



- Press the **TURNING TOOLS** soft key



- Edit the turning tool table: Set the **EDIT** soft key to **ON**

## 14.4 Tools in turning mode (option 50)

## Tool data in the turning tool table


Input parameters	Application	Input
<b>T</b>	Tool number: Must match the tool number of the turning tool in TOOL.T	-
<b>NAME</b>	Tool name: The TNC automatically takes on the tool name if you select the turning tool table in the tool table	<b>Input range: 32 characters max., only capital letters, no space characters</b>
<b>ZL</b>	Compensation value for tool length 1 (Z direction)	<b>-99999.9999...+99999.9999</b>
<b>XL</b>	Compensation value for tool length 2 (X direction)	<b>-99999.9999...+99999.9999</b>
<b>YL</b>	Compensation value for tool length 3 (Y direction)	<b>-99999.9999...+99999.9999</b>
<b>DZL</b>	Delta value for tool length 1 (Z direction), additive effect on ZL	<b>-99999.9999...+99999.9999</b>
<b>DXL</b>	Delta value for tool length 2 (X direction), additive effect on XL	<b>-99999.9999...+99999.9999</b>
<b>DYL</b>	Delta value for tool length 3 (Y direction), additive effect on YL	<b>-99999.9999...+99999.9999</b>
<b>RS</b>	Tool tip radius: The TNC considers the tool tip radius in turning cycles and implements tool tip radius compensation when contours with radius compensation <b>RL</b> or <b>RR</b> were programmed	<b>-99999.9999...+99999.9999</b>
<b>TO</b>	Tool orientation: Direction of tool tip	<b>1 to 9</b>
<b>ANGLE OF ORIENTATION</b>	Spindle orientation angle: Angle of the milling spindle for aligning the turning tool to the machining position	<b>-360.0...+360.0</b>
<b>T-ANGLE</b>	Setting angle for roughing and finishing tools	<b>0.0000...+179.9999</b>
<b>P-ANGLE</b>	Point angle for roughing and finishing tools	<b>0.0000...+179.9999</b>
<b>CUTLENGTH</b>	Cutting length of recessing tool	<b>0.0000...+99999.9999</b>
<b>CUTWIDTH</b>	Width of the recessing tool	<b>0.0000...+99999.9999</b>
<b>DCW</b>	Oversize for recessing tool width	<b>-99999.9999...+99999.9999</b>
<b>TYPE</b>	Type of turning tool: Roughing tool <b>ROUGH</b> , finishing tool <b>FINISH</b> , thread tool <b>THREAD</b> , recessing tool <b>RECESS</b> , button tool <b>BUTTON</b> , groove turning tool <b>RECTURN</b>	<b>ROUGH, FINISH, THREAD, RECESS, BUTTON, RECTURN</b>

### Orientation angle

With the spindle orientation angle **ORI** you define the angle position of the milling spindle for the turning tool. Orient the tool tip depending on the tool orientation **TO** to the rotary table center or in the opposite direction.



The tool must be clamped and measured in the correct position.  
Check the tool orientation after definition of a tool.



### Calculate the tool compensation

The measured compensation values **DXL** and **DZL** of a turning tool can be manually compensated in the tool management (option 93). The control automatically converts the input data into the tool coordinate system.












Refer to your machine manual. Tool management is a machine-dependent function, which may be partly or completely deactivated. The machine tool builder defines the exact range of functions.

Dialog parameters	Description	Input
Korrekturwert WPL-Z	Measured error of the workpiece in Z direction	-99999.9999...+99999.9999
Korrekturwert ØWPL-X	Measured error of the workpiece in X direction (diameter)	-99999.9999...+99999.9999
Anstellwinkel β	Inclination angle during machining	0.0000...+179.9999
Werkzeug umkehren	Definition of whether the turning tool was used in a rotated position in the tool spindle.	-
aktueller Wert DZL	Current calculated value for the tool	-
aktueller Wert DXL	Current calculated value for the tool	-
neuer Wert DZL	New calculated value for the tool	-
neuer Wert DXL	New calculated value for the tool	-

## 14.4 Tools in turning mode (option 50)

### Procedure

Proceed as follows to modify the compensation values:

- |   |   |
|---|---|
|    | ▶ Select any machine operating mode, e.g. <b>Manual operation</b>                               |
|    | ▶ Press the <b>TOOL TABLE</b> soft key  |
|    | ▶ Press the <b>TOOL MANAGEMENT</b> soft key   |
|    | ▶ Press the <b>FORM FOR TOOL</b> soft key   |
|    | ▶ Set the <b>EDIT</b> soft key to <b>ON</b>   |
|    | ▶ Use the arrow keys to select the <b>DXL</b> or <b>DZL</b> input field                         |
|    | ▶ Press the <b>CALCULATE TOOL COMPENSTN.</b> soft key   |
|   | > The control opens a pop-up window.  |
|   | ▶ Enter the compensation values   |
|  | ▶ Press the <b>APPLY</b> soft key if required   |
|   | > The control loads the compensation values. You can then enter further compensation values.    |
|  | ▶ Press the <b>OK</b> soft key.   |
|   | > The control closes the pop-up window and saves the new compensation values to the tool table. |



The control can describe the **DXL** and **DZL** columns using touch probe cycles.

**Further information:** Cycle Programming User's Manual

### Example

Input:

- Korrekturwert WPL-Z: 1
- Korrekturwert ØWPL-X: 1
- Anstellwinkel β: 90
- Werkzeug umkehren: Yes


Result

- DZL: +0.5
- DXL: +1

## Tools in turning mode (option 50) 14.4


## Tool data for turning tool

Input parameters	Application	Input
<b>ZL</b>	Tool length 1	Required
<b>XL</b>	Tool length 2	Required
<b>YL</b>	Tool length 3	Optional
<b>DZL</b>	Wear compensation <b>ZL</b>	Optional
<b>DXL</b>	Wear compensation <b>XL</b>	Optional
<b>DYL</b>	Wear compensation <b>YL</b>	Optional
<b>RS</b>	Cutting radius	Required
<b>TO</b>	Tool orientation	Required
<b>ORI</b>	Orientation angle	Required
<b>T-ANGLE</b>	Tool angle	Required
<b>P-ANGLE</b>	Point angle	Required
<b>TYPE</b>	Tool type	Required



## Tool data for recessing tools

Input parameters	Application	Input
<b>ZL</b>	Tool length 1	Required
<b>XL</b>	Tool length 2	Required
<b>YL</b>	Tool length 3	Optional
<b>DZL</b>	Wear compensation <b>ZL</b>	Optional
<b>DXL</b>	Wear compensation <b>XL</b>	Optional
<b>DYL</b>	Wear compensation <b>YL</b>	Optional
<b>RS</b>	Cutting radius	Required
<b>TO</b>	Tool orientation	Required
<b>ORI</b>	Orientation angle	Required
<b>CUTWIDTH</b>	Width of the recessing tool	Required
<b>DCW</b>	Oversize f. recessing tool width	Optional
<b>TYPE</b>	Tool type	Required





## 14.4 Tools in turning mode (option 50)

## Tool data for groove turning tools

Input parameters	Application	Input
ZL	Tool length 1	Required
XL	Tool length 2	Required
YL	Tool length 3	Optional
DZL	Wear compensation <b>ZL</b>	Optional
DXL	Wear compensation <b>XL</b>	Optional
DYL	Wear compensation <b>YL</b>	Optional
RS	Cutting radius	Required
TO	Tool orientation	Required
ORI	Orientation angle	Required
CUTLENGTH	Cutting length of recessing tool	Required
CUTWIDTH	Width of the recessing tool	Required
DCW	Oversize f. recessing tool width	Optional
TYPE	Tool type	Required


## Tool data for button tools

Input parameters	Application	Input
ZL	Tool length 1	Required
XL	Tool length 2	Required
YL	Tool length 3	Optional
DZL	Wear compensation <b>ZL</b>	Optional
DXL	Wear compensation <b>XL</b>	Optional
DYL	Wear compensation <b>YL</b>	Optional
RS	Cutting radius	Required
TO	Tool orientation	Required
ORI	Orientation angle	Required
T-ANGLE	Tool angle	Required
P-ANGLE	Point angle	Required
TYPE	Tool type	Required



## Tool data for threading tools

Input parameters	Application	Input
<b>ZL</b>	Tool length 1	Required
<b>XL</b>	Tool length 2	Required
<b>YL</b>	Tool length 3	Optional
<b>DZL</b>	Wear compensation <b>ZL</b>	Optional
<b>DXL</b>	Wear compensation <b>XL</b>	Optional
<b>DYL</b>	Wear compensation <b>YL</b>	Optional
<b>TO</b>	Tool orientation	Required
<b>ORI</b>	Orientation angle	Required
<b>T-ANGLE</b>	Tool angle	Required
<b>P-ANGLE</b>	Point angle	Required
<b>TYPE</b>	Tool type	Required



## 14.4 Tools in turning mode (option 50)

### Tool tip radius compensation TRC

Turning tools have a radius at the tool tip (**RS**). As a result, when machining tapers, chamfers and radii, this results in inaccuracies on the contour because programmed traverse paths are referenced to the theoretical tool tip S. TRC prevents the resulting deviations.



In the turning cycles the TNC automatically carries out tool radius compensation. In specific traversing blocks and within programmed contours, activate TRC with **RL** or **RR**.

In turning cycles the TNC checks the cutting geometry with the tip angle **P-ANGLE** and the setting angle **T-ANGLE**. Contour elements in the cycle are processed by the TNC only as far as this is possible with the specific tool. The TNC outputs a warning when residual material is left behind.



When the position of the cutting edge is neutral (**TO=2;4;6;8**), the direction of the radius compensation is ambiguous. In this case, TRC is only possible within cycles.

The TNC can also run tool tip radius compensation during inclined processing. The following limitation applies here: if you activate inclined processing with M128 then tool tip radius compensation without a cycle, i.e. in traversing blocks with **RL/RR**, is not possible. If you activate inclined processing with **M144** this limitation does not apply.





## 14.5 Turning program functions (option 50)

### Recessing and undercutting

Some cycles machine contours that you have written in a subprogram. You program these contours with path functions or FK functions. Further special contour elements are available to you for writing turning contours. In this way you can program complete recessing and undercutting as complete contour elements with a single NC block.







Recessing and undercutting always reference a previously defined linear contour element. You can only use the recess and undercut elements GRV and UDC in contour subprograms that have been called by a turning cycle.

**Further information:** Cycle Programming User's Manual

You have various input possibilities when defining recessing and undercutting. Some of these inputs are mandatory, and others you can leave out (optional). The mandatory inputs are symbolized as such in the help graphics. In some elements you can select between two different definitions. The TNC has soft keys with the corresponding selection possibilities.

Programming recessing and undercutting:

- 
  - ▶ Show the soft-key row with special functions
- 
  - ▶ Press the **TURNING PROGRAM FUNCTIONS** soft key
- 
  - ▶ Press the **RECESS/ UNDERCUT** soft key
- 
  - ▶ Press the **GRV** (recess) or **UDC** (undercut) soft key

## 14.5 Turning program functions (option 50)



### Programming recessing

Recessing is the machining of recesses in round components, usually for accommodation of locking rings and seals or as lubricating grooves. You can program recessing around the circumference or on the face end of the turned part. For this you have two separate contour elements:

- **GRV RADIAL:** Recess in circumference of component
- **GRV AXIAL:** Recess on face end of component

### Input parameters in recessing GRV

Input parameters	Application	Input
<b>CENTER</b>	Center of recess	Required
<b>R</b>	Corner radius of both inner corners	Optional
<b>DEPTH / DIAM</b>	Recess depth (pay attention to the sign!) / diameter of recess base	Required
<b>BREADTH</b>	Recess width	Required
<b>ANGLE / ANG_WIDTH</b>	Edge angle / aperture angle of both edges	Optional
<b>RND / CHF</b>	Curve / chamfer corner of contour near to starting point	Optional
<b>FAR_RND / FAR_CHF</b>	Curve / chamfer corner of contour away from starting point	Optional



The algebraic sign for the recess depth specifies the machining position (inside/outside machining) of the recess.

Algebraic sign of recess depth for outside machining:

- Use a negative sign when the contour element runs in a negative direction to the Z coordinate
- Use a positive sign when the contour element runs in a positive direction to the Z coordinate

Algebraic sign of recess depth for inside machining:

- Use a positive sign when the contour element runs in a negative direction to the Z coordinate
- Use a negative sign when the contour element runs in a positive direction to the Z coordinate

### Radial recess: depth=5, width=10, Pos.= Z-15

21 L X+40 Z+0

22 L Z-30

23 GRV RADIAL CENTER-15 DEPTH-5 BREADTH10 CHF1 FAR\_CHF1

24 L X+60

### Programming undercutting

Undercutting is usually required for the flush connection of counterparts. In addition undercutting can help to reduce the notch effect at corners. Threads and fits are often machined with an undercut. You have various contour elements for defining the different undercuts:

- **UDC TYPE\_E**: Undercut for cylindrical surface to be further processed in compliance with DIN 509
- **UDC TYPE\_F**: Undercut for plan and cylindrical surface for further processing in compliance with DIN 509
- **UDC TYPE\_H**: Undercut for more rounded transition in compliance with DIN 509
- **UDC TYPE\_K**: Undercut in face and cylindrical surface
- **UDC TYPE\_U**: Undercut in cylindrical surface
- **UDC THREAD**: Thread undercut in compliance with DIN 76



The TNC always interprets undercuts as form elements in the longitudinal direction. No undercuts are possible in the plane direction.

## 14.5 Turning program functions (option 50)

## Undercut DIN 509 UDC TYPE \_E

## Input parameters in undercut DIN 509 UDC TYPE\_E

Input parameters	Application	Input
R	Corner radius of both inner corners	Optional
DEPTH	Undercut depth	Optional
BREADTH	Width of undercut	Optional
ANGLE	Undercut angle	Optional


Undercut: depth = 2, width = 15

21 L X+40 Z+0

22 L Z-30

23 UDC TYPE\_E R1 DEPTH2 BREADTH15

24 L X+60



## Undercut DIN 509 UDC TYPE\_F

## Input parameters in undercut DIN 509 UDC TYPE\_F

Input parameters	Application	Input
R	Corner radius of both inner corners	Optional
DEPTH	Undercut depth	Optional
BREADTH	Width of undercut	Optional
ANGLE	Undercut angle	Optional
FACEDEPTH	Depth of face	Optional
FACEANGLE	Contour angle of face	Optional


Undercut form F: depth = 2, width = 15, depth of face = 1

21 L X+40 Z+0

22 L Z-30

23 UDC TYPE\_F R1 DEPTH2 BREADTH15 FACEDEPTH1

24 L X+60




**Undercut DIN 509 UDC TYPE\_H****Input parameters in undercut DIN 509 UDC TYPE\_H**

Input parameters	Application	Input
R	Corner radius of both inner corners	Required
BREADTH	Width of undercut	Required
ANGLE	Undercut angle	Required

**Undercut form H: depth = 2, width = 15, angle = 10°**


21 L X+40 Z+0
22 L Z-30
23 UDC TYPE_H R1 BREADTH10 ANGLE10
24 L X+60

**Undercut UDC TYPE\_K****Input parameters in undercut UDC TYPE\_K**

Input parameters	Application	Input
R	Corner radius of both inner corners	Required
DEPTH	Undercut depth (paraxial)	Required
ROT	Angle to longitudinal axis (default: 45°)	Optional
ANG_WIDTH	Opening angle of undercut	Required

**Undercut form K: depth = 2, width = 15, opening angle = 30°**

21 L X+40 Z+0
22 L Z-30
23 UDC TYPE_K R1 DEPTH3 ANG_WIDTH30
24 L X+60



## 14.5 Turning program functions (option 50)

## Undercut UDC TYPE\_U

## Input parameters in undercut UDC TYPE\_U

Input parameters	Application	Input
R	Corner radius of both inner corners	Required
DEPTH	Undercut depth	Required
BREADTH	Width of undercut	Required
RND / CHF	Curve / chamfer of outer corner	Required

## Undercut form U: depth = 3, width = 8

```

21 L X+40 Z+0
22 L Z-30
23 UDC TYPE_U R1 DEPTH3 BREADTH8 RND1
24 L X+60

```

## Undercut UDC THREAD

## Input parameters in undercut DIN 76 UDC THREAD



Input parameters	Application	Input
PITCH	Thread pitch	Optional
R	Corner radius of both inner corners	Optional
DEPTH	Undercut depth	Optional
BREADTH	Width of undercut	Optional
ANGLE	Undercut angle	Optional

## Thread undercut according to DIN 76: Thread pitch = 2

```

21 L X+40 Z+0
22 L Z-30
23 UDC THREAD PITCH2
24 L X+60

```







## Blank form update TURNDATA BLANK






The **TURNDATA BLANK** function enables you to use the blank form update feature. The control detects the described contour and only then machines the residual material.

With **TURNDATA BLANK** you call a contour description used by the TNC as an updated workpiece blank.

Define the function TURNDATA BLANK as follows:






-  ► Show the soft-key row with special functions
-  ► Press the **TURNING PROGRAM FUNCTIONS** soft key
-  ► Press the **FUNCTION TURNDATA** soft key
-  ► Press the **TURNDATA BLANK** soft key
- Press the soft key for the desired contour call

You can call the contour description in the following ways:

Soft key	Call
	Contour description in an external program Call via file name
	Contour description in an external program Call via string parameter
	Contour description in a subprogram Call via label number
	Contour description in a subprogram Call via label name
	Contour description in a subprogram Call via string parameter

## Deactivate blank form update

Deactivate blank form update as follows:

-  ► Show the soft-key row with special functions
-  ► Press the **TURNING PROGRAM FUNCTIONS** soft key
-  ► Press the **FUNCTION TURNDATA** soft key
-  ► Press the **TURNDATA BLANK** soft key
-  ► Press the **BLANK OFF** soft key

## 14.5 Turning program functions (option 50)

**Inclined turning**


It may sometimes be necessary for you to bring the swivel axes into a specific position to machine a specific process. This can be necessary for example when you can only machine contour elements according to a specific position due to tool geometry.

Inclining a swivel axis creates an offset from tool to tool. The function **M144** considers the position of the inclined axes and compensates this offset. In addition the function **M144** aligns the Z direction of the workpiece coordinate system to the direction of the centerline of the workpiece. If an inclined axis is a tilting table, so that the workpiece is sloping, the TNC runs traverse movements in the displaced workpiece coordinate system. If the inclined axis is a swivel head (tool is sloping) the workpiece coordinate system is not displaced.

After inclining the swivel axis you may have to again pre-position the tool in the Y coordinates and orient the position of the tool tip with the cycle 800.

Alternatively to function **M144** you can also use function **M128**. The effect is identical, but the following limitation applies: The TNC can also run tool tip radius compensation during inclined processing. The following limitation applies here: if you activate inclined processing with M128 then tool tip radius compensation without a cycle, i.e. in traversing blocks with **RL/RR**, is not possible. If you activate inclined processing with **M144** this limitation does not apply.

If the turning cycles are executed with **M144**, the angles of the tool to the contour change. The TNC automatically takes these modifications into account and thus also monitors the machining in inclined state.



You can use recessing cycles and thread cycles with inclined machining only with a rectangular tool angle (+90°, -90°).

Tool compensation **FUNCTION TURNDATA CORR-TCS** is always effective in the tool coordinate system, even during inclined machining.



## Turning program functions (option 50) 14.5

...	
12 M144	Activate inclined machining
13 L A-25 R0 FMAX	Position swivel axis
14 CYCL DEF 800 ADJUST XZ SYSTEM	Workpiece coordinate system and align tool
Q497=+90 ;PRECESSION ANGLE	
Q498=+0 ;REVERSE TOOL	
Q530=+2 ;INCLINED MACHINING	
Q531=-25 ;ANGLE OF INCIDENCE?	
Q532=750 ;FEED RATE	
Q533=+1 ;PREFERRED DIRECTION	
Q535=3 ;ECCENTRIC TURNING	
Q536=0 ;ECCENTRIC W/O STOP	
15 L X+165 Y+0 R0 FMAX	Pre-positioning the tool
16 L Z+2 R0 FMAX	Tool at starting position
...	Machining with inclined axis



# 15

**Manual Operation  
and Setup**

## Manual Operation and Setup

### 15.1 Switch-on, switch-off

#### 15.1 Switch-on, switch-off

##### Switch-on



Refer to your machine manual.

Danger exists for the operator when the machine is started up. Read the safety information before switching on the machine.



Switch-on and crossing over the reference points can vary depending on the machine tool.

Refer to your machine manual.

Switch on the power supply for TNC and machine. The TNC then displays the following dialog:

##### SYSTEM STARTUP

- ▶ TNC is started

##### POWER INTERRUPTED



- ▶ TNC message that the power was interrupted—clear the message

##### COMPILE A PLC PROGRAM

- ▶ The PLC program of the TNC is automatically compiled

##### RELAY EXT. DC VOLTAGE MISSING



- ▶ Switch on external dc voltage. The TNC checks the functioning of the EMERGENCY STOP circuit

##### MANUAL OPERATION

##### TRAVERSE REFERENCE POINTS



- ▶ Cross the datums manually in the prescribed sequence: For each axis press the **NC START** key; or



- ▶ Cross the datums in any sequence: Press and hold the machine axis direction button for each axis until the datum has been traversed



If your machine is equipped with absolute encoders, you can leave out crossing the reference marks. In such a case, the TNC is ready for operation immediately after the machine control voltage is switched on.

The TNC is now ready for operation in the **Manual operation** mode.



The reference points need only be crossed if the machine axes are to be moved. If you intend only to write, edit or test programs, you can select the **Programming** or **Test run** mode of operation immediately after switching on the control voltage. You can cross the reference points later. For this purpose, in **Manual operation** mode press the **PASS OVER REFERENCE** soft key.

### Crossing the reference point in a tilted working plane



#### **Danger of collision!**

Make sure that the angle values entered in the menu for tilting the working plane match the actual angles of the tilted axis.

Deactivate the "Tilt Working Plane" function before you cross the reference points. Take care that there is no collision. Retract the tool from the current position first, if necessary.

If this function was active when the control was turned on, then the TNC automatically activates the tilted working plane. The TNC then moves the axes in the tilted coordinate system when an axis-direction key is pressed. Position the tool in such a way that a collision is excluded during the subsequent crossing of the datums. To cross the datums you have to deactivate the **Tilt the working plane** function.

**Further Information:** "Activating manual tilting:", page 641



If you use this function, then for non-absolute encoders you must confirm the positions of the rotary axes, which the TNC displays in a pop-up window. The position displayed is the last active position of the rotary axes before switch-off.

If one of the two functions that were active before is active now, the **NC START** key has no function. The TNC outputs a corresponding error message.

## Manual Operation and Setup

### 15.1 Switch-on, switch-off

#### Switch-off




Deactivation is a machine-dependent function.  
Refer to your machine manual.


To prevent data from being lost on switch-off, you need to shut down the operating system of the TNC as follows:



- ▶ Operating mode: Press the **Manual operation** key



- ▶ Select the function for shutting down



- ▶ Confirm with the **SHUT DOWN** soft key
- ▶ When the TNC displays the message **Now you can switch off the TNC** in a pop-up window, you may switch off the power supply to the TNC



#### Caution: Data may be lost!

Inappropriate switch-off of the TNC can lead to data loss!

The control restarts after pressing the **RESTART** soft key. Switch-off during a restart can also result in data loss!

## 15.2 Moving the machine axes

### Note



Refer to your machine manual.

Moving with the axis direction keys can vary depending on the machine.

### Moving the axis with the axis direction keys



- ▶ Operating mode: Press the **MANUAL OPERATION** key



- ▶ Press the axis direction key and hold it down as long as you wish the axis to move; or



- ▶ To move the axis continuously: Press and hold the axis direction button and press the **NC START** key



- ▶ To stop: Press the **NC Stop** key

You can move several axes at a time with these two methods. The control then shows the feed rate. You can change the feed rate at which the axes are moved with the **F** soft key.

**Further Information:** "Spindle speed S, feed rate F and miscellaneous function M", page 593











If a moving task is active on the machine, the control displays the **control in operation** symbol.

## Manual Operation and Setup

### 15.2 Moving the machine axes

#### Incremental jog positioning


With incremental jog positioning you can move a machine axis by a preset distance.

-  ▶ Operating mode: Press the **MANUAL OPERATION** or **ELECTRONIC HANDWHEEL** key
-  ▶ Shift the soft-key row
-  ▶ Select incremental jog positioning: Switch the **INCREMENT** soft key to **ON**
-  ▶ Enter the infeed of the **linear axes** and confirm with the **CONFIRM VALUE** soft key
-  ▶ Alternatively, confirm with the **ENT** key
-  ▶ Use the arrow keys to position the cursor on the **rotary axis**
-  ▶ Enter the infeed of the **rotary axes** and confirm with the **CONFIRM VALUE** soft key
-  ▶ Alternatively, confirm with the **ENT** key
-  ▶ Confirm with the **OK** soft key
- ▶ The increment is active.
-  ▶ Deactivate incremental jog positioning: Switch the **INCREMENT** soft key to **OFF**



If you are in the increment menu, you can switch off incremental jog positioning with the **SWITCH OFF** soft key.

The maximum permissible value for infeed is 10 mm.





### Traverse with electronic handwheels

The TNC supports traversing with the following new electronic handwheels:

- HR 520: Handwheel with display, data transfer per cable
- HR 550FS: Handwheel with display, data transfer via radio

In addition to this, the TNC continues to support the cable handwheels HR 410 (without display) and HR 420 (with display).



#### **Caution: Danger to the operator and handwheel!**

All of the handwheel connectors may only be removed by authorized service personnel, even if it is possible without any tools!

Ensure that the handwheel is plugged in before you switch on the machine!

If you wish to operate your machine without the handwheel, disconnect the cable from the machine and secure the open socket with a cap!



Refer to your machine manual. Your machine tool builder can make additional functions of the HR 5xx available.



If you want to use the handwheel superimposing function on a virtual axis, then we recommend the handwheel HR 5xx.

**Further Information:** "Virtual tool axis VT", page 420

The portable HR 5xx handwheels feature a display on which the TNC shows information. In addition, you can use the handwheel soft keys for important setup functions, e.g. datum setting or entering and running M functions.

As soon as you have activated the handwheel with the handwheel activation key, the operating panel is locked. This is indicated by a pop-up window on the TNC screen.

If several handwheels are connected to a control the handwheel key is not available on the operating panel. Activate or deactivate the handwheel via the handwheel key on the handwheel. An active handwheel must be deactivated before another handwheel can be selected.



Refer to your machine manual.


This feature must be enabled and adapted by the machine tool builder.



## Manual Operation and Setup

### 15.2 Moving the machine axes

- 1 **EMERGENCY STOP** key
- 2 Handwheel display for status and for selecting functions
- 3 Soft keys
- 4 Axis selection keys; can be exchanged by the machine manufacturer depending on the axis configuration
- 5 Permissive key
- 6 Arrow keys for defining handwheel sensitivity
- 7 Handwheel activation key
- 8 Key for TNC traverse direction of the selected axis
- 9 Rapid traverse superimposing for the axis direction key
- 10 Spindle switch-on (machine-dependent function, key can be exchanged by the machine manufacturer)
- 11 "Generate NC block" key (machine-dependent function, key can be exchanged by the machine manufacturer)
- 12 Spindle switch-off (machine-dependent function, key can be exchanged by the machine manufacturer)
- 13 **CTRL** key for special functions (machine-specific function, key can be exchanged by the machine manufacturer)
- 14 **NC START** key (machine-dependent function, key can be exchanged by the machine manufacturer)
- 15 **NC STOP** key (machine-dependent function, key can be exchanged by the machine manufacturer)
- 16 Handwheel
- 17 Spindle speed potentiometer
- 18 Feed rate potentiometer
- 19 Cable connection, not available with the HR 550FS wireless handwheel



### Handwheel display

- 1 Only with wireless handwheel HR 550FS:** Shows whether the handwheel is in the docking station or whether wireless operation is active
- 2 Only with wireless handwheel HR 550FS:** Shows the signal strength, 6 bars = maximum signal strength
- 3 Only with wireless handwheel HR 550FS:** Shows the charge status of the rechargeable battery, 6 bars = fully charged A bar moves from the left to the right during recharging
- 4 ACTL:** Type of position display
- 5 Y+129.9788:** Position of the selected axis
- 6 \*:** STIB (control in operation); program run has been started or axis is in motion
- 7 S0:** Current spindle speed
- 8 F0:** Feed rate at which the selected axis is moving
- 9 E:** Error message
- 10 3D:** Tilted-working-plane function is active
- 11 2D:** Basic rotation function is active
- 12 RES 5.0:** Active handwheel resolution. Path traversed by the selected axis with a handwheel revolution
- 13 STEP ON or OFF:** Incremental jog active or inactive. If a function is active, the TNC additionally displays the active jog increment.
- 14** Soft-key row: Selection of various functions, described in the following sections



## Special features of the wireless handwheel HR 550FS



Due to various potential sources of interference, a wireless connection is not as reliable as a cable connection. Before you use the wireless handwheel it must therefore be checked whether there are any other radio users in the surroundings of the machine. This inspection for presence of radio frequencies or channels is recommended for all industrial radio systems.

If the HR 550 is not needed, always put it in the handwheel holder. This way you can ensure that the handwheel batteries are always ready for use thanks to the contact strip on the rear side of the wireless handwheel and the recharge control, and that there is a direct contact connection for the emergency stop circuit.

If an error (interruption of the radio connection, poor reception quality, defective handwheel component) occurs, the handwheel always reacts with an emergency stop.

**Caution: Danger to the operator and machine!**

Due to safety reasons you must switch off the wireless handwheel and the handwheel holder after an operating time of 120 hours at the latest so that the TNC can run a functional test when it is restarted!

If you use several machines with wireless handwheels in your workshop you have to mark the handwheels and holders that belong together so that their respective associations are clearly identifiable (e.g. by color stickers or numbers). The markings on the wireless handwheel and the handwheel holder must be clearly visible to the user!

Before every use, make sure that the correct handwheel for your machine is active.



The HR 550FS wireless handwheel features a rechargeable battery. The battery starts charging when you put the handwheel in the holder.

You can operate the HR 550FS with the battery for up to 8 hours before it must be recharged again. If not in use, it is recommended to put the handwheel in the handwheel holder.

As soon as the handwheel is in its holder, it switches internally to cable operation. This means you can still use it even if the handwheel is fully discharged. The functions are the same as with wireless operation.



When the handwheel is completely discharged, it takes about 3 hours until it is fully recharged in the handwheel holder.


Clean the contacts **1** in the handwheel holder and of the handwheel regularly to ensure their proper functioning.

The transmission range is amply dimensioned. If you should nevertheless happen to come near the edge of the transmission area, which is possible with very large machines, the HR 550FS warns you in time with a plainly noticeable vibration alarm. If this happens you must reduce the distance to the handwheel holder, into which the radio receiver is integrated.



**Caution: Danger to the workpiece and tool!**

If interruption-free operation is no longer possible within the transmission range the TNC automatically triggers an emergency stop. This can also happen during machining. Keep the distance to the handwheel holder to a minimum. If you do not use the handwheel, put it in the handwheel holder.




## Manual Operation and Setup

### 15.2 Moving the machine axes

If the TNC has triggered an emergency stop you must reactivate the handwheel. Proceed as follows:

- ▶ Select the **Programming** operating mode
- ▶ Press the **MOD** key to select the MOD function
- ▶ Scroll through the soft-key row
  - ▶ Select the configuration menu for the wireless handwheel: Press the **SET UP WIRELESS HANDWHEEL** soft key
  - ▶ Click the **Start handwheel** button to reactivate the wireless handwheel
  - ▶ To save the configuration and exit the configuration menu, press the **END** button



The **MOD** operating mode includes a function for commissioning and configuring the handwheel.

**Further Information:** "Configuring the HR 550FS wireless handwheel", page 724

#### Selecting the axis to be moved

You can activate directly through the axis address keys the principal axes X, Y, Z and three other axes defined by the machine tool builder. Your machine tool builder can also place the virtual axis VT directly on one of the free axis keys. If the virtual axis VT is not on one of the axis selection keys, proceed as follows:

- ▶ Press the **F1 (AX)** handwheel soft key: The TNC displays all active axes on the handwheel display. The currently active axis flashes.
- ▶ Select the desired axis with the handwheel soft keys **F1 (->)** or **F2 (<-)** and confirm with the **F3 (OK)** handwheel soft key.



The machine manufacturer can also configure the turning spindle (option number 50) as an optional axis.

Refer to your machine manual.

#### Setting the handwheel sensitivity

The handwheel sensitivity determines which path an axis takes per revolution of the handwheel. The sensitivity levels are predefined and are selectable with the handwheel arrow keys (only when incremental jog is not active).

Selectable sensitivity levels:

0.001/0.002/0.005/0.01/0.02/0.05/0.1/0.2/0.5/1 [mm/revolution or degrees/revolution]

Selectable sensitivity levels:

0.00005/0.001/0.002/0.004/0.01/0.02/0.03 [in mm/revolution or degrees/revolution]

### Moving the axes



- ▶ Activate the handwheel: Press the handwheel key on the HR 5xx: Now you can only operate the TNC via the HR 5xx; the TNC shows a pop-up window containing information on the TNC screen
- ▶ Select the desired operating mode with the **OPM** soft key if necessary



- ▶ If required, press and hold the permissive button



- ▶ Use the handwheel to select the axis to be moved. Select the additional axes with the soft keys as required



- ▶ Move the active axis in the positive direction; or



- ▶ Move the active axis in the negative direction



- ▶ Deactivate the handwheel: Press the handwheel key on the HR 5xx: Now you can operate the TNC again via the operating panel

### Potentiometer settings

The potentiometers of the machine operating panel continue to be active after you have activated the handwheel. If you want to use the potentiometers on the handwheel, proceed as follows:

- ▶ Press the **CTRL** and Handwheel keys on the HR 5xx. The TNC shows the soft-key menu for selecting the potentiometers on the handwheel display
- ▶ Press the **HW** soft key to activate the handwheel potentiometers

If you have activated the potentiometers on the handwheel, you must reactivate the potentiometers of the machine operating panel before deselecting the handwheel. Proceed as follows:

- ▶ Press the **CTRL** and handwheel keys on the HR 5xx; the TNC shows the soft-key menu for selecting the potentiometers on the handwheel display
- ▶ Press the **KBD** soft key to activate the potentiometers of the machine operating panel

## 15.2 Moving the machine axes

### Incremental jog positioning

With incremental jog positioning the TNC moves the currently active handwheel axis by a preset increment defined by you:

- ▶ Press the handwheel soft key **F2 (STEP)**
- ▶ Activate incremental jog positioning: Press handwheel soft key **3 (ON)**
- ▶ Select the desired jog increment by pressing the **F1** or **F2** key. If you press and hold the respective key, each time it reaches a decimal value 0 the TNC increases the counting increment by a factor of 10. By also pressing the **CTRL** key, you can increase the counting increment to 1. The smallest possible increment is 0.0001 mm (0.00001 inches). The largest possible increment is 10 mm (0.3937 inches).
- ▶ Confirm the selected jog increment with soft key **4 (OK)**
- ▶ With the **+** or **-** handwheel key, move the active handwheel axis in the corresponding direction

### Inputting miscellaneous functions M

- ▶ Press the **F3 (MSF)** handwheel soft key
- ▶ Press the **F1 (M)** handwheel soft key
- ▶ Select the desired M function number by pressing the **F1** or **F2** key
- ▶ Execute the M miscellaneous function with the **NC START** key

### Entering the spindle speed S

- ▶ Press the **F3 (MSF)** handwheel soft key
- ▶ Press the **F2 (S)** handwheel soft key
- ▶ Select the desired speed by pressing the **F1** or **F2** key. If you press and hold the respective key, each time it reaches a decimal value 0 the TNC increases the counting increment by a factor of 10. By also pressing the **CTRL** key, you can increase the counting increment to 1000
- ▶ Activate the new speed S with the **NC START** key



**Entering the feed rate F**

- ▶ Press the **F3 (MSF)** handwheel soft key
- ▶ Press the **F3 (F)** handwheel soft key
- ▶ Select the desired feed rate by pressing the **F1** or **F2** key. If you press and hold the respective key, each time it reaches a decimal value 0 the TNC increases the counting increment by a factor of 10. By also pressing the **CRTL** key, you can increase the counting increment to 1000
- ▶ Confirm the new feed rate F with the **F3 (OK)** handwheel soft key

**Datum setting**

- ▶ Press the **F3 (MSF)** handwheel soft key
- ▶ Press the **F4 (PRS)** handwheel soft key
- ▶ If required, select the axis in which the datum is to be set.
- ▶ Zero the axis with the handwheel soft key **F3 (OK)** or with **F1** and **F2** set the desired value and then confirm with **F3 (OK)**. By also pressing the **CTRL** key, you can increase the counting increment to 10

**Changing modes of operation**

With the handwheel soft key **F4 (OPM)** you can use the handwheel to switch the operating mode, provided that the current status of the control allows a mode change.

- ▶ Press the **F4 (OPM)** handwheel soft key
- ▶ Select the desired operating mode by handwheel soft key
  - MAN: **Manual operation**
  - MDI: **Positioning with manl.data input**
  - SGL: **Program run, single block**
  - RUN: **Program run, full sequence**

## Manual Operation and Setup

### 15.2 Moving the machine axes

#### Generating a complete traversing block



Your machine tool builder can assign any function to the "Generate NC block" handwheel key. Refer to your machine manual.

- ▶ Switch to the **Positioning with manl.data input** mode of operation
- ▶ If required, use the arrow keys on the TNC keyboard to select the NC block after which the new traversing block is to be inserted.
- ▶ Activate the handwheel
- ▶ Press the "Generate NC block" handwheel key: The TNC inserts a complete traversing block containing all axis positions selected through the MOD function.

#### Features in the program run modes of operation

You can use the following functions in the Program Run modes of operation:

- The **NC START** key (**NC START** handwheel key)
  - The **NC STOP** key (**NC STOP** handwheel key)
  - After the **NC STOP** key has been pressed: Internal stop (handwheel soft keys **MOP** and then **Stop**)
  - After the **NC STOP** key has been pressed: Traverse manual axes (handwheel soft keys **MOP** and then **MAN**)
  - Returning to the contour after the axes were moved manually during a program interruption (**MOP** and then **REPO** handwheel soft keys). The handwheel soft keys, which function similarly to the screen soft keys, are used for operating.
- Further Information:** "Returning to the contour", page 692
- On/off switch for the Tilt working plane function (handwheel soft keys **MOP** and then **3D**)

## 15.3 Spindle speed S, feed rate F and miscellaneous function M

### Application

In the **Manual operation** and **Electronic handwheel** operating modes, you can enter the spindle speed S, feed rate F and the miscellaneous functions M with soft keys.

**Further Information:** "Enter miscellaneous functions M and STOP", page 406



The machine tool builder determines which miscellaneous functions M are available on your control and what effects they have.

### Entering values

#### Spindle speed S, miscellaneous function M



- ▶ Select input for spindle speed: press the **S** soft key

#### SPINDLE SPEED S=



- ▶ Enter **1000** (spindle speed) and load with the **NC START** key

The spindle speed with the entered speed **S** is started with a miscellaneous function **M**. Input a miscellaneous function **M** in the same way.

#### Feed rate F

After entering a feed rate **F**, confirm your entry with the **ENT** key.

The following is valid for feed rate F:

- If you enter  $F=0$ , then the lowest feed rate from the machine parameter **manualFeed** (no. 400304) takes effect
- If the feed rate entered exceeds the value defined in the machine parameter **maxFeed** (no. 400302) then the parameter value in the machine parameter takes effect
- F is not lost during a power interruption
- The control displays the feed rate.
  - When **3D ROT** is active the machining feed rate is shown if several axes are moved
  - If **3D ROT** is not active, the feed drive display remains empty if several axes are moved

## Manual Operation and Setup

### 15.3 Spindle speed S, feed rate F and miscellaneous function M

#### Adjusting spindle speed and feed rate

With the override knobs you can vary the spindle speed S and feed rate F from 0% to 150% of the set value.

The feed rate potentiometer only lowers the programmed feed rate, not the feed rate calculated by the control.



The override knob for spindle speed is only functional on machines with infinitely variable spindle drive.



#### Feed rate limit F MAX



Refer to your machine manual.  
The feed-rate limit depends on the machine.

The **F MAX** soft key enables you to reduce the feed rate speed for all operating modes. The reduction applies to all rapid traverse and feed rate movements. The value you enter remains active after switch-off or switch-on.

The **F MAX** soft key is available in the following operating modes:

- Program run, single block
- Program run, full sequence
- Positioning with manl.data input

#### Procedure

To activate the feed rate limit F MAX, proceed as follows:



- ▶ Operating mode: Press the **POSITIONING WITH MANL.DATA INPUT** key



- ▶ Press the **F MAX** soft key



- ▶ Enter the desired maximum feed rate
- ▶ Press the OK soft key

## 15.4 Optional safety concept (functional safety FS)

### Miscellaneous



You machine tool builder adapts the HEIDENHAIN safety design to your machine. Refer to your machine manual.

Every machine tool operator is exposed to certain risks. Although protective devices can prevent access to dangerous points, the operator must also be able to work on the machine without this protection (e.g. protective door opened). Several guidelines and regulations to minimize these risks have been developed within the last few years.

The HEIDENHAIN safety concept integrated in the TNC controls complies with **Performance Level d** as per EN 13849-1 and SIL 2 as per IEC 61508, features safety-related modes of operation in accordance with EN 12417, and assures extensive operator protection.

The basis of the HEIDENHAIN safety concept is the dual-channel processor structure, which consists of the main computer (MC) and one or more drive controller modules (CC= control computing unit). All monitoring mechanisms are designed redundantly in the control systems. Safety-relevant system data are subject to a mutual cyclic data comparison. Safety-relevant errors always lead to safe stopping of all drives through defined stop reactions.

Defined safety functions are triggered and safe operating statuses are achieved via safety-relevant inputs and outputs (dual-channel implementation), which have an influence on the system in all operating modes.

In this chapter you will find explanations of the functions that are additionally available on a TNC with functional safety.

## Manual Operation and Setup

### 15.4 Optional safety concept (functional safety FS)

#### Explanation of terms

##### Safety-related operating modes

Description	Brief description
SOM_1	Safe operating mode 1: Automatic operation, production mode
SOM_2	Safe operating mode 2: Set-up mode
SOM_3	Safe operating mode 3: Manual intervention; only for qualified operators
SOM_4	Safe operating mode 4: Advanced manual intervention, process monitoring

##### Safety functions

Description	Brief description
SS0, SS1, SS1F, SS2	Safe stop: safe stopping of all drives using different methods
STO	Safe torque off: Energy supply to the motor is interrupted. Provides protection against unexpected start of the drives
SOS	Safe operating stop. Provides protection against unexpected start of the drives
SLS	Safely-limited speed. Prevents the drives from exceeding the specified speed limits when the protective door is opened

## Checking the axis positions



This function must be adapted to the TNC by your machine manufacturer. Refer to your machine manual.

After switch-on the TNC checks whether the position of an axis matches the position directly after switch-off. If a deviation occurs, this axis is displayed in red on the position display. Axes that are marked red can no longer be moved while the door is opened.

In such cases you must approach a test position for the axes in question. Proceed as follows:

- ▶ Select the **Manual operation** mode
- ▶ Execute the approach with **NC START** to move the axes in the sequence shown
- ▶ When the test position has been reached, the TNC asks whether the position was approached correctly: Confirm with the **OK** soft key if the TNC approached the test position correctly, and with **END** if the TNC approached the position incorrectly
- ▶ If you confirmed with **OK**, you must confirm the correctness of the test position again with the permissive key on the machine operating panel
- ▶ Repeat this procedure for all axes that you want to move to the test position



### **Danger of collision!**

Approach the test positions in such a way that no collision between tool and the workpiece or the clamping devices can occur. If necessary, pre-position the axes manually.



The location of the test position is specified by your machine tool builder. Refer to your machine manual.

## Manual Operation and Setup

### 15.4 Optional safety concept (functional safety FS)

#### Activating feed-rate limitation


When the **F LIMITED** soft key is set to **ON**, the TNC limits the maximum permissible axis speeds to the specified, safely limited speed.



- ▶ Operating mode: Press the **Manual operation** key



- ▶ Shift the soft-key row



- ▶ Switch on/off feed rate limit

#### Additional status displays

On a control with functional safety FS, the general status display contains additional information about the current status of safety functions. The TNC shows this information as operating statuses of the status displays **T**, **S** and **F**

Status display	Brief description
<b>STO</b>	Energy supply to the spindle or a feed drive is interrupted.
<b>SLS</b>	Safely-limited speed: A safely limited speed is active.
<b>SOS</b>	Safe operating stop: Safe operating stop is active.
<b>STO</b>	Safe torque off: Energy supply to the motor is interrupted.

The TNC shows the active safety-related mode of operation with an icon in the header to the right of the operating mode text:

Button	Safety-related operating mode
	<b>SOM_1</b> operating mode active
	<b>SOM_2</b> mode active
	<b>SOM_3</b> mode active
	<b>SOM_4</b> mode active




## 15.5 Datum management with the preset table

### Note



You should definitely use the preset table if:

- Your machine is equipped with rotary axes (tilting table or swivel head) and you work with the function for tilting the working plane
- Your machine is equipped with a spindle-head changing system
- Up to now you have been working with older TNC controls with REF-based datum tables
- You wish to machine identical workpieces that are differently aligned



The preset table can contain any number of lines (datums). To optimize the file size and the processing speed, only use as many rows as you need to manage your datums.

For safety reasons, new lines can be inserted only at the end of the preset table.

## 15.5 Datum management with the preset table

### Saving the datums in the preset table

The preset table has the name **PRESET.PR**, and is saved in the directory **TNC:\table**. **PRESET.PR** is editable in the **MANUAL OPERATION** and **ELECTRONIC HANDWHEEL** modes only if the **CHANGE PRESET** soft key was pressed. You can open the **PRESET.PR** preset table in the **PROGRAMMING** operating mode but not edit it.

It is permitted to copy the preset table into another directory (for data backup). Write-protected rows are also write-protected in the copied tables.

Never change the number of rows in the copied tables! If you want to reactivate the table, this may lead to problems.

To activate the preset table copied to another directory you have to copy it back to the directory **TNC:\table\**.

There are several methods for saving datums and basic rotations in the preset table:

- Manual input
- Using the probing cycles in the **MANUAL OPERATION** and **ELECTRONIC HANDWHEEL** modes
- Using probing cycles 400 to 402 and 410 to 419 in automatic mode

**Further information:** Cycle Programming User's Manual



Basic rotations from the preset table rotate the coordinate system about the preset, which is shown in the same line as the basic rotation.

Remember to ensure that the position of the tilting axes matches the corresponding values of the 3-D ROT menu when setting the datum. Therefore:










- If the "Tilt working plane" function is not active, the position display for the rotary axes must be = 0° (zero the rotary axes if necessary).
- If the "Tilt working plane" function is active, the position displays for the rotary axes must match the angles entered in the 3-D ROT menu.

**PLANE RESET** does not reset the active 3-D rotation.

The line 0 in the preset table is write protected. In line 0, the TNC always saves the datum that you most recently set manually via the axis keys or via soft key. If the datum set manually is active, the TNC displays the text **PR MAN(0)** in the status display







### Manually saving the datums in the preset table

In order to save datums in the preset table, proceed as follows:














- 
  - ▶ Operating mode: Press the **Manual operation** key
  
- 
  - ▶ Move the tool slowly until it touches (scratches) the workpiece surface, or position the measuring dial correspondingly
- 
- 
  
- 
  - ▶ Press the **PRESET TABLE** soft key
  - ▶ The TNC opens the preset table and sets the cursor to the row of the active datum.
- 
  - ▶ Select the functions for preset entry
  - ▶ The TNC displays all available input options in the soft-key row.
- 
  - ▶ Select the row in the preset table that you want to change (the row number is the preset number)
- 
  - ▶ If needed, select the column (axis) in the preset table that you want to change
- 
  - ▶ Use the soft keys to select one of the available entry possibilities

## 15.5 Datum management with the preset table

## Input options

Soft key	Function
	Directly transfer the actual position of the tool (the measuring dial) as the new datum: This function only saves the preset in the axis in which the cursor is currently hovering.
	Assign any value to the actual position of the tool (the measuring dial): This function only saves the preset in the axis in which the cursor is currently hovering. Enter the desired value in the pop-up window
	Incrementally shift a datum already stored in the table: This function only saves the preset in the axis in which the cursor is currently hovering. Enter the desired corrective value with the correct sign in the pop-up window. If inch display is active: Enter the value in inches, and the TNC will internally convert the entered values to mm
	Directly enter the new datum without calculation of the kinematics (axis-specific). Only use this function if your machine has a rotary table, and you want to set the datum to the center of the rotary table by entering 0. This function only saves the preset in the axis in which the cursor is currently hovering. Enter the desired value in the pop-up window. If inch display is active: Enter the value in inches, and the TNC will internally convert the entered values to mm
	Select the <b>BASE TRANSFORM./OFFSET</b> view. The standard <b>BASE TRANSFORM.</b> view shows the X, Y and Z columns. Depending on the machine, the SPA, SPB and SPC columns are displayed additionally. The TNC saves the basic rotation here (with the Z tool axis the TNC uses the SPC column). The <b>OFFSET</b> view shows the offset values for the preset.
	Write the currently active datum to a selectable line in the table: This function saves the datum in all axes, and then activates the appropriate row in the table automatically. If inch display is active: Enter the value in inches, and the TNC will internally convert the entered values to mm

### Editing the preset table

Soft key	Editing function in table mode
	Select the table start
	Select the table end
	Select the previous page in the table
	Select the next page in the table
	Select the functions for entering presets
	Display the "Basic Transformation/Axis Offset" selection
	Activate the datum of the selected line of the preset table
	Add the entered number of lines to the end of the table (2nd soft-key row)
	Copy the highlighted field (2nd soft-key row)
	Insert the copied field (2nd soft-key row)
	Reset the selected line: The TNC enters - in all columns (2nd soft-key row)
	Insert a single line at the end of the table (2nd soft-key row)
	Delete a single line at the end of the table (2nd soft-key row)

## 15.5 Datum management with the preset table

**Overwrite protection for datum**

Row 0 in the preset table is write-protected. The TNC saves the last manually set datum in row 0.

You can protect further rows in the preset table from being overwritten with the **LOCKED** column. The write-protected rows are color-highlighted in the preset table.

If you want to overwrite a write-protected row with a manual probing cycle, confirm with **OK** and enter the password (where password-protected).


**Caution: Data may be lost!**

If you forget the password, then you can no longer reset the write protection in a protected row.

If you protect a row with a password, please make a note of this password.

Ideally, use simple protection with the **LOCK / UNLOCK** soft key.


Proceed as follows to protect a datum from overwriting:



- ▶ Press the **CHANGE PRESET** soft key




- ▶ Select the **LOCKED** column




- ▶ Press the **EDIT CURRENT FIELD** soft key

Protection for datum without using password:




- ▶ Press the **LOCK / UNLOCK** soft key
- > The TNC writes an **L** in the **LOCKED** column.

Protect a datum with a password:




- ▶ Press the **LOCK / UNLOCK PASSWORD** soft key



- ▶ Enter the password into the pop-up window
- ▶ Confirm with the **OK** soft key or with the **ENT** key:
- > The TNC writes **###** to the **LOCKED** column.

**Rescind write-protection**


To edit a line you have previously write-protected, proceed as follows:



- ▶ Press the **CHANGE PRESET** soft key




- ▶ Select the **LOCKED** column




- ▶ Press the **EDIT CURRENT FIELD** soft key

Datum protected without password:




- ▶ Press the **LOCK / UNLOCK** soft key
- > The TNC rescinds the write protection.

Datum protected with a password:



- ▶ Press the **LOCK / UNLOCK PASSWORD** soft key



- ▶ Enter the password into the pop-up window
- ▶ Confirm with the **OK** soft key or with the **ENT** key
- > The TNC rescinds the write protection.

## 15.5 Datum management with the preset table

## Activating the datum

## Activating a datum from the preset table in the Manual operation mode



When activating a datum from the preset table, the TNC resets the active datum shift, mirroring, rotation and scaling factor.

However, a coordinate transformation that was programmed in Cycle 19, Tilted Working Plane, or through the PLANE function, remains active.



- ▶ Operating mode: Press the **Manual operation** key




- ▶ Display the preset table: Press the **PRESET TABLE** soft key



- ▶ Select the datum number that you want to activate; or



- ▶ With the **GOTO** key, select the datum number that you want to activate and confirm with the **ENT** key



- ▶ Activate the datum: Press the **ACTIVATE PRESET** soft key



- ▶ Confirm activation of the datum. The TNC sets the display and—if defined—the basic rotation



- ▶ Exit the preset table

## Activating a datum from the preset table in an NC program

Use Cycle 247 in order to activate datums from the preset table during a program run. In Cycle 247 you simply define the number of the datum to be activated.

**Further information:** Cycle Programming User's Manual



## 15.6 Datum setting without a 3-D touch probe

### Note

When you set a datum, you set the TNC display to the coordinates of a known workpiece position.



All manual probe functions are available with a 3-D touch probe.

**Further Information:** "Datum setting with a 3-D touch probe", page 629

### Preparation

- ▶ Clamp and align the workpiece
- ▶ Insert the zero tool with known radius into the spindle
- ▶ Ensure that the TNC is showing the actual positions

### Datum setting with an end mill



#### Protective measure

If the workpiece surface must not be scratched, you can lay a metal shim of known thickness  $d$  on it. You then enter a value that is greater than the desired preset by the value  $d$ .




- ▶ Operating mode: Press the **Manual operation** key



- ▶ Move the tool slowly until it touches (scratches) the workpiece surface



- ▶ Select the axis



### DATUM SETTING Z=



- ▶ Zero tool in spindle axis: Set the display to a known workpiece position (here, 0) or enter the thickness  $d$  of the shim. In the tool axis, offset the tool radius



Repeat the process for the remaining axes.

If the values for the tool in the tool axis have already been set, set the display of the tool axis to the length  $L$  of the tool or enter the sum  $Z=L+d$



The TNC automatically saves the datum set with the axis keys in line 0 of the preset table.

## 15.6 Datum setting without a 3-D touch probe


## Using touch probe functions with mechanical probes or measuring dials

If you do not have an electronic 3-D touch probe on your machine, you can also use all the previously described manual touch probe functions (exception: calibration function) with mechanical probes or by simply touching the workpiece with the tool.

**Further Information:** "Using a 3-D touch probe ", page 609

In place of the electronic signal generated automatically by a 3-D touch probe during probing, you can manually initiate the trigger signal for capturing the **probing position** by pressing a key.

Proceed as follows:



- ▶ Select any touch probe function by soft key
  - ▶ Move the mechanical probe to the first position to be captured by the TNC
  - ▶ Confirm the position: Press the **ACTUAL-POSITION CAPTURE** soft key for the TNC to save the current position
  - ▶ Move the mechanical probe to the next position to be captured by the TNC
  - ▶ Confirm the position: Press the **ACTUAL-POSITION CAPTURE** soft key for the TNC to save the current position
  - ▶ If required, move to additional positions and capture as described previously
  - ▶ **Datum:** In the menu window, enter the coordinates of the new datum, confirm with the **SET DATUM** soft key, or write the values to a table
- Further Information:** "Writing measured values from the touch probe cycles to a datum table", page 615
- Further Information:** "Writing measured values from the touch probe cycles to the preset table", page 616
- ▶ Terminate the probing function: Press the **END** key

## 15.7 Using a 3-D touch probe

### Overview

The following touch probe cycles are available in the **Manual operation** mode:











HEIDENHAIN only gives warranty for the function of the probing cycles if HEIDENHAIN touch probes are used.

Make sure during probing that the axis angles match the set tilt angles. The control checks this automatically if the **chkTiltingAxes** machine parameter (no. 204601) is activated.



The TNC must be specially prepared by the machine tool builder for the use of a 3-D touch probe. Refer to your machine manual.

Soft key	Function	Page
	Calibrating the 3-D Touch Probe	617
	Measuring a 3-D basic rotation by probing a plane	627
	Measuring a basic rotation using a line	626
	Setting the datum on any axis	629
	Set a corner as preset	630
	Set a circle center as preset	631
	Setting the centerline as datum	634
	Touch probe system data management	See Cycle Programming User's Manual

## 15.7 Using a 3-D touch probe



You can also use all manual touch probe cycles, except the corner probing cycle and plane probing cycle, in Turning mode. Please note that in Turning mode all measured values in the X coordinate are calculated and displayed as diameter values.

To use the touch probe in Turning mode you should separately calibrate the touch probe in Turning mode. As the factory default setting of the rotary spindle may vary between Milling Mode and Turning mode, you must calibrate the touch probe without any center offset. You can create additional tool data for the touch probe, e.g. as an indexed tool.



For more information about the touch probe table, refer to the User's Manual for Cycle Programming

**Traverse movements with a handwheel with display**

With a handwheel with display, it is possible to transfer control to the handwheel during a manual touch probe cycle.

Proceed as follows:







- ▶ Start the manual touch probe cycle
- ▶ Position the touch probe at a position near the first touch point
- ▶ Probe the first touch point
- ▶ Activate the handwheel on the handwheel
- > The control shows the pop-up window **Handwheel active**.
- ▶ Position the touch probe at a position near the second touch point
- ▶ Deactivate the handwheel on the handwheel
- > The control closes the pop-up window.
- ▶ Probe the second touch point
- ▶ If necessary, set the datum
- ▶ End the probing function



If the handwheel is active you cannot start the probing cycles.

## Functions in touch probe cycles

Soft keys that are used to select the probing direction or a probing routine are displayed in the manual touch probe cycles. The soft keys displayed vary depending on the respective cycle:

Soft key	Function
	Select the probing direction
	Capture the actual position
	Probe hole (inside circle) automatically
	Probe stud (outside circle) automatically
	Probe a model circle (center point of several elements)
	Select a paraxial probing direction for probing of holes, studs and model circles

### Automatic probing routine for holes, studs and model circles



If you use a function for probing a circle automatically, the TNC automatically positions the touch probe to the respective touch points. Ensure that the positions can be approached without collision.

If you use a probing routine for automatically probing a hole or a stud, or a model circle, the control opens a form with the required entry fields.

### Input fields in the Measure stud and Measure hole forms

Input field	Function
<b>Stud diameter?</b> or <b>Hole diameter</b>	Diameter of probe contact (optional for holes)
<b>Safety clearance?</b>	Distance to the probe contact in the plane
<b>Incr. clearance height?</b>	Positioning of touch probe in spindle axis direction (starting from the current position)
<b>Starting angle?</b>	Angle for the first probing operation (0° = positive direction of principal axis, i.e. in X+ for spindle axis Z). All other probe angles result from the number of touch points.
<b>Number of touch points?</b>	Number of probing operations (3 to 8)
<b>Angular length?</b>	Probing a full circle (360°) or a circle segment (angular length < 360°)

## 15.7 Using a 3-D touch probe

Automatic probing routine:


- ▶ Pre-position touch probe



- ▶ Select the probing function: Press the **PROBING CC** soft key



- ▶ Hole should be probed automatically: Press the **HOLE** soft key



- ▶ Select paraxial probing direction

- ▶ Start probing function: Press the **NC START** key  
The TNC carries out all pre-positioning and probing processes automatically


The TNC approaches the position at the feed rate **FMAX** defined in the touch probe table. The defined probing feed rate **F** is used for the actual probing operation.



Before starting the automatic probing routine, you need to preposition the touch probe near the first touch point. Offset the touch probe by approximately the safety clearance (value from the touch probe table + value from the input form) opposite to the probing direction.

For inside circles with large diameters, the TNC can also pre-position the touch probe on a circular arc with the positioning feed rate **FMAX**. This requires that you enter a safety clearance for prepositioning and the hole diameter in the input form. Position the touch probe inside the hole at a position that is offset by approximately the safety clearance from the wall. During pre-positioning, note the starting angle for the first probe process (at 0° the TNC probes in the positive direction of the principal axis).

## Selecting the probing cycle



- ▶ Operating mode: Select **Manual operation** or **Electronic handwheel**
- ▶ Select the probing functions: Press the **TOUCH PROBE** soft key
- ▶ Select the touch probe cycle by pressing the appropriate soft key, for example **PROBING POS**, for the TNC to display the associated menu



When you select a manual probing function, the TNC opens a form displaying all data required. The content of the forms varies depending on the respective function.

You can also enter values in some of the fields. Use the arrow keys to move to the desired input field. You can position the cursor only in fields that can be edited. Fields that cannot be edited are shown gray.

## 15.7 Using a 3-D touch probe

## Recording measured values from the touch probe cycles



The TNC must be specially prepared by the machine tool builder for use of this function. Refer to your machine manual.

After executing the respective selected touch probe cycle, the TNC displays the **WRITE LOG TO FILE** soft key. If you press this soft key, the TNC will record the current values determined in the active touch probe cycle.

If you store the measuring results, the TNC creates the text file TCHPRMAN.TXT. If you have not defined a path in the machine parameter **fn16DefaultPath**(no. 102202), the TNC will store the TCHPRMAN.TXT and TCHPRMAN.html files in the main directory TNC:\.



If you press the **WRITE LOG TO FILE** soft key, the TCHPRMAN.TXT file cannot be selected in the **Programming** operating mode. The TNC will otherwise display an error message.

The TNC writes the measured values to the TCHPRMAN.TXT or TCHPRMAN.html file. If you execute several touch probe cycles in succession and want to store the resulting measured data, you must make a backup of the contents stored in TCHPRMAN.TXT between the individual cycles by copying or renaming the file.

Format and content of the TCHPRMAN.TXT file are preset by the machine tool builder.



### Writing measured values from the touch probe cycles to a datum table



Use this function to save measured values in the workpiece coordinate system. If you want to save measured values in the workpiece coordinate system (REF coordinates), press the **ENTRY IN PRESET TABLE** soft key.

**Further Information:** "Writing measured values from the touch probe cycles to the preset table", page 616

With the **ENTER IN DATUM TABLE** soft key, the TNC can write the values measured during any touch probe cycle as applicable to a datum table:

- ▶ Select any probe function
- ▶ Enter the desired coordinates for the datum in the designated input boxes (depends on the touch probe cycle being run)
- ▶ Enter the datum number in the **Number in table=** input box
- ▶ Press the **ENTER IN DATUM TABLE** soft key; the TNC saves the datum in the specified datum table under the entered number

## 15.7 Using a 3-D touch probe

## Writing measured values from the touch probe cycles to the preset table



Use this function if you want to save measured values in the machine coordinate system (REF coordinates). If you want to save measured values in the workpiece coordinate system, press the **ENTER IN DATUM TABLE** soft key.


**Further Information:** "Writing measured values from the touch probe cycles to a datum table", page 615

With the **ENTRY IN PRESET TABLE** soft key, the TNC can write the values measured during any probe cycle in the preset table. The measured values are then stored referenced to the machine coordinate system (REF coordinates). The preset table has the name PRESET.PR, and is saved in the directory TNC:\table\.

- ▶ Select any probe function
- ▶ Enter the desired coordinates for the datum in the designated input boxes (depends on the touch probe cycle being run)
- ▶ Enter the preset number in the **Number in table:** input box
- ▶ Press the **ENTRY IN PRESET TABLE** soft key. The TNC saves the datum in the preset table under the entered number
  - Preset number is not available: The TNC saves the row only after pressing the **OK** soft key (Create row in table?)
  - Preset number is protected: Press the **OK** soft key and the active preset will be overwritten
  - Preset number is password-protected: Press the **OK** soft key, enter the password and the active preset will be overwritten



If writing to the table row is not possible due to a lock, the control displays a message. The probing is not aborted, however.



## 15.8 Calibrating 3-D touch probes

### Introduction

In order to precisely specify the actual trigger point of a 3-D touch probe, you must calibrate the touch probe, otherwise the TNC cannot provide precise measuring results.



Always calibrate a touch probe in the following cases:


- Commissioning
- Broken stylus
- Stylus exchange
- Change in the probe feed rate
- Irregularities caused, for example, when the machine heats up
- Change of active tool axis

When you press the **OK** soft key after calibration, the calibration values are applied to the active touch probe. The updated tool data then become immediately effective, there is no need to retrieve the tool again.





During calibration, the TNC finds the effective length of the stylus and the effective radius of the ball tip. To calibrate the 3-D touch probe, clamp a ring gauge or a stud of known height and known radius to the machine table.

The TNC provides calibration cycles for calibrating the length and the radius:

- ▶ Press the **TOUCH PROBE** soft key
- ▶ Display the calibration cycles: Press **CALIBRATE TS**
- ▶ Select the calibration cycle



### Calibration cycles of the TNC

Soft key	Function	Page
	Calibrating the length	618
	Measure the radius and the center offset using a calibration ring	619
	Measure the radius and the center offset using a stud or a calibration pin	619
	Measure the radius and the center offset using a calibration sphere 3-D calibrating (option 92)	619

## 15.8 Calibrating 3-D touch probes

## Calibrating the effective length




HEIDENHAIN only gives warranty for the function of the probing cycles if HEIDENHAIN touch probes are used.




The effective length of the touch probe is always referenced to the tool datum. The machine tool builder usually defines the spindle tip as the tool datum.

- ▶ Set the datum in the spindle axis such that for the machine tool table  $Z=0$ .



- ▶ Select the calibration function for the touch probe length: Press the **CAL**. Press **L**
- ▶ The TNC displays the current calibration data.
- ▶ Datum for length: Enter the height of the ring gauge in the menu window
- ▶ Move the touch probe to a position just above the ring gauge
- ▶ To change the traverse direction (if necessary), press a soft key or an arrow key
- ▶ Probe surface: Press **NC START** key
- ▶ Check results
- ▶ Press the **OK** soft key for the values to take effect
- ▶ Press the **CANCEL** soft key to terminate the calibrating function.
- ▶ The TNC logs the calibration process in TCHPRMAN.html.



## Calibrating the effective radius and compensating center misalignment




HEIDENHAIN only gives warranty for the function of the probing cycles if HEIDENHAIN touch probes are used.



The center offset can be determined only with a suitable touch probe.

If you want to calibrate using the outside of an object, you need to preposition the touch probe above the center of the calibration sphere or calibration pin. Ensure that the touch points can be approached without collision.



When calibrating the ball tip radius, the TNC executes an automatic probing routine. During the first cycle, the TNC determines the center of the calibration ring or stud (rough measurement) and positions the touch probe in the center. Then the ball tip radius is determined during the actual calibration process (fine measurement). If the touch probe allows probing from opposite orientations, the center offset is determined during another cycle.

The characteristic of whether and how your touch probe can be oriented is predefined in HEIDENHAIN touch probes. Other touch probes are configured by the machine manufacturer.

After the touch probe is inserted, it normally needs to be aligned exactly with the spindle axis. The calibration function can determine the offset between touch probe axis and spindle axis by probing from opposite orientations (rotation by 180°) and can calculate and implement the necessary compensation.


The calibration routine varies depending on how your touch probe can be oriented:

- No orientation possible or orientation possible in only one direction: The TNC executes one rough and one fine measurement and determines the effective ball tip radius (column R in tool.t)
- Orientation possible in two directions (e.g. HEIDENHAIN wired touch probes): The TNC executes one rough and one fine measurement, rotates the touch probe by 180° and then completes one more probing routine. The center offset (CAL\_OF in tchprobe.tp) is determined in addition to the radius by probing from opposite orientations
- Orientation possible in any direction (e.g. HEIDENHAIN infrared systems): The TNC executes one rough and one fine measurement, rotates the touch probe by 180° and then completes one more probing routine. The center offset (CAL\_OF in tchprobe.tp) is determined in addition to the radius by probing from opposite orientations

## 15.8 Calibrating 3-D touch probes

## Calibration using a calibration ring

Proceed as follows for manual calibration using a calibration ring:




- ▶ In the **Manual operation** mode, position the ball tip inside the bore of the ring gauge
- ▶ Select the calibration function: Press the **CAL. R** soft key
- > The TNC displays the current calibration data.
- ▶ Enter the diameter of the ring gauge
- ▶ Enter the start angle
- ▶ Enter the number of touch points
- ▶ Probe: Press the **NC START** key
- > The 3-D touch probe probes all required touch points in an automatic probing routine and calculates the effective ball-tip radius. If probing from opposite orientations is possible, the TNC calculates the center offset.
- ▶ Check results
- ▶ Press the **OK** soft key for the values to take effect
- ▶ Press the **END** soft key to terminate the calibrating function.
- > The TNC logs the calibration process in TCHPRMAN.html.



In order to be able to determine the ball-tip center misalignment, the TNC needs to be specially prepared by the machine manufacturer. Refer to your machine manual.

### Calibration with a stud or calibration pin

Proceed as follows for manual calibration with a stud or calibration pin:



- ▶ In the **Manual operation** mode, position the ball tip above the center of the calibration pin
- ▶ Select the calibration function: Press the **CAL. R** soft key
- ▶ Enter the outside diameter of the stud
- ▶ Enter the safety clearance
- ▶ Enter the start angle
- ▶ Enter the number of touch points
- ▶ Probe: Press the **NC START** key
- ▶ The 3-D touch probe probes all required touch points in an automatic probing routine and calculates the effective ball-tip radius. If probing from opposite orientations is possible, the TNC calculates the center offset.
- ▶ Check results
- ▶ Press the **OK** soft key for the values to take effect
- ▶ Press the **END** soft key to terminate the calibrating function.
- ▶ The TNC logs the calibration process in TCHPRMAN.html.




In order to be able to determine the ball-tip center misalignment, the TNC needs to be specially prepared by the machine manufacturer.

Refer to your machine manual.

## 15.8 Calibrating 3-D touch probes

## Calibration using a calibration sphere

Proceed as follows for manual calibration using a calibration sphere:



- ▶ In the **Manual operation** mode, position the ball tip above the center of the calibration sphere
- ▶ Select the calibration function: Press the **CAL. R** soft key
- ▶ Enter the outside diameter of the ball
- ▶ Enter the safety clearance
- ▶ Enter the start angle
- ▶ Enter the number of touch points
- ▶ Select Length measurement, if applicable
- ▶ If necessary, input the reference for the length
- ▶ Probe: Press the **NC START** key
- The 3-D touch probe probes all required touch points in an automatic probing routine and calculates the effective ball-tip radius. If probing from opposite orientations is possible, the TNC calculates the center offset.
- ▶ Check results
- ▶ Press the **OK** soft key for the values to take effect
- ▶ Press the **END** soft key to terminate the calibrating function or enter the number of probing points for 3-D calibration
- The TNC logs the calibration process in TCHPRMAN.html.




In order to be able to determine the ball-tip center misalignment, the TNC needs to be specially prepared by the machine manufacturer. Refer to your machine manual.



### 3-D calibration with a calibration sphere (option 92)


In addition to calibrating with a calibration sphere, the control also enables the touch probe to be calibrated dependent on the angle. For this purpose the control probes the calibration sphere in a quarter circle in the perpendicular. The 3-D calibration data specifies the deflection behaviour of the touch probe in any probing direction.

The **3D-ToolComp** software option (option 92) is required for this.



- ▶ Execute calibration using a calibration sphere
- ▶ Enter the number of touch points
- ▶ Press the **NC START** key
- ▶ The 3-D touch probe probes all required touch points in an automatic probing routine.
- ▶ Press the **OK** soft key.
- ▶ Press the **END** soft key to terminate the calibrating function.
- ▶ The TNC saves the deviations in a compensation value table at **TNC:\system\3D-ToolComp**.

The control creates a specific table for each calibrated touch probe. In the tool table the **DR2TABLE** column is automatically referenced to this.




# Manual Operation and Setup

## 15.8 Calibrating 3-D touch probes


### Displaying calibration values

The TNC saves the effective length and effective radius of the touch probe in the tool table. The TNC saves the touch probe center offset to the touch probe table in the columns **CAL\_OF1** (principal axis) and **CAL\_OF2** (minor axis). You can display the values on the screen by pressing the **TCH PROBE TABLE** soft key.


During calibration, the TNC automatically creates the TCHPRMAN.html log file to which the calibration values are saved.



Please make sure the correct tool number is active when you use the touch probe system. Regardless of whether you want to use a touch probe cycle in automatic mode or **Manual operation** mode.



For more information about the touch probe table, refer to the User's Manual for Cycle Programming




## 15.9 Compensating workpiece misalignment with 3-D touch probe

### Introduction



HEIDENHAIN only gives warranty for the function of the probing cycles if HEIDENHAIN touch probes are used.

Make sure during probing that the axis angles match the set tilt angles. The control checks this automatically if the **chkTiltingAxes** machine parameter (no. 204601) is activated.



The TNC electronically compensates workpiece misalignment by computing a "basic rotation."

For this purpose, the TNC sets the rotation angle to the desired angle with respect to the reference axis in the working plane.

The TNC interprets the measured angle as rotation around the tool direction, and saves the values in the columns SPA, SPB or SPC of the preset table.

To identify the basic rotation, probe two points on the side of the workpiece. The sequence in which you probe the points influences the calculated angle. The measured angle goes from the first to the second probing point. You can also identify the basic rotation by holes or studs.



Select the probe direction perpendicular to the angle reference axis when measuring workpiece misalignment.

To ensure that the basic rotation is calculated correctly during program run, program both coordinates of the working plane in the first positioning block.


You can also use a basic rotation in conjunction with the PLANE function. In this case, first activate the basic rotation and then the PLANE function.

You can also activate a basic rotation without probing a workpiece. For this purpose enter a value in the basic rotation menu and press the **SET BASIC ROTATION** soft key.

## Manual Operation and Setup

### 15.9 Compensating workpiece misalignment with 3-D touch probe

#### Identifying basic rotation



- ▶ Select the probing function by pressing the **PROBE ROTATION** soft key
- ▶ Position the touch probe at a position near the first touch point
- ▶ Select the probe direction or probing routine by soft key
- ▶ Probe: Press the **NC START** key
- ▶ Position the touch probe at a position near the second touch point
- ▶ Probe: Press the **NC START** key. The TNC determines the basic rotation and displays the angle after the dialog **Rotation angle**
- ▶ Activate basic rotation: Press the **SET BASIC ROTATION** soft key
- ▶ To terminate the probe function, press the **END** soft key

The TNC logs the probing process in TCHPRMAN.html.

#### Saving a basic rotation in the preset table

- ▶ After the probing process, enter the preset number in which the TNC is to save the active basic rotation in the **Number in table:** input box
- ▶ Press the **BASIC ROT.** Press the **BASIC ROT. IN PRESET TABLE** soft key to save the basic rotation in the preset table


#### Compensation of workpiece misalignment by rotating the table

- ▶ To compensate the identified misalignment by a rotary table position, press the **ALIGN ROT.** soft key after the probing process **ALIGN ROT. TABLE**



Position all axes to avoid a collision before table rotation. The TNC outputs an additional warning before table rotation.

- ▶ If you want to set the datum in the rotary table axis, press the **SET TABLE ROTATION** soft key.
- ▶ You can also save the misalignment of the rotary table in any line of the Preset table. Enter the line number and press the **TABLE ROT. IN PRESET TABLE** soft key. The TNC stores the angle in the offset column of the rotary table, e.g. with a C axis in the C\_OFFS column. You may have to change the view in the preset table with the **BASIS-TRANSFORM./OFFSET** soft key for this column to be displayed.




## Compensating workpiece misalignment with 3-D touch probe 15.9

### Displaying a basic rotation

When you select the **PROBING ROT** function, the TNC displays the active angle of basic rotation in the **Rotation angle** dialog. In addition, the rotary angle is shown in the split screen **PROGRAM + STATUS** screen layout in the **STATUS POS.** tab.

When the TNC moves along the machine axis in accordance with the basic rotation, a symbol for the basic rotation is shown in the status display.



### Canceling a basic rotation

- ▶ Select the probe function by pressing the **PROBING ROT** soft key
- ▶ Enter a rotation angle of "0" and confirm with the **SET BASIC ROTATION** soft key
- ▶ To terminate the probe function, press the **END** soft key

### Measuring 3-D basic rotation

The misalignment of any tilted plane can be measured by probing 3 positions. The **Probe in plane** function enables you to measure this misalignment and save it as a 3-D basic rotation in the preset table.



#### Please take the following into account when selecting probe points:

The sequence and position of the touch points determines how the TNC calculates the direction of the plane.


With the first two points you specify the direction of the reference axis. Define the second point in the positive direction of the desired reference axis. The position of the third point determines the direction of the minor axis and tool axis. Define the third point in the positive Y axis of the desired workplace coordinate system.

- 1ST point: On the reference axis
- 2ND point: On the reference axis, in a positive direction from the first point
- 3RD point: On the minor axis, in a positive direction of the desired workpiece coordinate system

Optionally inputting a datum angle enables you to define the nominal direction of the probed plane.


## Manual Operation and Setup

### 15.9 Compensating workpiece misalignment with 3-D touch probe




- ▶ Select the probing function: Press the **PROBING PL** soft key. The TNC then displays the current 3-D basic rotation
- ▶ Position the touch probe at a position near the first touch point
- ▶ Select the probe direction or probing routine by soft key
- ▶ Probe: Press the **NC START** key
- ▶ Position the touch probe at a position near the second touch point
- ▶ Probe: Press the **NC START** key
- ▶ Position the touch probe near the third touch point
- ▶ Probe: Press the **NC START** key. The TNC measures the 3-D basic rotation and displays the values for SPA, SPB and SPC in relation to the active coordinate system
- ▶ If required, enter the datum angle

Activate 3-D basic rotation:



- ▶ Press the **SET BASIC ROTATION** soft key

Saving a 3-D basic rotation in the preset table:



- ▶ Press the **BASIC ROT. IN PRESET TABLE** soft key



- ▶ To terminate the probe function, press the **END** soft key


The TNC saves the 3-D basic rotation in the columns SPA, SPB or SPC of the preset table.

#### Aligning 3-D basic rotation


If the machine has two rotary axes and the probed 3-D basic rotation is activated, you can align the rotary axes with reference to the 3-D basic rotation using the **ALIGN ROT.** soft key. Align **ALIGN ROT. AXES**. In such cases, Tilted Working Plane becomes active for all machine operating modes.

After aligning the plane, you can align the reference axis with the **Probing rot** function.

#### Displaying 3-D basic rotation

When a 3-D basic rotation is saved in the active datum, the TNC shows the  symbol for the 3-D basic rotation in the status display. The TNC traverses the machine axes according to the 3-D basic rotation.

#### Canceling a 3-D basic rotation







- ▶ Select the probe function by pressing the **PROBING PL** soft key
- ▶ Enter 0 for all angles
- ▶ Press the **SET BASIC ROTATION** soft key
- ▶ To terminate the probe function, press the **END** soft key

## 15.10 Datum setting with a 3-D touch probe

### Overview


The following soft-key functions are available for setting a datum on an aligned workpiece:

Soft key	Function	Page
	Datum setting on any axis with	629
	Setting a corner as datum	630
	Setting a circle center as datum	631
	Center line as datum Setting the center line as datum	634



Please ensure that the TNC refers to the probed value on the active datum or the last defined datum in **MANUAL OPERATION** mode with active datum shift. The datum shift is included in the position display.


### Datum setting on any axis



- ▶ Select the probing function by pressing the **POSITION PROBING** soft key
- ▶ Move the touch probe to a position near the touch point
- ▶ Select the axis and probing direction, e.g. Probe in direction Z-
- ▶ Probe: Press the **NC START** key
- ▶ **Datum:** Enter the nominal coordinates, confirm with the **SET DATUM** soft key
- ▶ **Further Information:** "Writing measured values from the touch probe cycles to a datum table", page 615
- ▶ To terminate the probe function, press the **END** soft key




HEIDENHAIN only gives warranty for the function of the probing cycles if HEIDENHAIN touch probes are used.




## 15.10 Datum setting with a 3-D touch probe

## Corner as datum



- ▶ Select the probing function: Press the **PROBING P** soft key
- ▶ Position the touch probe near the first touch point on the first workpiece edge
- ▶ Select the probe direction by soft key
- ▶ Probe: Press the **NC START** key
- ▶ Position the touch probe near the second touch point on the same workpiece edge
- ▶ Probe: Press the **NC START** key
- ▶ Position the touch probe near the first touch point on the second workpiece edge
- ▶ Select the probe direction by soft key
- ▶ Probe: Press the **NC START** key
- ▶ Position the touch probe near the second touch point on the same workpiece edge
- ▶ Probe: Press the **NC START** key
- ▶ **Datum:** Enter both datum coordinates into the menu window and confirm your entry with the **SET DATUM** soft key
- ▶ **Further Information:** "Writing measured values from the touch probe cycles to the preset table", page 616
- ▶ To terminate the probe function, press the **END** soft key



HEIDENHAIN only gives warranty for the function of the probing cycles if HEIDENHAIN touch probes are used.



You can identify the intersection of two straight lines by holes or studs and set this as the datum.

The "Corner as datum" probing cycle identifies the angle and intersection of two straight lines. In addition to datum setting, the cycle can also activate a basic rotation. The TNC has two soft keys for you to determine the straight line that you wish to use for this. The **ROT 1** soft key activates the angle of the first straight line as basic rotation and the **ROT 2** soft key the angle of the second straight line.

If you wish to activate the basic rotation in the cycle, you must always do this before datum setting. After you set a datum and write it into a datum table or preset table, the soft keys **ROT 1** and **ROT 2** will no longer be displayed.



### Circle center as datum

With this function, you can set the datum at the center of bore holes, circular pockets, cylinders, studs, circular islands, etc.


#### Inside circle:

The TNC probes the inside wall of a circle in all four coordinate axis directions.

For incomplete circles (circular arcs) you can choose the appropriate probing direction.



- ▶ Position the touch probe approximately in the center of the circle
- ▶ Select the touch probe function: Press the **PROBING CC** soft key
- ▶ Select the soft key for the desired probing direction
- ▶ Probe: Press the **NC START** key. The touch probe probes the inside wall of the circle in the selected direction. Repeat this process. After the third probing operation, you can have the TNC calculate the center (four touch points are recommended)
- ▶ Terminate the probing procedure and switch to the evaluation menu: Press the **EVALUATE** soft key
- ▶ **Datum:** In the menu window, enter both coordinates of the circle center, confirm with the **SET DATUM** soft key, or write the values to a table  
**Further Information:** "Writing measured values from the touch probe cycles to a datum table", page 615  
**Further Information:** "Writing measured values from the touch probe cycles to the preset table", page 616
- ▶ To terminate the probe function, press the **END** soft key




The TNC needs only three touch points to calculate outside or inside circles, e.g. with circle segments. More precise results are obtained if you measure circles using four touch points, however. You should always preposition the touch probe in the center, or as close to the center as possible.

## 15.10 Datum setting with a 3-D touch probe

## Outside circle:



- ▶ Position the touch probe at a position near the first touch point outside of the circle
- ▶ Select the touch probe function: Press the **PROBING CC** soft key
- ▶ Select the soft key for the desired probing direction
- ▶ Probe: Press the **NC START** key. The touch probe probes the inside wall of the circle in the selected direction. Repeat this process. After the third probing operation, you can have the TNC calculate the center (four touch points are recommended)
- ▶ Terminate the probing procedure and switch to the evaluation menu: Press the **EVALUATE** soft key
- ▶ **Datum:** Enter the coordinates of the datum, confirm with the **SET DATUM** soft key, or write the values to a table  
**Further Information:** "Writing measured values from the touch probe cycles to a datum table", page 615  
**Further Information:** "Writing measured values from the touch probe cycles to the preset table", page 616)
- ▶ To terminate the probe function, press the **END** soft key



Once the probing routine is completed, the TNC displays the current coordinates of the circle center and the circle radius.

### Setting the datum using multiple holes/cylindrical studs

The manual probing function **Model Circle** is part of the **Cir** probing function. Individual circles can be determined with paraxial probing operations.

A second soft-key row provides the soft key **PROBING CC (model circle)** for using multiple holes or circular studs to set the datum. You can set the intersection of two or more elements as datum.

### Setting the datum in the intersection of multiple holes/circular studs:

- Pre-position touch probe

Select **Model Circle** probing function




- Select the touch probe function: Press the **PROBING CC** soft key




- Press the **PROBING CC (model circle)** soft key

Probe a circular stud



- Circular stud should be probed automatically: Press **STUD** soft key



- Enter starting angle or select using soft key




- Start probing function: Press the **NC START** soft key

Probe the hole.



- Hole should be probed automatically: Press the **HOLE** soft key




- Enter starting angle or select using soft key



- Start probing function: Press the **NC START** soft key
- Repeat the probing procedure for the remaining elements
- Terminate the probing procedure and switch to the evaluation menu: Press the **EVALUATE** soft key
- **Datum:** In the menu window, enter both coordinates of the circle center, confirm with the **SET DATUM** soft key, or write the values to a table  
**Further Information:** "Writing measured values from the touch probe cycles to a datum table", page 615  
**Further Information:** "Writing measured values from the touch probe cycles to the preset table", page 616
- To terminate the probe function, press the **END** soft key

## 15.10 Datum setting with a 3-D touch probe



## Setting a center line as datum



- ▶ Select the probing function: Press the **PROBING CL** soft key
- ▶ Position the touch probe at a position near the first touch point
- ▶ Select the probing direction by soft key
- ▶ Probe: Press the **NC START** key
- ▶ Position the touch probe at a position near the second touch point
- ▶ Probe: Press the **NC START** key
- ▶ **Datum:** Enter the coordinates of the datum in the menu window, confirm with the **SET DATUM** soft key, or write the value to a table  
**Further Information:** "Writing measured values from the touch probe cycles to a datum table", page 615  
**Further Information:** "Writing measured values from the touch probe cycles to the preset table", page 616
- ▶ To terminate the probe function, press the **END** soft key



After you have measured the second touch point, you can use the evaluation menu to change the direction of the centerline. Using the soft keys, you can choose whether the datum should be set in the principal axis, minor axis or tool axis. This may be required if you want to save the set position on the principal or minor axis.



## Measuring workpieces with a 3-D touch probe


You can also use the touch probe in the **Manual operation** and **Electronic handwheel** operating modes to perform simple measurements on the workpiece. Numerous programmable touch probe cycles are available for more complex measuring tasks.

**Further information:** Cycle Programming User's Manual

With a 3-D touch probe you can determine:

- Position coordinates, and from them,
- Dimensions and angles on the workpiece

### Finding the coordinates of a position on an aligned workpiece



- ▶ Select the probing function: Press the **PROBING POS** soft key
- ▶ Move the touch probe to a position near the touch point
- ▶ Select the probing direction and the axis to which the coordinates relate: Use the corresponding soft keys to select
- ▶ Start the probing process: Press the **NC START** key

The TNC shows the coordinates of the touch point as reference point.

### Finding the coordinates of a corner point on the working plane

Find the coordinates of the corner point.


**Further Information:** "Corner as datum ", page 630

The TNC displays the coordinates of the probed corner as datum.


## Manual Operation and Setup

### 15.10 Datum setting with a 3-D touch probe

#### Measuring workpiece dimensions



- ▶ Select the probing function: Press the **PROBING POS** soft key
- ▶ Position the touch probe at a position near the first touch point A
- ▶ Select the probing direction by soft key
- ▶ Probe: Press the **NC START** key
- ▶ If you need the current datum later, write down the value that appears in the Datum display
- ▶ Datum: Enter "0"
- ▶ Cancel the dialog: Press the **END** key
- ▶ Select the probing function again: Press the **PROBING POS** soft key
- ▶ Position the touch probe at a position near the second touch point B
- ▶ Select the probe direction with the soft keys: Same axis but from the opposite direction
- ▶ Probe: Press the **NC START** key



The **Measured value** display shows the distance between the two points on the coordinate axis.

#### To return to the datum that was active before the length measurement:

- ▶ Select the probing function: Press the **PROBING POS** soft key
- ▶ Probe the first touch point again
- ▶ Set the datum to the value that you wrote down previously
- ▶ Cancel the dialog: Press the **END** key

#### Measuring angles

You can use the 3-D touch probe to measure angles in the working plane. You can measure


- The angle between the angle reference axis and a workpiece edge; or
- the angle between two sides

The measured angle is displayed as a value of max. 90°.


### Finding the angle between the angle reference axis and a workpiece edge




- ▶ Select the probe function by pressing the **PROBING ROT** soft key
- ▶ Rotation angle: If you wish to restore the current basic rotation later, note the value that appears under Rotation Angle
- ▶ Perform a basic rotation with the workpiece edge to be compared  
**Further Information:** "Compensating workpiece misalignment with 3-D touch probe ", page 625
- ▶ Press the **PROBING ROT** soft key to display the angle between the angle reference axis and the workpiece edge as the rotation angle
- ▶ Cancel the basic rotation, or restore the previous basic rotation
- ▶ Set the rotation angle to the value that you previously wrote down



### Measuring the angle between two workpiece edges



- ▶ Select the probe function by pressing the **PROBING ROT** soft key
- ▶ Rotation angle: If you wish to restore the current basic rotation later, note the value that appears under Rotation Angle
- ▶ Perform a basic rotation with the workpiece edge to be compared  
**Further Information:** "Compensating workpiece misalignment with 3-D touch probe ", page 625
- ▶ Probe the second edge in the same way as for a basic rotation, but do not set the rotation angle to 0
- ▶ Press the **ROTATION PROBING** soft key to display the angle PA between the workpiece edges as the rotation angle
- ▶ Cancel the basic rotation, or restore the previous basic rotation by setting the rotation angle to the value that you wrote down previously



## Manual Operation and Setup


### 15.11 Tilting the working plane (option 8)

#### 15.11 Tilting the working plane (option 8)

##### Application, function



The functions for tilting the working plane are interfaced to the control and the machine tool by the machine tool builder. With some swivel heads and tilting tables, the machine tool builder determines whether the entered angles are interpreted as coordinates of the rotary axes or as angular components of a tilted plane. Refer to your machine manual.



The TNC supports the tilting functions on machine tools with swivel heads and/or tilting tables. Typical applications are, for example, oblique holes or contours in an oblique plane. The working plane is always tilted around the active datum. The program is written as usual in a main plane, such as the X/Y plane, but is executed in a plane that is tilted relative to the main plane.

There are three functions available for tilting the working plane:

- Manual tilting with the **3-D ROT** soft key in the **Manual operation** and **Electronic handwheel** modes  
**Further Information:** "Activating manual tilting:", page 641
- Controlled tilting, Cycle **19 MACHINING PLANE** in machining program  
**Further information:** Cycle Programming User's Manual
- Tilting under program control, **PLANE** function in the machining program  
**Further Information:** "The PLANE function: Tilting the working plane (software option 8)", page 485

The TNC functions for tilting the working plane are coordinate transformations. The working plane is always perpendicular to the direction of the tool axis.



## Tilting the working plane (option 8) 15.11

When tilting the working plane, the TNC differentiates between two machine types:

### ■ Machine with tilting table

- You must tilt the workpiece into the desired position for machining by positioning the tilting table, for example with an L block.
- The position of the transformed tool axis **does not change** in relation to the machine coordinate system. Thus if you rotate the table—and therefore the workpiece—by 90° for example, the coordinate system **does not rotate**. If you press the Z+ axis direction button in the **Manual operation** mode, the tool moves in Z+ direction.
- In calculating the transformed coordinate system, the TNC considers only the mechanically influenced offsets of the particular tilting table (the "translational" components).

### ■ Machine with swivel head

- You must tilt the workpiece into the desired position for machining by positioning the swivel head, for example with an L block
- The position of the transformed tool axis changes in relation to the machine coordinate system. Thus if you rotate the swivel head of your machine—and therefore the tool—in the B axis by 90° for example, the coordinate system rotates also. If you press the Z+ axis direction button in the **Manual operation** mode, the tool moves in X+ direction of the machine coordinate system.
- In calculating the active coordinate system, the TNC considers both the mechanically influenced offsets of the particular swivel head (the so-called "translational" components) and offsets caused by tilting of the tool (3-D tool length compensation).



The TNC only supports tilting the working plane with spindle axis Z.

## Manual Operation and Setup

### 15.11 Tilting the working plane (option 8)

#### Traversing datums in tilted axes

The TNC automatically activates the tilted working plane if this function was enabled when the control was switched off. Then the TNC moves the axes in the tilted coordinate system when an axis-direction key is pressed. Position the tool in such a way that a collision is excluded during the subsequent crossing of the datums. To scan the reference points you have to deactivate the "Tilt Working Plane" function,

**Further Information:** "Activating manual tilting:", page 641



#### **Danger of collision!**

Make sure that the Tilt working plane function is active in the **MANUAL OPERATION** mode and that the angle values entered in the menu match the actual angles of the tilted axis.

Deactivate the "Tilt Working Plane" function before you cross the reference points. Take care that there is no collision. Retract the tool from the current position first, if necessary.

#### Position display in a tilted system


The positions displayed in the status window (**ACTL.** and **NOML.**) are referenced to the tilted coordinate system.

#### Limitations on working with the tilting function

- The **Actual-position capture** function is not allowed if the Tilt working plane function is active
- PLC positioning (determined by the machine tool builder) is not possible.

## Tilting the working plane (option 8) 15.11

### Activating manual tilting:



- To select manual tilting, press the **3-D ROT** soft key.



- Use the arrow keys to move the cursor to the menu point **Manual operation**



- To activate manual tilting, press the **ACTIVE** soft key




- Use the arrow keys to position the cursor on the desired rotary axis

- Enter the tilt angle



- Terminate the entry: Press the **END** key



If the tilted working plane function is active and the TNC moves the machine axes in accordance with the tilted axes, the status display shows the symbol.

If you set the "Tilt working plane" function for the **Program run** operating mode to **Active**, the tilt angle entered in the menu becomes active in the first block of the machining program. If you use Cycle **19 WORKING PLANE** or the **PLANE** function in the machining program, the angle values defined there are in effect. Angle values entered in the menu will be overwritten.

## 15.11 Tilting the working plane (option 8)



The control uses the following **transformation types** for tilting:

- **COORD ROT**
  - if a **PLANE** function was previously executed with **COORD ROT**
  - after **PLANE RESET**
  - with corresponding configuration of the machine parameter **CfgRotWorkPlane**(no. 201200) by the machine tool builder
    - after starting the control
    - after switching the kinematics
    - after running the cycle **19 WORKING PLANE**
- **TABLE ROT**
  - if a **PLANE** function was previously executed with **TABLE ROT**
  - with corresponding configuration of the machine parameter **CfgRotWorkPlane**(no. 201200) by the machine tool builder
    - after starting the control
    - after switching the kinematics
    - after running the cycle **19 WORKING PLANE**

#### To deactivate manual tilting

To deactivate, set the appropriate operating modes to **Inactive** in the **Tilt working plane** menu.

Even if the **3D-ROT** dialog in the **Manual operation** mode is set to **Active**, resetting the tilting (**PLANE RESET**) with an active basic transformation still functions correctly.

## Tilting the working plane (option 8) 15.11


### Setting the tool-axis direction as the active machining direction



This function must be enabled by your machine manufacturer. Refer to your machine manual.

Using this function in the **Manual operation** and **Electronic handwheel** operating modes, you can move the tool in the direction in which the tool axis is currently pointed using the axis direction keys or with the handwheel. Use this function if

- You want to retract the tool in the direction of the tool axis during suspension of a 5-axis machining program
- You want to machine with an inclined tool using the handwheel or the axis direction keys in Manual Operation mode



- ▶ To select manual tilting, press the **3-D ROT** soft key.




- ▶ Use the arrow keys to move the cursor to the menu item **Manual operation**




- ▶ To activate the current tool axis direction as the active machining direction, press the **TOOL AXIS** soft key



- ▶ Terminate the entry: Press the **END** key



To deactivate the tilting function, set the **Manual operation** menu item in the "Tilt working plane" menu to inactive.

The  symbol appears in the status display when the Move in tool axis direction function is active.



This function is even available when you interrupt program run and want to move the axes manually.

## 15.11 Tilting the working plane (option 8)

**Setting a datum in a tilted coordinate system**

After you have positioned the rotary axes, set the preset in the same manner as for a non-tilted system. The behavior of the TNC during datum setting depends on the setting in machine parameter **chkTiltingAxes** (no. 204601):

- **chkTiltingAxes: On** With an active tilted working plane, the TNC checks during datum setting in the X, Y and Z axes whether the current coordinates of the rotary axes agree with the tilt angles that you defined (3-D ROT menu). If the Tilt working plane function is not active, the TNC checks whether the rotary axes are at 0° (actual positions). If the positions do not reconcile, then the TNC issues an error message.
- **chkTiltingAxes: Off** The TNC does not check whether the current coordinates of the rotary axes (actual positions) agree with the tilt angles that you have defined.

**Danger of collision!**

Always set a reference point in all three reference axes.

## Camera-based monitoring of the setup situation VSC (option 15.12 number136)

### 15.12 Camera-based monitoring of the setup situation VSC (option number136)

#### Basics

#### Application



Refer to your machine manual.

This feature must be enabled and adapted by the machine tool builder.

Camera-based checking of the setup situation (option number 136 Visual Setup Control) allows you to monitor the current setup situation before and during processing, and to compare this with a safe target status. After setup, simple cycles for automatic monitoring are available.

Reference images of the current working space are recorded in the camera system. With Cycles 600 **GLOBAL WORKING SPACE** or 601 **LOCAL WORKING SPACE**, the TNC produces an image of the working space and compares the image with previously prepared reference images. These cycles can highlight irregularities in the working space. The operator decides whether the NC program is interrupted in the event of an error or continues to run.

Using VSC offers the following advantages:

- The control can recognize elements (e.g. tools, fixtures, etc.) that are in the working space once the program has started
- If you always want to clamp a workpiece at the same position (e.g. hole at top right), the control can check the clamping situation
- For documentation purposes you can generate an image of the current workspace (e.g. of a clamping situation that is rarely used)

**Further information:** Cycle Programming User's Manual

#### Requirements

As well as option number 136, a HEIDENHAIN camera system is required for VSC functions.

You must create an adequate number of reference images to allow the system to compare the situation reliably.

## Manual Operation and Setup

### 15.12 Camera-based monitoring of the setup situation VSC (option number136)

#### Terms

The following terms are used in connection with VSC:






Term	Explanation
Reference image	A reference image shows a situation in the working space that you regard as safe. Therefore only create reference images showing safe, non-hazardous situations.
Mid-value image	The control creates a mid-value image taking into account all reference images. The control compares new images with the mid-value image as part of evaluation.
Error	<p>If you generate an image showing a poor situation (such as an incorrectly clamped workpiece), you can generate an "image of error"</p> <p>It is not advisable to highlight an error image as a reference image.</p>
Monitoring area	Denotes an area that you highlight with the mouse. When evaluating new images, the control only refers to this area. Parts of images outside the monitoring area have no effect on the results of the monitoring process. Several monitoring areas can be defined. Monitoring areas are not linked to images.
Error	Area on an image containing a deviation from the desired position. Errors always refer to the image for which they were saved (image of error) or to the image most recently evaluated.
Monitoring phase	No further reference images are produced in the monitoring phase. You can use the cycle for automatic monitoring of your working space. In this phase, the control only issues a warning if it finds a deviation when comparing images.



# Camera-based monitoring of the setup situation VSC (option 15.12 number136)

## Overview

In the **Manual operation** mode, the control offers the following options:

Soft key	Function
	Open main VSC menu
	Show current camera view Produce live image
	Open VSC file manager The control shows the data saved for Cycle 600 and Cycle 601.
	Open camera cover
	Close camera cover

## Manual Operation and Setup

### 15.12 Camera-based monitoring of the setup situation VSC (option number136)

#### Produce live image

In the **Manual operation** mode, you can display and save the current camera view as a live image.

The control does not use the image captured here for automatic checking of the clamping situation. Images produced in this menu may be used for documentation and traceability. For example, you could record the current setup situation. The control saves the image produced as a .png file in **TNC:\system\visontool\live\_view**. The name of the saved image is made up of the date and time it was created.



#### Procedure

Proceed as follows to save the camera's live image:

- ▶ Press the **CAMERA** soft key
- ▶ Press the **LIVE IMAGE** soft key: The TNC shows you the current camera view
- ▶ Press the **SAVE IMAGE** soft key: Create a live image from the current camera view

#### Options in Live Image mode

The control provides the following options:

Soft key	Function
LIGHTER	Increase camera brightness The settings made here only affect Live Image mode, and have no influence on pictures taken in automatic mode.
DARKER	Reduce camera brightness The settings made here only affect Live Image mode, and have no influence on pictures taken in automatic mode.
VSC SETTINGS	Configuring the field of view of the camera Refer to your machine manual. These settings can only be made after entering a code number.
GO BACK	Go back to the previous screen

## Camera-based monitoring of the setup situation VSC (option 15.12 number136)

### Manage monitoring data

In the **Manual operation** mode you can manage images from Cycles 600 and 601.

Proceed as follows to enter the monitoring data:



- Press the **CAMERA** soft key



- Press the **MONITORING DATA MANAGEMENT** soft key: The control shows a list of the NC programs monitored




- Press the **OPEN** soft key: The control shows a list of monitoring points
- Edit the desired data






### Select data

You can select the buttons with the mouse. These interfaces make it easier to search and show results in a manageable way.

- **All images:** Display all images for this monitoring file
- **Reference images:** Only display reference images
- **Images with error:** Display all images where you have highlighted an error



### Features of the monitoring data management










Soft key	Function
	Mark selected image as a reference image Please note: A reference image shows a situation in the working space that you regard as safe. All reference images are used as part of the evaluation process. If you add or remove an image as a reference image, this has an effect on the results of image evaluation.
	Delete image currently selected
	Carry out automatic image evaluation The control carries out an image evaluation according to the reference images and the monitoring areas.
	Change monitoring area or highlight an error <b>Further Information:</b> "Configuration", page 650
	Go back to the previous screen If you change the configuration, the control carries out an image evaluation.

## Manual Operation and Setup

### 15.12 Camera-based monitoring of the setup situation VSC (option number136)

#### Configuration

You have the option of changing your settings for the monitoring area and errors at any time. When you press the **CONFIGURE** soft key, the soft key display changes and you can change your settings.

Soft key	Function
	Change settings for the monitoring area and sensitivity If you make a change in this menu, the results of the image evaluation may change.
	Draw new monitoring area If you add a new monitoring area, or change/delete monitoring areas already set, this will have an effect on the image evaluation. The same monitoring area applies to all reference images.
	Draw new error
	The control checks if or how the new settings affect this image
	The control checks if or how the new settings affect all images
	The control shows all drawn monitoring areas
	The control compares the momentary image with the mean image
	Save current image and return to the previous screen If you change the configuration, the control carries out an image evaluation.
	Discard images and return to the previous screen

You can also zoom the image with the buttons and shift the magnified image section with the mouse or arrow keys.

#### To draw the monitoring area or error area

Proceed as follows:

- ▶ Press the appropriate soft key, e.g. **DRAW AREA**
- ▶ Click on the image and select the area with the mouse
- > The control indicates the clicked area with a frame.
- ▶ Shift the area if required by holding down the mouse button

You can fix the drawn area by double-clicking it, thereby protecting it from unintentional shifting.

#### Deleting drawn areas

If you have drawn several monitoring areas or error areas, you can delete these individually.

Proceed as follows:

- ▶ Click on the area you wish to delete
- > The control indicates the clicked area with a frame.
- ▶ Press the **Delete** button

## Camera-based monitoring of the setup situation VSC (option 15.12 number136)

### Results of the image evaluation




The results of the image evaluation depend on the monitoring area and the reference images. When evaluating all images, each image is evaluated according to the current configuration and the results are compared with the data last saved.

If you change the monitoring area or add/delete reference images, the images may be tagged with the following symbol:

- **Triangle:** You have changed the monitoring data, e.g. tagged an image with errors as a reference image or deleted a monitoring area. This makes the monitoring less sensitive.

This has an effect on your reference images and on the mid-value image. As a result of your change to the configuration, the control can no longer detect errors that had been saved for this image! If you would like to continue, confirm the reduced monitoring sensitivity and the new settings will be accepted.

- **Solid circle:** You have changed the monitoring data, monitoring is more sensitive.
- **Blank circle:** No error message: All deviations saved in the image have been recognized, monitoring has not identified any conflicts.





# 16

**Positioning with  
Manual Data Input**

## 16.1 Programming and executing simple machining operations

### 16.1 Programming and executing simple machining operations

The **Positioning with manl.data input** mode of operation is particularly convenient for simple machining operations or to pre-position the tool. It enables you to write a short program, depending on the **programInputMode** (no. 101201), in HEIDENHAIN Klartext conversational programming or in ISO format, and execute it immediately. The program is stored in the file \$MDI.

You can use the following functions for example:

- Cycles
- Radius compensation
- Program section repetitions
- Q parameters

In the **Positioning with manl.data input** mode of operation, the additional status display can also be activated.



#### **Danger of collision!**

The control loses modally affective program information and therefore contextual references after the following handling:

- Cursor movement to another NC block
- The jump command **GOTO** to another NC block
- Editing an NC block
- Modifying Q parameter values with the **Q INFO** soft key
- Switching the operating modes

Loss of this contextual reference may cause undesired tool positions!



### Positioning with manual data input (MDI)



- ▶ Switch to the **Positioning with manl.data input** mode of operation



- ▶ Program the desired available function
- ▶ Press the **NC START** key
- ▶ The control executes the highlighted NC block.  
**Further Information:** "Programming and executing simple machining operations", page 654



#### Limitation

The following functions are not available in the **Positioning with manl.data input** operating mode:

- FK free contour programming
- Program call
  - **PGM CALL**
  - **SEL PGM**
  - **CALL SELECTED PGM**
- Programming graphics
- Program-run graphics



Using the **SELECT BLOCK** and **CUT OUT BLOCK** soft keys etc. you can also conveniently and rapidly reuse program sections from other NC programs.

**Further Information:** "Marking, copying, cutting and inserting program sections", page 143



You can control and modify Q parameters with the soft keys **Q PARAMETER LIST** and **Q INFO**.

**Further Information:** "Checking and changing Q parameters", page 344


# 16 Positioning with Manual Data Input

## 16.1 Programming and executing simple machining operations

### Example 1

A hole with a depth of 20 mm is to be drilled into a single workpiece. After clamping and aligning the workpiece and setting the datum, you can program and execute the drilling operation with a few lines of programming.

First you pre-position the tool above the workpiece with straight-line blocks and position with a safety clearance of 5 mm above the hole. Then drill the hole with Cycle **200 DRILLING**.



<b>0 BEGIN PGM \$MDI MM</b>	
<b>1 TOOL CALL 1 Z S2000</b>	Call the tool: tool axis Z, spindle speed 2000 rpm
<b>2 L Z+200 R0 FMAX</b>	Retract the tool (F MAX = rapid traverse)
<b>3 L X+50 Y+50 R0 FMAX M3</b>	Move the tool at F MAX to a position above the hole, spindle on
<b>4 CYCL DEF 200 DRILLING</b>	
<b>Q200=5 ;SET-UP CLEARANCE</b>	Set-up clearance of the tool above the hole
<b>Q201=-15 ;DEPTH</b>	Hole depth (algebraic sign=working direction)
<b>Q206=250 ;FEED RATE FOR PLNGNG</b>	Feed rate for drilling
<b>Q202=5 ;PLUNGING DEPTH</b>	Depth of each infeed before retraction
<b>Q210=0 ;DWELL TIME AT TOP</b>	Dwell time after every retraction in seconds
<b>Q203=-10 ;SURFACE COORDINATE</b>	Coordinate of the workpiece surface
<b>Q204=20 ;2ND SET-UP CLEARANCE</b>	Set-up clearance of the tool above the hole
<b>Q211=0.2 ;DWELL TIME AT DEPTH</b>	Dwell time in seconds at the hole bottom
<b>Q395=0 ;DEPTH REFERENCE</b>	Depth referenced to the tool tip or the cylindrical part of the tool
<b>5 CYCL CALL</b>	
<b>6 L Z+200 R0 FMAX M2</b>	Retract the tool
<b>7 END PGM \$MDI MM</b>	

Straight-line function:

**Further Information:** "Straight line L", page 259

### Protecting programs in \$MDI

The \$MDI file is intended for short programs that are only needed temporarily. Nevertheless, you can store a program, if necessary, by proceeding as described below:




- ▶ Operating mode: Press the **Programming** key



- ▶ To call the file manager, press the **PGM MGT** key.




- ▶ Move the highlight to the **\$MDI** file



- ▶ To copy the file: Press the **COPY** soft key

#### DESTINATION FILE =

- ▶ Enter the name under which you want to save the current contents of the \$MDI file, e.g. **HOLE**



- ▶ Press the **OK** soft key.



- ▶ To exit the file manager, press the **END** soft key

**Further Information:** "Copying a single file", page 153



# 17

**Test Run and  
Program Run**

## Test Run and Program Run

### 17.1 Graphics

### 17.1 Graphics

#### Application

In operating modes **Program run, single block** and **Program run, full sequence** and the operating mode **Test run** the TNC graphically simulates a machining operation.

The TNC features the following views:

- Plan view
- Projection in three planes
- 3-D view



In the **Test run** operating mode, you can also use the 3-D line graphics.

The TNC graphic depicts the workpiece as if it were being machined with a cylindrical end mill.

If a tool table is active, the TNC also considers the entries in the LCUTS, TANGLE and R2 columns.

With the model type 3-D **graphic setting** and in turning mode you also see the indexable inserts of the turning tools from **toolturn.trn**.

The TNC will not show a graphic if

- the current program has no valid workpiece blank definition
- no program is selected
- with blank form definition with a subprogram, the BLK FORM block was not yet run







The simulation of programs with 5-axis machining or tilted machining might run at reduced speed. With the MOD menu **Graphic settings** you can decrease the **Model quality** and in that way increase the speed of simulation.

## Speed of the setting test runs



The most recently set speed stays active until a power interruption. After the control is switched on the speed is set to FMAX.

After you have started a program, the TNC displays the following soft keys with which you can set the simulation speed:

Soft key	Functions
	Test program with the speed that will be used when actually running the program (programmed feed rates will be taken into account)
	Increase the simulation speed incrementally
	Decrease the simulation speed incrementally
	Test run at the maximum possible speed (default setting)

You can also set the simulation speed before you start a program:



- ▶ Select the function for setting the simulation speed






- ▶ Select the desired function by soft key, e.g. incrementally increasing the simulation speed

## Test Run and Program Run

### 17.1 Graphics

#### Overview: Display modes




In operating modes **Program run, single block** and **Program run, full sequence** and in the operating mode **Test run** the TNC displays the following soft keys:

Soft key	View
	Plan view
	Projection in three planes
	3-D view



The position of the soft keys depends on the selected operating mode.

The **Test run** mode of operation also offers the following views:

Soft key	View
	Volume view
	Volume view and tool paths
	Tool paths

#### Limitations during program run




The result of the simulation can be faulty if the TNC's computer is overloaded with complicated processing tasks.





### 3-D view

Choose 3-D view:

The high-resolution 3-D view enables you to display the surface of the machined workpiece in greater detail. With a simulated light source, the TNC creates realistic light and shadow conditions.




- Press the 3-D view soft key











## Test Run and Program Run






### 17.1 Graphics

#### Rotating, enlarging and shifting the 3-D view



- Select the functions for rotating and enlarging: The TNC displays the following soft keys:

Soft keys	Function
 	Rotate in 5° steps about the vertical axis
 	Tilt in 5° steps about the horizontal axis
	Enlarge the graphic stepwise
	Reduce the graphic stepwise
	Reset the graphic to its original size and angle
	► Scroll through the soft-key row




Soft keys	Function
 	Move the graphic upward or downward
 	Move the graphic to the left or right
	Reset the graphic to its original position and angle

You can also use the mouse to change the graphic display. The following functions are available:











- In order to rotate the model shown in three dimensions, hold down the right mouse button and move the mouse. If you simultaneously press the shift key, you can only rotate the model horizontally or vertically
- To shift the model shown: Hold the center mouse button or mouse wheel down and move the mouse. If you simultaneously press the shift key, you can only shift the model horizontally or vertically
- To zoom in on a certain area: Mark a zoom area by holding the left mouse button down. After you release the left mouse button, the TNC zooms in on the defined area
- To rapidly magnify or reduce any area: Rotate the mouse wheel backwards or forwards
- To return to the standard display: Press the shift key and simultaneously double-click with the right mouse key. The rotation angle is maintained if you only double-click with the right mouse key

### 3-D view in the Test Run operating mode

The **Test run** mode of operation also offers the following views:




Soft keys	Function
	Volume view
	Volume view and tool paths
	Tool paths

The **Test run** mode of operation also offers the following functions:

Soft keys	Function
	Show workpiece blank frame
	Highlight workpiece edges on 3-D model
	Show a transparent workpiece
	Show the end points of the tool paths
	Show the block numbers of the tool paths
	Show the workpiece in color
	Reset the volume model
	Reset the tool paths
	Display the rapid traverse movements
	<p>Activate measuring</p> <p>If measuring is activated, the control shows the corresponding coordinates in close proximity if you position the mouse cursor on the 3-D graphics of the workpiece.</p>



Note that the range of functions depends on the model quality selected. You can select the model quality in the MOD function **Graphic settings**.







By showing the tool paths you can depict the programmed paths of the TNC in three dimensions. A powerful zoom function is available for recognizing the details quickly.

You can use the tool paths display to inspect programs created externally for irregularities before machining. This can help you to avoid undesirable machining marks on the workpiece. If points were output wrongly by the the postprocessor, machining marks may arise.



The TNC shows traverse movements in rapid traverse in red.


## Plan view

Select the plan view in the **Test run** operating mode:

- 
  - ▶ Press the **FURTHER VIEW OPTIONS** soft key
- 
  - ▶ Press the **PLAN VIEW** soft key

Select plan view in the operating modes **Program run, single block** and **Program run, full sequence**:



- 
  - ▶ Press the **GRAPHICS** soft key
- 
  - ▶ Press the **PLAN VIEW** soft key





## Projection in three planes


The simulation shows three sectional planes and a 3-D model, similar to a technical drawing.

Select projection in three planes in the **Test run** operating mode:


- 
  - ▶ Press the **FURTHER VIEW OPTIONS** soft key
- 
  - ▶ Press the **VIEW ON 3 PLANES** soft key

Select projection in three planes in the operating modes **Program run, single block** and **Program run, full sequence**:


- 
  - ▶ Press the **GRAPHICS** soft key
- 
  - ▶ Press the **VIEW ON 3 PLANES** soft key



## 17.1 Graphics

**Move the sectional planes**



- Select the functions for shifting the sectional plane. The TNC offers the following soft keys:

**Soft keys****Function**

Shift the vertical sectional plane to the right or left



Shift the vertical sectional plane forward or backward




Shift the horizontal sectional plane upwards or downwards

The position of the sectional planes is visible during shifting.

The default setting of the sectional plane is selected so that it lies in the working plane in the workpiece center and in the tool axis on the top surface.



Return sectional planes to default setting:



- Select the function for resetting the sectional planes.



## Repeating graphic simulation

A part program can be graphically simulated as often as desired. To do so you can reset the graphic to the workpiece blank.

Soft key	Function
	Display unmachined blank in the operating modes <b>Program run, single block</b> and <b>Program run, full sequence</b>
	Display unmachined blank in the operating mode <b>Test run</b>

## Tool display

Regardless of the operating mode, you can also show the tool during the simulation.

Soft key	Function
	<b>Program run, full sequence / Program run, single block</b>
	<b>Test run</b>

## Test Run and Program Run

### 17.1 Graphics

#### Measurement of machining time


##### Machining time in the Test Run mode of operation

The control calculates the duration of the tool movements and displays this as machining time in the test run. The control takes feed movements and dwell times into account.

The time calculated by the control can only conditionally be used for calculating the production time because the control does not account for machine-dependent times, such as tool change.



The machining times shown for milling/turning operations in the simulation do not correspond to the actual machining times.



##### Machining time in the machine operating modes

Time display from program start to program end. The timer stops whenever machining is interrupted.

##### Activating the stopwatch function



- ▶ Shift the soft-key row until the soft-key for the stopwatch functions appears



- ▶ Select the stopwatch functions




- ▶ Select the desired function via soft key, e.g. saving the displayed time

##### Soft key

##### Stopwatch functions



Store displayed time



Display the sum of stored time and displayed time



Clear displayed time



## 17.2 Show the workpiece blank in the working space


### Application










In the **Test run** operating mode, you can graphically check the position of the workpiece blank or datum in the machine's working space and activate work space monitoring in the **Test run** mode: Press the **BLANK IN WORK SPACE** soft key to activate this function. Use the soft key **SW LIMIT MONITORING** (in the second soft key row) to activate or deactivate the function.

A transparent cuboid represents the workpiece blank. Its dimensions are shown in the **BLK FORM** table. The TNC takes the dimensions from the workpiece blank definition of the selected program.

For a test run it normally does not matter where the workpiece blank is located within the working space. However, if you activate working-space monitoring, you must graphically shift the workpiece blank so that it lies within the working space. Use the soft keys shown in the table.

You can also activate the current datum for the **Test run** operating mode.



Soft keys	Function
 	Shift workpiece blank in positive/negative X direction
 	Shift workpiece blank in positive/negative Y direction
 	Shift workpiece blank in positive/negative Z direction
	Show workpiece blank referenced to the set datum
	Switch monitoring function on or off
	Display machine reference point







Note that even with **BLK FORM CYLINDER**, a cuboid is shown in the working space as workpiece blank. When **BLK FORM ROTATION** is used, no workpiece blank is shown in the working space.

### 17.3 Functions for program display

#### Overview

In the **Program run single block** and **Program run full sequence** operating mode, the TNC displays the following soft keys for displaying a machining program in pages:

Soft key	Functions
	Go back one screen of the program
	Go forward one screen of the program
	Select start of program
	Select end of program

## 17.4 Test run

### Application

In the **Test run** operating mode, you can simulate programs and program sections to reduce programming errors when programs are running. The TNC checks the programs for the following:

- Geometrical incompatibilities
- Missing data
- Impossible jumps
- Violation of the machine's working space

The following functions are also available:

- Blockwise test run
- Interruption of test at any block
- Optional block skip
- Functions for graphic simulation
- Measure machining time
- Additional status display

## 17.4 Test run

**Danger of collision!**

The TNC cannot graphically simulate all traverse motions actually performed by the machine. These include

- Traverse motions during tool change, if the machine manufacturer defined them in a tool-change macro or via the PLC
- Positioning movements that the machine manufacturer defined in an M-function macro
- Positioning movements that the machine manufacturer performs via the PLC

HEIDENHAIN therefore recommends proceeding with caution for every new program, even when the program test did not output any error message, and no visible damage to the workpiece occurred.

With cuboid workpiece blanks, the TNC starts a program test run after a tool call at the following position:

- In the working plane in the center of the defined **BLK FORM**
- In the tool axis, 1 mm above the **MAX** point defined in the **BLK FORM**

With rotationally symmetric workpiece blanks, the TNC starts a program test run after a tool call at the following position:

- In the machining plane at the position  $X=0, Y=0$
- In the tool axis 1 mm above the defined workpiece blank

In order to ensure unambiguous behavior during program run, after a tool change you should always move to a position from which the TNC can position the tool for machining without causing a collision.



Your machine tool builder can also define a tool-change macro for the **Test run** operating mode. This macro will simulate the exact behavior of the machine. Refer to your machine manual.

## Execute test run



If the central tool file is active, a tool table must be active (status S) to conduct a test run. Select a tool table via the file manager in the **Test run** mode of operation.

For turning tools you can select a turning tool table with the file extension .trn, compatible with the selected tool table. This means that the turning tools must match in both selected tables.

You can select any preset table (status S) for the test run.

After **RESET + START**, line 0 of the temporarily loaded preset table automatically displays the momentarily active datum from **Preset.pr** (execution). Line 0 is selected when starting the test run until you define another datum in the NC program. All datums from lines > 0 are read by the control from the selected preset table of the test run.

With the **BLANK IN WORK SPACE** function, you activate working space monitoring for the test run.

**Further Information:** "Show the workpiece blank in the working space", page 671



- ▶ Operating mode: Press the **Test run** key








- ▶ Call the file manager with the **PGM MGT** key and select the file you wish to test

## Test Run and Program Run

### 17.4 Test run

The TNC then displays the following soft keys:

Soft key	Functions
	Reset the blank form, reset the previous tool data and test the entire program
	Test the entire program
	Test each NC block individually
	Executes the <b>Test run</b> until block N
	Halt test run (soft key only appears once you have started the test run)

You can interrupt the test run and continue it again at any point—even within a fixed cycle. In order to continue the test, the following actions must not be performed:

- Selecting another block with the arrow keys or the **GOTO** key
- Making changes to the program
- Selecting a new program


## Test run up to a certain block

With the **STOP AT** function the TNC executes a **Test run** up to the block with block number **N**.

To stop the **Test run** at any block, proceed as follows:



- ▶ Press the **STOP AT** soft key
- ▶ **Stop at: N** = Enter the block number at which the simulation should stop
- ▶ **Program** = Enter the name of the program containing the block with the selected block number. The control displays the name of the selected program; if the stop should be executed in a program that was called with **PGM CALL**, enter this name.
- ▶ **Repetitions** = If **N** is located in a program section repeat, enter the number of repeats that you want to run.  
Default 1: The control stops before **N** is simulated



## Possibilities in stopped condition

If you interrupt the **Test run** with the **STOP AT** function, you have the following possibilities in this stopped condition:

- **Block skip** enable or disable
- **Optional program stop** enable or disable
- Modify graphics resolution and model
- Modify the NC program in the **Programming** operating mode

If you modify the NC program in the **Programming** operating mode the simulation behaves as follows:

- Modification before the interruption point: The simulation restarts at the beginning
- Modification after the interruption point: Positioning at the interruption point is possible with **GOTO**

## Test Run and Program Run

### 17.5 Program run

### 17.5 Program run


#### Application

In the **Program run, full sequence** operating mode, the TNC executes a machining program continuously to its end or up to a program stop.

In the **Program run, single block** operating mode, the TNC executes each block individually after pressing the **NC START** key. With point pattern cycles and **CYCL CALL PAT** the controls stops after each point.

You can use the following TNC functions in the operating modes **Program run, single block** and **Program run, full sequence**:

- Interrupt program run
- Start the program run from a certain block
- Optional block skip
- Edit the tool table TOOL.T
- Checking and changing Q parameters
- Superimpose handwheel positioning
- Functions for graphic simulation
- Additional status display



#### Running a part program

##### Preparation

- 1 Clamp the workpiece to the machine table.
- 2 Set the datum
- 3 Select the necessary tables and pallet files (status M)
- 4 Select the part program (status M)



You can change the feed rate and spindle speed using the potentiometers.



Refer to your machine manual. The behavior of this function varies depending on the respective machine. You can reduce the feed rate with the **FMAX** soft key. The reduction applies to all rapid traverse and feed rate movements. The value you enter remains active after switch-off or switch-on.

##### Program Run, Full Sequence

- ▶ Start the machining program with the **NC START** key

##### Program Run, Single Block

- ▶ Start each block of the machining program individually with the **NC START** key



## Interrupt, stop or abort machining

There are several ways to stop a program run:

- Interrupt the program run with e.g. the miscellaneous function **M0**
- Interrupt the program run e.g. with the miscellaneous function **M0**
- Stop the program run e.g. with the **NC STOP** key in conjunction with the **INTERNAL STOP** soft key **INTERNAL STOP**
- Terminate the program run e.g. with the miscellaneous functions **M2** or **M30**

The control shows the current status of the program run in the status display.

**Further Information:** "General status display", page 90

The difference between an interrupted (terminated) program run and a stopped run is that an interrupted run allows the user to carry out the following actions:

- Select operating mode
- Check Q parameters and change these if necessary using the **Q INFO** function
- Change setting for the optional programmed interruption with **M1**
- Change setting for the programmed skipping of NC blocks with **/**



If the control registers an important error during a program run, it automatically stops the program run.  
Example: Cycle call with stationary spindle

## 17.5 Program run

**Program-controlled interruptions**

You can define interruptions directly in the machining program. The control interrupts the program run in the NC Block containing one of the following inputs:

- Programmed stop **STOP** (with and without miscellaneous function)
- Programmed stop **M0**
- Conditional stop **M1**

**Danger of collision!**

The control loses modally affective program information and therefore contextual references after the following handling:

- Cursor movement to another NC block
- The jump command **GOTO** to another NC block
- Editing an NC block

Loss of this contextual reference may cause undesired tool positions!



The miscellaneous function **M6** may also lead to a suspension of the program run. The machine manufacturer sets the functional scope of the miscellaneous functions.

### Manual program interruption

While a machining program is being executed in the **Program run, full sequence** operating mode, select the **Program run, single block** operating mode. The control interrupts the machining process at the end of the current machining step.

#### Abort program run.

- ▶ Press **NC STOP** key



- > The control does not exit the current NC block
- > The control shows the symbol for stopped status in the status display
- > Actions such as a change of operating mode are not possible
- > The program can be resumed with the **NC START** key

- ▶ Press the **INTERNAL STOP** soft key



- > The control briefly shows the symbol for aborting the program in the status display



- > The control shows the symbol for the exited inactive status in the status display
- > Actions such as a change of operating mode are available again

## 17.5 Program run

**Moving the machine axes during an interruption**

You can move the machine axes during an interruption in the same way as in the **Manual operation** mode.

**Danger of collision!**

If you interrupt the program run while the working plane is tilted, you can switch the coordinate system between tilted and non-tilted, as well as to the active tool axis direction, by pressing the **3-D ROT** soft key.

The functions of the axis direction keys, the electronic handwheel and the positioning logic for returning to the contour are evaluated by the TNC. When retracting the tool, make sure the correct coordinate system is active and the angular values of the tilt axes are entered in the 3-D ROT menu, if necessary.

**Modifying the reference point during an interruption**

If you modify the active reference point during an interruption, resuming the program run is only possible with **GOTO** or mid-program startup at the interruption point.

**Example:****Retracting the spindle after tool breakage**

- ▶ Interrupt machining
- ▶ Enable the axis direction keys: Press the **MANUAL TRAVERSE** soft key
- ▶ Move the machine axes with the axis direction keys



On some machines you may have to press the **NC START** key after the **MANUAL TRAVERSE** soft key to enable the axis direction keys. Refer to your machine manual.

## Resuming program run after an interruption



If you interrupt an NC program using the **INTERNAL STOP** key, you have to start machining at the start of the program or using the **BLOCK SCAN** function.

With machining cycles, mid-program startup is always executed at the start of the cycle. If you interrupt a program run during a machining cycle, the control repeats machining steps already carried out after a block scan.

If you interrupt the program run within a program section repetition, or within a subprogram, you must return to the interruption point using the **BLOCK SCAN** function.

When a program run is interrupted, the TNC stores:

- The data of the last defined tool
- Active coordinate transformations (e.g. datum shift, rotation, mirroring)
- The coordinates of the circle center that was last defined



Note that the stored data remain active until they are reset (e.g. if you select a new program).

The TNC uses the stored data for returning the tool to the contour after manual machine axis positioning during an interruption (**RESTORE POSITION** soft key).

### Resuming the program run with the NC Start key

You can resume program run by pressing the machine **START** button if the program was interrupted in one of the following ways:

- Press the **NC STOP** key
- Programmed interruption

### Resuming program run after an error

With an erasable error message:

- ▶ Remove the cause of the error
- ▶ Clear the error message from the screen: Press the **CE** key
- ▶ Restart the program, or resume program run where it was interrupted

## Test Run and Program Run

### 17.5 Program run

#### Retraction after a power interruption



The **Retraction** mode is enabled and adapted by the machine manufacturer. Refer to your machine manual.

With the **Retraction** mode of operation you can disengage the tool from the workpiece after an interruption in power.

If you activated a feed rate limit before a power failure, this is still active. You can deactivate the feed rate limit with the **CANCEL THE FEED RATE LIMITATION** soft key.

The **Retraction** mode of operation is selectable in the following conditions:

- Power interrupted
- No control voltage for the relay
- Traverse reference points




The **Retraction** operating mode offers the following modes of traverse:

Mode	Function
Machine axes	Movement of all axes in the machine coordinate system
Tilted system	Movement of all axes in the active coordinate system Effective parameters: Position of the tilting axes
Tool axis	Movements of the tool axis in the active coordinate system
Thread	Movements of the tool axis in the active coordinate system with compensating movement of the spindle Effective parameters: Thread pitch and direction of rotation



If tilting the working plane (option 8) is activated on your TNC, then the **Tilted system** traverse mode is available for you.(option 8)

The TNC selects the mode of traverse and the associated parameters automatically. If the traverse mode oder the parameters have not been correctly preselected, you are unable to reset them manually.



**Danger of collision!**

The TNC uses the last stored axis values for undefined axes. These axis values may not exactly correspond with the actual axis positions!

Consequently, the TNC may be unable to move the tool exactly along the actual tool direction when moving forward in the tool direction. If the tool is still in contact with the workpiece, it can cause stress or damage to the tool and workpiece. Stress or damage to the workpiece or tool can also be caused by uncontrolled coasting or braking of axes after a power interruption. If the tool is still in contact with the workpiece, move the axes carefully. Set the feed rate override to the smallest values possible. If you use the handwheel, use a small feed rate factor.

The traverse mode monitoring mode is not available for undefined axes. Watch the axes while you are moving them. Do not move to the traverse mode limits.


## Test Run and Program Run

### 17.5 Program run

#### Example

The power failed while a thread cutting cycle in the tilted working plane was being performed. You have to retract the tap:

- ▶ Switch on the power supply for control and machine. The TNC starts the operating system. This process may take several minutes. Then the TNC will display the message "Power interrupted" in the screen header



- ▶ Activate the **Retraction** mode: Press the **RETRACT** soft key. The TNC displays the message **Retraction selected**




- ▶ Acknowledge the power interruption: Press the **CE** key. The TNC compiles the PLC program.



- ▶ Switch on the control voltage: The TNC checks the functioning of the EMERGENCY STOP circuit. If there is at least one undefined axis you will have to compare the displayed positions with the actual axis values and confirm they are correct, and, if needed, following any instructions given in the dialog

- ▶ Check the preselected traverse mode: If required, select **THREAD**
- ▶ Check the preselected thread pitch: if required, enter the thread pitch
- ▶ Check the preselected direction of rotation: if needed, select the turning direction of the thread  
Right-handed thread: the main spindle turns clockwise when moving into the workpiece, counter-clockwise when retracting from it; left-handed thread: main spindle turns counter-clockwise when moving into the workpiece and clockwise when retracting from it




- ▶ Activate retraction: Press the **RETRACT** soft key

- ▶ Retraction: Retract the tool with the axis direction keys or the electronic handwheel  
Axis key Z+: Retraction from the workpiece  
Axis key Z-: Moving into the workpiece



- ▶ Exit retraction: Return to the original soft-key level



- ▶ End the **Retraction** mode: Press the **END RETRACTION** soft key. The TNC checks whether the **Retract** mode can be exited, following any instructions given in the dialog

- ▶ Answer confirmation request: If the tool was not correctly retracted, press the **NO** soft key. If the tool was correctly retracted, press the **YES** soft key. The TNC hides **Retraction selected** mode
- ▶ Initialize the machine: if required, cross the datums
- ▶ Establish the desired machine condition: If required, reset the tilted working plane



**Any entry into program: Mid-program startup**




**Danger of collision!**

If you use the **GOTO** key and the number of the NC block for going into a program, neither the TNC nor the PLC will execute any functions that ensure a safe start.

For safe entry, always use the **BLOCK SCAN** function.



The **BLOCK SCAN** function must be enabled and adapted by the machine manufacturer. Refer to your machine manual.



With the **BLOCK SCAN** function you can start an NC program at any desired NC block. The control factors workpiece machining up to this NC block into the calculations.

If the NC program was interrupted under the following conditions, the control saves the interruption point:

■ **INTERNAL STOP** soft key **INTERNAL STOP**

- Emergency stop
- Power failure

You can run the mid-program startup in the following ways:

- Mid-program startup in the main program, with repetitions if necessary
- Multi-level mid-program startup in subprograms and touch probe cycles
- Mid-program startup in a point table
- Block scan in pallet programs

At the start of mid-program startup the control resets all data, as with a selection of the NC program. During the mid-program startup you can change between **Program run full sequence** and **Program run single block**.



The TNC skips all touch probe cycles in a midprogramstartup. Result parameters from these cycles might therefore remain empty. If you wish to continue working with the results of a touch probe cycle, use the multi-level mid-program startup.



You must not use mid-program startup if you:

- The stretch filter is activated
- use touch probe cycles 0, 1, 3 and 4 in the search phase of the mid-program startup


## Test Run and Program Run

### 17.5 Program run


#### Procedure for simple mid-program startup



The control only displays the dialogs required by the process in the pop-up window.



- ▶ Press the **BLOCK SCAN** soft key
- The control shows a pop-up window with the active main program.
- ▶ **Start-up at: N** = Enter the number of the NC block where you wish to enter the NC program
- ▶ **Program** = Check the name and path of the NC program containing the NC block, or enter with the **SELECT** soft key
- ▶ **Repetitions** = Enter the number of machining operations which should be taken into account in the block scan if the NC block is located within a program section repetition.  
**Default 1 means first machining**



- ▶ Press the **ADVANCED** soft key if required to select the last saved interruption



- ▶ Press the **NC START** key
- The control starts the block scan, calculates until the entered NC block and shows the next dialog.

If you changed the machine status:



- ▶ Press the **NC START** key
- The control restores the machine status, e.g. TOOL CALL, M functions and shows the next dialog.

If you changed the axis positions:



- ▶ Press the **NC START** key
- The control approaches the specified positions in the specified sequence and shows the next dialog.  
Approach axes in individually selected sequence:  
**Further Information:** "Returning to the contour", page 692



- ▶ Press the **NC START** key
- The control resumes execution of the NC program.

#### Example of simple mid-program startup

After an internal stop you wish to start in block 12 in the third machining of LBL 1.

In the pop-up window enter the following data:

- **Start-up at: N** =12
- **Repetitions** = 3

### Procedure for multi-level mid-program startup


If you start in a subprogram that is called several times by the main program, use the multi-level mid-program startup. For this purpose, jump in the main program to the desired subprogram call. Use the function **CONTINUE BLOCK SCAN** to jump further from this position.




The control only displays the dialogs required by the process in the pop-up window.

You can also jump to the next startup point without restoring the machine status and the axis positions of the first startup point. For this purpose press the soft key **CONTINUE BLOCK SCAN** before you confirm the restoration with the **NC START** key.

Mid-program startup to the first start-up point:



- ▶ Press the **BLOCK SCAN** soft key
- ▶ Enter the first NC block where you wish to start



- ▶ Press the **ADVANCED** soft key if required to select the last saved interruption



- ▶ Press the **NC START** key
- > The control starts the block scan and calculates until the entered NC block.

If the control should restore the machine status of the entered NC block:



- ▶ Press the **NC START** key
- > The control restores the machine status, e.g. TOOL CALL, M functions.

If the control should restore the axis positions:



- ▶ Press the **NC START** key
- > The control moves in the specified sequence to the specified positions.

If the control should run the NC block:




- ▶ Select the **Program run single block** operating mode if required



- ▶ Press the **NC START** key
- > The control runs the NC block.

Mid-program startup to the next start-up point:



- ▶ Press the **CONTINUE BLOCK SCAN** soft key
- ▶ Enter the NC block where you wish to start

If you changed the machine status:



- ▶ Press the **NC START** key



- ▶ Press the **NC START** key

If the control should run the NC block:



- ▶ Press the **NC START** key

## Test Run and Program Run

### 17.5 Program run

- ▶ Repeat these steps if required to jump to the next start-up point




- ▶ Press the **NC START** key
- > The control resumes execution of the NC program.

#### Example of multi-level mid-program startup

You run a main program with several subprogram calls in the program Sub.h. You work with a touch probe cycle in the main program. You use the result of the touch probe cycle later for positioning.

After an internal stop you wish to start up in block 8 in the second call of the subprogram. This subprogram call is in block 53 of the main program. The touch probe cycle is in block 28 of the main program, i.e. before the desired start-up point.




- ▶ Press the **BLOCK SCAN** soft key
- ▶ In the pop-up window enter the following data:
  - **Start-up at: N =28**
  - **Repetitions = 1**



- ▶ Select the **Program run single block** operating mode if required




- ▶ Press the **NC START** key until the control runs the touch probe cycle
- > The control saves the result.



- ▶ Press the **CONTINUE BLOCK SCAN** soft key
- ▶ In the pop-up window enter the following data:
  - **Start-up at: N =53**
  - **Repetitions = 1**



- ▶ Press the **NC START** key until the control runs the NC block
- > The control jumps into the subprogram Sub.h.





- ▶ Press the **CONTINUE BLOCK SCAN** soft key
- ▶ In the pop-up window enter the following data:
  - **Start-up at: N =8**
  - **Repetitions = 1**



- ▶ Press the **NC START** key until the control runs the NC block
- > The control continues to run the subprogram and then returns to the main program.

### Block scan in a point table

If you start in a point table called by the main program, use the **ADVANCED** soft key.



- ▶ Press the **BLOCK SCAN** soft key
- > The control shows a pop-up window.
- ▶ Press the **ADVANCED** soft key
- > The control expands the pop-up window.
- ▶ **Point number** = enter the line number of the point table you start with
- ▶ **Point file** = Enter the name and path of the point table
- ▶ Press the **SELECT LAST BLOCK** soft key if required to select the last saved interruption
- ▶ Press the **NC START** key



### Block scan in pallet programs

With the pallet management you can also use the **BLOCK SCAN** function in conjunction with pallet tables.

If you interrupt the processing of pallet tables, the control always suggests the previously selected NC block of the interrupted NC program for the **BLOCK SCAN** function.



For **BLOCK SCAN** in pallet tables you also define the input field **Pallet line** =. The input refers to the line in the **NR** pallet table. This input is always required as an NC program may appear several times in a pallet table.



- ▶ Press the **BLOCK SCAN** soft key
- > The control shows a pop-up window.
- ▶ **Pallet line** = Enter the line number of the pallet table
- ▶ Enter **Repetitions** = if the NC block is located within a program section repetition
- ▶ Press the **ADVANCED** soft key if required
- > The control expands the pop-up window.
- ▶ Press the **SELECT LAST BLOCK** soft key to select the last saved interruption
- ▶ Press the **NC START** key


## Test Run and Program Run

### 17.5 Program run

#### Returning to the contour

With the **RESTORE POSITION** function, the TNC moves the tool to the workpiece contour in the following situations:

- Return to the contour after the machine axes were moved during a program interruption that was not performed with the **INTERNAL STOP** function.
- Return to the contour with a block scan with **RESTORE POS AT N**, for example after an interruption with **INTERNAL STOP**
- Depending on the machine, if the position of an axis has changed after the control loop has been opened during a program interruption



#### Procedure

To move to the contour, proceed as follows:

**RESTORE POSITION**

- Press the **RESTORE POSITION** soft key
- Restore the machine status, if required

Approach the axes in the sequence shown by the control:



- Press the **NC START** key

Approach the axes according to individually selected sequence:

**SELECT AXIS**

- Press the **SELECT AXIS** soft key
- Press the axis soft key of the first axis
- Press the **NC START** key



- Press the axis soft key of the second axis
- Press the **NC START** key



- Repeat the process for all axes

## 17.6 Automatic program start

### Application



The TNC must be specially prepared by the machine tool builder for use of the automatic program start function. Refer to your machine manual.




#### Caution: Danger for the operator!

The autostart function must not be used on machines that do not have an enclosed working space.

In a Program Run operating mode, you can use the **AUTOSTART** soft key to define a specific time at which the program that is currently active in this operating mode is to be started:



- ▶ Display window for setting the starting time
- ▶ **Time (hrs:min:sec):** Time of day at which the program is to be started
- ▶ **Date (DD.MM.YYYY):** Date on which the program is to be started
- ▶ To activate the start, press the **OK**



## Test Run and Program Run

### 17.7 Optional block skip


#### 17.7 Optional block skip

##### Application

Blocks that you mark with a "/" sign may be skipped in **Test run** or **Program Run, Full Sequence/Single Block**:



- ▶ To run or test the program without the NC blocks preceded by a slash, set the soft key to **ON**



- ▶ To run or test the program with the NC blocks preceded by a slash, set the soft key to **OFF**



This function does not work for **TOOL DEF** blocks.  
After a power interruption the TNC returns to the most recently selected setting.

##### Inserting the "/" character

- ▶ In the **Programming** mode you select the block in which the character is to be added



- ▶ Press the **INSERT** soft key

##### Erasing the "/" character

- ▶ In the **Programming** mode you select the block in which the character is to be erased



- ▶ Press the **REMOVE** soft key



## 17.8 Optional program-run interruption

### Application



Refer to your machine manual.

The behavior of this function varies depending on the respective machine.

The TNC optionally interrupts program run at blocks containing M1. If you use M1 in the **Program run** mode, the TNC does not switch off the spindle or coolant.



- ▶ Do not interrupt **Program run** or **Test run** with blocks containing M1: Set the soft key to **OFF**



- ▶ Interrupt **Program run** or **Test run** with blocks containing M1: Set the soft key to **ON**



# 18

## **MOD Functions**

## MOD Functions

### 18.1 MOD function

#### 18.1 MOD function


The MOD functions provide additional input possibilities and displays. In addition, you can enter code numbers to enable access to protected areas.

#### Selecting MOD functions

Open the pop-up window with the MOD functions:



- To select the MOD functions, press the **MOD** key. The TNC opens a pop-up window displaying the available MOD functions.



#### Changing the settings

As well as with the mouse, navigation with the keyboard is also possible in the MOD functions:

- Switch from the input area in the right window to the MOD function selections in the left window with the tab key
- Select MOD function
- Switch to the input field with the tab key or ENT key
- Enter value according to function and confirm with **OK** or make selection and confirm with **Apply**



If more than one possibility is available for a particular setting, you can superimpose a window listing all of the given possibilities by pressing the **GOTO** key. Select the setting with the **ENT** key. If you do not wish to change the setting, close the window with the **END** key.

#### Exiting MOD functions

- Exit the MOD functions: Press the **END** soft key or the **END** key

## Overview of MOD functions

The following functions are available independent of the selected operating mode:

### Code-number entry

- Code number

### Display settings

- Digital readouts
- Measuring unit (mm/inch) for position display
- Program entry for MDI
- Show time of day
- Show the info line

### Graphic settings

- Model type
- Model quality

### Machine settings

- Kinematics
- Traverse limits
- Tool-usage file
- External access

### System settings


- Set the system time
- Define the network connection
- Network: IP configuration

### Diagnostic functions

- Bus diagnosis
- Diagnosis of Drives
- HEROS information

### General information

- Software version
- FCL information
- License information
- Machine times



## MOD Functions

### 18.2 Graphic settings

#### 18.2 Graphic settings




With the MOD function **Graphic settings** you can select the model type and model quality .

To select **Graphic settings** proceed as follows:





- ▶ Select the group **Graphic settings** from the MOD menu
- ▶ Select the model type
- ▶ Select the model quality
- ▶ Press the **APPLY** soft key
- ▶ Press the **OK** soft key.

You have the following simulation parameters for the graphic settings:

##### Model type

Displayed symbol	Choice	Properties	Application
	3-D	Very true to detail, heavy time and processor consumption	Milling with undercuts, milling-turning operations
	2.5 D	Fast	Milling without undercuts
	No model	Very fast	Line graphics

##### Model quality

Displayed symbol	Choice	Properties
	Very high	High data transfer rate, exact depiction of tool geometry, depiction of block end points and block numbers possible
	High	High data transfer rate, exact depiction of tool geometry
	Medium	Medium data transfer rate, approximation of tool geometry
	Low	Low data transfer rate, coarse approximation of tool geometry

## 18.3 Machine settings

### External access




Refer to your machine manual. The machine tool builder can configure the external access options.

Machine-dependent function: With the **TNCOPT** soft key, you can permit or lock access for an external diagnostics or commissioning program.

With the MOD function **External access** you can grant or restrict access to the TNC. If you have restricted the external access it is no longer possible to connect to the TNC and exchange data via a network or a serial connection, e.g. with the TNCremo data transfer software.

Restricting external access:

- ▶ In the MOD menu select the **Machine settings** group **Machine settings**
- ▶ Select the **External access** menu
- ▶ Set the **EXTERNAL ACCESS ON/OFF** soft key to **OFF**
- ▶ Press the **OK** soft key



Computer-specific access control

If your machine manufacturer has set up computer-specific access control (machine parameter **CfgAccessControl** no. 123400)), you can permit access for up to 32 connections authorized by you. Select **Add** to create a new connection. The TNC opens an input window for you to enter the connection data.

Access settings

Host name	Host name of the external computer
Host IP	Network address of the external computer
Description	Additional information (text is shown in the overview list)

Type:


Ethernet	Network connection
Com 1	Serial interface 1
COM 2	Serial interface 2

Access rights:


Inquire	The TNC opens a query dialog with external access
Deny	Do not permit network access
Permit	Permit network access without query

If you assign the access right **Inquire** to a connection and access is implemented from this address, the TNC opens a pop-up window. You must permit or deny external access in the pop-up window:

External access	Permission
Yes	Permit once
Always	Permit continuously
Never	Deny continuously
No	Deny once



In the overview list an active connection is shown with a green symbol.  
Connections without access rights are shown gray in the overview list.





## Entering traverse limits



Refer to your machine manual.

The **Traverse limits** function must be enabled and adapted by the machine manufacturer.

The MOD function **Traverse limits** enables you to limit the actually usable tool path within the maximum traverse range. This enables you to define protection zones on each axis to protect a component from collision for example.


To enter traverse limits:

- ▶ In the MOD menu select the **Machine settings** group **Machine settings**
- ▶ Select the **Traverse limits** menu **Traverse limits**
- ▶ Enter the values of the desired axes as a reference value or load the momentary position with the **ACTUAL POSITION CAPTURE** soft key
- ▶ Press the **APPLY** soft key The TNC checks the values entered for validity.
- ▶ Press the soft key **OK**



The protection zone becomes active automatically as soon as you set a valid limit in an axis. Settings are kept even after restarting the control.

You can only deactivate the protection zone by deleting all values or pressing the **EMPTY EVERYTHING** soft key.



## 18.3 Machine settings

## Tool usage file



The tool usage test function must be enabled by your machine manufacturer. Refer to your machine manual.

With the MOD function **Tool-usage file** you can select whether the TNC never, once, or always creates a tool usage file.

Generate a tool usage file:

- ▶ In the MOD menu select the **Machine settings** group **Machine settings**
- ▶ Select the **Tool-usage file** menu **Tool-usage file**
- ▶ Select the desired setting for the operating modes **Program Run, Full Sequence/Single Block** and **Test run**
- ▶ Press the **APPLY** soft key **APPLY**
- ▶ Press the **OK** soft key

## Select kinematics



The **Kinematics selection** function must be enabled and adapted by the machine manufacturer. Refer to your machine manual.

You can use this function to test programs whose kinematics does not match the active machine kinematics. If your machine manufacturer saved different kinematic configurations in your machine, you can activate one of these kinematics configurations with the MOD function. When you select a kinematics model for the test run this does not affect machine kinematics.

**Danger of collision!**

When you switch the kinematics model for machine operation, the TNC implements all of subsequent movements with modified kinematics.

Ensure that you have selected the correct kinematics in the test run for checking your workpiece.

## 18.4 System settings

### Set the system time

With the **Set the system time** MOD function you can set the time zone, date and time manually or with the aid of an NTP server synchronization.

To set the system time manually:

- ▶ In the MOD menu select the **System settings** group **System settings**
- ▶ Press the **SET DATE/ TIME** soft key **SET DATE/ TIME**
- ▶ Select your time zone in the **Time zone** area **Time zone**
- ▶ Press the **LOCAL/NTP** soft key in order to select the **Set the time manually** entry
- ▶ If required, change the datum and the time
- ▶ Press the **OK** soft key

To set the system time with the aid of an NTP server:

- ▶ In the MOD menu select the **System settings** group **System settings**
- ▶ Press the **SET DATE/ TIME** soft key **SET DATE/ TIME**
- ▶ Select your time zone in the **Time zone** area **Time zone**
- ▶ Press the **LOCAL/NTP** soft key in order to synchronize the time entry through the NTP server
- ▶ Enter the host name or the URL of an NTP server
- ▶ Press the **ADD** soft key
- ▶ Press the **OK** soft key

## 18.5 Select the position display

## 18.5 Select the position display

## Application

You can influence the display of the coordinates for the operating mode **Manual operation** and the operating modes **Program run, full sequence** and **Program run, single block**.

The figure on the right shows the different tool positions:


- Initial position
- Target position of the tool
- Workpiece zero point
- Machine datum

The TNC position displays can show the following coordinates:

Function	Display
Nominal position: the value presently commanded by the TNC	NOML.
Actual position; current tool position	ACTL.
Reference position; actual position relative to the machine datum	REF ACTL
Reference position; nominal position relative to the machine datum	REF NOML
Servo lag; difference between nominal and actual positions	LAG
Distance remaining to the programmed position in the input system; difference between actual and target positions	ACTDST
Distance remaining to the programmed position with reference to the machine datum; difference between reference and target positions	REFDST
Traverses that were carried out with handwheel superimpositioning (M118)	M118

With the MOD function **Position display 1**, you can select the position display in the status display.

With the MOD function **Position display 2**, you can select the position display in the additional status display.



## 18.6 Setting the unit of measure

### Application

This MOD function determines whether the coordinates are displayed in millimeters (metric system) or inches.

- Metric system: e.g. X = 15.789 (mm), the value is displayed to 3 decimal places
- Inch system: e.g. X = 0.6216 (inches), value is displayed to 4 decimal places

If you would like to activate the inch display, the TNC shows the feed rate in inch/min. In an inch program you must enter the feed rate larger by a factor of 10.

## 18.7 Displaying operating times


### Application

The **MACHINE TIME** MOD function enables you to see various types of operating times:

Operating time	Meaning
<b>Control on</b>	Operating time of the control since being put into service
<b>Machine on</b>	Operating time of the machine tool since being put into service
<b>Program run</b>	Duration of controlled operation since being put into service



Refer to your machine manual. The machine tool builder can provide further operating time displays.



## MOD Functions

### 18.8 Software numbers

#### 18.8 Software numbers

##### Application

The following software numbers are displayed on the TNC screen after the **Software version** MOD function has been selected:

- **Control model:** Designation of the control (managed by HEIDENHAIN)
- **NC SW:** Number of the NC software (managed by HEIDENHAIN)
- **NCK:** Number of the NC software (managed by HEIDENHAIN)
- **PLC:** Number or name of the PLC software (managed by your machine manufacturer)

Your machine manufacturer can add further software numbers, e.g. from a connected camera.

In the **FCL Information** MOD function, the TNC shows the following information:

- **Development level (FCL=Feature Content Level):**  
Development level of the software installed on the control  
**Further Information:** "Feature Content Level (upgrade functions)", page 11

### 18.9 Enter the code number

##### Application

The TNC requires a code number for the following functions:

Function	Code number
Select user parameters	123
Configuring an Ethernet card	NET123
Enabling special functions for Q parameter programming	555343


## 18.10 Setting up data interfaces

### Serial interfaces on the TNC 640

The TNC 640 automatically uses the LSV2 transmission protocol for serial data transfer. The LSV2 protocol is prescribed and cannot be modified apart from setting the baud rate (machine parameter **baudRateLsv2**, no. 106606). You can also define another type of data transfer (interface). The settings described below are therefore effective only for the respective newly defined interface.

### Application

To set up a data interface, press the **MOD** key. Enter the code number 123. In the **CfgSerialInterface** (no. 106700) machine parameter, you can enter the following settings:



### Setting the RS-232 interface

Open the RS232 folder. The TNC then displays the following settings:

#### Set BAUD RATE (baud rate no. 106701)


You can set the BAUD RATE (data transfer speed) from 110 to 115 200 baud.

MOD Functions

18.10 Setting up data interfaces

Set protocol  
(protocol no. 106702)

The data transfer protocol controls the data flow of a serial transmission (comparable to MP5030 of the iTNC 530).



The BLOCKWISE setting here designates a method of data transfer in which data is transferred grouped in blocks. This should not be confused with the block-wise data reception and simultaneous block-wise running of older TNC contouring controls. The block-wise reception and simultaneous running of the same NC program is not supported by the control.

Data transmission protocol	Selection
Standard data transmission (transmission line-by-line)	STANDARD
Packet-based data transfer	BLOCKWISE
Transmission without protocol (only character-by-character)	RAW_DATA

Set data bits  
(dataBits no. 106703)

By setting the data bits you define whether a character is transmitted with 7 or 8 data bits.

Check parity  
(parity no. 106704)

The parity bit helps the receiver to detect transmission errors. The parity bit can be formed in three different ways:

- No parity (NONE): There is no error detection
- Even parity (EVEN): Here there is an error if the receiver finds that it has received an odd number of set bits
- Odd parity (ODD): Here there is an error if the receiver finds that it has received an even number of set bits

Set stop bits  
(stopBits no. 106705)

The start bit and one or two stop bits enable the receiver to synchronize each transmitted character during serial data transmission.



### Set handshake (flowControl no. 106706)

By handshaking, two devices control data transfer between them. A distinction is made between software handshaking and hardware handshaking.

- No data flow checking (NONE): Handshaking is not active
- Hardware handshaking (RTS\_CTS): Transmission stop is active through RTS
- Software handshaking (XON\_XOFF): Transmission stop is active through DC3 (XOFF)

### File system for file operation (fileSystem no. 106707)

In **fileSystem** you define the file system for the serial interface. This machine parameter is not required if you don't need a special file system.

- EXT: Minimum file system for printers or non-HEIDENHAIN transmission software. Corresponds to the EXT1 and EXT2 modes of earlier TNC controls.
- FE1: Communication with the TNCserver PC software or an external floppy disk unit.

### Block check character (bccAvoidCtrlChar no. 106708)

With Block Check Character (optional) no control character, you determine whether the checksum can correspond to a control character.

- TRUE: The checksum does not correspond to a control character
- FALSE: The checksum can correspond to a control character

### Condition of RTS line (rtsLow no. 106709)

With Condition of RTS line (optional) you determine whether the "low" level is active in idle state.

- TRUE: Level is "low" in idle state
- FALSE: Level is not "low" in idle state

## 18.10 Setting up data interfaces

### Define behavior after receipt of ETX (noEotAfterEtx no. 106710)

With define behavior after reception of ETX (optional) you determine whether the EOT character is sent after the ETX character was received.

- TRUE: The EOT character is not sent
- FALSE: The EOT character is sent

### Settings for the transmission of data using PC software TNCserver




Apply the following settings in machine parameter **RS232** (no. 106700):

Parameters	Selection
Data transfer rate in baud	Has to match the setting in TNCserver
Data transmission protocol	BLOCKWISE
Data bits in each transferred character	7 bits
Type of parity checking	EVEN
Number of stop bits	1 stop bit
Specify type of handshake:	RTS_CTS
File system for file operations	FE1

## Setting the operating mode of the external device (fileSystem)



In the FE2 and FEX operating modes you cannot use the "load all programs", "load offered program" and "load directory" functions.

Icon	External device	Operating mode
	PC with HEIDENHAIN TNCremo data transfer software	LSV2
	HEIDENHAIN floppy disk units	FE1
	Non-HEIDENHAIN devices such as printers, scanners, punchers, PC without TNCremo	FEX

## Software for data transfer

For transmitting files to and from the TNC, we recommend using the HEIDENHAIN TNCremo data transmission software. With TNCremo, data transmission is possible with all HEIDENHAIN controls via the serial interface or the Ethernet interface.



You can download the current version of TNCremo free of charge from the HEIDENHAIN Filebase ([www.heidenhain.com](http://www.heidenhain.com), <Software>, <PC software>, <TNCremo>).

System requirements for TNCremo:

- PC with 486 processor or higher
- Windows XP, Windows Vista, Windows 7, Windows 8 operating system
- 16 MB RAM
- 5 MB free memory space on your hard disk
- An available serial interface or connection to the TCP/IP network

## Installation under Windows

- ▶ Start the SETUP.EXE installation program with the file manager (Explorer)
- ▶ Follow the setup program instructions

## Starting TNCremo under Windows

- ▶ Click on <Start>, <Programs>, <HEIDENHAIN Applications>, <TNCremo>

When you start TNCremo for the first time, TNCremo automatically tries to set up a connection with the TNC.

## 18.10 Setting up data interfaces

## Data transfer between the TNC and TNCremo



Before you transmit a program from the TNC to the PC, you must make absolutely sure that you have already saved the program currently selected on the TNC. The TNC saves changes automatically when you switch the operating mode on the TNC, or when you select the file manager with the **PGM MGT** key.

Check whether the TNC is connected to the correct serial port on your PC or to the network.

Once you have started TNCremo, you will see a list of all files that are stored in the active directory in the upper section of the main window **1**. Using <File>, <Change directory>, you can select any drive or another directory on your PC.

If you want to control data transfer from the PC, establish the connection with your PC in the following manner:

- ▶ Select <File>, <Setup connection>. TNCremo now receives the file and directory structure from the TNC and displays this at the bottom left of the main window **2**
- ▶ To transfer a file from the TNC to the PC, select the file in the TNC window with a mouse click and drag and drop the highlighted file into the PC window **1**
- ▶ To transfer a file from the PC to the TNC, select the file in the PC window with a mouse click and drag and drop the highlighted file into the TNC window **2**

If you want to control data transfer from the TNC, establish the connection with your PC in the following manner:

- ▶ Select <Extras>, <TNCserver>. TNCremo is now started in server mode, and can receive data from the TNC and send data to the TNC
- ▶ You can now call the file management functions on the TNC by pressing the key **PGM MGT** in order to transfer the desired files  
**Further Information:** "Data transfer to or from an external data carrier", page 169



If you have exported a tool table from the control, the tool types are converted to a tool type number.


**Further Information:** "Available tool types", page 236

## End TNCremo

Select <File>, <Exit>



Refer also to the TNCremo context-sensitive help texts where all of the functions are explained in more detail. The help texts must be called with the **F1** key.



## 18.11 Ethernet interface

### Introduction

The TNC is shipped with a standard Ethernet card to connect the control as a client in your network. The TNC transmits data via the Ethernet card with

- the **smb** protocol (Server Message Block) for Windows operating systems, or
- the **TCP/IP** protocol family (Transmission Control Protocol/Internet Protocol) and with the NFS (Network File System)

### Connection possibility


You can connect the Ethernet card in your TNC to your network through the RJ45 connection (X26, 1000BaseTX, 100BaseTX and 10BaseT), or directly to a PC. The connection is metallically isolated from the control electronics.

For a 1000Base TX, 100BaseTX or 10BaseT connection you need a Twisted Pair cable to connect the TNC to your network.



The maximum cable length between TNC and a node depends on the quality grade of the cable, the sheathing and the type of network (1000BaseTX, 100BaseTX or 10BaseT).

No great effort is required to connect the TNC directly to a PC that has an Ethernet card. Simply connect the TNC (port X26) and the PC with an Ethernet crossover cable (trade names: crossed patch cable or crossed STP cable).



### Configuring the TNC



Make sure that the person configuring your TNC is a network specialist.

- ▶ Press the **MOD** key in the **Programming** mode and enter the code number NET123
- ▶ In the file manager, press the soft key **NET**

## 18.11 Ethernet interface



## General network settings

- Press the **CONFIGURE NETWORK** soft key to enter the general network settings. The **Computer name** tab is active:

Setting	Meaning
<b>Primary interface</b>	Name of the Ethernet interface to be integrated in your company network. Only active if a second, optional Ethernet interface is available on the control hardware
<b>Computer name</b>	Name displayed for the TNC in your company network
<b>Host file</b>	<b>Only required for special applications:</b> Name of a file in which the assignments of IP addresses to computer names is defined

- Select the **Interfaces** tab to enter the interface settings:


Setting	Meaning
<b>Interface list</b>	List of the active Ethernet interfaces. Select one of the listed interfaces (via mouse or arrow keys) <ul style="list-style-type: none"> <li><b>Activate</b> button: Activate the selected interface (<b>X</b> appears in the <b>Active</b> column)</li> <li><b>Deactivate</b> button: Deactivate the selected interface (- appears in the <b>Active</b> column)</li> <li><b>Configuration</b> button: Open the configuration menu</li> </ul>
<b>Allow IP forwarding</b>	<b>This function must be kept deactivated.</b> Only activate this function if external access via the second, optional Ethernet interface of the TNC is necessary for diagnostic purposes. Only do so after instruction by our Service Department



- Press the **Configuration** button to open the Configuration menu:

Setting	Meaning
<b>Status</b>	<ul style="list-style-type: none"> <li>■ <b>Interface active:</b> Connection status of the selected Ethernet interface</li> <li>■ <b>Name:</b> Name of the interface you are currently configuring</li> <li>■ <b>Plug connection:</b> Number of the plug connection of this interface on the logic unit of the control</li> </ul>
<b>Profile</b>	<p>Here you can create or select a profile in which all settings shown in this window are stored. HEIDENHAIN provides two standard profiles:</p> <ul style="list-style-type: none"> <li>■ <b>DHCP-LAN:</b> Settings for the standard TNC Ethernet interface, should work in a standard company network</li> <li>■ <b>MachineNet:</b> Settings for the second, optional Ethernet interface; for configuration of the machine network</li> </ul> <p>Press the corresponding buttons to save, load and delete profiles</p>
<b>IP address</b>	<ul style="list-style-type: none"> <li>■ Option <b>Automatically procure IP address:</b> The TNC is to procure the IP address from the DHCP server</li> <li>■ Option <b>Manually set IP address:</b> Manually define the IP address and subnet mask. Input: Four numerical values separated by periods, e.g. <b>160.1.180.20</b> and <b>255.255.0.0</b></li> </ul>
<b>Domain Name Server (DNS)</b>	<ul style="list-style-type: none"> <li>■ Option <b>Automatically procure DNS:</b> The TNC is to automatically procure the IP address of the domain name server</li> <li>■ Option <b>Manually configure the DNS:</b> Manually enter the IP addresses of the servers and the domain name</li> </ul>
<b>Default gateway</b>	<ul style="list-style-type: none"> <li>■ Option <b>Automatically procure default gateway:</b> Die TNC soll den Default-Gateway automatisch beziehen</li> <li>■ Option <b>Manually configure the default gateway:</b> Manually enter the IP addresses of the default gateway</li> </ul>

- Apply the changes with the **OK** button, or discard them with the **Cancel** button



## 18.11 Ethernet interface

- ▶ Select the tab **Internet**.

Setting	Meaning
Proxy	<ul style="list-style-type: none"> <li>■ <b>Direct connection to Internet / NAT:</b> The control forwards Internet inquiries to the default gateway and from there they must be forwarded through network address translation (e.g. if a direct connection to a modem is available)</li> <li>■ <b>Use proxy:</b> Define the <b>Address</b> and <b>Port</b> of the Internet router in your network, ask your network administrator for the correct address and port</li> </ul>

**Telemaintenance** The machine manufacturer configures the server for telemaintenance here. Changes must always be made in agreement with your machine tool builder

- ▶ Select the **Ping/Routing** tab to enter the ping and routing settings:




Setting	Meaning
Ping	<p>In the <b>Address:</b> field, enter the IP number for which you want to check the network connection. Input: four numerical values separated by periods, e.g. <b>160.1.180.20</b>. As an alternative, you can enter the name of the computer whose connection you want to check</p> <ul style="list-style-type: none"> <li>■ Press the <b>Start</b> button to begin the test. The TNC shows the status information in the Ping field</li> <li>■ Press the <b>Stop</b> button to conclude the test</li> </ul>

**Routing** For network specialists: Status information of the operating system for the current routing

- Press the **Update** button to refresh the routing information

- ▶ Select the **NFS UID/GID** tab to enter the user and group identifications:


Setting	Meaning
Set UID/GID for NFS shares	<ul style="list-style-type: none"> <li>■ <b>User ID:</b> Definition of which user identification the end user uses to access files in the network. Ask your network specialist for the proper value</li> <li>■ <b>Group ID:</b> Definition of the group identification with which you access files in the network. Ask your network specialist for the proper value</li> </ul>





- **DHCP server:** Settings for automatic network configuration


Setting	Meaning
<b>DHCP server</b>	<ul style="list-style-type: none"> <li>■ <b>IP addresses from:</b> Define the IP address as of which the TNC is to derive the pool of dynamic IP addresses. The TNC transfers the values that appear dimmed from the static IP address of the defined Ethernet interface; these values cannot be edited.</li> <li>■ <b>IP addresses to:</b> Define the IP address up to which the TNC is to derive the pool of dynamic IP addresses</li> <li>■ <b>Lease Time (hours):</b> Time within which the dynamic IP address is to remain reserved for a client. If a client logs on within this time, the TNC reassigns the same dynamic IP address.</li> <li>■ <b>Domain name:</b> Here you can define a name for the machine network if required. This is necessary if the same names are assigned in the machine network and in the external network, for example.</li> <li>■ <b>Forward DNS to external:</b> If <b>IP Forwarding</b> is active (Interfaces tab) and the option is active, you can specify that the name resolution for devices in the machine network can also be used by the external network.</li> <li>■ <b>Forward DNS from external:</b> If <b>IP Forwarding</b> is active (Interfaces tab) and the option is active, you can specify that the TNC is to forward DNS inquiries from devices within the machine network to the name server of the external network if the DNS server of the MC cannot answer the inquiry.</li> <li>■ <b>Status</b> button: Call an overview of the devices that are provided with a dynamic IP address in the machine network. You can also select settings for these devices.</li> <li>■ <b>Advanced options</b> button: Additional settings for the DNS/DHCP server.</li> <li>■ <b>Set standard values</b> button: Set factory settings.</li> </ul>
► <b>Sandbox:</b>	Changes must always be made in agreement with your machine tool builder



Network settings specific to the device

- ▶ Press the **DEFINE NETWORK CONNECTN.** soft key to enter the network settings for a specific device. You can define any number of network settings, but you can manage only seven at one time




Setting	Meaning
Network drive	<div><p>List of all connected network drives. The TNC shows the respective status of the network connections in the columns:</p><ul style="list-style-type: none"><li>■ <b>Mount:</b> Network drive connected / not connected</li><li>■ <b>Auto:</b> Network drive is to be connected automatically/manually</li><li>■ <b>Type:</b> Type of network connection. cifs and nfs are possible</li><li>■ <b>Drive:</b> Designation of the drive on the TNC</li><li>■ <b>ID:</b> Internal ID that identifies if a mount point has been used for more than one connection</li><li>■ <b>Server:</b> Name of the server</li><li>■ <b>Share:</b> Name of the directory on the server that the TNC is to access</li><li>■ <b>User:</b> User name with which the user logs on to the network</li><li>■ <b>Password:</b> Network password protected or not</li><li>■ <b>Query password?:</b> Query / do not query password during connection</li><li>■ <b>Options:</b> Display additional connection options</li></ul><p>To manage the network drives, use the screen buttons.</p><p>To add network drives, use the <b>Add</b> button: The TNC then starts the connection wizard, which guides you by dialog through the required definitions.</p></div>
Status log	<div><p>Display of status information and error messages.</p><p>Press the Clear button to delete the contents of the Status Log window.</p></div>




# 18.12 Firewall

## Application

You can set up a firewall for the primary network interface of the control. It can be configured so that incoming network traffic is blocked and/or a message is displayed, depending on the sender and the service. The firewall cannot be started for the second network interface of the control if it is active as the DHCP server. Once the firewall has been activated, a symbol appears at the lower right in the taskbar. The symbol changes depending on the safety level that the firewall was activated with, and informs about the level of the safety settings:

Icon	Meaning
	Firewall protection does not yet exist although configured according to the configuration. This can happen, for example, if PC names for which there are no equivalent IP addresses as yet were used in the configuration.
	Firewall active with medium security level
	Firewall active with high safety level. (All services except for the SSH are blocked)



Have the standard settings checked by your network specialist and change them if necessary.  
The settings in the additional tab **SSH settings** are in preparation for future enhancements and currently have no function.

## Configuring the firewall

Make your firewall settings as follows:

- ▶ Use the mouse to open the task bar at the bottom edge of the screen  
**Further Information:** "Window manager", page 99
- ▶ Press the green HEIDENHAIN button to open the JH menu
- ▶ Select the **Settings** menu item
- ▶ Select the **Firewall** menu item.

HEIDENHAIN recommends activating the firewall with the prepared default settings:

- ▶ Set the **Active** option to enable the firewall
- ▶ Press the **Set standard values** button to activate the default settings recommended by HEIDENHAIN.
- ▶ Exit the dialog with the **OK** button.

## 18.12 Firewall

## Firewall settings

Option	Meaning
Active	Switching the firewall on and off
Interface:	Selection of the <b>eth0</b> interface usually corresponds to X26 of the MC main computer. <b>eth1</b> corresponds to X116. You can check this in the network settings in the Interfaces tab. On main computer units with two Ethernet interfaces, the DHCP server is active by default for the second (non-primary) interface for the machine network. With this setting it is not possible to activate the firewall for <b>eth1</b> because the firewall and the DHCP server exclude themselves mutually
Report other inhibited packets:	Firewall active with high safety level. (All services except for the SSH are blocked)
Inhibit ICMP echo answer:	If this option is set, the control no longer responds to a PING request
Service	<p>This column contains the short names of the services that are configured with this dialog. For the configuration it is not important here whether the services themselves have been started</p> <ul style="list-style-type: none"> <li>■ <b>LSV2</b> contains the functionality for TNCremo and Teleservice, as well as the HEIDENHAIN DNC interface (ports 19000 to 19010)</li> <li>■ <b>SMB</b> only refers to incoming SMB connections, i.e. if a Windows release is made on the NC. Outgoing SMB connections (i.e. if a Windows release is connected to the NC) cannot be prevented.</li> <li>■ <b>SSH</b> stands for the Secure Shell protocol (port 22). As of HEROS 504, the LSV2 can be executed securely tunneled via this SSH protocol.</li> <li>■ <b>VNC</b> protocol means access to the screen contents. If this service is blocked, the screen content can no longer be accessed, not even with the TeleService programs from HEIDENHAIN (e.g. screenshot). If this service is blocked, the VNC configuration dialog shows a warning from HEROS that VNC is disabled in the firewall.</li> </ul>

Option	Meaning
Method	Under <b>Method</b> you can configure whether the service should not be available to anyone ( <b>Prohibit all</b> ), available to everyone ( <b>Permit all</b> ) or only available to some (Permit some). If you set <b>Permit some</b> you must also specify the computer (under Computer) that you wish to grant access to the respective service. If you do not specify any computer under <b>Computer</b> , the setting <b>Prohibit all</b> will automatically become active when the configuration is saved.
Log	If <b>Log</b> is activated, a "red" message is output if a network package for this service has been blocked. A "blue" message is output if a network packet for this service has been accepted.
Computer	If the setting <b>Permit some</b> is selected under <b>Method</b> , the relevant computers can be specified here. The computers can be entered with their IP addresses or host names separated by commas. If a host name is used, the system checks upon closing or saving of the dialog whether the host name can be translated into an IP address. If this is not the case, an error message is displayed and the dialog does not terminate. If a valid host name is specified, this host name is translated into an IP address each time the control is started. If a computer that was entered with its name changes its IP address, you may have to restart the control or formally change the firewall configuration to ensure that the control uses the new IP address for a host name in the firewall.
Advanced options	These settings are only intended for your network specialists
Set standard values	Resets the settings to the default values recommended by HEIDENHAIN

## MOD Functions

### 18.13 Configuring the HR 550FS wireless handwheel

#### 18.13 Configuring the HR 550FS wireless handwheel


##### Application

Press the **SET UP WIRELESS HANDWHEEL** soft key to configure the HR 550FS wireless handwheel. The following functions are available:

- Assigning the handwheel to a specific handwheel holder
- Setting the transmission channel
- Analyzing the frequency spectrum for determining the optimum transmission channel
- Select transmitter power
- Statistical information on the transmission quality

##### Assigning the handwheel to a specific handwheel holder

- ▶ Make sure that the handwheel holder is connected to the control hardware.
- ▶ Place the wireless handwheel you want to assign to the handwheel holder in the handwheel holder
- ▶ Press the **MOD** key to select the MOD function
- ▶ Select the **Machine settings** menu
- ▶ Select the configuration menu for the wireless handwheel:  
Press the **SET UP WIRELESS HANDWHEEL** soft key
- ▶ Click the **Connect HW** button: The TNC saves the serial number of the wireless handwheel located in the handwheel holder and shows it in the configuration window to the left of the **Connect HW** button
- ▶ To save the configuration and exit the configuration menu, press the **END** button
- ▶ Select the **Machine settings** menu
- ▶ Select the configuration menu for the wireless handwheel:  
Press the **SET UP WIRELESS HANDWHEEL** soft key
- ▶ Click the **Connect HR** button: The TNC saves the serial number of the wireless handwheel located in the handwheel holder and shows it in the configuration window to the left of the **Connect HR** button
- ▶ To save the configuration and exit the configuration menu, press the **END** button




## Configuring the HR 550FS wireless handwheel 18.13

### Setting the transmission channel

If the wireless handwheel is started automatically, the TNC tries to select the transmission channel supplying the best transmission signal. If you want to set the transmission channel manually, proceed as follows:

- ▶ Press the **MOD** key to select the MOD function
- ▶ Select the **Machine settings** menu
- ▶ Select the configuration menu for the wireless handwheel:  
Press the **SET UP WIRELESS HANDWHEEL** soft key
- ▶ Click the **Frequency spectrum** tab
- ▶ Click the **Stop HW** button: The TNC stops the connection to the wireless handwheel and determines the current frequency spectrum for all of the 16 available channels
- ▶ Memorize the number of the channel with the least amount of radio traffic (smallest bar)
- ▶ Click the **Start handwheel** button to reactivate the wireless handwheel
- ▶ Click the **Properties** tab
- ▶ Click the **Select channel** button: The TNC shows all available channel numbers. Click the channel number for which the TNC determined the least amount of radio traffic
- ▶ To save the configuration and exit the configuration menu, press the **END** button




### Selecting the transmitter power



Please keep in mind that the transmission range of the wireless handwheel decreases when the transmitter power is reduced.

- ▶ Press the **MOD** key to select the MOD function
- ▶ Select the **Machine settings** menu
- ▶ Select the configuration menu for the wireless handwheel:  
Press the **SET UP WIRELESS HANDWHEEL** soft key
- ▶ Click the **Set power** button: The TNC shows the three available power settings. Click the desired setting
- ▶ To save the configuration and exit the configuration menu, press the **END** button



## MOD Functions

### 18.13 Configuring the HR 550FS wireless handwheel

#### Statistical data

To display the statistical data, proceed as follows:

- ▶ Press the **MOD** key to select the MOD function
- ▶ Select the **Machine settings** menu
- ▶ To select the configuration menu for the wireless handwheel, press the **SET UP WIRELESS HANDWHEEL** soft key: The TNC displays the configuration menu with the statistical data

Under **Statistics**, the TNC displays information about the transmission quality.

If the reception quality is poor so that a proper and safe stop of the axes cannot be ensured anymore, an emergency-stop reaction of the wireless handwheel is triggered.

The displayed value **Max. successive lost** indicates whether reception quality is poor. If the TNC repeatedly displays values greater than 2 during normal operation of the wireless handwheel within the desired range of use, then there is a risk of an undesired disconnection. This can be corrected by increasing the transmitter power or by changing to another channel with less radio traffic.

If this occurs, try to improve the transmission quality by selecting another channel or by increasing the transmitter power.

**Further Information:** "Setting the transmission channel", page 725

**Further Information:** "Selecting the transmitter power", page 725





## 18.14 Load machine configuration

### Application



Caution: Data loss!

The TNC overwrites your machine configuration when you load (restore) a backup. The overwritten machine data will be lost in the process. You can no longer undo this process!

Your machine tool builder can provide you a backup with a machine configuration. After entering the keyword **RESTORE**, you can load the backup on your machine or programming station. Proceed as follows to load the backup:

- ▶ In the MOD dialog, enter the keyword **RESTORE**
- ▶ In the TNC's file manager, select the backup file (e.g. BKUP-2013-12-12\_.zip). The TNC opens a pop-up window for the backup
- ▶ Press emergency stop.
- ▶ Press the **OK** soft key to start the backup process



# 19

**Tables and  
Overviews**

## 19.1 Machine-specific user parameters

### 19.1 Machine-specific user parameters

#### Application

The parameter values are entered in the **configuration editor**.



To enable you to set machine-specific functions for users, your machine tool builder can define which machine parameters are available as user parameters. Furthermore, your machine tool builder can integrate additional machine parameters, which are not described in the following, into the TNC. Refer to your machine manual.

The machine parameters are grouped as parameter objects in a tree structure in the configuration editor. Each parameter object has a name (e.g. **Settings for screen displays**) that gives information about the parameters it contains. A parameter object, also called "entity," is marked with an "E" in the folder symbol in the tree structure. Some machine parameters have a key name to identify them unambiguously. The key name assigns the parameter to a group (e.g. X for X axis). The respective group folder bears the key name and is marked by a "K" in the folder symbol.



If you are in the configuration editor for the user parameters, you can change the display of the existing parameters. In the default setting, the parameters are displayed with short, explanatory texts. To display the actual system names of the parameters, press the key for the screen layout key and then the **SHOW SYSTEM NAME** soft key. Follow the same procedure to return to the standard display.








The icons of not yet active parameters and objects appear dimmed. These can be activated with the **MORE FUNCTIONS** and **INSERT** soft key.

The TNC saves a modification list of the last 20 changes to the configuration data. To restore modifications, select the corresponding line and press the **MORE FUNCTIONS** and **CANCEL CHANGE** soft keys.




### Calling the configuration editor and changing parameters

- ▶ Select the **PROGRAMMING** operating mode
- ▶ Press the **MOD** key
- ▶ Enter the code number **123**
- ▶ Changing parameters
- ▶ Press the **END** soft key to exit the configuration editor
- ▶ Confirm changes with the **STORE** soft key

The icon at the beginning of each line in the parameter tree shows additional information about this line. The icons have the following meanings:

-  Branch exists but is closed
-  Branch is open
-  Empty object, cannot be opened
-  Initialized machine parameter
-  Uninitialized (optional) machine parameter
-  Can be read but not edited
-  Can neither be read nor edited

The type of the configuration object is identified by its folder symbol:

-  Key (group name)
-  List
-  Entity (parameter object)

### Displaying help texts

The **HELP** key enables you to call a help text for each parameter object or attribute.

If the help text does not fit on one page (1/2 is then displayed at the upper right, for example), press the **HELP PAGE** soft key to scroll to the second page.

To exit the help text, press the **HELP** key again.

As well as the Help text, other information is displayed, e.g. unit of measurement, initial value, selection list. If the selected machine parameter matches a parameter in the previous control model, the corresponding MP number is displayed.

## 19.1 Machine-specific user parameters

## Parameter list

## Parameter settings

## DisplaySettings

Settings for screen display

Sequence of displayed axes

[0] to [7]

**Depends on available axes**

Type of position display in position window

**NOMINAL**

**ACTUAL**

**REF ACTL**

**REF NOML**

**LAG**

**ACTDST**

**REFDST**

**M 118**

Type of position display in status display

**NOMINAL**

**ACTUAL**

**REF ACTL**

**REF NOML**

**LAG**

**ACTDST**

**REFDST**

**M 118**

Definition of decimal separator for position display

.

Display of feed rate in operating mode Manual operation

**at axis key: Only display feed rate if axis direction key is pressed**

**always minimum: Always display feed rate**

Display of spindle position in the position display

**during closed loop: Only display spindle position if spindle is in position control**

**during closed loop and M5: Display spindle position if spindle is in position control and with M5**

Show or hide soft key preset table

**True: Soft key preset table is not displayed**

**False: Display soft key preset table**

Font size with program display

**FONT\_APPLICATION\_SMALL**

**FONT\_APPLICATION\_MEDIUM**

**Parameter settings**

---

## DisplaySettings

Display step for individual axes

List of all available axes

Display step for position display in mm or degrees

**0.1**

**0.05**

**0.01**

**0.005**

**0.001**

**0.0005**

**0.0001**

**0.00005 (Option 23)**

**0.00001 (Option 23)**

Display step for position display in inches

**0.005**

**0.001**

**0.0005**

**0.0001**

**0.00005 (Option 23)**

**0.00001 (Option 23)**

---

DisplaySettings

Definition of unit of measure valid for the display

**metric: Use metric system**

**inch: Use inch system**

---

DisplaySettings

Format of NC programs and display of cycles

Program input in HEIDENHAIN Klartext conversational text or in DIN/ISO

**HEIDENHAIN: Program input in operating mode MDI in Klartext conversational text dialog**

**ISO: Program input in Positioning with MDI mode of operation in DIN/ISO**

## 19.1 Machine-specific user parameters

### Parameter settings

---

#### DisplaySettings

Setting the NC and PLC dialog language

NC dialog language

**ENGLISH**

**GERMAN**

**CZECH**

**FRENCH**

**ITALIAN**

**SPANISH**

**PORTUGUESE**

**SWEDISH**

**DANISH**

**FINNISH**

**DUTCH**

**POLISH**

**HUNGARIAN**

**RUSSIAN**

**CHINESE**

**CHINESE\_TRAD**

**SLOVENIAN**

**KOREAN**

**NORWEGIAN**

**ROMANIAN**

**SLOVAK**

**TURKISH**

PLC dialog language

**See NC dialog language**

PLC error message language

**See NC dialog language**

Help language

**See NC dialog language**

---



**Parameter settings**

---

## DisplaySettings

Behavior with control start-up

Acknowledge "Power interrupted" message

**TRUE: Control start-up is not continued until the message has been acknowledged****FALSE: "Power interrupted" message not displayed**

---

DisplaySettings

Display mode for time display

Selection for display mode in the time display

**Analog****Digital****Logo****Analog and Logo****Digital and Logo****Analog on Logo****Digital on Logo**

---

DisplaySettings

Link row On/Off

Display setting for link row

**OFF: Deactivate the information line in the operating mode line****ON: Activate the information line in the operating mode line**

---

DisplaySettings

Settings for 3-D display

Model type of 3-D display

**3-D (compute-intensive): Model display for complex machining operations with undercuts****2.5-D: Model display for 3-axis machining operations****No Model: Model display is disabled**

Model quality of the 3-D display

**very high: High resolution; Block end points can be displayed****high: High resolution****medium: Medium resolution****low: Low resolution**

---

## 19.1 Machine-specific user parameters

### Parameter settings

---

DisplaySettings

Settings for the  
position display

#### **Position display**

with TOOL CALL DL

**As Tool Length:** The programmed oversize DL is considered as the tool length modification for display of the workpiece-based position

**As Workpiece Oversize:** The programmed oversize DL is considered as the workpiece oversize for display of the workpiece-based position

---

## Parameter settings

### ProbeSettings

Configuration of tool measurement

TT140\_1

M function for spindle orientation

**-1: Spindle orientation directly by NC**

**0: Function inactive**

**1 to 999: Number of M function for spindle orientation**

Probing routine

**MultiDirections: Probing from several directions**

**SingleDirection: Probing from one direction**

Probing direction for tool radius measurement

**X\_Positive, Y\_Positive, X\_Negative, Y\_Negative, Z\_Positive, Z\_Negative (depending on tool axis)**

Distance between lower surface of tool and upper surface of stylus

**0.001 bis 99.9999 [mm]: Offset between stylus to tool**

Rapid traverse in probing cycle

**10 to 300 000 [mm/min]: Rapid traverse in probing cycle**

Probing feed rate with tool measurement

**1 to 3 000 [mm/min]: Probing feed rate with tool measurement**

Calculation of probing feed rate

**ConstantTolerance: Calculation of probing feed rate with constant tolerance**

**VariableTolerance: Calculation of probing feed rate with variable tolerance**

**ConstantFeed: Constant probing feed rate**

Type of speed detection

**Automatic: Determine speed automatically**

**MinSpindleSpeed: Use minimum spindle speed**

Maximum permissible rotational speed the tool tip

**1 to 129 [m/min]: Permissible rotational speed on cutter circumference**

Maximum permissible speed with tool measurement

**0 to 1 000 [1/min]: Maximum permissible speed**

Maximum permissible measuring error with tool measurement

**0.001 to 0.999 [mm]: First maximum permissible measuring error**

Maximum permissible measuring error with tool measurement

**0.001 to 0.999 [mm]: Second maximum permissible measuring error**

NC stop during tool check

**True: NC program is stopped if breakage tolerance is exceeded**

**False: NC program is not stopped**

## 19.1 Machine-specific user parameters

Parameter settings

---

NC stop during tool measurement

**True: NC program is stopped if breakage tolerance is exceeded**

**False: NC program is not stopped**

Modifying of tool table during tool check and measurement

**AdaptOnMeasure: Table is modified after tool measurement**

**AdaptOnBoth: Table is modified after tool check and measurement**

**AdaptNever: Table is not modified after tool check and measurement**

Configuration of a round stylus

TT140\_1

Coordinates of the stylus center

**[0]: X coordinate of stylus center referenced to machine datum**

**[1]: Y coordinate of stylus center referenced to machine datum**

**[2]: Z coordinate of stylus center referenced to machine datum**

Safety clearance over stylus for pre-positioning

**0.001 to 99 999.9999 [mm]: Safety clearance in tool axis direction**

Safety zone around stylus for pre-positioning

**0.001 to 99 999.9999 [mm]: Safety clearance in plane perpendicular to tool axis**

---

## Parameter settings

### ChannelSettings

#### CH\_NC

##### Active kinematics

Kinematics to be activated

**List of machine kinematics**

Kinematics to be activated with control start-up

**List of machine kinematics**

##### Determining the behavior of the NC program

Resetting the machining time with program start

**True: Machining time is reset**

**False: Machining time is not reset**

PLC signal for number of pending machining cycle

**Dependent on machine manufacturer**

##### Geometry tolerances

Permissible deviation of circle radius

**0.0001 to 0.016 [mm]: Permissible deviation of circle radius on the circle end point compared to circle start point**

##### Configuration of machining cycles

Overlap factor for pocket milling

**0.001 to 1.414: Overlap factor for Cycle 4 POCKET MILLING and Cycle 5 CIRCULARPOCKET**

Behavior after machining a contour pocket

**PosBeforeMachining: Position as before machining a cycle**

**ToolAxClearanceHeight: Position tool axis to clearance height**

Display "Spindle ?" error message if M3/M4 is not active

**on: Output error message**

**off: Do not output error message**

Display "Enter negative depth" error message

**on: Output error message**

**off: Do not output error message**

Approach behavior on a slot wall in a cylindrical surface

**LineNormal: Approach with straight line**

**CircleTangential: Approach with an arc movement**

M function for spindle orientation in machining cycles

**-1: Spindle orientation directly via NC**

**0: Function inactive**

**1 to 999: Number of M function for spindle orientation**

Do not display "Plunging type not possible" error message

**on: Error message is not displayed**

## 19.1 Machine-specific user parameters

## Parameter settings

**off: Error message is displayed**

Behavior of M7 and M8 with cycles 202 and 204

**TRUE: At the end of cycle 202 and 204 the condition of M7 and M8 is restored before the cycle call**

**FALSE: At the end of cycle 202 and 204 the condition of M7 and M8 is not restored independently**

Automatic feed rate reduction after reaching SMAX

**100: Feed rate reduction deactivated**

**0 < factor < 100: Feed rate reduction activated. Minimum feed rate in percent of programmed feed rate in the turning cycle**

Geometry filter for filtering out linear elements

Type of stretch filter

**- Off: No filter active**

**- ShortCut: Leave out single points on polygon**

**- Average: The geometry filter smooths corners**

Maximum distance of filtered to unfiltered contour

**0 to 10 [mm]: The filtered out points lie within this tolerance to the resultant distance**

Maximum length of distance resulting from filtering

**0 to 1000 [mm]: Length over which geometry filtering is effective**

## Parameter settings

### Settings for the NC editor

#### Creating backup files

**TRUE: Create backup file after editing NC programs**

**FALSE: Create no backup file after editing NC programs**

#### Cursor behavior after deleting lines

**TRUE: Cursor is on previous line after deletion (iTNC behavior)**

**FALSE: Cursor is on subsequent line after deletion**

#### Cursor behavior with the first and last line

**TRUE: All-round cursors permitted at PGM beginning/end**

**FALSE: All-round cursors not permitted at PGM beginning/end**

#### Line break with multi-line blocks

**ALL: Always show lines completely**

**ACT: Only show lines of the active block completely**

**NO: Only show lines completely if the block is edited**

#### Activate help graphics with cycle input

**TRUE: Fundamentally always show help graphics during input**

**FALSE: Only show help graphics if the CYCLE HELP soft key is set to ON. The CYCLE HELPOFF/ON soft key is displayed in the Programming mode after pressing the "Screen layout" button**

#### Behavior of soft key row following a cycle input

**TRUE: Leave cycle soft key row active after a cycle definition**

**FALSE: Hide cycle soft key row after a cycle definition**

#### Confirmation request before block is deleted

**TRUE: Display confirmation request before deleting an NC block**

**FALSE: Do not display confirmation request before deleting an NC block**

#### Zeilennummer, bis zu der eine Prüfung des NC-Programms durchgeführt wird

**100 bis 100000: Program length for which geometry should be tested**

#### ISO programming: Block number increment

**0 to 250: Increment for generating ISO blocks in the program**

#### Define programmable axes

**TRUE: Use defined axis configuration**

**FALSE: Use default axis configuration XYZABCUVW**

#### Behavior with paraxial positioning blocks

**TRUE: Paraxial positioning blocks permitted**

**FALSE: Paraxial positioning blocks locked**

#### Line number up to which identical syntax elements are searched for

**500 to 400000: Search for selected elements with up/down arrow keys**

#### Behavior of PARAXMODE function with UVW axes

**FALSE: PARAXMODE function permitted**

19.1 Machine-specific user parameters

Parameter settings

**TRUE: PARAXMODE function locked**

Settings for the file manager

Display of dependent files

**MANUAL: Dependent files are displayed**

**AUTOMATIC: Dependent files are not displayed**

Path specifications for end users

List with drives and/or directories

**Drives and directories entered here are shown by the TNC in the file manager**

FN 16 output path for execution

**Path for FN 16 output if no path has been defined in the program**

FN 16 output path for Programming and Test Run operating modes

**Path for FN 16 output if no path has been defined in the program**

Serial Interface RS232

**Further Information:** "Setting up data interfaces", page 709



## 19.2 Connector pin layout and connection cables for data interfaces

### RS-232-C/V.24 interface for HEIDENHAIN devices



The interface complies with the requirements of EN 50 178 for **low voltage electrical separation**.

When using the 25-pin adapter block:

TNC		Conn. cable 365725-xx		Adapter block 310085-01		Conn. cable 274545-xx			
Male	Assignment	Female	Color	Female	Male	Female	Male	Color	Female
1	Do not assign	1		1	1	1	1	White/ Brown	1
2	RXD	2	Yellow	3	3	3	3	Yellow	2
3	TXD	3	Green	2	2	2	2	Green	3
4	DTR	4	Brown	20	20	20	20	Brown	8
5	Signal GND	5	Red	7	7	7	7	Red	7
6	DSR	6	Blue	6	6	6	6		6
7	RTS	7	Gray	4	4	4	4	Gray	5
8	CTR	8	Pink	5	5	5	5	Pink	4
9	Do not assign	9					8	Violet	20
Hsg.	External shield	Hsg.	External shield	Hsg.	Hsg.	Hsg.	Hsg.	External shield	Hsg.

## Tables and Overviews

### 19.2 Connector pin layout and connection cables for data interfaces

When using the 9-pin adapter block:

<b>TNC</b>		<b>Conn. cable 355484-xx</b>		<b>Adapter block 363987-02</b>		<b>Conn. cable 366964-xx</b>			
Male	Assignment	Female	Color	Male	Female	Male	Female	Color	Female
1	Do not assign	1	Red	1	1	1	1	Red	1
2	RXD	2	Yellow	2	2	2	2	Yellow	3
3	TXD	3	White	3	3	3	3	White	2
4	DTR	4	Brown	4	4	4	4	Brown	6
5	Signal GND	5	Black	5	5	5	5	Black	5
6	DSR	6	Violet	6	6	6	6	Violet	4
7	RTS	7	Gray	7	7	7	7	Gray	8
8	CTR	8	White/ Green	8	8	8	8	White/ Green	7
9	Do not assign	9	Green	9	9	9	9	Green	9
Hsg.	External shield	Hsg.	External shield	Hsg.	Hsg.	Hsg.	Hsg.	External shield	Hsg.

### Non-HEIDENHAIN devices

The connector layout of a non-HEIDENHAIN device may substantially differ from that of a HEIDENHAIN device.

It depends on the unit and the type of data transfer. The table below shows the connector pin layout on the adapter block.

Adapter block 363987-02		Conn. cable 366964-xx		
Female	Male	Female	Color	Female
1	1	1	Red	1
2	2	2	Yellow	3
3	3	3	White	2
4	4	4	Brown	6
5	5	5	Black	5
6	6	6	Violet	4
7	7	7	Gray	8
8	8	8	White/ Green	7
9	9	9	Green	9
Hsg.	Hsg.	Hsg.	External shield	Hsg.

## 19.2 Connector pin layout and connection cables for data interfaces

### Ethernet interface RJ45 socket

Maximum cable length:

- Unshielded: 100 m
- Shielded: 400 m

Pin	Signal	Description
1	TX+	Transmit Data
2	TX–	Transmit Data
3	REC+	Receive Data
4	Vacant	
5	Vacant	
6	REC–	Receive Data
7	Vacant	
8	Vacant	

## 19.3 Technical Information

### Explanation of symbols

- Default
- Axis option
- 1 Advanced Function Set 1
- 2 Advanced Function Set 2

### Specifications

<b>Components</b>	<ul style="list-style-type: none"> <li>■ Operating panel</li> <li>■ TFT color flat-panel display with soft keys</li> </ul>
<b>Program memory</b>	<ul style="list-style-type: none"> <li>■ Minimum 21 GB</li> </ul>
<b>Input resolution and display step</b>	<ul style="list-style-type: none"> <li>■ As fine as 0.1 µm for linear axes</li> <li>■ As fine as 0.01 µm for linear axes (with option 23)</li> <li>■ Up to 0.0001° for rotary axes</li> <li>■ Up to 0.000 01° for rotary axes (with option 23)</li> </ul>
<b>Input range</b>	<ul style="list-style-type: none"> <li>■ Maximum 999 999 999 mm or 999 999 999°</li> </ul>
<b>Interpolation</b>	<ul style="list-style-type: none"> <li>■ Linear in 4 axes</li> <li>■ Circular in 2 axes</li> <li>■ Helical: superimposition of circular and straight paths</li> </ul>
<b>Block processing time</b> 3-D straight line without radius compensation	<ul style="list-style-type: none"> <li>■ 0.5 ms</li> </ul>
<b>Axis feedback control</b>	<ul style="list-style-type: none"> <li>■ Position loop resolution: Signal period of the position encoder/1024</li> <li>■ Cycle time of position controller: 3 ms</li> <li>■ Cycle time of speed controller: 200 µs</li> </ul>
<b>Range of traverse</b>	<ul style="list-style-type: none"> <li>■ Maximum 100 m (3937 inches)</li> </ul>
<b>Spindle speed</b>	<ul style="list-style-type: none"> <li>■ Maximum 100,000 rpm (analog speed command signal)</li> </ul>
<b>Error compensation</b>	<ul style="list-style-type: none"> <li>■ Linear and nonlinear axis error, backlash, reversal peaks during circular movements, thermal expansion</li> <li>■ Static friction</li> </ul>
<b>Data interfaces</b>	<ul style="list-style-type: none"> <li>■ One each RS-232-C /V.24 max. 115 kilobaud</li> <li>■ Expanded interface with LSV-2 protocol for external operation of the TNC over the interface with HEIDENHAIN software TNCremo</li> <li>■ Ethernet interface 1000 BaseT</li> <li>■ 5 x USB (1 x front USB 2.0; 4 x rear USB 3.0)</li> </ul>
<b>Ambient temperature</b>	<ul style="list-style-type: none"> <li>■ Operation: 5 °C to +40 °C</li> <li>■ Storage: -20 °C to +60 °C</li> </ul>

## Input formats and units of TNC functions

<b>Positions, coordinates, circle radii, chamfer lengths</b>	-99 999.9999 to +99 999.9999 (5, 4: places before the decimal point, places after the decimal point) [mm]
<b>Tool numbers</b>	0 to 32 767.9 (5, 1)
<b>Tool names</b>	32 characters, enclosed by quotation marks with <b>TOOL CALL</b> . Permitted special characters: # \$ % & . , - _
<b>Detail values for tool compensation</b>	-99.9999 to +99.9999 (2, 4) [mm]
<b>Spindle speeds</b>	0 to 99 999.999 (5, 3) [rpm]
<b>Feed rates</b>	0 to 99,999.999 (5, 3) [mm/min] or [mm/tooth] or [mm/1]
<b>Dwell time in Cycle 9</b>	0 to 3600.000 (4, 3) [s]
<b>Thread pitch in various cycles</b>	-9.9999 to +9.9999 (2, 4) [mm]
<b>Angle for spindle orientation</b>	0 to 360.0000 (3, 4) [°]
<b>Angle for polar coordinates, rotation, tilting the working plane</b>	-360.0000 to 360.0000 (3, 4) [°]
<b>Polar coordination for screw line interpolation (CP)</b>	-5 400.0000 to 5 400.0000 (4, 4) [°]
<b>Datum numbers in Cycle 7</b>	0 to 2999 (4, 0)
<b>Scaling factor in Cycles 11 and 26</b>	0.000001 to 99.999999 (2, 6)
<b>Miscellaneous functions M</b>	0 to 999 (4, 0)
<b>Q parameter numbers</b>	0 to 1999 (4, 0)
<b>Q parameter values</b>	-99 999.9999 to +99 999.9999 (9, 6)
<b>Surface-normal vectors N and T with 3-D compensation</b>	-9.99999999 to +9.99999999 (1, 8)
<b>Labels (LBL) for program jumps</b>	0 to 999 (5, 0)
<b>Labels (LBL) for program jumps</b>	Any text string in quotation marks (""")
<b>Number of program section repeats REP</b>	1 to 65 534 (5, 0)
<b>Error number in Q parameter function FN14</b>	0 to 1199 (4, 0)

## User functions

### User functions

<b>Short description</b>	<ul style="list-style-type: none"> <li>■ Basic version: 3 axes plus closed-loop spindle</li> <li>■ Fourth NC axis plus auxiliary axis</li> <li>or</li> <li>□ 8 additional axes or 7 additional axes plus 2nd spindle</li> <li>■ Digital current and speed control</li> </ul>
<b>Program entry</b>	In HEIDENHAIN conversational format and DIN/ISO
<b>Position entry</b>	<ul style="list-style-type: none"> <li>■ Nominal positions for lines and arcs in Cartesian coordinates or polar coordinates</li> <li>■ Incremental or absolute dimensions</li> <li>■ Display and entry in mm or inches</li> </ul>
<b>Tool compensation</b>	<ul style="list-style-type: none"> <li>■ Tool radius in the working plane and tool length</li> <li>■ Radius compensated contour look ahead for up to 99 blocks (M120)</li> <li><b>2</b> Three-dimensional tool-radius compensation for changing tool data without having to recalculate an existing program</li> </ul>
<b>Tool tables</b>	Multiple tool tables with any number of tools
<b>Constant contour speed</b>	<ul style="list-style-type: none"> <li>■ With respect to the path of the tool center</li> <li>■ With respect to the cutting edge</li> </ul>
<b>Parallel operation</b>	Creating a program with graphical support while another program is being run
<b>3-D machining (Advanced Function Set 2)</b>	<ul style="list-style-type: none"> <li><b>2</b> Motion control with minimum jerk</li> <li><b>2</b> 3-D tool compensation through surface-normal vectors</li> <li><b>2</b> Using the electronic handwheel to change the angle of the swivel head during program run without affecting the position of the tool point. (TCPM = Tool Center Point Management)</li> <li><b>2</b> Keeping the tool normal to the contour</li> <li><b>2</b> Tool radius compensation perpendicular to traversing and tool direction</li> </ul>
<b>Rotary table machining (Advanced Function Set 1)</b>	<ul style="list-style-type: none"> <li><b>1</b> Programming of cylindrical contours as if in two axes</li> <li><b>1</b> Feed rate in distance per minute</li> </ul>
<b>Contour elements</b>	<ul style="list-style-type: none"> <li>■ Straight line</li> <li>■ Chamfer</li> <li>■ Circular path</li> <li>■ Circle center</li> <li>■ Circle radius</li> <li>■ Tangentially connected arc</li> <li>■ Rounded corners</li> </ul>
<b>Approaching and departing the contour</b>	<ul style="list-style-type: none"> <li>■ Via straight line: tangential or perpendicular</li> <li>■ Via circular arc</li> </ul>
<b>FK free contour programming</b>	<ul style="list-style-type: none"> <li>■ FK free contour programming in HEIDENHAIN conversational format with graphic support for workpiece drawings not dimensioned for NC</li> </ul>

**User functions**

<b>Program jumps</b>	<ul style="list-style-type: none"> <li>■ Subprograms</li> <li>■ Program section repeat</li> <li>■ Any desired program as subprogram</li> </ul>
<b>Machining cycles</b>	<ul style="list-style-type: none"> <li>■ Cycles for drilling, and conventional and rigid tapping</li> <li>■ Roughing of rectangular and circular pockets</li> <li>■ Cycles for pecking, reaming, boring, and counterboring</li> <li>■ Cycles for milling internal and external threads</li> <li>■ Finishing of rectangular and circular pockets</li> <li>■ Cycles for clearing level and inclined surfaces</li> <li>■ Cycles for milling linear and circular slots</li> <li>■ Cartesian and polar point patterns</li> <li>■ Contour-parallel contour pocket</li> <li>■ Contour train</li> <li>■ Cycles for turning operations</li> <li>■ OEM cycles (special cycles developed by the machine manufacturer) can also be integrated</li> </ul>
<b>Coordinate transformation</b>	<ul style="list-style-type: none"> <li>■ Datum shift, rotation, mirroring</li> <li>■ Scaling factor (axis-specific)</li> <li><b>1</b> Tilting the working plane (Advanced Function Set 1)</li> </ul>
<b>Q parameters</b> Programming with variables	<ul style="list-style-type: none"> <li>■ Mathematical functions: =, +, -, *, sin <math>\alpha</math>, cos <math>\alpha</math>, root</li> <li>■ Logical operations (=, <math>\neq</math>, &lt;, &gt;)</li> <li>■ Calculating with parentheses</li> <li>■ tan <math>\alpha</math>, arc sin, arc cos, arc tan, <math>a^n</math>, <math>e^n</math>, ln, log, absolute value of a number, constant <math>\pi</math>, negation, truncation of digits before or after the decimal point</li> <li>■ Functions for calculation of circles</li> <li>■ String parameters</li> </ul>
<b>Programming aids</b>	<ul style="list-style-type: none"> <li>■ Calculator</li> <li>■ Complete list of all current error messages</li> <li>■ Context-sensitive help function for error messages</li> <li>■ Graphic support for the programming of cycles</li> <li>■ Comment blocks in NC program</li> </ul>
<b>Teach-In</b>	<ul style="list-style-type: none"> <li>■ Actual positions can be transferred directly to the NC program</li> </ul>
<b>Test graphics</b> Display modes	<ul style="list-style-type: none"> <li>■ Graphical simulation before a program run, also while another program is being run</li> <li>■ Plan view / projection in 3 planes / 3-D view / 3-D line graphic</li> <li>■ Detail enlargement</li> </ul>
<b>Programming graphics</b>	<ul style="list-style-type: none"> <li>■ In Programming mode, the contour of the NC blocks is drawn on screen while they are being entered (2-D pencil-trace graphics), even if another program is running</li> </ul>



**User functions**

<b>Program-run graphics</b> Display modes	■ Graphic simulation of real-time machining in plan view / projection in 3 planes / 3-D view
<b>Machining time</b>	<ul style="list-style-type: none"> <li>■ Calculating the machining time in the Test Run operating mode</li> <li>■ Display of the current machining time in the Program Run operating modes</li> </ul>
<b>Contour, returning to</b>	<ul style="list-style-type: none"> <li>■ Block scan in any block in the program, returning the tool to the calculated nominal position to continue machining</li> <li>■ Program interruption, contour departure and return</li> </ul>
<b>Datum tables</b>	■ Multiple datum tables for storing workpiece-specific datums
<b>Touch probe cycles</b>	<ul style="list-style-type: none"> <li>■ Calibrating the touch probe</li> <li>■ Compensation of workpiece misalignment, manual or automatic</li> <li>■ Datum setting, manual or automatic</li> <li>■ Automatically measuring workpieces</li> <li>■ Cycles for automatic tool measurement</li> <li>■ Cycles for automatic kinematics measurement</li> </ul>

## Software options

### Advanced Function Set 1 (option 8)

#### Expanded functions Group 1

#### Machining with rotary tables

- Cylindrical contours as if in two axes
- Feed rate in distance per minute

#### Coordinate conversions:

Tilting the working plane

### Advanced Function Set 2 (option 9)

#### Expanded functions Group 2

Export license required

#### 3-D machining:

- Motion control with minimum jerk
- 3-D tool compensation through surface normal vectors
- Using the electronic handwheel to change the angle of the swivel head during program run without affecting the position of the tool point. (TCPM = Tool Center Point Management)
- Keeping the tool normal to the contour
- Tool radius compensation perpendicular to traversing direction and tool direction

#### Interpolation:

Linear in 6 axes

### HEIDENHAIN DNC (option 18)

Communication with external PC applications over COM component

### Display Step (option 23)

#### Display step

#### Input resolution:

- Linear axes down to 0.01  $\mu\text{m}$
- Rotary axes to 0.00001°

### Dynamic Collision Monitoring – DCM (option 40)

#### Dynamic Collision Monitoring

- The machine manufacturer defines objects to be monitored
- Warning in Manual operation
- Program interrupt in Automatic operation
- Includes monitoring of 5-axis movements

### DXF Converter (option 42)

#### DXF converter

- Supported DXF format: AC1009 (AutoCAD R12)
- Adoption of contours and point patterns
- Simple and convenient specification of reference points
- Selecting graphical features of contour sections from conversational programs

### Adaptive Feed Control – AFC (option 45)

#### Adaptive Feed Control

- Recording the actual spindle power by means of a teach-in cut
- Defining the limits of automatic feed rate control
- Fully automatic feed control during program run

**KinematicsOpt (option 48)****Optimizing the machine kinematics**

- Backup/restore active kinematics
- Test active kinematics
- Optimize active kinematics

**Mill-Turning (option 50)****Milling and turning modes****Functions:**

- Switching between Milling/Turning mode of operation
- Constant surface speed
- Tool-tip radius compensation
- Turning cycles
- Cycle 880: Gear hobbing (option 50 and option 131)

**KinematicsComp (option 52)****Three-dimensional compensation**

Compensation of position and component errors

Export license required

**3D-ToolComp (option 92)****3-D tool radius compensation depending on the tool's contact angle**

- Compensate the deviation of the tool radius depending on the tool's contact angle
- Compensation values in a separate compensation value table
- Prerequisite: Working with **LN** blocks

Export license required

**Extended Tool Management (option 93)****Extended tool management**

Python-based

**Advanced Spindle Interpolation (option number 96)****Interpolating spindle****Interpolation turning:**

- Cycle 291: Interpolation turning, coupling
- Cycle 292: Interpolation turning, contour finishing

**Spindle Synchronism (option 131)****Spindle synchronization**

- Synchronization of milling spindle and turning spindle
- Cycle 880: Gear hobbing (option 50 and option 131)

**Remote Desktop Manager (option 133)****Remote operation of external computer units**

- Windows on a separate computer unit
- Incorporated in the TNC interface

**Synchronizing Functions (option 135)****Synchronization functions****Real Time Coupling – RTC:**

Coupling of axes

**Visual Setup Control – VSC (option number 136)****Camera-based monitoring of the setup situation**

- Record the setup situation with a HEIDENHAIN camera system
- Visual comparison of planned and actual status in the workspace

**Cross Talk Compensation – CTC (option number 141)**

---

- |                                       |  |
|---------------------------------------|--|
| <b>Compensation of axis couplings</b> | <ul style="list-style-type: none"> <li>■ Determination of dynamically caused position deviation through axis acceleration</li> <li>■ Compensation of the TCP (<b>T</b>ool <b>C</b>enter <b>P</b>oint)</li> </ul> |
|---------------------------------------|--|

**Position Adaptive Control – PAC (option 142)**

---

- |                                  |   |
|----------------------------------|---|
| <b>Adaptive position control</b> | <ul style="list-style-type: none"> <li>■ Changing of the control parameters depending on the position of the axes in the working space</li> <li>■ Changing of the control parameters depending on the speed or acceleration of an axis</li> </ul> |
|----------------------------------|---|

**Load Adaptive Control – LAC (option 143)**

---

- |                              |   |
|------------------------------|---|
| <b>Adaptive load control</b> | <ul style="list-style-type: none"> <li>■ Automatic determination of workpiece weight and frictional forces</li> <li>■ Changing of control parameters depending on the actual mass of the workpiece</li> </ul> |
|------------------------------|---|

**Active Chatter Control – ACC (option number 145)**

---

- |                               |   |
|-------------------------------|---|
| <b>Active chatter control</b> | Fully automatic function for chatter control during machining |
|-------------------------------|---|

**Active Vibration Damping – AVD (option number 146)**

---

- |                                 |  |
|---------------------------------|--|
| <b>Active vibration damping</b> | Damping of machine oscillations to improve the workpiece surface |
|---------------------------------|--|

## Accessories

### Accessories

<b>Electronic handwheels</b>	<ul style="list-style-type: none"> <li>■ HR 410: Portable handwheel</li> <li>■ HR 550FS: Portable wireless handwheel with display</li> <li>■ HR 520: Portable handwheel with display</li> <li>■ HR 420: Portable handwheel with display</li> <li>■ HR 130: Panel-mounted handwheel</li> <li>■ HR 150: Up to three panel-mounted handwheels via handwheel adapter HRA 110</li> </ul>
<b>Touch probes</b>	<ul style="list-style-type: none"> <li>■ TS 260: Triggering 3-D touch probe with cable connection</li> <li>■ TS 440: 3-D touch trigger probe with infrared transmission</li> <li>■ TS 444: Battery-free 3-D touch trigger probe with infrared transmission</li> <li>■ TS 640: 3-D touch trigger probe with infrared transmission</li> <li>■ TS 740: High-precision 3-D touch trigger probe with infrared transmission</li> <li>■ TT 160: 3-D touch trigger probe for tool measurement</li> <li>■ TT 449: 3-D touch trigger probe for tool measurement with infrared transmission</li> </ul>

## Tables and Overviews

### 19.4 Overview tables

#### 19.4 Overview tables

##### Fixed cycles

Cycle number	Cycle name	DEF active	CALL active
7	DATUM SHIFT	■	
8	MIRRORING	■	
9	DWELL TIME	■	
10	ROTATION	■	
11	SCALING FACTOR	■	
12	PGM CALL	■	
13	ORIENTATION	■	
14	CONTOUR	■	
19	WORKING PLANE	■	
20	CONTOUR DATA	■	
21	PILOT DRILLING		■
22	ROUGH-OUT		■
23	FLOOR FINISHING		■
24	SIDE FINISHING		■
25	CONTOUR TRAIN		■
26	AXIS-SPECIFIC SCALING	■	
27	CYLINDER SURFACE		■
28	CYLINDER SURFACE		■
29	CYL SURFACE RIDGE		■
32	TOLERANCE	■	
39	CYL. SURFACE CONTOUR		■
200	DRILLING		■
201	REAMING		■
202	BORING		■
203	UNIVERSAL DRILLING		■
204	BACK BORING		■
205	UNIVERSAL PECKING		■
206	TAPPING		■
207	RIGID TAPPING		■
208	BORE MILLING		■
209	TAPPING W/ CHIP BRKG		■
210	SLOT RECIP. PLNG		■
211	CIRCULAR SLOT		■
212	POCKET FINISHING		■
213	STUD FINISHING		■

Cycle number	Cycle name	DEF active	CALL active
214	C. POCKET FINISHING		■
214	C. STUD FINISHING		■
220	POLAR PATTERN	■	
221	CARTESIAN PATTERN	■	
225	ENGRAVING		■
230	MULTIPASS MILLING		■
231	RULED SURFACE		■
232	FACE MILLING		■
233	FACE MILLING		■
239	ASCERTAIN THE LOAD	■	
240	CENTERING		■
241	SINGLE-LIP D.H.DRLNG		■
247	DATUM SETTING	■	
251	RECTANGULAR POCKET		■
252	CIRCULAR POCKET		■
253	SLOT MILLING		■
254	CIRCULAR SLOT		■
256	RECTANGULAR STUD		■
257	CIRCULAR STUD		■
258	POLYGON STUD		■
262	THREAD MILLING		■
263	THREAD MLLNG/CNTSNKG		■
264	THREAD DRILLNG/MLLNG		■
265	HEL. THREAD DRLG/MLG		■
267	OUTSIDE THREAD MLLNG		■
270	CONTOUR TRAIN DATA	■	
275	TROCHOIDAL SLOT		■
291	COUPLG.TURNG.INTERP.		■
292	CONTOUR.TURNG.INTRP.		■
800	ADJUST XZ SYSTEM	■	
801	RESET ROTARY COORDINATE SYSTEM	■	
810	TURN CONTOUR LONG.		■
811	SHOULDER, LONGITDNL.		■
812	SHOULDER, LONG. EXT.		■
813	TURN PLUNGE CONTOUR LONGITUDINAL		■
814	TURN PLUNGE LONGITUDINAL EXT.		■
815	CONTOUR-PAR. TURNING		■
820	TURN CONTOUR TRANSV.		■

## Tables and Overviews

### 19.4 Overview tables

Cycle number	Cycle name	DEF active	CALL active
821	SHOULDER, FACE		■
822	SHOULDER, FACE. EXT.		■
823	TURN TRANSVERSE PLUNGE		■
824	TURN PLUNGE TRANSVERSE EXT.		■
830	THREAD CONTOUR-PARALLEL		■
831	THREAD LONGITUDINAL		■
832	THREAD EXTENDED		■
840	RECESS TURNG, RADIAL		■
841	SIMPLE REC. TURNG., RADIAL DIR.		■
842	ENH.REC.TURNNG, RAD.		■
850	RECESS TURNG, AXIAL		■
851	SIMPLE REC TURNG, AX		■
852	ENH.REC.TURNING, AX.		■
860	CONT. RECESS, RADIAL		■
861	SIMPLE RECESS, RADL.		■
862	EXPND. RECESS, RADL.		■
870	CONT. RECESS, AXIAL		■
871	SIMPLE RECESS, AXIAL		■
872	EXPND. RECESS, AXIAL		■
880	GEAR HOBBING		■
892	CHECK IMBALANCE	■	

### Miscellaneous functions

M	Effect	Effective at block	Start	End	Page
<b>M0</b>	Program STOP/Spindle STOP/Coolant OFF			■	408
<b>M1</b>	Optional program run STOP/Spindle STOP/Coolant OFF			■	695
<b>M2</b>	Stop program/Spindle STOP/Coolant OFF/ CLEAR status display (depending on machine parameter)/Return jump to block 1			■	408
<b>M3</b>	Spindle ON clockwise		■		408
M4	Spindle ON counterclockwise		■		
M5	Spindle STOP			■	
<b>M6</b>	Tool change/STOP program run (depending on machine parameter)/Spindle STOP			■	408
<b>M8</b>	Coolant ON		■		408
M9	Coolant OFF			■	
<b>M13</b>	Spindle ON clockwise/Coolant ON		■		408
M14	Spindle ON counterclockwise/Coolant on		■		
<b>M30</b>	Same function as M2			■	408
<b>M89</b>	Vacant miscellaneous function <b>or</b> cycle call, modally effective (depending on machine parameter)		■	■	Cycles Manual



## Overview tables 19.4

M	Effect	Effective at block	Start	End	Page
<b>M91</b>	Within the positioning block: Coordinates are referenced to machine datum	■			409
<b>M92</b>	Within the positioning block: Coordinates are referenced to a position defined by machine manufacturer, e.g. tool change position	■			409
<b>M94</b>	Reduce the rotary axis display to a value below 360°	■			513
<b>M97</b>	Machine small contour steps			■	412
<b>M98</b>	Machine open contours completely			■	413
<b>M99</b>	Blockwise cycle call			■	Cycles Manual
<b>M101</b>	Automatic tool change with replacement tool if maximum tool life has expired			■	222
M102	Reset M101			■	
<b>M107</b>	Suppress error message for replacement tools with oversize			■	222
M108	Reset M107			■	
<b>M109</b>	Constant contouring speed at cutting edge (feed rate increase and reduction)	■			416
<b>M110</b>	Constant contouring speed at cutting edge (only feed rate reduction)	■			
M111	Reset M109/M110			■	
<b>M116</b>	Feed rate in mm/min on rotary axes	■			511
M117	Reset M116			■	
<b>M118</b>	Superimpose handwheel positioning during program run	■			419
<b>M120</b>	Pre-calculate the radius-compensated contour (LOOK AHEAD)	■			417
<b>M126</b>	Shorter-path traverse of rotary axes	■			512
M127	Reset M126			■	
<b>M128</b>	Maintaining the position of the tool tip when positioning with tilted axes (TCPM)	■			514
M129	Reset M128			■	
<b>M130</b>	Within the positioning block: Points are referenced to the untilted coordinate system	■			411
<b>M136</b>	Feed rate F in millimeters per spindle revolution	■			415
M137	Reset M136				
<b>M138</b>	Selection of tilted axes	■			517
<b>M140</b>	Retraction from the contour in the tool-axis direction	■			421
<b>M143</b>	Delete basic rotation	■			424
<b>M144</b>	Compensating the machine's kinematic configuration for ACTUAL/ NOMINAL positions at end of block	■			518
M145	Reset M144			■	
<b>M141</b>	Suppress touch probe monitoring	■			423
<b>M148</b>	Automatically retract tool from the contour at an NC stop	■			425
M149	Reset M148			■	

## 19.5 Functions of the TNC 640 and the iTNC 530 compared

## 19.5 Functions of the TNC 640 and the iTNC 530 compared

## Comparison: Specifications

Function	TNC 640	iTNC 530
Axes	18 maximum	18 maximum
<b>Input resolution and display step:</b>		
■ Linear axes	■ 0.1µm, 0.01 µm with option 23	■ 0.1 µm
■ Rotary axes	■ 0.001°, 0.00001° with option 23	■ 0.0001°
Control loops for high-frequency spindles and torque/linear motors	With option 49	With option 49
Display	19-inch TFT color flat-panel display or	19-inch TFT color flat-panel display or 15.1-inch TFT color flat-panel display
Memory media for NC, PLC programs and system files	Hard disk or SSDR solid state disk	Hard disk or SSDR solid state disk
Program memory for NC programs	> 21 GB	> 21 GB
Block processing time	0.5 ms	0.5 ms
HeROS operating system	Yes	Yes
<b>Interpolation:</b>		
■ Straight line	■ 6 axes	■ 5 axes
■ Circle	■ 3 axes	■ 3 axes
■ Helix	■ yes	■ Yes
■ Spline	■ No	■ Yes with option 9
Hardware	Modular in electrical cabinet	Modular in electrical cabinet

## Comparison: Data interfaces

Function	TNC 640	iTNC 530
Gigabit Ethernet 1000BaseT	X	X
RS-232-C/V.24 serial interface	X	X
RS-422/V.11 serial interface	-	X
USB interface	X	X

## Functions of the TNC 640 and the iTNC 530 compared 19.5

### Comparison: Accessories

Function	TNC 640	iTNC 530
<b>Electronic handwheels</b>		
■ HR 410510	X	X
■ HR 420	X	X
■ HR 520/530/550FS	X	X
■ HR 130	X	X
■ HR 150 via HRA 110	X	X
<b>Touch probes</b>		
■ TS 260/TS 460	X	X
■ TS 440/TS 444	X	X
■ TS 640/TS 642/TS 740	X	X
■ TS 220/TS 230	X	X
■ TS 249	X	X
■ SE 660	X	X
■ SE 540/SE 640/SE 642	X	X
■ TT 140	X	X
■ TT 160/TT460	X	X
■ TT 449	X	X
■ TL Nano	X	X
■ TL Micro 150/200/300	X	X
<b>Industrial PCs</b>		
■ IPC 6641	X	X
■ ITC 750/760	X	X
■ ITC 755	X	X

### Comparison: PC software

Function	TNC 640	iTNC 530
Programming station software	Available	Available
<b>TNCremo</b> for data transfer with <b>TNCbackup</b> for data back-up	Available	Available
<b>TNCremoPlus</b> data transfer software with "live" screen	Available	Available
<b>virtualTNC</b> : Control component for virtual machines	Available	Available

## 19.5 Functions of the TNC 640 and the iTNC 530 compared

## Comparison: Machine-specific functions

Function	TNC 640	iTNC 530
Switching the traverse range	Function available	Function available
Central drive (1 motor for multiple machine axes)	Function available	Function available
C axis drive (spindle motor drives rotary axis)	Function available	Function available
Automatic exchange of milling head	Function available	Function available
Support of angle heads	Function available	Function available
Balluf tool identification	Function available (with Python)	Function available
Management of multiple tool magazines	Function available	Function available
Expanded tool management via Python	Function available	Function available

## Comparison: User functions

Function	TNC 640	iTNC 530
<b>Program entry</b>		
■ In Klartext conversational language	■ X	■ X
■ DIN/ISO	■ X	■ X
■ With smarT.NC	■ –	■ X
■ With ASCII editor	■ X, directly editable	■ X, editable after conversion
<b>Position entry</b>		
■ Nominal positions for lines and arcs in Cartesian coordinates	■ X	■ X
■ Nominal positions for lines and arcs in polar coordinates	■ X	■ X
■ Incremental or absolute dimensions	■ X	■ X
■ Display and entry in mm or inches	■ X	■ X
■ Set the last tool position as pole (empty CC block)	■ X (error message if pole transfer is ambiguous)	■ X
■ Surface-normal vectors ( <b>LN</b> )	■ X	■ X
■ Spline sets ( <b>SPL</b> )	■ –	■ X, with option 9

## Functions of the TNC 640 and the iTNC 530 compared 19.5

Function	TNC 640	iTNC 530
<b>Tool compensation</b>		
■ In the working plane and tool length	■ X	■ X
■ Radius compensated contour look ahead for up to 99 blocks	■ X	■ X
■ Three-Dimensional Tool Radius Compensation	■ X, with option 9	■ X, with option 9
<b>Tool table</b>		
■ Central storage of tool data	■ X	■ X
■ Multiple tool tables with any number of tools	■ X	■ X
■ Flexible management of tool types	■ X	■ –
■ Filtered display of selectable tools	■ X	■ –
■ Sorting function	■ X	■ –
■ Column names	■ Sometimes with _	■ Sometimes with -
■ Copy function: Overwriting relevant tool data	■ X	■ X
■ Form view	■ Switchover with Screen Layout key	■ Switchover by soft key
■ Exchange of tool table between TNC 640 and iTNC 530	■ X	■ Not possible
Touch probe table for managing different 3-D touch probes	X	–
<b>Creating tool-usage file, checking the availability</b>	X	X
<b>Cutting data calculator:</b> Automatic calculation of spindle speed and feed rate	Simple cutting data calculator	Using stored technology tables
<b>Define any tables</b>		
	■ Freely definable tables (.TAB files)	■ Freely definable tables (.TAB files)
	■ Reading and writing with FN functions	■ Reading and writing with FN functions
	■ Definable via config. data	
	■ Table names must start with a letter	
	■ Reading and writing with SQL functions	

## 19.5 Functions of the TNC 640 and the iTNC 530 compared

Function	TNC 640	iTNC 530
<b>Constant contouring speed</b> relative to the path of the tool center or relative to the tool's cutting edge	X	X
<b>Parallel operation:</b> Creating programs while another program is being run	X	X
<b>Programming of counter axes</b>	X	X
<b>Tilting the working plane (Cycle 19, PLANE function)</b>	X, option 8	X, option 8
<b>Machining with a rotary table:</b>		
■ Programming of cylindrical contours as if in two axes		
■ Cylindrical surface (Cycle 27)	■ X, option 8	■ X, option 8
■ Cylinder surface, slot (Cycle 28)	■ X, option 8	■ X, option 8
■ Cylinder surface, ridge (Cycle 29)	■ X, option 8	■ X, option 8
■ Cylinder surface, external contour (Cycle 39)	■ X, option 8	■ X, option 8
■ Feed rate in mm/min or rev/min	■ X, option 8	■ X, option 8
<b>Traverse in tool-axis direction</b>		
■ Manual operation (3-D ROT menu)	■ X	■ X, FCL2 function
■ During program interruption	■ X	■ X
■ With handwheel superimpositioning	■ X	■ X, option #44
<b>Approaching and departing the contour</b> via a straight line or arc	X	X
<b>Entry of feed rates:</b>		
■ <b>F</b> (mm/min), rapid traverse <b>FMAX</b>	■ X	■ X
■ <b>FU</b> (feed per revolution mm/1)	■ X	■ X
■ <b>FZ</b> (tooth feed rate)	■ X	■ X
■ <b>FT</b> (time in seconds for path)	■ –	■ X
■ <b>FMAXT</b> (only for active rapid traverse potentiometer: time in seconds for path)	■ –	■ X
<b>FK free contour programming</b>		
■ Programming for workpiece drawings not dimensioned for NC programming	■ X	■ X
■ Conversion of FK program to Klartext conversational language	■ –	■ X
<b>Program jumps:</b>		
■ Maximum number of label numbers	■ 9999	■ 1000
■ Subprograms	■ X	■ X
■ Nesting depth for subprograms	■ 20	■ 6
■ Program section repetitions	■ X	■ X
■ Any desired program as subroutine	■ X	■ X

## Functions of the TNC 640 and the iTNC 530 compared 19.5

Function	TNC 640	iTNC 530
<b>Q parameter programming:</b>		
■ Standard mathematical functions	■ X	■ X
■ Formula entry	■ X	■ X
■ String processing	■ X	■ X
■ Local Q parameters <b>QL</b>	■ X	■ X
■ Nonvolatile Q parameters <b>QR</b>	■ X	■ X
■ Changing parameters during program interruption	■ X	■ X
■ FN15:PRINT	■ –	■ X
■ FN25:PRESET	■ –	■ X
■ FN26:TABOPEN	■ X	■ X
■ FN27:TABWRITE	■ X	■ X
■ FN28:TABREAD	■ X	■ X
■ FN29: PLC LIST	■ X	■ –
■ FN31: RANGE SELECT	■ –	■ X
■ FN32: PLC PRESET	■ –	■ X
■ FN37:EXPORT	■ X	■ –
■ FN38: SEND	■ X	■ X
■ Saving file externally with <b>FN16</b>	■ X	■ X
■ <b>FN16</b> formatting: Left-aligned, right-aligned, string lengths	■ X	■ X
■ Writing to LOG file with <b>FN16</b>	■ X	■ –
■ Displaying parameter contents in the additional status display	■ X	■ –
■ Displaying parameter contents during programming (Q-INFO)	■ X	■ X
■ <b>SQL</b> functions for writing and reading tables	■ X	■ –

## 19.5 Functions of the TNC 640 and the iTNC 530 compared

Function	TNC 640	iTNC 530
<b>Graphic support</b>		
■ 2-D programming graphics	■ X	■ X
■ REDRAW function ( <b>REDRAW</b> )	■ –	■ X
■ Show grid lines as the background	■ X	■ –
■ 3-D line graphics	■ X	■ X
■ Test graphics (plan view, projection on 3 planes, 3-D view)	■ X	■ X
■ High-resolution view	■ X	■ X
■ Tool display	■ X	■ X
■ Adjusting the simulation speed	■ X	■ X
■ Coordinates of line intersection for projection in 3 planes	■ –	■ X
■ Expanded zoom functions (mouse operation)	■ X	■ X
■ Displaying frame for workpiece blank	■ X	■ X
■ Displaying the depth value in plan view during mouse-over	■ X	■ X
■ Deliberately stop test run ( <b>STOP AT</b> )	■ X	■ X
■ Factor in tool change macro	■ X (differing to actual execution)	■ X
■ Program run graphics (plan view, projection in 3 planes, 3-D view)	■ X	■ X
■ High-resolution view	■ X	■ X



## Functions of the TNC 640 and the iTNC 530 compared 19.5

Function	TNC 640	iTNC 530
<b>Datum tables:</b> Storing workpiece-specific datums	X	X
<b>Preset table:</b> for saving reference points (presets)	X	X
<b>Pallet management</b>		
■ Support of pallet files	■ X	■ X
■ Tool-oriented machining	■ –	■ X
■ Pallet preset table: Managing pallet datums	■ –	■ X
<b>Returning to the contour</b>		
■ With mid-program startup	■ X	■ X
■ After program interruption	■ X	■ X
<b>Auto-start function</b>	X	X
<b>Teach-in:</b> Actual positions can be transferred to an NC program	X	X
<b>Enhanced file management</b>		
■ Creating multiple directories and subdirectories	■ X	■ X
■ Sorting function	■ X	■ X
■ Mouse operation	■ X	■ X
■ Selection of target directory by soft key	■ X	■ X
<b>Programming aids:</b>		
■ Help graphics for cycle programming	■ X	■ X
■ Animated help graphics when <b>PLANE/PATTERN DEF</b> function is selected	■ X	■ X
■ Help graphics for <b>PLANE/PATTERN DEF</b>	■ X	■ X
■ Context-sensitive help function for error messages	■ X	■ X
■ <b>TNCguide</b> , browser-based help system	■ X	■ X
■ Context-sensitive call of help system	■ X	■ X
■ Calculator	■ X (scientific)	■ X (standard)
■ Comment blocks in NC program	■ X	■ X
■ Structure blocks in NC program	■ X	■ X
■ Structure view in test run	■ –	■ X
<b>Dynamic Collision Monitoring (DCM):</b>		
■ Collision monitoring in Automatic operation	■ X, option 40	■ X, option 40
■ Collision monitoring in Manual operation	■ X, option 40	■ X, option 40
■ Graphic depiction of the defined collision objects	■ X, option 40	■ X, option 40
■ Collision checking in test run	■ –	■ X, option 40
■ Fixture monitoring	■ –	■ X, option 40
■ Tool carrier management	■ X	■ X, option 40

## 19.5 Functions of the TNC 640 and the iTNC 530 compared

Function	TNC 640	iTNC 530
<b>CAM support:</b>		
■ Loading of contours from DXF data	■ X, option 42	■ X, option 42
■ Loading of machining positions from DXF data	■ X, option 42	■ X, option 42
■ Offline filter for CAM files	■ –	■ X
■ Stretch filter	■ X	■ –
<b>MOD functions:</b>		
■ User parameters	■ Config data	■ Numerical structure
■ OEM help files with service functions	■ –	■ X
■ Data medium inspection	■ –	■ X
■ Load service packs	■ –	■ X
■ Setting the system time	■ X	■ X
■ Specify the axes for actual position capture	■ –	■ X
■ Definition of traverse range limits	■ X	■ X
■ Restricting external access	■ X	■ X
■ Switching the kinematics	■ X	■ X
<b>Calling fixed cycles:</b>		
■ With <b>M99</b> or <b>M89</b>	■ X	■ X
■ With <b>CYCL CALL</b>	■ X	■ X
■ With <b>CYCL CALL PAT</b>	■ X	■ X
■ With <b>CYC CALL POS</b>	■ X	■ X
<b>Special functions:</b>		
■ Create reverse program	■ –	■ X
■ Datum shift with <b>TRANS DATUM</b>	■ X	■ X
■ Adaptive Feed Control AFC	■ X, option 45	■ X, option 45
■ Global definition of cycle parameters: <b>GLOBAL DEF</b>	■ X	■ X
■ Pattern definition with <b>PATTERN DEF</b>	■ X	■ X
■ Definition and processing of point tables	■ X	■ X
■ Simple contour formula <b>CONTOUR DEF</b>	■ X	■ X
<b>Functions for large molds and dies:</b>		
■ Global program settings (GS)	■ –	■ X, option 44
■ Expanded <b>M128: FUNCTION TCPM</b>	■ X	■ X

## Functions of the TNC 640 and the iTNC 530 compared 19.5

Function	TNC 640	iTNC 530
<b>Status displays:</b>		
■ Positions, spindle speed, feed rate	■ X	■ X
■ Larger depiction of position display, Manual operation	■ X	■ X
■ Additional status display, form view	■ X	■ X
■ Display of the handwheel path during machining with handwheel superimposing	■ X	■ X
■ Display of distance-to-go in a tilted system	■ X	■ X
■ Dynamic display of Q-parameter contents, definable number ranges	■ X	■ –
■ Machine manufacturer-specific additional status display via Python	■ X	■ X
■ Graphic display of residual run time	■ –	■ X
Individual color settings of user interface	–	X

## 19.5 Functions of the TNC 640 and the iTNC 530 compared

## Comparator: Cycles

Cycle	TNC 640	iTNC 530
1 PECKING	X	X
2 TAPPING	X	X
3 SLOT MILLING	X	X
4 POCKET MILLING	X	X
5 CIRCULAR POCKET	X	X
6 ROUGH-OUT (SL I, recommended: SL II, Cycle 22)	–	X
7 DATUM SHIFT	X	X
8 MIRRORING	X	X
9 DWELL TIME	X	X
10 ROTATION	X	X
11 SCALING FACTOR	X	X
12 PGM CALL	X	X
13 ORIENTATION	X	X
14 CONTOUR	X	X
15 PILOT DRILLING (SL I, recommended: SL II, Cycle 21)	–	X
16 CONTOUR MILLING (SL I, recommended: SL II, Cycle 24)	–	X
17 RIGID TAPPING	X	X
18 THREAD CUTTING	X	X
19 WORKING PLANE	X, option 8	X, option 8
20 CONTOUR DATA	X	X
21 PILOT DRILLING	X	X
22 ROUGH-OUT	X	X
23 FLOOR FINISHING	X	X
24 SIDE FINISHING	X	X
25 CONTOUR TRAIN	X	X
26 AXIS-SPECIFIC SCALING	X	X
27 CYLINDER SURFACE	X, option 8	X, option 8
28 CYLINDER SURFACE	X, option 8	X, option 8
29 CYL SURFACE RIDGE	X, option 8	X, option 8
30 RUN CAM DATA	–	X
32 TOLERANCE	X	X
39 CYL. SURFACE CONTOUR	X, option 8	X, option 8
200 DRILLING	X	X
201 REAMING	X	X
202 BORING	X	X
203 UNIVERSAL DRILLING	X	X
204 BACK BORING	X	X

## Functions of the TNC 640 and the iTNC 530 compared 19.5

Cycle	TNC 640	iTNC 530
205 UNIVERSAL PECKING	X	X
206 TAPPING	X	X
207 RIGID TAPPING	X	X
208 BORE MILLING	X	X
209 TAPPING W/ CHIP BRKG	X	X
210 SLOT RECIP. PLNG	X	X
211 CIRCULAR SLOT	X	X
212 POCKET FINISHING	X	X
213 STUD FINISHING	X	X
214 C. POCKET FINISHING	X	X
215 C. STUD FINISHING	X	X
220 POLAR PATTERN	X	X
221 CARTESIAN PATTERN	X	X
225 ENGRAVING	X	X
230 MULTIPASS MILLING	X	X
231 RULED SURFACE	X	X
232 FACE MILLING	X	X
233 FACE MILLING	X	–
239 ASCERTAIN THE LOAD	X, option 143	–
240 CENTERING	X	X
241 SINGLE-LIP D.H.DRLNG	X	X
247 DATUM SETTING	X	X
251 RECTANGULAR POCKET	X	X
252 CIRCULAR POCKET	X	X
253 SLOT MILLING	X	X
254 CIRCULAR SLOT	X	X
256 RECTANGULAR STUD	X	X
257 CIRCULAR STUD	X	X
258 POLYGON STUD	X	–
262 THREAD MILLING	X	X
263 THREAD MLLNG/CNTSNKG	X	X
264 THREAD DRILLNG/MLLNG	X	X
265 HEL. THREAD DRLG/MLG	X	X
267 OUTSIDE THREAD MLLNG	X	X
270 CONTOUR TRAIN DATA for defining the behavior of Cycle 25	X	X
275 TROCHOIDAL SLOT	X	X
276 THREE-D CONT. TRAIN	–	X
290 INTERPOLATION TURNING	–	X, option 96

## 19.5 Functions of the TNC 640 and the iTNC 530 compared

Cycle	TNC 640	iTNC 530
291 COUPLG.TURNG.INTERP.	X, option 96	–
292 CONTOUR.TURNG.INTRP.	X, option 96	–
800 ADJUST XZ SYSTEM	X, option 50	–
801 RESET ROTARY COORDINATE SYSTEM	X, option 50	–
810 TURN CONTOUR LONG.	X, option 50	–
811 SHOULDER, LONGITDNL.	X, option 50	–
812 SHOULDER, LONG. EXT.	X, option 50	–
813 TURN PLUNGE CONTOUR LONGITUDINAL	X, option 50	–
814 TURN PLUNGE LONGITUDINAL EXT.	X, option 50	–
815 CONTOUR-PAR. TURNING	X, option 50	–
820 TURN CONTOUR TRANSV.	X, option 50	–
821 SHOULDER, FACE	X, option 50	–
822 SHOULDER, FACE. EXT.	X, option 50	–
823 TURN TRANSVERSE PLUNGE	X, option 50	–
824 TURN PLUNGE TRANSVERSE EXT.	X, option 50	–
830 THREAD CONTOUR-PARALLEL	X, option 50	–
831 THREAD LONGITUDINAL	X, option 50	–
832 THREAD EXTENDED	X, option 50	–
840 RECESS TURNG, RADIAL	X, option 50	–
841 SIMPLE REC. TURNG., RADIAL DIR.	X, option 50	–
842 ENH.REC.TURNNG, RAD.	X, option 50	–
850 RECESS TURNG, AXIAL	X, option 50	–
851 SIMPLE REC TURNG, AX	X, option 50	–
852 ENH.REC.TURNING, AX.	X, option 50	–
860 CONT. RECESS, RADIAL	X, option 50	–
861 SIMPLE RECESS, RADL.	X, option 50	–
862 EXPND. RECESS, RADL.	X, option 50	–
870 CONT. RECESS, AXIAL	X, option 50	–
871 SIMPLE RECESS, AXIAL	X, option 50	–
872 EXPND. RECESS, AXIAL	X, option 50	–
880 GEAR HOBBING	X, option 50, option 131	–
892 CHECK IMBALANCE	X, option 50	–

## Functions of the TNC 640 and the iTNC 530 compared 19.5

### Comparison: Miscellaneous functions

M	Effect	TNC 640	iTNC 530
<b>M00</b>	Program STOP/Spindle STOP/Coolant OFF	X	X
<b>M01</b>	Optional program STOP	X	X
<b>M02</b>	Stop program/Spindle STOP/Coolant OFF/ Clear status display (depending on machine parameter)/Return jump to block 1	X	X
<b>M03</b> M04 M05	Spindle ON clockwise Spindle ON counterclockwise Spindle STOP	X	X
<b>M06</b>	Tool change/Program run STOP (machine-specific function)/ Spindle STOP	X	X
<b>M08</b> M09	Coolant ON Coolant OFF	X	X
<b>M13</b> M14	Spindle ON clockwise/Coolant ON Spindle ON counterclockwise/Coolant on	X	X
<b>M30</b>	Same function as M02	X	X
<b>M89</b>	Free miscellaneous function <b>or</b> cycle call, modally effective (machine-specific function)	X	X
<b>M90</b>	Constant contouring speed at corners (not required at TNC 640)	–	X
<b>M91</b>	Within the positioning block: Coordinates are referenced to machine datum	X	X
<b>M92</b>	Within the positioning block: Coordinates are referenced to a position defined by machine manufacturer, e.g. tool change position	X	X
<b>M94</b>	Reduce the rotary axis display to a value below 360°	X	X
<b>M97</b>	Machine small contour steps	X	X
<b>M98</b>	Machine open contours completely	X	X
<b>M99</b>	Blockwise cycle call	X	X
<b>M101</b> M102	Automatic tool change with replacement tool if maximum tool life has expired Reset M101	X	X
<b>M103</b>	Reduce feed rate during plunging to factor F (percentage)	X	X
<b>M104</b>	Reactivate most recently set datum	– (recommended: Cycle 247)	X
<b>M105</b> M106	Machining with second $k_v$ factor Machining with first $k_v$ factor	–	X
<b>M107</b> M108	Suppress error message for replacement tools with oversize Reset M107	X	X
<b>M109</b>	Constant contouring speed at cutting edge (feed rate increase and reduction)	X	X
<b>M110</b> M111	Constant contouring speed at cutting edge (only feed rate reduction) Reset M109/M110	X	X

## 19.5 Functions of the TNC 640 and the iTNC 530 compared

M	Effect	TNC 640	iTNC 530
<b>M112</b> M113	Enter contour transitions between any two contour transitions Reset M112	– (recommended: Cycle 32)	X
<b>M114</b> M115	Automatic compensation of machine geometry when working with tilted axes Reset M114	– (recommended: M128, TCPM)	X, option 8
<b>M116</b> M117	Feed rate on rotary tables in mm/min Reset M116	X, option 8	X, option 8
<b>M118</b>	Superimpose handwheel positioning during program run	X	X
<b>M120</b>	Pre-calculate the radius-compensated contour (LOOK AHEAD)	X	X
<b>M124</b>	Contour filter	– (possible via user parameters)	X
<b>M126</b> M127	Shorter-path traverse of rotary axes Reset M126	X	X
<b>M128</b> M129	Maintaining the position of the tool tip when positioning tilted axes (TCPM) Reset M128	X, option 9	X, option 9
<b>M130</b>	Within the positioning block: Points are referenced to the untilted coordinate system	X	X
<b>M134</b> M135	Precision stop at non-tangential contour transitions when positioning with rotary axes Reset M134	–	X
<b>M136</b> M137	Feed rate F in millimeters per spindle revolution Reset M136	X	X
<b>M138</b>	Selection of tilted axes	X	X
<b>M140</b>	Retraction from the contour in the tool-axis direction	X	X
<b>M141</b>	Suppress touch probe monitoring	X	X
<b>M142</b>	Delete modal program information	–	X
<b>M143</b>	Delete basic rotation	X	X
<b>M144</b> M145	Compensating the machine's kinematic configuration for ACTUAL/NOMINAL positions at end of block Reset M144	X, option 9	X, option 9
<b>M148</b> M149	Automatically retract tool from the contour at an NC stop Reset M148	X	X
<b>M150</b>	Suppress limit switch message	– (possible via FN 17)	X
<b>M197</b>	Rounding the corners	X	–
<b>M200</b> <b>-M204</b>	Laser cutting functions	–	X



**Comparison: Touch probe cycles in the Manual operation and Electronic handwheel modes of operation**

Cycle	TNC 640	iTNC 530
Touch-probe table for managing 3-D touch probes	X	–
Calibrating the effective length	X	X
Calibrating the effective radius	X	X
Measuring a basic rotation using a line	X	X
Setting the datum on any axis	X	X
Setting a corner as datum	X	X
Setting a circle center as datum	X	X
Setting a center line as datum	X	X
Measuring a basic rotation using two holes/cylindrical studs	X	X
Setting the datum using four holes/cylindrical studs	X	X
Setting the circle center using three holes/cylindrical studs	X	X
Determine and offset misalignment of a plane	X	–
Support of mechanical touch probes by manually capturing the current position	By soft key or hard key	By hard key
Write measurement values to the preset table	X	X
Write measurement values to the datum table	X	X

## 19.5 Functions of the TNC 640 and the iTNC 530 compared

**Comparison: Probing system cycles for automatic workpiece control**

<b>Cycle</b>	<b>TNC 640</b>	<b>iTNC 530</b>
0 REF. PLANE	X	X
1 POLAR DATUM	X	X
2 CALIBRATE TS	–	X
3 MEASURING	X	X
4 MEASURING IN 3-D	X	X
9 CALIBRATE TS LENGTH	–	X
30 CALIBRATE TT	X	X
31 CAL. TOOL LENGTH	X	X
32 CAL. TOOL RADIUS	X	X
33 MEASURE TOOL	X	X
400 BASIC ROTATION	X	X
401 ROT OF 2 HOLES	X	X
402 ROT OF 2 STUDS	X	X
403 ROT IN ROTARY AXIS	X	X
404 SET BASIC ROTATION	X	X
405 ROT IN C-AXIS	X	X
408 SLOT CENTER REF PT	X	X
409 RIDGE CENTER REF PT	X	X
410 DATUM INSIDE RECTAN.	X	X
411 DATUM OUTS. RECTAN.	X	X
412 DATUM INSIDE CIRCLE	X	X
413 DATUM OUTSIDE CIRCLE	X	X
414 DATUM OUTSIDE CORNER	X	X
415 DATUM INSIDE CORNER	X	X
416 DATUM CIRCLE CENTER	X	X
417 DATUM IN TS AXIS	X	X
418 DATUM FROM 4 HOLES	X	X
419 DATUM IN ONE AXIS	X	X
420 MEASURE ANGLE	X	X
421 MEASURE HOLE	X	X
422 MEAS. CIRCLE OUTSIDE	X	X
423 MEAS. RECTAN. INSIDE	X	X
424 MEAS. RECTAN. OUTS.	X	X
425 MEASURE INSIDE WIDTH	X	X
426 MEASURE RIDGE WIDTH	X	X
427 MEASURE COORDINATE	X	X

## Functions of the TNC 640 and the iTNC 530 compared 19.5

Cycle	TNC 640	iTNC 530
430 MEAS. BOLT HOLE CIRC	X	X
431 MEASURE PLANE	X	X
440 MEASURE AXIS SHIFT	–	X
444 PROBING IN 3-D	X, option 92	–
441 FAST PROBING	Sometimes possible via touch probe table	X
450 SAVE KINEMATICS	X, option 48	X, option 48
451 MEASURE KINEMATICS	X, option 48	X, option 48
452 PRESET COMPENSATION	X, option 48	X, option 48
460 CALIBRATION OF TS ON A SPHERE	X	X
461 TS CALIBRATION OF TOOL LENGTH	X	X
462 CALIBRATION OF A TS IN A RING	X	X
463 TS CALIBRATION ON STUD	X	X
480 CALIBRATE TT	X	X
481 CAL. TOOL LENGTH	X	X
482 CAL. TOOL RADIUS	X	X
483 MEASURE TOOL	X	X
484 CALIBRATE IR TT	X	X
600 GLOBAL WORKING SPACE	X, option 136	–
601 LOCAL WORKING SPACE	X, option 136	–

### Comparison: Differences in programming

Function	TNC 640	iTNC 530
Switching the operating mode while a block is being edited	Permitted	Permitted
<b>File handling:</b>		
■ Save file function	■ Available	■ Available
■ Save file as function	■ Available	■ Available
■ Discard changes	■ Available	■ Available
<b>File management:</b>		
■ Mouse operation	■ Available	■ Available
■ Sorting function	■ Available	■ Available
■ Entry of name	■ Opens <b>Select file</b> pop-up window <b>Select file</b>	■ Synchronizes the cursor
■ Support of key combinations	■ Not available	■ Available
■ Favorites Management	■ Not available	■ Available
■ Configuration of column structure	■ Not available	■ Available

## 19.5 Functions of the TNC 640 and the iTNC 530 compared

Function	TNC 640	iTNC 530
■ Soft-key arrangement	■ Slightly different	■ Slightly different
Skip block function	Available	Available
Selecting a tool from the table	Selection via split-screen menu	Selection in a pop-up window
Programming special functions with the <b>SPEC FCT</b> key	Pressing the key opens a soft-key row as a submenu. To exit the submenu, press the <b>SPEC FCT</b> key again; then the TNC shows the last active soft-key row	Pressing the key adds the soft-key row as the last row. To exit the menu, press the <b>SPEC FCT</b> key again; then the TNC shows the last active soft-key row
Programming approach and departure motions with the <b>APPR DEP</b> key	Pressing the key opens a soft-key row as a submenu. To exit the submenu, press the <b>APPR DEP</b> key again; then the TNC shows the last active soft-key row	Pressing the key adds the soft-key row as the last row. To exit the menu, press the <b>APPR DEP</b> key again; then the TNC shows the last active soft-key row
Pressing the hard key <b>END</b> with active <b>CYCLE DEF</b> and <b>TOUCH PROBE</b> menus	Terminates the editing process and calls the file manager	Exits the respective menu
Calling the file manager while the <b>CYCLE DEF</b> and <b>TOUCH PROBE</b> menus are active	Terminates the editing process and calls the file manager. The respective soft-key row remains selected when the file manager is exited	<b>Key non-functional</b> error message <b>Key non-functional</b>
Calling the file manager while <b>CYCL CALL</b> , <b>SPEC FCT</b> , <b>PGM CALL</b> and <b>APPR/DEP</b> menus are active	Terminates the editing process and calls the file manager. The respective soft-key row remains selected when the file manager is exited	Terminates the editing process and calls the file manager. The basic soft-key row is selected when the file manager is exited

## Functions of the TNC 640 and the iTNC 530 compared 19.5

Function	TNC 640	iTNC 530
<b>Datum table:</b>		
■ Sorting function by values within an axis	■ Available	■ Not available
■ Resetting the table	■ Available	■ Not available
■ Hiding axes that are not present	■ Available	■ Available
■ Switching the list/form view	■ Switchover via split-screen key	■ Switchover by toggle soft key
■ Inserting individual line	■ Allowed everywhere, renumbering possible after request. Empty line is inserted, must be filled with zeros manually	■ Only allowed at the end of the table. Line with value 0 in all columns is inserted
■ Transfer of actual position values on individual axis to the datum table using the keys	■ Not available	■ Available
■ Transfer of actual position values on all active axes to the datum table using the keys	■ Not available	■ Available
■ Capturing the last positions measured by TS using the keys	■ Not available	■ Available
<b>FK free contour programming:</b>		
■ Programming of parallel axes	■ With X/Y coordinates, independent of machine type; switchover with <b>FUNCTION PARAXMODE</b>	■ Machine-dependent with the existing parallel axes
■ Automatic correction of relative references	■ Relative references in contour subprograms are not corrected automatically	■ All relative references are corrected automatically

## 19.5 Functions of the TNC 640 and the iTNC 530 compared

Function	TNC 640	iTNC 530
<b>Handling of error messages:</b>		
■ Help with error messages	■ Call via <b>ERR</b> key	■ Call via <b>HELP</b> key
■ Switching the operating mode while help menu is active	■ Help menu is closed when the operating mode is switched	■ Operating mode switchover is not allowed (key is non-functional)
■ Selecting the background operating mode while help menu is active	■ Help menu is closed when F12 is used for switching	■ Help menu remains open when F12 is used for switching
■ Identical error messages	■ Are collected in a list	■ Are displayed only once
■ Acknowledgment of error messages	■ Every error message (even if it is displayed more than once) must be acknowledged, the <b>Delete All</b> is available	■ Error message to be acknowledged only once
■ Access to protocol functions	■ Log and powerful filter functions (errors, keystrokes) are available	■ Complete log without filter functions available
■ Saving service files	■ Available. No service file is created when the system crashes	■ Available. A service file is automatically created when the system crashes

## Functions of the TNC 640 and the iTNC 530 compared 19.5

Function	TNC 640	iTNC 530
<b>Find function:</b>		
■ List of words recently searched for	■ Not available	■ Available
■ Show elements of active block	■ Not available	■ Available
■ Show list of all available NC blocks	■ Not available	■ Available
Starting the search function with the up/down arrow keys when highlighted	Works up to max. 100,000 blocks, can be set via configuration datum	No limitation regarding program length
<b>Programming graphics:</b>		
■ True-to-scale display of grid	■ Available	■ Not available
■ Editing contour subprograms in SLII cycles with <b>AUTO DRAW ON</b>	■ With error messages, in the main program the cursor is on the <b>CYCL CALL</b> block	■ If error messages occur, the cursor is on the block in the contour subprogram responsible for the error
■ Moving the zoom window	■ Repeat function not available	■ Repeat function available
<b>Programming minor axes:</b>		
■ Syntax <b>FUNCTION PARAXCOMP</b> : Define the behavior of the display and the paths of traverse	■ Available	■ Not available
■ Syntax <b>FUNCTION PARAXMODE</b> : Define the assignment of the parallel axes to be traversed	■ Available	■ Not available
<b>Programming OEM cycles</b>		
■ Access to table data	■ Via <b>SQL</b> commands and via <b>FN17/FN18</b> or <b>TABREAD-TABWRITE</b> functions	■ Via <b>FN17/FN18</b> or <b>TABREAD-TABWRITE</b> functions
■ Access to machine parameters	■ With the <b>CFGREAD</b> function	■ Via <b>FN18</b> functions
■ Creating interactive cycles with <b>CYCLE QUERY</b> , e.g. touch probe cycles in Manual Operation	■ Available	■ Not available

## 19.5 Functions of the TNC 640 and the iTNC 530 compared

## Comparison: Differences in Test Run, functionality

Function	TNC 640	iTNC 530
Entering a program with the <b>GOTO</b> key	Function only possible if the <b>START SINGLE</b> soft key was not pressed	Function also possible after <b>START SINGLE</b>
Calculation of machining time	Each time the simulation is repeated by pressing the <b>START</b> soft key, the machining time is totaled	Each time the simulation is repeated by pressing the <b>START</b> soft key, time calculation starts at 0
Single block	With point pattern cycles and <b>CYCL CALL PAT</b> , the control stops after each point	Point pattern cycles and <b>CYCL CALL PAT</b> are handled by the control as a single block

## Comparison: Differences in Test Run, operation

Function	TNC 640	iTNC 530
Arrangement of soft-key rows and soft keys within the rows	Arrangement of soft-key rows and soft-keys varies depending on the active screen layout.	
Zoom function	Each sectional plane can be selected by individual soft keys	Sectional plane can be selected via three toggle soft keys
Machine-specific miscellaneous functions M	Lead to error messages if they are not integrated in the PLC	Are ignored during Test Run
Displaying/editing the tool table	Function available via soft key	Function not available
3-D view: Transparent display of workpiece	Available	Function not available
3-D view: Transparent display of workpiece	Available	Function not available
3-D view: Display tool path	Available	Function not available
Adjustable model quality	Available	Function not available



### Comparison: Differences in Manual Operation, functionality

Function	TNC 640	iTNC 530
Jog increment function	The jog increment can be defined separately for linear and rotary axes	The jog increment applies for both linear and rotary axes
Preset table	<p>Basic transformation (translation and rotation) of machine table system to workpiece system via the <b>X</b>, <b>Y</b> and <b>Z</b> columns, as well as spatial angles <b>SPA</b>, <b>SPB</b> and <b>SPC</b>.</p> <p>In addition, the <b>X_OFFSETS</b> to <b>W_OFFSETS</b> columns can be used to define the axis offset of each individual axis. The function of the axis offsets can be configured.</p>	<p>Basic transformation (translation) of machine table system to workpiece system via the columns <b>X</b>, <b>Y</b> and <b>Z</b>, as well as a <b>ROT</b> basic rotation in the working plane (rotation).</p> <p>In addition, columns <b>A</b> to <b>W</b> can be used to define datums on the rotary and parallel axes.</p>
Behavior when setting datums	<p>Presetting in a rotary axis has the same effect as an axis offset. The offset is also effective for kinematics calculations and for tilting the working plane.</p> <p>The machine parameter <b>presetToAlignAxis</b> (no. 300203) is used to define whether the axis offset is to be taken into account internally after datum setting. Independently of this, an axis offset has always the following effects:</p> <ul style="list-style-type: none"> <li>■ An axis offset always influences the nominal position display of the affected axis (the axis offset is subtracted from the current axis value).</li> <li>■ If a rotary axis coordinate is programmed in an L block, then the axis offset is added to the programmed coordinate.</li> </ul>	<p>Rotary axis offsets defined by machine parameters do not influence the axis positions that were defined in the Tilt working plane function.</p> <p>MP7500 bit 3 defines whether the current rotary axis position referenced to the machine datum is taken into account, or whether a position of 0° is assumed for the first rotary axis (usually the C axis).</p>
<b>Handling of preset table:</b>		
■ Preset tables that depend on the range of traverse	■ Not available	■ Available
Definition of feed-rate limitation	Feed-rate limitation can be defined separately for linear and rotary axes	Only one feed-rate limitation can be defined for linear and rotary axes

## 19.5 Functions of the TNC 640 and the iTNC 530 compared

**Comparison: Differences in Manual Operation, operation**

Function	TNC 640	iTNC 530
Capturing the position values from mechanical probes	Confirm actual position with a soft key or hard key	Actual-position capture by hard key
Exiting the Touch Probe Functions menu	Using the <b>END</b> soft key or the <b>END</b> hard key	Using the <b>END</b> soft key or the <b>END</b> hard key

**Comparison: Differences in Program Run, operation**

Function	TNC 640	iTNC 530
Arrangement of soft-key rows and soft keys within the rows	Arrangement of soft-key rows and soft-keys differs according to the active screen layout.	
Operating mode switchover after program run has been suspended by switching to the <b>Program run, single block</b> operating mode and canceled with <b>INTERNAL STOP</b>	When you return to the <b>Program run, full sequence</b> mode: error message <b>Current block not selected</b> . Use mid-program startup to select the point of interruption	Switching the operating mode is allowed, modal information is saved, program run can be continued by pressing NC start
<b>GOTO</b> is used to go to FK sequences after program run was interrupted there before switching the operating mode	Error message <b>FK programming: Undefined starting position</b> Entering with mid-program startup is permitted	GOTO allowed
<b>Mid-program startup:</b>		
Switching the screen layout for mid-program startup	Only possible, if startup position has already been approached	Possible in all operating states
Error messages	Error messages are still active after the error has been corrected and must be acknowledged separately	Error messages are sometimes acknowledged automatically after the error has been corrected
Point patterns in single block	With point pattern cycles and <b>CYCL CALL PAT</b> , the control stops after each point.	Point pattern cycles and <b>CYCL CALL PAT</b> are handled by the control as a single block

### Comparison: Differences in Program Run, traverse movements



#### Caution: Check the traverse movements!

NC programs that were created on earlier TNC controls may lead to different traverse movements or error messages on a TNC 640!

Be sure to take the necessary care and caution when running-in programs!

See below for a list of known differences. The list does not claim to be complete!

Function	TNC 640	iTNC 530
Handwheel-superimposed traversing with <b>M118</b>	Effective in the active coordinate system (which may also be rotated or tilted), or in the machine coordinate system, depending on the setting in the 3-D ROT menu for manual operation	Effective in the machine coordinate system
Deleting basic rotation with <b>M143</b>	<b>M143</b> deletes the entries in columns <b>SPA</b> , <b>SPB</b> and <b>SPC</b> in the preset table, reactivating the corresponding preset table row does <b>not</b> activate the deleted basic rotation	<b>M143</b> does <b>not</b> delete the entry in the <b>ROT</b> column in the preset table, reactivating the corresponding preset table row activates the deleted basic rotation
Scaling approach/departure movements ( <b>APPRDEP/RND</b> )	Axis-specific scaling factor is allowed, radius is not scaled	Error message
Approach/departure with <b>APPRDEP</b>	Error message if <b>RO</b> is programmed for <b>APPR/DEP LN</b> or <b>APPR/DEP CT</b>	Tool radius 0 and compensation direction <b>RR</b> are assumed
Approach/departure with <b>APPR/DEP</b> if contour elements with length 0 are defined	Contour elements with length 0 are ignored. The approach/departure movements are calculated for the first and last valid contour element	An error message is issued if a contour element with length 0 is programmed after the <b>APPR</b> block (relative to the first contour point programmed in the <b>APPR</b> block) For a contour element with length 0 before a <b>DEP</b> block, the iTNC does not issue an error message, but uses the last valid contour element to calculate the departure movement

## 19.5 Functions of the TNC 640 and the iTNC 530 compared

Function	TNC 640	iTNC 530
Effect of Q parameters	<b>Q60 to Q99 (QS60 to QS99)</b> are always local.	<b>Q60 to Q99 (QS60 to QS99)</b> are local or global, depending on MP7251 in converted cycle programs (.cyc). Nested calls may cause problems
Automatic cancelation of tool radius compensation	<ul style="list-style-type: none"> <li>■ Block with <b>R0</b></li> <li>■ <b>DEP</b> block</li> <li>■ Program selection</li> <li>■ <b>END PGM</b></li> </ul>	<ul style="list-style-type: none"> <li>■ Block with <b>R0</b></li> <li>■ <b>DEP</b> block</li> <li>■ Program selection</li> <li>■ Programming of Cycle 10 <b>ROTATION</b></li> <li>■ <b>PGM CALL</b></li> </ul>
NC blocks with <b>M91</b>	No consideration of tool radius compensation	Consideration of tool radius compensation
Behavior with <b>M120 LA1</b>	No effect on processing, as the control interprets the input internally as an <b>LA0</b>	Possible undesired effect on processing, as the control interprets the entry internally as an <b>LA2</b>
Block scan in a point table	The tool is positioned above the next position to be machined	The tool is positioned above the last position that has been completely machined
Empty <b>CC</b> block (pole adoption from last tool position) in the NC program	Last positioning block in the working plane must contain both coordinates of the working plane	Last positioning block in the working plane does not necessarily need to contain both coordinates of the working plane. Can cause problems with <b>RND</b> or <b>CHF</b> blocks
Axis-specific scaling of <b>RND</b> block	<b>RND</b> block is scaled, the result is an ellipse	Error message is issued
Reaction if a contour element with length 0 is defined before or after a <b>RND</b> or <b>CHF</b> block	Error message is issued	<p>Error message is issued if a contour element with length 0 is located before the <b>RND</b> or <b>CHF</b> block</p> <p>Contour element with length 0 is ignored if the contour element with length 0 is located after the <b>RND</b> or <b>CHF</b> block</p>

## Functions of the TNC 640 and the iTNC 530 compared 19.5

Function	TNC 640	iTNC 530
Circle programming with polar coordinates	The incremental rotation angle <b>IPA</b> and the direction of rotation <b>DR</b> must have the same sign. Otherwise, an error message will be issued	The algebraic sign of the direction of rotation is used if the sign defined for <b>DR</b> differs from the one defined for <b>IPA</b>
Tool radius compensation on circular arc or helix with angular length = 0	The transition between the adjacent elements of the arc/helix is generated. Also, the tool axis motion is executed right before this transition. If the element is the first or last element to be corrected, the next or previous element is dealt with in the same way as the first or last element to be corrected	The equidistant line of the arc/helix is used for generating the tool path
Compensation of tool length in the position display	The values <b>L</b> and <b>DL</b> from the tool table and the value <b>DL</b> from the <b>TOOL CALL</b> block are taken into account in the position display	The values <b>L</b> and <b>DL</b> from the tool table are taken into account in the position display
<b>SLII Cycles 20 to 24:</b>		
■ Number of definable contour elements	■ Max. 16384 blocks in up to 12 subcontours	■ Max. 8192 contour elements in up to 12 subcontours, no restrictions for subcontour
■ Define the working plane	■ Tool axis in <b>TOOL CALL</b> block defines the working plane	■ The axes of the first positioning block in the first subcontour define the working plane
■ Position at end of SL cycle	■ With the <b>posAfterContPocket</b> (no. 201007) parameter, you can define whether the end position is above the last programmed position, or whether the tool moves to clearance height in the tool axis ■ If the tool moves to clearance height in the tool axis, both coordinates must be programmed with the first traverse movement	■ With MP7420, you can define whether the end position is above the last programmed position, or whether the tool moves only to clearance height in the tool axis ■ If the tool moves to clearance height in the tool axis, one coordinate must be programmed with the first traverse movement

## Tables and Overviews

### 19.5 Functions of the TNC 640 and the iTNC 530 compared

Function	TNC 640	iTNC 530
<b>SLII Cycles 20 to 24:</b>		
<ul style="list-style-type: none"> <li>■ Behavior with islands not contained in pockets</li> <li>■ Set operations for SL cycles with complex contour formulas</li> <li>■ Radius compensation is active during <b>CYCL CALL</b></li> <li>■ Paraxial positioning blocks in contour subprogram</li> <li>■ Miscellaneous functions <b>M</b> in contour subprogram</li> </ul>	<ul style="list-style-type: none"> <li>■ Cannot be defined with complex contour formula</li> <li>■ Real set operation possible</li> <li>■ Error message is issued</li> <li>■ Error message is issued</li> <li>■ Error message is issued</li> </ul>	<ul style="list-style-type: none"> <li>■ Restricted definition in complex contour formula is possible</li> <li>■ Only restricted performance of real set operation possible</li> <li>■ Radius compensation is canceled, program is executed</li> <li>■ Program is executed</li> <li>■ M functions are ignored</li> </ul>
<b>Cylinder surface machining</b> in general:		
<ul style="list-style-type: none"> <li>■ Contour definition</li> <li>■ Offset definition on cylinder surface</li> <li>■ Offset definition for basic rotation</li> <li>■ Circle programming with C/CC</li> <li>■ <b>APPR/DEP</b> blocks in contour definition</li> </ul>	<ul style="list-style-type: none"> <li>■ With X/Y coordinates, independent of machine type</li> <li>■ With datum shift in X/Y, regardless of machine type</li> <li>■ Function available</li> <li>■ Function available</li> <li>■ Function not available</li> </ul>	<ul style="list-style-type: none"> <li>■ Machine-dependent, with existing rotary axes</li> <li>■ Machine-specific datum shift in rotary axes</li> <li>■ Function not available</li> <li>■ Function not available</li> <li>■ Function available</li> </ul>
<b>Cylinder surface machining</b> with Cycle 28:		
<ul style="list-style-type: none"> <li>■ Complete roughing-out of slot</li> <li>■ Definable tolerance</li> </ul>	<ul style="list-style-type: none"> <li>■ Function available</li> <li>■ Function available</li> </ul>	<ul style="list-style-type: none"> <li>■ Function not available</li> <li>■ Function available</li> </ul>
<b>Cylinder surface machining</b> with Cycle 29	Direct plunging to contour of ridge	Circular approach to contour of ridge
<b>Cycles 25x for pockets, studs and slots:</b>		
<ul style="list-style-type: none"> <li>■ Plunging movements</li> </ul>	In limit ranges (geometrical conditions of tool/contour) error messages are triggered if plunging movements lead to unreasonable/critical behavior	In limit ranges (geometrical conditions of tool/contour), vertical plunging is used if required

## Functions of the TNC 640 and the iTNC 530 compared 19.5

Function	TNC 640	iTNC 530
<b>PLANE function:</b>		
<ul style="list-style-type: none"> <li>■ <b>TABLE ROT/COORD ROT</b></li> </ul>	<p>Effect:</p> <ul style="list-style-type: none"> <li>■ The transformation types are effective on all free rotary axes</li> <li>■ The control does not always position the free rotary axis with <b>TABLE ROT</b>, but depending on the current position, the programmed spatial angle and the machine kinematics</li> </ul> <p>Default with missing selection:</p> <ul style="list-style-type: none"> <li>■ <b>COORD ROT</b> is used</li> </ul>	<p>Effect</p> <ul style="list-style-type: none"> <li>■ The transformation types are only effective with a C rotary axis</li> <li>■ With <b>TABLE ROT</b> the control always positions the rotary axis</li> </ul> <p>Default with missing selection:</p> <ul style="list-style-type: none"> <li>■ <b>COORD ROT</b> is used</li> </ul>
<ul style="list-style-type: none"> <li>■ Machine is configured for axis angle</li> <li>■ Programming an incremental spatial angle according to <b>PLANE AXIAL</b></li> <li>■ Programming an incremental axis angle according to <b>PLANE SPATIAL</b> if the machine is configured for spatial angle</li> <li>■ Programming of <b>PLANE</b> functions with active Cycle 8 <b>MIRRORING</b></li> </ul>	<ul style="list-style-type: none"> <li>■ All <b>PLANE</b> functions can be used</li> <li>■ Error message is issued</li> <li>■ Error message is issued</li> <li>■ Mirroring has no influence on tilting using <b>AXIAL PLANE</b> and Cycle <b>19</b></li> </ul>	<ul style="list-style-type: none"> <li>■ Only <b>PLANE AXIAL</b> is executed</li> <li>■ Incremental spatial angle is interpreted as an absolute value</li> <li>■ Incremental axis angle is interpreted as an absolute value</li> <li>■ Function is available with all <b>PLANE</b> functions</li> </ul>
<b>Special functions for cycle programming:</b>		
<ul style="list-style-type: none"> <li>■ FN17</li> <li>■ FN18</li> </ul>	<ul style="list-style-type: none"> <li>■ Function available</li> <li>■ Values are always output in metric form</li> <li>■ Further details are different</li> <li>■ Function available</li> <li>■ Values are always output in metric form</li> <li>■ Details are different</li> </ul>	<ul style="list-style-type: none"> <li>■ Function available</li> <li>■ Values are output in the units of the active NC program</li> <li>■ Details are different</li> <li>■ Function available</li> <li>■ Values are output in the units of the active NC program</li> <li>■ Details are different</li> </ul>
Compensation of tool length in the position display	The tool length entries <b>L</b> and <b>DL</b> from the tool table are taken into account in the position display, from <b>TOOL CALL</b> block depending on the machine parameter <b>progToolCallIDL</b> (no. 124501)	The tool length entries <b>L</b> and <b>DL</b> from the tool table are taken into account in the position display

## 19.5 Functions of the TNC 640 and the iTNC 530 compared

## Comparison: Differences in MDI operation

Function	TNC 640	iTNC 530
Execution of connected sequences	Function available	Function available
Saving modally effective functions	Function available	Function available
Miscellaneous functions	<ul style="list-style-type: none"> <li>■ Status display for Q parameters</li> <li>■ Block functions, e.g. <b>COPY BLOCK</b></li> <li>■ ACC setting</li> <li>■ Program functions for turning</li> <li>■ Miscellaneous program functions, e.g. <b>FUNCTION DWELL</b></li> </ul>	<ul style="list-style-type: none"> <li>■ Global program settings</li> </ul>

## Comparison: Differences in programming station

Function	TNC 640	iTNC 530
Demo version	Programs with more than 100 NC blocks cannot be selected, an error message is issued	Programs can be selected, max. 100 NC blocks are displayed, further blocks are truncated in the display
Demo version	If nesting with <b>PGM CALL</b> results in more than 100 NC blocks, there is no test graphic display; an error message is not issued	Nested programs can be simulated
Copying NC programs	Copying to and from the directory <b>TNC:\</b> is possible with Windows Explorer	TNCremo or file manager of programming station must be used for copying
Shifting the horizontal soft-key row	Clicking on the soft-key bar shifts one soft-key row to the right or left	Clicking any soft-key bar activates the respective soft-key row



## Index

### 3

3-D basic rotation.....	627
3D compensation.....	523
Delta values.....	526
Face Milling.....	528
3-D compensation	
Normalized vector.....	525
3D compensation	
Peripheral Milling.....	529
Tool orientation.....	527
3-D compensation	
Tool shapes.....	526
3-D touch probe	
Calibrating.....	617
Using.....	609
3-D view.....	663

### A

About this manual.....	6
ACC.....	455
Accessing tables.....	367
Accessories.....	115
Actual position capture.....	139
Adaptive feed control.....	442
Adding comments.....	174, 176
Additional axes.....	129
Additional axes for rotary axes.	511
Adjusting spindle speed.....	594
ADP.....	538
AFC.....	442
Align tool axis.....	508
Angle functions.....	340
Approach contour.....	248
ASCII files.....	467
Automatic program start.....	693
Automatic tool measurement...	210

### B

Backup.....	108
Basic rotation.....	626
Measuring in Manual Operation	
mode.....	626
Behavior after receipt of ETX....	712
Block.....	141
Delete.....	141
Block check character.....	711
Block scan	
In a pallet table.....	691
In a point table.....	691

### C

CAD Viewer.....	295
CAD viewer and DXF converter	
screen layout.....	294
Calculating with parentheses...	378
Calculation of circles.....	341

Calculator.....	179
Calling tool management.....	232
Camera.....	645
CAM programming.....	523, 533
Cartesian coordinates	
Circular path around circle center	
CC.....	263
Straight line.....	259
Chamfer.....	260
Chatter Control.....	455
Checking	
Setup situation.....	645
Checking setup situation.....	645
Checking the axis positions.....	597
Circle.....	264, 266, 272
Circle center.....	262
Circular path.....	272
around circle center CC.....	263
Code number.....	708
Collision monitoring.....	431
Comparison.....	760
Compensating workpiece	
misalignment	
By measuring two points on a	
straight surface.....	625
Condition of RTS line.....	711
Connector pin layout for data	
interfaces.....	743
Context-sensitive help.....	194
Control panel.....	86
Coordinate transformation.....	464
Copying program sections	143, 143

### D

Data backup.....	108, 147
Data interface.....	709
Connector pin layouts.....	743
Set up.....	709
Data output on the screen.....	355
Data transfer	
File system.....	711
Software.....	713
Data transmission	
Behavior after receipt of ETX..	712
Block check character.....	711
Condition of RTS line.....	711
Data bits.....	710
Handshake.....	711
Parity.....	710
Protocol.....	710
Software TNC server.....	712
Stop bits.....	710
Datum shift	
Resetting.....	466
Via the datum table.....	465
Datum table	
Transferring probed values....	615
DCM.....	431

Defining local Q parameters.....	335
Defining nonvolatile Q parameters..	335
Defining the workpiece blank...	136
Depart contour.....	248
Dialog.....	137
Directory.....	148, 153
Copy.....	156
Create.....	153
Delete.....	157
Displaying HTML files.....	163
Displaying Internet files.....	163
Display of the NC program.....	176
Display screen.....	85
DNC.....	722
Information from NC program	366
Downloading help files.....	198
Dwell time.....	479, 480, 481
DXF converter.....	296
Selecting hole positions	
Icon.....	310
Mouse area.....	309
Setting a datum.....	301
Dynamic Collision Monitoring...	431

### E

Enter spindle speed.....	220
Error message.....	189
Help with.....	189
Ethernet interface.....	715
Configuring.....	715
Connecting and disconnecting	
network drives.....	170
Connection possibility.....	715
Introduction.....	715
External access.....	701
External data transfer.....	169

### F

FCL.....	708
FCL function.....	11
Feature Content Level.....	11
Feed control, automatic.....	442
Feed rate.....	593
Adjust.....	594
Input options.....	138
On rotary axes, M116.....	511
Feed rate factor for plunging	
movements M103.....	414
Feed rate in millimeters per spindle	
revolution M136.....	415
File	
create.....	153
Sort.....	159
tag.....	158
File functions.....	463
File management.....	145, 148
external data transfer.....	169

File Manager			
Calling.....	150		
File manager			
Copying files.....	153		
Copying tables.....	155		
Delete file.....	157		
Directories			
Copy.....	156		
Create.....	153		
Directory.....	148		
File type.....	145		
File type			
External file types.....	147		
Function overview.....	149		
Overwriting files.....	154		
Protect file.....	159		
Rename file.....	158		
Selecting files.....	151		
File status.....	150		
Filter for hole positions with DXF			
data update.....	311		
Firewall.....	721		
FK programming.....	277		
Circular paths.....	282		
End point.....	283		
Fundamentals.....	277		
FK-Programming			
Graphics.....	279		
FK programming			
Initiating dialog.....	280		
Input options			
Auxiliary points.....	286		
Circle data.....	284		
Closed contours.....	285		
Direction and length of			
contour elements.....	283		
Input options			
Relative data.....	287		
Straight lines.....	281		
Fluctuating spindle speed.....	477		
FN14: ERROR: Displaying error			
messages.....	347, 347		
FN16: F-PRINT: Output of formatted			
texts.....	351		
FN18: SYSREAD: Reading system			
data.....	356		
FN19: PLC: Transfer values to the			
PLC.....	365		
FN20: WAIT FOR: NC and PLC			
synchronization.....	365		
FN23: CIRCLE DATA: Calculate a			
circle from 3 points.....	341		
FN24: CIRCLE DATA: Calculate a			
circle from 4 points.....	341		
FN26: TABOPEN: Open a freely			
definable table.....	474		
FN27: TABWRITE: Write to a freely			
definable table.....	475		
FN28: TABREAD: Read from a			
freely definable table.....	476, 476		
FN29: PLC: Transfer values to the			
PLC.....	366		
FN37: EXPORT.....	366		
FN38: SEND: Send information			
Formatted output of Q parameter			
values.....	351		
Formatted output of text files...	351		
Form view.....	473		
Freely definable table			
open.....	474		
write to.....	475		
FS, Functional safety.....	595		
Full circle.....	263		
Functional safety FS.....	595		
Fundamentals.....	118		
<b>G</b>			
Graphics.....	660		
Display modes.....	662		
With programming.....	185		
Magnification of details....	188		
Graphic settings.....	700		
Graphic simulation.....	669		
Tool display.....	669		
<b>H</b>			
Handwheel.....	583		
Hard disk.....	145		
Helical interpolation.....	273		
Helix.....	273		
Help system.....	194		
Help with error message.....	189		
<b>I</b>			
Inclined-tool machining in a tilted			
plane.....	509		
Inclined turning.....	574		
Initiated tools.....	213		
Inserting and modifying blocks.	141		
Interrupt machining.....	679		
iTNC 530.....	84		
<b>K</b>			
Klartext.....	137		
<b>L</b>			
Load machine configuration....	727		
Look ahead.....	417		
<b>M</b>			
M91, M92.....	409		
Machine parameters.....	730		
Machine settings.....	701		
Manage datums.....	599		
Manual datum setting.....	629		
Circle center as datum.....	631		
Corner as datum.....	630		
On any axis.....	629		
Setting a center line as datum	634		
Without a 3-D touch probe....	607		
MDI.....	654		
Measurement of machining			
time.....	670		
Measuring workpieces.....	635		
Mid-program startup.....	687		
After power failure.....	687		
Miscellaneous functions.....	406		
enter.....	406		
For path behavior.....	412		
For program run inspection....	408		
For spindle and coolant.....	408		
Miscellaneous functions for			
coordinate entries.....	409		
Modes of Operation.....	87		
MOD function.....	698		
Exit.....	698		
Overview.....	699		
Select.....	698		
Monitoring			
Collision.....	431		
motion control.....	538		
Move machine axes			
Jog positioning.....	582		
Moving the machine axes.....	581		
With axis direction keys.....	581		
with the handwheel.....	583		
Multiple axis machining....	484, 519		
<b>N</b>			
NC and PLC synchronization....	365		
NC error message.....	189		
Nesting.....	323		
Network connection.....	170		
Network settings.....	715		
<b>O</b>			
Open contour corners M98.....	413		
Opening a BMP file.....	166		
Opening a GIF file.....	166		
Opening a JPG file.....	166		
Opening a PNG file.....	166		
Opening a video file.....	165		
Opening Excel files.....	162		
Opening graphic files.....	166		
Opening TXT files.....	165		
Open INI file.....	165		
Open TXT file.....	165		
Operating times.....	707		
<b>P</b>			
Pallet table.....	540		
Application.....	540		
Processing.....	542		
Selecting and exiting.....	542		
Pallet tables			
Transferring coordinates.....	540		
Parallel axes.....	457		

Paraxcomp.....	457	Process chain.....	533	Rapid traverse.....	202
Paraxmode.....	457	Processing DXF data		Reading out machine parameters....	391
Part families.....	336	Basic settings.....	298	Reading system data.....	356, 386
Path.....	148	Filter for hole positions.....	311	Recess.....	567
Path contours.....	258	Selecting a contour.....	303	Reference images.....	646
Cartesian coordinates.....	258	Selecting hole positions		Reference system.....	119, 129
Circle with tangential		Single selection.....	308	Basic.....	122
connection.....	266	Selecting machining positions	307	Input.....	126
Circular path with defined		Setting layers.....	300	Machine.....	120
radius.....	264	Program.....	132	Tool.....	127
Overview.....	258	Editing.....	140	Working plane.....	124
Polar coordinates.....	270	Opening a new program.....	136	Workpiece.....	123
Circular path around pole		Structure.....	132	Replacing texts.....	144
CC.....	272	Structuring.....	177	Resonance vibration.....	477
Circular path with tangential		Program call		Restore.....	108
connection.....	272	Any desired program as		Retraction.....	684
Overview.....	270	subprogram.....	319	After a power interruption.....	684
Straight line.....	271	Program defaults.....	429	Retraction from the contour....	421
Path functions		Programming graphics.....	279	Returning to the contour.....	692
Fundamentals.....	242	Programming tool movement..	137	Rotary axes.....	511
Circles and circular arcs....	245	Program run.....	678	Rotary axis	
Pre-position.....	246	Execute.....	678	Reduce display M94.....	513
PDF Viewer.....	161	Interrupt.....	679	Shortest-path traverse: M126.	512
PLANE function.....	485, 486	Mid-program startup.....	687	Rounded corners.....	261
Automatic positioning.....	501	Optional block skip.....	694	Rounding corners M197.....	426
Axis angle definition.....	499	Overview.....	678		
Euler angle definition.....	492	Resuming after interruption...	683	<b>S</b>	
Inclined-tool machining.....	509	Retraction.....	684	Save service files.....	193
Incremental definition.....	498	Program-section repeat.....	317	Screen layout.....	85
Overview.....	486	Projection in three planes.....	667	Search function.....	144
Point definition.....	496	Protection zone.....	703	Selecting a contour from DXF..	303
Positioning behavior.....	501	Pulsing spindle speed.....	477	Selecting positions from DXF...	307
Projection angle definition.....	490			Selecting the datum.....	131
Resetting.....	488	<b>Q</b>		Selecting the unit of measure..	136
Selection of possible solutions....	504	Q parameter		Select kinematics.....	704
Spatial angle definition.....	489	Export.....	366	Set BAUD rate.....	709
Vector definition.....	494	programming.....	332	Set data transmission speed....	709
Plan view.....	667	Transfer values to the PLC....	366	Software number.....	708
PLC and NC synchronization....	365	Q-Parameter		SPEC FCT.....	428
Pocket table.....	217	Transfer values to the PLC....	365	Special functions.....	428
Polar coordinates.....	129	Q parameter programming.....	382	SQL commands.....	367
Fundamentals.....	129	Additional functions.....	346	Status display.....	90
Programming.....	270	Angle functions.....	340	Additional.....	92
Positioning.....	654	Calculation of circles.....	341	General.....	90
With Manual Data Input.....	654	If-then decisions.....	342	Stop at.....	677
With tilted working plane....	411, 518	Mathematical functions.....	337	Straight line.....	259, 271
Post processor.....	534	Programming notes.....	334	String parameter	
Preset table.....	599	Q parameters.....	332, 382	Converting.....	387
Transferring probed values....	616	Checking.....	344	Copying a substring.....	385
Principal axes.....	129	Local parameters QL.....	332	Finding the length.....	389
Probing		Preassigned.....	394	Testing.....	388
With end mill.....	607	Residual parameters QR.....	332	String parameters.....	382
Probing a plane.....	627			Assign.....	383
Probing cycles.....	609	<b>R</b>		Chain-linking.....	383
Manual operating mode.....	609	Radius compensation.....	228	Reading system data.....	386
Probing with a 3-D touch probe	609	Entering.....	229	Structuring programs.....	177
		Outside corners, inside		Subprogram.....	315
		corners.....	230		

Any desired program.....	319	Tool length.....	204	Assign handwheel holder.....	724
Superimpose handwheel positioning M118.....	419	Tool load monitoring.....	454	Configure.....	724
Surface normal vector....		Tool management.....	231	Selecting transmitter power...	725
494, 510, 523, 525		Editing.....	233	Setting channel.....	725
Switch-off.....	580	Tool types.....	236	Statistical data.....	726
Switch-on.....	578	Tool measurement.....	210	Working space monitoring 671, 675	
<b>T</b>		Tool name.....	204	Workpiece positions.....	130
Table access.....	475	Tool number.....	204	Write to log.....	366
TCPM.....	519	Tool oversize		Writing probing values	
Reset.....	522	Suppress error message:		Log.....	614
Teach In.....	139, 259	M107.....	524	To the datum table.....	615
Teach-in cut.....	447	Tool radius.....	204	To the preset table.....	616
Test Run.....	672	Tool table.....	206	<b>Z</b>	
Test run		Edit, exit.....	211	Zero point shift.....	464
Execute.....	675	Editing functions.....	212	Coordinate input.....	464
Executing up to a certain block.....	677	Input options.....	206	ZIP archive.....	164
Test Run		Tool usage file.....	704		
Overview.....	672	Tool usage test.....	225, 225		
test run		Tool wear monitoring.....	454		
Setting speed.....	661	Touch probe cycles			
Text file.....	467	Manual.....	609		
Delete functions.....	468	Touch probe monitoring.....	423		
Finding text sections.....	470	TRANS DATUM.....	464		
Opening and exiting.....	467	Traverse limits.....	703		
Text variables.....	382	Traversing reference marks.....	578		
Tilt		Trigonometry.....	340		
Working plane.....	485	Turning			
Tilted axes.....	514	Switching.....	547		
Tilting		Tool data.....	559		
Resetting.....	488	Turning mode selection.....	547		
Working plane.....	486	Turning Operations.....	546		
Tilting the working plane.....	638	Feed rate.....	552		
Manual.....	638	Turning operations			
Tilting without rotary axes.....	508	Program spindle speed.....	550		
Tilt working plane		Turning Operations			
programmed.....	485	Tool tip radius compensation..	566		
TNCguide.....	194	T vector.....	525		
TNCremo.....	713	<b>U</b>			
Tool carrier management.....	438	Unbalance functions.....	553		
Tool change.....	222	Undercut.....	567		
Tool compensation.....	227	USB device			
Length.....	227	Connect.....	171		
Tool Compensation		Remove.....	171		
Radius.....	228	User parameters.....	730		
Tool compensation		Using touch probe functions with mechanical probes or measuring dials.....	608		
Three-dimensional.....	523	<b>V</b>			
Tool data.....	204	Vector.....	494		
Call.....	220	Version number.....	708		
Delta values.....	205	Version numbers.....	727		
Entering into the program.....	205	Virtual tool axis.....	420		
Enter into the table.....	206	VSC.....	645		
Export.....	238	<b>W</b>			
Import.....	238	Window Manager.....	99		
Tool data		Wireless handwheel.....	586		
Initiating.....	213				



# HEIDENHAIN

---

**DR. JOHANNES HEIDENHAIN GmbH**

Dr.-Johannes-Heidenhain-Straße 5

**83301 Traunreut, Germany**

☎ +49 8669 31-0

FAX +49 8669 32-5061

E-mail: [info@heidenhain.de](mailto:info@heidenhain.de)

---

**Technical support** FAX +49 8669 32-1000

**Measuring systems** ☎ +49 8669 31-3104

E-mail: [service.ms-support@heidenhain.de](mailto:service.ms-support@heidenhain.de)

**TNC support** ☎ +49 8669 31-3101

E-mail: [service.nc-support@heidenhain.de](mailto:service.nc-support@heidenhain.de)

**NC programming** ☎ +49 8669 31-3103

E-mail: [service.nc-pgm@heidenhain.de](mailto:service.nc-pgm@heidenhain.de)

**PLC programming** ☎ +49 8669 31-3102

E-mail: [service.plc@heidenhain.de](mailto:service.plc@heidenhain.de)

**Lathe controls** ☎ +49 8669 31-3105

E-mail: [service.lathe-support@heidenhain.de](mailto:service.lathe-support@heidenhain.de)

---

**[www.heidenhain.de](http://www.heidenhain.de)**

---

## Touch probes from HEIDENHAIN

help you reduce non-productive time and  
improve the dimensional accuracy of the finished workpieces.


### Workpiece touch probes

**TS 220** Signal transmission by cable

**TS 440, TS 444** Infrared transmission

**TS 640, TS 740** Infrared transmission

- Workpiece alignment
- Setting datums
- Workpiece measurement



### Tool touch probes

**TT 140** Signal transmission by cable

**TT 449** Infrared transmission

**TL** Contact-free laser systems

- Tool measurement
- Wear monitoring
- Tool breakage detection

