



HEIDENHAIN



User's Manual

PROFINET

Interface for Encoders

English (en)
3/2011

Content

- List of tables..... 3**
- List of figures..... 5**
- 1 Introduction 7**
 - 1.1 About absolute encoders 7
 - 1.2 About PROFINET technology..... 8
 - 1.3 Encoder Profiles..... 10
 - 1.4 References..... 11
 - 1.5 Abbreviations 12
- 2 Installation 13**
 - 2.1 Cables and standards 13
 - 2.2 Connectors and pin configuration 14
 - 2.3 Shielding concept of the encoder 15
 - 2.4 MAC-address 15
 - 2.5 LED indication 16
- 3 Configuration example..... 17**
 - 3.1 Device description file installation (GSDML)..... 17
 - 3.2 Setting encoder configuration 19
 - 3.3 Setting encoder device name..... 22
 - 3.4 Setting encoder parameters..... 25
 - 3.5 Isochronous real time settings (RT Class 3)..... 27
- 4 PROFINET IO data description 31**
 - 4.1 Encoder profile overview, PNO order no.3.162 31
 - 4.2 Application Class definition..... 32
 - 4.3 Standard signals..... 32
 - 4.4 Standard telegrams 33
 - 4.4.1 Standard Telegram 81..... 33
 - 4.4.2 Standard Telegram 82..... 34
 - 4.4.3 Standard Telegram 83..... 35
 - 4.4.4 Standard Telegram 84..... 36
 - 4.5 Format of G1_XIST1 and G1_XIST2 37
 - 4.6 Format of G1_XIST3 38
 - 4.7 Control word 2 (STW2_ENC)..... 39
 - 4.8 Status word 2 (ZSW2_ENC) 40
 - 4.9 Control word (G1_STW) 41
 - 4.10 Status word (G1_ZSW)..... 42
 - 4.11 Real time communication..... 43

5	Alarms and warnings.....	45
5.1	Diagnostics and Alarms	45
5.2	Channel diagnostics.....	45
5.3	Sensor status word.....	46
6	Acyclic Parameter Data.....	47
6.1	Acyclic data exchange.....	47
6.2	Identification and Maintenance (I&M functions).....	47
6.3	Base mode parameter access	48
6.3.1	General characteristics	48
6.3.2	Parameter requests and responses	48
6.3.3	Changing the preset value	48
6.3.4	Reading the preset value	49
6.4	Supported parameters.....	50
6.4.1	Parameter 922, read only	50
6.4.2	Parameter 925, read/write	50
6.4.3	Parameter 964, read only	50
6.4.4	Parameter 965, read only	50
6.4.5	Parameter 971, read/write	50
6.4.6	Parameter 974, read only	50
6.4.7	Parameter 975, read only	51
6.4.8	Parameter 979, read only	51
6.4.9	Parameter 980, read only	52
6.4.10	Parameter 61000, read/write	52
6.4.11	Parameter 61001, read only	52
6.4.12	Parameter 61002, read only	52
6.4.13	Parameter 61003, read only	52
6.4.14	Parameter 61004, read only	52
6.4.15	Parameter 65000 read/write	52
6.4.16	Parameter 65001, read only	53
6.4.17	Parameter 65002, read/write	53
6.4.18	Parameter 65003, read only.....	53
6.5	Example of reading and writing to a parameter.....	54
6.5.1	Used blocs.....	55

- 7 Functional description of the encoder 62**
 - 7.1 Code sequence 63
 - 7.2 Class 4 functionality 63
 - 7.3 G1_XIST1 Preset control 64
 - 7.4 Scaling function control 64
 - 7.5 Alarm channel control 65
 - 7.6 Compatibility mode 66
 - 7.7 Preset value 67
 - 7.8 Scaling function parameters 68
 - 7.8.1 Measuring units per revolution 68
 - 7.8.2 Total measuring range 69
 - 7.9 Maximum Master Sign-of-Life failures 73
 - 7.10 Velocity measuring units 74
 - 7.11 Encoder profile version 75
 - 7.12 Operating time 75
 - 7.13 Offset value 76
 - 7.14 Acyclic data 77
 - 7.14.1 PROFIdrive parameters 77
 - 7.14.2 Encoder parameter numbers 78
 - 7.14.3 Parameter 65000 and 65002- Preset value 79
 - 7.14.4 Parameter 65001-Operating status 80
 - 7.14.5 Parameter 65003- operating status 64 bit 83
 - 7.14.6 Identification & Maintenance functions 84
- 8 Firmware upgrade 85**
 - 8.1 Firmware upgrade in a PROFINET network 86
 - 8.2 Stand alone upgrade 90
 - 8.3 Error handling 91
 - 8.4 TFTP server installation 93
 - 8.5 DHCP server installation 95
 - 8.6 Local Area Network (LAN) configuration 97
- 9 Encoder replacement using LLDP 100**
- 10 Encoder state machine 106**
 - 10.1 Normal operation state 107
 - 10.1.1 Profile version 4.x 107
 - 10.1.2 Profile version 3.x 107
 - 10.1.3 Profile version 3.x and 4.x 107
 - 10.2 Parking state 107
 - 10.3 Set/shift home position (Preset) 107
 - 10.3.1 Preset depending on different telegrams 108
 - 10.3.2 Absolute preset with negative value 108
 - 10.4 Error state 108
 - 10.5 Error acknowledgement 108
 - 10.6 Start up 108
- 11 Frequently asked questions FAQ 109**

List of tables

Table 1	Bus Connection	14
Table 2	Power supply connection	14
Table 3	Led indication	16
Table 4	GSDML file	17
Table 5	Standard signals.....	32
Table 6	Output data Telegram 81	33
Table 7	Input data Telegram 81	33
Table 8	Output data Telegram 82	34
Table 9	Input data Telegram 82	34
Table 10	Output data Telegram 83	35
Table 11	Input data Telegram 83	35
Table 12	Output data Telegram 84	36
Table 13	Input data Telegram 84	36
Table 14	Format of G1_XIST3	38
Table 15	Control word 2 (STW2_ENC).....	39
Table 16	Detailed assignment of control word 2 (STW2_ENC)	39
Table 17	Status word 2 (ZSW2_ENC)	40
Table 18	Detailed assignment of status word 2 (ZSW2_ENC)	40
Table 19	Control word (G1_STW)	41
Table 20	Status word (G1_ZSW)	42
Table 21	Channel diagnostics	45
Table 22	Sensor status word.....	46
Table 23	Changing the preset value.....	48
Table 24	Reading the preset value (request)	49
Table 25	Reading the preset value (response)	49
Table 26	Hardware components.....	54
Table 27	Software components	54
Table 28	Parameters of SFB52	58
Table 29	Parameters of SFB53	59
Table 30	Supported encoder functions.....	62
Table 31	Code sequence.....	63
Table 32	Class 4 functionality	63
Table 33	G1_XIST1 Preset control	64
Table 34	Scaling function control	64
Table 35	Alarm channel control.....	65
Table 36	Compatibility mode.....	66
Table 37	Compatibility mode overview.....	66
Table 38	Measuring units per revolution.....	68
Table 39	Maximum master Sign of life failures	73
Table 40	Velocity measuring units.....	74

List of tables

Table 41	Encoder profile.....	75
Table 42	Operating time.....	75
Table 43	Offset value.....	76
Table 44	Supported PROFIdrive parameters.....	77
Table 45	Encoder parameter numbers.....	78
Table 46	Parameter 65000, Preset value.....	79
Table 47	Parameter 65002, Preset value 64 bit.....	79
Table 48	Parameter 65001, Operating status.....	80
Table 49	Parameter 65001, Sub index.....	81
Table 50	Parameter 65001, Sub index 1.....	82
Table 51	Parameter 65003, Operating status 64 bit.....	83
Table 52	Parameter 65003, Sub index.....	83
Table 53	Identification & Maintenance.....	84

List of figures

Figure 1	Bus connectors.....	14
Figure 2	Power supply connector.....	14
Figure 3	Installation of GSDML file.....	18
Figure 4	Encoder configuration.....	19
Figure 5	Example of connected encoder.....	20
Figure 6	Telegram selection.....	21
Figure 7	Selected telegram.....	21
Figure 8	How to set encoder device name.....	22
Figure 9	Device name.....	22
Figure 10	Assign device name.....	23
Figure 11	Assign name.....	23
Figure 12	How to verify device name.....	24
Figure 13	Verify device name.....	24
Figure 14	Parameter Access point.....	25
Figure 15	Parameter data.....	26
Figure 16	Save and compile.....	26
Figure 17	Download settings.....	27
Figure 18	Open Interface properties.....	27
Figure 19	RT Class option.....	28
Figure 20	Interface properties.....	28
Figure 21	IO Cycle properties.....	28
Figure 22	Port settings.....	29
Figure 23	Topology settings.....	29
Figure 24	Domain management.....	30
Figure 25	Overview of encoder profiles.....	31
Figure 26	Absolute value in G1_XIST1.....	37
Figure 27	Absolute value in G1_XIST2.....	37
Figure 28	Real time Communication.....	43
Figure 29	Request data block, DB1.....	55
Figure 30	Response data block, DB2.....	55
Figure 31	Instance data block, DB3.....	56
Figure 32	Instance data block, DB.....	56
Figure 33	Organization block, OB1.....	57
Figure 34	Diagnostic address of slot 1.....	60
Figure 35	Variable table.....	61
Figure 36	Cyclic operation.....	70
Figure 37	Non cyclic operation, preset control enabled.....	71
Figure 38	Non cyclic operation, preset control disabled.....	72
Figure 39	Firmware upgrade startpage.....	86
Figure 40	Firmware upgrade settings.....	87

List of figures

Figure 41	Firmware upgrade confirmation page.....	88
Figure 42	Firmware upgrade status page	89
Figure 43	Network parameters	90
Figure 44	SolarWinds TFTP server	93
Figure 45	SolarWinds TFTP server settings	94
Figure 46	Tiny DHCP Server	95
Figure 47	Tiny DHCP server settings	96
Figure 48	Tiny DHCP server settings	96
Figure 49	LAN- configuration	97
Figure 50	LAN properties.....	98
Figure 51	TCP/IP settings	99
Figure 52	LLDP Properties.....	100
Figure 53	LLDP Port configuration	101
Figure 54	LLDP Partner port settings	102
Figure 55	Open Topology editor.....	103
Figure 56	Topology editor	103
Figure 57	Edit Ethernet node.....	104
Figure 58	Factory reset.....	105
Figure 59	Factory set confirmation.....	105
Figure 60	Encoder state machine.....	106

1 Introduction

1.1 About absolute encoders

With an absolute encoder each angular position is assigned a coded position value generated by a code disc equipped with several parallel fine graduations tracks which are scanned individually. On single turn encoders, i.e. an encoder producing absolute positions within one revolution, the absolute position information repeats itself with every revolution. So called multi turn encoders can also distinguish between revolutions. The numbers of unique revolutions is determined by the resolution of the multi turn scanning and repeats itself after the total resolution is reached. A major benefit of absolute encoder type is that if the encoder loses power, the encoder is able to keep track of its position also if the shaft is turned during the power loss. This is due to the genuine absolute scanning principle.

An absolute encoder can also be used to calculate a digital speed value. By internally dividing the difference in position with a small delta time an accurate speed value can be calculated and transmitted to the subsequent electronics for closed loop control.

1.2 About PROFINET technology

PROFINET is the open industrial Ethernet standard of PROFIBUS & PROFINET International (PI) for automation. PROFINET uses TCP/IP and IT standards, and is in effect, real-time Ethernet. The PROFINET concept features a modular structure so that users can select the cascading functions themselves. They differ essentially because of the type of data exchange to fulfill the partly very high requirements of speed.

In conjunction with PROFINET, the two perspectives PROFINET CBA and PROFINET IO exist. PROFINET CBA is suitable for the component-based communication via TCP/IP and the real-time communication for real-time requirements in modular systems engineering. Both communication options can be used in parallel.

PROFINET IO was developed for real time (RT) and isochronous real time (IRT) communication with the de-centralized periphery. The designations RT and IRT merely describe the real-time properties for the communication within PROFINET IO.

To achieve these functions, three different protocol levels are defined:

- TCP/IP for PROFINET CBA and the commissioning of a plant with reaction times in the range of 100ms
- RT (Real-Time) protocol for PROFINET CBA and PROFINET IO applications up to 1 ms cycle times
- IRT (Isochronous Real-Time) for PROFINET IO applications in drive systems with cycles times of less than 1ms

Interfacing the peripherals devices such as encoders is implemented by PROFINET IO. Its basis is a cascading real-time concept. PROFINET IO defines the entire data exchange between controllers (devices with "master functionality") and the devices (devices with "slave functionality"), as well as parameter setting and diagnosis.

PROFINET IO is designed for the fast data exchange between Ethernet-based field devices and follows the provider-consumer model. The configuration of an IO-System has been kept nearly identical to the "look and feel" of PROFIBUS.

A PROFINET IO system consists of the following devices:

- The IO Controller, which contains the automation program and controls the automation task.
- The IO Device, which is a field device such as an encoder, monitored and controlled by an IO Controller.
- The IO Supervisor is software typically based on a PC for setting parameters and diagnosing individual IO Devices.

An application relation (AR) is established between an IO Controller and an IO Device. These ARs are used to define communication relations (CR) with different characteristics for the transfer of parameters, cyclic exchange of data and handling of alarms.

The characteristics of an IO Device are described by the device manufacturer in a General Station Description (GSD) file. The language used for this purpose is the GSDML (GSD Markup Language) - an XML based language. The GSD file provides the supervision software with a basis for planning the configuration of a PROFINET IO system.

Within PROFINET IO, process data and alarms are always transmitted in real time (RT). Real time in PROFINET is based on the definition of IEEE and IEC, which allow for only a limited time for execution of real-time services within a bus cycle. The RT communication represents the basis for the data exchange for PROFINET IO and real-time data are always treated with a higher priority than TCP (UDP)/IP data.

1.3 Encoder Profiles

Profiles are pre-defined configurations of the functions and features available from PROFINET for use in specific devices or applications such as encoders. They are specified by PI (PROFIBUS & PROFINET International) working groups and published by PI. Profiles are important for openness, interoperability and interchangeability, so that the end user can be sure that similar equipments from different vendors perform in a standardized way.

HEIDENHAIN comply with the definitions in the encoder profile 3.162, version 4.1. The encoder device profile describing encoder functionality and additional information about PROFINET can be ordered from PROFIBUS User Organization, PNO.

PROFINET is generally defined by PROFIBUS & PROFINET International (PI) and backed by the INTERBUS Club and, since 2003, is part of the IEC 61158 and IEC 61784 standards.

PROFIBUS User Organization

Haid-und-Nue Straße 7

D 76131 Karlsruhe

Tel: +49 721 96 58 590

Fax: + 49 721 96 58 589

Web: www.profibus.com

1.4 References

Profile Encoders for PROFIBUS and PROFINET V4.1,
Order No. 3.162

Profile Drive Technology, PROFIdrive V4.1,
PROFIBUS International, Order No. 3.172

PROFIBUS Encoder Profile V1.1, PROFIBUS International, Order
No. 3.062

PROFIBUS Guidelines, Part 1: Identification & Maintenance Func-
tions V1.1, PROFIBUS International, Order No. 3.502

PROFIBUS Guidelines, Part 3: Diagnosis, Alarms and Time Stamp-
ing V1.0, PROFIBUS International, Order No. 3.522

PROFINET Application Layer Service Definition Application Layer
Protocol Specification, Version 2.0,
PROFIBUS International, Order No. 2.332

PROFIBUS Guidelines: PROFIBUS Interconnection Technology
V1.1, PROFIBUS International, Order No. 2.142

PROFINET Guidelines: PROFINET Cabling and Interconnection
Technology V1.99, PROFIBUS International,
Order No. 2.252

1.5 Abbreviations

PI	PROFIBUS and PROFINET International
IO	Input/Output
DO	Drive Object
DU	Drive Unit
AR	Application Relation
CR	Communication Relation
MLS	Master Sign-Of-Life
RT	Real Time Ethernet
IRT	Isochronous Real Time Ethernet
IsoM	Isochronous Mode
LLDP	Link Layer Discovery Protocol
GSD	General Station Description
GSDML	General Station Description Markup Language
UDP	User Datagram Protocol
TCP	Transmission Control Protocol
IP	Internet Protocol
DHCP	Dynamic Host Configuration Protocol
TFTP	Trivial File Transfer Protocol
MAC	Media Access Control
I&M	Identification & Maintenance

2 Installation

A summary of the PROFINET guideline: PROFINET Cabling and interconnection Technology V 1.99, PROFIBUS International, Order No 2.252 is provided in this section.

2.1 Cables and standards

Two shielded copper cables twisted in pairs are defined as the normal transmission medium for PROFINET networks. In such networks the signal transmission is performed in accordance with 100BASE-TX at a transmission speed of 100 Mbps (Fast-Ethernet).


Only shielded cables and connecting elements are allowed in a PROFINET network. The individual components have to satisfy the requirements of Category 5 in accordance with IEC 11801. The entire transmission path has to meet the requirements of Class D in accordance with IEC 11801. Furthermore, PROFINET cables shall have a cable cross-section of AWG 22 in order to enable even complex cabling structures through minimum damping. For this reason, the specification of the PROFINET cables supports a modular setup, which ensures an IEC 11801-compliant structure on adherence to simple installation rules.

Transmission channels lengths are determined by the type of cable being used. The choice of cable is to be such that a transmission channel length of 100 meter is achieved between two active network devices. The use of a high number of plug connections has a negative effect on attenuation and reflection and consequently reduces the transmission channel length. A maximum of three interconnections can be inserted between two active devices without reduction of the permissible transmission lengths of 100 meters.

2.2 Connectors and pin configuration

M12 connectors are used for connecting the bus lines to the encoder. The M12 connector used is a 4-pin female shielded D-coded version.

The correct arrangement of the bus connectors are specified as follows:




Signal	Function	Pin
Tx+	Transmission data +	1
Tx-	Transmission data -	3
Rx+	Receiver data +	2
Rx-	Receiver data -	4

Table 1 Bus Connection

Figure 1 Bus connectors

Note: The encoder provides integrated switch functionality between the two M12 connectors used for PROFINET communication. It is important to distinguish between these ports when IRT-communication is used.

The M12 connector used for power supply of the encoder is constituted by a 4-pin male shielded A-coded version. The correct arrangement of the power supply line is specified as follows:



Signal	Function	Pin
+E Volt	Supply 10-30Vdc	1
Not connected	-	3
0 Volt	0 Volt	2
Not connected	-	4

Table 2 Power supply connection

Figure 2 Power supply connector

Note: Passive T-couplings are not possible to use in a PROFINET network. All devices must be connected through active network components.

2.3 Shielding concept of the encoder

Automation systems in an industrial environment are subjected to high levels of electromagnetic disturbance. Switching large electrical loads creates high interference levels that can be picked up in various ways by electronic devices with detrimental effects. Even under such conditions, electric components within an automation system must still guarantee a continuous, uninterrupted function.

The electromagnetic compatibility (EMC) of the entire plant must be ensured by using suitably designed components and assembling them correctly to make up the system. Data cabling is considered as a passive system and cannot be tested for EMC compliance individually. Nevertheless, cabling and connection elements for PROFINET supports compliance with devices requirements by providing a high-quality, comprehensive shielding concept.

To achieve the highest possible noise immunity and resistance against other EMC related disturbances the bus and power supply cables shall always be shielded. The screen should be connected to ground on both ends of the cable. In certain cases compensation current might flow over the screen.

2.4 MAC-address

PROFINET IO field devices are addressed using MAC addresses and IP addresses. All field devices have a unique MAC address. The MAC address is constituted by a 6 byte Ethernet address for each individual station and is unique worldwide. The MAC address consists of two parts, the first 3 bytes represents the manufacturer-specific ID and the last 3 bytes represents a consecutive number. The MAC address of the encoder is printed on the encoder label for commissioning purposes.

2.5 LED indication

The following table defines diagnostic indications shown by the encoders two bi-colored LEDs.

Bus	Module	Meaning	Cause
Off	Off	No power	
Red	Green	No connection to another device. Criteria: No data exchange	<ul style="list-style-type: none"> - bus disconnected - Master not available/switched off
Blinking* red	Green	Parameterization fault, no data exchange Criteria: Data exchange correct, however the encoder did not switch to the data exchange mode	<ul style="list-style-type: none"> - Slave not configured yet or wrong configuration - Wrong station address assigned - Actual configuration of the slave differs from the nominal configuration
Green	Red	System failure	Diagnosis exists, slave in data exchange mode
Green	Green	Data exchange and encoder functions properly	
Blinking* green	Blinking green	Firmware upgrade in process	
Blinking* red	Blinking red	Failure during firmware upgrade	

*) The blinking frequency is 0.5 Hz. Minimal indication time is 3 seconds.

Table 3 Led indication

3 Configuration example

This chapter will illustrate how to setup and configure a PROFINET encoder for working in RT Class 1 mode. In the following examples SIMOTION SCOUT V.4.1.5.6 and D435 motion controller is used. Please refer to the manufacturer of the configuration tool if other configuration tools are being used.

3.1 Device description file installation (GSDML)

In order to start using an absolute encoder with PROFINET interface, a device description file needs to be downloaded and imported to the configuration software. The device description file is called a **G**eneric **S**tation **D**escription **M**arkup **L**anguage file and contains the necessary implementation parameters needed for a PROFINET IO device.

The GSDML file can be downloaded from www.heidenhain.com

GSDML file
GSDMLV2.2-JH-PROFINET-Encoder-xxxxxxx.xml

Table 4 GSDML file

Installation of GSDML-files




Figure 3 Installation of GSDML file

1. Select Options -> Install GSD File and click the Browse button to navigate to the location of the GSD file. If a bitmap picture representing the encoder is requested, make sure that the bitmap file is located in the same folder as the GSDML file. A bitmap file is included in the zip-file downloadable from www.heidenhain.com.
2. Select the GSD file and click the Install button to start installing the selected GSD file.

3.2 Setting encoder configuration

When the GSD file has been installed the supported encoder types can be found in the HW Configuration under PROFINET IO->Additional Field Devices->Encoders->JH Group PROFINET Encoders. Select either multi turn 25 bit or single turn 13 bit encoder, dependent on the type of encoder to be configured. Drag and drop the encoder onto the PROFINET IO system as shown in the picture below. In the example below one 25 bit multiturn encoder was chosen. If more than one encoder shall be configured, then the following steps need to be done once for each device.




Figure 4 Encoder configuration

Configuration example

When correctly done, the encoder will appear on the PROFINET IO system as shown in figure 5 below.




Figure 5 Example of connected encoder

The next step will be to choose the data length and the type of data that should be sent to and from the IO controller. This is done by choosing different telegrams. Available telegrams for the multi-turn 25 bit encoder can be found under Multiturn 25 Bit -> EO Multiturn. In the example below standard telegram 81 is used. Drag and drop the telegram onto slot 1, sub slot 2 as shown in the figure 6 below. For more information regarding the different telegrams refer to chapter 4.4.




Figure 6 Telegram selection

The Standard Telegram 81 will appear on slot 1 sub slot 2 according to figure 7 below.

The screenshot shows the same table as in Figure 6, but with the 'Standard Telegram 81' entry in slot 1.2 highlighted with a red border. The 'I Address' is 0.11 and the 'Q address' is 0.3.

Slot	Module	Order number	I Address	Q address	Diagnostic address	Comment
0	PROFINET-ENCODER				8E92**	
07	Interface				204**	
09	Power 1				3041**	
09	Power 2				3040**	
1	EO Multiturn				3028**	
1.1	Encoder A/1000P				3030**	
1.2	Standard Telegram 81		0.11	0.3	3028**	

Figure 7 Selected telegram

Note: The steps above need to be performed once for each device.

3.3 Setting encoder device name

In a PROFINET network all IO devices needs to have a unique device name. The encoders are delivered without any device name preset from the factory. To set the encoder device name, double click on the encoder icon to open the Properties window.




Figure 8 How to set encoder device name

In the Properties window, enter an appropriate device name in the Device name field.




Figure 9 Device name

Make sure that the checkbox Assign IP address via IO controller is checked if the IP address for the encoder should be assign via the IO controller.

Then select PLC-> Ethernet->Assign Device Name to open the Assign device name window.




Figure 10 Assign device name

Choose the device on which the device name should be changed and then click on the Assign name button to adopt the changes and then click on the Close button. The MAC address of the encoder is written on the encoder label.




Figure 11 Assign name

Configuration example

Note: All connected devices need to be assigned a unique device name.

After changing device name, it is recommended to verify that the performed change has been done. This is done by opening the Verify Device Name window found under PLC->Ethernet->Verify Device Name.




Figure 12 How to verify device name

In the Verify Device Name window, verify that the Device name has changed and the status is OK as shown in the example according to figure 13 below.




Figure 13 Verify device name

3.4 Setting encoder parameters

This chapter describes how to change the user parameters in the encoder.

To set the encoder user parameters double click on the Parameter Access point field located under slot 1.1 as shown in figure 14, to open the Properties window.




Figure 14 Parameter Access point

Configuration example

In the Properties window, choose the Parameters" tab. To set the parameter data, change the value of the different parameters by clicking on the drop down list in the Value field for the respective parameter. For more information regarding parameter data, see chapter 7.




Figure 15 Parameter data

When the configuration and parameterization of the device has been done, the settings need to be saved and compiled. This is done by clicking on the Save and Compile option under the Station tab.




Figure 16 Save and compile

Then the settings need to be downloaded to the IO-controller. This is done by clicking on the Download option under the PLC Tab.




Figure 17 Download settings

3.5 Isochronous real time settings (RT Class 3)

This example is intended to illustrate the commissioning of a PROFINET encoder in isochronous operation. In the example below STEP 7 v5.4 SP5 and SIMOTION D435 motion controller is used. The basic principal for configuration and parameterization of the encoder is the same as described in chapter 3.2-3.4.

To set the IRT settings of the encoder, double click on the Interface field located under slot 0, sub slot X1 to open the Properties window.

Slot	Module	Order number	I Address	Q address	Diagnostic address	Comment
0	Encoder1v2				1632*	
X1	Interface				1637*	
P1	Port 1				1638*	
P2	Port 2				1639*	
1	ED Multiturn				1636*	
1.1	Parameter Access Point				1636*	
1.2	Standard Telegram 81		0...11	0...3		

Figure 18 Open Interface properties

Configuration example

Under the Synchronization tab change the value for the Parameter RT Class to IRT and the IRT option parameter to High Performance according to the picture below.




Figure 19 RT Class option

Under the Application tab check the box for Operate IO device/application in isochronous mode.




Figure 20 Interface properties

Under the IO Cycle tab change the Update Time Mode to fixed factor.




Figure 21 IO Cycle properties

Before the encoder can operate in IRT mode it is necessary to set from which port of the encoder the connection to the network has been done.

To set the topology double click on the port from which the encoder is connected to the network. This is either slot 0 sub slot P1 or slot 0 sub slot P2. In the example in figure 22 below Port 1 is used on the encoder. For port description of the encoder see chapter 2.2 Connectors and pin configuration.

Slot	Module	Order number	I Address	Q address	Diagnostic address	Comment
0	Encoder1v2				1632*	
0.1	Interface				1637*	
0.1	P1				1638*	
0.2	P2				1639*	
1.1	Parameter Access Port				1636*	
1.2	Standard Telegram 81		0..11	0..3	1635*	

Figure 22 Port settings

Under the Topology tab change the Partner port to the used port of your IO controller.

Properties - Interface - Port 1 (P1)

General | Addresses | **Topology** | Options

Port Interconnection

Local port: SIMOTION D\Encoder1v2\Port 1 (P1)

Medium: Local port: Copper Partner port: Copper

Cable name: Copper

Partners

Partner port: SIMOTION D\CBE30xPNxIO (D435)\Port 2 (X1400 P2)

Alternating partner ports:

Figure 23 Topology settings

Configuration example

When the above steps have been performed, it is recommended to verify that the setting for the encoder and the IO controller is correct. This is done by opening the Domain management Window found under Edit->PROFINET IO.

Verify that the RT Class is set to IRT and that the IRT option is set to High performance.




Figure 24 Domain management

The encoder is now prepared for operating in IRT mode.

4 PROFINET IO data description

4.1 Encoder profile overview, PNO order no.3.162

This manual is related to encoders that fulfill the demands and functionality according to encoder profile V4.1 (PNO no 3.162). The operating functions for encoders according to this profile are divided into two application classes, named Class 3 and Class 4. For an overview of the different encoder profile for PROFIBUS and PROFINET and the related standards, see figure 25 below.

For further information regarding the encoder functionality refer to the device profile. The profile and PROFINET technical information can be ordered at PNO in Karlsruhe, Germany (www.profinet.com).




Figure 25 Overview of encoder profiles

4.2 Application Class definition

The PROFINET encoders can be configured as a class 3 or class 4 PROFINET IO device according to the encoder profile V4.1 (PNO no 3.162). A Class 4 configured encoder fully supports all functionality according to the encoder profile V4.1.

CLASS 3 Encoder with base mode parameter access and limited parameterization of the encoder functionality. Isochronous mode **is not** supported.

CLASS 4 Encoder with scaling, Preset and base mode parameter access. Isochronous mode **is** supported.

4.3 Standard signals

Table 5 below describes the standard signals that are used to configure the IO data. The signals are described in the chapters that follow.

Significance	Abbreviation	Length (bits)	Data type
Velocity value A	NIST_A	16	Signed
Velocity value B	NIST_B	32	Signed
Control word	G1_STW	16	Unsigned
Status word	G1_ZSW	16	Unsigned
Position value 1	G1_XIST1	32	Unsigned
Position value 2	G1_XIST2	32	Unsigned
Position value 3	G1_XIST3	64	Unsigned
Control word 2	STW2_ENC	16	Unsigned
Status word 2	ZSW2_ENC	16	Unsigned

Table 5 Standard signals

4.4 Standard telegrams

Configuration of PROFINET encoders are made by choosing different telegram structures. The telegrams are used to specify the data length and which type of data that are sent to and from the IO controller. The following telegrams are supported.

4.4.1 Standard Telegram 81

Standard telegram 81 uses 4 bytes for output data from the IO controller to the encoder and 12 bytes of input data from the encoder to the IO-controller.

Output data from the IO controller:

2 bytes Control word 2 (STW2_ENC).
 2 bytes Control word (G1_STW).

IO Data	1	2
Set point	STW2_ENC	G1_STW

Table 6 Output data Telegram 81

Input data to the IO controller:

2 bytes Status word 2(ZSW2_ENC).
 2 bytes Status word (G1_ZSW).
 4 bytes Position value 1 (G1_XIST1).
 4 bytes Position value 2 (G1_XIST2).

IO Data	1	2	3	4	5	6
Actual value	ZSW2_ENC	G1_ZSW	G1_XIST1		G1_XIST2	

Table 7 Input data Telegram 81

4.4.2 Standard Telegram 82

Standard telegram 82 uses 4 bytes for output data from the IO controller to the encoder and 14 bytes of input data from the encoder to the controller.

Output data from the IO controller:

2 bytes Control word 2 (STW2_ENC).

2 bytes Control word (G1_STW).

IO Data	1	2
Set point	STW2_ENC	G1_STW

Table 8 Output data Telegram 82

Input data to the IO controller:

2 bytes Status word 2(ZSW2_ENC).

2 bytes Status word (G1_ZSW).

4 bytes Position value 1 (G1_XIST1).

4 bytes Position value 2 (G1_XIST2).

2 bytes Velocity value A (NIST_A)

IO Data	1	2	3	4	5	6	7
Actual value	ZSW2_ENC	G1_ZSW	G1_XIST1		G1_XIST2		NIST_A

Table 9 Input data Telegram 82

4.4.3 Standard Telegram 83

Standard telegram 83 uses 4 bytes for output data from the controller to the encoder and 16 bytes of input data from the encoder to the controller.

Output data from the IO controller:

2 bytes Control word 2 (STW2_ENC).

2 bytes Control word (G1_STW).

IO Data	1	2
Set point	STW2_ENC	G1_STW

Table 10 Output data Telegram 83

Input data to the IO controller:

2 bytes Status word 2(ZSW2_ENC).

2 bytes Status word (G1_ZSW).

4 bytes Position value 1 (G1_XIST1).

4 bytes Position value 2 (G1_XIST2).

4 bytes Velocity value B (NIST_B)

IO Data	1	2	3	4	5	6	7	8
Actual value	ZSW2_ENC	G1_ZSW	G1_XIST1		G1_XIST2		NIST_B	

Table 11 Input data Telegram 83

4.4.4 Standard Telegram 84

Standard telegram 84 uses 4 bytes for output data from the controller to the encoder and 20 bytes of input data from the encoder to the controller.

Output data from the IO controller:

2 bytes Control word 2 (STW2_ENC).

2 bytes Control word (G1_STW).

IO Data	1	2
Set point	STW2_ENC	G1_STW

Table 12 Output data Telegram 84

Input data to the IO controller:

2 bytes Status word 2(ZSW2_ENC).

2 bytes Status word (G1_ZSW).

8 bytes Position value 3 (G1_XIST3).

4 bytes Position value 2 (G1_XIST2).

4 bytes Velocity value B (NIST_B)

IO Data	1	2	3	4	5	6	7	8	9	10
Actual value	ZSW2_ENC	G1_ZSW	G1_XIST3			G1_XIST2		NIST_B		

Table 13 Input data Telegram 84

Note: In standard Telegram 84, G1_XIST2 is used to transfer error codes and optionally position values if the measuring length exceeds 64 bits.

4.5 Format of G1_XIST1 and G1_XIST2

The G1_XIST1 and G1_XIST2 signals consist of the absolute position value in binary format. By default the G1_XIST1 signal is equal to the G1_XIST2 signal. The format of the actual position values in G1_XIST1 and G1_XIST2 is shown below.

Format definition for G1_XIST1 and G1_XIST2:

- All values are presented in binary format
- The shift factor is always zero (right aligned value) for both G1_XIST1 and G1_XIST2.
- The setting in the encoder parameter data affects the position value in both G1_XIST1 and G1_XIST2.
- G1_XIST2 displays the error telegram instead of the position value if error occurs.

Example:

25 bit multi turn absolute encoder (8192 steps per revolution, 4096 distinguishable revolutions)

M = Multi turn value (Distinguishable revolutions)

S = Single turn value (number of steps per revolutions)




Figure 26 Absolute value in G1_XIST1




Figure 27 Absolute value in G1_XIST2

4.6 Format of G1_XIST3

G1_XIST3 is a 64 bit position value which is used to support encoders with a resolution exceeding 32 bits.

Format definition for G1_XIST3:

- Binary format
- The actual position value is always right aligned, a shifting factor is not used.
- The settings in the encoder parameter data affect the position value in G1_XIST3 if Class 4 is enabled.

IO Data	1	2	3	4
Format	64 bit position value			

Table 14 Format of G1_XIST3

4.7 Control word 2 (STW2_ENC)

The control word 2 (STW2_ENC) is referred to as the master sign of life and it includes the fault buffer handling and Control by PLC mechanism from PROFIdrive STW1 and the Controller Sign-Of-Life mechanism from PROFIdrive STW2. This signal is mandatory for controlling the clock synchronization.

Bit	Function
0..6	Reserved
7	Fault Acknowledge
8,9	Reserved
10	Control by PLC
11	Reserved
12..15	Controller Sign-of-life

Table 15 Control word 2 (STW2_ENC)

Bit	Value	Significance	Comments
7	1	Fault Acknowledge (0->1)	The fault signal is acknowledged with a positive edge. The encoder reaction to a fault depends on the type of fault.
	0	No significance	
10	1	Control by PLC	Control via interface, EO IO Data is valid.
	0	No Control by PLC	EO IO Data not valid, except Sign-Of-Life
12..15		Controller Sign-Of-Life	

Table 16 Detailed assignment of control word 2 (STW2_ENC)

4.8 Status word 2 (ZSW2_ENC)

The status word 2 (ZSW2_ENC) is referred to as the slave's sign of life and it includes the fault buffer handling and Control by PLC mechanism from PROFIdrive ZSW1 and the Slave Sign-Of-Life mechanism from PROFIdrive ZSW2. This signal is mandatory for controlling the clock synchronization.

Bit	Function
0..2	Reserved
3	Fault present/No fault
4..8	Reserved
9	Control requested
10,11	Reserved
12..15	Encoder Sign-of-life

Table 17 Status word 2 (ZSW2_ENC)

Bit	Value	Significance	Comments
3	1	Fault Present	Unacknowledged faults or currently not acknowledged faults (fault messages) are present (in the buffer). The fault reaction is fault-specific and device-specific. The acknowledging of a fault may only be successful, if the fault cause has disappeared or has been removed before. If the fault has been removed the encoder returns to operation. The related fault numbers are in the fault buffer.
	0	No Fault	
9	1	Control requested	The automation system is requested to assume control.
	0	No Control requested	Control by automation system is not possible, only possible at the device or by another interface.
12..15		Encoder Sign-Of-Life	

Table 18 Detailed assignment of status word 2 (ZSW2_ENC)

4.9 Control word (G1_STW)

The control word controls the functionality of major encoder functions.

Bit	Function
0..7	Function requests: Reference mark search, measurement on the fly
8..10	Reserved (without effect)
11	Home position mode position mode (Preset)
12	Request set/shift of home position (Preset)
13	Request absolute value cyclically
14	Activate parking sensor
15	Acknowledging a sensor error

Table 19 Control word (G1_STW)

Note: If the sensor parking is activated (bit 14 = 1) the encoder is still on the bus with the slave sign of life active and the encoder error and diagnostics switched off.

4.10 Status word (G1_ZSW)

The status word defines encoder states, acknowledgements, error messages of major encoder functions.

Bit	Function
0..7	Function status: Reference mark search, measurement on the fly
8	Probe 1 deflected
9	Probe 2 deflected position mode (Preset)
10	Reserved, set to zero
11	Requirements of error acknowledgment detected
12	Set/shift of home position (Preset) executed
13	Transmit absolute value cyclically
14	Parking sensor active
15	Sensor error

Table 20 Status word (G1_ZSW)

Note: If bit 13 Transmit absolute value cyclically or bit 15 Sensor error is not set there is no valid value or error code transferred in G1_XIST2.

Note: Bit 13 Transmit absolute value cyclically cannot be set at the same time as bit 15 Sensor error as these bits are used to indicate either a valid position value transmission (bit 13) or the error code transmission (bit 15) in G1_XIST2.

4.11 Real time communication

PROFINET IO uses three different communication channels to exchange data with programmable controllers and other devices. The non real time channel based on for example TCP (UDP)/IP is used for parameterization, configuration and acyclic read/write operations.

The RT or RealTime channel is used for process data transfer and alarms.

Real-time data are treated with a higher priority than data sent over the open channel. RT communications overrides the open channel to handle the data exchange with programmable Controllers.

The third channel, Isochronous Real Time (IRT) is the high performance, high speed channel used for demanding motion Control applications. IRT data are treated with a higher priority than RT data sent over the RT channel.




Figure 28 Real time Communication

PROFINET distinguishes between three real time classes for transmission of time critical process data. The three RT classes are:

Real-Time, RT Class 1

- Unsynchronized Real time communication
- Industrial standard switches can be used.
- Typical application area: Factory automation

Real-Time, RT Class 2

- Synchronized and unsynchronized data transmission
- Special switches supporting IRT is needed
- Typical application area: Factory automation

Isochronous Real Time, RT Class 3

The isochronous operation mode is used when real-time positioning with high performance is required. The basic principal is that all PROFINET devices on the net are clock synchronized with the controller using a global control broadcast enabling simultaneous data accusation from all devices with microsecond accuracy. The data exchange cycles for IRT are usually in the range of a few hundred microseconds up to a few milliseconds. The difference to real-time communication is essentially the high degree of determinism, so that the start of a bus cycle is maintained with high precision. The synchronization is monitored by sign-of life messages in Control word 2 (STW2_ENC) and Status word 2 (ZSW2_ENC).

- Clock synchronized data transmission
- Special switches supporting IRT is needed
- IRT is required for example motion control applications

5 Alarms and warnings

5.1 Diagnostics and Alarms

Diagnostic data is always transferred acyclically using Record Data communications over the non real time channel. An IO Supervisor must specifically request the diagnostic or status data from the IO device using RDO (Record Data Object) services.

Alarm data is transmitted from the IO device to the IO controller via the RT channel.

Alarm is generated by the encoder when failure occurs which effects the position value. Alarms can be reset (deleted) when all encoder parameters are within the specified value ranges and the position value is correct.

5.2 Channel diagnostics

The encoder outputs a diagnostic interrupt to the CPU when it detects one of the supported channel diagnostics.

Supported channel diagnostic	Diagnostic data record	Description
Position error	0x900A	The encoder fails to read the correct position value
Memory error	0x9000	The encoder fails to read stored offset or preset values from the non volatile memory
Commissioning diagnostics	0x9011	User parameter data assignment error

Table 21 Channel diagnostics

In a SIMATIC STEP 7 system the operation system responds by calling a diagnostic OB. The OB number and start information provides the cause and location of the error. The error information can be read by calling a system Function block (SFB54 RALRM for STEP 7). Then the user can decide how the system should handle the error.

Note: If the called OB is not included in the program the CPU will go to stop.

5.3 Sensor status word

Diagnosis information can be obtained by monitoring of the Error bit in the Sensor Status word G1_ZSW (bit 15) and evaluation of the error code transmitted in G1_XIST2.

Supported diagnostic	Error code in G1_XIST2	Description
Sensor group error	0x0001	The encoder fails to read the correct position value
Memory error	0x1001	The encoder fails to read stored offset or preset values from the non volatile memory
Command not supported	0x0F01	User parameter data assignment error or command error in commands words G1_STW and STW2_ENC
Master's sign of life fault	0x0F02	The number of permissible failures the controller's life sign was exceeded.

Table 22 Sensor status word

6 Acyclic Parameter Data

6.1 Acyclic data exchange

In addition to the cyclic data exchange, the PROFINET encoder also supports acyclic data exchange. The acyclic data exchange is transferred over the non-real time channel and is used to read out and write status information from and to the IO device. The acyclic data exchange is conducted in parallel to the cyclic data communication.

Example of acyclic data:

- Reading of diagnostic
- Reading of I&M functions
- Reading of PROFIdrive parameters

6.2 Identification and Maintenance (I&M functions)

Encoders according to the encoder profile 3.162 also support I&M functionality.

The main purpose of the I&M functions is to support the end user if the device is acting faulty or missing some of its functionality. The I&M functions could be seen as an electronic nameplate containing common information regarding the device and its manufacturer.

According to the PROFINET specification all IO devices must at least support the following I&M functions:

- Order ID
- MAC address
- Hardware Version
- Software Version
- Product type
- Manufacturer ID

For more information regarding additional I&M functions supported by the encoder, refer to chapter 7.14.6.

6.3 Base mode parameter access

6.3.1 General characteristics

Acyclic parameter can be transmitted 1(single) or up to 39 (multi) in one access. A parameter access can be up to 240 bytes long.

6.3.2 Parameter requests and responses

Request header:

Request ID, DO-ID and number of parameters of the access.

Parameter address:

One address for each parameter, if several parameters are accessed.

Parameter value:

If the Request ID is 0x02 (change value) the value is set in the request and if the Request ID is 0x01 (request value), the value appears in the reply.

6.3.3 Changing the preset value

Table 23 below shows the structure of a change value request.

Write of Preset value, parameter 65000 Parameter request		
Request reference	0x00	
Request ID	0x02	0x02 →Change value, 0x01 →read value
DO-ID (axis)	0x01	Drive Object ID
No of parameters	0x01	
Attribute	0x10	0x10→Value
No of elements	0x00	
Parameter number	0xFDE8	Parameter 65000
Sub index	0x0000	
Format	0x04	Data type integer 32
Number of values	0x01	

Table 23 Changing the preset value

6.3.4 Reading the preset value

The tables below show the structure of a read value request.

Read of Preset value, parameter 65000 Parameter request		
Request reference	0x00	
Request ID	0x01	0x01→read value
DO-ID (axis)	0x01	Drive Object ID
No of parameters	0x01	0x01 Read one parameter
Attribute	0x10	0x10→Value
No of elements	0x00	
Parameter number	0xFDE8	Parameter 65000
Sub index	0x0000	

Table 24 Reading the preset value (request)

Read of Preset value, parameter 65000 Parameter response		
Request reference	0x00	mirrored
Response ID	0x01	0x01→read value
DO-ID (axis)	0x01	mirrored
No of parameters	0x01	
Format	0x04	0x04= Data type unsigned 32
No of values	0x01	
Values or errors	0x00,0x00,0x00,0x64	Preset value 100

Table 25 Reading the preset value (response)

6.4 Supported parameters

6.4.1 Parameter 922, read only

922→ unsigned int, presents which telegram is used. Telegram 81,82,83 or 84 is possible.

6.4.2 Parameter 925, read/write

925→ unsigned int, maximum allowed MLS (Master sign-of-life) error. Parameter 925 may be used to set a maximum on how many consecutive Sign-of-life failures may occur.

6.4.3 Parameter 964, read only

964→unsigned int

964[0] = Manufacturer Id. This is set during manufacturing of the encoder.

964[1] = 0→DU Drive unit type, always set to 0.

964[2] = 201→Software version

964[3] = 2009→Software year

964[4] = 2805→ Software day and month

964[5] = 1→ Number of drive objects (DO)

6.4.4 Parameter 965, read only

965→OctetString 2

965[0] =0x3D→Encoder profile number

965[1] = 31 or 41 →Encoder profile version, set by customer (user_parameters)

6.4.5 Parameter 971, read/write

971→ unsigned int, Stores the local parameter set to a non volatile memory. Preset value is saved when writing value 1 and is set to 0 by the encoder firmware when finished. This means that the preset value has been saved when reading back value 0.

6.4.6 Parameter 974, read only

974→unsigned int

974[0] = 96→Max array length supported by parameter channel.

974[1] = 1→Numbers of multi parameters, 1 = no support of multi parameters.

974[2] = 1000→max time to process parameter request, n x 10 ms.

6.4.7 Parameter 975, read only

975 → unsigned int

975[0] = Manufacturer Id, Set in the production.

975[1] = 7011 → DO type

975[2] = 201 → Software version

975[3] = 2009 → Software year

975[4] = 2805 → Software day and month

975[5] = 0x0005 → PROFIdrive DO type class 5 = encoder interface

975[6] = 0x8000 → PROFIdrive SUB class 1, Encoder application class 4 supported.

975[7] = 0x0001 → Drive object Id (DO ID).

6.4.8 Parameter 979, read only

979 → unsigned long

979[0] = 0x00005111 → Number of index describing encoder, Numbers of described encoders, Version of parameter structure

979[1] = 0x80000000 → Sensor type

Bit 31 = 1 if configuration and parameterization is OK

Bit 0 = 0 Rotary encoder, Bit 0 = 1 linear encoder

Bit 1 = 0 always set to 0

Bit 2 = 0 → 32 bit data, Bit 2 = 1 → 64 bit data

979[2] = 8192 → Encoder scaled resolution

979[3] = 0 → Shift factor for G1_XIST1 always set to 0.

979[4] = 0 → Shift factor for G1_XIST2 always set to 0.

979[5] = 1 or 4096 → Singleturn = 1, Multiturn = 4096

979[6] = 0

979[7] = 0

979[8] = 0

979[9] = 0

979[10] = 0

6.4.9 Parameter 980, read only

This parameter shows the supported parameters

980 → unsigned int

980[0] = 922	980[9] = 61001
980[1] = 925	980[10] = 61002
980[2] = 964	980[11] = 61003
980[3] = 965	980[12] = 61004
980[4] = 971	980[13] = 65000
980[5] = 974	980[14] = 65001
980[6] = 975	980[15] = 65002
980[7] = 979	980[16] = 65003
980[8] = 61000	980[17] = 0

6.4.10 Parameter 61000, read/write

Name of station

61000 → OctetString, 240 octets

6.4.11 Parameter 61001, read only

IP of station

61001 → unsigned long

6.4.12 Parameter 61002, read only

MAC of station

61002 → OctetString, 6 octets

6.4.13 Parameter 61003, read only

Default gateway of station

61003 → unsigned long

6.4.14 Parameter 61004, read only

Subnet mask of station

61004 → unsigned long

6.4.15 Parameter 65000 read/write

Used with telegram 81-83

65000 → signed long, preset value 32 bit.

6.4.16 Parameter 65001, read only

Used with telegram 81-84

65001 → unsigned long

65001[0] = 0x000C0101 → Header, Version of parameter structure and numbers of index describing the encoder. 12 index and version 1.01

65001[1] = Operating status (Bit 4 alarm channel control is always set with profile version 4.x)

65001[2] = Alarm

65001[3] = Supported alarms

65001[4] = Warning

65001[5] = Warnings supported

65001[6] = 0x00000401 → Encoder profile version. Always set to this value.

65001[7] = Operating time

65001[8] = Offset value

65001[9] = Singleturn value, scaled value

65001[10] = Total measuring length, scaled value (Linear = 1)

65001[11] = Velocity unit

- step/10 ms
- step/100 ms
- step/1000 ms
- RPM

6.4.17 Parameter 65002, read/write

Used with telegram 84

65002 → signed long long, Preset value 64 bit.

6.4.18 Parameter 65003, read only

Used with telegram 84

65003 → unsigned long long,

65003[0] = 0x0000000000040101 → Header Version of parameter structure and numbers of index describing encoder. 4 index and version 1.01

65003[1] = Offset value 64 bit

65003[2] = Singleturn value 64 bit, scaled value

65003[3] = total measuring range in measuring units 64 bit, scaled value (Linear = 1)

6.5 Example of reading and writing to a parameter

This is an example of S7 blocks used for reading and writing to parameter 65000 (preset value). Experience with S7 programming and Statement List programming language STL is required.

Hardware components		
IO controller	SIEMENS S7-F CPU	CPU 315F-2PN/DP
IO Device	PROFINET encoder	

Table 26 Hardware components

Software components	
SIMATIC STEP 7	V5.4 + SP5
GSDML file for PROFINET encoder	GSDMLV2.2-JH-PROFINET-Encoder-xxxxxxx.xml

Table 27 Software components

6.5.1 Used blocs

Write record block SFB53 WRREC
 Read record block SFB52 RDREC
 Instance data blocks DB3 and DB4
 Request data block DB1
 Response data block DB2
 Organization blocks OB1, OB82 and OB86

SFB52

SFB52 is standard S7 block for reading parameters.

SFB53

SFB53 is standard S7 block for writing parameters.

DB1

DB1 is the request data block.

Address	Name	Type	Initial value	Comment
0.0		STRUCT		
+0.0	Request_reference_mirrored	BYTE	B#16#0	request number mirrored
+1.0	Response_ID	BYTE	B#16#0	request parameter
+2.0	DOID_mirrored	BYTE	B#16#0	Axis mirrored
+3.0	No_of_parameters	BYTE	B#16#0	response about number of parameter
+4.0	Format_parameter_1	BYTE	B#16#0	response about parameter 1 format
+5.0	No_of_values_parameter_1	BYTE	B#16#0	response about number of value of parameter 1
+6.0	parameter_number_01	DWORD	DW#16#0	Read value p65000
=10.0		END_STRUCT		

Figure 29 Request data block, DB1

DB2

DB2 is the response data block.

Address	Name	Type	Initial value	Actual value	Comment
0.0	Request_reference	BYTE	B#16#1	B#16#01	request number
1.0	Request_ID	BYTE	B#16#2	B#16#02	request parameter = 1; change parameter = 2
2.0	Axis	BYTE	B#16#0	B#16#00	Axis addressing for multi-axis drives
3.0	No_of_parameters	BYTE	B#16#1	B#16#01	write 1 parameters
4.0	Attribute_parameter_01	BYTE	B#16#10	B#16#10	write value
5.0	No_of_elements_01	BYTE	B#16#1	B#16#01	number of elements 1
6.0	parameter_number_01	WORD	W#16#FDE8	W#16#FDE8	parameter 65000 (Preset value 32)
8.0	Subindex_01	WORD	W#16#0	W#16#0000	subindex
10.0	Data_type	BYTE	B#16#4	B#16#04	data type integer 32
11.0	No_of_values	BYTE	B#16#1	B#16#01	Number of values = number of elements
12.0	Value	DINT	L#0	L#33554176	Value Of 65000

Figure 30 Response data block, DB2

DB3

DB3 is the instance data block of SFB52

DB3 -- PN_WR_RD_PRESET_LL\SIMATIC 300(1)\CPU 315F-2PN/DP						
	Address	Declaration	Name	Type	Initial value	Actual value
1	0.0	in	REQ	BOOL	FALSE	FALSE
2	2.0	in	ID	DWORD	DW#16#0	DW#16#0
3	6.0	in	INDEX	INT	0	0
4	8.0	in	MLEN	INT	0	0
5	10.0	out	VALID	BOOL	FALSE	FALSE
6	10.1	out	BUSY	BOOL	FALSE	FALSE
7	10.2	out	ERROR	BOOL	FALSE	FALSE
8	12.0	out	STATUS	DWORD	DW#16#0	DW#16#0
9	16.0	out	LEN	INT	0	0
10	18.0	in_out	RECORD	ANY	P#P 0.0 VOID 0	P#P 0.0 VOID 0

Figure 31 Instance data block, DB3

DB4

DB4 is the instance data block of SFB53

DB4 -- PN_WR_RD_PRESET_LL\SIMATIC 300(1)\CPU 315F-2PN/DP						
	Address	Declaration	Name	Type	Initial value	Actual value
1	0.0	in	REQ	BOOL	FALSE	FALSE
2	2.0	in	ID	DWORD	DW#16#0	DW#16#0
3	6.0	in	INDEX	INT	0	0
4	8.0	in	LEN	INT	0	0
5	10.0	out	DONE	BOOL	FALSE	FALSE
6	10.1	out	BUSY	BOOL	FALSE	FALSE
7	10.2	out	ERROR	BOOL	FALSE	FALSE
8	12.0	out	STATUS	DWORD	DW#16#0	DW#16#0
9	16.0	in_out	RECORD	ANY	P#P 0.0 VOID 0	P#P 0.0 VOID 0

Figure 32 Instance data block, DB

OB1

OB1 controls the read and write operation.

```

OB1 : "Main Program Sweep (Cycle)"

```

In network 1 and network 2 the user will see how to generate the request / response DB for writing/reading p65000 using S7 standard function blocks SFB53/53 easy handled by the VAT_1 variable table.

```

Network 1 : Write request

```

With the SFB53 "WRREC" (write record) you transfer a data record with the number INDEX to a DP slave device component defined by ID.

```

A      M      8.4
AN     M      8.1
AN     M      8.3
AN     M      8.2
S      M      8.0
L      W#16#B02E
T      #INDEX

CALL  "WRREC" , "InstanceDB_SFB53"    SFB53 / DB4      -- Write a Process Data Record
REQ   :=MS.0
ID    :=DW#16#7F7
INDEX :=#INDEX
LEN   :=16
DONE  :=M14.0
BUSY  :=MS.1
ERROR :=M14.2
STATUS:=MD10
RECORD:=P#DB1.DEX0.0 BYTE 16

A      M      8.1
R      M      8.0

```

```

Network 2 : Read request

```

With the SFB52 "RDREC" (read record) you read a data record with the number INDEX from a component.

```

A      M      8.4
AN     M      8.1
AN     M      8.3
AN     M      8.0
S      M      8.2

CALL  "RDREC" , "InstanceDB_SFB52"    SFB52 / DB3      -- Read a Process Data Record
REQ   :=MS.2
ID    :=DW#16#7F7
INDEX :=#INDEX
MLEN  :=10
VALID :=M16.0
BUSY  :=MS.3
ERROR :=M16.2
STATUS:=MD18
LEN   :=MW22
RECORD:=P#DB2.DEX0.0 BYTE 10

A      M      8.3
R      M      8.2

```

Figure 33 Organization block, OB1

Parameters of SFB52

Parameter	Declaration	Data type	Description
REQ	INPUT	BOOL	REQ=1 Enables data transfer
ID	INPUT	DWORD	Logical address of the PROFINET IO module or sub module (PAP-module address 2039)
INDEX*	INPUT	INT	Record number
MLEN*	INPUT	INT	Maximum length of the record information in bytes
VALID	OUTPUT	BOOL	New record has been received and is valid.
BUSY	OUTPUT	BOOL	Busy=1 during the read operation
ERROR	OUTPUT	BOOL	Error=1 read error
STATUS	OUTPUT	DWORD	Block status or error code
LEN*	OUTPUT	INT	Length of record information
RECORD	IN_OUT	ANY	Target area for the record

Table 28 Parameters of SFB52

*) Negative values are interpreted as 16-bit unsigned integers.

Parameters of SFB53

Parameter	Declaration	Data type	Description
REQ	INPUT	BOOL	REQ=1 Enables data transfer
ID	INPUT	DWORD	Logical address of the PROFINET IO module or sub module (PAP-module address 2039)
INDEX*	INPUT	INT	Record number
LEN*	INPUT	INT	Length of the record information in bytes
DONE	OUTPUT	BOOL	Data record was transferred
BUSY	OUTPUT	BOOL	Busy=1 during the write operation
ERROR	OUTPUT	BOOL	Error=1 write error
STATUS	OUTPUT	DWORD	Block status or error code
RECORD	IN_OUT	ANY	Data record

Table 29 Parameters of SFB53

*) Negative values are interpreted as 16-bit unsigned integers.

Diagnostic address of slot 1




Figure 34 Diagnostic address of slot 1

Variable table

With the variable table the user can monitor and modify variables.

Address	Symbol	Symbol comment	Display format	Status value	Modify value	
1	// Enable parameter write/read 1=enabled					
2	M 8.4		BOOL	false		
3						
4	// The flag M8.1 shows if writing is not yet completed (BUSY = 1: The write process is not yet terminated)					
5	M 8.1		BOOL	false		
6	// ERROR = 1: A write error has occurred					
7	M 14.2		BOOL	false		
8	// Write block status or error information					
9	MD 10		HEX	DW#16#00700000		
10						
11	// The flag M8.3 shows if reading is not yet completed (BUSY = 1: The read process is not yet terminated)					
12	M 8.3		BOOL	false		
13	// ERROR = 1: A read error has occurred					
14	M 16.2		BOOL	false		
15	// Read block status or error information					
16	MD 18		HEX	DW#16#00700000		
17						
18	// Position and control/status words					
19	PW 2		HEX	VW#16#0000		
20	PQW 2		HEX	VW#16#1000	W#16#1000	
21	PW 1		HEX	VW#16#0000		
22	PQW 1		HEX	VW#16#0400	W#16#0400	
23						
24	PID 4		HEX	DW#16#0001877E		
25	PID 8		HEX	DW#16#0001877E		
26						
27						
28						
29	// Write parameters:					
30	DB1.DBB 1	"Request_DB".Request_ID	request parameter = 1; change parameter = 2	HEX	B#16#02	
31	DB1.DBD 12	"Request_DB".Value	Write value 65000	HEX	DW#16#12345678	DW#16#12345678
32	DB2.DBD 6	"Respons_DB".parameter_number_01	Read value p65000	HEX	DW#16#00000000	
33						

Figure 35 Variable table

7 Functional description of the encoder

This chapter describes the functions that have been implemented in PROFINET encoders from HEIDENHAIN. The table below shows the supported functions in the PROFINET encoder.

Function
Code sequence
Class 4 functionality
G1_XIST1 Preset control
Scaling function control
Alarm channel control
Compatibility mode
Preset value
Preset value 64 bit
Measuring units per revolution/Measuring step
Total measuring range
Measuring units per revolution 64 bit
Total measuring range 64 bit
Maximum Master Sign of Life failures
Velocity measuring unit
Encoder Profile version
Operating time
Offset value
Offset value 64 bit

Table 30 Supported encoder functions

7.1 Code sequence

The code sequence defines whether the absolute position value should increase during clockwise or counter clockwise rotation of the encoder shaft seen from flange side. The code sequence is by default set to increase the absolute position value when the shaft is turned clockwise (0).

Attribute	Meaning	Value
CW	Increasing position values with clockwise rotation (seen from shaft side)	0
CCW	Increasing position values with counter clockwise rotation (seen from shaft side)	1

Table 31 Code sequence

Note: The position value will be affected when the code sequence is changed during operation. It might be necessary to perform a preset after the code sequence has been changed.

7.2 Class 4 functionality

This parameter enables or disables the measuring task functions Scaling, Preset and Code sequence. If the function is enabled, scaling and Code sequence control affects the position value in G1_XIST1, G1_XIST2 and G1_XIST3. A preset will in this case always affect G1_XIST2 and G1_XIST3 but if the parameter G1_XIST1 Preset control is disabled the preset will not affect the position value in G1_XIST1.

Attribute	Meaning	Value
Enable	Scaling/preset/code sequence control enabled	1
Disable	Scaling/preset/code sequence control disabled	0

Table 32 Class 4 functionality

7.3 G1_XIST1 Preset control

This parameter controls the effect of a preset on the G1_XIST1 actual value.
If Class 4 functionality is activated and G1_XIST1 Preset control is disabled, the position value in G1_XIST1 will not be affected by a Preset.

Attribute	Meaning	Value
Enable	G1_XIST1 is affected by a preset command	0
Disable	Preset does not affect G1_XIST1	1

Table 33 G1_XIST1 Preset control

Note: This parameter is disabled by setting the value to 1.

Note: There is no functionality of this parameter if the Class 4 functionality parameter is disabled.

7.4 Scaling function control

This parameter enables or disables the Scaling function of the encoder.

Attribute	Meaning	Value
Enable	Scaling function is enabled	1
Disable	Scaling function is disabled	0

Table 34 Scaling function control

Note: The parameter Class 4 functionality must be enabled to use this parameter.

7.5 Alarm channel control

This parameter enables or disables the encoder specific Alarm channel transferred as Channel Related Diagnosis. This functionality is used to limit the amount of data sent in isochronous mode.

If the value is zero (default value) only the communication related alarms are sent via the alarm channel. If the value is one (1) also encoder profile specific faults and warnings are sent via the alarm channel.

Attribute	Meaning	Value
Enable	Profile specific diagnosis is switch on	1
Disable	No profile specific diagnosis (default)	0

Table 35 Alarm channel control

Note: This parameter is only supported in compatibility mode.

7.6 Compatibility mode

This parameter defines if the encoder should run in a mode compatible to Version 3.1 of the Encoder Profile. See below for an overview of functions affected when the compatibility mode is enabled.

Attribute	Meaning	Value
Enable	Compatibility with encoder Profile V3.1	0
Disable	No backward compatibility (default)	1

Table 36 Compatibility mode

Function	Compatibility mode enabled (=0)	Compatibility mode disabled (=1)
Control by PLC (STW2_ENC)	Ignored, the control word (G1_STW) and the set point values are always valid. Control requested (ZSW2_ENC) is not supported and is set to 0.	Supported
User parameter Maximum Master Sign of Life failures	Supported	Not supported, one Sign of Life failure tolerated, PROFIdrive P925 is optional to control the life sign monitoring.
User parameter Alarm channel control	Supported	Not supported, the application alarm channel is active and controlled by a PROFIdrive parameter.
P965 Profile Version	31 (V3.1)	41 (V4.1)

Table 37 Compatibility mode overview

7.7 Preset value

The preset value function enables adaptation of the position value from the encoder to a known mechanical reference point of the system. The preset function sets the actual position of the encoder to zero (= default value) or to the selected preset value. The preset function is controlled by bits in the control word (G1_STW) and acknowledged by a bit in the status word (G1_ZSW). A preset value can be set more than once and it can be stored to the non-volatile memory using PROFIdrive parameter 971.

The preset function has an absolute and a relative operating mode selectable by bit 11 in the Control word (G1_STW). Bit 11 and bit 12 in the Control word controls the preset in the following way.

Normal operating mode: Bit 12 = 0

In this mode, the encoder will make no change in the output value.

Preset mode absolute: Bit 11 =0, Bit 12 = 1

In this mode, the encoder reads the current position value and calculates an internal offset value from the preset value and the current position value. The position value is then shifted with the calculated offset value to get a position value equal to the preset value. No preset will be made if a negative preset value is used while trying to initiate an absolute preset.

Preset mode relative: Bit 11 =1, Bit 12 = 1

In this mode the position value is shifted by the preset value, which could be a negative or a positive value set by encoder parameter 65000 or 65002.

The steps below should be followed by the IO-controller when modifying the Preset value parameters:

1. Read the requested Preset value parameter and check if the returned value meets the application requirements. If not, proceed with the following steps.
2. Write the Preset value into the individual parameter.
3. Store the value in the non-volatile memory by PROFIdrive parameter 971 if the value should be valid also after the next power on sequence.

Note: The preset function should only be used at encoder standstill.

Note: The number of possible preset cycles is unlimited.

Note: If scaling is used the preset function shall be used after the scaling function to ensure that the preset value is entered in the current measuring unit.

Note: There is no preset activated when the preset value is written to the encoder. The preset function is controlled by bits in the control and status words (G1_STW and G1_ZSW) and bit in the operating parameters. The preset value is used when a preset is requested by bit 12 in the control word (G1_STW).

7.8 Scaling function parameters

The scaling function converts the encoder’s physical absolute position value by means of software in order to change the resolution of the encoder. The scaling parameters will only be activated if the parameter Class 4 functionality and Scaling function control are enabled. The permissible value range for the scaling is limited by the resolution of the encoder. The scaling parameters are securely stored in the IO controller and are reloaded into the encoder at each power-up.

7.8.1 Measuring units per revolution

This parameter sets the single turn resolution of the encoder. In other words it is the number of different measuring steps during one revolution of the encoder.

Example:

For a 13-bit encoder with a single turn resolution of 13 bits the permissible value range for "Measuring units per revolution" is between 2^0 and 2^{13} (8192).

Parameter	Meaning	Data type
Measuring units per revolution	The single turn resolution in measuring steps	Unsigned 32
Measuring units per revolution 64 bit	The single turn resolution in measuring steps for encoders with a resolution exceeding 32 bits.	Unsigned 64

Table 38 Measuring units per revolution

Note: After downloading new scaling parameters, the preset function must be used to set the encoder starting point to absolute position 0 or to any required starting position within the scaled operating range.

7.8.2 Total measuring range

This parameter sets the total measuring range of the encoder. The total measuring range is calculated by multiplying the single turn resolution with the number of distinguishable revolutions.

Example:

The total measuring range for a 25 bit multi turn encoder with a 13 bit single turn and a 12 bit multi turn resolution is between 2^0 and 2^{25} (33 554 432).

The total measuring range is calculated as below:

$$\begin{aligned} & \text{Measuring units per revolution} \times \text{Total measuring range} \\ &= 8192 (2^{13}) \times 4096 (2^{12}) \\ &= 33554432 \end{aligned}$$

If the total measuring range is higher than 31 bit, telegram 84 and acyclic encoder parameter 65002 and 65003 must be used. In this case the 64 bit values are used and the 32 bit values are set to zero (0) by the encoder.

The device has two different operating modes, depending on the specified measuring range. When the device receives a parameter message, it checks the scaling parameters if a binary scaling can be used. If binary scaling can be used, the device selects operating mode A (see following explanation). If not, operating mode B is selected.

A. Cyclic operation (binary scaling)

Cyclic operation is used when operating with 2^x number of turns (2, 4, 8, 16, 32, 64, 128, 256, 512, 1024, 2048, 4096... number of turns). If the desired total measuring range is equal to the specified single turn resolution * 2^x (where $x \leq 12$) the encoder operates in endless cyclic operation (0 - max - 0 - max). If the position value increases above the maximum value by rotating the encoder shaft, the encoder continues from 0.

Example of a cyclic scaling:

Measuring units per revolution = 1 000
Total measuring range = 32 000
(2^5 = number of revolutions 32)




Figure 36 Cyclic operation

B. Non-cyclic operation

If the desired total measuring range is **not** equal to the specified single turn resolution * 2^x (where $x \leq 12$) the encoder operates in non-cyclic operation. The non-cyclic operation is affected by the parameter G1_XIST1 Preset control as described below.

G1_XIST1 Preset control = Enabled

If the position value increases or decreases outside the maximum value or below 0 with the parameter G1_XIST1 Preset control **enabled**, the device outputs the maximum position value within the scaled total range for both position values G1_XIST1 and G1_XIST2.

Example of non-cyclic scaling with G1_XIST1 Preset control enabled:

Measuring units per revolution = 100
 Total measuring range = 5000
 (number of revolutions 50)




Figure 37 Non cyclic operation, preset control enabled

G1_XIST1 Preset control = Disabled

With the parameter G1_XIST1 **disabled**, and if the position value increases or decreases outside the maximum value or below 0, the device will output the maximum position value within the scaled total range for the position value G1_XIST2. The position value G1_XIST1 is not limited to the scaled total range. For the position value G1_XIST1, the device will continue to output a scaled position value within the encoder's total measuring range (up to 33554432 positions for a 25 bit encoder).

Example of non-cyclic scaling with G1_XIST1 Preset control disabled:

Measuring units per revolution = 100
Total measuring range = 5000
(number of revolutions 50)





Figure 38 Non cyclic operation, preset control disabled

Handling 64 bit data

Siemens hardware configuration tool does not support 64 bit data type, so when writing larger numbers than 32 bit into the configuration tool, this needs to be done according to below:

Example:

Total measuring range in measuring units = 2^{36}



Take the 4 least significant bytes above and convert to decimal:
 →0x00 00 00 00 = **0** = Total measuring range LSB

Then take the 4 most significant bytes above and convert to decimal:
 →0x00 00 00 10 = **16** = Total measuring range MSB

In the configuration software enter the decimal values:
 Total measuring range LSB = **0**
 Total measuring range MSB = **16**

7.9 Maximum Master Sign-of-Life failures

With this parameter the number of allowed failures of the master’s sign of life is defined. The default value is one (1).

Parameter	Meaning	Value
Maximum Master Sign-of-Life failures	The number of permissible failures of the masters life sign.	1...255

Table 39 Maximum master Sign of life failures

Note: This parameter is only supported in compatibility mode.

7.10 Velocity measuring units

This parameter defines the coding of the velocity measuring units used to configure the signals NIST_A and NIST_B. Standard telegram 81 has no velocity information included and the encoder does not use the velocity unit information in this case. Telegram 82, 83 and 84 includes velocity output and needs a declaration of the velocity measuring unit.

Parameter	Meaning	Value
Velocity measuring units	Definition of the units for the encoder velocity output value	See below
Velocity measuring units		Value
Steps/s		0
Steps/100ms		1
Steps/10ms		2
RPM		3

Table 40 Velocity measuring units

The velocity calculations are made with a maximum of 19 bits resolution. If the resolution is higher than 2^{19} , the value used for velocity calculations is automatically reduced to 2^{19} .

Example:

For a 37 bit multi turn encoder with a 2^{25} single turn resolution and a 2^{12} multi turn resolution, the maximum single turn value for velocity calculations will be 219. For a single turn encoder the maximum resolution can be up to 31 bit, but the value used for velocity calculations will in this case also be 2^{19} .

Note: In case of the steps/s unit, an average is made over 200 ms and the value is multiplied by 5.

Note: If scaling has been set on the device the velocity calculation is based on the scaled position value. Consequently the accuracy of the velocity value is dependent of the scaling set to the device.

7.11 Encoder profile version

The encoder Profile Version is the version of the encoder profile document implemented in the encoder. This parameter is not affected by the Compatibility mode settings.

Bits	Meaning
0..7	Profile Version, least significant number, (value range: 0-99), decimal coding
8..15	Profile Version, most significant number, (value range: 0-99), decimal coding
16..31	Reserved

Table 41 Encoder profile

7.12 Operating time

The operating time monitor stores the operating time for the device in operating hours. The operating time is saved every six minutes in the non-volatile memory in the device. This happens as long as the device is powered on.

If the operating time function is not used the operating time value is set to the maximum value (0xFFFF FFFF).

Parameter	Meaning	Data type
Operating time	The accumulated power on time	Unsigned 32

Table 42 Operating time

7.13 Offset value

The offset value is calculated in the preset function and shifts the position value with the calculated value. The offset value is stored in a non volatile memory and can be read from the encoder at any time. The data type for the offset value is a 32 bit or 64 bit binary value with sign, whereby the offset value range is equal to the measuring range of the device.

The preset function is used after the scaling function. This means that the offset value is indicated according to the scaled resolution of the device.

Parameter	Meaning	Data type
Offset value	The offset value for encoders with a measuring range of maximum 32 bits	Integer 32
Offset value 64 bit	The offset value for encoders with a measuring range exceeding 32 bits	Integer 64

Table 43 Offset value

Note: The offset value is read only and cannot be modified by a parameter write access.

7.14 Acyclic data

The PROFINET encoder support the following acyclic data exchange functions.

7.14.1 PROFIdrive parameters

The encoder profile V4.1 (PNO no. 3.162) has adopted certain standard PROFIdrive parameter. The following PROFIdrive parameters are supported:

PNU (Prm.no)	Significance	Data type	Read/Write
922	Telegram selection	Unsigned 16	R
925	Number of Controller Sign-of-Life failures which may be tolerated.	Unsigned 16	R/W
964	Device identification	Array[n] Unsigned 16	R
965	Encoder Profile number	Octet string 2	R
971	Transfer to non volatile memory	Unsigned 16	W
974	Base Mode Parameter Access service identification	Array[n] Unsigned 16	R
975	Encoder object identification	Array[n] Unsigned 16	R
979	Sensor format	Array[n] Unsigned 32	R
980	List of supported parameters	Array[n] Unsigned 16	R

Table 44 Supported PROFIdrive parameters

Functional description of the encoder

7.14.2 Encoder parameter numbers

The table below specifies the encoder specific parameter that is supported.

PNU (Pm.no)	Significance	Data type	Read/Write
61000	Name of station	Octet String [240]	R
61001	IP of station	Unsigned 32	R
61002	MAC of station	Octet String[6]	R
61003	Default gateway of station	Unsigned 32	R
61004	Subnet Mask Of Station	Unsigned 32	R
65000	Preset value	Integer 32	R/W
65001	Operating status	Array [n] Integer 32	R
65002	Preset value 64 bit	Integer 64	R/W
65003	Operating status 64 bit	Array [n] Integer 64	R

Table 45 Encoder parameter numbers

7.14.3 Parameter 65000 and 65002- Preset value

The parameter 65000 and 65002 sets the value for the preset function. The parameter 65002 should be used if the preset value exceeds 32 bits.

PNU	65000
Significance	Preset value
Data type	Integer 32
Access	Read and write
Validity range	Profile specific
Explanation	The preset value sets the value for the preset function. The preset value can be stored in the non volatile memory by PROFIdrive parameter 971 and will be reloaded at each start up if stored.

Table 46 Parameter 65000, Preset value

PNU	65002
Significance	Preset value
Data type	Integer 64
Access	Read and write
Validity range	Profile specific
Explanation	The preset value sets the value for the preset function. The preset value can be stored in the non volatile memory by PROFIdrive parameter 971 and will be reloaded at each start up if stored.

Table 47 Parameter 65002, Preset value 64 bit

7.14.4 Parameter 65001-Operating status

This parameter structure is a read only structure where information on the Encoder operating status can be found. It is a complement to the PROFIdrive parameter 979 described in the Profile for Drive Technology, PROFIdrive V4.1, Order nr 3.172 available from PROFIBUS and PROFINET International.

PNU	65001
Significance	Encoder Operating Status
Data type	Array[n] Integer 32
Access	Read
Validity range	Profile specific
Explanation	The operating status displays the status of the encoder.

Table 48 Parameter 65001, Operating status

Sub index	Meaning
0	Header
1	Operating status
2	Faults
3	Supported Faults
4	Warnings
5	Supported warnings
6	Encoder Profile version
7	Operating time
8	Offset value
9	Measuring units per revolution
10	Total measuring range in measuring units
11	Velocity measuring unit

Table 49 Parameter 65001, Sub index

Sub index 1: Operating status

In sub index 1 the status of different encoder functions can be read out. The mapping of the respective functions is according to the table below.

Bits	Definition
0	Code sequence
1	Class 4 functionality
2	G1_XIST1 Preset control
3	Scaling function control
4	Alarm channel control
5	Compatibility mode
6...7	Reserved for the Encoder manufacturer
8..31	Reserved for future use

Table 50 Parameter 65001, Sub index 1

7.14.5 Parameter 65003- operating status 64 bit

The parameter structure 65003 is a read only structure where information on the 64 bit parameter values can be found.

PNU	65003
Significance	Encoder Operating Status 64 bit
Data type	Array[n] Integer 64
Access	Read
Validity range	Profile specific
Explanation	The status of encoder operating parameters with 64 bit length.

Table 51 Parameter 65003, Operating status 64 bit

Sub index	Meaning
0	Header
1	Offset value 64 bit
2	Measuring units per revolution 64 bit
3	Total measuring range in measuring units 64 bit

Table 52 Parameter 65003, Sub index

7.14.6 Identification & Maintenance functions

In addition to the PROFIdrive parameter 964, Device Identification, I&M functions are supported by the encoder. The I&M functions can be accessed with record index 0xAFF0-0xAFF4. The following I&M functions are supported.

I&M Parameter	Octets	Comment
Header		
Manufacturer specific	10	Not used
I&M Block		
MANUFACTURER_ID	2	Manufacturer Id
ORDER_ID	20	Encoder part number
SERIAL_NUMBER	16	Encoder serial number
HARDWARE_REVISION	2	Not used
SOFTWARE_REVISION	4	Software revision
REVISION_COUNTER	2	Not used
PROFILE_ID	2	Encoder Profile number
PROFILE_SPECIFIC_TYPE	2	Type of encoder,
IM_VERSION	2	Version of the I&M profile
IM_SUPPORTED	2	Value = 0 means support of I&M

Table 53 Identification & Maintenance

8 Firmware upgrade

The encoder supports a firmware upgrade function. The firmware upgrade function is developed to offer the possibility to upgrade the encoders in the future.

Before the upgrade of the encoder can start, the following tools are needed:

- A running TFTP server
- A WEB browser (Internet Explorer, Firefox, Opera etc.)
- DHCP server
(This is only needed if performing an upgrade outside a PROFINET network)

The encoder itself puts no restrictions on what TFTP/DHCP server to use. The customer can choose to use any TFTP/DHCP servers.

There are two different scenarios for software upgrade:

- Firmware upgrade in a PROFINET network.
- This is when the encoder is connected to a PROFINET network. The encoder will be provided with an IP address from the PROFINET IO controller (with DCP).
- Stand alone upgrade.
This is when the encoder is outside a PROFINET network. A DHCP server is required in order to provide the encoder with a valid IP address. This scenario might be valid if the encoder is a spare part or an encoder is picked out of a system for maintenance. There is currently no support for bulk upgrade. I.e. each encoder must be accessed and upgraded in turn.

8.1 Firmware upgrade in a PROFINET network

The following prerequisites have to be fulfilled in order to upgrade the encoder in a PROFINET network:

- The encoder should be attached to the network.
- The encoder must have a valid Device name and a valid IP address (assigned with DCP).
- A TFTP server should be enabled on the LAN where the encoder is attached. See chapter 8.4 for an example how to set up a TFTP server.

Once the encoder has been assign a valid IP address it should be accessible on the network. Enter the encoders IP address in the WEB browser to open the Firmware upgrade page.




Figure 39 Firmware upgrade startpage

When accessing the encoder with the web browser it will display a number of parameters. In the firmware upgrade section of the page, enter the following information:

- Server IP address - Enter the IP address to the TFTP server on the LAN
- Firmware filename - Enter the full file name of the new firmware file supplied by the TFTP server
- Date - Enter the current date for the upgrade. This is stored as part of the Upgrade History. The format is yyyy-mm-dd. E.g. 2010-11-15.

CONNECTION STATUS

Parameter	Value	Description
Connection Mode	Active RT	Real Time Mode
Execution State	Data Exchange	Encoder is running

ENCODER STATUS

Parameter	Value	Description
Encoder Type	1	Multiturn Encoder
Faults	0	No active faults
Warnings	0	No active warnings
Operating Time	15460	Hours x 0,1
Measuring Units Per Revolution	8192	Singleturn Resolution
Total Measuring Range In Measuring Units	33554432	Total Resolution
Encoder Velocity	0	Steps/s

FIRMWARE UPGRADE

UPGRADE HISTORY

Upgrades (Total)	Last Upgrade	Active Firmware
255	<input type="text"/>	

Set the IP address to the server, name of the firmware file as presented on the server and today's date. Click 'Submit Values' to store the values and 'Upgrade' to begin the upgrade.

Enter Server IP Address:

Enter Firmware Filename:

Enter Date (yyyy-mm-dd):

Figure 40 Firmware upgrade settings

The parameters are set by clicking the Submit Values button. After clicking the Submit Values button, update the page in the web browser. To start the upgrade, click on the Upgrade button.

A confirmation page is displayed where the upgrade has to be confirmed before the device starts the actual firmware upgrade process. The Continue button needs to be clicked in order to start the upgrade sequence.




Figure 41 Firmware upgrade confirmation page

During upgrade a progress page is displayed. Depending upon the choice of web browser, the auto generated progress page will take some time to be displayed. However, the progress web page should always be displayed when the upgrade is finished. If no errors occur during upgrade the encoder will automatically reboot itself and connect to the PROFINET IO-controller with the new firmware.




Figure 42 Firmware upgrade status page

During the upgrade, both the bus status LED and the device status LED will be flashing green. If an error occurs both LEDs will be flashing red.

If the upgrade fails check the error code displayed on the progress page. The error codes are described in chapter 8.3.

8.2 Stand alone upgrade

In order to start the stand alone upgrade the following prerequisites has to be fulfilled:

- The encoder should be attached to a LAN network
- There should be a DHCP enabled server on the LAN where the encoder is attached.
- A TFTP server should be enabled on the LAN where the encoder is attached.

The encoder firmware contains a DHCP client for IP assignment outside a PROFINET network. If no IP address is assigned by a DCP/PROFINET IO controller, the encoder will try to retrieve an IP address with DHCP.

First start the DHCP and TFTP servers and then power up the encoder. After approximately 20-30 seconds the encoder should have received a valid IP address. When the encoder has received a valid IP address, continue with the same upgrade procedure as described in chapter 8.1 Firmware upgrade in a PROFINET network.

It is possible to disable/enable the DHCP client in the encoder. Use the DHCP Enable/Disable button on the startup web page in order to toggle between the two modes. The encoder will keep this state until the user manually switches state again.

NETWORK PARAMETERS	
Parameter	Value
Device IP	192.168.0.3
Device Subnetmask	255.255.255.0
Device MAC	00:a0:cd:00:00:00
Default Gateway	192.168.0.255
DHCP Client	Disabled

DHCP Enable/Disable

Figure 43 Network parameters

Any TFTP server can be used to retrieve file image and any DHCP server can be used to assign IP addresses. Supplied in this manual is a description on how to install SolarWinds TFTP server (chapter 8.4) and Tiny DHCP (chapter 8.5) from SoftCab on a desktop PC.

8.3 Error handling

This chapter will list all the possible error codes that can occur during an upgrade error. The error code will be visible on the feedback webpage. If an error occurs the device will **not reboot** itself automatically. Instead it will wait upon user action. This is to allow the user to take the next step. E.g. the user might want to check some parameters before rebooting or try to run the upgrade procedure again.

Failed to download firmware file from server

Error code: -2

The user should verify the IP address and the image filename. If any of them is incorrect the user should go back and submit the correct parameters at the main html page (index.html). If the parameters are correct the user should verify that the TFTP server is running on the host computer and that the TFTP server settings are correct.

Host not responding/No contact with host computer

Error code: -3

The user should verify that the host computer is connected to the encoder. The ping command can be used for this purpose. If connected, go back to upgrade.html and click Confirm to try and upgrade again.

Checksum Error/File image error

Error code: -4

Calculated checksum doesn't match the one supplied by the image file. The most likely cause for this problem is that there was an error when downloading the file to the encoder. Go back to upgrade.html and press Confirm and try again.

Flash Erase/Write Error

Error code: -5

The image might be corrupt. Flash Erase or Write failed. If this error occurs the device can still start with its failsafe image. It will be displayed by the Execution State parameter on the web Page.

File Size Error

Error Code: -6

The firmware file is too big to be written to flash.

Insufficient Memory

Error Code: -7

There is not enough memory available to store the firmware file image.

Invalid Firmware File

Error Code: -8

Firmware file is not supported for this hardware.

8.4 TFTP server installation

The TFTP server used in this example is a freeware TFTP server for Windows NT/XP/Vista platforms and it can be downloaded from www.solarwinds.com.

Unzip the installation file and double click on the SolarWinds-TFTP-Server.exe file to start the installation. Follow the instructions on the screen to complete the installation.

Create a folder on C:\ named TFTP_Root (if it not already exists). Copy or Move the new firmware file used to the C:\TFTP_Root directory.

Start the SolarWinds TFTP server and click on the File->Configure tab to open up the Configure window.




Figure 44 SolarWinds TFTP server

In the Configure window:

- Make sure that the correct network interface is selected in the Used NIC selection menu. I.e. it is the network interface which is connected to the encoder network.
- Set up the path to the TFTP root directory. I.e. the TFTP-Root directory created under C:\.
- Leave the other parameters with their default values.
- Click Start to start the TFTP server service in Windows.




Figure 45 SolarWinds TFTP server settings

Note: The server will listen to port 69. Verify that there is no firewall blocking the port for incoming/outgoing requests. Disable any firewall temporarily if communication problems occur.

8.5 DHCP server installation

The DHCP server used in this example is a freeware DHCP server for Windows NT/XP/Vista platforms and can be downloaded from www.softcab.com.

Note: Before starting the installation, disconnect the PC (where the DHCP server is to be installed) from the office network. It can be connected to the network again when the server is configured.

Once the DHCP server has been downloaded, double click on the dhcp.exe file to start the installation and follow the instructions on the screen.

After installation, start the Tiny DHCP server program.




Figure 46 Tiny DHCP Server

The Unknown physical address is predefined. Select Drop incoming requests silently for unknown interfaces.

Select Add new and enter the MAC address of the device you attend to supply with an IP address. The MAC address for the encoder is written on the encoder label.




Figure 47 Tiny DHCP server settings




Figure 48 Tiny DHCP server settings

Provide the appropriate settings for the target device. It is important to make sure that the IP address of the encoder is on the same network as the desktop PC. The first three bytes of the IP address needs to be the same on the PC and the encoder.

If for example the PC have an IP address of 192.168.0.1 and subnet mask 255.255.255.0 the IP address of the encoder can be set to 192.168.0.2 and subnet 255.255.255.0. Once the above configuration is made the PC can be connected to the office network again if necessary.

8.6 Local Area Network (LAN) configuration

The picture shows a typical setup in order to upgrade the encoder.




Figure 49 LAN- configuration

Consider the connection between the desktop PC and the encoder. The encoder and the desktop PC both have to be on the same logical LAN.

In order to set the IP address of the desktop PC (windows). Go to the Control Panel and select Network Connection. Right click on the network interface connected to the local LAN. Then open the properties for the Internet Protocol (TCP/IP).




Figure 50 LAN properties

Set the appropriate IP address and Subnet mask for the interface according to the example below.




Figure 51 TCP/IP settings

Use Tiny DHCP server to provide the encoder with a valid IP address.

Note: It is recommended to keep the desktop PC disconnected from the office network to avoid issues with the office network.

9 Encoder replacement using LLDP

The encoder supports Link Layer Discovery Protocol (LLDP). LLDP is essentially a neighbor discovery protocol used by network devices for advertising of their identity, capabilities and inter-connections.

In a PROFINET network all IO devices are recognized by their device name. Sometimes an IO device needs to be replaced in an automation system, and this is when LLDP is useful. Using LLDP, the neighbor relations between the individual IO device and the IO controller are analyzed and stored on the IO controller. If an IO device has been replaced, the IO controller will recognize this and will redefine the device name.⁸

Follow the instruction below to exchange an IO device using LLDP:

Select properties of the PN-IO controllers interface module and enable Support device replacement without exchangeable medium.




Figure 52 LLDP Properties

Configure the topology of the system for all connected ports.

The screenshot shows the HW Config interface for a SIMATIC 300(1) system. The rack configuration on the left lists modules in slots 1 through 10. Slot 2 contains a CPU 315F-2PN/DP with MPI/DP, PN-IO, and two ports (Port 1 and Port 2). The main diagram shows an Ethernet(1) PROFINET-IO-System (100) connected to three profinete encoders labeled (1), (2), and (3). Below the diagram is a table for the profinete encoder2 module.


Slot	Module	Order number	I Address	Q address	Diagnostic address	Comment
0	profineteencoder2				2036*	
X7	Interface				2038*	
F7	Port 1				2039*	
F8	Port 2				2036*	
T	EO Multiturn				2035*	
1.1	Parameter Access Point				2035*	
1.2	Standard Telegram 81		24..35	8..11		

Slot is occupied, module is too wide, or the functionality of the inserted module is not transferable to the new module.

Figure 53 LLDP Port configuration

Encoder replacement using LLDP

In the properties window, select the corresponding partner port.



Slot is occupied, module is too wide, or the functionality of the inserted module is not transferable to the new module.

Figure 54 LLDP Partner port settings

Then select Edit-> PROFINET IO->Topology to open the topology editor.




Figure 55 Open Topology editor




Figure 56 Topology editor

Verify that the offline topology matches the online topology.

Encoder replacement using LLDP

After the above has been verified it is possible to replace any IO device if the ports are reconnected in the same way and the new device is set to factory reset.

To manually do a factory set of the encoder, follow the steps below:

Select PLC-> Ethernet-> Edit Ethernet Node.





Figure 57 Edit Ethernet node


Enter the encoder's MAC-address and then click on the Reset button. The MAC-address of the encoder is written on the encoder label.



The screenshot shows the 'Edit Ethernet Node' configuration window. The 'Ethernet node' section has a 'MAC address' field containing '00-A0-CD-00-00-00', which is highlighted with a red box. Below this is the 'Set IP configuration' section with options for 'Use IP parameters' (selected), 'Obtain IP address from a DHCP server', and 'Identified by' (Client ID, MAC address, Device name). The 'Reset to factory settings' section at the bottom has a 'Reset' button highlighted with a red box. Other buttons include 'Close' and 'Help'.

Figure 58 Factory reset

Click yes in the confirmation window to reset the encoder to its factory settings.



The screenshot shows a confirmation dialog box titled 'Edit Ethernet Node (4502:827)'. It features a yellow warning triangle icon and the text: 'Do you really want to reset the module to its factory settings? The module then only reacts over the LAN to the factory set MAC address.' At the bottom, there are two buttons: 'Yes' and 'No'. The 'Yes' button is highlighted with a red box.

Figure 59 Factory set confirmation

10 Encoder state machine




Figure 60 Encoder state machine

10.1 Normal operation state

10.1.1 Profile version 4.x

If using encoder complying with encoder profile v4.1, then bit 10 Control by PLC in Control word 2 needs to be set before the data in Control word is valid. If not set, Control word is not used by the encoder firmware.

10.1.2 Profile version 3.x

If using encoders complying with encoder profile 3.x, the data in Control word is always valid and bit 9 Control requested in Status word 2 is always cleared.

10.1.3 Profile version 3.x and 4.x

When using telegram 81-83 and Control word bit 13 Request absolute value cyclically is set, then Status word bit 13 Transmit absolute value cyclically is set. Status word bit 13 is cleared (bit 13=0) when Control word bit 13 is cleared. Status word bit 13 is always cleared, when using telegram 84 due to the fact that no absolute value is sent in G1_XIST2.

10.2 Parking state

This state can be reached from any other state. The position value in G1_XIST1, G1_XIST2 and G1_XIST3 are set to zero. Errors are cleared and alarms are disabled in parking mode.

10.3 Set/shift home position (Preset)

The Set/shift home position is initiated when Control word bit 12 Request set/shift of home position is set. In this case the Status word bit 12 Set/shift of home position executed is set to 1. In order to initiate a set/shift home position Class 4 functionality must be enabled otherwise there will be an error in G1_XIST2.

10.3.1 Preset depending on different telegrams

When using standard telegram 81-83, the acyclic encoder parameter 65000 Preset value 32 bit shall be used to set a preset value (≤ 32 bit) for the encoder. If the acyclic encoder parameter 65002 Preset value 64 bit is used in this case, an error message will be returned. With telegram 81-83 the operating status must be read by encoder parameter 65001 Operating status 32 bit.

With telegram 84, the acyclic encoder parameter 65002 Preset value 64 bit shall be used to set a preset value (≤ 64 bit) for the encoder. If the acyclic encoder parameter 65000 Preset value 32 bit is used in this case, an error message will be returned. With telegram 84 the operating status must be read by encoder parameter 65003 Operating status 64 bit.

10.3.2 Absolute preset with negative value

Preset data sent with acyclic encoder parameter 65000 or 65002 are signed values. The relative preset mode uses signed preset values, but with the absolute preset mode no preset will be made if a negative preset value (set with encoder parameter 65000 or 65002) is used while trying to initiate an absolute preset.

10.4 Error state

This state is reached when an error has occurred. The encoder can enter this state from both the normal operation state and the set/shift home position state. If an error occurs, the Status word bit 15 Sensor error is set, and the error code is displayed in G1_XIST2 instead of the position value.

10.5 Error acknowledgement

This state is reached when an error has occurred, and Control word bit 15 Acknowledging a sensor error has been set. The Status word bit 11 Requirement of error acknowledgment detected and Status word bit 15 Sensor error are set to 1.

10.6 Start up

This state is only reached when Control word bit 14 Activate parking sensor are cleared ($=0$). Once the Control word bit 14 are cleared, it takes about 500ms before the Status word bit 14 Parking sensor active are set to zero ($=0$). The reason for the delay is that before the encoder goes to normal operation mode, an initializing of the encoder is made.

11 Frequently asked questions FAQ

1. Problem:

Preset, parking mode and error reset is not possible.

Solution:

The Control By PLC bit in Control Word 2 has to be set to 1 (Profile V4.1).

2. Problem:

The preset value is lost if the power supply is switched off.

Solution:

Parameter 971 has to be set to 1 in order to save the preset value into non volatile memory.

HEIDENHAIN

DR. JOHANNES HEIDENHAIN GmbH

Dr.-Johannes-Heidenhain-Straße 5

83301 Traunreut, Germany

☎ +49 8669 31-0

[FAX] +49 8669 5061

E-mail: info@heidenhain.de

Technical support [FAX] +49 8669 32-1000

Measuring systems ☎ +49 8669 31-3104

E-mail: service.ms-support@heidenhain.de

TNC support ☎ +49 8669 31-3101

E-mail: service.nc-support@heidenhain.de

NC programming ☎ +49 8669 31-3103

E-mail: service.nc-pgm@heidenhain.de

PLC programming ☎ +49 8669 31-3102

E-mail: service.plc@heidenhain.de

Lathe controls ☎ +49 8669 31-3105

E-mail: service.lathe-support@heidenhain.de

www.heidenhain.de