




Working with the measured value display unit

ND 221



Indicator	Meaning
REF	If decimal points are blinking: Display is waiting for the reference mark to be crossed over. If decimal points are not blinking: Reference mark was crossed over — datum points are now stored in nonvolatile memory. Blinking: Waiting for operator to press ENT or CL.
in.	Position values displayed in inches.
↑1 / ↓2	Datum 1 / Datum 2 currently active.
SET	Blinking: Waiting for operator to confirm entry values.

The ND 221 is designed primarily for use with HEIDENHAIN **MT Length Gauges**. - MT gauges feature **one** reference mark. When the reference mark is crossed over, it generates a signal identifying that position as a reference point.

After switch-on, simply crossing over the reference mark re-establishes the relationship between axis positions and display values as it was last defined by datum setting.

It is also possible to use other photoelectric linear encoders (see "Parameter Settings for HEIDENHAIN Linear Encoders"). These encoders have one or more reference marks, which may also be *distance-coded*. With distance-coded reference marks, a maximum traverse of only 20 mm after switch-on suffices to re-establish the datum.

Switch-On



Ent...CL

Turn on the power (switch located on rear panel)


- Display shows `REF...CL`.
- REF blinks.



5 , 6 9 7

Switch on reference mark evaluation

- The display shows the value last assigned to the reference mark position.
- REF indicator glows.
- Decimal point blinks.



Cross over reference mark

Move the axis until the display becomes active and the decimal point no longer blinks.

If you do **not** wish reference mark evaluation, press **CL** instead of ENT.

Setting the Datum

The datum setting procedure assigns a display value to a specific axis position. The ND 221 allows you to set two separate datum points.



Select datum 1 or 2.



4 0

Enter a value, such as 40.



Confirm entered value.

You can switch from one datum to the other at any time. Use datum 2 when you want to display incremental dimensions.

Operating Parameters

The parameters are divided into "user parameters" and "protected operating parameters," which can only be accessed by entering a code number.

User parameters

User parameters are operating parameters that you can change **without** entering the code number: They are designated P00 to P30, P50, P51, P79, P86

Calling user parameters

To call user parameters **immediately after switch-on**:

- Press the MOD key as long as [ENT. . . CL] is visible in the display.

To call user parameters **during operation**:

- Press and hold the CL key, then press MOD.

To go **directly** to a specific user parameter:

- Press and hold the CL key, then press the first digit of the parameter number.
- Release both keys and press the second digit.

Protected operating parameters

Before you can change protected operating parameters you must enter the **code number 95 148** through [P00 CODE]: They **remain** accessible until you switch off the position display.

To page through the parameter list

- **Forward** paging: Press the MOD key.
- **Backward** paging: Press the \uparrow 1 / \downarrow 2 key.
By paging on, you automatically enter any change you've made in a parameter.

To change operating parameters

- Increase the parameter value with the decimal point key, **or**
- Decrease the parameter value with the minus key, **or**
- Enter the numerical value for the operating parameter, e.g. for P41 ([SET] blinks).

To correct your entries and show the parameter designation

- Press the CL key.

To exit the operating parameters

- Press ENT. All changes made become effective.

Operating Parameter List

Parameter	Meaning	Function / Effect	Setting
P00 CODE	Enter code number 95 148 to change a protected operating parameter.		
P01 INCH	Unit of measure	Display in millimeters	OFF
		Display in inches	ON
P30 dir Direction	Counting direction	Normal (Positive)	POS
		Inverse (Negative)	NEG
P32 Subd Subdivision	Subdivision of encoder signal period 400, 320, 256, 200, 160, 128, 100, 80, 50, 40, 20, 10, 8, 5, 4, 2, 1, 0.8, 0.5, 0.4, 0.2, 0.1		

Operating Parameter List — *continued*

Parameter	Meaning	Function / Effect	Setting
P33 STEP	Counting mode	0-1-2-3-4-5-6-7-8-9-0	1
		0-2-4-6-8-0	2
		0-5-0	5
P38 DEC Decimal point	Decimal places	1 / 2 / 3 / 4 / 5 / 6 (up to 8 with inch display)	
P41 COMP Compensation	Linear error compensation ¹⁾	-99 999 < P41 < +99 999 [$\mu\text{m}/\text{m}$] As of hardware version .1-: -99 999.9 < P41 < +99 999.9 [$\mu\text{m}/\text{m}$]	
P43 REF	Reference marks	One reference mark	SINGLE
		Distance-coded with 500 • GP (GP = grating period)	500
		Distance-coded with 1000 • GP (e.g. for LS 303 C / LS 603 C)	1000
		Distance-coded with 2000 • GP	2000
P44 REF	Reference mark evaluation	Evaluation	REF ON
		No evaluation	REF OFF
P45 ENCD Encoder	Encoder monitoring	No monitoring (Alarm Off)	ALARM OFF
		Contamination	ALARM C
		Frequency	ALARM F
		Contamination and frequency	ALARM CF
P50 U24	Baud rate baud	110, 150, 300, 600, 1200, 2400, 4800, 9600	
P51 U24	Additional line feeds	L INFEED 0 to 99 (Linefeed)	
P78 PRSE Preset	Value for datum	Enter numerical value for datum setting with the ENT key	
P80 SET	Reset/Preset	No zero reset/preset with CL/ENT	SET OFF
		Zero reset with CL (Set Zero), no preset with ENT	SET ZERO
		Zero reset with CL and preset with ENT to value in P79	PRESET
P82 NESC Message	Display after switch-on	ENT . . . CL message displayed	NESC ON
		ENT . . . CL message not displayed	NESC OFF
P85 MOD Mode	Inhibit PRINT function	PRINT inhibited	PRINT OFF
		PRINT not inhibited	PRINT ON

1) Determine entry value for P41

Example: Displayed measuring length $L_a = 620.000 \text{ mm}$
 Actual length (determined with, for example, the VM 101 comparator system from HEIDENHAIN) $L_t = 619.876 \text{ mm}$
 Length difference $\Delta L = L_t - L_a = -124 \mu\text{m}$
 Compensation factor k :
 $k = \Delta L / L_a = -124 \mu\text{m} / 0.62 \text{ m} = -200 [\mu\text{m}/\text{m}]$

Parameter Settings for HEIDENHAIN Linear Encoders

Model	Signal period [µm]	Reference marks	P43	Display step (unit: P01)		The following settings apply for mm:		
						Sub-division P32	Count mode P33	Decimal places P38
				mm	inches			
LIP 40x	2	one	single	0.001	0.00005	2	1	3
				0.0005	0.00002	4	5	4
				0.0002	0.00001	10	2	4
				0.0001	0.000005	20	1	4
				0.00005	0.000002	40	5	5
				0.00002	0.000001	100	2	5
LIP 101 VM	4	one	single	0.001	0.00005	4	1	3
				0.0005	0.00002	8	5	4
				0.0002	0.00001	20	2	4
				0.0001	0.000005	40	1	4
				0.00005	0.000002	80	5	5
LIF 101 LF 401	4	one	single	0.001	0.00005	4	1	3
				0.0005	0.00002	8	5	4
				0.0002	0.00001	20	2	4
				0.0001	0.000005	40	1	4
				0.00005	0.000002	80	5	5
MT	10	one	single	0.001	0.00005	10	1	3
				0.0005	0.00002	20	5	4
				0.0002	0.00001	50	2	4
				0.0001	0.000005	100	1	4
LID	10	one dist.c.	single 2000					
LS 103 LS 405 ULS/10	10	one dist.c.	0					
			1000					
LS 106 LS 406 LS 706 ULS/20	20	one dist.c.	single 1000	0.01	0.0005	2	1	2
				0.005	0.0002	4	5	3
				0.002	0.0001	10	2	3
				0.001	0.00005	20	1	3
				0.0005	0.00002	40	5	4
LIDA 190 LB 101	40	one	single	0.002	0.0001	20	2	3
				0.001	0.00005	40	1	3
				0.0005	0.00002	80	5	4
LIDA 2xx LB 3xx	100	one	single	0.01	0.0005	10	1	2
				0.005	0.0002	20	5	3
				0.002	0.0001	50	2	3
				0.001	0.00005	100	1	3
LIM 102	12 800	one	single	0.1	0.005	128	1	1
				0.05	0.002	256	5	2

Example:

Set parameters for any encoder

Linear encoder with signal period $s = 10 \mu\text{m}$

Desired display step $a = 0.0001 \text{ mm}$

Subdivision P32 = $0.001 \cdot s / a = 100$

Counting mode P33 = 1 (display counts 1, 2, 3, ...)

Decimal places of a : P38 = 4

Data Output

There are two ways to output data:


- ▶ PRINT function: Press MOD (this method can be inhibited with operating parameter P86); **or**
- ▶ Enter the command STX (CTRL B) over the RXD input.

A **connecting cable** (to a PC, for example) is available from HEIDENHAIN (Id.-Nr. 274 545 ..); cable length up to 20 m (66 ft).

Operating parameters for data output: P50, P51

Wiring, pin layout

Connecting cable is either **completely** wired (left) or only **partially** wired (right).



CHASSIS GND: Chassis Ground; **TXD:** Transmitted Data; **RXD:** Received Data;
RTS: Request To Send; **CTS:** Clear To Send; **DSR:** Data Set Ready; **SIGNAL GND:** Signal Ground; **DTR:** Data Terminal Ready

Signals	Signal level "active"	Signal level "not active"
TXD, RXD	-3 V to -15 V	+3 V to +15 V
RTS, CTS, DSR, DTR	+3 V to +15 V	-3 V to -15 V

Data transfer format and transmission control characters

Format	ASCII code
Data word	1 start bit, 7 data bits, parity bit (even parity), 2 stop bits
Control characters	Call measured value: STX (CTRL B), interrupt DC3 (CTRL S), resume DC1 (CTRL Q) Enquire error message: ENQ (CTRL E)

Sequence

- Sign
- Numerical value with decimal point
- Blank space
- Unit (blank space = mm, " = inches, ? = error)
- 2 blank spaces
- Carriage return
- Line feed

Storage and transfer times

The duration of data transfer depends on the selected baud rate and on the number of additional line feeds.

Latch signal	Storage time	Data transfer time
STX (CTRL) B	≤ 1 ms	≤ 23 ms
PRINT	≤ 22 ms	≤ 44 ms

Error Messages

To clear error message `ERROR` :

When you have removed the cause of the error,

➤ press CL.

Message	Cause and effect
<code>ERROR 01</code>	Last measured value not yet latched
<code>ERROR 02</code>	External device not ready for data transfer (<code>ERROR 02</code> only appears once)
<code>ERROR 03</code>	Data interface: Parity error or wrong data transfer format
<code>ERROR 10</code>	Incorrect input value
<code>ERROR 50</code>	Encoder signal too weak (encoder may be contaminated)
<code>ERROR 51</code>	Input frequency too high for encoder input (will occur for example when the scale is moved too quickly)
<code>ERROR 53</code>	Internal counter overflow
<code>ERROR 55</code>	Error while crossing over reference marks
<code>ERROR 80</code>	To clear the error message: Switch off the display unit.
<code>ERROR 83</code>	Should any of these error codes come up repeatedly, contact your HEIDENHAIN service agency.
<code>ERROR 84</code>	
<code>ERROR 86</code>	
<code>ERROR 99</code>	Check the operating parameters. Should this error code recur, contact your HEIDENHAIN service agency.

If **all decimal points light up**, the measured value is too large or too small. In this case, set a new datum **or** retract.

Distance-To-Go Mode


The standard setting for the display unit is to show the encoder position value. Particularly on machine tools and for tasks in automation, however, it can be very helpful for the display to instead show the distance remaining to a manually entered nominal position. You can then position the tool by simply moving the axis to the display value zero. **Code number 246 582** provides access to distance-to-go mode.

Display	Meaning
<code>DELTA OFF</code>	No distance-to-go display
<code>DELTA ON</code>	Distance-to-go display

“Traverse to zero” with distance-to-go display

- Select datum 2.
- Enter the nominal position.
- Move the axis to zero.

Rear Panel




 Interface X1 complies with the recommendations in VDE 0160, 5.88 for separation from line power.

Installation

You can fix the display unit to a mounting surface with M4 bolts.

The units can also be stacked. Adhesive inserts (included in delivery) prevent them from sliding.



Power Supply and Connection



Danger of electrical shock!

Unplug the power cord before opening the housing.
Connect a protective ground. This connection must never be interrupted.



Danger to internal components!

Do not engage or disengage any connections while the unit is under power.
Use only original replacement fuses.

Primary-clocked power supply, tolerates overvoltage in accordance with VDE 0160, 5.88. Overvoltage tolerance class 2.

Voltage range 100 V to 240 V (-15% to +10 %) **Frequency** 48 Hz to 62 Hz

Power consumption typ. 8 W **Line fuse** F 1 A (in unit)

Minimum cross-section of power line: 0.75 mm²



To increase the noise immunity, connect the ground terminal on the rear panel to the central ground point of the machine. (Minimum cross-section 6 mm²)

Ambient Conditions

Temperature range Operation: 0° C to + 45° C (32° F to 113° F)
Storage: -30° C to + 70° C (-22° F to 158° F)

Rel. humidity Annual average: < 75%; maximum: < 90%

Weight 1.5 kg

DR. JOHANNES HEIDENHAIN GmbH

Dr.-Johannes-Heidenhain-Straße 5
D-83301 Traunreut, Deutschland

☎ (086 69) 31-0

FAX (086 69) 50 61

☎ Service (086 69) 31-12 72

☎ TNC-Service (086 69) 31-14 46

FAX (086 69) 98 99