



HEIDENHAIN



User's Manual

ND 710

ND 750

**Position Display Units
for Milling Machines**

Position display (ND 710 only two axes)

- Select coordinate axes
(ND 710 only X and Y)
- Select axis-specific operating parameters

Status display:

SET = Datum setting

REF = blinking:

Traverse the
reference points.
On continuously:
Reference points
have been traversed.

Δ = Distance-to-go display

1 2 Datum 1 or 2

Inch = Display in inches


SCL = Scaling factor

->|<- = Touching the edge /
centerline

R = Radius/diameter
display

R+/- = Radius compensation

- Select datum 1 or 2
- Page backward in the list of
special functions
- Page backward in the list of
parameters



Numerical input

- Change the algebraic sign
- Call the last dialog
- In the parameter list:
change parameters

- Confirm entry
- In the parameter list
page forward

Call radius compensation of the current tool

- Select special functions
- In the list of special functions
page forward

- Cancel entry
- Reset the operating mode
- Zero the selected axis
(if activated in P80)
- Select parameters
CL plus two-digit number



This manual is for the ND display units with the following software numbers or higher:

ND 710 for two axes
ND 750 for three axes

AA00
AA00

About this manual

This manual is divided into two parts:

Teil I: Operating Instructions

- Fundamentals of positioning
- ND functions

Teil II: Installation and specifications

- Mounting the display unit on the machine
- Description of operating parameters

Part I Operating Instructions

| | |
|---|-----------|
| Fundamentals | 4 |
| Switch-On, Traversing the Reference Points | 9 |
| Datum Setting | 10 |
| Tool Compensation | 13 |
| Moving the Axes with Distance-To-Go | 14 |
| Bolt Hole Circles and Bolt Circle Segments | 16 |
| Linear Hole Patterns | 19 |
| Working with a Scaling Factor | 22 |
| Error Messages | 23 |

Part II Installation and Specifications

Page 25

Fundamentals



You can skip this chapter if you are already familiar with coordinate systems, incremental and absolute dimensions, nominal positions, actual positions and distance-to-go.



Coordinate system

To describe the geometry of a workpiece, the *Cartesian*^{*} coordinate system is used. The Cartesian coordinate system consists of three mutually perpendicular axes X, Y and Z. The point of intersection of these axes is called the **datum** or origin of the coordinate system.

Think of the axes as scales with divisions (usually in millimeters) which allow us to fix points in space referenced to the datum.

To determine positions on a workpiece, the coordinate system is "laid" onto the workpiece.

The machine axes are parallel to the axes of the coordinate system. The Z axis is normally the tool axis.



¹⁾ Named in honor of the French mathematician and philosopher René Descartes (1596 to 1650)


Datum setting

The workpiece drawing is used as the basis for machining the workpiece. To enable the dimensions in the drawing to be converted into traverse distances of machine axes X, Y and Z, each drawing dimension requires a datum or reference point on the workpiece (since a position can only be defined in relationship to another position).

The workpiece drawing always indicates **one** absolute datum (the datum for absolute dimensions). However, it may contain additional relative datums.

In the context of a numerical position display unit, *datum setting* means bringing the workpiece and the tool into a defined position in relation to each other and then setting the axis displays to the value which corresponds to that position. This establishes a fixed relationship between the actual positions of the axes and the displayed positions.

You can set 2 absolute datum points and store them in nonvolatile memory.



Absolute workpiece positions

Each position on the workpiece is uniquely defined by its absolute coordinates.

Example Absolute coordinates of position ①:

$$\begin{aligned} X &= 10 \text{ mm} \\ Y &= 5 \text{ mm} \\ Z &= 0 \text{ mm} \end{aligned}$$

If you are working according to a workpiece drawing with absolute dimensions, then you are moving the tool **to** the coordinates.

Relative workpiece positions

A position can also be defined relative to the previous nominal position. The datum for the dimension is then located at the previous nominal position. Such coordinates are termed **relative coordinates** or chain dimensions. Incremental coordinates are indicated by a preceding **I**.



Example Relative coordinate of position ② referenced to position ①:

$$\begin{aligned} IX &= 10 \text{ mm} \\ IY &= 10 \text{ mm} \end{aligned}$$

If you are working according to a workpiece drawing with incremental dimensions, then you are moving the tool **by** the dimensions.

Sign for incremental dimensioning

A relative dimension has a **positive** sign when the axis is moved in the positive direction, and a **negative** sign when it is moved in the negative direction.




Nominal position, actual position and distance-to-go

The position to which the tool is to move is called the **nominal** position (Ⓢ). The position at which the tool is actually located at any given moment is called the **actual** position (Ⓜ).

The distance from the nominal position to the actual position is called the distance-to-go (Ⓡ).

Sign for distance-to-go


When you are using the distance-to-go display, the nominal position becomes the relative datum (display value 0). The distance-to-go is therefore negative when you move in the positive axis direction, and positive when you move in the negative axis direction.



Position encoders

The position encoders on the machine convert the movements of the machine axes into electrical signals. The ND display unit evaluates these signals, determines the actual position of the machine axes and displays the position as a numerical value.


If the power is interrupted, the relationship between the machine axis positions and the calculated actual positions is lost. The reference marks on the position encoders and the REF reference mark evaluation feature enable the ND to quickly re-establish this relationship again when the power is restored.




Reference marks

The scales of the position encoders contain one or more reference marks. When a reference mark is crossed over, a signal is generated which identifies that position as a reference point (scale datum = machine datum).

When this reference mark is crossed over, the ND's reference mark evaluation feature (REF) restores the relationship between axis slide positions and display values which you last defined by setting the datum. If the linear encoders have **distance-coded** reference marks, you only need to move the machine axes a maximum of 20 mm to do this.



Switch-On, Traversing the Reference Marks



Crossing over the reference marks stores the last relationship between axis slide positions and display values for datum points 1 and 2 in nonvolatile memory.

Note that if you choose *not* to traverse the reference marks (by clearing the dialog ENT ... CL with the CL key), this relationship will be lost if the power is interrupted or when the unit is switched off.



If you wish to use multipoint axis error compensation you must traverse the reference marks (see "Multipoint axis error compensation")!

Datum Setting



If you want to save the datum points in nonvolatile memory, you must first cross over the reference marks.

Only after crossing over the reference marks can you set new datums or activate existing ones.

There are two ways to set datums:

Touch the workpiece with the tool and then set the desired datum (see example). You can also touch two edges and set the centerline between them as a datum. The tool data of the tool used for this are automatically considered (see "Tool Compensation").

After you have set a datum it can be activated as follows:






Select datum 1 or 2.

Datum setting with the tool

Example:


| | |
|---------------------------------|-----------|
| Working plane | X / Y |
| Tool axis | Z |
| Tool radius | R = 5 mm |
| Axis sequence for datum setting | X – Y – Z |






Z

Select the Z axis. SET lights up.
Status display I<- blinks.


PROBE Z (appears only briefly)

Touch the top of the workpiece with
the tool.


ENT

Z position is captured. SET blinks.
Retract the tool from the workpiece.
Status display I<- lights up.


0**ENT**

Enter the position value for the datum
in the Z axis.


**SPEC
FCT**

or

CL

After setting the datum, exit the
probing functions.

Tool Compensation

You can enter the axis, length and diameter of the current tool.

| | |
|-----------------|-------------------------------|
| SPEC FCT | Select the special functions. |
|-----------------|-------------------------------|

| | |
|---------------------------------|-------------------------|
| SPEC FCT or I1/12 | Select "tool diameter." |
|---------------------------------|-------------------------|

| TOOL DATA | |
|------------|-------------------------------|
| ENT | Confirm tool data input mode. |

| TOOL DIAM. | |
|----------------|--|
| 2 0 ENT | Enter the tool diameter, e.g. 20 mm, and confirm with ENT. |

| TOOL LENGTH | |
|----------------|--|
| 5 0 ENT | Enter the tool length, e.g. 50 mm, and confirm with ENT. |

⋮

1) only by ND 750

| TOOL AXIS | |
|-----------|--------------------|
| Z | Set the tool axis. |


| TOOL AXIS | |
|------------------------------|-----------------------------|
| SPEC FCT or CL | Exit the special functions. |

Moving the Axes with Distance-To-Go Display


Normally, the display shows the actual position of the tool. However, it is often more helpful to display the distance remaining to the nominal position (the distance-to-go). You can then position simply by moving the axis until the display value is zero.





You can enter the absolute coordinates in the distance-to-go display. An active radius compensation will be considered.

Example: Milling a shoulder with distance-to-go


| | |
|---|-------------------------------|
|  | Select the special functions. |
|---|-------------------------------|

| | |
|--|----------------------|
|  or  | Select "delta mode." |
|--|----------------------|

| | |
|---|---|
| DELTA MODE | |
|  | Confirm your selection, Δ lights up. |

| | |
|---|--|
|    | Select the axis, enter the nominal value, e.g. 20 mm, select radius compensation R+, |
|  | confirm with ENT. |

...





Move the machine axis to zero ①.



Select the axis, enter the nominal value, e.g. 30 mm, select radius compensation R-, and confirm with ENT.



Move the machine axis to zero ②.



Select the axis, enter the nominal value, e.g. 50 mm, select radius compensation R+, confirm with ENT.



Move the machine axis to zero ③



If appropriate, switch off the distance-to-go display.

Bolt Hole Circles and Bolt Circle Segments


Your display unit enables you to quickly and easily drill bolt hole circles and bolt hole circle segments. The required data is requested in the message field.

Each hole can be moved to by traversing to display value zero. This requires entry of the following data:

- Number of holes (maximum: 999)
- Circle center
- Circle radius
- Starting angle for first hole
- Angle step between the holes (only for circle segments)
- Hole depth

Example

| | |
|---------------------------|------------|
| Number of holes | 8 |
| Coordinates of the center | X = 50 mm |
| | Y = 50 mm |
| Circle radius | 20 mm |
| Starting angle | 30 degrees |
| Hole depth | Z = -5 mm |



| | |
|-----------------|-------------------------------|
| SPEC FCT | Select the special functions. |
|-----------------|-------------------------------|

| | |
|----------------------------|----------------------------|
| SPEC FCT 1/2 | Select "bolt hole" circle. |
|----------------------------|----------------------------|

| | |
|------------------|-------------------------|
| BOLT HOLE | |
| ENT | Confirm your selection. |

| | |
|-----------------------------|------------------------|
| FULL CIRCLE | |
| if req. - ENT | Confirm "full circle." |

| | |
|---------------------|--|
| NUMB. HOLES | |
| 8 ENT | Enter the number of holes, e.g. 8. Confirm with ENT. |

...

| | |
|---------------------------------------|--|
| CENTER X | |
| X 5 0 ENT | Enter the X coordinate of circle center, e.g. 50 mm, confirm with ENT. |

| | |
|---------------------------------------|--|
| CENTER Y | |
| Y 5 0 ENT | Enter the Y coordinate of circle center, e.g. 50 mm, confirm with ENT. |

| | |
|------------------------------|---|
| RADIUS | |
| 2 0 ENT | Enter the radius of the bolt hole circle, e.g. 20 mm. Confirm with ENT. |

| | |
|------------------------------|---|
| START ANGLE | |
| 3 0 ENT | Enter the start angle for the first hole, e.g. 30°. Confirm with ENT. |

...



| HOLE DEPTH | |
|--|---|
| <div>5</div> <div>-</div> <div>ENT</div> | Enter the total hole depth, e.g. -5 mm, and confirm with ENT. |



| START | |
|----------------|--|
| <div>ENT</div> | Start the display of the hole positions. |



| | |
|-------------------------------|---|
| <div>ENT</div> <div>1/2</div> | After the start, the distance-to-go mode becomes active (Δ symbol lights up). The hole number is shown briefly in the X axis. The individual holes are reached by traversing to zero. The holes can be selected with the ENT key or the 1/2 key. The minus key shows the hole number again. |
|-------------------------------|---|



| | |
|---|-------------------------------------|
| <div>SPEC FCT</div> <div>or</div> <div>CL</div> | Exit the bolt hole circle function. |
|---|-------------------------------------|

Linear Hole Patterns


The linear hole pattern feature allows you to easily create rows of holes to cover an area. The required data are requested in the message field.

You can position to each hole by traversing to display value zero. The following data are required:

- Coordinates of the first hole
- Number of holes per row (maximum: 999)
- Spacing between holes
- Angle between the rows and the reference axis
- Hole depth
- Number of rows (maximum: 999)
- Spacing between rows

Example

| | |
|-------------------------------|------------|
| Coordinates of the first hole | X = 20 mm |
| | Y = 15 mm |
| Number of holes per row | 4 |
| Spacing between holes | 16 mm |
| Angle | 15 degrees |
| Hole depth | Z = -30 mm |
| Number of rows | 3 |
| Spacing between rows | 20 mm |



| | |
|-----------------|---------------------------|
| SPEC FCT | Select special functions. |
|-----------------|---------------------------|

| | |
|----------------------------|------------------------|
| SPEC FCT 1/2 | Select "hole pattern." |
|----------------------------|------------------------|

| LIN. HOLE | |
|------------|--------------------------------|
| ENT | Confirm "linear hole" pattern. |

| 1ST HOLE X | |
|----------------------|---|
| 20 ENT | Enter the X coordinate of the first holes, e.g. 20, and confirm with ENT. |

| 1ST HOLE Y | |
|----------------------|---|
| 15 ENT | Enter the Y coordinate of the first holes, e.g. 15, and confirm with ENT. |

⋮


| HOLES ROW | |
|---------------------|--|
| 4 ENT | Enter the number of holes per row, e.g. 4, and confirm with ENT. |

| HOLE SPACE | |
|----------------------|--|
| 16 ENT | Enter the spacing between holes in the row and confirm with ENT. |

| ANGLE | |
|----------------------|---|
| 15 ENT | Enter the angle, e.g. 15 degrees, and confirm with ENT. |

| HOLE DEPTH | |
|------------------------|--|
| 30 - ENT | Enter the hole depth, e.g. -30 mm, and confirm with ENT. |

⋮



Working with Scaling Factors

Scaling factors enable you to increase or decrease the display values based on the actual traverse distance. The display values are changed symmetrically about the datum.


Enter scaling factors separately for each axis in parameter P12.

Parameter P11 activates and deactivates the scaling factors in all axes (see "Operating Parameters").

Example for enlarging a workpiece:

| | |
|-------|-----|
| P12.1 | 3.5 |
| P12.2 | 3.0 |
| P11 | ON |

This results in a larger workpiece as shown in the illustration at right:
① is the original size, ② is with axis-specific scaling factors.



If a scaling factor is active, SCL lights up in the status display.

Error messages

| Message | Cause and effect |
|--------------------|---|
| SIGNAL X | Encoder signal is too small, e.g. when an encoder is contaminated. |
| PROB. ERROR | Before touching off on the workpiece, the tool must move by a distance of at least 0.2 mm. |
| ERR. REF. X | The spacing of the reference marks as defined in P43 is not the same as the actual spacing. |
| FRQ. ERR. X | The input frequency for this encoder input is too high. This can occur when the scale is moved too fast. |
| ERR. MEMORY | Check sum error: Check the datum, operating parameters and compensation values for multi-point axis error compensation. If the error recurs, contact your service agency! |

To erase error messages:

After you have removed the cause of error:

- Press the CL key.

Part II Installation and Specifications

| | |
|---|-----------|
| Items Supplied | 26 |
| Connections on Rear Panel | 27 |
| Mounting | 28 |
| Power Connection | 28 |
| Connecting the Encoders | 29 |
| Operating Parameters | 30 |
| Entering/changing operating parameters | 30 |
| Operating parameter list | 31 |
| Linear Encoders | 33 |
| Setting the display step | 33 |
| Display step, signal period, and subdivision | 33 |
| Parameter settings for HEIDENHAIN linear encoders with 11 μ App | 34 |
| Multipoint Axis Error Compensation | 35 |
| Specifications | 38 |
| Dimensions of the ND 710/ND 750 | 39 |


Items Supplied

- **ND 710** for 2 axes
or
- **ND 750** for 3 axes
- **Power connector** Id. Nr. 257 811-01
- **User's Manual**

Optional Accessories

- **Tilting base** for housing bottom
Id. Nr. 281 619-01

Connections on Rear Panel




The interfaces X1, X2, X3 comply with the requirements for electrical separation according to EN 50178!

Mounting

ND 710/ND 750

To mount the display unit on a support, use the M4 threaded holes in the rubber feet. You can also mount the display unit on the optional tilting base.



Power Connection

Power leads: \textcircled{L} and \textcircled{N} ,
Connect protective ground to $\textcircled{\perp}$!




• **Danger of electrical shock!**

- Connect a protective ground. This connection must never be interrupted.
- Unplug the power cord before opening the housing.



To increase the noise immunity, connect the ground terminal on the rear panel to the central ground point of the machine. (Minimum cross-section: 6 mm²).



The display unit will operate over a voltage range of 90 Vac to 260 Vac. A voltage selector is therefore not necessary.

Connecting the Encoders

Your display unit will accept all HEIDENHAIN linear encoders with sinusoidal output signals (7 to 16 μA_{pp}) and distance-coded or single reference marks.

Assignment of the encoder inputs

Encoder input X1 is for the X axis

Encoder input X2 is for the Y axis

Encoder input X3 is for the Z axis (ND 750 only)

Encoder monitoring system

Your display unit features a monitoring system for checking the amplitude and frequency of the encoder signals. If it detects a faulty signal, one of the following error messages will be generated:


SIGNAL X

FRQ. X

Encoder monitoring can be activated with parameter P45.

If you are using linear encoders with distance-coded reference marks, the encoder monitoring system also checks whether the spacing of the reference marks as defined in parameter P43 is the same as the actual spacing on the scales. If it is not, the following error message will be generated:

ERR. REF. X



Operating parameters

Operating parameters allow you to modify the operating characteristics of your display unit and define the evaluation of the encoder signals. Operating parameters that can be changed by the user are called user parameters, and can be accessed with the SPEC FCT key and the dialog "PARAMETER" (user parameters are identified as such in the parameter list). The full range of parameters can only be accessed through the dialog "CODE" and by entering 95148. Operating parameters are designated by the letter P and a number. Example: **P11**. The parameter designation is shown in the input field when you select it with the DATUM and ENT key in the X display. The parameter setting is shown in the Y display.

Some operating parameters have separate values for each axis. In the **ND 750**, these parameters are identified by an index of 1 to 3, and in the **ND 710** by an index of one to two.

Example: P12.1 scaling factor, X axis
 P12.2 scaling factor, Y axis
 P12.3 scaling factor, Z axis (ND 750 only)

The operating parameters are preset before the unit leaves the factory. These factory settings are indicated in the parameter list in **boldface type**.

Entering and changing operating parameters

To access the operating parameters

- Press the SPEC FCT key.
- Press the SPEC FCT key or 1 2 , until "PARAMETER" appears in the X display.
- Confirm your selection by pressing "ENT."
- If required, press the 1 2 key to enter the code number **95148** and access the complete list of operating parameters.

To page through the operating parameters

- Page forwards by pressing the ENT key.
- Page backwards by pressing the 1 2 key.

To change parameter settings

- Press the minus key or enter the value and confirm with the ENT key.

To correct an entry

- Press CL: the old value reappears in the input line and becomes effective again.

To leave the operating parameters

- Press the SPEC FCT or CL key.

List of operating parameters

P1 Unit of measure 1)

| | |
|------------------------|------|
| Display in millimeters | MM |
| Display in inches | INCH |

P3.1 to P3.3 Radius/diameter display ¹⁾

| | |
|------------------------------------|-----------------|
| Display position value as radius | RADIUS |
| Display position value as diameter | DIAMETER |

P11 Activate scaling factor ¹⁾

| | |
|------------|-------------|
| Active | SCALING ON |
| Not active | SCALING OFF |

P12.1 to P12.3 Define scaling factor ¹⁾

| | |
|--|----------------------|
| Enter a scaling factor separately for each axis: | |
| Entry value > 1: workpiece will "grow" | |
| Entry value = 1: workpiece will remain the same size | |
| Entry value < 1: workpiece will "shrink" | |
| Input range: | 0.100000 to 9.999999 |
| Factory default setting: | 1.000000 |

P30.1 to P30.3 Counting direction

| | |
|---|--------------------|
| Positive counting direction with positive direction of traverse | DIRECT. POS |
| Negative counting direction with positive direction of traverse | DIRECT. NEG |

P32.1 to P32.3 Subdivision of the encoder signals

20 / 10 / 8 / 5 / 4 / 2 / 1 / 0.8 / 0.5 / 0.4 / 0.2 / 0.1

P33.1 to P33.3 Counting mode

0 - 1 - 2 - 3 - 4 - 5 - 6 - 7 - 8 - 9
 0 - 2 - 4 - 6 - 8
 0 - 5

P38.1 to P38.3 Decimal places

1 / 2 / **3** / **4** (up to 6 with inch display)

P40.1 to P40.3 Select type of axis error compensation

| | |
|---|------------------|
| No axis error compensation | CORR. OFF |
| Linear error compensation active, multipoint error comp. not active | CORR. LIN |
| Multipoint error compensation active, linear error compensation not active | CORR. ABS |

¹⁾ User parameter

P41.1 to P41.3 Linear axis error compensation

Input range (μm): -99999 to +99999

Factory default setting: **0**

Example: Displayed length $L_d = 620.000$ mm
 Actual length (as determined for example with the VM 101 from HEIDENHAIN)

$$L_a = 619.876 \text{ mm}$$

$$\text{Difference } \Delta L = L_a - L_d = -124 \text{ } \mu\text{m}$$

Compensation factor k:

$$k = \Delta L / L_d = -124 \text{ } \mu\text{m} / 0.62 \text{ m} = -200 \text{ } [\mu\text{m/m}]$$

P43.1 to P43.3 Reference marks

One reference mark SINGLE REF.M.

Distance-coded with 500 • SP 500 SP

Distance-coded with 1000 • SP **1000 SP**

Distance-coded with 2000 • SP 2000 SP

Distance-coded with 5000 • SP 5000 SP

(SP: signal period)

P44.1 to P44.3 Reference mark evaluationEvaluation **REF. X ON**

No evaluation REF. X OFF

P45.1 to P45.3 Encoder monitoringAmplitude and frequency
monitoring **ALARM ON**

No monitoring ALARM OFF

P48.1 to P48.3 Activate axis displayAxis display active **AXIS ON**

Not active AXIS OFF

P80 Function of the CL key

Reset to zero with CL CL...RESET

No reset to zero with CL CL.....OFF

P98 Dialog language¹⁾

| | LANGUAGE | D |
|------------|-----------------|----------|
| German | LANGUAGE | GB |
| English | LANGUAGE | F |
| French | LANGUAGE | I |
| Italian | LANGUAGE | NL |
| Dutch | LANGUAGE | E |
| Spanish | LANGUAGE | DK |
| Danish | LANGUAGE | S |
| Swedish | LANGUAGE | FI |
| Finnish | LANGUAGE | CZ |
| Czech | LANGUAGE | PL |
| Polish | LANGUAGE | H |
| Hungarian | LANGUAGE | P |
| Portuguese | LANGUAGE | |

¹⁾ User parameters

Linear Encoders

Selecting the display step with linear encoders

To select a certain display step you must define the following operating parameters:

- Subdivision (P32)
- Counting mode (P33)
- Decimal points (P38)

Example

Linear encoder with a signal period of 10 μm

Desired display step 0.000 5 mm

Subdivision (P32) 20

Counting mode (P33) 5

Decimal places (P38) 4

The following tables will help you select the parameters.

Display step, signal period and subdivision for linear encoders

| | | Signal period [μm] | | | | | | |
|--------------|-----------|---------------------------------|-----|-----|-----|-----|-----|-----|
| Display step | | 2 | 4 | 10 | 20 | 40 | 100 | 200 |
| [mm] | [inch] | P32: Subdivision | | | | | | |
| 0.000 1 | 0.000 005 | 20 | – | – | – | – | – | – |
| 0.000 2 | 0.000 01 | 10 | 20 | – | – | – | – | – |
| 0.000 5 | 0.000 02 | 4 | 8 | 20 | – | – | – | – |
| 0.001 | 0.000 05 | 2 | 4 | 10 | 20 | – | – | – |
| 0.002 | 0.000 1 | 1 | 2 | 5 | 10 | 20 | – | – |
| 0.005 | 0.000 2 | 0.4 | 0.8 | 2 | 4 | 8 | 20 | – |
| 0.01 | 0.000 5 | 0.2 | 0.4 | 1 | 2 | 4 | 10 | 20 |
| 0.02 | 0.001 | – | – | 0.5 | 1 | 2 | 5 | 10 |
| 0.05 | 0.002 | – | – | 0.2 | 0.4 | 0.8 | 2 | 4 |
| 0.1 | 0.005 | – | – | 0.1 | 0.2 | 0.4 | 1 | 2 |

Parameter settings for HEIDENHAIN linear encoders with 11 μA_{PP} signals

| Model | Signal period [μm] | Reference marks P 43 | Millimeters | | | | Inches | | | |
|---------------|------------------------------------|--------------------------------|----------------------|------------------|-------|-------------------|------------------------|------------------|-------|-------------------|
| | | | Display step [mm] | Subdivi- sion | Count | Decimal places | Display step [inch] | Subdivi- sion | Count | Decimal places |
| | | | | P 32 | P 33 | P 38 | | P 32 | P 33 | P 38 |
| CT | 2 | single | 0,0005 | 4 | 5 | 4 | 0,00002 | 4 | 2 | 5 |
| MT xx01 | | | 0,0002 | 10 | 2 | 4 | 0,00001 | 10 | 1 | 5 |
| LIP 401A/401R | | -/single | 0,0001 | 20 | 1 | 4 | 0,000005 | 20 | 5 | 6 |
| LF 103/103C | 4 | single/5000 | 0,001 | 4 | 1 | 3 | 0,00005 | 4 | 5 | 5 |
| LF 401/401C | | | 0,0005 | 8 | 5 | 4 | 0,00002 | 8 | 2 | 5 |
| LIF 101/101C | | | 0,0002 | 20 | 2 | 4 | 0,00001 | 20 | 1 | 5 |
| LIP 501/501C | | | | | | | | | | |
| MT xx | 10 | single | 0,0005 | 20 | 5 | 4 | 0,00002 | 20 | 2 | 5 |
| LS 303/303C | 20 | single/1000 | 0,01 | 2 | 1 | 2 | 0,0005 | 2 | 5 | 4 |
| LS 603/603C | | | 0,005 | 4 | 5 | 3 | 0,0002 | 4 | 2 | 4 |
| LS 106/106C | 20 | single/1000 | 0,001 | 20 | 1 | 3 | 0,00005 | 20 | 5 | 5 |
| LS 406/406C | | | | | | | | | | |
| LS 706/706C | | | | | | | | | | |
| ST 1201 | | - | | | | | | | | |
| LB 302/302C | 40 | single/2000 | 0,005 | 8 | 5 | 3 | 0,0002 | 8 | 2 | 4 |
| LIDA 10x/10xC | | | 0,002 | 20 | 2 | 3 | 0,0001 | 20 | 1 | 4 |
| LB 301/301C | 100 | single/1000 | 0,005 | 20 | 5 | 3 | 0,0002 | 20 | 2 | 4 |

Example:

Your encoder: LS 303 C, desired display step: 0,005 mm (5 μm), parameter settings: P01 = mm,
P43 = 1 000, P32 = 4, P33 = 5, P38 = 3

Multipoint Axis Error Compensation



If you want to use the multipoint axis error compensation feature, you must

- activate this feature with operating parameter 40 (see "Operating Parameters"),
- traverse the reference marks after switching on the display unit,
- enter compensation value table.

Your machine may have a non-linear axis error due to factors such as axis sag or drivescrew errors. Such deviations are usually measured with a comparator measuring system (such as the HEIDENHAIN VM 101).

For example, you can determine the screw pitch error $X=F(X)$ for the X axis.

An axis can only be corrected in relation to **one** axis that has an error. In each axis, a compensation value table with 16 compensation values can be generated. You can select the compensation table with the SPEC FCT key and the "PARAMETER\CODE" dialog.

To determine the compensation value (e.g. with a VM 101), the REF display must be selected after selecting the compensation-value table.



Select the REF.

Entries in the compensation value table

- Axis to be corrected: X, Y or Z (Z axis only with ND 750)
- Axis causing the error: X, Y or Z (Z axis only with ND 750)
- Datum for the axis to be corrected:
Here you enter the point starting at which the axis with error is to be corrected. This point indicates the absolute distance to the reference point.



Do not change the datum point after measuring the axis error and before entering the axis error into the compensation table.

- Spacing of the compensation points
The spacing of the compensation points is expressed as 2^x [μm].
Enter the value of the exponent x into the compensation value table.
Minimum input value: 6 (= 0.064 mm)
Maximum input value: 20 (= 8388.608 mm)
Example: 900 mm traverse and 15 compensation points:
results in 60.000 mm spacing between points.
Nearest power of two: 2^{16} [μm] = 65.536 mm
Entry in compensation value table: 16
- Compensation value
You enter the measured compensation value (in millimeters) for the displayed compensation point. Compensation point 0 always has the value 0 and cannot be changed.

Selecting the compensation table, entering an axis correction

| | |
|-----------------|---------------------------|
| SPEC FCT | Select special functions. |
|-----------------|---------------------------|

| | |
|-------------------------------|--|
| SPEC FCT or 1/2 | Select "parameter" if required, by repeatedly pressing the 1/2 key. |
|-------------------------------|--|

| | |
|-----------------------|---|
| PARAMETER | |
| ENT 1/2 | Select dialog for entering the code number. |

| | |
|----------------------------------|--|
| CODE | |
| 1 0 5 2 9 6 ENT | Enter code number 105296 and confirm with ENT. |

| | |
|---------------|---|
| AXIS X | |
| X ENT | Select the axis to be corrected (e.g. X), and confirm with ENT. |

| | |
|-----------------|--|
| X FCT. X | |
| X ENT | Enter the axis causing the error (e.g. X) (screw pitch error), and confirm with ENT. |

⋮

| | |
|----------------|---|
| DATUM X | |
| 2 7 ENT | Enter the active datum for the error on the axis to be corrected (e.g. 27 mm) and confirm with ENT. |


| | |
|------------------|---|
| SPACING X | |
| 1 0 ENT | Enter the spacing of the compensation points on the axis to be corrected, for example $2^{10} \mu\text{m}$ (equals 1024 mm) and confirm with ENT. |

| | |
|----------------------------------|---|
| 27.000 | |
| ENT 0 . 0 1 ENT | Compensation point no. 1 is displayed. Enter the associated compensation value (e.g. 0.01 mm) and confirm with ENT. |

| | |
|----------------|--|
| 28.024 | |
| ENT 1/2 | Enter all further compensation points. If you press the minus key, the unit will show the number of the current compensation point in the X display. |

| | |
|------------------------------|-----------------|
| SPEC FCT or CL | Conclude entry. |
|------------------------------|-----------------|

Deleting a compensation value table





Specifications


| | |
|----------------------------|--|
| Housing | ND 710/ND 750 Bench-top design, cast-metal housing Dimensions (W • H • D) 270 mm • 172 mm • 93 mm |
| Oper. temperature | 0° to 45° C (32° to 113° F) |
| Storage temperature | –20° to 70° C (–4° to 158° F) |
| Weight | Approx. 2.3 kg (5 lb) |
| Relative humidity | <75% annual average <90% in rare cases |
| Power supply | 90 Vac to 260 Vac (–15% to +10%) 48 Hz to 62 Hz |
| Power consumption | 15 W |
| Protection | IP 40 as per IEC 529 |

| | |
|------------------------|--|
| Encoder inputs | For encoders with 7 to 16 μ App Grating period 2, 4, 10, 20, 40, 100, and 200 μ m Reference mark evaluation for distance-coded and single reference marks |
| Input frequency | Max. 100 kHz for 30 m cable length |
| Display step | Adjustable (see “Linear Encoders”) |
| Datums | 2 (nonvolatile) |
| Functions | – Tool radius compensation – Distance-to-go display – Touching off function with tool – Circular & linear hole patterns – Scaling factor |

Dimensions mm/inches



Tilting base



HEIDENHAIN

DR. JOHANNES HEIDENHAIN GmbH

Dr.-Johannes-Heidenhain-Straße 5

83301 Traunreut, Germany

☎ + 49/86 69/31-0

FAX + 49/86 69/50 61

e-mail: info@heidenhain.de

☎ **Service** + 49/86 69/31-12 72

☎ TNC-Service + 49/86 69/31-14 46

FAX + 49/86 69/98 99

e-mail: service@heidenhain.de

<http://www.heidenhain.de>