




HEIDENHAIN

Operating Instructions

POSITIP 850

Programmable Digital Readout for Boring and Milling Machines




- Items Supplied**
- POSITIP 850 Display Unit
 - Power Cable
 - Operating Instructions
 - Certificate of Inspection

- Optional**
- KT 110 Edge Finder (Id.-Nr. 25102101)
 - Connector, 25-pole, for D-subminiature socket X41 (EXT) external functions (Id.-Nr. 249154ZY)
 - Data transfer cable, 25-pole, for D-subminiature socket X31 data output (Id.-Nr. 24286901)
 - Angle bracket (Id.-Nr. 25826101)

Selecting Milling/Turning



As delivered, the POSITIP 850 can be set up for either milling or turning applications. The following screen appears after the **first** power-up:



After pressing the **0** key, the program for milling is permanently set (i. e., is not affected by power interruptions), and this screen display cannot be accessed again. Selection of the turning function is then only possible via parameter P99.0 "Milling, Turning".

Manufacturer's Certificate

We hereby certify that the above unit is radioshielded in accordance with the German official register decree 1046/1984. The German postal authorities have been notified of the issuance of this unit and have been granted admission for examination of the series regarding compliance with the regulations.

Note

If this unit is incorporated by the user into a system then the complete system must comply with the above requirements.

These Operating Instructions are valid for software version 05.

Progr. 246XXX**05**

Sticker on
rear panel.



Contents

Page

Working with the POSITIP 850 For Milling

1	Controls and Screen Displays _____	5
2	Switch-On _____	6
3	Modes of Operation _____	6
4	Cross Over Reference Marks _____	7
5	Keys For User Guidance _____	8
6	External Program Output _____	15
7	External Program Input _____	17

Commissioning

1	Connections and Controls (Rear of Unit) _____	19
2	Mounting the POSITIP 850 _____	20
3	Connecting Linear and Angle Encoders _____	20
4	Connecting the KT 110 Edge Finder _____	21
5	Power Connection _____	21
6	Switch-On and Function Check _____	21
7	Optimizing the Parameters _____	22

Parameters

1	User Parameters _____	25
1.1	Changing User Parameters _____	26
1.2	Overview of User Parameters _____	28
2	Operating Parameters _____	29
2.1	Accessing the Operating Parameters _____	29
2.2	Configuring the User Parameters _____	31
2.3	Presetting the User Parameters _____	33
2.4	Overview of Operating Parameters _____	34
3	Tables _____	38
3.1	Display Step, Signal Period and Subdivision Factor for Linear Encoders _____	38
3.2	Display Step, Line Count and Subdivision Factor for Angle Encoders _____	38
3.3	Distance-Coded Reference Marks _____	39
4	Parameter Description _____	40
4.1	User Parameters _____	40
4.2	Operating Parameters P _____	41

Contents (cont'd.)


Page

Data Interface	1	Definition of the RS-232-C/V.24 Interface _____	46
	2	Pin Layout X31/Signal Description _____	46
	3	Connection of External Units (Wiring) _____	47
	4	Data Transfer _____	48
	4.1	Data Transfer Rate (Baud Rate) _____	48
	4.2	Data Format _____	48
	4.3	Measured Value Output _____	49
	4.3.1	Storage via RS-232-C Interface _____	49
	4.3.2	Storage via External Functions _____	50
	4.3.3	Storage via Probing Functions _____	52
	4.3.4	Sequence of Character Output _____	54
4.4	External Input/Output of Programs _____	56	
4.5	Input/Output of Operating Parameters _____	56	
External Functions	1	Pin Layout X41 (25-pole D-Subminiature Socket) _____	57
	2	External Zero Reset _____	57
	3	Storage (Pulse, Contact) _____	57
	4	Zero Crossover Signal _____	58
	5	EMERGENCY STOP Signal _____	58
Probe Systems	1	KT 110 Edge Finder _____	59
	2	TS 120 Touch Probe System _____	60
	3	Pin Layout X10 (15-pole D-Subminiature Socket) _____	61
Specifications		_____	62
Dimensions		_____	64

Working with the POSITIP 850 For Milling

This part of the Operating Instructions illustrates the most important procedures for operation of the POSITIP 850. For a more detailed explanation, simply call the HELP functions.

1 Controls and Screen Displays



Symbol behind the display value: Ø: Diameter display
 !: Scaling factor active




With these keys you select the datum (L1 to L20), the desired tool radius compensation (R-, R0, R+), and the data interface (FE, EXT)



Selection of cutting data calculator, pocket calculator functions and stopwatch functions



All operating modes, procedures, functions of the individual keys, and error messages are explained



For paging through the individual screens



Return to the previous menu or



Return to the main menu



Display user parameters

2 Switch-On



Before initial switch-on, please read the information in the chapter "Installation".

The power switch is located on the rear panel.

HEIDENHAIN

POSITIP 850

Press any key to continue
or
Press HELP key

After approximately 5 seconds the opening screen appears and POSITIP conducts a memory test.

Adjust brightness if necessary (control on rear panel).

► **Press any key**

MODE: BASIC

Pass over reference marks

X-AXIS

Y-AXIS

Z-AXIS

W-AXIS

NO
REF

Mode
of Op.

POSITIP is in the mode of operation which was last selected (in this case **BASIC**).

3 Modes of Operation

BASIC
Mode

Digital Readout for simple machining tasks

- Actual position display with up to 20 freely-selectable datum points

EXPERT
Mode

Digital Readout with expanded scope of functions


- Distance-To-Go display with radius compensation
- Bolt-hole circle
- Probing functions for datum setting

PROGO
Mode

Programmable Digital Readout

- Storage of up to 20 different programs
- Easy programming with conversational guidance, sub-programs and program section repeats

Select mode of operation



Press soft key and select desired mode of operation.

4 Cross Over Reference Marks

When a reference mark is crossed over, a signal is generated which identifies that position as a machine datum. Crossing the reference marks re-establishes the correspondence between axis slide positions and display values.



After a power interruption the reference marks must be crossed over in every axis.

After crossing the reference marks in all axes:

The screenshot shows a control panel with a 'SELECT FUNCTION' menu on the left and an 'EXPERT' menu on the right. The 'SELECT FUNCTION' menu has a 'REF' option highlighted. The axis positions are displayed as follows:

Axis	Position
X	+ 102.425
Y	+ 366.316
Z	- 31.022
W	+ 13.910

The 'EXPERT' menu includes options: 'Actual Posit.', 'Dist.-To-Go', 'Bolt Circle', and 'Probe'. At the bottom of the screen, there are labels for axes L1 through L6.

The main menu appears for the selected mode of operation. The abbreviation REF in the entry line indicates REF mode. The position data are referenced to the current datum (highlighted).

If you do not wish to work with reference mark evaluation:



Press soft key



If NO REF is pressed, positions and display values are lost after a power interruption!

5 Keys For User Guidance

HELP


The HELP function can guide you through the operation of the POSITIP 850. Think of it as integrated operating instructions. At **any time** during operation you can call up an explanation of the current screen image by pressing the HELP key. The HELP function can also tell you how to proceed when an **error message** occurs.

Calling the HELP Function

ACTUAL POSITION		BASIC	
-35.48	REF	Zero	
X + 1.380		Preset X	
Y - 1.334		Preset Y	
Z - 29.270		Preset Z	
W + 11.914		Preset W	
↓1 ↓2 ↓3 ↓4 ↓5 ↓6			

Example: POSITIP is in the main menu of the **BASIC** operating mode.

► Call HELP:

Press 

HELP: ACTUAL POSITION

After workpiece setup, set the datum (zero or preset value) for workpiece machining:
All positions are referenced to this point.

Zero

You can zero the axis displays for the current position


or
preset the displays to any desired values.


1/3

An explanation of **ACTUAL POSITION** appears on the screen.

A HELP text can consist of several pages. The current page and the total number of pages is displayed in the lower right-hand corner of the screen.

► Page further:

Press  to page forward

Press  to page backward

► Depart HELP:

Press  once again.

POSITIP returns to the original screen.



Return to the main menu of the selected mode of operation
(*EXPERT* or *PROGO*).

PROBE: EDGE		EXPERT
	REF	
X +	102.425	X-Axis
Y +	366.316	Y-Axis
Z -	31.022	Z-Axis
W +	13.910	W-Axis
↓1 ↓2 ↓3 ↓4 ↓5 ↓6		

Example: Operating mode **EXPERT**, the **PROBE: EDGE** function has been selected.

► **Return to the main menu:**

Press



SELECT FUNCTION		EXPERT
	REF	Actual Posit.
X +	102.425	Dist.- To-Go
Y +	366.316	
Z -	31.022	Bolt Circle
W +	13.910	Probe
↓1 ↓2 ↓3 ↓4 ↓5 ↓6		

POSITIP jumps back into the main menu of the **EXPERT** operating mode.



Return to the previous menu

PROBE: EDGE		REF	EXPERT
X +	102.425		X-Axis
Y +	366.316		Y-Axis
Z -	31.022		Z-Axis
W +	13.910		W-Axis
F1 F2 F3 F4 F5 F6			

Example: Operating mode **EXPERT**, the **PROBE: EDGE** function has been selected.


► Return to the previous menu (PROBE):

Press



PROBE		REF	EXPERT
X +	102.425		Edge
Y +	366.316		Center-Line
Z -	31.022		Circle Center
W +	13.910		
F1 F2 F3 F4 F5 F6			

POSITIP jumps back into the **PROBE** menu.

Each time you press the  key you jump back by one menu level until you reach the main menu of the selected mode of operation.




Paging forward and backward, selection of work screens and soft key assignment.

Selection of Work Screens

PROGRAM INPUT		PROGO
Program number	1	Set

		↑
0	BEGIN PGM 1 MM	↓
1	END PGM 1 MM	GOTO
↓1 ↓2 ↓3 ↓4 ↓5 ↓6		R- R0 R+

Example: POSITIP is in the **PROGRAM INPUT** main menu.


The  symbol indicates the currently-selected page (here, page 1).

► Select page 2:

Press



PROGRAM INPUT		PROGO
Position nominal value?	+0.000	Increm.
-----		Nominal Value X
		Nominal Value Y
0	BEGIN PGM 1 MM	Nominal Value Z
1	END PGM 1 MM	Nominal Value W
↓1 ↓2 ↓3 ↓4 ↓5 ↓6		R- R0 R+

The second page of the **PROGRAM INPUT** main menu has been selected. The  symbol now indicates page 2 as current page.

► Return to page 1:

Press



PROGRAM INPUT		PROGO
Program number	1	Set

		↑
0	BEGIN PGM 1 MM	↓
1	END PGM 1 MM	GOTO
↓1 ↓2 ↓3 ↓4 ↓5 ↓6		R- R0 R+

Display returns to the first page of **PROGRAM INPUT**.





Selection of datum points, tool radius compensation and data transfer protocol.

Selection of Datum Points

ACTUAL POSITION		BASIC
	-35.48	Zero
X +	1.380	Preset X
Y -	1.334	Preset Y
Z -	29.270	Preset Z
W +	11.914	Preset W
↓1 ↓2 ↓3 ↓4 ↓5 ↓6		

Example: POSITIP is in the main menu of the BASIC mode of operation. Datum 2 has been selected.

▶ **Select new datum, e.g. 12:**

Press   or hold down until datum 12 is selected. Out of 20 possible datum points, 6 can be displayed at once.

Selection of Tool Radius Compensation

DISTANCE-TO-GO		EXPERT
	+0.909	Incram.
X -	0.909	Nominal Value X
Y -	241.162	Nominal Value Y
Z +	600.000	Nominal Value Z
W -	3.086	Nominal Value W
↓1 ↓2 ↓3 ↓4 ↓5 ↓6		R- R0 R+

Example: The DISTANCE-TO-GO function has been selected. No tool radius compensation has been selected: Display R0

▶ **Select tool radius compensation, e.g. R+:**

Press 

Selection of the Data Transfer Protocol

EXTERNAL OUTPUT		PROGO
Program number ?		Start Output
1		Output All PGM
1/ 24		Escape
		PT 850 PGM Dir
		FE 401 PGM Dir
PT 850 PGM dir		FE EXT

Example: In the PROGO operating mode, the function EXTERNAL OUTPUT has been selected. The data transfer protocol is set on the FE 401: display FE

▶ **Set data transfer protocol to EXT, e.g. for printer:**

Press 



User Parameters

POSITIP features non-volatile parameter storage: the parameters become effective immediately upon switch-on. The parameters are divided into two groups: user parameters and operating parameters.

User parameters are parameters that can be changed during operation by pressing the MOD key.

Operating parameters concern machine characteristics and are given a fixed setting. For more information on operating parameters see the "Parameters" section.

Working with the POSITIP 50

User Parameters

Example: The DISTANCE-TO-GO function has been selected.

DISTANCE-TO-GO		EXPERT
+0.909	REF	Increment.
X -	0.909	Nominal Value X
Y -	241.162	Nominal Value Y
Z +	600.000	Nominal Value Z
W -	3.086	Nominal Value W
↓1 ↓2 ↓3 ↓4 ↓5 ↓6		R- R0 R+

► **Call user parameters:**

Press

An overview of available parameters appears on the screen.

USER PARAMETERS		
Ball Dia.	Scaling X	Radius X
Tool Dia.	Scaling Y	Radius Y
Baud RS-232C	Scaling Z	Radius Z
Mode of Op.	Scaling W	Radius W
Operat. Param.	Scaling OFF	Degrees Decimal

► **Change parameter:**

Select desired column

► **Call parameter:**

Press soft key

► **Depart user parameters:**


Press once again.



INFO Functions

The INFO functions can be selected from any menu level by pressing the INFO key. The following functions are then available: Cutting data calculator, stopwatch, pocket calculator.

Example: Calling the Cutting Data Calculator




► Call cutting data calculator:

Press

Cutting
Data



soft
key



The cutting data calculator for calculation of the spindle speed and feed rate appears on the screen.

Pressing the HELP key displays an explanation of this function.

► Depart INFO:

Press  once again.

POSITIP returns to the original screen.

6 External Program Output

Using the EXTERNAL OUTPUT function in the operating mode **PROGO**, you can transfer one or all of the programs in the PT 850 to an external storage device via the RS-232-C data interface. Programs can be archived on diskette with the FE 401 Floppy Disk Unit from HEIDENHAIN.

Printers used with the PT 850 must have a serial RS-232-C interface (please refer to "Data Interface" section 4.2, Data Format).


Example: Transferring a Program to the FE 401

SELECT FUNCTION PROGO

Program Number	Actual Posit.	Extern. Input
Program Input	Dist.-To-Go	Extern. Output
Teach-In		
Single Block	Bolt Circle	
Auto-matic	Probe	Clear Program

The main menu of the **PROGO** operating mode has been selected.

► **Call "External Output":**

Press Extern. Output  soft key

EXTERNAL OUTPUT PROGO

Program number ?



1

1 / 24

PT 850 PGM dir

The **EXTERNAL OUTPUT** menu appears on the screen.

► **Set the data interface to FE 401:**

Press   ("FE" should appear highlighted)

Selecting "FE" sets the data interface and the correct baud rate for the FE 401 Floppy Disk Unit.

► **FE:** Data transfer rate is **9600 baud**, regardless of the baud rate set via MOD.

► **EXT:** The baud rate set via **MOD** for printer output is in effect.

Output a single program:

▶ Enter program number

▶  Start
Output  Begin program output



Output all programs:

▶  Output
All PGM  Begin program output





If there are programs on the diskette with the same PGM number, they will be overwritten.

Directory of programs stored in the POSITIP program memory:

▶  PT 850
PGM Dir  The program number as well as the number of program blocks is displayed.

Directory of programs stored on FE diskettes:

▶  FE 401
PGM Dir  During read-in of the program directory, the dialog Reading FE directory is displayed.

Cancel data transfer:

▶  Escape  Data transfer is cancelled.

7 External Program Input

Using the EXTERNAL INPUT function in the operating mode **PROGO**, you can transfer programs from an external storage device into the PT 850 via the RS-232-C data interface. Programs can be archived on diskette with the FE 401 Floppy Disk Unit from HEIDENHAIN.

Computers used with the PT 850 must have a serial RS-232-C interface (for the data format, please refer to Data Interface, section 4.2).

Example: Loading a Program from the FE 401

SELECT FUNCTION		PROGO
Program Number	Actual Posit.	Extern. Input
Program Input	Dist.-To-Go	Extern. Output
Teach-In		
Single Block	Bolt Circle	
Auto-matic	Probe	Clear Program

The main menu of the **PROGO** operating mode has been selected.

► Call "External Input":

Press

Extern
Input



soft
key

EXTERNAL INPUT	PROGO
Program number ?	Start Input
1	
	Escape
	PT 850 PGM Dir
	FE 401 PGM Dir
	FE EXT

The **EXTERNAL INPUT** menu appears on the screen.

► Set the data interface to FE 401:

Press



("FE" should
appear
highlighted)

Selecting "FE" sets the data interface and the correct baud rate for the FE 401 Floppy Disk Unit.

- **FE:** Data transfer rate is **9600 baud**, regardless of the baud rate set via MOD.
- **EXT:** The baud rate set via **MOD** for printer output is in effect.

Enter the program number of the program to be transferred. If necessary, call up the directory of programs on the diskette using the soft key FE 401 PGM Dir (see "Program Output").




Start
Input



Start transfer of program from floppy disk unit to POSITIP.

Commissioning

1 Connections and Controls (Rear Panel)



* The buffer batteries (three AA-size 1.5 V batteries) serve as a power supply for the program memory. Exchange the batteries if the error message **EXCHANGE BUFFER BATTERY** appears.

The unit must remain switched on during battery exchange to prevent erasure of stored programs.



It is very important that you follow this sequence of steps when installing the unit for the first time.


Do not engage or disengage any connectors while the unit is under power.

2 Mounting the POSITIP 850

- ▶ Place the unit in its intended location. It can be fixed laterally to a base surface with the M4 tapped fixing holes (see illustration for dimensions).



An angle bracket for mounting the PT 850 on a table is available from HEIDENHAIN (Id.-Nr. 25826101).



3 Connecting Linear and Angle Encoders

- ▶ Any HEIDENHAIN linear encoders with sinusoidal output signals and single or distance-coded reference marks can be connected to the PT 850.
- ▶ Connect the encoders for the machine axes to the flange sockets for encoder input on the rear panel. Connect the machine axes to the flange sockets according to the following table:

Example: **Machine Axis** **Flange Socket** **Screen Display**

X →	X1 →	
Y →	X2 →	
Z →	X3 →	
W →	X4 →	

ACTUAL POSITION		BASIC
	REF	Preset
X +	0.000	Zero X
Y +	0.000	Zero Y
Z +	0.000	Zero Z
W +	0.000	Zero W
L1 L2 L3 L4 L5 L6		

4 Connecting the KT 110 Edge Finder

- ▶ Connect the KT 110 Edge Finder (available as accessory Id.-Nr. 25102101) to the D-subminiature socket X10 on the rear panel.
The PT 850 can also be connected to the TS 120 Touch Probe System (see Probe Systems section).

5 Power Connection

- ▶ Check whether there is a protective ground for the power connection. An M5 threaded pin on the rear panel provides an additional connection for protective ground.
- ▶ Connect power cable to the power input socket on the rear panel, and switch on power.

6 Switch-On and Function Check



The unit is adapted to the machine tool by means of parameters. See "Parameters" section. The unit is delivered with **preset parameters** to facilitate commissioning (see Parameters, section 2.4).

Proceed in the following sequence to commission the machine:

- ▶ Switch on power.
- ▶ Adjust desired screen image brightness with control on rear panel.
- ▶ Select desired application (milling or turning). The menu for application selection appears only **once** after initial switch-on.
- ▶ Press any key (except the HELP key).
- ▶ Choose **BASIC** mode of operation (see Working with the POSITIP 850).
- ▶ Press **NO REF** soft key. Now you need not traverse over the reference points (ignore error messages).
- ▶ Use MOD key and the code number **95148** to access the operating parameters (see Parameters, section 2).
- ▶ Optimize operating parameters (see section 7).
- ▶ Switch power off and then on again.
- ▶ Cross over the reference marks (see Working with the POSITIP 850).

Error Messages

After the reference marks have been crossed over there should be no error message in the display.

If an error message is displayed, press the HELP key for more information and then correct the error. Switch power off and then on again.

If several errors occur at once you can display the error messages one after the other by repeatedly pressing the CE key.

7 Optimizing the Parameters

You can adapt the functions of the POSITIP to the machine tool by optimizing the parameters. Proceed in the sequence given in the following checklist. Write the axis designations of the connected machine axes onto the checklist, and check off each point after you have completed the step.




Parameters which must be frequently changed during machine operation are entered as **user parameters** (see Parameters section). If the KT 110 Edge Finder or the TS 120 3D-Probe System is connected, the ball diameter must be entered in the corresponding the user parameter.

Checklist

	Parameter	Encoder Inputs/Axes			
		X1	X2	X3	X4
		Machine Axes			
▶ Are the machine axes assigned to the correct encoder inputs? (see section 3)					
▶ Do the axis designations in the ACTUAL POSITION display match the machine axes? Change if necessary.	P 50.*	○	○	○	○
▶ Check axis definition. The axes are set as linear axes. If a rotary axis is connected (for a rotary table), the axis must be set to "rotary". (The rotary axis display can be switched from degrees decimal to degrees/minutes/seconds via the user parameters).	P 48.*	○	○	○	○
▶ Enter parameter value for reference marks (see Parameters, table 3.3).	P 45.*	○	○	○	○
▶ Set counting direction of the machine axes according to the "Right Hand Rule". Increasing positive display values must correspond to the positive direction of machine axis traverse in relation to the workpiece.	P 40.*	○	○	○	○
▶ Approach a datum on the machine table and set the datum on the POSITIP. Then move the table parallel to the axis and compare the actually traversed length or angle with the value displayed on the POSITIP.	P 41.* P 42.*	○	○	○	○
▶ Check display step (see Parameters, tables 3.1 and 3.2).	P 43.* (linear) P 44.* (angle)	○	○	○	○
▶ Set the counting mode of the rotary axes (for rotary tables). (Presetting = 360°).	P 49.*	○	○	○	○

* The asterisk „*” signifies parameters which are specified according to axis by a number behind the decimal point (e.g. 1.1, 1.2 etc.).

(For parameter descriptions see Parameters, section 4).



Parameters

The operational characteristics of the POSITIP 850 can be modified via user parameters and operating parameters. While user parameters can be changed by the operator, operating parameters are given a fixed setting which corresponds to the details of the specific machine tool. The parameters are given a standard presetting in the factory.




All parameters are in non-volatile storage (i.e., they are not affected by power interruptions). All changes are effective immediately!

1 User Parameters

User parameters are parameters which must be entered or changed frequently during normal machine operation. Press the MOD key to call the menu for user parameters. To leave the menu, press the MOD key again.

Menu: User Parameters




1.1
Changing
User
Parameters

■ **Via soft key**


Soft keys are used to change from radius to diameter display, from degrees to degrees/minutes/seconds display and to select scaling factor ON or OFF.

Example: Radius or Diameter Display



■ Changing user parameters via numerical input

Example: Ball Tip Diameter



1.2 Overview of User Parameters

Selection via MOD key

Function	Axis	Change	Input
Radius/Diameter	X Y Z W	Soft key	—
Degrees Decimal or Degrees/min/sec	X Y Z W	Soft key	—
Scaling Factor	X Y Z W	Numerical input	0.100000 to 9.999999
Scaling Factor ON/OFF		Soft key	—
Ball Tip Diameter		Numerical input	0 to 199.999 mm
Tool Diameter		Numerical input	0 to ± 1999.999 mm
Baud Rate RS-232-C		Numerical input	110, 150, 300, 600, 1200, 2400, 4800, 9600, 19 200, 38 400 baud
Line Feed RS-232-C		Numerical input	0 to 99

(For descriptions of user parameters see section 4.1)



If "Diameter" or "Scaling Factor ON" have been selected, the following symbols appear behind the display value:

∅: Diameter display

!: Scaling factor active

2 Operating Parameters

There are three groups of operating parameters:


- ▶ P 1.1 to P13.0 – configuration of the user parameters
- ▶ P21.1 to P28.0 – presetting of the user parameters
- ▶ P40.1 to P99.0 – operating parameters for machine interface


These settings are normally made only once during commissioning and then remain fixed.



Operating parameters can only be selected through code number **95148** and should not be changed by the machine operator. We recommend that you keep a written copy of the entry values for the operating parameters or store them on an external data medium.

2.1 Accessing the Operating Parameters






Selecting the Operating Parameters

■ Selection via vertical soft arrow keys




Select desired operating parameter with vertical soft arrow keys.



or

■ Selection via GOTO



Press soft key (the last selected parameter number will appear in the input line).



Enter desired parameter number.




Select operating parameter.

Changing Operating Parameters

■ Changing operating parameters by entering a numerical value




Example: P 25.0 ball diameter
Enter numerical value (e.g. 5).




Pressing the soft key Enter transfers the entry value; the next parameter is then displayed.

■ Changing operating parameters with the horizontal soft arrow key




The frame in the parameter line indicates the current parameter entry value. Press the soft key to bring the next parameter entry value into the frame.



Pressing the soft key Enter transfers the entry value; the next parameter is then displayed.

2.2 Configuring the User Parameters

Pressing the MOD key calls the user parameters to the display. These parameters are located in soft-key fields in a certain arrangement of field positions. The field positions are indicated by the numbers in the illustration below. (Factory presetting as it appears after switch-on.)



The field position of any user parameter can be changed by means of the operating parameters P 1.1 to P 13.0. (Exception: field position 15 – operating parameters.) By entering a position of 0, the selected user parameter can be locked from access.


Changing the Field Position

- ▶ First you must gain access to the operating parameters using the procedure described above in section 2.1. Then select the desired soft-key field.

Example:


You wish to transfer the parameter in field position 14 to field position 13.

Original Display




Procedure

- ▶ Select the parameter in field position 14 (factory preset to P 8.0).
- ▶ Enter the new field position (position 13) with numeric keypad and press the soft key **Enter**.

Pressing the  key recalls the menu for the user parameters.

New Display



The overwritten parameter (Baud RS-232C) can be re-entered into the table as follows:

- ▶ Repeat procedure for access to operating parameters and select the overwritten parameter (P 7.0 Baud Rate RS-232C). This parameter has assumed the Position: 0.




Access to user parameters via the MOD key can be locked by entering Position: 0.

Note: Locked user parameters can only be changed via the operating parameters P21.1 to P28.0.

If you wish to transfer the locked user parameter (P 7.0) to the vacant field position 14, enter the field position 14 for this parameter.

2.3 Presetting the User Parameters

User parameters can also be set with the operating parameters (P21.1 to P28.0). This makes it possible to change locked user parameters. Changing these parameters is effective regardless of whether they are changed in the "User Parameters" menu or the "Operating Parameters" menu.



2.4

Overview of Operating Parameters



Function	Parameter	Axis*		Entry**
Radius/Diameter X1	P 1.1	X		1
Radius/Diameter X2	P 1.2	Y		2
Radius/Diameter X3	P 1.3	Z		3
Radius/Diameter X4	P 1.4	W		4
Angle Format	P 2.0			5
Scaling Factor X1	P 3.1	X		6
Scaling Factor X2	P 3.2	Y		7
Scaling Factor X3	P 3.3	Z		8
Scaling Factor X4	P 3.4	W		9
Scaling Factor ON	P 4.0			10
Ball Diameter	P 5.0			11
Tool Diameter	P 6.0			12
Baud Rate RS-232-C	P 7.0			13
Line Feed RS-232-C	P 8.0			14
Mode of Operation	P 9.0			0
Working Plane	P 13.0			0
Radius/Diameter X1	P 21.1	X		radius, diameter
Radius/Diameter X2	P 21.2	Y		
Radius/Diameter X3	P 21.3	Z		
Radius/Diameter X4	P 21.4	W		
Angle Format	P 22.0			degrees decimal, degrees/min/sec
Scaling Factor X1	P 23.1	X		1.000000 (0.100000 to 9.999999)
Scaling Factor X2	P 23.2	Y		
Scaling Factor X3	P 23.3	Z		
Scaling Factor X4	P 23.4	W		
Scaling Factor ON	P 24.0			OFF, ON
Ball Diameter	P 25.0			10.000 (0 to 199.999 mm)
Tool Diameter	P 26.0			0.000 (0 to ± 1999.999 mm)
Baud Rate RS-232-C	P 27.0			110, 150, 300, 600, 1200, 2400, 4800, 9600 , 19 200, 38 400 baud
Line Feed RS-232-C	P 28.0			1 (0 to 99)

Operating Parameters (cont'd.)



Function	Parameter	Axis*		Entry**
Counting Direction X1	P 40.1	X		normal , inverse
Counting Direction X2	P 40.2	Y		
Counting Direction X3	P 40.3	Z		
Counting Direction X4	P 40.4	W		
Signal Period X1	P 41.1	X		4 μm , 10 μm , 20 μm , 40 μm , 100 μm , 200 μm
Signal Period X2	P 41.2	Y		
Signal Period X3	P 41.3	Z		
Signal Period X4	P 41.4	W		
Line Count X1	P 42.1	X		1800 , 3600, 9000, 18000, 36000, 72000
Line Count X2	P 42.2	Y		
Line Count X3	P 42.3	Z		
Line Count X4	P 42.4	W		
Linear Subdivision X1	P 43.1	X		100, 80, 50, 40, 20 , 10, 8, 5, 4, 2, 1, 0.8, 0.5, 0.4, 0.2, 0.1 (depends on grating period set)
Linear Subdivision X2	P 43.2	Y		
Linear Subdivision X3	P 43.3	Z		
Linear Subdivision X4	P 43.4	W		
Angle Subdivision X1	P 44.1	X		100, 50, 25, 20 , 10, 8, 5, 4, 2.5, 2, 1, 0.4, 0.2 (depends on line count set)
Angle Subdivision X2	P 44.2	Y		
Angle Subdivision X3	P 44.3	Z		
Angle Subdivision X4	P 44.4	W		
Distance Coding X1	P 45.1	X		none, 500, 1000 , 2000
Distance Coding X2	P 45.2	Y		
Distance Coding X3	P 45.3	Z		
Distance Coding X4	P 45.4	W		

(For description see section 4.2)

* For the sake of simplicity, the axis designations are assumed to be those set in parameter P50.* (X1 = X, X2 = Y, X3 = Z, X4 = W). X1, X2, X3, X4 are the corresponding designations of the encoder inputs (see back of unit).

** Factory presettings are indicated in **bold type**.

Operating Parameters (cont.'d.)



Function	Parameter	Axis*		Entry**
Monitoring X1	P 46.1	X		off, on
Monitoring X2	P 46.2	Y		
Monitoring X3	P 46.3	Z		
Monitoring X4	P 46.4	W		
Linear Correction X1	P 47.1	X		0 to $\pm 99999 \mu\text{m/m}$
Linear Correction X2	P 47.2	Y		
Linear Correction X3	P 47.3	Z		
Linear Correction X4	P 47.4	W		
Axis Definition X1	P 48.1	X		off, linear , rotary
Axis Definition X2	P 48.2	Y		
Axis Definition X3	P 48.3	Z		
Axis Definition X4	P 48.4	W		
Angle Counting Mode X1	P 49.1	X		360° , $\pm 180^\circ$, $\pm \infty^\circ$
Angle Counting Mode X2	P 49.2	Y		
Angle Counting Mode X3	P 49.3	Z		
Angle Counting Mode X4	P 49.4	W		
Axis Designation X1	P 50.1	X		A, B, C, U, V, W, X, Y, Z
Axis Designation X2	P 50.2	Y		
Axis Designation X3	P 50.3	Z		
Axis Designation X4	P 50.4	W		
Axis Combination	P 51.0			off , 1+4, 2+4, 3+4, 1-4, 2-4, 3-4
Dialog Language	P 52.0			2 languages can be selected (see section 4.2)
Working Plane	P 53.0			X/Y , Y/Z, Z/X
Mirror Graphics	P 54.0			off , vertical and/or horizontal
Direction of Rotation, Bolt Circle Graphics	P 55.0			normal , inverse
Zero Range X1	P 56.1	X		0 (0 to 99.999 mm)
Zero Range X2	P 56.2	Y		
Zero Range X3	P 56.3	Z		
Zero Range X4	P 56.4	W		

Operating Parameters (cont'd.)



Function	Parameter	Axis*		Entry**
Display Freeze	P 57.0			off , concurrent, stopped
Distance-To-Go Mode	P 58.0			bar , actual value
Sleep Delay	P 59.0			15 5 to 98 (min.) 99 = no protective standby mode
Probing/RS-232-C	P 61.0			off , on
Counter Application	P 99.0			milling , turning

(For description see section 4.2)

* For the sake of simplicity, the axis designations are assumed to be those set in parameter P50.* (X1 = X, X2 = Y, X3 = Z, X4 = W). X1, X2, X3, X4 are the corresponding designations of the encoder inputs (see back of unit).

** Factory presettings are indicated in **bold type**.

3 Tables

3.1

Display Step, Signal Period and Subdivision Factor for Linear Encoders

Signal Period	4 μ m	10 μ m	20 μ m	40 μ m	100 μ m	200 μ m
Display Step	Subdivision Factor					
0.00005 mm/0.000002 in.	80	—	—	—	—	—
0.0001 mm/0.000005 in.	40	100	—	—	—	—
0.0002 mm/0.00001 in.	20	50	100	—	—	—
0.0005 mm/0.00002 in.	8	20	40	80	—	—
0.001 mm/0.00005 in.	4	10	20	40	100	—
0.002 mm/0.0001 in.	2	5	10	20	50	100
0.005 mm/0.0002 in.	0.8	2	4	8	20	40
0.01 mm/0.0005 in.	0.4	1	2	4	10	20
0.02 mm/0.001 in.	—	0.5	1	2	5	10
0.05 mm/0.002 in.	—	0.2	0.4	0.8	2	4
0.1 mm/0.005 in.	—	0.1	0.2	0.4	1	2

3.2

Display Step, Line Count and Subdivision Factor for Angle Encoders

Line Count		72000	36000	18000	9000	3600	1800
Display Step		Subdivision Factor					
Degrees Decimal	Degrees/Min/Sec	Subdivision Factor					
0.0001°	0°00'01"	50	100	—	—	—	—
0.0002°	0°00'01"	25	50	100	—	—	—
0.0005°	0°00'01"	10	20	40	—	—	—
0.001°	0°00'05"	5	10	20	40	—	—
0.002°	0°00'05"	2.5	5	10	20	—	—
0.005°	0°00'10"	1	2	4	8	20	—
0.01°	0°00'30"	—	—	2	4	10	20
0.02°	0°01'	—	—	—	—	5	10
0.05°	0°05'	—	—	—	—	2	4
0.1°	0°05'	—	—	—	—	1	2
0.5°	0°30'	—	—	—	—	—	0.4
1.0°	1°	—	—	—	—	—	0.2

3.3

Distance-Coded Reference Marks

Linear Encoder	Max. Traverse for Recovery of the Datum	Parameter
No distance-coded reference marks	Depends on position of the encoder	P 45.* = none
LS 101C	10 mm	P 45.* = 1000
LS 107C LS 303C LS 403C LS 404C LS 603C LS 704C	20 mm	
ULS 300C	10 mm (grating period 10 μ m) 20 mm (grating period 20 μ m)	
LID 311C LID 351C	20 mm	

Angle Encoder	Max. Rotation for Determination of the Absolute Position	Parameter
No distance-coded reference marks	1 rotation	P 45.* = none
ROD 250C (18000) RON 255C (18000) ROD 700C (18000) ROD 800C (18000)	20°	P 45.* = 1000
ROD 700C (36000) ROD 800C (36000)	10°	
ROD 700C (9000)	20°	P 45.* = 500

Parameters

4 Parameter Description

4.1

User Parameters

Radius/ Diameter	With this parameter you can select radius or diameter display for linear axes. If you select diameter, the symbol "Ø" will appear behind the display value.
Angle Format	The display for a rotary axis can be switched between degrees decimal and degrees/minutes/seconds.
Scaling Factor	With the scaling factor you can enter a correction to the workpiece to be machined. The correction range is (0.100000 to 9.999999). A scaling factor greater than 1 will enlarge the workpiece, while a scaling factor less than 1 will reduce it. You can enter a separate scaling factor for each axis.
Scaling Factor OFF/ON	By entering scaling factor OFF, all scaling factors are deactivated. When scaling factor ON is entered, the symbol "!" appears behind the display value.
Ball Tip Diameter (Probing)	In the Probe Edge function the position value must be corrected by the radius of the ball tip. The entry range for the ball tip diameter of the edge finder is 0 to 199.999 mm.
Tool Diameter	The tool diameter can be entered in the user parameters and in the operating mode PROGO (single block, automatic and teach-in). The tool diameter value last entered becomes effective automatically whenever radius compensation is entered.
Baud Rate RS-232-C	With this parameter you can set the data transfer rate (baud rate) for the data interface.
Line Feeds RS-232-C	With this parameter you can set the number of additional line feeds (blank lines) between values for an external device (maximum of 99 line feeds).
Special Case: Mode of Operation and Working Plane	These parameters are not configured as user parameters in the factory presetting. With the Mode of Operation parameter you can choose among the BASIC , EXPERT and PROGO modes of operation via the MOD key without switching the unit off. With the Working Plane parameter, the working plane can be selected during machining via the MOD key.



The user parameters **Mode of Operation** and **Working Plane** are only active if operating parameters P 9.0 and P 13.0 are configured as user parameters (see section 2.2).

4.2

Operating Parameters P



In the following description, **axis-specific parameters** are indicated by a parameter number with decimal point and asterisk (example: P 1.*).

The asterisk signifies the axis-specific designation after the decimal point (e.g. P 1.1, P 1.2 etc.).

Parameters which are **not axis-specific** are indicated by a **0** behind the decimal point (e.g. P 5.0).

P 1.* to P 13.0

The "User Parameters" menu is configured by entering positions in operating parameters P 1.* to P 13.0. The user parameters can be configured in any desired sequence within the positions 1–14. **Position: 0** locks the respective parameter from access via the MOD key (see section 2.2).

Special Case: P 9.0/P 13.0 Mode of Operation/ Working Plane

These parameters are configured as user parameters in the factory presetting (see sections 2.2 and 4.1).



With parameters P 1.* to P 8.0 as user parameters, all 14 freely selectable field positions are occupied. If you wish to define parameters P 9.0 and P 13.0 as user parameters, you must overwrite already occupied user parameters (e.g. parameter 8.0 Line Feed).

P 21.* to P 28.0

User parameters can also be set in the operating parameters (P 21.1 to P 28.0), making it possible to change even locked user parameters. Changing these parameters is effective regardless of whether they are changed in the "User Parameters" or in the "Operating Parameters" menu. (For description, see section 4.1.)

P 40.* Counting Direction

With parameter P 40.* you can set the counting direction separately for each axis.

P 41.* Signal Period

The signal period of the connected linear encoders is entered in parameter P 41.*.

If linear axis movement is measured using rotary encoders with nut and spindle, the signal period must be calculated with the following formula:

$$\text{Signal Period } [\mu\text{m}] = \frac{\text{Spindle Pitch [mm]} \cdot 1000}{\text{Line Count}}$$



Line count (P 42.*) and angle subdivision (P 44.*) are necessary only for rotary axes. For linear axes whose traverse is measured via rotary encoders with nut and spindle, the axis must be defined as a linear axis in parameter P 48.*.

P 42.*
Line Count

The line counts of rotary encoders connected to rotary axes must be entered in parameter P 42.*.

P 43.*
Linear
Subdivision

The subdivision factor is entered in parameter P 43.*. The subdivision factor determines the display step and depends on the setting of the signal period (see Table 3.1).

P 44.*
Angle
Subdivision

The angle subdivision determines the display step for rotary axes and depends on the line count setting (see Table 3.2).

P 45.*
Distance
Coding

Parameter P 45.* defines whether the display unit is to evaluate signals from encoders with single or with distance-coded reference marks. For encoders with single reference marks, enter **none** in parameter P 45.*. For distance-coded reference marks, the entry value depends on the encoder model (see Table 3.3).

P 46.*
Monitoring

With parameter P 46.* **on**, the corresponding encoder input signal is checked for the following errors:

- excessive traversing speed
- cable break
- measuring signal error

These errors are then displayed on the screen.

P 47.*
Linear Correction

Machine error can be measured with the aid of a comparator measuring system (e.g. VM 101 from HEIDENHAIN). These errors can be entered in parameter P 47.* as a linear correction factor in parts per million (ppm) measuring length.

Example: Measuring length 620 mm
Value actually measured (e.g. via VM 101) 619.876 mm
Difference = - 124 µm

Conversion to 1 m measuring length
$$\frac{- 124 \mu\text{m} \cdot 1000 \text{ mm}}{620 \text{ mm}} = - 200 \mu\text{m}$$

Correction factor - 200 µm

Linear Compensation	Parameter Input Range
"Lengthening" the encoder	P47: 0 to + 99 999 [µm/m]
"Shortening" the encoder	P47: 0 to - 99 999 [µm/m]

P 48.*
Axis Definition



Parameter P 48.* defines whether the axis input is inhibited (off) or the axis functions as a linear or rotary axis.

For unused encoder inputs enter off in parameter P 48.*.

P 49.*
Angle Counting Mode

Parameter P 49.* defines the way in which angular measurements are displayed.

Possible settings: 360° , $\pm 180^\circ$, $\pm \infty^\circ$.

P 50.*
Axis Designation

Parameter P 50.* defines the assignment of axis names to inputs.

Possible settings: A, B, C, U, V, W, X, Y, Z.

P 51.0
Axis Combination

Parameter P 51.* permits the following settings:

off: no combination

1+4: Axes X1 and X4 added and displayed on axis X1

2+4: Axes X2 and X4 added and displayed on axis X2

3+4: Axes X3 and X4 added and displayed on axis X3

1-4: Axis X4 subtracted from X1, result displayed on axis X1

2-4: Axis X4 subtracted from X2, result displayed on axis X2

3-4: Axis X4 subtracted from X3, result displayed on axis X3

P 52.0
Dialog Language

The dialog language can be chosen from two available languages. Which two languages are available depends on the program number:

Program No.	Languages	
246060-	German	English
246061-	French	English
246062-	Dutch	English
246063-	Italian	English
246064-	Spanish	English
246065-	Danish	English
246066-	Swedish	English
246067-	Finnish	English
246068-	Turkish	English
246069-	German	French
246070-	Dutch	French
246071-	Magyar	German
246072-	Czech	German
246073-	English	French

P 53.0
Working Plane

Parameter P 53.0 defines the working plane.

Possible settings: X/Y, Y/Z, Z/X

P 54.0 **Mirror Graphics**

Display of the bolt hole circle graphics can be set in parameter P 54.0 in the case that it deviates from the normal coordinate system.

off: no mirroring
ver: the vertical coordinate axis is mirrored
hor: the horizontal coordinate axis is mirrored
ve + ho: both coordinate axes are mirrored



When an axis is mirrored, the direction of rotation for hole numbering is changed in the graphics.

P 55.0 **Direction of** **Rotation, Bolt** **Circle Graphics**

Depending on the setting of parameter P 54.0, parameter P 55.0 defines the direction of rotation of the holes in the bolt hole circle graphics.

normal: direction of rotation (in the graphics) is from the first to the second axis.

inverted: direction of rotation (in the graphics) is from the second to the first axis.

P 56.* **Zero Range**

Parameter P 56.* defines a range around "zero" in which a zero crossover signal will be generated (see External Functions).
Input range: 0 to 99.999 mm.

P 57.0 **Display Freeze**

The current measured value is stored and output over the RS-232-C data interface with every storage procedure (CTRL, pulse, contact). The display on the **screen** can be set with parameter P 57.0:

off: the display is not stopped during a storage signal

concrnt: the display is stopped only for the duration of the storage signal

stopped: the display is stopped, but is updated by every storage signal

P 58.0 **Distance-To-Go** **Mode**

In the distance-to-go function, the actual value can be displayed instead of the graphic positioning aid.

bar: graphic positioning aid

actual value: display of the absolute position in small type beneath the distance-to-go display.

P 59.0 **Sleep Delay**

Parameter P 59.0 allows input of a delay time (in minutes) for protective standby mode. If no keys are pressed and no axis movements take place for the length of time entered as the delay time, the screen image is reversed. This prevents screen burning.

5 – 98: delay time in minutes

99: no protective standby mode.

P 61.0
Probe/RS-232-C

With parameter P 61.0 set to **on**, after probing with the edge finder (edge, centerline, or circle center) a storage signal is generated and the measured value is sent over the TXD output of the RS-232-C data interface. If no external device (such as a printer) is connected, parameter P 61.0 must be set to **off**. Otherwise the error message **EXTERNAL UNIT NOT READY** will appear after every probe.

P 99.0
Counter
Application

With parameter P 99.0 the POSITIP 850 is set up either for milling or turning.

Data Interface

POSITIP is equipped with a data interface according to EIA standard RS-232-C (CCITT standard V.24).

1 Definition of the RS-232-C/V.24 Interface

The data transfer code is ASCII with even parity bit. The RS-232-C data interface is designed for serial data transfer; devices with parallel data interfaces cannot be connected. Levels for TXD and RXD (negative level for "1"):

Logic Level	Working Level
"1": - 3 V to - 15 V	- 5 V to - 15 V
"0": + 3 V to + 15 V	+ 5 V to + 15 V

2 Pin Layout X31 Signal Description



Contact No.	Signal	Meaning
1	CHASSIS GND	Protective Ground
2	TXD*	Transmit Data
3	RXD*	Receive Data
4	RTS	Request To Send
5	CTS	Clear To Send
6	DSR	Data Set Ready
7	SIGNAL GND	Signal Ground
8-19		(vacant)
20	DTR	Data Terminal Ready
21-25		(vacant)


* The designations TXD, RXD indicate negative levels for "1".

3 Connection of External Units (Wiring)

The connecting cables must be wired in accordance with the type of data device employed. Pin layouts are sometimes non-standard.


Frequently used wiring:

Complete wiring



Signals RTS, CTS, DSR and DTR must have working level "1" (+ 5 to + 15 V) for data transfer.

Simplified wiring



Signals RTS, CTS, DSR and DTR have permanent working level "1" (+5 V to +15 V) due to bridges 4/5 and 6/20.

4 Data Transfer

Measured values, part programs and operating parameters can be transferred over the PT 850's RS-232-C data interface. The data interface can operate with two different data transfer protocols:

- ▶ External data transfer protocol (EXT) for printers, punching units, readers and other peripherals.
- ▶ FE data transfer protocol (FE) for the HEIDENHAIN FE 401 Floppy Disk Unit or a suitably adapted computer.

	Data Transfer Protocol	Start Data Transfer With
Measured value output	EXT	RS-232-C interface (CTRL B) Ext. functions (pulse, contact) Probing functions (edge finder)
Program input	FE or EXT	"EXTERNAL INPUT" menu
Program output	FE or EXT	"EXTERNAL OUTPUT" menu
Input and output of operating parameters	FE or EXT	"OPERATING PARAMETERS" menu

4.1

Data Transfer Rate (Baud Rate)

The baud rate indicates the number of bits which can be transferred per second.


Peripheral devices must be fully able to process the selected baud rate in order to avoid errors in data transfer. The desired baud rate is selectable under the user parameters (via the MOD key). The selected baud rate must be identical to the baud rate of the peripheral device.



In FE mode (for the FE 401 Floppy Disk Unit from HEIDENHAIN), the data transfer rate is always 9600 baud regardless of the baud rate set via the MOD key.

4.2

Data Format




The connected unit must be set to "even parity" because of the error monitoring employed in this output. A data transfer cable (Id.Nr. 242869..) is available from HEIDENHAIN.

4.3 Measured Value Output

The current display value can be transferred over the RS-232-C data interface to peripheral equipment such as a printer. After a storage command, the measured value is output (for a maximum of 4 axes) through an internal buffer. The storage signal can be generated via the RS-232-C interface, the "external functions", or via probing with the edge finder.

4.3.1 Storage via RS-232-C Interface

When the control character CTRL B (= STX) is transmitted, a storage signal is generated and the measured value is transmitted over the TXD output of the RS-232-C data interface. The duration of data transfer depends on the selected baud rate, the number of axes and the number of line feeds.



Interruption of Data Transfer


The receiving device can interrupt and restart data transfer by

- ▶ Start/stop via the RXD input of the data interface
 - DC3 = X OFF = CTRL S: interrupt data transfer
 - DC1 = X ON = CTRL Q: resume data transfer
- ▶ Control line CTS


After the stop signal CTS or the stop character DC3 has been received, no more than two additional characters can be output.

4.3.2
Storage via
External Functions

Contact closing against 0 V on the 25-pole D-subminiature socket X41 causes a storage signal to be generated and the measured value to be transmitted over the TXD output of the RS-232-C interface. The time required for data transfer depends on the selected baud rate, the number of axes, the number of line feeds and the type of storage signal (pulse or contact).




The transit time of the encoder signals from input to the internal buffer is approximately $4 \mu\text{s}$. The measured value which is stored is therefore the value which existed approximately $4 \mu\text{s}$ prior to the time point of storage.
 (See also External Functions).




4.3.3 Storage via Probing Functions

If parameter **P 61.0 Probe/RS-232-C** is set to **on**, then after probing with the edge finder in the probing functions **edge**, **centerline** or **circle center** a storage signal is generated and the measured value is sent over the TXD output of the RS-232-C interface. (See Parameters, section 4.2).


Sequence of Character Output (example PROBE: EDGE)



Sequence of Character Output (example PROBE: CENTERLINE)




Sequence of Character Output (example PROBE: CIRCLE CENTER)




4.3.4 Sequence of Character Output

Depending on the axis definition, the characters for measured value output are generated in the following order:


Sequence of Character Output (example for linear axis)




Sequence of character output (example for rotary axis/degree decimal display)



Example for rotary axis/degree-minutes-seconds display



 If the linear or angle encoder is defective, no display values are output. For the algebraic sign and the display value, question marks (?) are output.

4.4 External Input/ Output of Programs

In the **PROGO** mode of operation, it is possible to read programs into or out of POSITIP over the RS-232-C data interface (see Working with the POSITIP 850).




4.5 Input/Output of Operating Parameters

Operating parameters can be input and output over the RS-232-C data interface. Printers connected to the PT 850 must be equipped with a serial RS-232-C interface (for the data format see section 4.2).





Programs and operating parameters with the same program number can be stored with the FE 401 Floppy Disk Unit from HEIDENHAIN. When loading operating parameters, POSITIP automatically generates program number 850 unless a different number is entered.

Sequence:



- ▶ Select operating parameter (see Parameters, section 2).
- ▶  Select page 2 (menu for parameter input/output).
- ▶   Set interface to **FE** (FE 401 Floppy Disk Unit) or **EXT** (for printer or other peripheral device).

In FE mode, the data transfer rate is always 9600 baud, independent of the baud rate set via MOD. When EXT is selected, the baud rate set via MOD for printer output is effective.

- ▶  Operating parameters are read out with program number 850.
- ▶  Operating parameters with program number 850 are read in.



If you do not wish to input or output the operating parameters with program number 850, then the desired program number must be entered before pressing the **Param. Output** or **Param. Input** soft keys.

- ▶  Displays the program directory of the FE 401. During read-in of the directory, the dialog **Reading FE Directory:** is displayed.
- ▶  Data transfer is terminated.

External Functions

1 Pin Layout X41 (EXT) (25-pole D-Subminiature Socket)

Pin	Assignment	Duration of pulse/ contact closing
1/10	0 V	
2	I Set axis 1 to zero	$t \geq 100 \text{ ms}$
3	I Set axis 2 to zero	$t \geq 100 \text{ ms}$
4	I Set axis 3 to zero	$t \geq 100 \text{ ms}$
5	I Set axis 4 to zero	$t \geq 100 \text{ ms}$
14	O Zero crossover axis 1	
15	O Zero crossover axis 2	
16	O Zero crossover axis 3	
17	O Zero crossover axis 4	
21	O EMERGENCY STOP	
22	I Storage pulse	$t \geq 1.2 \mu\text{s}$
23	I Storage contact	$t \geq 7 \text{ ms}$

I = Input
O = Output

2 External Zero Reset

The inputs (pins 2, 3, 4, 5) are active LOW (open = high level).
 $U_{eH} \geq 3.9 \text{ V}$ (max. 15 V)
 $U_{eL} \leq 0.9 \text{ V}$ at $-I_{eL} \leq 6 \text{ mA}$
 Switching via TTL components (e.g. SN 74LSXX) is made possible by an internal **1 k Ω** pull-up resistor. Contact closing against 0 V (pin 1 or 10) clears display of the corresponding axis.



External zero reset is only possible during display of actual position.

3 Storage (Pulse, Contact)

Contact closing against 0 V (pin 1 or 10) causes a storage signal to be generated and a measured value to be output over the RS-232-C data interface (see Data Interface, section 4.3).

4 Zero Crossover Signal A zero crossover signal is produced when the display value of the corresponding axis is zero. A zero recognition range (0 to 99.999 mm) can be entered in parameter P 56.*. If the zero recognition range is moved over quickly, signal duration is approximately 180 ms.

Technical Data Open-collector output
Zero crossover signal active HIGH (open-collector transistor inhibited).

Permissible Load Types Resistive load
Inductive load only with quenching diode
High level output voltage $U_{oH} \leq 32 \text{ V}$
(32 V = absolute maximum value of the voltage applied over external resistor or relay)
Low level output voltage $U_{oL} \leq 0.4 \text{ V}$ at $I_{oL} \leq 100 \text{ mA}$
Low level output current $I_{oL} \leq 100 \text{ mA}$
(100 mA = absolute maximum value)
Signal triggering delay $t_{an} = 60 \pm 20 \text{ ms}$
Signal duration $t_s = 180 \text{ ms}$

5 EMERGENCY STOP Signal If a critical error occurs within POSITIP, an EMERGENCY STOP signal is sent over an open-collector output.

Technical Data Open-collector output
EMERGENCY STOP signal active HIGH (open-collector transistor inhibited).

Permissible Load Types Resistive load
Inductive load only with quenching diode
High level output voltage $U_{oH} \leq 32 \text{ V}$
(32 V = absolute maximum value of the voltage applied over external resistor or relay)
Low level output voltage $U_{oL} \leq 0.4 \text{ V}$ at $I_{oL} \leq 100 \text{ mA}$
Low level output current $I_{oL} \leq 100 \text{ mA}$
(100 mA = absolute maximum value)
Signal triggering delay $t_{an} \leq 50 \text{ ms}$

Probe Systems

The PT 850 has been factory-prepared for connection of the HEIDENHAIN KT 110 2D-Edge Finder and the TS 120 3D-Probe System. In the **EXPERT** and **PROGO** modes of operation, the PT 850 can utilize its software for evaluation of the scanning signals. Select the **PROBE** menu with the function "Probe". The **HELP** key calls up the appropriate **HELP** screens with information and guidance on using this menu.

1 KT 110 Edge Finder


The KT 110 2D-Edge Finder is used for probing electrically conductive materials. The KT 110 is inserted into a 20 mm collet. Connection is via the X10 D-subminiature socket on the rear panel of the PT 850.

Technical Data KT 110

Minimum duration of scanning signal: $t \geq 5 \mu\text{s}$
Interval between two probes: $t \geq 100 \text{ ms}$

For a complete technical description, please refer to the operating instructions for the KT 110.

Basic Circuit Diagram



Output voltage of edge finder: $U_{KT} = 3 \text{ V}$

Input current (assumed value): $I_e = 1 \text{ mA}$


On-state voltage at optocoupler (assumed value): $U_D = 1.5 \text{ V}$

2 TS 120 Touch Probe System

The TS 120 Triggering 3D Touch Probe System for HEIDENHAIN controls can be connected via a cable adapter to the X 10 D-subminiature socket on the rear of the unit. The material of the workpiece to be scanned must be electrically non-conducting. The stylus can deflect in the directions $\pm X$, $\pm Y$, and $-Z$. Upon stylus deflection, the TS 120 generates two triggering signals for differential line transmission.

Technical Data TS 120

The stylus can be deflected beyond the triggering point: The maximum stylus deflection in both X/Y direction and in Z direction is 20 mm (when the standard 47 mm stylus is used).
Various stylus lengths available
Various ball diameters available
Triggering signals: TTL square-wave pulses
For a complete technical description, please refer to the TS 120 operating instructions.



**3 Pin Layout X10
(15-pole
D-Subminiature
Socket)**

Pin	Assignment	Probe System
1	Internal shield	KT 110/TS 120
3	Standby signal	TS 120
5	+ 15 V	TS 120
6	+ 5 V	TS 120
8	0 V	KT 110/TS 120
9	Triggering signal	TS 120
10	Triggering signal	TS 120
14	KT +	KT 110
15	KT -	KT 110

Specifications POSITIP 850 For Milling

Mechanical Data

Housing Tabletop model, sheet metal chassis;
Dimensions (W x H x D) 420 mm x 298 mm x 330 mm
(16.5 in. x 11.7 in. x 13.0 in.)

Weight Approx. 11.7 kg (25.7 lb)

Operating Temperature 0 to 45° C (32 to 113° F)

Storage Temperature – 30 to 70° C (– 22 to 158° F)

Visual Display 12-inch monochrome CRT

Electrical Data

Power Supply Primary-clocked variable-voltage power supply 100 V – 240 V
(– 15% to + 10%)
Line frequency 48 Hz to 62 Hz

Power Consumption Approx. 31 W

Encoder Inputs For all HEIDENHAIN linear encoders with sinusoidal scanning signals, also with distance-coded reference marks

Signal amplitudes 7 to 16 μA_{PP}

Permissible input frequency Max. 100 kHz


Data Interface RS-232-C/V.24, for measured values, programs and operating parameters
110/150/300/600/1200/2400/4800/9600/19 200/38 400 baud

Features	
Axes	4 axes with the designations: A, B, C, U, V, W, X, Y or Z Combinations: $X1 \pm X4$ or $X2 \pm X4$ or $X3 \pm X4$
Display Step/ Signal Period	(see Parameters, tables 3.1 and 3.2)
Modes of Operation	BASIC, EXPERT, PROGO
Program Memory	20 different programs or 2000 program blocks
Datum Points	Five independent datum points, selectable as desired via keyboard
Reference Mark Evaluation	For linear and angle encoders with distance-coded reference marks or with one or more reference marks. After a power interruption the relationship between the encoder position and the display value is lost; this relationship is quickly and easily re-established by crossing the reference points.
Functions	<ul style="list-style-type: none"> ● Tool radius compensation ● Distance-To-Go display (traversing to display value 0) ● Bolt-hole circle with graphics ● Radius/Diameter display in 4 axes ● Probe functions for datum acquisition (workpiece edge, centerline or circle center) ● mm/inch display ● Scaling factor in 4 axes (0.100000 to 9.999999) ● Linear machine error compensation \pm (0 to 99999 $\mu\text{m}/\text{m}$) ● INFO: cutting data, pocket calculator functions, stopwatch ● HELP: built-in operating instructions
External Functions	<ul style="list-style-type: none"> ● Zero reset ● Storage command ● Signal output with display value of zero (zero recognition range: ± 99.999 mm)
Edge Finder	Connection of KT 110 (edge finder) or TS 120 (3D Touch Probe System) from HEIDENHAIN
Languages	Two languages can be selected (see Parameters, section 4.2)

Dimensions mm/inch






Front



Angle bracket with threaded bolt M5 x 20

Rear







HEIDENHAIN

Service

DR. JOHANNES HEIDENHAIN GmbH

Dr.-Johannes-Heidenhain-Straße 5

D-8225 Traunreut, Deutschland

☎ Allg. Service (086 69) 31-12 72

☎ TNC-Service (086 69) 31-14 46

FAX (086 69) 98 99

