




HEIDENHAIN

Pilot




Working with the Display Unit

VRZ 460



- ENT** Transfer entry to memory
- 1/2** Datum reset key for selection of appropriate datum
- REF** Reference mark evaluation
- CL** Clear entry/Call parameter key
- +/-** Change sign/Display mode key



Controls

Switch-on/Working in REF Mode

Datum Points

Setting the Datum


Absolute Dimensions/Incremental Dimensions

Positioning in Incremental Dimensions

Parameter Entry

- Function of the CL Key ● Display Range, Display Mode
- Tolerance Check Operating Mode

Error Messages



Switch-on/Working in REF Mode




Read the information in your **Operating Instructions** on initial operation before the first switch-on!

In REF mode the measured value display keeps the datum points in non-volatile storage. After activation of REF mode the reference mark of the encoder must be traversed (on encoders with distance-coded reference marks two reference marks must be traversed).

After traversing the reference mark(s) one time all datum points are reproduced.

The power switch is located at the rear of the housing.

Set "0/1" power switch to **1**:



The display blinks (depending on parameter P1, see Operating Instructions).

The blinking indicates that a power interruption has occurred.


Activate Reference Mark Evaluation:



REF blinks.

The displays indicate the stored REF values and remain "frozen".

Traverse encoder reference mark(s):



Display value changes concurrently: display value is based on the current datum.

REF glows continuously.

The measured value display is ready for operation and is in REF mode. New datum points may now be set.



This is the symbol for the handwheel of your machine or positioning device.

Deactivate REF mode



LED off.

REF mode is no longer active.

Datum points are not in non-volatile storage.

Switch-on/Working in REF Mode

Datum Points

Setting the Datum


Absolute Dimensions/Incremental Dimensions

Positioning in Incremental Dimensions

Parameter Entry

- Function of the CL Key ● Display Range, Display Mode
- Tolerance Check Operating Mode


Error Messages



Datum Points

Using datum points you can set a defined correlation between encoder position and the display value.

The VRZ 460 Display Unit permits the setting of two datum points which are represented by the symbols $\perp 1$ and $\perp 2$. One datum, for example, can be used for incremental positioning.



Switching to the Other Reference Point

| | | |
|---------------------|-------------------------|--|
| $\perp 1 / \perp 2$ | REF 84.551 $\perp 2$ | The display value changes suddenly. The value refers to the current datum indicated with the datum symbol (here $\perp 2$). |
|---------------------|-------------------------|--|

A switch-over to the other datum is possible both in REF mode ("REF" display) as well as outside of the REF mode.

Datum Points

Setting the Datum

Absolute Dimensions/Incremental Dimensions


Positioning in Incremental Dimensions

Parameter Entry

- Function of the CL Key
- Display Range, Display Mode
- Tolerance Check Operating Mode

Error Messages


Actual value/
Input display



Setting the Datum



Non-volatile storage of datum points is only ensured if the datum points are set in the REF mode (see "switch-on/Working in REF mode").



Display range: see parameter P3

Addressing the datum:



REF 25.493
+1

The symbol for datum 1 or 2 appears in the display. Display value refers to the current datum.

▼
Traverse the machine slide or tool to the datum position:



REF 31.864
+1

▼
Enter the new datum value for the current position, e.g. 45.000°:



REF 45 SET
+1

SET lights up. The entry value appears *left-justified* in the display.

▼
Transfer entry to memory:



REF 45.000
+1

SET goes out. The entry value appears *right-justified* in the display.

Falsely entered values can be corrected at any time. If the entry value is still left-justified in the display, then **CL** must be pressed before entering the correct value.

Setting the Datum

Absolute Dimensions/Incremental Dimensions

Positioning in Incremental Dimensions


Parameter Entry

- Function of the CL Key
- Display Range, Display Mode
- Tolerance Check Operating Mode


Error Messages

Absolute Dimensions/Incremental Dimensions

Absolute dimensions refer to one absolute, fixed datum. The rotary table or the tool is to move **to** a certain **position**.



Incremental dimensions refer to the previous position of the rotary table or tool. The rotary table or the tool is to move **by** a certain **amount**.



Absolute Dimensions/Incremental Dimensions

Positioning in Incremental Dimensions

Parameter Entry

- Function of the CL Key ● Display Range, Display Mode
- Tolerance Check Operating Mode


Error Messages

Positioning in Incremental Dimensions

With the datum point 1 the absolute datum is set. Datum 2 can be set to "0" after each positioning operation. By switching to datum 1 you can recall the absolute value.

Example

The tool is at the absolute position $+90^\circ$ and is to be moved in incremental dimensions by $+90^\circ$.



REF 90.000
↓1 The display shows the absolute position value relative to datum 1.

Switch to datum 2:

↓1/2 REF 31.864
↓2 Symbol for datum 2 appears. Display value is based on a previously set datum 2.

Zero datum 2:

0 REF 0.000
ENT ↓2 Tool is at zero position relative to datum 2.

Move tool by $+90^\circ$:

⊙ REF 90.000
↓2 Tool is at position 90° relative to datum 2.

Recall the absolute position:

↓1/2 REF 180.000
↓1 Tool is at position $(90^\circ + 90^\circ =) 180^\circ$ relative to datum 1.

Positioning in Incremental Dimensions

Parameter Entry

- Function of the CL Key
- Display Range, Display Mode
- Tolerance Check Operating Mode

Error Messages

Parameters

The Display Unit has operating parameters in non-volatile storage which immediately become active upon switch-on. The parameters are identified by the letter P followed by a parameter number. More detailed information regarding parameters can be found in the Operating Instructions.

The parameters that are important for operation are included in the pages of this pilot which are marked with the symbol ●.



Invalid parameter values will not be accepted by the display unit!

Parameter Entry (example parameter P3)

Call parameter (Press and hold CL key. Enter parameter number e.g. 3. Then release both keys):

CL **3** P3 2 The parameter and the current parameter value appear in the display.

Enter parameter **value** (e.g. 1):

1 P2 1 The parameter value appears right-justified in the display.

Clear mistaken entry, if necessary:

CL P2 2 The parameter appears with the last valid value.

A new value can then be entered:

0 P2 0 The new parameter appears in the display.

Transfer parameter to memory:

ENT 31.864 The last position value appears in the display.

Parameter Entry



- Function of the CL Key
- Display Range, Display Mode
- Tolerance Check Operating Mode

Error Messages

Function of the CL Key

The function of the CL key is set with the parameter P2. The CL key clears a false entry and calls the previous display value back. With parameter P2 you can also choose whether the display is set to "0" by pressing the CL key (without entering a numerical value).

Parameter P2: Function of the CL Key

| Function of the CL key | Parameter |
|--|-----------|
|  Does not set the display to "0" if the CL key is pressed without entering a numerical value. | P2: 0 |
|  Sets the display to "0" if the CL key is pressed without entering a numerical value. | P2: 1 |




During a datum entry or a parameter entry, display zeroing is not possible with the CL key.

Parameter P3: Display Range

| Display Range | Parameter |
|----------------------------|-----------|
| 0 ... 360° | P3: 0 |
| 0 ... ± 180° | P3: 1 |
| 0 ... ± max. display value | P3: 2 |

Display Mode


With the  key the the display can be switched from decimal-degree display to degrees-minutes-seconds display. It is not possible to switch while entering a value or a parameter.

Example: The Display Unit is in the "decimal-degree" mode.



The position value appears in the display as a decimal number.

Switch to degrees-minutes-seconds display:



The converted decimal value appears in the display in degrees-minutes-seconds.

Recall "decimal degree" display:



The actual position value appears again as a decimal number.

Tolerance Check Operating Mode



The lower and upper limit values are entered via parameters P8 and P9. P8 and P9 can only be called if beforehand the tolerance check operating mode was set with the parameter P7 = 5. In contrast to the previous parameter entry, the parameter number and the upper and lower limit values are displayed alternately in P8 and P9.

The tolerance status is output with the symbols:

> measured value is greater than the upper limit value

= measured value is within tolerance

< measured value is less than the lower measured value



The measured value display can output the tolerance status through two lines for external subsequent processing (see "remote operation" in the operating instructions).

Parameters for the Tolerance Check Operating Mode

| Tolerance Check Operating Mode | Parameter No. | Parameter Value |
|--------------------------------|---------------|-----------------------------|
| Switch to tolerance check mode | P7: | 5 |
| Set lower limit value | P8: | lower limit value with sign |
| Set upper limit value | P9: | upper limit value with sign |



The lower limit value must always be less than the upper limit value filed under parameter P9. In case of false entry, all three tolerance status symbols light up!

< 19.531

When a parameter value is transferred to memory, one of the symbols for tolerance status appears, depending on the current measured value.

Error 01

- A storage command followed another before the data output over the V.24 data interface was concluded.

▶ Acknowledge this error message with **CL**.

Error 02

- A storage command was given although the external unit was not ready or connected (e.g. in the display stop operating mode, see operating instructions).

▶ Acknowledge this error message with **CL**.

A subsequent error of this type will no longer be indicated. An interruption in power activates this error message again.

Error 05

- The encoder output signals are too large and the display unit may no longer be able to interpolate correctly.

▶ Acknowledge this error message with **CL**.

A subsequent error of this type will no longer be indicated. An interruption in power activates this error message again.

Error 06

- The distance-coded reference marks were traversed too quickly.

- The value given in parameter 5 for the distance coding of the reference marks does not correspond to the actual coding of the connected encoder.

▶ Acknowledge this error message with **CL**.

999.9.9.9.9

- All decimal points light up. The maximum display value was exceeded.

- All decimal points blink during an internal character overflow.

Display blinks

- A power interruption has occurred.
- The output signals of the encoder are too weak, e.g. because of scale fouling.
- Encoder is defective or not connected.
- The encoder was traversed too quickly, the permissible input frequency was exceeded.

▶ The blinking can be cleared with **REF**.

In order to work in REF mode the reference marks of the encoder must then be traversed.