

HEIDENHAIN



TNC 620

User's Manual Klartext Programming

NC Software 817600-08 817601-08 817605-08

English (en) 01/2021

Controls and displays

Keys

If you are using a TNC 620 with touch control, you can replace some keystrokes with gestures.

Further information: "Operating the touchscreen", Page 511

Keys on the screen

Кеу	Function
0	Select screen layout
0	Toggle the display between machine operating mode, program- ming mode, and a third desktop
	Soft keys for selecting functions on screen
	△ Switch the soft-key rows

Machine operating modes

Кеу	Function
M	Manual operation
(Electronic handwheel
	Positioning with Manual Data Input
	Program Run, Single Block
.	Program Run, Full Sequence

Programming modes

Кеу	Function
\	Programming
- >	Test Run

Entering and editing coordinate axes and numbers

Кеу		Function
X	V	Select the coordinate axes or enter them in the NC program
0	9	Numbers
	-/+	Decimal separator / Reverse algebraic sign
Р	Ι	Polar coordinate entry / Incremental values
٥		Q parameter programming / Q parameter status
++-		Capture actual position
NO ENT		Skip dialog questions, delete words
ENT		Confirm entry and resume dialog
END		Conclude the NC block, end your input
CE		Clear entries or error message
DEL		Abort dialog, delete program section

Tool functions

Кеу	Function
TOOL DEF	Define tool data in the NC program
TOOL CALL	Call tool data

Managing NC programs and files, control functions

Кеу	Function
PGM MGT	Select or delete NC programs or files, external data transfer
PGM CALL	Define program call, select datum and point tables
MOD	Select MOD functions
HELP	Display help text for NC error messages, call TNCguide
ERR	Display all current error messages
CALC	Show calculator
SPEC FCT	Show special functions
	Currently not assigned

Navigation keys

Кеу		Function
t	+	Position the cursor
GOTO □		Go directly to NC blocks, cycles, and parameter functions
HOME		Navigate to the beginning of a program or table
END		Navigate to the end of the program or table row
PG UP		Navigate up one page
PG DN		Navigate down one page
		Select the next tab in forms
H	Ē	Up/down one dialog box or button

Cycles, subprograms and program section repeats

Кеу		Function
TOUCH PROBE		Define touch probe cycles
CYCL DEF	CYCL CALL	Define and call cycles
LBL SET	LBL CALL	Enter and call subprograms and program section repeats
STOP		Enter program stop in an NC program

Programming path contours

Кеу	Function
APPR DEP	Contour approach and departure
FK	FK free contour programming
L	Straight line
CC 🕈	Circle center/pole for polar coordi- nates
C	Circular arc with center
CR	Circular arc with radius
CT -~~~	Circular arc with tangential transi- tion
CHF o	Chamfer/rounding arc

Potentiometer for feed rate and spindle speed

Feed rate	Spindle speed
50 (0) 150 0 WW. F %	50 (((((((((((((((((((

Contents

Contents

1	Basic information	31
2	First steps	49
3	Fundamentals	65
4	Tools	119
5	Programming contours	137
6	Programming aids	189
7	Miscellaneous functions	221
8	Subprograms and program section repeats	241
9	Programming Q parameters	261
10	Special functions	351
11	Multiple-axis machining	409
12	Data transfer from CAD files	473
13	Pallets	495
14	Operating the touchscreen	511
15	Tables and overviews	525

Contents

1	Basi	c information
		About this manual
	1.1	About this manual
	1.2	Control model, software and features
		Software options
		New functions 81760x-0840

2	First	steps	.49
	2.1	Overview	. 50
	2.2	Switching on the machine	51
	2.2	Acknowledging the power interruption	51
	2.3	Programming the first part	52
		Selecting the operating mode Important controls and displays	
		Creating a new NC program / file management	53
		Defining a workpiece blank	. 54
		Program layout	. 55
		Programming a simple contour	56
		Creating a cycle program	61

3	Fund	damentals	65
	3.1	The TNC 620	66
	5.1	HEIDENHAIN Klartext and DIN/ISO	
		Compatibility	
		compatibility.	
	3.2	Visual display unit and operating panel	67
		Display screen	67
		Setting the screen layout	
		Control panel	
		Screen keypad	69
	3.3	Modes of operation	70
		Manual Operation and El. Handwheel	70
		Positioning with Manual Data Input	70
		Programming	71
		Test Run	
		Program Run, Full Sequence and Program Run, Single Block	72
	3.4	NC fundamentals	73
		Position encoders and reference marks	
		Programmable axes	
		Reference systems	74
		Designation of the axes on milling machines	84
		Polar coordinates	
		Absolute and incremental workpiece positions	
		Selecting the preset	86
	3.5	Creating and entering NC programs	87
		Structure of an NC program in HEIDENHAIN Klartext	87
		Defining the workpiece blank: BLK FORM	88
		Creating a new NC program	91
		Programming tool movements in Klartext	93
		Actual position capture	
		Editing an NC program	
		The control's search function	. 100
	3.6	File management	102
		Files	102
		Displaying externally generated files on the control	104
		Directories	
		Paths	
		Overview: Functions of the file manager	
		Calling the file manager	
		Selecting drives, directories and files Creating a new directory	
		Creating new file	

Copying a single file	109
Copying files into another directory	110
Copying a table	111
Copying a directory	112
Choosing one of the last files selected	112
Deleting a file	113
Deleting a directory	113
Tagging files	114
Renaming a file	115
Sorting files	115
Additional functions	116

4	Tool	S	. 119
	4.1	Entering tool-related data	. 120
		Feed rate F	120
		Spindle speed S	. 121
	4.2	Tool data	122
		Requirements for tool compensation	. 122
		Tool number, tool name	. 122
		Tool length L	. 122
		Tool radius R	. 123
		Delta values for lengths and radii	.124
		Entering tool data into the NC program	. 125
		Calling the tool data	. 126
		Tool change	. 129
	4.3	Tool compensation	. 132
		Introduction	. 132
		Tool length compensation	. 132
		Tool radius compensation	. 133

5	Prog	ramming contours	. 137
	5.1	Tool movements	138
		Path functions	
		FK free contour programming (option 19)	
		Miscellaneous functions M	
		Subprograms and program section repeats	. 139
		Programming with Q parameters	139
	5.2	Fundamentals of path functions	. 140
		Programming tool movements for machining	. 140
	5.3	Approaching and departing a contour	. 144
		Starting point and end point	144
		Overview: Types of paths for contour approach and departure	146
		Important positions for approach and departure	. 147
		Approaching on a straight line with tangential connection: APPR LT	149
		Approaching on a straight line perpendicular to the first contour point: APPR LN	
		Approaching on a circular path with tangential connection: APPR CT	150
		Approaching on a circular path with tangential connection from a straight line to the contour:	
		APPR LCT	
		Departing in a straight line with tangential connection: DEP LT	
		Departing in a straight line perpendicular to the last contour point: DEP LN Departing on a circular path with tangential connection: DEP CT	
		Departing on a circular arc tangentially connecting the contour and a straight line: DEP LCT	
	5.4	Path contours – Cartesian coordinates	
		Overview of path functions	
		Straight line L	
		Inserting a chamfer between two straight lines	
		Rounded corners RND	
		Circle center CC	
		Circular arc C around circle center CC Circular arc CR with fixed radius	
		Circular arc CT with tangential transition	
		Example: Linear movements and chamfers with Cartesian coordinates	
		Example: Circular movements with Cartesian coordinates	
		Example: Full circle with Cartesian coordinates	
	5.5	Path contours – Polar coordinates	166
		Overview	
		Datum for polar coordinates: pole CC	
		Straight line LP	167
		Circular path CP around pole CC	168
		Circle CTP with tangential connection	168
		Helix	169

	Example: Linear movement with polar coordinates	171
	Example: Helix	172
5.6	Path contours – FK free contour programming (option 19)	.173
	Fundamentals	173
	Defining the working plane	.174
	FK programming graphics	175
	Initiating the FK dialog	176
	Pole for FK programming	176
	Free straight line programming	.177
	Free circular path programming	178
	Input possibilities	179
	Auxiliary points	182
	Relative data	.183
	Example: FK programming 1	185
	Example: FK programming 2	186
	Example: FK programming 3	187

6	Prog	ramming aids	
	6.1	GOTO function	
	••••	Using the GOTO key	
	6.2	Screen keypad	191
		Entering text with the screen keypad	
	6.3	Display of NC programs	
		Syntax highlighting	
		Scrollbar	
	6.4	Adding comments	
		Application	
		Entering comments during programming	
		Inserting comments after program entry	
		Entering a comment in a separate NC block	
		Commenting out an existing NC block	
		Functions for editing a comment	194
	6.5	Freely editing an NC program	195
	6.6	Skipping NC blocks	196
		Insert a slash (/)	
		Delete the slash (/)	196
	6.7	Structuring NC programs	
		Definition and applications	
		Displaying the program structure window / Changing the active window	
		Inserting a structure block in the program window	
		Selecting blocks in the program structure window	
	6.8	Calculator	
		Operation	
	6.9	Cutting data calculator	
		Application	
		Working with cutting data tables	202
	6.10	Programming graphics	
		Activating and deactivating programming graphics	
		Generating a graphic for an existing NC program	
		Block number display ON/OFF	
		Erasing the graphic Showing grid lines	
		Magnification or reduction of details	
		magnification of rouderion of detailor	

209
209
211
212
213
213
214
215
215
216

7	Mise	cellaneous functions	221
	7.1	Entering miscellaneous functions M and STOP	222
		Fundamentals	. 222
	7.2	Miscellaneous functions for program run inspection, spindle and coolant	. 223
		Overview	. 223
	7.3	Miscellaneous functions for coordinate entries	.224
		Programming machine-referenced coordinates: M91/M92	. 224
		Moving to positions in a non-tilted input coordinate system with a tilted working plane: M130	. 226
	7.4	Miscellaneous functions for path behavior	.227
		Machining small contour steps: M97	. 227
		Machining open contour corners: M98	. 228
		Feed rate factor for plunging movements: M103	. 229
		Feed rate in millimeters per spindle revolution: M136	
		Feed rate for circular arcs: M109/M110/M111	
		Pre-calculating radius-compensated contours (LOOK AHEAD): M120 (option 21)	
		Superimposing handwheel positioning during program run: M118 (option 21)	
		Retraction from the contour in the tool-axis direction: M140	
		Suppressing touch probe monitoring: M141	
		Deleting basic rotation: M143	
		Automatically retracting the tool from the contour at an NC stop: M148	
		Rounding corners: M197	.239

8	Sub	programs and program section repeats	241
	8.1	Labeling subprograms and program section repeats	
		Label	
	8.2	Subprograms	243
		Operating sequence	
		Programming notes	
		Programming the subprogram	
		Calling a subprogram	
	8.3	Program-section repeats	245
		Label	
		Operating sequence	245
		Programming notes	245
		Programming a program section repeat	246
		Calling a program section repeat	246
	8.4	Calling an external NC program	247
		Overview of the soft keys	
		Operating sequence	248
		Programming notes	248
		Calling an external NC program	250
	8.5	Nesting	252
		Types of nesting	252
		Nesting depth	252
		Subprogram within a subprogram	253
		Repeating program section repeats	
		Repeating a subprogram	255
	8.6	Programming examples	256
		Example: Milling a contour in several infeeds	
		Example: Groups of holes	257
		Example: Group of holes with multiple tools	

9	Prog	gramming Q parameters	261
	9.1	Principle and overview of functions	262
		Q parameter types	
		Programming notes	265
		Calling Q parameter functions	
	9.2	Part families – Q parameters in place of numerical values	
		Application	267
	9.3	Describing contours with mathematical functions	
		Application	
		Overview	
		Programming fundamental operations	269
	9.4	Trigonometric functions	271
		Definitions	
		Programming trigonometric functions	
	9.5	Circle calculations	
		Application	
	9.6	If-then decisions with Q parameters	
		Application	
		Abbreviations used	
		Jump conditions	275
		Programming if-then decisions	
	9.7	Entering formulas directly	277
		Entering formulas	277
		Rules for formulas	277
		Overview	
		Example: Trigonometric function	281
	9.8	Checking and changing Q parameters	
		Procedure	
	9.9	Additional functions	
		Overview	
		FN 14: ERROR – Displaying error messages	
		FN 16: F-PRINT – Formatted output of text and Q parameter values	
		FN 18: SYSREAD – Reading system data	
		FN 19: PLC – Transferring values to the PLC	
		FN 20: WAIT FOR – NC and PLC synchronization	
		FN 29: PLC – Transferring values to the PLC	
		FN 37: EXPORT FN 38: SEND – Send information from the NC program	
		דיז סט. סבוע – ספוע וווטודומנוטוד ווטוד נוופ זיע piografit	

9.10	String parameters	. 304
	String processing functions	. 304
	Assigning string parameters	. 305
	Chain-linking string parameters	306
	Converting a numerical value to a string parameter	307
	Copying a substring from a string parameter	308
	Reading system data	. 309
	Converting a string parameter to a numerical value	310
	Testing a string parameter	311
	Finding the length of a string parameter	312
	Comparing alphabetic priority	. 313
	Reading out machine parameters	314
9.11	Preassigned Q parameters	. 317
	Values from the PLC: Q100 to Q107	317
	Active tool radius: Q108	317
	Tool axis: Q109	318
	Spindle status: Q110	. 318
	Coolant on/off: Q111	. 318
	Overlap factor: Q112	. 318
	Unit of measurement for dimensions in the NC program: Q113	318
	Tool length: Q114	
	Coordinates after probing during program run	. 319
	Deviation between actual and nominal value during automatic tool measurement; for example, wit	
	the TT 160	319
	Tilting the working plane with workpiece angles: Coordinates calculated by the control for rotary	
	axes	. 319
	Measurement results from touch probe cycles	. 320
9.12	Accessing tables with SQL statements	
	Introduction	
	Programming SQL commands	
	Overview of functions	
	SQL BIND	
	SQL EXECUTE	
	SQL FETCH	
	SQL UPDATE	
	SQL INSERT	
	SQL COMMIT	
	SQL ROLLBACK	
	SQL SELECT.	
	Examples	342
9.13	Programming examples	. 344
	Example: Rounding a value	344
	Example: Ellipse	345

Example: Concave cylinder machined with Ball-nose cutter	347
Example: Convex sphere machined with end mill	349

10	Special functions		351
	10.1	Overview of special functions	. 352
		Main menu for SPEC FCT special functions	
		Program defaults menu	
		Functions for contour and point machining menu	
		Menu for defining different Klartext functions	354
	10.2	Function mode	. 355
		Program function mode	
		Function Mode Set	
	10.0		250
	10.3	Working with the parallel axes U, V and W	
		FUNCTION PARAXCOMP DISPLAY	
		Deactivating FUNCTION PARAXCOMP	
		FUNCTION PARAXMODE	
		Deactivating FUNCTION PARAXMODE	
		Example: Drilling with the W axis	
	10.4	Machining with polar kinematics	365
		Overview	. 365
		Activating FUNCTION POLARKIN	
		Deactivating FUNCTION POLARKIN	
		Example: SL cycles in the polar kinematics	. 370
	10.5	File functions	. 372
		Application	. 372
		Defining file functions	372
		OPEN FILE	. 373
	10.6	Defining coordinate transformations	. 375
		Overview	
		TRANS DATUM AXIS	376
		TRANS DATUM TABLE	. 377
		TRANS DATUM RESET	378
	10.7	Modifying presets	. 379
		Activating a preset	. 379
		Copying a preset	380
		Correcting a preset	
	10.8	Compensation table	382
		- Application	
		Types of compensation tables	
		Creating a compensation table	

	Activate the compensation table	. 383
	Editing a compensation table during program run	. 384
10.9	Accessing table values	. 385
	Application	. 385
	Reading a table value	385
	Writing a table value	. 386
	Adding a table value	. 387
10.10	Monitoring of configured machine components (option 155)	389
	Application	. 389
	Starting monitoring	389
10.11	Defining a counter	. 390
	Application	
	Defining FUNCTION COUNT	
10 10	Creative tout files	202
10.12	Creating text files	
	Application	
	Opening and exiting a text file Editing texts	
	Deleting and re-inserting characters, words and lines	
	Editing text blocks	
	Finding text sections	
10 13	Freely definable tables	396
10.15	Fundamentals	
	Creating a freely definable table	
	Editing the table format	
	Switching between table and form view	
	FN 26: TABOPEN – Open a freely definable table	
	FN 27: TABWRITE: Write to a freely definable table	
	FN 28: TABREAD – Read from a freely definable table	. 400
	Adapting the table format	.400
10.14	Pulsing spindle speed FUNCTION S-PULSE	401
	Programming a pulsing spindle speed	401
	Resetting the pulsing spindle speed	. 402
10.15	Dwell time FUNCTION FEED	. 403
	Programming a dwell time	.403
	Resetting the dwell time	. 404
10.16	Dwell time FUNCTION DWELL	. 405
	Programming a dwell time	

10.17 Lift off tool at NC stop: FUNCTION LIFTOFF	406
Programming tool lift-off with FUNCTION LIFTOFF	406
Resetting the lift-off function	408

11	11 Multiple-axis machining		409
	11.1	Functions for multiple axis machining	410
	44.0		
	11.2	The PLANE function: Tilting the working plane (option 8)	
		Introduction Overview	
		Defining the PLANE function	
		Position display	
		Resetting PLANE function	
		Defining the working plane with the spatial angle: PLANE SPATIAL	
		Defining the working plane with the projection angle: PLANE PROJECTED	
		Defining the working plane with the Euler angle: PLANE EULER	
		Defining the working plane with two vectors: PLANE VECTOR	
		Defining the working plane via three points: PLANE POINTS	
		Defining the working plane via a single incremental spatial angle: PLANE RELATIV	
		Tilting the working plane through axis angle: PLANE AXIAL	
		Defining the positioning behavior of the PLANE function	
		Automatic tilting into position MOVE/TURN/STAY	
		Selection of tilting possibilities SYM (SEQ) +/	
		Selection of the transformation type	
		Tilting the working plane without rotary axes	440
	11.3	Inclined-tool machining in a tilted plane (option 9)	441
		Function	441
		Inclined-tool machining via incremental traverse of a rotary axis	
		Inclined-tool machining via normal vectors	442
	11.4	Miscellaneous functions for rotary axes	443
		Feed rate in mm/min on rotary axes A, B, C: M116 (option 8)	
		Shorter-path traverse of rotary axes: M126	
		Reducing display of a rotary axis to a value less than 360°: M94	
		Retaining the position of the tool tip during the positioning of tilting axes (TCPM): M128	440
		(option 9)	446
		Selecting tilting axes: M138	
		Compensating the machine kinematics in ACTUAL/NOMINAL positions at end of block: M144	110
		(Option 9)	449
	11.5	FUNCTION TCPM (option 9)	
		Function	
		Defining FUNCTION TCPM	
		Effect of the programmed feed rate	
		Interpretation of the programmed rotary axis coordinates	
		Orientation interpolation between the start position and end position	
		Selection of tool reference point and center of rotation	
		Resetting FUNCTION TCPM	455

11.6	Three-dimensional tool compensation (option 9)	456
	Introduction	456
	Suppressing error messages with positive tool oversize: M107	457
	Definition of a normalized vector	458
	Permissible tool shapes	459
	Using other tools: Delta values	459
	3-D compensation without TCPM	460
	Face Milling: 3D compensation with TCPM	461
	Peripheral milling: 3-D radius compensation with TCPM and radius compensation (RL/RR)	463
	Interpretation of the programmed path	464
11.7	Running CAM programs	466
	From 3-D model to NC program	466
	Considerations required for post processor configuration	467
	Please note the following for CAM programming	469
	Possibilities for intervention on the control	471
	ADP motion control	471

12	Data	transfer from CAD files	.473
	12.1	Screen layout of the CAD viewer	474
		Fundamentals of the CAD viewer	. 474
	12.2	CAD Import (option 42)	475
		Application	475
		Using the CAD viewer	
		Opening the CAD file	
		Basic settings	477
		Setting layers	
		Setting a preset	480
		Setting the datum	482
		Selecting and saving a contour	486
		Selecting and saving machining positions	490

13	Palle	ts	.495
	13.1	Pallet management (option number 22)	. 496
		Application	. 496
		Selecting a pallet table	. 499
		Inserting or deleting columns	. 499
		Fundamentals of tool-oriented machining	500
	40.0		500
	13.2	Batch Process Manager (option 154)	. 502
	13.2	Application	. 502
	13.2		. 502
	13.2	Application	. 502 . 502
	13.2	Application Fundamentals	502 . 502 505 508

14	Oper	ating the touchscreen	.511
	14.1	Display unit and operation	. 512
		Touchscreen	
		Operating panel	.513
	14.2	Gestures	. 515
		Overview of possible gestures	. 515
		Navigating in the table and NC programs	. 516
		Operating the simulation	517
		Operating the CAD viewer	518

15	5 Tables and overviews5			
	15.1 System data			
	15.1	System data	526	
		List of FN 18 functions	526	
		Comparison: FN 18 functions	555	
	15.2	Overview tables	559	
		Miscellaneous functions	559	
		User functions	561	
	15.3	Differences between the TNC 620 and the iTNC 530	564	
		Comparison: PC software	564	
		Comparison: User functions	564	
		Comparison: Miscellaneous functions	569	
		Comparator: Cycles	571	
		Comparison: Touch probe cycles in the Manual operation and Electronic handwheel operating		
		modes	574	
		Comparison: Probing system cycles for automatic workpiece control	575	
		Comparison: Differences in programming	577	
		Comparison: Differences in Test Run, functionality	580	
		Comparison: Differences in Test Run, operation	581	
		Comparison: Differences in programming station	581	

Basic information

1.1 About this manual

Safety precautions

Comply with all safety precautions indicated in this document and in your machine tool builder's documentation!

Precautionary statements warn of hazards in handling software and devices and provide information on their prevention. They are classified by hazard severity and divided into the following groups:

ADANGER

Danger indicates hazards for persons. If you do not follow the avoidance instructions, the hazard **will result in death or severe injury.**

WARNING

Warning indicates hazards for persons. If you do not follow the avoidance instructions, the hazard **could result in death or serious injury**.

Caution indicates hazards for persons. If you do not follow the avoidance instructions, the hazard **could result in minor or moderate injury**.

NOTICE

Notice indicates danger to material or data. If you do not follow the avoidance instructions, the hazard **could result in property damage**.

Sequence of information in precautionary statements

All precautionary statements comprise the following four sections:

- Signal word indicating the hazard severity
- Type and source of hazard
- Consequences of ignoring the hazard, e.g.: "There is danger of collision during subsequent machining operations"
- Escape Hazard prevention measures

Informational notes

Observe the informational notes provided in these instructions to ensure reliable and efficient operation of the software. In these instructions, you will find the following informational notes:



The information symbol indicates a **tip**.

A tip provides additional or supplementary information.

0

This symbol prompts you to follow the safety precautions of your machine tool builder. This symbol also indicates machine-dependent functions. Possible hazards for the operator and the machine are described in the machine manual.



The book symbol represents a **cross reference** to external documentation, e.g. the documentation of your machine tool builder or other supplier.

Have you found any errors or would you like to suggest changes?

We continuously strive to improve our documentation for you. Please help us by sending your suggestions to the following e-mail address:

tnc-userdoc@heidenhain.de

1.2 Control model, software and features

This manual describes programming functions provided by controls as of the following NC software numbers.

Control model	NC software number
TNC 620	817600-08
TNC 620 E	817601-08
TNC 620 Programming Station	817605-08

The suffix E indicates the export version of the control. The following software option is unavailable or only available to a limited extent in the export version:

 Advanced Function Set 2 (option 9) limited to four-axis interpolation

The machine manufacturer adapts the usable features of the control to his machine by setting appropriate machine parameters. Some of the functions described in this manual may therefore not be among the features provided by the control on your machine tool.

Control functions that may not be available on your machine include:

Tool measurement with the TT

In order to find out about the actual features of your machine, please contact the machine manufacturer.

Many machine manufacturers, as well as HEIDENHAIN, offer programming courses for the HEIDENHAIN controls. Participation in one of these courses is recommended to familiarize yourself thoroughly with the control's functions.



m

User's Manual for Programming of Machining Cycles:

All functions provided by the machining cycles are described in the User's Manual for **Programming of Machining Cycles**. Please contact HEIDENHAIN if you need this User's Manual. ID: 1303427-xx

User's Manual for Programming of Measuring Cycles for Workpieces and Tools:

All functions provided by the touch-probe cycles are described in the User's Manual for **Programming of Measuring Cycles for Workpieces and Tools**. Please contact HEIDENHAIN if you need this User's Manual. ID: 1303431-xx



User's Manual for Setup, Testing and Running NC Programs:

All information for setting up the machine as well as for testing and running your NC programs is provided in the User's Manual for **Setup, Testing and Running NC Programs**. Please contact HEIDENHAIN if you need this User's Manual. ID: 1263172-xx

Software options

The TNC 620 features various software options, each of which can be enabled separately by your machine tool builder. The respective options provide the functions listed below:

Additional Axis (option 0 and optio	n 1)
Additional axis Additional control loops 1 and 2	
Advanced Function Set 1 (option 8)	
Advanced functions (set 1)	Machining with rotary tables
	 Cylindrical contours as if in two axes
	Feed rate in distance per minute
	Coordinate conversions:
	Tilting the working plane
Advanced Function Set 2 (option 9)	
Advanced functions (set 2)	3-D machining:
Export license required	3-D tool compensation through surface-normal vectors
	 Using the electronic handwheel to change the angle of the swive
	head during program run;
	the position of the tool point remains unchanged (TCPM = T ool C enter P oint M anagement)
	 Keeping the tool normal to the contour
	 Tool radius compensation normal to the tool direction
	 Manual traverse in the active tool-axis system
	Interpolation:
	Linear in > 4 axes (export license required)
Touch Probe Functions (option 17)	
Touch probe functions	Touch probe cycles:
	 Compensation of tool misalignment in automatic mode
	Set the preset in the Manual operation mode of operation
	Presetting in automatic mode
	 Automatically measuring workpieces
	 Tools can be measured automatically
HEIDENHAIN DNC (option 18)	
	Communication with external PC applications over COM component
Advanced Programming Features (option 19)
Expanded programming functions	FK free contour programming:
	Programming in HEIDENHAIN conversational format with graphic

support for workpiece drawings not dimensioned for NC

Advanced Programming Features (op	
	Fixed cycles:
	 Peck drilling, reaming, boring, counterboring, centering
	 Milling internal and external threads
	 Milling of rectangular and circular pockets and studs
	 Clearing level and oblique surfaces
	 Milling of straight and circular slots
	 Circular and linear point patterns
	 Contour train, contour pocket, trochoidal contour slot
	Engraving
	 OEM cycles (special cycles developed by the machine tool builder) can be integrated
Advanced Graphic Features (option 2	0)
Expanded graphic functions	Program-verification graphics, program-run graphics
	Plan view
	Projection in three planes
	3-D view
Advanced Function Set 3 (option 21)	
Expanded functions Group 3	Tool compensation:
	M120: Radius-compensated contour look ahead for up to 99 NC blocks (LOOK AHEAD)
	3-D machining:
	M118: Superimpose handwheel positioning during program run
Pallet Management (option 22)	
Pallet management	Processing workpieces in any sequence
CAD Import (option 42)	
CAD import	Support for DXF, STEP and IGES
	 Adoption of contours and point patterns
	 Simple and convenient specification of presets
	 Selecting graphical features of contour sections from conversational programs
KinematicsOpt (option 48)	
Optimizing the machine kinematics	Backup/restore active kinematics
	Test active kinematics
	 Optimize active kinematics
OPC UA NC Server (1 to 6) (options 5	6 to 61)
Standardized interface	The OPC UA NC Server provides a standardized interface (OPC UA) for external access to the control's data and functions
	These software options allow you to create up to six parallel client

Extended tool management Python-based Remote Desktop Manager (option 133) Windows on a separate computer unit Computer units Windows on a separate computer unit Incorporated in the control's interface State Reporting Interface – SRI (option 137) HTTP accesses to the control status Reading out the times of status changes Reading out the active NC programs Determination of dynamically caused position deviation acceleration Compensation of axis couplings Determination of the TCP (Tool Center Point) Position Adaptive Control – PAC (option 142) Adaptation of the control parameters depending on the the axes in the working space Adaptive position control Adaptation of the control parameters depending on the acceleration of the control parameters depending on the of the workpiece Adaptive load control Automatic determination of workpiece weight and frict Adaptive control – LAC (option 143) Adaptation of the control parameters depending on the of the workpiece Active Chatter Control – ACC (option 145) Datematic function for chatter control during machini	
Remote operation of external computer units Windows on a separate computer unit Incorporated in the control's interface Incorporated in the control's interface State Reporting Interface – SRI (option 137) Reading out the times of status changes HTTP accesses to the control status Reading out the times of status changes Reading out the active NC programs Cross Talk Compensation – CTC (option 141) Compensation of axis couplings Determination of dynamically caused position deviation acceleration Compensation of axis couplings Determination of the TCP (Tool Center Point) Position Adaptive Control – PAC (option 142) Adaptation of the control parameters depending on the the axes in the working space Adaptive position control Adaptation of the control parameters depending on the acceleration of an axis Load Adaptive Control – LAC (option 143) Adaptation of the control parameters depending on the acceleration of an axis Adaptive load control Automatic determination of workpiece weight and frict Adaptation of the control parameters depending on the of the workpiece Adaptation of the control parameters depending on the of the workpiece Active Chatter Control – ACC (option 145) Every parameters depending on the of the workpiece Active chatter control Fully automatic function for chatter control during machinin Machine	
computer units = Incorporated in the control's interface State Reporting Interface – SRI (option 137) HTTP accesses to the control status = Reading out the times of status changes = Reading out the active NC programs Cross Talk Compensation – CTC (option 141) Compensation of axis couplings = Determination of dynamically caused position deviation acceleration = Compensation of datis couplings = Determination of the TCP (Tool Center Point) Position Adaptive Control – PAC (option 142) = Adaptation of the control parameters depending on the the axes in the working space = Adaptation of the control parameters depending on the acceleration of an axis = Adaptation of the control parameters depending on the acceleration of an axis Load Adaptive Control – LAC (option 143) = Automatic determination of workpiece weight and frict = Adaptation of the control parameters depending on the of the workpiece = Adaptation of the control parameters depending on the of the workpiece Adaptive load control = Automatic determination of workpiece weight and frict = Adaptation of the control parameters depending on the of the workpiece Active Chatter Control – ACC (option 145) Active chatter control Fully automatic function for chatter control during machini Machine Vibration Control – MVC (option 146) Damping of machine oscillations for improvi	
State Reporting Interface – SRI (option 137) HTTP accesses to the control status = Reading out the times of status changes = Reading out the active NC programs Cross Talk Compensation – CTC (option 141) Compensation of axis couplings = Determination of dynamically caused position deviation acceleration = Compensation of axis couplings = Determination of the TCP (Tool Center Point) Position Adaptive Control – PAC (option 142) = Adaptation of the control parameters depending on the the axes in the working space = Adaptation of the control parameters depending on the acceleration of an axis = Adaptation of the control parameters depending on the acceleration of an axis Load Adaptive Control – LAC (option 143) = Automatic determination of workpiece weight and frict Adaptive load control = Automatic determination of workpiece weight and frict = Adaptation of the control parameters depending on the of the workpiece Active Chatter Control – ACC (option 145) Active chatter control Fully automatic function for chatter control during machini Machine Vibration Control – MVC (option 146) Tulty automatic function for improving the workpi	
HTTP accesses to the control status = Reading out the times of status changes = Reading out the active NC programs Cross Talk Compensation – CTC (option 141) Compensation of axis couplings = Determination of dynamically caused position deviation acceleration = Compensation Adaptive Control – PAC (option 142) = Adaptation of the CONTROL PAC (option 142) Adaptive position control = Adaptation of the control parameters depending on the the axes in the working space = Adaptation of the control parameters depending on the acceleration of an axis = Adaptation of the control parameters depending on the acceleration of an axis Load Adaptive Control – LAC (option 143) = Automatic determination of workpiece weight and frict = Adaptation of the control parameters depending on the acceleration of the workpiece = Adaptation of the control parameters depending on the acceleration of an axis Load Adaptive load control = Automatic determination of workpiece weight and frict = Adaptation of the control parameters depending on the of the workpiece Active Chatter Control – ACC (option 145) Active chatter control Fully automatic function for chatter control during machini Machine Vibration Control – MVC (option 146) Damping of machine oscillations for improving the workpi	
 Reading out the active NC programs Cross Talk Compensation – CTC (option 141) Compensation of axis couplings Determination of dynamically caused position deviation acceleration Compensation of the TCP (Tool Center Point) Position Adaptive Control – PAC (option 142) Adaptive position control Adaptation of the control parameters depending on the the axes in the working space Adaptive Control – LAC (option 143) Adaptive load control Automatic determination of workpiece weight and frict Adaptation of the control parameters depending on the of the workpiece Adaptation of the control parameters depending on the acceleration of an axis 	
Cross Talk Compensation – CTC (option 141) Compensation of axis couplings Determination of dynamically caused position deviation acceleration Compensation of the TCP (Tool Center Point) Position Adaptive Control – PAC (option 142) Adaptive position control Adaptation of the control parameters depending on the the axes in the working space Adaptation of the control parameters depending on the acceleration of an axis Load Adaptive Control – LAC (option 143) Adaptation of the control parameters depending on the acceleration of an axis Load Adaptive load control Automatic determination of workpiece weight and frict Adaptation of the control parameters depending on the of the workpiece Active Chatter Control – ACC (option 145) Active chatter control Fully automatic function for chatter control during machini Machine Vibration Control – MVC (option 146) Vibration damping for machines Damping of machine oscillations for improving the workpi	
Compensation of axis couplings Determination of dynamically caused position deviation acceleration Compensation of the TCP (Tool Center Point) Position Adaptive Control – PAC (option 142) Adaptive position control Adaptation of the control parameters depending on the the axes in the working space Adaptation of the control parameters depending on the acceleration of an axis Load Adaptive Control – LAC (option 143) Automatic determination of workpiece weight and frict Adaptation of the control parameters depending on the of the workpiece Adaptive load control Automatic determination of workpiece weight and frict Adaptation of the control parameters depending on the of the workpiece Active Chatter Control – ACC (option 145) Active chatter control Fully automatic function for chatter control during machinimized function for improving the workpiece 	
acceleration Compensation of the TCP (Tool Center Point) Position Adaptive Control – PAC (option 142) Adaptive position control Adaptive position control Adaptive position control Adaptive Control – LAC (option 143) Adaptive load control Adaptive load control Adaptive load control Adaptation of the control parameters depending on the of the workpiece Active Chatter Control – ACC (option 145) Active chatter control Fully automatic function for chatter control during machini Machine Vibration Control – MVC (option 146) Vibration damping for machines	
Position Adaptive Control – PAC (option 142) Adaptive position control Adaptation of the control parameters depending on the the axes in the working space Adaptation of the control parameters depending on the acceleration of an axis Load Adaptive Control – LAC (option 143) Automatic determination of workpiece weight and frict Adaptation of the control parameters depending on the of the workpiece Adaptive load control Automatic determination of workpiece weight and frict Adaptation of the control parameters depending on the of the workpiece Active Chatter Control – ACC (option 145) Active chatter control Fully automatic function for chatter control during machinit Machine Vibration Control – MVC (option 146) Vibration damping for machines Damping of machine oscillations for improving the workpiece 	
Adaptive position control Adaptation of the control parameters depending on the the axes in the working space Adaptation of the control parameters depending on the acceleration of an axis Load Adaptive Control – LAC (option 143) Adaptive load control Automatic determination of workpiece weight and frict Adaptation of the control parameters depending on the of the workpiece Adaptive load control Automatic determination of workpiece weight and frict Adaptation of the control parameters depending on the of the workpiece Active Chatter Control – ACC (option 145) Active chatter control Fully automatic function for chatter control during machini Machine Vibration Control – MVC (option 146) Vibration damping for machines Damping of machine oscillations for improving the workpi 	
the axes in the working space Adaptation of the control parameters depending on the acceleration of an axis Load Adaptive Control – LAC (option 143) Adaptive load control Automatic determination of workpiece weight and frict Adaptive load control Adaptation of the control parameters depending on the of the workpiece Active Chatter Control – ACC (option 145) Active chatter control Fully automatic function for chatter control during machini Machine Vibration Control – MVC (option 146) Damping of machine oscillations for improving the workpiece	
acceleration of an axis Load Adaptive Control – LAC (option 143) Adaptive load control Automatic determination of workpiece weight and frict Adaptation of the control parameters depending on the of the workpiece Active Chatter Control – ACC (option 145) Active chatter control Fully automatic function for chatter control during machinin Machine Vibration Control – MVC (option 146) Damping of machine oscillations for improving the workpi	e position of
Adaptive load control Automatic determination of workpiece weight and frict Adaptation of the control parameters depending on the of the workpiece Active Chatter Control – ACC (option 145) Active chatter control Fully automatic function for chatter control during machinin Machine Vibration Control – MVC (option 146) Damping of machine oscillations for improving the workpiece	e speed or
 Adaptation of the control parameters depending on the of the workpiece Active Chatter Control – ACC (option 145) Active chatter control Fully automatic function for chatter control during machinic Machine Vibration Control – MVC (option 146) Vibration damping for machines Damping of machine oscillations for improving the workpi 	
Active chatter controlFully automatic function for chatter control during machiniMachine Vibration Control – MVC (option 146)Damping of machine oscillations for improving the workpi	
Machine Vibration Control – MVC (option 146) Vibration damping for machines Damping of machine oscillations for improving the workpi	
Vibration damping for machines Damping of machine oscillations for improving the workpi	ng
quality through the following functions:	ece surface
 Active Vibration Damping (AVD) 	
 Frequency Shaping Control (FSC) 	
Batch Process Manager (option 154)	
Batch process manager Planning of production orders	
Component Monitoring (option 155)	
Component monitoring withoutMonitoring configured machine components for overloadexternal sensors	
Opt. contour milling (option 167)	
Optimized contour cycles Cycles for machining any pockets and islands using trocho	

Further options available

 HEIDENHAIN offers further hardware enhancements and software options that can be configured and implemented only by your machine tool builder. This includes functional safety (FS), for example.
 For more information, please refer to your machine tool builder's documentation or the HEIDENHAIN brochure titled **Options and Accessories**.

ID: 827222-xx

Feature Content Level (upgrade functions)

Along with software options, significant further improvements of the control software are managed via the **F**eature **C**ontent **L**evel upgrade functions. If you install a software update on your control you do not automatically have the functions available as covered by the FCL.



All upgrade functions are available to you without surcharge when you receive a new machine.

Upgrade functions are identified in the manual as **FCL n**. The **n** signifies the serial number of the development status.

You can purchase a code number in order to permanently enable the FCL functions. For more information, contact your machine tool builder or HEIDENHAIN.

Intended place of operation

The control complies with the limits for a Class A device in accordance with the specifications in EN 55022, and is intended for use primarily in industrially-zoned areas.

Legal information

The control software contains open-source software that is subject to special terms of use. These special terms of use have priority. Further information is available on the control as follows:

- Press the MOD key
- Select the General information group in the MOD menu
- Select the License information MOD function

Furthermore, the control software contains binary libraries of the OPC UA software from Softing Industrial Automation GmbH. For these libraries, additionally and preferentially the terms of use agreed between HEIDENHAIN and Softing Industrial Automation GmbH shall apply.

When using the OPC UA NC server or DNC server, you can influence the behavior of the control. Therefore, before using these interfaces for productive purposes, verify that the control can still be operated without malfunctions or drops in performance. The manufacturer of the software that uses these communication interfaces is responsible for performing system tests.

New functions 81760x-08

M

Overview of new and modified software functions

Further information about the previous software versions is presented in the **Overview of New and Modified Software Functions** documentation. Please contact HEIDENHAIN if you need this documentation. ID: 1322094-xx

- The BLK FORM FILE function allows you to use STL files to define the workpiece blank, and optionally the finished part, by specifying the path of the files. This enables you to use, e.g., 3-D models from the CAD system in your NC program
 Further information: "Defining the workpiece blank: BLK FORM", Page 88
- FUNCTION MODE SET allows you to activate settings defined by the machine tool builder (e.g., changes to the range of traverse) from within the NC program

Further information: "Function Mode Set", Page 355

The function **PRESET SELECT** allows you to activate a preset from the preset table. You can choose to retain active transformations and select the preset to which the function should apply.

Further information: "Activating a preset", Page 379

The function **PRESET COPY** allows you to copy a preset defined in the preset table to another row. You can optionally activate the copied preset and retain the active transformations.

Further information: "Copying a preset", Page 380

The function **PRESET CORR** allows you to correct the active preset.

Further information: "Correcting a preset", Page 380

- The function OPEN FILE allows the control to open different file formats (e.g., PNG files) using a suitable additional tool.
 Further information: "OPEN FILE", Page 373
- The function **POLARKIN** allows you to activate a polar kinematic model. In a polar kinematic model, the control performs movements using a rotary axis and two linear axes. You define the positioning behavior of the rotary axis, as well as whether machining is allowed at the center of rotation of the rotary axis.

Further information: "Machining with polar kinematics", Page 365

- The function TABDATA allows you to access the tool table and the compensation tables (*.tco and *.wco) during program run. In order to access the compensation tables, you need to activate them.
 - The function TABDATA READ allows you to read a value from a table and save it to a Q, QL, QR, or QS parameter.
 - Further information: "Reading a table value", Page 385
 - The function TABDATA WRITE allows you to write a value from a Q, QL, QR, or QS parameter into a table.
 Further information: "Writing a table value", Page 386

The function TABDATA ADD allows you to add a value from a Q, QL, or QR parameter to a value contained in a table.

Further information: "Adding a table value", Page 387

The function **MONITORING** allows you to visualize the monitoring of a defined machine component.

Further information: "Monitoring of configured machine components (option 155)", Page 389

The APPLY FILE NAME soft key has been added to the selection window provided by the SELECT FILE soft key. If the called file is located in the same directory as the file you are calling it from, pressing this soft key loads the name of the file without its path.

Further information: "Calling an external NC program", Page 250

In the mask file of the FN 16: F-PRINT (ISO: D16) function, you can define whether the control shows or hides blank lines for undefined QS parameters.

Further information: "Creating a text file", Page 291

- The FN 18: SYSREAD functions (ISO:D18) have been enhanced:
 - FN 18: SYSREAD (D18) ID50: values in the tool table
 - NR45: value in the RCUTS column
 - NR46: value in the LU column
 - NR47: value in theRN column
 - FN 18: SYSREAD (D18) ID950: values in the tool table of the current tool
 - NR45: value in the RCUTS column
 - NR46: value in the LU column
 - NR47: value in theRN column
 - FN 18: SYSREAD (D18) ID1070 NR1: active feed-rate limit through the F MAX soft key

Further information: "System data", Page 526

- The function SYSSTR(ID10321 NR20) allows you to determine the number of the current week in accordance with ISO 8601 Further information: "Reading system data", Page 309
- When you double-click a layer in the CAD-Viewer, the control marks the first contour element of this layer.

Further information: "Setting layers", Page 479

You can transfer the data from the CAD Import clipboard to an NC program as well as to other applications (e.g., Leafpad).
 Further information: "Application" Page 475

Further information: "Application", Page 475

Further information: User's Manual for Setup, Testing and Running NC Programs

HEIDENHAIN OPC UA NC Server (options 56 to 61)

OPC UA provides a standardized interface for secure data exchange between products independent of the manufacturer. HEIDENHAIN provides the **HEIDENHAIN OPC UA NC Server** for data exchange with the control. These software options allow you to create up to six parallel client connections. The **Connection Assistant** function has been added to the HEROS menu for setting up the connection. If user administration is active, you link the connections to specific users.

- As part of the HEIDENHAIN OPC UA NC Server (options 56 to 61), the machine parameter CfgMachineInfo (no. 131700), which allows you to define information about the machine, has been added.
- If you use TARGET in the BLK FORM FILE function to define a finished part, you can show or hide it by soft key in the Test Run operating mode (option 20)
- In Test Run operating mode, you can use the EXPORT WORKPIECE soft key to export the current status of the motion simulation as a 3-D model in STL format.
- In Test Run operating mode, the control provides an extended collision monitoring function that checks for collisions between the workpiece and the tool or tool holder. You can activate extended collision monitoring by soft key.
- You can use M3D and STL files (e.g., from the CAD system) as tool carrier files.
- The control supports USB data media with the NTFS file system.
- The control includes the additional tool Parole, which allows you to open video files.
- If a feed-rate limit has been activated with the F MAX soft key, the control displays an exclamation mark after the feed-rate value in the general status display.
- When the PARAXCOMP DISPLAY function is active, the control displays a corresponding icon in the general status display.
- When the PARAXCOMP MOVE function is active, the control displays a corresponding icon in the general status display.
- When the functions **PARAXMODE** oder **POLARKIN** are active, the control displays a corresponding icon in the general status display.
- In the RCUTS column of the tool table, you define the front-face cutting width of a tool (e.g., for indexable inserts).
- You define the usable length of a tool in the LU column of the tool table. The usable length limits the plunging depth of the tool in cycles.
- You define the neck radius of the tool in the RN column of the tool table. This allows the control to display the tool neck correctly in the simulation (e.g., for side milling cutters).
- A link to the Firewall settings HEROS function has been added to the External access MOD function.
- A link to the OPC UA NC Server License Settings HEROS function (options 56 to 61) has been added within the External access MOD function.
- If the machine tool builder has defined the parameter CfgOemInfo (no. 131700), then the control displays the Info about machine manufacturer area in the General information MOD group.

- If the machine operator has defined the CfgMachineInfo parameter (no. 131600), the control shows the Machine information area within the General information MOD group.
- Remote Desktop Manager (option 133) allows you to create private connections if user administration is active. Private connections are visible to and usable by the creator only.
- When user administration is active, the control automatically disables the LSV2 connections of the serial interfaces (COM1 and COM2) for security purposes.
- When user administration is active, you can create user-specific private network drive connections. Single Sign On allows you to connect to an encrypted network drive while logging on to the control.
- When configuring the user administration, you can use the Autologin function to define a user who will automatically be logged on by the control during booting.
- The machine parameter CfgTTRectStylus (no. 114300) has been added. This parameter allows you to define settings for a tool touch probe with a cuboid probe contact.

Changed functions 81760x-08

- You can use the RND element (ISO: G24) to connect circles that are perpendicular to the machining plane instead of lying in the machining plane.
- The M109 function allows the control to keep the feed rate constant at the cutting edge, including during approach and departure.

Further information: "Feed rate for circular arcs: M109/M110/ M111", Page 230

 The function M120 (option 21) for look-ahead calculation of a radius-compensated contour is no longer reset by milling cycles (option 19)

Further information: "Pre-calculating radius-compensated contours (LOOK AHEAD): M120 (option 21)", Page 232

- You can use UTF-8 character encoding in the mask file of FN 16: F-PRINT (ISO: D16)
- The priority of arithmetic operations has been changed in the Q parameter formula

Further information: "Rules for formulas", Page 277

- Scrolling in the structure window works in the same way as scrolling in the NC program You can define the position of the active structure block by soft key.
- The control uses the active unit of measure (mm or inches) for calculations in the cutting data calculator.
- Path finding between individual drilling positions has been optimized in the CAD-Viewer
- If, after a hardware change or an update, an error occurs when the control is booting, the control will automatically open the error window and display a question-type error. The control displays soft keys providing different response options.

Further information: "Detailed error messages", Page 209

The FILTER soft key in the error window allows the control to classify both error messages and warnings. As a result, the list of pending messages becomes shorter and easier to read.

Further information: "FILTER soft key", Page 210

In pallet tables (option 22), the control can also open NC programs containing blank spaces.

Further information: User's Manual for Setup, Testing and Running NC Programs

Option 146 has been renamed as Machine Vibration Control MVC

The Frequency Shaping Control (**FSC**) function has been added; it allows the control to suppress low-frequency machine vibrations.

- The control uses hatch marking to depict threads in the simulation.
- In the operating modes Program run, single block and Program run, full sequence, the Batch Process Manager (option 154) shows up to two statuses next to each other in the first column.
- In Program run, single block operating mode, the control interprets the workpiece blank definition as a single NC block only.

- The control displays the tool index in the block scan pop-up window if needed.
- The control takes into account manual axes when returning to the contour.
- When the PARAXCOMP DISPLAY function or the PARAXCOMP MOVE function is active, the control displays (D) or (M) after the respective axis designations on the Overview tab and the POS tab of the additional status display.
- On the FS tab of the additional status display, the control displays the active limits defined by the specific safety-related operating modes for every axis.
- On the TT tab of the additional status display, the control displays the tilt angle of the tool touch probe as well as information about the cuboid probe contacts.
- In Test Run operating mode, the control displays the M tab of the additional status display when the screen layout PROGRAM + STATUS is active.
- When you activate a handwheel with display, the control automatically activates the override potentiometer of the handwheel.
- In the operating modes Manual Operation and Positioning w/ Manual Data Input, you can activate a handwheel with display while a macro or a manual tool change is being executed.
- You can activate or deactivate the F MAX soft key for reducing the feed rate. The defined value is retained.
- By default, the control calculates the basic rotation in the input coordinate system (I-CS). If the axis angles and tilt angles don't coincide, the control calculates the basic rotation in the workpiece coordinate system (W-CS).
- In the compensation tables (*.tco and *.wco), the input range for all columns containing numerical values has been changed from +/- 999.999 to +/- 999.9999
- From within the Diagnostic functions MOD group, you can access TNCdiag and Hardware configuration without a code number.
- The name of a connection in the **Remote Desktop Manager** (option 133) must not contain characters other than letters, numbers, and underscores.
- The HEIDENHAIN OPC UA NC Server enables you to access the directories TNC: and PLC:, including while the NC software is switched off. The contents displayed vary depending on the assigned user's permissions.
- If, when configuring the user administration, you use the Connection to Windows domain function, the Use LDAPs check box allows you to set up a secure connection.
- If a remote log-in takes place while user administration is inactive, for example via SSH, the control automatically assigns the HEROS.LegacyUserNoCtrlfct role.
- When user administration is active, the NC.SetupProgramRun permission is required for the ACC (option 145) functions.
- If you deactivate the user administration and select the **Delete** existing user databases check box, the control also deletes the .home folder in the **TNC:** directory.

- If you enter a password or code number with Caps Lock active, then the control issues a message.
- The machine parameter **spindleDisplay** (no. 100807) has been enhanced. The control can also display the spindle position on the **Overview** tab of the additional status display when the spindle is in jog mode.

New cycle functions 81760x-08

Further information: User's Manual for Programming of Machining Cycles

- Cycle 277 OCM CHAMFERING (ISO: G277, option 167) This cycle allows the control to deburr contours that were last defined, roughed, or finish-machined with other OCM cycles.
- Cycle 1271 OCM RECTANGLE (ISO: G1271, option 167) This cycle allows you to define a rectangle that is then used as a pocket, island, or boundary for face milling in conjunction with other OCM cycles.
- Cycle 1272 OCM CIRCLE (ISO: G1272, option 167) This cycle allows you to define a circle that is then used as a pocket, island, or boundary for face milling in conjunction with other OCM cycles.
- Cycle 1273 OCM SLOT / RIDGE (ISO: G1273, option 167) This cycle allows you to define a slot that is then used as a pocket, island, or boundary for face milling in conjunction with other OCM cycles.
- Cycle 1278 OCM POLYGON (ISO: G1278, option 167) This cycle allows you to define a polygon that is then used as a pocket, island, or boundary for face milling in conjunction with other OCM cycles.
- Cycle 1281 OCM RECTANGLE BOUNDARY (ISO: G1281, option 167)

This cycle allows you to define a rectangular boundary for islands or open pockets that you previously programmed with the standard OCM forms.

- Cycle 1282 OCM CIRCLE BOUNDARY (ISO: G1282, option 167) This cycle allows you to define a circular boundary for islands or open pockets that you previously programmed with the standard OCM forms.
- The control offers an OCM cutting data calculator with which you can determine the optimum cutting data for the 272 OCM ROUGHING cycle (ISO: G272, option 167). Press the OCM CUTTING DATA soft key to open the cutting data calculator during cycle definition. You can load the results directly into the cycle parameters.

Changed cycle functions 81760x-08

Further information: User's Manual for Programming of Machining Cycles

- Cycle 225 ENGRAVING (ISO: G225) allows you to use system variables to engrave the number of the current week.
- Cycles 202 BORING (ISO: G202) and 204 BACK BORING (ISO: G204, option 19) restore the spindle status after machining to that which was active before the cycle.
- If the defined usable length in column LU of the tool table is less than the depth, the control displays an error message.

The following cycles monitor the usable length $\ensuremath{\text{LU}}$:

- All cycles for drilling and boring
- All cycles for tapping
- All cycles for the machining of pockets and studs
- Cycle 22 ROUGH-OUT (ISO: G122, option 19)
- Cycle 23 FLOOR FINISHING (ISO: G123, option 19)
- Cycle 24 SIDE FINISHING (ISO: G124, option 19)
- Cycle 233 FACE MILLING (ISO: G233, option 19)
- Cycle 272 OCM ROUGHING (ISO: G272, option 167)
- Cycle 273 OCM FINISHING FLOOR (ISO: G273, option 167)
- Cycle 274 OCM FINISHING SIDE (ISO: G274, option 167)
- Cycles 251 RECTANGULAR POCKET (ISO: G251), 252
 CIRCULAR POCKET (ISO: G252, option 19), and 272 OCM
 ROUGHING (ISO: G272, option 167) take into consideration a cutting width defined in the column RCUTS when calculating the plunging path.
- Cycles 208 BORE MILLING (ISO: G208), 253 SLOT MILLING (ISO: G208), and 254 CIRCULAR SLOT (ISO: G254, option 19) monitor a cutting width defined in the column RCUTS of the tool table. If the center of a tool that is not a center-cut tool would contact the workpiece surface, the control issues an error message.
- The machine manufacturer can hide Cycle 238 MEASURE MACHINE STATUS (ISO: G238, option 155).
- An input value of 2 has been added to parameter Q569 OPEN BOUNDARY in Cycle 271 OCM CONTOUR DATA (ISO: G271, option 167). The control uses this value to interpret the first contour within the CONTOUR DEF function as a boundary block of a pocket.

- Cycle 272 OCM ROUGHING (ISO: G272, option 167) was expanded:
 - The parameter Q576 SPINDLE SPEED allows you to define a spindle speed for the roughing tool.
 - The parameter Q579 PLUNGING FACTOR S allows you to define a factor for the spindle speed during plunging.
 - Use the parameter Q575 INFEED STRATEGY to define whether the control machines the contour from top to bottom or vice versa.
 - The maximum input range of parameter Q370 TOOL PATH OVERLAP has been changed. Old: from 0.01 to 1. New: from 0.04 to 1.99.
 - If helical plunging is not possible, the control attempts a reciprocating plunging motion with the tool.
- Cycle 273 OCM FINISHING FLOOR (ISO: G273, option 167) was expanded.

The following parameters have been added:

- Q595 STRATEGY: machining with equal path distances or constant tool angle
- Q577 APPROACH RADIUS FACTOR: factor for the tool radius in order to adapt the approach radius

Further information: User's Manual for **Programming of Measuring Cycles for Workpieces and Tools**

- Cycles 480 CALIBRATE TT (ISO: G480) and 484 CALIBRATE IR TT (ISO: G484, option 17) can be used to calibrate a tool touch probe with cuboid probe contacts.
- For rotating tools, Cycle 483 MEASURE TOOL (ISO: G483, option 17) first measures the tool length and then the tool radius.
- By default, Cycles 1410 PROBING ON EDGE (ISO: G1410) and 1411 PROBING TWO CIRCLES (ISO: G1411, option 17) calculate the basic rotation in the input coordinate system (I-CS). If the axis angles and tilt angles don't coincide, the cycles calculate the basic rotation in the workpiece coordinate system (W-CS).



First steps

2.1 Overview

This chapter is intended to help you quickly learn to handle the most important procedures on the control. For more information on the respective topic, see the section referred to in the text.

The following topics are covered in this chapter:

- Switching on the machine
- Programming the workpiece

The following topics are covered in the User's Manual for Setup, Testing and Running NC Programs:

- Switching on the machine
- Graphically testing the workpiece
- Setting up tools
- Setting up the workpiece
- Machining the workpiece

2.2 Switching on the machine

Acknowledging the power interruption

Caution: hazard to the user!

Machines and machine components always pose mechanical hazards. Electric, magnetic, or electromagnetic fields are particularly hazardous for persons with cardiac pacemakers or implants. The hazard starts when the machine is powered up!

- Read and follow the machine manual
- Read and follow the safety precautions and safety symbols
- Use the safety devices



Refer to your machine manual!

Switching on the machine and traversing the reference points can vary depending on the machine tool.

To switch on the machine, proceed as follows:

- Switch on the power supply for the control and the machine
- The control starts the operating system. This process may take several minutes.
- > The control will then display the "Power interrupted" message in the screen header.
- CE
- Press the CE key
- > The control compiles the PLC program.
- Switch on the machine control voltage
- > The control is in the Manual operation mode.




Depending on your machine, you may need to carry out further steps in order to run NC programs.

Further information on this topic

Switching on the machine

Further information: User's Manual for Setup, Testing and Running NC Programs



2.3 Programming the first part

Selecting the operating mode

You can write NC programs only in the **Programming** operating mode:



- Press the operating mode key
- > The control switches to the **Programming** operating mode.

Further information on this topic

Operating modes
 Further information: "Programming", Page 71

Important controls and displays

Кеу	Functions for conversational guidance			
ENT	Confirm entry and activate the next dialog prompt			
NO ENT	Ignore the dialog question			
END	End the dialog immediately			
DEL	Abort dialog, discard entries			
	Soft keys on the screen with which you select functions appropriate to the active operating state			
Eurthor inf	Eurther information on this tania			

Further information on this topic

- Writing and editing NC programs
 Further information: "Editing an NC program", Page 96
- Overview of keys
 Further information: "Controls and displays", Page 2

Creating a new NC program / file management

To create a new NC program, proceed as follows:


- Press the PGM MGT key PGM MGT > The control opens the file manager. The file management of the control is arranged much like the file management on a PC with Windows Explorer. The file management enables you to manage data in the control's internal memory. Select a folder Enter the desired file name with the extension .н Press the ENT key ENT
 - > The control asks for the unit of measure of the new NC program.

Press the soft key of the desired unit of measure: MM or INCH

The control automatically generates the first and last NC blocks of the NC program. You will not be able to change these NC blocks at a later time.

Further information on this topic

- File management Further information: "File management", Page 102
- Creating a new NC program Further information: "Creating and entering NC programs", Page 87



Defining a workpiece blank

Once you have opened a new NC program, you can define a workpiece blank. You can define a cuboid by entering the MIN and MAX points relative to the selected preset.

After you have selected the desired shape for the blank with the appropriate soft key, the control automatically initiates the workpiece blank definition process and prompts you to enter the required data.

To define a cuboid-shaped blank, proceed as follows:


- Press the soft key for the desired shape of the workpiece blank
- Working plane in graphic: XY: Enter the active spindle axis. Z is saved as default setting. Accept with the ENT key
- Workpiece blank def.: minimum X: Enter the smallest X coordinate of the blank relative to the preset, e.g. 0, and confirm with the ENT key
- Workpiece blank def.: minimum Y: Enter the smallest Y coordinate of the blank relative to the preset, e.g. 0, and confirm with the ENT key
- Workpiece blank def.: minimum Z: Enter the smallest Z coordinate of the blank relative to the preset, e.g. -40, and confirm with the ENT key
- Workpiece blank def.: maximum X: Enter the largest X coordinate of the blank relative to the preset, e.g. 100, and confirm with the ENT key
- Workpiece blank def.: maximum Y: Enter the largest Y coordinate of the blank relative to the preset, e.g. 100, and confirm with the ENT key
- Workpiece blank def.: maximum Z: Enter the largest Z coordinate of the blank relative to the preset, e.g. 0, and confirm with the ENT key
- > The control ends the dialog.


Example

O BEGIN PGM NEW MM
1 BLK FORM 0.1 Z X+0 Y+0 Z-40
2 BLK FORM 0.2 X+100 Y+100 Z+0
3 END PGM NEW MM

Further information on this topic

 Define workpiece blank
 Further information: "Creating a new NC program", Page 91





Program layout

NC programs should be arranged consistently in a similar manner. This makes it easier to find your place, accelerates programming and reduces errors.

Recommended program layout for simple, conventional contour machining

Example

•
O BEGIN PGM BSPCONT MM
1 BLK FORM 0.1 Z X Y Z
2 BLK FORM 0.2 X Y Z
3 TOOL CALL 5 Z \$5000
4 L Z+250 R0 FMAX M3
5 L X Y RO FMAX
6 L Z+10 R0 F3000 M8
7 APPR X YRL F500
16 DEP X Y F3000 M9
17 L Z+250 R0 FMAX M2
18 END PGM BSPCONT MM

- 1 Call tool, define tool axis
- 2 Retract the tool; turn on spindle
- 3 Pre-position the tool in the working plane near the contour starting point
- 4 Pre-position the tool along the tool axis above the workpiece, or pre-position the tool directly to the cutting depth, and turn on coolant as needed
- 5 Contour approach
- 6 Contour machining
- 7 Contour departure
- 8 Retract the tool, end the NC program

Further information on this topic

 Contour programming
 Further information: "Programming tool movements for machining", Page 140

Recommended program layout for simple cycle programs Example

O BEGIN PGM BSBCYC MM
1 BLK FORM 0.1 Z X Y Z
2 BLK FORM 0.2 X Y Z
3 TOOL CALL 5 Z \$5000
4 L Z+250 R0 FMAX M3
5 PATTERN DEF POS1(X Y Z)
6 CYCL DEF
6 CYCL DEF 7 CYCL CALL PAT FMAX M8

- 1 Call tool, define tool axis
- 2 Retract the tool; turn on spindle
- 3 Define the machining positions
- 4 Define the machining cycle
- 5 Call the cycle, and switch on the coolant
- 6 Retract the tool, end the NC program

Further information on this topic

 Cycle programming
 Further information: User's Manual for Programming of Machining Cycles


Programming a simple contour


Suppose you want to mill a single time around the contour shown on the right at a depth of 5 mm. You have already defined the workpiece blank.

After you have opened an NC block with a function key, the control will prompt you to enter all of the data in the header using dialog texts.

To program the contour, proceed as follows:

Call the tool





2

Retract the tool

L	 Press the L key
Z	 Press the Z axis key Enter the retraction value (e.g., 250 mm) Press the ENT key
ENT	 At radius compensation, press ENT The control applies R0, which means there is no radius compensation.
ENT	 At feed rate F, press the ENT key The control applies FMAX. If needed, enter a miscellaneous function M, such as M3, turn on spindle
END	 Press the END key The control saves the positioning block.
Pre-position	 he tool in the working plane Press the L key
X	 Press the X axis key Enter the value for the position to be approached (e.g., -20 mm)
Y	 Press the Y axis key Enter the value for the position to be approached (e.g., -20 mm) Press the ENT key
ENT	 Press the ENT key At radius compensation, press ENT
ENT	> The control applies R0 .
ENT	 At feed rate F, press the ENT key The control applies FMAX. If needed, enter a miscellaneous function M Press the END key
END	 The control saves the positioning block.

Position the	of to the cutting depth	
L	Press the L key	
Ζ	Press the Z axis key	
	Enter the value for the position to be approached (e.g., -5 mm)	
ENT	Press the ENT key	
ENT	At radius compensation, press ENT	
	The control applies RO .	
	Enter the value for the positioning feed rate (e.g., 3000 mm/min)	
ENT	Press the ENT key	
	Enter a miscellaneous function M , such as M8 to turn coolant on	
END	Press the END key	
	The control saves the positioning block.	
Approach tl	contour smoothly	
APPR DEP	Press the APPR DEP key	
	The control displays a soft key row with approach and departure functions.	
APPR CT	Press the APPR CT soft key	
~ <u>~</u>	Enter the coordinates of the contour starting point 1	
ENT	Press the ENT key	
	For the center angle CCA , enter the approach angle (e.g., 90°)	
ENT	Press the ENT key	
	Enter the approach radius (e.g., 8 mm)	
ENT	Press the ENT key	
D	Press the RL soft key	
RL	The control applies radius compensation to the left.	
	Enter the value for the machining feed rate (e.g., 700 mm/min)	
END	Press the END key	
	The control saves the approach movement.	

Machine the contour

L		Press the L key
		Enter the changing coordinates of contour point 2 (e.g., Y 95)
		Press the END key
	>	The control applies the changed value and retains all of the other information from the previous NC block.
L		Press the L key
		Enter the changing coordinates of contour point 3 (e.g., X 95)
END		Press the END key
CHF o		Press the CHF key
		Enter the chamfer width (10 mm)
		Press the END key
	>	The control saves the chamfer at the end of the linear block.
		Press the L key
		Enter the changing coordinates of contour point 4
END		Press the END key
CHF		Press the CHF key
<u>~~</u>		Enter the chamfer width (20 mm)
		Press the END key

Complete the contour with a smooth departure

L	Press the L key
	 Enter the changing coordinates of
	contour point 1
END	Press the END key
APPR DEP	Press the APPR DEP key
DEP CT	Press the DEP CT soft key
	 For the center angle CCA, enter the departure angle (e.g., 90°)
ENT	Press the ENT key
	Enter the departure radius (e.g., 8 mm)
ENT	Press the ENT key
	 Enter the value for the positioning feed rate (e.g., 3000 mm/min)
ENT	Press the ENT key
	 If needed, enter a miscellaneous function M, such as M9, turn off coolant
END	Press the END key
	> The control saves the departure movement.
Retract the	tool
L	Press the L key
Z	Press the Z axis key
	 Enter the retraction value (e.g., 250 mm)
ENT	Press the ENT key
ENT	At radius compensation, press ENT
	> The control applies RO .
ENT	At feed rate F, press the ENT key
	> The control applies FMAX .
	Enter a miscellaneous function M, such as M30 for program end
END	 Press the END key
	 The control saves the positioning block and ends the NC program.

Further information on this topic


- **Complete example with NC blocks** Further information: "Example: Linear movements and chamfers with Cartesian coordinates", Page 163
- Creating a new NC program Further information: "Creating and entering NC programs", Page 87
- Approaching/departing contours Further information: "Approaching and departing a contour", Page 144
- Programming contours Further information: "Overview of path functions", Page 154
- Programmable feed rates Further information: "Possible feed rate input", Page 94
- Tool radius compensation Further information: "Tool radius compensation", Page 133
- Miscellaneous functions M Further information: "Miscellaneous functions for program run inspection, spindle and coolant ", Page 223

Creating a cycle program


Suppose that you are tasked with drilling the holes shown to the right with a standard drilling cycle (depth: 20 mm). You have already defined the workpiece blank.

Call the tool

- Press the TOOL CALL key Press the ENT key ENT Confirm the tool axis Z with the ENT key Enter the spindle speed (e.g., 4500) Press the END key
 - > The control completes the NC block.







Enter the tool data, e.g., tool number 5

Re

Retract the	toc	si i
L		Press the L key
Ζ		Press the Z axis key
		Enter the retraction value (e.g., 250 mm)
ENT		Press the ENT key
ENT		At radius compensation, press ENT
	>	The control applies RO , which means there is no radius compensation.
ENT		At feed rate ${f F}$, press the ${f ENT}$ key
	>	The control applies FMAX .
		If needed, enter a miscellaneous function M , such as M3 , turn on spindle
		Press the END key
	>	The control saves the positioning block.
Define a pat	ter	n
SPEC FCT		Press the SPEC FCT key
	>	The control opens the soft key row containing the special functions.
CONTOUR + POINT MACHINING		Press the CONTOUR + POINT MACHINING soft key
PATTERN DEF	•	Press the PATTERN DEF soft key
POINT		Press the POINT soft key
•		Enter the coordinates of the first position
ENT		Confirm each entry with the ENT key
ENT		Press the ENT key
	>	The control opens the dialog for the next position.
		Enter the coordinates
ENT		Confirm each entry with the ENT key
		Enter the coordinates of all positions

	0
TNC:\nc_prog\BHB\Klartext_Stempel_stamp.h	-
Set_up_clearance? 047-x+1 [151 LNIT 047-x+2] [151 LNIT 051 LNIT 051 LNIT 047 LNI	
S7 CALL EDL Sale	. 6
	SET STANDARD VALUES

- key
- s of the first position
- with the ENT key
- e dialog for the next
- S
- with the ENT key
- Enter the coordinates of all positions
- Press the END key
- > The control saves the NC block.

Define the cycle

Define the cycle					
CYCL DEF	Press the CYCL DEF key				
DRILLING/ THREAD	Press the DRILLING/ THREAD soft key				
200	Press the 200 soft key				
	> The control starts the dialog for cycle definition.				
	Enter the cycle parameters				
ENT	Confirm each entry with the ENT key				
	 The control displays a graphic illustrating the respective cycle parameter. 				
Call the cycle	9				
CYCL CALL	Press the CYCL CALL key				
CYCLE CALL PAT	Press the CYCLE CALL PAT soft key				
ENT	Press the ENT key				
	> The control applies FMAX .				
	If needed, enter a miscellaneous function M				
END	Press the END key				
	The control saves the NC block.				
Retract the t	Retract the tool				
L	Press the L key				
Z	Press the Z axis key				
	 Enter the retraction value (e.g., 250 mm) 				
ENT	Press the ENT key				
ENT	At radius compensation, press ENT				
	> The control applies RO .				
ENT	At feed rate F, press the ENT key				
	> The control applies FMAX .				
	 Enter a miscellaneous function M, such as M30 for program end 				
END	Press the END key				
	 The control saves the positioning block and ends the NC program. 				

Example

0 BEGIN PGM C200 MM			
1 BLK FORM 0.1 Z X+0 Y+0 Z-40		Workpiece blank definition	
2 BLK FORM 0.2 X+100 Y+100 Z+0			
3 TOOL CALL 5 Z S4500		Tool call	
4 L Z+250 R0 FMAX M3		Retract the tool; turn on spindle	
5 PATTERN DEF POS1 (X+10 Y+10 Z+0) POS2 (X+10 Y+90 Z+0) POS3 (X+90 Y+90 Z+0) POS4 (X+90 Y+10 Z+0)		Define the machining positions	
6 CYCL DEF 200 DR	ILLING	Define the cycle	
Q200=2	;SET-UP CLEARANCE		
Q201=-20	;DEPTH		
Q206=250	;FEED RATE FOR PLNGNG		
Q202=5	;PLUNGING DEPTH		
Q210=0	;DWELL TIME AT TOP		
Q203=-10	;SURFACE COORDINATE		
Q204=20	;2ND SET-UP CLEARANCE		
Q211=0.2	;DWELL TIME AT DEPTH		
Q395=0	;DEPTH REFERENCE		
7 CYCL CALL PAT F	MAX M8	Turn on coolant; call cycle	
8 L Z+250 R0 FMAX M30		Retract the tool, end program	
9 END PGM C200 MM			

Further information on this topic

- Creating a new NC program
 Further information: "Creating and entering NC programs", Page 87
- Cycle programming
 Further information: User's Manual for Programming of
 Machining Cycles



Fundamentals

3.1 The TNC 620

HEIDENHAIN TNC controls are workshop-oriented contouring controls that enable you to program conventional milling and drilling operations right at the machine in easy-to-use Klartext conversational language. They are designed for milling, drilling, and boring machines, as well as for machining centers, with up to 6 axes. You can also change the angular position of the spindle under program control.

Keyboard and screen layout are clearly arranged in such a way that the functions are fast and easy to use.



HEIDENHAIN Klartext and DIN/ISO

HEIDENHAIN Klartext, the dialog-guided programming language for workshops, is an especially easy method of writing programs. Programming graphics illustrate the individual machining steps for programming the contour. If no NC-dimensioned drawing is available, then the FK free contour programming will help. Workpiece machining can be graphically simulated either during a test run or during a program run.

It is also possible to program in ISO format.

You can also enter and test one NC program while another NC program is machining a workpiece.

Compatibility

NC programs created on HEIDENHAIN contouring controls (starting from the TNC 150 B) may not always run on the TNC 620. If the NC blocks contain invalid elements, the control will mark these as ERROR blocks or with error messages when the file is opened.



Please also note the detailed description of the differences between the iTNC 530 and the TNC 620. **Further information:** "Differences between the TNC 620 and the iTNC 530", Page 564

3.2 Visual display unit and operating panel

Display screen

The control is available either as a compact version or with a separate display unit and operating panel. Both variants of the control come with a 15-inch TFT color flat-panel display.

1 Header

When the control is on, the screen displays the selected operating modes in the header: The machine operating mode at left and the programming mode at right. The currently active mode is displayed in the larger field of the header, where the dialog prompts and messages also appear (exception: if the control only displays graphics).

2 Soft keys


In the footer the control indicates additional functions in a soft-key row. You can select these functions by pressing the keys immediately below them. The thin bars immediately above the soft-key row indicate the number of soft-key rows that can be called with the keys to the right and left that are used to switch the soft keys. The bar representing the active soft-key row is blue

- **3** Soft-key selection keys
- **4** Keys for switching the soft keys
- 5 Setting the screen layout
- **6** Key for switchover between machine operating modes, programming modes, and a third desktop
- 7 Soft-key selection keys for machine tool builders
- 8 Keys for switching the soft keys for machine tool builders
- 9 USB connection

A

If you are using a TNC 620 with touch control, you can replace some keystrokes with gestures.

Further information: "Operating the touchscreen", Page 511



Setting the screen layout

You select the screen layout yourself. In the **Programming** operating mode, for example, you can have the control show the NC program blocks in the left window while the right window displays programming graphics. You could also display the program structure in the right window instead, or display only the NC program blocks in one large window. The available screen windows depend on the selected operating mode.

Setting up the screen layout:

O

 Press the screen layout key: The soft-key row shows the available layout options
 Further information: "Modes of operation", Page 70

PROGRAM + GRAPHICS Select the desired screen layout with a soft key

Control panel


The TNC 620 can be supplied with an integrated operating panel. As an alternative, the TNC 620 is also available with a separate display unit and an external operating panel with alphabetic keyboard.

- 1 Alphabetic keyboard for entering texts and file names, as well as for ISO programming
- 2 File management
 - Calculator
 - MOD function
 - HELP function
 - Show error messages
 - Toggle between the operating modes
- 3 Programming modes
- 4 Machine operating modes
- 5 Initiating programming dialogs
- 6 Navigation keys and GOTO jump command
- 7 Numerical input and axis selection
- 8 Touchpad
- 9 Mouse buttons
- 10 Machine operating panel More information Machine manual

The functions of the individual keys are described on the inside front cover.

If you are using a TNC 620 with touch control, you can replace some keystrokes with gestures.

Further information: "Operating the touchscreen", Page 511



3

A



Refer to your machine manual!

Some machine tool builders do not use the standard HEIDENHAIN operating panel.

External keys, e.g.**NC START** or **NC STOP**, are described in your machine manual.

Cleaning

Õ


Refer to your machine manual!

Follow the cleaning instructions of the machine tool builder.

The keyboard unit and the integrated machine operating panel must be cleaned only with anionic or nonionic cleaning agents.

Screen keypad

If you are using the compact version of the control (without alphabetic keyboard), you can enter letters and special characters with the screen keypad or with an alphabetic keyboard connected to the USB port.



Entering text with the screen keypad

Proceed as follows to use the screen keypad:

GOTO

8

Press the GOTO key if you want to enter letters, e.g. a program name or directory name, using the screen keypad.

- The control opens a window in which the numeric keypad of the control is displayed with the corresponding letters assigned.
- Press the numerical key until the cursor is on the desired letter
- Wait until the control transfers the selected character before you enter the next character
- Use the OK soft key to load the text into the open dialog field

Use the **abc/ABC** soft key to select upper or lower case. If your machine tool builder has defined additional special characters, you can call them with the **SPECIAL CHARACTERS** soft key and insert them. Use the **BACKSPACE** soft key to delete individual characters.

3.3 Modes of operation

Manual Operation and El. Handwheel

In the **Manual operation** mode of operation, you can set up the machine. You can position the machine axes manually or incrementally, and you can set presets.

If option 8 is active, you can tilt the working plane.

The **Electronic handwheel** operating mode supports manual traverse of machine axes with the HR electronic handwheel.

Soft keys for selecting the screen layout

Soft key	Window
POSITION	Positions
POSITION + STATUS	Left: positions, right: status display
POSITION + WORKPIECE	Left: positions, right: workpiece (option 20)

Positioning with Manual Data Input

This mode of operation is used for programming simple traversing movements, such as for face milling or pre-positioning.

Soft keys for selecting the screen layout

Soft key	Window
PGM	NC program
PROGRAM + STATUS	Left: NC program, right: status display
PROGRAM + WORKPIECE	Left: NC program, right: workpiece (option 20)

		100% S-		IMIT 1			
Ovr 100%	M 5/9		Active P	GM: TNC:\nc_prog	_Stea	pel_stamp.h	F100% 44
S 1800 F Omm/min			PGM CALL				OFF
®1	T 12 Z			LBL		REP	S100%
				LBL			S100%
			1		P# 		
	.0.000				M50	MS	i
С	+0.000		DL-PGM	+0.0000	DR - PGM	+0.0000	M
в	+0.000		DL-TAB	+0.0000	DR-TAB	+0.0000	+
Z	+110.000		L	+90.0000	R	+12.0000	
Y	+0.000		T : 1		LOUGH		No.
		(<u>La</u>)		r +0.000	c	+0.000	U .
X	+0.000	(c)	RENOML		8	+0.000	S E
Position di	splay MODE: NOML		Overview	PGM PAL LBL CY	C M POS T	OOL TT TRANS OPARA	

DNC 📰 Programming

Manual operation

END POUTSION L			
1.5.2.5 + 5.5.500 10.1.5 + 5.5.50 10.1.5 + 5.5.50 10.1.5 + 5.5.50 10.1.5 10.1 10.			
N: 133 -6, 6880 Dir. 124 -6, 6880 Dir. 124 -6, 6880 N: 133 -6, 6880 Dir. 124 -6, 6880 Dir. 124 -6, 6880 N: 133 -6, 6880 Dir. 124 -6, 6880 Dir. 124 -6, 6880 N: 134 -6, 6880 Dir. 124 -6, 6880 Dir. 124 -7, 6880 N: 134 -6, 6880 Dir. 124 -6, 6880 Dir. 124 -7, 748 N: 134 -6, 6880 Dir. 124 -6, 6880 Dir. 124 -7, 748 N: 134 -6, 6880 Dir. 124 -7, 748 -7, 748 -7, 748 N: 134 -7, 748 -7, 748 -7, 748 -7, 748 -7, 748	0		
10.732 -5.600 D0.734 -5.600 10.742 -5.600 D0.740 -5.600			
10.752 10.75			
0.138 +0.5000 00.700 +0.0000 0.700 +0.0000 00.700 +0.000 0.90 +0.000 00.700 +0.000 0.000 00.700 +0.000 0.000 00 +0.000 00.000 0.000 00 +0.000 00.000 0.000 00 +0.000 00.000 00.000 0.000 00 +0.000 00.000 00.000 00.000 0.000 00 +0.000 00.000 00.000 00.000 00.000 0.000 00 +0.000 00.000 00.000 00.000 00.000 00.000 0.000 00 +0.000 00.000 00.000 00.000 00.000 00.000 0.000 00 +0.000 000000			
10.738 +6.6600 10.758 +6.6600 10.758 +6.660 10.758 +6.660 10.758 10.758 10.75 10 10 10 10 10 10 1			
0768 -0669 06-768 -45,000 DL-F0H +0.0000 05-70H +5,000 165 m9 T β# 2			
01.738 -0.6660 00.738 -0.6660 01.701 -0.6660 00.701 -0.6660 01.701 -0.6660 00 10.701 -0.6660			
DL-TAB +0.0000 DR-TAB +0.0000			
	END PGM SM		
T TOOL CALL 7 Z \$1500 Z -115.000 Z -115.000			
BEGIN PGM \$MDI MM Y +07.093 C +0.000			
Overview PGH PAL LBL CYC M POS TOOL TT TRANS OPARA Smdi.h ArnomL x -4.764 8 +0.000 M	Smdi.h		

Programming

In this mode of operation you create NC programs. The FK free programming feature, the various cycles and the Q parameter functions help you with programming and add necessary information. If desired, you can have the programming graphics show the programmed paths of traverse.

Soft keys for selecting the screen layout

Soft key	Window
PGM	NC program
PROGRAM + SECTS	Left: NC program, right: program structure
PROGRAM + GRAPHICS	Left: NC program, right: programming graphics


Manual operation Programming The:::nc_rcogloBiditAtartex1WH84.H Image: Non-rcogloBiditAtartex1WH84.H THE:::nc_rcogloBiditAtartex1WH84.H Image: Non-rcogloBiditAtartex1WH84.H THE:::nc_rcogloBiditAtartex1WH84.H Image: Non-rcogloBiditAtartex1WH84.H THE:::nc_rcogloBiditAtartex1WH84.H Image: Non-rcogloBiditAtartex1WH84.H THE:::Non-rcogloBiditAtartex1WH84.H Image: Non-rcogloBiditAtartex1WH84.H TH:::Non-rcogloBiditAtartex1WH84.H Image: Non-rcogloBiditAtartex1WH84.H TH:::Non-rcogloBiditAtartex1WH84.H Image: Non-rcogloBiditAtartex1WH84.H Image: Non-rcogloBiditAtartex1WH84.H

Test Run

In the **Test Run** operating mode, the control simulates NC programs and program sections in order to check them for errors, such as geometrical incompatibilities, missing or incorrect data within the NC program, or violations of the working space. This simulation is supported graphically in different display modes. (option 20)

Soft keys for selecting the screen layout

Soft key	Window
PGM	NC program
PROGRAM + STATUS	Left: NC program, right: status display
PROGRAM	Left: NC program, right: workpiece
WORKPIECE	(option 20)
	Workpiece
WORKPIECE	(Option 20)




Program Run, Full Sequence and Program Run, Single Block

In the **Program Run Full Sequence** operating mode, the control runs an NC program continuously to its end or to a manual or programmed stop. You can resume program run after an interruption.

In the **Program Run Single Block** operating mode, you execute each NC block separately by pressing the **NC start** key. With point pattern cycles and **CYCL CALL PAT**, the control stops after each point. The workpiece blank definition will be interpreted as a separate NC block.

Soft keys for selecting the screen layout



Soft key	Window
PGM	NC program
PROGRAM + SECTS	Left: NC program, right: structure
PROGRAM + STATUS	Left: NC program, right: status display
PROGRAM	Left: NC program, right: workpiece
WORKPIECE	(option 20)
WORKPIECE	Workpiece
WORKFIEGE	(option 20)

Soft keys for screen layout with pallet tables(option 22 Pallet management)

Soft key	Window
PALLET	Pallet table
PROGRAM + PALLET	Left: NC program, right: pallet table
PALLET + STATUS	Left: pallet table, right: status display
PALLET + GRAPHICS	Left: pallet table, right: graphics
ВРМ	Batch Process Manager

NC fundamentals 3.4


Position encoders and reference marks

The machine axes are equipped with position encoders that register the positions of the machine table or tool. Linear axes are usually equipped with linear encoders, rotary tables and tilting axes with angle encoders.

When a machine axis moves, the corresponding position encoder generates an electrical signal. The control evaluates this signal and calculates the precise actual position of the machine axis.

If there is a power interruption, the calculated position will no longer correspond to the actual position of the machine slide. To recover this assignment, incremental position encoders are provided with reference marks. When a reference mark is crossed over, a signal identifying a machine-based reference point is transmitted to the control. This enables the control to re-establish the assignment of the displayed position to the current machine position. For linear encoders with distance-coded reference marks, the machine axes need to move by no more than 20 mm, for angle encoders by no more than 20°.

With absolute encoders, an absolute position value is transmitted to the control immediately upon switch-on. In this way the assignment of the actual position to the machine slide position is re-established directly after switch-on.




Programmable axes


 $\textcircled{\textbf{O}}$

In the default setting, the programmable axes of the control are in accordance with the axis definitions specified in DIN 66217. The designations of the programmable axes are given in the table below.

Principal axis	Parallel axis	Rotary axis
Х	U	А
Y	V	В
Z	W	С

Refer to your machine manual! The number, designation and assignment of the programmable axes depend on the machine. Your machine tool builder can define further axes, such as PLC axes.





Reference systems

For the control to move an axis in accordance with a defined path, it requires a **reference system**.

A paraxially mounted linear encoder on a machine tool serves as a simple reference system for linear axes. The linear encoder represents a **number ray**, a one-dimensional coordinate system.

To approach a point on the **plane**, the control requires two axes and therefore a reference system with two dimensions.

To approach a point in **space**, the control requires three axes and therefore a reference system with three dimensions. If these three axes are arranged perpendicularly to each other, this creates a **three-dimensional Cartesian coordinate system**.



According to the right-hand rule the fingertips point in the positive directions of the three principal axes.

For a point to be uniquely determined in space, a **coordinate origin** is needed in addition to the arrangement of the three dimensions. The common intersection serves as the coordinate origin in a 3-D coordinate system. This intersection has the coordinates **X+0**, **Y+0**, and **Z+0**.


In order, for example, for the control to always perform a tool change at the same position, as well as always execute a machining operation referenced to the current workpiece position, the control must be able to differentiate between different reference systems.


The control differentiates between the following reference systems:


- Machine coordinate system M-CS: Machine Coordinate System
- Basic coordinate system B-CS:
 Basic Coordinate System
- Workpiece coordinate system W-CS:
 Workpiece Coordinate System
- Working plane coordinate system WPL-CS:
 Working Plane Coordinate System
- Input coordinate system I-CS: Input Coordinate System
- Tool coordinate system T-CS: Tool Coordinate System

All reference systems build upon each other. They are subject to the kinematic chain of the specific machine tool.

The machine coordinate system is the reference system.







i

Machine coordinate system M-CS

The machine coordinate system corresponds to the description of kinematics and therefore to the actual mechanical design of the machine tool.

Because the mechanics of a machine tool never precisely correspond to a Cartesian coordinate system, the machine coordinate system consists of several one-dimensional coordinate systems. These one-dimensional coordinate systems correspond to the physical machine axes that are not necessarily perpendicular to each other.

The position and orientation of the one-dimensional coordinate systems are defined with the aid of translations and rotations based on the spindle tip in the description of kinematics.

The position of the coordinate origin, the machine datum, is defined by the machine manufacturer during machine configuration. The values in the machine configuration define the zero positions of the encoders and the corresponding machine axes. The machine datum does not necessarily have to be located in the theoretical intersection of the physical axes. It can therefore also be located outside of the traverse range.

Because the machine configuration values cannot be modified by the user, the machine coordinate system is used for determining constant positions, e.g. the tool change point.

Soft key	Application
BASE	The user can define shifts in the machine coordi-
TRANSFORM.	nate system according to the specific axis with us
	of the OFFSET values of the preset table

nate system according to the specific axis with use of the **OFFSET** values of the preset table.

 \bigcirc

The machine tool builder configures the **OFFSET** columns of the preset management in accordance with the machine.


Further information: User's Manual for Setup, Testing and Running NC Programs


NOTICE

Danger of collision!


Your control may feature an additional pallet preset table, depending on the machine. In this table the machine tool builder can define **OFFSET** values that take effect before the **OFFSET** values you specify in the preset table become effective. The **PAL** tab of the additional status display indicates whether a pallet preset is active, and which one. Since the **OFFSET** values of the pallet preset table are neither shown nor editable, there is a risk of collision during all movements!

- Refer to the machine tool builder's documentation
- Use pallet presets only in conjunction with pallets
- Check the display of the PAL tab before you start machining





Machine datum (MZP)



6

Another feature is **OEM-OFFSET**, which is available only to the machine tool builder. **OEM-OFFSET** can be used to define additive axis shifts for rotary and parallel axes. The sum of all **OFFSET** values (from all the above **OFFSET** input options) results in the difference between the **ACTL**. position and the **RFACTL** position of an axis.

The control converts all movements in the machine coordinate system, independent of the reference system used for value input. Example of a 3-axis machine tool with a Y axis as oblique axis, not arranged perpendicularly to the ZX plane:

- In the Positioning w/ Manual Data Input operating mode, run an NC block with L IY+10
- > The control determines the required axis nominal values from the defined values.
- > During positioning the control moves the **Y** and **Z** machine axes.
- The RFACTL and RFNOML displays show movements of the Y axis and Z axis in the machine coordinate system.
- > The **ACTL.** and **NOML.** displays only show one movement of the Y axis in the input coordinate system.
- In the Positioning w/ Manual Data Input operating mode, run an NC block with L IY-10 M91
- The control determines the required axis nominal values from the defined values.
- > During positioning the control only moves the Y machine axis.
- The RFACTL and RFNOML displays only show one movement of the Y axis in the machine coordinate system.
- > The **ACTL.** and **NOML.** displays show movements of the Y axis and Z axis in the input coordinate system.

The user can program positions related to the machine datum, e.g. by using the miscellaneous function **M91**.

Basic coordinate system B-CS

The basic coordinate system is a 3-D Cartesian coordinate system. Its coordinate origin is the end of the kinematics model.

The orientation of the basic coordinate system in most cases corresponds to that of the machine coordinate system. There may be exceptions to this if a machine manufacturer uses additional kinematic transformations.

The kinematic model and thus the position of the coordinate origin for the basic coordinate system is defined by the machine manufacturer in the machine configuration. The user cannot modify the machine configuration values.

The basic coordinate system serves to determine the position and orientation of the workpiece coordinate system.

Soft key	Application
BASE TRANSFORM. OFFSET	The user determines the position and orientation of the workpiece coordinate system by using a 3- D touch probe, for example. The control saves the values determined with respect to the basic coordi- nate system as BASE TRANSFORM. values in the preset management.



The machine tool builder configures the **BASE TRANSFORM.** columns of the preset management in accordance with the machine.


Further information: User's Manual for Setup, Testing and Running NC Programs


NOTICE

Danger of collision!

Your control may feature an additional pallet preset table, depending on the machine. In this table the machine tool builder can define **BASE TRANSFORM.** values that take effect before the **BASE TRANSFORM.** values you specify in the preset table become effective. The **PAL** tab of the additional status display indicates whether a pallet preset is active, and which one. Since the **BASE TRANSFORM.** values of the pallet preset table are neither visible nor editable, there is danger of collision during all movements!

- ▶ Refer to the machine tool builder's documentation
- Use pallet presets only in conjunction with pallets
- Check the display of the PAL tab before you start machining





Workpiece coordinate system W-CS

The workpiece coordinate system is a 3-D Cartesian coordinate system. Its coordinate origin is the active reference point.

The position and orientation of the workpiece coordinate system depend on the **BASE TRANSFORM.** values of the active line in the preset table.

Soft key	Application
BASE TRANSFORM. OFFSET	The user determines the position and orientation of the workpiece coordinate system by using a 3-D touch probe, for example. The control saves the values determined with respect to the basic coordinate system as BASE TRANSFORM. values in the preset management.

Further information: User's Manual for Setup, Testing and Running NC Programs

In the workpiece coordinate system the user defines the position and orientation of the working plane coordinate system with use of transformations.

Transformations in the workpiece coordinate system:

3D ROT functions

f


- **PLANE** functions
- Cycle 19 WORKING PLANE
- Cycle 7 DATUM SHIFT (shifting before tilting the working plane)
- Cycle 8 MIRRORING (mirroring before tilting the working plane)


The result of transformations built up on each other depends on the programming sequence.


In every coordinate system, program only the specified (recommended) transformations. This applies to both setting and resetting the transformations. Any other use may lead to unexpected or undesired results. Please observe the following programming notes.


Programming notes:

- Transformations (mirroring and shifting) that are programmed before the PLANE functions (except for PLANE AXIAL) will change the position of the tilt datum (origin of the working plane coordinate system WPL-CS) and the orientation of the rotary axes
 - If you just program a shift, then only the position of the tilt datum will change
 - If you just program mirroring, then only the orientation of the rotary axes will change
- When used in conjunction with PLANE AXIAL and Cycle 19, the programmed transformations (mirroring, rotation, and scaling) do not affect the position of the tilt datum or the orientation of the rotary axes









Other transformations are of course possible in the working plane coordinate system

Further information: "Working plane coordinate system WPL-CS", Page 80

Working plane coordinate system WPL-CS

The working plane coordinate system is a 3-D Cartesian coordinate system.

The position and orientation of the working plane coordinate system depend on the active transformations in the workpiece coordinate system.

Without active transformations in the workpiece coordinate system, the position and orientation of the working plane coordinate system and workpiece coordinate system are identical.

There are no transformations in the workpiece coordinate system on 3-axis machine tools or with pure 3-axis machining. The **BASE TRANSFORM.** values of the active line of the preset table have a direct effect on the working plane coordinate system with this assumption.

In the working plane coordinate system the user defines the position and orientation of the input coordinate system with use of transformations.

Transformations in the working plane coordinate system:

- Cycle 7 DATUM SHIFT
- Cycle 8 MIRRORING

i

- Cycle 10 ROTATION
- Cycle 11 SCALING FACTOR
- Cycle 26 AXIS-SPECIFIC SCALING
- PLANE RELATIVE

i

A

A


As a **PLANE** function, the **PLANE RELATIVE** is effective in the workpiece coordinate system and aligns the working plane coordinate system.

The values of additive tilting always relate to the current working plane coordinate system.


The result of transformations built up on each other depends on the programming sequence.


Without active transformations in the working plane coordinate system, the position and orientation of the input coordinate system and working plane coordinate system are identical.

In addition, there are no transformations in the workpiece coordinate system on 3-axis machine tools or with pure 3-axis machining. The **BASE TRANSFORM.** values of the active line of the preset table have a direct effect on the input coordinate system with this assumption.









Input coordinate system I-CS

The input coordinate system is a 3-D Cartesian coordinate system.

The position and orientation of the input coordinate system depend on the active transformations in the working plane coordinate system.

> Without active transformations in the working plane coordinate system, the position and orientation of the input coordinate system and working plane coordinate system are identical.

In addition, there are no transformations in the workpiece coordinate system on 3-axis machine tools or with pure 3-axis machining. The **BASE TRANSFORM.** values of the active line of the preset table have a direct effect on the input coordinate system with this assumption.

With the aid of positioning blocks in the input coordinate system, the user defines the position of the tool and therefore the position of the tool coordinate system.



î

The **NOML.**, **ACTL.**, **LAG**, and **ACTDST** displays are also based on the input coordinate system.

Positioning blocks in input coordinate system:

- Paraxial positioning blocks
- Positioning blocks with Cartesian or polar coordinates
- Positioning blocks with Cartesian coordinates and surface normal vectors

Example

- 7 X+48 R+
- 7 L X+48 Y+102 Z-1.5 R0

7 LN X+48 Y+102 Z-1.5 NX-0.04658107 NY0.00045007 NZ0.8848844 R0

The position of the tool coordinate system is determined by the Cartesian coordinates X, Y and Z also for positioning blocks with surface normal vectors. In conjunction with 3-D tool compensation, the position

of the tool coordinate system can be shifted along the surface normal vectors.





i


Orientation of the tool coordinate system can be performed in various reference systems. **Further information:** "Tool coordinate system T-CS",

Further information: "Tool coordinate system T-CS", Page 82









A contour referencing the input coordinate system origin can easily be transformed any way you need.

Tool coordinate system T-CS

The tool coordinate system is a 3-D Cartesian coordinate system. Its coordinate origin is the tool reference point. The values of the tool table, **L** and **R** with milling tools and **ZL**, **XL** and **YL** with turning tools, are referenced to this point.

Further information: User's Manual for Setup, Testing and Running NC Programs

In accordance with the values from the tool table, the coordinate origin of the tool coordinate system is shifted to the tool center point TCP. TCP stands for **T**ool **C**enter **P**oint.


If the NC program is not referenced to the tool tip, the tool center point must be shifted. The required shift is implemented in the NC program using the delta values during a tool call.



i

The position of the TCP as shown in the diagram is obligatory in conjunction with the 3-D tool compensation.

With the aid of positioning blocks in the input coordinate system, the user defines the position of the tool and therefore the position of the tool coordinate system.



The user defines the tool's angle of inclination either in the machine coordinate system or in the working plane coordinate system.

Tool angle of inclination in the machine coordinate system:

Example


7 L X+10 Y+45 A+10 C+5 R0 M128


Tool angle of inclination in the working plane coordinate system:


Example

6 FUNCTION TCPM F TCP AXIS SPAT PATHCTRL AXIS

- 7 L A+0 B+45 C+0 R0 F2500
- 7 LN X+48 Y+102 Z-1.5 NX-0.04658107 NY0.00045007 NZ0.8848844 TX-0.08076201 TY-0.34090025 TZ0.93600126 R0 M128
- 7 LN X+48 Y+102 Z-1.5 NX-0.04658107 NY0.00045007 NZ0.8848844 R0 M128








DR_{PROG}

A

i

With the shown positioning blocks with vectors, 3-D tool compensation is possible with compensation values **DL**, DR and DR2 from the TOOL CALL block or from the .tco compensation table. The methods of function of the compensation values depend on the type of tool. The control detects the various tool types with the columns L, R and R2 of the tool table: $\blacksquare R2_{TAB} + DR2_{TAB} + DR2_{PROG} = 0$ \rightarrow end mill $\blacksquare R2_{TAB} + DR2_{TAB} + DR2_{PROG} = R_{TAB} + DR_{TAB} + DR_{PROG}$ \rightarrow radius cutter or ball cutter $\bullet \quad 0 < R2_{TAB} + DR2_{TAB} + DR2_{PROG} < R_{TAB} + DR_{TAB} +$ → toroid cutter or toroidal cutter

Without the **TCPM** function or miscellaneous function M128, orientation of the tool coordinate system and input coordinate system is identical.



Designation of the axes on milling machines

The X, Y and Z axes on your milling machine are also referred to as tool axis, principal axis (1st axis) and secondary axis (2nd axis). The assignment of the tool axis is decisive for the assignment of the principal and secondary axes.

Tool axis	Principal axis	Secondary axis
Х	Y	Z
Y	Z	Х
Z	Х	Y

Polar coordinates

If the production drawing is dimensioned in Cartesian coordinates, you write the NC program using Cartesian coordinates. For parts containing circular arcs or angles, it is often simpler to give the dimensions in polar coordinates.


While the Cartesian coordinates X, Y and Z are three-dimensional and can describe points in space, polar coordinates are twodimensional and describe points in a plane. Polar coordinates have their datum at a circle center (CC), or pole. A position in a plane can be clearly defined by the:


- Polar Radius, the distance from the circle center CC to the position, and the
- Polar Angle, the value of the angle between the angle reference axis and the line that connects the circle center CC with the position.

Setting the pole and the angle reference axis

The pole is set by entering two Cartesian coordinates in one of the three planes. These coordinates also set the reference axis for the polar angle PA.

Coordinates of the pole (plane)	Angle reference axis
X/Y	+X
Y/Z	+Y
Z/X	+Z






Absolute and incremental workpiece positions


Absolute workpiece positions

Absolute coordinates are position coordinates that are referenced to the datum of the coordinate system (origin). Each position on the workpiece is unambiguously defined by its absolute coordinates.

Example 1: Holes dimensioned in absolute coordinates

Hole 1	Hole 2	Hole 3
X = 10 mm	X = 30 mm	X = 50 mm
Y = 10 mm	Y = 20 mm	Y = 30 mm





Incremental workpiece positions

Incremental coordinates are referenced to the last programmed nominal position of the tool, which serves as the relative (imaginary) datum. When you write an NC program in incremental coordinates, you thus program the tool to move by the distance between the previous and the subsequent nominal positions. This is why they are also referred to as chain dimensions.

To program a position in incremental coordinates, enter the letter ${\bf I}$ before the axis.

Example 2: Holes dimensioned in incremental coordinates

Absolute coordinates of hole 4


X = 10 mm	
Y = 10 mm	
Hole 5 with respect to 4	Hole 6 with respect to 5

	Tible 0, with respect to 5
X = 20 mm	X = 20 mm
Y = 10 mm	Y = 10 mm

Absolute and incremental polar coordinates

Absolute coordinates always refer to the pole and the angle reference axis.

Incremental polar coordinates always refer to the last programmed nominal position of the tool.



Selecting the preset

A production drawing specifies a certain form element of the workpiece (usually a corner) as the absolute reference point (datum). When setting the preset, first align the workpiece along the machine axes, and move the tool to a known position in each axis relative to the workpiece. For each position, set the display of the control either to zero or to a known position value. You thereby assign the workpiece to the reference system that is applicable for the control's display or your NC program.

If the production drawing is dimensioned in relative reference points, simply use the coordinate transformation cycles.

Further information: User's Manual for Programming of Machining Cycles


If the production drawing is not dimensioned for NC programming, then select a position or corner of the workpiece as a reference point from which the dimensions of the remaining workpiece positions can be determined.


A particularly convenient way of setting the presets is with a 3-D touch probe from HEIDENHAIN.

Further information: User's Manual for Setup, Testing and Running NC Programs

Example

The workpiece drawing shows holes (1 to 4), whose dimensions are shown relative to an absolute preset with the coordinates X=0 Y=0. The coordinates of holes 5 to 7 refer to the relative preset with the absolute coordinates X=450 Y=750. A **Datum shift** allows you to temporarily shift the datum to the position X = 450, Y = 750 in order for you to program the holes (5 to 7) without further calculations.





3.5 Creating and entering NC programs

Structure of an NC program in HEIDENHAIN Klartext

An NC program consists of a series of NC blocks. The illustration at right shows the elements of an NC block.

The control numbers the NC blocks of an NC program in ascending sequence.

The first NC block of an NC program is identified by **BEGIN PGM**, the program name, and the active unit of measure.

The subsequent NC blocks contain information on

- The workpiece blank
- Tool calls
- Approaching a safe position
- Feed rates and spindle speeds, as well as
- Path contours, cycles and other functions

The last block of a program is identified by ${\bf END}~{\bf PGM},$ the program name, and the active unit of measure.


NOTICE

Danger of collision!

The control does not automatically check whether collisions can occur between the tool and the workpiece. There is danger of collision during the approach movement after a tool change!

If necessary, program an additional safe auxiliary position





Defining the workpiece blank: BLK FORM

Immediately after creating a new NC program, you define an unmachined workpiece blank. If you wish to define the blank at a later stage, then press the **SPEC FCT** key, the **PROGRAM DEFAULTS** soft key, and then the **BLK FORM** soft key. The control needs this definition for its graphical simulations.

You only need to define the workpiece blank if you wish
to run a graphic test for the NC program.

The control can depict various types of blank forms:

Soft key	Function
	Define a rectangular blank
	Define a cylindrical blank
	Define a rotationally symmetric blank of any shape
	Load STL file as workpiece blank Optionally load an additional STL file as finished part

Rectangular blank

The sides of the cuboid lie parallel to the X, Y and Z axes. This blank is defined by two of its corner points:

- MIN point: the smallest X, Y and Z coordinates of the blank form, entered as absolute values.
- MAX point: the largest X, Y and Z coordinates of the blank form, entered as absolute or incremental values

Example

i

0 BEGIN PGM NEW MM	Program beginning, name, unit of measure
1 BLK FORM 0.1 Z X+0 Y+0 Z-40	Spindle axis, MIN point coordinates
2 BLK FORM 0.2 X+100 Y+100 Z+0	MAX point coordinates
3 END PGM NEW MM	Program end, name, unit of measure

Cylindrical blank

The cylindrical blank form is defined by the dimensions of the cylinder:

- X, Y or Z: Rotation axis
- D, R: Diameter or radius of the cylinder (with positive algebraic sign)
- L: Length of the cylinder (with positive algebraic sign)
- DIST: Shifting along the rotational axis
- DI, RI: Inside diameter or inside radius for a hollow cylinder



The parameters **DIST** and **RI** or **DI** are optional and need not be programmed.

Example

0 BEGIN PGM NEW MM	Program begin, name, unit of measure	
1 BLK FORM CYLINDER Z R50 L105 DIST+5 RI10	Spindle axis, radius, length, distance, inside radius	
2 END PGM NEW MM	Program end, name, unit of measure	

Rotationally symmetric blank of any shape

You define the contour of the rotationally symmetric blank in a subprogram. Use X, Y or Z as the rotation axis.

In the workpiece blank definition you refer to the contour description:


- DIM_D, DIM-R: Diameter or radius of the rotationally symmetrical blank form
- LBL: Subprogram with the contour description

The contour description may contain negative values in the rotation axis but only positive values in the reference axis. The contour must be closed, i.e. the contour beginning corresponds to the contour end.

If you define a rotationally symmetric blank with incremental coordinates, the dimensions are then independent of the diameter programming.



The subprogram can be designated with a number, an alphanumeric name, or a QS parameter.




Example

0 BEGIN PGM NEW MM	Program begin, name, unit of measure	
1 BLK FORM ROTATION Z DIM_R LBL1	Spindle axis, manner of interpretation, subprogram number	
2 M30	End of main program	
3 LBL 1	Subprogram start	
4 L X+0 Z+1	Starting point of contour	
5 L X+50	Programming in the positive direction of the principal axis	
6 L Z-20		
7 L X+70		
8 L Z-100		
9 L X+0		
10 L Z+1	Contour end	
11 LBL 0	End of subprogram	
12 END PGM NEW MM	Program end, name, unit of measure	

STL files as workpiece blank and optional finished part

Integrating STL files as workpiece blank and finished part is particularly convenient in combination with CAM programs, where the required 3-D models are available in addition to the NC program.



6

the number of permitted triangles:

- 20,000 triangles per STL file in ASCII format
- 50,000 triangles per STL file in binary format
- Binary files are loaded faster by the control.

In the workpiece blank definition you refer to the desired STL files by indicating the path. Use the **SELECT FILE** soft key if you want the control to take over the path information automatically.

If you do not wish to load a finished part, then close the dialog after the workpiece blank definition.



The path of the STL file can also be entered directly as text or with a QS parameter.

Example

•		
0 BEGIN PGM NEU MM	Program beginning, name, unit of measure	
1 BLK FORM FILE "TNC:\stl" TARGET "TNC:\stl"	Indication of path to the workpiece blank, path to the optional finished part	
2 END PGM NEU MM	Program end, name, unit of measure	
If the NC program and the 3-D models are in a folder or in a defined folder structure, relative paths make it		

easier to move the files later.

Creating a new NC program

An NC program is always entered in **Programming** mode. Example for creating a program:



• Operating mode: Press the **Programming** key

Further information: "Programming notes", Page 248

PGM MGT

- Press the PGM MGT key
- > The control opens the file manager.

Select the directory in which you wish to store the new NC program:

FILE NAME = NEW.H



- Enter the new program name
- Press the ENT key
- Select the unit of measure: Press the MM or INCH soft key
- > The control switches the screen layout and initiates the dialog for defining the **BLK FORM** (workpiece blank).
- Select a rectangular workpiece blank: Press the soft key for a rectangular blank form

Working plane in graphic: XY



Enter the spindle axis, e.g. Z

Workpiece blank def.: Minimum




Enter in sequence the X, Y and Z coordinates of the MIN point and confirm each of your entries with the ENT key

Workpiece blank def.: Maximum



Enter in sequence the X, Y and Z coordinates of the MAX point and confirm each of your entries with the ENT key



Example

0 BEGIN PGM NEW MM	Program begin, name, unit of measure	
1 BLK FORM 0.1 Z X+0 Y+0 Z-40	Spindle axis, MIN point coordinates	
2 BLK FORM 0.2 X+100 Y+100 Z+0	MAX point coordinates	
3 END PGM NEW MM	Program end, name, unit of measure	


The control automatically generates the block numbers as well as the $\ensuremath{\text{BEGIN}}$ and $\ensuremath{\text{END}}$ blocks.




If you do not wish to define a workpiece blank, then cancel the dialog at **Working plane in graphic: XY** using the **DEL** key!

Programming tool movements in Klartext

To program an NC block, initiate the dialog by pressing a function key. In the screen headline, the control then asks you for all the information necessary to program the desired function.





3

Possible feed rate input

Soft key	Functions for setting the feed rate
F MAX	Rapid traverse, blockwise. Exception: If defined before an APPR block, FMAX also in effect for moving to an auxiliary point
	Further information: "Important positions for approach and departure", Page 147
F AUTO	Traverse feed rate automatically calculated in TOOL CALL
F	Move at the programmed feed rate (unit of measure is mm/min or 1/10 inch/min). With rotary axes, the control interprets the feed rate in degrees/min, regardless of whether the NC program is written in mm or inches
FU	Define the feed per revolution (units in mm/1 or inch/1). Caution: In inch-programs, FU cannot be combined with M136
FZ	Define the tooth feed (units in mm/tooth or inch/ tooth). The number of teeth must be defined in the tool table in the CUT column.
Кеу	Functions for conversational guidance
	Ignore the dialog question
END	End the dialog immediately
DEL	Abort the dialog and erase the block

Actual position capture

The control enables you to transfer the current tool position into the NC program, for example during

- Positioning-block programming
- Cycle programming

To transfer the correct position values, proceed as follows:

- Place the input box at the position in the NC block where you want to insert a position value
- ------
- Select the actual-position-capture function

> In the soft-key row the control displays the axes

AXIS Z

A

- whose positions can be transferred.Select the axis
- > The control writes the current position of the selected axis into the active input box.
- In the working plane the control always captures the coordinates of the tool center, even though tool radius compensation is active.

The control takes the active tool length compensation into account and always captures the coordinate of the tool tip in the tool axis.

The control keeps the soft-key row for axis selection active until the **actual position capture** key is pressed again. This behavior remains in effect even if you save the current NC block or open a new NC block with a path function key. If you have to choose an input alternative via soft key (e.g. for radius compensation), then the control closes the soft-key row for axis selection.

The **Actual position capture** function is not permitted when the **Tilt working plane** function is active.

Editing an NC program



You cannot edit the active NC program while it is being run.

While you are creating or editing a NC program, you can select any desired line in the NC program or individual words in an NC block with the arrow keys or the soft keys:

Soft key / key	Function
PAGE	Go to previous page
	Go to next page
BEGIN	Go to beginning of program
	Go to end of program
	Change the position of the current NC block on the screen. Press this soft key to display additional NC blocks that are programmed before the current NC block No function if the NC program is fully visible on the server
	the screen Change the position of the current NC block on the screen. Press this soft key to display additional NC blocks that are programmed after the current NC block No function if the NC program is fully visible on the screen
+	Move from one NC block to the next NC block
-	Select individual words in an NC block
бото	Select a specific NC block Further information: "Using the GOTO key", Page 190
Soft key / key	Function
CE	Set the selected word to zeroErase an incorrect numberDelete the (clearable) error message
NO ENT	Delete the selected word

Soft key / key	Function	
DEL D	 Delete the selected NC block Errors and an error actions 	
	Erase cycles and program sections	
INSERT LAST NG BLOCK	Insert the NC block that you last edited or deleted	

Inserting an NC block at any desired location

- Select the NC block after which you want to insert a new NC block
- Initiate the dialog

Saving changes

The control normally saves changes automatically if you switch the operating mode or if you select the file manager. If you deliberately want to save changes to the NC program, proceed as follows:

- Select the soft-key row with the saving functions
- STORE
- Press the STORE soft key
- The control saves all changes made since the last time you saved the program.

Saving an NC program to a new file

You can save the contents of the currently active NC program under a different program name. Proceed as follows:

Select the soft-key row with the saving functions



- Press the SAVE AS soft key
- > The control opens a window in which you can enter the directory and the new file name.
- If necessary, select the target directory with the SWITCH soft key
- Enter the file name
- Confirm with the OK soft key or the ENT key, or abort the process by pressing the CANCEL soft key



The file saved with **SAVE AS** can also be found in the file manager by pressing the **LAST FILES** soft key.

Undoing changes

You can undo all changes made since the last time you saved the program. Proceed as follows:

Select the soft-key row with the saving functions

CANCEL
CHANGE

- Press the CANCEL CHANGE soft key
- > The control opens a window in which you can confirm or cancel this action.
- Reject the changes with the YES soft key or ENT key, or cancel the process with the NO soft key

Editing and inserting words

- Select a word in an NC block
- Overwrite it with the new value
- > The dialog is available while the word is highlighted.
- ▶ To accept the change, press the **END** key

If you want to insert a word, press the horizontal arrow key repeatedly until the desired dialog appears. You can then enter the desired value.

Looking for the same words in different NC blocks

- **→**
- Select a word in an NC block: Press the arrow key repeatedly until the desired word is highlighted
- ŧ
- Select an NC block with the arrow keys
 Arrow down: search forwards
 - Arrow up: search backwards

The word that is highlighted in the new NC block is the same as the one you selected previously.



If you start a search in a very long NC program, the control shows a progress indicator. You can cancel the search at any time, if necessary.

Marking, copying, cutting and inserting program sections

The control provides the following functions for copying program sections within an NC program or into another NC program:


Soft key	Function
SELECT BLOCK	Switch the marking function on
CANCEL SELECTION	Switch the marking function off
CUT OUT BLOCK	Cut the marked block
INSERT BLOCK	Insert the block that is stored in the buffer memory
COPY BLOCK	Copy the marked block

To copy a program section, proceed as follows:

- Select the soft key row containing the marking functions
- Select the first NC block of the section you wish to copy
- Mark the first NC block: Press the SELECT BLOCK soft key.
- The control highlights the NC block in color and displays the CANCEL SELECTION soft key.
- Place the cursor on the last NC block of the program section you wish to copy or cut.
- The control shows the marked NC blocks in a different color. You can end the marking function at any time by pressing the CANCEL SELECTION soft key.
- Copy the selected program section: Press the COPY BLOCK soft key. Cut the selected program section: Press the CUT OUT BLOCK soft key.
- > The control stores the selected block.

If you want to transfer a program section to another NC program, you now need to select the desired NC program in the file manager.

- Use the arrow keys to select the NC block after which you want to insert the copied/cut section
- Insert the saved program section: Press the INSERT BLOCK soft key
- End the marking function: Press the CANCEL SELECTION soft key



The control's search function

The search function of the control enables you to search for any text within an NC program and replace it by a new text, if required.

Finding any text

FIND

FIND

FIND

END

- Select the search function
 - The control superimposes the search window and displays the available search functions in the soft-key row.
 - Enter the text to be searched for, e.g.: TOOL
 - Select forwards search or backwards search
- 🕅 Manual operation 🛛 📀 Programming DNC \nc_prog\BHB\Klartext\HEBEL.H 1 × HEBEL MM 0.1 Z X-35 0.2 X+120 Y-50 Z-10 Y+20 Z+0 arch / Repla Find text CURRENT WORD Replace with REPLACE ALL Search forward COPY FIELD PASTE FIELD FIND REPLACE REPLACE AL

- Start the search process
- The control moves to the next NC block containing the text you are searching for
- Repeat the search process
- The control moves to the next NC block containing the text you are searching for
- Terminate the search function: Press the END soft key

Finding/Replacing any text

NOTICE

Caution: Data may be lost!

The **REPLACE** and **REPLACE ALL** functions overwrite all of the found syntax elements without a confirmation prompt. The original file is not automatically backed up by the control before the replacement process. As a result, NC programs may be irreversibly damaged.

- Back up the NC programs, if required, before you start the replacement
- Be appropriately careful when using **REPLACE** and **REPLACE ALL**

6

END

The **FIND** and **REPLACE** functions cannot be used in the active NC program while the program is running. These functions are also not available if write protection is active.

► Select the NC block containing the word you wish to find

FIND	 Select the search function
FIND	The control superimposes the search window and displays the available search functions in the soft-key row.
	Press the CURRENT WORD soft key
	The control loads the first word of the current NC block. If required, press the soft key again to load the desired word.
	Start the search process
FIND	The control moves to the next occurrence of the text you are searching for.
REPLACE	To replace the text and then move to the next occurrence of the text, press the REPLACE soft key. Or, to replace all text occurrences, press the REPLACE ALL soft key. Or, to skip the text and move to its next occurrence, press the FIND soft key

Terminate the search function: Press the END soft key

3.6 File management

Files

Files in the control	Туре
NC programs in HEIDENHAIN format in DIN/ISO format	.H .I
Compatible NC programs HEIDENHAIN unit programs HEIDENHAIN contour programs	.HU .HC
Tables forToolsTool changersDatumsPointsPresetsTouch probesBackup filesDependent data (e.g. structure items)Freely definable tablesPallets	.T .TCH .D .PNT .PR .TP .BAK .DEP .TAB .P
Texts as ASCII files Text files HTML files, e.g. result logs of touch probe cycles Help files	.A .TXT .HTML .CHM
CAD files as ASCII files	.DXF .IGES .STEP

When you write an NC program on the control, you must first enter a program name. The control saves the NC program to the internal memory as a file with the same name. The control can also save texts and tables as files.

The control provides a special file management window in which you can easily find and manage your files. Here you can call, copy, rename and erase files.

With the control, you can manage and save files up to a total size of **2 GB**.



Depending on the setting, the control generates backup files with the extension *.bak after editing and saving of NC programs. This reduces the available memory space.

File names

When you store NC programs, tables and texts as files, the control adds an extension to the file name, separated by a point. This extension indicates the file type.

File name	File type
PROG20	.Н

File names, drive names and directory names on the control must comply with the following standard: The Open Group Base Specifications Issue 6 IEEE Std 1003.1, 2004 Edition (POSIX Standard).


The following characters are permitted:

A B C D E F G H I J K L M N O P Q R S T U V W X Y Z a b c d e f g h i j k l m n o p q r s t u v w x y z 0 1 2 3 4 5 6 7 8 9 _ -

The following characters have special meanings:

Character	Meaning
	The last period (dot) in a file name is the extension separator
\and /	Directory separators
:	Separates the drive name from the directory

Do not use any other characters. This helps to prevent file transfer problems, etc.



A

The maximum permitted path length is 255 characters. The path length consists of the drive characters, the directory name and the file name, including the extension.

Further information: "Paths", Page 104

Displaying externally generated files on the control

The control features several additional tools which you can use to display the files shown in the table below. Some of the files can also be edited.

File types	Туре	
PDF files	pdf	
Excel tables	xls	
	CSV	
Internet files	html	
Text files	txt	
	ini	
Graphics files	bmp	
	gif	
	jpg	
	png	

Further information: User's Manual for Setup, Testing and Running NC Programs

Directories

To ensure that you can easily find your NC programs and files, we recommend that you organize your internal memory into directories (folders). You can divide a directory into further directories, which are called subdirectories. With the **-/+** key or **ENT** you can show or hide the subdirectories.

Paths

A path indicates the drive and all directories and subdirectories under which a file is saved. The individual names are separated by a backslash λ .




The maximum permitted path length is 255 characters. The path length consists of the drive characters, the directory name and the file name, including the extension.

Example

The directory AUFTR1 was created on the **TNC** drive. Then, in the AUFTR1 directory, the directory NCPROG was created and the NC program PROG1.H was copied into it. The NC program now has the following path:

TNC:\AUFTR1\NCPROG\PROG1.H

The chart at right illustrates an example of a directory display with different paths.



Soft key	Function	Page
	Copy a single file	109
SELECT	Display a specific file type	107
NEW FILE	Create new file	109
LAST	Display the last 10 files that were selected	112
DELETE	Delete a file	113
TAG	Tag a file	114
RENAME ABC = XYZ	Rename file	115
PROTECT	Protect a file against editing and erasure	116
	Cancel file protection	116
ADAPT NC PGM / TABLE	Import file of an iTNC 530	See the User's Manual for Setup, Testing and Running NC Programs
	Customize table view	400
NET	Manage network drives	See the User's Manual for Setup, Testing and Running NC Programs
SELECT EDITOR	Select the editor	116
SORT	Sort files by properties	115
	Copy a directory	112
	Delete directory with all its subdirectories	
	Refresh directory	
RENAME ABC = XYZ	Rename a directory	
NEW DIRECTORY	Create a new directory	

Overview: Functions of the file manager

Calling the file manager




- Press the PGM MGT key
- The control displays the file management window (see figure for default setting. If the control displays a different screen layout, press the WINDOW soft key).

The narrow window on the left shows the available drives and directories. Drives designate devices with which data are stored or transferred. A drive is the internal memory of the control. Other drives are the interfaces (RS232, Ethernet) to which you can connect a PC for example. A directory is always identified by a folder symbol to the left and the directory name to the right. Subdirectories are shown to the right of and below their parent directories. If there are subdirectories, you can show or hide them using the **-/+** key.

If the directory tree is longer than the screen, navigate using the scroll bar or a connected mouse.

The wide window on the right shows you all files that are stored in the selected directory. Each file is shown with additional information, illustrated in the table below.

Display	Meaning
File nan	ne File name and file type
Bytes	File size in bytes
Status	File properties:
E	File is selected in the Programming operat- ing mode
S	File is selected in the Test Run operating mode
Μ	The file is selected in a Program Run operating mode
+	File has non-displayed dependent files with the extension DEP, e.g. with use of the tool usage test
6	File is protected against erasing and editing
ß	File is protected against erasing and editing, because it is being run
Date	Date that the file was last edited
Time	Time that the file was last edited
0	To display the dependent files, set the machine parameter dependentFiles (no. 122101) to MANUAL .




Selecting drives, directories and files



 Call the file manager by pressing the PGM MGT key

Navigate with a connected mouse or use the arrow keys or the soft keys to move the cursor to the desired position on the screen:



Step 1: Select drive

Move the highlight to the desired drive in the left window

Select a drive: Press the SELECT soft key, or



I,

Press the ENT key

Step 2: Select a directory

- Move the highlight to the desired directory in the left window
- > The right-hand window automatically shows all files stored in the highlighted directory

Step 3: Select a file

SELECT TYPE
SHOW ALL

ENT

Press the SELECT TYPE soft key

- Press the SHOW ALL soft key
- Move the highlight to the desired file in the right window
- Press the SELECT soft key, or
- Press the ENT key
- The control opens the selected file in the operating mode from which you called the file manager.



If you enter the first letter of the file you are looking for in the file manager, the cursor automatically jumps to the first NC program with the same letter.

Filtering the display

To filter the displayed files, proceed as follows:



Press the SELECT TYPE soft key



Press the soft key for the desired file type

Alternative:



- Press the SHOW ALL soft key
- > The control displays all files in this folder.

Alternative:



- ▶ Use wildcards, such as **4*.H**
- The control will show all files of file type .h whose name starts with 4.

Alternative:



- Enter the file name extension, e.g. *.H;*.D
- The control will show all files of file type .h and .d.

Any display filter you have set will remain effective even after a control restart,

Creating a new directory

Move the highlight in the left window to the directory in which you want to create a subdirectory



- Press the NEW DIRECTORY soft key
- Enter a directory name Press the ENT key



- Press the OK soft key to confirm or
- Press the CANCEL soft key to abort

Creating new file

- Select the directory in the left window in which you wish to create the new file
- Position the cursor in the right window ►



- Press the NEW FILE soft key
- Enter the file name with extension



Press the ENT key

Copying a single file

- Move the cursor to the file you wish to copy
 - Press the COPY soft key to select the copying function
 - > The control opens a pop-up window.
- Copying files into the current directory



- Enter the name of the destination file.
- Press the ENT key or the OK soft key ►
- The control copies the file to the active directory. > The original file is retained.

Copying files into another directory



- Press the Target Directory soft key to select the target directory from a pop-up window
- Press the ENT key or the OK soft key
- > The control copies the file under the same name to the selected directory. The original file is retained.

F

When you start the copying process with the ENT key or the **OK** soft key, the control displays a pop-up window with a progress indicator.

Copying files into another directory

- Select a screen layout with two equally sized windows
- In the right window
- Press the SHOW TREE soft key
- Move the cursor to the directory into which you wish to copy the files, and display the files in this directory with the ENT key
- In the left window
- Press the SHOW TREE soft key
- Select the directory with the files that you want to copy, and display the files with the SHOW FILES soft key



ABC XYZ

- Press the Tag soft key: Call the file tagging functions
- Press the Tag soft key: Position the cursor on the file you wish to copy and tag. You can tag several files in this way, if desired
- Press the Copy soft key: Copy the tagged files into the target directory

Further information: "Tagging files", Page 114

If you have tagged files in both the left and right windows, the control copies from the directory in which the cursor is located.

Overwriting files

If you copy files to a directory in which other files are stored under the same name, the control will ask whether the files in the target directory should be overwritten:

- Overwrite all files (Existing files field selected): Press the OK soft key, or
- ▶ To leave the files as they are, press the CANCEL soft key

If you want to overwrite a protected file, select the **Protected files** field, or cancel the process.

Copying a table

Importing lines to a table

If you are copying a table into an existing table, you can overwrite individual lines with the **REPLACE FIELDS** soft key. Prerequisites:

- The target table must exist
- The file to be copied must only contain the lines you want to replace
- Both tables must have the same file extension

NOTICE

Caution: Data may be lost!

The **REPLACE FIELDS** function overwrites all lines of the target file that are contained in the copied table without a confirmation prompt. The original file is not automatically backed up by the control before the replacement process. As a consequence, tables may be irreversibly damaged.

- Back up the tables, if required, before you start the replacement
- Be accordingly careful when using REPLACE FIELDS

Example

With a tool presetter you have measured the length and radius of ten new tools. The tool presetter then generates the TOOL_Import.T tool table with 10 lines (for the 10 tools).

Proceed as follows:

- Copy this table from the external data medium to any directory
- Copy the externally created table to the existing table TOOL.T using the control's file manager.
- The control asks you whether you want to overwrite the existing TOOL.T tool table.
- Press the YES soft key
- The control will completely overwrite the current TOOL.T tool table. After this copying process the new TOOL.T table consists of 10 lines.
- Alternative: Press the REPLACE FIELDS soft key
- The control overwrites the 10 lines in the TOOL.T file. The data of the other lines is not changed.

Extracting lines from a table

You can select one or more lines in a table and save them in a separate table.

Proceed as follows:

- Open the table from which you want to copy lines
- Use the arrow keys to select the first line to be copied
- Press the MORE FUNCTIONS soft key
- Press the TAG soft key
- Select additional lines, if required
- Press the SAVE AS soft key
- Enter a name for the table in which the selected lines are to be saved

Copying a directory

- Move the highlight in the right window onto the directory you want to copy
- Press the COPY soft key
- > The control opens the window for selecting the target directory.
- Select the target directory and confirm with the ENT key or the OK soft key
- The control copies the selected directory and all its subdirectories to the selected target directory.

Choosing one of the last files selected



• Call the file manager: Press the **PGM MGT** key.



 Display the last ten files selected: Press the LAST FILES soft key

Press the arrow keys to move the cursor to the file you wish to select:




Moves the cursor up and down within a window




FNT

i

Select the file: Press the OK soft key, or



The **COPY FIELD** soft key allows you to copy the path of a marked file. You can reuse the copied path later (e.g., when calling a program with the **PGM CALL** key).



Deleting a file

NOTICE

Caution: Data may be lost!

The **DELETE** function permanently deletes the file. The control does not perform an automatic backup of the file prior to deletion (e.g., there is no recycle bin). Files are thereby irreversibly deleted.

Regularly back up important data to external drives

Proceed as follows:

Move the cursor to the file you want to delete



- Press the **DELETE** soft key
- > The control asks whether you want to delete the file.
- Press the OK soft key
- > The control deletes the file.
- Alternative: Press the CANCEL soft key
- > The control aborts the procedure.

Deleting a directory

NOTICE

Caution: Data may be lost!

The **DELETE ALL** function permanently deletes all files of the directory. The control does not perform an automatic backup of the files prior to deletion (e.g., there is no recycle bin). Files are thereby irreversibly deleted.

Regularly back up important data to external drives

Proceed as follows:

Move the cursor to the directory you want to delete



- Press the DELETE ALL soft key
- The control inquires whether you really intend to delete the directory and all its subdirectories and files.
- Press the OK soft key
- > The control deletes the directory.
- Alternative: Press the CANCEL soft key
- > The control aborts the procedure.

Tagging files

Soft key	Tagging function
TAG FILE	Tag a single file
TAG ALL FILES	Tag all files in the directory
UNTAG FILE	Untag a single file
UNTAG ALL FILES	Untag all files
	Copy all tagged files

Some functions, such as copying or erasing files, can not only be used for individual files, but also for several files at once. To tag several files, proceed as follows:

Move the cursor to the first file

	TAG
--	-----

- To display the tagging functions, press the TAG soft key
- TAG FILE
- ► To tag a file, press the **TAG FILE** soft key



TAG FILE

- Move the cursor to other files
- To tag another file, press the TAG FILE soft key, etc.

To copy tagged files:



Leave the active soft-key row



Press the COPY soft key

To delete tagged files:



Leave the active soft-key row



Press the **DELETE** soft key

Renaming a file

Move the cursor to the file you wish to rename



- Select the function for renaming: Press the RENAME soft key
- Enter the new file name; the file type cannot be changed
- ▶ To rename: Press the **OK** soft key or the **ENT** key

Sorting files

Select the folder in which you wish to sort the files



- Press the SORT soft key
- Select the soft key with the corresponding display criterion
 - SORT BY NAME
 - SORT BY SIZE
 - SORT BY DATE
 - SORT BY TYPE
 - SORT BY STATUS
 - UNSORTED

Additional functions

Protecting a file and canceling file protection

Place the cursor on the file you want to protect

MORE
FUNCTIONS

OTECT •

Press the **MORE FUNCTIONS** soft key Activate file protection:

Select the additional functions:

- Press the **PROTECT** soft key
- > The file is tagged with the "protected" symbol.



Cancel file protection: Press the UNPROTECT soft key

Selecting the editor

Place the cursor on the file you want to open ►

	MORE
l	FUNCTIONS

- Select the additional functions: Press the MORE FUNCTIONS soft key
- SELECT EDITOR
- Select the editor: Press the SELECT EDITOR soft key
- Mark the desired editor
 - **TEXT EDITOR** for text files (e.g., **.A** or **.TXT**)
 - **PROGRAM EDITOR** for NC programs .H and .I
 - **TABLE EDITOR** for tables (e.g., **.TAB** or **.T**)
 - BPM EDITOR for pallet tables .P
- Press the OK soft key

Connecting and removing USB storage devices

The control automatically detects connected USB devices with a supported file system.

To remove a USB device, proceed as follows:



- Move the cursor to the left-hand window
- Press the MORE FUNCTIONS soft key
- Remove the USB device

Further information: User's Manual for Setup, Testing and **Running NC Programs**

ADVANCED ACCESS RIGHTS

The **ADVANCED ACCESS RIGHTS** function can only be used in connection with user administration. This function requires the **public** directory.

Further information: User's Manual for Setup, Testing and Running NC Programs

Upon the first activation of user administration, the **public** directory below the TNC partition will be connected.



Access rights can only be defined for files located in the **public** directory.

For all files stored on the TNC partition instead of the **public** directory, the **user** function user will automatically be assigned as the owner.

Further information: User's Manual for Setup, Testing and Running NC Programs




Tools

4.1 Entering tool-related data

Feed rate F

The feed rate \mathbf{F} is the speed at which the tool center point moves. The maximum feed rates can be different for the individual axes and are set in machine parameters.



Input

You can enter the feed rate in the **TOOL CALL** block and in every positioning block.

Further information: "Creating the NC blocks with the path function keys ", Page 142

You enter the feed rate **F** in mm/min in millimeter programs, and in 1/10 inch/min in inch-programs, for resolution reasons. Alternatively, with the corresponding soft keys, you can also define the feed rate in mm per revolution (mm/1) **FU** or in mm per tooth (mm/tooth) **FZ**.

Rapid traverse

If you wish to program rapid traverse, enter **F MAX.** To enter **FMAX,** press the **ENT** key or the **FMAX** soft key when the dialog question **FEED RATE F = ?** appears on the control's screen.



To move your machine at rapid traverse, you can also program the corresponding numerical value, e.g. **F30000**. Unlike **FMAX**, this rapid traverse remains in effect not only in the individual block but in all blocks until you program a new feed rate.

Duration of effect

A feed rate entered as a numerical value remains in effect until an NC block with a different feed rate is reached. **FMAX** is only effective in the NC block in which it is programmed. After the NC block with **F MAX** is executed, the feed rate will return to the last feed rate entered as a numerical value.

Changing during program run

You can adjust the feed rate during the program run with the feed rate potentiometer F.

The feed-rate potentiometer only reduces the programmed feed rate, and not the feed rate calculated by the control.

Spindle speed S

The spindle speed S is entered in revolutions per minute (rpm) in a **TOOL CALL** block (tool call). Instead, you can also define the cutting speed Vc in meters per minute (m/min).

Programmed change

In the NC program, you can change the spindle speed in a **TOOL CALL** block by entering only the new spindle speed.

Proceed as follows:

TOOL

END

i

- Press the TOOL CALL key
- Ignore the dialog question for Tool number ? with the NO ENT key
- Ignore the dialog question for Working spindle axis X/Y/Z ? with the NO ENT key
- Enter the new spindle speed at the Spindle speed S= ? prompt, or switch to entry of the cutting speed by pressing the VC soft key
- Confirm your input with the END key

In the following cases the control changes only the speed:

- TOOL CALL block without tool name, tool number, and tool axis
- TOOL CALL block without tool name, tool number, with the same tool axis as in the previous TOOL CALL block

In the following cases the control runs the tool-change macro and inserts a replacement tool if necessary:

- TOOL CALL block with tool number
- TOOL CALL block with tool name
- **TOOL CALL** block without tool name or tool number, with a changed tool axis direction

Changing during program run


You can adjust the spindle speed during program run with the spindle speed potentiometer S.

4.2 Tool data

Requirements for tool compensation

You usually program the coordinates of path contours as they are dimensioned in the workpiece drawing. To allow the control to calculate the tool center path (i.e. the tool compensation) you must also enter the length and radius of each tool you are using.

You can enter tool data either directly in the NC program with **TOOL DEF** or separately in a tool tables. In a tool table, you can also enter additional data for the specific tool. The control will consider all the data entered for the tool when executing the NC program.



Tool number, tool name

Each tool is identified by a number between 0 and 32767. If you are working with tool tables, you can also enter a tool name for each tool. Tool names can have up to 32 characters.

A

Permitted characters: # \$ % & , - _ . 0 1 2 3 4 5 6 7 8 9 @ A B C D E F G H I J K L M N O P Q R S T U V W X Y Z

The control automatically replaces lowercase letters with corresponding uppercase letters during saving.

The tool number 0 is automatically defined as the zero tool with the length L=0 and the radius R=0. In tool tables, tool T0 should also be defined with L=0 and R=0.


Tool length L

f

Always enter the tool length ${\bf L}$ as an absolute value based on the tool reference point.

The absolute tool length is essential for the control in order to perform numerous functions (e.g., material removal simulation or **Dynamic Collision Monitoring** (**DCM**)).

The absolute length of the touch probe is always referenced to the tool reference point. The machine tool builder usually defines the spindle nose as the tool reference point.



Measuring the tool length

You can measure your tools in the machine (e.g., with a tool touch probe) or externally with a tool presetter. If such measurements are not possible, you can determine the tool length.

You have the following options for determining the tool length:

- With a gauge block
- With a calibration pin (inspection tool)



Before you determine tool length, you have to set the preset in the spindle axis.

Determining the tool length with a gauge block



You can only set the preset with a gauge block if the tool reference point is at the spindle nose.

Place the preset on the surface you want to touch off with the tool. This surface might have to be created first.

Proceed as follows to set the datum with a gauge block:

- Place the gauge block on the machine table
- Position the spindle nose next to the gauge block
- Gradually move in Z+ direction until you can just slide the gauge block under the spindle nose
- Set the datum in Z
- To determine the tool length, proceed as follows:
- Insert the tool
- Touch off the surface
- The control displays the absolute tool length as the actual position in the position display.

Determining the tool length with a calibration pin and a tool setter

Proceed as follows to set the preset with a calibration pin and a tool setter:


- Clamp the tool setter onto the machine table.
- Bring the flexible inner ring of the tool setter to the same height as the fixed outer ring.
- Set the gauge to 0
- Move the calibration pin onto the flexible inner ring.
- Set the datum in Z


To determine the tool length, proceed as follows:

- Insert the tool
- Move the tool onto the flexible inner ring until the gauge displays 0.
- The control displays the absolute tool length as the actual position in the position display.

Tool radius R

You can enter the tool radius R directly.





Delta values for lengths and radii

Delta values are offsets in the length and radius of a tool.

A positive delta value represents a tool oversize (**DL**, **DR**>0). For a machining operation with an oversize, enter the value for the oversize in the NC program with **TOOL CALL** or with the help of a compensation table.

A negative delta value describes a tool undersize (**DL**, **DR**<0). An undersize is entered in the tool table for wear.

Delta values are usually entered as numerical values. In a **TOOL CALL** block, you can also assign the values to Q parameters. Input range: You can enter a delta value with up to \pm 99.999 mm.

Delta values from the tool table influence the graphical representation of the clearing simulation.

Delta values from the NC program do not change the depicted size of the **tool** in the simulation. However, the programmed delta values move the **tool** in the simulation by the amount of the defined value.

6

F)

Delta values from the **TOOL CALL** block influence the position display depending on the optional machine parameter **progToolCallDL** (no. 124501; branch **CfgPositionDisplay** no. 124500).

Tool-specific Q parameters used as delta values

The control calculates all tool-specific Q parameters while a tool call is being executed. The respective Q parameters cannot be used as delta values until the tool call has been completed.

Tool-specific Q parameters that can be used:

Q parameters	Function
Q108	ACTIVE TOOL RADIUS
Q114	ACTIVE TOOL LENGTH


To be able to use tool-specific Q parameters as delta values, you need to program a second tool call.

Example of ball-nose cutter:

You can use **Q108** (active tool radius) to correct the length of a ballnose cutter to its center (**DL - Q108**).

1 TOOL CALL "BALL_MILL_D4" Z S10000

2 TOOL CALL DL-Q108



Entering tool data into the NC program



Refer to your machine manual!

The machine tool builder determines the scope of functions of the **TOOL DEF** function.

The number, length, and radius of a specific tool are defined in the **TOOL DEF** block of the NC program:

Proceed as follows for the definition:



▶ press the **TOOL DEF** key.



Press the appropriate soft key

- Tool number
- TOOL NAME
- QS
- Tool length: Compensation value for the tool length
- ► **Tool radius**: Compensation value for the tool radius

Example

4 TOOL DEF 5 L+10 R+5

Calling the tool data

Before you can call the tool, you have to define it in a **TOOL DEF** block or in the tool table.

A **TOOL CALL** in the NC program is programmed with the following data:



- Press the TOOL CALL key
- ► **Tool number**: Enter the number or name of the tool. With the **TOOL NAME** soft key, you can enter a name. With the **QS** soft key, you enter a string parameter. The control automatically puts the tool name in quotation marks. You must first assign a tool name to a string parameter. The names refer to an entry in the active tool table TOOL.T.



- Alternative: Press the SELECT soft key
- The control opens a window where you can select a tool directly from the TOOL.T tool table.
- To call a tool with other compensation values, enter a decimal point followed by the index you defined in the tool table.
- Working spindle axis X/Y/Z: Enter the tool axis
- Spindle speed S: Enter the spindle speed S in revolutions per minute (rpm) Alternatively, you can define the cutting speed Vc in meters per minute (m/min). Press the VC soft key
- Feed rate F: Enter feed rate F in millimeters per minute (mm/min). Alternatively, you can define the feed rate in millimeters per revolution (mm/1) by pressing the FU soft key or in millimeters per tooth (mm/tooth) by pressing FZ. The feed rate is effective until you program a new feed rate in a positioning block or in a TOOL CALL block
- Tool length oversize DL: Enter the delta value for the tool length
- Tool radius oversize DR: Enter the delta value for the tool radius
- ► **Tool radius oversize DR2**: Enter the delta value for the tool radius 2

i

In the following cases the control changes only the speed:

- TOOL CALL block without tool name, tool number, and tool axis
- TOOL CALL block without tool name, tool number, with the same tool axis as in the previous TOOL CALL block

In the following cases the control runs the tool-change macro and inserts a replacement tool if necessary:

- **TOOL CALL** block with tool number
- TOOL CALL block with tool name
- **TOOL CALL** block without tool name or tool number, with a changed tool axis direction

Tool selection in the pop-up window

If you open a pop-up window for tool selection, the control marks all tools available in the tool magazine green.

You can search for a tool in the pop-up window:

GOTO □

ENT

- Press the GOTO key
- Alternative: Press the FIND soft key
- Enter the tool name or tool number
- Press the ENT key
- > The control goes to the first tool that matches the entered search string.

The following functions can be used with a connected mouse:

- You can sort the data in ascending or descending order by clicking a column of the table head.
- You can arrange the columns in any sequence you want by clicking a column of the table head and then moving it with the mouse key pressed down

The pop-up windows displayed for a tool number search and a tool name search can be configured separately. The sort order and the column widths are retained when the control is switched off.

Tool call

Call tool number 5 in the tool axis Z with a spindle speed of 2500 rpm and a feed rate of 350 mm/min. The tool length and tool radius 2 are to be programmed with an oversize of 0.2 and 0.05 mm, the tool radius with an undersize of 1 mm.

Example

20 TOOL CALL 5.2 Z S2500 F350 DL+0.2 DR-1 DR2+0.05

The character ${\bf D}$ preceding ${\bf L},\, {\bf R}$ and ${\bf R2}$ designates delta values.

Preselection of tools



Refer to your machine manual!

The preselection of tools with **TOOL DEF** can vary depending on the individual machine tool.

If you are working with tool tables, use a **TOOL DEF** block to preselect the next tool. Simply enter the tool number, or a Q or QS parameter, or type the tool name in quotation marks.

Tool change

Automatic tool change



Refer to your machine manual!

The tool change function can vary depending on the individual machine tool.

If your machine tool has automatic tool changing capability, the program run is not interrupted. When the control reaches a tool call with **TOOL CALL**, it replaces the inserted tool by another from the tool magazine.

Automatic tool change if the tool life expires: M101



Refer to your machine manual! The function of **M101** can vary depending on the individual machine tool.

When the specified tool life has expired, the control can automatically insert a replacement tool and continue machining with it. Activate the miscellaneous function **M101** for this. **M101** is reset with **M102**.

Enter the respective tool life after which machining is to be continued with a replacement tool in the **TIME2** column of the tool table. In the **CUR_TIME** column the control enters the current tool life.

If the current tool life is higher than the value entered in the **TIME2** column, a replacement tool will be inserted at the next possible point in the program no later than one minute after expiration of the tool life. The change is made only after the NC block has been completed.

NOTICE

Danger of collision!

During an automatic tool change with **M101**, the control always retracts the tool in the tool axis first. There is danger of collision when retracting tools for machining undercuts, such as side milling cutters or T-slot milling cutters!

Deactivate the tool change with M102

After the tool change the control positions the tool according to the following logic, unless otherwise specified by the machine tool builder:

- If the target position in the tool axis is below the current position, the tool axis is positioned last
- If the target position in the tool axis is above the current position, the tool axis is positioned first

Input parameter BT (block tolerance)

Depending on the NC program, the machining time can increase as a result of the tool life verification and calculation of the automatic tool change. You can influence this with the optional input parameter **BT** (block tolerance).

If you enter the **M101** function, the control continues the dialog by requesting **BT**. Here you define the number of NC blocks (1 to 100) by which the automatic tool change may be delayed. The resulting time period by which the tool change is delayed depends on the content of the NC blocks (e.g. feed rate, path). If you do not define **BT**, the control uses the value 1 or, if applicable, a default value defined by the machine manufacturer.

The higher the value of **BT**, the smaller will be the effect of an extended program duration through the **M101** function. Please note that this will delay the automatic tool change!

Use the formula **BT** = 10: Average machining time of an **NC block in seconds** to calculate a suitable starting value for **BT**. Round the result up to an integer value. If the calculated result is greater than 100, use the maximum input value of 100.

If you want to reset the current age of a tool (e.g. after changing the indexable inserts), enter the value 0 in the CUR_TIME column.

Prerequisites for a tool change with M101

As replacement tools, use only tools with the same radius. The control does not automatically check the radius of the tool.

If you want the control to check the radius of the replacement tool, enter **M108** in the NC program.

The control performs the automatic tool change at a suitable point in the program. The automatic tool change is not performed:

- During execution of machining cycles
- While radius compensation (**RR/RL**) is active
- Directly after an approach function APPR
- Directly before a departure function DEP
- Directly before and after CHF and RND
- During execution of macros
- During execution of a tool change
- Directly after a TOOL CALL or TOOL DEF
- During execution of SL cycles

130

A

i

Overtime for tool life



This function must be enabled and adapted by the machine tool builder.

The tool condition at the end of planned tool life depends on e.g. the tool type, machining method and workpiece material. In the **OVRTIME** column of the tool table, enter the time in minutes for which the tool is permitted to be used beyond the tool life.

The machine manufacturer specifies whether this column is enabled and how it is used during tool search.

Prerequisites for NC blocks with surface-normal vectors and 3-D compensation

The active radius $(\mathbf{R} + \mathbf{DR})$ of the replacement tool must not deviate from the radius of the original tool. You can enter the delta values (\mathbf{DR}) either in the tool table or in the NC program (compensation table or **TOOL CALL** block). If deviations occur, the control displays a message and does not replace the tool. You can suppress this message with the M function **M107**, and reactivate it with **M108**.

Further information: "Three-dimensional tool compensation (option 9)", Page 456


4.3 Tool compensation

Introduction

The control adjusts the tool path by the compensation value for the tool length in the spindle axis. In the machining plane, it compensates the tool radius.

If you are writing the NC program directly on the control, the tool radius compensation is effective only in the working plane.

The control accounts for the compensation value in up to five axes including the rotary axes.



Tool length compensation

Length compensation becomes effective automatically as soon as a tool is called. To cancel length compensation, call a tool with the length L=0 (e.g. **TOOL CALL 0**).

NOTICE

Danger of collision!

The control uses the defined tool lengths for tool length compensation. Incorrect tool lengths will result in an incorrect tool length compensation. The control does not perform a length compensation and a collision check for tools with a length of **0** and after **TOOL CALL 0**. Danger of collision during subsequent tool positioning movements!

- Always define the actual tool length of a tool (not just the difference)
- ▶ Use TOOL CALL 0 only to empty the spindle

With length compensation, delta values from both the NC program and the tool table are considered.

Compensation value = $L + DL_{TAB} + DL_{Prog}$ with

L: Tool length L from TOOL DEF block or tool table

DL_{TAB}: Oversize for length **DL** in the tool table

DL _{Prog}: Oversize DL for length from TOOL CALL block or from the compensation table

The most recently programmed value takes effect. **Further information:** "Compensation table", Page 382

Tool radius compensation

An NC block can contain the following types of tool radius compensation:

- RL or RR for radius compensation of any contouring function
- **RO**, if there is no radius compensation
- R+ lengthens a paraxial movement by the amount of the tool radius
- R- shortens a paraxial movement by the amount of the tool radius



The control shows an active tool compensation in the general status display.

The radius compensation takes effect as soon as a tool is called and is moved with one of the abovementioned types of tool radius compensation within a straight-line block or within a paraxial movement in the working plane.



The control automatically cancels radius compensation in the following cases:

- Straight-line block with RO
- **DEP** function for departing from the contour
- Selection of a new NC program via **PGM MGT**

For radius compensation, the control takes the delta values from both the **TOOL CALL** block and the tool table into account:

Compensation value = $\mathbf{R} + \mathbf{D}\mathbf{R}_{TAB} + \mathbf{D}\mathbf{R}_{Prog}$ with

R: Tool radius **R** from **TOOL DEF** block or tool table


DR TAB: Oversize for radius **DR** in the tool table


DR _{Prog}: Oversize DR for radius from TOOL CALL block or from the compensation table Further information: "Compensation table", Page 382


Movements without radius compensation: R0

The tool center moves in the working plane to the programmed coordinate.

Applications: Drilling and boring, pre-positioning







Contouring with radius compensation: RR and RL

RR: The tool moves to the right of the programmed contour


RL: The tool moves to the left of the programmed contour

The tool center moves along the contour at a distance equal to the radius. **Right** or **left** are to be understood as based on the direction of tool movement along the workpiece contour.

Between two NC blocks with different radius compensations **RR** and **RL** you must program at least one traversing block in the working plane without radius compensation (that is, with **R0**).

The control does not put radius compensation into effect until the end of the NC block in which it is first programmed.

When radius compensation is activated with **RR/RL**, and in the case of cancellation with **R0**, the control always positions the tool perpendicularly to the programmed start or end point. Position the tool before the first contour point or after the last contour point such that the contour does not incur damage.



Input of radius compensation within path contours

Radius compensation is entered in an ${\rm L}$ block. Enter the coordinates of the target point and confirm your entry with the ${\rm ENT}$ key.

Radius comp.: RL/RR/no comp.?

RL	
RR	
ENT	


i

- Select tool movement to the left of the contour: Press the RL soft key, or
- Select tool movement to the right of the contour: Press the **RR** soft key, or
- Select tool movement without radius compensation or cancel radius compensation: Press the ENT key
- Terminate the NC block: Press the END key

Input of radius compensation within paraxial movements

Radius compensation is entered in a positioning block. Enter the coordinates of the target point, and confirm your entry with the **ENT** key.

TOOL RADIUS COMP: R+/R-/NO COMP?



Radius compensation: Machining corners

Outside corners:

If you program radius compensation, the control moves the tool around outside corners on a transitional arc. If necessary, the control reduces the feed rate at outside corners to reduce machine stress, for example at very great changes of direction

Inside corners:


The control calculates the intersection of the tool center paths at inside corners under radius compensation. From this point it then starts the next contour element. This prevents damage to the workpiece at the inside corners. The permissible tool radius, therefore, is limited by the geometry of the programmed contour.


NOTICE

Danger of collision!

The control needs safe positions for contour approach and departure. These positions must enable the control to perform compensating movements when radius compensation is activated and deactivated. Incorrect positions can lead to contour damage. Danger of collision during machining!

- Program safe approach and departure positions at a sufficient distance from the contour
- Consider the tool radius
- Consider the approach strategy








Programming contours

5.1 Tool movements

Path functions


A workpiece contour is usually composed of several contour elements such as straight lines and circular arcs. With the path functions, you can program the tool movements for **straight lines** and **circular arcs**.



FK free contour programming (option 19)

If a production drawing is not dimensioned for NC and the dimensions given are not sufficient for creating a part program, you can program the workpiece contour with the FK free contour programming. The control calculates the missing data.

With FK programming, you also program tool movements for **straight lines** and **circular arcs**.



Miscellaneous functions M

With the control's miscellaneous functions you can affect

- the program run, e.g., a program interruption
- the machine functions, such as switching spindle rotation and coolant supply on and off
- the path behavior of the tool

Subprograms and program section repeats

If a machining sequence occurs several times in a program, you can save time and reduce the chance of programming errors by entering the sequence once and then defining it as a subprogram or program-section repeat. If you wish to execute a specific NC program section only under certain conditions, you also define this machining sequence as a subprogram. In addition, you can have an NC program call a separate NC program for execution.

Further information: "Subprograms and program section repeats", Page 241

Programming with Q parameters

Instead of programming numerical values in an NC program, you enter markers called Q parameters. You can use the Q parameters for programming mathematical functions that control program execution or describe a contour.

In addition, programming with Q parameters enables you to measure with the 3-D touch probe during the program run.

Further information: "Programming Q parameters", Page 261

5.2 Fundamentals of path functions

Programming tool movements for machining

You create an NC program by programming the path functions for the individual contour elements in sequence You do this by entering the coordinates of the end points of the contour elements given in the production drawing. The control calculates the actual path of the tool from these coordinates, and from the tool data and radius compensation.

The control moves all machine axes programmed in the NC block of a path function simultaneously.

Movement parallel to the machine axes

If the NC block contains one coordinate, the control moves the tool parallel to the programmed machine axis.

Depending on the individual machine, the machining program is executed by movement of either the tool or the machine table on which the workpiece is clamped. Path contours are programmed as if the tool were moving.

Example

50 L X+100 50 Block number L Path function straight line

X+100 Coordinate of the end point

The tool retains the Y and Z coordinates and moves to the position X=100.


Movement in the main planes


If the NC block contains two coordinates, the control moves the tool in the programmed plane.

Example

L X+70 Y+50

The tool retains the Z coordinate and moves on the XY plane to the position X=70, Y=50.






Three-dimensional movement

If the NC block contains three coordinates, the control moves the tool spatially to the programmed position.

Example

L X+80 Y+0 Z-10



Circles and circular arcs

The control moves two machine axes simultaneously on a circular path relative to the workpiece. You can define a circular movement by entering the circle center ${\rm CC}$.

Use the path functions for circular arcs to program circles in the working plane. You define the main plane based on the spindle axis in the **TOOL CALL**.

Spindle axis	Main plane
Z	XY , also UV, XV, UY
Y	ZX , also WU, ZU, WX
X	YZ, also VW, YW, VZ

Circular motion in another plane

You can also use the **Tilt the working plane** function or Q parameters to program circular motions that do not lie in the main plane.

6


Further information: "The PLANE function: Tilting the working plane (option 8)", Page 411 **Further information:** "Principle and overview of functions", Page 262


Direction of rotation DR for circular movements

When a circular path has no tangential transition to another contour element, enter the direction of rotation as follows:

Clockwise direction of rotation: DR-

Counterclockwise direction of rotation: DR+





Radius compensation

The radius compensation must be in the NC block in which you move to the first contour element. You cannot activate radius compensation in an NC block for a circular path. It must be activated beforehand in a straight-line block.

Further information: "Path contours — Cartesian coordinates", Page 154

Further information: "Approaching and departing a contour", Page 144

Pre-positioning

NOTICE


Danger of collision!

The control does not automatically check whether collisions can occur between the tool and the workpiece. Incorrect prepositioning can also lead to contour damage. There is danger of collision during the approach movement!

- Program a suitable pre-position
- Check the sequence and contour with the aid of the graphic simulation

Creating the NC blocks with the path function keys

The gray path function keys initiate the dialog. The control asks you successively for all the necessary information and inserts the program block into the NC program.



Example - programming a straight line



Initiate the programming dialog, e.g. for a straight line

COORDINATES?

- Х
- Enter the coordinates of the straight-line end point, e.g. -20 in X

COORDINATES?



Enter the coordinates of the straight-line end point (e.g., 30 in Y) and confirm with the ENT key

Radius comp.: RL/RR/no comp.?



Select the radius compensation: Press the **RO** soft key for the tool to move without compensation, for example.

Feed rate F=? / F MAX = ENT



Enter 100 (e.g., a feed rate of 100 mm/min; for programming in inches: an input of 100 corresponds to a feed rate of 10 inches/min) and confirm your entry with the ENT key, or



- Move at rapid traverse: Press the FMAX soft key; or
- F AUTO
- Traverse at the feed rate defined in the TOOL ► CALL block: Press the F AUTO soft key.

MISCELLANEOUS FUNCTION M?



Enter 3 (miscellaneous function e.g. M3) and terminate the dialog with the END key

Example

L X-20 Y+30 R0 FMAX M3

5.3 Approaching and departing a contour


Starting point and end point

The tool approaches the first contour point from the starting point. The starting point must be:

- Programmed without radius compensation
- Approachable without danger of collision
- Close to the first contour point


Example in the figure on the right:

If you set the starting point in the dark gray area, the contour will be damaged when the first contour element is approached.



First contour point

You need to program a radius compensation for the tool movement to the first contour point.




Approaching the starting point in the spindle axis

When the starting point is approached, the tool must be moved to the working depth in the spindle axis. If danger of collision exists, approach the starting point in the spindle axis separately.

Example

30 L Z-10 R0 FMAX	
31 L X+20 Y+30 RL F350	



End point

The end point should be selected so that it is:

- Approachable without danger of collision
- Near to the last contour point
- In order to make sure the contour will not be damaged, the optimal ending point should lie on the extended tool path for machining the last contour element

Example in the figure on the right:


If you set the end point in the dark gray area, the contour will be damaged when the end point is approached.


Departing the end point in the spindle axis:

Program the departure from the end point in the spindle axis separately.

Example

50 L X+60 Y+70 R0 F700 51 L Z+250 R0 FMAX






Common starting and end points

Do not program any radius compensation if the starting point and end point are the same.

In order to make sure the contour will not be damaged, the optimal starting point should lie between the extended tool paths for machining the first and last contour elements.

Example in the figure on the right:


If you set the end point in the dark gray area, the contour will be damaged when the contour is approached/departed.



Overview: Types of paths for contour approach and departure

The functions for contour approach **APPR** and departure **DEP** are activated with the **APPR/DEP** key. You can then select the following path forms with the corresponding soft keys:

Approach	Departure	Function
APPR LT	DEP LT	Straight line with tangential connection
APPR LN	DEP LN	Straight line perpendicular to a contour point
APPR CT	DEP CT	Circular arc with tangential connection
APPR LCT	DEP LCT	Circular arc with tangential connection to the contour. Approach and departure to an auxiliary point outside the contour on a tangentially connecting line



Approaching and departing a helix

The tool approaches and departs a helix on its extension by moving in a circular arc that connects tangentially to the contour. You program helical approach and departure with the **APPR CT** and **DEP CT** functions.


Important positions for approach and departure

NOTICE

Danger of collision!

The control traverses from the current position (starting point P_S) to the auxiliary point P_H at the last feed rate entered. If you programmed **FMAX** in the last positioning block before the approach function, the control also approaches the auxiliary point P_H at rapid traverse.

Program a feed rate other than FMAX before the approach function



Starting point P_S

You program this position in the block before the APPR block. P_{S} lies outside the contour and is approached without radius compensation (R0).

Auxiliary point P_H

Some of the paths for approach and departure go through an auxiliary point P_H that the control calculates from your input in the APPR or DEP block.

- First contour point P_A and last contour point P_E
 You program the first contour point P_A in the APPR block.
 The last contour point P_E can be programmed with any path function. If the APPR block also includes the Z coordinate, the control moves the tool simultaneously to the first contour point P_A.
- End point P_N

The position P_N lies outside of the contour and results from your input in the DEP block. If the DEP block also includes the Z coordinate, the control moves the tool simultaneously to the end point $\mathsf{P}_N.$

Designation	Meaning	
APPR	Approach	
DEP	Departure	
L	Line	
С	Circle	
т	Tangential (smooth connection)	
N	Normal (perpendicular)	

NOTICE

Danger of collision!

The control does not automatically check whether collisions can occur between the tool and the workpiece. Incorrect prepositioning and incorrect auxiliary points P_H can also lead to contour damage. There is danger of collision during the approach movement!

- Program a suitable pre-position
- Check the auxiliary point P_H, the sequence and the contour with the aid of the graphic simulation

With the **APPR LT**, **APPR LN** and **APPR CT** functions, the control moves the tool to the auxiliary point P_H at the last programmed feed rate (which can also be **FMAX**). With the **APPR LCT** function, the control moves to the auxiliary point P_H at the feed rate programmed with the APPR block. If no feed rate is programmed yet before the approach block, the control generates an error message.

Polar coordinates

i)

You can also program the contour points for the following approach/ departure functions over polar coordinates:

- APPR LT becomes APPR PLT
- APPR LN becomes APPR PLN
- APPR CT becomes APPR PCT
- APPR LCT becomes APPR PLCT
- DEP LCT becomes DEP PLCT

Select by soft key an approach or departure function, then press the orange ${\bf P}$ key.

Radius compensation

The tool radius compensation is programmed together with the first contour point P_A in the APPR block. The DEP blocks automatically discard the tool radius compensation.




If you program **APPR LN** or **APPR CT** with **R0**, the control stops the machining/simulation with an error message. This method of function differs from the iTNC 530 control!

Approaching on a straight line with tangential connection: APPR LT

The tool moves on a straight line from the starting point P_S to an auxiliary point P_H . It then moves to the first contour point P_A on a straight line that connects tangentially to the contour. The auxiliary point P_H is separated from the first contour point P_A by the distance **LEN**.

- $\blacktriangleright\,$ Use any path function to approach the starting point P_{S}
- Initiate the dialog with the APPR DEP key and APPR LT soft key
 - Coordinates of the first contour point P_A
 - LEN: Distance from the auxiliary point P_H to the first contour point P_A
 - Radius compensation RR/RL for machining



Example

APPR LT

1

7 L X+40 Y+10 R0 FMAX M3	P _S without radius compensation	
8 APPR LT X+20 Y+20 Z-10 LEN15 RR F100	P_A with radius comp. RR, distance P_H to P_A : LEN=15	
9 L X+35 Y+35	End point of the first contour element	
10 L	Next contour element	

Approaching on a straight line perpendicular to the first contour point: APPR LN

- Use any path function to approach the starting point P_S.
- Initiate the dialog with the APPR DEP key and APPR LN soft key:
- APPR LN
- Coordinates of the first contour point P_A
- Length: Distance to the auxiliary point P_H.
 Always enter LEN as a positive value
- Radius compensation RR/RL for machining

7 L X+40 Y+10 R0 FMAX M3	Approach PS without radius compensation	
8 APPR LN X+10 Y+20 Z-10 LEN15 RR F100	PA with radius comp. RR	
9 L X+20 Y+35	End point of the first contour element	
10 L	Next contour element	

Approaching on a circular path with tangential connection: APPR CT

The tool moves on a straight line from the starting point P_S to an auxiliary point P_H . It then moves from PH to the first contour point PA following a circular arc that is tangential to the first contour element.


The arc from P_H to P_A is determined through the radius R and the center angle **CCA**. The direction of rotation of the circular arc is automatically derived from the tool path for the first contour element.

- Use any path function to approach the starting point P_S.
- Initiate the dialog with the APPR DEP key and APPR CT soft key



- Coordinates of the first contour point P_A
- Radius R of the circular arc
 - If the tool should approach the workpiece in the direction defined by the radius compensation: Enter R as a positive value
 - If the tool should approach the workpiece opposite to the radius compensation: Enter R as a negative value.
- Center angle **CCA** of the arc
 - CCA can be entered only as a positive value.
 - Maximum input value 360°
- Radius compensation RR/RL for machining

7 L X+40 Y+10 R0 FMAX M3	Approach PS without radius compensation	
8 APPR CT X+10 Y+20 Z-10 CCA180 R+10 RR F100 PA with radius compensation RR, radius R=10		
9 L X+20 Y+35	End point of the first contour element	
10 L	Next contour element	



Approaching on a circular path with tangential connection from a straight line to the contour: APPR LCT


The tool moves on a straight line from the starting point P_S to an auxiliary point P_H . It then moves to the first contour point P_A on a circular arc. The feed rate programmed in the APPR block is effective for the entire path that the control traversed in the approach block (path P_S to P_A).

If you have programmed the coordinates of all three principal axes X, Y and Z in the approach block, the control moves the tool from the position defined before the APPR block to the auxiliary point P_H on all three axes simultaneously. Then the control moves the tool from P_H to P_A only in the working plane.

The arc is connected tangentially both to the line $P_S - P_H$ as well as to the first contour element. Once these lines are known, the radius then suffices to completely define the tool path.

- ▶ Use any path function to approach the starting point P_S.
- Initiate the dialog with the APPR DEP key and APPR LCT soft key:
- APPR LCT
- Coordinates of the first contour point P_A
- Radius R of the circular arc. Enter R as a positive value
- Radius compensation RR/RL for machining

7 L X+40 Y+10 R0 FMAX M3 Approach PS without radius compensation	
8 APPR LCT X+10 Y+20 Z-10 R10 RR F100	PA with radius compensation RR, radius R=10
9 L X+20 Y+35 End point of the first contour element	
10 L	Next contour element




Departing in a straight line with tangential connection: DEP LT

The tool moves on a straight line from the last contour point P_E to the end point P_N . The line lies on the extension of the last contour element. P_N is separated from P_E by the distance **LEN**.

- Program the last contour element with the end point P_E and radius compensation
- ▶ Initiate the dialog with the APPR DEP key and DEP LT soft key



 LEN: Enter the distance from the last contour element P_E to the end point P_N.



Example

23 L Y+20 RR F100	Last contour element: PE with radius compensation	
24 DEP LT LEN12.5 F100	Depart contour by LEN=12.5 mm	
25 L Z+100 FMAX M2	Retract in Z, return jump, end program	


Departing in a straight line perpendicular to the last contour point: DEP LN

The tool moves on a straight line from the last contour point P_E to the end point P_N. The line departs on a perpendicular path from the last contour point P_E. P_N is separated from P_E by the distance **LEN** plus the tool radius.

- Program the last contour element with the end point P_E and radius compensation
- Initiate the dialog with the APPR DEP key and DEP LN soft key



 LEN: Enter the distance from the last contour element to P_N. Important: Enter a positive value in LEN



23 L Y+20 RR F100	Last contour element: PE with radius compensation
24 DEP LN LEN+20 F100	Depart perpendicular to contour by LEN=20 mm
25 L Z+100 FMAX M2	Retract in Z, return jump, end program

Departing on a circular path with tangential connection: DEP CT

The tool moves on a circular arc from the last contour point P_E to the end point $\mathsf{P}_\mathsf{N}.$ The circular arc connects tangentially to the last contour element.

- Program the last contour element with the end point P_E and radius compensation
- ▶ Initiate the dialog with the APPR DEP key and DEP CT soft key



- Center angle **CCA** of the arc
- Radius R of the circular arc
 - If the tool should depart the workpiece in the direction opposite to the radius compensation: Enter R as a positive value.
 - If the tool should depart the workpiece in the direction **opposite** to the radius compensation: Enter R as a negative value.

Example

23 L Y+20 RR F100	Last contour element: PE with radius compensation	
24 DEP CT CCA 180 R+8 F100	Center angle=180°, arc radius=8 mm	
25 L Z+100 FMAX M2	Retract in Z, return jump, end program	

γ

20 -

P_N


Departing on a circular arc tangentially connecting the contour and a straight line: DEP LCT

The tool moves on a circular arc from the last contour point P_S to an auxiliary point P_H . It then moves on a straight line to the end point P_N . The arc is tangentially connected both to the last contour element and to the line from P_H to P_N . Once these lines are known, the radius R suffices to unambiguously define the tool path.

- Program the last contour element with the end point P_E and radius compensation
- Initiate the dialog with the APPR/DEP key and DEP LCT soft key



- Enter the coordinates of the end point P_N
- Radius R of the circular arc. Enter R as a positive value



RR

RR

Х

23 L Y+20 RR F100	Last contour element: PE with radius compensation
24 DEP LCT X+10 Y+12 R+8 F100	Coordinates PN, arc radius=8 mm
25 L Z+100 FMAX M2	Retract in Z, return jump, end program

5.4 Path contours – Cartesian coordinates

Overview of path functions

Кеу	Function	Tool movement	Required input	Page
L	Straight line L	Straight line	Coordinates of the end point	155
CHF o	Chamfer: CHF	Chamfer between two straight lines	Chamfer side length	156
CC 🔶	Circle center CC	None	Coordinates of the circle center or pole	158
C or of the second seco	Circular arc C	Circular arc around a circle center CC to an arc end point	Coordinates of the arc end point, direction of rotation	159
CR	Circular arc CR	Circular arc with a certain radius	Coordinates of the arc end point, arc radius, direction of rotation	160
CT 	Circular arc CT	Circular arc with tangen- tial connection to the preceding and subsequent contour elements	Coordinates of the arc end point	162
RND	Corner rounding RND	Circular arc with tangen- tial connection to the preceding and subsequent contour elements	Rounding radius R	157
FK	FK free contour program- ming	Straight line or circular path with any connection to the preceding contour element	Input depends on the function	176

Straight line L

The control moves the tool in a straight line from its current position to the straight-line end point. The starting point is the end point of the preceding NC block.



- Press the L key to open a program block for a linear movement
- Coordinates of the end point of the straight line, if necessary
- Radius compensation RL/RR/R0
- Feed rate F
- Miscellaneous function M


Example

7 L X+10 Y+40 RL F200 M3
8 L IX+20 IY-15
9 L X+60 IY-10

Actual position capture

You can also generate a straight-line block (**L** block) by using the **actual position capture** key:

- In Manual Operation mode, move the tool to the position you want to capture
- Switch the screen display to programming
- Select the NC block after which you want to insert the straight line block
- ++-
- Press the actual position capture key
- > The control generates a straight-line block with the actual position coordinates.



Inserting a chamfer between two straight lines

The chamfer enables you to cut off corners at the intersection of two straight lines.

- The line blocks before and after the CHF block must be in the same working plane as the chamfer.
- The radius compensation before and after the CHF block must be the same
- The chamfer must be machinable with the current tool
- CHF o

Chamfer side length: Length of the chamfer, and if necessary:

Feed rate F (effective only in CHF block)


Example

A

7 L X+0 Y+30 RL F300 M3
8 L X+40 IY+5
9 CHF 12 F250
10 L IX+5 Y+0

You cannot start a contour with a **CHF** block. A chamfer is possible only in the working plane. The corner point is cut off by the chamfer and is not part of the contour.

A feed rate programmed in the **CHF** block is effective only in that CHF block. After the **CHF** block, the previous feed rate becomes effective again.



Rounded corners RND

The **RND** function creates rounding arcs at contour corners. The tool moves on an arc that connects tangentially to both the preceding and subsequent contour elements.

The rounding arc must be machinable with the called tool.

l	RND 💡
l	~

- Rounding radius: Enter the radius, and if necessary:
- Feed F (effective only in the RND block)

Example

A


•	
5 L X+10 Y+40 RL F300 M3	
6 L X+40 Y+25	
7 RND R5 F100	
8 L X+10 V+5	

In the preceding and subsequent contour elements, both coordinates must lie in the plane of the rounding arc. If you machine the contour without tool-radius compensation, you must program both coordinates in the plane.

The tool will not move to the corner point.

A feed rate programmed in the **RND** block is effective only in that **RND** block. After the **RND** block, the previous feed rate becomes effective again.

You can also use an $\ensuremath{\mathsf{RND}}$ block for a tangential contour approach.



Circle center CC

You can define a circle center for circles that you have programmed with the C key (circular path C) This is done in the following ways:

- Enter the Cartesian coordinates of the circle center in the working plane, or
- Use the position last programmed, or
- Take over the coordinates with the **Actual-position-capture** key

CC 🔶

Enter coordinates for the circle center or, if you want to use the last programmed position, enter no coordinates

Example

5 CC X+25 Y+25

or

10 L X+25 Y+25		
11 CC		

The program lines 10 and 11 do not refer to the illustration.

Validity


The circle center definition remains in effect until you program a new circle center.

Entering the circle center incrementally

If you enter the circle center with incremental coordinates, you have programmed it relative to the last programmed position of the tool.

6

The only effect of **CC** is to define a position as circle center: The tool does not move to this position. The circle center is also the pole for polar coordinates.



Circular arc C around circle center CC

Before programming a circular arc C, you must first specify the circle center \mathbf{CC} . The last programmed tool position will be the starting point of the arc.

- Move the tool to the starting point of the circle
- cc 🔶

C____

Enter the coordinates of the arc end point, if necessary:


Enter the **coordinates** of the circle center

- Direction of rotation DR
- Feed F
- Miscellaneous function M

Example

5 CC X+25 Y+25		
6 L X+45 Y+25 RR F200 M3		

7 C X+45 Y+25 DR+



Circular motion in another plane

The control normally makes circular movements in the active working plane. However, you can also program circular arcs that do not lie in the active working plane.


Example

3 TOOL CALL 1 Z S4000
4
5 CC X+25 Z+25
6 L X+45 Y+25 Z+25 RR F200 M3
7 C X+45 Z+25 DR+

By simultaneously rotating these circular movements you can create spatial arcs (arcs in three axes).

Full circle

For the end point, program the same coordinates as for the starting point.




circleDeviation (no. 200901).

Smallest possible circle that the control can traverse: 0.016 mm.

Circular arc CR with fixed radius

The tool moves on a circular path with the radius R.

- CR
- Coordinates of the arc end point
- Note on Radius R: The algebraic sign determines the size of the arc!
- Note on Direction of rotation DR: The algebraic sign determines whether the arc is concave or convex.
- Miscellaneous function M
- Feed F



Full circle

For a full circle, program two semicircle blocks in succession:

The end point of the first semicircle is the starting point of the second. The end point of the second semicircle is the starting point of the first.

Central angle CCA and arc radius R

The starting and end points on the contour can be connected with four arcs of the same radius: Smaller arc: CCA<180°

Enter the radius with a positive sign, i.e. R>0

Larger arc: CCA>180°

Enter the radius with a negative sign, i.e. R<0

The direction of rotation determines whether the arc is curving outward (convex) or curving inward (concave):

Convex: Direction of rotation **DR-** (with radius compensation **RL**) Concave: Direction of rotation **DR+** (with radius compensation **RL**)

> The distance from the starting and end points of the arc diameter cannot be greater than the diameter of the arc. The maximum radius is 99.9999 m.

You can also enter rotary axes A, B and C.

The control normally makes circular movements in the active working plane. However, you can also program circular arcs that do not lie in the active working plane. By simultaneously rotating these circular movements you can create spatial arcs (arcs in three axes).

Example

A

10 L X+40 Y+40 RL F200 M3

11 CR X+70 Y+40 R+20 DR- (arc 1)

or


11 CR X+70 Y+40 R+20 DR+ (arc 2)


or

11 CR X+70 Y+40 R-20 DR- (arc 3)

or

11 CR X+70 Y+40 R-20 DR+ (arc 4)





Circular arc CT with tangential transition

The tool moves on an arc that connects tangentially to the previously programmed contour element.

A connection between two contour elements is called tangential when there is no kink or corner at the intersection between the two contours—the transition is smooth.

The contour element to which the tangential arc connects must be programmed immediately before the **CT** block. This requires at least two positioning blocks.



Coordinates of the arc end point, and if necessary:

- Feed F
- Miscellaneous function M




7 L X+0 Y+25 RL F300 M3

8 L X+25 Y+30 9 CT X+45 Y+20


10 L Y+0

6

A tangential arc is a two-dimensional operation: the coordinates in the **CT** block and in the contour element preceding it must be in the same plane of the arc!




Example: Linear movements and chamfers with Cartesian coordinates




0 BEGIN PGM LINEAR MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-20	Define the workpiece blank for graphic workpiece simulation
2 BLK FORM 0.2 X+100 Y+100 Z+0	
3 TOOL CALL 1 Z S4000	Call the tool in the spindle axis and with spindle speed
4 L Z+250 R0 FMAX	Retract the tool in the spindle axis at rapid traverse FMAX
5 L X-10 Y-10 R0 FMAX	Pre-position the tool
6 L Z-5 R0 F1000 M3	Move to working depth at feed rate F = 1000 mm/min
7 APPR LT X+5 y+5 LEN10 RL F300	Approach the contour at point 1 on a straight line with tangential connection
8 L Y+95	Move to point 2
9 L X+95	Point 3: first straight line for corner 3
10 CHF 10	Program a chamfer with length 10 mm
11 L Y+5	Point 4: 2nd straight line for corner 3, 1st straight line for corner 4
12 CHF 20	Program a chamfer with length 20 mm
13 L X+5	Move to last contour point 1, second straight line for corner 4
14 DEP LT LEN10 F1000	Depart the contour on a straight line with tangential connection
15 L Z+250 R0 FMAX M2	Retract the tool, end program
16 END PGM LINEAR MM	

Example: Circular movements with Cartesian coordinates



0 BEGIN PGM CIRCULAR MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-20	Define the workpiece blank for graphic workpiece simulation
2 BLK FORM 0.2 X+100 Y+100 Z+0	
3 TOOL CALL 1 Z s4000	Call the tool in the spindle axis and with spindle speed
4 L Z+250 R0 FMAX	Retract the tool in the spindle axis at rapid traverse FMAX
5 L X-10 Y-10 R0 FMAX	Pre-position the tool
6 L Z-5 R0 F1000 M3	Move to working depth at feed rate F = 1000 mm/min
7 APPR LCT X+5 Y+5 R5 RL F300	Approach the contour at point 1 on a circular arc with tangential connection
8 L X+5 Y+85	Point 2: First straight line for corner 2
9 RND R10 F150	Insert radius with $R = 10 \text{ mm}$, feed rate: 150 mm/min
10 L X+30 Y+85	Move to point 3: Starting point of the arc with CR
11 CR X+70 Y+95 R+30 DR-	Move to point 4: End point of the arc with CR, radius 30 mm
12 L X+95	Move to point 5
13 L X+95 Y+40	Move to point 6
14 CT X+40 Y+5	Move to point 7: End point of the arc, circular arc with tangential connection to point 6, the control automatically calculates the radius
15 L X+5	Move to last contour point 1
16 DEP LCT X-20 Y-20 R5 F1000	Depart the contour on a circular arc with tangential connection
17 L Z+250 R0 FMAX M2	Retract the tool, end program
18 END PGM CIRCULAR MM	

Example: Full circle with Cartesian coordinates



0 BEGIN PGM C-CC MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-20	Workpiece blank definition
2 BLK FORM 0.2 X+100 Y+100 Z+0	
3 TOOL CALL 1 Z S3150	Tool call
4 CC X+50 Y+50	Define the circle center
5 L Z+250 R0 FMAX	Retract the tool
6 L X-40 Y+50 R0 FMAX	Pre-position the tool
7 L Z-5 R0 F1000 M3	Move to working depth
8 APPR LCT X+0 Y+50 R5 RL F300	Approach the starting point of the circle on a circular arc with tangential connection
9 C X+0 DR-	Move to the circle end point (= circle starting point)
10 DEP LCT X-40 Y+50 R5 F1000	Depart the contour on a circular arc with tangential connection
11 L Z+250 R0 FMAX M2	Retract the tool, end program
12 END PGM C-CC MM	

5.5 Path contours – Polar coordinates

Overview

With polar coordinates you can define a position in terms of its angle **PA** and its distance **PR** relative to a previously defined pole **CC**.

Polar coordinates are useful with:

- Positions on circular arcs
- Workpiece drawing dimensions in degrees, e.g. bolt hole circles

Overview of path functions with polar coordinates

Кеу	Tool movement	Required input	Page
ц + Р	Straight line	Polar radius, polar angle of the straight- line end point	167
с + Р	Circular path around circle center/pole to arc end point	Polar angle of the arc end point, direction of rotation	168
Ст + Р	Circular arc with tangential connection to the preceding contour element	Polar radius, polar angle of the arc end point	168
с + Р	Combination of a circular and a linear movement	Polar radius, polar angle of the arc end point, coordinate of the end point in the tool axis	169

HEIDENHAIN | TNC 620 | Klartext Programming User's Manual | 01/2021

Datum for polar coordinates: pole CC

You can set the pole CC at any point in the NC program, before indicating positions in polar coordinates. Set the pole in the same way as you would program the circle center.

- CC 🔶
- Coordinates: Enter Cartesian coordinates for the pole or, if you want to use the last programmed position, do not enter any coordinates. Before programming polar coordinates, define the pole. You can only define the pole in Cartesian coordinates. The pole remains in effect until you define a new pole.

Example

12 CC X+45 Y+25

Straight line LP

The tool moves in a straight line from its current position to the straight-line end point. The starting point is the end point of the preceding NC block.




Polar coordinate radius PR: Enter the distance from the pole CC to the straight-line end point


Polar-coordinates angle PA: Angular position of the straight-line end point between –360° and +360°

The sign of **PA** depends on the angle reference axis:

- If the angle from the angle reference axis to PR is counterclockwise: PA>0
- If the angle from the angle reference axis to PR is clockwise: PA<0</p>

12 CC X+45 Y+25	
13 LP PR+30 PA+0 RR F300 M3	
14 LP PA+60	
15 LP IPA+60	
16 LP PA+180	





Circular path CP around pole CC

The polar coordinate radius **PR** is also the radius of the arc. **PR** is defined by the distance from the starting point to the pole **CC**. The last programmed tool position will be the starting point of the arc.



Polar-coordinates angle PA: Angular position of the arc end point between -99999.9999° and +99999.9999°

Р

A

Direction of rotation DR

Example

- 18 CC X+25 Y+25
- 19 LP PR+20 PA+0 RR F250 M3

20 CP PA+180 DR+

With incremental inputs you must enter DR and PA with the same sign.

Consider this behavior when importing NC programs from earlier controls. Adapt the NC program if required.

Circle CTP with tangential connection

The tool moves on a circular path, starting tangentially from a preceding contour element.




Р


i

- Polar coordinate radius PR: Distance between the arc end point and the pole CC
- Polar coordinate angle PA: Angular position of the arc end point.

The pole is **not** the center of the contour arc!

12 CC X+40 Y+35	
13 L X+0 Y+35 RL F250 M3	
14 LP PR+25 PA+120	
15 CTP PR+30 PA+30	
16 L Y+0	






Helix

A helix is a combination of a circular movement in a main plane and a linear movement perpendicular to this plane. You program the circular path in a main plane.

A helix is programmed only in polar coordinates.



Application

- Large-diameter internal and external threads
- Lubrication grooves

Calculating the helix

To program a helix, you must enter the total angle through which the tool is to move on the helix in incremental dimensions, and the total height of the helix.

Thread revolutions n:	Thread revolutions + thread overrun at the start and end of the thread
Total height h:	Thread pitch P times thread revolu- tions n
Incremental total angle IPA:	Thread revolutions x 360° + angle for beginning of thread + angle for thread overrun
Starting coordinate Z:	Pitch P times (thread revolutions + thread overrun at start of thread)

Shape of the helix

The table below illustrates in which way the shape of the helix is determined by the work direction, direction of rotation and radius compensation.

Internal thread	Work direction	Direction of rotation	Radius compensation
Right-hand	Z+	DR+	RL
Left-hand	Z+	DR-	RR
Right-hand	Z–	DR-	RR
Left-hand	Z–	DR+	RL
External thread			
Right-hand	Z+	DR+	RR
Left-hand	Z+	DR-	RL
Right-hand	Z–	DR-	RL
Left-hand	Z–	DR+	RR

z↓

Programming a helix

Always enter the same algebraic sign for the direction of rotation and the incremental total angle **IPA**. The tool may otherwise move in a wrong path and damage the contour.

For the total angle **IPA** you can enter a value of -99 999.9999° to +99 999.9999°.

C

Ρ

i

Polar coordinates angle: Enter the total angle of tool traverse along the helix in incremental dimensions.

- After entering the angle, specify the tool axis with an axis selection key
- Coordinate: Enter the coordinate for the height of the helix in incremental dimensions
- Direction of rotation DR Clockwise helix: DR– Counterclockwise helix: DR+
- Enter the radius compensation according to the table


Example: Thread M6 x 1 mm with 5 revolutions

12 CC X+40 Y+25
13 L Z+0 F100 M3
14 LP PR+3 PA+270 RL F50
15 CP IPA-1800 IZ+5 DR-

25 25 40


5

Example: Linear movement with polar coordinates



0 BEGIN PGM LINEARPO MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-20	Workpiece blank definition
2 BLK FORM 0.2 X+100 Y+100 Z+0	
3 TOOL CALL 1 Z S4000	Tool call
4 CC X+50 Y+50	Define the preset for polar coordinates
5 L Z+250 R0 FMAX	Retract the tool
6 LP PR+60 PA+180 R0 FMAX	Pre-position the tool
7 L Z-5 R0 F1000 M3	Move to working depth
8 APPR PLCT PR+45 PA+180 R5 RL F250	Approach the contour at point 1 on a circular arc with tangential connection
9 LP PA+120	Move to point 2
10 LP PA+60	Move to point 3
11 LP PA+0	Move to point 4
12 LP PA-60	Move to point 5
13 LP PA-120	Move to point 6
14 LP PA+180	Move to point 1
15 DEP PLCT PR+60 PA+180 R5 F1000	Depart the contour on a circular arc with tangential connection
16 L Z+250 R0 FMAX M2	Retract the tool, end of program
17 END PGM LINEARPO MM	

Example: Helix



0 BEGIN PGM HELIX MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-20	Workpiece blank definition
2 BLK FORM 0.2 X+100 Y+100 Z+0	
3 TOOL CALL 1 Z S1400	Tool call
4 L Z+250 R0 FMAX	Retract the tool
5 L X+50 Y+50 R0 FMAX	Pre-position the tool
6 CC	Transfer the last programmed position as the pole
7 L Z-12.75 R0 F1000 M3	Move to working depth
8 APPR PCT PR+32 PA-182 CCA180 R+2 RL F100	Approach the contour on a circular arc with tangential connection
9 CP IPA+3240 IZ+13.5 DR+ F200	Helical interpolation
10 DEP CT CCA180 R+2	Depart the contour on a circular arc with tangential connection
11 L Z+250 R0 FMAX M2	Retract the tool, end of program
12 END PGM HELIX MM	

5.6 Path contours – FK free contour programming (option 19)

Fundamentals

Workpiece drawings that are not dimensioned for NC often contain unconventional coordinate data that cannot be entered with the gray path function keys.

You can enter such dimensional data directly by using the free contour programming function FK, e.g.

- If there are known coordinates on or in proximity to the contour element
- If coordinate data refers to another contour element
- If directional data and data regarding the course of the contour are known

The control derives the contour from the known coordinate data and supports the programming dialog with the interactive FK programming graphics. The figure at upper right shows a workpiece drawing for which FK programming is the most convenient programming method.



Programming notes

You must enter all available data for every contour element. Even the data that does not change must be entered in every NC block—otherwise it will not be recognized.

Q parameters are permissible in all FK elements, except in elements with relative references (e.g. **RX** or **RAN**), or in elements that are referenced to other NC blocks.

If both FK blocks and conventional blocks are entered in an NC program, the FK contour must be fully defined before you can return to conventional programming.


Program all of the contours before combining them (e.g., with the SL cycles). You thereby ensure that the contours are correctly defined and avoid unnecessary error messages.

The control needs a fixed point that it can use as the basis for all calculations. Use the gray path function keys to program a position that contains both coordinates of the working plane immediately before programming the FK contour. Do not enter any Q parameters in this NC block.

If the first NC block of an FK contour is an **FCT** or **FLT** block, you must program at least two NC blocks with the gray path function keys before it. This fully defines the approach direction.

Do not program an FK contour immediately after an **LBL** command.

You cannot combine the cycle call **M89** with FK programming.



Defining the working plane

The FK free contour programming feature can only be used for programming contour elements that lie in the working plane.

The control defines the working plane for FK programming according to the following hierarchy:

- 1 Through the plane defined in a **FPOL** block
- 2 Through the working plane specified and defined in the TOOL CALL (e.g., Z = X/Y plane)
- 3 If none of this applies, then the standard X/Y plane is active

Display of the FK soft key depends on the spindle axis specified when defining the workpiece blank. If for example you enter spindle axis \mathbf{Z} in the workpiece blank definition, the control only shows FK soft keys for the X/Y plane.

Switch the working plane

If you need a different working plane from the currently active plane, then proceed as follows:



- Press the PLANE XY ZX YZ soft key
- The control then displays the FK soft keys in the newly selected plane.

FK programming graphics

f

A

To use graphical support during FK programming, select the **PROGRAM + GRAPHICS** screen layout.

Further information: "Programming", Page 71

Program all of the contours before combining them (e.g., with the SL cycles). You thereby ensure that the contours are correctly defined and avoid unnecessary error messages.

Incomplete coordinate data often is not sufficient to fully define a workpiece contour. In this case, the control indicates the possible solutions in the FK graphic. You can then select the contour that matches the drawing.

The control uses various colors in the FK graphics:

- blue: uniquely specified contour element
- The last FK element is only shown in blue after the departure movement.
- violet: not yet uniquely specified contour element
- ocher: tool midpoint path
- red: rapid traverse
- **green:** more than one solution is possible

If the data permit several possible solutions and the contour element is displayed in green, select the correct contour element as follows:



Press the SHOW SOLUTION soft key repeatedly until the correct contour element is displayed. Use the zoom function if you cannot distinguish between possible solutions in the standard view

SELECT SOLUTION If the displayed contour element matches the drawing, then select this contour element with the SELECT SOLUTION soft key

If you do not yet wish to define a green contour element, then press the **START SINGLE** soft key to continue the FK dialog.




You should define the green contour elements as soon as possible with **SELECT SOLUTION** to limit ambiguity for the subsequent contour elements.

Showing block numbers in the graphic window

To show a block number in the graphic window:



Set the SHOW BLOCK NO. soft key to ON



Initiating the FK dialog

Proceed as follows to open the FK dialog:

- Press the FK key
- The control then displays the soft-key row with the FK functions.

If you initiate the FK dialog with one of these soft keys, the control shows additional soft-key rows. You can use them to enter known coordinates, directional data, and data regarding the course of the contour.

Soft key	FK element
FLT	Straight line with tangential connection
FL	Straight line without tangential connection
FCT	Circular arc with tangential connection
FC	Circular arc without tangential connection
FPOL	Pole for FK programming
PLANE XY ZX YZ	Select the working plane

Terminating the FK dialog

Proceed as follows to exit the soft-key row for FK programming:

END

Press the END soft key

Alternative:



▶ Press the **FK** key again

Pole for FK programming



- ► To display the soft keys for free contour programming, press the **FK** key
- FPOL

i)

- To initiate the dialog for defining the pole, press the FPOL soft key
- > The control displays the axis soft keys of the active working plane.
- Enter the pole coordinates using these soft keys

The pole for FK programming remains active until you define a new one using FPOL.

FK

Free straight line programming

Straight line without tangential connection

|--|

- ► To display the soft keys for free contour programming, press the **FK** key
- FL
- To initiate the dialog for free programming of straight lines, press the FL soft key
- > The control displays additional soft keys.
- Enter all known data in the NC block by using these soft keys
- The FK graphic displays the programmed contour element in violet until sufficient data is entered. If the entered data describes several solutions, the graphic will display the contour element in green.

Further information: "FK programming graphics", Page 175

Straight line with tangential connection

If the straight line connects tangentially to another contour element, initiate the dialog with the **FLT** soft key:



- To display the soft keys for free contour programming, press the FK key
- FLT
- ► To initiate the dialog, press the **FLT** soft key
- Enter all known data in the NC block by using the soft keys

Free circular path programming

Circular arc without tangential connection

- To display the soft keys for free contour programming, press the FK key
- FC
- ► To initiate the dialog for free programming of circular arcs, press the **FC** soft key
- The control displays soft keys with which you can enter direct data on the circular arc or data on the circle center.
- Enter all known data in the NC block by using these soft keys
- The FK graphic displays the programmed contour element in violet until sufficient data is entered. If the entered data describes several solutions, the graphic will display the contour element in green.

Further information: "FK programming graphics", Page 175

Circular arc with tangential connection

If the circular arc connects tangentially to another contour element, initiate the dialog with the **FCT** soft key:

FK	
	_

FCT

- ► To display the soft keys for free contour programming, press the **FK** key
- ► To initiate the dialog, press the **FCT** soft key
- Enter all known data in the NC block by using the soft keys

Input possibilities

End point coordinates

Soft keys K		Known data	
	Y	Cartesian coordinates X and Y	
PR	PA	Polar coordinates referenced to FPOL	

Example

7 FPOL X+20 Y+30	
8 FL IX+10 Y+20 RR F100	
9 FCT PR+15 IPA+30 DR+ R15	

Direction and length of contour elements

Soft keys	Known data
LEN	Length of a straight line
AN	Gradient angle of a straight line
	Chord length LEN of an arc
	Gradient angle AN of an entry tangent
CCA	Center angle of an arc

NOTICE


Danger of collision!


Incremental gradient angles **IAN** are referenced by the control to the direction of the previous traversing block. NC programs from previous control models (including iTNC 530) are not compatible. There is danger of collision during the execution of imported NC programs!


- Check the sequence and contour with the aid of the graphic simulation
- Adapt imported NC programs if required

Example

27 FLT X+25 LEN 12.5 AN+35 RL F200 28 FC DR+ R6 LEN 10 AN-45 29 FCT DR- R15 LEN 15








Circle center CC, radius and direction of rotation in the FC/FCT block

The control calculates a circle center for free-programmed arcs from the data you enter. This makes it possible to program full circles in an NC block with FK programming.

If you wish to define the circle center in polar coordinates you must use FPOL, not **CC**, to define the pole. FPOL is entered in Cartesian coordinates and remains in effect until the TNC encounters a NC block in which another **FPOL** is defined.

A programmed or automatically calculated circle center or pole is effective only in connected conventional or FK sections. If an FK section splits up two conventionally programmed sections, the information about a circle center or pole will be lost. The two conventionally programmed sections must each have their own (if necessary, identical) CC blocks. Conversely, this information will also be lost if there is a conventional section between two FK sections.



Soft keys		Known data
		Circle center in Cartesian coordi- nates
CC PR	PA +	Center point in polar coordinates
DR- DR+		Rotational direction of the arc
₹ R		Radius of an arc

Example

i


10 FC CCX+20 CCY+15 DR+ R15
11 FPOL X+20 Y+15
12 FL AN+40
13 FC DR+ R15 CCPR+35 CCPA+40

Closed contours

You can identify the beginning and end of a closed contour with the **CLSD** soft key. This reduces the number of possible solutions for the last contour element.

Enter \mbox{CLSD} as an addition to another contour data entry in the first and last NC blocks of an FK section.

Soft key	Known data		
	Beginning of contour:	CLSD+	
	End of contour:	CLSD-	



Example

12 L X+5 Y+35 RL F500 M3
13 FC DR- R15 CLSD+ CCX+20 CCY+35
•••
•••


Auxiliary points

For both free-programmed straight lines and free-programmed circular arcs, you can enter the coordinates of auxiliary points that are located on the contour or in its proximity.

Auxiliary points on a contour

The auxiliary points are located on the straight line, the extension of the straight line, or on the circular arc.

Soft keys		Known data
	P2X	X coordinate of an auxiliary point P1 or P2 of a straight line
P1Y	P2Y	Y coordinate of an auxiliary point P1 or P2 of a straight line
P1X	P2X	X coordinate of an auxiliary point P1, P2 or P3 of a circular path
P1Y	P2Y	Y coordinate of an auxiliary point P1, P2 or P3 of a circular path



Auxiliary points near a contour

Soft keys		Known data
PDX	PDY	X and Y coordinates of the auxil- iary point near a straight line
		Distance of auxiliary point to straight line
PDX	PDY	X and Y coordinates of an auxil- iary point near a circular arc
		Distance of auxiliary point to circular arc

Example

13 FC	DR- R10	P1X+42.929 P1Y+60.071
44 515		

14 FLT AN-70 PDX+50 PDY+53 D10

Relative data

i

Relative data are values based on another contour element. The soft keys and program words for relative entries begin with the letter \mathbf{R} . The figure on the right shows the dimensional data that should be programmed as relative data.

The coordinates and angles for relative data are always programmed in incremental dimensions. You must also enter the NC block number of the contour element on which the data are based.

The block number of the contour element on which the relative data are based can only be located up to 64 positioning blocks before the NC block in which you program the reference.


If you delete an NC block on which relative data are based, the control will display an error message. Change the NC program first before you delete this NC block.



Soft keys	Known data
RX N	Cartesian coordinates relative to NC block N
RPR N	Polar coordinates relative to NC block N

Example

12 FPOL X+10 Y+10	
13 FL PR+20 PA+20	
14 FL AN+45	
15 FCT IX+20 DR- R20 CCA+90 RX 13	
16 FL IPR+35 PA+0 RPR 13	



Υ

Data relative to NC block N: Direction and distance of the contour element

Soft key	Known data
RAN [N]	Angle between a straight line and another element or between the entry tangent of the arc and another element
PAR N	Straight line parallel to another contour element
DP	Distance from a straight line to a parallel contour element




17 FL LEN 20 AN+15	
18 FL AN+105 LEN 12.5	
19 FL PAR 17 DP 12.5	
20 FSELECT 2	
21 FL LEN 20 IAN+95	
22 FL IAN+220 RAN 18	

Data relative to NC block N: Circle center CC

Soft key	Known data	
RCCX N	RCCY N	Cartesian coordinates of the circle center relative to NC block N
RCCPR N	RCCPA N	Polar coordinates of the circle center relative to NC block N

Example

12 FL X+10 Y+10 RL
13 FL
14 FL X+18 Y+35
15 FL
16 FL
17 FC DR- R10 CCA+0 ICCX+20 ICCY-15 RCCX12 RCCY14



Х


220°

95

10


18

Example: FK programming 1




0 BEGIN PGM FK1 MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-20	Workpiece blank definition
2 BLK FORM 0.2 X+100 Y+100 Z+0	
3 TOOL CALL 1 Z S500	Tool call
4 L Z+250 R0 FMAX	Retract the tool
5 L X-20 Y+30 R0 FMAX	Pre-position the tool
6 L Z-10 R0 F1000 M3	Move to working depth
7 APPR CT X+2 Y+30 CCA90 R+5 RL F250	Approach the contour on a circular arc with tangential connection
8 FC DR- R18 CLSD+ CCX+20 CCY+30	FK contour section:
9 FLT	Program all known data for each contour element
10 FCT DR- R15 CCX+50 CCY+75	
11 FLT	
12 FCT DR- R15 CCX+75 CCY+20	
13 FLT	
14 FCT DR- R18 CLSD- CCX+20 CCY+30	
15 DEP CT CCA90 R+5 F1000	Depart the contour on a circular arc with tangential connection
16 L X-30 Y+0 R0 FMAX	
17 L Z+250 R0 FMAX M2	Retract the tool, end of program
18 END PGM FK1 MM	

Example: FK programming 2



0 BEGIN PGM FK2 MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-20	Workpiece blank definition
2 BLK FORM 0.2 X+100 Y+100 Z+0	
3 TOOL CALL 1 Z S4000	Tool call
4 L Z+250 R0 FMAX	Retract the tool
5 L X+30 Y+30 R0 FMAX	Pre-position the tool
6 L Z+5 RO FMAX M3	Pre-position the tool
7 L Z-5 R0 F100	Move to working depth
8 APPR LCT X+0 Y+30 R5 RR F350	Approach the contour on a circular arc with tangential connection
9 FPOL X+30 Y+30	FK contour section:
10 FC DR- R30 CCX+30 CCY+30	Program all known data for each contour element
11 FL AN+60 PDX+30 PDY+30 D10	
12 FSELECT 3	
13 FC DR- R20 CCPR+55 CCPA+60	
14 FSELECT 2	
15 FL AN-120 PDX+30 PDY+30 D10	
16 FSELECT 3	
17 FC X+0 DR- R30 CCX+30 CCY+30	
18 FSELECT 2	
19 DEP LCT X+30 Y+30 R5	Depart the contour on a circular arc with tangential connection
20 L Z+250 R0 FMAX M2	Retract the tool, end of program
21 END PGM FK2 MM	

Example: FK programming 3



0 BEGIN PGM FK3 MM	
1 BLK FORM 0.1 Z X-45 Y-45 Z-20	Workpiece blank definition
2 BLK FORM 0.2 X+120 Y+70 Z+0	
3 TOOL CALL 1 Z S4500	Tool call
4 L Z+250 R0 FMAX	Retract the tool
5 L X-70 Y+0 R0 FMAX	Pre-position the tool
6 L Z-5 R0 F1000 M3	Move to working depth
7 APPR CT X-40 Y+0 CCA90 R+5 RL F250	Approach the contour on a circular arc with tangential connection
8 FC DR- R40 CCX+0 CCY+0	FK contour section:
9 FLT	Program all known data for each contour element
10 FCT DR- R10 CCX+0 CCY+50	
11 FLT	
12 FCT DR+ R6 CCX+0 CCY+0	
13 FCT DR+ R24	
14 FCT DR+ R6 CCX+12 CCY+0	
15 FSELECT 2	
16 FCT DR- R1.5	
17 FCT DR- R36 CCX+44 CCY-10	
18 FSELECT 2	
19 FCT DR+ R5	
20 FLT X+110 Y+15 AN+0	
21 FL AN-90	
22 FL X+65 AN+180 PAR21 DP30	
23 RND R5	
24 FL X+65 Y-25 AN-90	
25 FC DR+ R50 CCX+65 CCY-75	
26 FCT DR- R65	
27 FSELECT 1	
28 FCT Y+0 DR- R40 CCX+0 CCY+0	
29 FSELECT 4	

30 DEP CT CCA90 R+5 F1000	Depart the contour on a circular arc with tangential connection
31 L X-70 R0 FMAX	
32 L Z+250 R0 FMAX M2	Retract the tool, end of program
33 END PGM FK3 MM	

6

Programming aids

6.1 GOTO function

Using the GOTO key

Jumping with the GOTO key

Use the **GOTO** key to jump to a specific location in the NC program, regardless of the active operating mode.

Proceed as follows:



N LINES

Press the GOTO key

- > The control opens a pop-up window.
- Enter a number
- Select the jump statement by soft key, e.g. move down the number of lines entered

The control provides the following options:

Soft key	Function
N LINES	Move up the number of lines entered
N LINES	Move down the number of lines entered
GOTO LINE NUMBER	Jump to the block number entered

Use the GOTO function only during programming and testing of NC programs. Use the block scan function during program run.
 Further information: User's Manual for Setup, Testing and Running NC Programs

Quick selection with the GOTO key

With the **GOTO** key, you can open the Smart Select window that makes it easy for you to select special functions or cycles.

Proceed as follows to select special functions:

Press the **SPEC FCT** key

GOTO □

- Press the GOTO key
- The control displays a pop-up window showing a structural view of the special functions
- Select the desired function


Further information: User's Manual for Programming of Machining Cycles

Opening the selection window with the GOTO key

When the control provides a selection menu, you can use the **GOTO** key to open the selection window. This allows you to view the available entries.

6.2 Screen keypad

If you are using the compact version of the control (without alphabetic keyboard), you can enter letters and special characters with the screen keypad or with an alphabetic keyboard connected to the USB port.



Entering text with the screen keypad

Proceed as follows to use the screen keypad:

GOTO

8

- Press the GOTO key if you want to enter letters, e.g. a program name or directory name, using the screen keypad.
- The control opens a window in which the numeric keypad of the control is displayed with the corresponding letters assigned.
- Press the numerical key until the cursor is on the desired letter
- Wait until the control transfers the selected character before you enter the next character
- Use the OK soft key to load the text into the open dialog field

Use the **abc/ABC** soft key to select upper or lower case. If your machine tool builder has defined additional special characters, you can call them with the **SPECIAL CHARACTERS** soft key and insert them. Use the **BACKSPACE** soft key to delete individual characters.


6.3 Display of NC programs

Syntax highlighting

The control displays syntax elements with various colors according to their meaning. Color-highlighting makes the NC programs easier to read and clearer.

Color highlighting of syntax elements

Use	Color
Use	Color
Standard color	Black
Display of comments	Green
Display of numerical values	Blue
Display of the block number	Violet
Display of FMAX Orange	
Display of the feed rate	Brown



Scrollbar

Screen content can be shifted with the mouse using the scroll bar at the right edge of the program window. In addition, the size and position of the scrollbar indicates program length and cursor position.

6.4 Adding comments

Application

You can add comments to an NC program to explain program steps or make general notes.

The control shows long comments in different ways, depending on the machine parameter **lineBreak** (no. 105404). It either wraps the comment lines or displays the >> symbol to indicate additional content. The last character in a comment block must not have any tilde(~).

You can add comments in different ways.

Entering comments during programming

- Enter the data for an NC block
- Press the semicolon key; on the alphabetic keyboard
- > The control displays the dialog prompt Comment?
- Enter the comment
- Press the END key to conclude the NC block

Inserting comments after program entry

- Select the NC block to which you want to add the comment
- Select the last word in the NC block with the right arrow key:
- Press the semicolon key; on the alphabetic keyboard
- > The control displays the dialog prompt Comment?
- Enter the comment
- Press the END key to conclude the NC block

Entering a comment in a separate NC block

- Select the NC block after which you want to insert the comment
- Initiate the programming dialog with the semicolon key (;) on the alphabetic keyboard
- Enter your comment and conclude the NC block by pressing the END key

Commenting out an existing NC block

Proceed as follows to change an existing NC block to a comment:


Press the INSERT COMMENT soft key

Select the NC block to be commented out



Alternative:

- Press the < key on the alphabetic keyboard</p>
- > The control inserts a semicolon; at the beginning of the block.
- Press the END key



Changing a comment for an NC block

Proceed as follows to change a commented-out NC block to an active NC block:

Select the comment block you want to change



Press the REMOVE COMMENT soft key

Alternative:

- Press the > key on the alphabetic keyboard
- > The control removes the semicolon; at the beginning of the block.
- Press the END key

Functions for editing a comment

Soft key	Function
BEGIN	Jump to beginning of comment
END	Jump to end of comment
MOVE WORD	Jump to the beginning of a word. Use a space to separate words
WOVE WORD	Jump to the end of a word. Use a space to separate words
INSERT OVERWRITE	Switch between paste and overwrite mode

6.5 Freely editing an NC program

Certain syntax elements, such as LN blocks, cannot be entered directly in the NC editor by using the available keys and soft keys. To prevent the use of an external text editor, the control offers the following possibilities:

- Free syntax input using the control's integrated text editor
- Free syntax input using the ? key in the NC editor

Free syntax input using the control's integrated text editor

To add syntax to an existing NC program, proceed as follows:

- Press the PGM MGT key
 - > The control opens the file manager.

Press the MORE FUNCTIONS soft key



EDITOR

ок

i

PGM MGT

- Press the SELECT EDITOR soft key
- > The control opens a selection window.
- Select the TEXT EDITOR option
- Confirm your selection with OK
- Add the desired syntax

The control does not check the syntax in the text editor. Check your entries in the NC editor when you are finished.

Free syntax input using the ? key in the NC editor



To use this function you will need a alphabetic keyboard connected via USB.

To add syntax to an existing, open NC program, proceed as follows:

仑	

Enter ?



> The control opens a new NC block.



- Add the desired syntax
 - Confirm your entry with END



After confirmation, the control checks the syntax. Errors will result in ERROR blocks.

6.6 Skipping NC blocks

Insert a slash (/)

You can optionally hide NC blocks.

To hide NC blocks in the **Programming** mode, proceed as follows:



Select the desired NC block



Press the INSERT soft key

> The control inserts a slash (/).

Delete the slash (/)

To show NC blocks again in the **Programming** mode, proceed as follows:



Select the hidden NC block



- Press the **REMOVE** soft key
- > The control removes the slash (/).

6.7 Structuring NC programs

Definition and applications

The control enables you to comment NC programs in structuring blocks. Structuring blocks are texts with up to 252 characters and are used as comments or headlines for the subsequent program lines.

With the aid of appropriate structuring blocks, you can organize long and complex NC programs in a clear and comprehensible manner.

This function is particularly convenient if you want to change the NC program later. Structuring blocks can be inserted into the NC program at any point.

Structure blocks can also be displayed in a separate window, and be edited or added to, as desired. Use the appropriate screen layout for this.

The control manages the inserted structure items in a separate file (extension: .SEC.DEP). This speeds navigation in the program structure window.

The **PROGRAM + SECTS** screen layout can be selected in the following operating modes:

- Program run, single block
- Program run, full sequence
- Programming

Displaying the program structure window / Changing the active window



- Display structure window: For this screen layout press the PROGRAM + SECTS soft key
- Change the active window: Press the CHANGE WINDOW soft key

TNC:\nc_prog\BHB\Kla → 1GB, h	rtext\1GB.h	BEGIN PGM 1GB - Machine hole Parameter de	pattern ID 27943	(L 1	
4 TOOL CALL 2 2 3452 CYCL DEF 203 UNITY 2200=72 38F1-1 2201=72 30F17 2208=150 FED 2202=5 PLIMB 2203=0 SUMPL 2203=0 SUMPL 2203=0 SUMPL 2203=0 SUMPL 2213=0 SUMPL 2213=0 SUMPL 2205=0 SUMPL	00 Y+100 Z+0 Rettern J0 E 7743764 00 RRAL DRILING P CLEARANCE 100 DEPL/SCANCE 100 DEPL/SCANCE 100 DEPL/SCANCE 100 DEPL/SCANCE MENT 100 CASE PLUNGING DEPTH ACTION FEED RATE FOR CHIP BINCH MAX 00 10 10 MILLING	- Mill pocket -Rough out -Finishing	battern Ll		
SELECT		COPY	;		INSERT
	BLOCK	BLOCK	INSERT	INSERT	LAST

Inserting a structure block in the program window

Select the NC block after which you want to insert the structuring block

SPEC FCT	Press the SPEC FCT key
PROGRAM- MING AIDS	Press the PROGRAMMING AIDS soft key
INSERT	Press the INSERT SECTION soft key
SECTION	Enter the structuring text
	 Change the structuring depth (indenting) via soft key
0	You can indent structure items only during editing.
A	You can also insert structure blocks with the key

Selecting blocks in the program structure window

combination **Shift + 8**.

If you are scrolling through the program structure window block by block, the control at the same time automatically moves the corresponding NC blocks in the program window. This way you can quickly skip large program sections.

i)


6.8 Calculator

Operation

The control features a calculator with the most important mathematical functions.

- ► To show the calculator, press the CALC key
- Select the arithmetic functions: Select the command via soft key or enter it with an alphanumeric keyboard
- ► To close the calculator, press the CALC key

Calculate function	Command (soft key)	
Addition	+	
Subtraction	-	
Multiplication	*	
Division	/	
Calculating with parentheses	()	
Arc cosine	ARC	
Sine	SIN	
Cosine	COS	
Tangent	TAN	
Exponent	ХЛҮ	
Square root SQRT		
Inverted function	1/x	
PI (3.14159265359)	PI	
Add value to buffer memory	M+	
Save value to buffer memory	MS	
Retrieve buffer memory contents	MR	
Delete buffer memory contents	MC	
Natural logarithm	LN	
Logarithm	LOG	
Exponential function	e^x	
Check the algebraic sign	SGN	
Calculate the absolute value	ABS	
Truncate decimal places	INT	
Truncate digits before the decimal point	FRAC	
Modulo	MOD	
Select view	View	
Delete value	CE	



Calculate function	Command (soft key)
Unit of measure	MM or INCH
Show angular value in radians (default: angular value in degrees)	RAD
Select numerical value notation	DEC (decimal) or HEX (hexadecimal)

Transferring the calculated value into the NC program

- With the arrow keys, select the word into which the calculated value is to be transferred
- Show the calculator by pressing the CALC key, and perform the desired calculation
- Press the CONFIRM VALUE soft key
- > The control transfers the value into the active input field and closes the calculator.
- You can also transfer values from an NC program into the calculator. When you press the **GET CURRENT VALUE** soft key or the **GOTO** key, the control transfers the value from the active input field to the calculator. The calculator remains in effect even after a change in operating modes. Press the **END** soft key to close the calculator.

Functions in the pocket calculator

Soft key	Function
AX. VALUES	Transfer the nominal or reference value of the respective axis position into the calculator
GET CURRENT VALUE	Transfer the numerical value from the active input field into the calculator
CONFIRM VALUE	Transfer the numerical value from the calculator into the active input field
COPY FIELD	Copy the numerical value from the calculator
PASTE FIELD	Insert the copied numerical value into the calcula- tor
CUTTING DATA CALCULATOR	Open the cutting data calculator
Voi	I can also move the calculator with the arrow keys

You can also move the calculator with the arrow keys of your alphabetic keyboard. If you have connected a mouse you can also position the calculator with this.

i)

6.9 Cutting data calculator

Application

With the cutting data calculator you can calculate the spindle speed and the feed rate for a machining process. Then you can load the calculated values into an opened feed rate or spindle speed dialog box in the NC program.

To open the cutting data calculator, press the **CUTTING DATA CALCULATOR** soft key.

The control shows the soft key if you

- press the CALC key
- Define spindle speeds
- Define feed rates
- Press the F soft key in Manual Operation mode
- Press the S soft key in Manual Operation mode

Display modes of the cutting data calculator

The cutting data calculator is displayed with different input fields depending on whether you calculate a spindle speed or a feed rate:

Window for spindle speed calculation:

Abbrev.	Meaning
T:	Tool number
D:	Diameter of the tool
VC:	Cutting speed
S=	Result for spindle speed

If you open the speed calculator in a dialog where the tool is already defined, the speed calculator automatically applies the tool number and diameter. You only need to enter **VC** in the dialog field.

Window for feed rate calculation:

i

Abbrev.	Meaning
T:	Tool number
D:	Diameter of the tool
VC:	Cutting speed
S:	Spindle speed
Z:	Number of teeth
FZ:	Feed per tooth
FU:	Feed per revolution
F=	Result for feed rate

You can transfer the feed rate from the **TOOL CALL** block into subsequent NC blocks by pressing the **F AUTO** soft key. If you have to change the feed rate later, you only need to adjust the feed rate value in the **TOOL CALL** block.



Functions of the cutting data calculator

You have the following possibilities depending on where you open the cutting data calculator:

Soft key	Function
APPLY	Transfer the value from the cutting data calculator into the NC program
CALCULATE FEEDRATE F SPEED S	Toggle between feed-rate calculation and spindle- speed calculation
ENTER FEED RATE FZ FU	Toggle between feed per tooth and feed per revolution
ENTER SPEED RPM VC S	Toggle between spindle speed and cutting speed
CUTTING DATA TABLE OFF ON	Activate or deactivate working with cutting data tables
SELECT	Select a tool from the tool table
ţ	Move the cutting data calculator in the direction of the arrow
POCKET CALCULATOR	Switch to the calculator
INCH	Use inch values in the cutting data calculator
END	Close the cutting data calculator

Working with cutting data tables

Application

If you store tables for materials, cutting materials, and cutting data on the control, then the cutting data calculator can use the values in these tables.

Proceed as follows before working with automatic calculation of the spindle speed and feed rate:

- Enter the type of workpiece material in the table WMAT.tab
- Enter the type of cutting material in the file TMAT.tab
- Enter the combination of workpiece material and cutting material in a cutting data table
- Define the tool with the necessary values in the tool table
 - Tool radius
 - Number of teeth
 - Cutting material
 - Cutting data table

Workpiece material WMAT

Define the workpiece materials in the WMAT.tab table. You must save this table in the directory **TNC:\table**.

This table contains the column **WMAT** for the material and a column called **MAT_CLASS**; here you categorize the materials into material classes with the same cutting conditions, e.g. according to DIN EN 10027-2.

Enter the workpiece material as follows in the cutting data calculator:

- Select the cutting data calculator
- Select Activate cutting data from table in the pop-up window
- Select WMAT from the drop-down menu

Cutting material TMAT

Cutting materials are defined in the TMAT.tab table. You must save this table in the directory **TNC:\table**.

You assign the cutting material in the **TMAT** column of the tool table. You can create columns with other names, such as **ALIAS1** and **ALIAS2** in order to enter alternative names for the same cutting material.

Cutting data table

Define the combinations of workpiece material and cutting material with the corresponding cutting data in a table with the file extension .CUT. You must save this table in the directory **TNC: \system\Cutting-Data**.

You assign the appropriate cutting data table in the **CUTDATA** column of the tool table.



Use this simplified table if you use tools that have only a single diameter, or if the diameter is not relevant to the feed rate, i.e. for indexable inserts.

The cutting data table contains the following columns:

- MAT_CLASS: Material class
- MODE: Machining mode, such as finishing
- TMAT: Cutting material
- VC: Cutting speed
- FTYPE: Type of feed rate FZ or FU
- F: Feed rate

NR 🔺	WMAT	MAT_CLASS
1		1(
2	1.0038	1
3	1.0044	1
4	1.0114	1
5	1.0177	10
6	1.0143	10
7	St 37-2	10
8	St 37-3 N	10
9	X 14 CrMo S 17	20
10	1.1404	2
11	1.4305	20
12	V2A	2
13	1.4301	2
14	AlCu4PBMg	10
15	Aluminium	100
16	PTFE	200

NR A	NAT_CLASS	NODE	TMAT	VC	FTYPE
0	10	Rough	HSS	28	
1	10	Rough	VHM	70	
2	10	Finish	HSS	30	
3	10	Finish	VHM	70	
4	10	Rough	HSS coated	78	
5	10	Finish	HSS coated	82	
6	20	Rough	VHM	90	
7	20	Finish	VHM	82	
8	100	Rough	HSS	150	
9	100	Finish	HSS	145	
10	100	Rough	VHM	450	
11	100	Finish	VHM	440	
12					
13					
14					

Diameter-dependent cutting data table

In many cases the diameter of the tool determines which cutting data you can use. Use the cutting data table with the file extension .CUTD for this purpose. You must save this table in the directory **TNC:\system\Cutting-Data**.

You assign the appropriate cutting data table in the $\ensuremath{\text{CUTDATA}}$ column of the tool table.

The diameter-dependent cutting data table contains the following additional columns:

- F_D_0: Feed rate for Ø 0 mm
- **F_D_0_1**: Feed rate for Ø 0.1 mm
- **F_D_0_12**: Feed rate for Ø 0.12 mm

· · · ·



You don't need to fill in all columns. If a tool diameter is between two defined columns, the control linearly interpolates the feed rate.

NR +	F_D_0	F_D_0_1	F_D_0_12	F_D_0_15	F_D_0_2	F_D_0_25	F_D_0_3	F_D_0_4	F_D_0_5	F_D_
1						0.0010			0.0010	
2									0.0020	
3						0.0010			0.0010	
4						0.0010			0.0010	
5									0.0020	
6						0.0010			0.0010	
7						0.0010			0.0010	
8									0.0020	
9						0.0010			0.0010	
10						0.0010			0.0030	
11						0.0010			0.0030	
12						0.0010			0.0030	
13						0.0010			0.0030	
14						0.0010			0.0030	
15						0.0010			0.0030	
16						0.0010			0.0010	
17									0.0020	
18						0.0010			0.0010	
19						0.0010			0.0010	
20									0.0020	
21						0.0010			0.0010	
22						0.0010			0.0010	
23									0.0020	
24						0.0010			0.0010	
25						0.0010			0.0030	
26						0.0010			0.0030	
27						0.0010			0.0030	
		0 - 0,5 mm	11			aa/1		0000, max		

6.10 Programming graphics

Activating and deactivating programming graphics

While you are writing an NC program, you can have the control generate a 2-D pencil-trace graphic of the programmed contour.

- Press the Screen layout key
- Press the PROGRAM + GRAPHICS soft key
- > The control shows the NC program to the left and graphics to the right.



- Set the AUTO DRAW soft key to ON
- > While you are entering the program lines, the control generates each programmed movement in the graphics window in the right screen half.

If you do not want the control to generate graphics during programming, then set the **AUTO DRAW** soft key to **OFF**.

- If AUTO DRAW is set to ON, then the control ignores the following program content when creating 2-D pencil-trace graphics:
 Program section repetitions
 - Jump commands
 - M functions, such as M2 or M30
 - Cycle calls
 - Warnings due to locked tools


Therefore, only use automatic drawing during contour programming.

The control resets the tool data when you reopen an NC program or press the \mbox{RESET} + \mbox{START} soft key.

The control uses various colors in the programming graphics:

- **blue:** completely defined contour element
- violet: not yet completely defined contour element, can still be modified by e.g. an RND
- light blue: holes and threads
- ocher: tool midpoint path
- red: rapid traverse

Further information: "FK programming graphics", Page 175



Generating a graphic for an existing NC program

- Use the arrow keys to select the NC block up to which you want the graphic to be generated, or press GOTO and enter the desired block number
- RESET + START
- Reset previously active tool data, and generate graphic: Press the RESET + START soft key

Additional functions:

Soft key	Function
RESET + START	Reset previously active tool data. Generate programming graphics
START SINGLE	Generate programming graphic blockwise
START	Generate a complete programming graphic, or complete it after RESET + START
STOP	Stop the programming graphics. This soft key only appears while the control is generating the programming graphics
VIEWS	Selecting views Plan view Front view Page view
SHOW TOOL PATHS OFF ON	Display or hide tool paths
SHOW FMAX PATHS OFF ON	Display or hide tool paths in rapid traverse

Block number display ON/OFF



► Shift the soft-key row



- Show block numbers: Set the SHOW BLOCK NO. soft key to ON
- Hide block numbers: Set the SHOW BLOCK NO. soft key to OFF

Erasing the graphic



GRAPHICS

- Shift the soft-key row
 - Erase the graphic: Press the CLEAR GRAPHICS soft key

Showing grid lines





- ► Shift the soft-key row
- Show grid lines: Press the Show grid lines soft key

Magnification or reduction of details

- You can select the graphics display
- Shift the soft-key row

The following functions are available:





The **RESET BLK FORM** soft key allows you to restore the original section.

You can also use the mouse to change the graphic display. The following functions are available:

- To shift the displayed model, hold down the center mouse button or the mouse wheel, and move the mouse. If you press the shift key at the same time, then you will be able to shift the model only horizontally or vertically.
- To zoom in on a certain area, mark a zoom area by holding the left mouse button down. After you release the left mouse button, the control zooms in on the defined area.
- To rapidly magnify or reduce any area, rotate the mouse wheel backwards or forwards.

6.11 Error messages

Display of errors

The control displays error messages in the following cases, for example:

- Incorrect data input
- Logical errors in the NC program
- Contour elements that are impossible to machine
- Incorrect use of touch probes
- Hardware updates

When an error occurs, the control displays it in the header.

The control uses different icons and text colors for different error classes.

lcon	Text color	Error class	
8	Red	Errors	
	Red	Errors	
18		Question type	
	Yellow	Warning	
	Green	Notes	
0	Blue	Information	

The control displays an error message in the header until it is cleared or replaced by a higher-priority error (higher error class). Information that appears only briefly is always displayed.

The control displays long and multi-line error messages in abbreviated form. The complete information on all pending errors is shown in the error window.

An error message that contains an NC block number was caused by an error in the indicated NC block or in the preceding NC block.

Opening the error window

When you open the error window, the complete information on all pending errors will be shown.

ERR

- Press the ERR key
- The control opens the error window and displays all accumulated error messages.

Detailed error messages

The control displays possible causes of the error and suggestions for solving the problem:

Open the error window


MORE INFO

MORE INFO

Position the cursor on the corresponding error message



- > The control opens a window with information on the error cause and corrective action.
- Exit the info: Press the MORE INFO soft key again



When an error message occurs at switch-on of the control due to hardware changes or updates, the control will automatically open the error window. The control displays an error of the question type.

You can correct this error only by pressing the corresponding soft key to acknowledge the question. If necessary, the control continues the dialog until the cause or correction of the error has been clearly determined.

Further information: User's Manual for Setup, Testing and Running NC Programs

If a rare **processor check error** should occur, the control will automatically open the error window. You cannot correct such an error.

Proceed as follows:

- Shut down the control
- Restart

INTERNAL INFO soft key

The **INTERNAL INFO** soft key supplies information on the error message. This information is only required if servicing is needed.

- Open the error window
- Position the cursor on the corresponding error message
- INTERNAL INFO
- Press the INTERNAL INFO soft key
- The control opens a window with internal information about the error.



 Exit the detailed information: Press the INTERNAL INFO soft key again



Щ <mark>,</mark> на	ardware/fireware change re. Programming Programming	
Number	Type Text	
126-0015	5 N Hardware/firmware change recognized	
	272 C	
Hardware	e/firmware change recognized	
Somethin	ng in the hardware setup or the firmware versions nged since the last start-up.	
nus chu	ngen since ine iner start op.	

FILTER soft key

The **FILTER** soft key allows you to group identical warnings and error messages in the error window. The grouping makes the list of messages shorter and easier to read.

Press the MORE FUNCTIONS soft key



Open the error window



OFF ON

- .
- Press the FILTER soft key
- The control groups identical warnings and error messages.
- The number of occurrences of the individual messages is indicated in parentheses in the respective line.



Exit the filter: Press the GO BACK soft key

ACTIVATE AUTOMATIC SAVING soft key

Using the **ACTIVATE AUTOMATIC SAVING** soft key, you can specify error numbers that cause the control to save a service file if an error with that number occurs.




Open the error window



ACTIVATE AUTOMATIC SAVING

- Press the MORE FUNCTIONS soft key
- Press the ACTIVATE AUTOMATIC SAVING soft key
- The control opens the ACTIVATE AUTOMATIC SAVING pop-up window.
- Define the entries
 - Error number: Enter the desired error number
 - active: Enable this option to automatically create the service file
 - Comment: Enter a comment on this error number, if required



 If an error with the specified error number occurs, a service file will be saved automatically.



STORE

Press the GO BACK soft key

Deleting errors

Clearing errors automatically

The control can automatically clear pending warning or error messages when an NC program is selected or restarted. The machine tool builder specifies in the optional machine parameter **CfgClearError** (no. 130200) whether these messages will automatically be cleared.

The factory default setting of the control defines that warning and error messages in the **Test Run** and **Programming** operating modes will be cleared automatically from the error window. Messages issued in the machine operating modes will not be cleared.

Clearing errors outside of the error window

CE

 $(\mathbf{\hat{o}})$

Press the CE key

The control clears the errors or notes being displayed in the header.



In certain situations you cannot use the $\mbox{\bf CE}$ key for clearing the errors because the key is used for other functions.

Clearing errors

- Open the error window
- Position the cursor on the corresponding error message
 Press the **DELETE** soft key

DELETE

. .



 As an alternative, clear all errors: Press the DELETE ALL soft key



If the cause of the error has not been corrected, the error message cannot be cleared. In this case, the error message remains in the window.

Error log

The control stores errors occurred and important events (e.g., system start) in an error log. The capacity of the error log is limited. When the log is full, the control uses a second file. When this is also full, the first error log is deleted and newly written etc. If required, switch from **CURRENT FILE** to **PREVIOUS FILE** to view the history.

Open the error window



- Press the LOG FILES soft key
- Open the error log file: Press the ERROR LOG soft key
- Set the previous error log if required: Press the PREVIOUS FILE soft key
- Set the current error log if required: Press the CURRENT FILE soft key

The oldest entry is at the beginning of the log file, and the most recent entry is at the end.

Keystroke log

The control stores each key pressed and important events (e.g., system start) in a keystroke log. The capacity of the keystroke log is limited. When the keystroke log is full, the control switches to a second keystroke log. When this is also full, the first keystroke log is deleted and newly written, etc. If required, switch from **CURRENT FILE** to **PREVIOUS FILE** to view the history of the inputs.

LOG FILES	 Press the LOG FILES soft key
KEYSTROKE	 Open the keystroke log file: Press the
LOG	KEYSTROKE LOG soft key
PREVIOUS	 Set the previous keystroke log if required: Press
FILE	the PREVIOUS FILE soft key
CURRENT	 Set the current keystroke log if required: Press the CURRENT FILE soft key

The control saves each key pressed during operation in a keystroke log. The oldest entry is at the beginning, and the most recent entry is at the end of the file.

Overview of	the keys and	soft keys for	viewing the log

Soft key/ Keys	Function
BEGIN	Go to beginning of keystroke log
	Go to end of keystroke log
FIND	Find text
CURRENT	Current keystroke log
PREVIOUS FILE	Previous keystroke log
t	Up/down one line
Ŧ	
	Return to main menu

Informational texts

If an operating error occurred, e.g. pressing an impermissible key or entering a value outside of a validity range, the control displays an information text in the header to inform you of the operating error. The control deletes this information text with the next valid entry.

Saving service files

If necessary, you can save the current status of the control and make it available to a service technician for evaluation. A group of service files is saved (error and keystroke logs as well as other files that contain information about the current status of the machine and the machining).



In order to facilitate sending service files via email, the control will only save active NC programs with a size of up to 10 MB in the service file. If the NC program is bigger, it will not be added to the created service file.

If you repeat the **SAVE SERVICE FILES** function with the same file name, the previously saved group of service files will be overwritten. Therefore, use a different file name when re-executing the function.

Saving service files



Open the error window



Press the LOG FILES soft key

- Press the SAVE SERVICE FILES soft key
- The control opens a pop-up window in which you can enter a file name or a complete path for the service file.
- Press the OK soft key
- > The control saves the service file.

Closing the error window

To close the error window again, proceed as follows:

END

Press the END soft key



- ► Alternative: Press the **ERR** key
- > The control closes the error window.

6.12 TNCguide context-sensitive help system

Application

0

Before you can use the TNCguide, you need to download the help files from the HEIDENHAIN home page

Further information: "Downloading current help files", Page 219

The **TNCguide** context-sensitive help system contains the user documentation in HTML format. The TNCguide is called with the **HELP** key, and the control often immediately displays the information specific to the condition from which the help was called (context-sensitive call). Even if you are editing an NC block and press the **HELP** key, you are usually brought to the exact place in the documentation that describes the corresponding function.



The control tries to start the TNCguide in the language that you have selected as the conversational language. If the required language version is not available, the control automatically opens the English version.

The following user documentation is available in TNCguide:

- User's Manual for Klartext Programming (BHBKlartext.chm)
- User's Manual for ISO programming (BHBIso.chm)
- User's Manual for Setup, Testing and Running NC Programs (BHBoperate.chm)
- User's Manual for Programming of Machining Cycles (BHBcycle.chm)
- User's Manual for Programming of Measuring Cycles for Workpieces and Tools (BHBtchprobe.chm)
- User's Manual for the TNCdiag application, if necessary (TNCdiag.chm)
- List of All Error Messages (errors.chm)

In addition, the **main.chm** "book" file is available, in which all existing .chm files are shown in one place.



As an option, your machine tool builder can embed machine-specific documentation in **TNCguide**. These documents then appear as a separate book in the **main.chm** file.

Contents Index Find	Switch-on
Controls of the TNC Fundamentals Contents	Switch-on and crossing over the reference points can vary depending on the machine tool. Refer to your machine manual.
First Steps with the TNC 320 Introduction	Switch on the power supply for TNC and machine. The TNC then displays the following dialog: SYSTEM STARTUP
Programming: Fundamenta	TNC is started
Programming: Programmin	POWER INTERRUPTED
Programming: Tools	CE TNC message that the power was interrupted-clear the message
Programming: Programmin	COMPLEE A PLC PROGRAM
Programming: Data transfe	The PLC program of the TNC is automatically compiled
Programming: Subprogram	The PLC program of the Tric is automatically compiled RELAY EXT, DC VOLTAGE MISSING
Programming: Q Parameters	
Programming: Miscellaneo	 Switch on external dc voltage. The TNC checks the functioning of the EMERGENCY STOP circuit
Programming: Special func	MANUAL OPERATION
Programming: Multiple Axis	TRAVERSE REFERENCE POINTS
Manual operation and setup Switch-on, switch-off	Costs the reference points manually in the displayed sequence: For each axis press the machine START button, or
Switch-on	Cross the reference points in any sequence. Press and hold the machine axis direction
Switch-off	button for each axis until the reference point has been traversed
Moving the machine axes	(Y)
BACK FORWARD	PAGE PAGE DIRECTORY WINDOW SWITCH

Working with TNCguide

Calling TNCguide

You have several options for starting the TNCguide:

- Use the HELP key
- First click the help symbol in the lower right-hand corner of the screen, then click the appropriate soft key
- Open a help file (.chm file) via the file management. The control can open any .chm file, even if it is not saved in the control's internal memory



On the Windows programming station, the TNCguide is opened in the internally defined standard browser.


For many soft keys there is a context-sensitive call through which you can go directly to the description of the soft key's function. This functionality requires using a mouse.

Proceed as follows:

- Select the soft-key row containing the desired soft key
- Click with the mouse on the help symbol that the control displays just above the soft-key row
- > The mouse pointer turns into a question mark.
- Move the question mark to the soft key for which you want an explanation
- The control opens the TNCguide. If there is no entry point for the selected soft key, then the control opens the book file **main.chm**. You can search for the desired explanation using full text search or by using the navigation.

Even if you are editing an NC block, context-sensitive help is available:

- Select any NC block
- Select the desired word
- Press the HELP key.
- The control opens the Help system and shows the description of the active function. This does not apply for miscellaneous functions or cycles from your machine tool builder.



Navigating in the TNCguide

It's easiest to use the mouse to navigate in TNCguide. A table of contents appears on the left side of the screen. By clicking the rightward pointing triangle you open subordinate sections, and by clicking the respective entry you open the individual pages. It is operated in the same manner as the Windows Explorer.

Linked text positions (cross references) are shown underlined and in blue. Clicking the link opens the associated page.

Of course you can also operate TNCguide through keys and soft keys. The following table contains an overview of the corresponding key functions.

Soft key	Function	
t	If the table of contents at left is active: Select the entry above it or below it	
ŧ	If the text window at right is active: Move the page downward or upward if texts or graphics are not shown completely	
→	If the table of contents at left is active: Open up the table of contents	
	If the text window at right is active: No function	
+	If the table of contents at left is active: Close the table of contents	
	If the text window at right is active: No function	
ENT	 If the table of contents at left is active: Use the cursor key to show the selected page If the text window at right is active: If the cursor is on a link, jump to the linked page 	
	 If the table of contents at left is active: Switch the tab between the display of the table of contents, display of the subject index, and the full-text search function and switching to the screen half at right If the text window at right is active: Jump 	
	back to the window at left	
Ēt	If the table of contents at left is active: Select the entry above it or below it	
Ē	If the text window at right is active: Jump to next link	
BACK	Select the page last shown	
FORWARD	Page forward if you have used the Select page last shown function	
PAGE	Move up by one page	
	Move down by one page	

Soft key	Function
DIRECTORY	Display or hide table of contents
WINDOW	Switch between full-screen display and reduced display. With the reduced display you can see some of the rest of the control window
SWITCH	The focus is switched internally to the control application so that you can operate the control when the TNCguide is open. If the full screen is active, the control reduces the window size automatically before the change of focus
END	Exit TNCguide

Subject index

The most important subjects in the Manual are listed in the subject index (**Index** tab). You can select them directly by mouse or with the arrow keys.

The left side is active.



- Select the Index tab
- Use the arrow keys or the mouse to select the desired keyword

Alternative:

- Enter the first few characters
- The control synchronizes the subject index and creates a list in which you can find the subject more easily.
- Use the ENT key to call the information on the selected keyword

Full-text search


On the **Find** tab, you can search all of TNCguide for a specific word.

The left side is active.

- Select the Find tab
- Activate the Find: entry field
- Enter the search word
- Press the ENT key
- > The control lists all sources containing the word.
- Use the arrow keys to navigate to the desired source
- Press the ENT key to go to the selected source

The full-text search only works for single words.

If you activate the **Search only in titles** function, the control searches only through headings and ignores the body text. To activate the function, use the mouse or select it and then press the space bar to confirm.



F)

Downloading current help files

You'll find the help files for your control software on the HEIDENHAIN homepage:

http://content.heidenhain.de/doku/tnc_guide/html/en/ index.html

Navigate to the suitable help file as follows:

- TNC Controls
- ▶ Series, e.g. TNC 600
- Desired NC software number, e.g.TNC 620 (81760x-07)
- Select the desired language version from the TNCguide online help table
- Download the ZIP file
- Extract the ZIP file
- Move the extracted CHM files to the TNC:\tncguide\en directory or the respective language subdirectory on the control



When using **TNCremo** to transfer the CHM files to the control, select the binary mode for files with the **.chm** extension.

Language	TNC directory
German	TNC:\tncguide\de
English	TNC:\tncguide\en
Czech	TNC:\tncguide\cs
French	TNC:\tncguide\fr
Italian	TNC:\tncguide\it
Spanish	TNC:\tncguide\es
Portuguese	TNC:\tncguide\pt
Swedish	TNC:\tncguide\sv
Danish	TNC:\tncguide\da
Finnish	TNC:\tncguide\fi
Dutch	TNC:\tncguide\nl
Polish	TNC:\tncguide\pl
Hungarian	TNC:\tncguide\hu
Russian	TNC:\tncguide\ru
Chinese (simplified)	TNC:\tncguide\zh
Chinese (traditional)	TNC:\tncguide\zh-tw
Slovenian	TNC:\tncguide\sl
Norwegian	TNC:\tncguide\no
Slovak	TNC:\tncguide\sk
Korean	TNC:\tncguide\kr
Turkish	TNC:\tncguide\tr
Romanian	TNC:\tncguide\ro



7.1 Entering miscellaneous functions M and STOP

Fundamentals

With the control's miscellaneous functions—also called M functions—you can affect:

- the program run, e.g. a program interruption
- the machine functions, such as switching spindle rotation and coolant supply on and off
- The path behavior of the tool

You can enter up to four M (miscellaneous) functions at the end of a positioning block or in a separate NC block. The control displays the following dialog question: **Miscellaneous function M**?

You usually enter only the number of the miscellaneous function in the programming dialog. With some miscellaneous functions, the dialog is extended so that you can enter the required parameters for this function.

In the **Manual operation** and **Electronic handwheel** operating modes, the M functions are entered with the ${\bf M}$ soft key.

Effectiveness of miscellaneous functions

Please note that some M functions become effective at the start of a positioning block, and others at the end, regardless of their position in the NC block.

Miscellaneous functions come into effect in the NC block in which they are called.

Some miscellaneous functions are effective only in the NC block in which they are programmed. Unless the miscellaneous function is only effective blockwise, you must either cancel it in a subsequent NC block with a separate M function, or it is automatically canceled by the control at the end of the program.



If multiple functions were programmed in a single NC block, the execution sequence is as follows:

- M functions taking effect at the start of the block are executed before those taking effect at the end of the block
- If all M functions are effective at the start or end of the block, execution takes place in the sequence as programmed

Entering a miscellaneous function in a STOP block

If you program a **STOP** block, the program run or test run is interrupted at the block, e.g. for a tool inspection. You can also enter an M (miscellaneous) function in a **STOP** block:

- To program an interruption of program run, press the STOP key
- ► Enter a miscellaneous function **M** if required

Example 87 STOP

7.2 Miscellaneous functions for program run inspection, spindle and coolant

Overview

 \bigcirc

Refer to your machine manual! The machine manufacturer can influence the behavior of the miscellaneous functions described below.


Μ	Effect	Effective at block	Start	End
MO	Program STC Spindle STO			•
M1	Coolant OFF	gram STOP P if necessary if necessary (function ne machine tool builder)		•
M2	STOP progra Spindle STO Coolant off Return jump Clear status Functional so parameter resetAt (no.	P to block 1 display cope depends on machine		•
M3	Spindle ON o	clockwise	-	
M4	Spindle ON o	counterclockwise	-	
M5	Spindle STO	Р		-
M6	Tool change Spindle STO Program STC			-
0	tool builder,	unction varies depending o , HEIDENHAIN recomment :ALL function for tool chang	ds that yo	
M8	Coolant ON		=	
M9	Coolant OFF			-
M13	Spindle ON o Coolant ON	clockwise		
M14	Spindle ON o Coolant ON	counterclockwise		
M30	Same as M2			-

7.3 Miscellaneous functions for coordinate entries

Programming machine-referenced coordinates: M91/ M92

Scale datum

On the scale, a reference mark indicates the position of the scale datum.



Machine datum

The machine datum is required for the following tasks:

- Define the axis traverse limits (software limit switches)
- Approach machine-referenced positions (such as tool change positions)
- Set a workpiece preset

The distance in each axis from the scale datum to the machine datum is defined by the machine tool builder in a machine parameter.

Standard behavior

The control references the coordinates to the workpiece datum.

Further information: User's Manual for Setup, Testing and Running NC Programs

Behavior with M91-Machine datum

If you want the coordinates in a positioning block to be referenced to the machine datum, enter M91 into these NC blocks.



If you program incremental coordinates in an M91 block, enter them with respect to the last programmed M91 position. If no M91 position is programmed in the active NC block, then enter the coordinates with respect to the current tool position.

The coordinate values on the control's screen are referenced to the machine datum. Switch the display of coordinates in the status display to REF.

Further information: User's Manual for Setup, Testing and Running NC Programs

Behavior with M92 – Additional machine reference point

 \bigcirc

Refer to your machine manual!

In addition to the machine datum, the machine tool builder can also define an additional machine-based position as a machine reference point (machine preset).

For each axis, the machine tool builder defines the distance between the machine preset and the machine datum.

If you want the coordinates in positioning blocks to be based on the machine preset, enter M92 into these NC blocks.



Radius compensation remains the same in blocks that are programmed with **M91** or **M92**. The tool length will **not** be taken into account.

Effect

M91 and M92 are effective only in the blocks in which M91 and M92 have been programmed.


M91 and M92 take effect at the start of block.

Workpiece preset

If you want the coordinates to always be referenced to the machine datum, you can inhibit presetting for one or more axes.

If preset setting is disabled for all axes, the control no longer displays the **SET PRESET** soft key in **Manual operation** mode.

The figure shows coordinate systems with the machine and workpiece datum.



M91/M92 in the Test Run mode

In order to be able to graphically simulate M91/M92 movements, you need to activate working space monitoring and display the workpiece blank referenced to the defined preset.

Further information: User's Manual for Setup, Testing and Running NC Programs

Moving to positions in a non-tilted input coordinate system with a tilted working plane: M130

Standard behavior with a tilted working plane

The control references the coordinates in the positioning blocks to the tilted working plane coordinate system.

Further information: "Working plane coordinate system WPL-CS", Page 80

Behavior with M130

Despite an active tilted working plane, the control references the coordinates in straight line blocks to the non-tilted input coordinate system.

M130 ignores only the **Tilt the working plane** function, but takes into account active transformations before and after tilting. This means that, when calculating the position, the control considers the axis angles of the rotary axes that are not in their zero position.

Further information: "Input coordinate system I-CS", Page 81

NOTICE

Danger of collision!

The function **M130** is only effective blockwise. The control executes the subsequent machining operations in the tilted working plane coordinate system again. Danger of collision during machining!

• Check the sequence and positions using a graphic simulation

Programming notes

- The function M130 is allowed only if the Tilt the working plane function is active.
- If the function M130 is combined with a cycle call, the control will interrupt machining with an error message.

Effect


M130 functions blockwise in straight-line blocks without tool radius compensation.

7.4 Miscellaneous functions for path behavior

Machining small contour steps: M97

Standard behavior

The control inserts a transition arc at outside corners. For very small contour steps, the tool would damage the contour. In such cases, the control interrupts the program run and generates the **Tool radius too large** error message.



Behavior with M97

The control determines a path intersection for the contour elements—such as inner corners—and moves the tool above this point.

Program M97 in the same NC block as the outside corner.

HEIDENHAIN recommends using the much more powerful **M120 LA** function instead of **M97**. **Further information**: "Pre-calculating radius-compensated contours (LOOK AHEAD): M120 (option 21)", Page 232

Effect

i


M97 is effective only in the NC block in which M97 is programmed.



The control does not completely finish the corner when it is machined with **M97**. You may wish to rework the contour with a smaller tool.

Example

5 TOOL DEF L R+20	Large tool radius
13 L X Y R F M97	Move to contour point 13
14 L IY-0.5 R F	Machine small contour steps 13 to 14
15 L IX+100	Move to contour point 15
16 L IY+0.5 R F M97	Machine small contour steps 15 to 16
17 L X Y	Move to contour point 17





Machining open contour corners: M98

Standard behavior

The control calculates the intersections of the cutter paths at inside corners and moves the tool in the new direction at those points.

If the contour is open at the corners, however, this will result in incomplete machining.





Behavior with M98

With the **M98** miscellaneous function, the control temporarily suspends radius compensation to ensure that both corners are completely machined:

Effect

M98 is effective only in the NC blocks in which **M98** is programmed.

M98 becomes effective at the end of the block.

Example: Move to the contour points 10, 11 and 12 in succession

10 L X Y RL F
11 L X IY M98
12 L IX+

Feed rate factor for plunging movements: M103

Standard behavior

The control moves the tool at the last programmed feed rate, regardless of the direction of traverse.

Behavior with M103

The control reduces the feed rate when the tool moves in the negative direction of the tool axis. The feed rate for plunging FZMAX is calculated from the last programmed feed rate FPROG and a factor F%:

FZMAX = FPROG x F%

Programming M103

If you program **M103** in a positioning block, the control continues the dialog by prompting you for the F factor.

Effect

F)

M103 becomes effective at the start of the block. Cancel **M103**: Program **M103** once again without a factor.

The **M103** is also effective with an active tilted working plane coordinate system. The feed rate reduction is then effective in the negative direction when moving the **tilted** tool axis.

Example

The feed rate for plunging is to be 20% of the feed rate in the plane.

	Actual contouring feed rate (mm/min):
17 L X+20 Y+20 RL F500 M103 F20	500
18 L Y+50	500
19 L IZ-2.5	100
20 L IY+5 IZ-5	141
21 L IX+50	500
22 L Z+5	500

Feed rate in millimeters per spindle revolution: M136

Standard behavior

The control moves the tool at the feed rate F in mm/min programmed in the NC program

Behavior with M136

i

In NC programs based on inch units, **M136** is not allowed in combination with the alternative **FU** feed rate. The spindle is not permitted to be controlled when **M136** is active.

It is not possible to combine **M136** with an oriented spindle stop. The control cannot calculate the feed rate because the spindle does not rotate during an oriented spindle stop.

With **M136**, the control does not move the tool in mm/min, but rather at the feed rate F in millimeters per spindle revolution programmed in the NC program. If you change the spindle speed by using the potentiometer, the control changes the feed rate accordingly.

Effect

M136 becomes effective at the start of the block. You can cancel **M136** by programming **M137**.

Feed rate for circular arcs: M109/M110/M111

Standard behavior

The control applies the programmed feed rate to the path of the tool center.

Behavior for circular arcs with M109

For inside and outside machining of circular arcs, the control keeps the feed rate at the cutting edge constant.

NOTICE

Caution: Danger to the tool and workpiece!

If the **M109** function is active, the control might significantly increase the feed rate when machining very small outside corners (acute angles). There is a risk of tool breakage or workpiece damage during machining.

 Do not use M109 for machining very small outside corners (acute angles)

230

Behavior for circular arcs with M110

With circular arcs, the control only keeps the feed rate constant for inside machining operations. The feed rate will not be adjusted for outside machining of circular arcs.



If you program **M109** or **M110** with a number > 200 before calling a machining cycle, the adjusted feed rate will also be effective for circular arcs within these machining cycles. The initial state is restored after finishing or canceling a machining cycle.

Effect

M109 and M110 become effective at the start of the block. M109 and M110 can be canceled with M111.

Pre-calculating radius-compensated contours (LOOK AHEAD): M120 (option 21)

Standard behavior

If the tool radius is larger than the contour step that needs to be machined with radius compensation, then the control interrupts program run and issues an error message. **M97** inhibits the error message, but this results in dwell marks and will also move the corner.

Further information: "Machining small contour steps: M97", Page 227

The control might damage the contour in case of undercuts.

Behavior with M120

The control checks radius-compensated contours for undercuts and tool path intersections, and calculates the tool path in advance from the current NC block. Areas of the contour that would be damaged by the tool will not be machined (shown darker in the figure). You can also use **M120** to calculate the tool radius compensation for digitized data or data from an external programming system. This means that you can compensate for deviations from the theoretical tool radius.

The number of NC blocks (99 max.) to be calculated in advance can be defined with **LA** (Look Ahead) following **M120**. Note that the larger the number of NC blocks you choose, the higher the block processing time will be.

Input


If you define **M120** in a positioning block, the control continues the dialog and prompts you for the number of **LA** NC blocks to be calculated in advance.

Effect

Program the function **M120** in an NC block that also contains an **RL** or **RR** radius compensation. This way, you can achieve consistent programming, resulting in clearly structured programs. You can deactivate the function **M120** with the following NC syntax:

- **R**0
- M120 LA0
- M120 without LA
- PGM CALL
- Cycle 19 or PLANE functions

M120 becomes effective at the start of the block and remains effective beyond the milling cycles (option 19).



Restrictions

- After an external or internal stop, you have to use a block scan to be able to re-approach the contour. Before the block scan, you need to cancel M120—otherwise the control will issue an error message.
- If you want to approach the contour on a tangential path, you must use the function APPR LCT. The NC block with APPR LCT must contain only the coordinates of the working plane.
- If you want to depart the contour on a tangential path, you must use the function **DEP LCT**. The NC block with **DEP LCT** must contain only the coordinates of the working plane.
- Before using the following functions, you have to cancel M120 and the radius compensation:
 - Cycle 32 TOLERANCE
 - Cycle 19 WORKING PLANE
 - PLANE function
 - M114
 - M128
 - TCPM FUNCTION

Superimposing handwheel positioning during program run: M118 (option 21)

Standard behavior



Refer to your machine manual!

Your machine tool builder must have prepared the control for this function.

In the Program Run operating modes, the control moves the tool as defined in the NC program.

Behavior with M118

M118 permits manual corrections by handwheel during the program run. For this purpose, you program **M118** and enter an axis-specific value (linear or rotary axis).

Input

If you enter **M118** in a positioning block, the control continues the dialog for this block by prompting you for the axis-specific values. Use the orange axis keys or the alphabetic keyboard for entering the coordinates.

Effect

To cancel handwheel positioning, program **M118** once again without coordinate input or end the NC program with **M30** / **M2**.



If the program aborts, handwheel positioning will also be canceled.

M118 becomes effective at the start of the block.

Example

A

You want to be able to use the handwheel during program run to move the tool in the working plane X/Y by ± 1 mm and in the rotary axis B by $\pm 5^{\circ}$ from the programmed value:

L X+0 Y+38.5 RL F125 M118 X1 Y1 B5

When programmed in an NC program, **M118** is always effective in the machine coordinate system.

The **POS HR** tab of the additional status display shows the **Max. val.** defined in **M118**.

Further information: User's Manual for Setup, Testing and Running NC Programs

The function **Handwheel superimposed** is also effective in the **Positioning w/ Manual Data Input** operating mode!

Retraction from the contour in the tool-axis direction: M140

Standard behavior

In the **Program Run Single Block** and **Program Run Full Sequence** operating modes, the control moves the tool as defined in the NC program.

Behavior with M140

With **M140 MB** (move back), you can retract the tool from the contour by a programmable distance in the direction of the tool axis.

Input

If you enter **M140** in a positioning block, the control continues the dialog and prompts you for the path the tool should use for retracting from the contour. Enter the desired path that the tool should follow when retracting from the contour, or press the **MB MAX** soft key to move to the limit of the traverse range.



In the optional machine parameter **moveBack** (no. 200903), the machine tool builder defines how far before a limit switch or a collision object a retraction movement **MB MAX** should end.

In addition, you can program the feed rate at which the tool traverses the entered path. If you do not enter a feed rate, the control moves the tool along the entered path at rapid traverse.

Effect

M140 is effective only in the NC block in which it is programmed. **M140** becomes effective at the start of the block.

Example

NC block 250: Retract the tool by 50 mm from the contour NC block 251: Move the tool to the limit of the traverse range

250 L X+0 Y+38.5 F125 M140 MB 50 F750

251 L X+0 Y+38.5 F125 M140 MB MAX

6

M140 is also effective if the **Tilt working plane** function is active. For machines with swivel heads the control then moves the tool in the tilted coordinate system.

With **M140 MB MAX** you can only retract in the positive direction.

Always define a tool call with tool axis before **M140**, otherwise the traverse direction is not defined.

NOTICE

Danger of collision!

If you use the **M118** function to modify the position of a rotary axis with the handwheel and then execute the **M140** function, the control ignores the superimposed values with the retraction movement. This results in unwanted and unpredictable movements, especially when using machines with head rotation axes. There is a danger of collision during these compensating movements!

Do not combine M118 with M140 when using machines with head rotation axes.

Suppressing touch probe monitoring: M141

Standard behavior

If the stylus is deflected, the control issues an error message as soon as you want to move a machine axis.

Behavior with M141

The control moves the machine axes even if the touch probe is deflected. This function is required if you wish to write your own measuring cycle in connection with Cycle **3** in order to retract the touch probe by means of a positioning block after it has been deflected.

NOTICE

Danger of collision!

The function **M141** suppresses the corresponding error message if the stylus is deflected. The control does not perform an automatic collision check with the stylus. Because of this behavior, you must check whether the touch probe can retract safely. There is a risk of collision if you choose the wrong direction for retraction.

 Carefully test the NC program or program section in Program run, single block operating mode



M141 functions only for movements with straight-line blocks.

Effect

M141 is effective only in the NC block in which **M141** is programmed.

M141 becomes effective at the start of the block.

Deleting basic rotation: M143

Standard behavior

The basic rotation remains in effect until it is reset or is overwritten with a new value.

Behavior with M143

The control deletes a basic rotation from the NC program.




The function **M143** is not permitted with mid-program startup.

Effect

M143 is effective only from the NC block in which it is programmed.

M143 becomes effective at the start of the block.



Automatically retracting the tool from the contour at an NC stop: M148

Standard behavior

In case of an NC stop, the control stops all traverse movements. The tool stops moving at the point of interruption.

Behavior with M148

 \bigcirc

Refer to your machine manual!

This function must be configured and enabled by your machine tool builder.

In the **CfgLiftOff** (no. 201400) machine parameter, the machine tool builder defines the path the control is to traverse for a **LIFTOFF** command. You can also use the **CfgLiftOff** machine parameter to deactivate the function.

Set the **Y** parameter in the **LIFTOFF** column of the tool table for the active tool. The control then retracts the tool from the contour by 2 mm max. in the direction of the tool axis.

Further information: User's Manual for Setup, Testing and Running NC Programs

LIFTOFF takes effect in the following situations:

- An NC stop triggered by you
- An NC stop triggered by the software, e.g. if an error occurred in the drive system
- When a power interruption occurs

Effect

M148 remains in effect until deactivated with M149.

M148 becomes effective at the start of the block, **M149** at the end of the block.

Rounding corners: M197

Standard behavior

With active radius compensation, the control inserts a transition arc at outside corners. This may lead to rounding of that edge.

Behavior with M197

With the **M197** function, the contour at the corner is tangentially extended and a smaller transition arc is then inserted. When you program the **M197** function and then press the **ENT** key, the control opens the **DL** input field. In **DL**, you define the length the control by which the control extends the contour elements. With **M197**, the corner radius is reduced, the corner is rounded less and the traverse movement is still smooth.

Effect

The **M197** function acts blockwise and is only effective on outside corners.

Example

L X... Y... RL M197 DL0.876



Subprograms and program section repeats

8.1 Labeling subprograms and program section repeats

Subprograms and program section repeats enable you to program a machining sequence once and then run it as often as necessary.

Label

The beginnings of subprograms and program section repeats in NC programs are marked by **(LBL)** labels.

A LABEL contains a number between 1 and 65535 or a name definable by you. Each LABEL number or LABEL name can be used only once within the NC program and is set with the **LABEL SET** key. The quantity of label names you are able to enter is limited only by the amount of internal memory.



Do not use a label number or label name more than once!

Label 0 (**LBL 0**) is used exclusively to mark the end of a subprogram and can therefore be used as often as desired.




Before creating your NC program, compare the subprogram and program section repeat programming techniques using the so-called If-Then Decisions. You can thereby avoid possible misunderstandings and programming errors.

Further information: "If-then decisions with Q parameters", Page 274

8.2 Subprograms

Operating sequence

- 1 The control executes the NC program up to the block in which a subprogram is called with **CALL LBL**
- 2 The subprogram is then executed until the subprogram end **LBL 0**
- 3 The control then resumes the NC program from the NC block after the subprogram call **CALL LBL**



Programming notes

- A main program can contain any number of subprograms
- You can call subprograms in any sequence and as often as desired
- A subprogram cannot call itself
- Write subprograms after the NC block with M2 or M30
- If subprograms are located in the NC program before the NC block with M2 or M30, they will be executed at least once even if they are not called

Programming the subprogram

- LBL SET
- To mark the beginning: Press the LBL SET key
- Enter the subprogram number. If you want to use a label name, press the LBL NAME soft key to switch to text entry.
- Enter the text
- Mark the end: Press the LBL SET key and enter the label number 0

Calling a subprogram

LBL CALL

- Call a subprogram: Press the LBL CALL key
- Enter the subprogram number of the subprogram you wish to call. If you want to use a label name, press the LBL NAME soft key to switch to text entry.
- If you want to enter the number of a string parameter as target address, press the QS soft key
- > The control then jumps to the label name that is specified in the string parameter defined.
- Ignore repeats REP by pressing the NO ENT key. Repeat REP is used only for program section repeats

A


CALL LBL 0 is not permitted (Label 0 is only used to mark the end of a subprogram).



8.3 Program-section repeats

Label

The beginning of a program section repeat is marked by the label LBL. The end of a program section repeat is identified by CALL LBL n REPn.



Operating sequence

- 1 The control executes the NC program up to the end of the program section (CALL LBL n REPn)
- 2 Then the program section between the called LABEL and the label call **CALL LBL n REPn** is repeated the number of times entered after **REP**
- 3 The control then resumes the NC program after the last repetition.

Programming notes

- You can repeat a program section up to 65 534 times in succession
- The total number of times the program section is executed is always one more than the programmed number of repeats, because the first repeat starts after the first machining process.

Programming a program section repeat

LBL SET

LBL

- To mark the beginning, press the LBL SET key and enter a LABEL NUMBER for the program section you wish to repeat. If you want to use a label name, press the LBL NAME soft key to switch to text entry.
- Enter the program section

Calling a program section repeat

- Call a program section: Press the **LBL CALL** key
- Enter the program section number of the program section to be repeated. If you want to use a LABEL name, press the LBL NAME soft key to switch to text entry
- Enter the number of repeats REP and confirm with the ENT key.

8.4 Calling an external NC program

Overview of the soft keys

When you press the **PGM CALL** key, the control displays the following soft keys:


Soft key	Function
CALL PROGRAM	Call an NC program with PGM CALL
SELECT DATUM TABLE	Select a datum table with SEL TABLE
SELECT POINT TABLE	Select a point table with SEL PATTERN
SELECT CONTOUR	Select a contour program with SEL CONTOUR
SELECT PROGRAM	Select an NC program with SEL PGM
CALL SELECTED PROGRAM	Call the last selected file with CALL SELECTED PGM
SELECT CYCLE	Select any NC program with SEL CYCLE as a machining cycle
	Further information: User's Manual for Programming of Machining Cycles

Operating sequence

- 1 The control executes the NC program up to the block in which another NC program is called with **CALL PGM**.
- 2 Then the other NC program is run from beginning to end.
- 3 The control then resumes the calling NC program with the NC block behind the program call.



If you want to program variable program calls in connection with string parameters, use the $\ensuremath{\text{SEL PGM}}$ function.



Programming notes

- The control does not require any labels to call an NC program.
- The called NC program must not have a CALL PGM call into the calling NC program (an endless loop ensues).
- The called NC program must not contain the miscellaneous function M2 or M30. If you have defined subprograms with labels in the called NC program, then you can replace M2 or M30 with the jump function FN 9: If +0 EQU +0 GOTO LBL 99.
- If you want to call a ISO program, enter the file type .I after the program name.
- You can also call an NC program with Cycle **12 PGM CALL**.
- You can also call any NC program with the function Select the cycle (SEL CYCLE).
- As a rule, Q parameters are effective globally with a PGM CALL. So please note that changes to Q parameters in the called NC program can also influence the calling NC program.



While the control is running the calling NC program, the editing of all called NC programs is disabled.

Checking the called NC programs

NOTICE

Danger of collision!

The control does not automatically check whether collisions can occur between the tool and the workpiece. If you do not specifically rescind the coordinate transformations in the called NC program, these transformations will also take effect in the calling NC program. Danger of collision during machining!

- Reset used coordinate transformations in the same NC program
- Check the machining sequence using a graphic simulation if required

The control checks the called NC programs:

- If the called NC program contains the miscellaneous functions
 M2 or M30, then the control displays a warning. The control automatically clears the warning as soon as you select another NC program.
- The control checks the called NC programs to see whether they are complete before running them. If the END PGM NC block is missing, the control aborts with an error message.

Further information: User's Manual for Setup, Testing and Running NC Programs

Path information

If the NC program you want to call is located in the same directory as the NC program you are calling it from, then you only need to enter the program name.

If the called NC program is not located in the same directory as the NC program you are calling it from, you must enter the complete path, e.g. **TNC:\ZW35\HERE\PGM1.H**

Alternatively, you can program relative paths:

- Starting from the folder of the calling NC program one folder level up ... PGM1.H
- Starting from the folder of the calling NC program one folder level down DOWN\PGM1.H
- Starting from the folder of the calling NC program one folder level up and in one other folder ... THERE PGM3.H

Calling an external NC program

Calling a program with PGM CALL

You can call an external NC program with the **PGM CALL** function. The control runs the external NC program from the position where it was called in the NC program.

Proceed as follows:



Press the PGM CALL key

- CALL PROGRAM
- Press the CALL PROGRAM soft key
- The control starts the dialog for defining the NC program to be called.
- Enter the path name with the keyboard

Alternative:



i)

- Press the SELECT FILE soft key
- > The control displays a selection window in which you can select the NC program to be called.
- Press the ENT key

If the called file is located in the same directory as the file you are calling it from, you can also integrate the file name without the path. The **APPLY FILE NAME** soft key provided in the selection window of the **SELECT FILE** soft key is available for this.

Call with SEL PGM and CALL SELECTED PGM

The function **SEL PGM** allows you to select an external NC program that you can separately call at a different position in the NC program. The control runs the external NC program from the position at which you called it in the NC program using **CALL SELECTED PGM**.

The **SEL PGM** function is also permitted with string parameters, so that you can dynamically control program calls.

To select the NC program, proceed as follows:



Press the PGM CALL key



Press the SELECT PROGRAM soft key

> The control starts the dialog for defining the

SELECT

FILE

i

Press the SELECT FILE soft key

NC program to be called.

- > The control displays a selection window in which you can select the NC program to be called.
- ► Press the ENT key

If the called file is located in the same directory as the file you are calling it from, you can also integrate the file name without the path. The **APPLY FILE NAME** soft key provided in the selection window of the **SELECT FILE** soft key is available for this.

To call the selected NC program, proceed as follows:

PGM CALL Press the PGM CALL key



CALL SELECTED

PROGRAM

i

Press the CALL SELECTED PROGRAM soft key

The control uses CALL SELECTED PGM to call the NC program that was selected last.

If an NC program that was called using **CALL SELECTED PGM** is missing, then the control interrupts the execution or simulation with an error message. In order to avoid undesired interruptions during program run, you can use the function **FN 18** (**ID10 NR110** and **NR111**) to check all paths at the beginning of the program. **Further information:** "FN 18: SYSREAD – Reading system data", Page 299

8.5 Nesting

Types of nesting

- Subprogram calls in subprograms
- Program-section repeats within a program-section repeat
- Subprogram calls within program-section repeats
- Program-section repeats within subprograms



Subprograms and program-section repeats can call external NC programs as well.

Nesting depth

The nesting depth defines, among other things, how often program sections or subprograms may contain further subprograms or program section repeats.

- Maximum nesting depth for subprograms: 19
- Maximum nesting depth for external NC programs: 19, for which a CYCL CALL has the effect of calling an external program
- You can nest program section repeats as often as desired

Subprogram within a subprogram

Example

0 BEGIN PGM UPGMS MM	
17 CALL LBL "UP1"	Call the subprogram marked with LBL SP1
35 L Z+100 R0 FMAX M2	Last program block of the main program with M2
36 LBL "UP1"	Beginning of subprogram SP1
39 CALL LBL 2	Call the subprogram marked with LBL 2
45 LBL 0	End of subprogram 1
46 LBL 2	Beginning of subprogram 2
62 LBL 0	End of subprogram 2
63 END PGM SUBPGMS MM	

Program execution

- 1 Main program UPGMS is executed up to NC block 17
- 2 Subprogram UP1 is called, and executed up to NC block 39
- 3 Subprogram 2 is called, and executed up to NC block 62. End of subprogram 2 and return jump to the subprogram from which it was called.
- 4 Subprogram UP1 is called, and executed from NC block 40 up to NC block 45. End of subprogram 1 and return jump to the main program UPGMS.
- 5 Main program UPGMS is executed from NC block 18 up to NC block 35. Return jump to NC block 1 and end of program

Repeating program section repeats

Example

0 BEGIN PGM REPS MM	
15 LBL 1	Beginning of program section repeat 1
20 LBL 2	Beginning of program section repeat 2
27 CALL LBL 2 REP 2	Program section call with two repeats
35 CALL LBL 1 REP 1	The program section between this NC block and LBL 1
	(NC block 15) is repeated once
50 END PGM REPS MM	

Program execution

- 1 Main program REPS is executed up to NC block 27
- 2 The program section between NC block 27 and NC block 20 is repeated twice
- 3 Main program REPS is executed from NC block 28 up to NC block 35
- 4 The program section between NC block 35 and NC block 15 is repeated once (including the program section repeat between NC block 20 and NC block 27)
- 5 Main program REPS is executed from NC block 36 up to NC block 50. Return jump to NC block 1 and end of program

Repeating a subprogram

Example

0 BEGIN PGM UPGREP MM	
10 LBL 1	Beginning of program section repeat 1
11 CALL LBL 2	Subprogram call
12 CALL LBL 1 REP 2	Program section call with two repeats
19 L Z+100 R0 FMAX M2	Last NC block of the main program with M2
20 LBL 2	Beginning of subprogram
28 LBL 0	End of subprogram
29 END PGM UPGREP MM	

Program execution


- 1 Main program UPGREP is executed up to NC block 11
- 2 Subprogram 2 is called and executed.
- 3 The program section between NC block 12 and NC block 10 is repeated twice. This means that subprogram 2 is repeated twice
- 4 Main program UPGREP is executed from NC block 13 up to NC block 19. Return jump to NC block 1 and end of program

8.6 Programming examples

Example: Milling a contour in several infeeds

Program run:

- Pre-position the tool to the workpiece surface
- Enter the infeed depth in incremental values
- Contour milling
- Repeat infeed and contour-milling




0 BEGIN PGM PGMWDH MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-40	
2 BLK FORM 0.2 X+100 Y+100 Z+0	
3 TOOL CALL 1 Z S500	Tool call
4 L Z+250 R0 FMAX	Retract the tool
5 L X-20 Y+30 R0 FMAX	Pre-position in the working plane
6 L Z+0 RO FMAX M3	Pre-position to the workpiece surface
7 LBL 1	Set label for program section repeat
8 L IZ-4 RO FMAX	Incremental downfeed (in the air)
9 APPR CT X+2 Y+30 CCA90 R+5 RL F250	Contour approach
10 FC DR- R18 CLSD+ CCX+20 CCY+30	Contour
11 FLT	
12 FCT DR- R15 CCX+50 CCY+75	
13 FLT	
14 FCT DR- R15 CCX+75 CCY+20	
15 FLT	
16 FCT DR- R18 CLSD- CCX+20 CCY+30	
17 DEP CT CCA90 R+5 F1000	Contour departure
18 L X-20 Y+0 R0 FMAX	Retract tool
19 CALL LBL 1 REP 4	Return jump to LBL 1; section is repeated a total of 4 times
20 L Z+250 R0 FMAX M2	Retract the tool, end of program
21 END PGM PGMWDH MM	

Example: Groups of holes

Program run:

- Approach the groups of holes in the main program
- Call the group of holes (subprogram 1) in the main program
- Program the group of holes only once in subprogram 1




0 BEGIN PGM UP1 A	٨M	
1 BLK FORM 0.1 Z X	2+0 Y+0 Z-20	
2 BLK FORM 0.2 X+	100 Y+100 Z+0	
3 TOOL CALL 1 Z S5	000	Tool call
4 L Z+250 R0 FMAX		Retract the tool
5 CYCL DEF 200 DR	RILLING	Cycle definition: Drilling
Q200=2	;SET-UP CLEARANCE	
Q201=-10	;DEPTH	
Q206=250	;FEED RATE FOR PLNGNG	
Q202=5	;PLUNGING DEPTH	
Q210=0	;DWELL TIME AT TOP	
Q203=+0	;SURFACE COORDINATE	
Q204=10	;2ND SET-UP CLEARANCE	
Q211=0.25	;DWELL TIME AT DEPTH	
Q395=0	;DEPTH REFERENCE	
6 L X+15 Y+10 R0 F	MAX M3	Move to starting point for group 1
7 CALL LBL 1		Call the subprogram for the group
8 L X+45 Y+60 R0 F	MAX	Move to starting point for group 2
9 CALL LBL 1		Call the subprogram for the group
10 L X+75 Y+10 R0	FMAX	Move to starting point for group 3
11 CALL LBL 1		Call the subprogram for the group
12 L Z+250 R0 FMA	X M2	End of main program
13 LBL 1		Beginning of subprogram 1: Group of holes
14 CYCL CALL		Hole 1
15 L IX+20 R0 FMAX	(M99	Move to 2nd hole, call cycle
16 L IY+20 R0 FMAX	(M99	Move to 3rd hole, call cycle
17 L IX-20 R0 FMAX	M99	Move to 4th hole, call cycle
18 LBL 0		End of subprogram 1
19 END PGM UP1 M	Μ	

Example: Group of holes with multiple tools

Program run:

- Program the fixed cycles in the main program
- Call the complete hole pattern (subprogram 1) in the main program
- Approach the groups of holes (subprogram 2) in subprogram 1
- Program the group of holes only once in subprogram 2



0 BEGIN PGM UP2 MM	Λ	
1 BLK FORM 0.1 Z X+	0 Y+0 Z-20	
2 BLK FORM 0.2 X+10	00 Y+100 Z+0	
3 TOOL CALL 1 Z S50	00	Centering drill tool call
4 L Z+250 R0 FMAX		Retract the tool
5 CYCL DEF 200 DRII	LLING	Cycle definition: Centering
Q200=2	;SET-UP CLEARANCE	
Q201=-3	;DEPTH	
Q206=250	;FEED RATE FOR PLNGNG.	
Q202=3	;PLUNGING DEPTH	
Q210=0	;DWELL TIME AT TOP	
Q203=+0	;SURFACE COORDINATE	
Q204=10	;2ND SET-UP CLEARANCE	
Q211=0.25	;DWELL TIME AT DEPTH	
Q395=0	;DEPTH REFERENCE	
6 CALL LBL 1		Call subprogram 1 for the entire hole pattern
7 L Z+250 R0 FMAX		
8 TOOL CALL 2 Z S40	00	Drill tool call
9 FN 0: Q201 = -25		New depth for drilling
10 FN 0: Q202 = +5		New plunging depth for drilling
11 CALL LBL 1		Call subprogram 1 for the entire hole pattern
12 L Z+250 R0 FMAX		
13 TOOL CALL 3 Z S5	00	Reamer tool call

14 CYCL DEF 201 R	EAMING	Cycle definition: Reaming
Q200=2	;SET-UP CLEARANCE	
Q201=-15	;DEPTH	
Q206=250	;FEED RATE FOR PLNGNG.	
Q211=0.5	;DWELL TIME AT DEPTH	
Q208=400	;RETRACTION FEED RATE	
Q203=+0	;SURFACE COORDINATE	
Q204=10	;2ND SET-UP CLEARANCE	
15 CALL LBL 1		Call subprogram 1 for the entire hole pattern
16 L Z+250 R0 FMA	X M2	End of main program
17 LBL 1		Beginning of subprogram 1: Entire hole pattern
18 L X+15 Y+10 R0	FMAX M3	Move to starting point for hole group 1
19 CALL LBL 2		Call subprogram 2 for the hole group
20 L X+45 Y+60 R0	FMAX	Move to starting point for hole group 2
21 CALL LBL 2		Call subprogram 2 for the hole group
22 L X+75 Y+10 R0	FMAX	Move to starting point for hole group 3
23 CALL LBL 2		Call subprogram 2 for the hole group
24 LBL 0		End of subprogram 1
25 LBL 2		Beginning of subprogram 2: Group of holes
26 CYCL CALL		Hole 1 with active machining cycle
27 L IX+20 R0 FMAX	(M99	Move to 2nd hole, call cycle
28 L IY+20 R0 FMAX	(M99	Move to 3rd hole, call cycle
29 L IX-20 R0 FMAX	M99	Move to 4th hole, call cycle
30 LBL 0		End of subprogram 2
31 END PGM SP2 MA	۸	



Programming Q parameters

9.1 Principle and overview of functions


With Q parameters you can program entire families of parts in a single NC program by programming variable Q parameters instead of fixed numerical values.

Q parameters can be used in the following ways:

- Coordinate values
- Feed rates
- Spindle speeds
- Cycle data

The control offers more ways to use Q parameters:

- Program contours that are defined through mathematical functions
- Making the execution of machining steps dependent on logical conditions
- Variably design FK programs



Q parameter types

Q parameters for numeric values

Q parameters are always identified with letters and numbers. The letters determine the type of Q parameter and the numbers the Q parameter range.

For more information, see the table below:

Q parameter type	Q parameter range	Meaning
Q parameters:		Parameters affect all NC programs in the control's memory
	0 to 99	Parameters for the user , if there are no overlaps with the HEIDENHAIN-SL cycles
		 These parameters have a local effect within so-called macros and OEM cycles. This means that changes are not returned to the NC program. For this reason, use the Q parameter range 1200 to 1399 for OEM cycles!
	100 to 199	Parameters for special functions on the control that can be read by NC programs of the user or by cycles
	200 to 1199	Parameters primarily used for HEIDENHAIN cycles
	1200 to 1399	Parameters preferentially used with manufacturer cycles if values are returned to the user program
	1400 to 1599	Parameters primarily used as input parameters for manufacturer cycles
	1600 to 1999	Parameters for users
QL parameters:		Parameters only effective locally within an NC program
	0 to 499	Parameters for users
QR parameters:		Parameters permanently affect all NC programs in the control's memory, including after a power interruption
	0 to 99	Parameters for users
	100 to 199	Parameters for HEIDENHAIN functions (e.g., cycles)
	200 to 499 Parameters for the machine tool builder (e.g., cycles	

0	QR parameters will be included in backups. If the machine tool builder did not define a specific path, the control will save the QR parameter values in the following path: SYS:\runtime\sys.cfg . This partition will
	only be backed up in full backups. Machine tool builders can use the following optional machine parameters to specify the paths:
	 pathNcQR (no. 131201) pathSimQR (no. 131202)
	If the machine tool builder used the optional machine parameters to specify a path on the TNC partition, you can perform a backup with the NC/PLC Backup

functions without entering a code number.

Q parameters for texts

 ${\bf QS}$ parameters (${\bf S}$ stands for string) are also available and enable you to process texts on the control.

Q parameter type	Q parameter range	Meaning	
QS parameters:		Parameters affect all NC programs in the control's memory	
	0 to 99	Parameters for the user , where no overlaps with the HEIDENHAIN SL cycles are present	
		1 These parameters have a local effect within so-called macros and OEM cycles. This means that changes are not returned to the NC program.	
		For this reason, use the QS parameter range 200 to 499 for OEM cycles!	
	100 to 199	Parameters for special functions on the control that can be read by NC programs of the user or by cycles	
	200 to 1199	Parameters primarily used for HEIDENHAIN cycles	
	1200 to 1399	Parameters preferentially used with manufacturer cycles if values are returned to the user program	
	1400 to 1599	Parameters primarily used as input parameters for manufacturer cycles	
	1600 to 1999	Parameters for users	

Programming notes

NOTICE

Danger of collision!

i

HEIDENHAIN cycles, manufacturer cycles and third-party functions use Q parameters. You can also program Q parameters within NC programs. If, when using Q parameters, the recommended Q parameter ranges are not used exclusively, then this can lead to overlapping (reciprocal effects) and thus cause undesired behavior. Danger of collision during machining!

- Only use Q parameter ranges recommended by HEIDENHAIN.
- Comply with the documentation from HEIDENHAIN, the machine tool builder, and suppliers.
- Check the machining sequence using a graphic simulation

You can mix Q parameters and numerical values within an NC program.

Q parameters can be assigned numerical values between -999 999 999 and +999 999. The input range is limited to 16 digits, of which 9 may be before the decimal point. Internally the control calculates numbers up to a value of 10¹⁰.

You can assign a maximum of 255 characters to **QS** parameters.

The control automatically assigns some Q and QS parameters the same data, e.g., the Q parameter **Q108** is automatically assigned the current tool radius.

Further information: "Preassigned Q parameters", Page 317

The control saves numerical values internally in a binary number format (standard IEEE 754). Due to the standardized format used, the control does not represent some decimal numbers with a binary number that is 100% exact (round-off error). If you use calculated Q parameter contents for jump commands or positioning moves, then you must take this fact into consideration.

You can reset Q parameters to the status **Undefined**. If a position is programmed with a Q parameter that is undefined, the control ignores this movement.

Calling Q parameter functions

When you are writing an NC program, press the **Q** key (in the numeric keypad for numerical input and axis selection, below the +/- key). The control then displays the following soft keys:

Soft key	Function group	Page
BASIC ARITHM.	Basic arithmetic (assign, add, subtract, multiply, divide, square root)	268
TRIGO- NOMETRY	Trigonometric functions	271
CIRCLE CALCU- LATION	Function for calculating circles	273
JUMP	lf/then conditions, jumps	274
DIVERSE FUNCTION	Other functions	284
FORMULA	Entering formulas directly	277
CONTOUR FORMULA	Function for machining complex contours	See the User's Manual for Programming of Machining Cycles
If you define or assign a Q parameter, then the control shows the Q , QL and QR soft keys. You can use these soft keys to select the desired parameter type. Then you define the parameter number. If you have a alphabetic keyboard connected via the USB port, you can press the Q key to open the dialog for entering a formula.		

9.2 Part families—Q parameters in place of numerical values

Application

The Q parameter function **FN 0: Assign** allows you to assign numerical values to Q parameters. You then use a Q parameter in place of the numerical value in the NC program.

Example


15 FN 0: Q10=25	Assign
	Q10 is assigned the value 25
25 L X +Q10	Means L X +25

You need write only one program for a whole family of parts, entering the characteristic dimensions as \mbox{Q} parameters.

To program a particular part, you then assign the appropriate values to the individual $\ensuremath{\Omega}$ parameters.

Example: Cylinder with Q parameters

Cylinder radius:	R = Q1
Cylinder height:	H = Q2
Cylinder Z1:	Q1 = +30
	Q2 = +10
Cylinder Z2:	Q1 = +10
	Q2 = +50



9.3 Describing contours with mathematical functions

Application

The Q parameters listed below enable you to program basic mathematical functions in a NC program:

h
Ζ,

- Select the Q parameter function: Press the Q key in the numeric keypad
- The Q parameter functions are displayed in the soft key row.

	Press the BASIC ARITHM. soft key
>	The control displays the soft keys for basic

mathematical functions

Overview

BASIC ARITHM

Soft key	Function
FNO X = Y	FN 0 : ASSIGN e.g., FN 0: Q5 = +60 Directly assign value Reset Q parameter value
FN1 X + Y	FN 1: ADDITION e. g., FN 1: Q1 = -Q2 + -5 Calculate and assign the sum of two values
FN2 X - Y	FN 2 : SUBTRACTION e. g. FN 2: Q1 = +10 - +5 Form and assign difference between two values
FN3 X * Y	FN 3: MULTIPLICATION e. g. FN 3: Q2 = +3 * +3 Form and assign the product of two values
FN4 X / Y	FN 4 : DIVISION e.g., FN 4: Q4 = +8 DIV +Q2 Calculate and assign the quotient of two values Not permitted: Division by 0
FN5 SQRT	FN 5 : SQUARE ROOT e.g., FN 5: Q20 = SQRT 4 Calculate and assign the square root of a value Not permitted: Square root of a negative value

You can enter the following to the right of the = sign:

- Two numbers
- Two Q parameters
- A number and a Q parameter

The Q parameters and numerical values in the equations can be entered with positive or negative signs.

Programming fundamental operations

Example: Assignment

16 FN 0: Q5 =		
17 FN 3: Q12 = +Q5 * +7		
Q	Select the Q parameter function: Press the Q key	
BASIC ARITHM.	 Select basic mathematical functions by pressing the BASIC ARITHM. soft key 	
FNO X = Y	To select the ASSIGN Q parameter function: Press the FN 0 X = Y soft key	
>	 The control asks you for the number of the result parameter. 	
•	Enter 5 (number of Q parameter)	
ENT	Confirm with the ENT key	
>	The control asks you for the value or parameter.	
▶	Enter 10 (value)	
ENT	Confirm with the ENT key	
>	As soon as the control reads the NC block, the value 10 is assigned to the parameter Q5 .	
Example: Multiplication		
0	Select the Q parameter function: Press the ${f Q}$ key	
BASIC ARITHM.	Select basic mathematical functions by pressing the BASIC ARITHM. soft key	
FN3 X · Y	To select the MULTIPLICATION Q parameter function, press the FN 3 X * Y soft key	
>	 The control asks you for the number of the result parameter. 	
▶	Enter 12 (number of Q parameter)	
ENT	Confirm with the ENT key	
>	 The control asks you for the first value or parameter. 	
•	Enter Q5 (parameter)	
ENT	Confirm with the ENT key	
>	 The control asks you for the second value or parameter. 	
•	Enter 7 for the second value	
ENT	Confirm with the ENT key	

Resetting Q parameters Example

BASIC	Select the Ω parameter function: Press the Q key
BASTO	
ARITHM.	 Select basic mathematical functions by pressing the BASIC ARITHM. soft key
FNO X = Y	To select the ASSIGN Q parameter function: Press the FN 0 X = Y soft key
	The control asks you for the number of the result parameter.
	Enter 5 (number of Q parameter)
ENT	Confirm with the ENT key
	> The control asks you for the value or parameter.
SET UNDEFINED	Press SET UNDEFINED

message **Invalid value**.

9

9.4 Trigonometric functions

Definitions


Sine: Cosine: sin α = a / c cos α = b / c

Tangent:

 $\cos \alpha = b / c$ $\tan \alpha = a / b = \sin \alpha / \cos \alpha$

where

- c is the side opposite the right angle
- $\blacksquare\,$ a is the side opposite the angle α
- b is the third side.
- The control can find the angle from the tangent:
- α = arctan (a / b) = arctan (sin α / cos α)



Example:

 $\begin{array}{l} a=25 \text{ mm} \\ b=50 \text{ mm} \\ \alpha=\arctan\left(a \ / \ b\right)=\arctan 0.5=26.57^\circ \\ \text{Furthermore:} \\ a^2+b^2=c^2 \ (\text{where } a^2=a \ x \ a) \\ c=\sqrt{\left(a^2+b^2\right)} \end{array}$

Programming trigonometric functions

You can also calculate trigonometric functions with Q parameters.

- Q
- Select the Q parameter function: Press the Q key in the numeric keypad
- The Q parameter functions are displayed in the soft key row.
- TRIGO-NOMETRY
- Press the TRIGONOMETRY soft key
- > The control displays the soft keys for trigonometric functions.

Overview

Soft key	Function
FN6 SIN(X)	FN 6: SINE e.g., FN 6: Q20 = SIN-Q5 Calculate and assign the sine of an angle in degrees (°)
FN7 COS(X)	FN 7: COSINE e.g., FN 7: Q21 = COS-Q5 Calculate and assign the cosine of an angle in degrees (°)
FN8 X LEN Y	FN 8: ROOT SUM OF SQUARES e. g., FN 8: Q10 = +5 LEN +4 Calculate and assign length from two values
FN13 X ANG Y	FN 13 : ANGLE e. g., FN 13: Q20 = +25 ANG-Q1 Calculate and assign an angle with the arc tangent of the opposite and adjacent sides of the triangle or with the sine and cosine of the angle (0 < angle < 360°).

9.5 Circle calculations

Application

The control can use the functions for calculating circles to calculate the circle center and the circle radius from three or four given points on the circle. The calculation is more accurate if four points are used.

Application: These functions can be used, for example, if you wish to determine the location and size of a hole or a pitch circle using the programmable probing function.

Soft key	Function
FN23 3 POINTS OF CIRCLE	FN 23: Determining the CIRCLE DATA from three points
	Example: FN 23: Q20 = CDATA Q30

The coordinate pairs of three points on a circle must be saved in **Q30** and the following five parameters—in this case, up to **Q35**.

The control then saves the circle center in the principal axis (X if spindle axis is Z) in parameter **Q20**, the circle center in the minor axis (Y if spindle axis is Z) in parameter **Q21**, and the circle radius in parameter **Q22**.

Soft key	Function
FN24 4 POINTS	FN 24: Determining the CIRCLE DATA from four
OF CIRCLE	points Example: FN 24: Q20 = CDATA Q30

The coordinate pairs of four points on a circle must be saved in parameter **Q30** and the following seven parameters—in this case, up to **Q37**.

The control then saves the circle center in the principal axis (X if spindle axis is Z) in parameter **Q20**, the circle center in the minor axis (Y if spindle axis is Z) in parameter **Q21**, and the circle radius in parameter **Q22**.



Note that **FN 23** and **FN 24** automatically overwrite the resulting parameter and the two following parameters.

9.6 If-then decisions with Q parameters

Application

In if-then decisions, the control compares a Q parameter with another Q parameter or a numerical value. If the condition is fulfilled, then the control continues the NC program at the label that is programmed after the condition.



Before creating your NC program, compare the if-then decisions with the subprogram and program section repeat programming techniques.

You can thereby avoid possible misunderstandings and programming errors.

Further information: "Labeling subprograms and program section repeats", Page 242

If it is not fulfilled, the control continues with the next NC block.

If you want to call an NC program, then program a program call with $\ensuremath{\text{PGM CALL}}$ after the label.

Abbreviations used

IF	:	lf
ΕQU	:	Equal to
NE	:	Not equal to
GT	:	Greater than
LT	:	Less than
GOTO	:	Go to
UNDEFINED	:	Undefined
DEFINED	:	Defined

Jump conditions

Unconditional jump

An unconditional jump is programmed by entering a conditional jump whose condition is always true. Example:

FN 9: IF+10 EQU+10 GOTO LBL1

Conditioning jumps with counters

The jump function allows you to repeat a machining operation any number of times. A Q parameter serves as a counter that increments by 1 at every program section repeat.

The jump function allows you to compare the counter with the number of desired machining operations.

6

These jumps differ from the subprogram and program section repeat programming techniques. On the one hand, for example, jumps require no completed program section ending with LBL 0. On the other hand, jumps do not take these return jump labels

into consideration!

Example

0 BEGIN PGM COUNTER MM	
1;	
2 Q1 = 0	Loaded value: Initialize counter
3 Q2 = 3	Loaded value: Number of jumps
4;	
5 LBL 99	Label
6 Q1 = Q1 + 1	Initialize counter: New Q1 value = Old Q1 value + 1
7 FN 12: IF +Q1 LT +Q2 GOTO LBL 99	Run program jumps 1 and 2
8 FN 9: IF +Q1 EQU +Q2 GOTO LBL 99	Run program jump 3
9;	
10 END PGM COUNTER MM	

Programming if-then decisions

Possibilities for jump inputs

The following inputs are possible for the condition $\ensuremath{\mathsf{IF}}$:

- Numbers
- Texts
- Q, QL, QR
- **QS** (string parameter)

You have three possibilities for entering the jump address GOTO:

- LBL NAME
- LBL NUMBER
- QS

The if-then decisions appear when the **JUMP** soft key is pressed. The control displays the following soft keys:

Soft key	Function
FN9 IF X EQ Y GOTO EQU	FN 9: IF EQUAL, JUMP e.g., FN 9: IF +Q1 EQU +Q3 GOTO LBL "UPCAN25" If both values or parameters are equal, jump to specified label
FN9 IF X EQ Y GOTO IS UNDEFINED	FN 9: IF UNDEFINED, JUMP e. g., FN 9: IF +Q1 IS UNDEFINED GOTO LBL "UPCAN25" If the specified parameter is undefined, then a jump is made to the specified label
FN9 IF X EQ Y GOTO IS DEFINED	FN 9: IF DEFINED, JUMP e.g., FN 9: IF +Q1 IS DEFINED GOTO LBL "UPCAN25" If the specified parameter is defined, then a jump is made to the specified label
FN10 IF X NE Y GOTO	FN 10 : IF UNEQUAL, JUMP e.g., FN 10: IF +10 NE -Q5 GOTO LBL 10 If both values or parameters are unequal, jump to specified label
FN11 IF X GT Y GOTO	FN 11 : IF GREATER, JUMP g. g., FN 11: IF+Q1 GT+10 GOTO LBL QS5 If the first value or parameter is greater than the second value or parameter, jump to specified label
FN12 IF X LT Y GOTO	FN 12 : IF LESS, JUMP e. g., FN 12: IF+Q5 LT+0 GOTO LBL "ANYNAME" If the first value or parameter is smaller than the second value or parameter, jump to specified label

9.7 Entering formulas directly

Entering formulas

Using soft keys, you can enter mathematical formulas containing multiple calculation operations directly into the NC program.



Select Q parameter function



- Press the FORMULA soft key
- Select Q, QL, or QR
- > The control displays the available mathematical operations in the soft-key row.

Rules for formulas

Sequence for the evaluation of a formula

If you enter a mathematical formula that contains more than one mathematical operation, the control always evaluates the individual operations in a defined sequence. A familiar example of this is the rule that multiplication/division takes place before addition/ subtraction (higher-level operations are performed first).

The control adheres to the following rules of priority for the evaluation of mathematical formulas:

Priority	Designation	Arithmetic operator
1	Remove parentheses	()
2	Note the sign, calculate the function	Minus sign, SIN , COS , LN etc.
3	Powers	^
4	Multiplication and division	* , /
5	Addition and subtraction	+, -

Evaluation of operations with the same priority

The control generally calculates operations with the same priority from the left to the right.

2 + 3 - 2 = (2 + 3) - 2 = 3

Exception: Concatenated powers are evaluated from right to left. $2 \land 3 \land 2 = 2 \land (3 \land 2) = 2 \land 9 = 512$

Example: Perform multiplication/division before addition/ subtraction

= 35

12 Q1 = 5 * 3 + 2 * 10

- 1st calculation 5 * 3 = 15
- 2nd calculation 2 * 10 = 20
- 3rd calculation: 15 + 20 = 35

Example: Calculate power before addition/subtraction

= 73

= 0.25

= 0.5

- 13 Q2 = SQ 10 3^3
- 1st calculation : 10 squared = 100
- 2nd calculation : 3 to the power of 3 = 27
- 3rd calculation: 100 27 = 73

Example: Calculate function before power

14 Q4 = SIN 30 ^ 2

- 1st calculation: Calculate sine of 30 = 0.5
- 2nd calculation: 0.5 squared = 0.25

Example: Evaluate expression in parentheses before function

15 Q5 = SIN (50 - 20)

- 1st calculation: Remove parentheses: 50 20 = 30
- 2nd calculation: Calculate sine of 30 = 0.5

Overview

The control displays the following soft keys:

Soft key	Linking function	Priority
	Addition	Addition/subtraction calcu-
•	e.g. Q10 = Q1 + Q5	lation
	Subtraction	Addition/subtraction calcu-
	e.g. Q25 = Q7 - Q108	lation
	Multiplication	Multiplication/division
	e.g. Q12 = 5 * Q5	calculation
	Division	Multiplication/division
/	e.g. Q25 = Q1 / Q2	calculation
	Opening parenthesis	Expression in parentheses
(e.g. Q12 = Q1 * (Q2 + Q3)	
	Closing parenthesis	Expression in parentheses
)	e.g. Q12 = Q1 * (Q2 + Q3)	
	Square of a value	Function
SQ	e.g. Q15 = SQ 5	
	Square root	Function
SQRT	e.g. Q22 = SQRT 25	
	Sine of an angle	Function
SIN	e.g. Q44 = SIN 45	
	Cosine of an angle	Function
COS	e.g. Q45 = COS 45	
	Tangent of an angle	Function
TAN	e.g. Q46 = TAN 45	
	Arc sine	Function
ASIN	Inverse of the sine. Determines the angle from the ratio of the	
	side opposite the angle and the hypotenuse	
	e.g. Q10 = ASIN (Q40 / Q20)	
ACOS	Arc cosine	Function
	Inverse of the cosine. Determines the angle from the ratio of the side adjacent to the angle and the hypotenuse	
	e.g. Q11 = ACOS Q40	
	Arc tangent	Function
ATAN	Inverse of the tangent. Determines the angle from the ratio of the	
	opposite side to the adjacent side	
	e.g. Q12 = ATAN Q50	
	Raising values to a power	Power
٨	e.g. Q15 = 3 ^ 3	
	Pi constant	
PI	$\pi = 3.14159$	
	e.g. Q15 = PI	

Soft key	Linking function	Priority
LN	Natural logarithm (LN) of a number	Function
LN	Base = $e = 2.7183$	
	e.g. Q15 = LN Q11	
LOG	Logarithm of a number	Function
LUG	Base = 10	
	e.g. Q33 = LOG Q22	
540	Exponential function (e ^ n)	Function
EXP	Base = e = 2.7183	
	e.g. Q1 = EXP Q12	
	Negate values	Function
NEG	Multiply by -1	
	e.g. Q2 = NEG Q1	
INT	Truncate decimal places	Function
INT	Form an integer	
	e.g. Q3 = INT Q42	
	The INT function does not round off—it simply	7
	 truncates the decimal places. Further information: "Example: Rounding a value", 	
	Page 344	
	Absolute value of a number	Function
ABS	e.g. Q4 = ABS Q22	
FRAC	Truncate places before the decimal point	Function
FRAC	Form a fraction	
	e.g. Q5 = FRAC Q23	
SGN	Check algebraic sign of a number	Function
SGN	e.g. Q12 = SGN Q50	
	If Q50 = 0 , then SGN Q50 = 0	
	If Q50 < 0 , then SGN Q50 = -1	
	If Q50 > 0 , then SGN Q50 = 1	
94	Calculate the modulo value (division remainder)	Function
Re la	e. g., Q12 = 400 % 360 Result: Q12 = 40	


Example: Trigonometric function

The lengths of the opposite side a in parameter **Q12** and the adjacent side b in **Q13** are given. The angle α is to be calculated.

Calculate the angle α from the opposite side a and the adjacent side b by means of the arc tangent; assign result **Q25**:

Q	Press the Q key
FORMULA	 Press the FORMULA soft key The control asks you for the number of the result parameter. Enter 25 Press the ENT key
\triangleright	 Scroll through the soft-key row
ATAN	Press the ATAN arc tangent function soft key
	 Scroll through the soft-key row
(Press the Opening parenthesis soft key
Q	 Enter 12 (the parameter number)
/	 Select division
Q	 Enter 13 (the parameter number)
)	Press the Closing parenthesis soft key
END	Press the END key to conclude the formula entry





9.8 Checking and changing Q parameters

Procedure

You can check Q parameters in all operating modes, and also edit them.


If needed, interrupt the program run (e.g., by pressing the NC STOP key and the INTERNAL STOP soft key), or stop the test run



A

- To call the Q parameter functions, press the Q INFO soft key or the Q key
- > The control lists all of the parameters and their corresponding current values.
- Use the arrow keys or the GOTO key to select the desired parameter.
- If you want to change the value, then press the EDIT CURRENT FIELD soft key, enter the new value, and confirm with the ENT key
- If you want to leave the value unchanged, then press the PRESENT VALUE soft key or close the dialog with the END key

All of the parameters with displayed comments are used by the control within cycles or as transfer parameters. If you want to check or edit local, global or string parameters, press the **SHOW PARAMETERS Q QL QR QS** soft key. The control then displays the specific parameter type. The functions previously described also apply.



You can have Q parameters also displayed in the additional status display in all operating modes (except **Programming** mode).

If needed, interrupt the program run (e.g., by pressing the NC STOP key and the INTERNAL STOP soft key), or stop the test run

Display the soft key row for screen layout

- PROGRAM + STATUS
- Select the layout option for the additional status display
- In the right half of the screen, the control shows the **Overview** status form.
- STATUS OF Q PARAM.

Q PARAMETER LIST Press the Q PARAMETER LIST soft key

Press the STATUS OF Q PARAM. soft key

- > The control opens a pop-up window.
- For each parameter type (Q, QL, QR, QS), define the parameter numbers you wish to check. Separate single Q parameters with a comma, and connect sequential Q parameters with a hyphen, e.g. 1,3,200-208. The input range per parameter type is 132 characters

0

The display in the **QPARA** tab always contains eight decimal places. The result of **Q1 = COS 89.999** is shown by the control as 0.00001745, for example. Very large or very small values are displayed by the control in exponential notation. The result of **Q1 = COS 89.999 * 0.001** is shown by the control as +1.74532925e-08, where e-08 corresponds to the factor of 10⁻⁸.

9.9 Additional functions

Overview

The additional functions appear when the **DIVERSE FUNCTION** soft key is pressed. The control displays the following soft keys:

Soft key	Function	Page
FN14 ERROR=	FN 14: ERROR Display error messages	285
FN16 F-PRINT	FN 16: F-PRINT Formatted output of texts or Q parameter values	291
FN18 SYS-DATUM READ	FN 18: SYSREAD Read system data	299
FN19 PLC=	FN 19: PLC Transfer values to the PLC	300
FN20 WAIT FOR	FN 20: WAIT FOR NC and PLC synchronization	300
FN26 OPEN TABLE	FN 26: TABOPEN Open a freely definable table	399
FN27 WRITE TO TABLE	FN 27: TABWRITE Write to a freely definable table	399
FN28 READ FROM TABLE	FN 28: TABREAD Read from a freely definable table	400
FN29 PLC LIST=	FN 29: PLC Transfer up to eight values to the PLC	301
FN37 EXPORT	FN 37: EXPORT Export local Q parameters or QS parameters into a calling NC program	301
FN38 SEND	FN 38: SEND Send information from the NC program	302

FN 14: ERROR – Displaying error messages

With the **FN 14: ERROR** error function, you can output error messages under program control. The messages are predefined by the machine tool builder or by HEIDENHAIN. If the control encounters an NC block with **FN 14: ERROR** during program run or test run, it will interrupt the run and display an error message. You must then restart the NC program.

Error number range	Standard dialog	
0 999	Machine-dependent dialog	
1000 1199	Internal error messages	

Example

The control is intended to display a message if the spindle is not switched on.

180 FN 14: ERROR = 1000

The following is a complete list of the **FN 14: ERROR** error messages. Please be aware that not all error messages are available, depending on the model of your control.

Error message predefined by HEIDENHAIN

Error number	Text
1000	Spindle?
1001	Tool axis is missing
1002	Tool radius too small
1003	Tool radius too large
1004	Range exceeded
1005	Start position incorrect
1006	ROTATION not permitted
1007	SCALING FACTOR not permitted
1008	MIRROR IMAGE not permitted
1009	Datum shift not permitted
1010	Feed rate is missing
1011	Input value incorrect
1012	Incorrect sign
1013	Entered angle not permitted
1014	Touch point inaccessible
1015	Too many points
1016	Contradictory input
1017	CYCL incomplete
1018	Plane wrongly defined
1019	Wrong axis programmed
1020	Wrong rpm

Text
Radius comp. undefined
Rounding-off undefined
Rounding radius too large
Program start undefined
Excessive nesting
Angle reference missing
No fixed cycle defined
Slot width too small
Pocket too small
Q202 not defined
Q205 not defined
Q218 must be greater than Q219
CYCL 210 not permitted
CYCL 211 not permitted
Q220 too large
Q222 must be greater than Q223
Q244 must be greater than 0
Q245 must not equal Q246
Angle range must be under 360°
Q223 must be greater than Q222
Q214: 0 not permitted
Traverse direction not defined
No datum table active
Position error: center in axis 1
Position error: center in axis 2
Hole diameter too small
Hole diameter too large
Stud diameter too small
Stud diameter too large
Pocket too small: rework axis 1
Pocket too small: rework axis 2
Pocket too large: scrap axis 1
Pocket too large: scrap axis 2
Stud too small: scrap axis 1
Stud too small: scrap axis 2
Stud too large: rework axis 1
Stud too large: rework axis 2
TCHPROBE 425: length exceeds max

Error number	Text
1059	TCHPROBE 425: length below min
1060	TCHPROBE 426: length exceeds max
1061	TCHPROBE 426: length below min
1062	TCHPROBE 430: diameter too large
1063	TCHPROBE 430: diameter too small
1064	No measuring axis defined
1065	Tool breakage tolerance exceeded
1066	Enter Q247 unequal to 0
1067	Enter Q247 greater than 5
1068	Datum table?
1069	Enter Q351 unequal to 0
1070	Thread depth too large
1071	Missing calibration data
1072	Tolerance exceeded
1073	Block scan active
1074	ORIENTATION not permitted
1075	3-D ROT not permitted
1076	Activate 3-D ROT
1077	Enter depth as negative
1078	Q303 in meas. cycle undefined!
1079	Tool axis not allowed
1080	Calculated values incorrect
1081	Contradictory meas. points
1082	Incorrect clearance height
1083	Contradictory plunge type
1084	This fixed cycle not allowed
1085	Line is write-protected
1086	Oversize greater than depth
1087	No point angle defined
1088	Contradictory data
1089	Slot position 0 not allowed
1090	Enter an infeed not equal to 0
1091	Switchover of Q399 not allowed
1092	Tool not defined
1093	Tool number not permitted
1094	Tool name not permitted
1095	Software option not active
1096	Kinematics cannot be restored

Error number	Text
1097	Function not permitted
1098	Contradictory workpc. blank dim.
1099	Measuring position not allowed
1100	Kinematic access not possible
1101	Meas. pos. not in traverse range
1102	Preset compensation not possible
1103	Tool radius too large
1104	Plunging type is not possible
1105	Plunge angle incorrectly defined
1106	Angular length is undefined
1107	Slot width is too large
1108	Scaling factors not equal
1109	Tool data inconsistent
1110	MOVE not possible
1111	Presetting not allowed!
1112	Thread angle too small!
1113	3-D ROT status is contradictory!
1114	Configuration is incomplete
1115	No turning tool is active
1116	Tool orientation is inconsistent
1117	Angle not possible!
1118	Radius too small!
1119	Thread runout too short!
1120	Contradictory meas. points
1121	Too many limits
1122	Machining strategy with limits not possible
1123	Machining direction not possible
1124	Check the thread pitch!
1125	Angle cannot be calculated
1126	Eccentric turning not possible
1127	No milling tool is active
1128	Insufficient length of cutting edge
1129	Gear definition is inconsistent or incomplete
1130	No finishing allowance provided
1131	Line does not exist in table
1132	Probing process not possible
1133	Coupling function not possible

Error number	Text	
1134	Machining cycle is not supported by this NC software	
1135	Touch probe cycle is not supported by this NC software	
1136	NC program aborted	
1137	Touch probe data incomplete	
1138	LAC function not possible	
1139	Rounding radius or chamfer is too large!	
1140	Axis angle not equal to tilt angle	
1141	Character height not defined	
1142	Excessive character height	
1143	Tolerance error: Workpiece rework	
1144	Tolerance error: Workpiece scrap	
1145	Faulty dimension definition	
1146	Illegal entry in compensation table	
1147	Transformation not possible	
1148	Tool spindle incorrectly configured	
1149	Offset of the turning spindle unknown	
1150	Global program settings are active	
1151	Faulty configuration of OEM macros	
1152	The combination of programmed oversizes is not possible	
1153	Measured value not captured	
1154	Check the monitoring of the tolerance	
1155	Hole is smaller than the stylus tip	
1156	Preset cannot be set	
1157	Alignment of a rotary table is not possible	
1158	Alignment of rotary axes is not possible	
1159	Infeed limited to length of cutting edge	
1160	Machining depth defined as 0	
1161	Tool type is unsuitable	
1162	Finishing allowance not defined	
1163	Machine datum could not be written	
1164	Spindle for synchronization could not be ascer- tained	
1165	Function is not possible in the active operating mode	
1166	Oversize defined too large	
1167	Number of teeth not defined	

Error number	Text	
1168	Machining depth does not increase monotonous- ly	
1169	Infeed does not decrease monotonously	
1170	Tool radius not defined correctly	
1171	Mode for retraction to clearance height not possible	
1172	Gear wheel definition incorrect	
1173	Probing object contains different types of dimen- sion definition	
1174	Dimension definition contains impermissible characters	
1175	Actual value in dimension definition faulty	
1176	Starting point of hole too deep	
1177	Dimension def.: Nominal value missing for manual pre-positioning	
1178	A replacement tool is not available	
1179	OEM macro is not defined	
1180	Measurement not possible with auxiliary axis	
1181	Start position not possible with modulo axis	
1182	Function only possible if door is closed	
1183	Number of possible records exceeded	
1184	Inconsistent machining plane due to axis angle with basic rot.	
1185	Transfer parameter contains an impermissible value	
1186	Tooth width RCUTS is defined too large	
1187	Usable length LU of the tool is too small	
1188	The defined chamfer is too large	
1189	Chamfer angle cannot be machined with the active tool	
1190	The allowances do not define any stock removal	
1191	Spindle angle not unique	

FN 16: F-PRINT – Formatted output of text and **Q** parameter values

Fundamentals

With the function FN 16: F-PRINT, you can save Q parameter values and output formatted texts (e.g. in order to save measurement reports).

You can output the values as follows:

- Save them to a file on the control
- Display them on the screen in a pop-up window
- Save them to an external file
- Print them using a connected printer

Procedure

Proceed as follows in order to output Q-parameter values and texts:

- Create a text file that defines the output format and contents
- In the NC program, use the function FN 16: F-PRINT in order to ► output the log

If you output the values to a file, the maximum size of the output file will be 20 KB.

Changing the output path of the log file

If you wish to save the measurement results in another directory, then you must modify the output path of the log file.

Change the output path as follows:

enange the eat	
MOD	Press the MOD key
▶	Enter the code number 123
+	Select the parameter Paths for the end user (CfgUserPath)
+	Select the parameter FN 16 output path for execution (fn16DefaultPath)
>	The control opens a pop-up window.
►	Select the output path for the machine operating modes
↓ ►	Select the parameter FN 16 output path for the Programming and Test Run op. modes (fn16DefaultPathSim)
>	The control opens a pop-up window.
►	Select the output path for the Programming and Test Run operating modes
Creating a text	file
•	rmatted texts and Q parameter values, use the ditor to create a text file. Define the format and Q

parameters to be output in this file.

Proceed as follows:

- PGM MGT
- Press the PGM MGT key



- Press the NEW FILE soft key
- Create a file with the extension .A

Available functions

Use the following formatting functions for creating a text file:

Special characters	Function	
п п •••••	Define output format for texts and variables between the quotation marks	
%F	 Format for Q parameters, QL, and QR: Define %: format F: Floating (decimal number), format for Q, QL, QR 	
9.3	 Format for Q parameters, QL, and QR: Total of 9 characters, including decimal separator Of these, 3 are decimal places 	
%S	Format for text variable QS	
%RS	Format for text variable QS Assumes the subsequent without any changes or formatting	
%D or %I	Format for integer	
,	Separation character between output format and parameter	
•	End of block character	
*	Beginning of a comment line Comments are not shown in the log	
%"	Output quotation marks	
%%	Output percent sign	
11	Output backslash	
\n	Output line break	
+	Q parameter value, right-aligned	
-	Q parameter value, left-aligned	

Example

Input	Meaning	
"X1 = %+9.3F", Q31;	 Format for Q parameter: "X1 =: The text X1 = is output %: Specify the format +: Number right-aligned 9.3: Total of 9 characters; 3 of them are decimal 	
	 places F: Floating (decimal number) , Q31: Output the value 	
	from Q31 ;: End of block 	

The following functions allow you to include the following additional information in the protocol log file:

Function
Gives the path for the NC program where you will find the FN 16 function. Example: "Measuring program: %S",CALL_PATH;
Closes the file to which you are writing with FN 16. Example: M_CLOSE;
Upon renewed output, appends the log to the existing log. Example: M_APPEND;
Upon renewed output, appends the log to the existing log until the maximum specified file size in kilobytes is exceeded. Example: M_APPEND_MAX20;
Overwrites the log upon renewed output. Example: M_TRUNCATE;
Prevents empty lines from being inserted into the log if QS parame- ters are not defined or empty. Example: M_EMPTY_HIDE;
Inserts empty lines into the log if QS parameters are not defined. Resets M_EMPTY_HIDE. Example: M_EMPTY_SHOW;
Outputs the text only for English conversa- tional language
Outputs the text only for German conversa- tional language
Outputs text only for Czech conversational language
Outputs text only for French conversational language

293

Keyword	Function
L_ITALIAN	Outputs text only for Italian conversational language
L_SPANISH	Outputs text only for Spanish conversation- al language
L_PORTUGUE	Outputs text only for Portuguese conversa- tional language
L_SWEDISH	Outputs text only for Swedish conversa- tional language
L_DANISH	Outputs text only for Danish conversational language
L_FINNISH	Outputs text only for Finnish conversational language
L_DUTCH	Outputs text only for Dutch conversational language
L_POLISH	Outputs text only for Polish conversational language
L_HUNGARIA	Outputs text only for Hungarian conversa- tional language
L_CHINESE	Outputs text only for Chinese conversation- al language
L_CHINESE_TRAD	Outputs text only for Chinese (traditional) conversational language
L_SLOVENIAN	Outputs text only for Slovenian conversa- tional language
L_NORWEGIAN	Outputs text only for Norwegian conversa- tional language
L_ROMANIAN	Outputs text only for Romanian conversa- tional language
L_SLOVAK	Outputs text only for Slovakian conversa- tional language
L_TURKISH	Outputs text only for Turkish conversational language
L_ALL	Display text independently of the conversa- tional language
HOUR	Number of hours from the real-time clock
MIN	Number of minutes from the real-time clock
SEC	Number of seconds from the real-time clock
DAY	Day from the real-time clock
MONTH	Month as a number from the real-time clock
STR_MONTH	Month as a string abbreviation from the real-time clock
YEAR2	Two-digit year from the real-time clock

Keyword	Function
YEAR4	Four-digit year from the real-time clock

Example

Example of a text file to define the output format:

"MEASURING LOG OF IMPELLER CENTER OF GRAVITY";

"DATUM: %02d.%02d.%04d",DAY,MONTH,YEAR4;

"TIME: %02d:%02d:%02d",HOUR,MIN,SEC;

"NO. OF MEASURED VALUES: = 1";

"X1 = %9.3F", Q31;

"Y1 = %9.3F", Q32;

"Z1 = %9.3F", Q33;

L_GERMAN;

"Werkzeuglänge beachten";

L_ENGLISH;

"Remember the tool length";

Example

Example of a text file that outputs a log file of variable length:

"MEASURING LOG";

"%S",QS1;

M_EMPTY_HIDE;

"%S",QS2;

"%S",QS3;

M_EMPTY_SHOW;

"%S",QS4;

M_CLOSE;

Example of an NC program that defines only QS3:

95 Q1 = 100 96 QS3 = "Pos 1: " || TOCHAR(DAT+Q1) 97 FN 16: F-PRINT TNC:\fn16.a / SCREEN:

Example of a screen output with two empty lines resulting from **QS1** and **QS4**:

FN16-PRINT Pos1:100 OK

Activating FN 16 output in an NC program

Within the $\ensuremath{\text{FN}}$ 16 you specify the output file that contains the texts to be output.

The control generates the output file:

- at the end of the program (END PGM),
- if a program is canceled (NC STOP key)
- as a result of the command **M_CLOSE**

Press the Q key.

Enter the path of the source and the path of the output file in the FN 16 function .

Proceed as follows:

Q	
DIVERSE	
FUNCTION	
FN16	1
F-PRINT	
SELECT	1
FILE	
ENT	

I)

Press the DIVERSE FUNCTION soft key

Press the FN16 F-PRINT soft key

- Press the SELECT FILE soft key
- Select the source, i.e. the text file in which the output file is defined
- Confirm with the ENT key
 - Enter the output path.

If the called file is located in the same directory as the file you are calling it from, you can also integrate the file name without the path. The **APPLY FILE NAME** soft key provided in the selection window of the **SELECT FILE** soft key is available for this.

Path entries in the FN 16 function

If you enter only the file name as the path for the log file, the control saves the log file in the directory in which the NC program with the **FN 16** function is located.

Program relative paths as an alternative to complete paths:

- Starting from the folder of the calling file one folder level down FN 16: F-PRINT MASKE\MASKE1.A/ PROT\PROT1.TXT
- Starting from the folder of calling file one folder level up and in another folder FN 16: F-PRINT ... \MASKE\MASKE1.A/ .. \PROT1.TXT



Operating and programming notes:

- If you output the same file more than once in the NC program, the control appends the current output to the end of the contents already output within the target file.
- In the FN 16 block, program the format file and the log file, each with the extension for the file type.
- The file name extension of the log file determines the file type of the output (e.g., TXT, A, XLS, HTML).
- Use FN 18 to receive much information that is relevant and interesting in log files, such as the number of the touch-probe cycle last used.
 Further information: "FN 18: SYSREAD – Reading system data", Page 299

Enter the source or the target with parameters

You can enter the source file and the output file as Q parameters or as QS parameters. For this purpose you previously define the desired parameter in the NC program.

Further information: "Assigning string parameters", Page 305

Enter Q parameters in the **FN 16** function with the following syntax so that the control can detect the Q parameters:

Input	Function
:'QS1'	Set QS parameters with preceding colon and between single quotation marks
:'QL3'.tx	t Specify additional file name extension for the target file if required
0	If you want to output a path with a QS parameter to a log file, then use the function %RS . This ensures that the control does not interpret the special characters as formatting characters.

Example

96 FN 16: F-PRINT TNC:\MASKE\MASKE1.A/ TNC:\PROT1.TXT

The control creates the file PROT1.TXT: MEASURING LOG OF IMPELLER CENTER OF GRAVITY DATE: July 15, 2015 TIME: 8:56:34 AM NO. OF MEASURED VALUES : = 1 X1 = 149.360 Y1 = 25.509 Z1 = 37.000 Remember the tool length

Displaying messages on the control screen

You can also use the function **FN 16: F-PRINT** to display any messages from the NC program in a pop-up window on the control screen. This makes it easy to display explanatory texts, including long texts, at any point in the NC program in a way that the user has to react to them. You can also display Q-parameter contents if the protocol description file contains such instructions.

For the message to appear on the control screen, you need only enter **SCREEN:** as the output path.

Example

i

96 FN 16: F-PRINT TNC:\MASKE\MASKE1.A/SCREEN:

If the message has more lines than fit in the pop-up window, you can use the arrow keys to page in the window.

If you output the same file more than once in the NC program, the control appends the current output to the end of the contents already output within the target file.

If you want to overwrite the previous pop-up window, program the function **M_CLOSE** or **M_TRUNCATE**.

Closing the pop-up window

You can close the pop-up window in the following ways:

- Press the CE key
- Controlled by the program with the output path sclr:

Example

96 FN 16: F-PRINT TNC:\MASKE\MASKE1.A/SCLR:

Exporting messages

With the **FN 16** function you can also store log files externally. To do so you must enter the target path in the **FN 16** function.

Example

96 FN 16: F-PRINT TNC:\MSK\MSK1.A / PC325:\LOG\PRO1.TXT

0

If you output the same file more than once in the NC program, the control appends the current output to the end of the contents already output within the target file.

Printing messages

You can also use the function **FN 16: F-PRINT** to print any messages on a connected printer.

Further information: User's Manual for Setup, Testing and Running NC Programs

In order for the messages to be sent to the printer, you must enter **Printer:** as the name of the log file and then enter the corresponding file name.

The control saves the file in the **PRINTER:** path until the file is printed.

Example

96 FN 16: F-PRINT TNC:\MASKE\MASKE1.A/PRINTER:\DRUCK1

FN 18: SYSREAD – Reading system data

With the **FN 18: SYSREAD** function, you can read system data and save them to Q parameters. The selection of the system datum occurs via a group number (ID no.), a system data number, and, if necessary, an index.

6

The read values of the function **FN 18: SYSREAD** are always output by the control in **metric** units regardless of the NC program's unit of measure.

As an alternative, you can use **TABDATA READ** to read out data from the active tool table. In this case, the control will automatically convert the table values to the unit of measure used in the NC program.

Further information: "System data", Page 526

Example: Assign the value of the active scaling factor for the Z axis to Q25.

55 FN 18: SYSREAD Q25 = ID210 NR4 IDX3

FN 19: PLC – Transferring values to the PLC

NOTICE

Danger of collision!

Changes to the PLC can result in undesired behavior and serious errors (e.g., inoperability of the control). For this reason, access to the PLC is protected by password. This function provides HEIDENHAIN as well as your machine tool builder and suppliers with the ability to communicate with the PLC from an NC program. It is not recommended for the machine operator or NC programmer to use this function. There is risk of collision during the execution of the function and during the subsequent machining!

- Only use the function in consultation with HEIDENHAIN, the machine tool builder, or the supplier.
- Comply with the documentation from HEIDENHAIN, the machine tool builder, and suppliers.

The **FN 19: PLC** function transfers up to two numerical values or Q parameters to the PLC.

FN 20: WAIT FOR – NC and PLC synchronization

NOTICE

Danger of collision!

Changes to the PLC can result in undesired behavior and serious errors (e.g., inoperability of the control). For this reason, access to the PLC is protected by password. This function provides HEIDENHAIN as well as your machine tool builder and suppliers with the ability to communicate with the PLC from an NC program. It is not recommended for the machine operator or NC programmer to use this function. There is risk of collision during the execution of the function and during the subsequent machining!

- Only use the function in consultation with HEIDENHAIN, the machine tool builder, or the supplier.
- Comply with the documentation from HEIDENHAIN, the machine tool builder, and suppliers.

With the **FN 20: WAIT FOR** function you can synchronize the NC and PLC during a program run. The NC stops machining until the condition that you have programmed in the **FN 20: WAIT FOR** block is fulfilled.

SYNC is used whenever you read, for example, system data via **FN 18: SYSREAD** that require synchronization with real time. The control stops the look-ahead calculation and executes the following NC block only when the NC program has actually reached that NC block.

Example: Pause internal look-ahead calculation, read current position in the X axis

32 FN 20: WAIT FOR SYNC

33 FN 18: SYSREAD Q1 = ID270 NR1 IDX1

FN 29: PLC – Transferring values to the PLC

NOTICE

Danger of collision!

Changes to the PLC can result in undesired behavior and serious errors (e.g., inoperability of the control). For this reason, access to the PLC is protected by password. This function provides HEIDENHAIN as well as your machine tool builder and suppliers with the ability to communicate with the PLC from an NC program. It is not recommended for the machine operator or NC programmer to use this function. There is risk of collision during the execution of the function and during the subsequent machining!

- Only use the function in consultation with HEIDENHAIN, the machine tool builder, or the supplier.
- Comply with the documentation from HEIDENHAIN, the machine tool builder, and suppliers.

The **FN 29: PLC** function transfers up to eight numerical values or Q parameters to the PLC.

FN 37: EXPORT

NOTICE

Danger of collision!

Changes to the PLC can result in undesired behavior and serious errors (e.g., inoperability of the control). For this reason, access to the PLC is protected by password. This function provides HEIDENHAIN as well as your machine tool builder and suppliers with the ability to communicate with the PLC from an NC program. It is not recommended for the machine operator or NC programmer to use this function. There is risk of collision during the execution of the function and during the subsequent machining!

- Only use the function in consultation with HEIDENHAIN, the machine tool builder, or the supplier.
- Comply with the documentation from HEIDENHAIN, the machine tool builder, and suppliers.

You need the **FN 37: EXPORT** function if you want to create your own cycles and integrate them in the control.

FN 38: SEND – Send information from the NC program

The function **FN 38: SEND** enables you to retrieve texts and Q parameter values from the NC program and write them to the log or send them to an external application, e.g. the StateMonitor.

The syntax consists of two parts:

Format of transmitted text: Output text with optional placeholders for variable values (e.g., %f)



Input may be in the form of QS parameters. Placeholders are case-sensitive, so make sure to enter them correctly.

Datum for placeholder in text: List of max. seven Q, QL, or QR variables (e.g., Q1)

Data transmission is through a standard TCP/IP computer network.



For more detailed information, consult the RemoTools SDK manual.

Example

Document the values from Q1 and Q23 in the log.

FN 38: SEND /"Q-Parameter Q1: %f Q23: %f" / +Q1 / +Q23

Example

Define the output format for the variable values.

FN 38: SEND /"Q-Parameter Q1: %05.1f" / +Q1

The control outputs the variable value as a five-digit number, of which one digit is a decimal place. The output will be padded with leading zeroes as needed.

FN 38: SEND /"Q-Parameter Q1: % 1.3f" / +Q1

The control outputs the variable value as a seven-digit number, of which three digits are decimal places. The output will be padded with blank spaces as needed.



To obtain **%** in the output text, enter **%%** at the desired position.

Example

i)

Send information to the StateMonitor.

With function **FN 38**, you can enter job data, among others. This requires a job that has been created in StateMonitor and an assignment to the machine tool being used.

Job management with the JobTerminal (option 4) is possible with StateMonitor version 1.2 or higher.

Requirements:

- Job number 1234
- Working step 1

FN 38: SEND /"JOB:1234_STEP:1_CREATE"	Create job
FN 38: SEND /"JOB:1234_STEP:1_CREATE_ITEMNAME: HOLDER_ITEMID:123_TARGETQ:20"	Alternative: Create job with part name, part number, and required quantity
FN 38: SEND /"JOB:1234_STEP:1_START"	Start job
FN 38: SEND /"JOB:1234_STEP:1_PREPARATION"	Start preparation
FN 38: SEND /"JOB:1234_STEP:1_PRODUCTION"	Production
FN 38: SEND /"JOB:1234_STEP:1_STOP"	Stop job
FN 38: SEND /"JOB:1234_STEP:1_ FINISH"	Finish job

In addition, the workpiece quantities for the job can be reported.

With the **OK**, **S**, and **R** placeholders, you can specify whether the quantity of reported workpieces has been machined correctly or not.

The **A** and **I** placeholders allow you to define how StateMonitor interprets the response. If absolute values are transferred, then StateMonitor overwrites the previously valid values. In the case of incremental values, StateMonitor increments the quantity.

FN 38: SEND /"JOB:1234_STEP:1_OK_A:23"	Actual amount (OK) absolute
FN 38: SEND /"JOB:1234_STEP:1_OK_I:1"	Actual amount (OK) incremental
FN 38: SEND /"JOB:1234_STEP:1_S_A:12"	Scrap (S) absolute
FN 38: SEND /"JOB:1234_STEP:1_S_I:1"	Scrap (S) incremental
FN 38: SEND /"JOB:1234_STEP:1_R_A:15"	Rework (R) absolute
FN 38: SEND /"JOB:1234_STEP:1_R_I:1"	Rework (R) incremental

9.10 String parameters

String processing functions

You can use the **QS** parameters to create variable character strings. You can output such character strings for example through the **FN 16:F-PRINT** function to create variable logs.

You can assign a linear sequence of characters (letters, numbers, special characters and spaces) up to a length of 255 characters to a string parameter. You can also check and process the assigned or imported values using the functions described below. As in Q parameter programming, you can use a total of 2000 QS parameters.

Further information: "Principle and overview of functions", Page 262

The **STRING FORMULA** and **FORMULA** Q parameter functions contain various functions for processing the string parameters.

Soft key	Functions of the STRING FORMULA	Page
DECLARE	Assigning string parameters	305
CFGREAD	Read out machine parameter	314
STRING FORMULA	Chain-linking string parameters	306
TOCHAR	Converting a numerical value to a string parameter	307
SUBSTR	Copy a substring from a string parameter	308
SYSSTR	Read system data	309

Soft key	Formula string functions	Page
TONUMB	Converting a string parameter to a numerical value	310
INSTR	Checking a string parameter	311
STRLEN	Finding the length of a string parameter	312
STRCOMP	Compare alphabetic priority	313

When you use the **STRING FORMULA** function, the result of the performed arithmetic operation is always a string. When you use the **FORMULA** function, the result of the performed arithmetic operation is always a numeric value.

Assigning string parameters

Before using string variables, you must first assign the variables. Use the **DECLARE STRING** command to do so.



Press the SPEC FCT key



- Press the PROGRAM FUNCTIONS soft key
- Press the STRING FUNCTIONS soft key



Press the DECLARE STRING soft key

Example

37 DECLARE STRING QS10 = "Workpiece"

Chain-linking string parameters

With the concatenation operator (string parameter || string parameter) you can make a chain of two or more string parameters.

Press the SPEC FCT key

UNCTIONS
STRING
UNCTIONS
STRING
FORMULA

- Press the PROGRAM FUNCTIONS soft key
- Press the STRING FUNCTIONS soft key
- Press the STRING FORMULA soft key
- Enter the number of the string parameter in which the control is to save the concatenated string. Confirm with the ENT key.
- Enter the number of the string parameter in which the **first** substring is saved. Confirm with the **ENT** key
- > The control shows the concatenation symbol ||
- Press the ENT key
- Enter the number of the string parameter in which the second substring is saved. Confirm with the ENT key
- Repeat the process until you have selected all the required substrings. Conclude with the END key

Example: QS10 is to include the complete text of QS12, QS13 and QS14 $\,$

37 QS10 = QS12 || QS13 || QS14

Parameter contents:

- QS12: Workpiece
- QS13: Status:
- QS14: Scrap
- QS10: Workpiece Status: Scrap

Converting a numerical value to a string parameter

With the **TOCHAR** function, the control converts a numerical value into a string parameter. This enables you to chain numerical values with string variables.



Show the soft-key row with special functions

- FUNCTIONS STRING FUNCTIONS
- Press the String functions soft key

Open the function menu



TOCHAR

- Press the STRING FORMULA soft key
- Select the function for converting a numerical value to a string parameter
- Enter the number or the desired Q parameter to be converted by the control, and confirm with the ENT key
- If desired, enter the number of digits after the decimal point that the control should convert, and confirm with the ENT key
- Close the parenthetical expression with the ENT key and confirm your entry with the END key

Example: Convert parameter Q50 to string parameter QS11, use 3 decimal places

37 QS11 = TOCHAR (DAT+Q50 DECIMALS3)

Copying a substring from a string parameter

The **SUBSTR** function copies a definable range from a string parameter.

SPEC FCT	Show the soft-key row with special functions
PROGRAM	 Open the function menu
STRING FUNCTIONS	 Press the String functions soft key
STRING	Press the STRING FORMULA soft key
FORMULA	Enter the number of the string parameter in which the control is to save the character string. Confirm with the ENT key.
	Select the function for cutting out a substring
SUBSTR	 Enter the number of the QS parameter from which the substring is to be copied. Confirm with the ENT key
	 Enter the number of the place starting from which to copy the substring, and confirm with the ENT key
	 Enter the number of characters to be copied, and confirm with the ENT key
	Close the parenthetical expression with the ENT key and confirm your entry with the END key
A	The first character of a text string starts internally at the
	0-position

Example: A four-character substring (LEN4) is read from the string parameter QS10 beginning with the third character (BEG2)

37 QS13 = SUBSTR (SRC_QS10 BEG2 LEN4)

Reading system data

With the function **SYSSTR** you can read system data and store them in string parameters. You select the system data through a group number (ID) and a number.

Entering IDX and DAT is not required.

Group name, ID no.	Number	Meaning	
Program information, 10010	1	Path of the current main program or pallet program	
	2	Path of the NC program shown in the block display	
	3	Path of the cycle selected with CYCL DEF 12 PGM CALL	
	10	Path of the NC program selected with SEL PGM	
Channel data, 10025	1	Channel name	
Values programmed in the tool call, 10060	1	Tool name	
Current system time, 10321	1 to 16, 20	 1: DD.MM.YYYY hh:mm:ss 2 and 16: DD.MM.YYYY hh:mm 3: DD.MM.YY hh:mm 4: YYYY-MM-DD hh:mm:ss 5 and 6: YYYY-MM-DD hh:mm 7: YY-MM-DD hh:mm 8 and 9: DD.MM.YYYY 10: DD.MM.YY 11: YYYY-MM-DD 12: YY-MM-DD 12: YY-MM-DD 13 and 14: hh:mm:ss 15: hh:mm 20: XX "XX" stands for the two-digit number of the current calendar week that—in accordance with ISO 8601 —is characterized by the following: It comprises seven days It begins with Monday It is numbered sequentially The first calendar week (week 01) is the week with the first Thursday of the Gragorian work 	
Touch-probe data, 10350	50	with the first Thursday of the Gregorian year. Probe type of the active touch probe TS	
	70	Probe type of the active touch probe TS	
	73	Key name of the active touch probe TT from MP activeTT	
Data for pallet machining, 10510	1	Name of the pallet being machined	
	2	Path of the selected pallet table	
NC software version, 10630	10	Version identifier of the NC software version	

Group name, ID no.	Number	Meaning
Tool data, 10950	1	Tool name
	2	DOC entry of the tool
	4	Tool-carrier kinematics

Converting a string parameter to a numerical value

The **TONUMB** function converts a string parameter to a numerical value. The value to be converted should be only numerical.

0	The QS parameter to be converted must contain only one numerical value. Otherwise, the control will output an error message.		
٥	 Select Q parameter function 		
FORMULA	 Press the FORMULA soft key Enter the number of the string parameter in which the control is to save the numerical value. Confirm with the ENT key. Shift the soft-key row 		
TONUMB	 Select the function for converting a string parameter to a numerical value Enter the number of the QS parameter to be converted by the control, and confirm with the ENT key Close the parenthetical expression with the ENT key and confirm your entry with the END key 		
Example parame	e: Convert string parameter QS11 to a numerical ter Q82		
37 Q82 = TONUMB (SRC_QS11)			

Testing a string parameter

The **INSTR** function checks whether (and where) a string parameter is contained in another string parameter.



Select Q parameter function

F	ORMULA

- Press the FORMULA soft key
- Enter the number of the Q parameter for the result and confirm with the ENT key
- The control saves the place at which the text to be searched for begins. It is saved in the parameter.
- Shift the soft-key row
- INSTR

A

 \triangleleft

- Select the function for checking a string parameter
- Enter the number of the QS parameter in which the text to be searched for is saved. Confirm with the ENT key
- Enter the number of the QS parameter to be searched for by the control, and confirm with the ENT key
- Enter the number of the place at which the control is to start search the substring, and confirm with the ENT key.
- Close the parenthetical expression with the ENT key and confirm your entry with the END key

The first character of a text string starts internally at the 0-position

If the control cannot find the required substring, it will save the total length of the string to be searched (counting starts at 1) in the result parameter.

If the substring to be searched for appears multiple times, then the control returns the first place at which it finds the substring.

Example: Search through QS10 for the text saved in parameter QS13. Begin the search at the third place.

37 Q50 = INSTR (SRC_QS10 SEA_QS13 BEG2)

Finding the length of a string parameter

The STRLEN function returns the length of the text saved in a selectable string parameter.

Q	 Select Q parameter function 		
FORMULA	 Press the FORMULA soft key Enter the number of the Q parameter in which the control is to save the ascertained string length. Confirm with the ENT key. Shift the soft-key row 		
STRLEN	 Select the function for finding the text length of a string parameter Enter the number of the QS parameter from which the control is to ascertain the length, and confirm with the ENT key Close the parenthetical expression with the ENT key and confirm your entry with the END key 		
-	e: Find the length of QS15 e = STRLEN (SRC_QS15)		
0	If the selected string parameter is not defined the control returns the result -1 .		

control returns the result -1.

Comparing alphabetic priority

The STRCOMP function compares string parameters for alphabetic priority.

٥	 Select Q parameter function 	
FORMULA	 Press the FORMULA soft key Enter the number of the Q parameter in which the control is to save the result of comparison, and confirm with the ENT key. 	
	Shift the soft-key row	
STRCOMP	 Select the function for comparing string parameters 	
	 Enter the number of the first QS parameter that the control is to compare, and confirm with the ENT key 	
	 Enter the number of the second QS parameter that the control is to compare, and confirm with the ENT key 	
	 Close the parenthetical expression with the ENT key and confirm your entry with the END key 	
A	The control returns the following results:	
	0: The compared QS parameters are identical	
	 -1: The first QS parameter precedes the second QS parameter alphabetically 	
	 +1: The first QS parameter follows the second QS parameter alphabetically 	

Example: QS12 and QS14 are compared for alphabetic priority 37 Q52 = STRCOMP (SRC_QS12 SEA_QS14)

Reading out machine parameters

With the **CFGREAD** function, you can read out machine parameters of the control as numerical values or as strings. The read-out values are always output in metric units of measure.

In order to read out a machine parameter, you must use the control's configuration editor to determine the parameter name, parameter object, and, if they have been assigned, the group name and index:

KEY_QS: Group name (key) of the machine parameter
 TAG_QS: Object name (entity) of the machine parameter
 ATR_QS: Name (attribute) of the machine parameter

IDX: Index of the machine parameter

lcon	Туре	Meaning	Example
₽ <mark>ĸ</mark>	Кеу	Group name of the machine parameter (if available)	CH_NC
₽₽ <mark>€</mark> _	Entity	Parameter object (name begins with Cfg)	CfgGeoCycle
	Attribute	Name of the machine parameter	displaySpindleErr
⊕ <mark>©</mark>]	Index	List index of a machine parameter (if available)	[0]
6		inge the display of the existing Ilt setting, the parameters are	
	Further information: Us and Running NC Progr	ser's Manual for Setup, Testing ams	
CFGREA		a machine parameter with the define a QS parameter with	
The follo	owing parameters are read	in the CFGREAD function's	

dialog:

Reading a string of a machine parameter

In order to store the content of a machine parameter as a string in a QS parameter:



Press the Q key.

STRING FORMULA

- Press the STRING FORMULA soft key
- Enter the number of the string parameter in which the control is to save the machine parameter
- Press the ENT key
- Select the CFGREAD function
- Enter the numbers of the string parameters for key, entity, and attribute
- ▶ Press the ENT key
- Enter the number for the index, or skip the dialog with NO ENT, whichever applies
- Close the parenthesized expression with the ENT key
- Press the END key to conclude entry

Example: Read as a string the axis designation of the fourth axis

Parameter settings in the configuration editor

DisplaySettings CfgDisplayData axisDisplayOrder [0] to [5]

Example

14 QS11 = ""	Assign string parameter for key
15 QS12 = "CfgDisplaydata"	Assign string parameter for entity
16 QS13 = "axisDisplay"	Assign string parameter for parameter name
17 QS1 = CFGREAD(KEY_QS11 TAG_QS12 ATR_QS13 IDX3)	Read out machine parameter

Reading a numerical value of a machine parameter

Store the value of a machine parameter as a numerical value in a Q parameter:



Select Q parameter function



Press the FORMULA soft key

- Enter the number of the Q parameter in which the control is to save the machine parameter
- ▶ Press the ENT key
- ▶ Select the **CFGREAD** function
- Enter the numbers of the string parameters for key, entity, and attribute
- ▶ Press the ENT key
- Enter the number for the index, or skip the dialog with NNO ENT, whichever applies
- Close the parenthesized expression with the ENT key
- ▶ Press the END key to conclude entry

Example: Read overlap factor as Q parameter

Parameter settings in the configuration editor

ChannelSettings

CH_NC

CfgGeoCycle

pocketOverlap

Example

14 QS11 = "CH_NC"	Assign string parameter for key
15 QS12 = "CfgGeoCycle"	Assign string parameter for entity
16 QS13 = "pocketOverlap"	Assign string parameter for parameter name
17 Q50 = CFGREAD(KEY_QS11 TAG_QS12 ATR_QS13)	Read out machine parameter

9.11 Preassigned Q parameters

The Q parameters **Q100** to **Q199** are assigned values by the control. The following types of information are assigned to the Q parameters:

- Values from the PLC
- Tool and spindle data
- Data on operating status
- Results of measurements from touch probe cycles etc.

The control saves the preassigned Q parameters **Q108** and **Q114** to **Q117** in the unit of measure used by the active NC program.

NOTICE

Danger of collision!

HEIDENHAIN cycles, manufacturer cycles and third-party functions use Q parameters. You can also program Q parameters within NC programs. If, when using Q parameters, the recommended Q parameter ranges are not used exclusively, then this can lead to overlapping (reciprocal effects) and thus cause undesired behavior. Danger of collision during machining!

- Only use Q parameter ranges recommended by HEIDENHAIN.
- Comply with the documentation from HEIDENHAIN, the machine tool builder, and suppliers.
- Check the machining sequence using a graphic simulation



You must not use preassigned Q parameters (QS parameters) between **Q100** and **Q199** (**QS100** and **QS199**) as calculation parameters in the NC programs.

Values from the PLC: Q100 to Q107

The control assigns values from the PLC to parameters ${\bf Q100}$ to ${\bf Q107}$ in an NC program.

Active tool radius: Q108

The active value of the tool radius is assigned to **Q108**. **Q108** is calculated from:

- Tool radius R (tool table or TOOL DEF block)
- Delta value DR from the tool table
- Delta value DR from the NC program (compensation table or TOOL CALL block)

Further information: "Delta values for lengths and radii", Page 124



The control remembers the current tool radius even if the power is interrupted.

Tool axis: Q109

The value of the parameter **Q109** depends on the current tool axis:

Parameter	Tool axis
Q109 = -1	No tool axis defined
Q109 = 0	X axis
Q109 = 1	Y axis
Q109 = 2	Z axis
Q109 = 6	U axis
Q109 = 7	V axis
Q109 = 8	W axis

Spindle status: Q110

The value of the parameter **Q110** depends on the M function last programmed for the spindle.

Parameter	M function
Q110 = -1	No spindle status defined
Q110 = 0	M3: Spindle ON, clockwise
Q110 = 1	M4: Spindle ON, counterclockwise
Q110 = 2	M5 after M3
Q110 = 3	M5 after M4

Coolant on/off: Q111

Parameter	M function
Q111 = 1	M8: Coolant ON
Q111 = 0	M9: Coolant OFF

Overlap factor: Q112

The control assigns **Q112** to the overlap factor for pocket milling.

Unit of measurement for dimensions in the NC program: Q113

During nesting with **PGM CALL**, the value of the parameter **Q113** depends on the dimensional data of the NC program from which the other NC programs are called.

Parameter	Parameter Dimensional data of the main program	
Q113 = 0	Metric system (mm)	
Q113 = 1	Imperial system (inch)	

Tool length: Q114

The current value for the tool length is assigned to Q114.



The control remembers the current tool length even if the power is interrupted.

Coordinates after probing during program run

The parameters **Q115** to **Q119** contain the coordinates of the spindle position at the instant of probing during programmed measurement with the 3-D touch probe. The coordinates are referenced to the preset that is active in **Manual operation** mode.

The length of the stylus and the radius of the ball tip are not compensated in these coordinates.

Parameter	Coordinate axis
Q115	X axis
Q116	Y axis
Q117	Z axis
Q118	4th axis Machine-dependent
Q119	5th axis Machine-dependent

Deviation between actual and nominal value during automatic tool measurement; for example, with the TT 160

Parameter	Deviation of actual from nominal value
Q115	Tool length
Q116	Tool radius

Tilting the working plane with workpiece angles: Coordinates calculated by the control for rotary axes

Parameter	Coordinates
Q120	A axis
Q121	B axis
Q122	C axis

Measurement results from touch probe cycles

Further information: User's Manual for Programming of Measuring Cycles for Workpieces and Tools

Parameters	Measured actual values
Q150	Angle of a straight line
Q151	Center in reference axis
Q152	Center in minor axis
Q153	Diameter
Q154	Pocket length
Q155	Pocket width
Q156	Length of the axis selected in the cycle
Q157	Position of the centerline
Q158	Angle in the A axis
Q159	Angle in the B axis
Q160	Coordinate of the axis selected in the cycle
Parameters	Measured deviation
Q161	Center in reference axis
Q162	Center in minor axis
Q163	Diameter
Q164	Pocket length
Q165	Pocket width
Q166	Measured length
Q167	Position of the centerline
Parameters	Determined space angle
Q170	Rotation about the A axis
Q171	Rotation about the B axis
Q172	Rotation about the C axis
Parameters	Workpiece status
Q180	Good
Q181	Rework
Q182	Scrap

Parameters	Tool measurement with the BLUM laser
Q190	Reserved
Q191	Reserved
Q192	Reserved
Q193	Reserved
Parameters	Reserved for internal use
Q195	Marker for cycles
Q196	Marker for cycles
Q197	Marker for cycles (machining patterns)
Q198	Number of the last active measuring cycle
Parameter value	Status of tool measurement with TT
Q199 = 0.0	Tool is within the tolerance.
Q199 = 1.0	Tool is worn (LTOL/RTOL is exceeded)
Q199 = 2.0	Tool is broken (LBREAK/RBREAK is exceeded)
Measuremen	t results from touch probe cycles 14xx
Parameters	Measured actual values
Q950	1st position in the reference axis
Q951	1st position in the minor axis
Q952	1st position in the tool axis
Q953	2nd position in the reference axis
Q954	2nd position in the minor axis
Q955	2nd position in the tool axis
Q956	3rd position in the reference axis
Q957	3rd position in the minor axis
Q958	3rd position in the tool axis
Q961	Spatial angle SPA in the WPL-CS
Q962	Spatial angle SPB in the WPL-CS
Q963	Spatial angle SPC in the WPL-CS
Q964	Angle of rotation in the I-CS
Q965	Angle of rotation in the coordinate system of the rotary table
Q966	First diameter
Q967	Second diameter

Parameters	Measured deviations
Q980	1st position in the reference axis
Q981	1st position in the minor axis
Q982	1st position in the tool axis
Q983	2nd position in the reference axis
Q984	2nd position in the minor axis
Q985	2nd position in the tool axis
Q986	3rd position in the reference axis
Q987	3rd position in the minor axis
Q988	3rd position in the tool axis
Q994	Angle in the I-CS
Q995	Angle in the coordinate system of the rotary table
Q996	First diameter
Q997	Second diameter
Parameter value	Workpiece status
Q183 = -1	Not defined
Q183 = 0	Pass
Q183 = 1	Rework
Q183 = 2	Scrap

9.12 Accessing tables with SQL statements

Introduction

If you would like to access numerical or alphanumerical content in a table or manipulate the table (e.g., rename columns or rows), then use the available SQL commands.

The syntax of the SQL commands available on the control is strongly influenced by the SQL programming language but does not conform with it entirely. In addition, the control does not support the full scope of the SQL language.



The names of tables and table columns must start with a letter and must not contain an arithmetic operator (e.g., +). Due to SQL commands, these characters can cause problems when data are input or read.



SQL functions can be tested only in the **Program run, single block**, **Program run, full sequence**, and **Positioning with Manual Data Input** operating modes.

Read- and write-accesses to individual values in a table can likewise be carried out using the functions **FN 26: TABOPEN**, **FN 27: TABWRITE**, and **FN 28: TABREAD**. **Further information:** "Freely definable tables",

HEIDENHAIN recommends that you use SQL functions instead of **FN 26**, **FN 27**, or **FN 28** in order to achieve maximum HDR hard-disk speeds for table applications and to reduce the amount of computing power used.

6

Page 396

The following terms will be used (along with others) in the following:

- "SQL command" refers to the available soft keys
- "SQL instructions" describe miscellaneous functions that are entered manually as part of the syntax
- A HANDLE in the syntax identifies a certain transaction (followed by the parameter for identification)
- A result set contains the result of the query

SQL transaction

In the NC software, table accesses occur through an SQL server. This server is controlled via the available SQL commands. The SQL commands can be defined directly in an NC program.

The server is based on a transaction model. A **transaction** consists of multiple steps that are executed together, thereby ensuring that the table entries are processed in an orderly and well-defined manner.

Example of transaction:

- Assign Q parameters to table columns for read or write access using SQL BIND
- Select data using SQL EXECUTE with the instruction SELECT
- Read, change, or add data using SQL FETCH, SQL UPDATE, or SQL INSERT
- Confirm or discard interaction using SQL COMMIT or SQL ROLLBACK
- Approve bindings between table columns and Q parameters using SQL BIND



You must conclude all transactions that have been started—even exclusively reading accesses. Concluding the transaction is the only way to ensure that changes and additions are transferred, that locks are removed, and that used resources are released.

Result set and handle

The **result set** contains a subset of a table file. It results from a **SELECT** query performed on the table.

The **result set** is created when a query is executed in the SQL server, thereby occupying resources there.

This query has the same effect as applying a filter to the table, so that only part of the data records become visible. To perform this query, the table file must be read at this point.

The SQL server assigns a **handle** to the **result set**, which enables you to identify the result set for reading or editing data and completing the transaction. The **handle** is the result of the query, which is visible in the NC program. The value 0 indicates an **invalid handle**, i.e. it was not possible to create a **result set** for that query. If no rows are found that satisfy the specified condition, an empty **result set** is created and assigned a valid **handle**.

Programming SQL commands



This function is not enabled until the code number **555343** is entered.

Press the PROGRAM FUNCTIONS soft key

You can program SQL commands in the **Programming** or **Positioning with mdi** operating modes:



Press the SPEC FCT key



SQL



Shift the soft-key row



Select the SQL command via soft key

NOTICE

Danger of collision!

Read and write accesses performed with the help of SQL commands always occur in metric units, regardless of the unit of measure selected for the table or the NC program. If, for example, you save a length from a table to a Q parameter, then the value is thereafter always in metric units. If this value is then used for the purpose of positioning in an inch program (L X +Q1800), then an incorrect position will result.

In inch programs, convert the read value prior to use

Overview of functions

Overview of soft keys

The control offers the following ways of working with SQL commands:

Soft key	Function	Page
SQL BIND	SQL BIND creates or disconnects a binding between table columns and Q or QS parameters	327
SQL Execute	SQL EXECUTE opens a transaction for selected table columns and table rows or enables the use of other SQL instructions (miscellaneous functions).	328
SQL FETCH	SQL FETCH transfers the values to the bound Q parameters	332
SQL ROLLBACK	SQL ROLLBACK discards all changes and concludes the transaction	338
SQL COMMIT	SQL COMMIT saves all changes and concludes the transaction	337
SQL UPDATE	SQL UPDATE expands the transaction to include the change of an existing row	334
SQL INSERT	SQL INSERT creates a new table row	336
SQL SELECT	SQL SELECT reads out a single value from a table and does not open any transaction	340

SQL BIND

SQL BIND links a Q parameter to a table column. The SQL commands **FETCH**, **UPDATE**, and **INSERT** evaluate this binding (assignment) during data transfer between the **result set** and the NC program.

An **SQL BIND** command without a table name or column name cancels the binding. At the latest, the binding is terminated at the end of the NC program or subprogram.

NC-Program

A

Programming notes:

- Program any number of bindings with SQL BIND..., before using the FETCH, UPDATE, or INSERT commands.
- During the read and write operations, the control considers only those columns that you have specified by means of the SELECT command. If you specify columns without a binding in the SELECT command, then the control interrupts the read or write operation with an error message.

SQL BIND Parameter no. for result: Define Q parameter for binding to the table column

- Database: column name: Define table name and table column (separate with .)
 - Table name: Synonym or path with filename of the table
 - **Column name**: Name displayed in the table editor

Example: Binding Q parameters to table columns

	11 SQL BIND Q881 "Tab_Example.Position_Nr"		
	12 SQL BIND Q882 "Tab_Example.Measure_X"		
ļ			
	13 SQL BIND Q883 "Tab Example.Measure Y"		
- !			
	14 SQL BIND Q884 "Tab_Example.Measure_Z"		
į,	Example: Remove binding		
	Example. Remove binding		
	91 SOL BIND 0881		
- 12			

91 SQL BIND Q881	
92 SQL BIND Q882	
93 SQL BIND Q883	
94 SQL BIND Q884	

SQL EXECUTE


 $\ensuremath{\textbf{SQL}}\xspace$ EXECUTE can be used in conjunction with various SQL instructions.

The following SQL instructions are used in the SQL command **SQL EXECUTE**.

InstructionFunctionSELECTSelect dataCREATE SYNONYMCreate synonym (replace long path names with short names)DROP SYNONYMDelete synonymCREATE TABLEGenerate a tableCOPY TABLECopy tableRENAME TABLERename tableDROP TABLEDelete a tableINSERTInsert table rowsUPDATEUpdate table rowsDELETEDelete table rowsALTER TABLEAdd table columns using ADD 			
CREATE SYNONYMCreate synonym (replace long path names with short names)DROP SYNONYMDelete synonymCREATE TABLEGenerate a tableCOPY TABLECopy tableRENAME TABLERename tableDROP TABLEDelete a tableINSERTInsert table rowsUPDATEUpdate table rowsDELETEDelete table rowsALTER TABLEAdd table columns using ADD	Instruction Function		
SYNONYMDelete synonymDROP SYNONYMDelete synonymCREATE TABLEGenerate a tableCOPY TABLECopy tableRENAME TABLERename tableDROP TABLEDelete a tableINSERTInsert table rowsUPDATEUpdate table rowsDELETEDelete table rowsALTER TABLEAdd table columns using ADD	SELECT	Select data	
CREATE TABLEGenerate a tableCOPY TABLECopy tableRENAME TABLERename tableDROP TABLEDelete a tableINSERTInsert table rowsUPDATEUpdate table rowsDELETEDelete table rowsALTER TABLEAdd table columns using ADD			
COPY TABLECopy tableRENAME TABLERename tableDROP TABLEDelete a tableINSERTInsert table rowsUPDATEUpdate table rowsDELETEDelete table rowsALTER TABLEAdd table columns using ADD	DROP SYNONYM	Delete synonym	
RENAME TABLE Rename table DROP TABLE Delete a table INSERT Insert table rows UPDATE Update table rows DELETE Delete table rows ALTER TABLE Add table columns using ADD 	CREATE TABLE	Generate a table	
DROP TABLE Delete a table INSERT Insert table rows UPDATE Update table rows DELETE Delete table rows ALTER TABLE Add table columns using ADD	COPY TABLE	Copy table	
INSERT Insert table rows UPDATE Update table rows DELETE Delete table rows ALTER TABLE Add table columns using ADD	RENAME TABLE	Rename table	
UPDATE Update table rows DELETE Delete table rows ALTER TABLE Add table columns using ADD	DROP TABLE	Delete a table	
DELETE Delete table rows ALTER TABLE Add table columns using ADD	INSERT	Insert table rows	
ALTER TABLE Add table columns using ADD	UPDATE	Update table rows	
	DELETE	Delete table rows	
	ALTER TABLE		

RENAME COLUMN Rename table columns

Example for the SQL EXECUTE command



Remarks:

- The gray arrows and associated syntax do not directly belong to the SQL EXECUTE command
- Black arrows and associated syntax indicate internal processes of SQL EXECUTE

SQL EXECUTE with the SQL instruction SELECT

The SQL server places the data in the **result set** row-by-row. The rows are numbered in ascending order, starting with 0. These row numbers (the **INDEX**) use the SQL commands **FETCH** and **UPDATE**.

SQL EXECUTE, in conjunction with the SQL instruction **SELECT**, selects the table values, transfers them to the **result set**, and always opens a transaction in the process. Unlike the SQL command **SQL SELECT**, the combination of **SQL EXECUTE** and the **SELECT** instruction allows multiple columns and rows to be selected at the same time.

In the function **SQL** ... "**SELECT...WHERE...**", you can enter the search criteria. You thereby restrict the number of rows to be transferred. If you do not use this option, then all of the rows in the table are loaded.

In the function **SQL** ... "**SELECT...ORDER BY...**", you can enter the ordering criterion. This entry consists of the column designation and the keyword **ASC** for ascending or **DESC** for descending order. If you do not use this option, then rows will be stored in a random order.

With the function **SQL** ... "**SELECT...FOR UPDATE**", you can lock the selected rows for other applications. Other applications can continue to read these rows but are unable to change them. If you make changes to the table entries, then it is absolutely necessary to use this option.

Empty result set: If no rows meet the search criterion, then the SQL server returns a valid **HANDLE** without table entries.

SQL EXECUTE

Define Parameter number for result

- The return value serves as an identifying feature of a successfully opened transaction
- The return value is used to control the read operation

In the specified parameters, the control stores the **HANDLE** under which the read operation will subsequently occur. The **HANDLE** is valid until you confirm or reject the transaction.

- 0: Faulty read operation
- Unequal to 0: Return value of the HANDLE
- Database: SQL instruction: Program an SQL instruction
 - SELECT: Table columns to be transferred (separate multiple columns with ,)
 - FROM: Synonym or absolute path of the table (path in single quotation marks)
 - WHERE (optional): Column names, condition, and comparison value (Q parameters after : in single quotation marks)
 - ORDER BY (optional): Column names and type of ordering (ASC for ascending and DESC for descending order)
 - FOR UPDATE (optional): To lock other processes from performing a write access to the selected rows

Conditions for WHERE entries

Condition	Programming
Equals	= ==
Not equal to	!= <>
Less than	<
Less than or equal to	<=
Greater than	>
Greater than or equal to	>=
empty	IS NULL
Not empty	IS NOT NULL
Linking multiple conditions:	
Logical AND	AND
Logical OR	OR

Example: selection of table rows

11 SQL BIND Q881 "Tab_Example.Position_Nr"	
12 SQL BIND Q882 "Tab_Example.Measure_X"	
13 SQL BIND Q883 "Tab_Example.Measure_Y"	
14 SQL BIND Q884 "Tab_Example.Measure_Z"	
20 SQL Q5 "SELECT Position_Nr,Measure_X,Measure_Y, Measure_Z FROM Tab_Example"	
Example: Select table rows with the WHERE function	
20 SQL Q5 "SELECT Position_Nr,Measure_X,Measure_Y, Measure_Z FROM Tab_Example WHERE Position_Nr<20"	

Example: Select table rows with the WHERE function and Q parameter

```
20 SQL Q5 "SELECT Position_Nr,Measure_X,Measure_Y,
Measure_Z FROM Tab_Example WHERE
Position_Nr==:'Q11'"
```

Example: Define the table name with absolute path information

```
20 SQL Q5 "SELECT Position_Nr,Measure_X,Measure_Y,
Measure_Z FROM 'V:\table\Tab_Example' WHERE
Position_Nr<20"
```

Example: Generate a table with CREATE TABLE

0 BEGIN PGM SQL_CREATE_TAB MM	
1 SQL Q10 "CREATE SYNONYM NEW FOR 'TNC:\table \NewTab.TAB'"	Create synonym
2 SQL Q10 "CREATE TABLE NEW AS SELECT X,Y,Z FROM 'TNC:\prototype_for_NewTab.tab'"	Create table
3 END PGM SQL_CREATE_TAB MM	

6

You can also define synonyms for tables that have not yet been generated.

i	

The sequence of the columns in the created file corresponds to the sequence within the **AS SELECT** instruction.

Example: Generate a table with CREATE TABLE and QS

For the instructions within the SQL command, you can likewise use single or combined QS parameters. If you check the content of a QS parameter in the additional status indicator (**QPARA** tab), then you will see only the first 30 characters and therefore not the complete content.

0 BEGIN PGM SQL_CREATE_TABLE_QS MM

- 1 DECLARE STRING QS1 = "CREATE TABLE "
- 2 DECLARE STRING QS2 = "'TNC:\nc_prog\demo\Doku \NewTab.t' "
- 3 DECLARE STRING QS3 = "AS SELECT "
- 4 DECLARE STRING QS4 = "DL,R,DR,L "
- 5 DECLARE STRING QS5 = "FROM "
- 6 DECLARE STRING QS6 = "'TNC:\table\tool.t"
- 7 QS7 = QS1 || QS2 || QS3 || QS4 || QS5 || QS6
- 8 SQL Q1800 QS7
- 9 END PGM SQL_CREATE_TABLE_QS MM

Examples

The following examples do not result in a cohesive NC program. The NC blocks show only possible uses of the SQL command **SQL EXECUTE**.


9 SQL Q1800 "CREATE SYNONYM my_table FOR 'TNC:- \table\WMAT.TAB'"	Create synonym
9 SQL Q1800 "DROP SYNONYM my_table"	Delete synonym
9 SQL Q1800 "CREATE TABLE my_table (NO,WMAT)"	Create table with the rows NO and WMAT.
9 SQL Q1800 "COPY TABLE my_table TO 'TNC:\table- \WMAT2.TAB'"	Copy table
9 SQL Q1800 "RENAME TABLE my_table TO 'TNC:\table- \WMAT3.TAB'"	Rename table
9 SQL Q1800 "DROP TABLE my_table"	Delete the table
9 SQL Q1800 "INSERT INTO my_table VALUES (1,'ENAW',240)"	Insert table row
9 SQL Q1800 "DELETE FROM my_table WHERE NR==3"	Delete table row
9 SQL Q1800 "ALTER TABLE my_table ADD (WMAT2)"	Insert table rows
9 SQL Q1800 "ALTER TABLE my_table DROP (WMAT2)"	Delete table row
9 SQL Q1800 "RENAME COLUMN my_table (WMAT2) TO (WMAT3)"	Rename table column

SQL FETCH

SQL FETCH reads a row from the **result set**. The values of the individual cells are stored by the control in the bound Q parameters. The transaction is defined through the **HANDLE** to be specified, and the row is defined by the **INDEX**.

SQL FETCH takes all of the columns into consideration that contain the **SELECT** instruction (SQL command **SQL EXECUTE**).

Example for the SQL FETCH command



Remarks:

- The gray arrows and associated syntax do not directly belong to the SQL FETCH command
- Black arrows and associated syntax indicate internal processes of SQL FETCH



- Define Parameter number for result (return values for the control):
 - 0: Successful read operation
 - **1**: Faulty read operation
- Database: SQL access ID: Define Q parameter for the HANDLE (for identifying the transaction)
- Define Database: Index for SQL result (row number within the result set)
 - Row number
 - Q parameter with the index
 - None defined: access to row 0

The optional syntax elements **IGNORE UNBOUND** and **UNDEFINE MISSING** are intended for the machine manufacturer.

Example: Transfer row number in the Q parameter

11 SQL BIND Q881 "Tab_Example.Position_Nr"

12 SQL BIND Q882 "Tab_Example.Measure_X"

13 SQL BIND Q883 "Tab_Example.Measure_Y"

14 SQL BIND Q884 "Tab_Example.Measure_Z"

• • •

20 SQL Q5 "SELECT Position_Nr,Measure_X,Measure_Y, Measure_Z FROM Tab_Example"

•••

30 SQL FETCH Q1 HANDLE Q5 INDEX+Q2

Example: Program the row number directly


30 SQL FETCH Q1 HANDLE Q5 INDEX5

SQL UPDATE

SQL UPDATE changes a row in the **result set**. The new values of the individual cells are copied by the control from the bound Q parameters. The transaction is defined through the **HANDLE** to be specified, and the row is defined by the **INDEX**. The control completely overwrites the already existing rows in the **result set**.

SQL UPDATE takes all of the columns into consideration that contain the **SELECT** instruction (SQL command **SQL EXECUTE**).

Example for the SQL UPDATE command



The gray arrows and associated syntax do not directly belong to the SQL UPDATE

Black arrows and associated syntax show internal processes of SQL UPDATE



- Define Parameter number for result (return values for the control):
 - **0**: Change was successful
 - 1: Change failed
- Database: SQL access ID: Define Q parameter for the HANDLE (for identifying the transaction)
- Define Database: Index for SQL result (row number within the result set)
 - Row number
 - Q parameter with the index
 - None defined: access to row 0

When writing to tables, the control checks the lengths of the string parameters. If the entries exceed the length of the columns to be described, then the control outputs an error message.

Example: Transfer row number in the Q parameter

11 SQL BIND Q881 "TAB_EXAMPLE.Position_NR"

12 SQL BIND Q882 "TAB_EXAMPLE.Measure_X"

13 SQL BIND Q883 "TAB_EXAMPLE.Measure_Y"

```
14 SQL BIND Q884 "TAB_EXAMPLE.Measure_Z"
```

```
• • •
```

```
20 SQL Q5 "SELECT
```

Position_NR,Measure_X,Measure_Y,Measure_Z FROM TAB_EXAMPLE"

•••

30 SQL FETCH Q1 HANDLE Q5 INDEX+Q2

Example: Program the row number directly


40 SQL UPDATE Q1 HANDLE Q5 INDEX5

SQL INSERT

SQL INSERT creates a new row in the **result set**. The values of the individual cells are copied by the control from the bound Q parameters. The transaction is defined via the **HANDLE** to be specified.

SQL INSERT takes all of the columns into consideration that contain the **SELECT** instruction (SQL command **SQL EXECUTE**). Table columns without a corresponding **SELECT** instruction (not contained in the query result) are described by the control with default values.

Example for the SQL INSERT command



Remarks:

- The gray arrows and associated syntax do not directly belong to the SQL INSERT command
- Black arrows and associated syntax indicate internal processes of SQL INSERT



Define Parameter number for result (return values for the control):

- **0**: Transaction successful
- **1**: Transaction failed
- Database: SQL access ID: Define Q parameter for the HANDLE (for identifying the transaction)



When writing to tables, the control checks the lengths of the string parameters. If the entries exceed the length of the columns to be described, then the control outputs an error message.

Example: Transfer row number in the Q parameter


11 SQL BIND Q881 "Tab_Example.Position_Nr"	
12 SQL BIND Q882 "Tab_Example.Measure_X"	
13 SQL BIND Q883 "Tab_Example.Measure_Y"	
14 SQL BIND Q884 "Tab_Example.Measure_Z"	
20 SQL Q5 "SELECT Position_Nr,Measure_X,Measure_Y, Measure_Z FROM Tab_Example"	
40 SQL INSERT Q1 HANDLE Q5	

SQL COMMIT

SQL COMMIT simultaneously transfers all of the rows that have been changed and added in a transaction back into the table. The transaction is defined via the **HANDLE** to be specified. In this context, a lock that has been set with **SELECT...FOR UPDATE** resets the control.

The assigned **HANDLE** (operation) loses its validity.

Example for the SQL COMMIT command



Remarks:

- The gray arrows and associated syntax do not directly belong to the SQL COMMIT command
- Black arrows and associated syntax indicate internal processes of SQL COMMIT



- Define Parameter number for result (return values for the control):
 - **0**: Transaction successful
 - 1: Transaction failed
- Database: SQL access ID: Define Q parameter for the HANDLE (for identifying the transaction)

Example

11 SQL BIND Q881 "Tab_Example.Position_Nr"	
12 SQL BIND Q882 "Tab_Example.Measure_X"	
13 SQL BIND Q883 "Tab_Example.Measure_Y"	
14 SQL BIND Q884 "Tab_Example.Measure_Z"	
20 SQL Q5 "SELECT Position_Nr,Measure_X,Measure_Y, Measure_Z FROM Tab_Example"	
30 SQL FETCH Q1 HANDLE Q5 INDEX+Q2	
40 SQL UPDATE Q1 HANDLE Q5 INDEX+Q2	
50 SQL COMMIT Q1 HANDLE Q5	


SQL ROLLBACK

SQL ROLLBACK discards all of the changes and additions of a transaction. The transaction is defined via the **HANDLE** to be specified.

The function of the SQL command $\ensuremath{\text{SQL ROLLBACK}}$ depends on the $\ensuremath{\text{INDEX}}$:

- Without INDEX:
 - The control discards all changes and additions of the transaction
 - The control resets a lock set with **SELECT...FOR UPDATE**
 - The control completes the transaction (the HANDLE loses its validity)
- With **INDEX**:
 - Only the indexed row remains in the result set (the control removes all of the other rows)
 - The control discards any changes and additions that may have been made in the non-specified rows
 - The control locks only those rows indexed with SELECT...FOR UPDATE (the control resets all of the other locks)
 - The specified (indexed) row is then the new Row 0 of the result set
 - The control does **not** complete the transaction (the **HANDLE** keeps its validity)
 - The transaction must be completed manually with SQL ROLLBACK or SQL COMMIT at a later time

Example for the SQL ROLLBACK command



Remarks:

- The gray arrows and associated syntax do not directly belong to the SQL ROLLBACK command
- Black arrows and associated syntax indicate internal processes of SQL ROLLBACK



- Define Parameter number for result (return values for the control):
 - **0**: Transaction successful
 - **1**: Transaction failed
- Database: SQL access ID: Define Q parameter for the HANDLE (for identifying the transaction)
- Define Database: Index for SQL result (row that remains in the result set)
 - Row number
 - Q parameter with the index

Example

11 SOL	BIND 0881	"Tab	_Example.Position_	Nr'
		IUD_	_Example.r osicion_	

12 SQL BIND Q882 "Tab_Example.Measure_X"

13 SQL BIND Q883 "Tab_Example.Measure_Y"

14 SQL BIND Q884 "Tab_Example.Measure_Z"

• • •

20 SQL Q5 "SELECT Position_Nr,Measure_X,Measure_Y, Measure_Z FROM Tab_Example"

•••

30 SQL FETCH Q1 HANDLE Q5 INDEX+Q2

• • •

50 SQL ROLLBACK Q1 HANDLE Q5

SQL SELECT


 $\ensuremath{\textbf{SQL SELECT}}$ reads a single value from a table and saves the result in the defined Q parameter.



You can select multiple values or multiple columns using the SQL command **SQL EXECUTE** and the **SELECT** instruction. **Further information:** "SQL EXECUTE", Page 328

With **SQL SELECT**, there is neither a transaction nor a binding between the table column and Q parameter. The control does not consider any bindings that may exist to the specified column. The control copies the read value only into the parameter specified for the result.

Example for the SQL SELECT command



Remark:

Black arrows and associated syntax show internal processes of SQL SELECT



- Define Parameter number for result (Q parameter for saving the value)
- Database: SQL command text: Program the SQL instruction
 - SELECT: Table column of the value to be transferred
 - FROM: Synonym or absolute path of the table (path in single quotation marks)
 - WHERE: Column designation, condition, and comparison value (Q parameter after : in single quotation marks)

Example: Read and save a value

```
20 SQL SELECT Q5 "SELECT Mess_X FROM Tab_Example
WHERE Position_NR==3"
```

Comparison

The results of the following NC programs are identical.

0 BEGIN PGM SQL_READ_WMAT MM	
1 SQL Q1800 "CREATE SYNONYM my_table FOR 'TNC: \table\WMAT.TAB'"	Create synonym
2 SQL BIND QS1800 "my_table.WMAT"	Bind QS parameters
3 SQL QL1 "SELECT WMAT FROM my_table WHERE NR==3"	Define search
3 SQL SELECT QS1800 "SELECT WMAT FROM my_table WHERE NR==3"	Read and save a value
For the instructions within the SQL command, y likewise use single or combined QS parameters If you check the content of a QS parameter in the additional status indicator (QPARA tab), then you see only the first 30 characters and therefore no complete content.	ne i will
3 DECLARE STRING QS1 = "SELECT "	
4 DECLARE STRING QS2 = "WMAT "	
5 DECLARE STRING QS3 = "FROM "	
6 DECLARE STRING QS4 = "my_table "	
7 DECLARE STRING QS5 = "WHERE "	
8 DECLARE STRING QS6 = "NR==3"	
9 QS7 = QS1 QS2 QS3 QS4 QS5 QS6	
10 SQL SELECT QL1 QS7	
11	

Examples

In the following example, the defined material is read from the table (**WMAT.TAB**) and is stored as a text in a QS parameter. The following example shows a possible application and the necessary program steps.



You can use the **FN 16** function, for example, in order to reuse QS parameters in your own log files. **Further information:** "Fundamentals", Page 291

Example: Use a synonym

0 BEGIN PGM SQL_READ_WMAT MM	
1 SQL Q1800 "CREATE SYNONYM my_table FOR 'TNC:- \table\WMAT.TAB'"	Create synonym
2 SQL BIND QS1800 "my_table.WMAT"	Bind QS parameters
3 SQL QL1 "SELECT WMAT FROM my_table WHERE NO==3"	Define search
4 SQL FETCH Q1900 HANDLE QL1	Execute search
5 SQL ROLLBACK Q1900 HANDLE QL1	Complete transaction
6 SQL BIND QS1800	Remove parameter binding
7 SQL Q1 "DROP SYNONYM my_table"	Delete synonym
8 END PGM SQL_READ_WMAT MM	

St	ер	Explanation
1	Create	Assign a synonym to a path (replace long paths with short names)
	synonym	The path TNC:\table\WMAT.TAB is always placed in single quotes
		The selected synonym is my_table
2	Bind QS	Bind a QS parameter to a table column
	parameters	QS1800 is freely available in NC programs
		The synonym replaces the entry of the complete path
		The defined column from the table is called WMAT
3	Define search	A search definition contains the entry of the transfer value
		 The QL1 local parameter (freely selectable) serves to identify the transaction (multiple transactions are possible simultaneously)
		The synonym defines the table
		The WMAT entry defines the table column of the read operation
		The entries NR and ==3 define the table rows of the read operation
		 Selected table columns and rows define the cells of the read operation
4	Execute search	The control performs the read operation
		SQL FETCH copies the values from the result set into the bound Q or QS parameter
		0 successful read operation
		1 faulty read operation
		The syntax HANDLE QL1 is the transaction designated by the parameter QL1
		The parameter Q1900 is a return value for checking whether the data have been read
5	Complete transaction	The transaction is concluded and the used resources are released

S	tep	Explanation
6	Remove binding	The binding between table columns and QS parameters is removed (release of necessary resources)
7	Delete synonym	The synonym is deleted again (release of necessary resources)
	Synony	rms are an alternative only to the required

The following NC program shows the entry of an absolute path.

absolute paths. Relative path entries are not possible.

Example: Use an absolute path

(I)

0 BEGIN PGM SQL_READ_WMAT_2 MM	
1 SQL BIND QS 1800 "'TNC:\table\WMAT.TAB'.WMAT"	Bind QS parameters
2 SQL QL1 "SELECT WMAT FROM 'TNC:\table\WMAT.TAB' WHERE NR ==3"	Define search
3 SQL FETCH Q1900 HANDLE QL1	Execute search
4 SQL ROLLBACK Q1900 HANDLE QL1	Complete transaction
4 SQL ROLLBACK Q1900 HANDLE QL1 5 SQL BIND QS 1800	

9.13 Programming examples

Example: Rounding a value

The **INT** function truncates the decimal places.

In order for the control to round correctly, rather than simply truncating the decimal places, add the value 0.5 to a positive number. For a negative number you must subtract 0.5.


The control uses the **SGN** function to detect whether a number is positive or negative.

0 BEGIN PGM ROUND MM	
1 FN 0: Q1 = +34.789	First number to be rounded
2 FN 0: Q2 = +34.345	Second number to be rounded
3 FN 0: Q3 = -34.432	Third number to be rounded
4;	
5 Q11 = INT (Q1 + 0.5 * SGN Q1)	Add the value 0.5 to Q1, then truncate the decimal places
6 Q12 = INT (Q2 + 0.5 * SGN Q2)	Add the value 0.5 to Q2, then truncate the decimal places
7 Q13 = INT (Q3 + 0.5 * SGN Q3)	Subtract the value 0.5 from Q3, then truncate the decimal places
8 END PGM ROUND MM	

Example: Ellipse

Program run

- The contour of the ellipse is approximated by many short line segments (defined in Q7). The more calculation steps you define for the lines, the smoother the curve becomes.
- The milling direction is determined with the starting angle and end angle in the plane: Machining direction is clockwise: Starting angle > end angle Machining direction is counterclockwise: Starting angle < end angle
- The tool radius is not taken into account




0 BEGIN PGM ELLIPSE MM	
1 FN 0: Q1 = +50	Center in X axis
2 FN 0: Q2 = +50	Center in Y axis
3 FN 0: Q3 = +50	Semiaxis in X
4 FN 0: Q4 = +30	Semiaxis in Y
5 FN 0: Q5 = +0	Starting angle in the plane
6 FN 0: Q6 = +360	End angle in the plane
7 FN 0: Q7 = +40	Number of calculation steps
8 FN 0: Q8 = +0	Rotational position of the ellipse
9 FN 0: Q9 = +5	Milling depth
10 FN 0: Q10 = +100	Feed rate for plunging
11 FN 0: Q11 = +350	Feed rate for milling
12 FN 0: Q12 = +2	Set-up clearance for pre-positioning
13 BLK FORM 0.1 Z X+0 Y+0 Z-20	Workpiece blank definition
14 BLK FORM 0.2 X+100 Y100 Z+0	
15 TOOL CALL 1 Z S4000	Tool call
16 L Z+250 R0 FMAX	Retract the tool
17 CALL LBL 10	Call machining operation
18 L Z+100 R0 FMAX M2	Retract the tool, end program
19 LBL 10	Subprogram 10: Machining operation
20 CYCL DEF 7.0 DATUM SHIFT	Shift datum to center of ellipse
21 CYCL DEF 7.1 X+Q1	
22 CYCL DEF 7.2 Y+Q2	
23 CYCL DEF 10.0 ROTATION	Account for rotational position in the plane
24 CYCL DEF 10.1 ROT+Q8	
25 Q35 = (Q6 -Q5) / Q7	Calculate angle increment
26 Q36 = Q5	Copy starting angle
27 Q37 = 0	Set counter

28 Q21 = Q3 *COS Q36	Calculate X coordinate for starting point
29 Q22 = Q4 *SIN Q36	Calculate Y coordinate for starting point
30 L X+Q21 Y+Q22 R0 FMAX M3	Move to starting point in the plane
31 L Z+Q12 R0 FMAX	Pre-position in spindle axis to set-up clearance
32 L Z-Q9 R0 FQ10	Move to working depth
33 LBL1	
34 Q36 = Q36 +Q35	Update the angle
35 Q37 = Q37 +1	Update the counter
36 Q21 = Q3 *COS Q36	Calculate the current X coordinate
37 Q22 = Q4 *SIN Q36	Calculate the current Y coordinate
38 L X+Q21 Y+Q22 R0 FQ11	Move to next point
39 FN 12: IF +Q37 LT +Q7 GOTO LBL 1	Unfinished? If not finished, return to LBL 1
40 CYCL DEF 10.0 ROTATION	Reset the rotation
41 CYCL DEF 10.1 ROT+0	
42 CYCL DEF 7.0 DATUM SHIFT	Reset the datum shift
43 CYCL DEF 7.1 X+0	
44 CYCL DEF 7.2 Y+0	
45 L Z+Q12 R0 FMAX	Move to set-up clearance
46 LBL 0	End of subprogram
47 END PGM ELLIPSE MM	

Example: Concave cylinder machined with Ball-nose cutter

Program run

- This NC program works only with a Ball-nose cutter. The tool length is measured from the sphere center
- The contour of the cylinder is approximated by many short line segments (defined in Q13). The more line segments you define, the smoother the contour becomes.
- The cylinder is milled in longitudinal cuts (here: parallel to the Y axis).
- The milling direction is determined with the starting angle and end angle in space: Machining direction clockwise: Starting angle > end angle Machining direction counterclockwise: Starting angle < end angle
- The tool radius is compensated automatically




0 BEGIN PGM CYLIN MM	
1 FN 0: Q1 = +50	Center in X axis
2 FN 0: Q2 = +0	Center in Y axis
3 FN 0: Q3 = +0	Center in Z axis
4 FN 0: Q4 = +90	Starting angle in space (Z/X plane)
5 FN 0: Q5 = +270	End angle in space (Z/X plane)
6 FN 0: Q6 = +40	Cylinder radius
7 FN 0: Q7 = +100	Length of the cylinder
8 FN 0: Q8 = +0	Rotational position in the X/Y plane
9 FN 0: Q10 = +5	Allowance for cylinder radius
10 FN 0: Q11 = +250	Feed rate for plunging
11 FN 0: Q12 = +400	Feed rate for milling
12 FN 0: Q13 = +90	Number of cuts
13 BLK FORM 0.1 Z X+0 Y+0 Z-50	Workpiece blank definition
14 BLK FORM 0.2 X+100 Y+100 Z+0	
15 TOOL CALL 1 Z S4000	Tool call
16 L Z+250 R0 FMAX	Retract the tool
17 CALL LBL 10	Call machining operation
18 FN 0: Q10 = +0	Reset allowance
19 CALL LBL 10	Call machining operation
20 L Z+100 R0 FMAX M2	Retract the tool, end program

21 LBL 10	Subprogram 10: Machining operation
22 Q16 = Q6 -Q10 - Q108	Account for allowance and tool, based on the cylinder radius
23 FN 0: Q20 = +1	Set counter
24 FN 0: Q24 = +Q4	Copy starting angle in space (Z/X plane)
25 Q25 = (Q5 -Q4) / Q13	Calculate angle increment
26 CYCL DEF 7.0 DATUM SHIFT	Shift datum to center of cylinder (X axis)
27 CYCL DEF 7.1 X+Q1	
28 CYCL DEF 7.2 Y+Q2	
29 CYCL DEF 7.3 Z+Q3	
30 CYCL DEF 10.0 ROTATION	Account for rotational position in the plane
31 CYCL DEF 10.1 ROT+Q8	
32 L X+0 Y+0 R0 FMAX	Pre-position in the plane to the cylinder center
33 L Z+5 R0 F1000 M3	Pre-position in the spindle axis
34 LBL 1	
35 CC Z+0 X+0	Set pole in the Z/X plane
36 LP PR+Q16 PA+Q24 FQ11	Move to starting position on cylinder, plunge-cutting obliquely into the material
37 L Y+Q7 R0 FQ12	Longitudinal cut in Y+ direction
38 FN 1: Q20 = +Q20 + +1	Update the counter
39 FN 1: Q24 = +Q24 + +Q25	Update solid angle
40 FN 11: IF +Q20 GT +Q13 GOTO LBL 99	Finished? If finished, jump to end
41 LP PR+Q16 PA+Q24 FQ11	Move on an approximated arc for the next longitudinal cut
42 L Y+0 R0 FQ12	Longitudinal cut in Y- direction
43 FN 1: Q20 = +Q20 + +1	Update the counter
44 FN 1: Q24 = +Q24 + +Q25	Update solid angle
45 FN 12: IF +Q20 LT +Q13 GOTO LBL 1	Unfinished? If not finished, return to LBL 1
46 LBL 99	
47 CYCL DEF 10.0 ROTATION	Reset the rotation
48 CYCL DEF 10.1 ROT+0	
49 CYCL DEF 7.0 DATUM SHIFT	Reset the datum shift
50 CYCL DEF 7.1 X+0	
51 CYCL DEF 7.2 Y+0	
52 CYCL DEF 7.3 Z+0	
53 LBL 0	End of subprogram
54 END PGM CYLIN	

Example: Convex sphere machined with end mill

Program run

- NC program requires an end mill.
- The contour of the sphere is approximated by many short line segments (in the Z/X plane, defined in Q14). The smaller you define the angle increment, the smoother the curve becomes.
- You can determine the number of contour cuts through the angle increment in the plane (defined in Q18).
- The tool moves upward in three-dimensional cuts.
- The tool radius is compensated automatically



0 BEGIN PGM SPHERE MM	
1 FN 0: Q1 = +50	Center in X axis
2 FN 0: Q2 = +50	Center in Y axis
3 FN 0: Q4 = +90	Starting angle in space (Z/X plane)
4 FN 0: Q5 = +0	End angle in space (Z/X plane)
5 FN 0: Q14 = +5	Angle increment in space
6 FN 0: Q6 = +45	Sphere radius
7 FN 0: Q8 = +0	Starting angle of rotational position in the X/Y plane
8 FN 0: Q9 = +360	End angle of rotational position in the X/Y plane
9 FN 0: Q18 = +10	Angle increment in the X/Y plane for roughing
10 FN 0: Q10 = +5	Allowance in sphere radius for roughing
11 FN 0: Q11 = +2	Set-up clearance for pre-positioning in the spindle axis
12 FN 0: Q12 = +350	Feed rate for milling
13 BLK FORM 0.1 Z X+0 Y+0 Z-50	Workpiece blank definition
14 BLK FORM 0.2 X+100 Y+100 Z+0	
15 TOOL CALL 1 Z S4000	Tool call
16 L Z+250 R0 FMAX	Retract the tool
17 CALL LBL 10	Call machining operation
18 FN 0: Q10 = +0	Reset allowance
19 FN 0: Q18 = +5	Angle increment in the X/Y plane for finishing
20 CALL LBL 10	Call machining operation
21 L Z+100 R0 FMAX M2	Retract the tool, end program
22 LBL 10	Subprogram 10: Machining operation
23 FN 1: Q23 = +q11 + +q6	Calculate Z coordinate for pre-positioning
24 FN 0: Q24 = +Q4	Copy starting angle in space (Z/X plane)
25 FN 1: Q26 = +Q6 + +Q108	Compensate sphere radius for pre-positioning
26 FN 0: Q28 = +Q8	Copy rotational position in the plane
27 FN 1: Q16 = +Q6 + -Q10	Account for allowance in the sphere radius
28 CYCL DEF 7.0 DATUM SHIFT	Shift datum to center of sphere
29 CYCL DEF 7.1 X+Q1	
30 CYCL DEF 7.2 Y+Q2	

31 CYCL DEF 7.3 Z-Q16	
32 CYCL DEF 10.0 ROTATION	Account for starting angle of rotational position in the plane
33 CYCL DEF 10.1 ROT+Q8	
34 LBL 1	Pre-position in the spindle axis
35 CC X+0 Y+0	Set pole in the X/Y plane for pre-positioning
36 LP PR+Q26 PA+Q8 R0 FQ12	Pre-position in the plane
37 CC Z+0 X+Q108	Set pole in the Z/X plane, offset by the tool radius
38 L Y+0 Z+0 FQ12	Move to working depth
39 LBL 2	
40 LP PR+Q6 PA+Q24 FQ12	Move upward on an approximated arc
41 FN 2: Q24 = +Q24 - +Q14	Update solid angle
42 FN 11: IF +Q24 GT +Q5 GOTO LBL 2	Inquire whether an arc is finished. If not finished, return to LBL 2
43 LP PR+Q6 PA+Q5	Move to the end angle in space
44 L Z+Q23 R0 F1000	Retract in the spindle axis
45 L X+Q26 R0 FMAX	Pre-position for next arc
46 FN 1: Q28 = +Q28 + +Q18	Update rotational position in the plane
47 FN 0: Q24 = +Q4	Reset solid angle
48 CYCL DEF 10.0 ROTATION	Activate new rotational position
49 CYCL DEF 10.0 ROT+Q28	
50 FN 12: IF +Q28 LT +Q9 GOTO LBL 1	
51 FN 9: IF +Q28 EQU +Q9 GOTO LBL 1	Unfinished? If not finished, return to LBL 1
52 CYCL DEF 10.0 ROTATION	Reset the rotation
53 CYCL DEF 10.1 ROT+0	
54 CYCL DEF 7.0 DATUM SHIFT	Reset datum shift
55 CYCL DEF 7.1 X+0	
56 CYCL DEF 7.2 Y+0	
57 CYCL DEF 7.3 Z+0	
58 LBL 0	End of subprogram
59 END PGM SPHERE MM	

10

Special functions

10.1 Overview of special functions

The control provides the following powerful special functions for a large number of applications:


Function	Description
Active Chatter Control (option 145)	See the User's Manual for Setup, Testing and Running NC Programs
Working with text files	Page 392
Working with freely definable tables	Page 396

Press the **SPEC FCT** key and the corresponding soft keys to access further special functions of the control. The following tables give you an overview of which functions are available.

Main menu for SPEC FCT special functions

SPEC FCT Press the SPEC FCT key to select the special functions

Soft key	Function	Description
FUNCTION MODE	Select machining mode or kinematics	Page 355
PROGRAM	Define program defaults	Page 353
CONTOUR + POINT MACHINING	Functions for contour and point machining	Page 353
TILT MACHINING PLANE	Define the PLANE function	Page 414
PROGRAM FUNCTIONS	Define different conversational functions	Page 354
PROGRAM- MING AIDS	Programming aids	Page 189



After pressing the **SPEC FCT** key, you can open the **smartSelect** selection window with the **GOTO** key. The control displays a structure overview with all available functions. You can rapidly navigate with the cursor or mouse and select functions in the tree diagram. The control displays online help for the selected function in the window on the right.


A

Program defaults menu

PROGRAM	
DEFAULTS	

Press the Program Defaults soft key

Soft key	Function	Description
BLK FORM	Define workpiece blank	Page 88
PRESET	Modifying the preset	Page 379
SELECT DATUM TABLE	Select datum table	See the User's Manual for Programming of Machining Cycles
SELECT COMPENS. TABLE	Select compensation table	Page 383
GLOBAL DEF	Define global cycle parameters	See the User's Manual for Programming of Machining Cycles



Functions for contour and point machining menu

CONTOUR + POINT MACHINING	 Press the soft key for functions for contour and point machining
Soft key	Function
DECLARE	Assign contour description
CONTOUR DEF	Define a simple contour formula
SEL CONTOUR	Select a contour definition
CONTOUR FORMULA	Define a complex contour formula
PATTERN DEF	Define regular machining pattern
SEL PATTERN	Select the point file with machining positions


Further information: User's Manual for Programming of **Machining Cycles**

168.h	g\BHB\Klartex	L (TGB.II		¥.			
BLK FORM * Mach Tool CAL CYCL DEF 0200=22 0201=2 0200=3 0200=45 0200=40 0200=20 0200=40 0200=20 0200=40 0200=40 0210=40 0210=40 0210=40 0200=40 <td< th=""><th>0.1 2 X-0 Y-2 0.2 X-100 1ne hole patte 2 X 64500 203 UNIVERSAL SST.UP CI 5 :DEPTH 5 :DEPTH NET 204 DATA ST. 104 DATA ST</th><th>-100 Z40 IN ID 27943K11 ORTLING EARANCE FOR PLONG DEPTH WE AT TOP COORDINATE IP CLEARANCE AKS GUNG DEPTH WE AT DEPTH CHIP BRKNG ERENCE</th><th>a</th><th>b X</th><th>•</th><th></th><th></th></td<>	0.1 2 X-0 Y-2 0.2 X-100 1ne hole patte 2 X 64500 203 UNIVERSAL SST.UP CI 5 :DEPTH 5 :DEPTH NET 204 DATA ST. 104 DATA ST	-100 Z40 IN ID 27943K11 ORTLING EARANCE FOR PLONG DEPTH WE AT TOP COORDINATE IP CLEARANCE AKS GUNG DEPTH WE AT DEPTH CHIP BRKNG ERENCE	a	b X	•		
Q335=+1	1	1	() ())()((
DECLARE	CONTOUR	SEL		CONTOUR	PATTERN	SEL	-

Menu for defining different Klartext functions

PROGRAM FUNCTIONS Press the PROGRAM FUNCTIONS soft key

Soft key	Function	Description
FUNCTION TCPM	Define the positioning behavior for rotary axes	Page 450
FUNCTION FILE	Define file functions	Page 372
FUNCTION PARAX	Define the positioning behavior for parallel axes U, V, W	Page 356
TRANSFORM / CORRDATA	Define coordinate transforma- tions	Page 375
FUNCTION COUNT	Define the counter	Page 390
STRING FUNCTIONS	Define string functions	Page 304
FUNCTION SPINDLE	Define pulsing spindle speed	Page 401
FUNCTION FEED	Define recurring dwell time	Page 403
FUNCTION DWELL	Define dwell time in seconds or revolutions	Page 405
FUNCTION LIFTOFF	Lift off tool at NC stop	Page 406
INSERT COMMENT	Add comments	Page 193
TABDATA	Write and read table values	Page 385
POLARKIN	Define polar kinematics	Page 365
MONITORING	Activate component monitoring	Page 389
FUNCTION PROG PATH	Choose path interpretation	Page 464



10.2 Function mode

Program function mode



Refer to your machine manual!

Your machine manufacturer enables this function.

If your machine manufacturer has enabled the selection of various kinematic models, then you can switch between them using the **FUNCTION MODE** soft key.

Procedure

To switch the kinematic model, proceed as follows:



Press the FUNCTION MODE soft key

Show the soft-key row for special functions



- Press the MILL soft key
- Press the SELECT KINEMATICS soft key
- Select the desired kinematic model

Function Mode Set

Refer to your machine manual!
 This function must be enabled and adapted by the machine tool builder.
 Your machine tool builder defines the available options in the machine parameter CfgModeSelect (no. 132200).

FUNCTION MODE SET allows you to activate settings defined by the machine tool builder (e.g., changes to the range of traverse) from within the NC program

To select a setting, proceed as follows:



Show the soft-key row with special functions



SELECT

Press the FUNCTION MODE soft key

Press the SET soft key



- > The control opens a selection window.
- Select the desired setting

10.3 Working with the parallel axes U, V and W


Overview

0

Refer to your machine manual! Your machine must be configured by the machine manufacturer if you want to use parallel-axis functions. The number, designation and assignment of the programmable axes depend on the machine.

In addition to the principal axes X, Y and Z, the parallel axes U, V and W are available.

The principal axes and parallel axes are usually assigned to each other as follows:




Principal axis	Parallel axis	Rotary axis
Х	U	А
Y	V	В
Z	W	С

The control provides the following functions for machining with the parallel axes U, V and W: $\label{eq:control}$

Soft key	Function	Meaning	Page
FUNCTION PARAXCOMP	PARAXCOMP	Define the control's behavior when positioning parallel axes	360
FUNCTION PARAXMODE	PARAXMODE	Define the axes the control is to use for machining	361
Sw sw	itching the machine kiner		
Υοι	u can deactivate the progr	amming of parallel axes	

with the machine parameter **noParaxMode** (no. 105413).

Automatic calculation of the parallel axes



If the machine tool builder has already enabled the parallel axis in the configuration, the control takes this axis into account in the calculations, without you having to program **PARAXCOMP**.

This means that the control permanently takes the parallel axis into account in the calculations and you can therefore also probe a workpiece with any position of the W axis, for example.

6

Please note that **PARAXCOMP OFF** does not deactivate the parallel axis in this case, but the control reactivates the standard configuration.

The control deactivates automatic calculation only if you include the axis in the NC block, e.g. **PARAXCOMP OFF** W.

FUNCTION PARAXCOMP DISPLAY

Use the **PARAXCOMP DISPLAY** function to activate the display function for parallel axis movements. The control includes movements of the parallel axis in the position display of the associated principal axis (sum display). Therefore, the position display of the principal axis always displays the relative distance from the tool to the workpiece, regardless of whether you move the principal axis or the minor axis.

Proceed as follows for the definition:

SPEC	
FCT	

Show the soft-key row with special functions

PROGRAM FUNCTIONS Press the PROGRAM FUNCTIONS soft key



Press the FUNCTION PARAX soft key

FUNCTION PARAXCOMP FUNCTION

ARAXCOM

DISPLAY

- Press the FUNCTION PARAXCOMP soft key
- Select the FUNCTION PARAXCOMP DISPLAY function
- Define the parallel axis whose movements the control is to take into account in the position display of the associated principal axis

Example

13 FUNCTION PARAXCOMP DISPLAY W

When **FUNCTION PARAXCOMP DISPLAY** is active, the control displays an icon in the status display.

lcon	Mode		
	FUNCTION PARAXCOMP DISPLAY is active		
	The PARAXMODE icon hides the active PARAXCOMP DISPLAY icon.		
	In the additional status display, the control also shows (D) for DISPLAY after the designations of the affected axes.		

No icon Standard kinematics is active

10

FUNCTION PARAXCOMP MOVE

Ü

SPEC FCT

PROGRAM

FUNCTION PARAX

FUNCTION PARAXCOMF

FUNCTION PARAXCOMP MOVE The **PARAXCOMP MOVE** function can be used only in connection with straight-line blocks (L).

The control uses the **PARAXCOMP MOVE** function to compensate for movements of a parallel axis by performing compensation movements in the associated principal axis.

For example, if a parallel-axis movement is performed in the negative W-axis direction, the principal axis Z is moved simultaneously in the positive direction by the same value. The relative distance from the tool to the workpiece remains the same. Application in gantry-type milling machines: Retract the spindle sleeve to move the cross beam down simultaneously.

Proceed as follows for the definition:

Show the soft-key row with special functions
Press the PROGRAM FUNCTIONS soft key
Press the FUNCTION PARAX soft key
Press the FUNCTION PARAXCOMP soft key
Select the FUNCTION PARAXCOMP MOVE function
Define the parallel axis

Example

13 FUNCTION PARAXCOMP MOVE W

When **FUNCTION PARAXCOMP MOVE** is active, the control displays an icon in the status display.

lcon	Mode
	FUNCTION PARAXCOMP MOVE is active
	The PARAXMODE icon hides the active PARAXCOMP MOVE icon.
	In the additional status display, the control also shows (M) for MOVE after the designations of the affected axes.
No icon	Standard kinematics is active
0	Possible offset values (U_OFFS, V_OFFS and W_OFFS from the preset table) to be taken into account will be specified by your machine tool builder in the presetToAlignAxis machine parameter (no. 300203).

Deactivating FUNCTION PARAXCOMP



After the control has booted, the configuration defined by the machine tool builder is in effect.

Check whether one of the icons for PARAXCOMP DISPLAY or PARAXCOMP MOVE is shown in the status display:




To reset the **PARAXCOMP** parallel-axis function, proceed as follows:

- Selection of NC program
- PARAXCOMP OFF

You must deactivate the parallel-axis functions before switching the machine kinematics.

Use the PARAXCOMP OFF function to switch off the PARAXCOMP **DISPLAY** and **PARAXCOMP MOVE** parallel-axis functions. Proceed as follows for the definition:



Show the soft-key row with special functions

- Press the PROGRAM FUNCTIONS soft key Press the FUNCTION PARAX soft key
 - Press the FUNCTION PARAXCOMP soft key

Select FUNCTION PARAXCOMP OFF

Enter an axis, if required

Example

```
13 FUNCTION PARAXCOMP OFF
13 FUNCTION PARAXCOMP OFF W
```

When FUNCTION PARAXCOMP is not active, the control does not display the corresponding icon and the additional information after the axis designations.



Your machine tool builder can activate the PARAXCOMP function permanently with a machine parameter. If you want to switch the function off, you must indicate the parallel axis in the NC block, for example FUNCTION PARAXCOMP OFF W.

Further information: "Automatic calculation of the parallel axes", Page 357

FUNCTION PARAXMODE



To activate the **PARAXMODE** function, you must always define three axes.

If your machine tool builder has not yet activated the **PARAXCOMP** function as default, you must activate **PARAXCOMP** before you can work with **PARAXMODE**.

In order for the control to offset the principal axis deselected with **PARAXMODE**, switch the **PARAXCOMP** function on for this axis.

Use the **PARAXMODE** function to define the axes the control is to use for machining. You program all traverse movements and contour descriptions in the principal axes X, Y and Z, independent of your machine.

Define 3 axes in the **PARAXMODE** function (e.g. **FUNCTION PARAXMODE X Y W**) to be used by the control for programmed traverse movements.

Proceed as follows for the definition:

SPEC FCT	Show the soft-key row with special functions
PROGRAM FUNCTIONS	Press the PROGRAM FUNCTIONS soft key
FUNCTION PARAX	Press the FUNCTION PARAX soft key
FUNCTION PARAXMODE	Press the FUNCTION PARAXMODE soft key
FUNCTION	Select FUNCTION PARAXMODE
PARAXMODE	Define the axes for machining

Example

13 FUNCTION PARAXMODE X Y W

When **FUNCTION PARAXMODE** is active, the control shows an icon in the status display.

lcon	Mode	
	FUNCTION PARAXMODE is active	
	The PARAXMODE icon hides the active PARAXCOMP icon.	
	The control additionally displays the selected Principal axes on the POS tab of the additional status display.	
No icon	Standard kinematics is active	

Moving the principal axis and the parallel axis

If the **PARAXMODE** function is active, the control uses the axes defined in the function to execute the programmed traverse movements. If the control is to move the principal axis deselected by **PARAXMODE**, you can identify this axis by additionally entering the character **&**. The **&** character then refers to the principal axis.

Proceed as follows:

Ľ	~

- Press the L key
- > The control opens a linear block.
- Define coordinates
- Define radius compensation
- Press the left arrow key
- > The control shows the &Z character.
- If applicable, use the axis-direction keys to select the axis
- Define coordinate
- Press the ENT key

Example

13 FUNCTION PARAXMODE X Y W


14 L Z+100 &Z+150 R0 FMAX

6

The & syntax element is only permitted in L blocks. Additional positioning of a principal axis with the & command is done in the REF system. If you have set the position display to display ACTUAL values, this movement will not be shown. If necessary, switch the position display to REF values.


Your machine tool builder will define the calculation of possible offset values (X_OFFS, Y_OFFS and Z_OFFS from the preset table) for the axes positioned with the **&** operator in the **presetToAlignAxis** machine parameter (no. 300203).

Deactivating FUNCTION PARAXMODE



Use the **PARAXCOMP OFF** function to switch off the parallel-axis function. The control then uses the principal axes defined by the machine tool builder.

Proceed as follows for the definition:



Example

13 FUNCTION PARAXMODE OFF

When **FUNCTION PARAXMODE** is not active, the control does not display the corresponding icon or entries on the **POS** tab.



Depending on the configuration by the machine tool builder, an active **PARAXCOMP** icon that was previously hidden by the **PARAXMODE** icon will then become visible.

Example: Drilling with the W axis

0 BEGIN PGM PAR MM		
1 BLK FORM 0.1 Z X+0 Y+0 Z-20		
2 BLK FORM 0.2 X+100 Y+100 Z+0		
3 TOOL CALL 5 Z S2222		Call the tool in the spindle axis Z
4 L Z+100 R0 FMAX M3		Position the principal axis
5 CYCL DEF 200 DRILLING		
Q200=+2	;SET-UP CLEARANCE	
Q201=-20	;DEPTH	
Q206=+150	;FEED RATE FOR PLNGNG	
Q202=+5	;PLUNGING DEPTH	
Q210=+0	;DWELL TIME AT TOP	
Q203=+0	;SURFACE COORDINATE	
Q204=+50	;2ND SET-UP CLEARANCE	
Q211=+0	;DWELL TIME AT DEPTH	
Q395=+0	;DEPTH REFERENCE	
6 FUNCTION PARAXCOMP DISPLAY Z		Activate display compensation
7 FUNCTION PARAXMODE X Y W		Positive axis selection
8 L X+50 Y+50 R0 FMAX M99		Infeed runs minor axis W
9 FUNCTION PARAXMODE OFF		Restore the standard configuration
10 L M30		
11 END PGM PAR MM		

10.4 Machining with polar kinematics

Overview

In a polar kinematic model, the path contours of the working plane are performed by one linear axis and one rotary axis instead of by two linear principal axes. The working plane is defined by the linear principal axis and the rotary axis while the working space is defined by these two axes and the infeed axis.

On turning and grinding machines that have only two linear principal axes, polar kinematics enable milling operations to be performed on the front face.

On milling machines, various linear principal axes can be replaced with suitable rotary axes. For example on large machines, polar kinematics enable you to machine much larger surfaces than with only the principal axes.

Refer to your machine manual! (Ö) Your machine must be configured by the machine tool builder so that you can use polar kinematics. A polar kinematic model consists of two linear axes and one rotary axis. The programmable axes vary depending on the machine. The polar rotary axis must be installed onto the table side so that it is opposite the selected linear axes and must be configured as a modulo axis. Thus, the linear axes must not be positioned between the rotary axis and the table. The maximum range of traverse of the rotary axis is limited by the software limit switches if necessary. The principal axes X, Y, and Z as well as the possible parallel axes U, V, and W can be used as radial axes or infeed axes.

The control, combined with polar kinematics, provides the following functions:

Soft key	Function	Meaning	Page
POLARKIN AXES	POLARKIN AXES	Define and activate polar kinematics	366
POLARKIN	POLARKIN OFF	Deactivate polar kinematics	368

Activating FUNCTION POLARKIN

Use the **POLARKIN AXES** function to activate the polar kinematics. The axis data define the radial axis, the infeed axis, and the polar axis. The **MODE** data influence the positioning behavior, whereas the **POLE** data define the machining at the pole. The pole is the center of rotation of the rotary axis in this case.


Notes on the axes to be selected:

- The first linear axis must be radial to the rotary axis.
- The second linear axis defines the infeed axis and must be parallel to the rotary axis.
- The rotary axis defines the polar axis and is defined last.
- Any available modulo axis that is installed onto the table side so that it is opposite the selected linear axes can be used as the rotary axis.
- The two selected linear axes thus span an area within which the rotary axis also lies.

MODE options:

Syntax	Function
POS	Seen from the center of rotation, the control performs machining in the positive direction of the radial axis.
	The radial axis must be prepositioned correspond- ingly.
NEG	Seen from the center of rotation, the control performs machining in the negative direction of the radial axis.
	The radial axis must be prepositioned correspond- ingly.
KEEP	The control remains with the radial axis on that side of the center of rotation on which the axis is positioned when the function is activated.
	If the radial axis is on the center of rotation upon switch-on, POS applies.
ANG	The control remains with the radial axis on that side of the center of rotation on which the axis is positioned when the function is activated.
	If you set POLE to ALLOWED , positioning through the pole is possible. The pole side is changed and a


180-degree rotation of the rotary axis is prevented.



POLE options:

Syntax	Function	
ALLOWED	The control permits machining operations at the pole	
SKIPPED	The control prevents machining operations at the pole	
	The disabled area corresponds to a circular surface with a radius of 0.001 mm (1 μm) around the pole.	

Program this as follows:



Show the soft key row with special functions

Press the PROGRAM FUNCTIONS soft key

- Press the POLARKIN soft key
- ► Press the **POLARKIN AXES** soft key
- Define the axes of the polar kinematics
- Select the **MODE** option
- Select the **POLE** option

Example

6 POLARKIN AXES X Z C MODE: KEEP POLE: ALLOWED

If polar kinematics is active, the control displays an icon in the status display.

lcon	Mode	
	Polar kinematics is active	
	The POLARKIN icon hides the active PARAXCOMP DISPLAY icon.	
	The control additionally displays the selected Principal axes on the POS tab of the additional status display.	
No icon	Standard kinematics is active	

Notes

Programming notes:

Before activating the polar kinematics, you must program the function PARAXCOMP DISPLAY with at least the principal axes X, Y, and Z.



HEIDENHAIN recommends defining all of the available axes within the **PARAXCOMP DISPLAY** function.

- Position the linear axis that will not be included in the polar kinematics to the coordinate of the pole, before the **POLARKIN** function. Otherwise, a non-machinable area with a radius that corresponds to at least the value of the deselected linear axis would result.
- Avoid performing machining operations at the pole or near the pole, because fluctuations in feed rate may occur in this area. For this reason, ideally use the following **POLE** option: **SKIPPED**.
- Polar kinematics cannot be combined with the following functions:
 - Traverse motions with M91
 - Tilting the working plane

FUNCTION TCPM or M128

Machining information:

The polar kinematics may require continuous motions to be divided into submotions (e.g., a linear motion that is divided into two submotions: a motion for approaching the pole and a motion for departing the pole). As a result, the distance-to-go display may differ from that of the standard kinematics.

Deactivating FUNCTION POLARKIN

Use the **POLARKIN OFF** function to deactivate the polar kinematics. Program this as follows:



Show the soft key row with special functions

- Press the PROGRAM FUNCTIONS soft key
- Press the POLARKIN soft key



Press the POLARKIN OFF soft key

Example

6 POLARKIN OFF

When the polar kinematics is not active, the control does not display the corresponding icon or entries on the **POS** tab.

Note

The following scenarios lead to deactivation of the polar kinematics:

- Execution of the **POLARKIN OFF** function
- Selection of an NC program
- Reaching the end of the NC program
- Abortion of the NC program
- Selecting a kinematic model
- Restarting the control

Example: SL cycles in the polar kinematics

0 BEGIN PGM POLARKIN_SL MM		
1 BLK FORM 0.1 Z X-100 Y-100 Z-30		
2 BLK FORM 0.2 X+100 Y+100 Z+0		
3 TOOL CALL 2 Z F2000		
4 FUNCTION PARAX	COMP DISPLAY X Y Z	Activate PARAXCOMP DISPLAY
5 L X+0 Y+0.0011	Z+10 A+0 C+0 FMAX M3	Pre-position outside of the disabled pole area
6 POLARKIN AXES Y	Z C MODE:KEEP POLE:SKIPPED	Activate POLARKIN
7 CYCL DEF 7.0 DAT		Datum shift in the polar kinematics
8 CYCL DEF 7.1 X+	50	
9 CYCL DEF 7.2 Y+	50	
10 CYCL DEF 7.3 Z+	+0	
11 CYCL DEF 14.0 C	ONTOUR	
12 CYCL DEF 14.1 C	ONTOUR LABEL2	
13 CYCL DEF 20 CO	NTOUR DATA	
Q1=-10	;MILLING DEPTH	
Q2=+1	;TOOL PATH OVERLAP	
Q3=+0	;ALLOWANCE FOR SIDE	
Q4=+0	;ALLOWANCE FOR FLOOR	
Q5=+0	;SURFACE COORDINATE	
Q6=+2	;SET-UP CLEARANCE	
Q7=+50	;CLEARANCE HEIGHT	
Q8=+0	;ROUNDING RADIUS	
Q9=+1	;ROTATIONAL DIRECTION	
14 CYCL DEF 22 RO	UGH-OUT	
Q10=-5	;PLUNGING DEPTH	
Q11=+150	;FEED RATE FOR PLNGNG	
Q12=+500	;FEED RATE F. ROUGHNG	
Q18=+0	;COARSE ROUGHING TOOL	
Q19=+0	;FEED RATE FOR RECIP.	
Q208=+99999	;RETRACTION FEED RATE	
Q401=+100	;FEED RATE FACTOR	
Q404=+0	;FINE ROUGH STRATEGY	
15 M99		
16 CYCL DEF 7.0 DATUM SHIFT		
17 CYCL DEF 7.1 X+0		
18 CYCL DEF 7.2 Y+0		
19 CYCL DEF 7.3 Z+0		
20 POLARKIN OFF		Deactivate POLARKIN
21 FUNCTION PARAXCOMP OFF X Y Z		Deactivate PARAXCOMP DISPLAY
22 L X+0 Y+0 Z+10 A+0 C+0 FMAX		
23 L M30		

24 LBL 2	
25 L X-20 Y-20 RR	
26 L X+0 Y+20	
27 L X+20 Y-20	
28 L X-20 Y-20	
29 LBL 0	
30 END PGM POLARKIN_SL MM	

10.5 File functions

Application

The **FILE FUNCTION** functions are used to perform file operations such as copying, moving, and deleting files from within the NC program.



Programming and operating information:

- You must not use FILE functions on NC programs or files, to which you have previously made reference with functions such as CALL PGM or CYCL DEF 12 PGM CALL.
- The FUNCTION FILE function is considered only in the Program run, single block and Program run, full sequence operating modes.

Defining file functions

Proceed as follows:

GRAM
TION

FUNCTION FILE Press the special functions key

Select the program functions

Select file operationsThe control displays the available functions.

Soft key	Function	Meaning
FILE COPY	FILE COPY	Copy file: Enter the name and path of the file to be copied, as well as the target path
FILE MOVE	FILE MOVE	Move file: Enter the name and path of the file to be moved, as well as the target path
FILE DELETE	FILE DELETE	Delete file: Enter the path and name of the file to be deleted
OPEN FILE	OPEN FILE	Open the file: Enter the name and path of the file

If you try to copy a file that does not exist, the control generates an error message.

FILE DELETE does not generate an error message if you try to delete a non-existing file.

OPEN FILE

Fundamentals

The **OPEN FILE** function allows you to open various file formats directly from the NC program.

The **OPEN FILE** function is available in the following operating modes:

- Positioning w/ Manual Data Input
- Test Run
- Program Run Single Block
- Program Run Full Sequence

The control opens the selected file using an appropriate HEROS tool.

Displayable file formats:

- PNG
- BMP
- PDF
- OGG
- OGV
- HTML

Programming OPEN FILE

To program the **OPEN FILE** function, proceed as follows:



OK

Select the program functions

Press the special functions key

- Select file operations
- Select the OPEN FILE function
- > The control initiates the dialog.
- Press the SELECT FILE soft key
- In the folder structure, select the file to be displayed
- Press the **Ok** soft key
- The control displays the path of the selected file and the STOP function.
- Optionally, program STOP
- The control concludes the entry of the OPEN FILE function.

Automatic display

The control provides only one HEROS tool for displaying some file formats. With the **OPEN FILE** function, the control then automatically uses this tool to display files of these formats.

Example

1 OPEN FILE "TNC:\CLAMPING_INFORMATION.HTML"

HEROS tool that can be used for displaying:

Mozilla Firefox



Selecting a HEROS tool for displaying

If more than one HEROS tool can be used to open a file format, you can select the tool to be used for displaying the file.

Example

1 OPEN FILE "TNC:\CLAMPING_INFORMATION.BMP"

HEROS tools that can be used for displaying:

- Geequie
- Ristretto Image Viewer

When executing the **OPEN FILE** function, the control will open the **Application?** window that lists all of the HEROS tools available for this purpose. From the HEROS tools available, you can select the tool you want to use.



10.6 Defining coordinate transformations

Overview

The control offers the following functions for programming coordinate transformations:

Soft key	Function
TRANS DATUM	Datum shift
FUNCTION CORRDATA	Select compensation tables
FUNCTION CORRDATA RESET	Reset compensation

TRANS DATUM

As an alternative to Cycle **7 DATUM SHIFT**, you can also use the **TRANS DATUM** Klartext function. Just as in Cycle **7**, you can use **TRANS DATUM** to directly program shift values or activate a line from a selectable datum table. In addition, there is also the **TRANS DATUM RESET** function, with which you can easily reset an active datum shift.



In the machine parameter **CfgDisplayCoordSys** (no. 127501), the machine tool builder specifies the coordinate system in which the status display shows an active datum shift.

TRANS DATUM AXIS

Example

13 TRANS DATUM AXIS X+10 Y+25 Z+42

You can define a datum shift by entering values in the respective axis with the TRANS DATUM AXIS function. You can define up to nine coordinates in one NC block, and incremental entries are possible. Proceed as follows for the definition:

SPEC FCT	Show the soft-key row with special functions
PROGRAM FUNCTIONS	Press the PROGRAM FUNCTIONS soft key
TRANSFORM / CORRDATA	Press the TRANSFORM / CORRDATA soft key
TRANS DATUM	Press the TRANS DATUM soft key
VALUES	Select the value input soft key
X Y Z	Enter the datum shift in the affected axes, confirming with the ENT key each time
0	Values entered as absolute numbers refer to the workpiece preset, which is specified either by presetting or by selecting a preset from the preset table.
	Incremental values always refer to the datum which was last valid (this may be a datum which has already been shifted).

TRANS DATUM TABLE

Example

13 TRANS DATUM TABLE TABLINE25

You can define a datum shift by selecting a datum number from a datum table with the **TRANS DATUM TABLE** function. Proceed as follows for the definition:



Show the soft-key row with special functions

Press the PROGRAM FUNCTIONS soft key

- PROGRAM FUNCTIONS



Select transformations



. D 🛛

- Select the TRANS DATUM datum shift
- Select the TRANS DATUM TABLE datum shift
- Enter the line number to be activated by the control, confirm with the ENT key
- If desired, enter the name of the datum table from which you want to activate the datum number, and confirm with the ENT key. If you do not want to define a datum table, confirm with the NO ENT key



If you have not defined a datum table in the **TRANS DATUM TABLE** block, then the control uses the datum table previously selected with **SEL TABLE** or the datum table activated in the **Program run, single block** or **Program run, full sequence** operating mode (status **M**).

TRANS DATUM RESET

Example

13 TRANS DATUM RESET

Use the **TRANS DATUM RESET** function to cancel a datum shift. How you previously defined the datum is irrelevant. Proceed as follows for the definition:

	SPEC FCT
ſ	PROGRAM
	FUNCTION
E	

Show the soft-key row with special functions

- Press the PROGRAM FUNCTIONS soft key
- TRANSFORM / CORRDATA
- TRANS DATUM

RESET DATUM SHIFT Select the **TRANS DATUM** datum shift

Select transformations

Press the RESET DATUM SHIFT soft key

10.7 Modifying presets

The control provides the following functions for modifying a preset directly in the NC program after it has been defined in the preset table:

- Activate the preset
- Copy the preset
- Correct the preset

Activating a preset

The function **PRESET SELECT** allows you to use a preset defined in the preset table and activate it as a new preset.

To activate the preset, use the preset number or the entry in the **Doc** column. If the entry in the **Doc** column is not unique, the control will activate the preset with the smallest preset number.



If you program **PRESET SELECT** without optional parameters, the behavior is the same as with Cycle **247 SET PRESET**.

Use the optional parameters to define the following:

- **KEEP TRANS**: Retain simple transformations
 - Cycle 7 DATUM SHIFT
 - Cycle 8 MIRRORING
 - Cycle 10 ROTATION
 - Cycle 11 SCALING FACTOR
 - Cycle 26 AXIS-SPECIFIC SCALING
- WP: Any changes apply to the workpiece preset
- PAL: Any changes apply to the pallet preset (option 22)

Procedure

Proceed as follows for the definition:



Press the SPEC FCT key



Press the PROGRAM DEFAULTS soft key

Press the PRESET soft key



- Press the PRESET SELECT soft key
- Define the desired preset number
- As an alternative, define the entry from the Doc column
- Retain the transformations where necessary
- If necessary, select the preset to which the change is to apply

Example

13 PRESET SELECT #3 KEEP TRANS WP

Select the preset 3 as workpiece preset and retain the transformations

Copying a preset

The function **PRESET COPY** allows you to copy a preset defined in the preset table and activate the preset copied.

To select the preset to be copied, use the preset number or the entry in the **Doc** column. If the entry in the **Doc** column is not unique, the control will select the preset with the smallest preset number.

Use the optional parameters to define the following:

- **SELECT TARGET:** Activate the copied preset
- **KEEP TRANS**: Retain simple transformations

Procedure

Proceed as follows for the definition:



Press the SPEC FCT key



Press the PROGRAM DEFAULTS soft key

- PRESET
- Press the **PRESET** soft key
- PRESET COPY
- Press the PRESET COPY soft key
- Define the preset number to be copied
- As an alternative, define the entry from the Doc column
- Define the new preset number
- Activate the copied preset, if necessary
- Retain the transformations where necessary

Example

13 PRESET COPY #1 TO #3 SELECT TARGET KEEP TRANS

Copy the preset 1 to line 3, activate the preset 3, and retain the transformations

Correcting a preset

The function **PRESET CORR** allows you to correct the active preset.

If both the basic rotation and a translation are corrected in an NC block, the control will first correct the translation and then the basic rotation.

The compensation values are given with respect to the active coordinate system.

Proceed as follows for the definition:



Press the PROGRAM DEFAULTS soft key

Show the soft key row with special functions

Press the **PRESET** soft key



- Press the PRESET CORR soft key
- Define the desired compensation values

Example

13 PRESET CORR X+10 SPC+45

The active preset is corrected by a value of +10 mm in X, and by +45° in SPC

10.8 Compensation table

Application

With the compensation table, you can save compensations in the tool coordinate system (T-CS) or in the working plane coordinate system (WPL-CS).

The compensation table **.tco** is the alternative to compensating with **DL**, **DR**, and **DR2** in the Tool Call block. As soon as you have activated a compensation table, the control overwrites the compensation value from the Tool Call block.

The compensation tables offer the following benefits:

- Values can be changed without adapting the NC program
- Values can be changed during NC program run

If you change a value, then this change does not become active until the compensation is called again.

Types of compensation tables

Via the file name extension, you can determine in which coordinate system the control will perform the compensation.

The control offers the following compensation options via tables:

- tco (tool correction): Compensation in the tool coordinate system (T-CS)
- wco (workpiece correction): Compensation in the working plane coordinate system (WPL-CS)

Compensation via the table is an alternative to compensation in the TOOL CALL block. Compensation from the table overwrites an already programmed compensation in the TOOL CALL block.

Tool compensation via the ".tco" table

The compensations in the tables with the file name extension ".tco" compensate for the active tool. The table applies to all tool types, which is why, during creation, you also see columns that you may not need for your tool type.



Enter only those values that are relevant to your tool. If you compensate for values that are not present with the existing tool, the control issues an error message.

The compensations have the following effects:

In the case of milling cutters, as an alternative to the delta values in the TOOL CALL

Tool compensation via the ".wco" table

The compensations in the tables with the file name extension ".wco" act as a shift in the working plane coordinate system (WPL-CS).

Creating a compensation table

Before you can work with a compensation table, you must first create the respective table.

You can create a compensation table as follows:

\Rightarrow	Switch to the Programming operating mode
PGM MGT	Press the PGM MGT key
NEW FILF	Press the NEW FILE soft key
	 Enter a file name with the desired extension (e.g., Corr.tco)
ENT	Confirm by pressing the ENT key
	 Select the unit of measure
ENT	 Confirm by pressing the ENT key
APPEND N LINES	Press the APPEND N LINES AT END soft key
AT END	 Enter the compensation values

Activate the compensation table

Select compensation table

If you are using compensation tables, then use the function **SEL CORR-TABLE** to activate the desired compensation table from within the NC program.

To add a compensation table to the NC program, proceed as follows:



Press the SPEC FCT key



-,
 - Press the PROGRAM DEFAULTS soft key
- ▶ Press the SELECT COMPENS. TABLE soft key
- Press the soft key of the table type (e.g., TCS)
- Select the table

If you are working without the **SEL CORR-TABLE** function, then you must activate the desired table prior to the test run or program run. In all operating modes, proceed as follows:

- Select the desired operating mode
- Select the desired table in the file manager
- In Test Run mode, the table receives the status S; in the operating modes Program run, single block and Program run, full sequence, the table receives the status M.

Activating a compensation value

To activate a compensation value in the NC program, proceed as follows:

SPEC FCT		Pres
PROGRAM		Pres
TRANSFORM /	►	Pres
TRANSFORM /	►	Pres
TCS		Pres (e.g.

- ss the SPEC FCT key
 - s the PROGRAM FUNCTIONS soft key
 - ss the TRANSFORM / CORRDATA soft key
 - s the FUNCTION CORRDATA soft key
 - s the soft key of the desired compensation , TCS)
 - Enter the line number

Duration of effect of the compensation

The activated compensation stays in effect until the end of the program or until a tool change occurs.

With FUNCTION CORRDATA RESET, you can program the compensations to reset.

Editing a compensation table during program run

You can change the values in the active compensation table during program run. As long as the compensation table is not yet active, the control dims the soft key.

Proceed as follows:



Press the SELECT COMPENS. TABLES soft key

- COMPENS TABLE
- Press the soft key for the desired table (e.g., COMPENS. TABLE T-CS)



- Set the EDIT soft key to ON
- Use the arrow keys to navigate to the desired location
- Edit the value



The changed data do not take effect until after the compensation has been activated again.

10.9 Accessing table values

Application

The **TABDATA** functions allow you to access table values. These functions enable automated editing of compensation values from within the NC program, for example.

You can access the following tables:

- Tool table *.t (read-only access)
- Compensation table ***.tco** (read and write access)
- Compensation table ***.wco** (read and write access)

In each case, the active table is accessed. Read-only access is always possible, whereas write access is possible only during program run. Write access during simulation or during a block scan has no effect.

If the unit of measure used in the NC program differs from that used in the table, the control will convert the values from **millimeters** to **inches**, and vice versa.

Reading a table value

The function **TABDATA READ** allows you to read a value from a table and save it to a Q parameter.

Depending on the type of column you want to transfer, you can use **Q**, **QL**, **QR**, or **QS** to save the value. The control will automatically convert the table values to the unit of measure used in the NC program.

The control reads from the tool table that is currently active. You can read a value from a compensation table only if you have activated the table concerned.

For example, the **TABDATA READ** function enables you to pre-check the data of the tool to be used to prevent error messages from occurring during program run.

Proceed as follows:

	0110	
SPEC FCT		Press the SPEC FCT key
PROGRAM FUNCTIONS		Press the PROGRAM FUNCTIONS soft key
TABDATA		Press the TABDATA soft key
TABDATA		Press the TABDATA READ soft key
READ		Enter the Q parameter for the result
ENT		Confirm with the ENT key
CORR - TCS		Press the soft key for the desired table (e.g., CORR-TCS)
		Enter the column name
ENT		Confirm with the ENT key
		Enter the line number of the table
ENT		Press the ENT key
Example		

12 SEL CORR-TABLE TCS "TNC:\table\corr.tco"	Activate the compensation table
13 TABDATA READ Q1 = CORR-TCS COLUMN "DR" KEY "5"	Save the value of line 5, column DR, from the compensation table to $\ensuremath{\text{Q1}}$

Writing a table value


The function **TABDATA WRITE** allows you to write a value from a Q parameter into a table

Depending on the type of column you want to write to, you can use **Q**, **QL**, **QR**, or **QS** as a transfer parameter.

In order to write into a compensation table, you need to activate the table.

You can use the **TABDATA WRITE** function after a touch probe cycle to enter a necessary tool compensation into the compensation table, for example.

Proceed as follows:



Example

12 SEL CORR-TABLE TCS "TNC:\table\corr.tco"	Activate the compensation table
13 TABDATA WRITE CORR-TCS COLUMN "DR" KEY "3" = Q1	Write the value from Q1 into line 3, column DR, of the compensation table

Adding a table value

The function **TABDATA ADD** allows you to add a value from a Q parameter to a value contained in the table.

Depending on the type of column you want to write to, you can use **Q**, **QL**, or **QR** as a transfer parameter.

In order to write into a compensation table, you need to activate the table.

You can use the **TABDATA ADD** function to update a tool compensation value after a measurement has been repeated, for example.

Proceed as follows:

SPEC FCT	Press the SPEC FCT key
PROGRAM FUNCTIONS	Press the PROGRAM FUNCTIONS soft key
TABDATA	Press the TABDATA soft key
TABDATA ADDITION	Press the TABDATA ADDITION soft key
CORR - TCS	Press the soft key for the desired table (e.g., CORR-TCS)
	Enter the column name
ENT	Confirm with the ENT key
	Enter the line number of the table
ENT	Confirm with the ENT key
	Enter the Q parameter
ENT	Confirm with the ENT key
Example	

12 SEL CORR-TABLE TCS "TNC:\table\corr.tco" Activate the compensation table 13 TABDATA ADD CORR-TCS COLUMN "DR" KEY "3" = Q1 Add the value from Q1 to line 3, column DR, of the compensation table

10.10 Monitoring of configured machine components (option 155)

Application



Refer to your machine manual! This function must be enabled and adapted by the machine tool builder.

The **MONITORING** function allows you to start and stop component monitoring from within the NC program.

The control monitors the selected component and shows the result in a heatmap on the workpiece.

A heatmap is similar to the image from an infrared camera.

- Green: component works under conditions defined as safe
- Yellow: component works under warning zone conditions

Press the special functions key

Select the program functions

Red: Overload condition

Starting monitoring

To start component monitoring, proceed as follows:




Select Monitoring

- Press the MONITORING HEATMAP START soft key
- Select the component released by the machine manufacturer

Only one component at a time can be monitored with the heatmap. If you start the heatmap several times in a row, monitoring of the previous component is stopped.

Stopping monitoring

Monitoring is stopped with the **MONITORING HEATMAP STOP** function.



10.11 Defining a counter

Application



Refer to your machine manual!

Your machine manufacturer enables this function.

The **FUNCTION COUNT** function allows you to control a simple counter from within the NC program. For example, this function allows you to count the number of manufactured workpieces.

Proceed as follows for the definition:



Show the soft key row with special functions



Press the PROGRAM FUNCTIONS soft key

FUNCTION COUNT Press the FUNCTION COUNT soft key

NOTICE

Caution: Data may be lost!

Only one counter can be managed by the control. If you execute an NC program that resets the counter, any counter progress of another NC program will be deleted.

- > Please check prior to machining whether a counter is active.
- If necessary, note down the counter value and enter it again via the MOD menu after execution.



You can use Cycle **225** to engrave the current counter value into the workpiece.

Further information: User's Manual for Programming of Machining Cycles

Effect in the operating mode Test Run

You can simulate the counter in the **Test Run** operating mode. Only the count you have defined directly in the NC program is effective. The count in the MOD menu remains unaffected.

Effect in the operating modes Program Run Single Block and Program Run Full Sequence

The count from the MOD menu is only effective in the **Program Run Single Block** and **Program Run Full Sequence** operating modes.

The count is retained even after a restart of the control.

1()

Defining FUNCTION COUNT

The **FUNCTION COUNT** function provides the following possibilities:

Soft key	Function
FUNCTION COUNT INC	Increase count by 1
FUNCTION COUNT RESET	Reset counter
FUNCTION COUNT TARGET	Set the nominal count (target value) to the desired value
	Input value: 0–9999
FUNCTION COUNT SET	Set the counter to the desired value Input value: 0–9999
FUNCTION COUNT ADD	Increment the counter by the desired value Input value: 0–9999
FUNCTION COUNT REPEAT	Repeat the NC program starting from this label if more parts are to be machined.

Example

5 FUNCTION COUNT RESET	Reset the counter value
6 FUNCTION COUNT TARGET10	Enter the target number of parts to be machined
7 LBL 11	Enter the jump label
8 L	Machining
51 FUNCTION COUNT INC	Increment the counter value
52 FUNCTION COUNT REPEAT LBL 11	Repeat the machining operations if more parts are to be machined
53 M30	

54 END PGM

10.12 Creating text files

Application

You can use the control's text editor to write and edit texts. Typical applications:

- Recording test results
- Documenting working procedures
- Creating formula collections

Text files have the extension .A (for ASCII files). If you want to edit other types of files, you must first convert them into type .A files.

Opening and exiting a text file

- Operating mode: Press the **Programming** key
- ► To call the file manager, press the **PGM MGT** key.
- Display type .A files: Press the SELECT TYPE soft key and then the SHOW ALL soft key
- Select a file and open it with the SELECT soft key or ENT key, or open a new file by entering the new file name and confirming your entry with the ENT key

To leave the text editor, call the file manager and select a file of a different file type, for example an NC program.

Soft key	Cursor movements
MOVE WORD	Move cursor one word to the right
MOVE WORD	Move cursor one word to the left
PAGE	Go to next screen page
PAGE	Go to previous screen page
BEGIN	Cursor at beginning of file
	Cursor at end of file

Editing texts

Above the first line of the text editor, there is an information field showing the file name, location and line information:

File: Name of the text file

Line in which the cursor is presently located

Column: Column in which the cursor is presently located

The text is inserted or overwritten at the location of the cursor. You can move the cursor to any desired position in the text file by pressing the arrow keys.

You can insert a line break with the **RETURN** or **ENT** key.

Deleting and re-inserting characters, words and lines

With the text editor, you can erase words and even lines, and insert them at any desired location in the text.

- Move the cursor to the word or line that you wish to erase and insert at a different place in the text
- Press the DELETE WORD or DELETE LINE soft key: The text is removed and buffered
- Move the cursor to the location where you wish to insert the text, and press the INSERT LINE / WORD soft key

Soft key	Function	
DELETE	Delete and temporarily store a line	
DELETE WORD	Delete and temporarily store a word	
DELETE CHAR	Delete and temporarily store a character	
INSERT LINE / WORD	Insert a line or word from temporary storage	

Editing text blocks

You can copy and erase text blocks of any size, and insert them at other locations. Before any of these actions, you must first select the desired text block:

To select a text block: Move the cursor to the first character of the text you wish to select.

SELECT
BLOCK

- ▶ Press the **SELECT BLOCK** soft key
- Move the cursor to the last character of the text you wish to select. You can select whole lines by moving the cursor up or down directly with the arrow keys—the selected text is shown in a different color.

After selecting the desired text block, you can edit the text with the following soft keys:

Soft key	Function
CUT OUT BLOCK	Delete the selected block and store temporarily
COPY BLOCK	Store the selected block temporarily without erasing (copy)

If desired, you can now insert the temporarily stored block at a different location:

- Move the cursor to the location where you want to insert the temporarily stored text block
- INSERT BLOCK
- Press the INSERT BLOCK soft key: The text block is inserted

You can insert the temporarily stored text block as often as desired

Transferring the selected block to a different file

- Select the text block as described previously
- APPEND TO FILE
- Press the APPEND TO FILE soft key.
- The control displays the **Destination file =** dialog prompt.
- Enter the path and the name of the destination file.
- The control appends the selected text block to the specified file. If no target file with the specified name is found, the control creates a new file with the selected text.

Inserting another file at the cursor position

- Move the cursor to the location in the text where you wish to insert another file
- READ
- Press the **READ FILE** soft key.
- The control displays the File name = dialog prompt.
- Enter the path and name of the file you want to insert

Finding text sections

With the text editor, you can search for words or character strings in a text. The control provides the following two options.

Finding the current text

The search function is used for finding the next occurrence of the word in which the cursor is presently located:

- Move the cursor to the desired word.
- Select the search function: Press the FIND soft key
- Press the FIND CURRENT WORD soft key
- Find a word: Press the FIND soft key
- Exit the search function: Press the END soft key

Finding any text

- Select the search function: Press the FIND soft key. The control displays the Find text : dialog prompt
- Enter the text that you wish to find
- ► Find text: Press the **FIND** soft key
- Exit the search function: Press the END soft key

10.13 Freely definable tables

Fundamentals

In freely definable tables you can save and read any information from the NC program. The Q parameter functions **FN 26** to **FN 28** are provided for this purpose.

You can change the format of freely definable tables, i.e. the columns and their properties, by using the structure editor. They enable you to make tables that are exactly tailored to your application.

You can also toggle between a table view (standard setting) and form view.

6

The names of tables and table columns must start with a letter and must not contain an arithmetic operator (e.g., +). Due to SQL commands, these characters can cause problems when data are input or read.

Creating a freely definable table

Proceed as follows:

PGM	
MGT	

- Press the PGM MGT key
- Enter any desired file name with the extension .TAB
- Confirm with the ENT key
 - > The TNC displays a pop-up window with permanently saved table formats.
 - Use the arrow key to select a table template, e.g. example.tab
- ENT

 \odot


ENT

- Confirm with the ENT key
- The control opens a new table in the predefined format.
- To adapt the table to your requirements you have to edit the table format
 Further information: "Editing the table format", Page 397

Refer to your machine manual! Machine tool builders may define their own table

templates and save them in the control. When you create a new table, the control opens a pop-up window listing all available table templates.

You can also save your own table templates in the TNC. To do so, create a new table, change the table format and save the table in the **TNC:\system\proto** directory. If you then create new table, the control offers your template in the selection window for table templates.



Editing the table format

Proceed as follows:

EDIT	
FORMAT	


- Press the EDIT FORMAT soft key
- > The control opens a pop-up window displaying the table structure.
- Adapt the format

The control provides the following options:

Structure command	Meaning
Available columns:	List of all columns contained in the table
Move before:	The entry highlighted in Available columns is moved in front of this column
Name	Column name: Is displayed in the header
Column type	TEXT: Text entry SIGN: + or - sign BIN: Binary number DEC: Decimal, positive, whole number (cardinal number) HEX: Hexadecimal number INT: Whole number LENGTH: Length (is converted in inch programs) FEED: Feed rate (mm/min or 0.1 inch/min) IFEED: Feed rate (mm/min or inch/min) FLOAT: Floating-point number BOOL: Logical value INDEX: Index TSTAMP: Fixed format for date and time UPTEXT: Text entry in upper case PATHNAME: Path name
Default value	Default value for the fields in this column
Width	Width of the column (number of charac- ters)
Primary key	First table column
Language-sensitive column name	Language-sensitive dialogs



Columns with a column type that permits letters, such as **TEXT**, can only be output or written to via QS parameters, even if the content of the cell is a number.



You can use a connected mouse or the navigation keys to move through the form.

Proceed as follows:

ŧ	

Press the navigation keys to jump to the input
fields

GOTC

4

Press the GOTO	key in	order to	open	expandable
menus				

 Use the arrow keys to navigate within an input field

6

In a table that already contains lines you can not change the table properties **Name** and **Column type**. Once you have deleted all lines, you can change these properties. If required, create a backup copy of the table beforehand. With the **CE** and **ENT** key combination, you can reset invalid values in fields with the **TSTAMP** column type.

Closing the structure editor

Proceed as follows:



- Press the OK soft key
- The control closes the editing form and applies the changes.
- Alternative: Press the CANCEL soft key
- > The control discards all entered changes.

Switching between table and form view

All tables with the **.TAB** extension can be opened in either list view or form view.

Switch the view as follows:



Press the Screen layout key



Press the soft key with the desired view

In the left half of the form view, the control lists the line numbers with the contents of the first column.

You can change the data as follows in the form view:



Press the ENT key in order to switch to the next input field on the right-hand side

Selecting another row to be edited:



Press the Next tab key
 The cursor jumps to the left window.

► Use the arrow keys to select the desired row

Press the Next tab key to switch back to the input window

TNC:\nc_prog1	123.TAB		NR: 0				
NR 0 1 2 3 4 5 6 7	X 100.001 99.994 99.989 100.002 99.990	Y 49.5 50.0 49.5 50.0	NR Goordinate Goordinate Goordinate Goordinate Remark			0 100 001 49.999 0 PAT 1	
8 9 10						_	
<] C mm Min S	19999.99999, m	€ 10X. +	Coordinate [mm]			1/1	
	HIDE/ SORT/ COLUMNS	EDIT		MORE FUNCTIONS	RESET	EDIT GURHENT FIELD	SORT

FN 26: TABOPEN – Open a freely definable table

With the function **FN 26: TABOPEN** you open a freely definable table to be written to with **FN 27** or to be read from with **FN 28**.



Only one table can be opened in an NC program at any one time. A new NC block with **FN 26: TABOPEN** automatically closes the last opened table. The table to be opened must have the extension **.TAB**.

Example: Open the table TAB1.TAB, which is saved in the directory TNC:\DIR1.

56 FN 26: TABOPEN TNC:\DIR1\TAB1.TAB

FN 27: TABWRITE: Write to a freely definable table

With the **FN 27: TABWRITE** function you write to the table that you previously opened with **FN 26: TABOPEN**.

You can define multiple column names in a **TABWRITE** block. The column names must be written between quotation marks and separated by a comma. You define in Q parameters the value that the control is to write to the respective column.



The FN 27: TABWRITE function is considered only in the Program run, single block and Program run, full sequence operating modes.

The **FN 18 ID992 NR16** function allows you to query the operating mode in which the NC program is running.

If you write to more than one column in an NC block, you must save the values under successive Q parameter numbers.

The control displays an error message if you try to write to a table cell that is locked or does not exist.

Use QS parameters if you want to write to a text field (such as column type UPTEXT). Use Q, QL, or QR parameters to write to numerical fields.

Example

You wish to write to the columns "Radius", "Depth", and "D" in line 5 of the presently opened table. The values to be written in the table are saved in the Q parameters Q5, Q6, and Q7.

53 Q5	= 3.75
-------	--------

54 Q6 = -5

55 Q7 = 7.5

56 FN 27: TABWRITE 5/"RADIUS, DEPTH, D" = Q5

FN 28: TABREAD – Read from a freely definable table

With the **FN 28: TABREAD** function you read from the table previously opened with **FN 26: TABOPEN**.

You can define, i.e. read, multiple column names in a **TABREAD** block. The column names must be written between quotation marks and separated by a comma. In the **FN 28** block you can define the Q parameter number in which the control is to write the value that is first read.



If you wish to read from more than one column in an NC block, the control will save the values under successive Q parameters of the same type, such as **QL1**, **QL2**, and **QL3**.

Use QS parameters if you want to read a text field. Use Q, QL, or QR parameters to read from numerical fields.

Example

You wish to read the values of the columns **X**, **Y**, and **D** from line 6 of the presently opened table. Save the first value in the Q parameter **Q10**, the second in **Q11**, and the third value in **Q12**.

From the same row, save the column **DOC** in **QS1**.

56 FN 28: TABREAD Q10 = 6/"X,Y,D"

57 FN 28: TABREAD QS1 = 6/"DOC"

Adapting the table format

NOTICE

Caution: Data may be lost!

The **ADAPT NC PGM / TABLE** function changes the format of all tables permanently. The control does not perform an automatic backup of the files prior to a format change. The files will thus be permanently changed and may no longer be usable.

 Only use the function in consultation with the machine tool builder.

Soft key	Function
ADAPT NC PGM / TABLE	Adapt format of tables present after changing the control software version
6	The names of tables and table columns must start with a letter and must not contain an arithmetic operator

(e.g., +). Due to SQL commands, these characters can cause problems when data are input or read.

10.14 Pulsing spindle speed FUNCTION S-PULSE

Programming a pulsing spindle speed

Application

0

Refer to your machine manual!

Read and note the functional description of the machine tool builder.

Follow the safety precautions.


Using the **S-PULSE FUNCTION** you can program a pulsing spindle speed, when operating at a constant spindle speed.

You can define the duration of a vibration (period length) using the P-TIME input value or a speed change in percent using the SCALE input value. The spindle speed changes in a sinusoidal form around the target value.

Procedure Example

13 FUNCTION S-PULSE P-TIME10 SCALE5

Proceed as follows for the definition:




The control never exceeds a programmed speed limit. The spindle speed is maintained until the sinusoidal curve of the **S-PULSE FUNCTION** falls below the maximum speed once more.

Symbols

In the status bar, the icon indicates the condition of the pulsing shaft speed:

lcon	Function
s %	Pulsing spindle speed active



Resetting the pulsing spindle speed

Example

18 FUNCTION S-PULSE RESET

Use the **FUNCTION S-PULSE RESET** to reset the pulsing spindle speed.

Proceed as follows for the definition:



Show the soft-key row with special functions



Press the PROGRAM FUNCTIONS soft key



Press the FUNCTION SPINDLE soft key



Press the RESET SPINDLE-PULSE soft key.

10.15 Dwell time FUNCTION FEED

Programming a dwell time

Application



Refer to your machine manual! Read and note the functional description of the machine tool builder.

Follow the safety precautions.

The **FUNCTION FEED DWELL** function can be used to program a recurring dwell time in seconds, e.g. to force chip breaking . Program **FUNCTION FEED DWELL** immediately prior to the machining you wish to run with chip breaking.

The **FUNCTION FEED DWELL** function is not effective with rapid traverse movements and probing motion.

NOTICE

Caution: Danger to the tool and workpiece!

When the **FUNCTION FEED DWELL** function is active, the control will repeatedly interrupt the feed movement. While the feed movement is interrupted, the tool remains at its current position, and the spindle continues to turn. During thread cutting, this behavior will cause the workpiece to become scrap. There is also a risk of tool breakage during execution!

Deactivate the FUNCTION FEED DWELL function before cutting threads

Procedure Example

13 FUNCTION FEED DWELL D-TIME0.5 F-TIME5

Proceed as follows for the definition:



FEED DWELL Show the soft-key row with special functions
 Press the **PROGRAM FUNCTIONS** soft key

- Press the FUNCTION FEED soft key
- Press the FEED DWELL soft key
 - Define the interval duration for dwelling D-TIME
 - Define the interval duration for cutting F-TIME

Resetting the dwell time



Reset the dwell time immediately following the machining with chip breaking.

Example

18 FUNCTION FEED DWELL RESET

Use **FUNCTION FEED DWELL RESET** to reset the recurring dwell time.

Proceed as follows for the definition:



Show the soft-key row with special functions



Press the PROGRAM FUNCTIONS soft key



Press the FUNCTION FEED soft key



Press the RESET FEED DWELL soft key

1

You can also reset the dwell time by entering D-TIME 0. The control automatically resets the **FUNCTION FEED DWELL** function at the end of a program.

10.16 Dwell time FUNCTION DWELL

Programming a dwell time

Application

The FUNCTION DWELL function enables you to program a dwell time in seconds or define the number of spindle revolutions for dwelling.

Procedure

Example

13 FUNCTION DWELL TIME10

Example

23 FUNCTION DWELL REV5.8

Proceed as follows for the definition:



Show the soft-key row with special functions

Press the PROGRAM FUNCTIONS soft key



FUNCTION DWELL soft key



DWELL

REVOLUTIONS

Press the DWELL TIME soft key

- Define the duration in seconds
- Alternatively, press the DWELL REVOLUTIONS soft key
- Define the number of spindle revolutions

10.17 Lift off tool at NC stop: FUNCTION LIFTOFF

Programming tool lift-off with FUNCTION LIFTOFF

Requirement

 $(\overline{\mathbf{0}})$

Refer to your machine manual!

This function must be configured and enabled by your machine tool builder. In the **CfgLiftOff** (no. 201400) machine parameter, the machine tool builder defines the path the control is to traverse for a **LIFTOFF** command. You can also use the **CfgLiftOff** machine parameter to deactivate the function.

In the $\ensuremath{\text{LIFTOFF}}$ column of the tool table, set the $\ensuremath{\text{Y}}$ parameter for the active tool.

Further information: User's Manual for Setup, Testing and Running NC Programs

Application

The **LIFTOFF** function is effective in the following situations:

- In case of an NC stop triggered by you
- In case of an NC stop triggered by the software, e. g. if an error has occurred in the drive system.
- In case of a power failure

The tool retracts from the contour by up to 2 mm. The control calculates the lift off direction based on the input in the **FUNCTION LIFTOFF** block.

You can program the **LIFTOFF** function in the following ways:

- FUNCTION LIFTOFF TCS X Y Z: Lift-off with a defined vector in the tool coordinate system
- FUNCTION LIFTOFF ANGLE TCS SPB: Lift-off with a defined angle in the tool coordinate system
- Lift-off in the tool axis direction with M148

Further information: "Automatically retracting the tool from the contour at an NC stop: M148", Page 238

Programming tool lift-off with a defined vector Example

18 FUNCTION LIFTOFF TCS X+0 Y+0.5 Z+0.5

With LIFTOFF TCS X Y Z, you define the lift-off direction as a vector in the tool coordinate system. The control calculates the lift-off height in each axis based on the tool path defined by the machine tool builder.

Proceed as follows for the definition:

SPEC FCT	Show the soft-key row with special functions
PROGRAM FUNCTIONS	Press the PROGRAM FUNCTIONS soft key
FUNCTION LIFTOFF	Press the FUNCTION LIFTOFF soft key
LIFTOFF TCS	 Press the LIFTOFF TCS soft key Enter X, Y, and Z vector components

Programming tool lift-off with a defined angle Example

18 FUNCTION LIFTOFF ANGLE TCS SPB+20

With LIFTOFF ANGLE TCS SPB, you define the lift-off direction as a spatial angle in the tool coordinate system.

The SPB angle you enter describes the angle between Z and X. If you enter 0°, the tool lifts off in the tool Z axis direction.

Proceed as follows for the definition:



Show the soft-key row with special functions



Press the PROGRAM FUNCTIONS soft key



LIFTOFF ANGLE TCS Press the FUNCTION LIFTOFF soft key

- Press the LIFTOFF ANGLE TCS soft key
- ▶ Enter the SPB angle

Resetting the lift-off function

Example

18 FUNCTION LIFTOFF RESET

Use the **FUNCTION LIFTOFF RESET** to reset the lift-off function. Proceed as follows for the definition:

SPEC FCT	Show the soft-key row with special functions
PROGRAM FUNCTIONS	Press the PROGRAM FUNCTIONS soft key
FUNCTION LIFTOFF	Press the FUNCTION LIFTOFF soft key
LIFTOFF RESET	Press the LIFTOFF RESET soft key
A	You can also reset the lift-off with M149.
	The control automatically resets the FUNCTION LIFTOFF

function at the end of a program.



Multiple-axismachining

11.1 Functions for multiple axis machining

This chapter summarizes the control functions for multiple axis machining:

Control function	Description	Page
PLANE	Define machining in the tilted working plane	411
M116	Feed rate of rotary axes	443
PLANE/M128	Inclined-tool machining	441
FUNCTION TCPM	Define the behavior of the control when positioning the rotary axes (enhancement of M128)	450
M126	Shortest-path traverse of rotary axes	444
M94	Reduce display value of rotary axes	445
M128	Define the behavior of the control when positioning the rotary axes	446
M138	Selection of tilted axes	448
M144	Calculate machine kinematics	449
LN blocks	Three-dimensional tool compensation	456

11.2 The PLANE function: Tilting the working plane (option 8)

Introduction

 $\textcircled{\textbf{O}}$

Refer to your machine manual!
The machine manufacturer must enable the functions for tilting the working plane!
You can only use the **PLANE** function in its entirety on machines having at least two rotary axes (table axes, head axes or combined axes). The **PLANE AXIAL** function is an exception. **PLANE AXIAL** can also be used on machines which have only one programmed rotary axis.

The **PLANE** functions provide powerful options to define tilted working planes in various ways.

The parameter definition of the **PLANE** functions is subdivided into two parts:

- The geometric definition of the plane, which is different for each of the available PLANE functions.
- The positioning behavior of the PLANE function, which is independent of the plane definition and is identical for all PLANE functions

Further information: "Defining the positioning behavior of the PLANE function", Page 430

NOTICE

Danger of collision!

When the machine is switched on, the control tries to restore the switch-off status of the tilted plane. This is prevented under certain conditions. For example, this applies if axis angles are used for tilting while the machine is configured with spatial angles, or if you have changed the kinematics.

- If possible, reset tilting before shutting the system down
- Check the tilted condition when switching the machine back on

Overview

Most **PLANE** functions (except **PLANE AXIAL**) can be used to describe the desired working plane independently of the rotary axes available on your machine. The following possibilities are available:

Soft key	Function	Required parameters	Page
SPATIAL	SPATIAL	Three spatial angles: SPA, SPB, and SPC	416
PROJECTED	PROJECTED	Two projection angles: PROPR and PROMIN and a rotation angle ROT	418
EULER	EULER	Three Euler angles: precession (EULPR), nutation (EULNU) and rotation (EULROT),	420
VECTOR	VECTOR	Normal vector for defining the plane and base vector for defining the direction of the tilted X axis	422
POINTS	POINTS	Coordinates of any three points in the plane to be tilted	425
REL. SPA.	RELATIVE	Single, incrementally effective spatial angle	427
AXIAL	AXIAL	Up to three absolute or incremental axis angles A,B,C	428
RESET	RESET	Reset the PLANE function	415

Running an animation

To familiarize yourself with the various definition possibilities of each **PLANE** function, you can start animated sequences via soft key. To do so, first enter animation mode and then select the desired **PLANE** function. While the animation plays, the control highlights the soft key of the selected **PLANE** function with a blue color.


Soft key	Function
SELECT ANIMATION OFF ON	Switch on the animation mode
SPATIAL	Select the desired animation (highlighted in blue)

Defining the PLANE function



Show the soft-key row with special functions

- TILT MACHINING PLANE
- Press the TILT MACHINING PLANE soft key
- The control displays the available PLANE functions in the soft-key row.
- Select the PLANE function



Selecting functions

- Press the soft key linked to the desired function
- > The control continues the dialog and prompts you for the required parameters.

Selecting the function while animation is active

- Press the soft key linked to the desired function
- > The control plays the animation.
- To apply the currently active function, press the soft key of that function again or press the ENT key

Position display

As soon as a **PLANE** function (except **PLANE AXIAL**) is active, the control shows the calculated spatial angle in the additional status display.

During tilting into position (**MOVE** or **TURN** mode), the control shows, in the rotary axis, the distance to go to the calculated final position of the rotary axis in the distance-to-go display (**ACTDST** and **REFDST**).



Resetting PLANE function

Example

25 PLANE RESET MOVE DIST50 F1000		
SPEC FCT	Show the soft-key row with special functions	
TILT MACHINING PLANE RESET	 Press the TILT MACHINING PLANE soft key The control displays the available PLANE functions in the soft-key row Select the reset function 	
MOVE END	 Specify whether the control should automatically move the tilting axes to home position (MOVE or TURN) or not (STAY) Further information: "Automatic tilting into position MOVE/TURN/STAY", Page 431 Press the END key. 	
1	The PLANE RESET function resets the active tilt and the angles (PLANE function or Cycle 19) (angle = 0 and function inactive). It does not need to be defined more than once. Deactivate tilting in the Manual operation mode in the 3-D ROT menu.	
	Further information: User's Manual for Setup, Testing and Running NC Programs	

Defining the working plane with the spatial angle: PLANE SPATIAL

Application

Spatial angles define a working plane through up to three rotations in the non-tilted workpiece coordinate system (**tilting sequence A-B-C**).

Most users assume three successive rotations in reverse order (**tilting sequence C-B-A**).

The result is identical for both perspectives, as the following comparison shows.


Example

PLANE SPATIAL SPA+45 SPB+0 SPC+90 ...

A-B-C

Home position A0° B0° C0°

Home position A0° B0° C0°





C+90°

HEIDENHAIN

C-B-A

Z






Z

 $\times)$


B+0°





C+90°



 $\langle \rangle$







Tilting order A-B-C:

- 1 Tilt about the non-tilted X axis of the workpiece coordinate system
- 2 Tilt about the non-tilted Y axis of the workpiece coordinate system
- 3 Tilt about the non-tilted Z axis of the workpiece coordinate system

Tilting order C-B-A:

- 1 Tilt about the non-tilted Z axis of the workpiece coordinate system
- 2 Tilt about the tilted Y axis
- 3 Tilt about the tilted X axis

Programming notes:

- You must always define all three spatial angles SPA, SPB and SPC, even if one or more have the value 0.
- Depending on the machine, Cycle **19** requires you to enter spatial angles or axis angles. If the configuration (machine parameter setting) allows the input of spatial angles, the angle definition is the same in Cycle **19** and in the **PLANE SPATIAL** function.
- You can select the desired positioning behavior.
 Further information: "Defining the positioning behavior of the PLANE function", Page 430


Input parameters Example

5 PLANE SPATIAL SPA+27 SPB+0 SPC+45




i

- Spatial angle A?: Rotational angle SPA about the (non-tilted) X axis. Input range from -359.9999 to +359.9999
- Spatial angle B?: Rotational angle SPB about the (non-tilted) Y axis. Input range from -359.9999 to +359.9999
- Spatial angle C?: Rotational angle SPC about the (non-tilted) Z axis. Input range from -359.9999 to +359.9999
- Continue with the positioning properties
 Further information: "Defining the positioning behavior of the PLANE function", Page 430



Abbreviations used

Abbreviation	Meaning
SPATIAL	In space
SPA	$\ensuremath{\textbf{Sp}}\xspace$ at the second s
SPB	Sp atial B : Rotation about the (non-tilted) Y axis
SPC	Sp atial C : Rotation about the (non-tilted) Z axis



Defining the working plane with the projection angle: PLANE PROJECTED


Application

Projection angles define a machining plane through the entry of two angles that you determine by projecting the first coordinate plane (Z/X plane with tool axis Z) and the second coordinate plane (Y/Z with tool axis Z) onto the machining plane to be defined.



Programming notes:


- The projection angles correspond to the angle projections on the planes of a rectangular coordinate system. The angles at the outer faces of the workpiece only are identical to the projection angles if the workpiece is rectangular. Thus, with workpieces that are not rectangular, the angle specifications from the engineering drawing often differ from the actual projection angles.
- You can select the desired positioning behavior.
 Further information: "Defining the positioning behavior of the PLANE function", Page 430




Input parameters



- Projection angle on 1st Coordinate plane?: Projected angle of the tilted machining plane in the 1st coordinate plane of the untilted coordinate system (Z/X for tool axis Z). Input range: from –89.9999° to +89.9999°. The 0° axis is the principal axis of the active working plane (X for tool axis Z, positive direction)
- Proj. angle on 2nd Coordinate plane?: Projected angle in the 2nd coordinate plane of the untilted coordinate system (Y/Z for tool axis Z). Input range: from -89.9999° to +89.9999°. The 0° axis is the minor axis of the active machining plane (Y for tool axis Z)
- ROT angle of tilted plane?: Rotation of the tilted coordinate system around the tilted tool axis (corresponds to a rotation with Cycle 10). The rotation angle provides an easy way to specify the direction of the principal axis of the working plane (X for tool axis Z, Z for tool axis Y). Input range: -360° to +360°
- Continue with the positioning properties
 Further information: "Defining the positioning behavior of the PLANE function", Page 430





Example

5 PLANE PROJECTED PROPR+24 PROMIN+24 ROT+30

Abbreviations used:

PROJECTED	Projected
PROPR	Principal plane
PROMIN	Minor plane
ROT	Rotation


Defining the working plane with the Euler angle: PLANE EULER

Application

Euler angles define a machining plane through up to three **rotations about the respectively tilted coordinate system**. The Swiss mathematician Leonhard Euler defined these angles.

6

You can select the desired positioning behavior. **Further information:** "Defining the positioning behavior of the PLANE function", Page 430




Input parameters

- PROJECTED
- Rot. angle Main coordinate plane?: Rotary angle EULPR around the Z axis. Please note:
 - Input range: -180.0000° to 180.0000°
 - The 0° axis is the X axis
- Tilting angle tool axis?: Tilting angle EULNUT of the coordinate system around the X axis shifted by the precession angle. Please note:
 - Input range: 0° to 180.0000°
 - The 0° axis is the Z axis
- ROT angle of tilted plane?: EULROT rotation of the tilted coordinate system around the tilted Z axis (corresponds to a rotation with Cycle 10). Use the rotation angle to easily define the direction of the X axis in the tilted working plane. Please note:
 - Input range: 0° to 360.0000°
 - The 0° axis is the X axis
- Continue with the positioning properties
 Further information: "Defining the positioning behavior of the PLANE function", Page 430


Example


5 PLANE EULER EULPR45 EULNU20 EULROT22



Abbreviations used

Abbreviation	Meaning
EULER	Swiss mathematician who defined these angles
EULPR	Pr ecession angle: angle describing the rotation of the coordinate system around the Z axis
EULNU	Nu tation angle: angle describing the rotation of the coordinate system around the X axis shifted by the precession angle
EULROT	Rot ation angle: angle describing the rotation of the tilted machining plane around the tilted Z axis





Defining the working plane with two vectors: PLANE VECTOR

Application


You can use the definition of a working plane via **two vectors** if your CAD system can calculate the base vector and normal vector of the tilted machining plane. A normalized input is not necessary. The control internally calculates the normal, so you can enter values between -9.999999 and +9.999999.

The base vector required for the definition of the machining plane is defined by the components **BX**, **BY** and **BZ**. The normal vector is defined by the components **NX**, **NY** and **NZ**.



Programming notes:

- The control calculates standardized vectors from the values you enter.
- The normal vector defines the slope and the orientation of the working plane. The base vector defines the orientation of the main axis X in the defined working plane. To ensure that the definition of the working plane is unambiguous, you must program the vectors perpendicular to each other. The machine tool builder defines how the control will behave for vectors that are not perpendicular.
- The programmed normal vector must not be too short, e.g. all directional components having a length of 0 or 0.0000001. In this case, the control would not be able to determine the slope. Machining is aborted and an error message is displayed. This behavior is independent of the configuration of the machine parameters.
- You can select the desired positioning behavior.
 Further information: "Defining the positioning behavior of the PLANE function", Page 430





Refer to your machine manual!

The machine tool builder configures the behavior of the control with vectors that are not perpendicular.

Alternatively to generating the default error message, the control can correct (or replace) the base vector that is not perpendicular. This correction (or replacement) does not affect the normal vector.

Default correction behavior of the control if the base vector is not perpendicular:

The base vector is projected along the normal vector onto the working plane (defined by the normal vector).

Correction behavior of the control if the base vector is not perpendicular and too short, parallel or antiparallel to the normal vector:

- If the normal vector has no X component, the base vector corresponds to the original X axis
- If the normal vector has no Y component, the base vector corresponds to the original Y axis

Input parameters




- X component of base vector?: X component BX of the base vector B; input range: from -9.9999999 to +9.9999999
- Y component of base vector?: Y component BY of the base vector B; input range: from -9.9999999 to +9.9999999
- Z component of base vector?: Z component BZ of the base vector B; input range: from -9.9999999 to +9.9999999
- X component of normal vector?: X component NX of the normal vector N; input range: from -9.9999999 to +9.9999999
- Y component of normal vector?: Y component NY of the normal vector N; input range: from -9.9999999 to +9.9999999
- Z component of normal vector?: Z component NZ of the normal vector N; input range: from -9.9999999 to +9.9999999
- Continue with the positioning properties
 Further information: "Defining the positioning behavior of the PLANE function", Page 430


Example


5 PLANE VECTOR BX0.8 BY-0.4 BZ-0.42 NX0.2 NY0.2 NZ0.92 ..

Abbreviations used

Abbreviation	Meaning
VECTOR	Vector
BX, BY, BZ	Base vector : X, Y, and Z components
NX, NY, NZ	Normal vector : X, Y, and Z components








Defining the working plane via three points: PLANE POINTS

Application

F)

A working plane can be uniquely defined by entering **any three points P1 to P3 in this plane**. This possibility is realized in the **PLANE POINTS** function.

- Programming notes:
- The three points define the slope and orientation of the plane. The position of the active datum is not changed through **PLANE POINTS**.
- Point 1 and Point 2 determine the orientation of the tilted main axis X (for tool axis Z).
- Point 3 defines the slope of the tilted working plane. In the defined working plane, the Y axis is automatically oriented perpendicularly to the main axis X. The position of Point 3 thus also determines the orientation of the tool axis and consequently the orientation of the working plane. To have the positive tool axis pointing away from the workpiece, Point 3 must be located above the connection line between Point 1 and Point 2 (right-hand rule).
- You can select the desired positioning behavior.
 Further information: "Defining the positioning behavior of the PLANE function", Page 430



Input parameters



- X coordinate of 1stplane point?: X coordinate P1X of the 1st plane point
- Y coordinate of 1stplane point?: Y coordinate P1Y of the 1st plane point
- Z coordinate of 1stplane point: Z coordinate P1Z of the 1st plane point
- X coordinate of 2ndplane point?: X coordinate P2X of the 2nd plane point
- Y coordinate of 2ndplane point?: Y coordinate P2Y of the 2nd plane point
- Z coordinate of 2ndplane point?: Z coordinate P2Z of the 2nd plane point
- X coordinate of 3rdplane point?: X coordinate P3X of the 3rd plane point
- Y coordinate of 3rdplane point?: Y coordinate P3Y of the 3rd plane point
- Z coordinate of 3rdplane point?: Z coordinate P3Z of the 3rd plane point
- Continue with the positioning properties
 Further information: "Defining the positioning behavior of the PLANE function", Page 430

Example


5 PLANE POINTS P1X+0 P1Y+0 P1Z+20 P2X+30 P2Y+31 P2Z+20 P3X+0 P3Y+41 P3Z+32.5


Abbreviations used


Abbreviation Meaning

Points

POINTS







Defining the working plane via a single incremental spatial angle: PLANE RELATIV

Application

A

Use a relative spatial angle when an already active tilted working plane is to be tilted by **another rotation**. Example: machining a 45° chamfer on a tilted plane.

Programming notes:

- The defined angle is always in effect in respect to the active working plane, regardless of the tilting function you used before.
- You can program any number of PLANE RELATIV functions in a row..
- If you want to return the working plane to the orientation that was active before the PLANE RELATIV function, define the same PLANE RELATIV function again but enter the value with the opposite algebraic sign.
- If you use PLANE RELATIV without previous tilting, PLANE RELATIV will be effective directly in the workpiece coordinate system. In this case, you can tilt the original working plane by entering a defined spatial angle in the PLANE RELATIV function.
- You can select the desired positioning behavior.
 Further information: "Defining the positioning behavior of the PLANE function", Page 430


Input parameters




- Incremental angle?: Spatial angle by which the active machining plane is to be rotated. Use a soft key to select the axis to be rotated around. Input range: -359.9999° to +359.9999°
- Continue with the positioning properties
 Further information: "Defining the positioning behavior of the PLANE function", Page 430

Example

5 PLANE RELATIV SPB-45		
Abbreviations used		
Abbreviation	Meaning	
RELATIVE	Relative to	






Tilting the working plane through axis angle: PLANE AXIAL

Application

The **PLANE AXIAL** function defines both the slope and the orientation of the working plane and the nominal coordinates of the rotary axes.

OI Th ac de Si ar of of	LANE AXIAL can also be used on machines that have here input of nominal coordinates (axis angle input) is dvantageous in that it provides an unambiguously efined tilting situation based on defined axis positions. Datial angles entered without an additional definition e often mathematically ambiguous. Without the use a CAM system, entering axis angles, in most cases, here mathematically axes are positioned erpendicularly.
	efer to your machine manual! your machine allows spatial angle definitions, you can ontinue your programming with PLANE RELATIV after _ANE AXIAL .
•	function. Entering 0 only resets the axis angle, but does not deactivate the tilting function. The axis angles of the PLANE AXIAL function are modally effective. If you program an incremental axis angle, the control will add this value to the currently effective axis angle. If you program two different rotary axes in two successive PLANE AXIAL functions, the new working plane is derived from the two defined axis angles.




Input parameters Example

5 PLANE AXIAL B-45

A	IA	4	
N	t	1	
 1	16	4	~
1.			1

Axis angle A?: Axis angle to which the A axis
is to be tilted. If entered incrementally, it is the
angle by which the A axis is to be tilted from its
current position. Input range: –99999.9999° to +99999.9999°

- Axis angle B?: Axis angle to which the B axis is to be tilted. If entered incrementally, it is the angle by which the B axis is to be tilted from its current position. Input range: -99999.9999° to +99999.9999°
- Axis angle C?: Axis angle to which the C axis is to be tilted. If entered incrementally, it is the angle by which the C axis is to be tilted from its current position. Input range: –99999.9999° to +99999.9999°
- Continue with the positioning properties
 Further information: "Defining the positioning behavior of the PLANE function", Page 430



Abbreviations used

Abbreviation	Meaning
AXIAL	In the axial direction

Defining the positioning behavior of the PLANE function

Overview

Independently of which PLANE function you use to define the tilted machining plane, the following functions are always available for the positioning behavior:

- Automatic positioning
- Selecting alternate tilting options (not for PLANE AXIAL)
- Selecting the type of transformation (not for PLANE AXIAL)

NOTICE

Danger of collision!

Cycle **8 MIRRORING** can have different effects in conjunction with the **Tilt working plane** function. The programming sequence, the mirrored axes, and the tilting function used are critical in this regard. There is a risk of collision during the tilting operation and subsequent machining!

- Check the sequence and positions using a graphic simulation
- Carefully test the NC program or program section in the Program run, single block operating mode

Examples

- 1 When Cycle **8 MIRRORING** is programmed before the tilting function without rotary axes:
 - The tilt of the PLANE function used (except PLANE AXIAL) is mirrored
 - Mirroring takes effect after tilting with PLANE AXIAL or Cycle 19
- 2 When Cycle **8 MIRRORING** is programmed before the tilting function with a rotary axis:
 - The mirrored rotary axis has no effect on the tilt specified in the **PLANE** function used, because only the movement of the rotary axis is mirrored

Automatic tilting into position MOVE/TURN/STAY

After you have entered all of the parameters for the plane definition, you must specify how the control is to tilt the rotary axes to the calculated axis value. This entry is mandatory.

The control offers the following ways of tilting the rotary axes to the calculated axis values:



- The PLANE function is to automatically tilt the rotary axes to the calculated axis values, with the relative position between the tool and the workpiece remaining the same.
- > The control carries out a compensating movement in the linear axes.
- The PLANE function is to automatically tilt the rotary axes to the calculated axis values, during which only the rotary axes are positioned.
- The control does **not** carry out a compensating movement in the linear axes.
- You tilt the rotary axes into position in a subsequent, separate positioning block


If you have selected the **MOVE** option (**PLANE** function is to automatically tilt into position with a compensation movement), then the two subsequently explained parameters **Dist. tool tip center of rot.** and **Feed rate? F=** must still be defined.

If you have selected the **TURN** option (**PLANE** function is to automatically tilt into position without compensation movement), then the subsequently explained **Feed rate?** parameter F= must still be defined.


As an alternative to a feed rate **F** defined directly by a numerical value, you can also tilt the axes into position with **FMAX** (rapid traverse) or **FAUTO** (feed rate from the **TOOL CALL** block).





If you use **PLANE** together with **STAY**, you have to position the rotary axes in a separate block after the **PLANE** function.



- Dist. tool tip center of rot. (incremental): The DIST parameter shifts the center of rotation of the tilting movement relative to the current position of the tool tip.
 - If the tool is already at the specified distance from the workpiece prior to being tilted into position, then it will be at the same relative position after being tilted into position (see center figure on the right, 1 = DIST)
 - If the tool is not at the specified distance from the workpiece before being tilted into position, then it will be offset relative to the original position after being tilted into position (see lower figure on the right, 1 = DIST)
- > The control tilts the tool (or table) relative to the tool tip.
- Feed rate? F=: Contour speed at which the tool is to be tilted into position
- Retraction length in the tool axis?: The retraction path MB takes effect incrementally from the current tool position in the active tool axis direction that the control approaches before tilting. MB MAX moves the tool to a position just before the software limit switch







Tilting the rotary axes into position in a separate NC block

To tilt the rotary axes into position in a separate positioning block (**STAY** option selected), proceed as follows:

NOTICE

Danger of collision!

The control does not automatically check whether collisions can occur between the tool and the workpiece. Incorrect or no prepositioning before tilting the tool into position can lead to a risk of collision during the tilting movement!

- Program a safe position before the tilting movement
- Carefully test the NC program or program section in the Program run, single block operating mode
- Select any PLANE function, and define automatic tilting into position with STAY. During program run, the control calculates the position values of the rotary axes present on the machine, and stores them in the system parameters Q120 (A axis), Q121 (B axis), and Q122 (C axis)
- Define the positioning block with the angular values calculated by the control

Example: Tilt a machine with a rotary table C and a tilting table A to a spatial angle of B+45

•••	
12 L Z+250 R0 FMAX	Position at clearance height
13 PLANE SPATIAL SPA+0 SPB+45 SPC+0 STAY	Define and activate the PLANE function
14 L A+Q120 C+Q122 F2000	Position the rotary axis with the values calculated by the control.
	Define machining in the tilted working plane

Selection of tilting possibilities SYM (SEQ) +/-

Based on the position that you have defined for the working plane, the control must calculate the appropriate position of the rotary axes present on your machine. In general, there are always two possible solutions.

For the selection of one of the possible solutions, the control offers two variants: **SYM** and **SEQ**. You use soft keys to choose the variants. **SYM** is the standard variant.

The entry of **SYM** or **SEQ** is optional.

SEQ assumes that the master axis is in its home position (0°). Relative to the tool, the master axis is the first rotary axis or the last rotary axis relative to the table (depending on the machine configuration). If both possible solutions are in the positive or negative range, then the control automatically uses the closer solution (shorter path). If you need the second possible solution, then you must either pre-position the master axis (in the area of the second possible solution) before tilting the working plane, or work with **SYM**.


Unlike **SEQ**, **SYM** uses the symmetry point of the master axis as its reference. Every master axis has two symmetry positions, which are 180° apart from each other (sometimes only one symmetry position is in the traverse range).


- Determine the symmetry point in the following manner:
 - Perform PLANE SPATIAL with any spatial angle and SYM+
 - Save the axis angle of the master axis in a Q parameter, (e.g., -100)
 - Repeat the PLANE SPATIAL function with SYM-
 - Save the axis angle of the master axis in a Q parameter (e.g., –80)
 - Calculate the average value (e.g., -90)
 - The average value corresponds to the symmetry point.

Reference for SEQ

i


Reference for SYM





With the **SYM** function, you select one of the possible solutions relative to the symmetry point of the master axis:

- SYM+ positions the master axis in the positive half-space relative to the symmetry point
- SYM- positions the master axis in the negative half-space relative to the symmetry point



With the **SEQ** function, you select one of the possible solutions relative to the home position of the master axis:

- SEQ+ positions the master axis in the positive tilting range relative to home position
- SEQ- positions the master axis in the negative tilting range relative to home position

If the solution you have selected with **SYM** (**SEQ**) is not within the machine's range of traverse, then the control displays the **Entered angle not permitted** error message.



If the **PLANE AXIAL** function is used, the **SYM (SEQ)** function has no effect.

If you do not define $\ensuremath{\textbf{SYM}}$ (SEQ), then the control determines the solution as follows:

- 1 Check whether both possible solutions are within the traverse range of the rotary axes
- 2 Two possible solutions: Based on the current position of the rotary axes, choose the possible solution with the shortest path
- 3 One possible solution: Choose the only solution
- 4 No possible solution: Issue the error message **Entered angle not permitted**

Examples

Machine with C rotary axis and A tilting table. Programmed function: PLANE SPATIAL SPA+0 SPB+45 SPC+0

Limit switch	Start position	SYM = SEQ	Resulting axis position
None	A+0, C+0	Not prog.	A+45, C+90
None	A+0, C+0	+	A+45, C+90
None	A+0, C+0	_	A–45, C–90
None	A+0, C–105	Not prog.	A–45, C–90
None	A+0, C–105	+	A+45, C+90
None	A+0, C–105	_	A–45, C–90
-90 < A < +10	A+0, C+0	Not prog.	A–45, C–90
-90 < A < +10	A+0, C+0	+	Error message
-90 < A < +10	A+0, C+0	-	A–45, C–90

Machine with B rotary axis and A tilting table (limit switches: A +180 and -100). Programmed function: PLANE SPATIAL SPA-45 SPB+0 SPC+0

SYM	SEQ	Resulting axis position	Kinematics view
+		A–45, B+0	XLz
-		Error message	No solution in limited range
	+	Error message	No solution in limited range
	-	A–45, B+0	XLz
6	the kinemat switching th point chang Depending	n of the symmetry point is contice. If you change the kinemane head), then the position of es as well. on the kinematics, the positive of SYM may not correspond to	itics (such as the symmetry re direction

of rotation of **SYM** may not correspond to the positive direction of rotation of **SEQ**. Therefore, ascertain the position of the symmetry point and the direction of rotation of **SYM** on each machine before programming.

Selection of the transformation type

The **COORD ROT** and **TABLE ROT** transformation types influence the orientation of the working plane coordinate system through the axis position of a so-called free rotary axis.

The entry of COORD ROT or TABLE ROT is optional.

Any rotary axis becomes a free rotary axis with the following configuration:


- The rotary axis has no effect on the tool angle of inclination because the rotary axis and the tool axis are parallel in the tilting situation
- The rotary axis is the first rotary axis in the kinematic chain starting from the workpiece

The effect of the **COORD ROT** and **TABLE ROT** transformation types therefore depends on the programmed spatial angles and the machine kinematics.



Programming notes:

- If no free rotary axis arises in a tilting situation, then the COORD ROT and TABLE ROT transformation types have no effect.
- With the PLANE AXIAL function, the COORD ROT and TABLE ROT transformation types have no effect.



Effect with a free rotary axis



Programming	notes
-------------	-------

- For the positioning behavior with the COORD ROT and TABLE ROT transformation types, it makes no difference whether the free rotary axis is a table axis or a head axis.
- The resulting axis position of the free rotary axis depends on an active basic rotation, among other factors.
- The orientation of the working plane coordinate system also depends on a programmed rotation; for example, by means of Cycle **10 ROTATION**.

Soft key	Function
ROT	COORD ROT:
Z,	> The control positions the free rotary axis to 0
	 The control orients the working plane coordinate system in accordance with the programmed spatial angle
ROT	TABLE ROT with:
\square	SPA and SPB equal to 0
	SPC equal or unequal to 0
	 The control orients the free rotary axis in accordance with the programmed spatial angle
	 The control orients the working plane coordinate system in accordance with the basic coordinate system
	TABLE ROT with:
	At least SPA or SPB unequal to 0
	SPC equal or unequal to 0
	 The control does not position the free rotary axis. The position prior to tilting the working plane is maintained
	 Since the workpiece was not positioned, the control orients the working plane coordinate system in accordance with the programmed spatial angle

uses the **COORD ROT** transformation type for the **PLANE** functions

Example


The following example shows the effect of the **TABLE ROT** transformation type in conjunction with a free rotary axis.

6	н.	B±45	ΡΛ	FMAX
0		D + J	NU	

7 PLANE SPATIAL SPA-90 SPB+20 SPC+0 TURN F5000 TABLE ROT Pre-position rotary axis Tilt the working plane

•••

•••



- > The control positions the B axis to the axis angle B+45
- > With the programmed tilting situation with SPA–90, the B axis becomes the free rotary axis
- The control does not position the free rotary axis. The position of the B axis prior to the tilting of the working plane is maintained
- Since the workpiece was not also positioned, the control orients the working plane coordinate system in accordance with the programmed spatial angle SPB+20

Tilting the working plane without rotary axes



Refer to your machine manual!

This function must be enabled and adapted by the machine tool builder.

The machine tool builder must take the precise angle into account, e.g. the angle of a mounted angular head in the kinematics description.

You can also orient the programmed working plane perpendicularly to the tool without defining rotary axes, e.g. when adapting the working plane for a mounted angular head.

Use the **PLANE SPATIAL** function and the **STAY** positioning behavior to swivel the working plane to the angle specified by the machine tool builder.

Example of mounted angular head with permanent tool direction Y:

Example

TOOL CALL 5 Z S4500

PLANE SPATIAL SPA+0 SPB-90 SPC+0 STAY



The tilt angle must be precisely adapted to the tool angle, otherwise the control will generate an error message.

11.3 Inclined-tool machining in a tilted plane (option 9)

Function


i

In combination with **M128** and the new **PLANE** functions, **inclined-tool machining** on a tilted machining plane is now possible. Two possibilities are available for definition:

- Inclined-tool machining via incremental traverse of a rotary axis
- Inclined-tool machining via normal vectors

Inclined-tool machining in a tilted machining plane only works with spherical cutters. If you are using 45° swivel heads and tilting tables, you can also define the incline angle as a spatial angle. Use **FUNCTION TCPM** for this purpose.

Further information: "FUNCTION TCPM (option 9)", Page 450



Inclined-tool machining via incremental traverse of a rotary axis

- Retract the tool
- Define any PLANE function; consider the positioning behavior
- Activate M128
- Via a straight-line block, traverse to the desired incline angle in the appropriate axis incrementally

12 L Z+50 R0 FMAX	Position at clearance height
13 PLANE SPATIAL SPA+0 SPB-45 SPC+0 MOVE DIST50 F1000	Define and activate the PLANE function
14 M128	Activate M128
15 L IB-17 F1000	Set the incline angle
	Define machining in the tilted working plane

Inclined-tool machining via normal vectors



Only one directional vector can be defined in the LN block. This vector defines the incline angle (normal vector NX, NY, NZ or tool directional vector TX, TY, TZ).

- Retract the tool
- Define any PLANE function; consider the positioning behavior
- Activate M128
- Execute NC program with LN blocks in which the tool direction is defined by a vector

12 L Z+50 R0 FMAX	Position at clearance height
13 PLANE SPATIAL SPA+0 SPB+45 SPC+0 MOVE DIST50 F1000	Define and activate the PLANE function
14 M128	Activate M128
15 LN X+31.737 Y+21.954 Z+33.165 NX+0.3 NY+0 NZ +0.9539 F1000 M3	Set the incline angle with the normal vector
	Define machining in the tilted working plane

11.4 Miscellaneous functions for rotary axes

Feed rate in mm/min on rotary axes A, B, C: M116 (option 8)

Standard behavior

 $(\overline{\mathbf{O}})$

A

The control interprets the programmed feed rate of a rotary axis in degrees/min (in mm programs and also in inch programs). The feed rate therefore depends on the distance from the tool center to the center of the rotary axis.

The larger this distance becomes, the greater the contouring feed rate.

Feed rate in mm/min on rotary axes with M116

Refer to your machine manual! The machine geometry must be specified by the machine tool builder in the kinematics description.

Programming notes:

- The **M116** function can be used with table axes and head axes.
- The M116 function also has an effect if the Tilt working plane function is active.
- It is not possible to combine the M128 or TCPM function with M116. If you want to activate M116 for an axis while the M128 or TCPM function is active, then you must indirectly deactivate the compensating movement for this axis using M138. This is done indirectly because, with M138, you specify the axis for which the M128 or TCPM function takes effect. Thus, M116 automatically affects the axis that was not selected with M138.
 Further information: "Selecting tilting axes: M138", Page 448
- Without the M128 or TCPM function, M116 can take effect for two rotary axes at the same time.

The control interprets the programmed feed rate of a rotary axis in mm/min (or 1/10 inch/min). In this case, the control calculates the feed for the block at the start of each NC block. The feed rate of a rotary axis will not change while the NC block is executed, even if the tool moves toward the center of the rotary axis.

Effect

M116 is effective in the working plane. Reset **M116** with **M117**. At the end of the program, **M116** is automatically canceled.

M116 becomes effective at the start of the block.

Shorter-path traverse of rotary axes: M126

Standard behavior

 \odot

Refer to your machine manual!

The positioning behavior of rotary axes is machinedependent.

M126 has an effect only on modulo axes.

In the case of modulo axes, the axis position begins again at 0° after the modulo length of $0^{\circ} - 360^{\circ}$ has been exceeded. This is the case for rotary axes that are mechanically capable of endless rotation.

In the case of non-modulo axes, the maximum rotation is mechanically limited. The position display of the rotary axis does not switch back to the starting value (e.g., $0^{\circ} - 540^{\circ}$).

The machine parameter **shortestDistance** (no. 300401) defines the standard behavior for the positioning of rotary axes. It is effective only for rotary axes whose position display is limited to a range of traverse of less than 360°. If the parameter is inactive, then the control traverses the programmed value from the actual position to the nominal position. If the parameter is active, then the control moves to the nominal position on the shortest path (even without **M126**).

Behavior without M126:

Without **M126**, the control moves a rotary axis whose position display is reduced to less than 360° along a long path. Examples:

Actual position	Nominal position	Range of traverse
350°	10°	–340°
10°	340°	+330°

Behavior with M126

With **M126**, the control moves a rotary axis whose position display is reduced to less than 360° on the shortest path of traverse. Examples:

Actual position	Nominal position	Range of traverse
350°	10°	+20°
10°	340°	–30°

Effect

M126 takes effect at the start of the block.

M127 and a program end reset M126.

Reducing display of a rotary axis to a value less than 360°: M94

Standard behavior

The control moves the tool from the current angular value to the programmed angular value.

Example:

Current angular value:	538°
Programmed angular value:	180°
Actual distance of traverse:	-358°

Behavior with M94

At the start of block, the control first reduces the current angular value to a value less than 360° and then moves the tool to the programmed value. If multiple rotary axes are active, **M94** will reduce the display of all rotary axes. As an alternative, you can specify a rotary axis after **M94**. The control then reduces the display of this axis only.

If you entered a traverse limit or a software limit switch is active, M94 is ineffective for the corresponding axis.

Example: Reduce the display of all active rotary axes

L M94

Example: Reduce the display of the C axis

L M94 C

Example: Reduce the display of all active rotary axes and then move the tool in the C axis to the programmed value

L C+180 FMAX M94

Effect

 $\boldsymbol{\textbf{M94}}$ is effective only in the NC block where it is programmed.

M94 becomes effective at the start of the block.

Retaining the position of the tool tip during the positioning of tilting axes (TCPM): M128 (option 9)

Standard behavior

If the inclination angle of the tool changes, this results in an offset of the tool tip compared to the nominal position. The control does not compensate for this offset. If the operator does not take this deviation into account in the NC program, offset machining is executed.

Behavior with M128 (TCPM: Tool Center Point Management)

If the position of a controlled tilting axis changes in the NC program, then the position of the tool tip relative to the workpiece remains unchanged.

NOTICE

Danger of collision!

Rotary axes with Hirth coupling must move out of the coupling to enable tilting. There is a danger of collision while the axis moves out of the coupling and during the tilting operation.


Retract the tool before changing the position of the tilting axis

After **M128**, you can still enter a maximum feed rate at which the control will carry out the compensating movements in the linear axes.

If you want to change the position of the tilting axis with the handwheel during program run, then use **M128** in conjunction with **M118**. The superimposing of handwheel positioning is performed with active **M128**, depending on the setting in the 3D ROT menu of **Manual operation** mode, in the active coordinate system or in the non-tilted coordinate system.

Programming notes:

- Before positioning with M91 or M92, and before a TOOL CALL block, reset the M128 function
- To avoid contour damage, use only radius cutters with M128
- The tool length must be measured from the spherical center of the Ball-nose cutter
- If M128 is active, then the control shows the TCPM symbol in the status display



i

M128 on tilting tables

If you program a tilting table movement while **M128** is active, then the control rotates the coordinate system accordingly. For example, if you rotate the C axis by 90° (through a positioning or datum shift) and then program a movement in the X axis, then the control executes the movement in the machine Y axis.

The control also transforms the set preset, which has been shifted by the movement of the rotary table.

M128 with three-dimensional tool compensation

If you carry out a three-dimensional tool compensation with active **M128** and active radius compensation **RL/RR**, then the control will automatically position the rotary axes for certain machine geometries (peripheral milling).

Further information: "Three-dimensional tool compensation (option 9)", Page 456

Effect

M128 takes effect at the start of the block, and **M129** takes effect at the end of the block. **M128** also takes effect in the manual operating modes and remains active even after a change in the operating mode. The feed rate for the compensating movement remains in effect until you program a new feed rate or reset **M128** with **M129**.

You can reset **M128** with **M129**. The control also resets **M128** when you select a new NC program in a program run mode.

Example: Perform compensation movements at a feed rate of no more than 1000 mm/min

L X+0 Y+38.5 IB-15 RL F125 M128 F1000

Inclined-tool machining with non-controlled rotary axes

If your machine has non-controlled rotary axes (so-called counter axes), then you can also perform inclined machining operations with these axes in conjunction with **M128**.

Proceed as follows:

- 1 Manually traverse the rotary axes to the desired positions. **M128** must not be active during this operation
- 2 Activate **M128**: the control reads the actual values of all existing rotary axes, calculates from this the new position of the tool center point, and updates the position display
- 3 The control performs the necessary compensating movement in the next positioning block
- 4 Execute the machining operation
- 5 At program end, reset **M128** with **M129**, and return the rotary axes to their initial positions

As long as M128 is active, the control monitors the actual positions of the non-controlled rotary axes. If the actual position deviates from the value that is definable by the machine manufacturer, then the control issues an error message and interrupts program run.

Selecting tilting axes: M138

Standard behavior

With the functions **M128**, **TCPM** and **Tilt working plane**, the control considers those rotary axes that have been specified by the machine tool builder in the machine parameters.

Behavior with M138

The control performs the above functions only in those tilting axes that you have defined using **M138**.



Refer to your machine manual!

If you restrict the number of tilting axes with the **M138** function, your machine may provide only limited tilting possibilities. The machine tool builder will decide whether the control takes the angles of deselected axes into account or sets them to 0.

Effect

M138 becomes effective at the start of the block.

You can cancel **M138** by reprogramming it without specifying any axes.

Example

Perform the above-mentioned functions only in the tilting axis C.

L Z+100 R0 FMAX M138 C

Compensating the machine kinematics in ACTUAL/ NOMINAL positions at end of block: M144 (Option 9)

Standard behavior

If the kinematics change, e.g. by inserting an adapter spindle or entering an inclination angle, the control will not compensate this modification. If the operator does not consider this modification to the kinematics for the NC program, machining will occur with an offset.

Behavior with M144

Refer to your machine manual! The machine geometry must be specified by the machine tool builder in the kinematics description.

The **M144** function enables the control to consider the modification to the machine kinematics in the position display and compensate the offset of the tool tip in relation to the workpiece.



(0)

Programming and operating notes:

- Positioning blocks with M91 or M92 are permitted while M144 is active.
- The position display in the Program Run Full Sequence and Program Run Single Block operating modes does not change until the tilting axes have reached their final position.

Effect

M144 becomes effective at the start of the block. **M144** does not work in connection with **M128** or the Tilt Working Plane function. You can cancel **M144** by programming **M145**.

11.5 FUNCTION TCPM (option 9)

Function



Refer to your machine manual!

The machine geometry must be specified by the machine tool builder in the kinematics description.

FUNCTION TCPM is an improvement on the **M128** function, with which you can define the behavior of the control during the positioning of rotary axes. With **FUNCTION TCPM**, you can define the effects of various functions yourself:

- Effect of the programmed feed rate: F TCP / F CONT
- Interpretation of the rotary axis coordinates programmed in the NC program: AXIS POS / AXIS SPAT
- Type of orientation interpolation between the start and end positions: PATHCTRL AXIS / PATHCTRL VECTOR
- Optional selection of a tool reference point and a center of rotation: REFPNT TIP-TIP / REFPNT TIP-CENTER / REFPNT CENTER-CENTER
- Maximum feed rate at which the control performs the compensation movements in the linear axes: F

If **FUNCTION TCPM** is active, the control shows the **TCPM** symbol in the position display.

NOTICE

Danger of collision!

Rotary axes with Hirth coupling must move out of the coupling to enable tilting. There is a danger of collision while the axis moves out of the coupling and during the tilting operation.

Retract the tool before changing the position of the tilting axis

Programming notes:

- Before positioning axes with M91 or M92, and before a TOOL CALL block, reset the FUNCTION TCPM function.
- Use only Ball-nose cutters for face milling operations in order to avoid contour damage. In combination with other tool shapes, you should use the graphic simulation to test the NC program for possible contour damage.

Defining FUNCTION TCPM




A

Select the special functions



Select the programming aids

FUNCTION TCPM Select FUNCTION TCPM



Effect of the programmed feed rate


The control provides two functions for defining the effect of the programmed feed rate:



► F TCP determines that the programmed feed rate is interpreted as the actual relative velocity between the tool tip (tool center point) and the workpiece



F CONT determines that the programmed feed rate is interpreted as the contouring feed rate of the axes programmed in the respective NC block.



13 FUNCTION TCPM F TCP	Feed rate refers to the tool tip
14 FUNCTION TCPM F CONT	Feed rate is interpreted as the speed of the tool along the contour

Interpretation of the programmed rotary axis coordinates

Up to now, machines with 45° swivel heads or 45° tilting tables could not easily set the angle of inclination or a tool orientation with respect to the currently active coordinate system (spatial angle). This function could only be realized through externally created NC programs with surface-normal vectors (LN blocks).

The control provides the following functionality:




► **AXIS POS** determines that the control interprets the programmed coordinates of rotary axes as the nominal position of the respective axis

AXIS SPATIAL AXIS SPAT determines that the control interprets the programmed coordinates of rotary axes as spatial angles



Programming notes:

- The AXIS POS function is primarily suitable in conjunction with perpendicularly arrayed rotary axes. Only if the programmed rotary axis coordinates define the working plane correctly (e.g. programmed using a CAM system), can you also use AXIS POS with different machine designs (e.g. 45° swivel heads).
- The AXIS SPAT function is used to define spatial angles that are given with respect to the active coordinate system (which might be tilted). The defined angles have the effect of incremental spatial angles. Always program all three spatial angles in the first positioning block after the AXIS SPAT function, even if they are 0°.



13 FUNCTION TCPM F TCP AXIS POS	Rotary axis coordinates are axis angles
18 FUNCTION TCPM F TCP AXIS SPAT	Rotary axis coordinates are spatial angles
20 L A+0 B+45 C+0 F MAX	Set tool orientation to B+45 degrees (spatial angle). Define spatial angles A and C with 0

Orientation interpolation between the start position and end position

With these functions, you define how the tool orientation between the programmed start position and end position is to be interpolated:



- PATHCTRL AXIS specifies that the rotary axes between the start position and end position are to be linearly interpolated. The surfaces that arise through milling with the tool circumference (peripheral milling) are not necessarily level, and they depend on the machine kinematics.
- PATH CONTROL VECTOR
- PATHCTRL VECTOR specifies that the tool orientation within the NC block always lies in the plane that is defined through the start orientation and end orientation. If the vector lies between the start position and end position in this plane, then milling with the tool circumference (peripheral milling) will produce a level surface.

In both cases, the programmed tool reference point is moved along a straight line between the start position and end position.



To obtain the most continuous multi-axis movement possible, define Cycle **32** with a **tolerance for rotary axes**.

Further information: User's Manual for Programming of Machining Cycles

PATHCTRL AXIS

You can use the **PATHCTRL AXIS** variant for NC programs with small orientation changes per NC block. In this case, the angle **TA** in Cycle **32** can be large.

You can use **PATHCTRL AXIS** both for face milling and also for peripheral milling.

Further information: "Running CAM programs", Page 466




HEIDENHAIN recommends the **PATHCTRL AXIS** variant. This enables smooth motion, which has a beneficial effect on the surface quality.

PATHCTRL VECTOR

You can use the **PATHCTRL VECTOR** variant for peripheral milling with large orientation changes per NC block.

13 FUNCTION TCPM F TCP AXIS SPAT PATHCTRL AXIS	The rotary axes are linearly interpolated between the start and end positions of the NC block.
14 FUNCTION TCPM F TCP AXIS SPAT PATHCTRL VECTOR	The rotary axes are interpolated such that the tool vector within the NC block always lies in the plane that is specified through the start orientation and end orientation.



Selection of tool reference point and center of rotation


The control provides the following functions for defining the tool reference point and center of rotation:



- REFPNT TIP-TIP: the (theoretical) tool tip is the reference point for positioning. The center of rotation is also located at the tool tip
- REF POINT
- REFPNT TIP-CENTER: the tool tip is the reference point for positioning. The center of rotation is located at the center of the cuttingedge radius.

REF POINT CNT-CNT REFPNT CENTER-CENTER: the center of the cutting-edge radius is the reference point for positioning. The center of rotation is also located at the center of the cutting-edge radius.

The reference point is optional. If you do not enter anything, the control uses **REFPNT TIP-TIP**.



REFPNT TIP-TIP

The **REFPNT TIP-TIP** variant corresponds to the default behavior of **FUNCTION TCPM**. You can use all previously allowed cycles and functions.

REFPNT TIP-CENTER

The **REFPNT TIP-CENTER** variant is mainly intended for the use with turning tools. In this case the center of rotation and the positioning point are not coincident. In an NC block, the center of rotation (center of the cutting-edge radius) is kept in position, but at the end of the block, the tool tip will no longer be in its initial position.

The main goal of selecting this reference point is to enable machining of complex contours in turning mode with active radius compensation and simultaneously inclined tilting axes (simultaneous turning). The use of this function only makes sense for control in turning mode (Option 50). Currently, this software option is only supported on the TNC 640.

REFPNT CENTER-CENTER

You can use the **REFPNT CENTER-CENTER** variant to machine parts with a tool whose tip is used as a reference point when executing NC programs generated in a CAD/CAM software where the paths are referenced to the center of the cutting edge radius instead of the tool tip.

Previously, this functionality could only be achieved by shortening the tool with **DL**. The variant with **REFPNT CENTER-CENTER** is advantageous in that the control knows the true tool length .

If you use **REFPNT CENTER-CENTER**, to program pocket milling cycles, the control generates an error message.

Example

•••	
13 FUNCTION TCPM F TCP AXIS SPAT PATHCTRL AXIS REFPNT TIP-TIP	Both the tool reference point and the center of rotation are located at the tool tip.
14 FUNCTION TCPM F TCP AXIS POS PATHCTRL AXIS REFPNT CENTER-CENTER	Both the tool reference point and the center of rotation are located at the center of the cutting-edge radius.

Resetting FUNCTION TCPM

RESET TCPM

•••

 FUNCTION RESET TCPM is to be used if you want to purposely reset the function within an NC program.

0

When you select a new NC program in the **Program run, single block** or **Program run, full sequence** operating modes, the control automatically resets the **TCPM** function.

Example

25 FUNCTION RESET TCPM

Resetting FUNCTION TCPM

•••

•••

11.6 Three-dimensional tool compensation (option 9)

Introduction


The control can perform a three-dimensional tool compensation (3-D compensation) for straight line blocks. Apart from the X, Y, and Z coordinates of the straight-line end point, these NC blocks must also contain the components NX, NY, and NZ of the surface-normal vector.

Further information: "Definition of a normalized vector", Page 458

If you want to carry out a tool orientation, these NC blocks need also a normalized vector with the components TX, TY, and TZ, which determines the tool orientation.

Further information: "Definition of a normalized vector", Page 458

The straight-line end point, the components for the surface normals as well as those for the tool orientation must be calculated by a CAM system.



Possible applications

- Use of tools with dimensions that do not correspond with the dimensions calculated by the CAM system (3-D compensation without definition of the tool orientation).
- Face milling: compensation of the cutter geometry in the direction of the surface-normal vector (3-D compensation with and without definition of the tool orientation). Cutting is usually with the end face of the tool.
- Peripheral milling: compensation of the cutter radius perpendicular to the direction of movement and perpendicular to the tool direction (3D radius compensation with definition of the tool orientation). Cutting is usually with the lateral surface of the tool.

Suppressing error messages with positive tool oversize: M107

Standard behavior

With positive tool compensation, programmed contours may be damaged. For NC programs with surface-normal blocks, the control checks whether critical oversizes result from tool compensations, and issues an error message if this is the case.

With Peripheral Milling the control triggers an error message in the following case:

DR_{Tab} + DR_{Prog} > 0

With Face Milling the control triggers an error message in the following case:

- $\square DR_{Tab} + DR_{Prog} > 0$
- $\blacksquare R2 + DR2_{Tab} + DR2_{Prog} > R + DR_{Tab} + DR_{Prog}$
- $\blacksquare R2 + DR2_{Tab} + DR2_{Prog} < 0$
- $\square DR2_{Tab} + DR2_{Prog} > 0$

Behavior with M107

With **M107** the control suppresses the error message.

Effect

M107 takes effect at the end of block.

You can reset M107 with M108.



With the **M108** function you can also have the radius of a replacement tool be checked even if three-dimensional tool compensation is not active.


Definition of a normalized vector

A normalized vector is a mathematical quantity possessing a magnitude of 1 and a direction. For LN blocks, the control requires up to two normalized vectors: one in order to determine the direction of the surface normals, and another (optional) to determine the direction of the tool orientation. The direction of a surface normal is determined by the components NX, NY, and NZ. In the case of an end mill and a Ball-nose cutter, the direction of the surface normals points away perpendicularly from the workpiece surface toward the tool reference point PT. A toroid cutter offers the possibility PT or PT' (see figure). The direction of tool orientation is determined by the components TX, TY, and TZ.

T

Programming notes:

- In the NC syntax, the order must be X,Y, Z for the position and NX, NY, NZ as well as TX, TY, TZ for the vectors.
- The NC syntax of LN blocks must always indicate all of the coordinates and all of the surface-normal vectors, even if the values have not changed from the previous NC block.
- To avoid possible feed interruptions during machining, precisely calculate the vectors and output them (recommended to seven decimal places).
- The 3-D tool compensation using surface normal vectors is effective for the coordinate data specified for the main axes X, Y, Z.
- If you load a tool with oversize (positive delta value), the control generates an error message. You can suppress the error message with the M107 function.
- The control will not warn you if there is a danger of contour damage due to tool oversizes.



Permissible tool shapes

You can describe the permissible tool shapes in the tool table via tool radii **R** and **R2**:

- Tool radius R: Distance from the tool center to the tool circumference
- Tool radius 2 R2: Radius of the curvature between the tool tip and tool circumference

The value of R2 generally determines the shape of the tool:

- R2 = 0: End mill
- R2 > 0: Toroid cutter with corner radius (R2 = R: Ball-nose cutter)

These data also provide the coordinates of the tool datum PT.

Using other tools: Delta values

If you use tools that have different dimensions from those of the originally programmed tools, then you can enter the difference between the tool lengths and radii as delta values in the tool table or in the NC program:


- Positive delta value DL, DR: The tool is larger than the original tool (oversize)
- Negative delta value DL, DR: The tool is smaller than the original tool (undersize)

The tool then compensates for the tool position by the sum of the delta values from the tool table and the programmed tool compensation (tool call or compensation table).

With **DR 2** you modify the rounding radius of the tool and therefore also the tool shape.

If you work with **DR 2** the following applies:

- R2 + DR2_{Tab} + DR2_{Prog} = End mill
- 0 < R2 + DR2_{Tab} + DR2_{Prog} < R: Toroid cutter
- R2 + DR2_{Tab} + DR2_{Prog} = R: Ball-nose cutter



3-D compensation without TCPM

If the NC program includes surface normal vectors, the control performs a 3-D compensation for three-axis machining. In this case, the **RL/RR** radius compensation and **TCPM** or **M128** must be inactive. The control displaces the tool in the direction of the surface-normal vectors by the total of the delta values (from the tool table and **TOOL CALL**).




The control generally uses the defined **delta values** for 3-D tool compensation. The entire tool radius \mathbf{R} + **D** \mathbf{R}) is only taken into account if you have activated the **FUNCTION PROG PATH IS CONTOUR** function.

Further information: "Interpretation of the programmed path", Page 464

Example: Block format with surface-normal vectors

1 LN X+31.737 Y+21.954 Z+33.165NX+0.2637581 NY+0.0078922 NZ-0.8764339 F1000 M3

LN:Straight line with 3-D compensationX, Y, Z:Compensated coordinates of the straight-line
end pointNX, NY, NZ:Components of the surface-normal vectorF:Feed rateM:Miscellaneous function



Face Milling: 3D compensation with TCPM

Face milling is a machining operation carried out with the front face of the tool. If the NC program contains surface-normal vectors and **TCPM** or **M128** is active, 3-D compensation is executed with 5-axis machining. Radius compensation RL/RR must not be active in this case. The control displaces the tool in the direction of the surfacenormal vectors by the total of the delta values (from the tool table and **TOOL CALL**).



The control generally uses the defined **delta values** for 3-D tool compensation. The entire tool radius **R** + **DR**) is only taken into account if you have activated the **FUNCTION PROG PATH IS CONTOUR** function.

Further information: "Interpretation of the programmed path", Page 464

If no tool orientation was defined in the ${\rm LN}$ block and ${\rm TCPM}$ is active, the control maintains the tool perpendicular to the workpiece contour.

Further information: "Retaining the position of the tool tip during the positioning of tilting axes (TCPM): M128 (option 9)", Page 446

If a tool orientation **T** has been defined in the **LN** block and M128 (or **FUNCTION TCPM**) is active at the same time, then the control will position the rotary axes automatically in such a way that the tool can reach the specified tool orientation. If you have not activated **M128** (or **TCPM FUNCTION**), then the control ignores the direction vector **T**, even if it is defined in the **LN** block.



Refer to your machine manual!


The control is not able to automatically position the rotary axes on all machines.

NOTICE

Danger of collision!

The rotary axes of a machine may have limited ranges of traverse, e.g. between -90° and +10° for the B head axis. Changing the tilt angle to a value of more than +10° may result in a 180° rotation of the table axis. There is a danger of collision during the tilting movement!

- Program a safe tool position before the tilting movement, if necessary.
- Carefully test the NC program or program section in the Program run, single block operating mode



Example: Block format with surface-normal vectors without tool orientation

LN X+31.737 Y+21.954 Z+33.165 NX+0.2637581 NY+0.0078922 NZ-0.8764339 F1000 M128

Example: Block format with surface-normal vectors and tool orientation

LN X+31.737 Y+21.954 Z+33.165 NX+0.2637581 NY+0.0078922 NZ-0.8764339 TX+0.0078922 TY-0.8764339 TZ+0.2590319 F1000 M128

LN:	Straight line with 3-D compensation
X, Y, Z:	Compensated coordinates of the straight-line end point
NX, NY, NZ:	Components of the surface-normal vector
ΤΧ, ΤΥ, ΤΖ :	Components of the normalized vector for workpiece orientation
F:	Feed rate
M:	Miscellaneous function

462

Peripheral milling: 3-D radius compensation with TCPM and radius compensation (RL/RR)

The control offsets the tool perpendicularly to the direction of motion and perpendicularly to the direction of the tool by the sum of the delta values **DR** (tool table and NC program). Determine the compensation direction with radius compensation **RL/RR** (see figure, traverse direction Y+). In order for the control to be able to reach the specified tool orientation, you need to activate the function **M128** or **TCPM**.

Further information: "Retaining the position of the tool tip during the positioning of tilting axes (TCPM): M128 (option 9)", Page 446 The control then positions the rotary axes automatically in such a way that the tool can reach the specified tool orientation with the active compensation.



A

Refer to your machine manual!

This function is only available with spatial angles. Your machine tool builder defines how these can be entered. The control is not able to automatically position the

rotary axes on all machines.

The control generally uses the defined **delta values** for 3-D tool compensation. The entire tool radius **R** + **DR**) is only taken into account if you have activated the **FUNCTION PROG PATH IS CONTOUR** function. **Further information:** "Interpretation of the programmed

path", Page 464

NOTICE


Danger of collision!

The rotary axes of a machine may have limited ranges of traverse, e.g. between -90° and $+10^{\circ}$ for the B head axis. Changing the tilt angle to a value of more than $+10^{\circ}$ may result in a 180° rotation of the table axis. There is a danger of collision during the tilting movement!

- Program a safe tool position before the tilting movement, if necessary.
- Carefully test the NC program or program section in the Program run, single block operating mode

There are two ways to define the tool orientation:

- In an LN block with the components TX, TY and TZ
- In an L block by indicating the coordinates of the rotary axes



Example: Block format with tool orientation

1 LN X+31.737 Y+21.954 Z+33.165 TX+0.0078922 TY-0.8764339 TZ+0.2590319 RR F1000 M128

LN:	Straight line with 3-D compensation
X, Y, Z:	Compensated coordinates of the straight-line end point
TX, TY, TZ :	Components of the normalized vector for workpiece orientation
RR:	Tool radius compensation
F:	Feed rate
M :	Miscellaneous function

Example: Block format with rotary axes

1 L X+31.737 Y+21.954 Z+33.165 B+12.357 C+5.896 RL F1000 M128


L:	Straight line
X, Y, Z:	Compensated coordinates of the straight-line end point
B , C :	Coordinates of the rotary axes for tool orien- tation
RL:	Radius compensation
F:	Feed rate
M :	Miscellaneous function

Interpretation of the programmed path

With the **FUNCTION PROG PATH** function, you decide whether the control will apply the 3-D radius compensation only to the delta values, just as before, or rather to the entire tool radius. If you activate **FUNCTION PROG PATH**, the programmed coordinates exactly correspond to the contour coordinates. With **FUNCTION PROG PATH OFF**, you deactivate this special interpretation.

Procedure

Proceed as follows for the definition:



You have the following possibilities:

Soft key	Function
IS CONTOUR	Activate the interpretation of the programmed path as the contour
	The control takes the full tool radius R + DR and the full corner radius R2 + DR2 into account for 3-D radius compensation.
OFF	Deactivate the special interpretation of the programmed path
	The control only uses the delta values DR and DR2 for 3-D radius compensation.

If you activate **FUNCTION PROG PATH**, the interpretation of the programmed path as the contour is effective for 3-D compensation movements until you deactivate the function.

11.7 Running CAM programs

If you create NC programs externally using a CAM system, you should pay attention to the recommendations detailed below. This will enable you to optimally use the powerful motion control functionality provided by the control and usually create better workpiece surfaces with shorter machining times. Despite high machining speeds, the control still achieves a very high contour accuracy. The basis for this is the HEROS 5 real-time operating system in conjunction with the **ADP** (Advanced Dynamic Prediction) function of the TNC 620. This enables the control to also efficiently process NC programs with high point densities.

From 3-D model to NC program

Here is a simplified description of the process for creating an NC program from a CAD model:

CAD: Model creation

Construction departments prepare a 3-D model of the workpiece to be machined. Ideally the 3-D model is designed for the center of tolerance.

CAM: Path generation, tool compensation

The CAM programmer specifies the machining strategies for the areas of the workpiece to be machined. The CAM system uses the surfaces of the CAD model to calculate the paths of the tool movements. These tool paths consist of individual points calculated by the CAM system so that each surface to be machined is approximated as nearly as possible while considering chord errors and tolerances. This way, a machineneutral NC program is created, known as a CLDATA file (cutter location data). A postprocessor generates a machine- and control-specific NC program, which can be processed by the CNC control. The postprocessor is adapted according to the machine tool and the control. The postprocessor is the link between the CAM system and the CNC control.



In the **BLK FORM FILE** syntax, you can integrate 3-D models in STL format as a workpiece blank and a finished part.

Further information: "Defining the workpiece blank: BLK FORM", Page 88

Control: Motion control, tolerance monitoring, velocity profile

The control uses the points defined in the NC program to calculate the movements of each machine axis as well as the required velocity profiles. Powerful filter functions then process and smooth the contour so that the control does not exceed the maximum permissible path deviation.

Mechatronics: Feed control, drive technology, machine tool The motions and velocity profiles calculated by the control are realized as actual tool movements by the machine's drive system.



Considerations required for post processor configuration

Take the following points into account with post processor configuration:

- Always set the data output for axis positions to at least four decimal places. This way you improve the quality of the NC data and avoid rounding errors, which can result in defects visible to the naked eye on the workpiece surface. Output of five decimal places may achieve improved surface quality for optical components as well as components with very large radii (i.e. small curvatures), for example molds for the automotive industry
- Always set the data output for the machining of surface normal vectors (LN blocks, only Klartext conversational programming) to exactly seven decimal places
- Avoid using successive incremental NC blocks because this may lead to the tolerances of the individual NC blocks being added together in the output
- Set the tolerance in Cycle 32 so that in standard behavior it is at least twice as large as the chord error defined in the CAM system. Also note the information describing the functioning of Cycle 32
- If the chord error selected in the CAM program is too large, then, depending on the respective curvature of a contour, large distances between NC blocks can result, each with large changes of direction. During machining this leads to drops in the feed rate at the block transitions. Recurring and equal accelerations (i.e. force excitation), caused by feed-rate drops in the heterogeneous NC program, can lead to undesirable excitation of vibrations in the machine structure.
- You can also use arc blocks instead of linear blocks to connect the path points calculated by the CAM system. The control internally calculates circles more accurately than can be defined via the input format
- Do not output any intermediate points on exactly straight lines. Intermediate points that are not exactly on a straight line can result in defects visible to the naked eye on the workpiece surface
- There should be exactly one NC data point at curvature transitions (corners)
- Avoid sequences of many short block paths. Short paths between blocks are generated in the CAM system when there are large curvature transitions with very small chord errors in effect. Exactly straight lines do not require such short block paths, which are often forced by the continuous output of points from the CAM system
- Avoid a perfectly even distribution of points over surfaces with a uniform curvature, since this could result in patterns on the workpiece surface
- For 5-axis simultaneous programs: avoid the duplicated output of positions if they only differ in the tool's angle of inclination
- Avoid the output of the feed rate in every NC block. This would negatively influence the control's velocity profile

Useful configurations for the machine tool operator:

- In order to enable a realistic graphic simulation, use 3-D models in STL format as a workpiece blank and finished part
 Further information: "Defining the workpiece blank: BLK FORM", Page 88
- In order to improve the structure of large NC programs, use the control's structuring function

Further information: "Structuring NC programs", Page 197
Use the control's commenting function in order to document

Use the control's commenting function in order to document NC programs

Further information: "Adding comments", Page 193

- Use the comprehensive cycles of the control available for the machining of holes and simple pocket geometries
 Further information: User's Manual for Programming of Machining Cycles
- For fits, output the contours with RL/RR tool radius compensation. This makes it easy for the machine operator to make necessary compensations
 Further information: "Tool compensation", Page 132
- Separate feed rates for pre-positioning, machining, and downfeeds, and define them via Q parameters at the beginning of the program

Example: Variable feed rate definitions

1 Q50 = 7500	FEED RATE FOR POSITIONING
2 Q51 = 750	FEED RATE FOR PLUNGING
3 Q52 = 1350	FEED RATE FOR MILLING
25 L Z+250 R0 FMAX	
26 L X+235 Y-25 FQ50	
27 L Z+35	
28 L Z+33.2571 FQ51	
29 L X+321.7562 Y-24.9573 Z+33.3978 FQ52	
30 L X+320.8251 Y-24.4338 Z+33.8311	

Please note the following for CAM programming

Adapting chord errors

Ť

Programming notes:

- For finishing operations, do not set the chord error in the CAM system to a value greater than 5 μm. In Cycle **32**, use an appropriate tolerance factor **T** of 1.3 to 3.
- For roughing operations, the total of the chord error and the tolerance T must be less than the defined machining oversize. In this way you can avoid contour damage.
- The specific values depend upon the dynamics of your machine.

Adapt the chord error in the CAM program, depending on the machining:


Roughing with preference for speed:

Use higher values for the chord error and the matching tolerance value in Cycle **32**. Both values depend on the oversize required on the contour. If a special cycle is available on your machine, use the roughing mode. In roughing mode the machine generally moves with high jerk values and high accelerations

- Normal tolerance in Cycle 32: Between 0.05 mm and 0.3 mm
- Normal chord error in the CAM system: Between 0.004 mm and 0.030 mm
- Finishing with preference for high accuracy:

Use smaller values for the chord error and a matching low tolerance in Cycle **32**. The data density must be high enough for the control to detect transitions and corners exactly. If a special cycle is available on your machine, use the finishing mode. In finishing mode the machine generally moves with low jerk values and low accelerations

- Normal tolerance in Cycle 32: Between 0.002 mm and 0.006 mm
- Normal chord error in the CAM system: Between 0.001 mm and 0.004 mm
- Finishing with preference for high surface quality: Use small values for the chord error and a matching larger tolerance in Cycle 32. The control is then able to better smooth the contour. If a special cycle is available on your machine, use the finishing mode. In finishing mode the machine generally moves with low jerk values and low accelerations
 - Normal tolerance in Cycle 32: Between 0.010 mm and 0.020 mm
 - Normal chord error in the CAM system: Approx. 0.005 mm



Further adaptations

Take the following points into account with CAM programming:

- For slow machining feed rates or contours with large radii, define the chord error to be only one-third to one-fifth of tolerance T in Cycle 32. Additionally, define the maximum permissible point spacing to be between 0.25 mm and 0.5 mm. The geometry error or model error should also be specified to be very small (max. 1 µm).
- Even at higher machining feed rates, point spacings of greater than 2.5 mm are not recommended for curved contour areas
- For straight contour elements, one NC point at the beginning of a line and one NC point at the end suffice. Avoid the output of intermediate positions
- In programs with five axes moving simultaneously, avoid large changes in the ratio of path lengths in linear and rotational blocks. Otherwise large reductions in the feed rate could result at the tool reference point (TCP)
- The feed-rate limitation for compensating movements (e.g. via M128 F...) should be used only in exceptional cases. The feedrate limitation for compensating movements can cause large reductions in the feed rate at the tool reference point (TCP).
- NC programs for 5-axis simultaneous machining with spherical cutters should preferably be output for the center of the sphere. The NC data are then generally more uniform. In Cycle 32, you can additionally set a higher rotary axis tolerance TA (e.g., between 1° and 3°) for an even more constant feed-rate curve at the tool center point (TCP).
- For NC programs for 5-axis simultaneous machining with toroid cutters or spherical cutters, where the NC output is for the south pole of the sphere, choose a lower rotary axis tolerance.
 0.1° is a typical value. However, the maximum permissible contour damage is the decisive factor for the rotational axis tolerance. This contour damage depends on the possible tool tilting, tool radius and contact depth of the tool. With 5-axis gear hobbing with an end mill you can calculate the maximum possible contour damage T directly from the cutter contact length L and permissible contour tolerance TA: T ~ K x L x TA K = 0.0175 [1/°]

Example: L = 10 mm, TA = 0.1°: T = 0.0175 mm

Possibilities for intervention on the control

Cycle **32 TOLERANCE** is available for influencing the behavior of CAM programs directly on the control. Please note the information describing the functioning of Cycle **32**. Also note the interactions with the chord error defined in the CAM system.

Further information: User's Manual for Programming of Machining Cycles

 \bigcirc

Refer to your machine manual!

Some machine tool builders provide an additional cycle for adapting the behavior of the machine to the respective machining operation (e.g., Cycle **332** Tuning). Cycle **332** can be used to modify filter settings, acceleration settings, and jerk settings.

Example

34 CYCL DEF 32.0 TOLERANCE

35 CYCL DEF 32.1 T0.05

36 CYCL DEF 32.2 HSC MODE:1 TA3

ADP motion control



This function must be enabled and adapted by the machine tool builder.

An insufficient quality of data in NC programs created on CAM systems frequently causes inferior surface quality of the milled workpieces. The **ADP** (Advanced Dynamic Prediction) feature expands the conventional look-ahead of the permissible maximum feed rate profile and optimizes the motion control of the feed axes during milling. This enables clean surfaces with short machining times to be cut, even with a strongly fluctuating distribution of points in adjacent tool paths. This significantly reduces or eliminates the reworking complexity.

These are the most important benefits of ADP:

- Symmetrical feed-rate behavior on forward and backward paths with bidirectional milling
- Uniform feed rate curves with adjacent cutter paths
- Improved reaction to negative effects (e.g. short, step-like contours, coarse chord tolerances, heavily rounded block endpoint coordinates) in NC programs generated by CAM systems
- Precise compliance to dynamic characteristics even in difficult conditions




Data transfer from CAD files

12.1 Screen layout of the CAD viewer

Fundamentals of the CAD viewer

Screen display

When you open the **CAD-Viewer**, the following screen layout is displayed:



- 1 Menu bar
- 2 Graphics window
- 3 List View window
- 4 Element Information window
- 5 Status bar

File types

The **CAD-Viewer** enables you to open standardized CAD data formats directly on the control.

The control displays the following file types:

File	Туре	Format
Step	.STP and .STEP	AP 203
		AP 214
IGES	.IGS and .IGES	Version 5.3
DXF	.DXF	R10 to 2015

12.2 CAD Import (option 42)

Application


You can open CAD files directly on the control in order to extract contours and machining positions from it. You can then store them as Klartext programs or as point files. Klartext programs acquired in this manner can also be run on older HEIDENHAIN controls, since these contour programs contain only **L** and **CC/C** blocks.



As an alternative to **CC** or **C** blocks, you can configure circular movements to be output as **CR** blocks. **Further information:** "Basic settings", Page 477

If you process files in **Programming** mode, then the control generates contour programs with the file extension **.H** and point files with the extension **.PNT** by default. You can select the file type in the save dialog.

To insert a selected contour or a selected machining position directly into an NC program, use the control's clipboard. Using the clipboard, you can even transfer the contents to the additional tools (e.g., **Leafpad** or **Gnumeric**).





Operating notes:

- Before loading the file into the control, ensure that the name of the file contains only permitted characters. Further information: "File names", Page 103
- The control does not support binary DXF format. Save the DXF file in ASCII format in the CAD or drawing program.

Using the CAD viewer



To use the **CAD-Viewer** without a touchscreen, you have to use a mouse or touchpad.

The **CAD-Viewer** runs as a separate application on the third desktop of the control. This enables you to use the screen switchover key to switch between the machine operating modes, the programming modes, and the **CAD-Viewer**. This is particularly useful if you want to add contours or machining positions to a Klartext program using the clipboard.



If you are using a TNC 620 with touch control, you can replace some keystrokes with gestures. **Further information:** "Operating the touchscreen",

Opening the CAD file

Page 511

Press the Programming key

PGM MGT

SELEC

ENT

Press the PGM MGT key

- > The control opens the file manager.
- Press the SELECT TYPE soft key
- > The control displays the selectable file formats.
- ► Press the **SHOW CAD** soft key
- ► Alternative: Press the SHOW ALL soft key
- Select the directory in which the CAD file is saved
- Select the desired CAD file

Press the ENT key


The control starts the CAD-Viewer and shows the file contents on the screen. The control displays the layers in the List View window and the drawing in the Graphics window.

12

Basic settings

The basic settings specified below are selected using the icons in the header bar.

lcon	Setting	
	Show or hide the List View window in order to expand the Graphics window	
1	Display of the various layers	
٢	Set preset, with optional selection of the plane	
9	Set datum, with optional selection of the plane	
G	Select contour	
┎ ╊	Select drilling positions	
	Set the zoom to the largest possible rendering of the entire graphical representation	
F	Switch background color (black or white)	
1 4	Switch between 2-D and 3-D mode. The active mode is highlighted in color	
mm inch	Set the unit of measure (mm or inch) for the file. The control then outputs the contour program and the machining positions in this unit of measure. The active unit of measure is highlight- ed in red	
0,01 0,001	Select the resolution. The resolution defines the number of decimal places and the number of positions for linearization.	
	Default setting: 4 decimal places with mm , and 5 decimal places with inch as the unit of measure	
	The CAD-Viewer linearizes all of the contours that are not in the XY plane. The finer the resolution, the more accurately the control will display the contours.	
	Switch between various views of the model e.g. Top	



lcon	Setting	
~	"Select, add, or remove contour elements" mode	
÷	The icon shows the current mode. Clicking the icon activates the next mode.	

The control displays the following icons only in certain modes.

lcon	Setting
5	The most recent step is undone.
Ĵ	Contour transfer mode: The tolerance specifies how far apart neighbor- ing contour elements may be from each other. You can use the tolerance to compensate for inaccuracies that occurred when the drawing was made. The default setting is 0.001 mm
C CR	Arc mode: Arc mode defines whether circular arcs are output in C format or CR format (e.g., for cylinder surface interpolation) in the NC program.
W	Point transfer mode: Specifies whether the control should display the tool path as a dashed line during the selection of machining positions
∛ -• †	Path optimization mode: The control optimizes the tool traverse movement so that there are shorter traverse movements between the machining positions. When the icon is pressed again, the optimization is reset
\bigcirc	Hole position mode: The control opens a pop-up window in which you can filter holes (full circles) based on their size
 S fi V n d c c c T 	Berating notes: Set the correct unit of measure, because the CAD ile does not contain this information. When creating NC programs for earlier control models, you must limit the resolution to three decimal places. In addition, you must remove the comments that the CAD-Viewer outputs into the contour program. The control displays the active basic settings in the status bar of the screen.

Setting layers

i `

CAD files usually contain several layers. The designer uses these layers to create groups of various types of elements, e.g. the actual workpiece contour, dimensions, auxiliary and design lines, shadings, and texts.

Hiding unneeded layers makes the graphics easier to read and facilitates the extraction of the required information.

Operating notes:

- The CAD file to be processed must contain at least one layer. Elements not assigned to a layer are automatically moved by the control to the anonymous layer.
- You can even select a contour if the designer has saved the lines on different layers.
- If you double-click a layer, the control switches to Contour Transfer mode and selects the first contour element that was drawn. The control highlights the other selectable elements of this contour in green. Especially in case of contours with many short elements, this procedure spares you the effort of running a manual search for the beginning of a contour.

When you open a CAD file in the **CAD-Viewer**, all layers available are shown.

Hiding a layer

To hide a layer, proceed as follows:




- Select the SET LAYER function
- > In the List View window the control shows all layers contained in the active CAD file.
- Select the desired layer
- Select the check box to deactivate it
- Alternatively, use the space key
- > The control hides the selected layer.

Showing a layer

To show a layer, proceed as follows:



- Select the SET LAYER function
- In the List View window the control shows all layers contained in the active CAD file.
- Select the desired layer
- Select the check box to activate it
- Alternatively, use the space key
- The control marks the selected layer in the List View with an x.
- > The selected layer is shown.



Setting a preset

The datum of the drawing in the CAD file is not always located in a manner that lets you use it as a workpiece preset. Therefore, the control provides a function with which you can shift the workpiece preset to a suitable location by clicking an element. You can also define the orientation of the coordinate system.

You can position the preset at the following locations:

- By directly inputting numerical values into the List View window
- For straight lines:
 - Starting point
 - Center
 - End point
- For circular arcs:
 - Starting point
 - Center
 - End point
- For full circles:
 - At the quadrant transitions
 - At the center
- At the intersection between:
 - Two straight lines, even if the point of intersection is actually on the extension of one of the lines
 - Straight line and circular arc
 - Straight line and full circle
 - Two circles (regardless of whether a circular arc or a full circle)



Operating note:


You can change the preset even after you have selected the contour. The control does not calculate the actual contour data until you save the selected contour in a contour program.

NC syntax

The preset and optional orientation are inserted in the NC program as a comment starting with **origin**.

4 ;orgin = X... Y... Z...

5 ;orgin_plane_spatial = SPA... SPB... SPC...



Setting a preset on a single element

To set a preset on a single element, proceed as follows:



- Select the mode for setting a preset
- Place the mouse pointer on the desired element
- > The control indicates possible locations for the preset on the selected element with stars.
- Select the star symbol that matches the desired preset position
- ▶ If necessary, use the zoom function
- The control sets the preset symbol at the selected location.
- In addition, align the coordinate system as needed
 Further information: "Adjusting the orientation of the coordinate system", Page 482

Setting a preset at the intersection between two elements

To set a preset at the intersection between two elements, proceed as follows:



- Select the mode for setting a preset
- Select the first element (straight line, full circle, or circular arc) using the left mouse button
- > The control highlights the element.
- Select the second element (straight line, circle, or circular arc) using the left mouse button
- The control sets the preset symbol on the intersection.
- In addition, align the coordinate system as needed
 - **Further information:** "Adjusting the orientation of the coordinate system", Page 482

A

Operating notes:

- If there are several possible intersections, the control selects the intersection nearest the mouse-click on the second element.
- If two elements do not intersect directly, the control automatically calculates the intersection of their extensions.
- If the control cannot calculate an intersection, it deselects the previously selected element.

Once a preset has been set, the control displays the preset icon with a yellow quadrant \oplus .

Use the following icon to delete a preset that has been set \Re .

Adjusting the orientation of the coordinate system

The following conditions must be met in order to align the coordinate system:

- Preset has been defined
- There are elements next to the preset that can be used for the desired alignment

The position of the coordinate system is defined by the orientation of the axes.

To align the coordinate system, proceed as follows:



- Select an element located in the positive X direction using the left mouse button
- > The control aligns the X axis.
- > The control changes the angle in C.
- Select an element located in the positive Y direction using the left mouse button
- > The control aligns the Y and Z axes.
- > The control changes the angles in A and C.




For angles not equal to 0, the control shows the List View in orange.

Element information

The control displays information about the element on the left of the window:

- Distance between the defined preset and the drawing datum
- Orientation of the coordinate system with respect to the drawing




Setting the datum

The workpiece preset is not always located in a manner that lets you machine the entire part. Therefore, the control has a function with which you can define a new datum and a tilting operation.

The datum with the orientation of the coordinate system can be set at the same positions as a preset.

Further information: "Setting a preset", Page 480



12

NC syntax

The datum and its optional orientation can be inserted as NC block or comments in the NC program by using the **TRANS DATUM AXIS** function for the datum and the **PLANE SPATIAL** function for the orientation.

If you define only one datum and its orientation, then the control inserts the functions in the NC program as an NC block.

```
4 TRANS DATUM AXIS X... Y... Z...
```

```
5 PLANE SPATIAL SPA... SPB... SPC... TURN MB MAX FMAX
```

If you additionally select contours or points, then the control inserts the functions in the NC program as comments.

```
4 ;TRANS DATUM AXIS X... Y... Z...
```

5 ;PLANE SPATIAL SPA... SPB... SPC... TURN MB MAX FMAX

Setting the datum on a single element

To set the datum on a single element, proceed as follows:



- Select the mode for specifying the datum
- Place the mouse pointer on the desired element
- > The control indicates possible locations for the datum on the selected element with stars.
- Select the star symbol that matches the desired datum position
- ▶ If necessary, use the zoom function
- The control sets the datum icon at the selected location.
- In addition, align the coordinate system as needed

Further information: "Adjusting the orientation of the coordinate system", Page 484

Setting a datum at the intersection between two elements

To set a datum at the intersection between two elements, proceed as follows:



i

- Select the mode for specifying the datum
- Select the first element (straight line, full circle, or circular arc) using the left mouse button
- > The control highlights the element.
- Select the second element (straight line, circle, or circular arc) using the left mouse button
- The control sets the datum icon on the point of intersection.
- In addition, align the coordinate system as needed
 Further information: "Adjusting the orientation of the coordinate system", Page 484

Operating notes:

- If there are several possible intersections, the control selects the intersection nearest the mouse-click on the second element.
- If two elements do not intersect directly, the control automatically calculates the intersection of their extensions.
- If the control cannot calculate an intersection, it deselects the previously selected element.

Once a datum has been set, the control displays the datum icon with a yellow surface \mathfrak{P} .

Use the following icon to delete a datum that has been set imes.

Adjusting the orientation of the coordinate system

The following conditions must be met in order to align the coordinate system:

- The datum has been set
- There are elements next to the preset that can be used for the desired alignment

The position of the coordinate system is defined by the orientation of the axes.

To align the coordinate system, proceed as follows:



- Select an element located in the positive X direction using the left mouse button
- > The control aligns the X axis.
- > The control changes the angle in C.
- Select an element located in the positive Y direction using the left mouse button
- > The control aligns the Y and Z axes.
- > The control changes the angles in A and C.

For angles not equal to 0, the control shows the List View in orange.

ĭ


Element information

In the Element Information window, the control displays how far away the datum you selected is from the workpiece preset. The control displays information about the element on the left of the window:

- Distance between the datum that has been set and the workpiece preset
- Orientation of the coordinate system



You can further shift the datum manually after it has been set. To do so, enter the desired axis values into the coordinate field.



Selecting and saving a contour

Operating notes:

- This function is not available if option 42 is not enabled.
- Specify the direction of rotation during contour selection so that it matches the desired machining direction.
- Select the first contour element such that approach without collision is possible.
- If the contour elements are very close to one another, use the zoom function.

The following elements can be selected as a contour:

- Line segment
- Circle

i

- Circular arc
- Polyline

i


Any curves (e.g., splines, ellipses)

Element information

In the Element Information window the control displays a range of information about the last contour element you selected in the List View window or in the Graphics window.

- Layer: specifies the active plane
- **Type**: specifies the type of element (e.g., line)
- **Coordinates**: specify the starting point and end point of an element, and the circle center and radius where appropriate

Ensure that the unit of measure used in the NC program matches with that used in the **CAD-Viewer**. Elements that have been copied from the **CAD-Viewer** to the clipboard do not contain any information about the unit of measure.



Select contour



Operating note:

i

If you double-click a layer in the list view window, the control switches to Contour Transfer mode and selects the first contour element that was drawn. The control highlights the other selectable elements of this contour in green. Especially in case of contours with many short elements, this procedure spares you the effort of running a manual search for the beginning of a contour.

To select a contour using available contour elements, proceed as follows:



- Select the contour selection mode
- Place the mouse pointer on the desired element
- The control displays the suggested direction of rotation as a dashed line.
- If you need to change the direction of rotation, move the mouse pointer towards the opposite end point
- Select the element using the left mouse button
- > The selected contour element turns blue.
- > The control shows the other selectable elements in green.

For branched contours, the control chooses the path with the smallest directional deviation. The control provides an additional mode that allows you to modify the suggested contour path.

Further information: "Creating contour paths independent of available contour elements", Page 489

- Select the last green element of the desired contour using the left mouse button
- The control changes the color of all selected elements to blue.
- > In the List View, all selected elements are given a check mark in the column **NC**.

Saving a contour

i

- The control also transfers two workpiece-blank definitions (BLK FORM) to the contour program. The first definition contains the dimensions of the entire CAD file. The second one, which is the active one, contains only the selected contour elements, so that an optimized size of the workpiece blank results.
- The control only saves elements that have been selected (blue elements), which means that they have been given a check mark in the List View window.

To save a selected contour, proceed as follows:

	1.11	
r		
		l

- Select the Save icon
- > The control prompts you to select the target directory, a file name, and the file type.
- Enter this information
- Confirm your input
- > The control saves the contour program.
- Alternative: Copy the selected contour elements to the clipboard

6

Ensure that the unit of measure used in the NC program matches with that used in the **CAD-Viewer**. Elements that have been copied from the **CAD-Viewer** to the clipboard do not contain any information about the unit of measure.

Deselecting the contour

To deselect the selected contour elements, proceed as follows:

- ×
- Select the Clear function to deselect all elements
- Alternative: Select individual elements by clicking them with the left mouse button while holding the CTRL key

Creating contour paths independent of available contour elements

To select any contours by using the end point, center, or transition points, proceed as follows:



i

- Select the contour selection mode
- Activate the "Add contour elements" mode
- The control displays the following icon:
- Place the mouse pointer on the contour element
- > The control displays selectable points.




Selectable points:

- End point or midpoint of a line or curve
- Quadrant transitions or center of a circle
- Points of intersection between existing elements
- Select the starting point as needed
- Select the starting element
- Select the subsequent element
- Alternative: Select any selectable point
- > The control creates the desired contour path.

Operating notes:

- The contour paths available depend on the selectable contour elements that are shown in green. Without the green elements, the control will display all solutions available. To remove the proposed contour path, select the first green element by pressing the left mouse button while holding the CTRL key down. As an alternative, you can switch to the Remove mode:
- If the contour element to be extended or shortened is a straight line, the control will extend or shorten the contour element along the same line. If the contour element to be extended or shortened is a circular arc, the control will extend or shorten the contour element along the same arc.



Selecting and saving machining positions

Operating notes:

f

- This function is not available if option 42 is not enabled.
- If the contour elements are very close to one another, use the zoom function.
- If required, configure the basic settings so that the control shows the tool paths. Further information: "Basic settings", Page 477

Three possibilities are available in the pattern generator for defining machining positions:

- Single selection: You select the desired machining positions by clicking them individually with the mouse
 Further information: "Single selection", Page 491
- Multiple selection by drag box: You select multiple machining positions by dragging a box around them with the mouse
 Further information: "Multiple selection by drag box", Page 491
- Multiple selection by search filter: You select all machining positions within a definable diameter range
 Further information: "Multiple selection by search filter", Page 492

6

Machining positions are deselected, deleted, or saved in the same manner as contour elements.

Selecting the file type

The following file types are available:

- Point table (.PNT)
- Klartext conversational language program (.H)


If you save the machining positions to a Klartext program, the control creates a separate linear block with a cycle call for every machining position (L X... Y... Z... F MAX M99).



The NC syntax used allows you to export NC programs generated by CAD import to old HEIDENHAIN controls and run them there.



The point tables (.**PNT**) of the TNC 620 and iTNC 530 are not compatible. Transferring a point table to and running it on the other control model leads to problems and unpredictable behavior.



Single selection

To select individual machining positions, proceed as follows:


- Select the mode for choosing a machining position
- Place the mouse pointer on the desired element
- > The control displays the selectable element in orange.
- Select the circle center as machining position
- Alternative: Select the circle or a circle segment
- > The control loads the selected machining position into the List View window.


Multiple selection by drag box


To select multiple machining positions by dragging a box around them, proceed as follows:



- Select the mode for choosing a machining position
- ► Activate the Add function
- > The control displays the following icon: ÷
- Drag a box around the desired area while holding down the left mouse button
- > The control displays the minimum and maximum diameter in a pop-up window.
- Change the filter settings as needed Further information: "Filter settings", Page 492
- Confirm the diameter range with OK
- > The control loads all machining position within the selected diameter range into the List View window.







Multiple selection by search filter

To select multiple machining positions by search filter, proceed as follows:

- Select the mode for choosing a machining position
- Activate the search filter
- > The control displays the minimum and maximum diameter in a pop-up window.
- Change the filter settings as needed Further information: "Filter settings", Page 492
- Confirm the diameter range with OK
- > The control loads all machining position within the selected diameter range into the List View window.


Filter settings


After you have used the guick selection function to mark hole positions, a pop-up window appears in which the smallest diameter found is to the left and the largest diameter to the right. With the buttons just below the diameter display you can adjust the diameter so that you can load the hole diameters that you want.


The following buttons are available:

lcon	Filter setting of smallest diameter
1<<	Display the smallest diameter found (default setting)
<	Display the next smaller diameter found
>	Display the next larger diameter found
>>	Display the largest diameter found. The control sets the filter for the smallest diameter to the value set for the largest diameter
lcon	Filter setting of largest diameter
lcon <<	Filter setting of largest diameter Display the smallest diameter found. The control sets the filter for the largest diameter to the value set for the smallest diameter
	Display the smallest diameter found. The control sets the filter for the largest diameter to the
<<	Display the smallest diameter found. The control sets the filter for the largest diameter to the value set for the smallest diameter

You can display the tool paths using the **SHOW TOOL PATH** icon. Further information: "Basic settings", Page 477








Element information

In the Element Information window, the control displays the coordinates of the last machining position selected.

You can also use the mouse to change the turning graphic. The following functions are available:

- To rotate the graphic move the mouse while holding down the right mouse button.
- To shift the displayed model, hold down the center mouse button or the mouse wheel (depending on your mouse model), and move the mouse.
- To zoom in on a certain area mark a zoom area by holding the left mouse button down
- To rapidly zoom in or out rotate the mouse wheel backwards or forwards
- To restore the standard view, double-click with the right mouse button





Pallets

13.1 Pallet management (option number 22)

Application



Ť

Refer to your machine manual!

Pallet table management is a machine-dependent function. The standard functional range is described below.

Pallet tables (**.p**) are mainly used in machining centers with pallet changers. The pallet tables call the different pallets (PAL), fixtures (FIX) optionally, and the associated NC programs (PGM). The pallet tables activate all defined presets and datum tables.

Without a pallet changer you can use pallet tables to process NC programs with different presets in sequence with just one press of $\rm NC\ Start.$



The file name of a pallet table must always begin with a letter.

Columns of the pallet table

The machine tool builder defines a pallet table prototype that opens automatically when you create a pallet table.

The prototype can include the following columns:

Column	Meaning	Field type
NR	The control creates the entry automatically. The entry is required for the input field Line number of the BLOCK SCAN function.	Mandatory field
ТҮРЕ	 The control differentiates between the following entries PAL Pallet FIX Fixture PGM NC program Select the entries using the ENT key and the arrow keys or by soft key. 	Mandatory field
NAME	File name The machine tool builder specifies the names for pallets and fixtures, if applicable, whereas you define program names. You must specify the complete path if the NC program is not saved in the directory of the pallet table.	Mandatory field
DATUM	Datum You must specify the complete path if the datum table is not saved in the folder of the pallet table. You activate datums from a datum table in the NC program using Cycle 7 .	Optional field This entry is only required if a datum table is used.
PRESET	Workpiece preset Enter the preset number of the workpiece.	Optional field

Column	Meaning	Field type
LOCATION	Location of the pallet	Optional field
	The entry MA indicates that there is a pallet or fixture in the working space of the machine and can be machined. Press the ENT key to enter MA . Press the NO ENT key to remove the entry and thus suppress machining.	If the column exists, the entry is mandatory.
LOCK	Line locked	Optional field
	Using an * you can exclude the line of the pallet table from processing. Press the ENT key to identify the line with the entry *. Press the NO ENT key to cancel the lock. You can lock the execution for individual NC programs, fixtures or entire pallets. Unlocked lines (e.g. PGM) in a locked pallet are also not executed.	
PALPRES	Number of the pallet preset	Optional field
		This entry is only required if pallet presets are used.
W-STATUS	Execution status	Optional field
		This entry is only required for tool- oriented machining.
METHOD	Machining method	Optional field
		This entry is only required for tool- oriented machining.
CTID	ID for mid-program startup	Optional field
		This entry is only required for tool- oriented machining.
SP-X, SP-Y, SP-Z	Clearance height in the linear axes X, Y, and Z	Optional field
SP-A, SP-B, SP-C	Clearance height in the rotary axes A, B, and C	Optional field
SP-U, SP-V, SP-W	Clearance height in the parallel axes U, V, and W	Optional field
DOC	Comment	Optional field
You can remove the LOCATION column if you are only using pallet tables in which the control is to machine all lines.		
Further information: "Inserting or deleting columns", Page 499		

Editing a pallet table

When you create a new pallet table, it is empty at first. Using the soft keys, you can insert and edit lines.

Soft key	Editing function
BEGIN	Select the table start
END	Select the table end
PAGE	Select the previous page in the table
PAGE	Select the next page in the table
INSERT LINE	Insert as last line in the table
DELETE LINE	Delete the last line in the table
APPEND N LINES AT END	Add several lines at end of table
COPY FIELD	Copy the current value
PASTE FIELD	Insert the copied value
BEGIN LINE	Select beginning of line
	Select end of line
FIND	Find text or value
SORT/ HIDE COLUMNS	Sort or hide table columns
EDIT CURRENT FIELD	Edit the current field
SORT	Sort by column contents
MORE FUNCTIONS	Miscellaneous functions, e.g. saving
SELECT	Open file path selection

Selecting a pallet table

Proceed as follows to select a pallet table or create a new pallet table:



÷

program run operating modePress the PGM MGT key

If no pallet tables are shown:



- Press the SELECT TYPE soft key
- Press the SHOW ALL soft key
- Select a pallet table with the arrow keys, or enter a name for a new pallet table (.p)

Switch to the **Programming** operating mode or a

ENT

Press the ENT key



You can select either a list view or form view using the **Screen Layout** key.

Inserting or deleting columns



This function is not enabled until the code number **555343** is entered.

Depending on the configuration, a newly created pallet table may not contain all columns. For tool-oriented machining, for example, you need columns that you have to insert first.

To insert a column in an empty pallet table, proceed as follows:

Open the pallet table




Press the MORE FUNCTIONS soft key



INSERT COLUMN

ENT

- Press the EDIT FORMAT soft key
- The control opens a pop-up window displaying the available columns
- Using the arrow keys, select the desired column.
- Press the INSERT COLUMN soft key



You can remove the column with the **DELETE COLUMN** soft key.

Fundamentals of tool-oriented machining

Application



Refer to your machine manual!

Tool-oriented machining is a machine-dependent function. The standard functional range is described below.

Tool-oriented machining allows you to machine several workpieces together even on a machine without pallet changer, which reduces tool-change times.

Limitation

NOTICE

Danger of collision!

Not all pallet tables and NC programs are suitable for tooloriented machining. With tool-oriented machining, the control no longer executes the NC programs continuously, but divides them at the tool calls. The division of the NC programs allows functions that were not reset to be effective across programs (machine states). This leads to a danger of collision during machining!

- Consider the stated limitations
- Adapt pallet tables and NC programs to the tool-oriented machining
 - Reprogram the program information after each tool in every NC program (e.g. M3 or M4).
 - Reset special functions and miscellaneous functions before each tool in every NC program (e. g., Tilt the working plane or M138)
- Carefully test the pallet table and associated NC programs in the **Program run, single block** operating mode

The following functions are not permitted:

- FUNCTION TCPM, M128
- M144
- M101
- M118
- Changing the pallet preset

The following functions require special attention, particularly for mid-program startup:

- Changing the machine statuses with a miscellaneous function (e.g. M13)
- Writing to the configuration (e.g. WRITE KINEMATICS)
- Traverse range switchover
- Cycle 32
- Tilting the working plane

Pallet table columns for tool-oriented machining

Unless the machine tool builder has made a different configuration, you need the following additional columns for tool-oriented machining:

Column	Meaning
W-STATUS	 The machining status defines the machining progress. Enter BLANK for an unmachined (raw) workpiece. The control changes this entry automatically during machining. The control differentiates between the following entries BLANK / no entry: Workpiece blank, requires machining INCOMPLETE: Partly machined, requires further machining ENDED: Machined completely, no further machining required EMPTY: Empty space, no machining required
	SKIP: Skip machining
METHOD	 Indicates the machining method Tool-oriented machining is also possible with a combination of pallet fixtures, but not for multiple pallets. The control differentiates between the following entries WPO: Workpiece oriented (standard) TO: Tool oriented (first workpiece) CTO: Tool oriented (further workpieces)
CTID	The control automatically generates the ID number for mid-program startup with block scan. If you delete or change the entry, mid-program startup is no longer possible.
SP-X, SP-Y, SP-Z, SP-A, SP-B, SP-C, SP-U, SP-V, SP-W	The entry for the clearance height in the existing axes is optional. You can enter safety positions for the axes. The control only approaches these positions if the machine tool builder processes them in the NC macros.

13.2 Batch Process Manager (option 154)

Application



Refer to your machine manual!

Your machine tool builder configures and enables the **Batch Process Manager** function.

The **Batch Process Manager** enables you to plan production orders on a machine tool.

You save the planned NC programs in a job list. You use the **Batch Process Manager** to open the job list.

The following information is displayed:

- Whether the NC program is free of errors
- Run time of the NC programs
- Availability of the tools
- Times at which manual interventions at the machine are necessary



The tool usage test function has to be enabled and switched on to ensure you get all information!

Further information: User's Manual for Setup, Testing and Running NC Programs

Fundamentals

The **Batch Process Manager** is available in the following operating modes:

- Programming
- Program run, single block
- Program run, full sequence

In the **Programming** operating mode, you can create and edit the job list.

The job list is executed in the **Program run, single block** and **Program run, full sequence** operating modes. Changes are possible only to a limited extent.

Screen display

When you open the **Batch Process Manager** in the **Programming** operating mode, the following screen layout is displayed:

Manual operation	Batcl	n Proces grammieren)	s Mana ^{BPM}	ager DNC	and the standard
TNC:\nc_prog\demo\Pallet	t\PALLET.P				
sary manual intervention	s Object		Time	Next manual intervention:	
Pallet not machina…	2	1	< 1 m	2	
				6s <u>-</u>	
Program	End		T Pgm	Pallet	
🗖 Palette: 1		•	\sim	Name 1	
PART_1.H	6s	v		l Datum table	
🏹 🖯 Palette: 2		I			
PART_21.H	13s	~	~	Preset	
PART_22.H	20s	6'	1	2 4	3
			6.5	Locked Machinable	
	~				
INSERT MOVE	RESET THE STATUS	MA(5) ^{NG}	EDI OFF	T DETAILS	SELECT

- 1 Displays all required manual interventions
- 2 Displays the next manual intervention
- 3 Shows any current soft keys provided by the machine tool builder
- 4 Shows the editable entries in the line highlighted in blue
- 5 Displays the current soft keys
- 6 Displays the job list

Columns in the job list

	•		
Column	Meaning		
No column name	Status of the Pallet , Clamping , or Program		
Program	Name or path of the Pallet , Clamping , or Program		
Duration	Run time in seconds		
	This column is only shown if you have a 19-inch screen.		
End	End of the run time		
	Time in Programming mode		
	 Actual time in Program run, single block and Program run, full sequence modes 		
Preset	Status of the workpiece preset		
т	Status of the inserted tools		
Pgm	Status of the NC program		
Sts	Machining status		

The status of the **Pallet**, **Clamping**, and **Program** is shown by means of icons in the first column.

The icons have the following meanings:

lcon	Meaning
	The Pallet, Clamping , or Program is locked
¥	The Pallet or Clamping is not enabled for machining
→	This line is currently being executed in Program run, single block or Program run, full sequence mode and cannot be edited
	In this line, the program was interrupted manual- ly

In the $\ensuremath{\textbf{Program}}$ column, the machining method is indicated by means of icons.

The icons have the following meanings:

lcon	Meaning
No icon	Workpiece-oriented machining
	Tool-oriented machining
	Start
1	End

The status is shown by means of icons in the $\ensuremath{\textit{Preset}},\,\ensuremath{\textit{T}},\,\ensuremath{\textit{and}}\,\,\ensuremath{\textit{Pgm}}$ columns.

The icons have the following meanings:

lcon	Meaning
√	Test completed
×	Test failed (e.g., because of expired tool life)
X	Test not yet completed
?	Incorrect program structure (e.g., pallet does not contain any subprograms)
\odot	Workpiece preset is defined
Δ	Check input
	You can assign a workpiece preset either to the pallet or to all NC subprograms.



Operating notes:

- In Programming operating mode, the T column is always empty because the control first checks the status in the Program run, single block and Program run, full sequence operating modes.
- If the tool usage test function is not enabled or is not switched on for your machine, then no icon is shown in the **Pgm** column

Further information: User's Manual for Setup, Testing and Running NC Programs

In the **Sts** columns, the machining status is indicated by icons. The icons have the following meanings:

lcon	Meaning
	Workpiece blank, machining required
	Partially machined, requires further machining
✓	Completely machined, no further machining required
	Skip machining



Operating notes:

- The machining status is automatically adjusted during machining
- The Sts column is shown in the Batch Process Manager only if the pallet table contains the W STATUS column

Further information: User's Manual for Setup, Testing and Running NC Programs


Opening the Batch Process Manager

Refer to your machine manual! In machine parameter **standardEditor** (no. 102902), your machine tool builder specifies the standard editor used by the control.

Programming operating mode

If the control does not open the pallet table (.p) in the Batch Process Manager as a job list, proceed as follows:

Select the desired job list





Press the Screen layout key



Press the BPM key

> The control opens the job list in the **Batch Process Manager**.

Soft keys

BPM

The following soft keys are available:

Ø	Refer to your machine manual! The machine tool builder can configure his own sof	
	keys.	

Soft key	Function
DETAILS OFF ON	Collapse or expand tree structure
EDIT OFF ON	Edit opened job list
INSERT REMOVE	Shows the soft keys INSERT BEFORE , INSERT AFTER , and REMOVE
MOVE	Move line
TAG	Select line

Soft key	Function
CANCEL THE MARKING	Cancel marking
INSERT BEFORE	Insert a new Pallet , Clamping , or Program before the cursor position
INSERT AFTER	Insert a new Pallet , Clamping , or Program after the cursor position
REMOVE	Delete line or block
	Switch active windows
SELECT	Select possible entries from a pop-up window
RESET THE STATUS	Reset the machining status to workpiece blank
MACHINING METHOD	Select workpiece-oriented or tool-oriented machining
ACCESSES OFF ON	Collapse or expand necessary manual interven- tions
TOOL MANAGEMENT	Open Extended Tool Management
INTERNAL STOP	Interrupt machining
A	Operating notes:
1	The TOOL MANAGEMENT and INTERNAL STOP soft keys are available only in the Program run, single block and Program run, full sequence operating modes.
	If the pallet table contains the W STATUS column, the RESET THE STATUS soft key is available.
	If the pallet table contains the W STATUS, METHOD, and CTID columns, the MACHINING METHOD soft key is available.
	Further information: User's Manual for Setup, Testing

and Running NC Programs

Creating a job list

You can only create a new job list in the file manager.

6	The file name of a job list must always begin with a letter.
⇒	Press the Programming key
PGM MGT	Press the PGM MGT key
	> The control opens the file manager.
NEW FILE	Press the NEW FILE soft key
	Enter the file name with extension (.p)
ENT	Confirm with the ENT key
	 The control opens an empty job list in the Batch Process Manager.
INSERT REMOVE	Press the INSERT REMOVE soft key
INSERT	Press the INSERT AFTER soft key
AFTER	 The control displays the various types on the right-hand side.
	Select the desired type
	Pallet
	Clamping
	Program
	The control inserts an empty line in the job list.
	The control shows the selected type on the right-hand side.
	 Define the entries
	Name: Enter the name directly or select one by means of the pop-up window, if there is one
	Datum table: Enter the datum directly, where applicable, or select one by means of the popup window
	 Preset: Enter the workpiece preset directly, where applicable
	 Locked: The selected line is excluded from machining
	 Machinable: The selected line is enabled for machining
ENT	Confirm your entries by pressing the ENT key.
	 Repeat the steps if required
EDIT OFF ON	Press the EDIT soft key

508

Editing a job list

You can edit a job list in the **Programming**, **Program run**, **single block**, and **Program run**, **full sequence** operating modes.

Operating notes:

- If a job list is selected in the Program run, single block or Program run, full sequence operating mode, it is not possible to edit the job list in the Programming operating mode.
- The possibilities of changing a job list during machining are limited, because the control defines a protected area.
- NC programs in the protected area are shown in light gray.

Proceed as follows to edit a line in the job list in the **Batch Process Manager**:

Open the desired job list



ŧ

i

Press the EDIT soft key

- Place the cursor on the desired line (e.g., Pallet)
- > The control displays the selected line in blue.
- > The control displays the editable entries on the right-hand side.
- Press the CHANGE WINDOW soft key if required
- > The control switches the active window.
- ▶ The following entries can be changed:
 - Name
 - Datum table
 - Preset
 - Locked
 - Machinable
- Confirm the edited entries by pressing the ENT key.
- > The control adopts the changes.
- Press the EDIT soft key





Proceed as follows to move a line in the job list in the Batch Process Manager:

Open the desired job list



- Press the EDIT soft key
- Place the cursor on the desired line (e.g., Program)
- > The control displays the selected line in blue.
- Press the MOVE soft key



INSERT BEFORE

00000000

EDIT OFF ON

- Press the TAG soft key
- > The control highlights the line in which the cursor is positioned.
- Place the cursor on the desired position.
- > When the cursor is placed at a suitable position, the control shows the INSERT BEFORE and **INSERT AFTER** soft keys.
- Press the INSERT BEFORE soft key
- > The control inserts the line at the new position.
- Press the GO BACK soft key
- Press the EDIT soft key



Operating the touchscreen

14.1 Display unit and operation

Touchscreen



Refer to your machine manual!

This function must be enabled and adapted by the machine tool builder.

The touchscreen is distinguished by a black frame and the lack of soft-key selection keys.

The TNC 620 has its operating panel integrated in the 19" screen.

1 Header

When the control is on, the screen displays the selected operating modes in the header.

- 2 Soft-key row for the machine tool builder
- 3 Soft-key row

The control shows further functions in a soft-key row. The active soft-key row is shown as a blue bar.

- 4 Integrated operating panel
- **5** Setting the screen layout
- **6** Switchover between machine operating modes, programming modes, and a third desktop



Operability of touchscreens regarding electrostatic discharge

Touchscreens from HEIDENHAIN work based on a capacitive method of touch detection. This makes them sensitive to the user's electrostatic discharge.

Users can discharge static electricity from their body by touching grounded metal objects. If problems with electrostatic discharge continue to occur, we recommend that users wear ESD shoes and ESD clothing.

Please also refer to the information provided by your machine tool builder.



Operating panel

Integrated operating panel

The operating panel is integrated in the screen. The content of the operating panel changes depending on the current operating mode.

- **1** Area for showing the following:
 - Alphabetic keyboard
 - HEROS menu
 - Potentiometer for the speed of simulation (only in the Test Run operating mode)
- 2 Machine operating modes
- 3 Programming modes

The control shows the active operating mode, to which the screen is switched, with a green background.

The control shows the operating mode in the background through a small white triangle.

- 4 File management
 - Calculator
 - MOD function
 - HELP function
 - Show error messages
- **5** Rapid access menu

Depending on the operating mode, you'll find the most important functions here at a glance.


- 6 Initiating the programming dialogs (only in the **Programming** and **Positioning w/ Manual Data Input** operating modes)
- 7 Numerical input and axis selection
- 8 Navigation
- 9 Arrows and the jump statement GOTO
- 10 Task bar

Further information: User's Manual for Setup, Testing and Running NC Programs

In addition, the machine tool builder supplies a machine operating panel.



Refer to your machine manual! External keys, e.g.**NC START** or **NC STOP**, are described in your machine manual.



Operating panel of the Test Run mode



Operating panel in the Manual Operation mode

Basic operation

The following keys, for example, can easily be replaced by hand gestures:


Кеу	Function	Gesture
0	Switch between operating modes	Tap on the operating mode in the header
\triangleright	Shift the soft-key row	Swipe horizontally over the soft-key row
	Soft-key selection keys	Tap on the function in the touchscreen

14.2 Gestures

Overview of possible gestures

The screen of the control is multi-touch capable. That means that it can distinguish various gestures, including with two or more fingers at once.

Symbol	Gesture	Meaning
	Тар	A brief touch by a finger on the screen
•		
	Double tap	Two brief touches on the screen
	Long press	Continuous contact of fingertip on the screen
٠		If you do not stop holding, the control will automatically cancel the holding gesture after approximately ten seconds. Permanent actuation is thus not possible.
	Swipe	Flowing motion over the screen
$\stackrel{\uparrow}{\leftarrow} \stackrel{\downarrow}{\overset{\downarrow}{\bullet}} \rightarrow$		
$\begin{array}{c} \uparrow \\ \bullet \\ \downarrow \end{array} \rightarrow$	Drag	A combination of long-press and then swipe, moving a finger over the screen when the starting point is clearly defined



Navigating in the table and NC programs

You can navigate in an NC program or a table as follows:

Symbol	Gesture	Function
	Тар	Mark the NC block or table line
		Stop scrolling
	Double tap	Activate the table line
	Swipe	Scroll through the NC program or table
$\stackrel{\uparrow}{\leftarrow} \stackrel{\uparrow}{\stackrel{\bullet}{\bullet}} \rightarrow$		

Operating the simulation

The control offers touch operation with the following graphics:

- Programming graphics in the **Programming** operating mode.
- 3-D view in the **Test Run** operating mode.
- 3-D view in the **Program Run Single Block** operating mode.
- 3-D view in the **Program Run Full Sequence** operating mode.
- Kinematics view

Rotating, zooming, or moving a graphic

ouble tap	Set the graphic to its original size
rag	Rotate the graphic (only 3-D graphics)
vo-finger drag	Move graphics
pread	Magnify the graphic
inch	Reduce the graphic
	wo-finger drag

Measuring a graphic

If you have activated measurement in the **Test Run** operating mode, the following additional function is available:

Symbol	Gesture	Function	
	Тар	Select the measuring point	
•			

Operating the CAD viewer

The control also supports touch operation for working with the **CAD-Viewer**. You have various gestures available depending on the operating mode.

To be able to use all applications, first use the icon to select the desired function:

lcon	Function
A	Default setting
+	Add
•	Works in the selection mode like a pressed Shift key
	Remove
	Works in the selection mode like a pressed CTRL key


Layer setting mode and specifying the workpiece preset

al size

Symbol	Gesture	Function
	Activate Add and double-tap on the background	Reset the graphic or 3-D model to its original size and angle
$\xrightarrow{\uparrow}$	Drag	Rotate the graphic or 3-D model (only in the Layer Setting mode)
, , , , , , , , , , , , , , , , , , ,	Two-finger drag	Move a graphic or 3-D model
	Spread	Enlarge a graphic or 3-D model
	Pinch	Reduce a graphic or 3-D model
• The second sec		


Selecting a contour

ymbol	Gesture	Function
	Tap on an element	Select element
	Tap on an element in the list-	Select or deselect an element
	view window	Select of deselect an element
	Activate Add and tap on an	Part, shorten, or lengthen an element
	element	
-	T	
	Activate Remove and tap on an element	Deselect an element
•	-	
	Double-tap on the background	Reset the graphic to its original size
	Swipe over an element	Show a preview of selected elements Show element information
<u>↑</u>		
$\leftarrow \bigcirc \rightarrow$		
•		



Selecting machining positions

Symbol	Gesture	Function
•	Tap on an element	Select element Select an intersection
	Double-tap on the background	Reset the graphic to its original size
	Swipe over an element	Show a preview of selected elements Show element information
 ← ● → ↓	Activate Add and drag	Spread a fast selection area
$\begin{array}{c} \uparrow \\ \bullet \\ \bullet \\ \downarrow \end{array} \rightarrow$	Activate Remove and drag	Spread an area for deselection of elements
$\leftarrow \bigcirc \uparrow \\ \downarrow \rightarrow$	Two-finger drag	Move graphics



You can switch back to the $\ensuremath{\text{Programming}}$ operating mode in the following ways:

Press the **Programming** key

The control switches to the **Programming** mode of operation.

Close the **CAD-Viewer**

The control automatically switches to the **Programming** operating mode.

Use the task bar to leave the CAD-Viewer open on the third desktop

The third desktop stays active in the background



Tables and overviews

15.1 System data

List of FN 18 functions

With the **FN 18: SYSREAD** function, you can read system data and save them to Q parameters. The selection of the system datum occurs via a group number (ID no.), a system data number, and, if necessary, an index.



The read values of the function **FN 18: SYSREAD** are always output by the control in **metric** units regardless of the NC program's unit of measure.

The following is a complete list of the **FN 18: SYSREAD** function. Please be aware that not all functions are available depending on the model of your control.

Group name	Group number ID	System data number NO	Index IDX	Description
Program i	nformation			
	10	3	-	Number of the active machining cycle
		6	-	Number of the most recently executed touch probe cycle -1 = None
		7	-	Type of calling NC program: -1 = None 0 = Visible NC program 1 = Cycle/macro, main program is visible 2 = Cycle/macro, there is no visible main program
		103	Q parameter number	Relevant within NC cycles; for inquiry as to whether the Q parameter given under IDX was explicitly stated in the associated CYCLE DEF.
		110	QS parameter number	Is there a file with the name QS(IDX)? 0 = No, 1 = Yes This function eliminates relative file paths.
		111	QS parameter number	Is there a directory with the name QS(IDX)? 0 = no, 1 = Yes Only absolute directory paths are possible.

Group name	Group number ID	System data number NO	Index IDX	Description
System ju	mp addresses			
	13	1	-	Label number or label name (string or QS) jumped to during M2/M30 instead of ending the current NC program. Value = 0: M2/M30 have the normal effect
		2	-	Label number or label name (string or QS) jumped to in the event of FN14: ERROR with the NC CANCEL reaction instead of abort- ing the NC program with an error message. The error number programmed in the FN14 command can be read under ID992 NR14. Value = 0: FN14 has the normal effect.
		3	-	Label number or label name (string or QS) jumped to in the event of an internal server error (SQL, PLC, CFG) or with erroneous file operations (FUNCTION FILECOPY, FUNCTION FILEMOVE, or FUNCTION FILEDELETE) instead of aborting the NC program with an error message. Value = 0: Error has the normal effect.
Indexed ad	ccess to Q parame	eters		
	15	10	Q parameter number	Reads Q(IDX)
		11	QL parameter no.	Reads QL(IDX)
		12	QR parameter no.	Reads QR(IDX)
Machine s	tatus			
	20	1	-	Active tool number
		2	-	Prepared tool number
		3	-	Active tool axis 0 = X 6 = U 1 = Y 7 = V 2 = Z 8 = W
		4	-	Programmed spindle speed
		5	-	Active spindle condition -1 = spindle condition not defined 0 = M3 active 1 = M4 active 2 = M5 active after M3 3 = M5 active after M4
		7	-	Active gear range
		8	-	Active coolant status 0 = off, 1 = on
		9	-	Active feed rate
		10	-	Index of prepared tool
		11	-	Index of active tool

Group name	Group number ID	System data number NO	Index IDX	Description
		14	-	Number of active spindle
		20	-	Programmed cutting speed in turning opera- tion
		21	-	Spindle mode in turning mode: 0 = constant speed 1 = constant cutting speed
		22	-	Coolant status M7: 0 = inactive, 1 = active
		23	-	Coolant status M8: 0 = inactive, 1 = active
Channel da	ata			
	25	1	-	Channel number
Cycle para	meters			
	30	1	-	Set-up clearance
		2	-	Hole depth / milling depth
		3	-	Plunging depth
		4	-	Feed rate for plunging
		5	-	First side length of pocket
		6	-	Second side length of pocket
		7	-	First side length of slot
		8	-	Second side length of slot
		9	-	Radius of circular pocket
		10	_	Feed rate for milling
		11	_	Rotational direction of the milling path
		12	-	Dwell time
		13	-	Thread pitch for Cycles 17 and 18
		14	-	Finishing allowance
		15	-	Roughing angle
		21	_	Probing angle
		22	-	Probing path
		23	-	Probing feed rate
		49	-	HSC mode (Cycle 32 Tolerance)
		50	_	Tolerance for rotary axes (Cycle 32 Tolerance
		52	Q parameter number	Type of transfer parameter for user cycles: –1: Cycle parameter not programmed in CYCL DEF 0: Cycle parameter numerically programmed in CYCL DEF (Q parameter) 1: Cycle parameter programmed as string in CYCL DEF (Q parameter)
		60	-	Clearance height (touch probe cycles 30 to 33)

	_
1	6

Group name	Group number ID	System data number NO	Index IDX	Description
		61	-	Inspection (touch probe cycles 30 to 33)
		62	-	Cutting edge measurement (touch probe cycles 30 to 33)
		63	-	Q parameter number for the result (touch probe cycles 30 to 33)
		64	-	Q parameter type for the result (touch probe cycles 30 to 33) 1 = Q, 2 = QL, 3 = QR
		70	-	Multiplier for feed rate (cycles 17 and 18)
Modal sta	tus			
	35	1	-	Dimensions: 0 = absolute (G90) 1 = incremental (G91)
		2	-	Radius compensation: 0 = R0 1 = RR/RL 10 = Face milling 11 = Peripheral milling
Data for S	QL tables			
	40	1	-	Result code for the last SQL command. If the last result code was 1 (=error), the error code is transferred as the return code.
Data from	the tool table			
	50	1	Tool no.	Tool length L
		2	Tool no.	Tool radius R
		3	Tool no.	Tool radius R2
		4	Tool no.	Oversize for tool length DL
		5	Tool no.	Tool radius oversize DR
		6	Tool no.	Tool radius oversize DR2
		7	Tool no.	Tool locked TL 0 = not locked, 1 = locked
		8	Tool no.	Number of the replacement tool RT
		9	Tool no.	Maximum tool age TIME1
		10	Tool no.	Maximum tool age TIME2
		11	Tool no.	Current tool age CUR.TIME
		12	Tool no.	PLC status
		13	Tool no.	Maximum tooth length LCUTS
		14	Tool no.	Maximum plunge angle ANGLE
		15	Tool no.	TT: Number of tool teeth CUT
		16	Tool no.	TT: Wear tolerance for length, LTOL
		17	Tool no.	TT: Wear tolerance for radius, RTOL

Group name	Group number ID	System data number NO	Index IDX	Description
		18	Tool no.	TT: Direction of rotation DIRECT 0 = positive, -1 = negative
		19	Tool no.	TT: Offset in plane R-OFFS R = 99999.9999
		20	Tool no.	TT: Offset in length L-OFFS
		21	Tool no.	TT: Breakage tolerance for length, LBREAK
		22	Tool no.	TT: Breakage tolerance for radius, RBREAK
		28	Tool no.	Maximum speed NMAX
		32	Tool no.	Point angle TANGLE
		34	Tool no.	LIFTOFF allowed (0 = No, 1 = Yes)
		35	Tool no.	Wear tolerance for radius R2TOL
		36	Tool no.	Tool type TYPE (miller = 0, grinder = 1, touch probe = 21)
		37	Tool no.	Corresponding line in the touch-probe table
		38	Tool no.	Timestamp of last use
		39	Tool no.	ACC
		40	Tool no.	Pitch for thread cycles
		44	Tool no.	Exceeding the tool life
		45	Tool no.	Front-face width of indexable insert (RCUTS)
		46	Tool no.	Usable length of the milling cutter
		47	Tool no.	Neck radius of the milling cutter (RN)

Group name	Group number ID	System data number NO	Index IDX	Description
Data from	the pocket table			
	51	1	Pocket number	Tool number
		2	Pocket number	0 = no special tool 1 = special tool
		3	Pocket number	0 = no fixed pocket 1 = fixed pocket
		4	Pocket number	0 = pocket not locked 1 = pocket locked
		5	Pocket number	PLC status
Determine	the tool pocket			
	52	1	Tool no.	Pocket number
		2	Tool no.	Tool magazine number
File inform	ation			
	56	1	-	Number of lines of the tool table
		2	-	Number of lines of the active datum table
		4	-	Number of lines in a freely definable table that has been opened with FN26: TABOPEN
Tool data f	or T and S strobe	s		
	57	1	T code	Tool number IDX0 = T0 strobe (store tool), IDX1 = T1 strobe (load tool), IDX2 = T2 strobe (prepare tool)
		2	T code	Tool index IDX0 = T0 strobe (store tool), IDX1 = T1 strobe (load tool), IDX2 = T2 strobe (prepare tool)
		5	-	Spindle speed IDX0 = T0 strobe (store tool), IDX1 = T1 strobe (load tool), IDX2 = T2 strobe (prepare tool)
Values prog	grammed in TOO	OL CALL		
	60	1	-	Tool number T
		2	-	Active tool axis 0 = X 1 = Y 2 = Z 6 = U 7 = V 8 = W
		3	-	Spindle speed S
		4	-	Oversize for tool length DL
		5	-	Tool radius oversize DR
		6	-	Automatic TOOL CALL 0 = Yes, 1 = No

Group name	Group number ID	System data number NO	Index IDX	Description
		8	-	Tool index
		9	-	Active feed rate
		10	-	Cutting speed [mm/min]
Values pro	ogrammed in TOO	L DEF		
	61	0	Tool no.	 Read the number of the tool change sequence: 0 = Tool already in spindle, 1 = Change between external tools, 2 = Change from internal to external tool, 3 = Change from special tool to external tool 4 = Load external tool, 5 = Change from external to internal tool, 6 = Change from special tool to internal tool, 7 = Change from special tool to internal tool, 8 = Load internal tool, 9 = Change from external tool to special tool 10 = Change from special tool to internal tool 11 = Change from special tool to internal tool 12 = Load special tool, 13 = Unload external tool, 14 = Unload internal tool, 15 = Unload special tool
		1	-	Tool number T
		2	-	Length
		3	-	Radius
		4	-	Index
		5	-	Tool data programmed in TOOL DEF 1 = Yes, 0 = No

Group name	Group number ID	System data number NO	Index IDX	Description
Values for	r LAC and VSC			
	71	0	0	Index of the NC axis for which the LAC weighing run will be performed or was last performed (X to W = 1 to 9)
			2	Total inertia determined by the LAC weighing run in [kgm²] (with A/B/C rotary axes) or total mass in [kg] (with X/Y/Z linear axes)
		1	0	Cycle 957 Retraction from thread
reely ava	ailable memory are	ea for OEM cycles		
	72	0-39	0 to 30	Freely available memory area for OEM cycles. The values are only reset by the control during a control reboot (= 0). With "Cancel," the values are not reset to the value that they had at the time of execu- tion. Up to and including 597110-11: only NR 0-9 and IDX 0-9 Starting with 597110-12: NR 0-39 and IDX 0-30
Freely ava	ailable memory are	ea for user cycles		
	73	0-39	0 to 30	 Freely available memory area for user cycles The values are only reset by the control during a control reboot (= 0). With "Cancel," the values are not reset to the value that they had at the time of execution. Up to and including 597110-11: only NR 0-9 and IDX 0-9 Starting with 597110-12: NR 0-39 and IDX 0-30
Read mini	imum and maxim	um spindle speed		
	90	1	Spindle ID	Minimum spindle speed of the lowest gear range. If no gear stages are configured, CfgFeedLimits/minFeed of the first parame- ter set of the spindle is evaluated. Index 99 = active spindle
		2	Spindle ID	Maximum spindle speed from the highest gear stage. If no gear stages are configured, CfgFeedLimits/maxFeed of the first parame- ter set of the spindle is evaluated. Index 99 = active spindle
Tool comp	pensation			
	200	1	1 = without oversize 2 = with oversize 3 = with	Active radius

	Group number ID	System data number NO	Index IDX	Description
			oversize and oversize from TOOL CALL	
		2	1 = without oversize 2 = with oversize 3 = with oversize and oversize from TOOL CALL	Active length
		3	1 = without oversize 2 = with oversize 3 = with oversize and oversize from TOOL CALL	Rounding radius R2
		6	Tool no.	Tool length Index 0= active tool
Coordinate tra				
:	210	1	-	Basic rotation (manual)
		2	-	Programmed rotation
		3	-	Active mirror axis. Bits 0 to 2 and 6 to 8: Axes X, Y, Z and U, V, W
		4	Axis	Active scaling factor Index: 1 - 9 (X, Y, Z, A, B, C, U, V, W)
		5	Rotary axis	3D-ROT Index: 1 - 3 (A, B, C)
		6	-	Tilt working plane in Program Run operating modes 0 = Not active -1 = Active
		7	-	Tilt working plane in Manual operating modes 0 = Not active -1 = Active
		8	QL parameter no.	Angle of misalignment between spindle and tilted coordinate system. Projects the angle specified in the QL parameter from the input coordinate system to the tool coordinate system. If IDX is omitted, the angle 0 is used for projection.
		10	-	Type of definition of the active tilt: 0 = no tilt—is returned if, both in Manual Operation and in the automatic modes, no tilt is active. 1 = axial 2 = spatial angle

Group name	Group number ID	System data number NO	Index IDX	Description
Active cod	ordinate system			
	211	_	-	1 = input system (default) 2 = REF system 3 = tool change system
Special tra	ansformations in	turning mode		
	215	1	-	Angle for the precession of the input system in the XY plane in turning mode. To reset the transformation the value 0 must be entered for the angle. This transformation is used in connection with Cycle 800 (parameter Q497).
		3	1-3	Reading out of the spatial angle written with NR2 Index: 1 - 3 (redA, redB, redC)
Current da	atum shift			
	220	2	Axis	Current datum shift in [mm] Index: 1 - 9 (X, Y, Z, A, B, C, U, V, W)
		3	Axis	Read the difference between reference point and preset. Index: 1 - 9 (X, Y, Z, A, B, C, U, V, W)
		4	Axis	Read values for OEM offset Index: 1 - 9 (X_OFFS, Y_OFFS, Z_OFFS,)
Traverse r	ange			
	230	2	Axis	Negative software limit switches Index: 1 - 9 (X, Y, Z, A, B, C, U, V, W)
		3	Axis	Positive software limit switches Index: 1 - 9 (X, Y, Z, A, B, C, U, V, W)
		5	-	Software limit switch on or off: 0 = on, 1 = off For modulo axes, either both the upper and lower limits or no limit at all must be set.
Read the	nominal position	in the REF system	ו	
	240	1	Axis	Current nominal position in the REF system
Read the i	nominal position	in the REF system	n, including offse	ets (handwheel, etc.)
	241	1	Axis	Current nominal position in the REF system
Read the	current position i	n the active coord	inate system	
	270	1	Axis	Current nominal position in the input system When called while tool radius compensation is active, the function supplies the uncom- pensated positions for the principal axes X, Y, and Z. If the function is called for a rotary axis and tool radius compensation is active, an error message is issued. Index: 1 to 9 (X, Y, Z, A, B, C, U, V, W)
Read the	current position i	n the active coord	inate system, in	cluding offsets (handwheel, etc.)
	271	1	Axis	Current nominal position in the input system

Group name	Group number ID	System data number NO	Index IDX	Description
Read inform	mation to M128			
	280	1	-	M128 active: -1 = Yes, $0 = $ No
		3	-	Condition of TCPM after Q No.: Q No. + 0: TCPM active, 0 = no, 1 = yes Q No. + 1: AXIS, 0 = POS, 1 = SPAT Q No. + 2: PATHCTRL, 0 = AXIS, 1 = VECTOR Q No. + 3: Feed rate, 0 = F TCP, 1 = F CONT
Machine ki	nematics			
	290	5	-	0: Temperature compensation not active 1: Temperature compensation active
		10	-	Index of the machine kinematics from Channels/ChannelSettings/CfgKin- List/kinCompositeModels programmed in FUNCTION MODE MILL or FUNCTION MODE TURN –1 = Not programmed.
	of the mechine ki	nomotico		
	of the machine ki		OS paramotor	Read the axis names of the active 3-axis
295	295	1	QS parameter no.	kinematics. The axis names of the active 3-axis according to QS(IDX), QS(IDX+1), and QS(IDX+2). 0 = Operation successful
		2	0	Is FACING HEAD POS function active? 1 = Yes, 0 = No
		4	Rotary axis	Read whether the defined rotary axis partici- pates in the kinematic calculation. 1 = Yes, 0 = No (A rotary axis can be excluded from the kinematics calculating using M138.) Index: 4, 5, 6 (A, B, C)
		6	Axis	Angle head: Displacement vector in the basic coordinate system B-CS through angle head Index: 1, 2, 3 (X, Y, Z)
		7	Axis	Angle head: Direction vector of the tool in the basic coordinate system B-CS Index: 1, 2, 3 (X, Y, Z)
		10	Axis	Determine programmable axes. Determine the axis ID associated with the specified axis index (index from CfgAxis/axisList). Index: 1 - 9 (X, Y, Z, A, B, C, U, V, W)
		11	Axis ID	Determine programmable axes. Determine the index of the axis (X = 1, Y = 2,) for the specified axis ID Index: Axis ID (index from CfgAxis/axisList)

Group name	Group number ID	System data number NO	Index IDX	Description
Modify the	e geometrical beh	navior		
	310	20	Axis	Diameter programming: $-1 = \text{on}, 0 = \text{off}$
Current sy	vstem time			
	320	1	0	System time in seconds that has elapsed since 01.01.1970, 00:00:00 (real time).
			1	System time in seconds that has elapsed since 01.01.1970, 00:00:00 (look-ahead calcu-lation).
		3	-	Read the processing time of the current NC program.
Formatting	g of system time			
	321	0	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: DD.MM.YYYY hh:mm:ss
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: DD.MM.YYYY hh:mm:ss
		1	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: D.MM.YYYY h:mm:ss
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: D.MM.YYYY h:mm:ss
		2	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: D.MM.YYYY h:mm
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: D.MM.YYYY h:mm
		3	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: D.MM.YY h:mm
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: D.MM.YY h:mm
		4	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: YYYY-MM-DD hh:mm:ss

Group name	Group number ID	System data number NO	Index IDX	Description
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: YYYY-MM-DD hh:mm:ss
		5	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: YYYY-MM-DD hh:mm
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: YYYY-MM-DD hh:mm
		6	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: YYYY-MM-DD h:mm
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: YYYY-MM-DD h:mm
		7	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: YY-MM-DD h:mm
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: YY-MM-DD h:mm
		8	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: DD.MM.YYYY
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: DD.MM.YYYY
		9	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: D.MM.YYYY
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: D.MM.YYYY
		10	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: D MM YY

Format: D.MM.YY

Group name	Group number ID	System data number NO	Index IDX	Description
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: D.MM.YY
		11	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: YYYY-MM-DD
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: YYYY-MM-DD
		12	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: YY-MM-DD
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: YY-MM-DD
		13	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: hh:mm:ss
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: hh:mm:ss
		14	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: h:mm:ss
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: h:mm:ss
		15	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: h:mm
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: h:mm

Group name	Group number ID	System data number NO	Index IDX	Description
Global Pro	ogram Settings (G	PS): Global activa	tion status	
	330	0	-	0 = No GPS setting is active 1 = Any GPS setting is active
Global Pro	ogram Settings (G	PS): Individual ac	tivation status	
	331	0	-	0 = No GPS setting is active 1 = Any GPS setting is active
		1	-	GPS: Basic rotation 0 = Off, 1 = On
		3	Axis	GPS: Mirroring 0 = Off, 1 = On Index: 1 - 6 (X, Y, Z, A, B, C)
		4	-	GPS: Shift in the modified workpiece system 0 = Off, 1 = On
		5	-	GPS: Rotation in input system 0 = Off, 1 = On
		6	-	GPS: Feed rate factor 0 = Off, 1 = On
		8	-	GPS: Handwheel superimpositioning 0 = Off, 1 = On
		10	-	GPS: Virtual tool axis VT 0 = Off, 1 = On
		15	-	 GPS: Selection of the handwheel coordinate system 0 = Machine coordinate system M-CS 1 = Workpiece coordinate system W-CS 2 = Modified workpiece coordinate system mW-CS 3 = Working plane coordinate system WPL-CS
		16	-	GPS: Shift in the workpiece system $0 = Off$, $1 = On$
		17	-	GPS: Axis offset 0 = Off, 1 = On

Group name	Group number ID	System data number NO	Index IDX	Description
Global Pro	ogram Settings (G	iPS)		
	332	1	-	GPS: Angle of a basic rotation
		3	Axis	GPS: Mirroring 0 = Not mirrored, 1 = Mirrored Index: 1 - 6 (X, Y, Z, A, B, C)
		4	Axis	GPS: Shift in the modified workpiece coordi- nate system mW-CS Index: 1 - 6 (X, Y, Z, A, B, C)
		5	-	GPS: Angle of rotation in input coordinate system I-CS
		6	-	GPS: Feed rate factor
		8	Axis	GPS: Handwheel superimpositioning Maximum value Index: 1 - 10 (X, Y, Z, A, B, C, U, V, W, VT)
		9	Axis	GPS: Value for handwheel superimpositioning Index: 1 - 10 (X, Y, Z, A, B, C, U, V, W, VT)
		16	Axis	GPS: Shift in the workpiece coordinate system W-CS Index: 1 - 3 (X, Y, Z)
		17	Axis	GPS: Axis offset Index: 4 - 6 (A, B, C)
TS touch t	trigger probe			
	350	50	1	Touch probe type: 0: TS120, 1: TS220, 2: TS440, 3: TS630, 4: TS632, 5: TS640, 6: TS444, 7: TS740
			2	Line in the touch-probe table
		51	-	Effective length
		52	1	Effective radius of the stylus tip
			2	Rounding radius
		53	1	Center offset (reference axis)
			2	Center offset (minor axis)
		54	-	Spindle-orientation angle in degrees (center offset)
		55	1	Rapid traverse
			2	Measuring feed rate
			3	Feed rate for pre-positioning: FMAX_PROBE or FMAX_MACHINE
		56	1	Maximum measuring range
			2	Set-up clearance
		57	1	Spindle orientation possible 0=No, 1=Yes
			2	Angle of spindle orientation in degrees

name	Group number ID	System data number NO	Index IDX	Description
TT tool tou	uch probe for too	l measurement		
	350	70	1	TT: Touch probe type
			2	TT: Line in the tool touch probe table
		71	1/2/3	TT: Touch probe center (REF system)
		72	-	TT: Touch probe radius
		75	1	TT: Rapid traverse
			2	TT: Measuring feed rate with stationary spindle
			3	TT: Measuring feed rate with rotating spindle
		76	1	TT: Maximum probing path
			2	TT: Safety clearance for linear measurement
			3	TT: Safety clearance for radius measurement
			4	TT: Distance from the lower edge of the cutter to the upper edge of the stylus
		77	-	TT: Spindle speed
		78	-	TT: Probing direction
		79	-	TT: Activate radio transmission
		80	-	TT: Stop probing movement upon stylus deflection
Preset from	m touch probe cy	cle (probing resul	ts)	
	360	1	Coordinate	Last preset of a manual touch probe cycle, or last touch point from Cycle 0 (input coordi-
				nate system). Compensations: length, radius, and center offset
		2	Axis	Compensations: length, radius, and center offset Last preset of a manual touch probe cycle, or
		2	Axis Coordinate	Compensations: length, radius, and center offset Last preset of a manual touch probe cycle, or last touch point from Cycle 0 (machine coordi- nate system, only axes from the active 3-D kinematics are allowed as index).
				Compensations: length, radius, and center offset Last preset of a manual touch probe cycle, or last touch point from Cycle 0 (machine coordi- nate system, only axes from the active 3-D kinematics are allowed as index). Compensation: only center offset Result of measurement in the input system of touch probe Cycles 0 and 1. The measure- ment result is read out in the form of coordi-
		3	Coordinate	Compensations: length, radius, and center offset Last preset of a manual touch probe cycle, or last touch point from Cycle 0 (machine coordi- nate system, only axes from the active 3-D kinematics are allowed as index). Compensation: only center offset Result of measurement in the input system of touch probe Cycles 0 and 1. The measure- ment result is read out in the form of coordi- nates. Compensation: only center offset Last preset of a manual touch probe cycle, or last touch point from Cycle 0 (workpiece coordinate system) The measurement result is read in the form of coordinates.
		3	Coordinate	Compensations: length, radius, and center offset Last preset of a manual touch probe cycle, or last touch point from Cycle 0 (machine coordi- nate system, only axes from the active 3-D kinematics are allowed as index). Compensation: only center offset Result of measurement in the input system of touch probe Cycles 0 and 1. The measure- ment result is read out in the form of coordi- nates. Compensation: only center offset Last preset of a manual touch probe cycle, or last touch point from Cycle 0 (workpiece coordinate system) The measurement result is read in the form of coordinates. Compensation: only center offset

HEIDENHAIN | TNC 620 | Klartext Programming User's Manual | 01/2021

_

Group name	Group number ID	System data number NO	Index IDX	Description
		11	-	Error status of probing: 0: Probing was successful –1: Touch point not reached –2: Touch probe already deflected at the start of the probing process
Read value	es from or write v	alues to the activ	e datum table	
	500	Row number	Column	Read values
Read value	es from or write v	alues to the prese	et table (basic tra	ansformation)
	507	Row number	1-6	Read values
Read axis	offsets from or w	rite axis offsets to	the preset table	e
	508	Row number	1-9	Read values
Data for pa	allet machining			
	510	1	-	Active line
		2	-	Current pallet number. Read value of the NAME column of the last PAL-type entry. If the column is empty or does not contain a numerical value, a value of –1 is returned.
		3	-	Active row of the pallet table.
		4	-	Last line of the NC program for the current pallet.
		5	Axis	Tool-oriented editing: Clearance height is programmed: 0 = No, 1 = Yes Index: 1 - 9 (X, Y, Z, A, B, C, U, V, W)
		6	Axis	Tool-oriented editing: Clearance height The value is invalid if ID510 NR5 returns the value 0 with the corresponding IDX. Index: 1 - 9 (X, Y, Z, A, B, C, U, V, W)
		10	-	Row number up to which the pallet table is to be searched during block scan.
		20	-	Type of pallet editing? 0 = Workpiece-oriented 1 = Tool oriented
		21	-	Automatic continuation after NC error: 0 = Locked 1 = Active 10 = Abort continuation 11 = Continuation with the rows in the pallet table that would have been executed next if not for the NC error 12 = Continuation with the row in the pallet table in which the NC error arose 13 = Continuation with the next pallet

Group name	Group number ID	System data number NO	Index IDX	Description
Read data	from the point ta	able		
	520	Row number	10	Read value from active point table.
			11	Read value from active point table.
			1-3 X/Y/Z	Read value from active point table.
Read or w	vrite the active pre	eset		
	530	1	-	Number of the active preset in the active preset table.
Active pal	let preset			
	540	1	-	Number of the active pallet preset. Returns the number of the active preset. If no pallet preset is active, the function returns the value –1.
		2	-	Number of the active pallet preset. As with NR1.
Values for	the basic transfo	rmation of the pa	llet preset	
	547	row number	Axis	Read values of the basic transformation from the pallet preset table Index: 1 to 6 (X, Y, Z, SPA, SPB, SPC)
Axis offse	ts from the pallet	preset table		
	548	Row number	Offset	Read values of the axis offsets from the pallet preset table Index: 1 - 9 (X_OFFS, Y_OFFS, Z_OFFS,)
OEM offse	et			
	558	Row number	Offset	Read values for OEM offset Index: 1 - 9 (X_OFFS, Y_OFFS, Z_OFFS,)
Read and	write the machine	e status		
	590	2	1-30	Freely available; not deleted during program selection.
		3	1-30	Freely available; not deleted during a power failure (persistent storage).
Read/writ	e look-ahead para	ameter of a single	axis (at machin	e level)
	610	1	-	Minimum feed rate (MP_minPathFeed) in mm/min
		2	-	Minimum feed rate at corners (MP_min- CornerFeed) in mm/min
		3	-	Feed-rate limit for high speeds (MP_maxG1Feed) in mm/min
		4	-	Max. jerk at low speeds (MP_maxPathJerk) in m/s ³
		5	-	Max. jerk at high speeds (MP_maxPath- JerkHi) in m/s ³
		6	-	Tolerance at low speeds (MP_pathTolerance in mm

Group name

Group number ID	System data number NO	Index IDX	Description
	7	-	Tolerance at high speeds (MP_pathToler- anceHi) in mm
	8	-	Max. derivative of jerk (MP_maxPathYank) in m/s ⁴
	9	-	Tolerance factor for curve machining (MP_curveTolFactor)
	10	-	Factor for max. permissible jerk at curvature changes (MP_curveJerkFactor)
	11	-	Maximum jerk with probing movements (MP_pathMeasJerk)
	12	-	Angle tolerance for machining feed rate (MP_angleTolerance)
	13	-	Angle tolerance for rapid traverse (MP_angle- ToleranceHi)
	14	-	Max. corner angle for polygons (MP_max- PolyAngle)
	18	-	Radial acceleration with machining feed rate (MP_maxTransAcc)
	19	-	Radial acceleration with rapid traverse (MP_maxTransAccHi)
	20	Index of physi- cal axis	Max. feed rate (MP_maxFeed) in mm/min
	21	Index of physi- cal axis	Max. acceleration (MP_maxAcceleration) in m/s ²
	22	Index of physi- cal axis	Maximum transition jerk of the axis in rapid traverse (MP_axTransJerkHi) in m/s ²
	23	Index of physi- cal axis	Maximum transition jerk of the axis during machining free rate (MP_axTransJerk) in m/s ³
	24	Index of physi- cal axis	Acceleration feedforward control (MP_com- pAcc)
	25	Index of physi- cal axis	Axis-specific jerk at low speeds (MP_axPath- Jerk) in m/s ³
	26	Index of physi- cal axis	Axis-specific jerk at high speeds (MP_ax- PathJerkHi) in m/s ³
	27	Index of physi- cal axis	More precise tolerance examination in corners (MP_reduceCornerFeed) 0 = deactivated, 1 = activated
	28	Index of physi- cal axis	DCM: Maximum tolerance for linear axes in mm (MP_maxLinearTolerance)
	29	Index of physi- cal axis	DCM: Maximum angle tolerance in [°] (MP_maxAngleTolerance)
	30	Index of physi- cal axis	Tolerance monitoring for successive threads (MP_threadTolerance)

Group name	Group number ID	System data number NO	Index IDX	Description
		31	Index of physi- cal axis	Form (MP_shape) of the axisCutterLoc filter 0: Off 1: Average 2: Triangle 3: HSC 4: Advanced HSC
		32	Index of physi- cal axis	Frequency MP_frequency) of the axisCutter Loc filter in Hz
		33	Index of physi- cal axis	Form (MP_shape) of the axisPosition filter 0: Off 1: Average 2: Triangle 3: HSC 4: Advanced HSC
		34	Index of physi- cal axis	Frequency (MP_frequency) of the axisPosi- tion filter in Hz
		35	Index of physi- cal axis	Order of the filter for Manual operating mode (MP_manualFilterOrder)
		36	Index of physi- cal axis	HSC mode (MP_hscMode) of the axisCut- terLoc filter
		37	Index of physi- cal axis	HSC mode (MP_hscMode) of the axisPosi- tion filter
		38	Index of physi- cal axis	Axis-specific jerk for probing movements (MP_axMeasJerk)
		39	Index of physi- cal axis	Weighting of the filter error for calculating filter deviation (MP_axFilterErrWeight)
		40	Index of physi- cal axis	Maximum filter length of position filter (MP_maxHscOrder)
		41	Index of physi- cal axis	Maximum filter length of CLP filter (MP_maxHscOrder)
		42	-	Maximum feed rate of the axis at machining feed rate (MP_maxWorkFeed)
		43	-	Maximum path acceleration at machining feed rate (MP_maxPathAcc)
		44	-	Maximum path acceleration at rapid traverse (MP_maxPathAccHi)
		51	Index of physi- cal axis	Compensation of following error in the jerk phase (MP_IpcJerkFact)
		52	Index of physi- cal axis	kv factor of the position controller in 1/s (MP_kvFactor)

Group name	Group number ID	System data number NO	Index IDX	Description
Measure th	ne maximum util	ization of an axis		
	621	0	Index of physi- cal axis	Conclude measurement of the dynamic load and save the result in the specified Q parameter.
Read SIK c	ontents			
	630	0	Option no.	You can explicitly determine whether the SIK option given under IDX has been set or not. 1 = option is enabled 0 = option is not enabled
		1	-	You can determine whether a Feature Content Level (for upgrade functions) is set, and which one. -1 = No FCL is set <no.> = FCL that is set</no.>
		2	-	Read serial number of the SIK -1 = No valid SIK in the system
		10	-	Define the type of control: 0 = iTNC 530 1 = NCK-based control (TNC 640, TNC 620, TNC 320, TNC 128, PNC 610,)
Read Func	tional Safety (FS)	information		
	820	1	-	FS limitations: 0 = No Functional Safety (FS) 1 = Guard door open (SOM1) 2 = Guard door open (SOM2) 3 = Guard door open (SOM3) 4 = Guard door open (SOM4) 5 = All guard doors closed
Counter				
	920	1	-	Planned workpieces. In Test Run operating mode the counter generally generates the value 0.
		2	-	Already machined workpieces. In Test Run operating mode the counter generally generates the value 0.
		12	-	Workpieces still to be machined. In Test Run operating mode the counter generally generates the value 0.
Read and v	write data of curr	ent tool		
	950	1	-	Tool length L
		2	-	Tool radius R
		3	-	Tool radius R2
		4	-	Oversize for tool length DL
		5	-	Tool radius oversize DR
		6	-	Tool radius oversize DR2

Group name	Group number ID	System data number NO	Index IDX	Description
		7	-	Tool locked TL 0 = not locked, 1 = locked
		8	-	Number of the replacement tool RT
		9	-	Maximum tool age TIME1
		10	-	Maximum tool age TIME2 at TOOL CALL
		11	-	Current tool age CUR.TIME
		12	-	PLC status
		13	-	Tooth length in the tool axis LCUTS
		14	_	Maximum plunge angle ANGLE
		15	-	TT: Number of tool teeth CUT
		16	-	TT: Wear tolerance for length LTOL
		17	-	TT: Wear tolerance for radius RTOL
		18	-	TT: Direction of rotation DIRECT 0 = positive, –1 = negative
		19	-	TT: Offset in plane R-OFFS R = 99999.9999
		20	-	TT: Offset in length L-OFFS
		21	-	TT: Break tolerance for length LBREAK
		22	-	TT: Break tolerance for radius RBREAK
		28	-	Maximum spindle speed [rpm] NMAX
		32	-	Point angle TANGLE
		34	-	LIFTOFF allowed (0 = No, 1 = Yes)
		35	_	Wear tolerance for radius R2TOL
		36	-	Tool type TYPE (miller = 0, grinder = 1, touch probe = 21)
		37	-	Corresponding line in the touch-probe table
		38	-	Timestamp of last use
		39	-	ACC
		40	_	Pitch for thread cycles
		44	_	Exceeding the tool life
		45	-	Front-face width of indexable insert (RCUTS
		46	-	Usable length of the milling cutter
		47	-	Neck radius of the milling cutter (RN)

Group name	Group number ID	System data number NO	Index IDX	Description
Freely avail	lable memory are	ea for tool manag	ement	
	956	0-9	-	Freely available data area for tool manage- ment. The data is not reset when the program is aborted.
Tool usage	and tooling			
	975	1	-	Tool usage test for the current NC program: Result –2: Test not possible, function disabled in the configuration Result –1: Test not possible, tool usage file missing Result 0: Test OK, all tools available Result 1: Test not OK
		2	Line	Check availability of the tools required in the pallet from line IDX in the current pallet table. -3 = No pallet is defined in row IDX, or function was called outside of pallet editing -2/-1/0/1 see NR1
Lift off the	tool at NC stop			
	980	3	-	 (This function is obsolete—HEIDENHAIN recommends not to use it any longer. ID980 NR3 = 1 is equivalent to ID980 NR1 = -1, ID980 NR3 = 0 has the same effect as ID980 NR1 = 0. Other values are not permissible.) Enable lift-off to the value defined in CfgLiftOff: 0 = Lock lift-off function 1 = Enable lift-off function
Touch prob	e cycles and coo	ordinate transform	ations	
	990	1	-	Approach behavior: 0 = Standard behavior 1 = Approach probing position without compensation. Effective radius, set-up clear- ance is zero
		2	16	Automatic / Manual machine operating modes
		4	-	0 = Stylus not deflected 1 = Stylus deflected
		6	-	TT tool touch probe active? 1 = Yes 0 = No
		8	-	Momentary spindle angle in [°]
		10	QS parameter no.	Determine the tool number from the tool name. The return value depends on the rules configured for the search of the replacement tool. If there are multiple tools with the same name, the first tool from the tool table will be selected.

Group name	Group number ID	System data number NO	Index IDX	Description
				If the tool selected by these rules is locked, a replacement tool will be returned. –1: No tool with the specified name found in the tool table or all qualifying tools are locked.
		16	0	0 = Transfer control over the channel spindle to the PLC, 1 = Assume control over the channel spindle
			1	0 = Pass tool spindle control to the PLC, 1 = Take control of the tool spindle
		19	-	Suppress touch prove movement in cycles: 0 = Movement will be suppressed (CfgMa- chineSimul/simMode parameter not equal to FullOperation or Test Run operating mode is active) 1 = Movement will be performed (CfgMa- chineSimul/simMode parameter = FullOpera- tion, can be programmed for testing purpos- es)
Status of	execution			
	992	10	-	Block scan active 1 = yes, 0 = no
		11	-	 Block scan—information on block scan: 0 = NC program started without block scan 1 = Iniprog system cycle is run before block scan 2 = Block scan is running 3 = Functions are being updated -1 = Iniprog cycle was canceled before block scan -2 = Cancellation during block scan -3 = Cancellation of the block scan after the search phase, before or during the update of functions -99 = Implicit cancellation
		12	-	 Type of canceling for interrogation within the OEM_CANCEL macro: 0 = No cancellation 1 = Cancellation due to error or emergency stop 2 = Explicit cancellation with internal stop after stop in the middle of the block 3 = Explicit cancellation with internal stop after stop at the end of a block
		14	-	Number of the last FN14 error
		16	-	Real execution active? 1 = execution, 0 = simulation
		17	-	2-D graphics during programming active? 1 = yes 0 = no

Group name	Group number ID	System data number NO	Index IDX	Description
		18	-	Live programming graphics (AUTO DRAW soft key) active? 1 = Yes 0 = No
		20	-	 Information on combined milling/turning mode of operation: 0 = Milling (after FUNCTION MODE MILL) 1 = Turning (after FUNCTION MODE TURN) 10 = Execute the operations for the turning-to-milling transition 11 = Execute the operations for the milling-to-turning transition
		30	-	Interpolation of multiple axes permitted? 0 = No (e.g. for straight cut control) 1 = yes
		31	-	R+/R– possible/permitted in MDI mode? 0 = No 1 = Yes
		32	0	Cycle call possible/permitted? 0 = No 1 = Yes
			Cycle number	Single cycle enabled: 0 = No 1 = Yes
		40	-	Copy tables in Test Run operating mode? Value 1 will be set when a program is selected and when the RESET+START soft key is pressed. The iniprog.h system cycle will then copy the tables and reset the system datum. 0 = no 1 = yes
		101	-	M101 active (visible condition)? 0 = no 1 = yes
		136	-	M136 active? 0 = no 1 = yes

Group name	Group number ID	System data number NO	Index IDX	Description
Activate m	achine paramete	r subfile		
	1020	13	QS parameter no.	Has a machine parameter subfile with path from QS number (IDX) been loaded? 1 = Yes 0 = No
Configurat	tion settings for a	ycles		
	1030	1	-	Display spindle does not rotate error message? (CfgGeoCycle/displaySpindleErr) 0 = no, 1 = yes
			-	Check the algebraic sign for depth error message! display? (CfgGeoCycle/displayDepthErr) 0 = no, 1 = yes
Data trans	fer between HEID	ENHAIN cycles ar	nd OEM macros	
	1031	1	0	Component monitoring: counter of the measurement. Cycle 238 Measure machine data automatically increments this counter.
			1	Component monitoring: Type of measure- ment -1 = No measurement. Writing of the value with FN17 concludes Cycle 238. 0 = Circular test 1 = Waterfall diagram 2 = Frequency response 3 = Envelope curve spectrum
			2	Component Monitoring: Index of the axis from CfgAxes\MP_axisList
			3 – 9	Component monitoring: further arguments depend on the measurement Further information: "Arguments for the circular interpolation test", Page Further information: "Arguments for the waterfall chart test", Page Further information: "Arguments for frequency response test", Page Further information: "Arguments for the envelope curve spectrum test", Page
		100	_	Component monitoring: optional names of the monitoring tasks, as specified in System Wonitoring CfgMonComponent . After completion of the measurement, the monitoring tasks stated here are execut- ed consecutively. When assigning the input parameters, remember to separate the listed monitoring tasks by commas.
User settir	ngs for the user in	nterface		
	1070	1	-	Feed rate limit of soft key FMAX; 0 = FMAX is inactive

Group name	Group number ID	System data number NO	Index IDX	Description
Bit test				
	2300	Number	Bit number	This function checks whether a bit has been set in a number. The number to be checked is transferred as NR, the bit to be searched for as IDX, with IDX0 designating the least significant bit. To call this function for great numbers, make sure to transfer NR as a Q parameter. 0 = Bit not set 1 = Bit set
Read prog	ram information (system string)		
	10010	1	-	Path of the current main program or pallet program.
		2	-	Path of the NC program shown in the block display.
		3	-	Path of the cycle selected with SEL CYCLE or CYCLE DEF 12 PGM CALL , or path of the currently active cycle
		10	-	Path of the NC program selected with SEL PGM " ".
Indexed ad	cess to QS param	neters		
	10015	20	QS parameter no.	Reads QS(IDX)
		30	QS parameter no.	Returns the string that you obtain if you replace anything except for letters and digits in QS(IDX) by '_'.
Read chan	nel data (system	string)		
	10025	1	-	Name of machining channel (key)
Read data	for SQL tables (sy	ystem string)		
	10040	1	-	Symbolic name of the preset table.
		2	-	Symbolic name of the datum table.
		3	-	Symbolic name of the pallet preset table.
		10	-	Symbolic name of the tool table.
		11	-	Symbolic name of the pocket table.
		12	-	Symbolic name of the turning tool table

name	Group number ID	System data number NO	Index IDX	Description
Values pro	grammed in the	tool call (system s	string)	
	10060	1	-	Tool name
Read macl	hine kinematics	(system strings)		
	10290	10	-	Symbolic name of the machine kinemat- ics from Channels/ChannelSettings/CfgKin- List/kinCompositeModels programmed in FUNCTION MODE MILL or FUNCTION MODE TURN .
Traverse ra	ange switchover	(system string)		
	10300	1	-	Key name of the last active range of traverse
Read curre	ent system time	(system string)		
	10321	1 - 16	-	1: DD.MM.YYYY hh:mm:ss 2 and 16: DD.MM.YYYY hh:mm 3: DD.MM.YY hh:mm 4: YYYY-MM-DD hh:mm:ss 5 and 6: YYYY-MM-DD hh:mm 7: YY-MM-DD hh:mm 8 and 9: DD.MM.YYY 10: DD.MM.YY 10: DD.MM.YY 11: YYYY-MM-DD 12: YY-MM-DD 13 and 14: hh:mm:ss 15: hh:mm As an alternative, you can use DAT in SYSSTR() to specify a system time in seconds that is to be used for formatting.
Read data	-	(TS, TT) (system s	string)	
	10350	50	-	TS probe type from TYPE column of the touch probe table (tchprobe.tp)
		70	-	Type of TT tool touch probe from CfgTT/type.
		73	-	Key name of the active tool touch probe TT from CfgProbes/activeTT .
Read and	write data of tou	ich probes (TS, TT)	(system string)	
Read and v	write data of tou 10350	rch probes (TS, TT) 74	(system string) -	Serial number of the active tool touch probe TT from CfgProbes/activeTT .
	10350		-	•
	10350	74	-	•
	10350 lata for pallet ma	74 achining (system s	-	TT from CfgProbes/activeTT .
Read the c	10350 lata for pallet m a 10510	74 achining (system s	- tring) -	TT from CfgProbes/activeTT . Pallet name
Read the c	10350 lata for pallet m a 10510	74 achining (system s	- tring) -	TT from CfgProbes/activeTT . Pallet name
Read the c Read versi	10350 Jata for pallet ma 10510 Jon ID of the NC 10630	74 achining (system s 1 2 software (system s	- - - string) -	TT from CfgProbes/activeTT . Pallet name Path of the selected pallet table. The string corresponds to the format of the version ID shown, e.g. 340590 09 or

Group name	Group number ID	System data number NO	Index IDX	Description
Read data	of the current too	ol (system string)		
	10950	1	-	Current tool name
		2	-	Entry from the DOC column of the active tool
		3	-	AFC control setting
		4	-	Tool-carrier kinematics
		5	-	Entry from the DR2TABLE column – file name of the compensation value table for 3D-ToolComp

Comparison: FN 18 functions

The following table lists the FN 18 functions from previous controls, which were not implemented in this manner in the TNC 620.

In most cases, this function has been replaced by another function.

No.	IDX	Contents	Replacement function
ID 10 Prog	ram information		
1	-	mm/inch condition	Q113
2	-	Overlap factor for pocket milling	CfgRead
4	-	Number of the active fixed cycle	ID 10 no. 3
ID 20 Macl	hine status		
15	Log. axis	Assignment between logic and geometric axes	
16	-	Feed rate for transition arcs	
17	_	Currently selected range of traverse	SYSTRING 10300
19	-	Maximum spindle speed for current gear stage and spindle	Maximum gear range: ID 90 No. 2
ID 50 Data	from the tool table		
23	Tool no.	PLC value	1)
24	Tool no.	Probe center offset in reference axis (CAL- OF1)	ID 350 NR 53 IDX 1
25	Tool no.	Probe center offset in minor axis (CALOF-2)	ID 350 NR 53 IDX 2
26	Tool no.	Spindle angle during calibration (CAL-ANG)	ID 350 NR 54
27	Tool no.	Tool type for pocket table (PTYP)	2)
29	Tool no.	Position P1	1)
30	Tool no.	Position P2	1)
31	Tool no.	Position P3	1)
33	Tool no.	Thread pitch (Pitch)	ID 50 NR 40
ID 51 Data	from the pocket tal	ble	
6	Pocket no.	Tool type	2)
7	Pocket no.	P1	2)

No.	IDX	Contents	Replacement function
8	Pocket no.	P2	2)
9	Pocket no.	P3	2)
10	Pocket no.	P4	2)
11	Pocket no.	P5	2)
12	Pocket no.	Pocket reserved	2)
		0 = No, 1 = Yes	
13	Pocket no.	Box magazine: Pocket above occupied: 0 = No, 1 = Yes	2)
14	Pocket no.	Box magazine: Pocket below occupied: 0 = No, 1 = Yes	2)
15	Pocket no.	Box magazine: Pocket to the left occupied: 0 = No, 1 = Yes	2)
16	Pocket number	Box magazine: Pocket to the right occupied: 0 = No, 1 = Yes	2)
ID 56 File inform	nation		
1	-	Number of lines of the tool table	
2	-	Number of lines of the active datum table	
3	Q parameters	Number of active axes that are programmed in the active datum table	
4	-	Number of lines in a freely definable table that has been opened with FN 26: TABOPEN	
ID 214 Current	contour data		
1	-	Contour transition mode	
2	-	Max. linearization error	
3	-	Mode for M112	
4	-	Character mode	
5	-	Mode for M124	1)
6	-	Specification for contour pocket machining	
7	-	Filter for control loop	
8	-	Tolerance programmed with Cycle 32	ID 30 no. 48
ID 240 Nominal	positions in the	REF system	
8	-	ACTUAL position in the REF system	
ID 280 Informat	ion on M128		
2	-	Feed rate that was programmed with M128	ID 280 NR 3
ID 290 Switch t	he kinematics		
1	-	Line of the active kinematics table	SYSSTRING 10290
2	Bit no.	Interrogate the bits in MP7500	Cfgread
3	-	Status of collision monitoring (old)	Can be activated and deactivat- ed in the NC program

No.	IDX	Contents	Replacement function
4	-	Status of collision monitoring (new)	Can be activated and deactivat- ed in the NC program
ID 310 Modi	fications of geom	netrical behavior	
116	-	M116: -1 = On, 0 = Off	
126	-	M126: -1 = On, 0 = Off	
ID 350 Touch	h-probe data		
10	-	TS: Touch-probe axis	ID 20 NR 3
11	-	TS: Effective ball radius	ID 350 NR 52
12	-	TS: Effective length	ID 350 NR 51
13	-	TS: Ring gauge radius	
14	1/2	TS: Center offset in reference/minor axis	ID 350 NR 53
15	-	TS: Direction of center offset relative to 0° position	ID 350 NR 54
20	1/2/3	TT: Center point X/Y/Z	ID 350 NR 71
21	-	TT: Plate radius	ID 350 NR 72
22	1/2/3	TT: 1st probing position X/Y/Z	Cfgread
23	1/2/3	TT: 2nd probing position X/Y/Z	Cfgread
24	1/2/3	TT: 3rd probing position X/Y/Z	Cfgread
25	1/2/3	TT: 4th probing position X/Y/Z	Cfgread
ID 370 Touch	h probe cycle set	tings	
1	-	Do not move to set-up clearance in Cycle 0.0 and 1.0 (as with ID990 NR1)	ID 990 NR 1
2	-	MP 6150 Rapid traverse for measurement	ID 350 NR 55 IDX 1
3	-	MP 6151 Machine rapid traverse as rapid traverse for measurement	ID 350 NR 55 IDX 3
4	-	MP 6120 Feed rate for measurement	ID 350 NR 55 IDX 2
5	-	MP 6165 Angle tracking on/off	ID 350 NR 57
ID 501 Datu	m table (REF syst	em)	
Line	Column	Value in datum table	Preset table
ID 502 Prese	et table		
Line	Column	Read the value from preset table, taking into account the active machining system	
ID 503 Prese	et table		
Line	Column	Read the value directly from the preset table	ID 507
ID 504 Prese	et table		
Line	Column	Read the basic rotation from the preset table	ID 507 IDX 4-6
ID 505 Datu	m table		
1	-	0 = No datum table selected	
		1 = Datum table selected	

No.	IDX	Contents	Replacement function
ID 510 Data fo	r pallet machining	3	
7	-	Test the insertion of a fixture from the PAL line	
ID 530 Active	preset		
2	Line	Write-protect the line in the active preset table:	FN 26 and FN 28: read out the Locked column
		0 = No, 1 = Yes	
ID 990 Approa	ich behavior		
2	10	0 = No execution in block scan	ID 992 NR 10 / NR 11
		1 = Execution in block scan	
3	Q parameters	Number of axes that are programmed in the selected datum table	
ID 1000 Machi	ine parameter		
MP number	MP index	Value of the machine parameter	CfgRead
ID 1010 Machi	ne parameter is d	efined	
MP number	MP index	0 = Machine parameter does not exist	CfgRead
		1 = Machine parameter exists	

¹⁾ Function or table column no longer exists

 $^{2)}\,$ Use FN 26 and FN 28 or SQL to read out the table cell

15.2 Overview tables

Miscellaneous functions

М	Effect Effective at block	Start	End	Page
M0	Program STOP/Spindle STOP/Coolant OFF			223
M1	Optional program run STOP/Spindle STOP/Coolant OFF			223
M2	Stop program/Spindle STOP/Coolant OFF/ CLEAR status display (depending on machine parameter)/Return jump to block 1			223
M3 M4 M5	Spindle ON clockwise Spindle ON counterclockwise Spindle STOP	•		223
M6	Tool change/STOP program run (depending on machine parameter)/Spindle STOP			223
M8 M9	Coolant ON Coolant OFF			223
M13 M14	Spindle ON clockwise/Coolant ON Spindle ON counterclockwise/Coolant on			223
M30	Same function as M2			223
M89	Vacant miscellaneous function or cycle call, modally effective (depending on machine parameter)	•		Cycles Manual
M91	Within the positioning block: Coordinates are referenced to machine datum			224
M92	Within the positioning block: Coordinates are referenced to a position defined by machine manufacturer, e.g. tool change position	•		224
M94	Reduce the rotary axis display to a value below 360°			445
M97	Machine small contour steps			227
M98	Machine open contours completely			228
M99	Blockwise cycle call			Cycles Manual
M101	Automatic tool change with replacement tool if maximum tool life has expired			129
M102	Reset M101			
	Feed rate factor for plunging movements			229
M107 M108	Suppress error message for replacement tools with oversize Reset M107			457
M109 M110 M111	Constant contouring speed at cutting edge (feed rate increase and reduction) Constant contouring speed at cutting edge (only feed rate reduction) Reset M109/M110			230
M116 M117	Feed rate in mm/min on rotary axes Reset M116	•		443
M118	Superimpose handwheel positioning during program run			234
M120	Pre-calculate the radius-compensated contour (LOOK AHEAD)			232
M126 M127	Shorter-path traverse of rotary axes Reset M126	•		444

М	Effect Effec	ctive at block	Start	End	Page
M128	Maintaining the position of the tool tip when positioning with tilte (TCPM)	ed axes	•		446
M129	Reset M128				
M130	Within the positioning block: Points are referenced to the untilted system	d coordinate			226
M136 M137	Feed rate F in millimeters per spindle revolution Reset M136				230
M138	Selection of tilted axes				448
M140	Retraction from the contour in the tool-axis direction		-		235
M141	Suppress touch probe monitoring		-		237
M143	Delete basic rotation		-		237
M144	Compensating the machine's kinematic configuration for ACTUA positions at end of block	L/NOMINAL	•		449
M145	Reset M144				
M148	Automatically retract tool from the contour at an NC stop				238
M149	Reset M148				
M197	Corner rounding		-		239

User functions

User functions					
Short description		Basic version: 3 axes plus closed-loop spindle			
		Additional axis for 4 axes plus closed-loop spindle			
		Additional axis for 5 axes plus closed-loop spindle			
Program entry	In H	HEIDENHAIN conversational format and ISO (G codes)			
Position entry	-	Nominal positions for lines and arcs in Cartesian coordinates or polar coordinates			
		Incremental or absolute dimensions			
		Display and entry in mm or inches			
Tool compensation		Tool radius in the working plane and tool length			
	х	Radius compensated contour look ahead for up to 99 blocks (M120)			
Tool tables	Mu	Itiple tool tables with any number of tools			
Constant contour speed		With respect to the path of the tool center			
		With respect to the cutting edge			
Parallel operation		Creating an NC program with graphical support while another NC program is being run			
Cutting data		comatic calculation of spindle speed, cutting speed, feed per tooth, and d per revolution			
3-D machining	2	Motion control with minimum jerk			
(Advanced Function Set 2)	2	3-D tool compensation via surface-normal vectors			
	2	Using the electronic handwheel to change the angle of the swivel head during program run without affecting the position of the tool center point (tool tip or center of sphere) (TCPM = T ool C enter P oint M anagement)			
	2	Keeping the tool normal to the contour			
	2	Tool radius compensation perpendicular to traversing and tool direction			
Rotary table machining	1	Programming of cylindrical contours as if in two axes			
(Advanced Function Set 1)	1	Feed rate in distance per minute			
Contour elements	-	Straight line			
		Chamfer			
		Circular path			
	-	Circle center			
		Circle radius			
		Tangentially connected arc			
		Rounded corners			

User functions			
Approaching and departing the contour		Via straight line: tangential or perpendicular	
		Via circular arc	
Free contour programming (FK)	x	FK free contour programming in HEIDENHAIN Klartext format with graphic support for workpiece drawings not dimensioned for NC	
Program jumps		Subprograms	
		Program section repeats	
		External NC programs	
Machining cycles		Cycles for drilling, and conventional and rigid tapping	
	х	Cycles for pecking, reaming, boring, and counterboring	
	х	Cycles for milling internal and external threads	
		Roughing and finishing rectangular and circular pockets	
	х	Roughing and finishing rectangular and circular studs	
	х	Cycles for clearing level and inclined surfaces	
	x	Cycles for milling linear and circular slots	
	x	Cartesian and polar point patterns	
	х	Contour pocket	
	х	Contour train	
	x	OEM cycles (special cycles developed by the machine manufacturer) can also be integrated	
Coordinate transformation		Datum shift, rotation, mirroring	
		Scaling factor (axis-specific)	
	1	Tilting of the working plane (Advanced Function Set 1)	
Q parameters		Mathematical functions =, +, -, $*$, /, roots	
Programming with variables		Logical operations (=, \neq , <, >)	
		Calculating with parentheses	
		sin α , cos α , tan α , arc sin, arc cos, arc tan, a ⁿ , e ⁿ , ln, log, absolute value of a number, constant π , negation, truncation of digits before or after the decimal point	
		Functions for calculation of circles	
		String parameters	

User functions		
Programming aids		Calculator
		Color highlighting of syntax elements
		Complete list of all current error messages
		Context-sensitive help function
		Graphic support for the programming of cycles
		Comment and structure blocks in the NC program
Teach-In		Actual positions can be transferred directly to the NC program
Test graphics Display modes		Graphic simulation before a program run, even while another NC program is being run
	х	Plan view / projection in 3 planes / 3-D view / 3-D line graphics
	х	Detail enlargement
Programming graphics	•	In the Programming operating mode, the contours of the NC blocks are drawn on screen while they are being entered (2-D pencil-trace graphics), even while another NC program is being run
Program-run graphics Display modes	х	Graphic simulation of real-time machining in plan view / projection in 3 planes / 3-D view
Machining time		Calculation of machining time in the Test Run operating mode
		Display of the current machining time in the Program Run, Single Block and Program Run, Full Sequence operating modes
Preset management		For saving any datums
Returning to the contour		Block scan in any NC block in the NC program, returning the tool to the calculated nominal position to continue machining
		NC program interruption, contour departure and return
Datum tables		Multiple datum tables for storing workpiece-specific datums
Touch probe cycles	х	Calibrating the touch probe
	x	Compensation of workpiece misalignment, manual or automatic
	x	Manual and automatic presetting
	х	Automatic workpiece measurement
	х	Tools can be measured automatically

15.3 Differences between the TNC 620 and the iTNC 530

Comparison: PC software

Function	TNC 620	iTNC 530
ConfigDesign for the configuration of machine parameters	Available	Not available
TNCanalyzer for the analysis and evaluation of service files	Available	Not available

Comparison: User functions

Function	TNC 620	iTNC 530
Program entry		
smarT.NC		X
 ASCII editor 	 X, directly editable 	 X, editable after conversion
Position entry		
 Set the last tool position as pole (empty CC block) 	 X (error message if pole transfer is ambiguous) 	• X
Spline sets (SPL)	I -	X, with option 9
Tool table		
 Flexible management of tool types 	X	
 Filtered display of selectable tools 	X	
 Sorting function 	X	
Column names	Sometimes with _	Sometimes with -
Form view	 Switchover with Screen Layout key 	 Switchover by soft key
 Exchange of tool table between TNC 620 and iTNC 530 	= X	 Not possible
Touch probe table for managing different 3-D touch probes	Х	-
Cutting data calculator : Automatic calculation of spindle speed and feed rate	 Simple cutting data calculator without stored table Cutting data calculator with stored technology tables 	Using stored technology tables

Function	TNC 620	iTNC 530
Define any tables	 Freely definable tables (.TAB files) 	 Freely definable tables (.TAB files)
	 Reading and writing with FN functions 	 Reading and writing with FN functions
	 Definable via config. data 	
	 The names of tables and table columns must start with a letter, and no arithmetic operators are permitted 	
	 Reading and writing with SQL functions 	
Traverse in tool-axis direction		
 Manual operation (3-D ROT menu) 	■ X	 X, FCL2 function
With handwheel superimpositioning	• X	X, option 44
Entry of feed rates:		
FT (time in seconds for path)	1 -	■ X
 FMAXT (only for active rapid traverse potentiometer: time in seconds for path) 		■ X
FK free contour programming		
 Programming for workpiece drawings not dimensioned for NC programming 	X, option 19	■ X
 Conversion of FK program to Klartext conversational language 		■ X
FK blocks in combination with M89		■ X
Program jumps:		
 Maximum number of labels 	65535	1000
Subprograms	X	■ X
Nesting depth for subprograms	2 0	■ 6

Fι	inction	TNC 620	iTNC 530
Q	parameter programming:		
	FN 15: PRINT		■ X
	FN 25: PRESET		■ X
	FN 29: PLC LIST	X	I -
	FN31: RANGE SELECT		■ X
	FN32: PLC PRESET		■ X
	FN37: EXPORT	X	
	FN 16	■ X	
	 Writing to LOG files 	■ X	-
	 Configurable behavior for undefined or empty QS parameters 		
	Displaying parameter contents in the additional status display	• X	
	SQL functions for writing and reading tables	X	I -
G	raphic support		
	2-D programming graphics	X	×
	REDRAW function (REDRAW)	-	X
	Show grid lines as the background	■ X	
-	Program run graphics (plan view, projection in 3 planes, 3-D view)	X, with option 20	• X
	 High-resolution view 	X	X
-	Test graphics (plan view, projection on 3 planes, 3-D view)	X, with option 20	• X
	Tool display	X, with option 20	X
	 Adjusting the simulation speed 	X, with option 20	X
	 Coordinates of line intersection for projection in 3 planes 		■ X
	 Expanded zoom functions (mouse operation) 	X, with option 20	X
	 Displaying frame for workpiece blank 	X, with option 20	X
	 Displaying the depth value in plan view during mouse-over 	X, with option 20	= X
	Deliberately stop test run (STOP AT)	X, with option 20	X
	 Factor in tool change macro 	 X (differing to actual execution) 	= X

Function	TNC 620	iTNC 530
Preset table		
Line 0 of the preset table can be edited manually	X	
Pallet management		
 Support of pallet files 	X, option 22	X
 Tool-oriented machining 	X, option 22	= X
 Management of presets for a pallet in a table 	X, option 22	• X
Programming aids:		
 Color highlighting of syntax elements 	X	
Calculator	 X (scientific) 	 X (standard)
Convert NC blocks to comments	■ X	
 Structure blocks in NC program 	■ X	■ X
 Structure view in test run 		■ X
Dynamic Collision Monitoring (DCM):		
 Collision monitoring in Automatic operation 	-	X, option 40
 Collision monitoring in Manual operation 		X, option 40
 Graphic depiction of the defined collision objects 	-	X, option 40
 Collision checking in test run 	-	X, option 40
 Fixture monitoring 	-	X, option 40
Tool carrier management	X	X, option 40
CAM support:		
Load contours from Step data and Iges data	 X, option 42 	I -
Load machining positions from Step data and Iges data	 X, option 42 	I -
 Offline filter for CAM files 	-	X
Stretch filter	• X	I -
MOD functions:		
User parameters	 Config data 	 Numerical structure
 OEM help files with service functions 	-	• X
Data medium inspection	-	• X
Load service packs	-	• X
 Specify the axes for actual position capture 		• X
Configure counter	X	

Function	TNC 620	iTNC 530
Special functions:		
 Create reverse program 		■ X
Adaptive Feed Control AFC		X, option 45
Define the counter with FUNCTION COUNT	= X	
Define the dwell time with FUNCTION FEED	X	
Define the dwell time with FUNCTION DWELL	X	
 Determine the integration of the programmed coordinates with FUNCTION PROG PATH 	■ X	
Functions for large molds and dies:		
 Global program settings (GS) 	1 -	X, option 44
Status displays:		
 Dynamic display of Q-parameter contents, definable number ranges 	■ X	
 Graphic display of residual run time 	-	■ X
Individual color settings of user interface	-	Х

568

15

Comparison: Miscellaneous functions

Μ	Effect	TNC 620	iTNC 530
M00	Program STOP/Spindle STOP/Coolant OFF	Х	Х
M01	Optional program STOP	Х	Х
M02	Stop program/Spindle STOP/Coolant OFF/ Clear status display (depending on machine parameter)/Return jump to block 1	Х	Х
M03 M04 M05	Spindle ON clockwise Spindle ON counterclockwise Spindle STOP	X	Х
M06	Tool change/Program run STOP (machine-specific function)/ Spindle STOP	Х	Х
M08 M09	Coolant ON Coolant OFF	Х	Х
M13 M14	Spindle ON clockwise/Coolant ON Spindle ON counterclockwise/Coolant on	Х	Х
M30	Same function as M02	Х	Х
M89	Free miscellaneous function or cycle call, modally effective (machine-specific function)	Х	Х
M90	Constant contouring speed at corners (not required at TNC 620)	_	Х
M91	Within the positioning block: Coordinates are referenced to machine datum	Х	Х
M92	Within the positioning block: Coordinates are referenced to a position defined by machine manufacturer, e.g. tool change position	Х	Х
M94	Reduce the rotary axis display to a value below 360°	Х	Х
M97	Machine small contour steps	Х	Х
M98	Machine open contours completely	Х	Х
M99	Blockwise cycle call	Х	Х
M101 M102	Automatic tool change with replacement tool if maximum tool life has expired Reset M101	Х	Х
M103	Reduce feed rate during plunging to factor F (percentage)	Х	X
M104	Reactivate most recently set preset	– (recommended: Cycle 247)	Х
M105 M106	Machining with second k _v factor Machining with first k _v factor	-	Х
M107 M108	Suppress error message for replacement tools with oversize Reset M107	Х	Х
M109	Constant contouring speed at cutting edge (feed rate increase	Х	Х
M110	and reduction) Constant contouring speed at cutting edge (only feed rate	Х	Х
M111	reduction) Reset M109/M110	X	Х
	Functionality for APPR and DEP	Х	

М	Effect	TNC 620	iTNC 530
M112 M113	Enter contour transitions between any two contour transitions Reset M112	– (recommended: Cycle 32)	Х
M114	Automatic compensation of machine geometry when working with tilted axes	– (recommended: M128, TCPM)	X, option 8
M115	Reset M114		
M116 M117	Feed rate on rotary tables in mm/min Reset M116	X, option 8	X, option 8
M118	Superimpose handwheel positioning during program run	X, option 21	Х
M120	Pre-calculate the radius-compensated contour (LOOK AHEAD)	X, option 21	Х
M124	Contour filter	– (possible via user parameters)	Х
M126 M127	Shorter-path traverse of rotary axes Reset M126	Х	Х
M128	Maintaining the position of the tool tip when positioning tilted axes (TCPM)	X, option 9	X, option 9
M129	Reset M128		
M130	Within the positioning block: Points are referenced to the untilt- ed coordinate system	Х	Х
M134 M135	Precision stop at non-tangential contour transitions when positioning with rotary axes Reset M134	X (depends on the machine tool builder)	Х
M136 M137	Feed rate F in millimeters per spindle revolution Reset M136	X	Х
M138	Selection of tilted axes	Х	Х
M140	Retraction from the contour in the tool-axis direction	Х	Х
M141	Suppress touch probe monitoring	Х	Х
M142	Delete modal program information	_	Х
M143	Delete basic rotation	Х	Х
M144	Compensating the machine's kinematic configuration for ACTUAL/NOMINAL positions at end of block	X, option 9	X, option 9
M145	Reset M144		
M148 M149	Automatically retract tool from the contour at an NC stop Reset M148	Х	Х
M150	Suppress limit switch message	-	Х
M197	Rounding the corners	Х	_
M200	Laser cutting functions	_	Х
-			

M204

Comparator: Cycles

Cycle	TNC 620	iTNC 530
1 PECKING (recommended: Cycle 200, 203, 205)	_	Х
2 TAPPING (recommended: Cycle 206, 207, 208)	_	Х
3 SLOT MILLING (recommended: Cycle 253)	_	Х
4 POCKET MILLING (recommended: Cycle 251)	_	Х
5 CIRCULAR POCKET (recommended: Cycle 252)	_	Х
6 ROUGH-OUT (SL I, recommended: SL II, Cycle 22)	-	Х
7 DATUM SHIFT	Х	Х
8 MIRRORING	Х	Х
9 DWELL TIME	Х	Х
10 ROTATION	Х	Х
11 SCALING FACTOR	Х	Х
12 PGM CALL	Х	Х
13 ORIENTATION	Х	Х
14 CONTOUR	Х	Х
15 PILOT DRILLING (SL I, recommended: SL II, Cycle 21)	-	Х
16 CONTOUR MILLING (SL I, recommended: SL II, Cycle 24)	_	Х
17 RIGID TAPPING (recommended: Cycle 207, 209)	_	Х
18 THREAD CUTTING	Х	Х
19 WORKING PLANE	X, option 8	X, option 8
20 CONTOUR DATA	X, option 19	Х
21 PILOT DRILLING	X, option 19	Х
22 ROUGH-OUT	X, option 19	Х
23 FLOOR FINISHING	X, option 19	Х
24 SIDE FINISHING	X, option 19	Х
25 CONTOUR TRAIN	X, option 19	Х
26 AXIS-SPECIFIC SCALING	Х	Х
27 CYLINDER SURFACE	X, option 8	X, option 8
28 CYLINDER SURFACE	X, option 8	X, option 8
29 CYL SURFACE RIDGE	X, option 8	X, option 8
30 RUN CAM DATA	-	Х
32 TOLERANCE	Х	Х
39 CYL. SURFACE CONTOUR	X, option 8	X, option 8
200 DRILLING	Х	Х
201 REAMING	X, option 19	Х
202 BORING	X, option 19	Х
203 UNIVERSAL DRILLING	X, option 19	Х
204 BACK BORING	X, option 19	Х

Cycle	TNC 620	iTNC 530
205 UNIVERSAL PECKING	X, option 19	Х
206 TAPPING	Х	Х
207 RIGID TAPPING	Х	Х
208 BORE MILLING	X, option 19	Х
209 TAPPING W/ CHIP BRKG	X, option 19	Х
210 SLOT RECIP. PLNG (recommended: Cycle 253, option 19)	_	Х
211 CIRCULAR SLOT (recommended: Cycle 254, option 19)	_	Х
212 POCKET FINISHING (recommended: Cycle 251, option 19)	_	Х
213 STUD FINISHING (recommended: Cycle 256, option 19)	_	Х
214 C. POCKET FINISHING (recommended: Cycle 252, option 19)	_	Х
215 C. STUD FINISHING (recommended: Cycle 257, option 19)	_	Х
220 POLAR PATTERN	X, option 19	Х
221 CARTESIAN PATTERN	X, option 19	Х
224 DATAMATRIX CODE PATTERN	X, option 19	_
225 ENGRAVING	X, option 19	Х
230 MULTIPASS MILLING (recommended: Cycle 233, option 19)	_	Х
231 RULED SURFACE	_	Х
232 FACE MILLING	X, option 19	Х
233 FACE MILLING	X, option 19	_
238 MEASURE MACHINE STATUS	X, Option 155	_
240 CENTERING	X, option 19	Х
241 SINGLE-LIP D.H.DRLNG	X, option 19	Х
247 PRESETTING	Х	Х
251 RECTANGULAR POCKET	X, option 19	Х
252 CIRCULAR POCKET	X, option 19	Х
253 SLOT MILLING	X, option 19	Х
254 CIRCULAR SLOT	X, option 19	Х
256 RECTANGULAR STUD	X, option 19	Х
257 CIRCULAR STUD	X, option 19	Х
258 POLYGON STUD	X, option 19	_
262 THREAD MILLING	X, option 19	Х
263 THREAD MLLNG/CNTSNKG	X, option 19	Х
264 THREAD DRILLNG/MLLNG	X, option 19	Х
265 HEL. THREAD DRLG/MLG	X, option 19	Х
267 OUTSIDE THREAD MLLNG	X, option 19	Х
270 CONTOUR TRAIN DATA for defining the behavior of Cycle 25	Х	Х
271 OCM CONTOUR DATA	X, option 167	_
272 OCM ROUGHING	X, option 167	_

Cycle	TNC 620	iTNC 530
273 OCM FINISHING FLOOR	X, option 167	_
274 OCM FINISHING SIDE	X, option 167	_
275 TROCHOIDAL SLOT	X, option 19	Х
276 THREE-D CONT. TRAIN	X, option 19	Х
277 OCM CHAMFERING	X, option 167	_
290 INTERPOLATION TURNING	_	X, option 96
1271 OCM RECTANGLE	X, option 167	_
1272 OCM CIRCLE	X, option 167	_
1273 OCM SLOT / RIDGE	X, option 167	_
1278 OCM POLYGON	X, option 167	_
1281 OCM RECTANGLE BOUNDARY	X, option 167	_
1282 OCM CIRCLE BOUNDARY	X, option 167	_

Comparison: Touch probe cycles in the Manual operation and Electronic handwheel operating modes

Cycle	TNC 620	iTNC 530
Touch-probe table for managing 3-D touch probes	Х	_
Calibrating the effective length	X, option 17	Х
Calibrating the effective radius	X, option 17	Х
Measuring a basic rotation using a line	X, option 17	Х
Setting the preset on any axis	X, option 17	Х
Setting a corner as preset	X, option 17	Х
Setting a circle center as preset	X, option 17	Х
Setting a center line as preset	X, option 17	Х
Measuring a basic rotation using two holes/cylindrical studs	X, option 17	Х
Setting the preset using four holes/cylindrical studs	X, option 17	Х
Setting the circle center using three holes/cylindrical studs	X, option 17	Х
Determine and offset misalignment of a plane	X, option 17	_
Support of mechanical touch probes by manually capturing the current position	By soft key or hard key	By hard key
Write measurement values to the preset table	X, option 17	Х
Write measurement values to the datum table	X, option 17	Х

Comparison: Probing system cycles for automatic workpiece control

Cycle	TNC 620	iTNC 530
0 REF. PLANE	X, option 17	Х
1 POLAR PRESET	X, option 17	Х
2 CALIBRATE TS	-	Х
3 MEASURING	X, option 17	Х
4 MEASURING IN 3-D	X, option 17	Х
9 CALIBRATE TS LENGTH	_	Х
30 CALIBRATE TT	X, option 17	Х
31 CAL. TOOL LENGTH	X, option 17	Х
32 CAL. TOOL RADIUS	X, option 17	Х
33 MEASURE TOOL	X, option 17	Х
400 BASIC ROTATION	X, option 17	Х
401 ROT OF 2 HOLES	X, option 17	Х
402 ROT OF 2 STUDS	X, option 17	Х
403 ROT IN ROTARY AXIS	X, option 17	Х
404 SET BASIC ROTATION	X, option 17	Х
405 ROT IN C AXIS	X, option 17	Х
408 SLOT CENTER PRESET	X, option 17	Х
409 RIDGE CENTER PRESET	X, option 17	Х
410 PRESET INSIDE RECTAN	X, option 17	Х
411 PRESET OUTS. RECTAN	X, option 17	Х
412 PRESET INSIDE CIRCLE	X, option 17	Х
413 PRESET OUTS. CIRCLE	X, option 17	Х
414 PRESET OUTS. CORNER	X, option 17	Х
415 PRESET INSIDE CORNER	X, option 17	Х
416 PRESET CIRCLE CENTER	X, option 17	Х
417 PRESET IN TS AXIS	X, option 17	Х
418 PRESET FROM 4 HOLES	X, option 17	Х
419 PRESET IN ONE AXIS	X, option 17	Х
420 MEASURE ANGLE	X, option 17	Х
421 MEASURE HOLE	X, option 17	Х
422 MEAS. CIRCLE OUTSIDE	X, option 17	Х
423 MEAS. RECTAN. INSIDE	X, option 17	Х
424 MEAS. RECTAN. OUTS.	X, option 17	Х
425 MEASURE INSIDE WIDTH	X, option 17	Х
426 MEASURE RIDGE WIDTH	X, option 17	Х
427 MEASURE COORDINATE	X, option 17	Х

Cycle	TNC 620	iTNC 530
430 MEAS. BOLT HOLE CIRC	X, option 17	Х
431 MEASURE PLANE	X, option 17	Х
440 MEASURE AXIS SHIFT	-	Х
441 FAST PROBING	X, option 17	Х
450 SAVE KINEMATICS	X, Option 48	X, option 48
451 MEASURE KINEMATICS	X, Option 48	X, option 48
452 PRESET COMPENSATION	X, Option 48	X, option 48
453 KINEMATICS GRID		_
460 CALIBRATION OF TS ON A SPHERE	X, option 17	Х
461 TS CALIBRATION OF TOOL LENGTH	X, option 17	Х
462 CALIBRATION OF A TS IN A RING	X, option 17	Х
463 TS CALIBRATION ON STUD	X, option 17	Х
480 CALIBRATE TT	X, option 17	Х
481 CAL. TOOL LENGTH	X, option 17	Х
482 CAL. TOOL RADIUS	X, option 17	Х
483 MEASURE TOOL	X, option 17	Х
484 CALIBRATE IR TT	X, option 17	Х
600 GLOBAL WORKING SPACE	Х	_
601 LOCAL WORKING SPACE	Х	_
1410 PROBING ON EDGE	X, option 17	_
1411 PROBING TWO CIRCLES	X, option 17	_
1420 PROBING IN PLANE	X, option 17	_

Comparison: Differences in programming

Function	TNC 620	iTNC 530
File management:		
 Entry of name 	Opens the Select file pop-up window.	 Synchronizes the cursor
 Support of key combinations 	Not available	 Available
 Favorites Management 	Not available	 Available
 Configuration of column structure 	 Not available 	 Available
Selecting a tool from the table	Selection via split-screen menu	Selection in a pop-up window
Programming special functions with the SPEC FCT key	Pressing the key opens a soft-key row as a submenu. To exit the submenu, press the SPEC FCT key again; then the control shows the last active soft-key row	Pressing the key adds the soft- key row as the last row. To exit the menu, press the SPEC FCT key again; then the control shows the last active soft-key row
Programming approach and depar- ture motions with the APPR DEP key	Pressing the key opens a soft-key row as a submenu. To exit the submenu, press the APPR DEP key again; then the control shows the last active soft-key row	Pressing the key adds the soft- key row as the last row. To exit the menu, press the APPR DEP key again; then the control shows the last active soft-key row
Pressing the hard key END with active CYCLE DEF and TOUCH PROBE menus	Terminates the editing process and calls the file manager	Exits the respective menu
Calling the file manager if CYCLE DEF and TOUCH PROBE menus are active	Terminates the editing process and calls the file manager. The respec- tive soft-key row remains selected when the file manager is exited	Key non-functional error message.
Calling the file manager if CYCL CALL, SPEC FCT, PGM CALL and APPR DEP menus are open	Terminates the editing process and calls the file manager. The respec- tive soft-key row remains selected when the file manager is exited	Terminates the editing process and calls the file manager. The basic soft-key row is selected when the file manager is exited

Function	TNC 620	iTNC 530
Datum table:		
 Sorting function by values within an axis 	 Available 	 Not available
Resetting the table	Available	 Not available
Switching the list/form view	Switch via the screen layout key	 Switchover by toggle soft key
 Inserting individual line 	 Allowed everywhere, renumbering possible after request. Empty line is inserted, must be filled with zeros manually 	 Only allowed at the end of the table. Line with value 0 in all columns is inserted
 Transfer of actual position values on individual axis to the datum table using the keys 	 Available in the Program Run Single Block and Program Run, Full Sequence operating modes 	Available
 Transfer of actual position values on all active axes to the datum table using the keys 	Not available	Available
 Capturing the last positions measured by TS using the keys 	 Not available 	Available
FK free contour programming:		
 Programming of parallel axes 	 With X/Y coordinates, independent of machine type; switchover with FUNCTION PARAXMODE 	 Machine-dependent with the existing parallel axes
 Automatic correction of relative references 	 Relative references in contour subprograms are not corrected automatically 	 All relative references are corrected automatically
 Specify the working plane during 	BLK form	 BLK form
programming	Plane XY ZX YZ soft key if the working plane differs	

Fu	Inction	TNC 620	iΤ	NC 530
Q	-parameter programming:			
	Q-parameter formula with SGN	Q12 = SGN Q50 If Q50 = 0 then Q12 = 0 If Q50 > 0 then Q12 = 1 If Q50 < 0 then Q12 -1	Q = =	12 = SGN Q50 If Q50 >= 0 then Q12 = 1 If Q50 < 0 then Q12 -1
-	Access to table data	 Via SQL commands and via FN 18 or TABREAD-TABWRITE functions To tool and compensation-value tables via TABDATA 	-	Via FN 18 or TABREAD-TABWRITE functions
	Access to machine parameters	 With the CFGREAD function 		Via FN 18 functions
	Creating interactive cycles with CYCLE QUERY , e.g. touch probe cycles in Manual Operation	 Available 	-	Not available
Н	andling of error messages:			
	Help with error messages	Call via ERR key		Call via HELP key
=	Switching the operating mode while help menu is active	 Help menu is closed when the operating mode is switched 		Operating mode switchover is not allowed (key is non- functional)
	Selecting the background operating mode while help menu is active	 Help menu is closed when F12 is used for switching 		Help menu remains open when F12 is used for switching
	Identical error messages	Are collected in a list		Are displayed only once
	Acknowledgment of error messages	 Every error message (even if it is displayed more than once) must be acknowledged, the DELETE ALL function is available 	-	Error message to be acknowledged only once
	Access to protocol functions	 Log and powerful filter functions (errors, keystrokes) are available 	-	Complete log without filter functions available
-	Saving service files	 Available. No service file is generated upon a system crash Error number selectable for which a service file will be generated automatically 	-	Available. A service file is generated automatically upon a system crash

Function	TNC 620	iTNC 530
Find function:		
 List of words recently searched for 	 Not available 	Available
Show elements of active block	Not available	 Available
 Show list of all available NC blocks 	Not available	 Available
Starting the search function with the up/down arrow keys when highlighted	Works up to max. 50000 NC blocks, can be set via configu- ration datum	No limitation regarding program length
Programming graphics:		
 True-to-scale display of grid 	Available	 Not available
 Editing contour subprograms in SLII cycles with AUTO DRAW ON 	 With error messages, in the main program the cursor is positioned on the CYCL CALL NC block 	 With error messages, the cursor is positioned on the NC block in the contour subprogram that caused the error
 Moving the zoom window 	 Repeat function not available 	 Repeat function available
Programming minor axes:		
 Syntax FUNCTION PARAXCOMP: Define the behavior of the display and the paths of traverse 	Available	 Not available
 Syntax FUNCTION PARAXMODE: Define the assignment of the parallel axes to be traversed 	 Available 	Not available

Comparison: Differences in Test Run, functionality

Function	TNC 620	iTNC 530
Entering a program with the GOTO key	Function only possible if the START SINGLE soft key was not pressed	Function also possible after START SINGLE
Calculation of machining time	Each time the simulation is repeat- ed by pressing the START soft key, the machining time is totaled	Each time the simulation is repeat- ed by pressing the START soft key, time calculation starts at 0
Single block	With point pattern cycles and CYCL CALL PAT , the control stops after each point	Point pattern cycles and CYCL CALL PAT are handled by the control as a single NC block

Comparison: Differences in Test Run, operation

Function	TNC 620	iTNC 530
Zoom function	Each sectional plane can be select- ed by individual soft keys	Sectional plane can be selected via three toggle soft keys
Machine-specific miscellaneous functions M	Lead to error messages if they are not integrated in the PLC	Are ignored during Test Run
Displaying/editing the tool table	Function available via soft key	Function not available
Tool depiction	 Turquoise: Tool length Red: Length of cutting edge and tool is engaged Blue: Length of cutting edge and tool is not engaged 	 Red: Tool is engaged Green: Tool is not engaged
View options of 3-D view	Available	Function not available
Adjustable model quality	Available	Function not available

Comparison: Differences in programming station

Function	TNC 620	iTNC 530
Demo version	NC programs with more than 100 NC blocks cannot be selected; an error message is issued	NC programs can be selected, max. 100 NC blocks are displayed, further NC blocks are truncated in the display
Demo version	If nesting with PGM CALL results in more than 100 NC blocks, there is no test graphic display; an error message is not issued	Nested NC programs can be simulated
Demo version	You can transfer up to 10 elements from the CAD viewer to an NC program.	You can transfer up to 31 lines from the DXF converter to an NC program.
Copying NC programs	Copying to and from the directo- ry TNC:\ is possible with Windows Explorer	TNCremo or file manager of programming station must be used for copying
Shifting the horizontal soft-key row	Clicking the soft-key bar shifts one soft-key row to the right or left	Clicking any soft-key bar activates the respective soft-key row

Index

3	
3D compensation	456
Delta values	459
Face Milling	461
Peripheral Milling	463
Tool orientation	460
3-D compensation	
Normalized vector	458
Tool shapes	459

Α

About this manual	32
Actual position capture	95
Adding comments 192,	193
Additional axes	84
Additional axes for rotary axes.	443
ADP	471
Align tool axis	440
ASCII files	392

В

Batch Process Manager	502
application	502
creating a job list	508
editing a job list	509
fundamentals	502
job list	503
opening	505
Block	. 97
Delete	. 96
Inserting and modifying	. 97

С

CAD Import	475
CAD viewer	475
Basic settings	477
defining the plane	482
Filter for hole positions	492
preset setting	480
Selecting a contour	486
Setting layers	479
Calculating with parentheses	277
Calculator	199
Calling a program	
Calling any NC program	
CAM programming 456,	466
Cartesian coordinates	
Circular arc around circle cen	ter
CC	159
circular arc with specified	
radius	160
Circular arc with tangential	
transition	162
Straight line	155
Chamfer	156
Circle	168

Circle calculation Circle center Circular arc	
around circle center CC	159
with fixed radius	
with tangential transition	
Circular path	
Around pole	168
Cleaning	. 69
Comparison of functions	564
Compensation table	
Creating	
Туре	382
Component Monitoring 389,	
Context-sensitive help	215
Contour	
Approaching	
Departing	144
Selecting from DXF file	
Control panel	
Coordinate transformation	375
Copying program sections 99), 99
Counter	390

D

Data output to a server Datum shift Coordinate input Resetting Via the datum table Defining local Q parameters Defining nonvolatile Q parameter	
Create Delete	93 109 112 109 113 192
Information from NC program Downloading help files Dwell time cyclic once	302 219 403 405 404
E	

Error message	208
deleting	211
filtering	210
help with	208

F

FCL function Feature Content Level	
	. 39
Feed rate Input options	. 94
On rotary axes, M116	
Feed rate factor for plunging	443
movements M103	229
Feed rate in millimeters per spir	
revolution M136	230
File	230
Copying	109
create	109
Overwriting	110
protecting	116
Sorting	115
File functions	372
File management	572
Copying a table	111
External file types	104
File manager	104
Calling	106
Delete file	113
Directories	110
Сору	112
Create	109
Directory	103
	102
Function overview	105
Rename file	115
Selecting files	107
Files	107
Tagging	114
File status	106
Filter for hole positions when	100
applying CAD data	492
FK programming	173
Circular paths	178
Dialog initiation	176
End point	179
Fundamentals	173
Graphics	175
•	ions
Auxiliary points	182
Circle data	180
Closed contours	181
Direction and length of	
contour elements	179
Input opt	ions
Relative data	183
Straight lines	177
Working plane	174
Fluctuating spindle speed	401
FN14: ERROR – Displaying erro	
messages	285
FN 16: F-PRINT: formatted output	ut of
text	291

FN 18: SYSREAD:reading system data
synchronization
FN 23: CIRCLE DATA: Calculate a circle from 3 pointsFN 23 273
FN 24: KREISDATEN: Calculate a
circle from 4 pointsFN 24 273
FN26: TABOPEN: Open a freely definable table
definable table
FN28: TABREAD: Read from a
freely definable table 400, 400
FN 29: PLC: Transfer values to the PLC
FN 37: EXPORT 301
FN 38: SEND:Send information 302
Form view 398
Freely definable table
open
write to
FUNCTION COUNT
FUNCTION DWELL
FUNCTION FEED DWELL 403
Fundamentals

G

Gestures GOTO	
Graphics	
With programming	205
Magnification of details	207

Н

Hard disk	102
Heatmap	389
Helical interpolation	169
Helix	169
Help system	215
Help with error message	208

L

Import
Table from iTNC 530 400
Inclined-tool machining in a tilted
plane 441
iTNC 530
J
Jump conditions 275

Jump conditions	275
Jumping	
with GOTO	190
K	

Klartext.....

Μ

M91, M92 224
Message, outputting on screen 298
Message, printing 299
Miscellaneous functions 222
entering 222
For path behavior 227
For program run inspection. 223
For spindle and coolant 223
Miscellaneous functions for
coordinate entries 224
Modes of Operation 70
motion control 471
Multiple axis machining 410, 450

Ν

NC and PLC synchronization 3	300
NC block	97
NC error message 2	208
NC program	87
Editing	96
structuring 1	197
Nesting 2	252

)

Open contour corners M98	228
Option	36

Pallet table	496
Application	496
columns	496
editing	498
inserting a column	499
selecting and exiting	499
tool-oriented	500
Parallel axes	356
Paraxcomp	356
Paraxmode	356
Part families	267
Path	104
Path contours	154
Cartesian coordinates	154
Overview	154
Polar coordinates	166
Circular path with tangent	ial
connection	168
Overview	166
Straight line	167
Path functions	
Fundamentals	138
Circles and circular arcs	141
Pre-positioning	142
PLANE function 411,	413

Automatic tilting into position..... 431 Axis angle definition...... 428 Euler angle definition...... 420 Inclined-tool machining...... 441 Incremental definition...... 427 Overview...... 413 Point definition..... 425 positioning behavior...... 430 Projection angle definition.... 418 Resetting..... 415 selection of possible solutions..... 434 Spatial angle definition...... 416 Transformation type..... 437 Vector definition..... 422 PLC and NC synchronization.... 300 Circular path around pole CC..... 168 Programming...... 166 Positioning with tilted working plane.... 226, 449 Post processor...... 467 Preset Process chain..... 466 Processing DXF data Selecting machining positions....

490
Program 87
Opening a new program 91
structuring 197
Program defaults 353
Programm
Structure 87
Programming graphics 175
Programming Q parameters
Circle calculation 273
Programming tool movement 93
Program-section repeat 245
Pulsing spindle speed 401

Q

Q parameter
Export 301
programming 262
Transfer values to the PLC 301
Q-Parameter
Transferring values to the
PLC 300
Q parameter programming
If-then decision 274

HEIDENHAIN | TNC 620 | Klartext Programming User's Manual | 01/2021

93

Mathematical functions...... 268

Q-parameter programming	
Additional functions	284
Programming notes	265
Trigonometric functions	271
Q parameters 262,	263
checking	282
Formatted output	291
Local parameters Q	262
Local parameters QL	263
Preassigned	317
Programming	304
Residual parameters QR 2	262,
263	
String parameters QS	304

R

Radius compensation
Outside corners, inside corners
S14 Reading system data
Working plane
Resonance vibration
Reduce display M94
S
Saving service files 214 Screen
touchscreen

Selecting hole position Single selection	101
Selecting hole positions	491
icon	492
mouse area	491
Selecting positions from DXF	490
Selecting the unit of measure	. 91

Software option	36
SPEC FCT.	
Special functions	352
Spindle speed	
Entering	126
SQL statement	323
Straight line 155,	167
String parameter	
Converting	310
Copying a substring	308
Finding the length	312
Testing	311
String parameters	304
Assign	305
Chain-linking	306
Reading system data	309
Structuring NC programs	197
Subprogram	243
Superimposing handwheel	
positioning M118	234
Surface normal vector	
422, 442, 456 ,	458
System data	
list	526

Т

TABDATA		385
Table access		
SQL		323
TABDATA		385
TABWRITE		399
ТСРМ		450
Resetting		455
Teach In	95 ,	155
Text editor		195
Text file		392
Creating		291
Delete functions		393
Finding text sections		395
formatted output		291
Opening and exiting		392
Text variables		304
Tilt		
Working plane		411
Tilting		
Resetting		415
Working plane		413
Tilting axes		446
Tilting without rotary axes		440
Tilt working plane		
programmed		411
TNCguide		215
TOOL CALL		126
Tool change		129
Tool compensation		132
Length		132
Radius		133
Table		382

Three-dimensional	456
Tool data	122
Calling	126
Delta values	124
Entering into the program	125
Tool date	
Replacing	111
TOOL DEF	125
Tool length	122
Tool name	122
Tool number	122
Tool-oriented machining	500
Tool oversize	
Suppress error: M107	457
Tool radius	123
Touch gestures	515
Touch operating panel	513
Touch probe monitoring	237
Touchscreen	512
TRANS DATUM	376
Trigonometric functions	271
Trigonometry	271
T vector	458
V	

Vector..... 422

W
Workpiece positions
Write to log 302

HEIDENHAIN

DR. JOHANNES HEIDENHAIN GmbH Dr.-Johannes-Heidenhain-Straße 5

83301 Traunreut, Germany 2 +49 8669 31-0 FAX +49 8669 32-5061 E-mail: info@heidenhain.de

 Technical support
 FAX
 +49 8669 32-1000

 Measuring systems
 C
 +49 8669 31-3104
 E-mail: service.ms-support@heidenhain.de ஜ்⁺ +49 8669 31-3101 NC support E-mail: service.nc-support@heidenhain.de NC programming @ +49 8669 31-3103 E-mail: service.nc-pgm@heidenhain.de PLC programming 2 +49 8669 31-3102 E-mail: service.plc@heidenhain.de APP programming 🐵 +49 8669 31-3106 E-mail: service.app@heidenhain.de

www.heidenhain.de


Touch probes from HEIDENHAIN

help you reduce non-productive time and improve the dimensional accuracy of the finished workpieces.

Workpiece touch probes

TS 248, TS 260	Signal transmission by cable
TS 460	Radio or infrared transmission
TS 640, TS 740	Infrared transmission

- Workpiece alignment
- Preset setting
- Workpiece measurement



Tool touch probes

TT 160	Signal transmission by cable
TT 460	Infrared transmission

- Tool measurement
- Wear monitoring
- Tool breakage detection



www.klartext-portal.com

The Information Site for **HEIDENHAIN Controls**

Klartext App

The Klartext on Your Mobile Device

Apple Play Store

App Store



Google



###