

## TNC 640





User's Manual  
DIN/ISO Programming

NC Software  
340590-04  
340591-04  
340595-04



English (en)  
3/2014

## Controls of the TNC






### Keys on visual display unit

Key	Function
	Select split screen layout
	Toggle the display between machining and programming modes
	Soft keys for selecting functions on screen
	Shifting between soft-key rows



### Alphanumeric keyboard

Key	Function
	File names, comments
	DIN/ISO programming







### Machine operating modes

Key	Function
	Manual operation
	Electronic handwheel
	Positioning with manual data input
	Program run, single block
	Program run, full sequence



### Programming modes

Key	Function
	Programming
	Test run



### Program/file management, TNC functions

Key	Function
	Select or delete programs and files, external data transfer
	Define program call, select datum and point tables
	Select MOD functions
	Display help text for NC error messages, call TNCguide
	Display all current error messages
	Show calculator







### Navigation keys

Key	Function
	Move highlight
	Go directly to blocks, cycles and parameter functions



### Potentiometer for feed rate and spindle speed

Feed rate	Spindle speed
	










## Cycles, subprograms and program section repeats

Key	Function
	Define touch probe cycles
 	Define and call cycles
 	Enter and call labels for subprogramming and program section repeats
	Enter program stop in a program





## Tool functions

Key	Function
	Define tool data in the program
	Call tool data
















## Programming path movements

Key	Function
	Approach/depart contour
	FK free contour programming
	Straight line
	Circle center/pole for polar coordinates
	Circular arc with center
	Circle with radius
	Circular arc with tangential connection
 	Chamfer/Corner rounding

## Special functions

Key	Function
	Show special functions
	Select the next tab in forms
 	Up/down one dialog box or button

## Entering and editing coordinate axes and numbers

Key	Function
 ... 	Select coordinate axes or enter them in a program
 ... 	Numbers
 	Decimal point / Reverse algebraic sign
 	Polar coordinate input / Incremental values
	Q-parameter programming / Q-parameter status
	Save actual position or values from calculator
	Skip dialog questions, delete words
	Confirm entry and resume dialog
	Conclude block and exit entry
	Clear numerical entry or TNC error message
	Abort dialog, delete program section



**Fundamentals**

### About this manual

The symbols used in this manual are described below.



This symbol indicates that important information about the function described must be considered.



This symbol indicates that there is one or more of the following risks when using the described function:

- Danger to workpiece
- Danger to fixtures
- Danger to tool
- Danger to machine
- Danger to operator



This symbol indicates a possibly dangerous situation that may cause light injuries if not avoided.



This symbol indicates that the described function must be adapted by the machine tool builder. The function described may therefore vary depending on the machine.



This symbol indicates that you can find detailed information about a function in another manual.

### Would you like any changes, or have you found any errors?

We are continuously striving to improve our documentation for you. Please help us by sending your requests to the following e-mail address: [tnc-userdoc@heidenhain.de](mailto:tnc-userdoc@heidenhain.de).

## TNC model, software and features

This manual describes functions and features provided by TNCs as of the following NC software numbers.

<b>TNC model</b>	<b>NC software number</b>
TNC 640	340590-04
TNC 640 E	340591-04
TNC 640 Programming Station	340595-04

The suffix E indicates the export version of the TNC. The export version of the TNC has the following limitations:

- Simultaneous linear movement in up to 4 axes

The machine tool builder adapts the usable features of the TNC to his machine by setting machine parameters. Some of the functions described in this manual may therefore not be among the features provided by the TNC on your machine tool.

TNC functions that may not be available on your machine include:

- Tool measurement with the TT

Please contact your machine tool builder to become familiar with the features of your machine.

Many machine manufacturers, as well as HEIDENHAIN, offer programming courses for the TNCs. We recommend these courses as an effective way of improving your programming skill and sharing information and ideas with other TNC users.



### **User's Manual for Cycle Programming:**

All of the cycle functions (touch probe cycles and fixed cycles) are described in the Cycle Programming User's Manual. Please contact HEIDENHAIN if you require a copy of this User's Manual. ID: 892905-xx

# Fundamentals

## TNC model, software and features

### Software options

The TNC 640 features various software options that can be enabled by your machine tool builder. Each option is to be enabled separately and contains the following respective functions:

#### Software option 1 (option number 08)

- 
- |                               |   |   |
|-------------------------------|---|---|
| <b>Rotary table machining</b> | ■ | Programming of cylindrical contours as if in two axes |
|                               | ■ | Feed rate in distance per minute                      |
- 
- |                                  |   |                                |
|----------------------------------|---|--------------------------------|
| <b>Coordinate transformation</b> | ■ | Working plane, tilting the ... |
|----------------------------------|---|--------------------------------|
- 
- |                      |   |  |
|----------------------|---|--|
| <b>Interpolation</b> | ■ | Circle in 3 axes with tilted working plane (spacial arc) |
|----------------------|---|--|

#### Software option 2 (option number 09)

- 
- |                      |   |  |
|----------------------|---|--|
| <b>3-D machining</b> | ■ | Motion control with minimum jerk   |
|                      | ■ | 3-D tool compensation through surface normal vectors   |
|                      | ■ | Using the electronic handwheel to change the angle of the swivel head during program run without affecting the position of the tool point. (TCPM = <b>T</b> ool <b>C</b> enter <b>P</b> oint <b>M</b> anagement) |
|                      | ■ | Keeping the tool normal to the contour   |
|                      | ■ | Tool radius compensation perpendicular to traversing and tool direction  |
- 
- |                      |   |   |
|----------------------|---|---|
| <b>Interpolation</b> | ■ | Linear in 5 axes (subject to export permit) |
|----------------------|---|---|

#### HEIDENHAIN DNC (option number 18)

- 
- |  |   |  |
|--|---|--|
|  | ■ | Communication with external PC applications over COM component |
|--|---|--|

#### Display step (Option number 23)

- 
- |  |   |  |
|--|---|--|
| <b>Input resolution and display step</b> | ■ | Linear axes down to 0.01 $\mu\text{m}$ |
|  | ■ | Rotary axes to 0.00001°                |

#### Dynamic Collision Monitoring (DCM) software option (option number 40)

- 
- |  |   |  |
|--|---|--|
| <b>Collision monitoring in all machine operating modes</b> | ■ | The machine manufacturer defines objects to be monitored |
|  | ■ | Three warning levels in manual operation                 |
|  | ■ | Program interrupt during automatic operation             |
|  | ■ | Includes monitoring of 5-axis movements                  |



### DXF Converter software option (option number 42)

---

- Extracting contour programs and machining positions from DXF data.
- Extracting contour sections from plain-language programs.
- Supported DXF format: AC1009 (AutoCAD R12)
- For contours and point patterns
- Simple and convenient specification of reference points
- Select graphical features of contour sections from conversational programs

### Adaptive Feed Control (AFC) software option (option number 45)

---

- Function for adaptive feed-rate control for optimizing the machining conditions during series production
- Recording the actual spindle power by means of a teach-in cut
- Defining the limits of automatic feed rate control
- Fully automatic feed control during program run

### KinematicsOpt software option (option number 48)

---

- Touch-probe cycles for automatic testing and optimization of the machine kinematics
- Backup/restore active kinematics
- Test active kinematics
- Optimize active kinematics

### Mill-Turning software option (option number 50)

---

- Functions for milling/turning mode
- Switching between Milling/Turning mode of operation
- Constant cutting speed
- Tool-tip radius compensation
- Turning cycles

### Extended Tool Management software option (option number 93)

---

- Extended tool management, python-based

### Remote Desktop Manager software option (option number 133)

---

- Remote operation of external computer units (e.g. Windows PC) via the TNC user interface
- Windows on a separate computer unit
- Incorporated in the TNC interface

### Synchronizing Functions software option (option number 135)

---

- Real Time Coupling (RTC)
- Coupling of axes

## Fundamentals

### TNC model, software and features

---

#### Cross Talk Compensation (CTC) software option (option number 141)

- |                                       |   |  |
|---------------------------------------|---|--|
| <b>Compensation of axis couplings</b> | ■ | Determination of dynamically caused position deviation through axis acceleration |
|                                       | ■ | Compensation of the TCP  |

---

#### Position Adaptive Control (PAC) software option (option number 142)

- |                                    |   |   |
|------------------------------------|---|---|
| <b>Changing control parameters</b> | ■ | Changing of the control parameters depending on the position of the axes in the working space |
|                                    | ■ | Changing of the control parameters depending on the speed or acceleration of an axis          |

---

#### Load Adaptive Control (LAC) software option (option number 143)

- |   |   |   |
|---|---|---|
| <b>Dynamic changing of control parameters</b> | ■ | Automatic determination of workpiece weight and frictional forces   |
|   | ■ | Continuous adaptation of the parameters of the adaptive precontrolling to the actual weight of the workpiece during machining |

---

#### Active Chatter Control (ACC) software option (option number 145)

Fully automatic function for chatter control during machining

## Feature Content Level (upgrade functions)

Along with software options, significant further improvements of the TNC software are managed via the **Feature Content Level** upgrade functions. Functions subject to the FCL are not available simply by updating the software on your TNC.



All upgrade functions are available to you without surcharge when you receive a new machine.

Upgrade functions are identified in the manual with **FCL n**, where **n** indicates the sequential number of the feature content level.

You can purchase a code number in order to permanently enable the FCL functions. For more information, contact your machine tool builder or HEIDENHAIN.

## Intended place of operation

The TNC complies with the limits for a Class A device in accordance with the specifications in EN 55022, and is intended for use primarily in industrially-zoned areas.

## Legal information

This product uses open source software. Further information is available on the control under

- ▶ Programming and Editing operating mode
- ▶ MOD function
- ▶ **License Info** soft key

#### New functions

##### New Functions 34059x-02

DXF files can be opened directly on the TNC in order to extract contours and point patterns ("Programming: Data transfer from DXF files or plain-language contours", page 229).

The active tool-axis direction can now be activated in manual mode and during handwheel superimposition as a virtual tool axis ("Superimposing handwheel positioning during program run: M118", page 340).

The machine manufacturer can now define any areas on the machine for collision monitoring ("Dynamic Collision Monitoring (software option)", page 351).

Writing and reading data in freely definable tables ("Freely definable tables", page 377).

The Adaptive Feed Control (AFC) function has been integrated ("Adaptive Feed Control Software Option (AFC)", page 357)

New touch probe cycle 484 for calibrating the wireless TT 449 tool touch probe (see User's Manual for Cycles).

The new HR 520 and HR 550 FS handwheels are supported ("Traverse with electronic handwheels", page 458).

New machining cycle 225 ENGRAVING (see User's Manual for Cycle Programming)

New Active Chatter Control (ACC) software option ("Active Chatter Control (ACC; software option)", page 370).

New manual probing cycle "Center line as datum" ("Setting a center line as datum", page 503).

New function for rounding corners ("Rounding corners: M197", page 346).

External access to the TNC can now be blocked with a MOD function ("External access", page 553).

### **New Functions 34059x-02**

The maximum number of characters for the NAME and DOC fields in the tool table has been increased from 16 to 32 ("Enter tool data into the table", page 164).

The columns AFC and ACC were added to the tool table ("Enter tool data into the table", page 164).

Operation and position behavior of the manual probing cycles has been improved ("Using 3-D touch probes ", page 482).

Predefined values can now be entered into a cycle parameter with the PREDEF function in cycles (see User's Manual for Cycle Programming).

The status display has been expanded with the AFC tab ("Additional status displays", page 76).

The FUNCTION TURNDATA SPIN turning function has been expanded with an input option for maximum speed ("Program spindle speed", page 432).

A new optimization algorithm is now used with the KinematicsOpt cycles (see User's Manual for Cycle Programming).

With Cycle 257, circular stud milling, a parameter is now available with which you can determine the approach position on the stud (see User's Manual for Cycle Programming)

With Cycle 256, rectangular stud, a parameter is now available with which you can determine the approach position on the stud (see User's Manual for Cycle Programming).

With the "Basic Rotation" probing cycle, workpiece misalignment can now be compensated for via a table rotation ("Compensation of workpiece misalignment by rotating the table", page 496)

#### New functions 34059x-04

New special operating mode **Retraction** ("Retraction after a power interruption", page 540).

New graphic simulation ("Graphics ", page 522).

New MOD function "tool usage file" within the machine settings group ("Tool usage file", page 555).

New MOD function "set system time" within the systems settings group ("Set the system time", page 557).

New MOD group "graphic settings" ("Graphic settings", page 552).

With the new syntax for the adaptive feed control (AFC) you can start or end a teach-in step ("Recording a teach-in cut", page 362).

With the new cutting data calculator you can calculate the spindle speed and the feed rate ("Cutting data calculator", page 139).

In the TURNDATA function, you can now define the effect of the tool compensation ("Tool compensation in the program", page 434).

Now you can activate and deactivate the active chatter compensation (ACC) by soft key ("Activating/deactivating ACC", page 371).

New if/then decisions were introduced in the jump commands ("Programming if-then decisions", page 271).

The character set of the fixed cycle 225 Engraving was expanded by more characters and the diameter sign (see User's Manual for Cycle Programming).

New fixed cycle 275 trochoidal milling (see User's Manual for Cycle Programming)

New fixed cycle 233 ENGRAVING (see User's Manual for Cycle Programming)

In the drilling cycles 200, 203 and 205 the parameter Q395 BEZUG DEPTH REFERENCE was introduced in order to evaluate the T ANGLE (see User's Manual for Cycle Programming).

The probing cycle 4 MEASURING IN 3-D was introduced (see User's Manual for Cycle Programming).

### Changed functions 34059x-04

The turning tool table was expanded by the column NAME ("Tool data", page 435).

Now up to 4 functions are allowed in an NC block ("Fundamentals", page 328).

New soft keys for value transfer have been introduced in the pocket calculator ("Operation", page 136).

The distance-to-go display can now also be displayed in the input system ("Position Display Types", page 558).

Cycle 241 SINGLE-LIP DEEP HOLE DRILLING was expanded by several input parameters (see User's Manual for Cycle Programming).

Cycle 404 was expanded by the parameter Q305 NUMBER IN TABLE (see User's Manual for Cycle Programming).

In the thread milling cycles 26x an approaching feed rate was introduced (see User's Manual for Cycle Programming).

In Cycle 205 Universal Pecking you can now use parameter Q208 to define a feed rate for retraction (see User's Manual for Cycle Programming).





## Contents

1	First Steps with the TNC 640.....	49
2	Introduction.....	69
3	Programming: Fundamentals, file management.....	89
4	Programming: Programming aids.....	131
5	Programming: Tools.....	159
6	Programming: Programming contours.....	195
7	Programming: Data transfer from DXF files or plain-language contours.....	229
8	Programming: Subprograms and program section repeats.....	247
9	Programming: Q Parameters.....	263
10	Programming: Miscellaneous functions.....	327
11	Programming: Special functions.....	347
12	Programming: Multiple Axis Machining.....	383
13	Programming: Pallet editor.....	421
14	Programming: Turning Operations.....	427
15	Manual operation and setup.....	453
16	Positioning with Manual Data Input.....	515
17	Test run and program run.....	521
18	MOD functions.....	549
19	Tables and overviews.....	579



<b>1</b>	<b>First Steps with the TNC 640</b>	<b>49</b>
<b>1.1</b>	<b>Overview</b>	<b>50</b>
<b>1.2</b>	<b>Machine switch-on</b>	<b>50</b>
	Acknowledging the power interruption and moving to the reference points	50
<b>1.3</b>	<b>Programming the first part</b>	<b>51</b>
	Selecting the correct operating mode	51
	The most important TNC keys	51
	Creating a new program/file management	52
	Defining a workpiece blank	53
	Program layout	54
	Programming a simple contour	55
	Creating a cycle program	57
<b>1.4</b>	<b>Graphically testing the first part</b>	<b>59</b>
	Selecting the correct operating mode	59
	Selecting the tool table for the test run	59
	Choosing the program you want to test	60
	Selecting the screen layout and the view	60
	Starting the test run	61
<b>1.5</b>	<b>Setting up tools</b>	<b>62</b>
	Selecting the correct operating mode	62
	Preparing and measuring tools	62
	The tool table TOOL.T	63
	The pocket table TOOL_PTCH	64
<b>1.6</b>	<b>Workpiece setup</b>	<b>65</b>
	Selecting the correct operating mode	65
	Clamping the workpiece	65
	Datum setting with 3-D touch probe	66
<b>1.7</b>	<b>Running the first program</b>	<b>67</b>
	Selecting the correct operating mode	67
	Choosing the program you want to run	67
	Start the program	67

<b>2</b>	<b>Introduction.....</b>	<b>69</b>
<b>2.1</b>	<b>The TNC 640.....</b>	<b>70</b>
	Programming: HEIDENHAIN conversational and ISO formats.....	70
	Compatibility.....	70
<b>2.2</b>	<b>Visual display unit and operating panel.....</b>	<b>71</b>
	Display screen.....	71
	Setting the screen layout.....	71
	Control Panel.....	72
<b>2.3</b>	<b>Modes of Operation.....</b>	<b>73</b>
	Manual Operation and El. Handwheel.....	73
	Positioning with Manual Data Input.....	73
	Programming.....	73
	Test Run.....	74
	Program Run, Full Sequence and Program Run, Single Block.....	74
<b>2.4</b>	<b>Status displays.....</b>	<b>75</b>
	"General" status display.....	75
	Additional status displays.....	76
<b>2.5</b>	<b>Window Manager.....</b>	<b>83</b>
	Task bar.....	84
<b>2.6</b>	<b>SELinux security software.....</b>	<b>85</b>
<b>2.7</b>	<b>Accessories: HEIDENHAIN 3-D Touch Probes and Electronic Handwheels.....</b>	<b>86</b>
	3-D touch probes.....	86
	HR electronic handwheels.....	87

<b>3</b>	<b>Programming: Fundamentals, file management.....</b>	<b>89</b>
<b>3.1</b>	<b>Fundamentals.....</b>	<b>90</b>
	Position encoders and reference marks.....	90
	Reference system.....	90
	Reference system on milling machines.....	91
	Designation of the axes on milling machines.....	91
	Polar coordinates.....	92
	Absolute and incremental workpiece positions.....	93
	Selecting the datum.....	94
<b>3.2</b>	<b>Opening programs and entering.....</b>	<b>95</b>
	Organization of an NC program in DIN/ISO format.....	95
	Define the blank: G30/G31.....	96
	Opening a new part program.....	97
	Programming tool movements in DIN/ISO.....	99
	Actual position capture.....	100
	Editing a program.....	101
	The TNC search function.....	104
<b>3.3</b>	<b>File manager: Fundamentals.....</b>	<b>106</b>
	Files.....	106
	Displaying externally generated files on the TNC.....	108
	Data Backup.....	108

<b>3.4 Working with the file manager.....</b>	<b>109</b>
Directories.....	109
Paths.....	109
Overview: Functions of the file manager.....	110
Calling the file manager.....	111
Selecting drives, directories and files.....	112
Creating a new directory.....	113
Creating a new file.....	113
Copying a single file.....	113
Copying files into another directory.....	114
Copying a table.....	115
Copying a directory.....	115
Choosing one of the last files selected.....	116
Deleting a file.....	117
Deleting a directory.....	117
Tagging files.....	118
Renaming a file.....	119
Sorting files.....	119
Additional functions.....	120
Additional tools for management of external file types.....	121
Data transfer to/from an external data medium.....	126
The TNC in a network.....	128
USB devices on the TNC.....	129

<b>4</b>	<b>Programming: Programming aids.....</b>	<b>131</b>
<b>4.1</b>	<b>Adding comments.....</b>	<b>132</b>
	Application.....	132
	Entering comments during programming.....	132
	Inserting comments after program entry.....	132
	Entering a comment in a separate block.....	132
	Functions for editing of the comment.....	133
<b>4.2</b>	<b>Display of NC Programs.....</b>	<b>134</b>
	Syntax highlighting.....	134
	Scrollbar.....	134
<b>4.3</b>	<b>Structuring programs.....</b>	<b>135</b>
	Definition and applications.....	135
	Displaying the program structure window / Changing the active window.....	135
	Inserting a structuring block in the (left) program window.....	135
	Selecting blocks in the program structure window.....	135
<b>4.4</b>	<b>Calculator.....</b>	<b>136</b>
	Operation.....	136
<b>4.5</b>	<b>Cutting data calculator.....</b>	<b>139</b>
	Application.....	139
<b>4.6</b>	<b>Programming graphics.....</b>	<b>142</b>
	Generate/do not generate graphics during programming.....	142
	Generating a graphic for an existing program.....	142
	Block number display ON/OFF.....	143
	Erasing the graphic.....	143
	Showing grid lines.....	143
	Magnification or reduction of details.....	144

## **4.7 Error messages..... 145**

Display of errors.....	145
Open the error window.....	145
Closing the error window.....	145
Detailed error messages.....	146
INTERNAL INFO soft key.....	146
Clearing errors.....	147
Error log.....	147
Keystroke log.....	148
Informational texts.....	149
Saving service files.....	149
Calling the TNCguide help system.....	150

## **4.8 TNCguide context-sensitive help system..... 151**

Application.....	151
Working with the TNCguide.....	152
Downloading current help files.....	156



<b>5</b>	<b>Programming: Tools.....</b>	<b>159</b>
<b>5.1</b>	<b>Entering tool-related data.....</b>	<b>160</b>
	Feed rate F.....	160
	Spindle speed S.....	161
<b>5.2</b>	<b>Tool data.....</b>	<b>162</b>
	Requirements for tool compensation.....	162
	Tool number, tool name.....	162
	Tool length L.....	162
	Tool radius R.....	162
	Delta values for lengths and radii.....	163
	Entering tool data into the program.....	163
	Enter tool data into the table.....	164
	Importing tool tables.....	172
	Pocket table for tool changer.....	173
	Call tool data.....	176
	Tool change.....	178
	Tool usage test.....	181
	Tool management (software option).....	183
<b>5.3</b>	<b>Tool compensation.....</b>	<b>190</b>
	Introduction.....	190
	Tool length compensation.....	190
	Tool radius compensation.....	191

<b>6</b>	<b>Programming: Programming contours.....</b>	<b>195</b>
<b>6.1</b>	<b>Tool movements.....</b>	<b>196</b>
	Path functions.....	196
	Miscellaneous functions M.....	196
	Subprograms and program section repeats.....	196
	Programming with Q parameters.....	196
<b>6.2</b>	<b>Fundamentals of Path Functions.....</b>	<b>197</b>
	Programming tool movements for workpiece machining.....	197
<b>6.3</b>	<b>Approaching and departing a contour.....</b>	<b>200</b>
	Starting point and end point.....	200
	Tangential approach and departure.....	202
	Overview: Types of paths for contour approach and departure.....	203
	Important positions for approach and departure.....	204
	Approaching on a straight line with tangential connection: APPR LT.....	205
	Approaching on a straight line perpendicular to the first contour point: APPR LN.....	205
	Approaching on a circular path with tangential connection: APPR CT.....	206
	Approaching on a circular path with tangential connection from a straight line to the contour: APPR LCT.....	206
	Departing in a straight line with tangential connection: DEP LT.....	207
	Departing in a straight line perpendicular to the last contour point: DEP LN.....	207
	Departing on a circular path with tangential connection: DEP CT.....	207
	Departing on a circular arc tangentially connecting the contour and a straight line: DEP LCT.....	208
<b>6.4</b>	<b>Path contours - Cartesian coordinates.....</b>	<b>209</b>
	Overview of path functions.....	209
	Programming path functions.....	209
	Straight line in rapid traverse G00 Straight line with feed rate G01 F.....	210
	Inserting a chamfer between two straight lines.....	211
	Corner rounding G25.....	212
	Circle center I, J.....	213
	Circular path C around circle center CC.....	214
	CircleG02/G03/G05 with defined radius.....	215
	Circle G06 with tangential connection.....	217
	Example: Linear movements and chamfers with Cartesian coordinates.....	218
	Example: Circular movements with Cartesian coordinates.....	219
	Example: Full circle with Cartesian coordinates.....	220

**6.5 Path contours – Polar coordinates..... 221**

Overview..... 221

Zero point for polar coordinates: pole I, J..... 222

Straight line in rapid traverse G10 Straight line with feed rate G11 F..... 222

Circular path G12/G13/G15 around pole I, J..... 223

Circle G16 with tangential connection..... 223

Helix..... 224

Example: Linear movement with polar coordinates..... 226

Example: Helix..... 227

<b>7</b>	<b>Programming: Data transfer from DXF files or plain-language contours.....</b>	<b>229</b>
<b>7.1</b>	<b>Processing DXF Files (Software Option).....</b>	<b>230</b>
	Application.....	230
	Opening a DXF file.....	231
	Working with the DXF converter.....	231
	Basic settings.....	232
	Setting layers.....	234
	Defining the datum.....	235
	Selecting and saving a contour.....	237
	Selecting and saving machining positions.....	241

<b>8</b>	<b>Programming: Subprograms and program section repeats.....</b>	<b>247</b>
<b>8.1</b>	<b>Labeling Subprograms and Program Section Repeats.....</b>	<b>248</b>
	Label.....	248
<b>8.2</b>	<b>Subprograms.....</b>	<b>249</b>
	Operating sequence.....	249
	Programming notes.....	249
	Programming a subprogram.....	249
	Calling a subprogram.....	250
<b>8.3</b>	<b>Program-section repeats.....</b>	<b>251</b>
	Label G98.....	251
	Operating sequence.....	251
	Programming notes.....	251
	Programming a program section repeat.....	251
	Calling a program section repeat.....	252
<b>8.4</b>	<b>Any desired program as subprogram.....</b>	<b>253</b>
	Operating sequence.....	253
	Programming notes.....	253
	Calling any program as a subprogram.....	254
<b>8.5</b>	<b>Nesting.....</b>	<b>255</b>
	Types of nesting.....	255
	Nesting depth.....	255
	Subprogram within a subprogram.....	256
	Repeating program section repeats.....	257
	Repeating a subprogram.....	258
<b>8.6</b>	<b>Programming examples.....</b>	<b>259</b>
	Example: Milling a contour in several infeeds.....	259
	Example: Groups of holes.....	260
	Example: Group of holes with several tools.....	261

<b>9</b>	<b>Programming: Q Parameters.....</b>	<b>263</b>
<b>9.1</b>	<b>Principle and overview of functions.....</b>	<b>264</b>
	Programming notes.....	265
	Calling Q parameter functions.....	266
<b>9.2</b>	<b>Part families—Q parameters in place of numerical values.....</b>	<b>267</b>
	Application.....	267
<b>9.3</b>	<b>Describing contours with mathematical functions.....</b>	<b>268</b>
	Application.....	268
	Overview.....	268
	Programming fundamental operations.....	269
<b>9.4</b>	<b>Angle functions (trigonometry).....</b>	<b>270</b>
	Definitions.....	270
	Programming trigonometric functions.....	270
<b>9.5</b>	<b>If-then decisions with Q parameters.....</b>	<b>271</b>
	Application.....	271
	Unconditional jumps.....	271
	Programming if-then decisions.....	271
<b>9.6</b>	<b>Checking and changing Q parameters.....</b>	<b>272</b>
	Procedure.....	272
<b>9.7</b>	<b>Additional functions.....</b>	<b>274</b>
	Overview.....	274
	D14: Displaying error messages.....	275
	D18: Reading system data.....	279
	D19: Transfer values to PLC.....	288
	D20: NC and PLC synchronization.....	288
	D29: Transfer values to the PLC.....	290
	D37 EXPORT.....	290

**9.8 Accessing tables with SQL commands..... 291**

Introduction..... 291  
A transaction..... 292  
Programming SQL commands..... 294  
Overview of the soft keys..... 294  
SQL BIND..... 295  
SQL SELECT..... 296  
SQL FETCH..... 298  
SQL UPDATE..... 299  
SQL INSERT..... 299  
SQL COMMIT..... 300  
SQL ROLLBACK..... 300

**9.9 Entering formulas directly..... 301**

Entering formulas..... 301  
Rules for formulas..... 303  
Programming example..... 304

**9.10 String parameters..... 305**

String processing functions..... 305  
Assigning string parameters..... 306  
Chain-linking string parameters..... 306  
Converting a numerical value to a string parameter..... 307  
Copying a substring from a string parameter..... 308  
Converting a string parameter to a numerical value..... 309  
Checking a string parameter..... 310  
Finding the length of a string parameter..... 311  
Comparing alphabetic sequence..... 312  
Reading machine parameters..... 313

## **9.11 Preassigned Q parameters..... 316**

Values from the PLC: Q100 to Q107.....	316
Active tool radius: Q108.....	316
Tool axis: Q109.....	316
Spindle status: Q110.....	317
Coolant on/off: Q111.....	317
Overlap factor: Q112.....	317
Unit of measurement for dimensions in the program: Q113.....	317
Tool length: Q114.....	317
Coordinates after probing during program run.....	318
Deviation between actual value and nominal value during automatic tool measurement with the TT 130.....	318
Tilting the working plane with mathematical angles: rotary axis coordinates calculated by the TNC.....	318
Measurement results from touch probe cycles (see also User's Manual for Cycle Programming).....	319

## **9.12 Programming examples..... 321**

Example: Ellipse.....	321
Example: Concave cylinder machined with spherical cutter.....	323
Example: Convex sphere machined with end mill.....	325



<b>10 Programming: Miscellaneous functions.....</b>	<b>327</b>
<b>10.1 Entering miscellaneous functions M and STOP.....</b>	<b>328</b>
Fundamentals.....	328
<b>10.2 M functions for program run inspection, spindle and coolant.....</b>	<b>329</b>
Overview.....	329
<b>10.3 Miscellaneous functions for coordinate data.....</b>	<b>330</b>
Programming machine-referenced coordinates: M91/M92.....	330
Moving to positions in a non-tilted coordinate system with a tilted working plane: M130.....	332
<b>10.4 Miscellaneous functions for path behavior.....</b>	<b>333</b>
Machining small contour steps: M97.....	333
Machining open contour corners: M98.....	334
Feed rate factor for plunging movements: M103.....	335
Feed rate in millimeters per spindle revolution: M136.....	336
Feed rate for circular arcs: M109/M110/M111.....	337
Calculating the radius-compensated path in advance (LOOK AHEAD): M120.....	338
Superimposing handwheel positioning during program run: M118.....	340
Retraction from the contour in the tool-axis direction: M140.....	342
Suppressing touch probe monitoring: M141.....	343
Deleting basic rotation: M143.....	344
Automatically retract tool from the contour at an NC stop: M148.....	345
Rounding corners: M197.....	346

<b>11 Programming: Special functions.....</b>	<b>347</b>
<b>11.1 Overview of special functions.....</b>	<b>348</b>
Main menu for SPEC FCT special functions.....	348
Program defaults menu.....	349
Functions for contour and point machining menu.....	349
Menu of various DIN/ISO functions.....	350
<b>11.2 Dynamic Collision Monitoring (software option).....</b>	<b>351</b>
Function.....	351
Collision monitoring in the manual operating modes.....	353
Collision monitoring in Automatic operation.....	355
Graphic depiction of the protected space.....	356
<b>11.3 Adaptive Feed Control Software Option (AFC).....</b>	<b>357</b>
Application.....	357
Defining the AFC basic settings.....	359
Recording a teach-in cut.....	362
Activating/deactivating AFC.....	365
Log file.....	367
Tool breakage/tool wear monitoring.....	368
Spindle load monitoring.....	369
<b>11.4 Active Chatter Control (ACC; software option).....</b>	<b>370</b>
Application.....	370
Activating/deactivating ACC.....	371
<b>11.5 Defining DIN/ISO Functions.....</b>	<b>372</b>
Overview.....	372
<b>11.6 Creating Text Files.....</b>	<b>373</b>
Application.....	373
Opening and exiting text files.....	373
Editing texts.....	374
Deleting and re-inserting characters, words and lines.....	374
Editing text blocks.....	375
Finding text sections.....	376

<b>11.7 Freely definable tables.....</b>	<b>377</b>
Fundamentals.....	377
Creating a freely definable table.....	377
Editing the table format.....	377
Switching between table and form view.....	379
D26: TAPOPEN: Open a freely definable table.....	380
D27: TAPWRITE: Write to a freely definable table.....	381
D28: TAPREAD: Read from a freely definable table.....	382

<b>12 Programming: Multiple Axis Machining.....</b>	<b>383</b>
<b>12.1 Functions for multiple axis machining.....</b>	<b>384</b>
<b>12.2 The PLANE Function: Tilting the Working Plane (Software Option 1).....</b>	<b>385</b>
Introduction.....	385
Defining the PLANE function.....	387
Position display.....	387
Resetting the PLANE function.....	388
Defining the working plane with the spatial angle: PLANE SPATIAL.....	389
Defining the working plane with the projection angle: PLANE PROJECTED.....	391
Defining the working plane with the Euler angle: PLANE EULER.....	392
Defining the working plane with two vectors: PLANE VECTOR.....	394
Defining the working plane via three points: PLANE POINTS.....	396
Defining the working plane via a single incremental spatial angle: PLANE SPATIAL.....	398
Tilting the working plane through axis angle: PLANE AXIAL (FCL 3 function).....	399
Specifying the positioning behavior of the PLANE function.....	401
<b>12.3 Inclined-tool machining in a tilted machining plane (software option 2).....</b>	<b>406</b>
Function.....	406
Inclined-tool machining via incremental traverse of a rotary axis.....	406
<b>12.4 Miscellaneous functions for rotary axes.....</b>	<b>407</b>
Feed rate in mm/min on rotary axes A, B, C: M116 (software option 1).....	407
Shortest-path traverse of rotary axes: M126.....	408
Reducing display of a rotary axis to a value less than 360°: M94.....	409
Maintaining the position of the tool tip when positioning with tilted axes (TCPM): M128 (software option 2).....	410
Selecting tilting axes: M138.....	413
Compensating the machine's kinematics configuration for ACTUAL/NOMINAL positions at end of block: M144 (software option 2).....	414
<b>12.5 FUNCTION TCPM (software option 2).....</b>	<b>415</b>
Function.....	415
Defining the TCPM FUNCTION.....	415
Mode of action of the programmed feed rate.....	416
Interpretation of the programmed rotary axis coordinates.....	416
Type of interpolation between the starting and end position.....	418
Resetting the TCPM FUNCTION.....	419

<b>12.6 Peripheral Milling: 3-D radius compensation with TCPM and radius compensation (G41/ G42)</b> .....	<b>420</b>
Application.....	420

<b>13 Programming: Pallet editor.....</b>	<b>421</b>
<b>13.1 Pallet Management.....</b>	<b>422</b>
Application.....	422
Select pallet table.....	424
Exiting the pallet file.....	424
Run pallet file.....	424

<b>14 Programming: Turning Operations.....</b>	<b>427</b>
<b>14.1 Turning Operations on Milling Machines (Software Option 50).....</b>	<b>428</b>
Introduction.....	428
<b>14.2 Basis Functions (Software Option 50).....</b>	<b>429</b>
Switching between milling/turning mode of operation.....	429
Graphical display of turning operations.....	431
Program spindle speed.....	432
Feed rate.....	433
Tool call.....	433
Tool compensation in the program.....	434
Tool data.....	435
Tool tip radius compensation TRC.....	440
Recessing and undercutting.....	441
Inclined turning.....	447
<b>14.3 Unbalance Functions.....</b>	<b>449</b>
Unbalance while turning.....	449
Measure Unbalance cycle.....	451

<b>15 Manual operation and setup.....</b>	<b>453</b>
<b>15.1 Switch-on, switch-off.....</b>	<b>454</b>
Switch-on.....	454
Switch-off.....	456
<b>15.2 Moving the machine axes.....</b>	<b>457</b>
Note.....	457
Moving the axis with the machine axis direction buttons.....	457
Incremental jog positioning.....	457
Traverse with electronic handwheels.....	458
<b>15.3 Spindle speed S, feed rate F and miscellaneous function M.....</b>	<b>468</b>
Application.....	468
Entering values.....	468
Adjusting spindle speed and feed rate.....	469
Activating feed-rate limitation.....	469
<b>15.4 Functional safety FS (option).....</b>	<b>470</b>
Miscellaneous.....	470
Explanation of terms.....	471
Checking the axis positions.....	472
Activating feed-rate limitation.....	473
Additional status displays.....	474
<b>15.5 Datum setting without a 3-D touch probe.....</b>	<b>475</b>
Note.....	475
Preparation.....	475
Workpiece presetting with axis keys.....	475
Datum management with the preset table.....	476
<b>15.6 Using 3-D touch probes.....</b>	<b>482</b>
Overview.....	482
Functions in touch probe cycles.....	484
Selecting touch probe cycles.....	486
Recording measured values from the touch-probe cycles.....	487
Writing measured values from the touch probe cycles in a datum table.....	488
Writing measured values from the touch probe cycles in the preset table.....	489



**15.7 Calibrating a 3-D touch trigger probe.....490**

Introduction..... 490  
Calibrating the effective length..... 491  
Calibrating the effective radius and compensating center misalignment..... 492  
Displaying calibration values..... 494

**15.8 Compensating workpiece misalignment with 3-D touch probe..... 495**

Introduction..... 495  
Identifying basic rotation.....496  
Saving a basic rotation in the preset table..... 496  
Compensation of workpiece misalignment by rotating the table..... 496  
Displaying a basic rotation..... 497  
Canceling a basic rotation.....497

**15.9 Datum Setting with 3-D Touch Probe.....498**

Overview..... 498  
Datum setting in any axis..... 498  
Corner as datum..... 499  
Circle center as datum.....501  
Setting a center line as datum..... 503  
Measuring workpieces with a 3-D touch probe..... 504  
Using touch probe functions with mechanical probes or measuring dials.....507

**15.10 Tilting the working plane (software option 1)..... 508**

Application, function..... 508  
Traversing reference points in tilted axes..... 510  
Position display in a tilted system..... 510  
Limitations on working with the tilting function..... 510  
To activate manual tilting:..... 511  
Setting the current tool-axis direction as the active machining direction.....512  
Setting the datum in a tilted coordinate system..... 513

<b>16 Positioning with Manual Data Input.....</b>	<b>515</b>
<b>16.1 Programming and executing simple machining operations.....</b>	<b>516</b>
Positioning with manual data input (MDI).....	516
Protecting and erasing programs in \$MDI.....	519

<b>17 Test run and program run.....</b>	<b>521</b>
<b>17.1 Graphics.....</b>	<b>522</b>
Application.....	522
Speed of the Setting test runs.....	523
Overview: Display modes.....	524
Plan view.....	525
Projection in three planes.....	525
3-D view.....	526
Repeating graphic simulation.....	529
Tool display.....	529
Measurement of machining time.....	530
<b>17.2 Showing the workpiece blank in the working space.....</b>	<b>531</b>
Application.....	531
<b>17.3 Functions for program display.....</b>	<b>532</b>
Overview.....	532
<b>17.4 Test Run.....</b>	<b>533</b>
Application.....	533
<b>17.5 Program run.....</b>	<b>535</b>
Application.....	535
Running a part program.....	536
Interrupt machining.....	537
Moving the machine axes during an interruption.....	538
Resuming program run after an interruption.....	538
Retraction after a power interruption.....	540
Any entry into program (mid-program startup).....	543
Returning to the contour.....	545
<b>17.6 Automatic program start.....</b>	<b>546</b>
Application.....	546
<b>17.7 Optional block skip.....</b>	<b>547</b>
Application.....	547
Inserting the "/" character.....	547
Erasing the "/" character.....	547

<b>17.8 Optional program-run interruption.....</b>	<b>548</b>
Application.....	548

<b>18 MOD functions.....</b>	<b>549</b>
<b>18.1 MOD function.....</b>	<b>550</b>
Selecting MOD functions.....	550
Changing the settings.....	550
Exiting MOD functions.....	550
Overview of MOD functions.....	551
<b>18.2 Graphic settings.....</b>	<b>552</b>
<b>18.3 Machine settings.....</b>	<b>553</b>
External access.....	553
Tool usage file.....	555
Select kinematics.....	556
<b>18.4 System settings.....</b>	<b>557</b>
Set the system time.....	557
<b>18.5 Position Display Types.....</b>	<b>558</b>
Application.....	558
<b>18.6 Unit of Measurement.....</b>	<b>559</b>
Application.....	559
<b>18.7 Displaying operating times.....</b>	<b>559</b>
Application.....	559
<b>18.8 Software numbers.....</b>	<b>560</b>
Application.....	560
<b>18.9 Entering the code number.....</b>	<b>560</b>
Application.....	560

<b>18.10 Setting up data interfaces.....</b>	<b>561</b>
Serial interfaces on the TNC 640.....	561
Application.....	561
Setting the RS-232 interface.....	561
Setting the BAUD RATE (baudRate).....	561
Setting the protocol (protocol).....	562
Setting data bits (dataBits).....	562
Check parity (parity).....	562
Setting the stop bits (stopBits).....	562
Setting handshaking (flowControl).....	563
File system for file operations (fileSystem).....	563
Settings for data transfer with the TNCserver PC software.....	563
Setting the operating mode of the external device (fileSystem).....	564
Data transfer software.....	565
<b>18.11 Ethernet interface.....</b>	<b>567</b>
Introduction.....	567
Connection options.....	567
Configuring the TNC.....	567
<b>18.12 Firewall.....</b>	<b>573</b>
Application.....	573
<b>18.13 Configure HR 550 FS wireless handwheel.....</b>	<b>576</b>
Application.....	576
Assigning the handwheel to a specific handwheel holder.....	576
Setting the transmission channel.....	577
Selecting the transmitter power.....	577
Statistical data.....	578
<b>18.14 Load machine configuration.....</b>	<b>578</b>
Application.....	578

<b>19 Tables and overviews.....</b>	<b>579</b>
<b>19.1 Machine-specific user parameters.....</b>	<b>580</b>
Application.....	580
<b>19.2 Connector pin layout and connection cables for data interfaces.....</b>	<b>590</b>
RS-232-C/V.24 interface for HEIDENHAIN devices.....	590
Non-HEIDENHAIN devices.....	592
Ethernet interface RJ45 socket.....	593
<b>19.3 Technical Information.....</b>	<b>594</b>
<b>19.4 Overview tables.....</b>	<b>602</b>
Fixed cycles.....	602
Miscellaneous functions.....	603
<b>19.5 Functions of the TNC 640 and the iTNC 530 compared.....</b>	<b>605</b>
Comparison: Specifications.....	605
Comparison: Data interfaces.....	605
Comparison: Accessories.....	606
Comparison: PC software.....	606
Comparison: Machine-specific functions.....	607
Comparison: User functions.....	607
Comparator: Cycles.....	614
Comparison: Miscellaneous functions.....	617
Comparison: Touch probe cycles in the Manual Operation and El. Handwheel modes.....	618
Comparison: Touch probe cycles for automatic workpiece inspection.....	620
Comparison: Differences in programming.....	621
Comparison: Differences in Test Run, functionality.....	626
Comparison: Differences in Test Run, operation.....	626
Comparison: Differences in Manual Operation, functionality.....	626
Comparison: Differences in Manual Operation, operation.....	628
Comparison: Differences in Program Run, operation.....	628
Comparison: Differences in Program Run, traverse movements.....	629
Comparison: Differences in MDI operation.....	633
Comparison: Differences in programming station.....	634
<b>19.6 DIN/ISO function overview.....</b>	<b>635</b>
DIN/ISO Function Overview TNC 640.....	635





# 1

**First Steps with  
the TNC 640**

## 1.1 Overview

### 1.1 Overview

This chapter is intended to help TNC beginners quickly learn to handle the most important procedures. For more information on a respective topic, see the section referred to in the text.

The following topics are included in this chapter:

- Machine switch-on
- Programming the first part
- Graphically testing the first part
- Setting up tools
- Workpiece setup
- Running the first program

### 1.2 Machine switch-on

#### Acknowledging the power interruption and moving to the reference points



Switch-on and crossing over the reference points can vary depending on the machine tool. Refer to your machine manual.

- ▶ Switch on the power supply for TNC and machine: The TNC starts the operating system. This process may take several minutes. Then the TNC will display the "Power interrupted" message in the screen header.



- ▶ Press the CE key: The TNC compiles the PLC program.



- ▶ Switch on the machine control voltage: The TNC checks operation of the emergency stop circuit and goes into the reference run mode




- ▶ Cross the reference points manually in the displayed sequence: For each external axis, press the **START** key. If you have absolute linear and angle encoders on your machine there is no need for a reference run

The TNC is now ready for operation in the **Manual Operation** mode.

#### Further information on this topic

- Traversing the reference marks: See "Switch-on", page 454
- Operating modes: See "Programming", page 73



## 1.3 Programming the first part

### Selecting the correct operating mode

You can write programs only in Programming mode:








- ▶ Press the operating mode key: The TNC goes into the **Programming** operating mode

#### Further information on this topic

- Operating modes: See "Programming", page 73

### The most important TNC keys

Functions for conversational guidance	Key
Confirm entry and activate the next dialog prompt	
Ignore the dialog question	
End the dialog immediately	
Abort dialog, discard entries	
Soft keys on the screen with which you select functions appropriate to the active state	

#### Further information on this topic

- Writing and editing programs: See "Editing a program", page 101
- Overview of keys: See "Controls of the TNC", page 2


# First Steps with the TNC 640

## 1.3 Programming the first part

### Creating a new program/file management

PGM  
MGT

- ▶ Press the PGM MGT key: The TNC opens the file management. The file management of the TNC is arranged much like the file management on a PC with the Windows Explorer. The file management enables you to manipulate data on the TNC hard disk
- ▶ Use the arrow keys to select the folder in which you want to open the new file
- ▶ Enter any desired file name with the extension **.I**: The TNC then automatically opens a program and asks for the unit of measure for the new program
- ▶ Selecting the unit of measure: Press the MM or INCH soft key



The TNC automatically generates the first and last blocks of the program. Afterwards you can no longer change these blocks.

### Further information on this topic


- File management: See "Working with the file manager", page 109
- Creating a new program: See "Opening programs and entering", page 95

## Defining a workpiece blank

After you have created a new program you can define a workpiece blank. For example, define a cuboid by entering the MIN and MAX points, each with reference to the selected reference point.

After you have selected the desired blank form via soft key, the TNC automatically initiates the workpiece blank definition and asks for the required data:

- ▶ **Spindle axis Z - Plane XY:** Enter the active spindle axis. G17 is saved as default setting. Accept with the **ENT** key
- ▶ **Workpiece blank def.: minimum X:** Smallest X coordinate of the workpiece blank with respect to the reference point, e.g. 0. Confirm with the **ENT** key
- ▶ **Workpiece blank def.: minimum Y:** Smallest Y coordinate of the workpiece blank with respect to the reference point, e.g. 0. Confirm with the **ENT** key
- ▶ **Workpiece blank def.: minimum Z:** Smallest Z coordinate of the workpiece blank with respect to the reference point, e.g. -40. Confirm with the **ENT** key
- ▶ **Workpiece blank def.: maximum X:** Largest X coordinate of the workpiece blank with respect to the reference point, e.g. 100. Confirm with the **ENT** key
- ▶ **Workpiece blank def.: maximum Y:** Largest Y coordinate of the workpiece blank with respect to the reference point, e.g. 100. Confirm with the **ENT** key
- ▶ **Workpiece blank def.: maximum Z:** Largest Z coordinate of the workpiece blank with respect to the reference point, e.g. 0. Confirm with the **ENT** key. The TNC concludes the dialog



### Example NC blocks

```
%NEW G71 *
N10 G30 G17 X+0 Y+0 Z-40 *
N20 G31 X+100 Y+100 Z+0 *
N99999999 %NEW G71 *
```

### Further information on this topic

- Define the blank: page 97

## First Steps with the TNC 640

### 1.3 Programming the first part

#### Program layout

NC programs should be arranged consistently in a similar manner. This makes it easier to find your place, accelerates programming and reduces errors.

#### Recommended program layout for simple, conventional contour machining

- 1 Call tool, define tool axis
- 2 Retract the tool
- 3 Pre-position the tool in the working plane near the contour starting point
- 4 In the tool axis, position the tool above the workpiece, or preposition immediately to workpiece depth. If required, switch on the spindle/coolant
- 5 Contour approach
- 6 Contour machining
- 7 Contour departure
- 8 Retract the tool, end program

#### Further information on this topic

- Contour programming: See "Tool movements in the program"

#### Recommended program layout for simple cycle programs

- 1 Call tool, define tool axis
- 2 Retract the tool
- 3 Define the fixed cycle
- 4 Move to the machining position
- 5 Call the cycle, switch on the spindle/coolant
- 6 Retract the tool, end program

#### Further information on this topic

- Cycle programming: See User's Manual for Cycles

#### Layout of contour machining programs

```
%BSPCONT G71 *
N10 G30 G71 X... Y... Z... *
N20 G31 X... Y... Z... *
N30 T5 G17 S5000 *
N40 G00 G40 G90 Z+250 *
N50 X... Y... *
N60 G01 Z+10 F3000 M13 *
N70 X... Y... RL F500 *
...
N160 G40 ... X... Y... F3000 M9 *
N170 G00 Z+250 M2 *
N99999999 BSPCONT G71 *
```


#### Cycle program layout

```
%BSBCYC G71 *
N10 G30 G71 X... Y... Z... *
N20 G31 X... Y... Z... *
N30 T5 G17 S5000 *
N40 G00 G40 G90 Z+250 *
N50 G200... *
N60 X... Y... *
N70 G79 M13 *
N80 G00 Z+250 M2 *
N99999999 BSBCYC G71 *
```

## Programming a simple contour









The contour shown to the right is to be milled once to a depth of 5 mm. You have already defined the workpiece blank. After you have initiated a dialog through a function key, enter all the data requested by the TNC in the screen header.

- TOOL CALL
  - ▶ Call the tool: Enter the tool data. Confirm each of your entries with the **ENT** key. Do not forget the tool axis
  
- L
  - ▶ Press the **L** key to open a program block for a linear movement
  
- ←
  - ▶ Press the left arrow key to switch to the input range for G codes
  
- G00
  - ▶ Press the **G0** soft key if you want to enter a rapid traverse motion
  
- L
  - ▶ Retract the tool: Press the orange axis key **Z** in order to get clear in the tool axis, and enter the value for the position to be approached, e.g. 250. Press the **ENT** key
  - ▶ **Radius comp.: RL/RR/no comp.?** confirm with the **ENT** key: Activate no radius compensation
  - ▶ Confirm **Miscellaneous function F=?** with the **END** key: The TNC stores the entered positioning block
  
- L
  - ▶ Press the **L** key to open a program block for a linear movement
  
- ←
  - ▶ Press the left arrow key to switch to the input range for G codes
  
- G00
  - ▶ Press the **G0** soft key if you want to enter a rapid traverse motion
  - ▶ Pre-position the tool in the working plane: Press the orange axis key **X** and enter the value for the position to be approached, e.g. -20.
  - ▶ Press the orange axis key **Y** and enter the value for the position to be approached, e.g. -20. Confirm your entry with the **ENT** key.
  - ▶ **Radius comp.: RL/RR/no comp.?** confirm with the **ENT** key: Activate no radius compensation
  - ▶ Confirm **Miscellaneous function F=?** with the **END** key: The TNC stores the entered positioning block
  
- L
  - ▶ Move tool to depth: Press the orange axis key and enter the value for the position to be approached, e.g. -5. Press the **ENT** key
  - ▶ **Radius comp.: RL/RR/no comp.?** confirm with the **ENT** key: Activate no radius compensation
  - ▶ **Feed rate F=?** Enter the positioning feed rate, e.g. 3000 mm/min and confirm with the **ENT** key
  - ▶ **Miscellaneous function M?** Switch on the spindle and coolant, e.g. **M13** and confirm with the **END** key: The TNC stores the entered positioning block
  
- G
  - ▶ Enter **26** to move to the contour: Define the **rounding radius** of the approaching arc



## First Steps with the TNC 640

### 1.3 Programming the first part

- 
  - ▶ Machine the contour and move to the contour point **2**: You only need to enter the information that changes. In other words, enter only the Y coordinate 95 and save your entry with the **END** key
- 
  - ▶ Approach contour point **3**: Enter the X coordinate 95 and save your entry with the **END** key
- 
  - ▶ Define the chamfer at the contour point **3**: Enter the chamfer width 10 mm and confirm with the **END** key
- 
  - ▶ Approach contour point **4**: Enter the Y coordinate 5 and save your entry with the **END** key
- 
  - ▶ Define the chamfer at the contour point **4**: Enter the chamfer width 20 mm and confirm with the **END** key
- 
  - ▶ Approach contour point **1**: Enter the X coordinate 5 and save your entry with the **END** key
- 
  - ▶ Enter **27** to depart from the contour: Define the **rounding radius** of the departing arc
- 
  - ▶ Enter **0**. To retract the tool, select : Press the orange axis key **Z** in order to get clear in the tool axis, and enter the value for the position to be approached, e.g. 250. Press the **ENT** key
  - ▶ **Radius comp.: RL/RR/no comp.?** confirm with the **ENT** key: Activate no radius compensation
  - ▶ **MISCELLANEOUS FUNCTION M?** Enter **M2** to enter end of program, then confirm with the **END** key. The TNC saves the entered positioning block

#### Further information on this topic



- **Complete example with NC blocks:** See "Example: Linear movements and chamfers with Cartesian coordinates", page 218
- Creating a new program: See "Opening programs and entering", page 95
- Approaching/departing contours: See "Approaching and departing a contour"
- Programming contours: See "Overview of path functions", page 209
- Tool radius compensation: See "Tool radius compensation ", page 191
- Miscellaneous functions (M): See "M functions for program run inspection, spindle and coolant ", page 329



## Creating a cycle program

The holes (depth of 20 mm) shown in the figure at right are to be drilled with a standard drilling cycle. You have already defined the workpiece blank.

- TOOL CALL
  - ▶ Call the tool: Enter the tool data. Confirm each of your entries with the **ENT** key. **Do not forget the tool axis**
- L
  - ▶ Press the **L** key to open a program block for a linear movement
- ←
  - ▶ Press the left arrow key to switch to the input range for G codes
- G00
  - ▶ Press the **G0** soft key if you want to enter a rapid traverse motion
  - ▶ Retract the tool: Press the orange **Z** axis key in order to get clear in the tool axis, and enter the value for the position to be approached, e.g. 250. Press the **ENT** key
  - ▶ **Radius comp.:** Confirm **RL/RR/no comp?** with the ENT key: Activate no radius compensation
  - ▶ Confirm **Miscellaneous function F=?** with the **END** key: The TNC stores the entered positioning block
  - ▶ Call the cycle menu
- CYCL DEF
  - ▶ Display the drilling cycles
- DRILLING/  
THREAD
  - ▶ Select standard drilling cycle 200: The TNC starts the dialog for cycle definition. Enter all parameters requested by the TNC step by step and conclude each entry with the **ENT** key. In the screen to the right, the TNC also displays a graphic showing the respective cycle parameter
- 200
  - ▶ Select standard drilling cycle 200: The TNC starts the dialog for cycle definition. Enter all parameters requested by the TNC step by step and conclude each entry with the **ENT** key. In the screen to the right, the TNC also displays a graphic showing the respective cycle parameter
- G
  - ▶ Enter **0** to move to the first drilling position: Enter the **coordinates** of the drilling position, switch-on the coolant and spindle, and call the cycle via **M99**
- X
  - ▶ Enter **0** to move to a further drilling position: Enter the **coordinates** of the respective drilling positions, and call the cycle with **M99**
- G
  - ▶ Enter **0**. To retract the tool, select : Press the orange axis key **Z** in order to get clear in the tool axis, and enter the value for the position to be approached, e.g. 250. Press the **ENT** key
  - ▶ **Radius comp.:** Confirm **RL/RR/No comp.?** with the **ENT** key: Activate no radius compensation
  - ▶ **Miscellaneous function M?** Enter **M2** to enter end of program, then confirm with the **END** key. The TNC stores the entered positioning block



### Example NC blocks

```
%C200 G71 *
```

```
N10 G30 G17 X+0 Y+0 Z-40 *
```

Definition of workpiece blank

## First Steps with the TNC 640

### 1.3 Programming the first part

N20 G31 X+100 Y+100 Z+0 *	
N30 T5 G17 S4500 *	Tool call
N40 G00 G40 G90 Z+250 *	Retract the tool
N50 G200 DRILLING	Define the cycle
Q200=2 ;SET-UP CLEARANCE	
Q201=-20 ;DEPTH	
Q206=250 ;FEED RATE FOR PLNGNG	
Q202=5 ;PLUNGING DEPTH	
Q210=0 ;DWELL TIME AT TOP	
Q203=-10 ;SURFACE COORDINATE	
Q204=20 ;2ND SET-UP CLEARANCE	
Q211=0.2 ;DWELL TIME AT BOTTOM	
N60 X+10 Y+10 M13 M99 *	Spindle and coolant on, call the cycle
N70 X+10 Y+90 M99 *	Call the cycle
N80 X+90 Y+10 M99 *	Call the cycle
N90 X+90 Y+90 M99 *	Call the cycle
N100 G00 Z+250 M2 *	Retract the tool, end program
N99999999 %C200 G71 *	

#### Further information on this topic

- Creating a new program: See "Opening programs and entering", page 95
- Cycle programming: See User's Manual for Cycles, "Cycle fundamentals / Overviews"

## 1.4 Graphically testing the first part

### Selecting the correct operating mode


You can test programs only in the Test Run mode:



- ▶ Press the operating-mode key: The TNC goes into the **Test Run** operating mode

### Further information on this topic

- Operating modes of the TNC: See "Modes of Operation", page 73
- Testing programs: See "Test Run", page 533




### Selecting the tool table for the test run


You only need to execute this step if you have not activated a tool table in the Test Run mode.



- ▶ Press the **PGM MGT** key: The TNC opens the file management



- ▶ Press the **select type** soft key: The TNC shows a soft-key menu for selection of the file type to be displayed



- ▶ Press the **DEFAULT** soft key: The TNC shows all saved files in the right window



- ▶ Move the highlight to the left onto the directories



- ▶ Move the highlight to the **TNC:\** directory



- ▶ Move the highlight to the right onto the files



- ▶ Move the highlight to the file **TOOL.T** (active tool table) and load with the ENT key: **TOOL.T** receives the status **S** and is therefore active for the test run



- ▶ Press the **END** key: Exit the file management



### Further information on this topic

- Tool management: See "Enter tool data into the table", page 164
- Testing programs: See "Test Run", page 533

## First Steps with the TNC 640

### 1.4 Graphically testing the first part





#### Choosing the program you want to test

- 
  - ▶ Press the **PGM MGT** key: The TNC opens the file management
- 
  - ▶ Press the **LAST FILES** soft key: The TNC opens a pop-up window with the most recently selected files
  - ▶ Use the arrow keys to select the program that you want to test. Load with the ENT key




#### Further information on this topic

- Selecting a program: See "Working with the file manager", page 109

#### Selecting the screen layout and the view

- 
  - ▶ Press the key for selecting the screen layout: The TNC displays all available alternatives in the soft-key row
- 
  - ▶ Press the **PROGRAM+GRAPHICS** soft key: In the left half of the screen the TNC shows the program; in the right half it shows the workpiece blank
- 
  - ▶ Press the **FURTHER VIEW OPTIONS** soft key
- 
  - ▶ Move the soft-key row further and select the desired view by soft key

The TNC features the following views:

Soft key	Function
	Plan view
	Projection in three planes
	3-D view

#### Further information on this topic

- Graphic functions: See "Graphics ", page 522
- Running a test run: See "Test Run", page 533

## Starting the test run



- ▶ Press the **RESET + START** soft key: The TNC simulates the active program up to a programmed break or to the program end
- ▶ While the simulation is running, you can use the soft keys to change views



- ▶ Press the **STOP** soft key: The TNC interrupts the test run



- ▶ Press the **START** soft key: the TNC resumes the test run after an interruption.

## Further information on this topic

- Running a test run: See "Test Run", page 533
- Graphic functions: See "Graphics ", page 522
- Adjust the simulation speed: See "Speed of the Setting test runs", page 523

## First Steps with the TNC 640

### 1.5 Setting up tools

### 1.5 Setting up tools

#### Selecting the correct operating mode


Tools are set up in the **Manual Operation** mode:



- ▶ Press the operating-mode key: The TNC switches to the **Manual** mode of operation

#### Further information on this topic

- Operating modes of the TNC: See "Modes of Operation", page 73



#### Preparing and measuring tools

- ▶ Clamp the required tools in their chucks
- ▶ When measuring with an external tool presetter: Measure the tools, note down the length and radius, or transfer them directly to the machine through a transfer program
- ▶ When measuring on the machine: store the tools in the tool changer page 64

## The tool table TOOL.T

In the tool table TOOL.T (permanently saved under **TNC:\TABLE**), save the tool data such as length and radius, but also further tool-specific information that the TNC needs to perform its functions.

To enter tool data in the tool table TOOL.T, proceed as follows:

- 
- ▶ Display the tool table
  - ▶ Edit the tool table: Set the **EDITING** soft key to ON
  - ▶ With the upward or downward arrow keys you can select the tool number that you want to edit
  - ▶ With the rightward or leftward arrow keys you can select the tool data that you want to edit
  - ▶ To exit the tool table, press the **END** key

T	NAME	L	R	R2	DL	DR
0	MALWERKZEUG	0	0	0	0	0
100		30	1	0	0	0
204		40	2	0	0	0
306		50	3	0	0	0
408		60	4	0	0	0
510		80	5	0	0	0
612		60	6	0	0	0
714		70	7	0	0	0
816		80	8	0	0	0
918		90	9	0	0	0
1020		90	10	0	0	0
1122		90	11	0	0	0
1224		90	12	0	0	0
1326		90	13	0	0	0
1428		100	14	0	0	0
1530		100	15	0	0	0
1632		100	16	0	0	0
1734		100	17	0	0	0
1836		100	18	0	0	0
1938		100	19	0	0	0
2040		100	20	0	0	0
2142		100	5	5	0	0
2244		120	22	0	0	0
2346		120	23	0	0	0
2448		120	24	0	0	0
2550		120	25	0	0	0
2652		120	26	0	0	0

### Further information on this topic

- Operating modes of the TNC: See "Modes of Operation", page 73
- Working with the tool table: See "Enter tool data into the table", page 164

## 1.5 Setting up tools

### The pocket table TOOL\_PTCH




The function of the pocket table depends on the machine. Refer to your machine manual.

In the pocket table TOOL\_PTCH (permanently saved under **TNC:\TABLE**) you specify which tools your tool magazine contains.

To enter data in the pocket table TOOL\_PTCH, proceed as follows:



- ▶ Displaying the tool table: The TNC shows the tool table



- ▶ Display the pocket table: The TNC shows the pocket table
- ▶ Edit the pocket table: Set the **EDIT** soft key to ON
- ▶ With the upward or downward arrow keys you can select the pocket number that you want to edit
- ▶ With the rightward or leftward arrow keys you can select the data that you want to edit
- ▶ Exit the pocket table: press the **END** key.

P	T	TNAME	RSV	ST	F	L	DOC
0.0	5.010						
1.1	1.02						
1.2	2.04						
1.3	3.06						
1.4	4.08						
1.5	5.010	R					
1.6	6.012						
1.7	7.014						
1.8	8.016						
1.9	9.018						
1.10	10.020						
1.11	11.022						
1.12	12.024						
1.13	13.026						
1.14	14.028						
1.15	15.030						
1.16	16.032						
1.17	17.034						
1.18	18.036						
1.19	19.038						
1.20	20.040						
1.21	21.042						
1.22	22.044						
1.23	23.046						
1.24	24.048						
1.25	25.050						
1.26	26.052						

### Further information on this topic

- Operating modes of the TNC: See "Modes of Operation", page 73
- Working with the pocket table: See "Pocket table for tool changer", page 173



## 1.6 Workpiece setup

### Selecting the correct operating mode

Workpieces are set up in the **Manual Operation** or **Electronic Handwheel** mode



- ▶ Press the operating-mode key: The TNC switches to the **Manual** mode of operation

### Further information on this topic

- Manual Operation mode: See "Moving the machine axes", page 457

### Clamping the workpiece

Mount the workpiece with a fixture on the machine table. If you have a 3-D touch probe on your machine, then you do not need to clamp the workpiece parallel to the axes.

If you do not have a 3-D touch probe available, you have to align the workpiece so that it is fixed with its edges parallel to the machine axes.

## First Steps with the TNC 640

### 1.6 Workpiece setup

#### Datum setting with 3-D touch probe

- ▶ Insert a 3-D touch probe Insert the 3-D touch probe: In the MDI mode, run a **TOOL CALL** block containing the tool axis and then return to the **Manual Operation** mode



- ▶ Select the probing functions: The TNC displays all available functions in the soft-key row



- ▶ Set the datum at a workpiece corner, for example
- ▶ Position the touch probe near the first touch point on the first workpiece edge
- ▶ Select the probing direction via soft key
- ▶ Press NC start Press NC start: The touch probe moves in the defined direction until it contacts the workpiece and then automatically returns to its starting point
- ▶ Use the axis-direction keys to pre-position the touch probe to a position near the second touch point on the first workpiece edge
- ▶ Press NC start Press NC start: The touch probe moves in the defined direction until it contacts the workpiece and then automatically returns to its starting point
- ▶ Use the axis-direction keys to pre-position the touch probe to a position near the first touch point on the second workpiece edge
- ▶ Select the probing direction via soft key
- ▶ Press NC start Press NC start: The touch probe moves in the defined direction until it contacts the workpiece and then automatically returns to its starting point
- ▶ Use the axis-direction keys to pre-position the touch probe to a position near the second touch point on the second workpiece edge
- ▶ Press NC start Press NC start: The touch probe moves in the defined direction until it contacts the workpiece and then automatically returns to its starting point
- ▶ Then the TNC shows the coordinates of the measured corner point
- ▶ To set to 0: Press the **SET DATUM** soft key
- ▶ Press the **END** soft key to close the menu





#### Further information on this topic

- Datum setting: See "Datum Setting with 3-D Touch Probe ", page 498

## 1.7 Running the first program

### Selecting the correct operating mode



You can run programs either in the Single Block or the Full Sequence mode:

-  ▶ Press the operating-mode key: The TNC goes into the **Program Run, Single Block** mode and the TNC executes the program block by block. You have to confirm each block with the NC start key
-  ▶ Press the operating-mode key: The switches to the **Program Run, Full Sequence** operating mode: The TNC switches to that mode and runs the program after NC start up to a program interruption or to the end of the program

### Further information on this topic

- Operating modes of the TNC: See "Modes of Operation", page 73
- Running programs: See "Program run", page 535


### Choosing the program you want to run

-  ▶ Press the **PGM MGT** key: The TNC opens the file management
-  ▶ Press the **LAST FILES** soft key: The TNC opens a pop-up window with the most recently selected files
- ▶ If desired, use the arrow keys to select the program that you want to run. Load with the ENT key

### Further information on this topic


- File management: See "Working with the file manager", page 109

### Start the program

-  ▶ Press the NC start key: The TNC runs the active program

### Further information on this topic

- Running programs: See "Program run", page 535





# 2

**Introduction**

## Introduction

### 2.1 The TNC 640

#### 2.1 The TNC 640

HEIDENHAIN TNC controls are workshop-oriented contouring controls that enable you to program conventional machining operations right at the machine in an easy-to-use conversational programming language. They are designed for milling and drilling machines, as well as machining centers, with up to 18 axes. You can also change the angular position of the spindle under program control.

An integrated hard disk provides storage for as many programs as you like, even if they were created off-line. For quick calculations you can call up the on-screen pocket calculator at any time.

Keyboard and screen layout are clearly arranged in such a way that the functions are fast and easy to use.



#### Programming: HEIDENHAIN conversational and ISO formats

The HEIDENHAIN conversational programming format is an especially easy method of writing programs. Interactive graphics illustrate the individual machining steps for programming the contour. If a production drawing is not dimensioned for NC, the FK free contour programming feature performs the necessary calculations automatically. Workpiece machining can be graphically simulated either during or before actual machining.

It is also possible to program the TNCs in ISO format or DNC mode.

You can also enter and test one program while the control is running another.

#### Compatibility

Machining programs created on HEIDENHAIN contouring controls (starting from the TNC 150 B) may not always run on the TNC 640. If NC blocks contain invalid elements, the TNC will mark them as ERROR blocks when the file is opened.



See "Functions of the TNC 640 and the iTNC 530 compared", page 605. Please also note the detailed description of the differences between the iTNC 530 and the TNC 640

## 2.2 Visual display unit and operating panel

### Display screen

The TNC is shipped with a 19-inch TFT flat-panel display.

#### 1 Header

When the TNC is on, the selected operating modes are shown in the screen header: the machining mode at the left and the programming mode at right. The currently active operating mode is displayed in the larger box, where the dialog prompts and TNC messages also appear (unless the TNC is showing only graphics).

#### 2 Soft keys

In the footer the TNC indicates additional functions in a soft-key row. You can select these functions by pressing the keys immediately below them. The lines immediately above the soft-key row indicate the number of soft-key rows that can be called with the black arrow keys to the right and left. The bar representing the active soft-key row is highlighted

#### 3 Soft-key selection keys


#### 4 Shifting between soft-key rows

#### 5 Setting the screen layout

#### 6 Shift key for switchover between machining and programming modes

#### 7 Soft-key selection keys for machine tool builders

#### 8 Switching the soft-key rows for machine tool builders




### Setting the screen layout

You select the screen layout yourself: In the Programming mode of operation, for example, you can have the TNC show program blocks in the left window while the right window displays programming graphics. You could also display the program structure in the right window instead, or display only program blocks in one large window. The available screen windows depend on the selected operating mode.

To change the screen layout:

- ▶ Press the screen layout key: The soft-key row shows the available layout options, see "Operating modes", page 62

- ▶ Select the desired screen layout




## Introduction

### 2.2 Visual display unit and operating panel

#### Control Panel

The TNC 640 is delivered with an integrated keyboard. The figure to the right shows the operating elements of the operating panel:

- 1 Alphabetic keyboard for entering texts and file names, and for ISO programming.
- 2
  - File management
  - Calculator
  - MOD function
  - HELP function
- 3 Programming modes
- 4 Machine operating modes
- 5 Initiation of programming dialogs
- 6 Navigation keys and **GOTO** jump command
- 7 Numerical input and axis selection
- 8 Touchpad
- 9 Mouse function keys
- 10 USB connection



The functions of the individual keys are described on the inside front cover.



Some machine manufacturers do not use the standard operating panel from HEIDENHAIN. Refer to your machine manual.

Machine panel buttons, e.g. NC START or NC STOP, are described in the manual for your machine tool.





## 2.3 Modes of Operation


### Manual Operation and El. Handwheel

The Manual Operation mode is required for setting up the machine tool. In this mode of operation, you can position the machine axes manually or by increments, set the datums, and tilt the working plane.

The El. Handwheel mode of operation allows you to move the machine axes manually with the HR electronic handwheel.

#### Soft keys for selecting the screen layout (select as described previously)



Window	Soft key
Positions	
Left: positions, right: status display	




### Positioning with Manual Data Input

This mode of operation is used for programming simple traversing movements, such as for face milling or prepositioning.

#### Soft keys for selecting the screen layout




Window	Soft key
Program	
Left: program blocks, right: status display	




### Programming

In this mode of operation you can write your part programs. The FK free programming feature, the various cycles and the Q parameter functions help you with programming and add necessary information. If desired, you can have the programming graphics show the programmed paths of traverse.

#### Soft keys for selecting the screen layout

Window	Soft key
Program	
Left: program, right: program structure	
Left: program, right: programming graphics	




## Introduction

### 2.3 Modes of Operation

#### Test Run

In the Test Run mode of operation, the TNC checks programs and program sections for errors, such as geometrical incompatibilities, missing or incorrect data within the program or violations of the working space. This simulation is supported graphically in different display modes.

Soft keys for selecting the screen layout: See "Program Run, Full Sequence and Program Run, Single Block", page 74.




#### Program Run, Full Sequence and Program Run, Single Block

In the Program Run, Full Sequence mode of operation the TNC executes a part program continuously to its end or to a manual or programmed stop. You can resume program run after an interruption.

In the Program Run, Single Block mode of operation you execute each block separately by pressing the machine START button.

#### Soft keys for selecting the screen layout

Window	Soft key
Program	PSM
Left: program, right: program structure	PROGRAM + SECTS
Left: program, right: status	PROGRAM + STATUS
Left: program, right: graphics	PROGRAM + GRAPHICS
Graphics	GRAPHICS
Window	Soft key
Pallet table	PALLET
Left: program, right: pallet table	PROGRAM + PALLET
Left: pallet table, right: status	PALLET + STATUS




## 2.4 Status displays

### "General" status display

The status display in the lower part of the screen informs you of the current state of the machine tool. It is displayed automatically in the following modes of operation:

- Program Run, Single Block and Program Run, Full Sequence, except if the screen layout is set to display graphics only, and
- Positioning with Manual Data Input (MDI).

In the Manual Operation and El. Handwheel modes the status display appears in the large window.









### Information in the status display

Icon	Meaning
<b>ACTL.</b>	Position display: Actual, nominal or distance-to-go coordinates mode
<b>XYZ</b>	Machine axes; the TNC displays auxiliary axes in lower-case letters. The sequence and quantity of displayed axes is determined by the machine tool builder. Refer to your machine manual for more information
	Number of the active presets from the preset table. If the datum was set manually, the TNC displays the text <b>MAN</b> behind the symbol
<b>F S M</b>	The displayed feed rate in inches corresponds to one tenth of the effective value. Spindle speed S, feed rate F and active M functions
	Axis is clamped
	Axis can be moved with the handwheel
	Axes are moving under a basic rotation
	Axes are moving in a tilted working plane
<b>TC PM</b>	The <b>M128</b> function or <b>TCPM FUNCTION</b> is active
	No active program

## Introduction

### 2.4 Status displays

Icon	Meaning
	Program run has started
	Program run is stopped
	Program run is being aborted
	Turning mode is active
	The Dynamic Collision Monitoring function (DCM) is active
	The Adaptive Feed Function (AFC) is active (software option)
<u>ACC</u>	The Active Chatter Control feature (ACC) is active (software option)
<u>CTC</u>	The Cross Talk Compensation (CTC) is active (software option)

#### Additional status displays

The additional status displays contain detailed information on the program run. They can be called in all operating modes except for the Programming mode of operation.

##### To switch on the additional status display:



- ▶ Call the soft-key row for screen layout




- ▶ Select the layout option for the additional status display: In the right half of the screen, the TNC shows the **OVERVIEW** status form

##### To select an additional status display:



- ▶ Switch the soft-key rows until the STATUS soft keys appear



- ▶ Either select the additional status display directly by soft key, e.g. positions and coordinates, or



- ▶ use the switch-over soft keys to select the desired view

The available status displays described below can be selected either directly by soft key or with the switch-over soft keys.



Please note that some of the status information described below is not available unless the associated software option is enabled on your TNC.




## Introduction

### 2.4 Status displays


#### Program section repeat/Subprograms (LBL tab)

Soft key	Meaning
No direct selection possible	Active program section repeats with block number, label number, and number of programmed repeats/repeats yet to be run
	Active subprogram numbers with block number in which the subprogram was called and the label number that was called




#### Information on standard cycles (CYC tab)

Soft key	Meaning
No direct selection possible	Active machining cycle
	Active values of Cycle 32 Tolerance




### Active miscellaneous functions M (M tab)

Soft key	Meaning
No direct selection possible	List of the active M functions with fixed meaning
	List of the active M functions that are adapted by your machine manufacturer



### Positions and coordinates (POS tab)

Soft key	Meaning
<b>STATUS POS.</b>	Type of position display, e.g. actual position
	Tilt angle of the working plane
	Angle of a basic rotation
	Active kinematics





## Introduction

### 2.4 Status displays

#### Information on tools (TOOL tab)

##### Soft key Meaning

Soft key	Meaning
	Display of active tool: <ul style="list-style-type: none"> <li>■ T: Tool number and name</li> <li>■ RT: Number and name of a replacement tool</li> </ul>
	Tool axis
	Tool length and radii
	Oversizes (delta values) from the tool table (TAB) and the <b>TOOL CALL</b> (PGM)
	Tool life, maximum tool life (TIME 1) and maximum tool life for <b>TOOL CALL</b> (TIME 2)
	Display of programmed tool and replacement tool




#### Tool measurement (TT tab)



The TNC displays the TT tab only if the function is active on your machine.

##### Soft key Meaning

Soft key	Meaning
No direct selection possible	Number of the tool to be measured
	Display whether the tool radius or the tool length is being measured
	MIN and MAX values of the individual cutting edges and the result of measuring the rotating tool (DYN = dynamic measurement)
	Cutting edge number with the corresponding measured value. If the measured value is followed by an asterisk, the permissible tolerance in the tool table was exceeded







### Coordinate transformations (TRANS tab)

Soft key	Meaning
<b>STATUS COORD. TRANSF.</b>	Name of the active datum table
	Active datum number (#), comment from the active line of the active datum number (DOC) from Cycle G53
	Active datum shift (Cycle G54); The TNC displays an active datum shift in up to 8 axes
	Mirrored axes (Cycle G28)
	Active basic rotation
	Active rotation angle (Cycle G73)
	Active scaling factor/factors (Cycles G72); The TNC displays an active scaling factor in up to 6 axes
	Scaling datum

For further information, refer to the User's Manual for Cycles, "Coordinate Transformation Cycles."

### Displaying Q parameters (QPARA tab)

Soft key	Meaning
<b>STATUS OF Q PARAM.</b>	Display the current values of the defined Q parameters
	Display the character strings of the defined string parameters




## Introduction

### 2.4 Status displays

#### Adaptive Feed Control (AFC tab, software option)



The TNC displays the AFC tab only if the function is active on your machine.



Soft key	Meaning
No direct selection possible	Active tool (number and name)
	Cut number
	Current factor of the feed potentiometer in percent
	Active spindle load in percent
	Reference load of the spindle
	Current spindle speed
	Current deviation of the speed
	Current machining time
	Line diagram, in which the current spindle load and the value commanded by the TNC for the feed-rate override are shown

## 2.5 Window Manager



The machine tool builder determines the scope of function and behavior of the window manager. Refer to your machine manual.

The TNC features the Xfce window manager. Xfce is a standard application for UNIX-based operating systems, and is used to manage graphical user interfaces. The following functions are possible with the window manager:

- Display a task bar for switching between various applications (user interfaces).
- Manage an additional desktop, on which special applications from your machine tool builder can run.
- Control the focus between NC-software applications and those of the machine tool builder.
- The size and position of pop-up windows can be changed. It is also possible to close, minimize and restore the pop-up windows.



The TNC shows a star in the upper left of the screen if an application of the window manager or the window manager itself has caused an error. In this case, switch to the window manager and correct the problem. If required, refer to your machine manual.

## Introduction

### 2.5 Window Manager

#### Task bar


In the task bar you can choose different workspaces by mouse click. The TNC provides the following workspaces:

- Workspace 1: Active mode of operation
- Workspace 2: Active programming mode
- Workspace 3: Manufacturer's applications (optionally available)

In the task bar you can also select other applications that you have started together with the TNC (switch for example to the **PDF viewer** or **TNCguide**)

Click the green HEIDENHAIN symbol to open a menu in which you can get information, make settings or start applications. The following functions are available:

- **About Xfce:** Information on the Windows manager Xfce
- **About HEROS:** Information about the operating system of the TNC
- **NC Control:** Start and stop the TNC software. Only permitted for diagnostic purposes
- **Web Browser:** Start Mozilla Firefox
- **Diagnostics:** Available only to authorized specialists to start diagnostic functions
- **Settings:** Configuration of miscellaneous settings
  - **Date/Time:** Set the date and time
  - **Language:** Language setting for the system dialogs. During startup the TNC overwrites this setting with the language setting of the machine parameter CfgLanguage
  - **Network:** Network setting
  - **Reset WM-Conf:** Restore basic settings of the Windows Manager. May also reset settings implemented by your machine manufacturer
  - **Screensaver:** Settings for the screen saver; several are available
  - **Shares:** Configure network connections
  - **Firewall:** Configuring the Firewall See "Firewall", page 573
- **Tools:** Only for authorized users. The applications available under tools can be started directly by selecting the pertaining file type in the file management of the TNC (See "File manager: Fundamentals", page 106)



## 2.6 SELinux security software

**SELinux** is an extension for Linux-based operating systems. SELinux is an additional security software package based on Mandatory Access Control (MAC) and protects the system against the running of unauthorized processes or functions and therefore protects against viruses and other malware.

MAC means that each action must be specifically permitted otherwise the TNC will not run it. The software is intended as protection in addition to the normal access restriction in Linux. Certain processes and actions can only be executed if the standard functions and access control of SELinux permit it.



The SELinux installation of the TNC is prepared to permit running of only those programs installed with the HEIDENHAIN NC software. Other programs cannot be run with the standard installation.

The access control of SELinux under HEROS 5 is regulated as follows:

- The TNC runs only those applications installed with the HEIDENHAIN NC software.
- Files in connection with the safety of the software (SELinux system files, HEROS 5 boot files etc.) may only be changed by programs that are selected explicitly.
- New files generated by other programs must never be executed.
- There are only two processes that are permitted to execute new files:
  - Starting a software update: A software update from HEIDENHAIN can replace or change system files.
  - Starting the SELinux configuration: The configuration of SELinux is usually password-protected by your machine tool builder. Refer here to the relevant machine tool manual.



HEIDENHAIN generally recommends activating SELinux because it provides additional protection against attacks from outside.

## Introduction

### 2.7 Accessories: HEIDENHAIN 3-D Touch Probes and Electronic Handwheels

### 2.7 Accessories: HEIDENHAIN 3-D Touch Probes and Electronic Handwheels

#### 3-D touch probes

The various HEIDENHAIN 3-D touch probes enable you to:

- Automatically align workpieces
- Quickly and precisely set datums
- Measure the workpiece during program run
- Measure and inspect tools



All of the cycle functions (touch probe cycles and fixed cycles) are described in the Cycle Programming User's Manual. Please contact HEIDENHAIN if you require a copy of this User's Manual. ID: 892905-xx

#### The TS 220, TS 440, TS 444, TS 640 and TS 740 triggering touch probes edge finder

These touch probes are particularly effective for automatic workpiece alignment, datum setting and workpiece measurement. The TS 220 transmits the triggering signals to the TNC via cable and is a cost-effective alternative for applications where digitizing is not frequently required.

The TS 640 (see figure) and the smaller TS 440 feature infrared transmission of the triggering signal to the TNC. This makes them highly convenient for use on machines with automatic tool changers.

Principle of operation: HEIDENHAIN triggering touch probes feature a wear resisting optical switch that generates an electrical signal as soon as the stylus is deflected. This signal is transmitted to the control, which stores the current position of the stylus as the actual value.

#### TT 140 tool touch probe for tool measurement

The TT 140 is a triggering 3-D touch probe for tool measurement and inspection. Your TNC provides three cycles for this touch probe with which you can measure the tool length and radius automatically either with the spindle rotating or stopped. The TT 140 features a particularly rugged design and a high degree of protection, which make it insensitive to coolants and swarf. The triggering signal is generated by a wear-resistant and highly reliable optical switch.



## Accessories: HEIDENHAIN 3-D Touch Probes and Electronic Handwheels 2.7 Handwheels

### HR electronic handwheels

Electronic handwheels facilitate moving the axis slides precisely by hand. A wide range of traverses per handwheel revolution is available. Apart from the HR 130 and HR 150 panel-mounted handwheels, HEIDENHAIN also offers the HR 410 portable handwheel.







# 3

**Programming:  
Fundamentals, file  
management**

## 3.1 Fundamentals

### 3.1 Fundamentals


#### Position encoders and reference marks

The machine axes are equipped with position encoders that register the positions of the machine table or tool. Linear axes are usually equipped with linear encoders, rotary tables and tilting axes with angle encoders.

When a machine axis moves, the corresponding position encoder generates an electrical signal. The TNC evaluates this signal and calculates the precise actual position of the machine axis.

If there is a power interruption, the calculated position will no longer correspond to the actual position of the machine slide. To recover this association, incremental position encoders are provided with reference marks. The scales of the position encoders contain one or more reference marks that transmit a signal to the TNC when they are crossed over. From that signal the TNC can re-establish the assignment of displayed positions to machine positions. For linear encoders with distance-coded reference marks, the machine axes need to move by no more than 20 mm, for angle encoders by no more than 20°.

With absolute encoders, an absolute position value is transmitted to the control immediately upon switch-on. In this way the assignment of the actual position to the machine slide position is re-established directly after switch-on.




#### Reference system

A reference system is required to define positions in a plane or in space. The position data are always referenced to a predetermined point and are described through coordinates.

The Cartesian coordinate system (a rectangular coordinate system) is based on the three coordinate axes X, Y and Z. The axes are mutually perpendicular and intersect at one point called the datum. A coordinate identifies the distance from the datum in one of these directions. A position in a plane is thus described through two coordinates, and a position in space through three coordinates.



Coordinates that are referenced to the datum are referred to as absolute coordinates. Relative coordinates are referenced to any other known position (reference point) you define within the coordinate system. Relative coordinate values are also referred to as incremental coordinate values.



## Reference system on milling machines

When using a milling machine, you orient tool movements to the Cartesian coordinate system. The illustration at right shows how the Cartesian coordinate system describes the machine axes. The figure illustrates the right-hand rule for remembering the three axis directions: the middle finger points in the positive direction of the tool axis from the workpiece toward the tool (the Z axis), the thumb points in the positive X direction, and the index finger in the positive Y direction.

The TNC 640 can control up to 18 axes. The axes U, V and W are secondary linear axes parallel to the main axes X, Y and Z, respectively. Rotary axes are designated as A, B and C. The illustration at lower right shows the assignment of secondary axes and rotary axes to the main axes.



## Designation of the axes on milling machines

The X, Y and Z axes on your milling machine are also referred to as tool axis, principal axis (1st axis) and secondary axis (2nd axis). The assignment of the tool axis is decisive for the assignment of the principal and secondary axes.

Tool axis	Principal axis	Secondary axis
X	Y	Z
Y	Z	X
Z	X	Y

## 3.1 Fundamentals

## Polar coordinates

If the production drawing is dimensioned in Cartesian coordinates, you also write the NC program using Cartesian coordinates. For parts containing circular arcs or angles it is often simpler to give the dimensions in polar coordinates.



While the Cartesian coordinates X, Y and Z are three-dimensional and can describe points in space, polar coordinates are two-dimensional and describe points in a plane. Polar coordinates have their datum at a circle center (CC), or pole. A position in a plane can be clearly defined by the:

- Polar Radius, the distance from the circle center CC to the position, and the
- Polar Angle, the value of the angle between the angle reference axis and the line that connects the circle center CC with the position.

## Setting the pole and the angle reference axis

The pole is set by entering two Cartesian coordinates in one of the three planes. These coordinates also set the reference axis for the polar angle H.

Coordinates of the pole (plane)	Reference axis of the angle
X/Y	+X
Y/Z	+Y
Z/X	+Z




## Absolute and incremental workpiece positions

### Absolute workpiece positions

Absolute coordinates are position coordinates that are referenced to the datum of the coordinate system (origin). Each position on the workpiece is uniquely defined by its absolute coordinates.

Example 1: Holes dimensioned in absolute coordinates

Hole 1	Hole 2	Hole 3
X = 10 mm	X = 30 mm	X = 50 mm
Y = 10 mm	Y = 20 mm	Y = 30 mm



### Incremental workpiece positions

Incremental coordinates are referenced to the last programmed nominal position of the tool, which serves as the relative (imaginary) datum. When you write an NC program in incremental coordinates, you thus program the tool to move by the distance between the previous and the subsequent nominal positions. This is why they are also referred to as chain dimensions.

To program a position in incremental coordinates, enter the function G91 before the axis.

Example 2: Holes dimensioned in incremental coordinates

#### Absolute coordinates of hole 4

X = 10 mm

Y = 10 mm

#### Hole 5, with respect to 4


G91 X = 20 mm

G91 Y = 10 mm

#### Hole 6, with respect to 5

G91 X = 20 mm


G91 Y = 10 mm



### Absolute and incremental polar coordinates

Absolute polar coordinates always refer to the pole and the angle reference axis.

Incremental polar coordinates always refer to the last programmed nominal position of the tool.



## 3.1 Fundamentals

## Selecting the datum

A production drawing identifies a certain form element of the workpiece, usually a corner, as the absolute datum. When setting the datum, you first align the workpiece along the machine axes, and then move the tool in each axis to a defined position relative to the workpiece. Set the display of the TNC either to zero or to a known position value for each position. This establishes the reference system for the workpiece, which will be used for the TNC display and your part program.



If the production drawing is dimensioned in relative coordinates, simply use the coordinate transformation cycles (see User's Manual for Cycles, Cycles for Coordinate Transformation).

If the production drawing is not dimensioned for NC, set the datum at a position or corner on the workpiece from which the dimensions of the remaining workpiece positions can be most easily measured.

The fastest, easiest and most accurate way of setting the datum is by using a 3-D touch probe from HEIDENHAIN. See "Setting the Datum with a 3-D Touch Probe" in the Cycle Programming User's Manual.

## Example

The workpiece drawing shows holes (1 to 4) whose dimensions are shown with respect to an absolute datum with the coordinates  $X=0$   $Y=0$ . Holes 5 to 7 are dimensioned with respect to a relative datum with the absolute coordinates  $X=450$ ,  $Y=750$ . With the **DATUM SHIFT** cycle you can temporarily set the datum to the position  $X=450$ ,  $Y=750$ , to be able to program holes 5 to 7 without further calculations.



## 3.2 Opening programs and entering

### Organization of an NC program in DIN/ISO format

A part program consists of a series of program blocks. The figure at right illustrates the elements of a block.


The TNC numbers the blocks of a part program automatically depending on machine parameter **blockIncrement** (105409). The machine parameter **blockIncrement** (105409) defines the block number increment.

The first block of a program is identified by %, the program name and the active unit of measure.

The subsequent blocks contain information on:

- The workpiece blank
- Tool calls
- Approaching a safe position
- Feed rates and spindle speeds, as well as
- Path contours, cycles and other functions

The last block of a program is identified by **N99999999** the program name and the active unit of measure.



After each tool call, HEIDENHAIN recommends always traversing to a safe position from which the TNC can position the tool for machining without causing a collision!

## Programming: Fundamentals, file management

### 3.2 Opening programs and entering




#### Define the blank: G30/G31

Immediately after initiating a new program, you define a cuboid, unmachined workpiece blank. If you wish to define the blank at a later stage, press the **spec fct** key, the PROGRAM DEFAULTS soft key, and then the **BLK FORM** soft key. The TNC needs this definition for graphic simulation.



You only need to define the workpiece blank if you wish to run a graphic test for the program!

The TNC can depict various types of blank forms.

Soft key	Function
	Define a workpiece blank
	Define a cylindrical blank
	Define a rotationally symmetric blank

#### Rectangular blank

The sides of the cuboid lie parallel to the X, Y and Z axes. This blank is defined by two of its corner points:

- MIN point G30: the smallest X, Y and Z coordinates of the blank form, entered as absolute values
- MAX point G31: the largest X, Y and Z coordinates of the blank form, entered as absolute or incremental values

#### Example: Display the BLK FORM in the NC program

<code>%NEW G71 *</code>	Program begin, name, unit of measure
<code>N10 G30 G17 X+0 Y+0 Z-40 *</code>	Spindle axis, MIN point coordinates
<code>N20 G31 X+100 Y+100 Z+0 *</code>	MAX point coordinates
<code>N99999999 %NEW G71 *</code>	Program end, name, unit of measure



### Cylindrical blank

The cylindrical blank form is defined by the dimensions of the cylinder:

- R: Radius of the cylinder
- L: Length of the cylinder
- DIST: Distance from datum to cylinder end
- RI: Inside radius for a hollow cylinder



The **DIST** and **RI** parameters are optional and do not need to be programmed.

### Example: Display the BLK FORM CYLINDER in the NC program

<b>0 BEGIN PGM NEW MM</b>	Program begin, name, unit of measure
<b>1 BLK FORM CYLINDER Z R50 L105 DIST+5 RI10</b>	Spindle axis, radius, length, distance, inside radius
<b>2 END PGM NEW MM</b>	Program end, name, unit of measure

### Rotationally symmetric blank of any shape

You define the contour of the rotationally symmetric blank in a subprogram. In the workpiece blank definition you refer to the contour description:

- DIM\_D, DIM\_R: Diameter or radius of the rotationally symmetrical blank form
- LBL: Subprogram with the contour description



The subprogram can be designated with a number, an alphanumeric name, or a QS parameter.

### Example: Display the BLK FORM ROTATION in the NC program

<b>0 BEGIN PGM NEW MM</b>	Program begin, name, unit of measure
<b>1 BLK FORM ROTATION Z DIM_R LBL 1</b>	Spindle axis, manner of interpretation, subprogram number
<b>2 M30</b>	End of main program
<b>3 LBL 1</b>	Beginning of subprogram
<b>4 L X+0 Z+1</b>	Beginning of contour
<b>5 L X+50</b>	
<b>6 L Z-20</b>	
<b>7 L X+70</b>	
<b>8 L Z-100</b>	
<b>9 L X+0</b>	
<b>10 L Z+1</b>	End of contour
<b>11 LBL 0</b>	End of subprogram
<b>12 END PGM NEW MM</b>	Program end, name, unit of measure

### Opening a new part program

You always enter a part program in the **PROGRAMMING AND EDITING** mode of operation. An example of program initiation:

## Programming: Fundamentals, file management

### 3.2 Opening programs and entering



- ▶ Select the **PROGRAMMING** mode of operation



- ▶ To call the file manager, Press the PGM MGT key.

Select the directory in which you wish to store the new program:

.I



- ▶ Enter the new program name and confirm your entry with the ENT key.



- ▶ Selecting the unit of measure: Press the MM or INCH soft key. The TNC switches the screen layout and initiates the dialog for defining the **BLK FORM** (workpiece blank)



- ▶ Select a rectangular workpiece blank: Press the soft key for a rectangular blank form

#### WORKING PLANE IN GRAPHIC: XY



- ▶ Enter spindle axis, e.g. Z

#### WORKPIECE BLANK DEF.: MINIMUM



- ▶ Enter in sequence the X, Y and Z coordinates of the MIN point and confirm each of your entries with the ENT key

#### WORKPIECE BLANK DEF.: MAXIMUM



- ▶ Enter in sequence the X, Y and Z coordinates of the MAX point and confirm each of your entries with the ENT key

#### Example: Display the BLK form in the NC program

<code>%NEW G71 *</code>	Program begin, name, unit of measure
<code>N10 G30 G17 X+0 Y+0 Z-40 *</code>	Spindle axis, MIN point coordinates
<code>N20 G31 X+100 Y+100 Z+0 *</code>	MAX point coordinates
<code>N99999999 %NEW G71 *</code>	Program end, name, unit of measure

The TNC automatically generates the first and last blocks of the program.



If you do not wish to define a blank form, cancel the dialog at **Working plane in graphic: XY** by pressing the DEL key.

## Programming tool movements in DIN/ISO

Press the SPEC FCT key to program a block. Press the PROGRAM FUNCTIONS soft key, and then the DIN/ISO soft key. You can also use the gray contouring keys to get the corresponding G code.



If you enter DIN/ISO functions via a connected USB keyboard, make sure that capitalization is active.

### Example of a positioning block

**G** ▶ Enter **1** and press the ENT key to open the block



### COORDINATES ?

**X** ▶ **10** (Enter the target coordinate for the X axis)

**Y** ▶ **20** (Enter the target coordinate for the Y axis)

**ENT** ▶ go to the next question with ENT.

### MILLINGDEFINITIONPOINTPATH

**G** ▶ Enter **40** and confirm with ENT to traverse without tool radius compensation, **or**

**G 4 1** ▶ Move to the left or right of the programmed contour: Select G41 or G42 by soft key

**G 4 2**

### FEED RATE F=?

▶ **100** (Enter a feed rate of 100 mm/min for this path contour)

**ENT** ▶ go to the next question with ENT.

### MISCELLANEOUS FUNCTION M ?

▶ Enter **3** (miscellaneous function **M3** "Spindle ON").

**END** ▶ With the END key, the TNC ends this dialog.

### The program-block window displays the following line:

```
N30 G01 G40 X+10 Y+5 F100 M3 *
```

### 3.2 Opening programs and entering

#### Actual position capture

The TNC enables you to transfer the current tool position into the program, for example during


- Positioning-block programming
- Cycle programming

To transfer the correct position values, proceed as follows:

- ▶ Place the input box at the position in the block where you want to insert a position value



- ▶ Select actual-position capture: In the soft-key row the TNC displays the axes whose positions can be transferred



- ▶ Select an axis: The TNC writes the current position of the selected axis into the active input box



In the working plane the TNC always captures the coordinates of the tool center, even though tool radius compensation is active.

In the tool axis the TNC always captures the coordinates of the tool tip and thus always takes the active tool length compensation into account.

The TNC keeps the soft-key row for axis selection active until you deactivate it by pressing the actual-position-capture key again. This behavior remains in effect even if you save the current block and open a new one with a path function key. If you select a block element in which you must choose an input alternative via soft key (e.g. for radius compensation), then the TNC also closes the soft-key row for axis selection.












The actual-position-capture function is not allowed if the tilted working plane function is active.

## Editing a program










You cannot edit a program while it is being run by the TNC in a machine operating mode.

While you are creating or editing a part program, you can select any desired line in the program or individual words in a block with the arrow keys or the soft keys:

Function	Soft key/Keys
Go to previous page	
Go to next page	
Go to beginning of program	
Go to end of program	
Change the position of the current block on the screen. Press this soft key to display additional program blocks that are programmed before the current block	
Change the position of the current block on the screen. Press this soft key to display additional program blocks that are programmed after the current block	
Move from one block to the next	 
Select individual words in a block	 
To select a certain block, press the <b>GOTO</b> key, enter the desired block number, and confirm with the <b>ENT</b> key. Or: Enter the block number step and press the <b>N LINES</b> soft key to jump over the entered number of lines upward or downward	

## Programming: Fundamentals, file management

### 3.2 Opening programs and entering

Function	Soft key/Key
Set the selected word to zero	
Erase an incorrect number	
Delete the (clearable) error message	
Delete the selected word	
Delete the selected block	
Erase cycles and program sections	
Insert the block that you last edited or deleted	

#### Inserting blocks at any desired location

- ▶ Select the block after which you want to insert a new block and initiate the dialog

#### Editing and inserting words

- ▶ Select a word in a block and overwrite it with the new one. The plain-language dialog is available while the word is highlighted
- ▶ To accept the change, press the **END** key

If you want to insert a word, press the horizontal arrow key repeatedly until the desired dialog appears. You can then enter the desired value.

#### Looking for the same words in different blocks

Set the AUTO DRAW soft key to OFF.



- ▶ To select a word in a block, press the arrow keys repeatedly until the highlight is on the desired word.



- ▶ Select a block with the arrow keys

The word that is highlighted in the new block is the same as the one you selected previously.



If you have started a search in a very long program, the TNC shows a progress display window. You then have the option of canceling the search via soft key.

### Finding any text

- ▶ Select the search function: Press the **FIND** soft key. The TNC displays the **Find text:** dialog prompt
- ▶ Enter the text that you wish to find
- ▶ To find the text, Press the **FINDRUN** soft key

### Marking, copying, deleting and inserting program sections

The TNC provides certain functions for copying program sections within an NC program or into another NC program—see the table below.


To copy a program section, proceed as follows:

- ▶ Select the soft-key row containing the marking functions
- ▶ Select the first (last) block of the section you wish to copy
- ▶ To mark the first (last) block, press the **SELECT BLOCK** soft key. The TNC then highlights the first character of the block and the **CANCEL SELECTION** soft key appears
- ▶ Move the highlight to the last (first) block of the program section you wish to copy or delete. The TNC shows the marked blocks in a different color. You can end the marking function at any time by pressing the **CANCEL SELECTION** soft key
- ▶ To copy the selected program section, press the **COPY BLOCK** soft key. To delete the selected section, press the **DELETE BLOCK** soft key. The TNC stores the selected block
- ▶ Using the arrow keys, select the block after which you wish to insert the copied (deleted) program section



To insert the section into another program, select the corresponding program using the file manager and then mark the block after which you wish to insert the copied block.

- ▶ To insert the block, press the **INSERT BLOCK** soft key
- ▶ To end the marking function, press the **Cancel selection** soft key



## Programming: Fundamentals, file management

### 3.2 Opening programs and entering

Function	Soft key
Switch the marking function on	SELECT BLOCK
Switch the marking function off	CANCEL SELECTION
Delete the marked block	CUT OUT BLOCK
Insert the block that is stored in the buffer memory	INSERT BLOCK
Copy the marked block	COPY BLOCK

### The TNC search function

The search function of the TNC enables you to search for any text within a program and replace it by a new text, if required.

#### Finding any text

- ▶ If required, select the block containing the word you wish to find

FIND

- ▶ Select the search function: The TNC superimposes the search window and displays the available search functions in the soft-key row (see table of search functions)

X

- ▶ **+40** (Enter the text to be searched for. The search is case-sensitive.)

FIND


- ▶ Start the search process: The TNC moves to the next block containing the text you are searching for

FIND

- ▶ Repeat the search process: The TNC moves to the next block containing the text you are searching for

END

- ▶ End the search function





### Finding/Replacing any text



The find/replace function is not possible if

- a program is protected
- the program is currently being run by the TNC

When using the **REPLACE ALL** function, ensure that you do not accidentally replace text that you do not want to change. Once replaced, such text cannot be restored.

- ▶ If required, select the block containing the word you wish to find



- ▶ Select the Search function: The TNC superimposes the search window and displays the available search functions in the soft-key row



- ▶ Enter the text to be searched for. Please note that the search is case-sensitive. Then confirm with the **ENT** key



- ▶ Enter the text to be inserted. Please note that the entry is case-sensitive



- ▶ Start the search process: The TNC moves to the next occurrence of the text you are searching for



- ▶ If you wish to replace the text and then move to the next position where the text was found, press the **Replace** soft key. To replace all instances: Press the **REPLACE ALL** soft key. To not replace the text and jump to the next instance: Press the **FIND** soft key



- ▶ End the search function

## Programming: Fundamentals, file management

### 3.3 File manager: Fundamentals

### 3.3 File manager: Fundamentals

#### Files

Files in the TNC	Type
<b>Programs</b>	
in HEIDENHAIN format	.H
in DIN/ISO format	.I
<b>Tables for</b>	
Tools	.T
Tool changers	.TCH
Datums	.D
Points	.PNT
Presets	.PR
Touch probes	.TP
Backup files	.BAK
Dependent files (e.g. structure items)	.DEP
Freely definable tables	.TAB
Pallets	.P
Turning tools	.TRN
<b>Texts as</b>	
ASCII files	.A
Protocol files	.TXT
Help files	.CHM
<b>Drawing data as</b>	
ASCII files	.DXF

When you write a part program on the TNC, you must first enter a program name. The TNC saves the program to the hard disk as a file with the same name. The TNC can also save texts and tables as files.

The TNC provides a special file management window in which you can easily find and manage your files. Here you can call, copy, rename and erase files.

You can manage an almost unlimited number of files with the TNC. The available memory is at least **21 GB**. A single NC program can be up to **2 GB** in size.



Depending on the setting, the TNC generates a backup file (\*.bak) after editing and saving of NC programs. This can reduce the memory space available to you.

### File names

When you store programs, tables and texts as files, the TNC adds an extension to the file name, separated by a point. This extension indicates the file type.

File name	File type
PROG20	.H

File names should not exceed 25 characters, otherwise the TNC cannot display the entire file name.

File names on the TNC must comply with this standard: The Open Group Base Specifications Issue 6 IEEE Std 1003.1, 2004 Edition (Posix-Standard). Accordingly, the file names may include the characters below:

A B C D E F G H I J K L M N O P Q R S T U V W X Y Z a b c d e f g  
h i j k l m n o p q r s t u v w x y z 0 1 2 3 4 5 6 7 8 9 . \_ -

You should not use any other characters in file names in order to prevent any file transfer problems.



The maximum limit for the path and file name together is 82 characters, See "Paths", page 109.

## Programming: Fundamentals, file management

### 3.3 File manager: Fundamentals

#### Displaying externally generated files on the TNC

The TNC features several additional tools which you can use to display the files shown in the table below. Some of the files can also be edited.

File types	Type
PDF files	pdf
Excel tables	xls
	csv
Internet files	html
Text files	txt
	ini
Graphics files	bmp
	gif
	jpg
	png

For further information about displaying and editing the listed file types: See page 121

#### Data Backup

We recommend saving newly written programs and files on a PC at regular intervals.

The TNCremoNT data transmission freeware from HEIDENHAIN is a simple and convenient method for backing up data stored on the TNC.

You additionally need a data medium on which all machine-specific data, such as the PLC program, machine parameters, etc., are stored. Ask your machine manufacturer for assistance, if necessary.



Saving the contents of the entire hard disk (2GB) can take up to several hours. In this case, it is a good idea to save the data outside of work hours, e.g. during the night.

Take the time occasionally to delete any unneeded files so that the TNC always has enough hard-disk space for system files (such as the tool table).



Depending on operating conditions (e.g., vibration load), hard disks generally have a higher failure rate after three to five years of service. HEIDENHAIN therefore recommends having the hard disk inspected after three to five years.

## 3.4 Working with the file manager

### Directories

To ensure that you can easily find your files, we recommend that you organize your hard disk into directories. You can divide a directory into further directories, which are called subdirectories. With the `-/+` key or `ENT` you can show or hide the subdirectories.

### Paths

A path indicates the drive and all directories and subdirectories under which a file is saved. The individual names are separated by a backslash `\`.



The path, including all drive characters, directory and the file name, including the extension, must not exceed 82 characters!


Drive designations must not include more than 8 uppercase letters.

### Example

The directory **AUFTR1** was created on the **TNC:\** drive. Then, in the **AUFTR1** directory, the subdirectory **NCPROG** was created and the part program **PROG1.H** was copied into it. The part program now has the following path:

**TNC:\AUFTR1\NCPROG\PROG1.H**



















The chart at right illustrates an example of a directory display with different paths.



## Programming: Fundamentals, file management

### 3.4 Working with the file manager

#### Overview: Functions of the file manager

Function	Soft key	Page
Copy a single file		113
Display a specific file type		112
Create new file		113
Display the last 10 files that were selected		116
Delete a file or directory		117
Tag a file		118
Rename a file		119
Protect a file against editing and erasure		120
Cancel file protection		120
Importing tool tables		183
Manage network drives		128
Select the editor		120
Sort files by properties		119
Copy a directory		115
Delete directory with all its subdirectories		
Display all the directories of a particular drive		
Rename a directory		
Create a new directory		


## Calling the file manager



PGM  
MGT

- ▶ Press the PGM MGT key: The TNC displays the file management window (see illustration for default setting). If the TNC displays a different screen layout, press the WINDOW soft key

The narrow window on the left shows the available drives and directories. Drives designate devices with which data are stored or transferred. One drive is the hard disk of the TNC. Other drives are the interfaces (RS232, Ethernet), which can be used, for example, for connecting a personal computer. A directory is always identified by a folder symbol to the left and the directory name to the right. Subdirectories are shown to the right of and below their parent directories. A triangle in front of the folder symbol indicates that there are further subdirectories, which can be shown with the  $-/+$  or ENT keys.

The wide window on the right shows you all files that are stored in the selected directory. Each file is shown with additional information, illustrated in the table below.



Display	Meaning
<b>File name</b>	Name with max. 25 characters
<b>Type</b>	File type
<b>Bytes</b>	File size in bytes
<b>Status</b>	File properties:
E	Program is selected in the Programming mode of operation
S	Program is selected in the Test Run mode of operation
M	Program is selected in a Program Run mode of operation
	File is protected against erasing and editing
	File is protected against erasing and editing, because it is being run
<b>Date</b>	Date that the file was last edited
<b>Time</b>	Time that the file was last edited

## Programming: Fundamentals, file management

### 3.4 Working with the file manager

#### Selecting drives, directories and files



- ▶ Call the file manager

Use the arrow keys or the soft keys to move the highlight to the desired position on the screen:



- ▶ Moves the highlight from the left to the right window, and vice versa



- ▶ Moves the highlight up and down within a window



- ▶ Moves the highlight one page up or down within a window



#### Step 1: Select drive

- ▶ Move the highlight to the desired drive in the left window



- ▶ Select a drive: Press the SELECT soft key, or



- ▶ Press the ENT key


#### Step 2: Select a directory

- ▶ Move the highlight to the desired directory in the left-hand window—the right-hand window automatically shows all files stored in the highlighted directory

#### Step 3: Select a file



- ▶ Press the SELECT TYPE soft key




- ▶ Press the soft key for the desired file type, or



- ▶ to display all files: Press the SHOW ALL soft key; or

- ▶ Move the highlight to the desired file in the right window



- ▶ Press the SELECT soft key, or



- ▶ Press the ENT key

The TNC opens the selected file in the operating mode from which you called the file manager



## Creating a new directory


Move the highlight in the left window to the directory in which you want to create a subdirectory

- ▶ **NEW** (enter the new directory name)




- ▶ Press the **ENT** key

### DIRECTORY \CREATE NEW ?



- ▶ Press the **YES** soft key to confirm, or



- ▶ the **NO** soft key to abort.

## Creating a new file

- ▶ Select the directory in which you wish to create the new file.



- ▶ **NEW** Enter the new file name with the file extension, and confirm with **ENT**, or




- ▶ Open a dialog to create a new file, **NEW** Enter the new file name with the file extension, and confirm with **ENT**.



## Copying a single file


- ▶ Move the highlight to the file you wish to copy



- ▶ Press the **COPY** soft key: Select the copying function. The TNC opens a pop-up window



- ▶ Enter the name of the destination file and confirm your entry with the **ENT** key or the **OK** soft key: The TNC copies the file into the active directory or into the selected target directory. The original file is retained, or



- ▶ Press the Target Directory soft key to call a pop-up window in which you select the target directory by pressing the **ENT** key or the **OK** soft key: the TNC copies the file to the selected directory. The original file is retained.



When the copying process has been started with **ENT** or the **OK** soft key, the TNC displays a pop-up window with a progress indicator.

### 3.4 Working with the file manager

#### Copying files into another directory

- ▶ Select a screen layout with two equally sized windows
- ▶ To display directories in both windows, press the **PATH** soft key

In the right window

- ▶ Move the highlight to the directory into which you wish to copy the files, and display the files in this directory with the **ENT** key

In the left window

- ▶ Select the directory with the files that you wish to copy and press ENT to display the files in this directory.



- ▶ Call the file tagging functions



- ▶ Move the highlight to the file you want to copy and tag it. You can tag several files in this way, if desired



- ▶ Copy the tagged files into the target directory

Additional tagging functions: See "Tagging files", page 118.

If you have tagged files in both the left and right windows, the TNC copies from the directory in which the highlight is located.

#### Overwriting files

If you copy files into a directory in which other files are stored under the same name, the TNC will ask whether the files in the target directory should be overwritten:

- ▶ To overwrite all files ("Existing files" check box selected), press the OK soft key, or
- ▶ Press the CANCEL soft key if no file is to be overwritten

If you wish to overwrite a protected file, you need to select the "Protected files" check box or cancel the copying process.

## Copying a table

### Importing lines to a table

If you are copying a table into an existing table, you can overwrite individual lines with the **REPLACE FIELDS** soft key. Prerequisites:

- The target table must already exist
- The file to be copied must only contain the lines you want to replace
- Both tables must have the same file extension



The **REPLACE FIELDS** function is used to overwrite lines in the target table. To avoid losing data, create a backup copy of the original table.

### Example

With a tool presetter you have measured the length and radius of ten new tools. The tool presetter then generates the TOOL\_Import.T tool table with 10 lines (for the 10 tools).

- ▶ Copy this table from the external data medium to any directory
- ▶ Copy the externally created table to the existing table using the TNC file management. The TNC asks if you wish to overwrite the existing TOOL.T tool table:
- ▶ If you press the **YES** soft key, the TNC will completely overwrite the current TOOL.T tool table. After the copying process the new TOOL.T table consists of 10 lines.
- ▶ Or press the **REPLACE FIELDS** soft key for the TNC to overwrite the 10 lines in the TOOL.T file. The data of the other lines is not changed.

### Extracting lines from a table

You can select one or more lines in a table and save them in a separate table.

- ▶ Open the table from which you want to copy lines
- ▶ Use the arrow keys to select the first line to be copied
- ▶ Press the **MORE FUNCTIONS** soft key
- ▶ Press the **TAG** soft key
- ▶ Select additional lines, if required
- ▶ Press the **SAVE AS** soft key
- ▶ Enter a name for the table in which the selected lines are to be saved

### Copying a directory

- ▶ Move the highlight in the right window onto the directory you want to copy
- ▶ Press the **copy** soft key: the TNC opens the window for selecting the target directory
- ▶ Select the target directory and confirm with **ENT** or the **OK** soft key: The TNC copies the selected directory and all its subdirectories to the selected target directory

## Programming: Fundamentals, file management

### 3.4 Working with the file manager

#### Choosing one of the last files selected



- ▶ Call the file manager




- ▶ To display the 10 files last selected: Press the **LAST FILES** soft key.

Use the arrow keys to move the highlight to the file you wish to select:




- ▶ Moves the highlight up and down within a window



- ▶ To select a file: Press the **OK** soft key, or...



- ▶ Press the **ENT** key



## Deleting a file

**Caution: Data may be lost!**

Once you delete files they cannot be restored!

- ▶ Move the highlight to the file you want to delete



- ▶ To select the erasing function: Press the **DELETE** soft key. The TNC asks whether you really want to delete the file
- ▶ To confirm deletion: press the **OK** soft key, or
- ▶ To interrupt deletion: Press the **CANCEL** soft key

## Deleting a directory

**Caution: Data may be lost!**

Once you delete files they cannot be restored!

- ▶ Move the highlight to the directory you want to delete








- ▶ To select the erasing function: Press the **DELETE** soft key. The TNC inquires whether you really intend to delete the directory and all its subdirectories and files
- ▶ To confirm deletion: Press the **OK** soft key, or...
- ▶ To interrupt deletion: Press the **CANCEL** soft key

## Programming: Fundamentals, file management

### 3.4 Working with the file manager

#### Tagging files

Tagging function	Soft key
Tag a single file	
Tag all files in the directory	
Untag a single file	
Untag all files	
Copy all tagged files	

Some functions, such as copying or erasing files, can not only be used for individual files, but also for several files at once. To tag several files, proceed as follows:

- ▶ Move the highlight to the first file



- ▶ To display the tagging functions: Press the **TAG** soft key




- ▶ To tag a file: Press the **TAG FILE** soft key



- ▶ Move the highlight to the next file you wish to tag: Only works via soft keys. Do not use the arrow keys!



- ▶ To tag another file: Press the **TAG FILE** soft key, etc.



- ▶ To copy tagged files: Press the **COPY TAG** soft key, or ...




- ▶ To delete tagged files: Press **END** to end the marking function, and then **DELETE** to delete the tagged files.



## Renaming a file

- ▶ Move the highlight to the file you wish to rename



- ▶ Select the renaming function
- ▶ Enter the new file name; the file type cannot be changed
- ▶ To rename: Press the **OK** soft key or the **ENT** key

## Sorting files

- ▶ Select the folder in which you wish to sort the files



- ▶ Select the SORT soft key
- ▶ Select the soft key with the corresponding display criterion


## Programming: Fundamentals, file management

### 3.4 Working with the file manager

#### Additional functions

##### Protecting a file / Canceling file protection

- ▶ Move the highlight to the file you want to protect



- ▶ To select additional functions: Press the **MORE FUNCTIONS** soft key




- ▶ Activate file protection: press the **PROTECT** soft key. The file now has status P.




- ▶ To cancel the file protection: Press the **UNPROTECT** soft key

##### Selecting the editor

- ▶ Move the highlight in the right window onto the file you want to open




- ▶ To select additional functions: Press the **MORE FUNCTIONS** soft key



- ▶ To select the editor with which to open the selected file, press the SELECT EDITOR soft key
- ▶ Mark the desired editor
- ▶ Press the OK soft key to open the file

##### Connecting/removing a USB device

- ▶ Move the highlight to the left window



- ▶ To select additional functions: Press the **MORE FUNCTIONS** soft key



- ▶ Shift the soft-key row

- ▶ Search for a USB device

- ▶ In order to remove the USB device, move the highlight to the USB device



- ▶ Remove the USB device

More information: See "USB devices on the TNC", page 129.



## Additional tools for management of external file types

The additional tools enable you to display or edit various externally created file types on the TNC.

File types	Description
PDF files (pdf)	page 121
Excel spreadsheets (xls, csv)	page 122
Internet files (htm, html)	page 122
ZIP archives (zip)	page 123
Text files (ASCII files, e.g. txt, ini)	page 124
Graphics files (bmp, jpg, gif, png)	page 125



If you transfer files from a PC to the control by means of TNCremoNT, you must have entered the file name extension pdf, xls, zip, bmp gif, jpg and png in the list of the file types for binary transmission (menu item **Extras >Configuration >Mode** in TNCremoNT).

## Displaying PDF files

To open PDF files directly on the TNC, proceed as follows:


- ▶ Call the file manager
- ▶ Select the directory in which the PDF file is saved
- ▶ Move the highlight to the PDF file
- ▶ Press ENT: The TNC opens the PDF file in its own application using the **PDF viewer** additional tool

With the key combination ALT+TAB you can always return to the TNC user interface while leaving the PDF file open. Alternatively, you can also click the corresponding symbol in the taskbar to switch back to the TNC interface.

If you position the mouse pointer over a button, a brief tooltip explaining the function of this button will be displayed. More information on how to use the **PDF viewer** is provided under **Help**.

To exit the **PDF viewer**, proceed as follows:

- ▶ Use the mouse to select the **File** menu item
- ▶ Select the menu item **Close**: The TNC returns to the file manager



## Programming: Fundamentals, file management

### 3.4 Working with the file manager

#### Displaying and editing Excel files

Proceed as follows to open and edit Excel files with the extension **xls** or **csv** directly on the TNC:

- PGM MGT
- ▶ Call the file manager
  - ▶ Select the directory in which the Excel file is saved
  - ▶ Move the highlight to the Excel file
- ENT
- ▶ Press ENT: The TNC opens the Excel file in its own application using the **Gnumeric** additional tool

With the key combination ALT+TAB you can always return to the TNC user interface while leaving the Excel file open. Alternatively, you can also click the corresponding symbol in the taskbar to switch back to the TNC interface.

If you position the mouse pointer over a button, a brief tooltip explaining the function of this button will be displayed. More information on how to use the **Gnumeric** function is provided under **Help**.

To exit **Gnumeric**, proceed as follows:

- ▶ Use the mouse to select the **File** menu item
- ▶ Select the menu item **Quit**: The TNC returns to the file manager

#### Displaying Internet files

To open Internet files with the extension **htm** or **html** directly on the TNC, proceed as follows:



- PGM MGT
- ▶ Call the file manager
  - ▶ Select the directory in which the Internet file is saved
  - ▶ Move the highlight to the Internet file
- ENT
- ▶ Press ENT: The TNC opens the Internet file in its own application using the **Mozilla Firefox** additional tool

With the key combination ALT+TAB you can always return to the TNC user interface while leaving the PDF file open. Alternatively, you can also click the corresponding symbol in the taskbar to switch back to the TNC interface.

If you position the mouse pointer over a button, a brief tooltip explaining the function of this button will be displayed. More information on how to use **Mozilla Firefox** is provided under **Help**.

To exit **Mozilla Firefox**, proceed as follows:

- ▶ Use the mouse to select the **File** menu item
- ▶ Select the menu item **Quit**: The TNC returns to the file manager



### Working with ZIP archives

To open ZIP archives with the extension **zip** directly on the TNC, proceed as follows:

PGM  
MGT

- ▶ Call the file manager
- ▶ Select the directory in which the archive file is saved
- ▶ Move the highlight to the archive file
- ▶ Press ENT: The TNC opens the archive file in its own application using the **Xarchiver** additional tool

ENT

With the key combination ALT+TAB you can always return to the TNC user interface while leaving the archive file open. Alternatively, you can also click the corresponding symbol in the taskbar to switch back to the TNC interface.


If you position the mouse pointer over a button, a brief tooltip explaining the function of this button will be displayed. More information on how to use the **Xarchiver** function is provided under **Help**.



Please note that the TNC does not carry out any binary-to-ASCII conversion or vice versa when compressing or decompressing NC programs and NC tables. When such files are transferred to TNC controls using other software versions, the TNC may not be able to read them.

To exit **Xarchiver**, proceed as follows:

- ▶ Use the mouse to select the **Archive** menu item
- ▶ Select the menu item **Quit**: The TNC returns to the file manager



## Programming: Fundamentals, file management

### 3.4 Working with the file manager

#### Displaying and editing text files

To open and edit text files (ASCII files, e.g. with the extension **txt** or **ini**), proceed as follows:

PGM  
MGT

- ▶ Call the file manager
- ▶ Select the drive and the directory in which the text file is saved
- ▶ Move the highlight to the text file
- ▶ Press the ENT key: The TNC displays a window for selection of the editor
- ▶ Press ENT to select the **mouse pad** application. Alternatively, you can also open the TXT files with the TNC's internal text editor
- ▶ The TNC opens the text file in its own application using the **Mousepad** additional tool

ENT




If you open an H or I file on an external drive and save it on the TNC drive using **Mousepad**, the programs are not converted automatically to the internal control format. Programs that are saved in this way cannot be run or opened with the TNC editor.

With the key combination ALT+TAB you can always return to the TNC user interface while leaving the text file open. Alternatively, you can also click the corresponding symbol in the taskbar to switch back to the TNC interface.

The shortcuts you are familiar with from Windows, which you can use to edit texts quickly (CTRL+C, CTRL+V,...), are available within Mousepad.

To exit **Mousepad**, proceed as follows:

- ▶ Use the mouse to select the **File** menu item
- ▶ Select the menu item **Quit**: The TNC returns to the file manager



### Displaying graphic files

To open graphics files with the extension bmp, gif, jpg or png directly on the TNC, proceed as follows:

- PGM  
MGT
- ▶ Call the file manager
  - ▶ Select the directory in which the graphics file is saved
  - ▶ Move the highlight to the graphics file
  - ▶ Press the ENT key The TNC opens the text file in its own application using the **Mousepad** additional tool
- ENT

With the key combination ALT+TAB you can always return to the TNC user interface while leaving the graphics file open. Alternatively, you can also click the corresponding symbol in the taskbar to switch back to the TNC interface.

More information on how to use the **ristretto** function is provided under **Help**.

To exit **ristretto**, proceed as follows:

- ▶ Use the mouse to select the **File** menu item
- ▶ Select the menu item **Quit**: The TNC returns to the file manager



## Programming: Fundamentals, file management

### 3.4 Working with the file manager

#### Data transfer to/from an external data medium



Before you can transfer data to an external data medium, you must set up the data interface (See "Setting up data interfaces", page 561).

Depending on the data transfer software you use, problems can occur occasionally when you transmit data over a serial interface. They can be overcome by repeating the transmission.

PGM  
MGT

- ▶ Call the file manager



- ▶ Select the screen layout for the data transfer: Press the WINDOW key. In the left half of the screen the TNC shows all files in the current directory. In the right half of the screen it shows all files saved in the root directory (TNC:\).


Use the arrow keys to highlight the file(s) that you want to transfer:



- ▶ Moves the highlight up and down within a window




- ▶ Moves the highlight from the right to the left window, and vice versa




If you wish to copy from the TNC to the external data medium, move the highlight in the left window to the file to be transferred.

If you wish to copy from the external data medium to the TNC, move the highlight in the right window to the file to be transferred.



- ▶ To select another drive or directory: Press the soft key for choosing the directory. The TNC opens a pop-up window. Select the desired directory in the pop-up window by using the arrow keys and the ENT key.



- ▶ Transmitting individual files: Press the COPY soft key, or...



- ▶ To transfer several files: To transfer several files, press the TAG soft key (in the second soft-key row, see "Tagging files", page 111)

- ▶ Confirm with the OK or with the ENT key. A status window appears on the TNC, informing about the copying progress, or



- ▶ To end data transfer, move the highlight into left window and then press the WINDOW soft key. The standard file manager window is displayed again



To select another directory in the split-screen display, press the **SHOW TREE** soft key. If you press the **SHOW FILES** soft key, the TNC shows the content of the selected directory!

## 3.4 Working with the file manager


## The TNC in a network



To connect the Ethernet card to your network, See "Ethernet interface", page 567.

The TNC logs error messages during network operation, See "Ethernet interface", page 567.

If the TNC is connected to a network, the directory window displays additional drives (see figure). All the functions described above (selecting a drive, copying files, etc.) also apply to network drives, provided that you have been granted the corresponding rights.



## Connecting and disconnecting a network drive

PGM MGT

- ▶ Call the file manager: Press the **PGM MGT** soft key and if necessary press the **WINDOW** key to set up the screen as it is shown at upper right

NET

- ▶ To select the network settings: Press the **NETWORK** soft key (second soft key row).
- ▶ To manage the network drives: Press the **DEFINE NETWORK CONNECTN.** soft key. In a window the TNC shows the network drives available for access. With the soft keys described below you can define the connection for each drive.

Function	Soft key
Establish the network connection. If the connection is active, the TNC marks the <b>Mount</b> column.	<b>Connect</b>
Disconnect the network connection	<b>Unmount</b>
Automatically establish network connection whenever the TNC is switched on. The TNC marks the <b>Auto</b> column if the connection is established automatically	<b>Auto</b>
Set up new network connection	<b>Add</b>
Delete existing network connection	<b>Remove</b>
Copy network connection	<b>Copy</b>
Edit network connection	<b>Machining</b>
Clear status window	<b>Clear</b>



## USB devices on the TNC

Backing up data from or loading onto the TNC is especially easy with USB devices. The TNC supports the following USB block devices:

- Floppy disk drives with FAT/VFAT file system
- Memory sticks with the FAT/VFAT file system
- Hard disks with the FAT/VFAT file system
- CD-ROM drives with the Joliet (ISO 9660) file system

The TNC automatically detects these types of USB devices when connected. The TNC does not support USB devices with other file systems (such as NTFS). The TNC displays the **USB: TNC does not support device** error message when such a device is connected.



The TNC also displays the **USB: TNC does not support device** error message if you connect a USB hub. In this case, simply acknowledge the message with the CE key.

In theory, you should be able to connect all USB devices with the file systems mentioned above to the TNC. It may happen that a USB device is not identified correctly by the control. In such cases, use another USB device.

The USB devices appear as separate drives in the directory tree, so you can use the file-management functions described in the earlier chapters correspondingly.










Your machine tool builder can assign permanent names for USB devices. Refer to your machine manual.


## Programming: Fundamentals, file management

### 3.4 Working with the file manager

To remove a USB device, proceed as follows:

-  ▶ Call the file manager: Press the **PGM MGT** key
-  ▶ Select the left window with the arrow key
-  ▶ Use the arrow keys to select the USB device to be removed
-  ▶ Scroll through the soft-key row
-  ▶ Select additional functions
-  ▶ Select the function for removing USB devices. The TNC removes the USB device from the directory tree
-  ▶ Exit the file manager

In order to re-establish a connection with a USB device that has been removed, press the following soft key:

-  ▶ Select the function for reconnection of USB devices

# 4

**Programming:  
Programming aids**

## Programming: Programming aids

### 4.1 Adding comments

#### 4.1 Adding comments

##### Application


You can add comments to a part program to explain program steps or make general notes.



If the TNC cannot show the entire comment on the screen, the >> sign is displayed.

The last character in a comment block must not have any tilde (~).

You have the following possibilities for adding comments.



##### Entering comments during programming

- ▶ Enter the data for a program block, then press the semicolon key ";" on the alphabetic keyboard—the TNC displays the dialog prompt **COMMENT?**
- ▶ Enter your comment and conclude the block by pressing the **END** key






##### Inserting comments after program entry

- ▶ Select the block to which a comment is to be added
- ▶ Select the last word in the block with the right arrow key: Press the semicolon key on the ASCII keyboard: The TNC displays the dialog prompt **Comment?**
- ▶ Enter your comment and conclude the block by pressing the **END** key

##### Entering a comment in a separate block

- ▶ Select the block after which the comment is to be inserted
- ▶ Initiate the programming dialog with the semicolon key (;) on the alphabetic keyboard
- ▶ Enter your comment and conclude the block by pressing the **END** key

## Functions for editing of the comment

Function	Soft key
Jump to beginning of comment	
Jump to end of comment	
Jump to the beginning of a word. Words must be separated by a space	
Jump to the end of a word. Words must be separated by a space	
Switch between insert mode and overwrite mode	

## 4.2 Display of NC Programs

### 4.2 Display of NC Programs

#### Syntax highlighting


The TNC displays syntax elements with various colors according to their meaning. Programs are made more legible and clear with color-highlighting.

#### Color highlighting of syntax elements

Use	Color
Standard color	Black
Display of comments	Green
Display of numerical values	Blue
Block number	Purple

#### Scrollbar

You can move the screen content with the mouse via the scrollbar on the right edge of the program window. In addition, the size and position of the scrollbar indicates program length and cursor position.



## 4.3 Structuring programs


### Definition and applications

This TNC function enables you to comment part programs in structuring blocks. Structuring blocks are short texts with up to 37 characters and are used as comments or headlines for the subsequent program lines.



With the aid of appropriate structuring blocks, you can organize long and complex programs in a clear and comprehensible manner.

This function is particularly convenient if you want to change the program later. Structuring blocks can be inserted into the part program at any point. They can also be displayed in a separate window, and edited or added to, as desired.



The inserted structure items are managed by the TNC in a separate file (extension: .SEC.DEF). This speeds navigation in the program structure window.



### Displaying the program structure window / Changing the active window

- 
  - ▶ To display the program structure window, select the screen display **PGM + SECTS**
- 
  - ▶ To change the active window, press the **soft** key.

### Inserting a structuring block in the (left) program window

- ▶ Select the block after which the structuring block is to be inserted
- 
  - ▶ Press the **INSERT SECTION** soft key or the \* key on the ASCII keyboard
  - ▶ Enter the structuring text with the alphabetic keyboard
- 
  - ▶ If necessary, change the structure depth with the **soft** key

### Selecting blocks in the program structure window

If you are scrolling through the program structure window block by block, the TNC at the same time automatically moves the corresponding NC blocks in the program window. This way you can quickly skip large program sections.

## 4.4 Calculator


### 4.4 Calculator

#### Operation

The TNC features an integrated calculator with the basic mathematical functions.

- ▶ Use the **CALC** key to show and hide the on-line calculator
- ▶ Selecting the calculator: The calculator is operated with short commands via soft key or through the alphabetic keyboard.

Mathematical function	Command (key)
Addition	+
Subtraction	-
Multiplication	*
Division	/
Calculations in parentheses	( )
Arc cosine	ARC
Sine	SIN
Cosine	COS
Tangent	TAN
Powers of values	X^Y
Square root	SQRT
Inversion	1/x
pi (3.14159265359)	PI
Add value to buffer memory	M+
Save the value to buffer memory	MS
Recall from buffer memory	MR
Delete buffer memory contents	MC
Natural logarithm	LN
Logarithm	LOG
Exponential function	e^x
Check the algebraic sign	SGN
Form the absolute value	ABS





Mathematical function	Command (key)
Truncate decimal places	INT
Truncate integers	FRAC
Modulus operator	MOD
Select view	View
Delete value	CE
Unit of measure	MM or INCH
Display mode for angle values	DEG (degree) or RAD (radian measure)
Display mode of the numerical value	DEC (decimal) or HEX (hexadecimal)

### Transferring the calculated value into the program

- ▶ Use the arrow keys to select the word into which the calculated value is to be transferred
- ▶ Superimpose the on-line calculator by pressing the **CALC** key and perform the desired calculation
- ▶ Press the actual-position-capture key or the APPLY VALUE soft key for the TNC to transfer the calculated value into the active input box and to close the calculator.










You can also transfer values from a program into the calculator. When you press the GET CURRENT VALUE soft key of the GOTO key, the TNC transfers the value from the active input field to the calculator. The calculator remains in effect even after a change in operating modes. Press the END soft key to close the calculator.

# 4 Programming: Programming aids

## 4.4 Calculator

### Functions in the pocket calculator

Function	Soft key
Load the value of the respective axis position from the additional status display (position display 2) into the calculator	
Load the numerical value from the active input field into the pocket calculator	
Load the numerical value from the pocket calculator field into the active input field	
Copy the numerical value from the pocket calculator	
Insert the copied numerical value into the pocket calculator	
Open the cutting data calculator	
Position the calculator in the center	



You can also shift the calculator with the arrow keys on your keyboard. If you have connected a mouse you can also position the calculator with this.

## 4.5 Cutting data calculator


### Application

With the cutting data calculator you can calculate the spindle speed and the feed rate for a machine process. Then you can load the calculated values into an opened feed-rate or spindle-speed dialog box in the NC program.



Do not use the cutting data calculator if you have programmed the **M136** function. With the **M136** function the TNC move the tool at the feed rate **F** in millimeters/spindle revolution as specified in the program, but the cutting data calculator always calculates feed rate in mm per minute.

You cannot perform any cutting data calculation in turning mode with the cutting data calculator because the feed rate and spindle speed data are different in turning mode from milling mode. During turning, feed rates are usually defined in mm per revolution (M136), but the cutting data calculator always calculates in mm per minute. In addition, the radius in the cutting data calculator is with respect to the tool, but turning operations need the tool diameter.



To open the cutting data calculator, press the CUTTING DATA CALCULATOR soft key. The TNC shows the soft key if you

- open the pocket calculator (CALC key)
- open the dialog field for spindle speed input in the T block
- open the dialog field for feed rate input in positioning blocks or cycles
- enter a feed rate in manual operation (F soft key)
- enter a spindle speed in manual operation (S soft key)

The cutting data calculator is displayed with different input fields depending on whether you calculate a spindle speed or a feed rate:

#### Window or spindle speed calculation:

Code letter	Meaning
R:	Tool radius (mm)
VC:	Cutting speed (m/min)
S=	Result for spindle speed (rev/min)

## Programming: Programming aids

### 4.5 Cutting data calculator

#### Window for feed rate calculation:





Code letter	Meaning
S:	Spindle speed (rpm)
Z:	Number of teeth on the tool (n)
FZ:	Feed per tooth (mm/tooth)
FU:	Feed per revolution (mm/rev)
F=	Result for feed rate (mm/min)



You can also calculate the feed rate in the T block and automatically transfer it to the subsequent positioning blocks and cycles. For feed rate input in positioning blocks or cycles, select the soft key F AUTO. The TNC then uses the feed rate defined in the T block. If you have to change the feed rate later, you only need to adjust the feed-rate value in the T block.

#### Functions in the cutting data calculator:

Function	Soft key
Load the spindle speed from the cutting data calculator form into an open dialog field.	
Load the feed rate from the cutting data calculator form into an open dialog field.	
Load the cutting speed from the cutting data calculator form into an open dialog field.	
Load the feed per tooth from the cutting data calculator form into an open dialog field.	
Load the feed per revolution from the cutting data calculator form into an open dialog field.	
Load the tool radius into the cutting data calculator form	
Load the spindle speed from the opened dialog form into the cutting data calculator form	
Load the feed rate from the opened dialog form into the cutting data calculator form	
Load the feed per revolution from the opened dialog form into the cutting data calculator form	
Load the feed per tooth from the opened dialog form into the cutting data calculator form	
Load the value from an opened dialog form into the cutting data calculator form	
Switch to the pocket calculator	

<b>Function</b>	<b>Soft key</b>
Move the cutting data calculator in the direction of the arrow	
Position the cutting data calculator in the center	
Use inch values in the cutting data calculator	
Close the cutting data calculator	

## Programming: Programming aids


### 4.6 Programming graphics

#### 4.6 Programming graphics

##### Generate/do not generate graphics during programming

While you are writing the part program, you can have the TNC generate a 2-D pencil-trace graphic of the programmed contour.

- ▶ To switch the screen layout to displaying program blocks to the left and graphics to the right, press the **SPLIT SCREEN** key and the **PGM + GRAPHICS** soft key.



- ▶ Set the **AUTO DRAW** soft key to **EIN**. While you are entering the program lines, the TNC generates each path contour you program in the graphics window in the right screen half

If you do not wish to have the TNC generate graphics during programming, set the **AUTO DRAW** soft key to **OFF**.

Even when **AUTO DRAW ON** is active, graphics are not generated for program section repeats.

##### Generating a graphic for an existing program


- ▶ Use the arrow keys to select the block up to which you want the graphic to be generated, or press **GOTO** and enter the desired block number



- ▶ To generate graphics, press the **RESET + START** soft key.

##### Additional functions:


Function	Soft key
Generate a complete graphic	
Generate programming graphic blockwise	
Generate a complete graphic or complete it after <b>RESET + START</b>	
Stop the programming graphics. This soft key only appears while the TNC is generating the interactive graphics	



### Block number display ON/OFF



- ▶ Shift the soft-key row: See picture



- ▶ To show block numbers: Set the **SHOW OMIT BLOCK NO.** soft key to **SHOW**
- ▶ To omit block numbers: Set the **SHOW OMIT BLOCK NO.** soft key to **OMIT**

### Erasing the graphic



- ▶ Shift the soft-key row: See picture




- ▶ To erase the graphic: Press the **CLEAR GRAPHIC** soft key.

### Showing grid lines



- ▶ Shift the soft-key row: See picture



- ▶ Show grid lines: Press the **"Show grid lines"** soft key




## 4.6 Programming graphics

### Magnification or reduction of details

You can select the graphics display by selecting a detail with the frame overlay. You can now magnify or reduce the selected detail.


- ▶ Select the soft-key row for detail magnification/reduction (second row, see figure)


The following functions are available:

Function	Soft key
Show and move the frame overlay. Press and hold the desired soft key to move the frame overlay	
Shrink the frame overlay – Press soft key for shrinking	
Enlarge the frame overlay – Press soft key	

- ▶ Confirm the selected area with the **WINDOW DETAIL** soft key

The **RESET WORKPIECE BLANK** soft key is used to restore the original section.


 If you have connected a mouse you can draw a frame overlay with the left mouse button for the area to be magnified. You can also use the mouse to magnify or shrink the graphics.





## 4.7 Error messages

### Display of errors

The TNC generates error messages when it detects problems such as:

- Incorrect data input
- Logical errors in the program
- Contour elements that are impossible to machine
- Incorrect use of touch probes

When an error occurs, it is displayed in red type in the header. Long and multi-line error messages are displayed in abbreviated form. If an error occurs in the background mode, the word "Error" is displayed in red type. Complete information on all pending errors is shown in the error window.

If a rare "processor check error" should occur, the TNC automatically opens the error window. You cannot remove such an error. Shut down the system and restart the TNC.

The error message is displayed in the header until it is cleared or replaced by a higher-priority error.

An error message that contains a program block number was caused by an error in the indicated block or in the preceding block.

### Open the error window



- ▶ Press the **ERR** key. The TNC opens the error window and displays all accumulated error messages.

### Closing the error window



- ▶ Press the **END** soft key—or



- ▶ Press the **ERR** key. The TNC closes the error window.

## Programming: Programming aids

### 4.7 Error messages


#### Detailed error messages

The TNC displays possible causes of the error and suggestions for solving the problem:

- ▶ Open the error window

MORE  
INFO

- ▶ Information on error causes and remedies: Position the highlight on the error message and press the **MORE INFO** soft key. The TNC opens a window with information on the error cause and corrective action.
- ▶ Exit Info: Press the **MORE INFO** soft key again



#### INTERNAL INFO soft key

The INTERNAL INFO soft key supplies information on the error message. This information is only required if servicing is needed.


- ▶ Open the error window.

INTERNAL  
INFO

- ▶ Detailed information about the error message: Position the highlight on the error message and press the **INTERNAL INFO** soft key. The TNC opens a window with internal information about the error
- ▶ To exit Details, press the **INTERNAL INFO** soft key again.

## Clearing errors



### Clearing errors outside of the error window

- ▶  Clear the error/message in the header: Press the CE key



In some operating modes (such as the Editing mode), the CE button cannot be used to clear the error, since the button is reserved for other functions.

### Clearing more than one error





- ▶ Open the error window
  - ▶  To delete an individual error: Position the highlight on the error message and press the DELETE soft key.
  - ▶  To delete all error messages: Press the DELETE ALL soft key.



If the cause of the error has not been removed, the error message cannot be deleted. In this case, the error message remains in the window.

## Error log

The TNC stores errors and important events (e.g. system startup) in an error log. The capacity of the error log is limited. If the log is full, the TNC uses a second file. If this is also full, the first error log is deleted and written to again, and so on. To view the error history, switch between **CURRENT FILE** and **PREVIOUS FILE**.





- ▶ Open the error window.
  - ▶  Press the LOG FILES soft key.
  - ▶  Open the error log file: Press the ERROR LOG soft key.
  - ▶  If you need the previous log file: Press the **PREVIOUS FILE** soft key.
  - ▶  If you need the current log file: Press the **Current File** soft key.

The oldest entry is at the beginning of the error log file, and the most recent entry is at the end.

## 4.7 Error messages








### Keystroke log

The TNC stores keystrokes and important events (e.g. system startup) in a keystroke log. The capacity of the keystroke log is limited. If the keystroke log is full, the control switches to a second keystroke log. If this second file becomes full, the first keystroke log is cleared and written to again, and so on. To view the keystroke history, switch between **CURRENT FILE** and **PREVIOUS FILE**.

-  ▶ Press the LOG FILES soft key
-  ▶ Open the keystroke log file: Press the **KEYSTROKE LOG FILE** soft key
-  ▶ If you need the previous log file: Press the **PREVIOUS FILE** soft key
-  ▶ If you need the current log file: Press the **Current File** soft key

The TNC saves each key pressed during operation in a keystroke log. The oldest entry is at the beginning, and the most recent entry is at the end of the file.

### Overview of the buttons and soft keys for viewing the log files

Function	Soft key/Keys
Go to beginning of log file	
Go to end of log file	
Current log file	
Previous log file	
Up/down one line	 
Return to main menu	

### Informational texts

After a faulty operation, such as pressing a key without function or entering a value outside of the valid range, the TNC displays a (green) text in the header, informing you that the operation was not correct. The TNC clears this informational text upon the next valid input.

### Saving service files

If necessary, you can save the "Current status of the TNC," and make it available to a service technician for evaluation. A group of service files is saved (error and keystroke log files, as well as other files that contain information about the current status of the machine and the machining).

If you repeat the "Save service files" function with the same file name, the previously saved group of service data files is overwritten. To avoid this, use another file name when you repeat the function.

#### Saving service files

- ▶ Open the error window.



- ▶ Press the LOG FILES soft key.



- ▶ Press the **Save service files** soft key: The TNC opens a pop-up window in which you can enter a name for the service file.



- ▶ Saving service files: Press the **OK** soft key.

## Programming: Programming aids

### 4.7 Error messages

#### Calling the TNCguide help system

You can call the TNC's help system via soft key. Immediately the help system shows you the same error explanation that you receive by pressing the **HELP** soft key.



If your machine manufacturer also provides a help system, the TNC shows an additional **MACHINE MANUFACTURER** soft key with which you can call this separate help system. There you will find further, more detailed information on the error message concerned.



- ▶ Call the help for HEIDENHAIN error messages



- ▶ Call the help for HEIDENHAIN error messages, if available

## 4.8 TNCguide context-sensitive help system

### Application



Before you can use the TNCguide, you need to download the help files from the HEIDENHAIN home page (See "Downloading current help files", page 156).

The **TNCguide** context-sensitive help system includes the user documentation in HTML format. The TNCguide is called with the **HELP** key, and the TNC often immediately displays the information specific to the condition from which the help was called (context-sensitive call). Even if you are editing an NC block and press the HELP key, you are usually brought to the exact place in the documentation that describes the corresponding function.



The TNC always tries to start the TNCguide in the language that you have selected as the conversational language on your TNC. If the files with this language are not yet available on your TNC, it automatically opens the English version.


The following user documentation is available in the TNCguide:

- Conversational Programming User's Manual (**BHBKlartext.chm**)
- DIN/ISO User's Manual (**BHBIso.chm**)
- User's Manual for Cycle Programming (**BHBtchprobe.chm**)
- List of All Error Messages (**errors.chm**)

In addition, the **main.chm** "book" file is available, with the contents of all existing .chm files.



As an option, your machine tool builder can embed machine-specific documentation in the **TNCguide**. These documents then appear as a separate book in the **main.chm** file.



## Programming: Programming aids

### 4.8 TNCguide context-sensitive help system

#### Working with the TNCguide

##### Calling the TNCguide

There are several ways to start the TNCguide:

- ▶ Press the **HELP** key if the TNC is not already showing an error message
- ▶ Click the help symbol at the lower right of the screen beforehand, then click the appropriate soft keys
- ▶ Use the file manager to open a help file (.chm file). The TNC can open any .chm file, even if it is not saved on the TNC's hard disk



If one or more error messages are waiting for your attention, the TNC shows the help directly associated with the error messages. To start the **TNCguide**, you first have to acknowledge all error messages.


When the help system is called on the programming station, the TNC starts the internally defined standard browser (usually the Internet Explorer), or otherwise a browser adapted by HEIDENHAIN.

For many soft keys there is a context-sensitive call through which you can go directly to the description of the soft key's function. This functionality requires using a mouse. Proceed as follows:

- ▶ Select the soft-key row containing the desired soft key
- ▶ Click with the mouse on the help symbol that the TNC displays just above the soft-key row: The mouse pointer turns into a question mark
- ▶ Move the question mark to the soft key for which you want an explanation, and click: The TNC opens the TNCguide. If no specific part of the help is assigned to the selected soft key, the TNC opens the book file **main.chm**, in which you can use the search function or the navigation to find the desired explanation manually

Even if you are editing an NC block, context-sensitive help is available:

- ▶ Select any NC block
- ▶ Use the arrow keys to move the cursor to the block
- ▶ Press the HELP key: The TNC starts the help system and shows a description for the active function (does not apply to miscellaneous functions or cycles that were integrated by your machine tool builder)

















### Navigating in the TNCguide

It's easiest to use the mouse to navigate in the TNCguide. A table of contents appears on the left side of the screen. By clicking the rightward pointing triangle you open subordinate sections, and by clicking the respective entry you open the individual pages. It is operated in the same manner as the Windows Explorer.





Linked text positions (cross references) are shown underlined and in blue. Clicking the link opens the associated page.

Of course you can also operate the TNCguide through keys and soft keys. The following table contains an overview of the corresponding key functions.

Function	Soft key
<ul style="list-style-type: none"> <li>■ If the table of contents at left is active: Select the entry above it or below it</li> </ul>	
<ul style="list-style-type: none"> <li>■ If the text window at right is active: Move the page downward or upward if texts or graphics are not shown completely</li> </ul>	
<ul style="list-style-type: none"> <li>■ If the table of contents at left is active: Open up the table of contents If the branch is at its end, jump into the window at right</li> <li>■ If the text window at right is active: No function</li> </ul>	
<ul style="list-style-type: none"> <li>■ If the table of contents at left is active: Close the table of contents</li> <li>■ If the text window at right is active: No function</li> </ul>	
<ul style="list-style-type: none"> <li>■ If the table of contents at left is active: Use the cursor key to show the selected page</li> <li>■ If the text window at right is active: If the cursor is on a link, jump to the linked page</li> </ul>	
<ul style="list-style-type: none"> <li>■ If the table of contents at left is active: Switch the tab between the display of the table of contents, display of the subject index, and the full-text search function and switching to the screen half at right</li> <li>■ If the text window at right is active: Jump back to the window at left</li> </ul>	
<ul style="list-style-type: none"> <li>■ If the table of contents at left is active: Select the entry above it or below it</li> <li>■ If the text window at right is active: Jump to next link</li> </ul>	 
Select the page last shown	
Page forward if you have used the "select page last shown" function	
Move up by one page	
Move down by one page	

## Programming: Programming aids

### 4.8 TNCguide context-sensitive help system

Function	Soft key
Display or hide table of contents	
Switch between full-screen display and reduced display. With the reduced display you can see some of the rest of the TNC window	
The focus is switched internally to the TNC application so that you can operate the control when the TNCguide is open. If the full screen is active, the TNC reduces the window size automatically before the change of focus	
Exiting TNCguide	

#### Subject index

The most important subjects in the Manual are listed in the subject index (**Index** tab). You can select them directly by mouse or with the cursor keys.


The left side is active.



- ▶ Select the **Index** tab
- ▶ Activate the **Keyword** input field
- ▶ Enter the word for the desired subject and the TNC synchronizes the index and creates a list in which you can find the subject more easily, or
- ▶ Use the arrow key to highlight the desired keyword
- ▶ Use the ENT key to call the information on the selected keyword



You can enter the search word only with a keyboard connected via USB.



### Full-text search

In the **Find** tab you can search the entire TNCguide for a specific word.

The left side is active.



- ▶ Select the **Find** tab
- ▶ Activate the **Find:** input field
- ▶ Enter the desired word and confirm with the ENT key: The TNC lists all sources containing the word
- ▶ Use the arrow key to highlight the desired source
- ▶ Press the ENT key to go to the selected source



You can enter the search word only with a keyboard connected via USB.

The full-text search only works for single words.

If you activate the **Search only in titles** function (by mouse or by using the cursor and the space key), the TNC searches only through headings and ignores the body text.

## Programming: Programming aids

### 4.8 TNCguide context-sensitive help system

#### Downloading current help files

You'll find the help files for your TNC software on the HEIDENHAIN homepage [www.heidenhain.de](http://www.heidenhain.de) under:

- ▶ Documentation and information
- ▶ User Documentation
- ▶ TNCguide
- ▶ Select the desired language
- ▶ TNC Controls
- ▶ Series, e.g. TNC 600
- ▶ Desired NC software number, e.g. TNC 640 (34059x-04)
- ▶ Select the desired language version from the **TNCguide online help** table
- ▶ Download the ZIP file and unpack it
- ▶ Move the unzipped CHM files to the TNC in the **TNC:\tncguide\en** directory or into the respective language subdirectory (see also the following table)



If you want to use TNCremoNT to transfer the CHM files to the TNC, then in the **Extras >Configuration >Mode >Transfer in binary format** menu item you have to enter the extension **.CHM**.

<b>Language</b>	<b>TNC directory</b>
German	TNC:\tncguide\de
English	TNC:\tncguide\en
Czech	TNC:\tncguide\cs
French	TNC:\tncguide\fr
Italian	TNC:\tncguide\it
Spanish	TNC:\tncguide\es
Portuguese	TNC:\tncguide\pt
Swedish	TNC:\tncguide\sv
Danish	TNC:\tncguide\da
Finnish	TNC:\tncguide\fi
Dutch	TNC:\tncguide\nl
Polish	TNC:\tncguide\pl
Hungarian	TNC:\tncguide\hu
Russian	TNC:\tncguide\ru
Chinese (simplified)	TNC:\tncguide\zh
Chinese (traditional)	TNC:\tncguide\zh-tw
Slovenian (software option)	TNC:\tncguide\sl
Norwegian	TNC:\tncguide\no
Slovak	TNC:\tncguide\sk
Korean	TNC:\tncguide\kr
Turkish	TNC:\tncguide\tr
Romanian	TNC:\tncguide\ro



# 5

**Programming:  
Tools**


## Programming: Tools

### 5.1 Entering tool-related data

#### 5.1 Entering tool-related data

##### Feed rate **F**

The feed rate **F** is the speed (in millimeters per minute or inches per minute) at which the tool center point moves. The maximum feed rates can be different for the individual axes and are set in machine parameters.



##### Input

You can enter the feed rate in the **T** block and in every positioning block (See "Programming tool movements in DIN/ISO", page 99). In millimeter-programs you enter the feed rate in mm/min, and in inch-programs, for reasons of resolution, in 1/10 inch/min.

##### Rapid traverse

If you wish to program rapid traverse, enter **G00**.

##### Duration of effect

A feed rate entered as a numerical value remains in effect until a block with a different feed rate is reached. If the new feed rate is **G00** (rapid traverse), the last programmed feed rate is once again valid after the next block with **G01**.

##### Changing during program run

You can adjust the feed rate during program run with the feed-rate override knob **F**.



## Spindle speed S

The spindle speed S is entered in revolutions per minute (rpm) in a **T** block. Instead, you can also define the cutting speed Vc in m/min.

### Programmed change

In the part program, you can change the spindle speed in a **T** block by entering the spindle speed only:



- ▶ To program the spindle speed, press the **S** key on the alphabetic keyboard
- ▶ Enter the new spindle speed

### Changing during program run

You can adjust the spindle speed during program run with the spindle speed override knob S.

## Programming: Tools


### 5.2 Tool data

#### 5.2 Tool data

##### Requirements for tool compensation

You usually program the coordinates of path contours as they are dimensioned in the workpiece drawing. To allow the TNC to calculate the tool center path—i.e. the tool compensation—you must also enter the length and radius of each tool you are using.

Tool data can be entered either directly in the part program with **G99** or separately in a tool table. In a tool table, you can also enter additional data for the specific tool. The TNC will consider all the data entered for the tool when executing the part program.




##### Tool number, tool name

Each tool is identified by a number between 0 and 32767. If you are working with tool tables, you can also enter a tool name for each tool. Tool names can have up to 32 characters.

The tool number 0 is automatically defined as the zero tool with the length  $L=0$  and the radius  $R=0$ . In tool tables, tool T0 should also be defined with  $L=0$  and  $R=0$ .

##### Tool length L

You should always enter the tool length  $L$  as an absolute value based on the tool reference point. The entire tool length is essential for the TNC in order to perform numerous functions involving multi-axis machining.



##### Tool radius R

You can enter the tool radius  $R$  directly.

## Delta values for lengths and radii


Delta values are offsets in the length and radius of a tool.

A positive delta value describes a tool oversize (**DL**, **DR**, **DR2**>0). If you are programming the machining data with an allowance, enter the oversize value in the **T** block of the part program.

A negative delta value describes a tool undersize (**DL**, **DR**, **DR2**<0). An undersize is entered in the tool table for wear.

Delta values are usually entered as numerical values. In a **T** block, you can also assign the values to Q parameters.

Input range: You can enter a delta value with up to  $\pm 99.999$  mm.



Delta values from the tool table influence the graphical representation of the **tool**. The representation of the **workpiece** remains the same in the simulation.

Delta values from the **T** block change the represented size of the **workpiece** during the simulation. The simulated **tool size** remains the same.

## Entering tool data into the program

The number, length and radius of a specific tool is defined in the **G99** block of the part program.

- ▶ Select the tool definition: Press the **TOOL DEF** key

TOOL  
DEF

- ▶ **Tool number:** Each tool is uniquely identified by its tool number
- ▶ **Tool length:** Compensation value for the tool length
- ▶ **Tool radius:** Compensation value for the tool radius



In the programming dialog, you can transfer the value for tool length and tool radius directly into the input line by pressing the desired axis soft key.

### Example

```
N40 G99 T5 L+10 R+5 *
```

## Programming: Tools

### 5.2 Tool data

#### Enter tool data into the table

You can define and store up to 9999 tools and their tool data in a tool table. Also see the Editing Functions later in this Chapter. In order to be able to assign various compensation data to a tool (indexing tool number), insert a line and extend the tool number by a dot and a number from 1 to 9 (e.g. **T 5.2**).

You must use tool tables if

- you wish to use indexed tools such as stepped drills with more than one length compensation value
- your machine tool has an automatic tool changer
- you want to fine-rough the contour with Cycle G122, (see "User's Manual for Cycle Programming, ROUGH-OUT")
- you want to work with Cycles 251 to 254 (see "User's Manual for Cycle Programming," Cycles 251 to 254)



If you create or manage further tool tables, the file name has to start with a letter.

You can select either list view or form view for tables via the "Screen layout" key.

When you open the tool table you can also change its layout.

**Tool table: Standard tool data**

<b>Abbr.</b>	<b>Inputs</b>	<b>Dialog</b>
<b>T</b>	Number by which the tool is called in the program (e.g. 5, indexed: 5.2)	-
<b>NAME</b>	Name by which the tool is called in the program (no more than 32 characters, all capitals, no spaces)	<b>Tool name?</b>
<b>L</b>	Compensation value for tool length L	<b>Tool length?</b>
<b>R</b>	Compensation value for the tool radius R	<b>Tool radius R?</b>
<b>R2</b>	Tool radius R2 for toroid cutters (only for 3-D radius compensation or graphical representation of a machining operation with spherical or toroid cutters)	<b>Tool radius R2?</b>
<b>DL</b>	Delta value for tool length L	<b>Tool length oversize?</b>
<b>DR</b>	Delta value for tool radius R	<b>Tool radius oversize?</b>
<b>DR2</b>	Delta value for tool radius R2	<b>Tool radius oversize R2?</b>
<b>LCUTS</b>	Tooth length of the tool for Cycle 22	<b>Tooth length in the tool axis?</b>
<b>ANGLE</b>	Maximum plunge angle of the tool for reciprocating plunge-cut in Cycles 22 and 208	<b>Maximum plunge angle?</b>
<b>TL</b>	Set tool lock ( <b>TL</b> : for Tool Locked)	<b>Tool locked?</b> Yes = ENT / No = NO ENT
<b>RT</b>	Number of a replacement tool, if available ( <b>RT</b> : for Replacement Tool; see also <b>TIME2</b> ).	<b>Replacement tool?</b>
<b>TIME1</b>	Maximum tool life in minutes. This function can vary depending on the individual machine tool. Your machine manual provides more information	<b>Maximum tool age?</b>
<b>TIME2</b>	Maximum tool life in minutes during <b>TOOL CALL</b> : If the current tool life reaches or exceeds this value, the TNC changes the tool during the next <b>TOOL CALL</b> (see also <b>CUR_TIME</b> ).	<b>Maximum tool age for TOOL CALL?</b>
<b>CUR_TIME</b>	Current age of the tool in minutes: The TNC automatically counts the current tool life ( <b>CUR_TIME</b> : for <b>CUR</b> rent <b>TIME</b> . A starting value can be entered for used tools	<b>Current tool age?</b>

## Programming: Tools

### 5.2 Tool data

Abbr.	Inputs	Dialog
<b>TYPE</b>	Tool type: Press the ENT key to edit the field; the GOTO key opens a window in which you can select the tool type. You can assign tool types to specify the display filter settings such that only the selected type is visible in the table	<b>Tool type?</b>
<b>DOC</b>	Comment on tool (up to 32 characters)	<b>Tool comment?</b>
<b>PLC</b>	Information on this tool that is to be sent to the PLC	<b>PLC status?</b>
<b>PTYP</b>	Tool type for evaluation in the pocket table	<b>Tool type for pocket table?</b>
<b>NMAX</b>	Limit the spindle speed for this tool. The programmed value is monitored (error message) as well as an increase in the shaft speed via the potentiometer. Function inactive: Enter -. <b>Input range:</b> 0 to +999999, if function not active: enter -	<b>Maximum speed [rpm]?</b>
<b>LIFTOFF</b>	Definition of whether the TNC should retract the tool in the direction of the positive tool axis at an NC stop in order to avoid leaving dwell marks on the contour. If <b>Y</b> is defined, the TNC retracts the tool from the contour, provided that this function was activated in the NC program with M148 . See "Automatically retract tool from the contour at an NC stop: M148", page 345	<b>Retract tool Y/N ?</b>
<b>TP_NO</b>	Reference to the number of the touch probe in the touch-probe table	<b>Number of the touch probe</b>
<b>T_ANGLE</b>	Point angle of the tool. Is used by the Centering cycle (Cycle 240) in order to calculate the centering depth from the diameter entry	<b>Point angle?</b>
<b>AFC</b>	Control setting for the adaptive feed control AFC that you have defined in the <b>NAME</b> column of the AFC.TAB table. Apply the feedback-control strategy with the <b>ASSIGN AFC CONTROL SETTING</b> soft key (3rd soft-key row) <b>Input range:</b> 10 characters max.	<b>Feedback-control strategy?</b>
<b>LAST_USE</b>	Date and time that the tool was last inserted via <b>TOOL CALL</b> <b>Input range:</b> Max. 16 characters, format specified internally: Date = yyyy.mm.dd, time = hh.mm	<b>LAST_USE</b>
<b>ACC</b>	Activate or deactivate active chatter control for the respective tool (page 370). <b>Input range:</b> 0 (inactive) and 1 (active)	<b>ACC status</b> <b>1=active/0=inactive</b>

**Tool table: Tool data required for automatic tool measurement**

For a description of the cycles for automatic tool measurement, see the User's Manual for Cycle Programming.

<b>Abbr.</b>	<b>Inputs</b>	<b>Dialog</b>
<b>CUT</b>	Number of teeth (20 teeth maximum)	<b>Number of teeth?</b>
<b>LTOL</b>	Permissible deviation from tool length L for wear detection. If the entered value is exceeded, the TNC locks the tool (status <b>L</b> ). Input range: 0 to 0.9999 mm	<b>Wear tolerance: length?</b>
<b>RTOL</b>	Permissible deviation from tool radius R for wear detection. If the entered value is exceeded, the TNC locks the tool (status <b>L</b> ). Input range: 0 to 0.9999 mm	<b>Wear tolerance: radius?</b>
<b>R2TOL</b>	Permissible deviation from tool radius R2 for wear detection. If the entered value is exceeded, the TNC locks the tool (status <b>L</b> ). Input range: 0 to 0.9999 mm	<b>Wear tolerance: Radius 2?</b>
<b>DIRECT.</b>	Cutting direction of the tool for measuring the tool during rotation	<b>Cutting direction (M3 = -)?</b>
<b>R_OFFS</b>	Tool radius measurement: Tool offset between stylus center and tool center. Default setting: No value entered (offset = tool radius)	<b>Tool offset: radius?</b>
<b>L_OFFS</b>	Tool length measurement: Tool offset in addition to <b>offsetToolAxis</b> (114104) between upper surface of stylus and lower surface of tool. Default: 0	<b>Tool offset: length?</b>
<b>LBREAK</b>	Permissible deviation from tool length <b>L</b> for breakage detection. If the entered value is exceeded, the TNC locks the tool (status <b>L</b> ). Input range: 0 to 0.9999 mm	<b>Breakage tolerance: length?</b>
<b>RBREAK</b>	Permissible deviation from tool radius R for breakage detection. If the entered value is exceeded, the TNC locks the tool (status <b>L</b> ). Input range: 0 to 0.9999 mm	<b>Breakage tolerance: radius?</b>

## Programming: Tools

### 5.2 Tool data

#### Edit the tool table

The tool table that is active during execution of the part program is designated **TOOL.T** and must be saved in the **TNC:\table** directory.

Other tool tables that are to be archived or used for test runs are given any other names with the extension **T**. By default, for Test Run and Programming modes the TNC uses the "simtool.t" table, which is also stored in the "table" directory. In the Test Run mode, press the **TOOL TABLE** soft key to edit it.

To open the tool table **TOOL.T**:

- ▶ Select any machine operating mode



- ▶ To select the tool table, press the **TOOL TABLE** soft key.



- ▶ Set the **EDIT** soft key to **ON**

T	NAME	L	R	R2	DL	DR
0	WALWERKZEUG	0	0	0	0	0
1	02	30	1	0	0	0
2	04	40	2	0	0	0
3	06	50	3	0	0	0
4	08	60	4	0	0	0
5	10	60	5	0	0	0
6	12	60	6	0	0	0
7	14	70	7	0	0	0
8	16	80	8	0	0	0
9	18	90	9	0	0	0
10	20	90	10	0	0	0
11	22	90	11	0	0	0
12	24	90	12	0	0	0
13	26	90	13	0	0	0
14	28	100	14	0	0	0
15	30	100	15	0	0	0
16	32	100	16	0	0	0
17	34	100	17	0	0	0
18	36	100	18	0	0	0
19	38	100	19	0	0	0
20	40	100	20	0	0	0
21	42	100	5	5	0	0
22	44	120	22	0	0	0
23	46	120	23	0	0	0
24	48	120	24	0	0	0
25	50	120	25	0	0	0
26	52	120	26	0	0	0

#### Displaying only specific tool types (filter setting)

- ▶ Press the **TABLE FILTER** soft key (fourth soft-key row)
- ▶ Select the tool type by pressing a soft key: The TNC only shows tools of the type selected
- ▶ Cancel filter: Press the previously selected tool type again or select another tool type



The machine tool builder adapts the features of the filter function to the requirements of your machine. Refer to your machine manual.



### Hiding or sorting the tool table columns

You can adapt the layout of the tool table to your needs. Columns that should not be displayed can be hidden:

- ▶ Press the **SORT/HIDE COLUMNS** soft key (fourth soft-key row)
- ▶ Select the appropriate column name with the arrow key
- ▶ Press the **HIDE COLUMN** soft key to remove this column from the table layout

You can also modify the sequence of columns in the table:

- ▶ You can also modify the sequence of columns in the table with the "Move to" dialog. The entry highlighted in **Available columns** is moved in front of this column

You can use a connected mouse or the TNC keyboard to navigate in the form. Navigation using the TNC keyboard:



With the Fix number of columns function, you can define how many columns (0 -3) are fixed to the left screen edge. These columns are also displayed if you navigate in the table to the right.

## Programming: Tools

### 5.2 Tool data

#### Opening any other tool table


















- ▶ Select the Programming mode of operation

PGM  
MGT

- ▶ Call the file manager
- ▶ Press the **SELECT TYPE** soft key to select the file type
- ▶ Show files of type .T press the **SHOW .T** soft key.
- ▶ Select a file or enter a new file name. Conclude your entry with the **ENT** key or the **SELECT** soft key

When you have opened the tool table, you can edit the tool data by moving the cursor to the desired position in the table with the arrow keys or the soft keys. You can overwrite the stored values, or enter new values at any position. The available editing functions are illustrated in the table below.

If the TNC cannot show all positions in the tool table in one screen page, the highlight bar at the top of the table will display the symbol ">>" or "<<".

Editing functions for tool tables	Soft key
Select beginning of table	
Select end of table	
Select previous page in table	
Select next page in table	
Find the text or number	
Move to beginning of line	
Move to end of line	
Copy highlighted field	
Insert copied field	
Add the entered number of lines (tools) at the end of the table	
Adding a row with tool number for entering	
Delete current line (tool)	
Sort the tools according to the content of a column	
Show all drills in the tool table	
Show all cutters in the tool table	
Show all taps/thread cutters in the tool table	
Show all touch probes in the tool table	

### Exiting the tool table

- Call the file manager and select a file of a different type, such as a part program



## Pocket table for tool changer



The machine tool builder adapts the features of the pocket table to the requirements of your machine. Refer to your machine manual.


For automatic tool changing you need the a pocket table. You manage the assignment of your tool changer in the pocket table. The pocket table is in the **TNC:\TABLE** directory. The machine tool builder can adapt the name, path and content of the pocket table. You can also select various layouts using soft keys in the **TABLE FILTER** menu.

T	NAME	L	R	R2	DL	DR
0	MALWERKZEUG	0	0	0	0	0
100		20	41	0	0	0
204		40	2	0	0	0
306		50	3	0	0	0
408		50	4	0	0	0
5010		50	5	0	0	0
6012		60	6	0	0	0
7014		70	7	0	0	0
8016		80	8	0	0	0
9018		90	9	0	0	0
10020		90	10	0	0	0
11022		90	11	0	0	0
12024		90	12	0	0	0
13026		90	13	0	0	0
14028		100	14	0	0	0
15030		100	15	0	0	0
16032		100	16	0	0	0
17034		100	17	0	0	0
18036		100	18	0	0	0
19038		100	19	0	0	0
20040		100	20	0	0	0
21042		100	5	5	0	0
22044		120	22	0	0	0
23046		120	23	0	0	0
24048		120	24	0	0	0
25050		120	25	0	0	0
26052		120	26	0	0	0

### Editing a pocket table in a Program Run operating mode



- ▶ To select the tool table, press the **TOOL TABLE** soft key.



- ▶ Select the pocket table: Press the **POCKET TABLE** soft key



- ▶ Set the **EDIT** soft key to **ON**. On your machine this might not be necessary or even possible. Refer to your machine manual.

## Programming: Tools













### 5.2 Tool data

#### Selecting a pocket table in the Programming mode of operation

PGM  
MGT

- ▶ Call the file manager
- ▶ Display the file types: Press the **SHOW ALL** soft key
- ▶ Select a file or enter a new file name. Conclude your entry with the **ENT** key or the **SELECT** soft key

Abbr.	Inputs	Dialog
<b>P</b>	Pocket number of the tool in the tool magazine	-
<b>T</b>	Tool number	<b>Tool number?</b>
<b>RSV</b>	Pocket reservation for box magazines	<b>Pocket reserv.: Yes = ENT / No = NO ENT</b>
<b>ST</b>	Special tool ( <b>ST</b> ); If your special tool blocks pockets in front of and behind its actual pocket, these additional pockets need to be locked in column L (status L).	<b>Special tool?</b>
<b>F</b>	The tool is always returned to the same pocket in the tool magazine	<b>Fixed pocket? Yes = ENT / No = NO ENT</b>
<b>L</b>	Locked pocket (see also column ST)	<b>Pocket locked Yes = ENT / No = NO ENT</b>
<b>DOC</b>	Display of the comment to the tool from TOOL.T	-
<b>PLC</b>	Information on this tool pocket that is to be sent to the PLC	<b>PLC status?</b>
<b>P1 ... P5</b>	Function is defined by the machine tool builder. The machine tool documentation provides further information	<b>Value?</b>
<b>PTYP</b>	Tool type. Function is defined by the machine tool builder. The machine tool documentation provides further information	<b>Tool type for pocket table?</b>
<b>LOCKED_ABOVE</b>	Box magazine: Lock the pocket above	<b>Lock the pocket above?</b>
<b>LOCKED_BELOW</b>	Box magazine: Lock the pocket below	<b>Lock the pocket below?</b>
<b>LOCKED_LEFT</b>	Box magazine: Lock the pocket at left	<b>Lock the pocket at left?</b>
<b>LOCKED_RIGHT</b>	Box magazine: Lock the pocket at right	<b>Lock the pocket at right?</b>

Editing functions for pocket tables	Soft key
Select beginning of table	
Select end of table	
Select previous page in table	
Select next page in table	
Reset pocket table	
Reset tool number column T	
Go to beginning of the line	
Go to end of the line	
Simulate a tool change	
Select a tool from the tool table: The TNC shows the contents of the tool table. Use the arrow keys to select a tool, press <b>OK</b> to transfer it to the pocket table	
Edit the current field	
Sort the view	



The machine manufacturer defines the features, properties and designations of the various display filters. Refer to your machine manual.

## Programming: Tools

### 5.2 Tool data

#### Call tool data

A TOOL CALL block in the part program is defined with the following data:

- ▶ Select the tool call function with the **TOOL CALL** key



- ▶ **Tool number:** Enter the number or name of the tool. The tool must already be defined in a **G99** block or in the tool table. With the **tool name** soft key you can enter a name. With the **QS** soft key you enter a string parameter. The TNC automatically places the tool name in quotation marks. You have to assign a tool name to a string parameter first. Names always refer to an entry in the active tool table TOOL .T. If you wish to call a tool with other compensation values, also enter the index you defined in the tool table after the decimal point. There is a **SELECT** soft key for calling a window from which you can select a tool defined in the tool table TOOL.T directly without having to enter the number or name.
- ▶ **Working spindle axis X/Y/Z:** Enter the tool axis.
- ▶ **Spindle speed S:** Enter the spindle speed in rpm. Alternatively, you can define the cutting speed Vc in m/min. Press the **VC** soft key
- ▶ **Feed rate F:** F [mm/min or 0.1 inch/min] stays effective until you program a new feed rate in a positioning or T block
- ▶ **Tool length oversize DL:** Delta value for the tool length
- ▶ **Tool radius oversize DR:** Delta value for tool radius
- ▶ **Tool radius oversize DR2:** Delta value for tool radius 2



If you open a pop-up window for tool selection, the TNC marks all tools available in the tool magazine green.

You can also search for a tool in the pop-up window. To do so, press the **SEARCH** soft key and enter the tool number or tool name. With the **OK** soft key you can load the tool into the dialog box.



**Example: Tool call**

Call tool number 5 in the tool axis Z with a spindle speed of 2500 rpm and a feed rate of 350 mm/min. The tool length is to be programmed with an oversize of 0.2 mm, the tool radius 2 with an oversize of 0.05 mm, and the tool radius with an undersize of 1 mm.

```
N20 T 5.2 G17 S2500 DL+0.2 DR-1
```

The character **D** preceding **L** and **R** designates delta values.

**Tool preselection with tool tables**

If you are working with tool tables, use **G51** to preselect the next tool. Simply enter the tool number or a corresponding Q parameter, or type the tool name in quotation marks.

## Programming: Tools

### 5.2 Tool data

#### Tool change



The tool change function can vary depending on the individual machine tool. Refer to your machine manual.

#### Tool change position

The tool change position must be approachable without collision. Use the miscellaneous functions **M91** and **M92** to enter machine-based (rather than workpiece-based) coordinates for the tool change position. If **T 0** is programmed before the first tool call, the TNC moves the tool spindle in the tool axis to a position that is independent of the tool length.

#### Manual tool change

To change the tool manually, stop the spindle and move the tool to the tool change position:

- ▶ Move to the tool change position under program control
- ▶ Interrupt program run and See "Interrupt machining", page 537
- ▶ Change the tool
- ▶ Resume program run and See "Resuming program run after an interruption", page 538

#### Automatic tool change

If your machine tool has automatic tool changing capability, the program run is not interrupted. When the TNC reaches a **T** it replaces the inserted tool by another from the tool magazine.

#### Automatic tool change if the tool life expires: **M101**



The function of **M101** can vary depending on the individual machine tool. Refer to your machine manual.

When the specified tool life has expired, the TNC can automatically insert a replacement tool and continue machining with it. Activate the miscellaneous function **M101** for this. **M101** is reset with **M102**.

Enter the respective tool life after which machining is to be continued with a replacement tool in the **TIME2** column of the tool table. In the **CUR\_TIME** column the TNC enters the current tool life. If the current tool life is higher than the value entered in the **TIME2** column, a replacement tool will be inserted at the next possible point in the program no later than one minute after expiration of the tool life. The change is made only after the NC block has been completed.

The TNC performs the automatic tool change at a suitable point in the program. The automatic tool change is not performed:

- During execution of machining cycles
- While radius compensation is active (**RR/RL**)
- Directly after an approach function **APPR**
- Directly before a departure function **DEP**
- Directly before and after **CHF** and **RND**
- During execution of macros
- During execution of a tool change
- Directly after a **TOOL CALL** or **TOOL DEF**
- During execution of SL cycles



**Caution: Danger to the workpiece and tool!**

Switch off the automatic tool change with **M102** if you are working with special tools (e.g. side mill cutter) because the TNC at first always moves the tool away from the workpiece in tool axis direction.

Depending on the NC program, the machining time can increase as a result of the tool life verification and calculation of the automatic tool change. You can influence this with the optional input element **BT** (block tolerance)

If you enter the **M101** function, the TNC continues the dialog by requesting the **BT**. Here you define the number of NC blocks (1 - 100) by which the automatic tool change may be delayed. The resulting time period by which the tool change is delayed depends on the content of the NC blocks (e.g. feed rate, path). If you do not define **BT**, the TNC uses the value 1 or, if applicable, a default value defined by the machine manufacturer.



The more you increase the value of **BT**, the smaller will be the effect of an extended program duration through **M101**. Please note that this will delay the automatic tool change!

To calculate a suitable output value for **BT** use the formula **BT = 10 : Average machining time of an NC block in seconds**. Round up to the next odd integer. If the calculated result is greater than 100, use the maximum input value of 100.

If you want to reset the current age of a tool (e.g. after changing the indexable inserts), enter the value 0 in the **CUR\_TIME** column.

The **M101** function is not available for turning tools and in turning mode.

## Programming: Tools

### 5.2 Tool data

#### Prerequisites for NC blocks with surface-normal vectors and 3-D compensation

The active radius (**R + DR**) of the replacement tool must not differ from the radius of the original tool. You can enter the delta values (**DR**) either in the tool table or in the **T** block. If there are any deviations, the TNC displays an error message and does not replace the tool. You can suppress this message with the M function **M107**, and reactivate it with **M108**.

## Tool usage test



The tool usage test function must be enabled by your machine manufacturer. Refer to your machine manual.



The tool usage test is not available for turning tools.

In order to be able to conduct a tool usage test, tool usage files have to be generated. "Tool usage file"


The conversational program has to be completely simulated in the **Test Run** operating mode or executed in the **Program Run, Full Sequence or Single Block** operating mode.

### Applying the tool usage test

Before starting a program in the Program Run mode of operation, you can use the **TOOL USAGE** and **TOOL USAGE TEST** soft keys to check whether the tools being used in the selected program are available and have sufficient remaining service life. The TNC then compares the actual service-life values in the tool table with the nominal values from the tool usage file.

After you have pressed the **TOOL USAGE TEST** soft key, the TNC displays the result of the tool usage test in a pop-up window. To close the pop-up window, press the ENT key.

The TNC saves the tool usage times in a separate file with the extension **pgmname.H.T.DEP**. This file is not visible unless the machine parameter **CfgPgmMgt/dependentFiles** is set to **MANUAL**. The generated tool usage file contains the following information:



Column	Meaning
<b>TOKEN</b>	<ul style="list-style-type: none"> <li>■ <b>TOOL</b>: Tool usage time per <b>TOOL CALL</b>. The entries are listed in chronological order.</li> <li>■ <b>TTOTAL</b>: Total usage time of a tool</li> <li>■ <b>STOTAL</b>: Call of a subprogram; the entries are listed in chronological order</li> <li>■ <b>TIMETOTAL</b>: The total machining time of the NC program is entered in the <b>WTIME</b> column. In the <b>PATH</b> column the TNC saves the path name of the corresponding NC programs. The <b>TIME</b> column shows the sum of all <b>TIME</b> entries (without rapid traverse). The TNC sets all other columns to 0</li> <li>■ <b>TOOLFILE</b>: In the <b>PATH</b> column, the TNC saves the path name of the tool table with which you conducted the Test Run. This enables the TNC during the actual tool usage test to detect whether you performed the test run with the <b>TOOL.T</b></li> </ul>
<b>TNR</b>	Tool number (-1: No tool inserted yet)

## Programming: Tools

### 5.2 Tool data

Column	Meaning
<b>IDX</b>	Tool index
<b>NAME</b>	Tool name from the tool table
<b>TIME</b>	Tool-usage time in seconds (feed time)
<b>WTIME</b>	Tool-usage time in seconds (total usage time between tool changes)
<b>RAD</b>	<b>Tool radius R + Oversize of tool radius DR</b> from the tool table. (in mm)
<b>BLOCK</b>	Block number in which the <b>TOOL CALL</b> block was programmed
<b>PATH</b>	<ul style="list-style-type: none"> <li>■ <b>TOKEN = TOOL</b>: Path name of the active main program or subprogram</li> <li>■ <b>TOKEN = STOTAL</b>: Path name of the subprogram</li> </ul>
<b>T</b>	Tool number with tool index
<b>OVRMAX</b>	Maximum feed rate override that occurred during machining. During Test Run the TNC enters the value 100 (%)
<b>OVRMIN</b>	Minimum feed rate override that occurred during machining. During Test Run the TNC enters the value -1
<b>NAMEPROG</b>	<ul style="list-style-type: none"> <li>■ 0: The tool number is programmed</li> <li>■ 1: The tool name is programmed</li> </ul>

There are two ways to run a tool usage test for a pallet file:

- The highlight in the pallet file is on a pallet entry: The TNC runs the tool usage test for the entire pallet
- The highlight in the pallet file is on a pallet entry: The TNC runs the tool usage test for the entire pallet

## Tool management (software option)



Tool management is a machine-dependent function, which may be partly or completely deactivated. The machine tool builder defines the exact range of functions. Refer to your machine manual.

With the tool management, your machine tool builder can provide many functions with regard to tool handling. Examples:

- Easily readable and, if you desired, adaptable representation of the tool data in fillable forms
- Any description of the individual tool data in the new table view
- Mixed representation of data from the tool table and the pocket table
- Fast sorting of all tool data by mouse
- Use of graphic aids, e.g. color coding of tool or magazine status
- Program-specific list of all available tools
- Program-specific usage sequence of all tools
- Copying and pasting of all tool data pertaining to a tool
- Graphic depiction of tool type in the table view and in the detail view for a better overview of the available tool types

The screenshot shows a software window titled 'Expanded tool management' with a 'Programming' tab. The main area displays a table with columns for tool ID, name, type, status, and remaining life. The table contains 32 rows of data, with some rows highlighted in green and others in blue. The bottom of the window features a navigation bar with buttons for 'BEGIN', 'END', 'PAGE', 'MAGAZINE MANAGEMENT', 'FORM FOR TOOL', and 'END'.

ID	NAME	TYPE	STATUS	MAGAZINE	TOOL LIFE	REMAINING LIFE
1	02	0	Not monitored		0	0
2	04	0	Not monitored		0	0
3	06	0	Not monitored		0	0
4	08	0	Not monitored		0	0
5	010	0	Not monitored		0	0
6	012	0	Not monitored		0	0
7	014	0	Not monitored		0	0
8	016	0	Not monitored		0	0
9	018	0	Not monitored		0	0
10	020	0	Not monitored		0	0
11	022	0	Not monitored		0	0
12	024	0	Not monitored		0	0
13	026	0	Not monitored		0	0
14	028	0	Not monitored		0	0
15	030	0	Not monitored		0	0
16	032	0	Not monitored		0	0
17	034	0	Not monitored		0	0
18	036	0	Not monitored		0	0
19	038	0	Not monitored		0	0
20	040	0	Not monitored		0	0
21	042	0	Not monitored		0	0
22	044	0	Not monitored		0	0
23	046	0	Not monitored		0	0
24	048	0	Not monitored		0	0
25	050	0	Not monitored		0	0
26	052	0	Not monitored		0	0
27	054	0	Not monitored		0	0
28	056	0	Not monitored		0	0
29	058	0	Not monitored		0	0
30	060	0	Not monitored		0	0
31	062	0	Not monitored		0	0
32	064	0	Not monitored		0	0

## Programming: Tools

### 5.2 Tool data

#### Calling the tool management



The tool management call can differ as described below. Refer to your machine manual.



- ▶ To select the tool table, press the **TOOL TABLE** soft key.



- ▶ Scroll through the soft-key row



- ▶ Select the **tool management** soft key: The TNC goes into the new table view (see figure at right)

NO.	NAME	PRGR	TL	POCKET	MAGAZINE	TOOL LIFE	REMAINING LIFE
1	D02	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
2	D04	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
3	D06	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
4	D08	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
5	D10	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
6	D12	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
7	D14	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
8	D16	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
9	D18	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
10	D20	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
11	D22	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
12	D24	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
13	D26	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
14	D28	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
15	D30	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
16	D32	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
17	D34	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
18	D36	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
19	D38	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
20	D40	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
21	D42	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
22	D44	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
23	D46	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
24	D48	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
25	D50	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
26	D52	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
27	D54	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
28	D56	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
29	D58	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
30	D60	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
31	D62	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0
32	D64	0	0	<input type="checkbox"/>	MAGAZINE	Not monitored	0

In the new view, the TNC presents all tool information in the following four tabs:

- **Tools:** Tool specific information
- **Pockets:** Pocket-specific information
- **Tooling list:** List of all tools in the NC program that is selected in the Program Run mode (only if you have already created a tool usage file, See "Tool usage test", page 181)
- **T usage order:** List of the sequence of all tools that are inserted in the program selected in the Program Run mode (only if you have already made a tool usage file, See "Tool usage test", page 181)



You can edit the tool data only in the form view, which you can activate by pressing the **FORM FOR TOOL** soft key or the **ENT** key for the currently highlighted tool.











If you use tool management without a mouse, then you can activate and deactivate functions with the "-/+ " check box.




## Operating the tool management

The tool management can be operated by mouse or with the keys and soft keys:

### Editing functions of tool management

	Soft key
Select beginning of table	
Select end of table	
Select previous page in table	
Select next page in table	
Call the fillable form view for the tool or magazine pocket highlighted in the table. Alternative function: Press the <b>ENT</b> key	
Go to the next tab: <b>Tools, Pockets, Tooling list, T usage order</b>	
Search function (Find): Here you can select the column to be searched and the search term via a list or by entering it	
Show programmed-tools column (if <b>Pockets</b> tab is active)	
Define the settings:	
<ul style="list-style-type: none"> <li>■ <b>SORT COLUMN</b> active: Click the column header to sort the content of the column</li> <li>■ <b>MOVE COLUMN</b> active: The column can be moved by drag and drop</li> </ul>	
Reset the manually changed settings (moved columns) to original condition	












## Programming: Tools

### 5.2 Tool data

In addition, you can perform the following functions by mouse:

- **Sorting function.** You can sort the data in ascending or descending order (depending on the active setting) by clicking a column of the table head.
- **Arrange columns.** You can arrange the columns in any sequence you want by clicking a column of the table head and then moving it with the mouse key pressed down. The TNC does not save the current column sequence when you exit the tool management (depending on the active setting).
- **Show miscellaneous information in the form view.** The TNC displays tool tips when you leave the mouse pointer on an active input field for more than a second and when you have set the **EDIT ON/OFF** soft key to **ON**.

If the form view is active, the following functions are available to you:

Editing functions form view	Soft key
Select the tool data of the previous tool	
Select the tool data of the next tool	
Select previous tool index (only active if indexing is enabled)	
Select the next tool index (only active if indexing is enabled)	
Discard all changes made since the form was last called ("Undo" function)	
Insert a line (tool index) (2nd soft-key row)	
Delete a line (tool index) (2nd soft-key row)	
Copy the tool data of the selected tool (2nd soft-key row)	
Insert the copied tool data in the selected tool (2nd soft-key row)	

### Importing tool data

Using this function you can simply import tool data that you have measured externally on a presetting device, for example. The file to be imported must have the CSV format (Comma Separated Values). The **CSV** file format describes the structure of a text file for exchanging simply structured data. Accordingly, the import file must have the following structure:

- **Row 1:** In the first line you define the column names in which the data defined in the subsequent lines is to be placed. The column names are separated from each other by commas.
- **Other lines:** All the other lines contain the data that you wish to import into the tool table. The order of the data must match the order of the column names in Line 1. The data is separated by commas, decimal numbers are to be defined with a decimal point.

Follow the steps outlined below for importing:

- ▶ Copy the tool table to be imported to the hard disk of the TNC in the **TNC:\systems\tooltab** directory
- ▶ Start Extended Tool Management
- ▶ Select the **IMPORT TOOL** soft key in the Tool Management: The TNC shows a pop-up window with the CSV files stored in the **TNC:\systems\tooltab** directory
- ▶ Use the arrow keys or mouse to select the file to be imported and confirm with the **ENT** key: The TNC shows the content of the CSV file in a pop-up window
- ▶ Start import procedure with **START** soft key



- The CSV file to be imported must be stored in the **TNC:\system\tooltab** directory.
- If you import the tool data of tools whose numbers are in the pocket table, the TNC issues an error message. You can then decide whether you want to skip this data record or insert a new tool. The TNC inserts a new tool into the first empty line of the tool table.
- Make sure that the column designations are specified correctly, See "Enter tool data into the table", page 164.
- You can import any tool data, the associated data record does not have to contain all the columns (or data) of the tool table.
- The column names can be in any order, the data must be defined in the corresponding order.

## Programming: Tools

### 5.2 Tool data

#### Sample import file:

T,L,R,DL,DR	Line 1 with column names
4,125.995,7.995,0,0	Line 2 with tool data
9,25.06,12.01,0,0	Line 3 with tool data
28,196.981,35,0,0	Line 4 with tool data

#### Exporting tool data

Using this function you can simply export tool data to read it into the tool database of your CAM system, for example. The TNC stores the exported file in the CSV format (Comma Separated Values). The **CSV** file format describes the structure of a text file for exchanging simply structured data. The export file has the following structure:

- **Line 1:** In the first line the TNC stores the column names of all the relevant tool data to be defined. The column names are separated from each other by commas.
- **Further lines:** All the other lines contain the data of the tools that you have exported. The order of the data matches the order of the column names in Line 1. The data is separated by commas, the TNC outputs decimal numbers with a decimal point.

Follow the steps outlined below for exporting:

- ▶ In the tool management you use the arrow keys or mouse to mark the tool data that you wish to export
- ▶ Select the **EXPORT TOOL** soft key, the TNC shows a pop-up window: specify the name for the CSV file, confirm with the **ENT** key
- ▶ Press the **START** soft key to start the export process: The TNC shows the status of the delete export process in a pop-up window
- ▶ Terminate the export process by pressing the **END** key or soft key



The TNC always stores the exported CSV file in the **TNC:\system\tooltab** directory.

### Deleting marked tool data

Using this function you can simply delete tool data that you no longer need.

Follow the steps outlined below for deleting:

- ▶ In the tool management you use the arrow keys or mouse to mark the tool data that you wish to delete
- ▶ Select the **DELETE MARKED TOOLS** soft key and the TNC shows a pop-up window listing the tool data to be deleted
- ▶ Press the **START** soft key to start the delete process: The TNC shows the status of the delete process in a pop-up window
- ▶ Terminate the delete process by pressing the **END** key or soft key



- The TNC deletes all the data of all the tools selected. Make sure that you really no longer need the tool data, because there is no Undo function available.
- You cannot delete the tool data of tools still stored in the pocket table. First remove the tool from the magazine.

## Programming: Tools

### 5.3 Tool compensation


#### 5.3 Tool compensation

##### Introduction

The TNC adjusts the spindle path in the spindle axis by the compensation value for the tool length. In the working plane, it compensates the tool radius.

If you are writing the part program directly on the TNC, the tool radius compensation is effective only in the working plane.

The TNC accounts for the compensation value in up to five axes including the rotary axes.



##### Tool length compensation

Length compensation becomes effective automatically as soon as a tool is called. To cancel length compensation, call a tool with the length  $L=0$ .



##### **Danger of collision!**

If you cancel a positive length compensation with **T 0** the distance between tool and workpiece will be reduced.

After **T** the path of the tool in the spindle axis, as entered in the part program, is adjusted by the difference between the length of the previous tool and that of the new one.

For tool length compensation, the control takes the delta values from both the **T** block and the tool table into account:

Compensation value =  $L + DL_{TOOL CALL} + DL_{TAB}$  with

**L**: Tool length **L** from the **G99** block or tool table

**DL<sub>TOOL CALL</sub>**: Oversize for length **DL** in the **T 0** block

**DL<sub>TAB</sub>**: Oversize for length **DL** in the tool table

## Tool radius compensation

The block for programming a tool movement contains:

- **G41** or **G42** for radius compensation
- **G40** if there is no radius compensation

The radius compensation is effective as soon as a tool is called and traversed with a straight line block in the working plane with **G41** or **G42**.



The TNC automatically cancels radius compensation if you:

- program a straight line block with **G40**
- program a **PGM CALL**
- Select a new program with **PGM MGT**

For radius compensation, the TNC takes the delta values from both the **T** block and the tool table into account:

Compensation value =  $R + DR_{\text{TOOL CALL}} + DR_{\text{TAB}}$  where

**R:** Tool radius **R** from the **G99** block or tool table

**DR<sub>TOOL</sub>** Oversize for radius **DR** in the **T** block



**CALL:**

**DR<sub>TAB</sub>:** Oversize for radius **DR** in the tool table

### Contouring without radius compensation: G40

The tool center moves in the working plane along the programmed path or to the programmed coordinates.

Applications: Drilling and boring, pre-positioning



## Programming: Tools

### 5.3 Tool compensation

#### Contouring with radius compensation: G42 and G41

**G43:** The tool moves to the right of the programmed contour

**G42:** The tool moves to the left of the programmed contour


The tool center moves along the contour at a distance equal to the radius. "Right" or "left" are to be understood as based on the direction of tool movement along the workpiece contour. See figures.



Between two program blocks with different radius compensations **G43** and **G42** you must program at least one traversing block in the working plane without radius compensation (that is, with **G40**).

The TNC does not put radius compensation into effect until the end of the block in which it is first programmed.

In the first block in which radius compensation is activated with **G42/G41** or canceled with **G40** the TNC always positions the tool perpendicular to the programmed starting or end position. Position the tool at a sufficient distance from the first or last contour point to prevent the possibility of damaging the contour.



#### Entering radius compensation

Radius compensation is entered in a **G01** block.

G 4 1

- ▶ Select tool movement to the left of the programmed contour: Select function G41, or

G 4 2

- ▶ Select tool movement to the right of the contour: Select function G42, or

G 4 0

- ▶ Select tool movement without radius compensation or cancel radius compensation: Select function G40

END

- ▶ To conclude the block, press END.





**Radius compensation: Machining corners**

- Outside corners:  
If you program radius compensation, the TNC moves the tool around outside corners on a transitional arc. If necessary, the TNC reduces the feed rate at outside corners to reduce machine stress, for example at very great changes of direction.
- Inside corners:  
The TNC calculates the intersection of the tool center paths at inside corners under radius compensation. From this point it then starts the next contour element. This prevents damage to the workpiece at the inside corners. The permissible tool radius, therefore, is limited by the geometry of the programmed contour.

**Danger of collision!**

To prevent the tool from damaging the contour, be careful not to program the starting or end position for machining inside corners at a corner of the contour.





# 6

**Programming:  
Programming  
contours**


## Programming: Programming contours

### 6.1 Tool movements

#### 6.1 Tool movements

##### Path functions

A workpiece contour is usually composed of several contour elements such as straight lines and circular arcs. With the path functions, you can program the tool movements for **straight lines** and **circular arcs**.



##### Miscellaneous functions M

With the TNC's miscellaneous functions you can affect

- the program run, e.g., a program interruption
- the machine functions, such as switching spindle rotation and coolant supply on and off
- the path behavior of the tool

##### Subprograms and program section repeats

If a machining sequence occurs several times in a program, you can save time and reduce the chance of programming errors by entering the sequence once and then defining it as a subprogram or program section repeat. If you wish to execute a specific program section only under certain conditions, you also define this machining sequence as a subprogram. In addition, you can have a part program call a separate program for execution.

Programming with subprograms and program section repeats is described in Chapter 7.

##### Programming with Q parameters

Instead of programming numerical values in a part program, you enter markers called Q parameters. You assign the values to the Q parameters separately with the Q parameter functions. You can use the Q parameters for programming mathematical functions that control program execution or describe a contour.

In addition, parametric programming enables you to measure with the 3-D touch probe during program run.

Programming with Q parameters is described in Chapter 8.

## 6.2 Fundamentals of Path Functions

### Programming tool movements for workpiece machining

You create a part program by programming the path functions for the individual contour elements in sequence. You usually do this by entering **the coordinates of the end points of the contour elements** given in the production drawing. The TNC calculates the actual path of the tool from these coordinates, and from the tool data and radius compensation.

The TNC moves all axes programmed in a single block simultaneously.

#### Movement parallel to the machine axes

The program block contains only one coordinate. The TNC thus moves the tool parallel to the programmed axis.

Depending on the individual machine tool, the part program is executed by movement of either the tool or the machine table on which the workpiece is clamped. Nevertheless, you always program path contours as if the tool were moving and the workpiece remaining stationary.

#### Example:

```
N50 G00 X+100 *
```

**N50**           Block number  
**G00**           Path function "straight line at rapid traverse"  
**X+100**        Coordinate of the end point

The tool retains the Y and Z coordinates and moves to the position X=100. See figure.



#### Movement in the main planes

The program block contains two coordinates. The TNC thus moves the tool in the programmed plane.

#### Example

```
N50 G00 X+70 Y+50 *
```

The tool retains the Z coordinate and moves in the XY plane to the position X=70, Y=50 (see figure).



## Programming: Programming contours


### 6.2 Fundamentals of Path Functions

#### Three-dimensional movement

The program block contains three coordinates. The TNC thus moves the tool in space to the programmed position.

#### Example

```
N50 G01 X+80 Y+0 Z-10 *
```




#### Circles and circular arcs

The TNC moves two axes simultaneously on a circular path relative to the workpiece. You can define a circular movement by entering the circle center **CC**.

When you program a circle, the control assigns it to one of the main planes. This plane is defined automatically when you set the spindle axis during a **tool call**:

Spindle axis	Main plane
(G17)	XY, also UV, XY, UY
(G18)	ZX, also WU, ZU, WX
(G19)	YZ, also VW, YW, VZ



You can program circles that do not lie parallel to a main plane by using the function for tilting the working plane (see User's Manual for Cycles, Cycle 19, WORKING PLANE) or Q parameters (See "Principle and overview of functions", page 264).

#### Direction of rotation DR for circular movements

When a circular path has no tangential transition to another contour element, enter the direction of rotation as follows:

Clockwise direction of rotation: **G02/G12**

Counterclockwise direction of rotation: **G03/G13**

**Radius compensation**

The radius compensation must be in the block in which you move to the first contour element. You cannot activate radius compensation in a circle block. It must be activated beforehand in a straight-line block (See "Path contours - Cartesian coordinates", page 209).

**Pre-position****Danger of collision!**

Before running a part program, always pre-position the tool to prevent the possibility of damaging it or the workpiece.

## Programming: Programming contours

### 6.3 Approaching and departing a contour

#### 6.3 Approaching and departing a contour


##### Starting point and end point

The tool approaches the first contour point from the starting point. The starting point must be:

- Programmed without radius compensation
- Approachable without danger of collision
- Close to the first contour point


Figure at upper right:

If you set the starting point in the dark gray area, the contour will be damaged when the first contour element is approached.



##### First contour point

You need to program a radius compensation for the tool movement to the first contour point.




##### Approaching the starting point in the spindle axis

When the starting point is approached, the tool must be moved to the working depth in the spindle axis. If danger of collision exists, approach the starting point in the spindle axis separately.

##### NC blocks

```
N30 G00 G40 X+20 Y+30 *
```

```
N40 Z-10 *
```





### End point

The end point should be selected so that it is:

- Approachable without danger of collision
- Near to the last contour point
- In order to make sure the contour will not be damaged, the optimal ending point should lie on the extended tool path for machining the last contour element

Figure at upper right:

If you set the ending point in the dark gray area, the contour will be damaged when the end point is approached.



Departing the end point in the spindle axis:

Program the departure from the end point in the spindle axis separately. See figure at center right.

### NC blocks

```
N50 G00 G40 X+60 Y+70 *
```

```
N60 Z+250 *
```




### Common starting and end points

Do not program any radius compensation if the starting point and end point are the same.

In order to make sure the contour will not be damaged, the optimal starting point should lie between the extended tool paths for machining the first and last contour elements.

Figure at upper right:

If you set the end point in the dark gray area, the contour will be damaged when the first contour element is approached.





## Programming: Programming contours

### 6.3 Approaching and departing a contour

#### Tangential approach and departure

With **G26** (figure at center right), you can program a tangential approach to the workpiece, and with **G27** (figure at lower right) a tangential departure. In this way you can avoid dwell marks.



#### Starting point and end point

The starting point and the end point lie outside the workpiece, close to the first and last contour points. They are to be programmed without radius compensation.

#### Approach

- ▶ **G26** is entered after the block in which the first contour element is programmed: This will be the first block with radius compensation **G41/G42**

#### Departure

- ▶ **G27** after the block in which the last contour element is programmed: This will be the last block with radius compensation **G41/G42**











The radius for **G26** and **G27** must be selected so that the TNC can execute the circular path between the starting point and the first contour point, as well as the last contour point and the end point.

**Example NC blocks**

N50 G00 G40 G90 X-30 Y+50 *	Starting point
N60 G01 G41 X+0 Y+50 F350 *	First contour point
N70 G26 R5 *	Tangential approach with radius R = 5 mm
...	
<b>PROGRAM CONTOUR BLOCKS</b>	
...	Last contour point
N210 G27 R5 *	Tangential departure with radius R = 5 mm
N220 G00 G40 X-30 Y+50 *	End point

**Overview: Types of paths for contour approach and departure**

The functions for contour approach **APPR** and departure **DEP** are activated with the **APPR/DEP** key. You can then select the desired path function with the corresponding soft key:

Function	Approach	Departure
Straight line with tangential connection		
Straight line perpendicular to a contour point		
Circular arc with tangential connection		
Circular arc with tangential connection to the contour. Approach and departure to an auxiliary point outside the contour on a tangentially connecting line		

**Approaching and departing a helix**

The tool approaches and departs a helix on its extension by moving in a circular arc that connects tangentially to the contour. You program helical approach and departure with the **APPR CT** and **DEP CT** functions.

## Programming: Programming contours


### 6.3 Approaching and departing a contour

#### Important positions for approach and departure

- Starting point  $P_S$   
You program this position directly before the APPR block.  $P_S$  lies outside the contour and is approached without radius compensation (R0).
- Auxiliary point  $P_H$

Some of the paths for approach and departure go through an auxiliary point  $P_H$  that the TNC calculates from your input in the APPR or DEP block. The TNC moves from the current position to the auxiliary point  $P_H$  at the feed rate last programmed. If you have programmed **FMAX** (positioning at rapid traverse) in the last positioning block before the approach function, the TNC also approaches the auxiliary point  $P_H$  at rapid traverse.

- First contour point  $P_A$  and last contour point  $P_E$   
You program the first contour point  $P_A$  in the APPR block. The last contour point  $P_E$  can be programmed with any path function. If the APPR block also contains a Z axis coordinate, the TNC will first move the tool to  $P_H$  in the working plane, and then move it to the entered depth in the tool axis.
- End point  $P_N$   
The position  $P_N$  lies outside of the contour and results from your input in the DEP block. If the DEP block also contains a Z axis coordinate, the TNC will first move the tool to  $P_N$  in the working plane, and then move it to the entered depth in the tool axis.



Abbreviation	Meaning
APPR	Approach
DEP	Departure
L	Line
C	Circle
T	Tangential (smooth connection)
N	Normal (perpendicular)




The TNC does not check whether the programmed contour will be damaged when moving from the actual position to the auxiliary point  $P_H$ . Use the test graphics to check.

With the APPR LT, APPR LN and APPR CT functions, the TNC moves the tool from the actual position to the auxiliary point  $P_H$  at the feed rate/rapid traverse that was last programmed. With the APPR LCT function, the TNC moves to the auxiliary point  $P_H$  at the feed rate programmed with the APPR block. If no feed rate is programmed before the approach block, the TNC generates an error message.


### Approaching on a straight line with tangential connection: APPR LT

The tool moves on a straight line from the starting point  $P_S$  to an auxiliary point  $P_H$ . It then moves to the first contour point  $P_A$  on a straight line that connects tangentially to the contour. The auxiliary point  $P_H$  is separated from the first contour point  $P_A$  by the distance **LEN**.

- ▶ Use any path function to approach the starting point  $P_S$ .
- ▶ Initiate the dialog with the **APPR/DEP** key and **APPR LT** soft key:




- ▶ Coordinates of the first contour point  $P_A$
- ▶ **LEN**: Distance from the auxiliary point  $P_H$  to the first contour point  $P_A$
- ▶ Radius compensation **G41/G42** for machining



### Approaching on a straight line perpendicular to the first contour point: APPR LN

- ▶ Use any path function to approach the starting point  $P_S$ .
- ▶ Initiate the dialog with the **APPR/DEP** key and **APPR LN** soft key:



- ▶ Coordinates of the first contour point  $P_A$
- ▶ Length: Distance to the auxiliary point  $P_H$ . Always enter **LEN** as a positive value!
- ▶ Radius compensation **G41/G42** for machining

## Programming: Programming contours


### 6.3 Approaching and departing a contour

#### Approaching on a circular path with tangential connection: APPR CT


The tool moves on a straight line from the starting point  $P_S$  to an auxiliary point  $P_H$ . It then moves from  $P_H$  to the first contour point  $P_A$  following a circular arc that is tangential to the first contour element.

The arc from  $P_H$  to  $P_A$  is determined through the radius  $R$  and the center angle **CCA**. The direction of rotation of the circular arc is automatically derived from the tool path for the first contour element.

- ▶ Use any path function to approach the starting point  $P_S$ .
- ▶ Initiate the dialog with the **APPR/DEP** key and **APPR CT** soft key:



- ▶ Coordinates of the first contour point  $P_A$
- ▶ Radius  $R$  of the circular arc
  - If the tool should approach the workpiece in the direction defined by the radius compensation: Enter  $R$  as a positive value
  - If the tool should approach from the workpiece side: Enter  $R$  as a negative value.
- ▶ Center angle **CCA** of the arc
  - CCA can be entered only as a positive value.
  - Maximum input value  $360^\circ$
- ▶ Radius compensation **G41/G42** for machining




#### Approaching on a circular path with tangential connection from a straight line to the contour: APPR LCT

The tool moves on a straight line from the starting point  $P_S$  to an auxiliary point  $P_H$ . It then moves to the first contour point  $P_A$  on a circular arc. The feed rate programmed in the APPR block is effective for the entire path that the TNC traversed in the approach block (path  $P_S$  to  $P_A$ ).


If you have programmed the coordinates of all three principal axes  $X$ ,  $Y$  and  $Z$  in the approach block, the TNC moves the tool from the position defined before the APPR block simultaneously in all three axes to the auxiliary point  $P_H$  and then, only in the working plane, from  $P_H$  to  $P_A$ .

The arc is connected tangentially both to the line  $P_S$ – $P_H$  as well as to the first contour element. Once these lines are known, the radius then suffices to completely define the tool path.

- ▶ Use any path function to approach the starting point  $P_S$ .
- ▶ Initiate the dialog with the **APPR/DEP** key and **APPR LCT** soft key:



- ▶ Coordinates of the first contour point  $P_A$
- ▶ Radius  $R$  of the circular arc. Enter  $R$  as a positive value
- ▶ Radius compensation **G41/G42** for machining




### Departing in a straight line with tangential connection: DEP LT

The tool moves on a straight line from the last contour point  $P_E$  to the end point  $P_N$ . The line lies on the extension of the last contour element.  $P_N$  is separated from  $P_E$  by the distance **LEN**.

- ▶ Program the last contour element with the end point  $P_E$  and radius compensation
- ▶ Initiate the dialog with the **APPR/DEP** key and **DEP LT** soft key:




- ▶ **LEN**: Enter the distance from the last contour element  $P_E$  to the end point  $P_N$ .




### Departing in a straight line perpendicular to the last contour point: DEP LN

The tool moves on a straight line from the last contour point  $P_E$  to the end point  $P_N$ . The line departs on a perpendicular path from the last contour point  $P_E$ .  $P_N$  is separated from  $P_E$  by the distance **LEN** plus the tool radius.

- ▶ Program the last contour element with the end point  $P_E$  and radius compensation
- ▶ Initiate the dialog with the **APPR/DEP** key and **DEP LN** soft key:





- ▶ **LEN**: Enter the distance of the end point  $P_N$ . Remember: always enter **LEN** as a positive value!



### Departing on a circular path with tangential connection: DEP CT

The tool moves on a circular arc from the last contour point  $P_E$  to the end point  $P_N$ . The circular arc connects tangentially to the last contour element.

- ▶ Program the last contour element with the end point  $P_E$  and radius compensation
- ▶ Initiate the dialog with the **APPR/DEP** key and **DEP CT** soft key:
  - ▶ Center angle **CCA** of the arc
  - ▶ Radius **R** of the circular arc
    - If the tool should depart the workpiece in the direction opposite to the radius compensation: Enter **R** as a positive value.
    - If the tool should depart the workpiece in the direction **opposite** to the radius compensation: Enter **R** as a negative value.



## Programming: Programming contours

### 6.3 Approaching and departing a contour


#### Departing on a circular arc tangentially connecting the contour and a straight line: DEP LCT

The tool moves on a circular arc from the last contour point  $P_E$  to an auxiliary point  $P_H$ . It then moves on a straight line to the end point  $P_N$ . The arc is tangentially connected both to the last contour element and to the line from  $P_H$  to  $P_N$ . Once these lines are known, the radius  $R$  suffices to unambiguously define the tool path.

- ▶ Program the last contour element with the end point  $P_E$  and radius compensation
- ▶ Initiate the dialog with the **APPR/DEP** key and **DEP LCT** soft key:










- ▶ Enter the coordinates of the end point  $P_N$
- ▶ Radius  $R$  of the circular arc. Enter  $R$  as a positive value





## 6.4 Path contours - Cartesian coordinates

### Overview of path functions

Function	Path function key	Tool movement	Required input	Page
Straight line <b>L</b>		Straight line	Coordinates of the end point of the straight line	210
Chamfer: <b>CHF</b>		Chamfer between two straight lines	Chamfer side length	211
Circle center <b>CC</b>		None	Coordinates of the circle center or pole	213
Circular arc <b>C</b>		Circular arc around a circle center CC to an arc end point	Coordinates of the arc end point, direction of rotation	214
Circular arc <b>CR</b>		Circular arc with a certain radius	Coordinates of the arc end point, arc radius, direction of rotation	215
Kreisbogen <b>CT</b>		Circular arc with tangential connection to the preceding and subsequent contour elements	Coordinates of the arc end point	217
Corner rounding <b>RND</b>		Circular arc with tangential connection to the preceding and subsequent contour elements	Rounding radius R	212

### Programming path functions

You can program path functions conveniently by using the gray path function keys. In further dialogs, you are prompted by the TNC to make the required entries.



If you enter DIN/ISO functions via a connected USB keyboard, make sure that capitalization is active.

## Programming: Programming contours


### 6.4 Path contours - Cartesian coordinates

#### Straight line in rapid traverse G00 Straight line with feed rate G01 F

The TNC moves the tool in a straight line from its current position to the straight-line end point. The starting point is the end point of the preceding block.



- ▶ **Coordinates** of the end point of the straight line, if necessary
- ▶ **Radius compensation**
- ▶ **Feed rate F**
- ▶ **Miscellaneous function M**



#### Movement at rapid traverse

You can also use the **L** key to create a straight line block for a rapid traverse movement (**G00** block):

- ▶ Press the **L** key to open a program block for a linear movement
- ▶ Press the left arrow key to switch to the input range for G codes
- ▶ Press the **G0** soft key if you want to enter a rapid traverse movement

#### Example NC blocks

```
N70 G01 G41 X+10 Y+40 F200 M3 *
```

```
N80 G91 X+20 Y-15 *
```

```
N90 G90 X+60 G91 Y-10 *
```

#### Capture actual position

You can also generate a straight-line block (**G01** block) by using the **actual-position-capture** key:

- ▶ In the Manual Operation mode, move the tool to the position you want to capture
- ▶ Switch the screen display to Programming and Editing
- ▶ Select the program block after which you want to insert the L block



- ▶ Press the **actual-position-capture key**. The TNC generates an L block with the actual position coordinates.

### Inserting a chamfer between two straight lines

The chamfer enables you to cut off corners at the intersection of two straight lines.

- The line blocks before and after the **G24** block must be in the same working plane as the chamfer.
- The radius compensation before and after the **G24** block must be the same
- The chamfer must be machinable with the current tool



- ▶ **Chamfer side length:** Length of the chamfer, and if necessary:
- ▶ **Feed rate F** (effective only in **G24** block)

#### Example NC blocks

```
N70 G01 G41 X+0 Y+30 F300 M3 *
```


```
N80 X+40 G91 Y+5 *
```

```
N90 G24 R12 F250 *
```

```
N100 G91 X+5 G90 Y+0 *
```



You cannot start a contour with a **G24** block.  
 A chamfer is possible only in the working plane.  
 The corner point is cut off by the chamfer and is not part of the contour.  
 A feed rate programmed in the CHF block is effective only in that block. After the block, the previous feed rate becomes effective again.



## Programming: Programming contours

### 6.4 Path contours - Cartesian coordinates

#### Corner rounding G25

The **G25** function is used for rounding off corners.

The tool moves on an arc that is tangentially connected to both the preceding and subsequent contour elements.

The rounding arc must be machinable with the called tool.



- ▶ **Rounding radius:** Enter the radius of the arc, and if necessary:
- ▶ **Feed rate F** (effective only in the **G25** block)


#### Example NC blocks

```
5 L X+10 Y+40 RL F300 M3
```

```
6 L X+40 Y+25
```

```
7 RND R5 F100
```

```
8 L X+10 Y+5
```



In the preceding and subsequent contour elements, both coordinates must lie in the plane of the rounding arc. If you machine the contour without tool-radius compensation, you must program both coordinates in the working plane.

The corner point is cut off by the rounding arc and is not part of the contour.

A feed rate programmed in the **G25** block is effective only in that **G25** block. After the **G25** block, the previous feed rate becomes effective again.

You can also use an **G25** block for a tangential contour approach.


## Circle center I, J

You can define a circle center for circles that you have programmed with the **G02**, **G03** or **G05** function. This is done in the following ways:

- Entering the Cartesian coordinates of the circle center in the working plane, or
- Using the circle center defined in an earlier block, or
- Capturing the coordinates with the **actual-position-capture** key

SPEC  
FCT

- ▶ To program the circle center, press the SPEC FCT key
- ▶ Press the PROGRAM FUNCTIONS soft key
- ▶ Press the DIN/ISO soft key
- ▶ Press the I or J soft key
- ▶ Enter coordinates for the circle center or, if you want to use the last programmed position, **G29** coordinates



### Example NC blocks

```
N50 I+25 J+25 *
```

or

```
N10 G00 G40 X+25 Y+25 *
```

```
N20 G29 *
```

The program blocks 10 and 11 do not refer to the illustration.

### Validity

The circle center definition remains in effect until a new circle center is programmed.

### Entering the circle center incrementally

If you enter the circle center with incremental coordinates, you have programmed it relative to the last programmed position of the tool.



The only effect of **CC** is to define a position as circle center: The tool does not move to this position. The circle center is also the pole for polar coordinates.

## Programming: Programming contours

### 6.4 Path contours - Cartesian coordinates

#### Circular path C around circle center CC

Before programming a circular arc, you must first enter the circle center **I**, **J**. The last programmed tool position will be the starting point of the arc.

##### Direction of rotation

- In clockwise direction: **G02**
  - In counterclockwise direction: **G03**
  - Without programmed direction: **G05**. The TNC traverses the circular arc with the last programmed direction of rotation
- ▶ Move the tool to the circle starting point

- J** ▶ Enter the **coordinates** of the circle center
- I**
- C** ▶ Enter the **coordinates** of the arc end point, and if necessary:
- ▶ **Feed rate F**
  - ▶ **Miscellaneous function M**



The TNC normally makes circular movements in the active working plane. If you program circular arcs that do not lie in the active working plane, for example **G2 Z... X...** with a tool axis Z, and at the same time rotate this movement, then the TNC moves the tool in a spatial arc, which means a circular arc in 3 axes (software option 1).

#### Example NC blocks

```
N50 I+25 J+25 *
```

```
N60 G01 G42 X+45 Y+25 F200 M3 *
```

```
N70 G03 X+45 Y+25 *
```

#### Full circle



For the end point, enter the same point that you used for the starting point.



The starting and end points of the arc must lie on the circle.

Input tolerance: up to 0.016 mm (selected through the **circleDeviation** machine parameter).

Smallest possible circle that the TNC can traverse: 0.0016 µm.



### Circle G02/G03/G05 with defined radius


The tool moves on a circular path with the radius R.

#### Direction of rotation

- In clockwise direction: **G02**
- In counterclockwise direction: **G03**
- Without programmed direction: **G05**. The TNC traverses the circular arc with the last programmed direction of rotation



- ▶ **Coordinates** of the arc end point
- ▶ **Radius R** (the algebraic sign determines the size of the arc)
- ▶ **Miscellaneous function M**
- ▶ **Feed rate F**



#### Full circle

For a full circle, program two blocks in succession:

The end point of the first semicircle is the starting point of the second. The end point of the second semicircle is the starting point of the first.

#### Central angle CCA and arc radius R

The starting and end points on the contour can be connected with four arcs of the same radius:

Smaller arc:  $CCA < 180^\circ$

Enter the radius with a positive sign  $R > 0$

Larger arc:  $CCA > 180^\circ$

Enter the radius with a negative sign  $R < 0$

The direction of rotation determines whether the arc is curving outward (convex) or curving inward (concave):

Convex: Direction of rotation **G02** (with radius compensation **G41**)


Concave: Direction of rotation **G03** (with radius compensation **G41**)



The distance from the starting and end points of the arc diameter cannot be greater than the diameter of the arc.

The maximum radius is 99.9999 m.

You can also enter rotary axes A, B and C.



## Programming: Programming contours

### 6.4 Path contours - Cartesian coordinates

#### Example NC blocks

```
N100 G01 G41 X+40 Y+40 F200 M3 *
```

```
N110 G02 X+70 Y+40 R+20 * (ARC 1)
```

or


```
N110 G03 X+70 Y+40 R+20 * (ARC 2)
```

or

```
N110 G02 X+70 Y+40 R-20 * (ARC 3)
```

or

```
N110 G03 X+70 Y+40 R-20 * (ARC 4)
```





### Circle G06 with tangential connection

The tool moves on an arc that starts tangentially to the previously programmed contour element.

A transition between two contour elements is called tangential when there is no kink or corner at the intersection between the two contours—the transition is smooth.

The contour element to which the tangential arc connects must be programmed immediately before the **G06** block. This requires at least two positioning blocks.



- ▶ **Coordinates** of the arc end point, and if necessary:
- ▶ **Feed rate F**
- ▶ **Miscellaneous function M**

#### Example NC blocks

```
N70 G01 G41 X+0 Y+25 F300 M3 *
```


```
N80 X+25 Y+30 *
```

```
N90 G06 X+45 Y+20 *
```

```
G01 Y+0 *
```




A tangential arc is a two-dimensional operation: the coordinates in the **G06** block and in the contour element preceding it must be in the same plane of the arc!



## Programming: Programming contours


### 6.4 Path contours - Cartesian coordinates

#### Example: Linear movements and chamfers with Cartesian coordinates



<b>%LINEAR G71 *</b>	
<b>N10 G30 G17 X+0 Y+0 Z-20 *</b>	Define the workpiece blank for graphic workpiece simulation
<b>N20 G31 G90 X+100 Y+100 Z+0 *</b>	
<b>N30 T1 G17 S4000 *</b>	Call the tool in the spindle axis and with the spindle speed S
<b>N40 G00 G40 G90 Z+250 *</b>	Retract the tool in the spindle axis at rapid traverse
<b>N50 X-10 Y-10 *</b>	Pre-position the tool
<b>N60 G01 Z-5 F1000 M3 *</b>	Move to working depth at feed rate F = 1000 mm/min
<b>N70 G01 G41 X+5 Y+5 F300 *</b>	Approach the contour at point 1, activate radius compensation G41
<b>N80 G26 R5 F150 *</b>	Tangential approach
<b>N90 Y+95 *</b>	Move to point 2
<b>N100 X+95 *</b>	Point 3: first straight line for corner 3
<b>N110 G24 R10 *</b>	Program a chamfer with length 10 mm
<b>N120 Y+5 *</b>	Point 4: 2nd straight line for corner 3, 1st straight line for corner 4
<b>N130 G24 R20 *</b>	Program a chamfer with length 20 mm
<b>N140 X+5 *</b>	Move to last contour point 1, second straight line for corner 4
<b>N150 G27 R5 F500 *</b>	Tangential exit
<b>N160 G40 X-20 Y-20 F1000 *</b>	Retract the tool in the working plane, cancel radius compensation
<b>N170 G00 Z+250 M2 *</b>	Retract the tool, end program
<b>N99999999 %LINEAR G71 *</b>	

### Example: Circular movements with Cartesian coordinates




<b>%CIRCULAR G71 *</b>	
<b>N10 G30 G17 X+0 Y+0 Z-20 *</b>	Define the workpiece blank for graphic workpiece simulation
<b>N20 G31 G90 X+100 Y+100 Z+0 *</b>	
<b>N30 T1 G17 S4000 *</b>	Call the tool in the spindle axis and with the spindle speed S
<b>N40 G00 G40 G90 Z+250 *</b>	Retract the tool in the spindle axis at rapid traverse
<b>N50 X-10 Y-10 *</b>	Pre-position the tool
<b>N60 G01 Z-5 F1000 M3 *</b>	Move to working depth at feed rate F = 1000 mm/min
<b>N70 G01 G41 X+5 Y+5 F300 *</b>	Approach the contour at point 1, activate radius compensation G41
<b>N80 G26 R5 F150 *</b>	Tangential approach
<b>N90 Y+85 *</b>	Point 2: First straight line for corner 2
<b>N100 G25 R10 *</b>	Insert radius with R = 10 mm, feed rate: 150 mm/min
<b>N110 X+30 *</b>	Move to point 3: Starting point of the arc
<b>N120 G02 X+70 Y+95 R+30 *</b>	Move to point 4: End point of the arc with G02, radius 30 mm
<b>N130 G01 X+95 *</b>	Move to point 5
<b>N140 Y+40 *</b>	Move to point 6
<b>N150 G06 X+40 Y+5 *</b>	Move to point 7: End point of the arc, circular arc with tangential connection to point 6, TNC automatically calculates the radius
<b>N160 G01 X+5 *</b>	Move to last contour point 1
<b>N170 G27 R5 F500 *</b>	Depart the contour on a circular arc with tangential connection
<b>N180 G40 X-20 Y-20 F1000 *</b>	Retract the tool in the working plane, cancel radius compensation
<b>N190 G00 Z+250 M2 *</b>	Retract the tool in the tool axis, end of program
<b>N99999999 %CIRCULAR G71 *</b>	

## Programming: Programming contours

### 6.4 Path contours - Cartesian coordinates

#### Example: Full circle with Cartesian coordinates



<code>%C-CC G71 *</code>	
<code>N10 G30 G17 X+0 Y+0 Z-20 *</code>	Definition of workpiece blank
<code>N20 G31 G90 X+100 Y+100 Z+0 *</code>	
<code>N30 T1 G17 S3150 *</code>	Tool call
<code>N40 G00 G40 G90 Z+250 *</code>	Retract the tool
<code>N50 I+50 J+50 *</code>	Define the circle center
<code>N60 X-40 Y+50 *</code>	Pre-position the tool
<code>N70 G01 Z-5 F1000 M3 *</code>	Move to working depth
<code>N80 G41 X+0 Y+50 F300 *</code>	Approach starting point, radius compensation G41
<code>N90 G26 R5 F150 *</code>	Tangential approach
<code>N100 G02 X+0 *</code>	Move to the circle end point (= circle starting point)
<code>N110 G27 R5 F500 *</code>	Tangential exit
<code>N120 G01 G40 X-40 Y-50 F1000 *</code>	Retract the tool in the working plane, cancel radius compensation
<code>N130 G00 Z+250 M2 *</code>	Retract the tool in the tool axis, end of program
<code>N99999999 %C-CC G71 *</code>	

## 6.5 Path contours – Polar coordinates











### Overview

With polar coordinates you can define a position in terms of its angle **H** and its distance **R** relative to a previously defined pole **I, J**.

Polar coordinates are useful with:

- Positions on circular arcs
- Workpiece drawing dimensions in degrees, e.g. bolt hole circles

### Overview of path functions with polar coordinates

Function	Path function key	Tool movement	Required input	Page
Straight line <b>G10, G11</b>	 + 	Straight line	Polar radius, polar angle of the straight-line end point	222
Circular arc <b>G12, G13</b>	 + 	Circular path around circle center/pole to arc end point	Polar angle of the arc end point,	223
Circular arc <b>G15</b>	 + 	Circular path corresponding to active direction of rotation	Polar angle of the circle end point	223
Circular arc <b>G16</b>	 + 	Circular arc with tangential connection to the preceding contour element	Polar radius, polar angle of the arc end point	223
Helical interpolation	 + 	Combination of a circular and a linear movement	Polar radius, polar angle of the arc end point, coordinate of the end point in the tool axis	224

## Programming: Programming contours


### 6.5 Path contours – Polar coordinates

#### Zero point for polar coordinates: pole I, J

You can define the pole CC anywhere in the part program before blocks containing polar coordinates. Set the pole in the same way as you would program the circle center.

SPEC  
FCT

- ▶ To program a pole, press the SPEC FCT key.
- ▶ Press the PROGRAM FUNCTIONS soft key
- ▶ Press the DIN/ISO soft key
- ▶ Press the I or J soft key
- ▶ **Coordinates:** Enter Cartesian coordinates for the pole or, if you want to use the last programmed position, enter **G29**. Before programming polar coordinates, define the pole. You can only define the pole in Cartesian coordinates. The pole remains in effect until you define a new pole.



#### Example NC blocks

```
N120 I+45 J+45 *
```

#### Straight line in rapid traverse G10 Straight line with feed rate G11 F

The tool moves in a straight line from its current position to the straight-line end point. The starting point is the end point of the preceding block.

L

- ▶ **Polar coordinate radius R:** Enter the distance from the pole CC to the straight-line end point.

P

- ▶ **Polar coordinate angle H:** Angular position of the straight-line end point between  $-360^\circ$  and  $+360^\circ$

The sign of **H** depends on the angle reference axis:

- If the angle from the angle reference axis to **R** is counterclockwise: **H**>0
- If the angle from the angle reference axis to **R** is clockwise: **H**<0

#### Example NC blocks


```
N120 I+45 J+45 *
```

```
N130 G11 G42 R+30 H+0 F300 M3 *
```

```
N140 H+60 *
```

```
N150 G91 H+60 *
```

```
N160 G90 H+180 *
```



### Circular path G12/G13/G15 around pole I, J

The polar coordinate radius **R** is also the radius of the arc. **R** is defined by the distance from the starting point to the pole **I, J**. The last programmed tool position will be the starting point of the arc.

#### Direction of rotation


- In clockwise direction: **G12**
- In counterclockwise direction: **G13**
- Without programmed direction: **G15**. The TNC traverses the circular arc with the last programmed direction of rotation



- ▶ **Polar coordinate angle H**: Angular position of the arc end point between  $-99999.9999^\circ$  and  $+99999.9999^\circ$



- ▶ **Direction of rotation DR**



#### Example NC blocks

```
N180 I+25 J+25 *
```

```
N190 G11 G42 R+20 H+0 F250 M3 *
```

```
N200 G13 H+180 *
```



For incremental coordinates, enter the same sign for DR and PA.

### Circle G16 with tangential connection

The tool moves on a circular path, starting tangentially from a preceding contour element.




- ▶ **Polar coordinate radius R**: Distance between the arc end point and the pole **I, J**



- ▶ **Polar coordinate angle H**: Angular position of the arc end point.



The pole is **not** the center of the contour arc!



#### Example NC blocks

```
N120 I+40 J+35 *
```

```
N130 G01 G42 X+0 Y+35 F250 M3 *
```

```
N140 G11 R+25 H+120 *
```

```
N150 G16 R+30 H+30 *
```

```
N160 G01 Y+0 *
```


## Programming: Programming contours

### 6.5 Path contours – Polar coordinates

#### Helix

A helix is a combination of a circular movement in a main plane and a linear movement perpendicular to this plane. You program the circular path in a main plane.

A helix is programmed only in polar coordinates.



#### Application

- Large-diameter internal and external threads
- Lubrication grooves

#### Calculating the helix

To program a helix, you must enter the total angle through which the tool is to move on the helix in incremental dimensions, and the total height of the helix.

Thread revolutions n: Thread revolutions + overrun at start and end of thread

Total height h: Thread pitch P times thread revolutions n

Incremental total angle H: Thread revolutions x 360° + angle for beginning of thread + angle for thread overrun

Starting coordinate Z: Pitch P times (thread revolutions + thread overrun at start of thread)

#### Shape of the helix

The table below illustrates in which way the shape of the helix is determined by the work direction, direction of rotation and radius compensation.

Internal thread	Work direction	Direction of rotation	Radius compensation
Right-hand	Z+	G13	G41
Left-hand	Z+	G12	G42
Right-hand	Z-	G12	G42
Left-hand	Z-	G13	G41
External thread			
Right-hand	Z+	G13	G42
Left-hand	Z+	G12	G41
Right-hand	Z-	G12	G41
Left-hand	Z-	G13	G42




### Programming a helix



Always enter the same algebraic sign for the direction of rotation and the incremental total angle **G91 H**. The tool may otherwise move in a wrong path and damage the contour.

For the total angle **G91 H** you can enter a value of  $-99\,999.9999^\circ$  to  $+99\,999.9999^\circ$ .

- ▶ **Polar coordinates-angle:** Enter the total angle of tool traverse along the helix in incremental dimensions. **After entering the angle, specify the tool axis with an axis selection key.**
- ▶ **Coordinate:** Enter the coordinate for the height of the helix in incremental dimensions
- ▶ **Enter the radius compensation** according to the table



### Example NC blocks: Thread M6 x 1 mm with 5 revolutions

N120 I+40 J+25 \*

N130 G01 Z+0 F100 M3 \*


N140 G11 G41 R+3 H+270 \*

N150 G12 G91 H-1800 Z+5 \*

## Programming: Programming contours


### 6.5 Path contours – Polar coordinates

#### Example: Linear movement with polar coordinates



<b>%LINEARPO G71 *</b>	
<b>N10 G30 G17 X+0 Y+0 Z-20 *</b>	Definition of workpiece blank
<b>N20 G31 G90 X+100 Y+100 Z+0 *</b>	
<b>N30 T1 G17 S4000 *</b>	Tool call
<b>N40 G00 G40 G90 Z+250 *</b>	Define the datum for polar coordinates
<b>N50 I+50 J+50 *</b>	Retract the tool
<b>N60 G10 R+60 H+180 *</b>	Pre-position the tool
<b>N70 G01 Z-5 F1000 M3 *</b>	Move to working depth
<b>N80 G11 G41 R+45 H+180 F250 *</b>	Approach the contour at point 1
<b>N90 G26 R5 *</b>	Approach the contour at point 1
<b>N100 H+120 *</b>	Move to point 2
<b>N110 H+60 *</b>	Move to point 3
<b>N120 H+0 *</b>	Move to point 4
<b>N130 H-60 *</b>	Move to point 5
<b>N140 H-120 *</b>	Move to point 6
<b>N150 H+180 *</b>	Move to point 1
<b>N160 G27 R5 F500 *</b>	Tangential exit
<b>N170 G40 R+60 H+180 F1000 *</b>	Retract the tool in the working plane, cancel radius compensation
<b>N180 G00 Z+250 M2 *</b>	Retract in the spindle axis, end of program
<b>N99999999 %LINEARPO G71 *</b>	

## Example: Helix



<b>%HELIX G71 *</b>	
<b>N10 G30 G17 X+0 Y+0 Z-20 *</b>	Definition of workpiece blank
<b>N20 G31 G90 X+100 Y+100 Z+0 *</b>	
<b>N30 T1 G17 S1400 *</b>	Tool call
<b>N40 G00 G40 G90 Z+250 *</b>	Retract the tool
<b>N50 X+50 Y+50 *</b>	Pre-position the tool
<b>N60 G29 *</b>	Transfer the last programmed position as the pole
<b>N70 G01 Z-12,75 F1000 M3 *</b>	Move to working depth
<b>N80 G11 G41 R+32 H+180 F250 *</b>	Approach first contour point
<b>N90 G26 R2 *</b>	Connection
<b>N100 G13 G91 H+3240 Z+13.5 F200 *</b>	Helical traverse
<b>N110 G27 R2 F500 *</b>	Tangential exit
<b>N120 G01 G40 G90 X+50 Y+50 F1000 *</b>	Retract the tool, end program
<b>N130 G00 Z+250 M2 *</b>	



# 7

**Programming:  
Data transfer from  
DXF files or plain-  
language contours**

## Programming: Data transfer from DXF files or plain-language contours


### 7.1 Processing DXF Files (Software Option)

#### 7.1 Processing DXF Files (Software Option)

##### Application

DXF files created in a CAD system can be opened directly by the TNC, in order to extract contours or machining positions, and save them as conversational programs or as point files. Plain-language programs acquired in this manner can also be run by older TNC controls, since these contour programs contain only **L** and **CC/C** blocks.

If you process DXF files in the **Programming** operating mode, the TNC generates contour programs with the file extension **.H** and point files with the extension **.PNT** by default. If you process DXF files in the smart.NC operating mode, the TNC generates contour programs with the file extension **.HC** and point files with the extension **.HP** by default. However, you can choose the desired file type in the saving dialog. Furthermore, you can also save the selected contour or the selected machining positions to the clipboard of the TNC and then insert them directly in an NC program.



The DXF files to be processed must be stored on the hard disk of your TNC.

Before loading the file to the TNC, ensure that the name of the DXF file does not contain any blank spaces or impermissible special characters. See "File names", page 107.

The DXF file to be opened must contain at least one layer.

The TNC supports the most common DXF format, R12 (equivalent to AC1009).

The TNC does not support binary DXF format. When generating the DXF file from a CAD or drawing program, make sure that you save the file in ASCII format.

The following DXF elements can be selected as contours:

- LINE (straight line)
- CIRCLE (complete circle)
- ARC (circular arc)
- POLYLINE


## Opening a DXF file



- ▶ Select the Programming mode of operation



- ▶ Call the file manager



- ▶ In order to see the soft-key menu for selecting the file type to be displayed, press the **SELECT TYPE** soft key



- ▶ In order to show all DXF files, press the **SHOW DXF** soft key
- ▶ Select the directory in which the DXF file is saved



- ▶ Select the desired DXF file, and load it with the ENT key. The TNC starts the DXF converter and shows the contents of the DXF file on the screen. The TNC shows the layers in the left window, and the drawing in the right window

## Working with the DXF converter



You cannot use the DXF converter without a mouse. All operating modes and functions as well as contours and machining positions can only be selected with the mouse.







The DXF converter runs as a separate application on the third desktop of the TNC. This enables you to use the screen switchover key to switch between the machine operating modes, the programming modes and the DXF converter as desired. This is especially useful if you want to insert contours or machining positions in a plain-language program by copying through the clipboard.


## Programming: Data transfer from DXF files or plain-language contours

### 7.1 Processing DXF Files (Software Option)




#### Basic settings

The basic settings specified below are selected using the icons in the toolbar. The icons displayed may vary depending on the operating mode of the TNC.

Setting	Button
Set the zoom to the largest possible view	
Change colors (change the background color)	
Switch between 2-D and 3-D mode. If 3-D mode is active, you can rotate and tilt the view with the right mouse button	
Set the unit of measure (mm or inches) of the DXF file. The TNC then outputs the contour program and the machining positions in this unit of measure	
The resolution specifies how many decimal places the TNC should use when generating the contour program. Default setting: 4 decimal places (equivalent to resolution of 0.1 µm when the unit of measure MM is active).	
Select a contour for turning	





Setting	Button
<p>Contour transfer mode, set the tolerance: The tolerance specifies how far apart neighboring contour elements may be from each other. You can use the tolerance to compensate for inaccuracies that occurred when the drawing was made. The default setting depends on the extent of the entire DXF file</p>	
<p>The mode for point transfer on circles and circle segments determines whether the TNC automatically loads the circle center point when selecting machining positions via mouse click (OFF), or if additional points on the circle should be shown as well.</p> <ul style="list-style-type: none"> <li>■ OFF <b>Do not show</b> additional points on the circle. Assume the circle center point directly when a circle or arc is clicked</li> <li>■ ON <b>Show</b> additional points on the circle. Assume each desired circle point by clicking it</li> </ul>	
<p>Mode for point assumption: Specify whether the TNC should display the tool path during selection of machining positions.</p>	



Please note that you must set the correct unit of measure, since the DXF file does not contain any such information.

If you want to generate programs for older TNC controls, you must limit the resolution to three decimal places. In addition, you must remove the comments that the DXF converter inserts into the contour program.

The TNC displays the active basic settings in the footer of the screen.

## Programming: Data transfer from DXF files or plain-language contours

### 7.1 Processing DXF Files (Software Option)

#### Setting layers


As a rule, DXF files contain multiple layers, with which the designer organizes the drawings. The designer uses the layers to create groups of various types of elements, such as the actual workpiece contour, dimensions, auxiliary and design lines, shadings, and texts.

So that as little unnecessary information as possible appears on the screen during selection of the contours, you can hide all excessive layers contained in the DXF file.



The DXF file to be processed must contain at least one layer.

You can even select a contour if the designer has saved it on different layers.



- ▶ If it has not already been activated, select the mode for the layer settings. In the left window the TNC shows all layers contained in the active DXF file
- ▶ To hide a layer, select the layer with the left mouse button, and click its check box to hide it
- ▶ To show a layer, select the layer with the left mouse button, and click its check box again to show it

## Defining the datum

The datum of the drawing for the DXF file is not always located in a manner that lets you use it directly as a reference point for the workpiece. Therefore, the TNC has a function with which you can shift the drawing datum to a suitable location by clicking an element.


You can define a reference point at the following locations:

- At the beginning, end or center of a straight line
- At the beginning or end of a circular arc
- At the transition between quadrants or at the center of a complete circle
- At the intersection between:
  - A straight line and a straight line, even if the intersection is actually on the extension of one of the lines
  - Straight line – circular arc
  - Straight line – full circle
  - Circle – circle (regardless of whether a circular arc or a full circle)



You must use the touchpad on the TNC keyboard or a mouse attached via the USB port in order to specify a reference point.

You can also change the reference point once you have already selected the contour. The TNC does not calculate the actual contour data until you save the selected contour in a contour program.



## Programming: Data transfer from DXF files or plain-language contours

### 7.1 Processing DXF Files (Software Option)

#### Selecting a reference point on a single element



- ▶ Select the mode for specifying the reference point
- ▶ Click the element on which you want to set the reference point with the left mouse button. The TNC indicates possible locations for reference points on the selected element with stars
- ▶ Click the star you want to select as reference point: The TNC sets the datum symbol at the selected place. Use the zoom function if the selected element is too small.

#### Selecting a reference point on the intersection of two elements



- ▶ Select the mode for specifying the reference point
- ▶ Click the first element (straight line, complete circle or circular arc) with the left mouse button. The TNC indicates possible locations for reference points on the selected element with stars.
- ▶ Click the second element (straight line, complete circle or circular arc) with the left mouse button. The TNC sets the reference-point symbol on the intersection.



The TNC calculates the intersection of two elements even if it is on the extension of one of these elements.


If the TNC calculates multiple intersections, it selects the intersection nearest the mouse-click on the second element.

If the TNC cannot calculate an intersection, it rescinds the marking of the first element.

## Processing DXF Files (Software Option) 7.1

### Element information

At the bottom left of the screen, the TNC shows how far the reference point you have chosen is located from the drawing datum.



### Selecting and saving a contour




You must use the touchpad on the TNC keyboard or a mouse attached via the USB port in order to select a contour.

Specify the direction of rotation during contour selection so that it matches the desired machining direction.

Select the first contour element such that approach without collision is possible.

If the contour elements are very close to one another, use the zoom function.



## Programming: Data transfer from DXF files or plain-language contours

### 7.1 Processing DXF Files (Software Option)



- ▶ Select the mode for choosing a contour. The TNC hides the layers shown in the left window, and the right window becomes active for contour selection
- ▶ To select a contour element, click the desired contour element with the left mouse button. The selected contour element turns blue. At the same time, the TNC marks the selected element with a symbol (circle or line) in the left window
- ▶ To select the next contour element, click the desired contour element with the left mouse button. The selected contour element turns blue. If further contour elements in the selected machining sequence are clearly selectable, these elements turn green. Click on the last green element to assume all elements into the contour program. The TNC shows all selected contour elements in the left window. The TNC displays elements that are still green in the **NC** column without a check mark. The TNC does not save these elements to the contour program. You can also include the marked elements in the contour program by clicking in the left window
- ▶ If necessary you can also deselect elements that you already selected, by clicking the element in the right window again, but this time while pressing the **CTRL** key. You can deselect all selected elements by clicking the recycle bin icon



If you have selected polylines, the TNC shows a two-level ID number in the left window. The first number is the serial contour element number, the second element is the element number of the respective polyline from the DXF file.



- ▶ Save the selected contour elements to the clipboard of the TNC so that you can then insert the contour in a plain-language program, or



- ▶ To save the selected contour elements in a plain-language program, enter any file name and the target directory in the pop-up window displayed by the TNC. Default setting: Name of the DXF file. If the name of the DXF file contains special characters or spaces, the TNC replaces the characters with underscores. Alternately, you can also press the OK button: Plain language program (.H) or contour description (.HC)



- ▶ Confirm the entry: The TNC saves the contour program to the selected directory




- ▶ If you want to select more contours, press the Cancel Selected Elements soft key and select the next contour as described above.



The TNC also transfers two workpiece-blank definitions () to the contour program. The first definition contains the dimensions of the entire DXF file. The second one, which is the active one, contains only the selected contour elements, so that an optimized size of the workpiece blank results.

The TNC only saves elements that have actually been selected (blue elements), which means that they have been given a check mark in the left window.

When you save a file you can first add a bookmark for the file location Later you can select the bookmark if you want to save more files in the same directory. If you want to add a bookmark or select one, click the path information next to the symbol in the saving dialog box



. The TNC opens a menu in which you can manage the bookmarks.

## Programming: Data transfer from DXF files or plain-language contours

### 7.1 Processing DXF Files (Software Option)

#### Dividing, extending and shortening contour elements

If contour elements to be selected in the drawing connect poorly, then you must first divide the contour element. This function is automatically available if you are in the mode for selecting a contour.


Proceed as follows:

- ▶ The poorly connecting contour element is selected, so it is colored blue
- ▶ Click the contour element to be divided: The TNC shows the point of intersection with a star in a circle, and the selectable end points with simple stars
- ▶ Press the **CTRL** key and click the point of intersection: The TNC divides the contour element at the point of intersection and the stars disappear. If there is a gap, or the elements overlap, the TNC extends or shortens these poorly connecting contour elements to the point of intersection of the two elements
- ▶ Click the divided contour element again: The TNC shows the end points and points of intersection again
- ▶ Click the desired end point: The TNC now colors the divided element blue
- ▶ Select the next contour element



If the contour element to be extended or shortened is a straight line, then the TNC extends/shortens the contour element along the same line. If the contour element to be extended or shortened is a circular arc, then the TNC extends/shortens the contour element along the same arc.

In order to use this function, at least two contour elements must already be selected, so that the direction is clearly determined.





### Element information

At the bottom left of the screen, the TNC displays information about the contour element that you last selected via mouse click in the left or right window.

- End point of the straight line, and the starting point is grayed out.
- Circle center point, circle end point, and direction of rotation.  
Grayed out: the starting point and circle radius

### Select a contour for a turning operation

You can also use the DXF converter to select contours for turning. Before you enter a milling contour, you must set the datum to the rotation center. If you select a turning contour, it is saved with Z and X coordinates. In addition, all X coordinate values in turning contours are transferred as diameter values, i.e. the drawing dimensions for the X axis are doubled. All contour elements below the center of rotation are not selected and are saved in gray.



- ▶ Select the mode of a turning contour: The TNC shows only the selectable elements above the rotation center
- ▶ Use the left mouse key to select the desired contour elements: The TNC displays the selected contour elements in blue and shows the selected element with a symbol (circular or straight) in the left window

### Selecting and saving machining positions




You must use the touchpad on the TNC keyboard or a mouse attached via the USB port in order to select a machining position.

If the positions to be selected are very close to one another, use the zoom function.

If required, configure the basic settings so that the TNC shows the tool paths, See "Basic settings", page 232.

Three possibilities are available in the pattern generator for defining machining positions:

- Individual selection: You select the desired machining position through individual mouse clicks (See "Single selection", page 242)
- Quick selection of hole positions in an area defined by the mouse: By dragging the mouse to define an area, you can select all the hole positions within it ("Rapid selection of hole positions with the mouse area").
- Quick selection of hole positions by entering a diameter: By entering a hole diameter, you can select all hole positions with that diameter in the DXF file ("Rapid selection of hole positions by entering a diameter").



# Programming: Data transfer from DXF files or plain-language contours

## 7.1 Processing DXF Files (Software Option)

### Single selection



- ▶ Select the mode for choosing a machining position. The TNC hides the layers shown in the left window, and the right window becomes active for position selection
- ▶ To select a machining position, click the desired element with the left mouse button: The TNC indicates possible locations for machining positions on the selected element with stars. Click one of the stars: The TNC loads the selected position into the left window (displays a point symbol). If you click a circle, the TNC adopts the circle center as machining position
- ▶ If necessary you can also deselect elements that you already selected, by clicking the element in the right window again, but this time while pressing the **CTRL** key (click inside the marked area)
- ▶ If you want to specify the machining position at the intersection of two elements, click the first element with the left mouse button: the TNC displays stars at the selectable machining positions.
- ▶ Click the second element (straight line, complete circle or circular arc) with the left mouse button. The TNC loads the intersection of the elements into the left window (displays a point symbol).



- ▶ Save the selected machining positions to the clipboard of the TNC so that you can then insert them as a positioning block with cycle call in a plain-language program, or




- ▶ To save the selected machining positions to a point file, enter the target directory and any file name in the pop-up window displayed by the TNC. Default setting: Name of the DXF file. If the name of the DXF file contains special characters or spaces, the TNC replaces the characters with underscores. Alternately, you can also select the file type: Point table (**.PNT**), pattern generator table (**.HP**) or plain language program (**.H**). If you save the machining positions to a plain-language program, the TNC creates a separate linear block with cycle call for every machining position (**L X... Y... M99**). You can also transfer this program to old TNC controls and run it there.



- ▶ Confirm the entry. The TNC saves the contour program in the directory in which the DXF file is also saved



- ▶ If you want to select more machining positions in order to save them to a different file, press the Cancel selected elements icon and select as described above



### Rapid selection of hole positions with the mouse area



- ▶ Select the mode for choosing a machining position. The TNC hides the layers shown in the left window, and the right window becomes active for position selection
- ▶ Press the shift key on the keyboard and drag the left mouse key to define an area in which the TNC is to adopt all included circle centers as hole positions: the TNC opens a window in which you can filter the holes by size
- ▶ Configure the filter settings See "" and confirm with the **USE** soft key. The TNC loads the selected positions into the left window (and displays a point symbol)

- ▶ If necessary you can also deselect elements that you already selected, by dragging an area open again, but this time while pressing the **CTRL** key



- ▶ Save the selected machining positions to the clipboard of the TNC so that you can then insert them as a positioning block with cycle call in a plain-language program, or




- ▶ To save the selected machining positions to a point file, enter the target directory and any file name in the pop-up window displayed by the TNC. Default setting: Name of the DXF file. If the name of the DXF file contains special characters or spaces, the TNC replaces the characters with underscores. Alternately, you can also select the file type: Point table (.PNT), pattern generator table (.HP) or plain language program (.H). If you save the machining positions to a plain-language program, the TNC creates a separate linear block with cycle call for every machining position (**L X... Y... M99**). You can also transfer this program to old TNC controls and run it there.



- ▶ Confirm the entry. The TNC saves the contour program in the directory in which the DXF file is also saved



- ▶ If you want to select more machining positions in order to save them to a different file, press the Cancel selected elements icon and select as described above



## Programming: Data transfer from DXF files or plain-language contours

### 7.1 Processing DXF Files (Software Option)

#### Rapid selection of hole positions by entering a diameter



- ▶ Select the mode for choosing a machining position. The TNC hides the layers shown in the left window, and the right window becomes active for position selection



- ▶ Open the dialog for diameter input: enter any diameter in the pop-up window displayed by the TNC
- ▶ Enter the desired diameter and confirm it with the **ENT** key: the TNC searches the DXF file for the entered diameter and then shows a pop-up window with the diameter selected that is closest to the diameter you entered. Also, you can retroactively filter the holes according to size
- ▶ If required, configure the filter settings See "" and confirm with the **USE** soft key: The TNC loads the selected positions into the left window (and displays a point symbol)



- ▶ If necessary you can also deselect elements that you already selected, by dragging an area open again, but this time while pressing the **CTRL** key




- ▶ Save the selected machining positions to the clipboard of the TNC so that you can then insert them as a positioning block with cycle call in a plain-language program, or
- ▶ To save the selected machining positions to a point file, enter the target directory and any file name in the pop-up window displayed by the TNC. Default setting: Name of the DXF file. If the name of the DXF file contains special characters or spaces, the TNC replaces the characters with underscores. Alternately, you can also select the file type: Point table (**.PNT**), pattern generator table (**.HP**) or plain language program (**.H**). If you save the machining positions to a plain-language program, the TNC creates a separate linear block with cycle call for every machining position (**L X... Y... M99**). You can also transfer this program to old TNC controls and run it there.



- ▶ Confirm the entry. The TNC saves the contour program in the directory in which the DXF file is also saved



- ▶ If you want to select more machining positions in order to save them to a different file, press the Cancel selected elements icon and select as described above





### Filter settings

After you have used the quick selection function to mark hole positions, a pop-up window appears in which the smallest diameter found is to the left and the largest diameter to the right. With the buttons just below the diameter display you can adjust the smallest diameter in the left area and largest in the right area so that you can load the hole diameters that you want.

The following buttons are available:

Filter setting of smallest diameter	Button
Display the smallest diameter found (default setting)	
Display the next smaller diameter found	
Display the next larger diameter found	
Display the largest diameter found. The TNC sets the filter for the smallest diameter to the value set for the largest diameter	
Filter setting of largest diameter	Button
Display the smallest diameter found. The TNC sets the filter for the largest diameter to the value set for the smallest diameter	
Display the next smaller diameter found	
Display the next larger diameter found	
Display the largest diameter found (default setting)	

With the **apply path optimization** option on (default setting), the TNC sorts the selected machining positions for the most efficient possible tool path. You can have the tool paths displayed by clicking the "Show tool path" icon, See "Basic settings", page 232.




## Programming: Data transfer from DXF files or plain-language contours

### 7.1 Processing DXF Files (Software Option)



#### Element information

At the bottom left of the screen, the TNC displays the coordinates of the machining position that you last selected via mouse click in the left or right window



#### Undoing actions

You can undo the four most recent actions that you have taken in the mode for selecting machining positions. The following icons are available:

Function	Button
Undo the most recently conducted action	
Repeat the most recently conducted action	

#### Mouse functions

Use the mouse for magnifying and reducing as follows:

- Define the zoom area by dragging the mouse with the left button depressed
- If you have a wheel mouse, you can use it to zoom in and out. The zooming center is the location of the mouse pointer
- Click the magnifying glass icon or double-click with the right mouse button to reset the view to the default setting

You can move the current view by pressing and holding the center mouse button.

If 3-D mode is active, you can rotate and tilt the view by pressing and holding the right mouse button.

Deselecting selected positions:

- To deselect two or more selected positions, press and hold the Ctrl key and open a box with the left mouse key
- To deselect individual positions, press and hold the Ctrl key and click them individually

# 8

**Programming:  
Subprograms and  
program section  
repeats**

## Programming: Subprograms and program section repeats

### 8.1 Labeling Subprograms and Program Section Repeats

#### 8.1 Labeling Subprograms and Program Section Repeats

Subprograms and program section repeats enable you to program a machining sequence once and then run it as often as necessary.

##### Label

The beginnings of subprograms and program section repeats are marked in a part program by labels (**G98 L**).

A LABEL is identified by a number between 1 and 999 or by a name you define. Each LABEL number or LABEL name can be set only once in the program with the **LABEL SET** key or by entering **G98**. The number of label names you can enter is only limited by the internal memory.



Do not use a label number or label name more than once!


Label 0 (**G98 L0**) is used exclusively to mark the end of a subprogram and can therefore be used as often as desired.



## 8.2 Subprograms

### Operating sequence

- 1 The TNC executes the part program up to calling a subprogram, **Ln.0**.
- 2 The subprogram is then executed from beginning to end, **G98 L0**.
- 3 The TNC then resumes the part program from the block after the subprogram call **Ln.0**



### Programming notes

- A main program can contain up to 254 subprograms
- You can call subprograms in any sequence and as often as desired
- A subprogram cannot call itself
- Write subprograms at the end of the main program (behind the block with M2 or M30)
- If subprograms are located before the block with M2 or M30, they will be executed at least once even if they are not called

### Programming a subprogram

LBL  
SET

- ▶ To mark the beginning, press the LBL SET key
- ▶ Enter the subprogram number. If you want to use a label name, press the **lbl name** soft key to switch to text entry
- ▶ To mark the end, press the LBL SET key and enter the label number "0"

## Programming: Subprograms and program section repeats

### 8.2 Subprograms

#### Calling a subprogram

LBL  
CALL

- ▶ To call a subprogram, Press the LBL CALL key
- ▶ **Label number:** Enter the label number of the subprogram you wish to call. If you want to use a label name, press the **lbl name** soft key to switch to text entry.
- ▶ If you want to enter the number of a string parameter as target address, press the QS soft key. The TNC will then jump to the label name that is specified in the defined string parameter




**G98 L 0** is not permitted (Label 0 is only used to mark the end of a subprogram).

## 8.3 Program-section repeats

### Label G98

The beginning of a program section repeat is marked by the label **G98 L**. The end of a program section repeat is identified by **Ln,m**.



### Operating sequence

- 1 The TNC executes the part program up to the end of the program section (**Ln,m**)
- 2 Then the program section between the called LABEL and the label call **Ln,m** is repeated the number of times entered after **M**
- 3 The TNC resumes the part program after the last repetition.

### Programming notes

- You can repeat a program section up to 65 534 times in succession
- The total number of times the program section is executed is always one more than the programmed number of repeats

### Programming a program section repeat



- ▶ To mark the beginning, press the LBL SET key and enter a LABEL NUMBER for the program section you wish to repeat. If you want to use a label name, press the **lbl name** soft key to switch to text entry
- ▶ Enter the program section

### 8.3 Program-section repeats

#### Calling a program section repeat

LBL  
CALL

- ▶ Press the LBL CALL key
- ▶ **To call subprograms/section repeats:** Enter the label number of the subprogram to be called, then confirm with the **ent** key. If you want to use a label name, press the " key to switch to text entry. If you want to enter the number of a string parameter as target address: Press the QS soft key; the TNC will then jump to the label name that is specified in the string parameter defined.
- ▶ **Repeat REP:** Enter the number of repeats, then confirm with the **ENT** key.


## 8.4 Any desired program as subprogram

### Operating sequence



If you want to program variable program calls in connection with string parameters, use the SEL PGM function.

- 1 The TNC executes the part program up to the block in which another program is called with **%**.
- 2 Then the other program is run from beginning to end.
- 3 The TNC then resumes the first part program (i.e. the calling program) with the block after the program call.






### Programming notes

- No labels are needed to call any program as a subprogram
- The called program must not contain the miscellaneous functions M2 or M30. If you have defined subprograms with labels in the called program, you can then use M2 or M30 with the **D09 P01 +0 P02 +0 P03 99** jump function to force a jump over this program section
- The called program must not contain a **%** call into the calling program, otherwise an infinite loop will result

## Programming: Subprograms and program section repeats

### 8.4 Any desired program as subprogram

#### Calling any program as a subprogram

- 
  - ▶ To select the functions for program call, press the **PGM CALL** key
- 
  - ▶ Press the **PROGRAM** soft key: The TNC starts the dialog for defining the program to be called. Use the screen keyboard to enter the path name (**GOTO** key), or
- 
  - ▶ press the SELECT PROGRAM soft key for the TNC to display a selection window in which you can select the program to be called. Confirm with the **END** key



If the program you want to call is located in the same directory as the program you are calling it from, then you only need to enter the program name.

If the called program is not located in the same directory as the program you are calling it from, you must enter the complete path, e.g. **TNC: \ZW35\SCHRUPP\PGM1.H**

If you want to call a DIN/ISO program, enter the file type .I after the program name.

You can also call a program with Cycle **G39**.

As a rule, Q parameters are effective globally with a %. So please note that changes to Q parameters in the called program can also influence the calling program.



#### **Danger of collision!**

Coordinate transformations that you define in the called program remain in effect for the calling program too, unless you reset them.

## 8.5 Nesting

### Types of nesting

- Subprograms within a subprogram
- Program section repeats within a program section repeat
- Subprograms repeated
- Program section repeats within a subprogram

### Nesting depth

The nesting depth is the number of successive levels in which program sections or subprograms can call further program sections or subprograms.

- Maximum nesting depth for subprograms: 19
- Maximum nesting depth for main program calls: 19, where a **G79** acts like a main program call
- You can nest program section repeats as often as desired

## Programming: Subprograms and program section repeats

### 8.5 Nesting

#### Subprogram within a subprogram

##### Example NC blocks

<b>%UPGMS G71 *</b>	
...	
<b>N17 L "UP1",O *</b>	Subprogram at label G98 L1 is called
...	
<b>N35 G00 G40 Z+100 M2 *</b>	Last program block of the main program (with M2)
<b>N36 G98 L "UP1"</b>	Beginning of subprogram SP1
...	
<b>N39 L2,O *</b>	Subprogram at label G98 L2 is called
...	
<b>N45 G98 L0 *</b>	End of subprogram 1
<b>N46 G98 L2 *</b>	Beginning of subprogram 2
...	
<b>N62 G98 L0 *</b>	End of subprogram 2
<b>N99999999 %UPGMS G71 *</b>	

##### Program execution

- 1 Main program UPGMS is executed up to block 17.
- 2 Subprogram SP1 is called, and executed up to block 39.
- 3 Subprogram 2 is called, and executed up to block 62. End of subprogram 2 and return jump to the subprogram from which it was called.
- 4 Subprogram 1 is called, and executed from block 40 up to block 45. End of subprogram 1 and return jump to the main program UPGMS.
- 5 Main program UPGMS is executed from block 18 up to block 35. Return jump to block 1 and end of program.



## Repeating program section repeats

### Example NC blocks

<b>%REPS G71 *</b>	
...	
<b>N15 G98 L1 *</b>	Beginning of program section repeat 1
...	
<b>N20 G98 L2 *</b>	Beginning of program section repeat 2
...	
<b>N27 L2,2 *</b>	Program section between this block and G98 L2
...	(block N20) is repeated twice
<b>N35 L1,1 *</b>	Program section between this block and G98 L1
...	(block N15) is repeated once
<b>N99999999 %REPS G71 *</b>	

### Program execution

- 1 Main program REPS is executed up to block 27.
- 2 Program section between block 27 and block 20 is repeated twice.
- 3 Main program REPS is executed from block 28 to block 35.
- 4 Program section between block 35 and block 15 is repeated once (including the program section repeat between 20 and block 27).
- 5 Main program REPS is executed from block 36 to block 50 (end of program).

## Programming: Subprograms and program section repeats

### 8.5 Nesting

#### Repeating a subprogram

##### Example NC blocks

<b>%UPGREP G71 *</b>	
...	
<b>N10 G98 L1 *</b>	Beginning of program section repeat 1
<b>N11 L2,0 *</b>	Subprogram call
<b>N12 L1,2 *</b>	Program section between this block and G98 L1
...	(block N10) is repeated twice
<b>N19 G00 G40 Z+100 M2 *</b>	Last block of the main program with M2
<b>N20 G98 L2 *</b>	Beginning of subprogram
...	
<b>N28 G98 L0 *</b>	End of subprogram
<b>N99999999 %UPGREP G71 *</b>	

##### Program execution


- 1 Main program UPGREP is executed up to block 11.
- 2 Subprogram 2 is called and executed.
- 3 Program section between block 12 and block 10 is repeated twice. This means that subprogram 2 is repeated twice.
- 4 Main program UPGREP is executed from block 13 to block 19.  
End of program.

## 8.6 Programming examples

### Example: Milling a contour in several infeeds

Program sequence:

- Pre-position the tool to the workpiece surface
- Enter the infeed depth in incremental values
- Contour milling
- Repeat infeed and contour-milling



<code>%PGMREP G71 *</code>	
<code>N10 G30 G17 X+0 Y+0 Z-40 *</code>	
<code>N20 G31 G90 X+100 Y+100 Z+0 *</code>	
<code>N30 T1 G17 S3500 *</code>	Tool call
<code>N40 G00 G40 G90 Z+250 *</code>	Retract the tool
<code>N50 I+50 J+50 *</code>	Set pole
<code>N60 G10 R+60 H+180 *</code>	Pre-position in the working plane
<code>N70 G01 Z+0 F1000 M3 *</code>	Pre-position to the workpiece surface
<code>N80 G98 L1 *</code>	Set label for program section repeat
<code>N90 G91 Z-4 *</code>	Infeed depth in incremental values (in space)
<code>N100 G11 G41 G90 R+45 H+180 F250 *</code>	First contour point
<code>N110 G26 R5 *</code>	Contour approach
<code>N120 H+120 *</code>	
<code>N130 H+60 *</code>	
<code>N140 H+0 *</code>	
<code>N150 H-60 *</code>	
<code>N160 H-120 *</code>	
<code>N170 H+180 *</code>	
<code>N180 G27 R5 F500 *</code>	Contour departure
<code>N190 G40 R+60 H+180 F1000 *</code>	Retract tool
<code>N200 L1,4 *</code>	Return jump to label 1; section is repeated a total of 4 times
<code>N200 G00 Z+250 M2 *</code>	Retract the tool, end program
<code>N99999999 %PGMWDH G71 *</code>	


## Programming: Subprograms and program section repeats

### 8.6 Programming examples

#### Example: Groups of holes

Program sequence:

- Approach the groups of holes in the main program
- Call the group of holes (subprogram 1)
- Program the group of holes only once in subprogram 1




<code>%SP1 G71 *</code>	
<code>N10 G30 G17 X+0 Y+0 Z-40 *</code>	
<code>N20 G31 G90 X+100 Y+100 Z+0 *</code>	
<code>N30 T1 G17 S3500 *</code>	Tool call
<code>N40 G00 G40 G90 Z+250 *</code>	Retract the tool
<code>N50 G200 DRILLING</code>	Define the DRILLING cycle
<code>Q200=2 ;SET-UP CLEARANCE</code>	
<code>Q201=-30 ;DEPTH</code>	
<code>Q206=300 ;FEED RATE FOR PLNGNG</code>	
<code>Q202=5 ;PLUNGING DEPTH</code>	
<code>Q210=0 ;DWELL TIME AT TOP</code>	
<code>Q203=+0 ;SURFACE COORDINATE</code>	
<code>Q204=2 ;2ND SET-UP CLEARANCE</code>	
<code>Q211=0 ;DWELL TIME AT BOTTOM</code>	
<code>N60 X+15 Y+10 M3 *</code>	Move to starting point for group 1
<code>N70 L1,0 *</code>	Call the subprogram for the group
<code>N80 X+45 Y+60 *</code>	Move to starting point for group 2
<code>N90 L1,0 *</code>	Call the subprogram for the group
<code>N100 X+75 Y+10 *</code>	Move to starting point for group 3
<code>N110 L1,0 *</code>	Call the subprogram for the group
<code>N120 G00 Z+250 M2 *</code>	End of main program
<code>N130 G98 L1 *</code>	Beginning of subprogram 1: Group of holes
<code>N140 G79 *</code>	Call cycle for 1st hole
<code>N150 G91 X+20 M99 *</code>	Move to 2nd hole, call cycle
<code>N160 Y+20 M99 *</code>	Move to 3rd hole, call cycle
<code>N170 X-20 G90 M99 *</code>	Move to 4th hole, call cycle
<code>N180 G98 L0 *</code>	End of subprogram 1
<code>N99999999 %UP1 G71 *</code>	

### Example: Group of holes with several tools

Program sequence:

- Program the fixed cycles in the main program
- Call the entire hole pattern (subprogram 1)
- Approach the groups of holes in subprogram 1, call group of holes (subprogram 2)
- Program the group of holes only once in subprogram 2



<b>%SP2 G71 *</b>	
<b>N10 G30 G17 X+0 Y+0 Z-40 *</b>	
<b>N20 G31 G90 X+100 Y+100 Z+0 *</b>	
<b>N30 T1 G17 S5000 *</b>	Call tool: center drill
<b>N40 G00 G40 G90 Z+250 *</b>	Retract the tool
<b>N50 G200 DRILLING</b>	Define the CENTERING cycle
<b>Q200=2 ;SET-UP CLEARANCE</b>	
<b>Q201=-3 ;DEPTH</b>	
<b>Q206=250 ;FEED RATE FOR PLNGNG</b>	
<b>Q202=3 ;PLUNGING DEPTH</b>	
<b>Q210=0 ;DWELL TIME AT TOP</b>	
<b>Q203=+0 ;SURFACE COORDINATE</b>	
<b>Q204=10 ;2ND SET-UP CLEARANCE</b>	
<b>Q211=0.2 ;DWELL TIME AT BOTTOM</b>	
<b>N60 L1,0 *</b>	Call subprogram 1 for the entire hole pattern
<b>N70 G00 Z+250 M6 *</b>	Tool change
<b>N80 T2 G17 S4000 *</b>	Call tool: drill
<b>N90 D0 Q201 P01 -25 *</b>	New depth for drilling
<b>N100 D0 Q202 P01 +5 *</b>	New plunging depth for drilling
<b>N110 L1,0 *</b>	Call subprogram 1 for the entire hole pattern
<b>N120 G00 Z+250 M6 *</b>	Tool change
<b>N130 T3 G17 S500 *</b>	Call tool: reamer
<b>N140 G201 REAMING</b>	Cycle definition: REAMING
<b>Q200=2 ;SET-UP CLEARANCE</b>	
<b>Q201=-15 ;DEPTH</b>	
<b>Q206=250 ;FEED RATE FOR PLNGNG</b>	
<b>Q211=0.5 ;DWELL TIME AT BOTTOM</b>	
<b>Q208=400 ;RETRACTION FEED RATE</b>	
<b>Q203=+0 ;SURFACE COORDINATE</b>	
<b>Q204=10 ;2ND SET-UP CLEARANCE</b>	
<b>N150 L1,0 *</b>	Call subprogram 1 for the entire hole pattern
<b>N160 G00 Z+250 M2 *</b>	End of main program

## Programming: Subprograms and program section repeats

### 8.6 Programming examples

N170 G98 L1 *	Beginning of subprogram 1: Entire hole pattern
N180 G00 G40 G90 X+15 Y+10 M3 *	Move to starting point for group 1
N190 L2,0 *	Call subprogram 2 for the group
N200 X+45 Y+60 *	Move to starting point for group 2
N210 L2,0 *	Call subprogram 2 for the group
N220 X+75 Y+10 *	Move to starting point for group 3
N230 L2,0 *	Call subprogram 2 for the group
N240 G98 L0 *	End of subprogram 1
N250 G98 L2 *	Beginning of subprogram 2: Group of holes
N260 G79 *	Call cycle for 1st hole
N270 G91 X+20 M99 *	Move to 2nd hole, call cycle
N280 Y+20 M99 *	Move to 3rd hole, call cycle
N290 X-20 G90 M99 *	Move to 4th hole, call cycle
N300 G98 L0 *	End of subprogram 2
N310 %UP2 G71 *	

# 9

**Programming: Q  
Parameters**

## Programming: Q Parameters

### 9.1 Principle and overview of functions

#### 9.1 Principle and overview of functions


You can program entire families of parts in a single part program. You do this by entering variables called Q parameters instead of fixed numerical values.

Q parameters can represent information such as:

- Coordinate values
- Feed rates
- Spindle speeds
- Cycle data

Q parameters also enable you to program contours that are defined with mathematical functions. You can also use Q parameters to make the execution of machining steps depend on logical conditions.

Q parameters are designated by letters and a number between 0 and 1999. Parameters that take effect in different manners are available. Please refer to the following table:



Meaning	Range
Freely applicable parameters, as long as no overlapping with SL cycles can occur. They are globally effective for all programs stored in the TNC memory.	<b>Q0 to Q99</b>
Parameters for special TNC functions	<b>Q100 to Q199</b>
Parameters that are primarily used for cycles, globally effective for all programs stored in the TNC memory	<b>Q200 to Q1199</b>
Parameters that are primarily used for OEM cycles, and are globally effective for all programs stored in the TNC memory. This may require coordination with the machine manufacturer or supplier	<b>Q1200 to Q1399</b>
Parameters that are primarily used for <b>call-active</b> OEM cycles, globally effective for all programs that are stored in the TNC memory	<b>Q1400 to Q1499</b>
Parameters that are primarily used for <b>Def-active</b> OEM cycles, globally effective for all programs that are stored in the TNC memory	<b>Q1500 to Q1599</b>



Meaning	Range
Freely applicable parameters, globally effective for all programs stored in the TNC memory	<b>Q1600 to Q1999</b>
Freely usable <b>QL</b> parameters, only effective locally (within a program)	<b>QL0 to QL499</b>
Freely usable <b>QR</b> parameters that are nonvolatile, i.e. they remain in effect even after a power interruption	<b>QR0 to QR499</b>

**QS** parameters (the **S** stands for string) are also available on the TNC and enable you to process texts. In principle, the same ranges are available for **QS** parameters as for Q parameters (see table above).



Note that for the **QS** parameters the **QS100 to QS199** range is reserved for internal texts. Local parameters QL are only effective within the respective program, and are not applied as part of program calls or macros.

### Programming notes

You can mix Q parameters and fixed numerical values within a program.

Q parameters can be assigned numerical values between -999 999 999 and +999 999 999. The input range is limited to 15 digits, of which 9 may be before the decimal point. Internally the TNC calculates numbers up to a value of  $10^{10}$ .

You can assign a maximum of 254 characters to **QS** parameters.



The TNC always assigns some Q and QS parameters the same data. For example, **Q108** is always assigned the current tool radius, See " Preassigned Q parameters", page 316.







The TNC saves numerical values internally in a binary number format (standard IEEE 754). Due to this standardized format some decimal numbers do not have an exact binary representation (round-off error). Keep this in mind especially when you use calculated Q-parameter contents for jump commands or positioning movements.

## Programming: Q Parameters

### 9.1 Principle and overview of functions

#### Calling Q parameter functions

When you are writing a part program, press the “Q” key (in the numeric keypad for numerical input and axis selection, below the +/- key). The TNC then displays the following soft keys:

Function group	Soft key	Page
Basic arithmetic (assign, add, subtract, multiply, divide, square root)		268
Trigonometric functions		270
If/then conditions, jumps		271
Other functions		274
Entering formulas in the part program		301
Function for machining complex contours		See User's Manual for Cycles



The TNC shows the soft keys Q, QL and QR when you are defining or assigning a Q parameter. First press one of these soft keys to select the desired type of parameter, and then enter the parameter number.

If you have a USB keyboard connected, you can press the Q key to open the dialog for entering a formula.

## 9.2 Part families—Q parameters in place of numerical values

### Application

The Q parameter function **D0: ASSIGN** assigns numerical values to Q parameters. This enables you to use variables in the program instead of fixed numerical values.

### Example NC blocks


<b>N150 D00 Q10 P01 +25 *</b>	Assign
...	Q10 is assigned the value 25
<b>N250 G00 X +Q10 *</b>	Corresponds to G00 X +25

You need write only one program for a whole family of parts, entering the characteristic dimensions as Q parameters.

To program a particular part, you then assign the appropriate values to the individual Q parameters.

### Example: Cylinder with Q parameters

Cylinder radius:	$R = Q1$
Cylinder height:	$H = Q2$
Cylinder Z1:	$Q1 = +30$ $Q2 = +10$
Cylinder Z2:	$Q1 = +10$ $Q2 = +50$



## Programming: Q Parameters

### 9.3 Describing contours with mathematical functions







### 9.3 Describing contours with mathematical functions

#### Application

The Q parameters listed below enable you to program basic mathematical functions in a part program:

- ▶ Select a Q-parameter function: Press the Q key (in the numerical keypad at right). The Q-parameter functions are displayed in a soft-key row
- ▶ Select the mathematical functions: Press the **BASIC ARITHMETIC** soft key. The TNC then displays the following soft keys:

#### Overview

Function	Soft key
<b>D00: ASSIGN</b> e.g. <b>D00 Q5 P01 +60 *</b> Directly assign value	
<b>D01: ADDITION</b> z.B. <b>D01 Q1 P01 -Q2 P02 -5 *</b> Form and assign sum from two values	
<b>D02: SUBTRACTION</b> e.g. <b>D02 Q1 P01 +10 P02 +5 *</b> Form and assign difference between two values	
<b>D03: MULTIPLICATION</b> e.g. <b>D03 Q2 P01 +3 P02 +3 *</b> Form and assign the product of two values	
<b>D04: DIVISION</b> e.g. <b>D04 Q4 P01 +8 P02 +Q2 *</b> Form and assign the quotient of two values <b>Not permitted:</b> Division by 0	
<b>D05: SQUARE ROOT</b> e.g. <b>D05 Q50 P01 4 *</b> Form and assign the square root of a value <b>Not permitted:</b> Square root from negative value	




To the right of the "=" character you can enter the following:

- Two numbers
- Two Q parameters
- A number and a Q parameter

The Q parameters and numerical values in the equations can be entered with positive or negative signs.

## Programming fundamental operations

### Example 1


-  ▶ To select the Q parameter function, press the Q key.
-  ▶ To select the mathematical functions, press the BASIC ARITHMETIC soft key.
-  ▶ To select the Q parameter function ASSIGN, Press the D0 X=Y soft key

### Program blocks in the TNC


```
N17 D00 Q5 P01 +10 *
```

```
N17 D03 Q12 P01 +Q5 P02 +7 *
```




### PARAMETER NUMBER FOR RESULT?

-  ▶ **12** Enter the Q parameter number and confirm with the **ENT** key


### FIRST VALUE / PARAMETER?

-  ▶ Enter **10**: Assign the numerical value 10 to Q5 and confirm with the **ENT** soft key.


### Example 2

-  ▶ To select the Q parameter function, press the Q key.
-  ▶ To select the mathematical functions, press the BASIC ARITHMETIC soft key.
-  ▶ To select the Q parameter function MULTIPLICATION, Press D3 X \* Y soft key


### PARAMETER NUMBER FOR RESULT?

-  ▶ **12** Enter the Q parameter number and confirm with the **ENT** key

### FIRST VALUE / PARAMETER?

-  ▶ Enter **Q5** as the first value and confirm with the **ENT** key.

### SECOND VALUE / PARAMETER?

-  ▶ Enter **7** as the second value and confirm with the **ENT** key.

## Programming: Q Parameters

### 9.4 Angle functions (trigonometry)

#### 9.4 Angle functions (trigonometry)

##### Definitions

**Sine:**  $\sin \alpha = a / c$

**Cosine:**  $\cos \alpha = b / c$


**Tangent:**  $\tan \alpha = a / b = \sin \alpha / \cos \alpha$

where

- c is the side opposite the right angle
- a is the side opposite the angle  $\alpha$
- b is the third side.

The TNC can find the angle from the tangent:

$$\alpha = \arctan (a / b) = \arctan (\sin \alpha / \cos \alpha)$$



##### Example:

a = 25 mm

b = 50 mm

$$\alpha = \arctan (a / b) = \arctan 0.5 = 26.57^\circ$$

Furthermore:

$$a^2 + b^2 = c^2 \text{ (where } a^2 = a \times a \text{)}$$

$$c = \sqrt{a^2 + b^2}$$

#### Programming trigonometric functions

Press the ANGLE FUNCTION soft key to call the trigonometric functions. The TNC then displays the soft keys below.

Programming: Compare "Example: Programming fundamental operations."

Function	Soft key
<b>D06: SINE</b> e.g. <b>D06 Q20 P01 -Q5 *</b> Define and assign the sine of an angle in degrees (°)	
<b>D07: COSINE</b> e.g. <b>D07 Q21 P01 -Q5 *</b> Define and assign the cosine of an angle in degrees (°)	
<b>D08: SQUARE ROOT FROM SQUARE SUM</b> e.g. <b>D08 Q10 P01 +5 P02 +4 *</b> Form and assign length from two values	
<b>D13: ANGLE</b> e.g. <b>D13 Q20 P01 +10 P02 -Q1 *</b> Form and assign an angle with arctan from two sides or with sine and cosine of the angle (0 < angle < 360°)	

## 9.5 If-then decisions with Q parameters

### Application

The TNC can make logical if-then decisions by comparing a Q parameter with another Q parameter or with a numerical value. If the condition is fulfilled, the TNC continues the program at the label that is programmed after the condition (for information on labels, See "Labeling Subprograms and Program Section Repeats", page 248). If it is not fulfilled, the TNC continues with the next block.

To call another program as a subprogram, enter a % program call after the block with the target label.





### Unconditional jumps

An unconditional jump is programmed by entering a conditional jump whose condition is always true. Example:

**D09 P01 +10 P02 +10 P03 1 \***

### Programming if-then decisions

Press the JUMP soft key to call the if-then conditions. The TNC then displays the following soft keys:

Function	Soft key
<b>D09: IF EQUAL, JUMP</b> e.g. <b>D09 P01 +Q1 P02 +Q3 P03 "UPCAN25" *</b> If both values or parameters are equal, jump to specified label	
<b>D10: IF NOT EQUAL TO, JUMP</b> e.g. <b>D10 P01 +10 P02 -Q5 P03 10 *</b> If both values or parameters are not equal, jump to specified label	
<b>D11: IF GREATER, JUMP</b> e.g. <b>D11 P01 +Q1 P02 +10 P03 5 *</b> If the first value or parameter is greater than the second value or parameter, jump to specified label	
<b>D12: IF SMALLER, JUMP</b> e.g. <b>D12 P01 +Q5 P02 +0 P03 "ANYNAME" *</b> If the first value or parameter is smaller than the second value or parameter, jump to specified label	

## Programming: Q Parameters

### 9.6 Checking and changing Q parameters

### 9.6 Checking and changing Q parameters

#### Procedure

You can check Q parameters in all operating modes (when writing, testing and running programs) and also edit them.

- ▶ If you are in a program run, interrupt it if required (for example, by pressing the machine STOP button and the **INTERNAL STOP** soft key). If you are in a test run, interrupt it.



Q  
INFO

- ▶ To call the Q parameter functions, press the Q INFO soft key or the Q key
- ▶ The TNC lists all parameters and their current values. Use the arrow keys or the **GOTO** key to select the desired parameter.
- ▶ If you would like to change the value, press the EDIT CURRENT FIELD soft key, enter the new value, and confirm with the **ENT** key.
- ▶ To leave the value unchanged, press the PRESENT VALUE soft key or end the dialog with the **END** key.



The parameters used by the TNC internally or in cycles are provided with comments.

If you want to check or edit local, global or string parameters, press the **SHOW PARAMETERS q QL QR qs** soft key. The TNC then displays the specific parameter type. The functions previously described also apply.





You can have the Q parameters be shown in the additional status display in the Manual, El. Handwheel, Single Block, Full Sequence and Test Run operating modes.


- ▶ If you are in a program run, interrupt it if required (for example, by pressing the machine STOP button and the **INTERNAL STOP** soft key). If you are in a test run, interrupt it.



- ▶ Call the soft-key row for screen layout



- ▶ Select the layout option for the additional status display: In the right half of the screen, the TNC shows the **Overview** status form



- ▶ Press the **STATUS OF Q PARAM.** soft key



- ▶ Press the **Q PARAMETER LIST** soft key
- ▶ The TNC opens a pop-up window in which you can enter the desired range for display of the Q parameters or string parameters. Multiple Q parameters are entered separated by commas (e.g. Q 1,2,3,4). To define display ranges, enter a hyphen (e.g. Q 10-14).





## Programming: Q Parameters

### 9.7 Additional functions

#### 9.7 Additional functions

##### Overview

Press the DIVERSE FUNCTION soft key to call the additional functions. The TNC then displays the following soft keys:

Function	Soft key	Page
<b>D14:ERROR</b> Displaying error messages		275
<b>D19:PLC</b> Transfer values to the PLC		288
<b>D29:PLC</b> Transfer up to eight values to the PLC		290
<b>D37:EXPORT</b> Export local Q parameters or QS parameters into a calling program		290

## D14: Displaying error messages

With the **D14** function, you can call messages under program control. The messages are predefined by the machine tool builder or by HEIDENHAIN. If the TNC encounters a block with **D14** during program run or test run, it will interrupt the run and display an error message. The program must then be restarted. The error numbers are listed in the table.

Range of error numbers	Standard dialog text
0 ... 999	Machine-dependent dialog
1000 ... 1199	Internal error messages (see table)

### Example NC block

The TNC is to display the text stored under error number 254:

```
N180 D14 P01 254 *
```

### Error message predefined by HEIDENHAIN

Error number	Text
1000	Spindle?
1001	Tool axis is missing
1002	Tool radius too small
1003	Tool radius too large
1004	Range exceeded
1005	Start position incorrect
1006	ROTATION not permitted
1007	SCALING FACTOR not permitted
1008	MIRROR IMAGE not permitted
1009	Datum shift not permitted
1010	Feed rate is missing
1011	Input value incorrect
1012	Incorrect sign
1013	Entered angle not permitted
1014	Touch point inaccessible
1015	Too many points
1016	Contradictory input
1017	CYCL incomplete
1018	Plane wrongly defined
1019	Wrong axis programmed
1020	Wrong rpm
1021	Radius comp. undefined
1022	Rounding-off undefined
1023	Rounding radius too large
1024	Program start undefined

## Programming: Q Parameters

### 9.7 Additional functions

Error number	Text
1025	Excessive nesting
1026	Angle reference missing
1027	No fixed cycle defined
1028	Slot width too small
1029	Pocket too small
1030	Q202 not defined
1031	Q205 not defined
1032	Q218 must be greater than Q219
1033	CYCL 210 not permitted
1034	CYCL 211 not permitted
1035	Q220 too large
1036	Q222 must be greater than Q223
1037	Q244 must be greater than 0
1038	Q245 must not equal Q246
1039	Angle range must be under 360°
1040	Q223 must be greater than Q222
1041	Q214: 0 not permitted
1042	Traverse direction not defined
1043	No datum table active
1044	Position error: center in axis 1
1045	Position error: center in axis 2
1046	Hole diameter too small
1047	Hole diameter too large
1048	Stud diameter too small
1049	Stud diameter too large
1050	Pocket too small: rework axis 1
1051	Pocket too small: rework axis 2
1052	Pocket too large: scrap axis 1
1053	Pocket too large: scrap axis 2
1054	Stud too small: scrap axis 1
1055	Stud too small: scrap axis 2
1056	Stud too large: rework axis 1
1057	Stud too large: rework axis 2
1058	TCHPROBE 425: length exceeds max
1059	TCHPROBE 425: length below min
1060	TCHPROBE 426: length exceeds max
1061	TCHPROBE 426: length below min
1062	TCHPROBE 430: diameter too large
1063	TCHPROBE 430: diameter too small

Error number	Text
1064	No measuring axis defined
1065	Tool breakage tolerance exceeded
1066	Enter Q247 unequal to 0
1067	Enter Q247 greater than 5
1068	Datum table?
1069	Enter Q351 unequal to 0
1070	Thread depth too large
1071	Missing calibration data
1072	Tolerance exceeded
1073	Block scan active
1074	ORIENTATION not permitted
1075	3-D ROT not permitted
1076	Activate 3-D ROT
1077	Enter depth as negative
1078	Q303 in meas. cycle undefined!
1079	Tool axis not allowed
1080	Calculated values incorrect
1081	Contradictory meas. points
1082	Incorrect clearance height
1083	Contradictory plunge type
1084	This fixed cycle not allowed
1085	Line is write-protected
1086	Oversize greater than depth
1087	No point angle defined
1088	Contradictory data
1089	Slot position 0 not allowed
1090	Enter an infeed not equal to 0
1091	Switchover of Q399 not allowed
1092	Tool not defined
1093	Tool number not allowed
1094	Tool name not allowed
1095	Software option not active
1096	Kinematics cannot be restored
1097	Function not permitted
1098	Contradictory workpc. blank dim.
1099	Measuring position not allowed
1100	Kinematic access not possible
1101	Meas. pos. not in traverse range
1102	Preset compensation not possible

## Programming: Q Parameters

### 9.7 Additional functions

<b>Error number</b>	<b>Text</b>
1103	Tool radius too large
1104	Plunging type is not possible
1105	Plunge angle incorrectly defined
1106	Angular length is undefined
1107	Slot width is too large
1108	Scaling factors not equal
1109	Tool data inconsistent

**D18: Reading system data**

With the **D18** function you can read system data and store them in Q parameters. You select the system data through a group name (ID number), and additionally through a number and an index.

Group name, ID no.	Number	Index	Meaning
Program information, 10	3	-	Number of the active fixed cycle
	103	Q parameter number	Relevant within NC cycles; for inquiry as to whether the Q parameter given under IDX was explicitly stated in the associated CYCLE DEF.
System jump addresses, 13	1	-	Label jumped to during M2/M30 instead of ending the current program. Value = 0: M2/M30 has the normal effect
	2	-	Label jumped to if FN14: ERROR after the NC CANCEL reaction instead of aborting the program with an error. The error number programmed in the FN14 command can be read under ID992 NR14. Value = 0: FN14 has the normal effect.
	3	-	Label jumped to in the event of an internal server error (SQL, PLC, CFG) instead of aborting the program with an error message. Value = 0: Server error has the normal effect.
Machine status, 20	1	-	Active tool number
	2	-	Prepared tool number
	3	-	Active tool axis 0=X, 1=Y, 2=Z, 6=U, 7=V, 8=W
	4	-	Programmed spindle speed
	5	-	Active spindle condition: -1=not defined, 0=M3 active, 1=M4 active, 2=M5 after M3, 3=M5 after M4
	7	-	Gear range
	8	-	Coolant status: 0=off, 1=on
	9	-	Active feed rate
	10	-	Index of prepared tool
	11	-	Index of active tool
Channel data, 25	1	-	Channel number

## Programming: Q Parameters

### 9.7 Additional functions

Group name, ID no.	Number	Index	Meaning
Cycle parameter, 30	1	-	Set-up clearance of active fixed cycle
	2	-	Drilling depth / milling depth of active fixed cycle
	3	-	Plunging depth of active fixed cycle
	4	-	Feed rate for pecking in active fixed cycle
	5	-	1st side length for rectangular pocket cycle
	6	-	2nd side length for rectangular pocket cycle
	7	-	1st side length for slot cycle
	8	-	2nd side length for slot cycle
	9	-	Radius for circular pocket cycle
	10	-	Feed rate for milling in active fixed cycle
	11	-	Direction of rotation for active fixed cycle
	12	-	Dwell time for active fixed cycle
	13	-	Thread pitch for Cycles 17, 18
	14	-	Finishing allowance for active fixed cycle
	15	-	Direction angle for rough out in active fixed cycle
	21	-	Probing angle
	22	-	Probing path
	23	-	Probing feed rate
Modal condition, 35	1	-	Dimensions: 0 = absolute (G90) 1 = incremental (G91)
Data for SQL tables, 40	1	-	Result code for the last SQL command
Data from the tool table, 50	1	Tool no.	Tool length
	2	Tool no.	Tool radius
	3	Tool no.	Tool radius R2
	4	Tool no.	Oversize for tool length DL
	5	Tool no.	Tool radius oversize DR
	6	Tool no.	Tool radius oversize DR2
	7	Tool no.	Tool locked (0 or 1)
	8	Tool no.	Number of the replacement tool



Group name, ID no.	Number	Index	Meaning
	9	Tool no.	Maximum tool age TIME1
	10	Tool no.	Maximum tool age TIME2
	11	Tool no.	Current tool age CUR. TIME
	12	Tool no.	PLC status
	13	Tool no.	Maximum tooth length LCUTS
	14	Tool no.	Maximum plunge angle ANGLE
	15	Tool no.	TT: Number of tool teeth CUT
	16	Tool no.	TT: Wear tolerance for length LTOL
	17	Tool no.	TT: Wear tolerance for radius RTOL
	18	Tool no.	TT: Rotational direction DIRECT (0=positive/-1=negative)
	19	Tool no.	TT: Offset in plane R-OFFS
	20	Tool no.	TT: Offset in length L-OFFS
	21	Tool no.	TT: Break tolerance for length LBREAK
	22	Tool no.	TT: Break tolerance for radius RBREAK
	28	Tool no.	Maximum rpm NMAX
	32	Tool no.	Point angle TANGLE
	34	Tool no.	LIFTOFF allowed (0= No, 1= Yes)
	35	Tool no.	Wear tolerance for radius R2TOL
	37	Tool no.	Corresponding line in the touch-probe table
	38	Tool no.	Timestamp of last use
Pocket table data, 51	1	Pocket number	Tool number
	2	Pocket number	Special tool: 0=No, 1=Yes
	3	Pocket number	Fixed pocket: 0=No, 1=Yes
	4	Pocket number	Locked pocket: 0=No, 1=Yes
	5	Pocket number	PLC status

## Programming: Q Parameters

### 9.7 Additional functions

Group name, ID no.	Number	Index	Meaning
Values programmed immediately after TOOL CALL, 60	1	-	Tool number T
	2	-	Active tool axis 0 = X 6 = U 1 = Y 7 = V 2 = Z 8 = W
	3	-	Spindle speed S
	4	-	Oversize for tool length DL
	5	-	Tool radius oversize DR
	6	-	Automatic TOOL CALL 0 = Yes, 1 = No
	7	-	Tool radius oversize DR2
	8	-	Tool index
	9	-	Active feed rate
Values programmed immediately after TOOL DEF, 61	1	-	Tool number T
	2	-	Length
	3	-	Radius
	4	-	Index
	5	-	Tool data programmed in TOOL DEF 1 = Yes, 0 = No
Active tool compensation, 200	1	1 = without oversize 2 = with oversize 3 = with oversize and Oversize from TOOL CALL	Active radius
	2	1 = without oversize 2 = with oversize 3 = with oversize and Oversize from TOOL CALL	Active length
	3	1 = without oversize 2 = with oversize 3 = with oversize and Oversize from TOOL CALL	Rounding radius R2

Group name, ID no.	Number	Index	Meaning
Active transformations, 210	1	-	Basic rotation in MANUAL OPERATION mode
	2	-	Programmed rotation with Cycle 10
	3	-	Active mirrored axis
			0: Mirroring not active
			+1: X axis mirrored
			+2: Y axis mirrored
			+4: Z axis mirrored
			+64: U axis mirrored
			+128: V axis mirrored
			+256: W axis mirrored
			Combinations = Sum of individual axes
	4	1	Active scaling factor in X axis
	4	2	Active scaling factor in Y axis
	4	3	Active scaling factor in Z axis
	4	7	Active scaling factor in U axis
	4	8	Active scaling factor in V axis
	4	9	Active scaling factor in W axis
	5	1	3-D ROT A axis
	5	2	3-D ROT B axis
5	3	3-D ROT C axis	
6	-	Tilted working plane active / inactive (-1/0) in a Program Run operating mode	
7	-	Tilted working plane active / inactive (-1/0) in a Manual operating mode	
Active datum shift, 220	2	1	X axis
		2	Y axis
		3	Z axis
		4	A axis
		5	B axis
		6	C axis
		7	U axis
		8	V axis
		9	W axis

## Programming: Q Parameters

### 9.7 Additional functions

Group name, ID no.	Number	Index	Meaning
Traverse range, 230	2	1 to 9	Negative software limit switch in axes 1 to 9
	3	1 to 9	Positive software limit switch in axes 1 to 9
	5	-	Software limit switch on or off: 0 = on, 1 = off
Nominal position in the REF system, 240	1	1	X axis
		2	Y axis
		3	Z axis
		4	A axis
		5	B axis
		6	C axis
		7	U axis
		8	V axis
		9	W axis
Current position in the active coordinate system, 270	1	1	X axis
		2	Y axis
		3	Z axis
		4	A axis
		5	B axis
		6	C axis
		7	U axis
		8	V axis
		9	W axis
Interpretation of coordinates in turning operation, 310	20	1 to 3 (X, Y, Z)	Coordinates are give with respect to: 0 = diameter, -1 = radius

Group name, ID no.	Number	Index	Meaning	
TS triggering touch probe, 350	50	1	Touch probe type	
		2	Line in the touch-probe table	
	51	-	Effective length	
	52	1	Effective ball radius	
		2	Rounding radius	
	53	1	Center offset (reference axis)	
		2	Center offset (minor axis)	
	54	-	Spindle-orientation angle in degrees (center offset)	
	55	1	Rapid traverse	
		2	Measuring feed rate	
	56	1	Maximum measuring range	
		2	Safety clearance	
	57	1	Spindle orientation possible: 0=No, 1=Yes	
		2	Spindle-orientation angle	
	TT tool touch probe	70	1	Touch probe type
			2	Line in the touch-probe table
71		1	Center point in reference axis (REF system)	
		2	Center point in minor axis (REF system)	
		3	Center point in tool axis (REF system)	
72		-	Probe contact radius	
75		1	Rapid traverse	
		2	Measuring feed rate for stationary spindle	
		3	Measuring feed rate for rotating spindle	
76		1	Maximum measuring range	
		2	Safety clearance for linear measurement	
		3	Safety clearance for radial measurement	
77		-	Spindle speed	
78		-	Probing direction	

## Programming: Q Parameters

### 9.7 Additional functions

Group name, ID no.	Number	Index	Meaning
Reference point from touch probe cycle, 360	1	1 to 9 (X, Y, Z, A, B, C, U, V, W)	Last reference point of a manual touch probe cycle, or last touch point from Cycle 0 without probe length compensation but with probe radius compensation (workpiece coordinate system)
	2	1 to 9 (X, Y, Z, A, B, C, U, V, W)	Last reference point of a manual touch probe cycle, or last touch point from Cycle 0 without probe length or probe radius compensation (machine coordinate system)
	3	1 to 9 (X, Y, Z, A, B, C, U, V, W)	Result of measurement of the touch probe cycles 0 and 1 without probe radius or probe length compensation
	4	1 to 9 (X, Y, Z, A, B, C, U, V, W)	Last reference point of a manual touch probe cycle, or last touch point from Cycle 0 without probe length or stylus probe compensation (workpiece coordinate system)
	10	-	Oriented spindle stop
Value from the active datum table in the active coordinate system, 500	Line	Column	Read values
Basic transformation, 507	Line	1 to 6 (X, Y, Z, SPA, SPB, SPC)	Read the basic transformation of a preset
Axis offset, 508	Line	1 to 9 (X_OFFS, Y_OFFS, Z_OFFS, A_OFFS, B_OFFS, C_OFFS, U_OFFS, V_OFFS, W_OFFS)	Read the axis offset of a preset
Active preset, 530	1	-	Read the number of the active preset
Read data of the current tool, 950	1	-	Tool length L
	2	-	Tool radius R
	3	-	Tool radius R2
	4	-	Oversize for tool length DL
	5	-	Tool radius oversize DR
	6	-	Tool radius oversize DR2
	7	-	Tool locked TL 0 = not locked, 1 = locked
	8	-	Number of the replacement tool RT
	9	-	Maximum tool age TIME1
	10	-	Maximum tool age TIME2
	11	-	Current tool age CUR. TIME

Group name, ID no.	Number	Index	Meaning
	12	-	PLC status
	13	-	Maximum tooth length LCUTS
	14	-	Maximum plunge angle ANGLE
	15	-	TT: Number of tool teeth CUT
	16	-	TT: Wear tolerance for length LTOL
	17	-	TT: Wear tolerance for radius RTOL
	18	-	TT: Direction of rotation DIRECT 0 = positive, -1 = negative
	19	-	TT: Offset in plane R-OFFS
	20	-	TT: Offset in length L-OFFS
	21	-	TT: Break tolerance for length LBREAK
	22	-	TT: Break tolerance for radius RBREAK
	23	-	PLC value
	24	-	Tool type TYP 0 = milling cutter, 21 = touch probe
	27	-	Corresponding line in the touch-probe table
	32	-	Point angle
	34	-	Lift off
Touch probe cycles, 990	1	-	Approach behaviour: 0 = standard behavior 1 = effective radius, safety clearance zero
	2	-	0 = Pushbutton monitoring off 1 = Pushbutton monitoring on
	4	-	0 = Stylus not deflected 1 = Stylus deflected
Execution status, 992	10	-	Mid-program startup active 1 = yes, 0 = no
	11	-	Search phase
	14	-	Number of the last FN14 error
	16	-	Real execution active 1 = execution , 2 = simulation

**Example: Assign the value of the active scaling factor for the Z axis to Q25.**

**N55 D18: SYSREAD Q25 = ID210 NR4 IDX3**

## Programming: Q Parameters

### 9.7 Additional functions

#### D19: Transfer values to PLC

The **D19** function transfers up to two numerical values or Q parameters to the PLC.

Increments and units: 0.1 µm or 0.0001°

**Example: Transfer the numerical value 10 (which means 1 µm or 0.001°) to the PLC**

```
N56 D19 P01 +10 P02 +Q3 *
```

#### D20: NC and PLC synchronization



This function may only be used with the permission of your machine tool builder.

With the **D20** function you can synchronize the NC and PLC during a program run. The NC stops machining until the condition that you have programmed in the D20 block is fulfilled. The TNC can check the following PLC operands:

PLC operand	Abbreviation	Address range
Markers	<b>M</b>	0 to 4999
Input	<b>I</b>	0 to 31, 128 to 152 64 to 126 (first PL 401 B) 192 to 254 (second PL 401 B)
Output	<b>O</b>	0 to 30 32 to 62 (first PL 401 B) 64 to 94 (second PL 401 B)
Counter	<b>C</b>	48 to 79
Timer	<b>T</b>	0 to 95
Byte	<b>B</b>	0 to 4095
Word	<b>W</b>	0 to 2047
Double word	<b>D</b>	2048 to 4095



The TNC 640 uses an extended interface for communication between the PLC and NC. This is a new, symbolic Application Programmer Interface (**API**). The familiar previous PLC-NC interface is also available and can be used if desired. The machine tool builder decides whether the new or old TNC API is used. Enter the name of the symbolic operand as string to wait for the defined condition of the symbolic operand.

The following conditions are permitted in the D20 block:

Condition	Abbreviation
Equal to	==
Less than	<
Greater than	>
Less than or equal	<=
Greater than or equal	>=

In addition, the **D20** function is available. **WAIT FOR SYNC** is used whenever you read, for example, system data via **D18** that require synchronization with real time. The TNC stops the look-ahead calculation and executes the subsequent NC block only when the NC program has actually reached that block.

**Example: Stop program run until the PLC sets marker 4095 to 1**

```
N32 D20: WAIT FOR M4095==1
```

**Example: Stop program run until the PLC sets the symbolic operand to 1**

```
N32 D20: APISPIN[0].NN_SPICONTROLINPOS==1
```

**Example: Pause internal look-ahead calculation, read current position in the X axis**

```
N32 D20: WAIT FOR SYNC
```

```
N33 D18: SYSREAD Q1 = ID270 NR1 IDX1
```

## Programming: Q Parameters

### 9.7 Additional functions

#### D29: Transfer values to the PLC

The D29 function transfers up to eight numerical values or Q parameters to the PLC.

Increments and units: 0.1  $\mu\text{m}$  or 0.0001°

**Example: Transfer the numerical value 10 (which means 1  $\mu\text{m}$  or 0.001°) to the PLC**

```
N56 D29 P01 +10 P02 +Q3
```

#### D37 EXPORT

You need the D37 function if you want to create your own cycles and integrate them in the TNC. The Q parameters 0 to 99 are effective only locally. This means that the Q parameters are effective only in the program in which they were defined. With the D37 function you can export locally effective Q parameters into another (calling) program.



The TNC exports the value that the parameter has at the time of the EXPORT command.

The parameter is exported only to the presently calling program.

**Example: The local Q parameter Q25 is exported**

```
N56 D37 Q25
```

**Example: The local Q parameters Q25 to Q30 are exported**

```
N56 D37 Q25 - Q30
```

## 9.8 Accessing tables with SQL commands

### Introduction

Accessing of tables is programmed on the TNC with SQL commands in **transactions**. A transaction consists of multiple SQL commands that guarantee an orderly execution of the table entries.



Tables are configured by the machine manufacturer. Names and designations required as parameters for SQL commands are also specified.

The following **terms** are used:

- **Table:** A table consists of x columns and y rows. It is saved as a file in the File Manager of the TNC, and is addressed with the path and file name (=table name). Synonyms can also be used for addressing, as an alternative to the path and file name.
- **Columns:** The number and names of the columns are specified when configuring the table. In some SQL commands the column name is used for addressing.
- **Rows:** The number of rows is variable. You can insert new rows. There are no row numbers or other designators. However, you can select rows based on the contents of a column. Rows can only be deleted in the table editor, not by an NC program.
- **Cell:** The part of a column in a row.
- **Table entry:** Content of a cell.
- **Result set:** During a transaction, the selected columns and rows are managed in the result set. You can view the result set as a sort of "intermediate memory," which temporarily assumes the set of selected columns and rows. Result set
- **Synonym:** This term defines a name used for a table instead of its path and file name. Synonyms are specified by the machine manufacturer in the configuration data.

## Programming: Q Parameters

### 9.8 Accessing tables with SQL commands

#### A transaction

In principle, a transaction consists of the following actions:

- Address the table (file), select rows and transfer them to the result set.
- Read rows from the result set, change rows or insert new rows.
- Conclude transaction: If changes/insertions were made, the rows from the result set are placed in the table (file).


Other actions are also necessary so that table entries can be edited in an NC program and to ensure that other changes are not made to copies of the same table rows at the same time. This results in the following **transaction sequence**:

- 1 A Q parameter is specified for each column to be edited. The Q parameter is assigned to a column—it is "bound" (**SQL BIND...**
- 2 Address the table (file), select rows and transfer them to the result set. In addition, you define which columns are transferred to the result set (**SQL SELECT...**). You can lock the selected rows. Other processes can then read these rows, but cannot change the table entries. You should always lock the selected rows when you are going to make changes (**SQL SELECT ... FOR UPDATE**).
- 3 Read rows from the result set, modify and/or add new rows:
  - Adopt one row of the result set into the Q parameters of your NC program (**SQL FETCH...**)
  - Prepare changes in the Q parameters and transfer to a row in the result set (**SQL UPDATE...**)
  - Prepare new table row in the Q parameters and transfer as a new row to the result set (**SQL INSERT...**)
- 4 Conclude transaction:
  - If changes/insertions were made, the data from the result set is placed in the table (file). The data is now saved in the file. Any locks are canceled, and the result set is released (**SQL COMMIT...**).
  - If table entries were **not** changed or inserted (only read access), any locks are canceled and the result set is released (**SQL ROLLBACK... WITHOUT INDEX**).

Multiple transactions can be edited at the same time.



You must conclude a transaction, even if it consists solely of read accesses. Only this guarantees that changes/insertions are not lost, that locks are canceled, and that result sets are released.



### Result set

The selected rows are numbered in ascending order within the result set, starting from 0. This numbering is referred to as the **index**. The index is used for read and write accesses, enabling a row of the result set to be specifically addressed.

It can often be advantageous to sort the rows in the result set. Do this by specifying the table column containing the sorting criteria. Also select ascending or descending order (**SQL SELECT ... ORDER BY ...**).

The selected rows that were transferred to the result set are addressed with the **HANDLE**. All following SQL commands use the handle to refer to this "set of selected columns and rows."

When concluding a transaction, the handle is released (**SQL COMMIT...** or **SQL ROLLBACK...**). It is then no longer valid.


You can edit more than one result set at the same time. The SQL server assigns a new handle for each "Select" command.

### "Binding" Q parameters to columns

The NC program does not have direct access to the table entries in the result set. The data must be transferred in Q parameters. In the other direction, the data is first prepared in the Q parameters and then transferred to the result set.

Specify with **SQL BIND ...** which table columns are mapped to which Q parameters. The Q parameters are "bound" (assigned) to the columns. Columns that are not bound to Q parameters are not included in the read-/write-processes.

If a new table row is generated with **SQL INSERT...**, the columns not bound to Q parameters are filled with default values.



## Programming: Q Parameters


### 9.8 Accessing tables with SQL commands

#### Programming SQL commands



This function can only be programmed if you have entered the code number 555343.

Program SQL commands in the Programming mode:



- ▶ To select the MOD functions, press **SQL**
- ▶ Select an SQL command via soft key (see overview) or press the **SQL EXECUTE** soft key and program the SQL command

#### Overview of the soft keys

Function	Soft key
<b>SQL EXECUTE</b> Program a Select command.	
<b>SQL BIND</b> Bind a Q parameter to a table column.	
<b>SQL FETCH</b> Read table rows from the result set and save them in Q parameters.	
<b>SQL UPDATE</b> Save data from the Q parameters in an existing table row in the result set.	
<b>SQL INSERT</b> Save data from the Q parameters in a new table row in the result set.	
<b>SQL COMMIT</b> Transfer table rows from the result set into the table and conclude the transaction.	
<b>SQL ROLLBACK</b> <ul style="list-style-type: none"> <li>■ If <b>INDEX</b> is not programmed: Discard any changes/insertions and conclude the transaction.</li> <li>■ If <b>INDEX</b> is programmed: The indexed row remains in the result set. All other rows are deleted from the result set. The transaction is <b>not</b> concluded.</li> </ul>	

## SQL BIND

**SQL BIND** binds a Q parameter to a table column. The SQL commands "Fetch," "Update" and "Insert" evaluate this binding (assignment) during data transfer between the result set and the NC program.

An **SQL BIND** command without a table or column name cancels the binding. Binding remains effective at most until the end of the NC program or subprogram.



- You can program any number of bindings. Read and write processes only take into account the columns that were entered in the "Select" command.
- **SQL BIND...** must be programmed **before** "Fetch," "Update" or "Insert" commands are programmed. You can program a "Select" command without a preceding "Bind" command.
- If in the "Select" command you include columns for which no binding is programmed, an error occurs during read/write processes (program interrupt).

SQL  
BIND

- ▶ **Parameter no. for result:** Q parameter that is bound (assigned) to the table column.
- ▶ **Database: column name:** Enter the table name and column name separated by a ..  
**Table name:** Synonym or path and file name of this table. The synonym is entered directly, whereas the path and file name are entered in single quotation marks  
**Column designation:** Designation of the table column as given in the configuration data

### Bind a Q parameter to a table column

```
11SQL BIND Q881
   "TAB_EXAMPLE.MEAS_NO"
```

```
12SQL BIND Q882
   "TAB_EXAMPLE.MEAS_X"
```

```
13SQL BIND Q883
   "TAB_EXAMPLE.MEAS_Y"
```

```
14SQL BIND Q884
   "TAB_EXAMPLE.MEAS_Z"
```

### Cancel binding

```
91 SQL BIND Q881
```

```
92 SQL BIND Q882
```

```
93 SQL BIND Q883
```

```
94 SQL BIND Q884
```

## Programming: Q Parameters

### 9.8 Accessing tables with SQL commands

#### SQL SELECT

**SQL SELECT** selects table rows and transfers them to the result set.

The SQL server places the data in the result set row-by-row. The rows are numbered in ascending order, starting from 0. This row number, called the **INDEX**, is used in the SQL commands "Fetch" and "Update."

Enter the selection criteria in the **SQL SELECT...WHERE...** function. This lets you restrict the number of rows to be transferred. If you do not use this option, all rows in the table are loaded.

Enter the sorting criteria in the **SQL SELECT...ORDER BY...** function. Enter the column designation and the keyword for ascending/descending order. If you do not use this option, the rows are placed in random order.

Lock out the selected rows for other applications with the **SQL SELECT...FOR UPDATE** function. Other applications can continue to read these rows, but cannot change them. We strongly recommend using this option if you are making changes to the table entries.

**Empty result set:** If no rows match the selection criteria, the SQL server returns a valid handle but no table entries.

SQL  
EXECUTE

- ▶ **Parameter no. for result:** Q parameter for the handle. The SQL server returns the handle for the group of columns and rows selected with the current "Select" command. With an error (selection could not be executed) the SQL server returns a 1. Code 0 identifies an invalid handle.
- ▶ **Data bank: SQL command text:** with the following elements:
  - **SELECT** (keyword): Name of the SQL command, names of the table columns to be transferred. Separate column names with a , (comma) (see examples). Q parameters must be bound to all columns entered here.
  - **FROM** table name: Synonym or path and file name of this table. The synonym is entered directly: the path name and table name are entered in single quotation marks (see examples of the SQL command); names of the table columns to be transferred—separate several columns by a comma (see examples). Q parameters must be bound to all columns entered here.

#### Select all table rows

```
11SQL BIND Q881
   "TAB_EXAMPLE.MEAS_NO"
12SQL BIND Q882
   "TAB_EXAMPLE.MEAS_X"
13SQL BIND Q883
   "TAB_EXAMPLE.MEAS_Y"
14SQL BIND Q884
   "TAB_EXAMPLE.MEAS_Z"
. . .
20SQL Q5 "SELECT
   MEAS_NO,MEAS_X,MEAS_Y, MEAS_Z
  FROM TAB_EXAMPLE"
```

#### Selection of table rows with the WHERE function

```
. . .
20SQL Q5 "SELECT
   MEAS_NO,MEAS_X,MEAS_Y, MEAS_Z
  FROM TAB_EXAMPLE WHERE
   MEAS_NO<20"
```

#### Selection of table rows with the WHERE function and Q parameters

```
. . .
20SQL Q5 "SELECT
   MEAS_NO,MEAS_X,MEAS_Y, MEAS_Z
  FROM TAB_EXAMPLE WHERE
   MEAS_NO==:'Q11'"
```

#### Table name defined with path and file name

```
. . .
20SQL Q5 "SELECT
   MEAS_NO,MEAS_X,MEAS_Y, MEAS_Z
  FROM 'V:\TABLE\TAB_EXAMPLE'
  WHERE MEAS_NO<20"
```



- Optional:  
**WHERE** selection criteria: A selection criterion consists of a column name, condition (see table) and comparative value. Link selection criteria with logical AND or OR. Program the comparative value directly or with a Q parameter. A Q parameter is introduced with a colon and placed in single quotation marks (see example).
- Optional:  
**ORDER BY** column name **ASC** for ascending sorting, or **ORDER BY** column name **DESC** for descending sorting. If you program neither ASC nor DESC, ascending sorting is executed by default. The TNC places the selected rows in the indicated column.
- Optional:  
**FOR UPDATE** (keyword): The selected rows are locked against write-accesses from other processes.

Condition	Programming
Equal to	= ==
Not equal to	!= <>
Less than	<
Less than or equal to	<=
Greater than	>
Greater than or equal to	>=
<b>Linking multiple conditions:</b>	
Logical AND	AND
Logical OR	OR

## Programming: Q Parameters

### 9.8 Accessing tables with SQL commands

#### SQL FETCH

**SQL FETCH** reads the row addressed with **INDEX** from the result set, and places the table entries in the bound (assigned) Q parameters.

The result set is addressed with the **HANDLE**.

**SQL FETCH** takes into account all columns entered in the "Select" command.

SQL  
FETCH

- ▶ **Parameter no. for result:** Q parameter, in which the SQL server has reported the result:  
0: No error occurred  
1: Error occurred (incorrect handle or index too large)
- ▶ **Database: SQL access ID:** Q parameter with the **handle** for identifying the result set (also see **SQL SELECT**).
- ▶ **Database: Index to SQL result:** Line number within the result set. The table entries of this row are read and are transferred into the bound Q parameters. If you do not enter an index, the first row is read (n=0).  
Either enter the row number directly or program the Q parameter containing the index

#### Row number is transferred in a Q parameter

```

11SQL BIND Q881
   "TAB_EXAMPLE.MEAS_NO"

12SQL BIND Q882
   "TAB_EXAMPLE.MEAS_X"

13SQL BIND Q883
   "TAB_EXAMPLE.MEAS_Y"

14SQL BIND Q884
   "TAB_EXAMPLE.MEAS_Z"

. . .

20SQL Q5 "SELECT
   MEAS_NO,MEAS_X,MEAS_Y, MEAS_Z
  FROM TAB_EXAMPLE"

. . .

30 SQL FETCH Q1HANDLE Q5 INDEX
   +Q2
  
```

#### Row number is programmed directly

```

. . .

30 SQL FETCH Q1HANDLE Q5 INDEX5
  
```

## SQL UPDATE

**SQL UPDATE** transfers the data prepared in the Q parameters into the row of the result set addressed with **INDEX**. The existing row in the result set is completely overwritten.

**SQL UPDATE** takes into account all columns entered in the "Select" command.

SQL  
UPDATE

- ▶ **Parameter no. for result:** Q parameter, in which the SQL server has reported the result:  
0: No error occurred  
1: Error occurred (incorrect handle, index too large, value outside of value range or incorrect data format)
- ▶ **Database: SQL access ID:** Q parameter with the **handle** for identifying the result set (also see **SQL SELECT**).
- ▶ **Database: Index to SQL result:** Line number within the result set. The table entries prepared in the Q parameters are written to this row. If you do not enter an index, the first row is written to (n=0). Either enter the row number directly or program the Q parameter containing the index

### Row number is programmed directly

...

40 SQL UPDATEQ1 HANDLE Q5 INDEX5

## SQL INSERT

**SQL INSERT** generates a new row in the result set and transfers the data prepared in the Q parameters into the new row.

**SQL INSERT** takes into account all columns entered in the "Select" command. Table columns not entered in the "Select" command are filled with default values.

SQL  
INSERT

- ▶ **Parameter no. for result:** Q parameter, in which the SQL server has reported the result:  
0: No error occurred  
1: Error occurred (incorrect handle, value outside of value range or incorrect data format)
- ▶ **Database: SQL access ID:** Q parameter with the **handle** for identifying the result set (also see **SQL SELECT**).

### Row number is transferred in a Q parameter

11SQL BIND Q881  
"TAB\_EXAMPLE.MEAS\_NO"

12SQL BIND Q882  
"TAB\_EXAMPLE.MEAS\_X"

13SQL BIND Q883  
"TAB\_EXAMPLE.MEAS\_Y"

14SQL BIND Q884  
"TAB\_EXAMPLE.MEAS\_Z"

...

20SQL Q5 "SELECT  
MEAS\_NO,MEAS\_X,MEAS\_Y, MEAS\_Z  
FROM TAB\_EXAMPLE"

...

40 SQL INSERTQ1 HANDLE Q5

## Programming: Q Parameters

### 9.8 Accessing tables with SQL commands

#### SQL COMMIT

**SQL COMMIT** transfers all rows in the result set back to the table. A lock set with **SELECT...FOR UPDATE** is canceled.

The handle given in the **SQL SELECT** command loses its validity.

SQL  
COMMIT

- ▶ **Parameter no. for result:** Q parameter, in which the SQL server has reported the result:
  - 0: No error occurred
  - 1: Error occurred (incorrect handle or equal entries in columns requiring unique entries)
- ▶ **Database: SQL access ID:** Q parameter with the **handle** for identifying the result set (also see **SQL SELECT**).

```

11SQL BIND Q881
   "TAB_EXAMPLE.MEAS_NO"
12SQL BIND Q882
   "TAB_EXAMPLE.MEAS_X"
13SQL BIND Q883
   "TAB_EXAMPLE.MEAS_Y"
14SQL BIND Q884
   "TAB_EXAMPLE.MEAS_Z"
. . .
20SQL Q5 "SELECT
   MEAS_NO,MEAS_X,MEAS_Y, MEAS_Z
  FROM TAB_EXAMPLE"
. . .
30 SQL FETCH Q1HANDLE Q5 INDEX
   +Q2
. . .
40 SQL UPDATEQ1 HANDLE Q5 INDEX
   +Q2
. . .
50 SQL COMMITQ1 HANDLE Q5

```

#### SQL ROLLBACK

How **SQL ROLLBACK** is executed depends on whether **INDEX** is programmed:

- If **INDEX** is not programmed: The result set is **not** written back to the table (any changes/insertions are discarded). The transaction is closed and the handle given in the **SQL SELECT** command loses its validity. Typical application: Ending a transaction solely containing read-accesses.
- If **INDEX** is programmed: The indexed row remains. All other rows are deleted from the result set. The transaction is **not** concluded. A lock set with **SELECT...FOR UPDATE** remains for the indexed row. For all other rows it is reset.

SQL  
ROLLBACK

- ▶ **Parameter no. for result:** Q parameter, in which the SQL server has reported the result:
  - 0: No error occurred
  - 1: Error occurred (incorrect handle)
- ▶ **Database: SQL access ID:** Q parameter with the **handle** for identifying the result set (also see **SQL SELECT**).
- ▶ **Database: Index to SQL result:** Line that is to remain in the result set. Either enter the row number directly or program the Q parameter containing the index

```

11SQL BIND Q881
   "TAB_EXAMPLE.MEAS_NO"
12SQL BIND Q882
   "TAB_EXAMPLE.MEAS_X"
13SQL BIND Q883
   "TAB_EXAMPLE.MEAS_Y"
14SQL BIND Q884
   "TAB_EXAMPLE.MEAS_Z"
. . .
20SQL Q5 "SELECT
   MEAS_NO,MEAS_X,MEAS_Y, MEAS_Z
  FROM TAB_EXAMPLE"
. . .
30 SQL FETCH Q1HANDLE Q5 INDEX
   +Q2
. . .
50 SQL ROLLBACKQ1 HANDLE Q5















```

## 9.9 Entering formulas directly

### Entering formulas












You can enter mathematical formulas that include several operations directly into the part program by soft key.

Press the **FORMULA** soft key to call the mathematical functions. The TNC displays the following soft keys in several soft-key rows:

Mathematical function	Soft key
<b>Addition</b> e.g. $Q10 = Q1 + Q5$	
<b>Subtraction</b> e.g. $Q25 = Q7 - Q108$	
<b>Multiplication</b> e.g. $Q12 = 5 * Q5$	
<b>Division</b> e.g. $Q25 = Q1 / Q2$	
<b>Open parentheses</b> e.g. $Q12 = Q1 * (Q2 + Q3)$	
<b>Close parentheses</b> e.g. $Q12 = Q1 * (Q2 + Q3)$	
<b>Square value</b> e.g. $Q15 = SQ 5$	
<b>Square root</b> e.g. $Q22 = SQRT 25$	
<b>Sine of an angle</b> e.g. $Q44 = SIN 45$	
<b>Cosine of an angle</b> e.g. $Q45 = COS 45$	
<b>Tangent of an angle</b> e.g. $Q46 = TAN 45$	
<b>Arc sine</b> Inverse function of the sine; determine the angle from the ratio of the opposite side to the hypotenuse e.g. $Q10 = ASIN 0.75$	
<b>Arc cosine</b> Inverse function of the cosine; determine the angle from the ratio of the adjacent side to the hypotenuse e.g. $Q11 = ACOS Q40$	
<b>Arc tangent</b> Inverse function of the tangent; determine the angle from the ratio of the opposite side to the adjacent side e.g. $Q12 = ATAN Q50$	

## Programming: Q Parameters

### 9.9 Entering formulas directly

Mathematical function	Soft key
<b>Powers</b> e.g. Q15 = 3^3	
<b>Constant "pi" (3,14159)</b> e.g. Q15 = PI	
<b>Natural logarithm (LN) of a number</b>  Base 2.7183 e.g. Q15 = LN Q11	
<b>Logarithm of a number, base 10</b> e.g. Q33 = LOG Q22	
<b>Exponential function, 2.7183n</b> e.g. Q1 = EXP Q12	
<b>Negate (multiplication by -1)</b> e.g. Q2 = NEG Q1	
<b>Truncate digits after the decimal point</b>  Form an integer e.g. Q3 = INT Q42	
<b>Absolute value</b>  e.g. Q4 = ABS Q22	
<b>Truncate digits before the decimal point</b> Form a fraction e.g. Q5 = FRAC Q23	
<b>Check the algebraic sign of a digit</b> e.g. Q12 = SGN Q50 When return value Q12 = 1, then Q50 >= 0 When return value Q12 = -1, then Q50 < 0	
<b>Calculate modulo value (division rest)</b> e.g. Q12 = 400 % 360 Result: Q12 = 40	

## Rules for formulas

Mathematical formulas are programmed according to the following rules:

### Higher-level operations are performed first

$$12 \text{ Q1} = 5 * 3 + 2 * 10 = 35$$

- 1 Calculation  $5 * 3 = 15$
- 2 Calculation  $2 * 10 = 20$
- 3 Calculation  $15 + 20 = 35$

or

$$13 \text{ Q2} = \text{SQ } 10 - 3^3 = 73$$

- 1 Calculation step 10 squared = 100
- 2 Calculation step 3 to the third power = 27
- 3 Calculation  $100 - 27 = 73$

### Distributive law

Law of distribution with parentheses calculation




$$a * (b + c) = a * b + a * c$$

## Programming: Q Parameters











### 9.9 Entering formulas directly

#### Programming example

Calculate an angle with the arc tangent from the opposite side (Q12) and adjacent side (Q13); then store in Q25.

- 
  - ▶ To select the formula entering function, press the Q key and the FORMULA soft key, or use the shortcut:
- 
- 
  - ▶ Press the Q key on the ASCII keyboard.

#### PARAMETER NUMBER FOR RESULT?

- 
  - ▶ Enter parameter number **25** and press the **ENT** key.
- 
  - ▶ Shift the soft-key row and select the arc tangent function
- 
- 
  - ▶ Shift the soft-key row and open the parentheses
- 
- 
  - ▶ Enter Q parameter number **12**
- 
  - ▶ Select division
- 
  - ▶ Enter Q parameter number **13**
- 
  - ▶ Close parentheses and conclude formula entry
- 

#### Example NC block

```
37 Q25 = ATAN (Q12/Q13)
```










## 9.10 String parameters

### String processing functions

You can use the **QS** parameters to create variable character strings. function to create variable logs.

You can assign a linear sequence of characters (letters, numbers, special characters and spaces) up to a length of 256 characters to a string parameter. You can also check and process the assigned or imported values by using the functions described below. As in Q-parameter programming, you can use a total of 2000 QS parameters (See "Principle and overview of functions", page 264).

The **STRING FORMULA** and **FORMULA** Q-parameter functions contain various functions for processing the string parameters.

<b>STRING FORMULA functions</b>	<b>Soft key</b>	<b>Page</b>
Assigning string parameters		306
Chain-linking string parameters		306
Converting a numerical value to a string parameter		307
Copy a substring from a string parameter		308
<b>Formula string functions</b>	<b>Soft key</b>	<b>Page</b>
Converting a string parameter to a numerical value		309
Checking a string parameter		310
Finding the length of a string parameter		311
Compare alphabetic priority		312



When you use a **STRING FORMULA**, the result of the arithmetic operation is always a string. When you use the **FORMULA** function, the result of the arithmetic operation is always a numeric value.

## Programming: Q Parameters

### 9.10 String parameters

#### Assigning string parameters

You have to assign a string variable before you use it. Use the **DECLARE STRING** command to do so.

SPEC  
FCT

- ▶ Show the soft-key row with special functions

PROGRAM  
FUNCTIONS

- ▶ Select the menu for defining various plain-language functions

STRING  
FUNCTIONS

- ▶ Select string functions

DECLARE  
STRING

- ▶ Select the **DECLARE STRING** function

#### Example NC block

```
N37 DECLARE STRING QS10 = "WORKPIECE"
```

#### Chain-linking string parameters

With the concatenation operator (string parameter || string parameter) you can make a chain of two or more string parameters.

SPEC  
FCT

- ▶ Show the soft-key row with special functions

PROGRAM  
FUNCTIONS

- ▶ Select the menu for defining various plain-language functions

STRING  
FUNCTIONS

- ▶ Select string functions

STRING  
FORMULA

- ▶ Select the **STRING FORMULA** function
- ▶ Enter the number of the string parameter in which the TNC is to save the concatenated string. Confirm with the **ENT** key
- ▶ Enter the number of the string parameter in which the **second** substring is saved. Confirm with the **ENT** key: The TNC shows the chain symbol ||
- ▶ Confirm your entry with the **ENT** key
- ▶ Enter the number of the string parameter in which the **second** substring is saved. Confirm with the **ENT** key
- ▶ Repeat the process until you have selected all the required substrings. Conclude with the **END** key

**Example: QS10 is to include the complete text of QS12, QS13 and QS14**

```
N37 QS10 = QS12 || QS13 || QS14
```

Parameter contents:

- **QS12: Workpiece**
- **QS13: Status:**
- **QS14: Scrap**
- **QS10: Workpiece Status: Scrap**

### Converting a numerical value to a string parameter

With the **TOCHAR** function, the TNC converts a numerical value to a string parameter. This enables you to chain numerical values with string variables.

SPEC  
FCT

- ▶ Show the soft-key row with special functions

PROGRAM  
FUNCTIONS

- ▶ Select the menu for defining various plain-language functions

STRING  
FUNCTIONS

- ▶ Select string functions

STRING  
FORMULA

- ▶ Select the **STRING FORMULA** function

TOCHAR

- ▶ Select the function for converting a numerical value to a string parameter
- ▶ Enter the number or the desired Q parameter to be converted, and confirm with the **ENT** key
- ▶ If desired, enter the number of decimal places that the TNC should convert, and confirm with the **ENT** key
- ▶ Close the parenthetical expression with the **ENT** key and confirm your entry with the **END** key

**Example: Convert parameter Q50 to string parameter QS11, use 3 decimal places**






```
N37 QS11 = TOCHAR ( DAT+Q50 DECIMALS3 )
```

## Programming: Q Parameters

### 9.10 String parameters

#### Copying a substring from a string parameter

The **SUBSTR** function copies a definable range from a string parameter.

- 
  - ▶ Show the soft-key row with special functions
- 
  - ▶ Select the menu for defining various plain-language functions
- 
  - ▶ Select string functions
- 
  - ▶ Select the **STRING FORMULA** function
  - ▶ Enter the number of the string parameter in which the TNC is to save the copied string. Confirm with the **ENT** key
- 
  - ▶ Select the function for cutting out a substring
  - ▶ Enter the number of the QS parameter from which the substring is to be copied. Confirm with the **ENT** key
  - ▶ Enter the number of the place starting from which to copy the substring, and confirm with the **ENT** key
  - ▶ Enter the number of characters to be copied, and confirm with the **ENT** key
  - ▶ Close the parenthetical expression with the **ENT** key and confirm your entry with the **END** key



Remember that the first character of a text sequence starts internally with the zeroth place.

**Example: A four-character substring (LEN4) is read from the string parameter QS10 beginning with the third character (BEG2)**

```
N37 QS13 = SUBSTR ( SRC_QS10 BEG2 LEN4 )
```

## Converting a string parameter to a numerical value

The **TONUMB** function converts a string parameter to a numerical value. The value to be converted should be only numerical.



The QS parameter must contain only one numerical value. Otherwise the TNC will output an error message.



- ▶ Select Q-parameter functions



- ▶ Select the **FORMULA** function
- ▶ Enter the number of the parameter in which the TNC is to save the numerical value. Confirm with the **ENT** key



- ▶ Shift the soft-key row












- ▶ Select the function for converting a string parameter to a numerical value
- ▶ Enter the number of the Q parameter to be converted, and confirm with the ENT key
- ▶ Close the parenthetical expression with the **ENT** key and confirm your entry with the **END** key

## Programming: Q Parameters

### 9.10 String parameters

#### Checking a string parameter

The **INSTR** function checks whether a string parameter is contained in another string parameter.

-  ▶ Select Q-parameter functions
-  ▶ Select the **FORMULA** function
-  ▶ Enter the number of the Q parameter for the result and confirm with the **ent** key. The TNC saves in the parameter the position at which the sought-after text begins.
-  ▶ Shift the soft-key row
-  ▶ Select the function for checking a string parameter
-  ▶ Enter the number of the QS parameter in which the text to be searched for is saved. Confirm with the ENT key
-  ▶ Enter the number of the QS parameter to be searched, and confirm with the ENT key
-  ▶ Enter the number of the place starting from which the TNC is to search the substring, and confirm with the **ENT** key
-  ▶ Close the parenthetical expression with the **ENT** key and confirm your entry with the **END** key



Remember that the first character of a text sequence starts internally with the zeroth place.

If the TNC cannot find the required substring, it will save the total length of the string to be searched (counting starts at 1) in the result parameter.








If the substring is found in more than one place, the TNC returns the first place at which it finds the substring.

**Example: Search through QS10 for the text saved in parameter QS13. Begin the search at the third place.**

```
N37 Q50 = INSTR ( SRC_QS10 SEA_QS13 BEG2 )
```

### Finding the length of a string parameter

The **STRLEN** function returns the length of the text saved in a selectable string parameter.

-  ▶ Select Q-parameter functions
-  ▶ Select the **FORMULA** function
-  ▶ Enter the number of the Q parameter in which the TNC is to save the ascertained string length. Confirm with the **ENT** key
-  ▶ Shift the soft-key row
-  ▶ Select the function for finding the text length of a string parameter
-  ▶ Enter the number of the QS parameter whose length the TNC is to ascertain, and confirm with the ENT key
-  ▶ Close the parenthetical expression with the **ENT** key and confirm your entry with the **END** key

#### Example: Find the length of QS15









```
N37 Q52 = STRLEN ( SRC_QS15 )
```

## Programming: Q Parameters

### 9.10 String parameters

#### Comparing alphabetic sequence

The **STRCOMP** function compares string parameters for alphabetic priority.

-  ▶ Select Q-parameter functions
-  ▶ Select the **FORMULA** function
-  ▶ Enter the number of the Q parameter in which the TNC is to save the result of comparison. Confirm with the **ENT** key
-  ▶ Shift the soft-key row
-  ▶ Select the function for comparing string parameters
-  ▶ Enter the number of the first QS parameter to be compared, and confirm with the **ENT** key
-  ▶ Enter the number of the second QS parameter to be compared, and confirm with the **ENT** key
-  ▶ Close the parenthetical expression with the **ENT** key and confirm your entry with the **END** key



The TNC returns the following results:

- **0**: The compared QS parameters are identical
- **-1**: The first QS parameter **precedes** the second QS parameter alphabetically
- **+1**: The first QS parameter **follows** the second QS parameter alphabetically

#### Example: QS12 and QS14 are compared for alphabetic priority





```
N37 Q52 = STRCOMP ( SRC_QS12 SEA_QS14 )
```



## Reading machine parameters

Use the **CFGREAD** function to read out TNC machine parameters as numerical values or as strings.

In order to read out a machine parameter, you must use the TNC's configuration editor to determine the parameter name, parameter object, and, if they have been assigned, the group name and index

Type	Meaning	Example	Icon
<b>Key</b>	Group name of the machine parameter (if assigned)	CH_NC	
<b>Entity</b>	Parameter object (the name starts with "Cfg...")	CfgGeoCycle	
<b>Attribute</b>	Name of the machine parameter	displaySpindleErr	
<b>Index</b>	List index of a machine parameter (if assigned)	[0]	



If you are in the configuration editor for the user parameters, you can change the display of the existing parameters. In the default setting, the parameters are displayed with short, explanatory texts. To display the actual system names of the parameters, press the key for the screen layout and then the SHOW SYSTEM NAME soft key. Follow the same procedure to return to the standard display.

Each time you want to interrogate a machine parameter with the **CFGREAD** function, you must first define a QS parameter with attribute, entity and key.

The following parameters are read in the CFGREAD function's dialog:

- **KEY\_QS**: Group name (key) of the machine parameter
- **TAG\_QS**: Object name (entity) of the machine parameter
- **ATR\_QS**: Name (attribute) of the machine parameter
- **IDX**: Index of the machine parameter

## Programming: Q Parameters

### 9.10 String parameters

#### Reading a string of a machine parameter

In order to store the content of a machine parameter as a string in a QS parameter:

- SPEC  
FCT ▶ Show the soft-key row with special functions
- PROGRAM  
FUNCTIONS ▶ Select the menu for defining various plain-language functions
- STRING  
FUNCTIONS ▶ Select string functions
- STRING  
FORMULA
  - ▶ Select the **STRING FORMULA** function
  - ▶ Enter the number of the string parameter in which the TNC is to save the machine parameter. Confirm with the **ENT** key
  - ▶ Select the CFGREAD function
  - ▶ Enter the numbers of the string parameters for the key, entity and attribute, then confirm with the **ENT** key
  - ▶ Enter the number for the index, or skip the dialog with NO ENT, whichever applies
  - ▶ Close the parenthetical expression with the **ENT** key and confirm your entry with the **END** key

#### Example: Read as a string the axis designation of the fourth axis



##### Parameter settings in the configuration editor

```
DisplaySettings
CfgDisplayData
    axisDisplayOrder
        [0] to [5]
```

14 DECLARE STRINGQS11 = ""	Assign string parameter for key
15 DECLARE STRINGQS12 = "CFGDISPLAYDATA"	Assign string parameter for entity
16 DECLARE STRINGQS13 = "AXISDISPLAYORDER"	Assign string parameter for parameter name
17 QS1 = CFGREAD( KEY_QS11 TAG_QS12 ATR_QS13 IDX3 )	Read out machine parameter

### Reading a numerical value of a machine parameter

In order to store the value of a machine parameter as a numerical value in a Q parameter:

-  ▶ Select Q-parameter functions
-  ▶ Select the FORMULA function
- ▶ Enter the number of the Q parameter in which the TNC is to save the machine parameter. Confirm with the **ENT** key
- ▶ Select the CFGREAD function
- ▶ Enter the numbers of the string parameters for the key, entity and attribute, then confirm with the **ENT** key
- ▶ Enter the number for the index, or skip the dialog with NO ENT, whichever applies
- ▶ Close the parenthetical expression with the **ENT** key and confirm your entry with the **END** key

### Example: Read overlap factor as Q parameter

#### Parameter settings in the configuration editor

```
ChannelSettings
CH_NC
  CfgGeoCycle
    pocketOverlap
```

14 DECLARE STRINGQS11 = "CH_NC"	Assign string parameter for key
15 DECLARE STRINGQS12 = "CFGGEOCYCLE"	Assign string parameter for entity
16 DECLARE STRINGQS13 = "POCKETOVERLAP"	Assign string parameter for parameter name
17 Q50 = CFGREAD( KEY_QS11 TAG_QS12 ATR_QS13 )	Read out machine parameter

## Programming: Q Parameters

### 9.11 Preassigned Q parameters

#### 9.11 Preassigned Q parameters

The Q parameters Q100 to Q199 are assigned values by the TNC. The following types of information are assigned to Q parameters:

- Values from the PLC
- Tool and spindle data
- Data on operating status
- Results of measurements from touch probe cycles etc.

The TNC saves the values for the preassigned Q parameters Q108, Q114 and Q115 to Q117 in the unit of measure used by the active program.



Do not use preassigned Q parameters (or QS parameters) between **Q100** and **Q199** (**QS100** and **QS199**) as calculation parameters in NC programs. Otherwise you might receive undesired results.

#### Values from the PLC: Q100 to Q107

The TNC uses the parameters Q100 to Q107 to transfer values from the PLC to an NC program.

#### Active tool radius: Q108

The active value of the tool radius is assigned to Q108. Q108 is calculated from:

- Tool radius R (tool table or **G99** block)
- Delta value DR from the tool table
- Delta value DR from the **T** block



The TNC remembers the current tool radius even if the power is interrupted.

#### Tool axis: Q109

The value of Q109 depends on the current tool axis:

Tool axis	Parameter value
No tool axis defined	Q109 = -1
X axis	Q109 = 0
Y axis	Q109 = 1
Z axis	Q109 = 2
U axis	Q109 = 6
V axis	Q109 = 7
W axis	Q109 = 8

**Spindle status: Q110**

The value of the parameter Q110 depends on the M function last programmed for the spindle.

<b>M function</b>	<b>Parameter value</b>
No spindle status defined	Q110 = -1
M3: Spindle ON, clockwise	Q110 = 0
M4: Spindle ON, counterclockwise	Q110 = 1
M5 after M3	Q110 = 2
M5 after M4	Q110 = 3

**Coolant on/off: Q111**

<b>M function</b>	<b>Parameter value</b>
M8: Coolant ON	Q111 = 1
M9: Coolant OFF	Q111 = 0

**Overlap factor: Q112**

The overlap factor for pocket milling (pocketOverlap) is assigned to Q112.

**Unit of measurement for dimensions in the program: Q113**

During nesting with PGM CALL, the value of the parameter Q113 depends on the dimensional data of the program from which the other programs are called.

<b>Dimensional data of the main program</b>	<b>Parameter value</b>
Metric system (mm)	Q113 = 0
Inch system (inches)	Q113 = 1

**Tool length: Q114**

The current value for the tool length is assigned to Q114.



The TNC remembers the current tool length even if the power is interrupted.

## Programming: Q Parameters

### 9.11 Preassigned Q parameters

#### Coordinates after probing during program run

The parameters Q115 to Q119 contain the coordinates of the spindle position at the moment of contact during programmed measurement with the 3-D touch probe. The coordinates refer to the datum point that is active in the Manual Operation mode.

The length of the stylus and the radius of the ball tip are not compensated in these coordinates.

Coordinate axis	Parameter value
X axis	Q115
Y axis	Q116
Z axis	Q117
4th Axis Machine-dependent	Q118
V. axis Machine-dependent	Q119

#### Deviation between actual value and nominal value during automatic tool measurement with the TT 130

Deviation of actual from nominal value	Parameter value
Tool length	Q115
Tool radius	Q116

#### Tilting the working plane with mathematical angles: rotary axis coordinates calculated by the TNC

Coordinates	Parameter value
A axis	Q120
B axis	Q121
C axis	Q122

**Measurement results from touch probe cycles (see also User's Manual for Cycle Programming)**

<b>Measured actual values</b>	<b>Parameter value</b>
Angle of a straight line	Q150
Center in reference axis	Q151
Center in minor axis	Q152
Diameter	Q153
Pocket length	Q154
Pocket width	Q155
Length of the axis selected in the cycle	Q156
Position of the centerline	Q157
Angle in the A axis	Q158
Angle in the B axis	Q159
Coordinate of the axis selected in the cycle	Q160
<b>Measured deviation</b>	<b>Parameter value</b>
Center in reference axis	Q161
Center in minor axis	Q162
Diameter	Q163
Pocket length	Q164
Pocket width	Q165
Measured length	Q166
Position of the centerline	Q167
<b>Determined space angle</b>	<b>Parameter value</b>
Rotation about the A axis	Q170
Rotation about the B axis	Q171
Rotation about the C axis	Q172
<b>Workpiece status</b>	<b>Parameter value</b>
Good	Q180
Rework	Q181
Scrap	Q182

## Programming: Q Parameters

### 9.11 Preassigned Q parameters

<b>Tool measurement with the BLUM laser</b>	<b>Parameter value</b>
Reserved	Q190
Reserved	Q191
Reserved	Q192
Reserved	Q193
<b>Reserved for internal use</b>	<b>Parameter value</b>
Marker for cycles	Q195
Marker for cycles	Q196
Marker for cycles (machining patterns)	Q197
Number of the last active measuring cycle	Q198
<b>Status of tool measurement with TT</b>	<b>Parameter value</b>
Tool within tolerance	Q199 = 0.0
Tool is worn (LTOL/RTOL is exceeded)	Q199 = 1.0
Tool is broken (LBREAK/RBREAK is exceeded)	Q199 = 2.0




## 9.12 Programming examples

### Example: Ellipse

Program sequence

- The contour of the ellipse is approximated by many short lines (defined in Q7). The more calculation steps you define for the lines, the smoother the curve becomes.
- The milling direction is determined with the starting angle and end angle in the plane :  
Machining direction is clockwise:  
Starting angle > end angle  
Machining direction is counterclockwise:  
Starting angle < end angle
- The tool radius is not taken into account.



<b>%ELLIPSE G71 *</b>	
<b>N10 D00 Q1 P01 +50 *</b>	Center in X axis
<b>N20 D00 Q2 P01 +50 *</b>	Center in Y axis
<b>N30 D00 Q3 P01 +50 *</b>	Semiasis in X
<b>N40 D00 Q4 P01 +30 *</b>	Semiasis in Y
<b>N50 D00 Q5 P01 +0 *</b>	Starting angle in the plane
<b>N60 D00 Q6 P01 +360 *</b>	End angle in the plane
<b>N70 D00 Q7 P01 +40 *</b>	Number of calculation steps
<b>N80 D00 Q8 P01 +30 *</b>	Rotational position of the ellipse
<b>N90 D00 Q9 P01 +5 *</b>	Milling depth
<b>N100 D00 Q10 P01 +100 *</b>	Feed rate for plunging
<b>N110 D00 Q11 P01 +350 *</b>	Feed rate for milling
<b>N120 D00 Q12 P01 +2 *</b>	Set-up clearance for pre-positioning
<b>N130 G30 G17 X+0 Y+0 Z-20 *</b>	Definition of workpiece blank
<b>N140 G31 G90 X+100 Y+100 Z+0 *</b>	
<b>N150 T1 G17 S4000 *</b>	Tool call
<b>N160 G00 G40 G90 Z+250 *</b>	Retract the tool
<b>N170 L10.0 *</b>	Call machining operation
<b>N180 G00 Z+250 M2 *</b>	Retract the tool, end program
<b>N190 G98 L10 *</b>	Subprogram 10: Machining operation
<b>N200 G54 X+Q1 Y+Q2 *</b>	Shift datum to center of ellipse
<b>N210 G73 G90 H+Q8 *</b>	Account for rotational position in the plane
<b>N220 Q35 = ( Q6 - Q5 ) / Q7 *</b>	Calculate angle increment
<b>N230 D00 Q36 P01 +Q5 *</b>	Copy starting angle
<b>N240 D00 Q37 P01 +0 *</b>	Set counter
<b>N250 Q21 = Q3 * COS Q36 *</b>	Calculate X coordinate for starting point
<b>N260 Q22 = Q4 * SIN Q36 *</b>	Calculate Y coordinate for starting point

## Programming: Q Parameters


### 9.12 Programming examples

N270 G00 G40 X+Q21 Y+Q22 M3 *	Move to starting point in the plane
N280 Z+Q12 *	Pre-position in spindle axis to set-up clearance
N290 G01 Z-Q9 FQ10 *	Move to working depth
N300 G98 L1 *	
N310 Q36 = Q36 + Q35 *	Update the angle
N320 Q37 = Q37 + 1 *	Update the counter
N330 Q21 = Q3 * COS Q36 *	Calculate the current X coordinate
N340 Q22 = Q4 * SIN Q36 *	Calculate the current Y coordinate
N350 G01 X+Q21 Y+Q22 FQ11 *	Move to next point
N360 D12 P01 +Q37 P02 +Q7 P03 1 *	Unfinished? If not finished, return to LBL 1
N370 G73 G90 H+0 *	Reset the rotation
N380 G54 X+0 Y+0 *	Reset the datum shift
N390 G00 G40 Z+Q12 *	Move to set-up clearance
N400 G98 L0 *	End of subprogram
N99999999 %ELLIPSE G71 *	

### Example: Concave cylinder machined with spherical cutter

Program sequence

- This program functions only with a spherical cutter. The tool length refers to the sphere center.
- The contour of the cylinder is approximated by many short line segments (defined in Q13). The more line segments you define, the smoother the curve becomes.
- The cylinder is milled in longitudinal cuts (here: parallel to the Y axis).
- The milling direction is determined with the starting angle and end angle in space :  
Machining direction clockwise:  
Starting angle > end angle  
Machining direction counterclockwise:  
Starting angle < end angle
- The tool radius is compensated automatically.



<b>%CYLIN G71 *</b>	
<b>N10 D00 Q1 P01 +50 *</b>	Center in X axis
<b>N20 D00 Q2 P01 +0 *</b>	Center in Y axis
<b>N30 D00 Q3 P01 +0 *</b>	Center in Z axis
<b>N40 D00 Q4 P01 +90 *</b>	Starting angle in space (Z/X plane)
<b>N50 D00 Q5 P01 +270 *</b>	End angle in space (Z/X plane)
<b>N60 D00 Q6 P01 +40 *</b>	Cylinder radius
<b>N70 D00 Q7 P01 +100 *</b>	Length of the cylinder
<b>N80 D00 Q8 P01 +0 *</b>	Rotational position in the X/Y plane
<b>N90 D00 Q10 P01 +5 *</b>	Allowance for cylinder radius
<b>N100 D00 Q11 P01 +250 *</b>	Feed rate for plunging
<b>N110 D00 Q12 P01 +400 *</b>	Feed rate for milling
<b>N120 D00 Q13 P01 +90 *</b>	Number of cuts
<b>N130 G30 G17 X+0 Y+0 Z-50 *</b>	Definition of workpiece blank
<b>N140 G31 G90 X+100 Y+100 Z+0 *</b>	
<b>N150 T1 G17 S4000 *</b>	Tool call
<b>N160 G00 G40 G90 Z+250 *</b>	Retract the tool
<b>N170 L10.0 *</b>	Call machining operation
<b>N180 D00 Q10 P01 +0 *</b>	Reset allowance
<b>N190 L10.0</b>	Call machining operation
<b>N200 G00 G40 Z+250 M2 *</b>	Retract the tool, end program
<b>N210 G98 L10 *</b>	Subprogram 10: Machining operation
<b>N220 Q16 = Q6 - Q10 - Q108 *</b>	Account for allowance and tool, based on the cylinder radius
<b>N230 D00 Q20 P01 +1 *</b>	Set counter
<b>N240 D00 Q24 P01 +Q4 *</b>	Copy starting angle in space (Z/X plane)
<b>N250 Q25 = ( Q5 - Q4 ) / Q13 *</b>	Calculate angle increment
<b>N260 G54 X+Q1 Y+Q2 Z+Q3 *</b>	Shift datum to center of cylinder (X axis)

## Programming: Q Parameters


### 9.12 Programming examples

N270 G73 G90 H+Q8 *	Account for rotational position in the plane
N280 G00 G40 X+0 Y+0 *	Pre-position in the plane to the cylinder center
N290 G01 Z+5 F1000 M3 *	Pre-position in the spindle axis
N300 G98 L1 *	
N310 I+0 K+0 *	Set pole in the Z/X plane
N320 G11 R+Q16 H+Q24 FQ11 *	Move to starting position on cylinder, plunge-cutting obliquely into the material
N330 G01 G40 Y+Q7 FQ12 *	Longitudinal cut in Y+ direction
N340 D01 Q20 P01 +Q20 P02 +1 *	Update the counter
N350 D01 Q24 P01 +Q24 P02 +Q25 *	Update solid angle
N360 D11 P01 +Q20 P02 +Q13 P03 99 *	Finished? If finished, jump to end
N370 G11 R+Q16 H+Q24 FQ11 *	Move in an approximated "arc" for the next longitudinal cut
N380 G01 G40 Y+0 FQ12 *	Longitudinal cut in Y- direction
N390 D01 Q20 P01 +Q20 P02 +1 *	Update the counter
N400 D01 Q24 P01 +Q24 P02 +Q25 *	Update solid angle
N410 D12 P01 +Q20 P02 +Q13 P03 1 *	Unfinished? If not finished, return to LBL 1
N420 G98 L99 *	
N430 G73 G90 H+0 *	Reset the rotation
N440 G54 X+0 Y+0 Z+0 *	Reset the datum shift
N450 G98 L0 *	End of subprogram
N99999999 %ZYLIN G71 *	

### Example: Convex sphere machined with end mill

Program sequence

- This program requires an end mill.
- The contour of the sphere is approximated by many short lines (in the Z/X plane, defined in Q14). The smaller you define the angle increment, the smoother the curve becomes.
- You can determine the number of contour cuts through the angle increment in the plane (defined in Q18).
- The tool moves upward in three-dimensional cuts.
- The tool radius is compensated automatically.



<b>%SPHERE G71 *</b>	
<b>N10 D00 Q1 P01 +50 *</b>	Center in X axis
<b>N20 D00 Q2 P01 +50 *</b>	Center in Y axis
<b>N30 D00 Q4 P01 +90 *</b>	Starting angle in space (Z/X plane)
<b>N40 D00 Q5 P01 +0 *</b>	End angle in space (Z/X plane)
<b>N50 D00 Q14 P01 +5 *</b>	Angle increment in space
<b>N60 D00 Q6 P01 +45 *</b>	Sphere radius
<b>N70 D00 Q8 P01 +0 *</b>	Starting angle of rotational position in the X/Y plane
<b>N80 D00 Q9 P01 +360 *</b>	End angle of rotational position in the X/Y plane
<b>N90 D00 Q18 P01 +10 *</b>	Angle increment in the X/Y plane for roughing
<b>N100 D00 Q10 P01 +5 *</b>	Allowance in sphere radius for roughing
<b>N110 D00 Q11 P01 +2 *</b>	Set-up clearance for pre-positioning in the spindle axis
<b>N120 D00 Q12 P01 +350 *</b>	Feed rate for milling
<b>N130 G30 G17 X+0 Y+0 Z-50 *</b>	Definition of workpiece blank
<b>N140 G31 G90 X+100 Y+100 Z+0 *</b>	
<b>N150 T1 G17 S4000 *</b>	Tool call
<b>N160 G00 G40 G90 Z+250 *</b>	Retract the tool
<b>N170 L10.0 *</b>	Call machining operation
<b>N180 D00 Q10 P01 +0 *</b>	Reset allowance
<b>N190 D00 Q18 P01 +5 *</b>	Angle increment in the X/Y plane for finishing
<b>N200 L10.0 *</b>	Call machining operation
<b>N210 G00 G40 Z+250 M2 *</b>	Retract the tool, end program
<b>N220 G98 L10 *</b>	Subprogram 10: Machining operation
<b>N230 D01 Q23 P01 +Q11 P02 +Q6 *</b>	Calculate Z coordinate for pre-positioning
<b>N240 D00 Q24 P01 +Q4 *</b>	Copy starting angle in space (Z/X plane)
<b>N250 D01 Q26 P01 +Q6 P02 +Q108 *</b>	Compensate sphere radius for pre-positioning
<b>N260 D00 Q28 P01 +Q8 *</b>	Copy rotational position in the plane
<b>N270 D01 Q16 P01 +Q6 P02 -Q10 *</b>	Account for allowance in the sphere radius
<b>N280 G54 X+Q1 Y+Q2 Z-Q16 *</b>	Shift datum to center of sphere
<b>N290 G73 G90 H+Q8 *</b>	Account for starting angle of rotational position in the plane
<b>N300 G98 L1 *</b>	Pre-position in the spindle axis
<b>N310 I+0 J+0 *</b>	Set pole in the X/Y plane for pre-positioning

## Programming: Q Parameters

### 9.12 Programming examples

N320 G11 G40 R+Q26 H+Q8 FQ12 *	Pre-position in the plane
N330 I+Q108 K+0 *	Set pole in the Z/X plane, offset by the tool radius
N340 G01 Y+0 Z+0 FQ12 *	Move to working depth
N350 G98 L2 *	
N360 G11 G40 R+Q6 H+Q24 FQ12 *	Move upward in an approximated "arc"
N370 D02 Q24 P01 +Q24 P02 +Q14 *	Update solid angle
N380 D11 P01 +Q24 P02 +Q5 P03 2 *	Inquire whether an arc is finished. If not finished, return to LBL 2
N390 G11 R+Q6 H+Q5 FQ12 *	Move to the end angle in space
N400 G01 G40 Z+Q23 F1000 *	Retract in the spindle axis
N410 G00 G40 X+Q26 *	Pre-position for next arc
N420 D01 Q28 P01 +Q28 P02 +Q18 *	Update rotational position in the plane
N430 D00 Q24 P01 +Q4 *	Reset solid angle
N440 G73 G90 H+Q28 *	Activate new rotational position
N450 D12 P01 +Q28 P02 +Q9 P03 1 *	Unfinished? If not finished, return to LBL 1
N460 D09 P01 +Q28 P02 +Q9 P03 1 *	
N470 G73 G90 H+0 *	Reset the rotation
N480 G54 X+0 Y+0 Z+0 *	Reset the datum shift
N490 G98 L0 *	End of subprogram
N99999999 %SPHERE G71 *	

# 10

**Programming:  
Miscellaneous  
functions**

## Programming: Miscellaneous functions

### 10.1 Entering miscellaneous functions M and STOP

#### 10.1 Entering miscellaneous functions M and STOP

##### Fundamentals

With the TNC's miscellaneous functions—also called M functions—you can affect

- the program run, e.g., a program interruption
- the machine functions, such as switching spindle rotation and coolant supply on and off
- the path behavior of the tool



The machine tool builder may add some M functions that are not described in this User's Manual. Refer to your machine manual.

You can enter up to four M functions at the end of a positioning block or in a separate block. The TNC then shows the dialog:

##### Miscellaneous function M?

You usually enter only the number of the M function in the programming dialog. Some M functions can be programmed with additional parameters. In this case, the dialog is continued for the parameter input.

In the Manual Operation and EI. Handwheel modes of operation, the M functions are entered with the **M** soft key.



Please note that some M functions become effective at the start of a positioning block, and others at the end, regardless of their position in the NC block.

M functions come into effect in the block in which they are called.

Some M functions are effective only in the block in which they are programmed. Unless the M function is only effective blockwise, either you must cancel it in a subsequent block with a separate M function, or it is automatically canceled by the TNC at the end of the program.

##### Entering an M function in a STOP block

If you program a **STOP** block, the program run or test run is interrupted at the block, for example for tool inspection. You can also enter an M function in a **STOP** block:



- ▶ To program an interruption of program run, press the **STOP** key
- ▶ Enter a miscellaneous function **M**

##### Example NC blocks

```
N87 G36 M6
```



## 10.2 M functions for program run inspection, spindle and coolant

### Overview



The machine tool builder can influence the behavior of the miscellaneous functions described below. Refer to your machine manual.

M	Effect	Effective at block	Start	End
<b>M0</b>	Program STOP Spindle STOP			■
<b>M1</b>	Optional program STOP Spindle STOP if necessary Coolant OFF if necessary (not effective during Test Run, function determined by the machine tool builder)			■
<b>M2</b>	STOP program run Spindle STOP Coolant OFF Return jump to block 1 CLEAR status display (depending on machine parameter <b>clearMode</b> )			■
<b>M3</b>	Spindle ON clockwise		■	
<b>M4</b>	Spindle ON counterclockwise		■	
<b>M5</b>	Spindle STOP			■
<b>M6</b>	Tool change Spindle STOP Program STOP			■
<b>M8</b>	Coolant ON		■	
<b>M9</b>	Coolant OFF			■
<b>M13</b>	Spindle ON clockwise Coolant ON		■	
<b>M14</b>	Spindle ON counterclockwise Coolant ON		■	
<b>M30</b>	Same as M2			■

## Programming: Miscellaneous functions


### 10.3 Miscellaneous functions for coordinate data

#### 10.3 Miscellaneous functions for coordinate data

##### Programming machine-referenced coordinates: M91/M92

###### Scale reference point

On the scale, a reference mark indicates the position of the scale reference point.



###### Machine datum

The machine datum is required for the following tasks:

- Defining the limits of traverse (software limit switches)
- Approach machine-referenced positions (such as tool change positions)
- Set a workpiece datum

The distance in each axis from the scale reference point to the machine datum is defined by the machine tool builder in a machine parameter.

###### Standard behavior

The TNC references coordinates to the workpiece datum (See "Datum setting without a 3-D touch probe", page 475).

###### Behavior with M91 – Machine datum

If you want the coordinates in a positioning block to be referenced to the machine datum, end the block with M91.



If you program incremental coordinates in an M91 block, enter them with respect to the last programmed M91 position. If no M91 position is programmed in the active NC block, then enter the coordinates with respect to the current tool position.

The coordinate values on the TNC screen are referenced to the machine datum. Switch the display of coordinates in the status display to REF, See "Status displays", page 75.

### Behavior with M92—Additional machine datum



In addition to the machine datum, the machine tool builder can also define an additional machine-based position as a reference point.

For each axis, the machine tool builder defines the distance between the machine datum and this additional machine datum. Refer to your machine manual.

If you want the coordinates in a positioning block to be based on the additional machine datum, end the block with M92.



Radius compensation remains the same in blocks that are programmed with M91 or M92. The tool length, however, is **not** compensated.

### Effect

M91 and M92 are effective only in the blocks in which they are programmed.


M91 and M92 take effect at the start of block.

### Workpiece datum

If you want the coordinates to always be referenced to the machine datum, you can inhibit datum setting for one or more axes.

If datum setting is inhibited for all axes, the TNC no longer displays the SET DATUM soft key in the Manual Operation mode.

The figure shows coordinate systems with the machine datum and workpiece datum.



### M91/M92 in the Test Run mode

In order to be able to graphically simulate M91/M92 movements, you need to activate working space monitoring and display the workpiece blank referenced to the set datum, See "Showing the workpiece blank in the working space ", page 531.

## Programming: Miscellaneous functions

### 10.3 Miscellaneous functions for coordinate data

#### Moving to positions in a non-tilted coordinate system with a tilted working plane: M130

##### Standard behavior with a tilted working plane

The TNC places the coordinates in the positioning blocks in the tilted coordinate system.

##### Behavior with M130

The TNC places coordinates in straight line blocks in the untilted coordinate system.

The TNC then positions the (tilted) tool to the programmed coordinates of the untilted system.



##### **Danger of collision!**

Subsequent positioning blocks or fixed cycles are carried out in a tilted coordinate system. This can lead to problems in fixed cycles with absolute pre-positioning.

The function M130 is allowed only if the tilted working plane function is active.

##### Effect


M130 functions blockwise in straight-line blocks without tool radius compensation.

## 10.4 Miscellaneous functions for path behavior

### Machining small contour steps: M97

#### Standard behavior

The TNC inserts a transition arc at outside corners. If the contour steps are very small, however, the tool would damage the contour. In such cases the TNC interrupts program run and generates the error message "Tool radius too large."




#### Behavior with M97

The TNC calculates the intersection of the contour elements—as at inside corners—and moves the tool over this point.

Program M97 in the same block as the outside corner.



Instead of **M97** you should use the much more powerful function **M120 LA**. See "Calculating the radius-compensated path in advance (LOOK AHEAD): M120 ", page 338!



#### Effect

M97 is effective only in the blocks in which it is programmed.



A corner machined with M97 will not be completely finished. You may wish to rework the contour with a smaller tool.

#### Example NC blocks

N50 G99 G01 ... R+20 *	Large tool radius
...	
N130 X ... Y ... F ... M97 *	Move to contour point 13
N140 G91 Y-0.5 ... F ... *	Machine small contour step 13 to 14
N150 X+100 ... *	Move to contour point 15
N160 Y+0.5 ... F ... M97 *	Machine small contour step 15 to 16
N170 G90 X ... Y ... *	Move to contour point 17


## Programming: Miscellaneous functions

### 10.4 Miscellaneous functions for path behavior

#### Machining open contour corners: M98


##### Standard behavior

The TNC calculates the intersections of the cutter paths at inside corners and moves the tool in the new direction at those points. If the contour is open at the corners, however, this will result in incomplete machining.



##### Behavior with M98

With the miscellaneous function M98, the TNC temporarily suspends radius compensation to ensure that both corners are completely machined:



##### Effect

M98 is effective only in the blocks in which it is programmed. M98 takes effect at the end of block.

##### Example NC blocks

Move to the contour points 10, 11 and 12 in succession:

```
N100 G01 G41 X ... Y ... F ... *
```

```
N110 X ... G91 Y ... M98 *
```

```
N120 X+ ... *
```

## Feed rate factor for plunging movements: M103

### Standard behavior

The TNC moves the tool at the last programmed feed rate, regardless of the direction of traverse.

### Behavior with M103

The TNC reduces the feed rate when the tool moves in the negative direction of the tool axis. The feed rate for plunging FZMAX is calculated from the last programmed feed rate FPROG and a factor F%:

$$FZMAX = FPROG \times F\%$$

### Programming M103

If you enter M103 in a positioning block, the TNC continues the dialog by asking you the factor F.

### Effect

M103 becomes effective at the start of block.

To cancel M103, program M103 once again without a factor.



M103 is also effective in an active tilted working plane. The feed rate reduction is then effective during traverse in the negative direction of the **tilted** tool axis.

### Example NC blocks

The feed rate for plunging is to be 20% of the feed rate in the plane.

...	Actual contouring feed rate (mm/min):
N170 G01 G41 X+20 Y+20 F500 M103 F20 *	500
N180 Y+50 *	500
N190 G91 Z-2.5 *	100
N200 Y+5 Z-5 *	141
N210 X+50 *	500
N220 G90 Z+5 *	500

## Programming: Miscellaneous functions

### 10.4 Miscellaneous functions for path behavior

#### Feed rate in millimeters per spindle revolution: M136

##### Standard behavior

The TNC moves the tool at the programmed feed rate F in mm/min

##### Behavior with M136



In inch-programs, M136 is not permitted in combination with the new alternate feed rate FU.  
The spindle is not permitted to be controlled when M136 is active.

With M136, the TNC does not move the tool in mm/min, but rather at the programmed feed rate F in millimeters per spindle revolution. If you change the spindle speed by using the spindle override, the TNC changes the feed rate accordingly.

##### Effect

M136 becomes effective at the start of block.

You can cancel M136 by programming M137.



## Feed rate for circular arcs: M109/M110/M111

### Standard behavior

The TNC applies the programmed feed rate to the path of the tool center.

### Behavior at circular arcs with M109

The TNC adjusts the feed rate for circular arcs at inside and outside contours so that the feed rate at the tool cutting edge remains constant.



#### **Caution: Danger to the workpiece and tool!**

On very small outside corners the TNC may increase the feed rate so much that the tool or workpiece can be damaged. Avoid **M109** with small outside corners.

### Behavior at circular arcs with M110

The TNC keeps the feed rate constant for circular arcs at inside contours only. At outside contours, the feed rate is not adjusted.



If you define M109 or M110 before calling a machining cycle with a number greater than 200, the adjusted feed rate is also effective for circular arcs within these machining cycles. The initial state is restored after finishing or aborting a machining cycle.

### Effect

M109 and M110 become effective at the start of block. To cancel M109 or M110, enter M111.

## Programming: Miscellaneous functions

### 10.4 Miscellaneous functions for path behavior

#### Calculating the radius-compensated path in advance (LOOK AHEAD): M120

##### Standard behavior

If the tool radius is larger than the contour step that is to be machined with radius compensation, the TNC interrupts program run and generates an error message. M97 (See "Machining small contour steps: M97", page 333) suppresses the error message, but it results in dwell marks and will also move the corner.

If the programmed contour contains undercut features, the tool may damage the contour.


##### Behavior with M120

The TNC checks radius-compensated paths for contour undercuts and tool path intersections, and calculates the tool path in advance from the current block. Areas of the contour that might be damaged by the tool are not machined (dark areas in figure).

You can also use M120 to calculate the radius compensation for digitized data or data created on an external programming system. This means that deviations from the theoretical tool radius can be compensated.

Use LA (Look Ahead) behind M120 to define the number of blocks (maximum: 99) that you want the TNC to calculate in advance.

Note that the larger the number of blocks you choose, the higher the block processing time will be.



##### Input

If you enter M120 in a positioning block, the TNC continues the dialog for this block by asking you the number of blocks LA that are to be calculated in advance.

##### Effect

M120 must be located in an NC block that also contains radius compensation **G41** or **G42**. M120 is then effective from this block until

- radius compensation is canceled with **G40**
- M120 LA0 is programmed, or
- M120 is programmed without LA, or
- another program is called with **%**
- the working plane is tilted with Cycle **G80** or the PLANE function

M120 becomes effective at the start of block.

**Restrictions**

- After an external or internal stop, you can only re-enter the contour with the function RESTORE POS. AT N. Before you start the block scan, you must cancel M120, otherwise the TNC will output an error message.
- When using the path functions **G25** and **G24**, the blocks before and after **G25** or **G24** must contain only coordinates in the working plane.
- Before using the functions listed below, you have to cancel M120 and the radius compensation:
  - Cycle **G60** Tolerance
  - Cycle **G80** Working plane
  - PLANE function
  - M114
  - M128
  - TCPM FUNCTION

## Programming: Miscellaneous functions

### 10.4 Miscellaneous functions for path behavior

#### Superimposing handwheel positioning during program run: M118

##### Standard behavior

In the program run modes, the TNC moves the tool as defined in the part program.

##### Behavior with M118

M118 permits manual corrections by handwheel during program run. Just program M118 and enter an axis-specific value (linear or rotary axis) in millimeters.



The handwheel superimpositioning function with M118 in combination with collision monitoring is only possible in stopped condition. To be able to use M118 without limitations, you have to deselect DCM either by soft key in the menu, or activate a kinematics model without collision monitored objects (CMOs)

##### Input

If you enter M118 in a positioning block, the TNC continues the dialog for this block by asking you the axis-specific values. The coordinates are entered with the orange axis direction buttons or the ASCII keyboard.

##### Effect

Cancel handwheel positioning by programming M118 once again without coordinate input.

M118 becomes effective at the start of block.

##### Example NC blocks

You want to be able to use the handwheel during program run to move the tool in the working plane X/Y by  $\pm 1$  mm and in the rotary axis B by  $\pm 5^\circ$  from the programmed value:

```
N250 G01 G41 X+0 Y+38.5 F125 M118 X1 Y1 B5 *
```



M118 is effective in a tilted coordinate system if you activate the tilted working plane function for the Manual Operation mode. If the tilted working plane function is not active for the Manual Operation mode, the original coordinate system is effective. M118 also functions in the Positioning with MDI mode of operation!

**Virtual tool axis VT**

Your machine tool builder must have prepared the TNC for this function. Refer to your machine manual.

With the virtual tool axis you can also traverse in the direction of a sloping tool with the handwheel with machines with swivel heads. To traverse in a virtual tool axis direction select the VT axis on the display of your handwheel, See "Traverse with electronic handwheels", page 458. With an HR 5xx handwheel you can select the virtual axis directly with the orange VI axis key if required (refer to your machine manual).

You can also carry out handwheel superimpositioning in the currently active tool axis direction with the M118 function. For this purpose, you must at least define the spindle axis with the permitted traverse range (e.g. M118 Z5) in the M118 function and select the VT axis on the handwheel.

## Programming: Miscellaneous functions

### 10.4 Miscellaneous functions for path behavior

#### Retraction from the contour in the tool-axis direction: M140

##### Standard behavior

In the program run modes, the TNC moves the tool as defined in the part program.

##### Behavior with M140

With M140 MB (move back) you can enter a path in the direction of the tool axis for departure from the contour.

##### Input

If you enter M140 in a positioning block, the TNC continues the dialog and asks for the desired path of tool departure from the contour. Enter the requested path that the tool should follow when departing the contour, or press the MB MAX soft key to move to the limit of the traverse range.

In addition, you can program the feed rate at which the tool traverses the entered path. If you do not enter a feed rate, the TNC moves the tool along the entered path at rapid traverse.

##### Effect

M140 is effective only in the block in which it is programmed.

M140 becomes effective at the start of block.

##### Example NC blocks

Block 250: Retract the tool 50 mm from the contour.

Block 251: Move the tool to the limit of the traverse range.

```
N250 G01 X+0 Y+38.5 F125 M140 MB50 *
```

```
N251 G01 X+0 Y+38.5 F125 M140 MB MAX *
```



M140 is also effective if the tilted-working-plane function is active. On machines with tilting heads, the TNC then moves the tool in the tilted coordinate system.

With **M140 MB MAX** you can only retract in the positive direction.

Always define a TOOL CALL with a tool axis before entering **M140**, otherwise the direction of traverse is not defined.



##### Danger of collision!

When dynamic collision monitoring (DCM) is active, the TNC might move the tool only until it detects a collision and, from there, complete the NC program without any error message. This can result in tool paths different from those programmed!

## Suppressing touch probe monitoring: M141

### Standard behavior

When the stylus is deflected, the TNC outputs an error message as soon as you attempt to move a machine axis.

### Behavior with M141

The TNC moves the machine axes even if the touch probe is deflected. This function is required if you wish to write your own measuring cycle in connection with measuring cycle 3 in order to retract the stylus by means of a positioning block after it has been deflected.



#### **Danger of collision!**

If you use M141, make sure that you retract the touch probe in the correct direction.

M141 functions only for movements with straight-line blocks.

### Effect

M141 is effective only in the block in which it is programmed.

M141 becomes effective at the start of block.

## Programming: Miscellaneous functions

### 10.4 Miscellaneous functions for path behavior

#### Deleting basic rotation: M143

##### Standard behavior

The basic rotation remains in effect until it is reset or is overwritten with a new value.

##### Behavior with M143

The TNC erases a programmed basic rotation from the NC program.



The function **M143** is not permitted during mid-program startup.

##### Effect

M143 is effective only in the block in which it is programmed.  
M143 becomes effective at the start of the block.



## Automatically retract tool from the contour at an NC stop: M148

### Standard behavior

At an NC stop the TNC stops all traverse movements. The tool stops moving at the point of interruption.

### Behavior with M148



The M148 function must be enabled by the machine tool builder. The machine tool builder defines in a machine parameter the path that the TNC is to traverse for a **LIFTOFF** command.

The TNC retracts the tool from the contour by up to 2 mm in the direction of the tool axis if, in the **LIFTOFF** column of the tool table, you set the parameter **Y** for the active tool. See "Enter tool data into the table", page 164.

**LIFTOFF** takes effect in the following situations:

- An NC stop triggered by you
- An NC stop triggered by the software, e.g. if an error occurred in the drive system
- When a power interruption occurs



### Danger of collision!

Remember that, especially on curved surfaces, the surface can be damaged during return to the contour. Retract the tool before returning to the contour!

In the **CfgLiftOff** machine parameter, define the value by which the tool is to be retracted. In the **CfgLiftOff** machine parameter you can also switch the function off.

### Effect

M148 remains in effect until deactivated with M149.

M148 becomes effective at the start of block, M149 at the end of block.

## Programming: Miscellaneous functions

### 10.4 Miscellaneous functions for path behavior

#### Rounding corners: M197

##### Standard behavior

The TNC inserts a transition arc at outside corners with active radius compensation. This may lead to grinding of the edge.

##### Behavior with M197

With Function M197 the contour at the corner is tangentially extended and a smaller transition arc is then inserted. When you program Function M197 and then press the ENT key, the TNC opens the **DL** input field. In **DL** you define the length with which the TNC extends the contour elements. With M197 the corner radius is reduced, the corner grinds less and the traverse movement is still tangential.

##### Effect

The Function M197 is effective blockwise and is only effective on outside corners.

##### Example NC blocks

```
L X... Y... RL M197 DL0.876
```

# 11

**Programming:  
Special functions**

## Programming: Special functions

### 11.1 Overview of special functions

#### 11.1 Overview of special functions

The TNC provides the following powerful special functions for a large number of applications:

Function	Description
Dynamic Collision Monitoring (DCM—software option)	page 351
Adaptive Feed Control Software Option (AFC—software option)	page 357
Active Chatter Control (ACC—software option)	page 370
Working with text files	page 373
Working with freely definable tables	page 377

Press the **SPEC FCT** and the corresponding soft keys to access further special functions of the TNC. The following tables will give you an overview of which functions are available.

#### Main menu for SPEC FCT special functions


SPEC  
FCT

► Press the special functions key

Function	Soft key	Description
Define program defaults	PROGRAM DEFAULTS	page 349
Functions for contour and point machining	CONTOUR + POINT MACHINING	page 349
Define the <b>PLANE</b> function	TILT MACHINING PLANE	page 387
Define different DIN/ISO functions	PROGRAM FUNCTIONS	page 350
Define turning functions	TURNING PROGRAM FUNCTIONS	page 429
Define structure items	INSERT SECTION	page 135



After pressing the SPEC FCT key, you can open the **smartSelect** selection window with the GOTO key. The TNC displays a structure overview with all available functions. You can rapidly navigate with the cursor or mouse and select functions in the tree diagram. The TNC displays online help for the specific functions in the window on the right.




## Program defaults menu

PROGRAM  
DEFAULTS

- ▶ Select the program defaults menu

Function	Soft key	Description
Define workpiece blank	BLK FORM	page 96
Select datum table	DATUM TABLE	See User's Manual for Cycles
Define global cycle parameters	GLOBAL DEF	See User's Manual for Cycles




## Functions for contour and point machining menu

CONTOUR  
+ POINT  
MACHINING

- ▶ Select the menu for functions for contour and point machining

Function	Soft key	Description
Assign contour description	DECLARE CONTOUR	See User's Manual for Cycles
Select a contour definition	SEL CONTOUR	See User's Manual for Cycles
Define a complex contour formula	CONTOUR FORMULA	See User's Manual for Cycles



# Programming: Special functions


## 11.1 Overview of special functions

### Menu of various DIN/ISO functions

PROGRAM  
FUNCTIONS

- ▶ Select the menu for defining various DIN/ISO functions

Function	Soft key	Description
Define the positioning behavior for rotary axes	TCPM	page 415
Define string functions	STRING FUNCTIONS	page 305
Define DIN/ISO functions	DIN/ISO	page 372
Add comments	INSERT COMMENT	page 132



## 11.2 Dynamic Collision Monitoring (software option)

### Function




The Dynamic Collision Monitoring (DCM) must be adapted by the machine manufacturer for the TNC and for the machine. Refer to your machine manual.

The machine manufacturer can define any objects that are monitored by the TNC during all machining operations. If two objects monitored for collision come within a defined distance of each other, the TNC outputs an error message.

The TNC can display the defined collision objects graphically in all machine modes of operation, See "Graphic depiction of the protected space", page 356.

The TNC also monitors the current tool with the length and radius entered in the tool table for collision (assuming a cylindrical tool). TNC likewise monitors the stepped tools according to the definition in the tool table and also displays it accordingly.



## Programming: Special functions

### 11.2 Dynamic Collision Monitoring (software option)



#### Keep these constraints in mind:

- DCM helps to reduce the danger of collision. However, the TNC cannot consider all possible constellations in operation.
- Collisions of defined machine components and the tool with the workpiece are not detected by the TNC.
- DCM can only protect those machine components from collision that your machine tool builder has correctly defined with regard to dimensions, orientation and position.
- The TNC can monitor the tool only if a **positive tool radius** has been defined in the tool table. The TNC cannot monitor tools with a radius of 0 (as is often used in drilling tools) and therefore issues an appropriate warning.
- The TNC can only monitor tools for which you have defined **positive tool lengths**.
- When a touch probe cycle starts, the TNC no longer monitors the stylus length and ball-tip diameter so that you can also probe in collision objects.
- For certain tools (such as face milling cutters), the diameter that would cause a collision can be greater than the dimensions defined in the tool-compensation data.
- The handwheel superimpositioning function with **M118** in combination with collision monitoring is only possible in stopped condition. To be able to use **M118** without limitations, you have to deselect DCM either by soft key in the **Collision Monitoring (DCM)** menu, or activate a kinematics model without collision monitored objects (CMOs).
- For tapping with a floating tap holder only the basic setting of the floating tap holder is taken into account.
- The tool oversizes **DL** and **DR** from the tool table are taken into account by the TNC. Tool oversizes in the **TOOL CALL** are not taken into account.



The TNC cannot implement collision monitoring if with an axis-direction key or the handwheel you carry out a movement over several axes simultaneously. For example such a movement with several axes is implemented as follows:

- In the tilted working plane on a machine with swivel head (sloping tool).
- With active TCPM

This monitoring is first supported with software 34059x-03.



### Collision monitoring in the manual operating modes

In the **Manual Operation** and **El. Handwheel** operating modes, the TNC stops a motion if two objects monitored for collision approach each other within a distance of 1 to 2 mm. In this case, the TNC displays an error message naming the two objects causing collision.

If you have selected a screen layout in which positions are displayed on the left and collision objects on the right, then the TNC additionally marks the colliding objects in red.



Once a collision warning is displayed, machine motions via the direction keys or handwheel are possible only if the motion increases the distance between the collision objects. For example, by pressing the axis direction key for the opposite direction.

Motions that reduce the distance or leave it unchanged are not allowed as long as collision monitoring is active.

## Programming: Special functions

### 11.2 Dynamic Collision Monitoring (software option)

#### Deactivating collision monitoring

If you have to reduce the distance between collision-monitored objects for lack of space, the collision monitoring function can be deactivated.



#### Danger of collision!

If you deactivate collision monitoring, the TNC does not output an error message with a pending collision. With inactive collision monitoring the symbol for collision monitoring in the operating mode bar starts to blink:

In addition, the TNC shows a corresponding symbol in the position display (see the table below).

Symbols in the status display show the condition of collision monitoring:

Function	Symbol
Collision monitoring active	
Collision monitoring is not available	
Collision monitoring is not active	



- ▶ Shift the soft-key row if necessary




- ▶ Select the menu for deactivating collision monitoring



- ▶ Select the **Manual Operation** menu item
- ▶ To deactivate collision monitoring, press the **ENT** key, and the symbol for collision monitoring in the operating mode display starts to blink


- ▶ Move axes manually, pay attention to traverse direction
- ▶ To reactivate the collision monitor: Press the ENT key



### Collision monitoring in Automatic operation



The handwheel superimpositioning function with M118 in combination with collision monitoring is only possible in stopped condition.

If collision monitoring is on, the TNC shows the symbol in the position display .

If you have deactivated collision monitoring, the symbol for collision monitoring flashes in the operating-mode bar.



#### **Danger of collision!**

The M140 (See "Retraction from the contour in the tool-axis direction: M140", page 342) and M150 (See "") functions might cause non-programmed movements if the TNC detects a collision when executing these functions!

The TNC monitors motions blockwise, i.e. it outputs a warning in the block which would cause a collision, and interrupts program run. A reduction of the feed rate, as with Manual Operation, does not occur. The TNC outputs a collision warning if two objects monitored for collision approach each other within a distance of 5 mm.



## 11.3 Adaptive Feed Control Software Option (AFC)

### Application



This feature must be enabled and adapted by the machine tool builder.


Refer to your machine manual.

Your machine tool builder may also have specified whether the TNC uses the spindle power or any other value as the input value for the feed control.



Adaptive feed control is not intended for tools with diameters less than 5 mm. This limit diameter might also be greater if the spindle's rated power is very high.

Do not work with adaptive feed control in operations in which the feed rate and spindle speed must be adapted to each other, such as tapping.



In adaptive feed control the TNC automatically controls the feed rate during program run as a function of the current spindle power consumption. The spindle power required for each machining step is to be recorded in a teach-in cut and saved by the TNC in a file belonging to the part program. When each machining step is started, which is normally when the spindle is switched on, the TNC controls the feed rate so that it remains within the limits that you have defined.

This makes it possible to avoid negative effects on the tool, the workpiece, and the machine that might be caused by changing cutting conditions. Cutting conditions are changed particularly by:

- Tool wear
- Fluctuating cutting depths that occur especially with cast parts
- Fluctuating hardness caused by material flaws

## Programming: Special functions

### 11.3 Adaptive Feed Control Software Option (AFC)

Adaptive feed control (AFC) offers the following benefits:

- Optimization of machining time  
By controlling the feed rate, the TNC tries to maintain the recorded maximum spindle power during the entire machining time. It shortens the machining time by increasing the feed rate in machining zones with little material removal.
- Tool monitoring  
If the spindle power exceeds the recorded maximum value, the TNC decreases the feed rate until the reference spindle power is reattained. If the maximum spindle power is exceeded during machining and at the same time the feed rate falls below the minimum that you defined, the TNC reacts by shutting down. This helps to prevent further damage after a tool breaks or is worn out.
- Protection of the machine's mechanical elements  
Timely feed rate reduction and shutdown responses help to avoid machine overload

### Defining the AFC basic settings

You make the control settings for the TNC feed rate control in the table **AFC.TAB**, which must be saved in the root directory **TNC:\table**.

The data in this table are default values that were copied during a teach-in cut into a file belonging to the respective program and serve as the basis for control. The following data are to be defined in this table:

Column	Function
<b>NR</b>	Consecutive line number in the table (has no further functions)
<b>AFC</b>	Name of the control setting. You enter this name in the <b>AFC</b> column of the tool table. It specifies the assignment of control parameters to the tool.
<b>FMIN</b>	Feed rate at which the TNC is to conduct a shutdown response. Enter the value in percent with respect to the programmed feed rate. Input range: 50 to 100 %
<b>FMAX</b>	Maximum feed rate in the material up to which the TNC can automatically increase the feed rate. Enter the value in percent of the programmed feed rate.
<b>FIDL</b>	Feed rate for traverse when the tool is not cutting (feed rate in the air). Enter the value in percent of the programmed feed rate.
<b>FENT</b>	Feed rate for traverse when the tool moves into or out of the material. Enter the value in percent with respect to the programmed feed rate. Maximum input value: 100 %

## Programming: Special functions

### 11.3 Adaptive Feed Control Software Option (AFC)

Column	Function
<b>OVLD</b>	<p>Desired reaction of the TNC to overload:</p> <ul style="list-style-type: none"> <li>■ <b>M</b>: Execution of a macro defined by the machine tool builder</li> <li>■ <b>S</b>: Immediate NC stop</li> <li>■ <b>F</b>: NC stop if the tool has been retracted</li> <li>■ <b>E</b>: Just display an error message on the screen</li> <li>■ <b>-</b>: No overload reaction</li> </ul> <p>The TNC conducts a shutdown response if the maximum spindle power is exceeded for more than one second and at the same time the feed rate falls below the minimum you defined. Enter the desired function via the ASCII keyboard.</p>
<b>POUT</b>	<p>Spindle power at which the TNC is to detect tool exit from the workpiece. Enter the value in percent of the learned reference load. Recommended input value: 8 %</p>
<b>SENS</b>	<p>Sensitivity (aggressiveness) of feedback control. A value between 50 and 200 can be entered. 50 is for slow control, 200 for a very aggressive control. An aggressive control reacts quickly and with strong changes to the values, but it tends to overshoot. Recommended value: 100</p>
<b>PLC</b>	<p>Value that the TNC is to transfer to the PLC at the beginning of a machining step. The machine tool builder defines the function, so refer to your machine manual.</p>



In the **AFC.TAB** table you can define as many control settings (lines) as desired.

If there is no **AFC.TAB** table in the **TNC:\table** directory, the TNC uses permanently defined internal control settings for the teach-in cut. It is best, however, to work with the **AFC.TAB** table.



## Adaptive Feed Control Software Option (AFC) 11.3

Proceed as follows to create the AFC.TAB file (only necessary if the file does not yet exist):

- ▶ Select the **Programming** mode of operation
- ▶ Call the file manager: Press the **PGM MGT** key
- ▶ Select the **TNC:\** directory
- ▶ Make the new file **AFC.TAB** and confirm with the **ENT** key: The TNC shows a list of table formats
- ▶ Select the **AFC.TAB** table format and confirm with the **ENT** key: The TNC creates a table with the **Standard** control settings

## Programming: Special functions

### 11.3 Adaptive Feed Control Software Option (AFC)

#### Recording a teach-in cut

The TNC provides several cycles that enable you start and stop a teach-in step:

- **FUNCTION AFC CUT BEGIN TIME1 DIST2 LOAD3** This TNC starts a sequence of cuts with active AFC. The switch from the teach-in cut to closed-loop mode begins as soon as the reference load was determined in the teach-in phase, or once one of the conditions TIME, DIST or LOAD is fulfilled. With TIME you define the maximum duration in seconds of the teach-in phase. DIST defines the maximum distance for the teach-in cut. With LOAD you can set a reference load directly.
- **FUNCTION AFC CUT END** The AFC CUT END function deactivates the AFC control
- **FUNCTION AFC CTRL** The AFC CTRL function activates closed-loop mode starting with the place at which this block is run (even if the teach-in phase has not yet been completed).

To program the AFC functions for starting and ending the teach in cut, proceed as follows:

- ▶ In the **Programming** mode, press the SPEC FCT key
- ▶ Select the **Program Functions** soft key
- ▶ Select the **FunCtion AFC** soft key
- ▶ Select the function

With a teach-in cut the TNC firstly copies the basic settings defined in the AFC.TAB table into the file **<name>.H.AFC.DEP** for each machining step. **<name>** is the name of the NC program for which you have recorded the teach-in cut. In addition, the TNC measures the maximum spindle power consumed during the teach-in cut and saves this value in the table.

Each line in the **<name>.H.AFC.DEP** file stands for a machining section, that you start with **FUNCTION AFC CUT BEGIN** and complete with **FUNCTION AFC CUT END**. You can edit all data of the **<name>.H.AFC.DEP** file if you wish to optimize them. If you have optimized the values in comparison with the values in the AFC.TAB table, the TNC places an asterisk \* in front of the control settings in the AFC column. Besides the data from the AFC.TAB table, See "Defining the AFC basic settings", page 359, the TNC saves the following additional information in the **<name>.H.AFC.DEP** file:

Column	Function
<b>NR</b>	Number of the machining step
<b>TOOL</b>	Number or name of the tool with which the machining step was made (not editable)
<b>IDX</b>	Index of the tool with which the machining step was made (not editable)
<b>N</b>	Difference for tool call: <ul style="list-style-type: none"> <li>■ <b>0</b>: Tool was called by its tool number</li> <li>■ <b>1</b>: Tool was called by its tool name</li> </ul>
<b>PREF</b>	Reference load of the spindle. The TNC measures the value in percent with respect to the rated power of the spindle

## Adaptive Feed Control Software Option (AFC) 11.3

Column	Function
ST	Status of the machining step: <ul style="list-style-type: none"><li>■ <b>L</b>: In the next program run, a teach-in cut is recorded for this machining step. The TNC overwrites any existing values in this line</li><li>■ <b>C</b>: The teach-in cut was successfully completed. The next program run can be conducted with automatic feed control</li></ul>
AFC	Name of the control setting

## Programming: Special functions

### 11.3 Adaptive Feed Control Software Option (AFC)

Remember the following before you record a teach-in cut:

- If required, adapt the control settings in the AFC.TAB table
- Enter the desired control setting for all tools in the **AFC** column of the tool table TOOL.T
- Select the program for teach-in
- Activate the adaptive feed control by soft key, See "Activating/deactivating AFC", page 365



You can teach any number of machining steps for a tool. Your machine tool builder will either make a function available for this, or will integrate this possibility in the functions for switching on the spindle. Refer to your machine manual.

The functions for starting and ending a machining step are machine-dependent. Refer to your machine manual.



When you are performing a teach-in cut, the TNC shows the spindle reference power determined until this time in a pop-up window.

You can reset the reference power at any time by pressing the **pref reset** soft key. The TNC then restarts the learning phase.

When you record a teach-in cut, the TNC internally sets the spindle override to 100 %. Then you can no longer change the spindle speed.

During the teach-in cut, you can influence the measured reference load by using the feed rate override to make any changes to the contouring feed rate.

You do not have to run the entire machining step in the learning mode. If the cutting conditions do not change significantly, you can switch to the control mode immediately. Press the **EXIT LEARNING** soft key, and the status changes from **L** to **C**.

You can repeat a teach-in cut as often as desired. Manually change the status from **ST** back to **L**. It may be necessary to repeat the teach-in cut if the programmed feed rate is far too fast, and forces you to sharply decrease the feed rate override during the machining step.

The TNC changes the status from teach-in (**L**) to controlling (**C**) only when the recorded reference load is greater than 2 %. Adaptive feed control is not possible for smaller values.

Proceed as follows to select and, if required, edit the **<name>.H.AFC.DEP** file:



- ▶ Select the **Program Run, Full Sequence** operating mode



- ▶ Shift the soft-key row

## Adaptive Feed Control Software Option (AFC) 11.3



- ▶ Select the table of AFC settings
- ▶ Make optimizations if required



Note that the **<name>.H.AFC.DEP** file is locked against editing as long as the NC program **<name>.H** is running.

The TNC removes the editing lock if one of the following functions has been executed:

- **M02**
- **M30**
- **END PGM**

You can also change the **<name>.H.AFC.DEP** file in the Programming mode of operation. If necessary, you can even delete a machining step (entire line) there.



In order to edit the **<name>.H.AFC.DEP** file, you might have to set the file manager so that all file types are displayed (**SELECT TYPE** soft key) Also see: "Files", page 106

### Activating/deactivating AFC



- ▶ Select the **Program Run, Full Sequence** operating mode




- ▶ Shift the soft-key row



- ▶ To activate the adaptive feed control: Set the soft key to **ON**, and the TNC displays the AFC symbol in the position display, See "Status displays", page 75



- ▶ To deactivate the adaptive feed control: Set the soft key to **OFF**



## Programming: Special functions

### 11.3 Adaptive Feed Control Software Option (AFC)



The adaptive feed control remains active until you deactivate it by soft key. The TNC remembers the setting of the soft key even if the power is interrupted.

If the adaptive feed control is active in the **control** mode, the TNC internally sets the spindle override to 100 %. Then you can no longer change the spindle speed.

If the adaptive feed control is active in the **control** mode, the TNC takes over the feed rate override function:

- If you increase the feed rate override, it has no influence on the control.
- If you decrease the feed rate override by more than **10 %** with respect to the maximum setting, the TNC switches the adaptive feed control off. In this case the TNC displays a window to inform you.

In NC blocks containing **FMAX**, the adaptive feed control is **not active**.

Mid-program startup is allowed during active feed control and the TNC takes the cut number of the startup point into account.

The TNC shows various pieces of information in the additional status display when adaptive feed control is active. See "Additional status displays", page 76. In addition, in the position display the TNC shows the symbol



.

## Log file

The TNC stores various pieces of information for each machining step of a teach-in cut in the **<name>.H.AFC2.DEP** file. **<name>** is the name of the NC program for which you have recorded the teach-in cut. During control, the TNC updates the data and makes various evaluations. The following data are to be saved in this table:

Column	Function
<b>NR</b>	Number of the machining step
<b>TOOL</b>	Number or name of the tool with which the machining step was made
<b>IDX</b>	Index of the tool with which the machining step was made
<b>SNOM</b>	Nominal spindle speed [rpm]
<b>SDIF</b>	Maximum difference of the spindle speed in % of the nominal speed
<b>LTIME</b>	Machining time for the teach-in cut
<b>CTIME</b>	Machining time for the control cut
<b>TDIFF</b>	Time difference in % between the machining time during teach-in and control
<b>PMAX</b>	Maximum recorded spindle power during machining. The TNC shows the value as a percent of the spindle's rated power.
<b>PREF</b>	Reference load of the spindle. The TNC shows the value as a percent of the spindle's rated power.
<b>FMIN</b>	Smallest occurring feed factor. The TNC shows the value as a percentage of the programmed feed rate
<b>OVLD</b>	Reaction by the TNC to overload: <ul style="list-style-type: none"> <li>■ <b>M</b>: A macro defined by the machine tool builder has been run</li> <li>■ <b>S</b>: Immediate NC stop was conducted</li> <li>■ <b>F</b>: NC stop was conducted after the tool was retracted</li> <li>■ <b>E</b>: An error message was displayed</li> <li>■ <b>-</b>: There was no overload reaction</li> </ul>
<b>BLOCK</b>	Block number at which the machining step begins

## Programming: Special functions

### 11.3 Adaptive Feed Control Software Option (AFC)



The TNC records the total machining time for all teach-in cuts (**LTIME**), all control cuts (**CTIME**) and the total time difference (**TDIFF**), and enters it after the keyword **TOTAL** in the last line of the log file.  
The TNC can only calculate the time difference (**TDIFF**) if you have completed the teach-in step. Otherwise the column remains empty.

Proceed as follows to select the **<name>.H.AFC2.DEP** file:



- ▶ Select the **Program Run, Full Sequence** operating mode



- ▶ Shift the soft-key row



- ▶ Select the table of AFC settings



- ▶ Show the log file

#### Tool breakage/tool wear monitoring



This feature must be enabled and adapted by the machine tool builder.  
Refer to your machine manual.

With the breakage/wear monitor, a cut-based tool breakage detection during active AFC can be realized.

Through the functions that can be defined by the machine tool builder you can define a percentage value for wear or breakage detection with respect to the rated power.

When the defined limit spindle power range is not maintained, the TNC conducts an NC stop.



## Spindle load monitoring



This feature must be enabled and adapted by the machine tool builder. Refer to your machine manual.

With the spindle load monitoring function you can easily have the spindle load monitored in order, for example, to detect overloading the spindle power.

The function is independent of AFC, i.e. it is not cut-based and does not depend on teach-in steps. Through the functions that can be defined by the machine tool builder, you only need to define the percentage value for spindle limit power with respect to the rated power.

When the defined limit spindle power range is not maintained, the TNC conducts an NC stop.

## Programming: Special functions

### 11.4 Active Chatter Control (ACC; software option)

#### 11.4 Active Chatter Control (ACC; software option)

##### Application



This feature must be enabled and adapted by the machine tool builder.

Refer to your machine manual.

Strong forces come into play during roughing (power milling). Depending on the tool spindle speed, the resonances in the machine tool and the chip volume (metal-removal rate during milling), the tool can sometimes begin to “chatter.” This chattering places heavy strain on the machine, and causes ugly marks on the workpiece surface. The tool, too, is subject to heavy and irregular wear from chattering. In extreme cases it can result in tool breakage.

To reduce the inclination to chattering, HEIDENHAIN now offers an effective antidote with **ACC** (Active Chatter Control). The use of this control function is particularly advantageous during heavy cutting. ACC makes substantially higher metal removal rates possible. This makes it possible to increase your metal removal rate by up to 25 % and more, depending on the type of machine. You reduce the mechanical load on the machine and increase the life of your tools at the same time.



Please note that ACC was developed especially for heavy cutting and is particularly effective in this area. You need to conduct appropriate tests to ensure whether ACC is also advantageous during standard roughing.

When you use the ACC feature, you must enter the number of tool cuts **CUT** for the corresponding tool in the TOOL.T tool table.

### Activating/deactivating ACC

To activate ACC, for the respective tool in the tool table TOOL.T you first the column **ACC** to **Y** (ENT key = Y, NO ENT key = N).


To activate; deactivate ACC for the machine mode,




- ▶ Select the **Program Run, Full Sequence**, the **Program Run, Single Block** or the **Positioning with Manual Data Input** mode of operation



- ▶ Shift the soft-key row



- ▶ To activate ACC, set the soft key to **ON** and the TNC displays the ACC symbol in the position display, See "Status displays", page 75



- ▶ To deactivate ACC: Set the soft key to **OFF**

If collision monitoring is on, in the position display the TNC shows the symbol **ACC**.

## Programming: Special functions

### 11.5 Defining DIN/ISO Functions














#### 11.5 Defining DIN/ISO Functions

##### Overview



If a USB keyboard is connected, you can also enter the DIN/ISO functions by using the USB keyboard.

The TNC provides soft keys with the following functions for creating DIN/ISO programs:

Function	Soft key
Select DIN/ISO functions	
Feed rate	
Tool movements, cycles and program functions	
X coordinate of the circle center/pole	
Y coordinate of the circle center/pole	
Label call for subprogram and program section repeat	
Miscellaneous function	
Block number	
Tool call	
Polar coordinate angle	
Z coordinate of the circle center/pole	
Polar coordinate radius	
Spindle speed	

## 11.6 Creating Text Files

### Application

You can use the TNC's text editor to write and edit texts. Typical applications:







- Recording test results
- Documenting working procedures
- Creating formula collections

Text files are type .A files (ASCII files). If you want to edit other types of files, you must first convert them into type .A files.

### Opening and exiting text files

- ▶ Select the Programming and Editing mode of operation
- ▶ Call the file manager: Press the **PGM MGT** key
- ▶ Display type .A files: Press the **SELECT TYPE** and then the **SHOW .A** soft keys
- ▶ Select a file and open it with the **SELECT** soft key or **ENT** key, or create a new file by entering the new file name and confirming your entry with the **ENT** key

To leave the text editor, call the file manager and select a file of a different file type, for example a part program

Cursor movements	Soft key
Move cursor one word to the right	
Move cursor one word to the left	
Go to next screen page	
Go to previous screen page	
Go to beginning of file	
Go to end of file	

## Programming: Special functions

### 11.6 Creating Text Files

#### Editing texts

Above the first line of the text editor, there is an information field showing the file name, location and line information:

- File:** Name of the text file  
**Line:** Line in which the cursor is presently located  
**Column:** Column in which the cursor is presently located





The text is inserted or overwritten at the location of the cursor. You can move the cursor to any desired position in the text file by pressing the arrow keys.

The line in which the cursor is presently located is depicted in a different color. You can insert a line break with the Return or **ENT** key.

#### Deleting and re-inserting characters, words and lines

With the text editor, you can erase words and even lines, and insert them at any desired location in the text.


- ▶ Move the cursor to the word or line that you wish to erase and insert at a different place in the text
- ▶ Press the **DELETE WORD** or **DELETE LINE** soft key. The text is placed in the buffer memory
- ▶ Move the cursor to the location where you wish to insert the text, and press the **RESTORE LINE/WORD** soft key

Function	Soft key
Delete and temporarily store a line	
Delete and temporarily store a word	
Delete and temporarily store a character	
Insert a line or word from temporary storage	

## Editing text blocks

You can copy and erase text blocks of any size, and insert them at other locations. Before any of these actions, you must first select the desired text block:

- ▶ To select a text block: Move the cursor to the first character of the text you wish to select.




- ▶ Press the **SELECT BLOCK** soft key
- ▶ Move the cursor to the last character of the text you wish to select. You can select whole lines by moving the cursor up or down directly with the arrow keys—the selected text is shown in a different color

After selecting the desired text block, you can edit the text with the following soft keys:

Function	Soft key
Delete the selected block and store temporarily	
Store the selected block temporarily without erasing (copy)	

If desired, you can now insert the temporarily stored block at a different location:

- ▶ Move the cursor to the location where you want to insert the temporarily stored text block




- ▶ Press the **INSERT BLOCK** soft key: The text block is inserted.

You can insert the temporarily stored text block as often as desired

## Transferring the selected block to a different file


- ▶ Select the text block as described previously



- ▶ Press the **APPEND TO FILE** soft key. The TNC displays the dialog prompt **Destination file =**
- ▶ Enter the path and name of the destination file. The TNC appends the selected text to the specified file. If no target file with the specified name is found, the TNC creates a new file with the selected text.

## Inserting another file at the cursor position

- ▶ Move the cursor to the location in the text where you wish to insert another file



- ▶ Press the **READ FILE** soft key. The TNC displays the dialog prompt **File name =**
- ▶ Enter the path and name of the file you want to insert

## Programming: Special functions

### 11.6 Creating Text Files

#### Finding text sections

With the text editor, you can search for words or character strings in a text. Two functions are available:

##### Finding the current text

The search function is used for finding the next occurrence of the word in which the cursor is presently located:

- ▶ Move the cursor to the desired word.
- ▶ Select the search function: Press the **FIND** soft key
- ▶ Press the **FIND CURRENT WORD** soft key
- ▶ Exit the search function: Press the **END** soft key

##### Finding any text

- ▶ Select the search function: Press the **FIND** soft key. The TNC displays the dialog prompt **Find text:**
- ▶ Enter the text that you wish to find
- ▶ Find the text: Press the **EXECUTE** soft key
- ▶ Exit the search function: Press the **END** soft key




## 11.7 Freely definable tables

### Fundamentals

In freely definable tables you can read and save any information from the NC program. The Q parameter functions **D26** to **D28** are provided for this purpose.

You can change the format of freely definable tables, i.e. the columns and their properties, by using the structure editor. They enable you to make tables that are exactly tailored to your application.

You can also switch between table view (default setting) and form view.



### Creating a freely definable table

- ▶ To call the file manager, press the **PGM MGT** key
- ▶ Enter any file name with the .TAB extension and confirm with the **ENT** key. The TNC displays a pop-up window with permanently saved table formats
- ▶ Use the arrow key to select a table template, e.g. **EXAMPLE.TAB** and confirm with the **ent** key: The TNC opens a new table in the predefined format
- ▶ To adapt the table to your requirements you have to edit the table format, See "Editing the table format", page 377



Machine tool builders may define their own table templates and save them in the TNC. When you create a new table, the TNC opens a pop-up window listing all available table templates.




You can also save your own table templates in the TNC. To do this, you create a new table, change the table format and save the table in the directory. Then your template will also be available in the list box for table templates when you create a new table.

### Editing the table format

- ▶ Press the **EDIT FORMAT** soft key (2nd soft-key level): The TNC opens the editor form, in which the table structure is shown. The meanings of the structure commands (header entries) are shown in the following table.

Structure command	Meaning
<b>Available columns:</b>	List of all columns contained in the table
<b>Move before:</b>	The entry highlighted in <b>Available columns</b> is moved in front of this column



## Programming: Special functions

### 11.7 Freely definable tables

Structure command	Meaning
<b>Name</b>	Column name: Is displayed in the header
<b>Column type</b>	<b>TEXT</b> : Text entry <b>SIGN</b> : Sign + or - <b>BIN</b> : Binary number <b>DEC</b> : Decimal, positive, complete number (cardinal number) <b>HEX</b> : Hexadecimal number <b>INT</b> : Complete number <b>LENGTH</b> : Length (is converted in inch programs) <b>FEED</b> : Feed rate (mm/min or 0.1 inch/min) <b>IFEED</b> : Feed rate (mm/min or inch/min) <b>FLOAT</b> : Floating-point number <b>BOOL</b> : Logical value <b>INDEX</b> : Index <b>TSTAMP</b> : Fixed format for date and time
<b>Default value</b>	Default value for the fields in this column
<b>Width</b>	Width of the column (number of characters)
<b>Primary key</b>	First table column
<b>Language-sensitive column name</b>	Language-sensitive dialogs

You can use a connected mouse or the TNC keyboard to navigate in the form. Navigation using the TNC keyboard:



In a table that already has lines, you cannot change the table properties and . Once you have deleted all lines, you can change these properties. If required, create a backup copy of the table beforehand.

In a field of the **TSTAMP** column type you can reset an invalid value if you press the CE key and then the ENT key.

### Exiting the structure editor

- ▶ Press the **OK** soft key. The TNC closes the editor form and applies the changes. All changes are discarded by pressing the **CANCEL** soft key.


### Switching between table and form view

All tables with the file extension **.TAB** can be opened in either list view or form view.

In the form view the TNC lists the line numbers with the contents of the first column in the left half of the screen.

In the right half you can change the data.

- ▶ Press the **ENT** key or the arrow key to move to the next input field.
- ▶ To select another line, press the green navigation key (folder symbol). This moves the cursor to the left window, and you can select the desired line with the arrow keys. Press the green navigation key to switch back to the input window.



## Programming: Special functions

### 11.7 Freely definable tables

#### D26: TAOPEN: Open a freely definable table

With the function **D26: TABOPEN** you open a freely definable table to be written to with **D27** or to be read from with **D28**.



Only one table can be open in an NC program. A new block with **TABOPEN** automatically closes the last opened table.

The table to be opened must have the file name extension **.TAB**.

**Example: Open the table TAB1.TAB, which is saved in the directory TNC:\DIR1.**

```
N56 D26: TABOPEN TNC:\DIR1\TAB1.TAB
```

### D27: TAPWRITE: Write to a freely definable table

After you have opened a table with **D26: TABOPEN** you can use the function **D27: TAPWRITE** to write to it.

You can define and write to several column names in a **TABWRITE** block. The column names must be written between quotation marks and separated by a comma. You define the values that the TNC is to write to the respective column with Q parameters.



Note that by default the **D27: TABWRITE** function writes values to the currently open table also in the Test Run mode. The **D18 ID992 NR16** function enables you to query in which operating mode the program is to be run. If the **D27** function is to be run only in the Program Run operating modes, you can skip the respective program section by using a jump command page 271.

You can write only to numerical table fields.

If you wish to write to more than one column in a block, you must save the values under successive Q parameter numbers.

#### Example

You wish to write to the columns "Radius," "Depth" and "D" in line 5 of the presently opened table. The value to be written in the table must be saved in the Q parameters Q5, Q6 and Q7.

```
N53 Q5 = 3.75
```

```
N54 Q6 = -5
```

```
N55 Q7 = 7.5
```

```
N56 D27: TABWRITE 5/"RADIUS,DEPTH,D" = Q5
```

## Programming: Special functions

### 11.7 Freely definable tables

#### D28: TAPREAD: Read from a freely definable table

After you have opened a table with **D26: TABOPEN** you can use the function **D28:TABREAD** to read from it.

You can define and read several column names in a **TABREAD** block. The column names must be written between quotation marks and separated by a comma. In the **D28** block you can define the Q parameter number in which the TNC is to write the value that is first read.



You can read only numerical table fields.  
If you wish to read from more than one column in a block, the TNC will save the values under successive Q parameter numbers.

#### Example

You wish to read the values of the columns "Radius," "Depth" and "D" from line 6 of the presently opened table. Save the first value in Q parameter Q10 (second value in Q11, third value in Q12).

```
N56 D28: TABREAD Q10 = 6/"RADIUS,DEPTH,D"
```

# 12

**Programming:  
Multiple Axis  
Machining**

## Programming: Multiple Axis Machining

### 12.1 Functions for multiple axis machining

#### 12.1 Functions for multiple axis machining

The TNC functions for multiple axis machining are described in this chapter.

<b>TNC function</b>	<b>Description</b>	<b>Page</b>
<b>PLANE</b>	Define machining in the tilted working plane	385
<b>M116</b>	Feed rate of rotary axes	407
<b>PLANE/M128</b>	Inclined-tool machining	406
<b>FUNCTION TCPM</b>	Define the behavior of the TNC when positioning the rotary axes (improvement of M128)	415
<b>M126</b>	Shortest-path traverse of rotary axes	408
<b>M94</b>	Reduce display value of rotary axes	409
<b>M128</b>	Define the behavior of the TNC when positioning the rotary axes	410
<b>M138</b>	Selection of tilted axes	413
<b>M144</b>	Calculate machine kinematics	414



## 12.2 The PLANE Function: Tilting the Working Plane (Software Option 1)

### Introduction







The machine manufacturer must enable the functions for tilting the working plane!

You can only use the **PLANE** function in its entirety on machines which have at least two rotary axes (head and/or table). Exception: **PLANE AXIAL** can also be used if only a single rotary axis is present or active on your machine.





The **PLANE** function is a powerful function for defining tilted working planes in various manners.

All **PLANE** functions available on the TNC describe the desired working plane independently of the rotary axes actually present on your machine. The following possibilities are available:

Function	Required parameters	Soft key	Page
<b>SPATIAL</b>	Three spatial angles: <b>SPA</b> , <b>SPB</b> , and <b>SPC</b>		389
<b>PROJECTED</b>	Two projection angles: <b>PROPR</b> and <b>PROMIN</b> and a rotation angle <b>ROT</b>		391
<b>EULER</b>	Three Euler angles: precession ( <b>EULPR</b> ), nutation ( <b>EULNU</b> ) and rotation ( <b>EULROT</b> )		392
<b>VECTOR</b>	Normal vector for defining the plane and base vector for defining the direction of the tilted X axis		394

## Programming: Multiple Axis Machining

### 12.2 The PLANE Function: Tilting the Working Plane (Software Option 1)

Function	Required parameters	Soft key	Page
<b>POINTS</b>	Coordinates of any three points in the plane to be tilted		396
<b>RELATIV</b>	Single, incrementally effective spatial angle		398
<b>AXIAL</b>	Up to three absolute or incremental axis angles <b>A,B,C</b>		399
<b>RESET</b>	Reset the PLANE function		388



The parameter definition of the **PLANE** function is separated into two parts:

- The geometric definition of the plane, which is different for each of the available **PLANE** functions.
- The positioning behavior of the **PLANE** function, which is independent of the plane definition and is identical for all **PLANE** functions, See "Specifying the positioning behavior of the PLANE function", page 401



The actual-position-capture function is not possible with an active tilted working plane.

If you use the **PLANE** function when **M120** is active, the TNC automatically rescinds the radius compensation, which also rescinds the **M120** function.

Always use **PLANE RESET** to reset **PLANE** functions. Entering 0 in all **PLANE** parameters does not completely reset the function.

If you restrict the number of tilting axes with the **M138** function, your machine may provide only limited tilting possibilities.

You can only use the PLANE functions with tool axis Z.

The TNC only supports tilting the working plane with spindle axis Z.

# The PLANE Function: Tilting the Working Plane (Software Option 1) 12.2


## Defining the PLANE function

SPEC  
FCT

- ▶ Show the soft-key row with special functions

TILT  
MACHINING  
PLANE

- ▶ To reset the **PLANE** function, press the **TILT MACHINING PLANE** soft key: The TNC displays the available definitions in the soft-key row




## Selecting functions

- ▶ Select the desired function by soft key. The TNC continues the dialog and requests the required parameters

## Position display

As soon as a **PLANE** function is active, the TNC shows the calculated spatial angle in the additional status display (see figure). As a rule, the TNC internally always calculates with spatial angles, independent of which **PLANE** function is active.







During tilting (**MOVE** or **TURN** mode) in the Distance-To-Go mode (**DIST**), the TNC shows (in the rotary axis) the distance to go (or calculated distance) to the final position of the rotary axis.



## Programming: Multiple Axis Machining

### 12.2 The PLANE Function: Tilting the Working Plane (Software Option 1)

#### Resetting the PLANE function

- ▶  Show the soft-key row with special functions
- ▶  To select special TNC functions, press the **SPECIAL TNC FUNCT.** soft key
- ▶  To select the PLANE function, press the **TILT MACHINING PLANE** soft key: The TNC displays the available definitions in the soft-key row
- ▶  Select the Reset function. This internally resets the **PLANE** function, but does not change the current axis positions
- ▶  Specify whether the TNC should automatically move the rotary axes to the default setting (**MOVE** or **TURN**) or not (**STAY**), See "Automatic positioning: MOVE/TURN/STAY (entry is mandatory)", page 401
- ▶  To conclude entry, Press END.

#### NC block

```
25 PLANE RESET MOVE ABST50 F1000
```



The **PLANE RESET** function resets the current **PLANE** function—or an active cycle **G80**—completely (angles = 0 and function is inactive). It does not need to be defined more than once.


## The PLANE Function: Tilting the Working Plane (Software Option 1) 12.2

### Defining the working plane with the spatial angle: PLANE SPATIAL

#### Application

Spatial angles define a working plane using up to three rotations of the coordinate system; two perspectives that have always the same result are available for this purpose.

- **Rotations about the machine-based coordinate system:** The sequence of the rotations is first around the machine axis C, then around the machine axis B, and then around the machine axis A.
- **Rotations about the respectively tilted coordinate system:** The sequence of rotations is first around the machine axis C, then around the rotated axis B, and then around the rotated axis A. This perspective is usually easier to understand, because one rotary axis is fixed so that the rotations of the coordinate system are easier to comprehend.



#### Before programming, note the following

You must always define the three spatial angles **SPA**, **SPB**, and **SPC**, even if one of them = 0.


This operation corresponds to Cycle19 if the entries in Cycle 19 are defined as spatial angles on the machine side.

Parameter description for the positioning behavior:  
See "Specifying the positioning behavior of the PLANE function", page 401.

## Programming: Multiple Axis Machining

### 12.2 The PLANE Function: Tilting the Working Plane (Software Option 1)



#### Input parameters



- ▶ **Spatial angle A?:** Rotational angle **SPA** around the fixed machine axis X (see figure at top right). Input range from  $-359.9999^\circ$  to  $+359.9999^\circ$
- ▶ **Spatial angle B?:** Rotational angle **SPB** around the fixed machine axis Y (see figure at top right). Input range from  $-359.9999^\circ$  to  $+359.9999^\circ$
- ▶ **Spatial angle C?:** Rotational angle **SPC** around the fixed machine axis Z (see figure at center right). Input range from  $-359.9999^\circ$  to  $+359.9999^\circ$
- ▶ Continue with the positioning properties, See "Specifying the positioning behavior of the PLANE function", page 401

#### Abbreviations used

Abbreviation	Meaning
SPATIAL	In space
SPA	<b>Spatial A:</b> Rotation around the X axis
SPB	<b>Spatial B:</b> Rotation around the Y axis
SPC	<b>Spatial C:</b> Rotation around the Z axis



#### NC block

```
5 PLANE SPATIAL SPA+27 SPB+0 SPC
+45 .....
```

## The PLANE Function: Tilting the Working Plane (Software Option 1) 12.2

### Defining the working plane with the projection angle: PLANE PROJECTED

#### Application


Projection angles define a machining plane through the entry of two angles that you determine by projecting the first coordinate plane (Z/X plane with tool axis Z) and the second coordinate plane (Y/Z with tool axis Z) onto the machining plane to be defined.



#### Before programming, note the following

You can only use projection angles if the angle definitions are given with respect to a rectangular cuboid. Otherwise there will be deformations on the workpiece.



Parameter description for the positioning behavior:  
See "Specifying the positioning behavior of the PLANE function", page 401.



#### Input parameters



- ▶ **Proj. angle in 1st coord. plane?:** Projected angle of the tilted machining plane in the 1st coordinate plane of the fixed machine coordinate system (Z/X for tool axis Z, see figure at top right). Input range: from  $-89.9999^\circ$  to  $+89.9999^\circ$ . The  $0^\circ$  axis is the principal axis of the active working plane (X for tool axis Z. See figure at top right for positive direction)
- ▶ **Proj. angle in 2nd coord. plane?:** Projected angle in the 2nd coordinate plane of the fixed machine coordinate system (Y/Z for tool axis Z, see figure at top right). Input range: from  $-89.9999^\circ$  to  $+89.9999^\circ$ . The  $0^\circ$  axis is the minor axis of the active machining plane (Y for tool axis Z)
- ▶ **ROT angle of tilted plane? :** Rotation of the tilted coordinate system around the tilted tool axis (corresponds to a rotation with Cycle 10 ROTATION). The rotation angle is used to simply specify the direction of the principal axis of the working plane (X for tool axis Z, Z for tool axis Y; see figure at bottom right). Input range:  $-360^\circ$  to  $+360^\circ$
- ▶ Continue with the positioning properties, See "Specifying the positioning behavior of the PLANE function", page 401



#### NC block

```
5 PLANE PROJECTED PROPR+24 PROMIN+24 PROROT+30 .....
```

## Programming: Multiple Axis Machining

### 12.2 The PLANE Function: Tilting the Working Plane (Software Option 1)

Abbreviations used:


<b>PROJECTED</b>	Projected
<b>PROPR</b>	Principle plane
<b>PROMIN</b>	Minor plane
<b>PROMIN</b>	Rotation

#### Defining the working plane with the Euler angle: PLANE EULER

##### Application

Euler angles define a machining plane through up to three **rotations about the respectively tilted coordinate system**. The Swiss mathematician Leonhard Euler defined these angles. When applied to the machine coordinate system, they have the following meanings:

Precession angle: <b>EULPR</b>	Rotation of the coordinate system around the Z axis
Nutation angle: <b>EULNU</b>	Rotation of the coordinate system around the X axis already shifted by the precession angle
Rotation angle: <b>EULROT</b>	Rotation of the tilted machining plane around the tilted Z axis



#### Before programming, note the following

Parameter description for the positioning behavior:  
See "Specifying the positioning behavior of the PLANE function", page 401.






## The PLANE Function: Tilting the Working Plane (Software Option 1) 12.2

### Input parameters



- ▶ **Rot. angle of main coord. plane?:** Rotary angle **EULPR** around the Z axis (see figure at top right). Please note:
  - Input range:  $-180.0000^\circ$  to  $180.0000^\circ$
  - The  $0^\circ$  axis is the X axis
- ▶ **Swivel angle of tool axis?:** Tilting angle **EULNU** of the coordinate system around the X axis shifted by the precession angle (see figure at center right). Please note:
  - Input range:  $0^\circ$  to  $180.0000^\circ$
  - The  $0^\circ$  axis is the Z axis
- ▶ **ROT angle of the tilted plane?:** Rotation **EULROT** of the tilted coordinate system around the tilted Z axis (corresponds to a rotation with Cycle 10 ROTATION). Use the rotation angle to simply define the direction of the X axis in the tilted machining plane (see figure at bottom right). Please note:
  - Input range:  $0^\circ$  to  $360.0000^\circ$
  - The  $0^\circ$  axis is the X axis
- ▶ Continue with the positioning properties, See "Specifying the positioning behavior of the PLANE function", page 401



### NC block

```
5 PLANE EULER EULPR45 EULNU20 EULROT22 .....
```

## Programming: Multiple Axis Machining

### 12.2 The PLANE Function: Tilting the Working Plane (Software Option 1)

#### Abbreviations used

Abbreviation	Meaning
EULER	Swiss mathematician who defined these angles
EULPR	<b>P</b> recession angle: angle describing the rotation of the coordinate system around the Z axis
EULNU	<b>N</b> utation angle: angle describing the rotation of the coordinate system around the X axis shifted by the precession angle
EULROT	<b>R</b> otation angle: angle describing the rotation of the tilted machining plane around the tilted Z axis

#### Defining the working plane with two vectors: PLANE VECTOR

##### Application

You can use the definition of a working plane via **two vectors** if your CAD system can calculate the base vector and normal vector of the tilted machining plane. A normalized input is not necessary. The TNC calculates the normal, so you can enter values between  $-9.999999$  and  $+9.999999$ .

The base vector required for the definition of the machining plane is defined by the components **BX**, **BY** and **BZ** (see figure at right). The normal vector is defined by the components **NX**, **NY** and **NZ**.




##### Before programming, note the following

The base vector defines the direction of the principal axis in the tilted machining plane, and the normal vector determines the orientation of the tilted machining plane, and at the same time is perpendicular to it.

The TNC calculates standardized vectors from the values you enter.

Parameter description for the positioning behavior: See "Specifying the positioning behavior of the PLANE function", page 401.






## The PLANE Function: Tilting the Working Plane (Software Option 1) 12.2

### Input parameters



- ▶ **X component of base vector?:** X component **BX** of the base vector B (see figure at top right). Input range: -9.9999999 to +9.9999999
- ▶ **Y component of base vector?:** Y component **BY** of the base vector B (see figure at top right). Input range: -9.9999999 to +9.9999999
- ▶ **Z component of base vector?:** Z component **BZ** of the base vector B (see figure at top right). Input range: -9.9999999 to +9.9999999
- ▶ **X component of normal vector?:** X component **NX** of the normal vector N (see figure at center right). Input range: -9.9999999 to +9.9999999
- ▶ **Y component of normal vector?:** Y component **NY** of the normal vector N (see figure at center right). Input range: -9.9999999 to +9.9999999
- ▶ **Z component of normal vector?:** Z component **NZ** of the normal vector N (see figure at lower right). Input range: -9.9999999 to +9.9999999
- ▶ Continue with the positioning properties, See "Specifying the positioning behavior of the PLANE function", page 401



### NC block

```
5 PLANE VECTOR BX0.8 BY-0.4 BZ-0.42 NX0.2 NY0.2 NZ0.92 ..
```

### Abbreviations used

Abbreviation	Meaning
VECTOR	Vector
BX, BY, BZ	Base vector: X, Y and Z components
NX, NY, NZ	Normal vector: X, Y and Z components

## Programming: Multiple Axis Machining

### 12.2 The PLANE Function: Tilting the Working Plane (Software Option 1)

#### Defining the working plane via three points: PLANE POINTS

##### Application

A working plane can be uniquely defined by entering **any three points P1 to P3 in this plane**. This possibility is realized in the **PLANE POINTS** function.




##### Before programming, note the following

The connection from Point 1 to Point 2 determines the direction of the tilted main axis (X for tool axis Z).

The direction of the tilted tool axis is determined by the position of Point 3 relative to the connecting line between Point 1 and Point 2. Use the right-hand rule (thumb = X axis, index finger = Y axis, middle finger = Z axis (see figure at right)) to remember: thumb (X axis) points from Point 1 to Point 2, index finger (Y axis) points parallel to the tilted Y axis in the direction of Point 3. Then the middle finger points in the direction of the tilted tool axis.

The three points define the slope of the plane. The position of the active datum is not changed by the TNC.

Parameter description for the positioning behavior:  
See "Specifying the positioning behavior of the PLANE function", page 401.






## The PLANE Function: Tilting the Working Plane (Software Option 1) 12.2

### Input parameters



- ▶ **X coordinate of 1st plane point?:** X coordinate **P1X** of the 1st plane point (see figure at top right)
- ▶ **Y coordinate of 1st plane point?:** Y coordinate **P1Y** of the 1st plane point (see figure at top right)
- ▶ **Z coordinate of 1st plane point?:** Z coordinate **P1Z** of the 1st plane point (see figure at top right)
- ▶ **X coordinate of 2nd plane point?:** X coordinate **P2X** of the 2nd plane point (see figure at center right)
- ▶ **Y coordinate of 2nd plane point?:** Y coordinate **P2Y** of the 2nd plane point (see figure at center right)
- ▶ **Z coordinate of 2nd plane point?:** Z coordinate **P2Z** of the 2nd plane point (see figure at center right)
- ▶ **X coordinate of 3rd plane point?:** X coordinate **P3X** of the 3rd plane point (see figure at bottom right)
- ▶ **Y coordinate of 3rd plane point?:** Y coordinate **P3Y** of the 3rd plane point (see figure at bottom right)
- ▶ **Z coordinate of 3rd plane point?:** Z coordinate **P3Z** of the 3rd plane point (see figure at bottom right)
- ▶ Continue with the positioning properties. See "Specifying the positioning behavior of the PLANE function", page 401



### NC block

```
5 PLANE POINTS P1X+0 P1Y+0 P1Z+20 P2X+30 P2Y+31 P2Z+20 P3X
+0 P3Y+41 P3Z+32.5 .....
```

### Abbreviations used

Abbreviation	Meaning
--------------	---------

POINTS	Points
--------	--------

## Programming: Multiple Axis Machining

### 12.2 The PLANE Function: Tilting the Working Plane (Software Option 1)

#### Defining the working plane via a single incremental spatial angle: PLANE SPATIAL

##### Application

Use an incremental spatial angle when an already active tilted working plane is to be tilted by **another rotation**. Example: machining a 45° chamfer on a tilted plane.



##### Before programming, note the following


The defined angle is always in effect in respect to the active working plane, regardless of the function you have used to activate it.

You can program any number of **PLANE RELATIVE** functions in a row.


If you want to return to the working plane that was active before the **PLANE RELATIVE** function, define the **PLANE RELATIVE** function again with the same angle but with the opposite algebraic sign.

If you use the **PLANE RELATIVE** function in a non-tilted working plane, then you simply rotate the non-tilted plane about the spatial angle defined in the **PLANE** function.

Parameter description for the positioning behavior: See "Specifying the positioning behavior of the PLANE function", page 401.




##### Input parameters



- ▶ **Incremental angle?:** Spatial angle about which the active machining plane is to be rotated additionally (see figure at right). Use a soft key to select the axis to be rotated about. Input range:  $-359.9999^\circ$  to  $+359.9999^\circ$
- ▶ Continue with the positioning properties, See "Specifying the positioning behavior of the PLANE function", page 401

##### Abbreviations used

Abbreviation	Meaning
RELATIVE	Relative to



##### NC block

```
5 PLANE RELATIV SPB-45 .....
```

## The PLANE Function: Tilting the Working Plane (Software Option 1) 12.2

### Tilting the working plane through axis angle: PLANE AXIAL (FCL 3 function)

#### Application

The **PLANE AXIAL** function defines both the position of the working plane and the nominal coordinates of the rotary axes. This function is particularly easy to use on machines with Cartesian coordinates and with kinematics structures in which only one rotary axis is active.



**PLANE AXIAL** can also be used if you have only one rotary axis active on your machine.

You can use the **PLANE RELATIVE** function after **PLANE AXIAL** if your machine allows spatial angle definitions. Refer to your machine manual.



#### Before programming, note the following


Enter only axis angles that actually exist on your machine. Otherwise the TNC generates an error message.

Rotary axis coordinates defined with **PLANE AXIAL** are modally effective. Successive definitions therefore build on each other. Incremental input is allowed.

Use **PLANE RESET** to reset the **PLANE AXIAL** function. Resetting by entering 0 does not deactivate **PLANE AXIAL**.

**SEQ**, **TABLE ROT** and **COORD ROT** have no function in conjunction with **PLANE AXIAL**.


Parameter description for the positioning behavior:  
See "Specifying the positioning behavior of the PLANE function", page 401.




## Programming: Multiple Axis Machining

### 12.2 The PLANE Function: Tilting the Working Plane (Software Option 1)

#### Input parameters



- ▶ **Axis angle A?**: Axis angle **to which** the A axis is to be tilted. If entered incrementally, it is the angle **by which** the A axis is to be tilted from its current position. Input range:  $-99999.9999^\circ$  to  $+99999.9999^\circ$
- ▶ **Axis angle B?**: Axis angle **to which** the B axis is to be tilted. If entered incrementally, it is the angle **by which** the B axis is to be tilted from its current position. Input range:  $-99999.9999^\circ$  to  $+99999.9999^\circ$
- ▶ **Axis angle C?**: Axis angle **to which** the C axis is to be tilted. If entered incrementally, it is the angle **by which** the C axis is to be tilted from its current position. Input range:  $-99999.9999^\circ$  to  $+99999.9999^\circ$
- ▶ Continue with the positioning properties, See "Specifying the positioning behavior of the PLANE function", page 401



#### NC block

```
5 PLANE AXIAL B-45 .....
```

#### Abbreviations used

Abbreviation	Meaning
--------------	---------

AXIAL	In the axial direction
-------	------------------------



## Specifying the positioning behavior of the PLANE function

### Overview

Independently of which PLANE function you use to define the tilted machining plane, the following functions are always available for the positioning behavior:

- Automatic positioning
- Selection of alternate tilting possibilities (not with **PLANE AXIAL**)
- Selection of the type of transformation (not with **PLANE AXIAL**)

### Automatic positioning: MOVE/TURN/STAY (entry is mandatory)

After you have entered all parameters for the plane definition, you must specify how the rotary axes will be positioned to the calculated axis values:

MOVE	▶ The PLANE function is to automatically position the rotary axes to the calculated position values. The position of the tool relative to the workpiece is to remain the same. The TNC carries out a compensation movement in the linear axes
TURN	▶ The PLANE function is to automatically position the rotary axes to the calculated position values, but only the rotary axes are positioned. The TNC does <b>not</b> carry out a compensation movement in the linear axes
STAY	▶ You will position the rotary axes later in a separate positioning block


If you have selected the **MOVE** option (**PLANE** function is to position the axes automatically), the following two parameters must still be defined: **Dist. tool tip - center of rot.** and **Feed rate? F=**.

If you have selected the **TURN** option (**PLANE** function is to position the axes automatically without any compensating movement), the following parameter must still be defined: **Feed rate? F=**.

As an alternative to defining a feed rate **F** directly by numerical value, you can also position with **FMAX** (rapid traverse) or **FAUTO** (feed rate from the **TOOL CALLT** block).



If you use **PLANE AXIAL** together with **STAY**, you have to position the rotary axes in a separated block after the **PLANE** function.



## Programming: Multiple Axis Machining

### 12.2 The PLANE Function: Tilting the Working Plane (Software Option 1)




- ▶ **Dist. tool tip - center of rot.** (incremental): The TNC tilts the tool (or table) relative to the tool tip. The **DIST** parameter shifts the center of rotation of the positioning movement relative to the current position of the tool tip.



#### Note:

- If the tool is already at the given distance to the workpiece before positioning, then relatively speaking the tool is at the same position after positioning (see figure at center right, **1** = DIST).
- If the tool is not at the given distance to the workpiece before positioning, then relatively speaking the tool is offset from the original position after positioning (see figure at bottom right, **1**=DIST).

- ▶ **Feed rate? F=:** Contour speed at which the tool should be positioned
- ▶ **Retraction length in the tool axis?:** Retraction path **MB** is effective incrementally from the current tool position in the active tool axis direction that the TNC approaches **before tilting**. **MB MAX** positions the tool just before the software limit switch.



## The PLANE Function: Tilting the Working Plane (Software Option 1) 12.2

### Positioning the rotary axes in a separate block

Proceed as follows if you want to position the rotary axes in a separate positioning block (option **STAY** selected):



#### **Danger of collision!**

Pre-position the tool to a position where there is no danger of collision with the workpiece (clamping devices) during positioning.

- ▶ Select any **PLANE** function, and define automatic positioning with the **STAY** option. During program execution the TNC calculates the position values of the rotary axes present on the machine, and stores them in the system parameters Q120 (A axis), Q121 (B axis) and Q122 (C axis)
- ▶ Define the positioning block with the angular values calculated by the TNC

### NC example blocks: Position a machine with a rotary table C and a tilting table A to a space angle of B+45°

...	
12 L Z+250 R0 FMAX	Position at clearance height
13 PLANE SPATIAL SPA+0 SPB+45 SPC+0 STAY	Define and activate the PLANE function
14 L A+Q120 C+Q122 F2000	Position the rotary axis with the values calculated by the TNC
...	Define machining in the tilted working plane

## Programming: Multiple Axis Machining

### 12.2 The PLANE Function: Tilting the Working Plane (Software Option 1)

#### Selection of alternate tilting possibilities: SEQ +/- (entry optional)

The position you define for the working plane is used by the TNC to calculate the appropriate positioning of the rotary axes present on the machine. In general there are always two solution possibilities.

Use the **SEQ** switch to specify which possibility the TNC should use:

- **SEQ+** positions the master axis so that it assumes a positive angle. The master axis is the 1st rotary axis from the tool, or the last rotary axis from the table (depending on the machine configuration (see figure at top right)).
- **SEQ-** positions the master axis so that it assumes a negative angle.


If the solution you chose with **SEQ** is not within the machine's range of traverse, the TNC displays the **Entered angle not permitted** error message.



When the **PLANE AXIS** function is used, the **SEQ** switch is nonfunctional.

- 1 The TNC first checks whether both solution possibilities are within the traverse range of the rotary axes.
- 2 If they are, then the TNC selects the shortest possible solution.
- 3 If only one solution is within the traverse range, the TNC selects this solution
- 4 If neither solution is within the traverse range, the TNC displays the **Entered angle not permitted** error message.

If you do not define **SEQ**, the TNC determines the solution as follows:



## The PLANE Function: Tilting the Working Plane (Software Option 1) 12.2

### Example for a machine with a rotary table C and a tilting table

#### A. Programmed function: PLANE SPATIAL SPA+0 SPB+45 SPC+0

Limit switch	Starting position	SEQ	Resulting axis position
None	A+0, C+0	not prog.	A+45, C+90
None	A+0, C+0	+	A+45, C+90
None	A+0, C+0	-	A-45, C-90
None	A+0, C-105	not prog.	A-45, C-90
None	A+0, C-105	+	A+45, C+90
None	A+0, C-105	-	A-45, C-90
$-90 < A < +10$	A+0, C+0	not prog.	A-45, C-90
$-90 < A < +10$	A+0, C+0	+	Error message
None	A+0, C-135	+	A+45, C+90

#### Selecting the type of transformation (entry optional)

On machines with C-rotary tables, a function is available for specifying the type of transformation:



- ▶ **COORD ROT** specifies that the PLANE function should only rotate the coordinate system to the defined tilting angle. The rotary table is not moved; the compensation is purely mathematical.




- ▶ **TABLE ROT** specifies that the PLANE function should position the rotary table to the defined tilting angle. Compensation results from rotating the workpiece.



When the **PLANE AXIAL** function is used, **COORD ROT** and **TABLE ROT** are nonfunctional.

If you use the **TABLE ROT** function in conjunction with a basic rotation and a tilting angle of 0, then the TNC tilts the table to the angle defined in the basic rotation.



## Programming: Multiple Axis Machining

### 12.3 Inclined-tool machining in a tilted machining plane (software option 2)

### 12.3 Inclined-tool machining in a tilted machining plane (software option 2)


#### Function

In combination with **M128** and the new **PLANE** functions, **inclined-tool machining** in a tilted machining plane is now possible. Two possibilities are available for definition:

- Inclined-tool machining via incremental traverse of a rotary axis
- Inclined-tool machining via normal vectors



Inclined-tool machining in a tilted machining plane only functions with spherical cutters. With 45° swivel heads and tilting tables you can also define the incline angle as a space angle. Use the , See "FUNCTION TCPM (software option 2)", page 415.



#### Inclined-tool machining via incremental traverse of a rotary axis

- ▶ Retract the tool
- ▶ Activate M128
- ▶ Define any PLANE function; consider the positioning behavior
- ▶ Via a straight-line block, traverse to the desired incline angle in the appropriate axis incrementally

#### Example NC blocks

...	
N12 G00 G40 Z+50 M128 *	Position at clearance height, activate M128
N13 PLANE SPATIAL SPA+0 SPB-45 SPC+0 MOVE ABST50 F900 *	Define and activate the PLANE function
N14 G01 G91 F1000 B-17 *	Set the incline angle
...	Define machining in the tilted working plane

## 12.4 Miscellaneous functions for rotary axes

### Feed rate in mm/min on rotary axes A, B, C: M116 (software option 1)

#### Standard behavior

The TNC interprets the programmed feed rate of a rotary axis in degrees/min (in mm programs and also in inch programs). The feed rate therefore depends on the distance from the tool center to the center of axis rotation.

The larger this distance becomes, the greater the contouring feed rate.

#### Feed rate in mm/min on rotary axes with M116



The machine geometry must be specified by the machine tool builder in the description of kinematics. M116 works only on rotary tables. M116 cannot be used with swivel heads. If your machine is equipped with a table/head combination, the TNC ignores the swivel-head rotary axes.

**M116** is also effective in an active tilted working plane and in combination with M128 if you used the **M138** function to select rotary axes, See "Selecting tilting axes: M138", page 413. Then **M116** affects only those rotary axes that were not selected with **M138**.

The TNC interprets the programmed feed rate of a rotary axis in degrees/min (or 1/10 inch/min). In this case, the TNC calculates the feed for the block at the start of each block. With a rotary axis, the feed rate is not changed during execution of the block even if the tool moves toward the center of the rotary axis.

#### Effect

M116 is effective in the working plane. To reset M116, enter M117. M116 is also canceled at the end of the program.

M116 becomes effective at the start of block.

## Programming: Multiple Axis Machining

### 12.4 Miscellaneous functions for rotary axes

#### Shortest-path traverse of rotary axes: M126

##### Standard behavior



The behavior of the TNC when positioning the rotary axes depends on the machine tool. Refer to your machine manual.

The standard behavior of the TNC while positioning rotary axes whose display has been reduced to values less than  $360^\circ$  is dependent on machine parameter **shortestDistance** (300401). This machine parameter defines whether the TNC should consider the difference between nominal and actual position, or whether it should always (even without M126) choose the shortest path to the programmed position. Examples:

Actual position	Nominal position	Traverse
$350^\circ$	$10^\circ$	$-340^\circ$
$10^\circ$	$340^\circ$	$+330^\circ$

##### Behavior with M126

With M126, the TNC will move the axis on the shorter path of traverse for rotary axes whose display is reduced to values less than  $360^\circ$ . Examples:

Actual position	Nominal position	Traverse
$350^\circ$	$10^\circ$	$+20^\circ$
$10^\circ$	$340^\circ$	$-30^\circ$

##### Effect

M126 becomes effective at the start of block.

To cancel M126, enter M127. At the end of program, M126 is automatically canceled.



## Reducing display of a rotary axis to a value less than 360°: M94

### Standard behavior

The TNC moves the tool from the current angular value to the programmed angular value.

### Example:

Current angular value:	538°
Programmed angular value:	180°
Actual distance of traverse:	-358°

### Behavior with M94

At the start of block, the TNC first reduces the current angular value to a value less than 360° and then moves the tool to the programmed value. If several rotary axes are active, M94 will reduce the display of all rotary axes. As an alternative you can enter a rotary axis after M94. The TNC then reduces the display only of this axis.

### Example NC blocks

To reduce display of all active rotary axes:

```
N50 M94 *
```

To reduce display of the C axis only:

```
N50 M94 C *
```

To reduce display of all active rotary axes and then move the tool in the C axis to the programmed value:

```
N50 G00 C+180 M94 *
```

### Effect

M94 is effective only in the block in which it is programmed.

M94 becomes effective at the start of block.

## Programming: Multiple Axis Machining

### 12.4 Miscellaneous functions for rotary axes

#### Maintaining the position of the tool tip when positioning with tilted axes (TCPM): M128 (software option 2)

##### Standard behavior

The TNC moves the tool to the positions given in the part program. If the position of a tilted axis changes in the program, the resulting offset in the linear axes must be calculated, and traversed in a positioning block.

##### Behavior with M128 (TCPM: Tool Center Point Management)



The machine geometry must be specified by the machine tool builder in the description of kinematics.

If the position of a controlled tilted axis changes in the program, the position of the tool tip to the workpiece remains the same.



##### Caution: Danger to the workpiece!

For tilted axes with Hirth coupling: Do not change the position of the tilted axis until after retracting the tool. Otherwise you might damage the contour when disengaging from the coupling.

After **M128** you can program another feed rate, at which the TNC will carry out the compensation movements in the linear axes.

If you wish to use the handwheel to change the position of the tilted axis during program run, use **M128** in conjunction with **M118**. Handwheel positioning in a machine-based coordinate system is possible when **M128** is active.




Before positioning with **M91** or **M92** and before a **T BLOCK**, **RESET M128**.

To avoid contour gouging you must use only spherical cutters with **M128**.

The tool length must refer to the spherical center of the tool tip.

If **M128** is active, the TNC shows the TCPM symbol in the status display.



**M128 on tilting tables**

If you program a tilting table movement while **M128** is active, the TNC rotates the coordinate system accordingly. If, for example, you rotate the C axis by 90° (through a positioning command or datum shift) and then program a movement in the X axis, the TNC executes the movement in the machine axis Y.

The TNC also transforms the defined datum, which has been shifted by the movement of the rotary table.

**M128 with 3-D tool compensation**

If you carry out a 3-D tool compensation with active **M128** and active radius compensation **/G41/G42**, the TNC will automatically position the rotary axes for certain machine geometrical configurations (Peripheral millingSee "Three-dimensional tool compensation (software option 2)").

**Effect**

**M128** becomes effective at the start of block, **M129** at the end of block. **M128** is also effective in the manual operating modes and remains active even after a change of mode. The feed rate for the compensation movement will be effective until you program a new feed rate or until you cancel **M128** with **M129**.

Enter **M129** to cancel **M128**. The TNC also cancels **M128** if you select a new program in a program run operating mode.

**Example NC blocks**

Feed rate of 1000 mm/min for compensation movements:

```
N50 G01 G41 X+0 Y+38.5 IB-15 F125 M128 F1000 *
```

## Programming: Multiple Axis Machining

### 12.4 Miscellaneous functions for rotary axes

#### Inclined machining with noncontrolled rotary axes

If you have noncontrolled rotary axes (counting axes) on your machine, then in combination with M128 you can also perform inclined machining operations with these axes.

- 1 Manually traverse the rotary axes to the desired positions.  
M128 must not be active!
- 2 Activate M128: The TNC reads the actual values of all rotary axes present, calculates from this the new position of the tool center point, and updates the position display
- 3 The TNC performs the necessary compensating movement in the next positioning block
- 4 Carry out the machining operation
- 5 At the end of program, reset M128 with M129, and return the rotary axes to the initial positions

Proceed as follows:



As long as M128 is active, the TNC monitors the actual positions of the noncontrolled rotary axes. If the actual position deviates from the nominal position by a value greater than that defined by the machine manufacturer, the TNC outputs an error message and interrupts program run.

## Selecting tilting axes: M138

### Standard behavior

The TNC performs M128 and TCPM, and tilts the working plane, only in those axes for which the machine tool builder has set the appropriate machine parameters.

### Behavior with M138

The TNC performs the above functions only in those tilting axes that you have defined using M138.



If you restrict the number of tilting axes with the **M138** function, your machine may provide only limited tilting possibilities.

### Effect

M138 becomes effective at the start of block.

You can reset M138 by reprogramming it without entering any axes.

### Example NC blocks

Perform the above-mentioned functions only in the tilting axis C:

```
N50 G00 Z+100 R0 M138 C *
```

## Programming: Multiple Axis Machining

### 12.4 Miscellaneous functions for rotary axes

#### Compensating the machine's kinematics configuration for ACTUAL/NOMINAL positions at end of block: M144 (software option 2)

##### Standard behavior

The TNC moves the tool to the positions given in the machining program. If the position of a tilted axis changes in the program, the resulting offset in the linear axes must be calculated, and traversed in a positioning block.

##### Behavior with M144

The TNC calculates into the position value any changes in the machine's kinematics configuration which result, for example, from adding a spindle attachment. If the position of a controlled tilted axis changes, the position of the tool tip to the workpiece is also changed. The resulting offset is calculated in the position display.



Positioning blocks with M91/M92 are permitted if M144 is active.

The position display in the operating modes FULL SEQUENCE and SINGLE BLOCK does not change until the tilting axes have reached their final position.

##### Effect

M144 becomes effective at the start of the block. M144 does not function in connection with M128 or a tilted working plane.

You can cancel M144 by programming M145.



The machine geometry must be specified by the machine tool builder in the description of kinematics.

The machine tool builder determines the behavior in the automatic and manual operating modes. Refer to your machine manual.

## 12.5 FUNCTION TCPM (software option 2)

### Function



The machine geometry must be specified by the machine tool builder in the description of kinematics.



#### For tilted axes with Hirth coupling:

Only change the position of the tilted axis after retracting the tool. Otherwise you might damage the contour when disengaging from the coupling.




Before positioning with **M91** or **M92** and before a **TOOL CALL**: Reset **TCPM FUNCTION**.

To avoid contour gouging you must use only spherical cutters with **TCPM FUNCTION**.

The tool length must refer to the spherical center of the tool tip.

If **TCPM FUNCTION** is active, the TNC shows the symbol **TCPM** in the position display.



**TCPM FUNCTION** is an improvement on the **M128** function, with which you can define the behavior of the TNC when positioning the rotary axes. In contrast to **M128**, with **TCPM FUNCTION** you can define the mode of action of various functions:

- Mode of action of the programmed feed rate: **F TCP / F CONT**
- Interpretation of the rotary axis coordinates programmed in the NC program: **AXIS POS / AXIS SPAT**
- Type of interpolation between start and target position: **PATHCTRL AXIS / PATHCTRL VECTOR**

### Defining the TCPM FUNCTION

SPEC  
FCT

- ▶ Select the special functions

PROGRAM  
FUNCTIONS

- ▶ Select the programming aids

FUNCTION  
TCPM

- ▶ Select the TCPM FUNCTION

## Programming: Multiple Axis Machining

### 12.5 FUNCTION TCPM (software option 2)

#### Mode of action of the programmed feed rate

The TNC provides two functions for defining the mode of action of the programmed feed rate:

- |              |  |
|--------------|--|
| F<br>TCP     | ▶ <b>F TCP</b> determines that the programmed feed rate is interpreted as the actual relative velocity between the tool point (TCP = Tool Center Point) and the workpiece. |
| F<br>CONTOUR | ▶ <b>F CONT</b> determines that the programmed feed rate is interpreted as the contouring feed rate of the axis programmed in the respective NC block.                     |

#### Example NC blocks

...	
13 FUNCTION TCPM F TCP ...	Feed rate refers to the tool tip
14 FUNCTION TCPM F CONT ...	Feed rate is interpreted as the speed of the tool along the contour
...	

#### Interpretation of the programmed rotary axis coordinates

Up to now, machines with 45° swivel heads or 45° tilting tables could not easily set the angle of inclination or a tool orientation with respect to the currently active coordinate system (spatial angle). This function could only be realized through specially written programs with normal vectors (LN blocks).

The TNC now provides the following function:

- |                  |   |
|------------------|---|
| AXIS<br>POSITION | ▶ <b>AXIS POS</b> determines that the TNC interprets the programmed coordinates of rotary axes as the nominal position of the respective axis |
| AXIS<br>SPATIAL  | ▶ <b>AXIS SPAT</b> determines that the TNC interprets the programmed coordinates of rotary axes as the spatial angle                          |





**AXIS POS** should be used primarily if your machine is equipped with Cartesian rotary axes. You can also use **AXIS POS** with 45°-swivel heads/tilting tables if it is ensured that the programmed rotary axis coordinates define the desired orientation of the working plane correctly (this can be accomplished with a CAM system, for example).

**AXIS SPAT:** The rotary axis coordinates entered in the positioning block are space angles that are given with respect to the currently active (perhaps tilted) coordinate system (incremental space angle).

After you switch on **FUNCTION TCPM** with **AXIS SPAT**, in the first positioning block you should always program all three spatial angles in the inclination angle definition. This also applies if one or more spatial angles are 0°. **AXIS SPAT:** The rotary axis coordinates entered in the positioning block are space angles that are given with respect to the currently active (perhaps tilted) coordinate system (incremental space angle).

#### Example NC blocks

...	
<b>13 FUNCTION TCPM F TCP AXIS POS ...</b>	Rotary axis coordinates are axis angles
...	
<b>18 FUNCTION TCPM F TCP AXIS SPAT ...</b>	Rotary axis coordinates are spatial angles
<b>20 L A+0 B+45 C+0 F MAX</b>	Set tool orientation to B+45 degrees (spatial angle). Define spatial angles A and C with 0
...	

## Programming: Multiple Axis Machining

### 12.5 FUNCTION TCPM (software option 2)

#### Type of interpolation between the starting and end position

The TNC provides two functions for defining the type of interpolation between the starting and end position:

PATH  
CONTROL  
AXIS

- ▶ **PATHCTRL AXIS** determines that the tool point between the starting and end position of the respective NC block moves on a straight line (**Face Milling**). The direction of the tool axis at the starting and end positions corresponds to the respective programmed values, but the tool circumference does not describe a defined path between the starting and end positions. The surface produced by milling with the tool circumference (**Peripheral Milling**) depends on the machine geometry

PATH  
CONTROL  
VECTOR

- ▶ **PATHCTRL VECTOR** determines that the tool tip between the starting and end position of the respective NC block moves on a straight line and also that the direction of the tool axis between starting and end position is interpolated so that a plane results from machining at the tool circumference (**Peripheral Milling**)



#### With PATHCTRL VECTOR, remember:

Any defined tool orientation is generally accessible through two different tilting angle positions. The TNC uses the solution over the shortest available path—starting from the current position.

To attain the most continuous multiaxis movement possible, define Cycle 32 with a **tolerance for rotary axes** (see Touch Probe Cycles User's Manual, Cycle 32 TOLERANCE). The tolerance of the rotary axes should be about the same as the tolerance of the contouring deviation that is also defined in Cycle 32. The greater the tolerance for the rotary axes is defined, the greater are the contour deviations during peripheral milling.

## Resetting the TCPM FUNCTION

RESET  
TCPM

- ▶ **FUNCTION RESET TCPM** is to be used if you want to purposely reset the function within a program.



The TNC automatically resets **TCPM FUNCTION** if you select a new program in a program run mode.  
You can reset the **TCPM FUNCTION** only if the **PLANE** function is inactive. If required, run **PLANE RESET** before **FUNCTION RESET TCPM**.

### Example NC blocks

...

**25 FUNCTION RESETTCPM**

Reset TCPM FUNCTION

...

## Programming: Multiple Axis Machining


### 12.6 Peripheral Milling: 3-D radius compensation with TCPM and radius compensation (G41/G42)

### 12.6 Peripheral Milling: 3-D radius compensation with TCPM and radius compensation (G41/G42)

#### Application

With peripheral milling, the TNC displaces the tool perpendicular to the direction of movement and perpendicular to the tool direction by the sum of the delta values **DR** (tool table and **T** block). Determine the compensation direction with radius compensation **G41/G42** (see figure at upper right, traverse direction Y+).

For the TNC to be able to reach the set tool orientation, you need to activate the function **M128** See "Maintaining the position of the tool tip when positioning with tilted axes (TCPM): M128 (software option 2)", page 410 and subsequently the tool radius compensation. The TNC then positions the rotary axes automatically so that the tool can reach the orientation defined by the coordinates of the rotary axes with the active compensation.



This function is possible only on machines for which you can define spatial angles for the tilting axis configuration. Refer to your machine manual.

The TNC is not able to automatically position the rotary axes on all machines.

Refer to your machine manual.

Note that the TNC makes a compensating movement by the defined **delta values**. The tool radius R defined in the tool table has no effect on the compensation.



#### Danger of collision!

On machines whose rotary axes only allow limited traverse, sometimes automatic positioning can require the table to be rotated by 180°. In this case, make sure that the tool head does not collide with the workpiece or the clamps.

You can define the tool orientation in a G01 block as described below.

#### Example: Definition of the tool orientation with M128 and the coordinates of the rotary axes

N10 G00 G90 X-20 Y+0 Z+0 B+0 C+0 *	Pre-position
N20 M128 *	Activate M128
N30 G01 G42 X+0 Y+0 Z+0 B+0 C+0 F1000 *	Activate radius compensation
N40 X+50 Y+0 Z+0 B-30 C+0 *	Position the rotary axis (tool orientation)

# 13

**Programming:  
Pallet editor**

## Programming: Pallet editor

### 13.1 Pallet Management

#### 13.1 Pallet Management

##### Application



Pallet table management is a machine-dependent function. The standard functional range is described below. Refer to your machine manual.

Pallet tables are used for machining centers with pallet changers: The pallet table calls the part programs that are required for the different pallets, and activates presets, datum shifts and datum tables.


You can also use pallet tables to run in succession several programs that have different reference points.



















If you want to create or manage pallet tables, the name of the file must begin with a letter.

Pallet tables contain the following information:

- **TYPE** (entry obligatory): Identification for pallet or NC program (select with **ENT**)
- **NAME** (entry obligatory): Pallet or program name. The machine tool builder determines the pallet name (see your machine tool manual). The program name must be stored in the same directory as the pallet table. Otherwise you must enter the full path name for the program
- **PRESET** (entry optional): Preset number from the preset table. The preset number defined here is interpreted by the TNC as a workpiece datum.
- **DATUM** (entry optional): Name of the datum table. The datum table must be stored in the same directory as the pallet table. Otherwise you must enter the full path name for the datum table. Datums from the datum table can be activated in the NC program with Cycle 7 **DATUM SHIFT**
- **LOCATION** (entry obligatory): The entry "**MA**" indicates that the machine is loaded with a pallet or fixture that can be machined. The TNC only machines pallets or fixtures identified by "**MA**". To enter "**MA**", press the ENT key. Press the NO ENT key to remove the entry.
- **LOCK** (entry optional): Lock execution of a pallet line. Press the ENT key to mark the execution of a pallet line as locked (the affected line will be identified by "**\***"). Press the NO ENT key to cancel the lock. You can lock the execution for individual programs, fixtures or entire pallets. Non-locked lines (e.g. PGM) of a locked pallet will also not be executed.



Editing function	Soft key
Select beginning of table	
Select end of table	
Select previous page in table	
Select next page in table	
Insert as last line in the table	
Delete the last line in the table	
Add the number of lines that can be entered at the end of the table	
Copy highlighted field	
Insert copied field	
Select beginning of line	
Select end of line	
Copy the current value	
Insert the current value	
Edit the current field	
Sort by content of column	
Additional functions, e.g. saving	

## Programming: Pallet editor

### 13.1 Pallet Management

#### Select pallet table

- ▶ Call the file manager in the Programming and Editing or Program Run mode: Press the **PGM MGT** key
- ▶ Display all type .P files: Press the **SELECT TYPE** and **SHOW ALL** soft keys
- ▶ Select a pallet table with the arrow keys, or enter a new file name to create a new table
- ▶ Confirm your entry with the **ENT** key

#### Exiting the pallet file

- ▶ Call the file manager: Press the **PGM MGT** key
- ▶ Select a different type of file: Press the **SELECT TYPE** soft key and the soft key for the desired file type, for example **SHOW.H**
- ▶ Select the desired file

#### Run pallet file



MP7683 defines whether the pallet table is to be executed blockwise or continuously.

Use the screen layout button to switch between table view and form view.



- ▶ Select the file manager in the Program Run, Full Sequence or Program Run, Single Block operating modes: Press the **PGM MGT** key
- ▶ Display all type .P files: Press the **SELECT TYPE** and **SHOW P.** soft keys
- ▶ Select the pallet table with the arrow keys and confirm with **ENT**
- ▶ Execute the pallet table: Press the NC start key



### Screen layout for executing pallet tables

You can have the TNC display the program contents and pallet file contents on the screen together by selecting the screen layout **PROGRAM + PALLET**. During execution, the TNC then shows program blocks to the left and the pallet to the right. To check the program contents before execution, proceed as follows:

- ▶ Select a pallet table
- ▶ With the arrow keys, choose the program you would like to check
- ▶ Press the **OPEN PGM** soft key: the TNC displays the selected program on the screen. You can now page through the program with the arrow keys
- ▶ To return to the pallet table, press the **END PGM** soft key





# 14

**Programming:  
Turning  
Operations**

## Programming: Turning Operations

### 14.1 Turning Operations on Milling Machines (Software Option 50)

#### 14.1 Turning Operations on Milling Machines (Software Option 50)

##### Introduction

Special types of milling machines allow performing both milling and drilling operations. A workpiece can thus be machined completely on one machine without rechucking, even if complex milling and turning applications are required.

Turning operations are machining processes by which workpieces are rotated, thus implementing the cutting movements. A fixed tool carries out infeed and feed movements. Turning applications, depending on machining direction and task, are subdivided into various production processes, e.g. longitudinal turning, face turning, groove turning or thread turning. The TNC offers you several cycles for each of the various production processes (see User's Manual, Cycles, "Turning" chapter).


On the TNC you can simply switch between Milling and Turning mode within the NC program. In Turning mode, the rotary table serves as turning spindle, whereas the milling spindle with the tool is fixed. This enables rotationally symmetric contours to be created. The preset must be in the center of the turning spindle.

With the management of turning tools, other geometric descriptions are considered than with milling or drilling tools. To be able to execute tool radius compensation, for example, you have to define the tool radius. To support these definitions, the TNC provides special tool management for turning tools, See "Tool data", page 435.

Different cycles are available for machining. These can also be used with additionally inclined swivel axes: page 447

The assignment of the axes with turning is defined so that the X coordinates describe the diameter of the workpiece and the Z coordinates the longitudinal positions.

Programming is thus always done in the XZ coordinate plane. The machine axes to be used for the required motions depend on the respective machine kinematics and are determined by the machine manufacturer. This makes NC programs with turning functions largely exchangeable and independent of the machine model.



## 14.2 Basis Functions (Software Option 50)

### Switching between milling/turning mode of operation




The machine has to have been adapted by the machine manufacturer for turning operations and switching the mode of operation. Refer to your machine manual.

To switch between milling and turning operations you must switch to the specific mode.

You can switch these operating modes with the NC functions FUNCTION MODE TURN and FUNCTION MODE MILL.

The TNC shows a symbol in the status display when the turning mode is active

Mode of operation	Symbol
Turning mode active: FUNCTION MODE TURN	
Milling mode active: FUNCTION MODE MILL	No symbol

When the modes of operation are switched between, the TNC executes a macro that defines the machine-specific settings for the specific mode of operation. In the NC functions FUNCTION MODE TURN and FUNCTION MODE MILL you can define a machine kinematic model that the machine tool builder can request and activate in the macro. Switching the machine kinematics is a machine-dependent function. Refer to your machine manual.



The preset must be in the center of the turning spindle in turning mode.

The position of the tool tip must be aligned to the center of the turning spindle. Position the Y coordinates in Turning mode to the center of the turning spindle.

Check the orientation of the tool spindle. The tool tip must be aligned to the center of the turning spindle for outside machining. The tool tip must be aligned opposite to the center of the turning spindle for inside machining.

Check whether the rotation direction of the turning spindle is correct for the loaded tool.

If you process heavy workpieces with high speeds then high physical forces occur. Ensure that the workpiece is firmly clamped to avoid accidents or machine damage.

## Programming: Turning Operations

### 14.2 Basis Functions (Software Option 50)



In Turning mode, diameter values are displayed on the X axis position display. The TNC then shows a diameter symbol on the position display.






In Turning mode, the spindle potentiometer is effective on the turning spindle (rotary table).

Switching mode is not possible if "Tilting the working plane" or TCPM is active.

In Turning mode, no coordinate conversions are permitted except for the datum shift cycle.

You can also use the smartSelect function for defining the turning functions See "Overview of special functions", page 348.

Entering the operation mode:

- 
  - ▶ Show the soft-key row with special functions
- 
  - ▶ Select the menu for **TURNING PROGRAM FUNCTIONS**
- 
  - ▶ Select **BASIC FUNCTIONS**
- 
  - ▶ Select **FUNCTION MODE**
- 
  - ▶ Select the function for Turning or Milling mode
  - ▶ Select the kinematic model that is to be activated with switchover (machine-dependent function). If you do not want to define a kinematic model, confirm with the NO ENT key

#### NC syntax

**11 FUNCTION MODE TURN "AC\_TABLE" ; ACTIVATE TURNING MODE**


**12 FUNCTION MODE MILL "B\_HEAD" ; ACTIVATE MILLING MODE**

## Graphical display of turning operations

You can graphically simulate turning processes with the line graphic in Programming operating mode. The requirement for this is a workpiece blank definition suitable for the turning process.

The assignment of the axes with turning is defined so that the X coordinates describe the diameter of the workpiece and the Z coordinates the longitudinal positions. To display the traverse movements in Turning mode you must use a workpiece blank definition with the spindle axis **Y**.

Even when turning occurs in a 2D plane (X and Z coordinates) you must still program the Y values when defining the workpiece blank. The TNC requires the Y expansion for calculating the workpiece blank cuboid. It is sufficient when you enter small values here such as -1 and +1, as the Y coordinates in Turning mode are not considered as the operating axis.



In the Program Test operating mode, you can only use the 3D line graphic for simulating processing in Turning mode.

## NC syntax

<b>%LT 200 G71 *</b>	
<b>N10 G30 G18 X+0 Y-1 Z-50 *</b>	Define the workpiece blank for graphic workpiece simulation
<b>N20 G31 G90 X+87 Y+1 Z+2 *</b>	
<b>N30 T301 *</b>	Tool call
<b>N40 G00 G40 G90 Z+250 *</b>	Retract the tool in the spindle axis at rapid traverse
<b>N50 FUNCTION MODE TURN *</b>	Activate Turning mode

## Programming: Turning Operations

### 14.2 Basis Functions (Software Option 50)

#### Program spindle speed



If you machine at constant cutting speed, the selected gear range limits the possible spindle speed range. The possible gear ranges (if applicable) depend on your machine.

With turning you can machine both at constant spindle speed and constant cutting speed.

If you machine at constant cutting speed **VCONST:ON**, the TNC modifies speed according to the distance of the tool tip to the center of the turning spindle. The TNC increases table speed with positioning in the direction of the turning center and reduces speed with movements away from the turning center.


For processing with constant spindle speed **VCONST:OFF**, speed is independent of the tool position.

Use FUNCTION TURNDATA SPIN to define the speed. The TNC now provides the following entry elements:

- VCONST: Constant cutting speed on/off (obligatory)
- VC: Cutting speed (optional)
- S: Nominal speed when no constant cutting speed is active (optional)
- S MAX: Maximum speed with constant cutting speed (optional), is reset with S MAX 0
- gearrange: Gear range for the turning spindle (optional)

Defining the speed:

- SPEC FCT** ▶ Show the soft-key row with special functions
- TURNING PROGRAM FUNCTIONS** ▶ Select the menu for **TURNING PROGRAM FUNCTIONS**
- FUNCTION TURNDATA** ▶ Select FUNCTION TURNDATA
- TURNDATA SPIN** ▶ Select TURNDATA SPIN
- VCONST: ON** ▶ Select the function for speed entry VCONST:



#### NC syntax

<b>3 FUNCTION TURNDATA SPIN VCONST:ON VC:100 GEARRANGE:2</b>	Definition of a constant cutting speed in gear range 2
<b>3 FUNCTION TURNDATA SPIN VCONST:OFF S550</b>	Definition of a constant spindle speed
...	




## Feed rate

With turning, feed rates are often specified in millimeters per revolution. The TNC moves the tool according to a defined value for each spindle revolution. The resulting contouring feed rate is thus dependent on the speed of the turning spindle. With high speeds the TNC increases the feed rate and with low speeds reduces the feed rate. With uniform cutting depth you can machine with constant cutting force to achieve a constant cut thickness.

The programmed feed rate on a TNC is by default always interpreted in millimeters per minute (mm/min). If you wish to define feed rate in millimeters per revolution (mm/rev.), you must program **M136**. The TNC then interprets all subsequent feed rate specifications in mm/rev. until **M136** is canceled.

**M136** is effective modally at the beginning of the block and can be canceled with **M137**.



## NC syntax

<b>%LT 200 G71 *</b>	
<b>N40 G00 G40 G90 X+102 Z+2</b>	Movement at rapid traverse
...	
<b>N30 G01 X+87 F200 *</b>	Movement at a feed rate of 200 mm/min
<b>N40 M136 *</b>	Feed rate in millimeters per revolution
<b>N50 G01 X+154 F0.2 *</b>	Movement at a feed rate of 0.2 mm/rev.
...	

## Tool call

Just as in Milling mode, turning tools are called with the **TOOL CALL** function. You merely have to enter the tool number or tool name in the **TOOL CALL** block.



You can call and insert a turning tool both in Milling mode and in Turning mode.

## NC syntax

<b>N40 FUNCTION MODE TURN</b>	Turning mode selection
<b>N50 T301</b>	Tool call

## Programming: Turning Operations

### 14.2 Basis Functions (Software Option 50)

#### Tool compensation in the program

With **FUNCTION TURNDATA CORR** you can define additional compensation values for the active tool. In **FUNCTION TURNDATA CORR** you can enter delta values for tool lengths in the X direction **DXL** and in the Z direction **DZL**. The compensation values have an additive effect on the compensation values from the turning tool table. **FUNCTION TURNDATA CORR** is always effective for the active tool. A renewed **TOOL CALL** deactivates compensation again. When you exit the program (e.g. PGM MGT), the TNC automatically resets the compensation values.

When you enter the function **FUNCTION TURNDATA CORR** you can specify by soft key the effect of the tool compensation:

- **FUNCTION TURNDATA CORR-TCS**: The tool compensation is effective in the tool coordinate system
- **FUNCTION TURNDATA CORR-WCS**: The tool compensation is effective in the workpiece coordinate system



Tool compensation **FUNCTION TURNDATA CORR-TCS** is always effective in the tool coordinate system, even during inclined machining.

Defining tool compensation:

- SPEC  
FCT ▶ Show the soft-key row with special functions
- TURNING  
PROGRAM  
FUNCTIONS ▶ Select the menu for **TURNING PROGRAM FUNCTIONS**
- FUNCTION  
TURNDATA ▶ Select **FUNCTION TURNDATA**
- TURNDATA  
CORR ▶ Select **TURNDATA CORR**

#### NC syntax

```
21 FUNCTION TURNDATA CORR-TCS:Z/X DZL:0.1 DXL:0.05
```

```
...
```

### Tool data

You define turning-specific tool data in the turning tool table **TOOLTURN.TRN**.

The tool number saved in column **T** refers to the number of the turning tool in the TOOL.T. geometry values, e.g. **L** and **R** from TOOL.T are not effective with turning tools.

In addition you must identify turning tools in the tool table TOOL.T as turning tools. For this, in column TYP select the tool type **TURN** for the appropriate tool. If you require additional geometric data for a tool you can create further indexed tools for this.



The tool number in TOOLTURN.TRN must match the tool number of the turning tool in TOOL.T. If you enter or copy a new line you can then enter the corresponding number.

Below the table window the TNC displays dialog text, unit specification and entry area for the specific input field.

## Programming: Turning Operations

### 14.2 Basis Functions (Software Option 50)


#### Tool data in the turning tool table

Input element	Application	Input
<b>T</b>	Tool number must match the tool number of the turning tool in TOOL.T	-
<b>NAME</b>	Tool name: The TNC automatically takes on the tool name if you select the turning tool table in the tool table	<b>Input range: 32 characters max., only capital letters, no space characters</b>
<b>ZL</b>	Compensation value for tool length 1 (Z direction)	<b>-99999.9999...+99999.9999</b>
<b>XL</b>	Compensation value for tool length 2 (X direction)	<b>-99999.9999...+99999.9999</b>
<b>DZL</b>	Delta value for tool length 1 (Z direction), additive effect on ZL	<b>-99999.9999...+99999.9999</b>
<b>DXL</b>	Delta value for tool length 2 (X direction), additive effect on XL	<b>-99999.9999...+99999.9999</b>
<b>RS</b>	Tool tip radius: The TNC considers the tool tip radius in turning cycles and implements tool tip radius compensation when contours with radius compensation <b>RL</b> or <b>RR</b> were programmed	<b>-99999.9999...+99999.9999</b>
<b>TO</b>	Tool orientation: Direction of tool tip	<b>1 to 9</b>
<b>ANGLE OF ORIENTATION (ORI)</b>	Spindle orientation angle: Angle of the milling spindle for aligning the turning tool to the machining position	<b>-360.0...+360.0</b>
<b>T-ANGLE</b>	Setting angle for roughing and finishing tools	<b>0.0000...+179.9999</b>
<b>P-ANGLE</b>	Point angle for roughing and finishing tools	<b>0.0000...+179.9999</b>
<b>CUTLENGTH</b>	Cutting length of recessing tool	<b>0.0000...+99999.9999</b>
<b>CUTWIDTH</b>	Width of recessing tool	<b>0.0000...+99999.9999</b>
<b>TYPE</b>	Type of turning tool: Roughing tool <b>ROUGH</b> , finishing tool <b>FINISH</b> , thread tool <b>THREAD</b> , recessing tool <b>RECESS</b> , button tool <b>BUTTON</b> , groove turning tool <b>RECTURN</b>	<b>ROUGH, FINISH, THREAD, RECESS, BUTTON, RECTURN</b>

With the spindle orientation angle **ORI** you define the angle position of the milling spindle for the turning tool. Orient the tool tip depending on the tool orientation **TO** to the rotary table center or in the opposite direction.




The tool must be clamped and measured in the correct position.  
Check the tool orientation after definition of a tool.



### Tool data for turning tool

#### Required and optional tool data for turning tool


Input element	Application	Input
ZL	Tool length 1	Required
XL	Tool length 2	Required
DZL	Wear compensation <b>ZL</b>	Optional
DXL	Wear compensation <b>XL</b>	Optional
RS	Cutting radius	Required
TO	Tool orientation	Required
ORI	Orientation angle	Required
T-ANGLE	Tool angle	Required
P-ANGLE	Point angle	Required
TYPE	Tool type	Required



### Tool data for recessing tools

#### Required and optional tool data for recessing tools

Input element	Application	Input
ZL	Tool length 1	Required
XL	Tool length 2	Required
DZL	Wear compensation <b>ZL</b>	Optional
DXL	Wear compensation <b>XL</b>	Optional
RS	Cutting radius	Required
TO	Tool orientation	Required
ORI	Orientation angle	Required
CUTWIDTH	Width of recessing tool	Required
TYPE	Tool type	Required




## Programming: Turning Operations

### 14.2 Basis Functions (Software Option 50)

#### Tool data for groove turning tools

##### Required and optional tool data for groove turning tools


Input element	Application	Input
ZL	Tool length 1	Required
XL	Tool length 2	Required
DZL	Wear compensation <b>ZL</b>	Optional
DXL	Wear compensation <b>XL</b>	Optional
RS	Cutting radius	Required
TO	Tool orientation	Required
ORI	Orientation angle	Required
CUTLENGTH	Cutting length of recessing tool	Required
CUTWIDTH	Width of recessing tool	Required
TYPE	Tool type	Required



#### Tool data for button tools

##### Required and optional tool data for button tools



Input element	Application	Input
ZL	Tool length 1	Required
XL	Tool length 2	Required
DZL	Wear compensation <b>ZL</b>	Optional
DXL	Wear compensation <b>XL</b>	Optional
RS	Cutting radius	Required
TO	Tool orientation	Required
ORI	Orientation angle	Required
T-ANGLE	Tool angle	Required
P-ANGLE	Point angle	Required
TYPE	Tool type	Required



## Tool data for threading tools

## Required and optional tool data for threading tools

Input element	Application	Input
ZL	Tool length 1	Required
XL	Tool length 2	Required
DZL	Wear compensation <b>ZL</b>	Optional
DXL	Wear compensation <b>XL</b>	Optional
TO	Tool orientation	Required
ORI	Orientation angle	Required
T-ANGLE	Tool angle	Required
P-ANGLE	Point angle	Required
TYPE	Tool type	Required



## Programming: Turning Operations


### 14.2 Basis Functions (Software Option 50)

#### Tool tip radius compensation TRC

Turning tools have a radius at the tool tip (**RS**). When machining tapers, chamfers and radii, this results in inaccuracies on the contour because programmed traverse paths are always referenced to the theoretical tool tip **S** (see figure at upper right). TRC prevents the resulting deviations.


In turning cycles the TNC automatically carries out tool tip radius compensation. In specific traversing blocks and within programmed contours, activate TRC with **RL** or **RR**.

In turning cycles the TNC checks the cutting geometry with the point angle **P-ANGLE** and the setting angle **T-ANGLE**. Contour elements in the cycle are processed by the TNC only as far as this is possible with the specific tool. The TNC outputs a warning when residual material is left behind.



When the position of the cutting edge is neutral (**TO=2;4;6;8**), the direction of the radius compensation is ambiguous. In this case, TRC is only possible within cycles.

The TNC can also run tool tip radius compensation during inclined processing. The following limitation applies: If you activate inclined processing with M128 then tool tip radius compensation without a cycle, i.e. in traversing blocks with **RL/RR**, is not possible. If you activate inclined processing with **M144** this limitation does not apply.





## Recessing and undercutting

Some cycles machine contours that you have written in a subprogram. You program these contours with plain-language path functions or FK functions. Further special contour elements are available to you for writing turning contours. In this way you can program complete recessing and undercutting as complete contour elements with a single NC block.



Recessing and undercutting always reference a previously defined linear contour element. Recessing elements GRV and undercut elements UDC can only be used in contour subprograms that are called by a turning cycle (see User's Manual, Cycles, Turning).

You have various input possibilities when defining recessing and undercutting. Some of these inputs are mandatory, and others you can leave out (optional). The mandatory inputs are symbolized as such in the help graphics. In some elements you can select between two different definitions. The TNC has soft keys with the corresponding selection possibilities.

Programming recessing and undercutting:

SPEC  
FCT

- ▶ Show the soft-key row with special functions

TURNING  
PROGRAM  
FUNCTIONS

- ▶ Select the menu for **TURNING PROGRAM FUNCTIONS**

RECESS/  
UNDERCUT

- ▶ Select RECESS/UNDERCUT

GRV

- ▶ Select GRV (recess) or UDC (undercut)

## Programming: Turning Operations

### 14.2 Basis Functions (Software Option 50)



#### Programming recessing

Recessing is the machining of recesses in round components, usually for accommodation of locking rings and seals or as lubricating grooves. You can program recessing around the circumference or on the face ends of the turned part. For this you have two separate contour elements:

- **GRV RADIAL:** Recess in circumference of component
- **GRV AXIAL:** Recess on face end of component

#### Input elements in recessing GRV

Input element	Application	Input
<b>CENTER</b>	Center of recess	Required
<b>R</b>	Corner radius of both inner corners	Optional
<b>DEPTH / DIAM</b>	Recess depth (pay attention to the algebraic sign!) / diameter of recess base	Required
<b>BREADTH</b>	Recess width	Required
<b>ANGLE / ANG_WIDTH</b>	Edge angle / aperture angle of both edges	Optional
<b>RND / CHF</b>	Curve / chamfer corner of contour near to starting point	Optional
<b>FAR_RND / FAR_CHF</b>	Curve / chamfer corner of contour away from starting point	Optional



The algebraic sign for the recess depth specifies the machining position of the recess (inside/outside machining).

Algebraic sign of recess depth for outside machining:

- Use a negative sign when the contour element runs in a negative direction to the Z coordinate
- Use a positive sign when the contour element runs in a positive direction to the Z coordinate

Algebraic sign of recess depth for inside machining:

- Use a positive sign when the contour element runs in a negative direction to the Z coordinate
- Use a negative sign when the contour element runs in a positive direction to the Z coordinate

#### Radial recess: depth=5, width=10, Pos.= Z-15

```
N30 G01 X+40 Z+0
```

```
N40 G01 Z-30
```

```
N50 GRV RADIAL CENTER-15 DEPTH-5 BREADTH10 CHF1 FAR_CHF1
```

```
N60 G01 X+60
```

### Programming undercutting

Undercutting is usually required for the flush connection of counterparts. In addition undercutting can help to reduce the notch effect at corners. Threads and fits are often machined with an undercut. You have various contour elements for defining the different undercuts:

- **UDC TYPE\_E**: Undercut for cylindrical surface to be further processed in compliance with DIN 509
- **UDC TYPE\_F**: Undercut for plan and cylindrical surface for further processing in compliance with DIN 509
- **UDC TYPE\_H**: Undercut for more rounded transition in compliance with DIN 509
- **UDC TYPE\_K**: Undercut in face and cylindrical surface
- **UDC TYPE\_U**: Undercut in cylindrical surface
- **UDC THREAD**: Thread undercut in compliance with DIN 76



The TNC always interprets undercuts as form elements in the longitudinal direction. No undercuts are possible in the plane direction.

## Programming: Turning Operations

### 14.2 Basis Functions (Software Option 50)

#### Undercut DIN 509 UDC TYPE\_E

##### Input elements in undercut DIN 509 UDC TYPE\_E

Input element	Application	Input
R	Corner radius of both inner corners	Optional
DEPTH	Undercut depth	Optional
BREADTH	Undercut width	Optional
ANGLE	Undercut angle	Optional

##### Radial recess: depth=5, width=10, Pos.= Z-15

```
N30 G01 X+40 Z+0
```

```
N40 G01 Z-30
```

```
N50 UDC TYPE_E R1 DEPTH2 BREADTH15
```

```
N60 G01 X+60
```

#### Undercut DIN 509 UDC TYPE\_F

##### Input elements in undercut DIN 509 UDC TYPE\_F

Input element	Application	Input
R	Corner radius of both inner corners	Optional
DEPTH	Undercut depth	Optional
BREADTH	Undercut width	Optional
ANGLE	Undercut angle	Optional
FACEDEPTH	Depth of face	Optional
FACEANGLE	Contour angle of face	Optional



##### Undercut form F: depth = 2, width = 15, depth of face = 1

```
N30 G01 X+40 Z+0
```

```
N40 G01 Z-30
```

```
N50 UDC TYPE_F R1 DEPTH2 BREADTH15 FACEDEPTH1
```

```
N60 L X+60
```




**Undercut DIN 509 UDC TYPE\_H****Input elements in undercut DIN 509 UDC TYPE\_H**


Input element	Application	Input
R	Corner radius of both inner corners	Required
BREADTH	Undercut width	Required
ANGLE	Undercut angle	Required

**Undercut form F: depth = 2, width = 15, depth of face = 1**

N30 G01 X+40 Z+0
N40 G01 Z-30
N50 UDC TYPE_H R1 BREADTH10 ANGLE10
N60 L X+60

**Undercut UDC TYPE\_K****Input elements in undercut UDC TYPE\_K**

Input element	Application	Input
R	Corner radius of both inner corners	Required
DEPTH	Undercut depth (paraxially)	Required
ROT	Angle to longitudinal axis (default: 45°)	Optional
ANG_WIDTH	Opening angle of undercut	Required

**Undercut form F: depth = 2, width = 15, depth of face = 1**

N30 G01 X+40 Z+0
N40 G01 Z-30
N50 UDC TYPE_K R1 DEPTH3 ANG_WIDTH30
N60 L X+60

## Programming: Turning Operations

### 14.2 Basis Functions (Software Option 50)

#### Undercut UDC TYPE\_U

##### Input elements in undercut UDC TYPE\_U

Input element	Application	Input
R	Corner radius of both inner corners	Required
DEPTH	Undercut depth	Required
BREADTH	Undercut width	Required
RND / CHF	Curve / chamfer of outer corner	Required

##### Undercut form U: depth = 3, width = 8

```

N30 G01 X+40 Z+0
N40 G01 Z-30
N50 UDC TYPE_U R1 DEPTH3 BREADTH8 RND1
N60 L X+60

```

#### Undercut UDC THREAD

##### Input elements in undercut DIN 76 UDC THREAD



Input element	Application	Input
PITCH	Thread pitch	Optional
R	Corner radius of both inner corners	Optional
DEPTH	Undercut depth	Optional
BREADTH	Undercut width	Optional
ANGLE	Undercut angle	Optional

##### Undercut form U: depth = 3, width = 8

```

N30 G01 X+40 Z+0
N40 G01 Z-30
N50 UDC THREAD PITCH2
N60 L X+60

```



## Inclined turning


It may sometimes be necessary for you to bring the swivel axes into a specific position to machine a specific process. This can be necessary for example when you can only machine contour elements according to a specific position due to tool geometry.

Inclining a swivel axis creates an offset from tool to tool. The function **M144** considers the position of the inclined axes and compensates this offset. In addition the function **M144** aligns the Z direction of the workpiece coordinate system to the direction of the centerline of the tool. If an inclined axis is a tilting table, so that the workpiece is sloping, the TNC runs traverse movements in the displaced workpiece coordinate system. If the inclined axis is a swivel head (tool is sloping) the workpiece coordinate system is not displaced.

After inclining the swivel axis you may have to again pre-position the tool in the Y coordinates and orient the position of the tool tip with the cycle 800.

Alternatively to function **M144** you can also use function **M128**. The effect is identical, but the following limitation applies: The TNC can also run tool tip radius compensation during inclined processing. If you activate inclined processing with **M128** then tool tip radius compensation without a cycle, i.e. in traversing blocks with **RL/RR**, is not possible. If you activate inclined processing with **M144** this limitation does not apply.

If the turning cycles are executed with **M144**, the angles of the tool to the contour change. The TNC automatically takes these modifications into account and thus also monitors the machining in inclined state.



You can use recessing cycles and thread cycles with inclined machining only with a rectangular tool angle (+90°, -90°).

Tool compensation **FUNCTION TURNDATA CORR-TCS** is always effective in the tool coordinate system, even during inclined machining.

## Programming: Turning Operations

### 14.2 Basis Functions (Software Option 50)

#### Example NC blocks: Inclined machining on a machine with a rotary table C and a tilting table A

...	
12 M144	Activate inclined machining
13 L A-25 R0 FMAX	Position swivel axis
14 CYCL DEF 800 ADAPT ROTARY COORDINATE SYSTEM	Workpiece coordinate system and align tool
Q497=+90           ;PRECISION ANGLE	
Q498=+0           ;REVERSE TOOL	
15 L X+165 Y+0 R0 FMAX	Pre-position the tool
16 L Z+2 R0 FMAX	Tool at starting position
...	Machining with inclined axis



## 14.3 Unbalance Functions


### Unbalance while turning

#### General information



The machine has to have been adapted by the machine manufacturer for monitoring and measuring unbalance. The unbalance functions are not required some machine types. These functions might not be available on your machine. Refer to your machine manual.

The unbalance functions described here are basic functions that are set up and adapted to the machine by the machine manufacturer. The scope and effect of the described functions may therefore vary from machine to machine. The machine manufacturer may also provide different unbalance functions. Refer to your machine manual.



In a turning operation, the tool is in a fixed position, whereas the rotary table and the clamped workpiece rotate. Depending on the size of the workpiece, the mass that is set in rotation can be very large. As the workpiece rotates, it creates an outward centrifugal force.

The centrifugal force that occurs basically depends on the rotational speed, the mass and the unbalance of the workpiece. An unbalance occurs if an object with a rotationally nonsymmetrical mass distribution is set in rotation. The rotation of the mass object creates outward-directed centrifugal forces. If the rotating mass is evenly distributed, the centrifugal forces cancel each other out.

Unbalance is significantly influenced by the structural shape of the workpiece (e.g. nonsymmetrical pump body) and by the chucking equipment. As these factors frequently cannot be changed, you should compensate any existing unbalance by means of balancing weights. The TNC provides the "Measure Unbalance" cycle for this purpose. The cycle determines the existing unbalance and calculates the mass and position of the required balancing weight.



The rotation of the workpiece creates centrifugal forces that can cause vibration (resonance), depending on the unbalance. This vibration has a negative effect on the machining process and reduces the tool life. High centrifugal forces can damage the machine or push the workpiece out of the fixture.

Check the unbalance whenever you clamp a new workpiece. If required, use balancing weights to compensate any unbalance.

The removal of material during machining will change the mass distribution within the workpiece. This may also have an influence on workpiece unbalance. Therefore, unbalance checks should also be carried out between machining steps.

Keep in mind the mass and unbalance of the workpiece when choosing the speed. Do not use high speeds with heavy workpieces or high unbalance loads.

#### Unbalance Monitor function

The Unbalance Monitor function monitors the unbalance of a workpiece in Turning mode. If a maximum unbalance limit specified by the machine manufacturer is exceeded, the TNC issues an error message and initiates an emergency stop. In addition, you can further decrease the permissible unbalance limit by setting the machine parameter **limitUnbalanceUsr**. If this limit is exceeded, the TNC will display an error message, but the table rotation will not be stopped. The TNC automatically activates the Unbalance Monitor function when you switch to Turning mode. The unbalance monitor is effective until you switch back to Milling mode.


## Measure Unbalance cycle

To ensure maximum safety and minimum strain on the machine and workpiece during turning, you should check the unbalance of the clamped workpiece and compensate it with a balancing weight. The TNC provides the Measure Unbalance cycle for this purpose. The Measure Unbalance cycle determines the unbalance of the workpiece and calculates the mass and position of a balancing weight.

To determine unbalance:




- ▶ Shift the soft-key row in the Manual Operation mode



- ▶ Select the **MANUAL CYCLES** soft key



- ▶ Select the **TURNING** soft key




- ▶ Select the MEASURE UNBALANCE soft key
- ▶ Enter the speed for unbalance detection
- ▶ Press the NC start button: The cycle starts rotating the table at a low speed and gradually increases the speed up to the defined value. The TNC displays a window that shows the calculated mass and radial position of the balancing weight.

If you wish to use a different radial position or mass for the balancing weight, you can overwrite one value and have the other value recalculated automatically.



Repeat the unbalance measurement after you have clamped a balancing weight.

In some cases, you may need to place two or more balancing weights at different positions in order to compensate unbalance.





# 15

**Manual operation  
and setup**

## Manual operation and setup

### 15.1 Switch-on, switch-off

#### 15.1 Switch-on, switch-off

##### Switch-on



Switch-on and crossing over the reference points can vary depending on the machine tool.  
Refer to your machine manual.

Switch on the power supply for TNC and machine. The TNC then displays the following dialog:

##### SYSTEM STARTUP

- ▶ TNC is started

##### POWER INTERRUPTED



- ▶ TNC message that the power was interrupted—clear the message

##### COMPILE A PLC PROGRAM

- ▶ The PLC program of the TNC is automatically compiled

##### RELAY EXT. DC VOLTAGE MISSING



- ▶ Switch on external dc voltage. The TNC checks the functioning of the EMERGENCY STOP circuit

##### MANUAL OPERATION

##### TRAVERSE REFERENCE POINTS



- ▶ Cross the reference points manually in the displayed sequence: For each axis press the machine START button, or



- ▶ Cross the reference points in any sequence: Press and hold the machine axis direction button for each axis until the reference point has been traversed



If your machine is equipped with absolute encoders, you can leave out crossing the reference marks. In such a case, the TNC is ready for operation immediately after the machine control voltage is switched on.

The TNC is now ready for operation in the Manual Operation mode.



The reference points need only be crossed if the machine axes are to be moved. If you intend only to edit or test programs, you can select the Programming and Editing or Test Run modes of operation immediately after switching on the control voltage.

You can cross the reference points later, by pressing the **PASS OVER REFERENCE** soft key in the Manual Operation mode.

### Crossing the reference point in a tilted working plane



#### **Danger of collision!**

Make sure that the angle values entered in the menu for tilting the working plane match the actual angles of the tilted axis.

Deactivate the "Tilt Working Plane" function before you cross the reference points. Take care that there is no collision. Retract the tool from the current position first, if necessary.

The TNC automatically activates the tilted working plane if this function was enabled when the control was switched off. Then the TNC moves the axes in the tilted coordinate system when an axis-direction key is pressed. Position the tool in such a way that a collision is excluded during the subsequent crossing of the reference points. To scan the reference points you have to deactivate the "Tilt Working Plane" function, See "To activate manual tilting:", page 511.



If you use this function, then for non-absolute encoders you must confirm the positions of the rotary axes, which the TNC displays in a pop-up window. The position displayed is the last active position of the rotary axes before switch-off.

If one of the two functions that were active before is active now, the **NC START** button has no function. The TNC outputs a corresponding error message.

## Manual operation and setup

### 15.1 Switch-on, switch-off

#### Switch-off

To prevent data from being lost at switch-off, you need to shut down the operating system of the TNC as follows:

- ▶ Select the Manual Operation mode



- ▶ Select the function for shutting down, confirm again with the **YES** soft key
- ▶ When the TNC displays the message **NOW IT IS SAFE TO TURN POWER OFF** in a pop-up window, you may cut off the power supply to the TNC



#### **Caution: Data may be lost!**

Inappropriate switch-off of the TNC can lead to data loss!

Remember that pressing the END key after the control has been shut down restarts the control. Switch-off during a restart can also result in data loss!



## 15.2 Moving the machine axes

### Note



Traversing with the machine axis direction buttons can vary depending on the machine tool. Refer to your machine manual.

### Moving the axis with the machine axis direction buttons



- ▶ Select Manual operating mode



- ▶ Press the machine axis direction button and hold it as long as you wish the axis to move, or



- ▶ Move the axis continuously: Press and hold the machine axis direction button, then briefly press the machine START button



- ▶ To stop the axis, press the machine STOP button

You can move several axes at a time with these two methods. You can change the feed rate at which the axes are traversed with the **F** soft key, See "Spindle speed S, feed rate F and miscellaneous function M", page 468.

### Incremental jog positioning


With incremental jog positioning you can move a machine axis by a preset distance.



- ▶ Select the Manual Operation or El. Handwheel mode



- ▶ Shift the soft-key row



- ▶ Select incremental jog positioning: Switch INCREMENT soft key to ON

#### JOG INCREMENT =




- ▶ Enter the jog increment in mm, and confirm with the ENT key



- ▶ Press the machine axis direction button as often as desired



The maximum permissible value for infeed is 10 mm.



## Manual operation and setup

### 15.2 Moving the machine axes

#### Traverse with electronic handwheels

The TNC supports traversing with the following new electronic handwheels:

- HR 520: Handwheel compatible for connection to HR 420 with display, data transfer per cable
- HR 550 FS: Handwheel with display, radio data transmission

In addition to this, the TNC continues to support the cable handwheels HR 410 (without display) and HR 420 (with display).



#### **Caution: Danger to the operator and handwheel!**

All of the handwheel connectors may only be removed by authorized service personnel, even if it is possible without any tools!

Ensure that the handwheel is plugged in before you switch on the machine!

If you wish to operate your machine without the handwheel, disconnect the cable from the machine and secure the open socket with a cap!



Your machine tool builder can make additional functions of the HR 5xx available. Refer to your machine manual.



A HR 5xx handwheel is recommended if you want to use the handwheel superimposition in virtual axis function. See "Virtual tool axis VT".


The portable HR 5xx handwheels feature a display on which the TNC shows information. In addition, you can use the handwheel soft keys for important setup functions, e.g. datum setting or entering and running M functions.

As soon as you have activated the handwheel with the handwheel activation key, the operating panel is locked. This is indicated by a pop-up window on the TNC screen.



## Moving the machine axes 15.2

- 1** EMERGENCY STOP button
- 2** Handwheel display for status display and function selection, for further information, ""
- 3** Soft keys
- 4** Axis selection keys; can be exchanged by the machine manufacturer depending on the axis configuration
- 5** Permissive key
- 6** Arrow keys for defining handwheel sensitivity
- 7** Handwheel activation key
- 8** Key for TNC traverse direction of the selected axis
- 9** Rapid traverse superimposition for direction key
- 10** Spindle switch-on (machine-dependent function, key can be exchanged by the machine manufacturer)
- 11** "Generate NC block" key (machine-dependent function, key can be exchanged by the machine manufacturer)
- 12** Spindle switch-off (machine-dependent function, key can be exchanged by the machine manufacturer)
- 13** CTRL key for special functions (machine-dependent function, key can be exchanged by the machine manufacturer)
- 14** NC start (machine-dependent function, key can be exchanged by the machine manufacturer)
- 15** NC stop (machine-dependent function, key can be exchanged by the machine manufacturer)
- 16** Handwheel
- 17** Spindle speed potentiometer
- 18** Feed rate potentiometer
- 19** Cable connection, not available with the HR 550 FS wireless handwheel




## Manual operation and setup

### 15.2 Moving the machine axes

#### Handwheel display

- 1 **Only with wireless handwheel HR 550 FS:** Shows whether the handwheel is in the docking station or whether wireless operation is active
- 2 **Only with wireless handwheel HR 550 FS:** Shows the field strength, 6 bars = maximum field strength
- 3 **Only with wireless handwheel HR 550 FS:** Shows the charge status of the rechargeable battery, 6 bars = fully charged A bar moves from the left to the right during recharging
- 4 **ACTL:** Type of position display
- 5 **Y+129.9788:** Position of the selected axis
- 6 **\***: STIB (control in operation); program run has been started or axis is in motion
- 7 **S0:** Current spindle speed
- 8 **F0:** Feed rate at which the selected axis is moving
- 9 **E:** Error message
- 10 **3D:** Tilted-working-plane function is active
- 11 **2D:** Basic rotation function is active
- 12 **RES 5.0:** Active handwheel resolution. Distance in mm/rev (°/rev for rotary axes) that the selected axis moves for one handwheel revolution
- 13 **STEP ON or OFF:** Incremental jog active or inactive. If the function is active, the TNC also displays the active jog increment
- 14 **Soft-key row:** Selection of various functions, described in the following sections



### Special features of the HR 550 FS wireless handwheel



Due to various potential sources of interference, a wireless connection is not as reliable as a cable connection. Before you use the wireless handwheel it must therefore be checked whether there are any other radio users in the surroundings of the machine. This inspection for presence of radio frequencies or channels is recommended for all industrial radio systems.

When the HR550 is not needed, always put it in the handwheel holder. This way you can ensure that the handwheel batteries are always ready for use thanks to the contact strip on the rear side of the wireless handwheel and the recharge control, and that there is a direct contact connection for the emergency stop circuit.

If an error (interruption of the radio connection, poor reception quality, defective handwheel component) occurs, the handwheel always reacts with an emergency stop.

Please read the notes on the configuration of the HR 550 FS wireless handwheel. See "Configure HR 550 FS wireless handwheel", page 576



#### **Caution: Danger to the operator and machine!**

Due to safety reasons you must switch off the wireless handwheel and the handwheel holder after an operating time of 120 hours at the latest so that the TNC can run a functional test when it is restarted!

If you use several machines with wireless handwheels in your workshop you have to mark the handwheels and holders that belong together so that their respective associations are clearly identifiable (e.g. by color stickers or numbers). The markings on the wireless handwheel and the handwheel holder must be clearly visible to the user!

Before every use, make sure that the correct handwheel for your machine is active.

## Manual operation and setup

### 15.2 Moving the machine axes

The HR 550 FS wireless handwheel features a rechargeable battery. The battery is recharged when you put the handwheel in the holder (see figure).

You can operate the HR 550 FS with the accumulator for up to 8 hours before it must be recharged again. It is recommended, however, that you always put the handwheel in its holder when you are not using it.

As soon as the handwheel is in its holder, it switches internally to cable operation. In this way you can use the handwheel even if it were completely discharged. The functions are the same as with wireless operation.



When the handwheel is completely discharged, it takes about 3 hours until it is fully recharged in the handwheel holder.


Clean the contacts **1** in the handwheel holder and of the handwheel regularly to ensure their proper functioning.

The transmission range is amply dimensioned. If you should nevertheless happen to come near the edge of the transmission area, which is possible with very large machines, the HR 550 FS warns you in time with a plainly noticeable vibration alarm. If this happens you must reduce the distance to the handwheel holder, into which the radio receiver is integrated.




**Caution: Danger to the workpiece and tool!**

If interruption-free operation is no longer possible within the transmission range the TNC automatically triggers an emergency stop. This can also happen during machining. Try to stay as close as possible to the handwheel holder and put the handwheel in its holder when you are not using it.



If the TNC has triggered an emergency stop you must reactivate the handwheel. Proceed as follows:

- ▶ Select the Programming and Editing mode of operation
- ▶ Select the MOD function: Press the MOD key
- ▶ Scroll through the soft-key row



- ▶ Select the configuration menu for the wireless handwheel: Press the **SET UP WIRELESS HANDWHEEL** soft key
- ▶ Click the **Start handwheel** button to reactivate the wireless handwheel
- ▶ To save the configuration and exit the configuration menu, press the **END** button

The MOD mode of operation includes a function for initial operation and configuration of the handwheel. See "Configure HR 550 FS wireless handwheel", page 576.

### Selecting the axis to be moved

You can activate directly through the axis address keys the principal axes X, Y, Z and three other axes defined by the machine tool builder. Your machine tool builder can also place the virtual axis VT directly on one of the free axis keys. If the virtual axis VT is not on one of the axis selection keys, proceed as follows:

- ▶ Press the handwheel soft key F1 (**AX**): The TNC displays all active axes on the handwheel display. The currently active axis blinks
- ▶ Select the desired axis with the handwheel soft keys F1 (->) or F2 (<-) and confirm with the handwheel soft key F3 (**OK**)

### Setting the handwheel sensitivity

The handwheel sensitivity specifies the distance an axis moves per handwheel revolution. The sensitivity levels are pre-defined and are selectable with the handwheel arrow keys (only when incremental jog is not active).

Selectable sensitivity levels: 0.01/0.02/0.05/0.1/0.2/0.5/1/2/5/10/20 [mm/revolution or degrees/revolution]

## Manual operation and setup

### 15.2 Moving the machine axes

#### Moving the axes



- ▶ To activate the handwheel, press the handwheel button on the HR 5xx: You can now only operate the TNC via the HR 5xx, and the TNC displays a pop-up window with text on the TNC screen
- ▶ Select the desired operating mode via the OPM soft key if necessary



- ▶ If required, press and hold the permissive button



- ▶ Use the handwheel to select the axis to be moved. Select the additional axes via soft key, if required



- ▶ Move the active axis in the positive direction, or



- ▶ Move the active axis in the negative direction



- ▶ To deactivate the handwheel, press the handwheel key on the HR 5xx: Now you can operate the TNC again via the operating panel

#### Potentiometer settings

The potentiometers of the machine operating panel continue to be active after you have activated the handwheel. If you want to use the potentiometers on the handwheel, proceed as follows:

- ▶ Press the **CTRL** and Handwheel keys on the HR 5xx. The TNC shows the soft-key menu for selecting the potentiometers on the handwheel display
- ▶ Press the **HW** soft key to activate the handwheel potentiometers

If you have activated the potentiometers on the handwheel, you must reactivate the potentiometers of the machine operating panel before deselecting the handwheel. Proceed as follows:

- ▶ Press the **CTRL** and Handwheel keys on the HR 5xx. The TNC shows the soft-key menu for selecting the potentiometers on the handwheel display
- ▶ Press the **KBD** soft key to activate the potentiometers of the machine operating panel



### Incremental jog positioning

With incremental jog positioning the TNC moves the currently active handwheel axis by a preset distance defined by you:

- ▶ Press the handwheel soft key F2 (**STEP**)
- ▶ Activate incremental jog positioning: Press handwheel soft key 3 (**ON**)
- ▶ Select the desired jog increment by pressing the F1 or F2 key. If you press and hold the respective key, each time it reaches a decimal value 0 the TNC increases the counting increment by a factor of 10. If in addition you press the **Ctrl** key, the counting increment increases to 1. The smallest possible jog increment is 0.0001 mm. The largest possible is 10 mm
- ▶ Confirm the selected jog increment with soft key 4 (**OK**)
- ▶ With the + or – handwheel key, move the active handwheel axis in the corresponding direction

### Entering miscellaneous functions M

- ▶ Press the handwheel soft key F3 (**MSF**)
- ▶ Press the handwheel soft key F1 (**M**)
- ▶ Select the desired M function number by pressing the F1 or F2 key
- ▶ Execute the M function with the NC start key

### Entering the spindle speed S

- ▶ Press the handwheel soft key F3 (**MSF**)
- ▶ Press the handwheel soft key F2 (**S**)
- ▶ Select the desired speed by pressing the F1 or F2 key. If you press and hold the respective key, each time it reaches a decimal value 0 the TNC increases the counting increment by a factor of 10. If in addition you press the **Ctrl** key, the counting increment increases to 1000
- ▶ Activate the new speed S with the NC start key

## Manual operation and setup

### 15.2 Moving the machine axes

#### Entering the feed rate F

- ▶ Press the handwheel soft key F3 (**MSF**)
- ▶ Press the handwheel soft key F3 (**F**)
- ▶ Select the desired feed rate by pressing the F1 or F2 key. If you press and hold the respective key, each time it reaches a decimal value 0 the TNC increases the counting increment by a factor of 10. If in addition you press the **Ctrl** key, the counting increment increases to 1000
- ▶ Confirm the new feed rate F with the handwheel soft key F3 (**OK**)

#### Datum setting

- ▶ Press the handwheel soft key F3 (**MSF**)
- ▶ Press the handwheel soft key F4 (**PRS**)
- ▶ If required, select the axis in which the datum is to be set.
- ▶ Reset the axis with the handwheel soft key F3 (**OK**), or with F1 and F2 set the desired value and then confirm with F3 (**OK**)  
By also pressing the **Ctrl** key, you can increase the counting increment to 10

#### Changing modes of operation

With the handwheel soft key F4 (**OPM**), you can use the handwheel to switch the mode of operation, provided that the current status of the control allows a mode change.

- ▶ Press the handwheel soft key F4 (**OPM**)
- ▶ Select the desired operating mode by handwheel soft key
  - MAN: Manual Operation
  - MDI: Positioning with manual data input
  - SGL: Program run, single block
  - RUN: Program run, full sequence

### Generating a complete L Block



Your machine tool builder can assign any function to the "Generate NC block" handwheel key. Refer to your machine manual.

- ▶ Select the **Positioning with MDI** operating mode
- ▶ If required, use the arrow keys on the TNC keyboard to select the NC block after which the new L block is to be inserted
- ▶ Activate the handwheel
- ▶ Press the "Generate NC block" handwheel key: The TNC inserts a complete L block containing all axis positions selected through the MOD function

### Features in the program run modes of operation

You can use the following functions in the Program Run modes of operation:

- NC start (handwheel NC-start key)
- NC stop (handwheel NC-stop key)
- After the NC-stop key has been pressed: Internal stop (handwheel soft keys **MOP** and then **STOP**)
- After the NC-stop key has been pressed: Manual axis traverse (handwheel soft keys **MOP** and then **MAN**)
- Returning to the contour after the axes were moved manually during a program interruption (handwheel soft keys **MOP** and then **REPO**). Operation is via the handwheel soft keys as with the screen soft keys, See "Returning to the contour", page 545
- On/off switch for the Tilted Working Plane function (handwheel soft keys **MOP** and then **3D**)

## Manual operation and setup

### 15.3 Spindle speed S, feed rate F and miscellaneous function M

#### 15.3 Spindle speed S, feed rate F and miscellaneous function M

##### Application


In the Manual Operation and El. Handwheel operating modes, you can enter the spindle speed S, feed rate F and the miscellaneous functions M with soft keys. The miscellaneous functions are described in Chapter 7 "Programming: Miscellaneous functions."



The machine tool builder determines which miscellaneous functions M are available on your control and what effects they have.

##### Entering values

###### Spindle speed S, miscellaneous function M



- ▶ To enter the spindle speed, press the S soft key

###### SPINDLE SPEED S=



- ▶ Enter **1000** (spindle speed) and confirm your entry with the machine START button.

The spindle speed S with the entered rpm is started with a miscellaneous function M. Proceed in the same way to enter a miscellaneous function M.

###### Feed rate F

After entering a feed rate F, you must confirm your entry with the **ENT** key instead of the machine START button.

The following is valid for feed rate F:

- If you enter F=0, then the lowest feed rate from the machine parameter **manualFeed** is effective.
- If the feed rate entered exceeds the value defined in the machine parameter **maxFeed**, then the parameter value is effective.
- F is not lost during a power interruption

## Spindle speed S, feed rate F and miscellaneous function M 15.3

### Adjusting spindle speed and feed rate

With the override knobs you can vary the spindle speed S and feed rate F from 0% to 150% of the set value.



The override knob for spindle speed is only functional on machines with infinitely variable spindle drive.



### Activating feed-rate limitation



The feed-rate limit depends on the machine. Refer to your machine manual.


When the F LIMITED soft key is set to ON, the TNC limits the maximum permissible axis speed to the safely limited speed specified by the machine manufacturer.



- ▶ Select the **Manual Operation** mode



- ▶ Scroll to the last soft-key row



- ▶ Switch on/off feed rate limit

## Manual operation and setup

### 15.4 Functional safety FS (option)

#### 15.4 Functional safety FS (option)

##### Miscellaneous

Every machine tool operator is exposed to certain risks. Although protective devices can prevent access to dangerous points, the operator must also be able to work on the machine without this protection (e.g. protective door opened). Several guidelines and regulations to minimize these risks have been developed within the last few years.

The HEIDENHAIN safety concept integrated in the TNC controls complies with **Performance Level d** as per EN 13849-1 and SIL 2 as per IEC 61508, features safety-related modes of operation in accordance with EN 12417, and assures extensive operator protection.

The basis of the HEIDENHAIN safety concept is the dual-channel processor structure, which consists of the main computer (MC) and one or more drive controller modules (CC= control computing unit). All monitoring mechanisms are designed redundantly in the control systems. Safety-relevant system data are subject to a mutual cyclic data comparison. Safety-relevant errors always lead to safe stopping of all drives through defined stop reactions.

Defined safety functions are triggered and safe operating statuses are achieved via safety-relevant inputs and outputs (dual-channel implementation), which have an influence on the system in all operating modes.

In this chapter you will find explanations of the functions that are additionally available on a TNC with functional safety.



You machine tool builder adapts the HEIDENHAIN safety concept to your machine. Refer to your machine manual.

## Explanation of terms

### Safety-related operating modes

Description	Brief description
SOM_1	Safe operating mode 1: automatic operation, production mode
SOM_2	Safe operating mode 2: set-up mode
SOM_3	Safe operating mode 3: manual intervention; only for qualified operators
SOM_4	Safe operating mode 4: Advanced manual intervention, process monitoring

### Safety functions

Description	Brief description
SS0, SS1, SS1F, SS2	Safe stop: safe stopping of all drives using different methods
STO	Safe torque off: energy supply to the motor is interrupted. Provides protection against unexpected start of the drives
SOS	Safe operating stop. Provides protection against unexpected start of the drives
SLS	Safely-limited speed. Prevents the drives from exceeding the specified speed limits when the protective door is opened

## Manual operation and setup

### 15.4 Functional safety FS (option)

#### Checking the axis positions



This function must be adapted to the TNC by your machine manufacturer. Refer to your machine manual.

After switch-on the TNC checks whether the position of an axis matches the position directly after switch-off. If a deviation occurs this axis is displayed red in the position display. Axes that are marked red can no longer be moved while the door is opened.

In such cases you must approach a test position for the axes in question. Proceed as follows:

- ▶ Select the **Manual Operation** mode
- ▶ Execute the approach with NC Start to move the axes in the sequence shown
- ▶ When the test position has been reached, the TNC asks whether the position was approached correctly: Confirm with the OK soft key if the TNC approached the test position correctly, and with END if the TNC approached the position incorrectly.
- ▶ If you confirmed with OK, you must confirm the correctness of the test position again with the permissive button on the machine operating panel
- ▶ Repeat this procedure for all axes that you want to move to the test position



#### **Danger of collision!**

Approach the test positions in such a way that no collision between tool and the workpiece or the clamping devices can occur. If necessary, pre-position the axes manually.



The location of the test position is specified by your machine tool builder. Refer to your machine manual.



### Activating feed-rate limitation


When the F LIMITED soft key is set to ON, the TNC limits the maximum permissible axis speeds to the specified, safely limited speed.



- ▶ Select the **Manual Operation** mode



- ▶ Scroll to the last soft-key row



- ▶ Switch on/off feed rate limit

## Manual operation and setup





### 15.4 Functional safety FS (option)

#### Additional status displays

On a control with functional safety FS, the general status display contains additional information about the current status of safety functions. The TNC shows this information as operating statuses of the status displays **T**, **S** and **F**

Status display	Brief description
<b>STO</b>	Energy supply to the spindle or a feed drive is interrupted.
<b>SLS</b>	Safely-limited speed: A safely limited speed is active.
<b>SOS</b>	Safe operating stop: Safe operating stop is active.
<b>STO</b>	Safe torque off: Energy supply to the motor is interrupted.

The TNC shows the active safety-related mode of operation with an icon in the header to the right of the operating mode text:

Button	Safety-related operating mode
	<b>SOM_1</b> operating mode active
	<b>SOM_2</b> mode active
	<b>SOM_3</b> mode active
	<b>SOM_4</b> mode active

## 15.5 Datum setting without a 3-D touch probe

### Note



Setting the datum with a 3-D touch probe: See "Datum Setting with 3-D Touch Probe", page 498.

You fix a datum by setting the TNC position display to the coordinates of a known position on the workpiece.

### Preparation

- ▶ Clamp and align the workpiece
- ▶ Insert the zero tool with known radius into the spindle
- ▶ Ensure that the TNC is showing the actual position values

### Workpiece presetting with axis keys



#### Protective measure

If the workpiece surface must not be scratched, you can lay a metal shim of known thickness  $d$  on it. Then enter a tool axis datum value that is larger than the desired datum by the value  $d$ .



- ▶ Select the **MANUAL OPERATION** mode



- ▶ Move the tool slowly until it touches (scratches) the workpiece surface




- ▶ Select the axis

#### DATUM SETTING Z=



- ▶ Zero tool, spindle axis: Set the display to a known workpiece position (here, 0) or enter the thickness  $d$  of the shim. In the machining plane: Take the tool radius into account



Repeat the process for the remaining axes.

If you are using a preset tool, set the display of the tool axis to the length  $L$  of the tool or enter the sum  $Z=L+d$



The TNC automatically saves the datum set with the axis keys in line 0 of the preset table.

## Manual operation and setup

### 15.5 Datum setting without a 3-D touch probe

#### Datum management with the preset table




You should definitely use the preset table if:

- Your machine is equipped with rotary axes (tilting table or swivel head) and you work with the function for tilting the working plane
- Your machine is equipped with a spindle-head changing system
- Up to now you have been working with older TNC controls with REF-based datum tables
- You wish to machine identical workpieces that are differently aligned

The preset table can contain any number of lines (datums). To optimize the file size and the processing speed, you should use only as many lines as you need for datum management.

For safety reasons, new lines can be inserted only at the end of the preset table.



### Saving the datums in the preset table

The preset table has the name **PRESET.PR**, and is saved in the directory **TNC:\table**. **PRESET.PR** is editable in the **Manual Operation** and **El. Handwheel** modes only if the **CHANGE PRESET** soft key was pressed.

It is permitted to copy the preset table into another directory (for data backup). Lines that were written by your machine tool builder are also always write-protected in the copied tables. You therefore cannot edit them.

Never change the number of lines in the copied tables! That could cause problems when you want to reactivate the table.

To activate the preset table copied to another directory you have to copy it back to the directory **TNC:\table\**.

There are several methods for saving datums and/or basic rotations in the preset table:

- Through probing cycles in the **Manual Operation** or **El. Handwheel** modes (see Chapter 14)
- Through the probing cycles 400 to 402 and 410 to 419 in automatic mode (see User's Manual, Cycles, Chapters 14 and 15)
- Manual entry (see description below)



Basic rotations from the preset table rotate the coordinate system about the preset, which is shown in the same line as the basic rotation.

Remember to ensure that the position of the tilting axes matches the corresponding values of the 3-D ROT menu when setting the datum. Therefore:

- If the "Tilt working plane" function is not active, the position display for the rotary axes must be = 0° (zero the rotary axes if necessary).
- If the "Tilt working plane" function is active, the position displays for the rotary axes must match the angles entered in the 3-D ROT menu.










The line 0 in the preset table is write protected. In line 0, the TNC always saves the datum that you most recently set manually via the axis keys or via soft key. If the datum set manually is active, the TNC displays the text **PR MAN(0)** in the status display.




## Manual operation and setup

### 15.5 Datum setting without a 3-D touch probe

#### Manually saving the datums in the preset table

In order to set datums in the preset table, proceed as follows:

-  ▶ Select the **MANUAL OPERATION** mode
-  ▶ Move the tool slowly until it touches (scratches) the workpiece surface, or position the measuring dial correspondingly
-  ▶
-  ▶
-  ▶ Display the preset table: The TNC opens the preset table and sets the cursor to the active table row
-  ▶ Select functions for entering the presets: The TNC displays the available possibilities for entry in the soft-key row. See the table below for a description of the entry possibilities
-  ▶ Select the line in the preset table that you want to change (the line number is the preset number)
-  ▶ If needed, select the column (axis) in the preset table that you want to change
-  ▶ Use the soft keys to select one of the available entry possibilities (see the following table)

Function	Soft key
Directly transfer the actual position of the tool (the measuring dial) as the new datum: This function only saves the datum in the axis which is currently highlighted	
Assign any value to the actual position of the tool (the measuring dial): This function only saves the datum in the axis which is currently highlighted. Enter the desired value in the pop-up window	
Incrementally shift a datum already stored in the table: This function only saves the datum in the axis which is currently highlighted. Enter the desired corrective value with the correct sign in the pop-up window. If inch display is active: Enter the value in inches, and the TNC will internally convert the entered values to mm	

**Function****Soft key**

Directly enter the new datum without calculation of the kinematics (axis-specific). Only use this function if your machine has a rotary table, and you want to set the datum to the center of the rotary table by entering 0. This function only saves the datum in the axis which is currently highlighted. Enter the desired value in the pop-up window. If inch display is active: Enter the value in inches, and the TNC will internally convert the entered values to mm



Select the BASIC TRANSFORMATION/AXIS OFFSET view. The BASIC TRANSFORMATION view shows the X, Y and Z columns. Depending on the machine, the SPA, SPB and SPC columns are displayed additionally. Here, the TNC saves the basic rotation (for the Z tool axis, the TNC uses the SPC column). The OFFSET view shows the offset values for the preset
















Write the currently active datum to a selectable line in the table: This function saves the datum in all axes, and then activates the appropriate row in the table automatically. If inch display is active: Enter the value in inches, and the TNC will internally convert the entered values to mm



## Manual operation and setup

### 15.5 Datum setting without a 3-D touch probe

#### Editing the preset table

Editing function in table mode	Soft key
Select beginning of table	
Select end of table	
Select previous page in table	
Select next page in table	
Select the functions for preset entry	
Display the "Basic Transformation/Axis Offset" selection	
Activate the datum of the selected line of the preset table	
Add the entered number of lines to the end of the table (2nd soft-key row)	
Copy the highlighted field (2nd soft-key row)	
Insert the copied field (2nd soft-key row)	
Reset the selected line: The TNC enters - in all columns (2nd soft-key row)	
Insert a single line at the end of the table (2nd soft-key row)	
Delete a single line at the end of the table (2nd soft-key row)	



### Activating a datum from the preset table in the Manual Operation mode



When activating a datum from the preset table, the TNC resets the active datum shift, mirroring, rotation and scaling factor.

However, a coordinate transformation that was programmed in Cycle 19 Tilted Working Plane, or through the PLANE function, remains active.



- ▶ Select the **MANUAL OPERATION** mode




- ▶ Display the preset table



- ▶ Select the datum number you want to activate, or



- ▶ With the GOTO key, select the datum number that you want to activate. Confirm with the ENT key



- ▶ Activating the datum



- ▶ Confirm activation of the datum. The TNC sets the display and—if defined—the basic rotation



- ▶ Exit the preset table

### Activating a datum from the preset table in an NC program

To activate datums from the preset table during program run, use Cycle 247. In Cycle 247 you define the number of the datum that you want to activate (see User's Manual, Cycles, Cycle 247 SET DATUM).

## Manual operation and setup

### 15.6 Using 3-D touch probes

#### 15.6 Using 3-D touch probes

##### Overview










The following touch probe cycles are available in the Manual Operation mode:



HEIDENHAIN only gives warranty for the function of the probing cycles if HEIDENHAIN touch probes are used.



The TNC must be specially prepared by the machine tool builder for the use of a 3-D touch probe. Refer to your machine manual.

Function	Soft key	Page
Calibrating the effective length		491
Calibrating the effective radius	 	492
Measuring a basic rotation using a line	 PROBING ROT	496
Setting a datum in any axis	 PROBING POS	498
Setting a corner as datum	 PROBING P	499
Setting a circle center as datum	 PROBING CC	501
Setting the centerline as datum	 PROBING CL	503
Touch probe system data management	 TCH PROBE TABLE	See User's Manual for Cycles



You can also use all manual touch probe cycles, except the corner probing cycle, in Turning mode. Observe that in Turning mode all measured data in the X coordinate are calculated and displayed as diameter values.

To use the touch probe in Turning mode you should separately calibrate the touch probe in Turning mode. Because the basic setting of the turning spindle in Milling mode and Turning mode may deviate, you should calibrate the touch probe without center offset. You can create additional tool data for this purpose, e.g. as an indexed tool.







For more information about the touch probe table, refer to the User's Manual for Cycle Programming.

## Manual operation and setup

### 15.6 Using 3-D touch probes

#### Functions in touch probe cycles

Soft keys that are used to select the probing direction or a probing routine are displayed in the manual touch probe cycles. The soft keys displayed vary depending on the respective cycle:

Soft key	Function
	Select the probing direction
	Capture the actual position
	Probe hole (inside circle) automatically
	Probe stud (outside circle) automatically

#### Automatic probing routine for holes and studs



If you use a function for probing a circle automatically, the TNC automatically positions the touch probe to the respective touch points. Ensure that the positions can be approached without collision.

If you use a probing routine for probing a hole or a stud automatically, the TNC opens a form with the required input fields.

#### Input fields in the Measure stud and Measure hole forms

Input field	Function
<b>Stud diameter?</b> or <b>Hole diameter?</b>	Diameter of probe contact (optional for holes)
Safety clearance?	Distance to the probe contact in the plane
<b>Incr. clearance height?</b>	Positioning of touch probe in spindle axis direction (starting from the current position)
<b>Starting angle?</b>	Angle for the first probing operation ( $0^\circ$ = Positive direction of principal axis, i.e. in X+ for spindle axis Z). All other probe angles result from the number of touch points.
<b>Number of touch points?</b>	Number of probing operations (3 to 8)
<b>Angular length?</b>	Probing a full circle ( $360^\circ$ ) or a circle segment (angular length $< 360^\circ$ )

Position the touch probe approximately in the center of the hole (inside circle) or near the first touch point on the stud (outside circle), and select the soft key for the first probing direction. Once you press the machine START button to start the touch probe cycle, the TNC automatically performs all repositioning movements and probing operations.

The TNC positions the touch probe to the individual touch points, taking the safety clearance into account. If a clearance height has been defined, the TNC positions the touch probe to clearance height in the spindle axis beforehand.

The TNC approaches the position at the feed rate **FMAX** defined in the touch probe table. The defined probing feed rate **F** is used for the actual probing operation.



Before starting the automatic probing routine, you need to reposition the touch probe near the first touch point. Offset the touch probe by approximately the safety clearance (value from touch probe table + value from input form) opposite to the probing direction.

For an inside circle with a large diameter, the TNC can also reposition the touch probe on a circular arc at the positioning feed rate FMAX. This requires that you enter a safety clearance for repositioning and the hole diameter in the input form. Position the touch probe inside the hole at a position that is offset by approximately the safety clearance from the wall. For repositioning, keep in mind the starting angle for the first probing operation (with an angle of 0°, the TNC probes in the positive direction of the principal axis).

## Manual operation and setup


### 15.6 Using 3-D touch probes

#### Selecting touch probe cycles

- ▶ Select the Manual Operation or El. Handwheel mode of operation



- ▶ Select the touch probe functions by pressing the **TOUCH PROBE** soft key. The TNC displays additional soft keys (see overview table).



- ▶ Select the touch probe cycle by pressing the appropriate soft key, for example **PROBING POS**, for the TNC to display the associated menu



When you select a manual probing function, the TNC opens a form displaying all data required. The content of the forms varies depending on the respective function.

You can also enter values in some of the fields. Use the arrow keys to move to the desired input field. You can position the cursor only in fields that can be edited. Fields that cannot be edited appear dimmed.

## Recording measured values from the touch-probe cycles



The TNC must be specially prepared by the machine tool builder for use of this function. Refer to your machine manual.

After executing any selected touch probe cycle, the TNC displays the soft key **WRITE LOG TO FILE**. If you press this soft key, the TNC will record the current values determined in the active touch probe cycle.

If you store the measuring results, the TNC creates the text file TCHPRMAN.TXT. Unless you define a specific path in the machine parameter **fn16DefaultPath**, the TNC will store the TCHPRMAN.TXT file in the main directory **TNC:\**.



When you press the **WRITE LOG TO FILE** soft key, the TCHPRMAN.TXT file must not be active in the **Programming** mode of operation. The TNC will otherwise display an error message.

The TNC stores the measured data in the TCHPRMAN.TXT file only. If you execute several touch probe cycles in succession and want to store the resulting measured data, you must make a backup of the contents stored in TCHPRMAN.TXT between the individual cycles by copying or renaming the file.

Format and content of the TCHPRMAN.TXT file are preset by the machine tool builder.

## Manual operation and setup

### 15.6 Using 3-D touch probes

#### Writing measured values from the touch probe cycles in a datum table



Use this function if you want to save measured values in the workpiece coordinate system. If you want to save measured values in the machine-based coordinate system (REF coordinates), press the **ENTER IN PRESET TABLE soft key**. See "Writing measured values from the touch probe cycles in the preset table", page 489.

With the **ENTER IN DATUM TABLE** soft key, the TNC can write the values measured during a touch probe cycle in a datum table:

- ▶ Select any probe function
- ▶ Enter the desired coordinates of the datum in the appropriate input boxes (depends on the touch probe cycle being run)
- ▶ Enter the datum number in the **Number in table=** input box
- ▶ Press the **ENTER IN DATUM TABLE** soft key. The TNC saves the datum in the indicated datum table under the entered number



## Writing measured values from the touch probe cycles in the preset table



Use this function if you want to save measured values in the machine-based coordinate system (REF coordinates). If you want to save measured values in the workpiece coordinate system, use the **ENTER IN DATUM TABLE soft key**. See "Writing measured values from the touch probe cycles in a datum table", page 488.

With the **ENTER IN PRESET TABLE** soft key, the TNC can write the values measured during a probe cycle in the preset table. The measured values are then stored referenced to the machine-based coordinate system (REF coordinates). The preset table has the name PRESET.PR, and is saved in the directory TNC:\table\.

- ▶ Select any probe function
- ▶ Enter the desired coordinates of the datum in the appropriate input boxes (depends on the touch probe cycle being run)
- ▶ Enter the preset number in the **Number in table:** input box
- ▶ Press the **ENTER IN PRESET TABLE** soft key. The TNC saves the datum in the preset table under the entered number

## Manual operation and setup

### 15.7 Calibrating a 3-D touch trigger probe

### 15.7 Calibrating a 3-D touch trigger probe

#### Introduction

In order to precisely specify the actual trigger point of a 3-D touch probe, you must calibrate the touch probe, otherwise the TNC cannot provide precise measuring results.



Always calibrate a touch probe in the following cases:

- Commissioning
- Stylus breakage
- Stylus exchange
- Change in the probe feed rate
- Irregularities caused, for example, when the machine heats up
- Change of active tool axis

When you press the OK soft key after calibration, the calibration values are applied to the active touch probe. The updated tool data become effective immediately, and a new tool call is not necessary.

During calibration, the TNC finds the "effective" length of the stylus and the "effective" radius of the ball tip. To calibrate the 3-D touch probe, clamp a ring gauge or a stud of known height and known radius to the machine table.





The TNC provides calibration cycles for calibrating the length and the radius:

- ▶ Press the **TOUCH PROBE** soft key



- ▶ Display the calibration cycles: Press CALIBRATE TS
- ▶ Select the calibration cycle

#### Calibration cycles of the TNC

Soft key	Function	Page
	Calibrating the length	491
	Measure the radius and the center offset using a calibration ring	492
	Measure the radius and the center offset using a stud or a calibration pin	492
	Measure the radius and the center offset using a calibration sphere	492

## Calibrating the effective length




HEIDENHAIN only gives warranty for the function of the probing cycles if HEIDENHAIN touch probes are used.




The effective length of the touch probe is always referenced to the tool datum. The machine tool builder usually defines the spindle tip as the tool datum.

- ▶ Set the datum in the spindle axis such that for the machine tool table  $Z=0$ .



- ▶ Select the calibration function for the touch probe length: Press the **CAL. L** soft key. The TNC opens a menu window with input fields
- ▶ Datum for length: Enter the height of the ring gauge
- ▶ New cal. spindle angle: Spindle angle that is used for the calibration. The TNC uses CAL\_ANG from the touch probe table as a default value. If you change the value, the TNC saves the value to the touch probe table during calibration
- ▶ Move the touch probe to a position just above the ring gauge
- ▶ To change the traverse direction (if necessary), press a soft key or an arrow key
- ▶ To probe the upper surface of the ring gauge, press the machine START button
- ▶ Check the results (change the values if required)
- ▶ Press the **OK** soft key for the values to take effect
- ▶ Press the **END** soft key to terminate the calibrating function



## Manual operation and setup

### 15.7 Calibrating a 3-D touch trigger probe

#### Calibrating the effective radius and compensating center misalignment




HEIDENHAIN only gives warranty for the function of the probing cycles if HEIDENHAIN touch probes are used.



The center offset can be determined only with a suitable touch probe.

If you want to calibrate using the outside of an object, you need to preposition the touch probe above the center of the calibration sphere or calibration pin. Ensure that the touch points can be approached without collision.



When calibrating the ball tip radius, the TNC executes an automatic probing routine. During the first probing cycle, the TNC determines the center of the calibration ring or stud (coarse measurement) and positions the touch probe in the center. Then the ball tip radius is determined during the actual calibration process (fine measurement). If the touch probe allows probing from opposite orientations, the center offset is determined during another cycle.

The characteristic of whether and how your touch probe can be oriented is already defined in HEIDENHAIN touch probes. Other touch probes are configured by the machine tool builder.

After the touch probe is inserted, it normally needs to be aligned exactly with the spindle axis. The calibration function can determine the offset between touch-probe axis and spindle axis by probing from opposite orientations (rotation by 180°) and can compute the compensation.

The calibration routine varies depending on how your touch probe can be oriented:

- No orientation possible or orientation possible in only one direction: The TNC executes one approximate and one fine measurement and determines the effective ball tip radius (column R in tool.t)
- Orientation possible in two directions (e.g. HEIDENHAIN touch probes with cable): The TNC executes one approximate and one fine measurement, rotates the touch probe by 180° and then executes four more probing operations. The center offset (CAL\_OF in tchprobe.tp) is determined in addition to the radius by probing from opposite orientations.
- Any orientation possible (e.g. HEIDENHAIN infrared touch probes): For probing routine, see "orientation possible in two directions."

Proceed as follows for manual calibration using a calibration ring:

- ▶ In the Manual Operation mode, position the ball tip inside the bore of the ring gauge



- ▶ Select the calibration function: Press the **CAL. R** soft key
- ▶ Enter the diameter of the ring gauge
- ▶ Enter the safety clearance
- ▶ New cal. spindle angle: Spindle angle that is used for the calibration. The TNC uses CAL\_ANG from the touch probe table as a default value. If you change the value, the TNC saves the value to the touch probe table during calibration
- ▶ Start the probing procedure: Press the machine START button. The 3-D touch probe probes all required touch points in an automatic probing routine and calculates the effective ball-tip radius. If probing from opposite orientations is possible, the TNC calculates the center offset
- ▶ Check the results (change the values if required)
- ▶ Press the **OK** soft key for the values to take effect
- ▶ Press the **END** soft key to terminate the calibrating function




In order to be able to determine the ball-tip center misalignment, the TNC needs to be specially prepared by the machine manufacturer. Refer to your machine manual.

## Manual operation and setup

### 15.7 Calibrating a 3-D touch trigger probe

Proceed as follows for manual calibration with a stud or calibration pin:

- ▶ In the Manual Operation mode, position the ball tip above the center of the calibration pin



- ▶ Select the calibration function: Press the **CAL. R** soft key
- ▶ Enter the diameter of the stud
- ▶ Enter the safety clearance
- ▶ New cal. spindle angle: Spindle angle that is used for the calibration. The TNC uses CAL\_ANG from the touch probe table as a default value. If you change the value, the TNC saves the value to the touch probe table during calibration
- ▶ Start the probing procedure: Press the machine START button. The 3-D touch probe probes all required touch points in an automatic probing routine and calculates the effective ball-tip radius. If probing from opposite orientations is possible, the TNC calculates the center offset
- ▶ Check the results (change the values if required)
- ▶ Press the **OK** soft key for the values to take effect
- ▶ Press the **END** soft key to terminate the calibrating function



In order to be able to determine the ball-tip center misalignment, the TNC needs to be specially prepared by the machine manufacturer. Refer to your machine manual.

### Displaying calibration values

The TNC saves the effective length and effective radius of the touch probe in the tool table. The TNC saves the ball-tip center offset of the touch probe in the touch-probe table in the **CAL\_OF1** (principal axis) and **CAL\_OF2** (secondary axis) columns. You can display the values on the screen by pressing the TOUCH PROBE TABLE soft key.



Make sure that you have activated the correct tool number before using the touch probe, regardless of whether you wish to run the touch probe cycle in automatic mode or manual mode.



For more information about the touch probe table, refer to the User's Manual for Cycle Programming.



## 15.8 Compensating workpiece misalignment with 3-D touch probe

### Introduction




HEIDENHAIN only gives warranty for the function of the probing cycles if HEIDENHAIN touch probes are used.

The TNC electronically compensates workpiece misalignment by computing a "basic rotation."

For this purpose, the TNC sets the rotation angle to the desired angle with respect to the reference axis in the working plane. See figure at right.

The TNC saves the basic rotation, depending on the tool axis, in the columns SPA, SPB or SPC of the preset table.

To identify the basic rotation, probe two points on the side of the workpiece. The sequence in which you probe the points influences the calculated angle. The measured angle goes from the first to the second probing point. You can also identify the basic rotation by holes or studs.



Select the probe direction perpendicular to the angle reference axis when measuring workpiece misalignment.

To ensure that the basic rotation is calculated correctly during program run, program both coordinates of the working plane in the first positioning block.


You can also use a basic rotation in conjunction with the PLANE function. In this case, first activate the basic rotation and then the PLANE function.

You can also activate a basic rotation without probing a workpiece. For this purpose enter a value in the basic rotation menu and press the **Set basic rotation** soft key.

## Manual operation and setup

### 15.8 Compensating workpiece misalignment with 3-D touch probe

#### Identifying basic rotation



- ▶ Select the probe function by pressing the **PROBING ROT** soft key
- ▶ Position the touch probe at a position near the first touch point
- ▶ Select a probe direction perpendicular to the angle reference axis: Select the axis and direction using an arrow key
- ▶ Start the probing procedure: Press the machine START button
- ▶ Position the touch probe at a position near the second touch point
- ▶ To probe the workpiece, press the machine START button. The TNC determines the basic rotation and displays the angle after the dialog **Rotation angle**
- ▶ Activate basic rotation: Press the **Set basic rotation** soft key
- ▶ Terminate the probe function by pressing the END soft key

#### Saving a basic rotation in the preset table

- ▶ After the probing process, enter the preset number in which the TNC is to save the active basic rotation in the **Number in table:** input box
- ▶ Press the **BASIC ROT. IN presettab.** soft key to save the basic rotation in the preset table


#### Compensation of workpiece misalignment by rotating the table

- ▶ To compensate the identified misalignment by a rotary table position, press the **ALIGN ROTARY TABLE** soft key after the probing process



Position all axes to avoid a collision before table rotation. The TNC outputs an additional warning before table rotation.

- ▶ If you want to set the datum in the rotary table axis, press the **SET TABLE ROTATION** soft key.
- ▶ You can also save the misalignment of the rotary table in any line of the Preset table. Enter the line number and press the **TABLEROT IN PRESETTAB.** soft key. The TNC saves the angle in the offset column of the rotary table, e.g. in the C\_OFFS column with a C axis. If necessary, the view in the Preset table has to be changed with the **BASIS-TRANSFORM./OFFSET** soft key to display this column.






## Compensating workpiece misalignment with 3-D touch probe 15.8

### Displaying a basic rotation

When you select the **PROBING ROT** function, the TNC displays the active angle of basic rotation in the dialog **Rotation angle**. The TNC also displays the rotation angle in the additional status display (**STATUS POS.**).

In the status display a symbol is shown for a basic rotation whenever the TNC is moving the axes according to a basic rotation.



### Canceling a basic rotation

- ▶ Select the probe function by pressing the **PROBING ROT** soft key
- ▶ Enter a rotation angle of zero and confirm with the **SET BASIC ROTATION** soft key
- ▶ Terminate the probe function by pressing the **END** soft key





## Manual operation and setup

### 15.9 Datum Setting with 3-D Touch Probe


#### 15.9 Datum Setting with 3-D Touch Probe

##### Overview


The following soft-key functions are available for setting the datum on an aligned workpiece:

Soft key	Function	Page
	Datum setting in any axis with	498
	Setting a corner as datum	499
	Setting a circle center as datum	501
	Center line as datum Setting the centerline as datum	503

##### Datum setting in any axis




- ▶ To select the touch probe function, press the **PROBING POS** soft key
- ▶ Move the touch probe to a position near the touch point
- ▶ Use the soft keys to select the probe axis and direction in which you want to set the datum, such as Z in direction Z–
- ▶ Start the probing procedure: Press the machine START button
- ▶ **Datum**: Enter the nominal coordinate and confirm your entry with the **Set datum** soft key, See "Writing measured values from the touch probe cycles in a datum table", page 488
- ▶ Exit the probing function: Press the **END** soft key.




HEIDENHAIN only gives warranty for the function of the probing cycles if HEIDENHAIN touch probes are used.

### Corner as datum



- ▶ Select the touch probe function: Press the **PROBING P** soft key
- ▶ Position the touch probe near the first touch point on the first workpiece edge
- ▶ Select the probe direction by soft key
- ▶ Start the probing procedure: Press the machine START button
- ▶ Position the touch probe near the second touch point on the same workpiece edge
- ▶ Start the probing procedure: Press the machine START button
- ▶ Position the touch probe near the first touch point on the second workpiece edge
- ▶ Select the probe direction by soft key
- ▶ Start the probing procedure: Press the machine START button
- ▶ Position the touch probe near the second touch point on the same workpiece edge
- ▶ Start the probing procedure: Press the machine START button
- ▶ **Datum:** Enter both datum coordinates into the menu window, and confirm your entry with the **Set datum** soft key, or See "Writing measured values from the touch probe cycles in the preset table", page 489)
- ▶ Exit the probing function: press the END soft key.



HEIDENHAIN only gives warranty for the function of the probing cycles if HEIDENHAIN touch probes are used.



You can identify the intersection of two straight lines by holes or studs and set this as the datum. For each straight line however, probing must only be with two identical touch probe functions (e.g. two holes).

**15.9 Datum Setting with 3-D Touch Probe**

The "Corner as datum" probing cycle identifies the angle and intersection of two straight lines. In addition to datum setting, the cycle can also activate a basic rotation. The TNC has two soft keys for you to decide which straight line you wish to use for this. The soft key **ROT 1** activates the angle of the first straight line as basic rotation and the soft key **ROT 2** the angle of the second straight line.

If you wish to activate the basic rotation in the cycle, you must always do this before datum setting. After you set a datum or write to a zero point or preset table the **ROT 1** and **ROT 2** soft keys are no longer displayed.

## Circle center as datum


With this function, you can set the datum at the center of bore holes, circular pockets, cylinders, studs, circular islands, etc.

### Inside circle:


The TNC probes the inside wall of a circle in all four coordinate axis directions.

For incomplete circles (circular arcs) you can choose the appropriate probing direction.

- ▶ Position the touch probe approximately in the center of the circle



- ▶ Select the touch probe function: Press the **PROBING CC** soft key
- ▶ Select the probing direction or press the soft key for the automatic probing routine
- ▶ Probing: Press the machine START button. The touch probe probes the inside wall of the circle in the selected direction. If you are not using the automatic probing routine, you need to repeat this procedure. After the third probing operation, you can have the TNC calculate the center (four touch points are recommended)
- ▶ Terminate the probing procedure and switch to the evaluation menu: Press the **EVALUATE** soft key
- ▶ **Datum:** In the menu window, enter both coordinates of the circle center, confirm with the **SET DATUM** soft key, or write the values to a table (See "Writing measured values from the touch probe cycles in a datum table", page 488, or See "Writing measured values from the touch probe cycles in the preset table", page 489)
- ▶ Terminate the probing function: Press the **END** soft key



The TNC needs only three touch points to calculate outside or inside circles, e.g. for circle segments. More precise results are obtained if you measure circles using four touch points, however. You should always preposition the touch probe in the center, or as close to the center as possible.

## Manual operation and setup

### 15.9 Datum Setting with 3-D Touch Probe

#### Outside circle:


- ▶ Position the touch probe at a position near the first touch point outside of the circle
- ▶ Select the probe direction by soft key
- ▶ Probing: Press the machine START button. If you are not using the automatic probing routine, you need to repeat this procedure. After the third probing operation, you can have the TNC calculate the center (four touch points are recommended).
- ▶ Terminate the probing procedure and switch to the evaluation menu: Press the EVALUATE soft key
- ▶ **Datum:** Enter the coordinates of the datum and confirm your entry with the **SET DATUM** soft key, or write the values to a table (See "Writing measured values from the touch probe cycles in a datum table", page 488, or See "Writing measured values from the touch probe cycles in the preset table", page 489)
- ▶ To terminate the probe function, press the **END** soft key

After the probing procedure is completed, the TNC displays the current coordinates of the circle center and the circle radius PR.

#### Setting the datum using multiple holes/cylindrical studs

A second soft-key row provides a soft key for using multiple holes or cylindrical studs to set the datum. You can set the intersection of two or more elements as datum.


Select the probing function for the intersection of holes/cylindrical studs:



- ▶ Select the touch probe function: Press the **PROBING CC** soft key




- ▶ Hole is to be probed automatically: Define by soft key



- ▶ Circular stud is to be probed automatically: Define by soft key

Preposition the touch probe approximately in the center of the hole or near the first touch point of the circular stud. After you have pressed the NC Start key, the TNC automatically probes the points on the circle.

Move the touch probe to the next hole, repeat the probing operation and have the TNC repeat the probing procedure until all the holes have been probed to set the datum.




Setting the datum in the intersection of multiple holes:



- ▶ Preposition the touch probe approximately in the center of the hole
- ▶ Hole is to be probed automatically: Define by soft key
- ▶ Probing: Press the machine START button. The touch probe probes the circle automatically.
- ▶ Repeat the probing procedure for the remaining elements
- ▶ Terminate the probing procedure and switch to the evaluation menu: Press the **EVALUATE** soft key
- ▶ **Datum:** In the menu window, enter both coordinates of the circle center, confirm with the **SET DATUM** soft key, or write the values to a table (See "Writing measured values from the touch probe cycles in a datum table", page 488, or See "Writing measured values from the touch probe cycles in the preset table", page 489)
- ▶ Terminate the probing function: Press the **END** soft key



### Setting a center line as datum



- ▶ Select the probe function: Press the **PROBING** soft key
- ▶ Position the touch probe at a position near the first touch point
- ▶ Select the probing direction by soft key
- ▶ Start the probing procedure: Press the NC Start button
- ▶ Position the touch probe at a position near the second touch point
- ▶ Start the probing procedure: Press the NC Start button
- ▶ **Datum:** Enter the coordinate of the datum in the menu window, confirm with the **SET DATUM** soft key, or write the value to a table (See "Writing measured values from the touch probe cycles in a datum table", page 488, or See "Writing measured values from the touch probe cycles in the preset table", page 489.
- ▶ Exit the probing function: Press the **END** key



After you have measured the second touch point, you can use the evaluation menu to change the direction of the centerline. You can choose by soft key whether the datum or zero point should be set in the reference axis, minor axis or tool axis. This can be necessary if, for example, you would like to save the measured position in the reference and minor axis.



## Manual operation and setup


### 15.9 Datum Setting with 3-D Touch Probe

#### Measuring workpieces with a 3-D touch probe

You can also use the touch probe in the Manual Operation and EI. Handwheel operating modes to make simple measurements on the workpiece. Numerous programmable probe cycles are available for complex measuring tasks (see User's Manual for Cycles, Chapter 16, Checking workpieces automatically). With a 3-D touch probe you can determine:

- Position coordinates, and from them,
- Dimensions and angles on the workpiece

#### Finding the coordinates of a position on an aligned workpiece



- ▶ Select the probing function: Press the **PROBING POS** soft key
- ▶ Move the touch probe to a position near the touch point
- ▶ Select the probe direction and axis of the coordinate. Use the corresponding soft keys for selection
- ▶ Start the probing procedure: Press the machine START button


The TNC shows the coordinates of the touch point as reference point.

#### Finding the coordinates of a corner in the working plane


Find the coordinates of the corner point: See "Corner as datum ", page 499. The TNC displays the coordinates of the probed corner as reference point.



### Measuring workpiece dimensions



- ▶ Select the probing function: Press the **PROBING POS** soft key
- ▶ Position the touch probe at a position near the first touch point A
- ▶ Select the probing direction by soft key
- ▶ Start the probing procedure: Press the machine START button
- ▶ If you need the current datum later, write down the value that appears in the Datum display
- ▶ Datum: Enter "0"
- ▶ Cancel the dialog: Press the **END** key
- ▶ Select the touch probe function again: Press the **PROBING POS** soft key
- ▶ Position the touch probe at a position near the second touch point B
- ▶ Select the probe direction with the soft keys: Same axis but from the opposite direction
- ▶ To probe the workpiece, press the machine START button



The value displayed as datum is the distance between the two points on the coordinate axis.

#### To return to the datum that was active before the length measurement:

- ▶ Select the probing function: Press the **PROBING POS** soft key
- ▶ Probe the first touch point again
- ▶ Set the datum to the value that you wrote down previously
- ▶ Cancel the dialog: Press the **END** key

### Measuring angles

You can use the 3-D touch probe to measure angles in the working plane. You can measure


- the angle between the angle reference axis and a workpiece edge, or
- the angle between two sides

The measured angle is displayed as a value of maximum 90°.


## Manual operation and setup

### 15.9 Datum Setting with 3-D Touch Probe

#### Finding the angle between the angle reference axis and a workpiece edge




- ▶ Select the probe function by pressing the **PROBING ROT** soft key
- ▶ Rotation angle: If you will need the current basic rotation later, write down the value that appears under Rotation angle
- ▶ Make a basic rotation with workpiece edge to be compared See "Compensating workpiece misalignment with 3-D touch probe ", page 495
- ▶ Press the **PROBING ROT** soft key to display the angle between the angle reference axis and the workpiece edge as the rotation angle
- ▶ Cancel the basic rotation, or restore the previous basic rotation
- ▶ Set the rotation angle to the value that you previously wrote down



#### Measuring the angle between two workpiece edges


- ▶ Select the probe function by pressing the **PROBING ROT** soft key
- ▶ Rotation angle: If you need the current basic rotation later, write down the displayed rotation angle
- ▶ Make a basic rotation with first workpiece edge See "Compensating workpiece misalignment with 3-D touch probe ", page 495
- ▶ Probe the second edge as for a basic rotation, but do not set the rotation angle to zero!
- ▶ Press the **PROBING ROT** soft key to display the angle PA between the workpiece edges as the rotation angle
- ▶ Cancel the basic rotation, or restore the previous basic rotation by setting the rotation angle to the value that you wrote down previously




## Using touch probe functions with mechanical probes or measuring dials

If you do not have an electronic 3-D touch probe on your machine, you can also use all the previously described manual touch probe functions (exception: calibration function) with mechanical probes or by simply touching the workpiece with the tool.


In place of the electronic signal generated automatically by a 3-D touch probe during probing, you can manually initiate the trigger signal for capturing the **probing position** by pressing a key. Proceed as follows:



- ▶ Select any touch probe function by soft key
- ▶ Move the mechanical probe to the first position to be captured by the TNC



- ▶ Confirm the position: Press the actual-position-capture soft key for the TNC to save the current position
- ▶ Move the mechanical probe to the next position to be captured by the TNC



- ▶ Confirm the position: Press the actual-position-capture soft key for the TNC to save the current position
- ▶ If required, move to additional positions and capture as described previously
- ▶ **Datum:** In the menu window, enter the coordinates of the new datum, confirm with the **SET DATUM** soft key, or write the values to a table (See "Writing measured values from the touch probe cycles in a datum table", page 488, or See "Writing measured values from the touch probe cycles in the preset table", page 489)
- ▶ Terminate the probing function: Press the **END** key

## Manual operation and setup

### 15.10 Tilting the working plane (software option 1)

#### 15.10 Tilting the working plane (software option 1)

##### Application, function




The functions for tilting the working plane are interfaced to the TNC and the machine tool by the machine tool builder. With some swivel heads and tilting tables, the machine tool builder determines whether the entered angles are interpreted as coordinates of the rotary axes or as angular components of a tilted plane. Refer to your machine manual.

The TNC supports the tilting functions on machine tools with swivel heads and/or tilting tables. Typical applications are, for example, oblique holes or contours in an oblique plane. The working plane is always tilted around the active datum. The program is written as usual in a main plane, such as the X/Y plane, but is executed in a plane that is tilted relative to the main plane.

There are three functions available for tilting the working plane:

- Manual tilting with the **3-D ROT** soft key in the Manual Operation mode and Electronic Handwheel mode, See "To activate manual tilting:", page 511
- Tilting under program control, Cycle **G80** in the part program (see User's Manual for Cycles, Cycle 19 WORKING PLANE)
- Tilting under program control, **PLANE** function in the part program See "The PLANE Function: Tilting the Working Plane (Software Option 1)", page 385

The TNC functions for "tilting the working plane" are coordinate transformations. The working plane is always perpendicular to the direction of the tool axis.



## Tilting the working plane (software option 1) 15.10

When tilting the working plane, the TNC differentiates between two machine types:

### ■ Machine with tilting table

- You must tilt the workpiece into the desired position for machining by positioning the tilting table, for example with an L block.
- The position of the transformed tool axis **does not change** in relation to the machine-based coordinate system. Thus if you rotate the table—and therefore the workpiece—by 90° for example, the coordinate system **does not rotate**. If you press the Z+ axis direction button in the Manual Operation mode, the tool moves in Z+ direction.
- In calculating the transformed coordinate system, the TNC considers only the mechanically influenced offsets of the particular tilting table (the so-called "translational" components).

### ■ Machine with swivel head

- You must bring the tool into the desired position for machining by positioning the swivel head, for example with an L block.
- The position of the transformed tool axis changes in relation to the machine-based coordinate system. Thus if you rotate the swivel head of your machine—and therefore the tool—in the B axis by 90° for example, the coordinate system rotates also. If you press the Z+ axis direction button in the Manual Operation mode, the tool moves in X+ direction of the machine-based coordinate system.
- In calculating the transformed coordinate system, the TNC considers both the mechanically influenced offsets of the particular swivel head (the so-called "translational" components) and offsets caused by tilting of the tool (3-D tool length compensation).



The TNC only supports tilting the working plane with spindle axis Z.

## Manual operation and setup

### 15.10 Tilting the working plane (software option 1)

#### Traversing reference points in tilted axes

The TNC automatically activates the tilted working plane if this function was enabled when the control was switched off. Then the TNC moves the axes in the tilted coordinate system when an axis-direction key is pressed. Position the tool in such a way that a collision is excluded during the subsequent crossing of the reference points. To scan the reference points you have to deactivate the "Tilt Working Plane" function, See "To activate manual tilting:", page 511.



#### **Danger of collision!**

Be sure that the function for tilting the working plane is active in the Manual Operation mode and that the angle values entered in the menu match the actual angles of the tilted axis.

Deactivate the "Tilt Working Plane" function before you cross the reference points. Take care that there is no collision. Retract the tool from the current position first, if necessary.

#### Position display in a tilted system


The positions displayed in the status window (**ACTL.** and **NOML.**) are referenced to the tilted coordinate system.

#### Limitations on working with the tilting function

- The probing function for basic rotation is not available if you have activated the working plane function in the Manual Operation mode.
- The actual-position-capture function is not allowed if the tilted working plane function is active.
- PLC positioning (determined by the machine tool builder) is not possible.

## Tilting the working plane (software option 1) 15.10

### To activate manual tilting:



- ▶ To select manual tilting, Press the 3-D ROT soft key



- ▶ Use the arrow keys to move the highlight to the **Manual Operation** menu item



- ▶ To activate manual tilting, press the Active soft key




- ▶ Use the arrow keys to position the highlight on the desired rotary axis

- ▶ Enter the tilt angle



- ▶ To conclude entry, press the END key



To reset the tilting function, set the desired operating modes in the menu **Tilt working plane** to inactive.

If the Working Plane function is active and the TNC moves the machine axes in accordance with the tilted axes, the status display shows the symbol .

If you activate the "Tilt working plane" function for the Program Run operating mode, the tilt angle entered in the menu becomes active in the first block of the part program. If you use Cycle **G80** or the **PLANE** function in the part program, the angle values defined there are in effect. Angle values entered in the menu will be overwritten.

## Manual operation and setup

### 15.10 Tilting the working plane (software option 1)


#### Setting the current tool-axis direction as the active machining direction



This function must be enabled by your machine manufacturer. Refer to your machine manual.

In the Manual Operation and El. Handwheel modes of operation you can use this function to move the tool via the external direction keys or with the handwheel in the direction that the tool axis is currently pointed. Use this function if

- You want to retract the tool in the direction of the tool axis during program interrupt of a 5-axis machining program.
- You want to machine with an inclined tool using the handwheel or the external direction keys in the Manual Operation mode.



- ▶ To select manual tilting, Press the 3-D ROT soft key



- ▶ Use the arrow keys to move the highlight to the **Manual Operation** menu item




- ▶ To activate the current tool-axis direction as the active machining direction, press the Tool Axis soft key




- ▶ To conclude entry, press the END key

To reset the tilting function, set the **Manual Operation** menu item in the "Tilt working plane" menu to inactive.

When the **Move in tool-axis direction** function is active, this symbol appears in the status display: .



This function is even available when you interrupt program run and want to move the axes manually.





### Setting the datum in a tilted coordinate system

After you have positioned the rotary axes, set the datum in the same manner as for a non-tilted system. The behavior of the TNC during datum setting depends on the setting in machine parameter **CfgPresetSettings/chkTiltingAxes**:

- **chkTiltingAxes: On** With an active tilted working plane, the TNC checks during datum setting in the X, Y and Z axes whether the current coordinates of the rotary axes agree with the tilt angles that you defined (3-D ROT menu). If the tilted working plane function is not active, the TNC checks whether the rotary axes are at 0° (actual positions). If the positions do not agree, the TNC will display an error message.
- **chkTiltingAxes: Off** The TNC does not check whether the current coordinates of the rotary axes (actual positions) agree with the tilt angles that you defined.



#### **Danger of collision!**

Always set a reference point in all three reference axes.



# 16

**Positioning with  
Manual Data Input**

## Positioning with Manual Data Input

### 16.1 Programming and executing simple machining operations

#### 16.1 Programming and executing simple machining operations

The Positioning with Manual Data Input mode of operation is particularly convenient for simple machining operations or to pre-position the tool. It enables you to write a short program in HEIDENHAIN conversational programming or in ISO format, and execute it immediately. You can also call TNC cycles. The program is stored in the file \$MDI. In the Positioning with MDI mode of operation, the additional status displays can also be activated.

#### Positioning with manual data input (MDI)



##### Limitation

The following functions are not available in the MDI mode:

- FK free contour programming
- Program section repeats
- Subprogramming
- Path compensation
- The programming graphics
- Program call %
- The program-run graphics



- ▶ Select the Positioning with MDI mode of operation. Program the file \$MDI as you wish




- ▶ Starting program run: Machine START key

## Programming and executing simple machining operations 16.1

### Example 1

A hole with a depth of 20 mm is to be drilled into a single workpiece. After clamping and aligning the workpiece and setting the datum, you can program and execute the drilling operation in a few lines.

First you pre-position the tool with straight-line blocks to the hole center coordinates at a setup clearance of 5 mm above the workpiece surface. Then drill the hole with Cycle **G200**.



<b>%\$MDI G71 *</b>		
<b>N10 T1 G17 S2000 *</b>		Call the tool: tool axis Z, spindle speed 2000 rpm
<b>N20 G00 G40 G90 Z+200 *</b>		Retract the tool (rapid traverse)
<b>N30 X+50 Y+50 M3 *</b>		Move the tool at rapid traverse to a position above the hole. Spindle on.
<b>N40 G01 Z+2 F2000 *</b>		Position the tool to 2 mm above the hole
<b>N50 G200 DRILLING *</b>		Define Cycle G200 DRILLING
<b>Q200=2</b>	<b>;SET-UP CLEARANCE</b>	Set-up clearance of the tool above the hole
<b>Q201=-20</b>	<b>;DEPTH</b>	Hole depth (algebraic sign=working direction)
<b>Q206=250</b>	<b>;FEED RATE FOR PLNGNG</b>	Feed rate for drilling
<b>Q202=10</b>	<b>;PLUNGING DEPTH</b>	Depth of each infeed before retraction
<b>Q210=0</b>	<b>;DWELL TIME AT TOP</b>	Dwell time at top for chip release (in seconds)
<b>Q203=+0</b>	<b>;SURFACE COORDINATE</b>	Workpiece surface coordinate
<b>Q204=50</b>	<b>;2ND SET-UP CLEARANCE</b>	Position after the cycle, with respect to Q203
<b>Q211=0.5</b>	<b>;DWELL TIME AT BOTTOM</b>	Dwell time in seconds at the hole bottom
<b>N60 G79 *</b>		Call Cycle G200 PECKING
<b>N70 G00 G40 Z+200 M2 *</b>		Retract the tool
<b>N9999999 %\$MDI G71 *</b>		End of program

Straight-line function: See "Straight line in rapid traverse G00

Straight line with feed rate G01 F", page 210

DRILLING cycle: See User's Manual for Cycles, Cycle 200

DRILLING.

## Positioning with Manual Data Input

### 16.1 Programming and executing simple machining operations

#### Example 2: Correcting workpiece misalignment on machines with rotary tables

- ▶ For running a basic rotation with the 3-D touch probe, see "Touch Probe Cycles in the Manual Operation and El. Handwheel modes of operation," section "Compensating workpiece misalignment," in the Cycle Programming User's Manual.
- ▶ Write down the rotation angle and cancel the basic rotation



- ▶ Select operating mode: Positioning with MDI



- ▶ Select the axis of the rotary table, enter the rotation angle you wrote down previously and set the feed rate. For example. **L C+2.561 F50**



- ▶ Conclude entry



- ▶ Press the machine START button: The rotation of the table corrects the misalignment

### Protecting and erasing programs in \$MDI

The \$MDI file is generally intended for short programs that are only needed temporarily. Nevertheless, you can store a program, if necessary, by proceeding as described below:




- ▶ Select the Programming and Editing mode of operation



- ▶ To call the file manager, press the PGM MGT key (program management).



- ▶ Move the highlight to the \$MDI file



- ▶ Select "Copy file": Press the COPY soft key

#### DESTINATION FILE =

- ▶ Enter the name under which you want to save the current contents of the \$MDI file, e.g. **HOLE**.



- ▶ Copy the file



- ▶ Close the file manager: Press the END soft key

For more information: See "Copying a single file", page 113.





# 17

**Test run and  
program run**

## Test run and program run

### 17.1 Graphics

### 17.1 Graphics

#### Application

In the program run modes of operation as well as in the Test Run mode, the TNC graphically simulates the machining of the workpiece.

The TNC features the following views:

- Plan view
- Projection in three planes
- 3-D view



In the Test Run, you can also use the 3-D line graphics.

The TNC graphic depicts the workpiece as if it were being machined with a cylindrical end mill.

If a tool table is active, the TNC also considers the entries in the LCUTS, T-ANGLE and R2 columns.

With the model type 3-D **graphic setting** and in turning mode you also see the indexable inserts of the turning tools from **toolturn.trn**.

The TNC will not show a graphic if

- the current program has no valid workpiece blank definition
- no program is selected
- if the BLK FORM block was not yet executed during the workpiece blank definition with the aid of a subprogram



The simulation of programs with 5-axis machining or tilted machining might run at reduced speed. With the MOD menu **Graphic settings** you can decrease the **model quality** and in that way increase the speed of simulation.

## Speed of the Setting test runs



The most recently set speed stays active until a power interruption. After the control is switched on the speed is set to FMAX.

After you have started a program, the TNC displays the following soft keys with which you can set the simulation speed:

Functions	Soft key
Perform the test run at the same speed at which the program will be run (programmed feed rates are taken into account)	
Increase the simulation speed incrementally	
Decrease the simulation speed incrementally	
Test run at the maximum possible speed (default setting)	

You can also set the simulation speed before you start a program:



- ▶ Select the function for setting the simulation speed






- ▶ Select the desired function by soft key, e.g. incrementally increasing the simulation speed

## Test run and program run

### 17.1 Graphics

#### Overview: Display modes




The TNC displays the following soft keys in the Program Run and Test Run modes of operation:

View	Soft key
Plan view	
Projection in three planes	
3-D view	



The position of the soft keys depends on the selected operating mode.

The Test Run operating mode additionally offers the following views:

View	Soft key
Volume view	
Volume view and tool paths	
Tool paths	

#### Limitations during program run




The result of the simulation can be faulty if the TNC's computer is overloaded with complicated processing tasks.

### Plan view

Select plan view:




▶ Press the plan-view soft key




### Projection in three planes

The simulation shows three sectional planes and a 3-D model, similar to a technical drawing.


Select projection in three planes:









▶ Press the view-in-three-planes soft key



Move the sectional planes:




▶ Select the functions for shifting the sectional plane. The TNC offers the following soft keys:

Function	Soft keys
Shift the vertical sectional plane to the right or left	 
Shift the vertical sectional plane forward or backward	 
Shift the horizontal sectional plane upwards or downwards	 

The position of the sectional planes is visible during shifting. The default setting of the sectional plane is selected so that it lies in the working plane in the workpiece center and in the tool axis on the top surface.

Return sectional planes to default setting:



▶ Select the function for resetting the sectional planes.


## Test run and program run

### 17.1 Graphics



#### 3-D view

Choose 3-D view:


The high resolution 3-D view enables you to display the surface of the machined workpiece in greater detail. With a simulated light source, the TNC creates realistic light and shadow conditions.



- ▶ Press the 3-D view soft key



### Rotating, enlarging, reducing and shifting the 3-D view



- ▶ Select functions for rotating and magnifying/reducing: The TNC shows the following soft keys

Function	Soft keys
Rotate in 5° steps about the vertical axis	
Tilt in 5° steps about the horizontal axis	
Magnify the graphic stepwise	
Reduce the graphic stepwise	
Reset the graphic to its original size	



- ▶ Shift the soft-key row

Function	Soft Keys
Shift the graphic upward or downward	
Shift the graphic to the left or right	
Reset the graphic to its original position	

If there is a mouse attached to your TNC, you can also perform the functions described above with the mouse:




- ▶ In order to rotate the graphic shown in three dimensions: Hold the right mouse button down and move the mouse. After you release the right mouse button, the TNC orients the workpiece to the defined orientation
- ▶ In order to shift the graphic shown: Hold the center mouse button or the wheel button down and move the mouse. The TNC shifts the workpiece in the corresponding direction. After you release the center mouse button, the TNC shifts the workpiece to the defined position
- ▶ In order to zoom in on a certain area with the mouse: Mark a zoom area by holding the left mouse button down. After you release the left mouse button, the TNC zooms in on the defined area of the workpiece
- ▶ In order to quickly zoom in and out with the mouse: Rotate the wheel button forward or backward

## Test run and program run







### 17.1 Graphics

#### 3-D view in the Test Run mode of operation

The Test Run operating mode additionally offers the following views:

Function	Soft Keys
Volume view	
Volume view and tool paths	
Tool paths	

The Test Run operating mode additionally offers the following functions:

Function	Soft Keys
Show workpiece blank frame	
Highlight workpiece edges	
Show a transparent workpiece	
Show the endpoints of the tool paths	
Show the block numbers of the tool paths	
Show the workpiece in color	






Note that the range of functions depends on the model quality selected. You can select the model quality in the MOD function **Graphic settings**.



By showing the tool paths you can depict the programmed paths of the TNC in three dimensions. A powerful zoom function is available for recognizing details quickly.


In particular, you can use the tool paths display to inspect programs created externally for irregularities before machining. This can help you to avoid undesirable traces of the machining process on the workpiece. Such traces of machining can occur when points are output incorrectly by the postprocessor. The TNC shows traverse movements with FMAX in red.







## Repeating graphic simulation

A part program can be graphically simulated as often as desired. To do so you can reset the graphic to the workpiece blank.

Function	Soft key
Show the unmachined workpiece blank	

## Tool display

Regardless of the operating mode, you can also show the tool during the simulation.

Function	Soft key
Program Run, Full Sequence / Program Run, Single Block	
Test Run	


## Test run and program run

### 17.1 Graphics

#### Measurement of machining time

##### Program Run modes of operation

The timer counts and displays the time from program start to program end. The timer stops whenever machining is interrupted.



##### Test Run

The timer displays the time that the TNC calculates for the duration of tool movements that are executed at feed rate. Dwell times are included in the calculation by the TNC. The time calculated by the TNC can only conditionally be used for calculating the production time because the TNC does not account for the duration of machine-dependent interruptions, such as tool change.

##### Activating the stopwatch function



- ▶ Shift the soft-key row until the soft-key for the stopwatch functions appears



- ▶ Select the stopwatch functions



- ▶ Select the desired function via soft key, e.g. saving the displayed time.

##### Stopwatch functions

##### Soft key

Store displayed time



Display the sum of stored time and displayed time



Clear displayed time



## 17.2 Showing the workpiece blank in the working space









### Application

This MOD function enables you to graphically check the position of the workpiece blank or reference point in the machine's working space and to activate work space monitoring in the Test Run mode of operation. This function is activated with the **BLANK IN WORKSPACE** soft key. You can activate or deactivate the function with the **SW limit monitoring** soft key (2nd soft-key row).

Another transparent cuboid represents the workpiece blank. Its dimensions are shown in the **BLK FORM** table. The TNC takes the dimensions from the workpiece blank definition of the selected program. The workpiece cuboid defines the coordinate system for input. Its datum lies within the traverse-range cuboid.


For a test run it normally does not matter where the workpiece blank is located within the working space. However, if you activate working-space monitoring, you must graphically shift the workpiece blank so that it lies within the working space. Use the soft keys shown in the table.

You can also activate the current datum for the Test Run operating mode (see the last line of the following table).

Function	Soft keys
Shift workpiece blank in positive/negative X direction	 
Shift workpiece blank in positive/negative Y direction	 
Shift workpiece blank in positive/negative Z direction	 
Show workpiece blank referenced to the set datum	
Switch monitoring function on or off	



Note that even with **BLK FORM CYLINDER**, a cuboid is shown in the working space as workpiece blank. When **BLK FORM ROTATION** is used, no workpiece blank is shown in the working space.







## Test run and program run

### 17.3 Functions for program display

#### 17.3 Functions for program display

##### Overview

In the program run modes, the TNC provides the following soft keys for displaying a part program in pages:

Functions	Soft key
Go back in the program by one screen	
Go forward in the program by one screen	
Go to the start of the program	
Go to the end of the program	

## 17.4 Test Run

### Application

In the Test Run mode of operation you can simulate programs and program sections to reduce programming errors during program run. The TNC checks the programs for the following:

- Geometrical incompatibilities
- Missing data
- Impossible jumps
- Violation of the machine's working space

The following functions are also available:

- Blockwise test run
- Interruption of test at any block
- Optional block skip
- Functions for graphic simulation
- Measure machining time
- Additional status display



#### **Danger of collision!**

The TNC cannot graphically simulate all traverse motions actually performed by the machine. These include

- Traverse motions during tool change, if the machine manufacturer defined them in a tool-change macro or via the PLC
- Positioning movements that the machine manufacturer defined in an M-function macro
- Positioning movements that the machine manufacturer performs via the PLC

HEIDENHAIN therefore recommends proceeding with caution for every new program, even when the program test did not output any error message, and no visible damage to the workpiece occurred.

After a tool call, the TNC always starts a program test at the following position:

- In the machining plane at the position  $X=0$ ,  $Y=0$
- In the tool axis, 1 mm above the **MAX** point defined in the **BLK FORM**

With rotationally symmetric workpiece blanks, the TNC starts a program test run after a tool call at the following position:

- In the machining plane at the position  $X=0$ ,  $Y=0$
- In the tool axis at the position  $Z=1$

If you call the same tool, the TNC resumes program simulation from the position last programmed before the tool call.

In order to ensure unambiguous behavior during program run, after a tool change you should always move to a position from which the TNC can position the tool for machining without causing a collision.

## Test run and program run

### 17.4 Test Run



Your machine tool builder can also define a tool-change macro for the Test Run operating mode. This macro will simulate the exact behavior of the machine. Refer to your machine manual.

#### Execute test run



If the central tool file is active, a tool table must be active (status S) to conduct a test run. Select the desired tool table by using the file manager (PGM MGT) in the Test Run mode of operation.

The **toolturn.trn** is always used for turning tools, eliminating any manual selection.

With the **BLANK IN WORK SPACE** function, you activate a workspace monitor for the test run, See "Showing the workpiece blank in the working space ", page 531.



- ▶ Select the Test Run operating mode
- ▶ Call the file manager with the **PGM MGT** key and select the file you wish to test, or

The TNC then displays the following soft keys:

Functions	Soft key
Reset the blank form and test the entire program	
Test the entire program	
Test each program block individually	
Halt test run (soft key only appears once you have started the test run)	

You can interrupt the test run and continue it again at any point—even within a fixed cycle. In order to continue the test, the following actions must not be performed:

- Selecting another block with the arrow keys or the GOTO key
- Making changes to the program
- Selecting a new program

## 17.5 Program run


### Application

In the Program Run, Full Sequence mode of operation the TNC executes a part program continuously to its end or up to a program stop.

In the Program Run, Single Block mode of operation you must start each block separately by pressing the machine **START** button.

The following TNC functions are available in the program run modes of operation:

- Interrupt program run
- Starting the program run from a certain block
- Optional block skip
- Editing the tool table TOOL.T
- Checking and changing Q parameters
- Superimposing handwheel positioning
- Functions for graphic simulation
- Additional status display



## Test run and program run

### 17.5 Program run

#### Running a part program

##### Preparation

- 1 Clamp the workpiece to the machine table.
- 2 Set the datum
- 3 Select the necessary tables and pallet files (status M)
- 4 Select the part program (status M).



You can adjust the feed rate and spindle speed with the override knobs.



It is possible to reduce the feed rate when starting the NC program using the **FMAX** soft key. The reduction applies to all rapid traverse and feed rate movements. The value you enter is no longer in effect after the machine has been turned off and on again. In order to re-establish the respectively defined maximum feed rate after switch-on, you need to re-enter the corresponding value.

The behavior of this function varies depending on the respective machine. Refer to your machine manual.

##### Program Run, Full Sequence

- ▶ Start the part program with the machine **START** button

##### Program Run, Single Block

- ▶ Start each block of the part program individually with the machine **START** button



## Interrupt machining

There are several ways to interrupt a program run:

- Programmed interruptions
- Pressing the machine **STOP** button
- Switching to Program Run, Single Block

If the TNC registers an error during program run, it automatically interrupts the machining process.

### Programmed interruptions

You can program interruptions directly in the part program. The TNC interrupts the program run at a block containing one of the following entries:

- **G38** (with and without miscellaneous function)
- Miscellaneous function **M0**, **M2** or **M30**
- Miscellaneous function **M6** (determined by the machine tool builder)

### Interruption through the machine **STOP** button

- ▶ Press the machine **STOP** button: The block that the TNC is currently executing is not completed. The NC stop signal in the status display blinks (see table)
- ▶ If you do not wish to continue the machining process, you can reset the TNC with the **INTERNAL STOP** soft key. The NC stop signal in the status display goes out. In this case, the program must be restarted from the program beginning

Icon	Meaning
	Program run is stopped

### Interruption of machining by switching to the Program Run, Single Block mode of operation.

You can interrupt a program that is being run in the Program Run, Full Sequence mode of operation by switching to the Program Run, Single Block mode. The TNC interrupts the machining process at the end of the current block.

## Test run and program run

### 17.5 Program run

#### Moving the machine axes during an interruption

You can move the machine axes during an interruption in the same way as in the Manual Operation mode.



#### Danger of collision!

If you interrupt program run while the working plane is tilted, you can switch the coordinate system between tilted and non-tilted, as well as to the active tool axis direction, by pressing the 3-D ROT soft key.

The functions of the axis direction buttons, the electronic handwheel and the positioning logic for returning to the contour are then evaluated by the TNC. When retracting the tool make sure the correct coordinate system is active and the angular values of the tilt axes are entered in the 3-D ROT menu, if necessary.

#### Example:

#### Retracting the spindle after tool breakage

- ▶ Interrupt machining
- ▶ Enable the external direction keys: Press the **MANUAL TRAVERSE** soft key
- ▶ Move the axes with the machine axis direction buttons.



On some machines you may have to press the machine **START** button after the **MANUAL OPERATION** soft key to enable the axis direction buttons. Refer to your machine manual.

#### Resuming program run after an interruption



If you cancel a program with INTERNAL STOP, you have to start the program with the **RESTORE POS. AT N** function or with GOTO "0".

If a program run is interrupted during a fixed cycle, the program must be resumed from the beginning of the cycle. This means that some machining operations will be repeated.

If you interrupt a program run during execution of a subprogram or program section repeat, use the **RESTORE POS AT N** function to return to the position at which the program run was interrupted.

When a program run is interrupted, the TNC stores:

- The data of the last defined tool
- Active coordinate transformations (e.g. datum shift, rotation, mirroring)
- The coordinates of the circle center that was last defined



Note that the stored data remain active until they are reset (e.g. if you select a new program).

The stored data are used for returning the tool to the contour after manual machine axis positioning during an interruption (**RESTORE POSITION** soft key).

#### Resuming program run with the **START** button

You can resume program run by pressing the machine **START** button if the program was interrupted in one of the following ways:

- Machine **STOP** button pressed
- Programmed interruption

#### Resuming program run after an error

With an erasable error message:

- ▶ Remove the cause of the error
- ▶ Clear the error message from the screen: Press the **CE** key
- ▶ Restart the program, or resume program run where it was interrupted

#### With a non-erasable error message

- ▶ Press and hold the **END** key for two seconds. This induces a TNC system restart
- ▶ Remove the cause of the error
- ▶ Restart

If you cannot correct the error, write down the error message and contact your service agency.

## Test run and program run

### 17.5 Program run

#### Retraction after a power interruption



The **Retraction** mode of operation must be enabled and adapted by the machine tool builder. Refer to your machine manual.

With the **Retraction** mode of operation you can disengage the tool from the workpiece after an interruption in power.

The **Retraction** mode of operation is selectable in the following conditions:

- Power interruption
- Relay external DC voltage missing
- Traverse reference points


The Retraction operating mode offers the following modes of traverse:

Mode	Function
Machine axes	Movement of all axes in the original coordinate system
Tilted system	Movement of all axes in the active coordinate system Effective parameters: Position of the tilting axes
Tool axis	Movements of the tool axis in the active coordinate system
Thread	Movements of the tool axis in the active coordinate system with compensating movement of the spindle Effective parameters: Thread pitch and direction of rotation



The **tilted system** mode of traverse is available only when the "tilting the working plane" software option is enabled on your TNC.

The TNC selects the mode of traverse and the associated parameters automatically. If the traverse mode or the parameters were not correctly chosen, you can change them manually.



**Danger of collision!**

For nonreferenced axes, the TNC adopts the most recently saved axis values. These values generally are not the exact actual axis positions!

As a result, for example, the tool might not move exactly along the actual tool direction. If the tool is still in contact with the workpiece, it can cause stress or damage to the tool and workpiece. Stress or damage to the workpiece or tool can also be caused by uncontrolled coasting or braking of axes after a power interruption. Move the axes carefully if the tool is still in contact with the workpiece. Set the feed rate override to the smallest values possible. If you use the handwheel, use a small feed rate factor.

The traverse range monitoring is not available for nonreferenced axes. Observe the axes while you move them. Do not move to the limits of traverse.


## Test run and program run

### 17.5 Program run

#### Example

The power failed while a thread cutting cycle in the tilted working plane was being performed. You have to retract the tap:

- ▶ Switch on the power supply for TNC and machine: The TNC starts the operating system. This process may take several minutes. Then the TNC will display the message "Power interrupted" in the screen header



- ▶ Activate the retraction mode Press the **RETRACT** soft key. The TNC displays the message "RETRACT."




- ▶ To acknowledge the power interruption, press the **CE** key. The TNC compiles the PLC program.




- ▶ Switch on external DC voltage. The TNC checks the functioning of the EMERGENCY STOP circuit. If at least one axis is not referenced, you have to compare the displayed position values with the actual axis value and confirm their agreement. Follow the dialog, if required.

- ▶ Check the preselected traversing mode: if required, select **THREAD**
- ▶ Check the preselected thread pitch: if required, enter the thread pitch
- ▶ Check the preselected direction of rotation: if required, select the direction of thread rotation.  
Right-hand thread: The Spindle turns in clockwise direction when moving into the workpiece and counterclockwise when retracting  
Left-hand thread: The Spindle turns in clockwise direction when moving into the workpiece and counterclockwise when retracting




- ▶ To activate retraction, press the **RETRACT** soft key

- ▶ Retraction: retract the tool with the machine axes keys or the electronic handwheel  
Z+: Retracting from the workpiece  
Z-: Entering the workpiece



- ▶ Exit retraction: return to the original soft-key level



- ▶ End the retraction mode: press the **END RETRACTION** soft key. The TNC checks whether the retraction mode can be ended. If necessary, follow the dialog.

- ▶ Answer the confirmation request: If the tool was not correctly retracted, press the **NO** soft key. If the tool was correctly retracted, press the **YES** soft key. The TNC hides the retraction dialog.
- ▶ Initialize the machine: if required, scan the reference points
- ▶ Establish the desired machine condition: if required, reset the tilted working plane

## Any entry into program (mid-program startup)



The **RESTORE POS AT N** feature must be enabled and adapted by the machine tool builder. Refer to your machine manual.

With the **RESTORE POS AT N** feature (block scan) you can start a part program at any block you desire. The TNC scans the program blocks up to that point. Machining can be graphically simulated.

If you have interrupted a part program with an **INTERNAL STOP**, the TNC automatically offers the interrupted block N for mid-program startup.




Mid-program startup must not begin in a subprogram.

All necessary programs, tables and pallet files must be selected in a program run mode of operation (status M).

If the program contains a programmed interruption before the startup block, the block scan is interrupted. Press the machine **START** button to continue the block scan.

After a block scan, return the tool to the calculated position with **RESTORE POSITION**.

Tool length compensation does not take effect until after the tool call and a following positioning block. This also applies if you have only changed the tool length.



## Test run and program run

### 17.5 Program run




The TNC skips all touch probe cycles in a mid-program startup. Result parameters that are written to from these cycles might therefore remain empty.

You may not use mid-program startup if the following occurs after a tool change in the machining program:

- The program is started in an FK sequence
- The stretch filter is active
- Pallet management is used
- The program is started in a threading cycle (Cycles 17, 18, 19, 206, 207 and 209) or the subsequent program block
- Touch-probe cycles 0, 1 and 3 are used before program start

- ▶ Go to the first block of the current program to start a block scan:  
Enter **GOTO "0"**



- ▶ Select mid-program startup: Press the **MID-PROGRAM STARTUP** soft key
- ▶ **Startup at N:** Enter the block number N at which the block scan should end.
- ▶ **Program:** Enter the name of the program containing block N
- ▶ **Repetitions:** If block N is located in a program section repeat or in a subprogram that is to be run repeatedly, enter the number of repetitions to be calculated in the block scan
- ▶ To start the block scan, press the machine **START** button.
- ▶ Contour approach (see following section)

#### Entering a program with the GOTO key



If you use the **GOTO** block number key for going into a program, neither the TNC nor the PLC will execute any functions that ensure a safe start.

If you use the GOTO block number key for going into a subprogram,

- the TNC will skip the end of the subprogram (**G98 L0**)
- the TNC will reset function M126 (Shorter-path traverse of rotary axes)


In such cases you must always use the mid-program startup function.



## Returning to the contour

With the **RESTORE POSITION** function, the TNC returns to the workpiece contour in the following situations:

- Return to the contour after the machine axes were moved during a program interruption that was not performed with the **INTERNAL STOP** function
  - Return to the contour after a block scan with **RESTORE POS AT N**, for example after an interruption with **INTERNAL STOP**
  - Depending on the machine, if the position of an axis has changed after the control loop has been opened during a program interruption
- ▶ To select a return to contour, Press the **RESTORE POSITION** soft key
- ▶ Restore machine status, if required
- ▶ To move the axes in the sequence that the TNC suggests on the screen, press the machine **START** button, or
- ▶ To move the axes in any sequence: press the soft keys **RESTORE X**, **RESTORE Z**, etc., and activate each axis with the machine **START** button.
- ▶ To resume machining, press the machine **START** button.



## Test run and program run

### 17.6 Automatic program start

### 17.6 Automatic program start

#### Application



The TNC must be specially prepared by the machine tool builder for use of the automatic program start function. Refer to your machine manual.




#### Caution: Danger for the operator!

The autostart function must not be used on machines that do not have an enclosed working space.

In a Program Run operating mode, you can use the **AUTOSTART** soft key (see figure at upper right) to define a specific time at which the program that is currently active in this operating mode is to be started:



- ▶ Show the window for entering the starting time (see figure at center right)
- ▶ **Time (hrs:min:sec):** Time of day at which the program is to be started
- ▶ **Date (DD.MM.YYYY):** Date on which the program is to be started
- ▶ To activate the start, press the **OK**



## 17.7 Optional block skip

### Application

In a test run or program run, the control can skip over blocks that begin with a slash "/":



- ▶ To run or test the program without the blocks preceded by a slash, set the soft key to **ON**



- ▶ To run or test the program with the blocks preceded by a slash, set the soft key to **OFF**



This function does not work for **TOOL DEF** blocks. After a power interruption the TNC returns to the most recently selected setting.

### Inserting the "/" character

- ▶ In the **Programming** mode you select the block in which the character is to be inserted



- ▶ Select the **INSERT** soft key

### Erasing the "/" character

- ▶ In the **Programming** mode you select the block in which the character is to be deleted



- ▶ Select the **REMOVE** soft key

## Test run and program run

### 17.8 Optional program-run interruption

### 17.8 Optional program-run interruption

#### Application

The TNC optionally interrupts program run at blocks containing M1. If you use M1 in the Program Run mode, the TNC does not switch off the spindle or coolant.



- ▶ Do not interrupt program run or test run at blocks containing M1: Set soft key to **OFF**



- ▶ Interrupt program run or test run at blocks containing M1: Set soft key to **ON**

# 18

**MOD functions**

## MOD functions

### 18.1 MOD function

#### 18.1 MOD function


The MOD functions provide additional input possibilities and displays. In addition you can enter code numbers to enable access to protected areas.

#### Selecting MOD functions

Open the pop-up window with the MOD functions:

MOD

- ▶ To select the MOD functions, Press the **MOD** key. The TNC opens a pop-up window displaying the available MOD functions.



#### Changing the settings

As well as with the mouse, navigation with the keyboard is also possible in the MOD functions:

- ▶ Switch from the input area in the right window to the MOD function selections in the left window with the tab key
- ▶ Select MOD function
- ▶ Switch to the input field with the tab key or ENT key
- ▶ Enter value according to function and confirm with **OK** or make selection and confirm with **Apply**



If more than one possibility is available for a particular setting, you can superimpose a window listing all of the given possibilities by pressing the GOTO key. Select the setting with the ENT key. If you don't want to change the setting, close the window again with END.

#### Exiting MOD functions

- ▶ To close the MOD functions, Press the CANCEL or **END** key

## Overview of MOD functions

The following functions are available independent of the selected operating mode:

Code-number entry

- Code number

Display settings

- Position Displays
- Unit of measurement (mm/inches) for position display
- Program entry for MDI
- Show time of day
- Show the info line

Graphic settings

- Model type
- Model quality

Machine settings

- Kinematics selection
- Tool-usage file
- External access

System settings


- Set the system time
- Define the network connection
- Network: IP configuration

Diagnostic functions

- Bus diagnosis
- Drive diagnosis
- HEROS information

General information

- Software version
- FCL information
- License information
- Machine times



## MOD functions

### 18.2 Graphic settings

#### 18.2 Graphic settings




With the MOD function **Graphic settings**, you can select the model type and model quality.

Select the graphic settings:





- ▶ In the MOD menu, select the **Graphic settings** group
- ▶ Select the model type
- ▶ Select the model quality
- ▶ Press the **Apply** soft key
- ▶ Press the **OK** soft key

You have the following simulation parameters for the graphic settings:

##### Model type

Choice	Properties	Application	Displayed symbol
3-D	Very true to detail, heavy time and processor consumption	Milling with undercuts, milling-turning operations	
2.5 D	Fast	Milling without undercuts,	
No model	Very fast	Line graphics	

##### Model quality

Choice	Properties	Displayed symbol
Very high	High data transfer rate, exact depiction of tool geometry, depiction of block end points and block numbers possible	
High	High data transfer rate, exact depiction of tool geometry	
Medium	Medium data transfer rate, approximation of tool geometry	
Low	Low data transfer rate, coarse approximation of tool geometry	



## 18.3 Machine settings

### External access




The machine tool builder can configure the external access options. Refer to your machine manual.

Machine-dependent function: With the **TNCOPT** soft key, you can permit or lock access for an external diagnostics or commissioning program.

With the MOD function **External access** you can grant or restrict access to the TNC. If you have restricted the external access it is no longer possible to connect to the TNC and exchange data via a network or a serial connection, e.g. with the TNCremo data transfer software.

Restricting external access:

- ▶ In the MOD menu select the **Machine settings** group
- ▶ Select the **External access** menu
- ▶ Mark the selection field **Restrict external access** (with the space bar or mouse)
- ▶ Press the **Apply** soft key



## MOD functions

### 18.3 Machine settings

#### Computer-specific access control

If your machine tool builder has set up computer-specific access control (machine parameter **CfgAccessCtrl**), you can permit access for up to 32 connections authorized by you. Select **Add new** to create a new connection. The TNC opens an input window for you to enter the connection data.

#### Access settings


Host name	Host name of the external computer
Host IP	Network address of the external computer
Description	Additional information (text is shown in the overview list)

#### Type:

Ethernet	Network connection
Com 1	Serial interface 1
COM 2	Serial interface 2

#### Access rights:

Inquire	The TNC opens a query dialog with external access
Deny	Do not permit network access
Permit	Permit network access without query
Only machine manufacturer	Connection possible only when a code number is entered (machine tool builder)



If you assign the access right **Query** to a connection and access is implemented from this address, the TNC opens a pop-up window. You must permit or deny external access in the pop-up window:

External access	Permission
Yes	Permit once
Always	Permit continuously
Never	Deny continuously
No	Deny once



In the overview list an active connection is shown with a green symbol.  
Connections without access rights are shown gray in the overview list.

### Tool usage file



The tool usage test function must be enabled by your machine manufacturer. Refer to your machine manual.

With the MOD function **Tool usage file** you can select whether the TNC never, once, or always uses a tool usage file.

To generate a tool usage file:

- ▶ In the MOD menu select the **Machine settings** group
- ▶ Select the **Tool usage file** menu
- ▶ Select the desired setting for the **Program Run, Full Sequence/Single Block** and **Test Run** operating modes
- ▶ Press the **APPLY** soft key
- ▶ Press the **OK** soft key

## MOD functions

### 18.3 Machine settings

#### Select kinematics



The **Select Kinematics** function must be enabled and adapted by the machine manufacturer.  
Refer to your machine manual.

You can use this function to test programs whose kinematics does not match the active machine kinematics. If your machine manufacturer saved different kinematic configurations in your machine, you can activate one of these kinematics configurations with the MOD function. When you select a kinematics model for the test run this does not affect machine kinematics.



#### **Danger of collision!**

When you switch the kinematics model for machine operation, the TNC implements all of subsequent movements with modified kinematics.

Ensure that you have selected the correct kinematics in the test run for checking your workpiece.

## 18.4 System settings

### Set the system time

With the **Set system time** MOD function you can set the time zone, data and time manually or with the aid of an NTP server synchronization.

To set the system time manually:

- ▶ In the MOD menu, select the **System settings** group
- ▶ Press the **SET DATE/TIME** soft key
- ▶ Select your time zone in the **Time zone** area
- ▶ Press the **Local/NTP** soft key in order to select the **Set time manually** entry
- ▶ If required, change the datum and the time
- ▶ Press the **OK** soft key

To set the system time with the aid of an NTP server:

- ▶ In the MOD menu, select the **System settings** group
- ▶ Press the **SET DATE/TIME** soft key
- ▶ Select your time zone in the **Time zone** area
- ▶ Press the **Local/NTP** soft key in order to synchronize the time entry through the NTP server
- ▶ Enter the host name or the URL of an NTP server
- ▶ Press the **ADD** soft key
- ▶ Press the **OK** soft key

## MOD functions

### 18.5 Position Display Types

#### 18.5 Position Display Types

##### Application

In the Manual Operation mode and in the Program Run modes of operation, you can select the type of coordinates to be displayed.

The figure at right shows the different tool positions:


- Starting position
- Target position of the tool
- Workpiece datum
- Machine datum

The TNC position displays can show the following coordinates:

Function	Display
Nominal position: the value presently commanded by the TNC	NOML.
Actual position; current tool position	ACTL.
Reference position; the actual position relative to the machine datum	REF ACTL
Reference position; the nominal position relative to the machine datum	REF NOML
Servo lag; difference between nominal and actual positions (following error)	LAG
Distance remaining to the programmed position in the input system; difference between actual and target positions	ACTDST
Distance remaining to the programmed position with reference to the machine datum; difference between reference and target positions	REFDST
Traverses that were carried out with handwheel superimpositioning (M118)	M118

With the MOD function **Position display 1**, you can select the position display in the status display.

With the MOD function **Position display 2**, you can select the position display in the status display.



## 18.6 Unit of Measurement

### Application

This MOD function determines whether the coordinates are displayed in millimeters (metric system) or inches.

- To select the metric system (e.g. X = 15.789 mm), set the Change MM/INCH function to mm. The value is displayed to 3 decimal places.
- To select the inch system (e.g. X = 0.6216 inches), set the Change MM/INCH function to inches. The value is displayed to 4 decimal places

If you would like to activate the inch display, the TNC shows the feed rate in inch/min. In an inch program you must enter the feed rate larger by a factor of 10.

## 18.7 Displaying operating times


### Application

The MACHINE TIME soft key enables you to see various types of operating times:

Operating time	Meaning
Control on	Operating time of the control since being put into service
Machine on	Operating time of the machine tool since being put into service
Program run	Duration of controlled operation since being put into service



The machine tool builder can provide further operating time displays. Refer to your machine manual.



## MOD functions

### 18.8 Software numbers

### 18.8 Software numbers

#### Application

The following software numbers are displayed on the TNC screen after the "Software version" MOD function has been selected:

- **Control model:** Designation of the control (managed by HEIDENHAIN)
- **NC software:** Number of the NC software (managed by HEIDENHAIN)
- **NCK:** Number of the NC software (managed by HEIDENHAIN)
- **PLC software:** Number or name of the PLC software (managed by your machine tool builder)

In the "FCL information" MOD function, the TNC shows the following information:

- **Development level (FCL=Feature Content Level):**  
Development level of the software installed on the control, See "Feature Content Level (upgrade functions)", page 11

### 18.9 Entering the code number

#### Application

The TNC requires a code number for the following functions:

Function	Code number
Selecting user parameters	123
Configuring an Ethernet card	NET123
Enabling special functions for Q parameter programming	555343




## 18.10 Setting up data interfaces

### Serial interfaces on the TNC 640

The TNC 640 automatically uses the LSV2 transmission protocol for serial data transfer. The LSV2 protocol is permanent and cannot be changed except for setting the baud rate (machine parameter **baudRateLsv2**). You can also specify another type of transmission (interface). The settings described below are therefore effective only for the respective newly defined interface.

### Application

To set up a data interface, select the file management (PGM MGT) and press the MOD key. Press the MOD key again and enter the code number 123. The TNC shows the user parameter **GfgSerialInterface**, in which you can enter the following settings:



### Setting the RS-232 interface

Open the RS232 folder. The TNC then displays the following settings:

### Setting the BAUD RATE (baudRate)

You can set the BAUD RATE (data transfer speed) from 110 to 115 200 baud.

## MOD functions

### 18.10 Setting up data interfaces

#### Setting the protocol (protocol)

The data transfer protocol controls the data flow of a serial transmission (comparable to MP5030 of the iTNC 530).



Here, the BLOCKWISE setting designates a form of data transfer where data is transmitted in blocks. This is not to be confused with the blockwise data reception and simultaneous blockwise processing by older TNC contouring controls. Blockwise reception of an NC program and simultaneous machining of the program is not possible!

Data transmission protocol	Selection
Standard data transmission (transmission line-by-line)	STANDARD
Packet-based data transfer	BLOCKWISE
Transmission without protocol (only character-by-character)	RAW_DATA

#### Setting data bits (dataBits)

By setting the data bits you define whether a character is transmitted with 7 or 8 data bits.

#### Check parity (parity)

The parity bit helps the receiver to detect transmission errors. The parity bit can be formed in three different ways:

- No parity (NONE): There is no error detection
- Even parity (EVEN): Here there is an error if the receiver finds that it has received an odd number of set bits
- Odd parity (ODD): Here there is an error if the receiver finds that it has received an even number of set bits

#### Setting the stop bits (stopBits)

The start bit and one or two stop bits enable the receiver to synchronize to every transmitted character during serial data transmission.

### Setting handshaking (flowControl)

By handshaking, two devices control data transfer between them. A distinction is made between software handshaking and hardware handshaking.

- No data flow checking (NONE): Handshaking is not active
- Hardware handshaking (RTS\_CTS): Transmission stop is active through RTS
- Software handshaking (XON\_XOFF): Transmission stop is active through DC3 (XOFF)

### File system for file operations (fileSystem)

In **fileSystem** you define the file system for the serial interface. This machine parameter is not required if you don't need a special file system.

- EXT: Minimum file system for printers or non-HEIDENHAIN transmission software. Corresponds to the EXT1 and EXT2 modes of earlier TNC controls.
- FE1: Communication with the TNCserver PC software or an external floppy disk unit.

### Settings for data transfer with the TNCserver PC software

Enter the following settings in the user parameters (**serialInterfaceRS232 / definition of data blocks for the serial ports / RS232**):

Parameters	Selection
Data transfer rate in baud	Has to match the setting in TNCserver
Data transmission protocol	BLOCKWISE
Data bits in each transferred character	7 bits
Type of parity checking	EVEN
Number of stop bits	1 stop bit
Specify type of handshake:	RTS_CTS
File system for file operations	FE1




## MOD functions

### 18.10 Setting up data interfaces

#### Setting the operating mode of the external device (fileSystem)



The functions "Transfer all files," "Transfer selected file," and "Transfer directory" are not available in the FE2 and FEX modes.

External device	Operating mode	Icon
PC with HEIDENHAIN data transfer software TNCremoNT	LSV2	
HEIDENHAIN floppy disk units	FE1	
Non-HEIDENHAIN devices such as printers, scanners, punchers, PC without TNCremoNT	FEX	

## Data transfer software

For transfer of files to and from the TNC, we recommend using the HEIDENHAIN TNCremo data transfer software. With TNCremo, data transfer is possible with all HEIDENHAIN controls via the serial interface or the Ethernet interface.



You can download the current version of TNCremo free of charge from the HEIDENHAIN Filebase ([www.heidenhain.de](http://www.heidenhain.de), Services and Documentation, Software, PC Software, TNCremoNT).

System requirements for TNCremo:

- PC with 486 processor or higher
- Windows 95, Windows 98, Windows NT 4.0, Windows 2000, Windows XP, Windows Vista operating systems
- 16 MB RAM
- 5 MB free memory space on your hard disk
- An available serial interface or connection to the TCP/IP network

### Installation under Windows

- ▶ Start the SETUP.EXE installation program with the file manager (Explorer)
- ▶ Follow the setup program instructions

### Starting TNCremoNT under Windows

- ▶ Click on <Start>, <Programs>, <HEIDENHAIN Applications>, <TNCremo>

When you start TNCremo for the first time, TNCremo automatically tries to set up a connection with the TNC.

## 18.10 Setting up data interfaces

## Data transfer between the TNC and TNCremoNT



Before you transfer a program from the TNC to the PC, you must make absolutely sure that you have already saved the program currently selected on the TNC. The TNC saves changes automatically when you switch the mode of operation on the TNC, or when you select the file manager via the PGM MGT key.

Check whether the TNC is connected to the correct serial port on your PC or to the network.

Once you have started TNCremoNT, you will see a list of all files that are stored in the active directory in the upper section of the main window **1**. Using <File>, <Change directory>, you can select any drive or another directory on your PC.

If you want to control data transfer from the PC, establish the connection with your PC in the following manner:

- ▶ Select <File>, <Setup connection>. TNCremoNT now receives the file and directory structure from the TNC and displays this at the bottom left of the main window **2**
- ▶ To transfer a file from the TNC to the PC, select the file in the TNC window with a mouse click and drag and drop the highlighted file into the PC window **1**
- ▶ To transfer a file from the PC to the TNC, select the file in the PC window with a mouse click and drag and drop the highlighted file into the TNC window **2**

If you want to control data transfer from the TNC, establish the connection with your PC in the following manner:


- ▶ Select <Extras>, <TNCserver>. TNCremoNT is now in server mode. It can receive data from the TNC and send data to the TNC
- ▶ On the TNC, select the functions for file management using the **PGM MGT** key. See "Data transfer to/from an external data medium", page 126 and transfer the desired files

## Exiting TNCremoNT

Select <File>, <Exit>



Refer also to the TNCremoNT context-sensitive help texts where all of the functions are explained in more detail. The help texts must be called with the F1 key.



## 18.11 Ethernet interface

### Introduction

The TNC is shipped with a standard Ethernet card to connect the control as a client in your network. The TNC transmits data via the Ethernet card with

- the **smb** protocol (Server Message Block) for Windows operating systems, or
- the **TCP/IP** protocol family (Transmission Control Protocol/Internet Protocol) and with support from the NFS (Network File System)

### Connection options


You can connect the Ethernet card in your TNC to your network through the RJ45 connection (X26, 100BaseTX or 10BaseT), or directly to a PC. The connection is metallically isolated from the control electronics.

For a 100BaseTX or 10BaseT connection you need a Twisted Pair cable to connect the TNC to your network.



The maximum cable length between TNC and a node depends on the quality grade of the cable, the sheathing and the type of network (100BaseTX or 10BaseT).

No great effort is required to connect the TNC directly to a PC that has an Ethernet card. Simply connect the TNC (port X26) and the PC with an Ethernet crossover cable (trade names: crossed patch cable or STP cable).



### Configuring the TNC



Make sure that the person configuring your TNC is a network specialist.

- ▶ Press the MOD key in the Programming and Editing operating mode and enter the code number NET123.
- ▶ In the file manager, select the NETWORK soft key. The TNC displays the main screen for network configuration

# MOD functions

## 18.11 Ethernet interface

### General network settings



- ▶ Press the **DEFINE NET** soft key to enter the general network settings. The **Computer name** tab is active:

Setting	Meaning
<b>Primary interface</b>	Name of the Ethernet interface to be integrated in your company network. Only active if a second, optional Ethernet interface is available on the control hardware
<b>Computer name</b>	Name displayed for the TNC in your company network
<b>Host file</b>	<b>Only required for special applications:</b> Name of a file in which the assignments of IP addresses to computer names is defined

- ▶ Select the **Interfaces** tab to enter the interface settings:

Setting	Meaning
<b>Interface list</b>	List of the active Ethernet interfaces. Select one of the listed interfaces (via mouse or arrow keys) <ul style="list-style-type: none"> <li>■ <b>Activate</b> button: Activate the selected interface (an <b>X</b> appears in the <b>Active</b> column)</li> <li>■ <b>Deactivate</b> button: Deactivate the selected interface (- in the <b>Active</b> column)</li> <li>■ <b>Configuration</b> button: Open the configuration menu</li> </ul>

**Allow IP forwarding** **This function must be kept deactivated.** Only activate this function if external access via the second, optional Ethernet interface of the TNC is necessary for diagnostic purposes. Only do so after instruction by our Service Department






- Press the **Configuration** button to open the Configuration menu:

Setting	Meaning
<b>Status</b>	<ul style="list-style-type: none"> <li>■ <b>Active interface:</b> Connection status of the selected Ethernet interface</li> <li>■ <b>Name:</b> Name of the interface you are currently configuring</li> <li>■ <b>Plug connection:</b> Number of the plug connection of this interface on the logic unit of the control</li> </ul>
<b>Profile</b>	<p>Here you can create or select a profile in which all settings shown in this window are stored. HEIDENHAIN provides two standard profiles:</p> <ul style="list-style-type: none"> <li>■ <b>DHCP-LAN:</b> Settings for the standard TNC Ethernet interface, should work in a standard company network</li> <li>■ <b>MachineNet:</b> Settings for the second, optional Ethernet interface; for configuration of the machine network</li> </ul> <p>Press the corresponding buttons to save, load and delete profiles</p>
<b>IP address</b>	<ul style="list-style-type: none"> <li>■ Option <b>Automatically procure IP address:</b> The TNC is to procure the IP address from the DHCP server</li> <li>■ Option <b>Manually set IP address:</b> Manually define the IP address and subnet mask. Input: Four numerical values separated by points, in each field, e.g. <b>160.1.180.20</b> and <b>255.255.0.0</b></li> </ul>
<b>Domain Name Server (DNS)</b>	<ul style="list-style-type: none"> <li>■ Option <b>Automatically procure DNS:</b> The TNC is to automatically procure the IP address of the domain name server</li> <li>■ Option <b>Manually configure DNS:</b> Manually enter the IP addresses of the servers and the domain name</li> </ul>
<b>Default gateway</b>	<ul style="list-style-type: none"> <li>■ Option <b>Automatically procure default GW:</b> The TNC is to automatically procure the default gateway</li> <li>■ Option <b>Manually configure default GW:</b> Manually enter the IP addresses of the default gateway</li> </ul>

- Apply the changes with the **OK** button, or discard them with the **Cancel** button



# MOD functions

## 18.11 Ethernet interface

▶ The **Internet** tab currently has no function.

Setting	Meaning
<b>Proxy</b>	<ul style="list-style-type: none"> <li>■ <b>Direct connection to Internet/NAT:</b> The control forwards Internet inquiries to the default gateway and from there they must be forwarded through network address translation (e.g. if a direct connection to a modem is available).</li> <li>■ <b>Use proxy:</b> Define the <b>Address</b> and <b>Port</b> of the Internet router in your network, ask your network administrator for the correct address and port</li> </ul>

**Telemaintenance** The machine manufacturer configures the server for telemaintenance here. Changes must always be made in agreement with your machine tool builder




▶ Select the **Ping/Routing** tab to enter the ping and routing settings:

Setting	Meaning
<b>Ping</b>	<p>In the <b>Address:</b> field, enter the IP number for which you want to check the network connection. Input: Four numerical values separated by periods, e.g. <b>160.1.180.20</b>. As an alternative, you can enter the name of the computer whose connection you want to check</p> <ul style="list-style-type: none"> <li>■ Press the <b>Start</b> button to begin the test. The TNC shows the status information in the Ping field</li> <li>■ Press the <b>Stop</b> button to conclude the test</li> </ul>

<b>Routing</b>	<p>For network specialists: Status information of the operating system for the current routing</p> <ul style="list-style-type: none"> <li>■ Press the <b>Update</b> button to refresh the routing information</li> </ul>
----------------	--


▶ Select the **NFS UID/GID** tab to enter the user and group identifications:

Setting	Meaning
<b>Set UID/GID for NFS shares</b>	<ul style="list-style-type: none"> <li>■ <b>User ID:</b> Definition of which user identification the end user uses to access files in the network. Ask your network specialist for the proper value</li> <li>■ <b>Group ID:</b> Definition of the group identification with which you access files in the network. Ask your network specialist for the proper value</li> </ul>



► **DHCP server:** Settings for automatic network configuration

Setting	Meaning
<b>DHCP server</b>	<ul style="list-style-type: none"> <li>■ <b>IP addresses from:</b> Define the IP address as of which the TNC is to derive the pool of dynamic IP addresses. The TNC transfers the values that appear dimmed from the static IP address of the defined Ethernet interface; these values cannot be edited.</li> <li>■ <b>IP addresses to:</b> Define the IP address up to which the TNC is to derive the pool of dynamic IP addresses</li> <li>■ <b>Lease Time (hours):</b> Time within which the dynamic IP address is to remain reserved for a client. If a client logs on within this time, the TNC reassigns the same dynamic IP address.</li> <li>■ <b>Domain name:</b> Here you can define a name for the machine network if required. This is necessary if the same names are assigned in the machine network and in the external network, for example.</li> <li>■ <b>Forward DNS externally:</b> If <b>IP Forwarding</b> is active (Interfaces tab) and the option is active, you can specify that the name resolution for devices in the machine network can also be used by the external network.</li> <li>■ <b>Forward DNS from outside:</b> If <b>IP Forwarding</b> is active (Interfaces tab) and the option is active, you can specify that the TNC is to forward DNS inquiries from devices within the machine network to the name server of the external network if the DNS server of the MC cannot answer the inquiry.</li> <li>■ <b>Status</b> button: Call an overview of the devices that are provided with a dynamic IP address in the machine network. You can also select settings for these devices.</li> <li>■ <b>Additional options</b> button: Additional settings for the DNS/DHCP server.</li> <li>■ <b>Set standard values</b> button: Set factory settings.</li> </ul>



### Network settings specific to the device



- ▶ Press the **DEFINE MOUNT** soft key to enter the network settings for a specific device. You can define any number of network settings, but you can manage only seven at one time

Setting	Meaning
<b>Network drive</b>	List of all connected network drives. The TNC shows the respective status of the network connections in the columns: <ul style="list-style-type: none"> <li>■ <b>Mount:</b> Network drive connected / not connected</li> <li>■ <b>Auto:</b> Network drive is to be connected automatically /manually</li> <li>■ <b>Type:</b> Type of network connection. cifs and nfs are possible</li> <li>■ <b>Drive:</b> Designation of the drive on the TNC</li> <li>■ <b>ID:</b> Internal ID that identifies if a mount point has been used for more than one connection</li> <li>■ <b>Server:</b> Name of the server</li> <li>■ <b>Authorization name:</b> Name of the directory on the server that the TNC is to access</li> <li>■ <b>User:</b> User name with which the user logs on to the network</li> <li>■ <b>Password:</b> Network drive password protected / not protected</li> <li>■ <b>Request password?:</b> Request / Do not request password during connection</li> <li>■ <b>Options:</b> Display additional connection options</li> </ul>

To manage the network drives, use the screen buttons.

To add network drives, use the **Add** button: The TNC then starts the connection wizard, which guides you by dialog through the required definitions.

<b>Status log</b>	Display of status information and error messages. Press the Clear button to delete the contents of the Status Log window.
-------------------	--






## 18.12 Firewall

### Application

You can set up a firewall for the primary network interface of the control. It can be configured so that incoming network traffic is blocked and/or a message is displayed depending on the sender and the service. However, the firewall cannot be started for the second network interface of the control if it is active as DHCP server.

Once the firewall has been activated, a symbol appears at the lower right in the taskbar. The symbol changes depending on the safety level that the firewall was activated with, and informs about the level of the safety settings:

Icon	Meaning
	No firewall protection provided although it was activated in the configuration. This can happen, for example, if PC names were used in the configuration for which there are no equivalent IP addresses as yet.
	Firewall active with medium safety level
	Firewall active with high safety level. (All services except for the SSH are blocked)



Have the standard settings checked by your network specialist and change them if necessary.

The settings in the additional tab **SSH settings** are in preparation for future enhancements and currently have no function.

### Configuring the firewall

Make your firewall settings as follows:

- ▶ Use the mouse to open the task bar at the bottom edge of the screen (See "Window Manager", page 83)
- ▶ Press the green HEIDENHAIN button to open the JH menu.
- ▶ Select the **Settings** menu item
- ▶ Select the **Firewall** menu item.

HEIDENHAIN recommends activating the firewall with the prepared default settings:

- ▶ Set the **Active** option to switch on the firewall
- ▶ Press the **Set standard values** button to activate the default settings recommended by HEIDENHAIN.
- ▶ Close the dialog with **OK**

## 18.12 Firewall

## Firewall settings

Option	Meaning
Active	Switching the firewall on or off
Interface:	Selection of the <b>eth0</b> interface usually corresponds to X26 of the MC main computer. <b>eth1</b> corresponds to X116. You can check this in the network settings in the Interfaces tab. On main computer units with two Ethernet interfaces, the DHCP server is active by default for the second (non-primary) interface for the machine network. With this setting it is not possible to activate the firewall for <b>eth1</b> because the firewall and the DHCP server exclude themselves mutually
Report other inhibited packets:	Firewall active with high safety level. (All services except for the SSH are blocked)
Inhibit ICMP echo answer:	If this option is set, the control no longer answers to a PING request.
Service	<p>This column contains the short names of the services that are configured with this dialog. For the configuration it is not important here whether the services themselves have been started</p> <ul style="list-style-type: none"> <li>■ <b>LSV2</b> contains the functionality for TNCRemoNT and Teleservice, as well as the HEIDENHAIN DNC interface (ports 19000 to 19010)</li> <li>■ <b>SMB</b> only refers to incoming SMB connections, i.e. if a Windows release is made on the NC. Outgoing SMB connections (i.e. if a Windows release is connected to the NC) cannot be prevented.</li> <li>■ <b>SSH</b> stands for the Secure Shell protocol (port 22). As of HEROS 504, the LSV2 can be executed safely tunneled via this SSH protocol.</li> <li>■ <b>VNC</b> protocol means access to the screen contents. If this service is blocked, the screen content can no longer be accessed, not even with the Teleservice programs from HEIDENHAIN (e.g. screenshot). If this service is blocked, the VNC configuration dialog shows a warning from HEROS that VNC is disabled in the firewall.</li> </ul>

Option	Meaning
Method	Under <b>Method</b> you can configure whether the service should not be available to anyone ( <b>Prohibit all</b> ), available to everyone ( <b>Permit all</b> ) or only available to some (Permit some). If you set <b>Permit some</b> you must also specify the computer (under Computer) that you wish to grant access to the respective service. If you do not specify any computer under <b>Computer</b> , the setting <b>Prohibit all</b> will become active automatically when the configuration is saved.
Log	If <b>Log</b> is activated, a "red" message is output if a network package for this service was blocked. A "blue" message is output if a network package for this service was accepted.
Computer	If the setting <b>Permit some</b> is selected under <b>Method</b> , the relevant computers can be specified here. The computers can be entered with their IP addresses or host names separated by commas. If a host name is used, the system checks upon closing or saving of the dialog whether the host name can be translated into an IP address. If this is not the case, the user receives an error message and the dialog box is not closed. If you enter a valid host name, this host name will be translated into an IP address upon every startup of the control. If a computer that was entered with its name changes its IP address, you may have to restart the control or formally change the firewall configuration to ensure that the control uses the new IP address for a host name in the firewall.
Advanced options	These settings are only intended for your network specialists.
Set standard values	Resets the settings to the default values recommended by HEIDENHAIN

## MOD functions

### 18.13 Configure HR 550 FS wireless handwheel

#### 18.13 Configure HR 550 FS wireless handwheel


##### Application

Press the **SET UP WIRELESS HANDWHEEL** soft key to configure the HR 550 FS wireless handwheel. The following functions are available:

- Assigning the handwheel to a specific handwheel holder
- Setting the transmission channel
- Analyzing the frequency spectrum for determining the optimum transmission channel
- Select transmitter power
- Statistical information on the transmission quality

##### Assigning the handwheel to a specific handwheel holder

- ▶ Make sure that the handwheel holder is connected to the control hardware.
- ▶ Place the wireless handwheel you want to assign to the handwheel holder in the handwheel holder
- ▶ Press the MOD key to select the MOD function
- ▶ Scroll through the soft-key row
  - ▶ Select the configuration menu for the wireless handwheel: Press the **SET UP WIRELESS HANDWHEEL** soft key
  - ▶ Click the **Connect HR** button: The TNC saves the serial number of the wireless handwheel located in the handwheel holder and shows it in the configuration window to the left of the **Connect HR** button
  - ▶ To save the configuration and exit the configuration menu, press the **END** button







## Configure HR 550 FS wireless handwheel 18.13

### Setting the transmission channel

If the wireless handwheel is started automatically, the TNC tries to select the transmission channel supplying the best transmission signal. If you want to set the transmission channel manually, proceed as follows:

- ▶ Press the MOD key to select the MOD function
- ▶ Scroll through the soft-key row
  - ▶ Select the configuration menu for the wireless handwheel: Press the **SET UP WIRELESS HANDWHEEL** soft key
  - ▶ Click the **Frequency spectrum** tab
  - ▶ Click the **Stop HR** button: The TNC stops the connection to the wireless handwheel and determines the current frequency spectrum for all of the 16 available channels
  - ▶ Memorize the number of the channel with the least amount of radio traffic (smallest bar)
  - ▶ Click the **Start handwheel** button to reactivate the wireless handwheel
  - ▶ Click the **Properties** tab
  - ▶ Click the **Select channel** button: The TNC shows all available channel numbers. Click the channel number for which the TNC determined the least amount of radio traffic
  - ▶ To save the configuration and exit the configuration menu, press the **END** button




### Selecting the transmitter power



Please keep in mind that the transmission range of the wireless handwheel decreases when the transmitter power is reduced.

- ▶ Press the MOD key to select the MOD function
- ▶ Scroll through the soft-key row
  - ▶ Select the configuration menu for the wireless handwheel: Press the **SET UP WIRELESS HANDWHEEL** soft key
  - ▶ Click the **Set power** button: The TNC shows the three available power settings. Click the desired setting
  - ▶ To save the configuration and exit the configuration menu, press the **END** button



## MOD functions

### 18.13 Configure HR 550 FS wireless handwheel

#### Statistical data

Under **Statistics**, the TNC displays information about the transmission quality.


If the reception quality is poor so that a proper and safe stop of the axes cannot be ensured anymore, an emergency-stop reaction of the wireless handwheel is triggered.

The displayed value **Max. successive lost** indicates whether reception quality is poor. If the TNC repeatedly displays values greater than 2 during normal operation of the wireless handwheel within the desired range of use, then there is a risk of an undesired disconnection. This can be corrected by increasing the transmitter power or by changing to another channel with less radio traffic.

If this occurs, try to improve the transmission quality by selecting another channel (See "Setting the transmission channel", page 577) or by increasing the transmitter power (See "Selecting the transmitter power", page 577).

To display the statistical data, proceed as follows:

- ▶ Press the MOD key to select the MOD function
- ▶ Scroll through the soft-key row
  - ▶ To select the configuration menu for the wireless handwheel, press the **SET UP WIRELESS HANDWHEEL** soft key: The TNC displays the configuration menu with the statistical data



### 18.14 Load machine configuration

#### Application



Caution: Data loss!

The TNC overwrites your machine configuration when you load (restore) a backup. The overwritten machine data will be lost in the process. You can no longer undo this process!

Your machine tool builder can provide you a backup with a machine configuration. After entering the keyword RESTORE, you can load the backup on your machine or programming station. Proceed as follows to load the backup:

- ▶ In the MOD dialog, enter the keyword RESTORE
- ▶ In the TNC's file management, select the backup file (e.g. BKUP-2013-12-12\_.zip). The TNC opens a pop-up window for the backup
- ▶ Press the emergency stop
- ▶ Press the OK soft key to start the backup process

# 19

**Tables and  
overviews**

## Tables and overviews

### 19.1 Machine-specific user parameters

### 19.1 Machine-specific user parameters

#### Application

The parameter values are entered in the **configuration editor**.



To enable you to set machine-specific functions, your machine tool builder can define which machine parameters are available as user parameters. Furthermore, your machine tool builder can integrate additional machine parameters, which are not described in the following, into the TNC. Refer to your machine manual.

The machine parameters are grouped as parameter objects in a tree structure in the configuration editor. Each parameter object has a name (e.g. **CfgDisplayLanguage**) that gives information about the parameters it contains. A parameter object (entity) is marked with an "E" in the folder symbol in the tree structure. Some machine parameters have a key name to identify them unambiguously. The key name assigns the parameter to a group (e.g. X for X axis). The respective group folder bears the key name and is marked by a "K" in the folder symbol.










If you are in the configuration editor for the user parameters, you can change the display of the existing parameters. In the default setting, the parameters are displayed with short, explanatory texts. To display the actual system names of the parameters, press the key for the screen layout and then the SHOW SYSTEM NAME soft key. Follow the same procedure to return to the standard display. Parameters not yet active and objects appear dimmed. These can be activated with the MORE FUNCTIONS and INSERT soft key. The TNC saves a modification list of the last 20 changes to the configuration data. To restore modifications, select the corresponding line and press the MORE FUNCTIONS and DISCARD CHANGES soft keys.




### Calling the configuration editor and changing parameters

- ▶ Select the **Programming** mode of operation
- ▶ Press the **MOD** key
- ▶ Enter the code number **123**.
- ▶ Changing parameters
- ▶ Press the **END** soft key to exit the configuration editor
- ▶ Press the **SAVE** soft key to save changes

The icon at the beginning of each line in the parameter tree shows additional information about this line. The icons have the following meanings:

-  Branch exists but is closed
-  Branch is open
-  Empty object, cannot be opened
-  Initialized machine parameter
-  Uninitialized (optional) machine parameter
-  Can be read but not edited
-  Can neither be read nor edited

The type of the configuration object is identified by its folder symbol:

-  Key (group name)
-  List
-  Entity or parameter object

### Displaying help texts

The **HELP** key enables you to call a help text for each parameter object or attribute.

If the help text does not fit on one page (1/2 is then displayed at the upper right, for example), press the **HELP PAGE** soft key to scroll to the second page.

To exit the help text, press the **HELP** key again.

Additional information, such as the unit of measure, the initial value, or a selection list, is also displayed. If the selected machine parameter matches a parameter in the TNC, the corresponding MP number is shown.

## Tables and overviews

### 19.1 Machine-specific user parameters

#### Parameter list

##### Parameter settings

---

#### DisplaySettings

Settings for screen display

Sequence of displayed axes

[0] to [5]

**Depends on the available axes**

Type of position display in the position window

**NOML.**

**ACTL**

**REF ACTL**

**REF NOML**

**LAG**

**DIST**

Type of position display in the status display

**NOML.**

**ACTL**

**REF ACTL**

**REF NOML**

**LAG**

**DIST**

Definition of decimal separator for position display

.

Feed rate display in Manual Operation operating mode

**At axis key: Display the feed rate only if an axis direction button is pressed**

**Always minimum: Always display the algebraic sign**

Display of spindle position in the position display

**During closed loop: Display spindle position only if spindle is in position control loop**

**During closed loop and M5: Display of spindle position if spindle is servo controlled and M5 is active**

Display or hide the PRESET TABLE soft key.

**True: Preset table soft key is not displayed**

**False: Preset Table soft key is displayed**

---

**Parameter settings**

## DisplaySettings

Display step for the individual axes

List of all available axes

Display step for position display in mm or degrees

**0.1**

**0.05**

**0.01**

**0.005**

**0.001**

**0.0005**

**0.0001**

**0.00005 (Display step software option)**

**0.00001 (Display step software option)**

Display step for position display in inches

**0.005**

**0.001**

**0.0005**

**0.0001**

**0.00005 (Display step software option)**

**0.00001 (Display step software option)**

## DisplaySettings

Definition of the unit of measure valid for the display

**metric: Use the metric system**

**inch: Use the inch system**

## DisplaySettings

Format of the NC programs and cycle display

Program entry in HEIDENHAIN plain language or in DIN/ISO

**HEIDENHAIN: Program entry in plain language in MDI mode**

**ISO: Program entry in MDI mode in DIN/ISO format**

Depiction of the cycles

**TNC\_STD: Display the cycles with comments**

**TNC\_PARAM: Display the cycles without comments**

## Tables and overviews

### 19.1 Machine-specific user parameters

#### Parameter settings

---

##### DisplaySettings

Behavior during control startup

**True: Display "Power Interrupted" message**

**False: Do not display "Power Interrupted" message**

---

##### DisplaySettings

Definition of the NC and PLC conversational language

NC conversational language

**ENGLISH**

**GERMAN**

**CZECH**

**FRENCH**

**ITALIAN**

**SPANISH**

**PORTUGUESE**

**SWEDISH**

**DANISH**

**FINNISH**

**DUTCH**

**POLISH**

**HUNGARIAN**

**RUSSIAN**

**CHINESE**

**CHINESE\_TRAD**

**SLOVENIAN**

**ESTONIAN**

**KOREAN**

**LATVIAN**

**NORWEGIAN**

**ROMANIAN**

**SLOVAK**

**TURKISH**

**LITHUANIAN**

PLC conversational language

**See NC conversational language**

PLC error message language

**See NC conversational language**

Language for online help

**See NC conversational language**

---



## Parameter settings

---

### DisplaySettings

Behavior during control startup

Acknowledge the "Power interrupted" message

**TRUE: Run-up is continued only after the message has been acknowledged**

**FALSE: The "power interrupted" message does not appear**

Depiction of the cycles

**TNC\_STD: Display the cycles with comments**

**TNC\_PARAM: Display the cycles without comments**

---

### DisplaySettings

Settings for program-run graphics

Type of graphic display

**High (compute-intensive): The orientation of linear and rotary axes is considered for the graphic display (3-D)**

**Low: Only the orientation of linear axes is considered for the program-run graphics (2.5-D).**

**Disabled: The program-run graphics are deactivated**

---

### ProbeSettings

Configuration of probing behavior

Manual operation: Inclusion of basic rotation

**TRUE: Including active basic rotation during probing**

**FALSE: Always move on paraxial path during probing**

Automatic mode: Multiple measurements in probing functions

**1 to 3 Probe points per probing process**

Automatic mode: Confidence range for multiple measurement

**0.002 to 0.999 [mm]: Range within which the measured value must be during multiple measurements**

Configuration of a round stylus

Coordinates of the stylus center

**[0]: X coordinate of the stylus center with respect to the machine datum**

**[1]: Y coordinate of the stylus center with respect to the machine datum**

**[2]: Z coordinate of the stylus center with respect to the machine datum**

Safety clearance above the stylus for pre-positioning

**0.001 to 99 999.9999 [mm]: Safety clearance in tool axis direction**

Safety zone around the stylus for prepositioning

**0.001 to 99 999.9999 [mm]: Safety clearance in the plane perpendicular to the tool axis**

---

## Tables and overviews

### 19.1 Machine-specific user parameters

#### Parameter settings

---

CfgToolMeasurement

M function for spindle orientation

**-1: Spindle orientation directly by NC**

**0: Function inactive**

**1 to 999: Number of the M function for spindle orientation**

Probing direction for tool radius measurement

**X\_Positive, Y\_Positive, X\_Negative, Y\_Negative (depending on the tool axis)**

Distance from lower edge of tool to upper edge of stylus

**0.001 to 99.9999 [mm]: Offset of probe contact to the tool**

Rapid traverse in probing cycle

**10 to 300 000 [mm/min]: Rapid traverse in probing cycle**

Probing feed rate for tool measurement

**1 to 3 000 [mm/min]: Probing feed rate for tool measurement**

Calculation of the probing feed rate

**ConstantTolerance: Calculation of the probing feed rate with constant tolerance**

**VariableTolerance: Calculation of the probing feed rate with variable tolerance**

**ConstantFeed: Constant probing feed rate**

Max. permissible surface cutting speed at the tooth edge

**1 to 129 [m/min]: Permissible rotational speed at the circumference of the milling tool**

Maximum permissible speed during tool measurement

**0 to 1 000 [1/min]: Maximal permissible speed**

Maximum permissible measuring error for tool measurement

**0.001 to 0.999 [mm]: First maximum permissible error of measurement**

Maximum permissible measuring error for tool measurement

**0,001 to 0,999 [mm]: Second maximum permissible error of measurement**

Probing routine

**MultiDirections: Probing from multiple directions**

**SingleDirection: Probing from one direction**

---

## Parameter settings

---

### ChannelSettings

#### CH\_NC

##### Active kinematics

Kinematics to be activated

##### **List of machine kinematics**

##### Geometry tolerances

Permissible deviation of the radius

**0.0001 to 0,016 [mm]: Permissible deviation of circle radius between circle end point and circle starting point**

##### Configuration of the fixed cycles

Overlap factor for pocket milling

**0.001 to 1.414: Overlapping factor for Cycle 4 POCKET MILLING and Cycle 5 CIRCULAR POCKET MILLING**

Display the "Spindle?" error message if M3/M4 is not active

**on: Output an error message**

**off: Do not output an error message**

Display the "Enter a negative depth" error message

**on: Output an error message**

**off: Do not output an error message**

Behavior when moving to wall of slot in the cylinder surface

**LineNormal: Approach on a straight line**

**CircleTangential: Approach on a circular path**

M function for spindle orientation

**-1: Spindle orientation directly by NC**

**0: Function inactive**

**1 to 999: Number of the M function for spindle orientation**

Specify behavior of the NC program

Reset the machining time when program starts

**True: Machining time is reset**

**False: Machining time is not reset**

---

## Tables and overviews

### 19.1 Machine-specific user parameters

#### Parameter settings

---

Geometry filter for culling linear elements

Type of stretch filter

- **Off: No filter active**
- **ShortCut: Omit individual points on a polygon**
- **Average: The geometry filter smoothes corners**

Maximum distance of the filtered to the unfiltered contour

**0 to 10 [mm]: The filtered points lie within this tolerance to the resulting path**

Maximum length of the distance resulting from filtering

**0 to 1000 [mm]: Length over which geometry filtering is active**

Settings for the NC editor

Generate backup files

- TRUE: Generate backup file after editing NC programs**
- FALSE: Do not generate backup file after editing NC programs**

Behavior of the cursor after deletion of lines

- TRUE: Cursor is placed on the preceding line after deletion (iTNC behavior)**
- FALSE: Cursor is placed on the following line after deletion**

Behavior of the cursor on the first or last line

- TRUE: Cursor jumps from end to beginning of program**
- FALSE: Cursor does not jump from end to beginning of program**

Line break with multiline blocks

- ALL: Always display all lines**
- ACT: Only display the lines of the active block completely**
- NO: Only display all lines when block is edited**

Activate help

- TRUE: Always display help graphics during input**
- FALSE: Only display help graphics when the CYCLE HELP soft key is set to ON. The CYCLE HELP OFF/ON soft key is displayed in Programming operating mode after pressing the "Screen layout" key**

Behavior of the soft-key row after a cycle entry

- TRUE: The cycle soft-key row remains active after a cycle definition**
- FALSE: The cycle soft-key row is hidden after a cycle definition**

Safety check when deleting blocks

- TRUE: Display confirmation question when deleting an NC block**
- FALSE: Do not display confirmation question when deleting an NC block**

Line number up to which a test of the NC program is to be run

**100 to 9999: Program length for which the geometry is to be checked**

ISO programming: Block number increment

**0 to 250: Numerical increments between DIN/ISO blocks in the program**

**Parameter settings**

---

Line number to which identical syntax elements are searched for

**500 to 9999: Search for cursored elements with up / down arrow keys**

---

Paths for the end user

List of drives and/or directories

**Drives or directories entered here are shown in the TNC's file manager**

FN 16 output path for execution

**Path for FN 16 output when no path is defined in the program**

FN 16 output path for the Programming and Test Run op. modes

**Path for FN 16 output when no path is defined in the program**

---

Settings for the file management

Display of dependent files

**MANUAL: Dependent files are displayed**

**AUTOMATIC: Dependent files are not displayed**

---

Universal Time (Greenwich Mean Time)

Time difference to universal time [h]

**-12 to 13: Time difference in hours relative to Greenwich Mean Time**

---

Serial Interface: See "Setting up data interfaces", page 561

## Tables and overviews

### 19.2 Connector pin layout and connection cables for data interfaces

#### 19.2 Connector pin layout and connection cables for data interfaces

##### RS-232-C/V.24 interface for HEIDENHAIN devices



The interface complies with the requirements of EN 50 178 for **low voltage electrical separation**.

When using the 25-pin adapter block:

TNC		Conn. cable 365725-xx		Adapter block 310085-01			Conn. cable 274545-xx		
Male	Assignment	Female	Color	Female	Male	Female	Male	Color	Female
1	Do not assign	1		1	1	1	1	White/ Brown	1
2	RXD	2	Yellow	3	3	3	3	Yellow	2
3	TXD	3	Green	2	2	2	2	Green	3
4	DTR	4	Brown	20	20	20	20	Brown	8
5	Signal GND	5	Red	7	7	7	7	Red	7
6	DSR	6	Blue	6	6	6	6		6
7	RTS	7	Gray	4	4	4	4	Gray	5
8	CTR	8	Pink	5	5	5	5	Pink	4
9	Do not assign	9					8	Violet	20
Hsg.	External shield	Hsg.	External shield	Hsg.	Hsg.	Hsg.	Hsg.	External shield	Hsg.

## Connector pin layout and connection cables for data interfaces 19.2

When using the 9-pin adapter block:

<b>TNC</b>		<b>Conn. cable 355484-xx</b>		<b>Adapter block 363987-02</b>			<b>Conn. cable 366964-xx</b>		
Male	Assignment	Female	Color	Male	Female	Male	Female	Color	Female
1	Do not assign	1	Red	1	1	1	1	Red	1
2	RXD	2	Yellow	2	2	2	2	Yellow	3
3	TXD	3	White	3	3	3	3	White	2
4	DTR	4	Brown	4	4	4	4	Brown	6
5	Signal GND	5	Black	5	5	5	5	Black	5
6	DSR	6	Violet	6	6	6	6	Violet	4
7	RTS	7	Gray	7	7	7	7	Gray	8
8	CTR	8	White/ Green	8	8	8	8	White/ Green	7
9	Do not assign	9	Green	9	9	9	9	Green	9
Hsg.	External shield	Hsg.	External shield	Hsg.	Hsg.	Hsg.	Hsg.	External shield	Hsg.

## Tables and overviews

### 19.2 Connector pin layout and connection cables for data interfaces

#### Non-HEIDENHAIN devices

The connector layout of a non-HEIDENHAIN device may substantially differ from that of a HEIDENHAIN device.

It depends on the unit and the type of data transfer. The table below shows the connector pin layout on the adapter block.

<b>Adapter block 363987-02</b>		<b>Conn. cable 366964-xx</b>		
Female	Male	Female	Color	Female
1	1	1	Red	1
2	2	2	Yellow	3
3	3	3	White	2
4	4	4	Brown	6
5	5	5	Black	5
6	6	6	Violet	4
7	7	7	Gray	8
8	8	8	White/ Green	7
9	9	9	Green	9
Hsg.	Hsg.	Hsg.	Ext. shield	Hsg.



**Ethernet interface RJ45 socket**

Maximum cable length:

- Unshielded: 100 m
- Shielded: 400 m

<b>Pin</b>	<b>Signal</b>	<b>Description</b>
1	TX+	Transmit Data
2	TX-	Transmit Data
3	REC+	Receive Data
4	Vacant	
5	Vacant	
6	REC-	Receive Data
7	Vacant	
8	Vacant	

## Tables and overviews

### 19.3 Technical Information

### 19.3 Technical Information

#### Explanation of symbols

- Standard
- Axis option
- 1 Software option 1
- 2 Software option 2

#### User functions

<b>Short description</b>	<ul style="list-style-type: none"> <li>■ Basic version: 3 axes plus closed-loop spindle</li> <li>■ Fourth NC axis plus auxiliary axis</li> <li>or</li> <li>□ 8 additional axes or 7 additional axes plus 2nd spindle</li> <li>■ Digital current and shaft speed control</li> </ul>
<b>Short description</b>	<ul style="list-style-type: none"> <li>■ Basic version: 3 axes plus closed-loop spindle</li> <li>□ 1st additional axis for 4 axes plus closed-loop spindle</li> <li>□ 1st additional axis for 5 axes plus closed-loop spindle</li> </ul>
<b>Program entry</b>	In HEIDENHAIN conversational and DIN/ISO
<b>Position data</b>	<ul style="list-style-type: none"> <li>■ Nominal positions for lines and arcs in Cartesian coordinates or polar coordinates</li> <li>■ Incremental or absolute dimensions</li> <li>■ Display and entry in mm or inches</li> </ul>
<b>Tool compensation</b>	<ul style="list-style-type: none"> <li>■ Tool radius in the working plane and tool length</li> <li>■ Radius compensated contour look ahead for up to 99 blocks (M120)</li> <li>2 Three-dimensional tool-radius compensation for subsequent changing of tool data without having to recalculate the program</li> </ul>
<b>Tool tables</b>	Multiple tool tables with any number of tools
<b>Constant contour speed</b>	<ul style="list-style-type: none"> <li>■ With respect to the path of the tool center</li> <li>■ With respect to the cutting edge</li> </ul>
<b>Parallel operation</b>	Creating a program with graphical support while another program is being run
<b>3-D machining (software option 2)</b>	<ul style="list-style-type: none"> <li>2 Motion control with minimum jerk</li> <li>2 3-D tool compensation through surface normal vectors</li> <li>2 Using the electronic handwheel to change the angle of the swivel head during program run without affecting the position of the tool point. (TCPM = <b>T</b>ool <b>C</b>enter <b>P</b>oint <b>M</b>anagement)</li> <li>2 Keeping the tool normal to the contour</li> <li>2 Tool radius compensation perpendicular to traversing and tool direction</li> </ul>
<b>Rotary table machining (software option 1)</b>	<ul style="list-style-type: none"> <li>1 Programming of cylindrical contours as if in two axes</li> <li>1 Feed rate in distance per minute</li> </ul>

## User functions

<b>Contour elements</b>	<ul style="list-style-type: none"> <li>■ Straight line</li> <li>■ Chamfer</li> <li>■ Circular path</li> <li>■ Circle center</li> <li>■ Circle radius</li> <li>■ Tangentially connected arc</li> <li>■ Corner rounding</li> </ul>
<b>Approaching and departing the contour</b>	<ul style="list-style-type: none"> <li>■ Via straight line: tangential or perpendicular</li> <li>■ Via circular arc</li> </ul>
<b>FK free contour programming</b>	<ul style="list-style-type: none"> <li>■ FK free contour programming in HEIDENHAIN conversational format with graphic support for workpiece drawings not dimensioned for NC</li> </ul>
<b>Program jumps</b>	<ul style="list-style-type: none"> <li>■ Subprograms</li> <li>■ Program-section repeat</li> <li>■ Any desired program as subroutine</li> </ul>
<b>Fixed cycles</b>	<ul style="list-style-type: none"> <li>■ Cycles for drilling, and conventional and rigid tapping</li> <li>■ Roughing of rectangular and circular pockets</li> <li>■ Cycles for pecking, reaming, boring, and counterboring</li> <li>■ Cycles for milling internal and external threads</li> <li>■ Finishing of rectangular and circular pockets</li> <li>■ Cycles for clearing level and inclined surfaces</li> <li>■ Cycles for milling linear and circular slots</li> <li>■ Cartesian and polar point patterns</li> <li>■ Contour-parallel contour pocket</li> <li>■ Contour train</li> <li>■ Cycles for turning operations</li> <li>■ OEM cycles (special cycles developed by the machine tool builder) can also be integrated</li> </ul>
<b>Coordinate transformation</b>	<ul style="list-style-type: none"> <li>■ Datum shift, rotation, mirroring</li> <li>■ Scaling factor (axis-specific)</li> <li><b>1</b> Tilting the working plane (software option 1)</li> </ul>
<b>Q parameters</b> Programming with Variables	<ul style="list-style-type: none"> <li>■ Mathematical functions: =, +, -, *, sin <math>\alpha</math>, cos <math>\alpha</math>, root</li> <li>■ Logical operations (=, <math>\neq</math>, &lt;, &gt;)</li> <li>■ Calculating with parentheses</li> <li>■ tan <math>\alpha</math>, arc sin, arc cos, arc tan, <math>a^n</math>, <math>e^n</math>, ln, log, absolute value of a number, constant <math>\pi</math>, negation, truncation of digits before or after the decimal point</li> <li>■ Functions for calculation of circles</li> <li>■ String parameters</li> </ul>
<b>Programming aids</b>	<ul style="list-style-type: none"> <li>■ Calculator</li> <li>■ Complete list of all current error messages</li> </ul>

## Tables and overviews

### 19.3 Technical Information

#### User functions

---

- Context-sensitive help function for error messages
  - Graphic support for the programming of cycles
  - Comment blocks in the NC program
- 

#### Teach-In

- Actual positions can be transferred directly into the NC program
- 

#### Test run graphics

Display modes

- Graphic simulation before program run, even while another program is being run
  - Plan view / projection in 3 planes / 3-D view / 3-D line graphic
  - Magnification of details
- 

#### Programming graphics

- In the Programming mode, the contour of the NC blocks is drawn on screen while they are being entered (2-D pencil-trace graphics), even while another program is running
- 

#### Program Run graphics

Display modes

- Graphic simulation of real-time machining in plan view / projection in 3 planes / 3-D view
- 

#### Machining time

- Calculating the machining time in the Test Run mode of operation
  - Display of the current machining time in the Program Run operating modes
- 

#### Returning to the contour

- Mid-program startup in any block in the program, returning the tool to the calculated nominal position to continue machining
  - Program interruption, contour departure and return
- 

#### Datum tables

- Multiple datum tables, for storing workpiece-related datums
- 

#### Touch probe cycles

- Calibrate the touch probe
- Compensation of workpiece misalignment, manual or automatic
- Datum setting, manual or automatic
- Automatic workpiece measurement
- Cycles for automatic tool measurement
- Cycles for automatic tool measurement
- Cycles for automatic kinematics measurement

## Specifications

<b>Components</b>	<ul style="list-style-type: none"> <li>■ Operating panel</li> <li>■ TFT color flat-panel display with soft keys</li> </ul>
<b>Program memory</b>	<ul style="list-style-type: none"> <li>■ Minimum 21 GB</li> </ul>
<b>Input resolution and display step</b>	<ul style="list-style-type: none"> <li>■ Up to 0.1 µm for linear axes</li> <li>■ Up to 0.01 µm for linear axes (with option 23)</li> <li>■ Up to 0.0001° for rotary axes</li> <li>■ Up to 0.000 01° for rotary axes (with option 23)</li> </ul>
<b>Input range</b>	<ul style="list-style-type: none"> <li>■ Maximum 999 999 999 mm or 999 999 999°</li> </ul>
<b>Interpolation</b>	<ul style="list-style-type: none"> <li>■ Linear in 4 axes</li> <li>■ Circular in 2 axes</li> <li>■ Helical: superimposition of circular and straight paths</li> <li>■ Helical: superimposition of circular and straight paths</li> </ul>
<b>Block processing time</b> 3-D straight line without radius compensation	<ul style="list-style-type: none"> <li>■ 0.5 ms</li> </ul>
<b>Axis feedback control</b>	<ul style="list-style-type: none"> <li>■ Position loop resolution: Signal period of the position encoder/1024</li> <li>■ Cycle time of position controller: 3 ms</li> <li>■ Cycle time of speed controller: 200 µs</li> </ul>
<b>Range of traverse</b>	<ul style="list-style-type: none"> <li>■ Maximum 100 m (3937 inches)</li> </ul>
<b>Spindle speed</b>	<ul style="list-style-type: none"> <li>■ Maximum 100 000 rpm (analog speed command signal)</li> </ul>
<b>Error compensation</b>	<ul style="list-style-type: none"> <li>■ Linear and nonlinear axis error, backlash, reversal peaks during circular movements, thermal expansion</li> <li>■ Stick-slip friction</li> </ul>
<b>Data interfaces</b>	<ul style="list-style-type: none"> <li>■ One each RS-232-C /V.24 max. 115 kilobaud</li> <li>■ Expanded interface with LSV-2 protocol for external operation of the TNC over the interface with HEIDENHAIN software TNCremo</li> <li>■ Ethernet interface 1000 Base T</li> <li>■ 3 x USB 2.0</li> </ul>
<b>Ambient temperature</b>	<ul style="list-style-type: none"> <li>■ Operation: 0 °C to +45 °C</li> <li>■ Storage: -30 °C to +70 °C</li> </ul>

## Tables and overviews

### 19.3 Technical Information

#### Accessories

<b>Electronic Handwheels</b>	<ul style="list-style-type: none"> <li>■ One HR 410 portable handwheel, or</li> <li>■ One HR 550 FS portable wireless handwheel with display or</li> <li>■ One HR 520 portable handwheel with display, or</li> <li>■ One HR 420 portable handwheel with display or</li> <li>■ One HR 130 panel-mounted handwheel, or</li> <li>■ Up to three HR 150 panel-mounted handwheels via HRA 110 handwheel adapter</li> </ul>
<b>Touch probes</b>	<ul style="list-style-type: none"> <li>■ TS 220: triggering 3-D touch probe with cable connection, or</li> <li>■ TS 440: 3-D touch trigger probe with infrared transmission</li> <li>■ TS 444: Battery-free 3-D touch trigger probe with infrared transmission</li> <li>■ TS 640: 3-D touch trigger probe with infrared transmission</li> <li>■ TS 740: High-precision 3-D touch trigger probe with infrared transmission</li> <li>■ TT 140: 3-D touch trigger probe for tool measurement</li> <li>■ TT 449: 3-D touch trigger probe for tool measurement with infrared transmission</li> </ul>

#### Hardware, options

- 1st additional axis for 4 axes plus spindle
- 2nd additional axis for 5 axes plus spindle

#### Software option 1 (option number 08)

<b>Rotary table machining</b>	<ul style="list-style-type: none"> <li>■ Programming of cylindrical contours as if in two axes</li> <li>■ Feed rate in distance per minute</li> </ul>
-------------------------------	---

<b>Coordinate transformation</b>	<ul style="list-style-type: none"> <li>■ Working plane, tilting the ...</li> </ul>
----------------------------------	--

<b>Interpolation</b>	<ul style="list-style-type: none"> <li>■ Circle in 3 axes with tilted working plane (spacial arc)</li> </ul>
----------------------	--

#### Software option 2 (option number 09)

<b>3-D machining</b>	<ul style="list-style-type: none"> <li>■ Motion control with minimum jerk</li> <li>■ 3-D tool compensation through surface normal vectors</li> <li>■ Using the electronic handwheel to change the angle of the swivel head during program run without affecting the position of the tool point. (TCPM = <b>T</b>ool <b>C</b>enter <b>P</b>oint <b>M</b>anagement)</li> <li>■ Keeping the tool normal to the contour</li> <li>■ Tool radius compensation perpendicular to traversing and tool direction</li> </ul>
----------------------	---

<b>Interpolation</b>	<ul style="list-style-type: none"> <li>■ Linear in 5 axes (subject to export permit)</li> </ul>
----------------------	---

#### HEIDENHAIN DNC (option number 18)

- Communication with external PC applications over COM component

#### Display step (Option number 23)

<b>Input resolution and display step</b>	<ul style="list-style-type: none"> <li>■ Linear axes down to 0.01 <math>\mu\text{m}</math></li> <li>■ Rotary axes to 0.00001°</li> </ul>
--	--

**Dynamic Collision Monitoring (DCM) software option (option number 40)**

- |  |   |
|--|---|
| <b>Collision monitoring in all machine operating modes</b> | <ul style="list-style-type: none"> <li>■ The machine manufacturer defines objects to be monitored</li> <li>■ Three warning levels in manual operation</li> <li>■ Program interrupt during automatic operation</li> <li>■ Includes monitoring of 5-axis movements</li> </ul> |
|--|---|

**DXF Converter software option (option number 42)**

- |   |  |
|---|--|
| <b>Extracting contour programs and machining positions from DXF data. Extracting contour sections from plain-language programs.</b> | <ul style="list-style-type: none"> <li>■ Supported DXF format: AC1009 (AutoCAD R12)</li> <li>■ For contours and point patterns</li> <li>■ Simple and convenient specification of reference points</li> <li>■ Select graphical features of contour sections from conversational programs</li> </ul> |
|---|--|

**Adaptive Feed Control (AFC) software option (option number 45)**

- |   |  |
|---|--|
| <b>Function for adaptive feed-rate control for optimizing the machining conditions during series production</b> | <ul style="list-style-type: none"> <li>■ Recording the actual spindle power by means of a teach-in cut</li> <li>■ Defining the limits of automatic feed rate control</li> <li>■ Fully automatic feed control during program run</li> </ul> |
|---|--|

**KinematicsOpt software option (option number 48)**

- |  |  |
|--|--|
| <b>Touch-probe cycles for automatic testing and optimization of the machine kinematics</b> | <ul style="list-style-type: none"> <li>■ Backup/restore active kinematics</li> <li>■ Test active kinematics</li> <li>■ Optimize active kinematics</li> </ul> |
|--|--|

**Mill-Turning software option (option number 50)**

- |   |   |
|---|---|
| <b>Functions for milling/turning mode</b> | <ul style="list-style-type: none"> <li>■ Switching between Milling/Turning mode of operation</li> <li>■ Constant cutting speed</li> <li>■ Tool-tip radius compensation</li> <li>■ Turning cycles</li> </ul> |
|---|---|

**Extended Tool Management software option (option number 93)**

- |  |  |
|--|--|
|  | <ul style="list-style-type: none"> <li>■ Extended tool management, python-based</li> </ul> |
|--|--|

## Tables and overviews

### 19.3 Technical Information

#### Remote Desktop Manager software option (option number 133)

---

- |   |  |
|---|--|
| <b>Remote operation of external computer units (e.g. Windows PC) via the TNC user interface</b> | <ul style="list-style-type: none"> <li>■ Windows on a separate computer unit</li> <li>■ Incorporated in the TNC interface</li> </ul> |
|---|--|

#### Synchronizing Functions software option (option number 135)

---

- |                                 |  |
|---------------------------------|--|
| <b>Real Time Coupling (RTC)</b> | <ul style="list-style-type: none"> <li>■ Coupling of axes</li> </ul> |
|---------------------------------|--|

#### Cross Talk Compensation (CTC) software option (option number 141)

---

- |                                       |   |
|---------------------------------------|---|
| <b>Compensation of axis couplings</b> | <ul style="list-style-type: none"> <li>■ Determination of dynamically caused position deviation through axis acceleration</li> <li>■ Compensation of the TCP</li> </ul> |
|---------------------------------------|---|

#### Position Adaptive Control (PAC) software option (option number 142)

---

- |                                    |   |
|------------------------------------|---|
| <b>Changing control parameters</b> | <ul style="list-style-type: none"> <li>■ Changing of the control parameters depending on the position of the axes in the working space</li> <li>■ Changing of the control parameters depending on the speed or acceleration of an axis</li> </ul> |
|------------------------------------|---|

#### Load Adaptive Control (LAC) software option (option number 143)

---

- |   |  |
|---|--|
| <b>Dynamic changing of control parameters</b> | <ul style="list-style-type: none"> <li>■ Automatic determination of workpiece weight and frictional forces</li> <li>■ Continuous adaptation of the parameters of the adaptive precontrolling to the actual weight of the workpiece during machining</li> </ul> |
|---|--|

#### Active Chatter Control (ACC) software option (option number 145)

---

Fully automatic function for chatter control during machining



### Input format and unit of TNC functions

<b>Positions, coordinates, circle radii, chamfer lengths</b>	-99 999.9999 to +99 999.9999 (5, 4: places before the decimal point, places after the decimal point) [mm]
<b>Tool numbers</b>	0 to 32 767.9 (5, 1)
<b>Tool names</b>	16 characters, enclosed by quotation marks with <b>TOOL CALL</b> . Permitted special characters: #, \$, %, &, -
<b>Delta values for tool compensation</b>	-99.9999 to +99.9999 (2, 4) [mm]
<b>Spindle speeds</b>	0 to 99 999.999 (5, 3) [rpm]
<b>Feed rates</b>	0 to 99 999.999 (5.3) [mm/min] or [mm/tooth] or [mm/rev]
<b>Dwell time in Cycle 9</b>	0 to 3600.000 (4, 3) [s]
<b>Thread pitch in various cycles</b>	-99.9999 to +99.9999 (2, 4) [mm]
<b>Angle of spindle orientation</b>	0 to 360.0000 (3, 4) [°]
<b>Angle for polar coordinates, rotation, tilting the working plane</b>	-360.0000 to 360.0000 (3, 4) [°]
<b>Polar coordinate angle for helical interpolation (CP)</b>	-5 400.0000 to 5 400.0000 (4, 4) [°]
<b>Datum numbers in Cycle 7</b>	0 to 2999 (4, 0)
<b>Scaling factor in Cycles 11 and 26</b>	0.000001 to 99.999999 (2, 6)
<b>Miscellaneous functions M</b>	0 to 999 (4, 0)
<b>Q parameter numbers</b>	0 to 1999 (4, 0)
<b>Q parameter values</b>	-99 999.9999 to +99 999.9999 (9, 6)
<b>Surface-normal vectors N and T with 3-D compensation</b>	-9.99999999 to +9.99999999 (1, 8)
<b>Labels (LBL) for program jumps</b>	0 to 999 (5, 0)
<b>Labels (LBL) for program jumps</b>	Any text string in quotes (" ")
<b>Number of program section repeats REP</b>	1 to 65 534 (5, 0)
<b>Error number with Q parameter function FN14</b>	0 to 1199 (4, 0)

## Tables and overviews

### 19.4 Overview tables

#### 19.4 Overview tables

##### Fixed cycles

Cycle number	Cycle designation	DEF active	CALL active
7	Datum shift	■	
8	Mirror image	■	
9	Dwell time	■	
10	Rotation	■	
11	Scaling factor	■	
12	Program call	■	
13	Spindle orientation	■	
14	Contour definition	■	
19	Tilting the working plane	■	
20	Contour data SL II	■	
21	Pilot drilling SL II		■
22	Rough out SL II		■
23	Floor finishing SL II		■
24	Side finishing SL II		■
25	Contour train		■
26	Axis-specific scaling	■	
27	Cylinder surface		■
28	Cylindrical surface slot		■
29	Cylinder surface ridge		■
32	Tolerance	■	
200	Drilling		■
201	Reaming		■
202	Boring		■
203	Universal drilling		■
204	Back boring		■
205	Universal pecking		■
206	Tapping with a floating tap holder, new		■
207	Rigid tapping, new		■
208	Bore milling		■
209	Tapping with chip breaking		■
220	Polar pattern	■	
221	Cartesian pattern	■	
230	Multipass milling		■
231	Ruled surface		■
232	Face milling		■

Cycle number	Cycle designation	DEF active	CALL active
233	Face milling (selectable machining direction, consider the sides)		■
240	Centering		■
241	Single-lip deep-hole drilling		■
247	Datum setting	■	
251	Rectangular pocket (complete machining)		■
252	Circular pocket (complete machining)		■
253	Slot milling		■
254	Circular slot		■
256	Rectangular stud (complete machining)		■
257	Circular stud (complete machining)		■
262	Thread milling		■
263	Thread milling/countersinking		■
264	Thread drilling/milling		■
265	Helical thread drilling/milling		■
267	Outside thread milling		■
275	Trochoidal slot		■

### Miscellaneous functions

M	Effect	Effective at block...	Start	End	Page
<b>M0</b>	Program STOP/Spindle STOP/Coolant OFF			■	329
<b>M1</b>	Optional program run STOP/Spindle STOP/Coolant OFF			■	548
<b>M2</b>	Program run STOP/Spindle STOP/Coolant OFF/CLEAR status display (depending on machine parameter)/Return jump to block 1			■	329
<b>M3</b>	Spindle ON clockwise		■		329
M4	Spindle ON counterclockwise		■		
M5	Spindle STOP			■	
<b>M6</b>	Tool change/STOP program run (depending on machine parameter)/Spindle STOP			■	329
<b>M8</b>	Coolant on		■		329
M9	Coolant off			■	
<b>M13</b>	Spindle ON clockwise /coolant ON		■		329
M14	Spindle ON counterclockwise/coolant on		■		
<b>M30</b>	Same function as M2			■	329
<b>M89</b>	Vacant miscellaneous function <b>or</b> cycle call, modally effective (depending on MPs)		■	■	
<b>M91</b>	Within the positioning block: Coordinates are referenced to machine datum		■		330
<b>M92</b>	Within the positioning block: Coordinates are referenced to position defined by machine tool builder, such as tool change position		■		330

## Tables and overviews

### 19.4 Overview tables

M	Effect	Effective at block...	Start	End	Page
<b>M94</b>	Reduce the rotary axis display to a value below 360°		■		"Example NC blocks"
<b>M97</b>	Machine small contour steps			■	333
<b>M98</b>	Machine open contours completely			■	334
<b>M99</b>	Blockwise cycle call			■	Cycles Manual
<b>M101</b>	Automatic tool change with replacement tool if maximum tool life has expired			■	178
M102	Reset M101			■	
<b>M107</b>	Suppress error message for replacement tools with oversize			■	178
M108	Reset M107			■	
<b>M109</b>	Constant contouring speed at cutting edge (feed rate increase and reduction)		■		337
M110	Constant contouring speed at cutting edge (only feed rate reduction)		■		
M111	Reset M109/M110			■	
<b>M116</b>	Feed rate in mm/min on rotary axes		■		407
M117	Reset M116			■	
<b>M118</b>	Superimpose handwheel positioning during program run		■		340
<b>M120</b>	Pre-calculate the radius-compensated contour (LOOK AHEAD)		■		338
<b>M126</b>	Shorter-path traverse of rotary axes:		■		408
M127	Reset M126			■	
<b>M128</b>	Maintaining the position of the tool tip when positioning with tilted axes (TCPM)		■		410
M129	Reset M128			■	
<b>M130</b>	Within the positioning block: Points are referenced to the untilted coordinate system		■		332
<b>M138</b>	Selection of tilted axes		■		413
<b>M140</b>	Retraction from the contour in the tool-axis direction		■		342
<b>M143</b>	Delete basic rotation		■		344
<b>M144</b>	Compensating the machine's kinematic configuration for ACTUAL/NOMINAL positions at end of block		■		414
M145	Reset M144			■	
<b>M141</b>	Suppress touch probe monitoring		■		343
<b>M148</b>	Automatically retract tool from the contour at an NC stop		■		345
M149	Reset M148			■	

## 19.5 Functions of the TNC 640 and the iTNC 530 compared

### Comparison: Specifications

Function	TNC 640	iTNC 530
Axes	18 maximum	18 maximum
<b>Input resolution and display step:</b>		
<ul style="list-style-type: none"> <li>■ Linear axes</li> <li>■ Rotary axes</li> </ul>	<ul style="list-style-type: none"> <li>■ 0.1µm, 0.01 µm with option 23</li> <li>■ 0.001°, 0.00001° with option 23</li> </ul>	<ul style="list-style-type: none"> <li>■ 0.1 µm</li> <li>■ 0.0001°</li> </ul>
Control loops for high-frequency spindles and torque/linear motors	With option 49	With option 49
Display	19-inch TFT color flat-panel display or	19-inch TFT color flat-panel display or 15.1-inch TFT color flat-panel display
Memory media for NC, PLC programs and system files	Hard disk or SSDR solid state disk	Hard disk or SSDR solid state disk
Program memory for NC programs	> 21 GB	> 21 GB
Block processing time	0.5 ms	0.5 ms
HeROS operating system	yes	yes
Windows XP operating system	no	Option
<b>Interpolation:</b>		
<ul style="list-style-type: none"> <li>■ Straight line</li> <li>■ Circle</li> <li>■ Helix</li> <li>■ Spline</li> </ul>	<ul style="list-style-type: none"> <li>■ 5 axes</li> <li>■ 3 axes</li> <li>■ yes</li> <li>■ no</li> </ul>	<ul style="list-style-type: none"> <li>■ 5 axes</li> <li>■ 3 axes</li> <li>■ yes</li> <li>■ Yes with option 9</li> </ul>
Hardware	modular in electrical cabinet	Modular in electrical cabinet

### Comparison: Data interfaces

Function	TNC 640	iTNC 530
Gigabit Ethernet 1000BaseT	X	X
RS-232-C/V.24 serial interface	X	X
RS-422/V.11 serial interface	-	X
USB interface	X	X

## Tables and overviews

### 19.5 Functions of the TNC 640 and the iTNC 530 compared

#### Comparison: Accessories

Function	TNC 640	iTNC 530
<b>Electronic handwheels</b>		
■ HR 410	■ X	■ X
■ HR 420	■ X	■ X
■ HR 520/530/550	■ X	■ X
■ HR 130	■ X	■ X
■ HR 150 via HRA 110	■ X	■ X
<b>Touch probes</b>		
■ TS 220	■ X	■ X
■ TS 440	■ X	■ X
■ TS 444	■ X	■ X
■ TS 449 / TT 449	■ X	■ X
■ TS 640	■ X	■ X
■ TS 740	■ X	■ X
■ TT 130 / TT 140	■ X	■ X
Industrial PC <b>IPC 61xx</b>	–	X

#### Comparison: PC software

Function	TNC 640	iTNC 530
Programming station software	Available	Available
<b>TNCremoNT</b> for data transfer with <b>TNCbackup</b> for data backup	Available	Available
<b>TNCremoPlus</b> data transfer software with "live" screen	Available	Available
<b>RemoTools SDK 1.2:</b> Function library for developing your own applications for communicating with HEIDENHAIN controls	Limited functionality available	Available
<b>virtualTNC:</b> Control component for virtual machines	Not available	Available
<b>ConfigDesign:</b> Software for configuring the control	Available	Not available
<b>TeleService:</b> Software for remote diagnostics and maintenance	Available	Available

**Comparison: Machine-specific functions**

Function	TNC 640	iTNC 530
Switching the traverse range	Function available	Function available
Central drive (1 motor for multiple machine axes)	Function available	Function available
C-axis operation (spindle motor drives rotary axis)	Function available	Function available
Automatic exchange of milling head	Function available	Function available
Support of angle heads	Function not available	Function available
Balluf tool identification	Function available (with Python)	Function available
Management of multiple tool magazines	Function available	Function available
Expanded tool management via Python	Function available	Function available

**Comparison: User functions**

Function	TNC 640	iTNC 530
<b>Program entry</b>		
■ HEIDENHAIN conversational	■ X	■ X
■ DIN/ISO	■ X	■ X
■ With smarTNC	■ –	■ X
■ With ASCII editor	■ X, directly editable	■ X, editable after conversion
<b>Position entry</b>		
■ Nominal positions for lines and arcs in Cartesian coordinates	■ X	■ X
■ Nominal positions for lines and arcs in polar coordinates	■ X	■ X
■ Incremental or absolute dimensions	■ X	■ X
■ Display and entry in mm or inches	■ X	■ X
■ Set the last tool position as pole (empty CC block)	■ X (error message if pole transfer is ambiguous)	■ X
■ Surface normal vectors ( <b>LN</b> )	■ X	■ X
■ Spline blocks ( <b>SPL</b> )	■ –	■ X, with option 09

## Tables and overviews

### 19.5 Functions of the TNC 640 and the iTNC 530 compared

Function	TNC 640	iTNC 530
<b>Tool compensation</b>		
■ In the working plane, and tool length	■ X	■ X
■ Radius compensated contour look ahead for up to 99 blocks	■ X	■ X
■ Three-dimensional tool radius compensation	■ X, with option 09	■ X, with option 09
<b>Tool table</b>		
■ Central storage of tool data	■ X	■ X
■ Multiple tool tables with any number of tools	■ X	■ X
■ Flexible management of tool types	■ X	■ –
■ Filtered display of selectable tools	■ X	■ –
■ Sorting function	■ X	■ –
■ Column names	■ Sometimes with _	■ Sometimes with -
■ Copy function: Overwriting relevant tool data	■ X	■ X
■ Form view	■ Switchover with split-screen layout key	■ Switchover by soft key
■ Exchange of tool table between TNC 640 and iTNC 530	■ X	■ Not possible
Touch-probe table for managing different 3-D touch probes	X	–
<b>Creating tool-usage file, checking the availability</b>	X	X
<b>Cutting data calculation</b> Automatic calculation of spindle speed and feed rate	Simple cutting data calculator	Using technology tables
<b>Define any tables</b>	<ul style="list-style-type: none"> <li>■ Freely definable tables (.TAB files)</li> <li>■ Reading and writing with FN functions</li> <li>■ Definable via config. data</li> <li>■ Table names must start with a letter</li> <li>■ Reading and writing with SQL functions</li> </ul>	<ul style="list-style-type: none"> <li>■ Freely definable tables (.TAB files)</li> <li>■ Reading and writing with FN functions</li> </ul>



## Functions of the TNC 640 and the iTNC 530 compared 19.5

Function	TNC 640	iTNC 530
<b>Constant contouring speed:</b> Relative to the path of the tool center or relative to the tool's cutting edge	X	X
<b>Parallel operation:</b> Creating programs while another program is being run	X	X
<b>Programming of counter axes</b>	X	X
<b>Tilting the working plane (Cycle 19, PLANE function)</b>	X, option #08	X, option #08
<b>Machining with rotary tables</b>		
■ Programming of cylindrical contours as if in two axes		
■ Cylinder Surface (Cycle 27)	■ X, option #08	■ X, option #08
■ Cylinder Surface Slot (Cycle 28)	■ X, option #08	■ X, option #08
■ Cylinder Surface Ridge (Cycle 29)	■ X, option #08	■ X, option #08
■ Cylinder Surface External Contour (Cycle 39)	■ –	■ X, option #08
■ Feed rate in mm/min or rev/min	■ X, option #08	■ X, option #08
<b>Traverse in tool-axis direction</b>		
■ Manual operation (3-D ROT menu)	■ X	■ X, FCL2 function
■ During program interruption	■ X	■ X
■ With handwheel superimpositioning	■ X	■ X, option #44
<b>Approaching and departing the contour:</b> Via a straight line or arc	X	X
<b>Entry of feed rates:</b>		
■ <b>F</b> (mm/min), rapid traverse <b>FMAX</b>	■ X	■ X
■ <b>FU</b> (feed per revolution mm/rev)	■ X	■ X
■ <b>FZ</b> (tooth feed rate)	■ X	■ X
■ <b>FT</b> (time in seconds for path)	■ –	■ X
■ <b>FMAXT</b> (only for active rapid traverse pot: time in seconds for path)	■ –	■ X
<b>FK free contour programming</b>		
■ Programming for workpiece drawings not dimensioned for NC programming	■ X	■ X
■ Conversion of FK program to conversational dialog	■ –	■ X
<b>Program jumps:</b>		
■ Maximum number of label numbers	■ 9999	■ 1000
■ Subprograms	■ X	■ X
■ Nesting depth for subprograms	■ 20	■ 6
■ Program section repeats	■ X	■ X
■ Any desired program as subroutine	■ X	■ X

## Tables and overviews

### 19.5 Functions of the TNC 640 and the iTNC 530 compared

Function	TNC 640	iTNC 530
<b>Q parameter programming:</b>		
■ Standard mathematical functions	■ X	■ X
■ Formula entry	■ X	■ X
■ String processing	■ X	■ X
■ Local Q parameters <b>QL</b>	■ X	■ X
■ Nonvolatile Q parameters <b>QR</b>	■ X	■ X
■ Changing parameters during program interruption	■ X	■ X
■ FN15:PRINT	■ –	■ X
■ FN25:PRESET	■ –	■ X
■ FN26:TABOPEN	■ X	■ X
■ FN27:TABWRITE	■ X	■ X
■ FN28:TABREAD	■ X	■ X
■ FN29: PLC LIST	■ X	■ –
■ FN31: RANGE SELECT	■ –	■ X
■ FN32: PLC PRESET	■ –	■ X
■ FN37:EXPORT	■ X	■ –
■ FN38: SEND	■ –	■ X
■ Saving file externally with <b>FN16</b>	■ –	■ X
■ <b>FN16</b> formatting: Left-aligned, right-aligned, string lengths	■ –	■ X
■ Writing to LOG file with <b>FN16</b>	■ X	■ –
■ Displaying parameter contents in the additional status display	■ X	■ –
■ Displaying parameter contents during programming (Q-INFO)	■ X	■ X
■ <b>SQL</b> functions for writing and reading tables	■ X	■ –

## Functions of the TNC 640 and the iTNC 530 compared 19.5

Function	TNC 640	iTNC 530
<b>Graphic support</b>		
■ 2-D programming graphics	■ X	■ X
■ REDRAW function	■ –	■ X
■ Show grid lines as the background	■ X	■ –
■ 3-D line graphics	■ X	■ X
■ Test graphics (plan view, projection in 3 planes, 3-D view)	■ X	■ X
■ High-resolution view	■ X	■ X
■ Tool display	■ X	■ X
■ Set the simulation speed	■ X	■ X
■ Coordinates of line intersection for projection in 3 planes	■ –	■ X
■ Expanded zoom functions (mouse operation)	■ X	■ X
■ Displaying frame for workpiece blank	■ X	■ X
■ Displaying the depth value in plan view during mouse-over	■ –	■ X
■ Targeted stop of test run (STOP AT N)	■ –	■ X
■ Consideration of tool change macro	■ –	■ X
■ Program run graphics (plan view, projection in 3 planes, 3-D view)	■ X	■ X
■ High-resolution view	■ X	■ X

## Tables and overviews

### 19.5 Functions of the TNC 640 and the iTNC 530 compared

Function	TNC 640	iTNC 530
<b>Datum tables:</b> for storing workpiece-related datums	X	X
<b>Preset table:</b> for saving reference points (presets)	X	X
<b>Pallet management</b>		
■ Support of pallet files	■ X	■ X
■ Tool-oriented machining	■ –	■ X
■ Pallet preset table: for managing pallet datums	■ –	■ X
<b>Returning to the contour</b>		
■ With mid-program startup	■ X	■ X
■ After program interruption	■ X	■ X
<b>Autostart function</b>		
<b>Actual position capture:</b> Actual positions can be transferred to the NC program	X	X
<b>Enhanced file management</b>		
■ Creating multiple directories and subdirectories	■ X	■ X
■ Sorting function	■ X	■ X
■ Mouse operation	■ X	■ X
■ Selection of target directory by soft key	■ X	■ X
<b>Programming aids:</b>		
■ Help graphics for cycle programming	■ X	■ X
■ Animated help graphics when <b>PLANE/PATTERN DEF</b> function is selected	■ –	■ X
■ Help graphics for <b>PLANE/PATTERN DEF</b>	■ X	■ X
■ Context-sensitive help function for error messages	■ X	■ X
■ <b>TNCguide:</b> Browser-based help system	■ X	■ X
■ Context-sensitive call of help system	■ X	■ X
■ Calculator	■ X (scientific)	■ X (standard)
■ Comment blocks in NC program	■ X	■ X
■ Structure blocks in NC program	■ X	■ X
■ Structure view in test run	■ –	■ X
<b>Dynamic Collision Monitoring (DCM):</b>		
■ Collision monitoring in Automatic operation	■ X, option #40	■ X, option #40
■ Collision monitoring in Manual operation	■ X, option #40	■ X, option #40
■ Graphic depiction of the defined collision objects	■ X, option #40	■ X, option #40
■ Collision checking in the Test Run mode	■ –	■ X, option #40
■ Fixture monitoring	■ –	■ X, option #40
■ Tool carrier management	■ –	■ X, option #40

## Functions of the TNC 640 and the iTNC 530 compared 19.5

Function	TNC 640	iTNC 530
<b>CAM support:</b>		
■ Loading of contours from DXF data	■ X, option #42	■ X, option #42
■ Loading of machining positions from DXF data	■ X, option 42	■ X, option #42
■ Offline filter for CAM files	■ –	■ X
■ Stretch filter	■ X	■ –
<b>MOD functions:</b>		
■ User parameters	■ Config data	■ Numerical structure
■ OEM help files with service functions	■ –	■ X
■ Data medium inspection	■ –	■ X
■ Load service packs	■ –	■ X
■ Setting the system time	■ X	■ X
■ Select the axes for actual position capture	■ –	■ X
■ Definition of traverse range limits	■ –	■ X
■ Restricting external access	■ X	■ X
■ Switching the kinematics	■ X	■ X
<b>Calling fixed cycles:</b>		
■ With <b>M99</b> or <b>M89</b>	■ X	■ X
■ With <b>CYCL CALL</b>	■ X	■ X
■ With <b>CYCL CALL PAT</b>	■ X	■ X
■ With <b>CYC CALL POS</b>	■ X	■ X
<b>Special functions:</b>		
■ Creating backward programs	■ –	■ X
■ Datum shift with <b>TRANS DATUM</b>	■ X	■ X
■ Adaptive Feed Control AFC	■ X, option #45	■ X, option #45
■ Global definition of cycle parameters: <b>GLOBAL DEF</b>	■ X	■ X
■ Pattern definition with <b>PATTERN DEF</b>	■ X	■ X
■ Definition and execution of point tables	■ X	■ X
■ Simple contour formula <b>CONTOUR DEF</b>	■ X	■ X
<b>Functions for large molds and dies:</b>		
■ Global program settings (GS)	■ –	■ X, option #44
■ Expanded <b>M128: FUNCTION TCPM</b>	■ X	■ X
<b>Status displays:</b>		
■ Positions, spindle speed, feed rate	■ X	■ X
■ Larger depiction of position display, Manual Operation	■ X	■ X
■ Additional status display, form view	■ X	■ X
■ Display of handwheel traverse when machining with handwheel superimposition	■ X	■ X
■ Display of distance-to-go in a tilted system	■ –	■ X

## Tables and overviews

### 19.5 Functions of the TNC 640 and the iTNC 530 compared

Function	TNC 640	iTNC 530
■ Dynamic display of Q-parameter contents, definable number ranges	■ X	■ –
■ OEM-specific additional status display via Python	■ X	■ X
■ Graphic display of residual run time	■ –	■ X
Individual color settings of user interface	–	X

#### Comparator: Cycles

Cycle	TNC 640	iTNC 530
1, Pecking	X	X
2, Tapping	X	X
3, Slot milling	X	X
4, Pocket milling	X	X
5, Circular pocket	X	X
6, Rough out (SL I, recommended: SL II, Cycle 22)	–	X
7, Datum shift	X	X
8, Mirror image	X	X
9, Dwell time	X	X
10, Rotation	X	X
11, Scaling	X	X
12, Program call	X	X
13, Spindle orientation	X	X
14, Contour definition	X	X
15, Pilot drilling (SL I, recommended: SL II, Cycle 21)	–	X
16, Contour milling (SL I, recommended: SL II, Cycle 24)	–	X
17, tapping (controlled spindle)	X	X
18, Thread cutting	X	X
19, Working plane	X, option #08	X, option #08
20, Contour data	X	X
21, Pilot drilling	X	X
22, rough-out:	X	X
■ Parameter Q401, feed rate factor	■ –	■ X
■ Parameter Q404, fine roughing strategy	■ –	■ X
23, Floor finishing	X	X
24, Side finishing	X	X
25, Contour train	X	X
26, Axis-specific scaling	X	X
27, contour surface	X, option #08	X, option #08
28, Cylinder surface	X, option #08	X, option #08
29, Cylinder surface ridge	X, option #08	X, option #08

## Functions of the TNC 640 and the iTNC 530 compared 19.5

Cycle	TNC 640	iTNC 530
30, run 3-D data	–	X
32, tolerance with HSC mode and TA	X	X
39, Cylinder surface external contour	–	X, option #08
200, Drilling	X	X
201, Reaming	X	X
202, Boring	X	X
203, Universal drilling	X	X
204, Back boring	X	X
205, Universal pecking	X	X
206, Tapping with floating tap holder, new	X	X
207, Rigid tapping, new	X	X
208, Bore milling	X	X
209, Tapping with chip breaking	X	X
210, Slot with reciprocating plunge	X	X
211, Circular slot	X	X
212, Rectangular pocket finishing	X	X
213, Rectangular stud finishing	X	X
214, Circular pocket finishing	X	X
215, Circular stud finishing	X	X
220, Polar pattern	X	X
221, Cartesian pattern	X	X
225, Engraving	X	X
230, Multipass milling	X	X
231, Ruled surface	X	X
232, Face milling	X	X
233, Face milling, new	X	–
240, Centering	X	X
241, single-lip deep-hole drilling	X	X
247, Datum setting	X	X
251, Rectangular pocket (complete)	X	X
252, Circular pocket (complete)	X	X
253, Slot milling (complete)	X	X
254, Circular slot (complete)	X	X
256, Rectangular stud (complete)	X	X
257, Circular stud (complete)	X	X
262, Thread milling	X	X
263, Thread milling/counter sinking	X	X
264, Thread drilling/milling	X	X
265, Helical thread drilling/milling	X	X

## Tables and overviews

### 19.5 Functions of the TNC 640 and the iTNC 530 compared

Cycle	TNC 640	iTNC 530
267, outside thread milling	X	X
270, contour train data for defining the behavior of Cycle 25	–	X
275, trochoidal milling	X	X
276, 3-D contour train	–	X
290, Interpolation turning	–	X, option 96
800, Adapt rotary coordinate system	X	–
801, Reset rotary coordinate system	X	–
810, Turn contour, longitudinal	X	–
811, Turn shoulder, longitudinal	X	–
812, Turn shoulder, longitudinal extended	X	–
813, Turn, longitudinal plunge	X	–
814, Turn, longitudinal plunge extended	X	–
815, Turn contour-parallel	X	–
820, Turn contour, transverse	X	–
821, Turn shoulder face	X	–
822, Turn shoulder face extended	X	–
823, Turn, transverse plunge	X	–
824, Turn, transverse plunge extended	X	–
830, Thread, contour-parallel	X	–
831, Thread, longitudinal	X	–
832, Thread, extended	X	–
840, Recessing contour, radial	X	–
841, Recessing simple, radial	X	–
842, Recessing, radial extended	X	–
850, Recessing contour, axial	X	–
851, Recessing simple axial	X	–
852, Recessing axial extended	X	–
860, Recessing contour, radial	X	–
861, Recessing, radial	X	–
862, Recessing, radial extended	X	–
870, Recessing contour, axial	X	–
871, Recessing, axial	X	–
872, Recessing, axial extended	X	–



### Comparison: Miscellaneous functions

M	Effect	TNC 640	iTNC 530
<b>M00</b>	Program STOP/Spindle STOP/Coolant OFF	X	X
<b>M01</b>	Optional program STOP	X	X
<b>M02</b>	Program run STOP/Spindle STOP/Coolant OFF/CLEAR status display (depending on machine parameter)/Return jump to block 1	X	X
<b>M03</b>	Spindle ON clockwise	X	X
M04	Spindle ON counterclockwise		
M05	Spindle STOP		
<b>M06</b>	Tool change/Stop program run (machine-dependent function)/Spindle STOP	X	X
<b>M08</b>	Coolant on	X	X
M09	Coolant off		
<b>M13</b>	Spindle ON clockwise /coolant ON	X	X
M14	Spindle ON counterclockwise/coolant on		
<b>M30</b>	Same function as M02	X	X
<b>M89</b>	Vacant miscellaneous function <b>or</b> cycle call, modally effective (machine-dependent function)	X	X
<b>M90</b>	Constant contouring speed at corners (not required at TNC 640)	–	X
<b>M91</b>	Within the positioning block: Coordinates are referenced to machine datum	X	X
<b>M92</b>	Within the positioning block: Coordinates are referenced to position defined by machine tool builder, such as tool change position	X	X
<b>M94</b>	Reduce the rotary axis display to a value below 360°	X	X
<b>M97</b>	Machine small contour steps	X	X
<b>M98</b>	Machine open contours completely	X	X
<b>M99</b>	Blockwise cycle call	X	X
<b>M101</b>	Automatic tool change with replacement tool if maximum tool life has expired	X	X
M102	Reset M101		
<b>M103</b>	Reduce feed rate during plunging to factor F (percentage)	X	X
<b>M104</b>	Reactivate most recently set datum	–	X
<b>M105</b>	Machining with second $k_v$ factor	–	X
M106	Machining with first $k_v$ factor		
<b>M107</b>	Suppress error message for replacement tools with oversize	X	X
M108	Reset M107		
<b>M109</b>	Constant contouring speed at cutting edge (feed rate increase and reduction)	X	X
M110	Constant contouring speed at cutting edge (only feed rate reduction)		
M111	Reset M109/M110		
<b>M112</b>	Enter contour transition between two contour elements	–	X
M113	Reset M112	(recommended: Cycle 32)	

## Tables and overviews

### 19.5 Functions of the TNC 640 and the iTNC 530 compared

M	Effect	TNC 640	iTNC 530
<b>M114</b> M115	Automatic compensation of machine geometry when working with tilted axes Reset M114	– (recommended: M128, TCPM)	X, option #08
<b>M116</b> M117	Feed rate on rotary tables in mm/min Reset M116	X, option #08	X, option #08
<b>M118</b>	Superimpose handwheel positioning during program run	X	X
<b>M120</b>	Pre-calculate the radius-compensated contour (LOOK AHEAD)	X	X
<b>M124</b>	Contour filter	– (possible via user parameters)	X
<b>M126</b> M127	Shorter-path traverse of rotary axes: Reset M126	X	X
<b>M128</b> M129	Maintaining the position of the tool tip when positioning with tilted axes (TCPM) Reset M128	X, option #09	X, option #09
<b>M130</b>	Within the positioning block: Points are referenced to the untilted coordinate system	X	X
<b>M134</b> M135	Exact stop at nontangential contour transitions when positioning with rotary axes Reset M134	–	X
<b>M136</b> M137	Feed rate F in millimeters per spindle revolution Reset M136	X	X
<b>M138</b>	Selection of tilted axes	X	X
<b>M140</b>	Retraction from the contour in the tool-axis direction	X	X
<b>M141</b>	Suppress touch probe monitoring	X	X
<b>M142</b>	Delete modal program information	–	X
<b>M143</b>	Delete basic rotation	X	X
<b>M144</b> M145	Compensating the machine's kinematic configuration for ACTUAL/NOMINAL positions at end of block Reset M144	X, option #09	X, option #09
<b>M148</b> M149	Automatically retract tool from the contour at an NC stop Reset M148	X	X
<b>M150</b>	Suppress limit switch message	– (possible via FN 17)	X
<b>M197</b>	Rounding the corners	X	–
<b>M200</b> <b>-M204</b>	Laser cutting functions	–	X

#### Comparison: Touch probe cycles in the Manual Operation and El. Handwheel modes

Cycle	TNC 640	iTNC 530
Touch-probe table for managing 3-D touch probes	X	–
Calibrating the effective length	X	X
Calibrating the effective radius	X	X

## Functions of the TNC 640 and the iTNC 530 compared 19.5

<b>Cycle</b>	<b>TNC 640</b>	<b>iTNC 530</b>
Measuring a basic rotation using a line	X	X
Set the datum in any axis	X	X
Setting a corner as datum	X	X
Setting a circle center as datum	X	X
Setting a center line as datum	X	X
Measuring a basic rotation using two holes/cylindrical studs	X	X
Setting the datum using four holes/cylindrical studs	X	X
Setting the circle center using three holes/cylindrical studs	X	X
Support of mechanical touch probes by manually capturing the current position	By soft key	By hard key
Writing measured values in preset table	X	X
Writing measured values in datum tables	X	X

## Tables and overviews

### 19.5 Functions of the TNC 640 and the iTNC 530 compared

#### Comparison: Touch probe cycles for automatic workpiece inspection

Cycle	TNC 640	iTNC 530
0, reference plane	X	X
1, polar datum	X	X
2, calibrating TS	–	X
3, measuring	X	X
4, measuring in 3-D	X	X
9, calibrating TS length	–	X
30, calibrating TT	X	X
31, measuring tool length	X	X
32, measuring tool radius	X	X
33, measuring tool length and radius	X	X
400, basic rotation	X	X
401, basic rotation from two holes	X	X
402, basic rotation from two studs	X	X
403, compensating a basic rotation via a rotary axis	X	X
404, setting a basic rotation	X	X
405, compensating workpiece misalignment by rotating the C axis	X	X
408, slot center datum	X	X
409, ridge center datum	X	X
410, datum from inside of rectangle	X	X
411, datum from outside of rectangle	X	X
412, datum from inside of circle	X	X
413, datum from outside of circle	X	X
414, datum at outside corner	X	X
415, datum at inside corner	X	X
416, datum at circle center	X	X
417, datum in touch probe axis	X	X
418, datum at center of 4 holes	X	X
419, datum in one axis	X	X
420, measuring an angle	X	X
421, measuring a hole	X	X
422, measuring a circle from outside	X	X
423, measuring a rectangle from inside	X	X
424, measuring a rectangle from outside	X	X
425, measuring inside width	X	X
426, measuring a ridge from outside	X	X
427, boring	X	X
430, measuring a bolt hole circle	X	X

## Functions of the TNC 640 and the iTNC 530 compared 19.5

Cycle	TNC 640	iTNC 530
431, measuring a plane	X	X
440, measuring an axis shift	–	X
441, Rapid probing (on TNC 640 partly possible with touch probe table)	–	X
450, saving the kinematics	X, option 48	X, option 48
451, measuring the kinematics	X, option 48	X, option 48
452, preset compensation	X, option 48	X, option 48
460, calibrating a TS on a sphere	X	X
461, calibrate TS length	X	X
462, calibration in a ring	X	X
463, calibration on stud	X	X
480, calibrating a TT	X	X
481, measuring/inspecting the tool length	X	X
482, measuring/inspecting the tool radius	X	X
483, measuring/inspecting the tool length and radius	X	X
484, calibrating the infrared TT	X	X

### Comparison: Differences in programming

Function	TNC 640	iTNC 530
Switching the operating mode while a block is being edited	Permitted	Permitted
<b>File handling:</b>		
■ <b>Save file</b> function	■ Available	■ Available
■ <b>Save file as</b> function	■ Available	■ Available
■ Discard changes	■ Available	■ Available
<b>File management:</b>		
■ Mouse operation	■ Available	■ Available
■ Sorting function	■ Available	■ Available
■ Entry of name	■ Opens the <b>Select file</b> pop-up window	■ Synchronizes the cursor
■ Support of shortcuts	■ Not available	■ Available
■ Favorites management	■ Not available	■ Available
■ Configuration of column structure	■ Not available	■ Available
■ Soft-key arrangement	■ Slightly different	■ Slightly different
Skip block function	Available	Available
Selecting a tool from the table	Selection via split-screen menu	Selection in a pop-up window

## Tables and overviews

### 19.5 Functions of the TNC 640 and the iTNC 530 compared

Function	TNC 640	iTNC 530
Programming special functions with the <b>SPEC FCT</b> key	Pressing the key opens a soft-key row as a submenu. To exit the submenu, press the <b>SPEC FCT</b> key again; then the TNC shows the last active soft-key row	Pressing the key adds the soft-key row as the last row. To exit the menu, press the <b>SPEC FCT</b> key again; then the TNC shows the last active soft-key row
Programming approach and departure motions with the <b>APPR DEP</b> key	Pressing the key opens a soft-key row as a submenu. To exit the submenu, press the <b>APPR DEP</b> key again; then the TNC shows the last active soft-key row	Pressing the key adds the soft-key row as the last row. To exit the menu, press the <b>APPR DEP</b> key again; then the TNC shows the last active soft-key row
Pressing the <b>END</b> hard key while the <b>CYCLE DEF</b> and <b>TOUCH PROBE</b> menus are active	Terminates the editing process and calls the file manager	Exits the respective menu
Calling the file manager while the <b>CYCLE DEF</b> and <b>TOUCH PROBE</b> menus are active	Terminates the editing process and calls the file manager. The respective soft-key row remains selected when the file manager is exited	Error message <b>Key non-functional</b>
Calling the file manager while <b>CYCL CALL</b> , <b>SPEC FCT</b> , <b>PGM CALL</b> and <b>APPR/DEP</b> menus are active	Terminates the editing process and calls the file manager. The respective soft-key row remains selected when the file manager is exited	Terminates the editing process and calls the file manager. The basic soft-key row is selected when the file manager is exited

## Functions of the TNC 640 and the iTNC 530 compared 19.5

Function	TNC 640	iTNC 530
<b>Datum table:</b>		
■ Sorting function by values within an axis	■ Available	■ Not available
■ Resetting the table	■ Available	■ Not available
■ Hiding axes that are not present	■ Available	■ Available
■ Switching the list/form view	■ Switchover via split-screen key	■ Switchover by toggle soft key
■ Inserting individual line	■ Allowed everywhere, renumbering possible after request. Empty line is inserted, must be filled with zeros manually	■ Only allowed at end of table. Line with value 0 in all columns is inserted
■ Transfer of actual position values in individual axis to the datum table per keystroke	■ Not available	■ Available
■ Transfer of actual position values in all active axes to the datum table per keystroke	■ Not available	■ Available
■ Using a key to capture the last positions measured by TS	■ Not available	■ Available
<b>FK free contour programming:</b>		
■ Programming of parallel axes	■ With X/Y coordinates, independent of machine type; switchover with <b>FUNCTION PARAXMODE</b>	■ Machine-dependent with the existing parallel axes
■ Automatic correction of relative references	■ Relative references in contour subprograms are not corrected automatically	■ All relative references are corrected automatically

## Tables and overviews

### 19.5 Functions of the TNC 640 and the iTNC 530 compared

Function	TNC 640	iTNC 530
<b>Handling of error messages:</b>		
<ul style="list-style-type: none"> <li>■ Help with error messages</li> <li>■ Switching the operating mode while help menu is active</li> <li>■ Selecting the background operating mode while help menu is active</li> <li>■ Identical error messages</li> <li>■ Acknowledgment of error messages</li> <li>■ Access to protocol functions</li> <li>■ Saving service files</li> </ul>	<ul style="list-style-type: none"> <li>■ Call via <b>ERR</b> key</li> <li>■ Help menu is closed when the operating mode is switched</li> <li>■ Help menu is closed when F12 is used for switching</li> <li>■ Are collected in a list</li> <li>■ Every error message (even if it is displayed more than once) must be acknowledged, the <b>Delete all</b> function is available</li> <li>■ Log and powerful filter functions (errors, keystrokes) are available</li> <li>■ Available. No service file is created when the system crashes</li> </ul>	<ul style="list-style-type: none"> <li>■ Call via <b>HELP</b> key</li> <li>■ Operating mode switchover is not allowed (key is non-functional)</li> <li>■ Help menu remains open when F12 is used for switching</li> <li>■ Are displayed only once</li> <li>■ Error message to be acknowledged only once</li> <li>■ Complete log without filter functions available</li> <li>■ Available. A service file is automatically created when the system crashes</li> </ul>



## Functions of the TNC 640 and the iTNC 530 compared 19.5

Function	TNC 640	iTNC 530
<b>Find function:</b>		
<ul style="list-style-type: none"> <li>■ List of words recently searched for</li> <li>■ Show elements of active block</li> <li>■ Show list of all available NC blocks</li> </ul>	<ul style="list-style-type: none"> <li>■ Not available</li> <li>■ Not available</li> <li>■ Not available</li> </ul>	<ul style="list-style-type: none"> <li>■ Available</li> <li>■ Available</li> <li>■ Available</li> </ul>
Starting the find function with the up/down arrow keys when highlight is on a block	Works with max. 9999 blocks, can be set via config datum	No limitation regarding program length
<b>Programming graphics:</b>		
<ul style="list-style-type: none"> <li>■ True-to-scale display of grid</li> <li>■ Editing contour subprograms in SLII cycles with <b>AUTO DRAW ON</b></li> <li>■ Moving the zoom window</li> </ul>	<ul style="list-style-type: none"> <li>■ Available</li> <li>■ If error messages occur, the cursor is on the <b>CYCL CALL</b> block in the main program</li> <li>■ Repeat function not available</li> </ul>	<ul style="list-style-type: none"> <li>■ Not available</li> <li>■ If error messages occur, the cursor is on the error-causing block in the contour subprogram</li> <li>■ Repeat function available</li> </ul>
<b>Programming minor axes:</b>		
<ul style="list-style-type: none"> <li>■ Syntax <b>FUNCTION PARAXCOMP</b>: Define the behavior of the display and the paths of traverse</li> <li>■ Syntax <b>FUNCTION PARAXMODE</b>: Define the assignment of the parallel axes to be traversed</li> </ul>	<ul style="list-style-type: none"> <li>■ Available</li> <li>■ Available</li> </ul>	<ul style="list-style-type: none"> <li>■ Not available</li> <li>■ Not available</li> </ul>
<b>Programming OEM cycles</b>		
<ul style="list-style-type: none"> <li>■ Access to table data</li> <li>■ Access to machine parameters</li> <li>■ Creating interactive cycles with <b>CYCLE QUERY</b>, e.g. touch-probe cycles in Manual Operation mode</li> </ul>	<ul style="list-style-type: none"> <li>■ Via <b>SQL</b> commands and via <b>FN17/FN18</b> or <b>TABREAD-TABWRITE</b> functions</li> <li>■ With the <b>CFGREAD</b> function</li> <li>■ Available</li> </ul>	<ul style="list-style-type: none"> <li>■ Via <b>FN17/FN18</b> or <b>TABREAD-TABWRITE</b> functions</li> <li>■ Via <b>FN18</b> functions</li> <li>■ Not available</li> </ul>

## Tables and overviews

### 19.5 Functions of the TNC 640 and the iTNC 530 compared

#### Comparison: Differences in Test Run, functionality

Function	TNC 640	iTNC 530
Test Run up to block N	Function not available	Function available
Calculation of machining time	Each time the simulation is repeated by pressing the START soft key, the machining time is totaled	Each time the simulation is repeated by pressing the START soft key, time calculation starts at 0

#### Comparison: Differences in Test Run, operation

Function	TNC 640	iTNC 530
Arrangement of soft-key rows and soft keys within the rows	Arrangement of soft-key rows and soft-keys varies depending on the active screen layout.	
Zoom function	Each sectional plane can be selected by individual soft keys	Sectional plane can be selected via three toggle soft keys
Machine-specific miscellaneous functions M	Lead to error messages if they are not integrated in the PLC	Are ignored during Test Run
Displaying/editing the tool table	Function available via soft key	Function not available
3-D view Displays a transparent workpiece	Available	Function not available
3-D view Displays a transparent tool	Available	Function not available
3-D view Displays tool paths	Available	Function not available
Adjustable model quality	Available	Function not available

#### Comparison: Differences in Manual Operation, functionality

Function	TNC 640	iTNC 530
Jog increment function	The jog increment can be defined separately for linear and rotary axes	The jog increment applies for both linear and rotary axes
Preset table	Basic transformation (translation and rotation) of machine table system to workpiece system via the columns <b>X</b> , <b>Y</b> and <b>Z</b> , as well as spatial angles <b>SPA</b> , <b>SPB</b> and <b>SPC</b> . In addition, the columns <b>X_OFFS</b> to <b>W_OFFS</b> can be used to define the axis offset of each individual axis. The function of the axis offsets can be configured.	Basic transformation (translation ) of machine table system to workpiece system via the columns <b>X</b> , <b>Y</b> and <b>Z</b> , as well as a <b>ROT</b> basic rotation in the working plane (rotation). In addition, the columns <b>A</b> to <b>W</b> can be used to define datums in the rotary and parallel axes.

## Functions of the TNC 640 and the iTNC 530 compared 19.5

Function	TNC 640	iTNC 530
Behavior during presetting	<p>Presetting in a rotary axis has the same effect as an axis offset. The offset is also effective for kinematics calculations and for tilting the working plane.</p> <p>The machine parameter <b>CfgAxisPropKinn-&gt;presetToAlignAxis</b> is used to define whether the axis offset is to be taken into account internally after zero setting.</p> <p>Independently of this, an axis offset has always the following effects:</p> <ul style="list-style-type: none"> <li>■ An axis offset always influences the nominal position display of the affected axis (the axis offset is subtracted from the current axis value).</li> <li>■ If a rotary axis coordinate is programmed in an L block, then the axis offset is added to the programmed coordinate.</li> </ul>	<p>Rotary axis offsets defined by machine parameters do not influence the axis positions that were defined in the Tilt working plane function.</p> <p>MP7500 bit 3 defines whether the current rotary axis position referenced to the machine datum is taken into account, or whether a position of 0° is assumed for the first rotary axis (usually the C axis).</p>
<b>Handling of preset table:</b>		
<ul style="list-style-type: none"> <li>■ Editing the preset table in the Programming mode of operation</li> <li>■ Preset tables that depend on the range of traverse</li> </ul>	<ul style="list-style-type: none"> <li>■ Possible</li> <li>■ Not available</li> </ul>	<ul style="list-style-type: none"> <li>■ Not possible</li> <li>■ Available</li> </ul>
Definition of feed-rate limitation	Feed-rate limitation can be defined separately for linear and rotary axes	Only one feed-rate limitation can be defined for linear and rotary axes

## Tables and overviews

### 19.5 Functions of the TNC 640 and the iTNC 530 compared

#### Comparison: Differences in Manual Operation, operation

Function	TNC 640	iTNC 530
Capturing the position values from mechanical probes	Actual-position capture by soft key	Actual-position capture by hard key
Exiting the touch probe functions menu	Only via the <b>END</b> soft key	Via the <b>END</b> soft key or the <b>END</b> hard key

#### Comparison: Differences in Program Run, operation

Function	TNC 640	iTNC 530
Arrangement of soft-key rows and soft keys within the rows	Arrangement of soft-key rows and soft-keys varies depending on the active screen layout.	
Operating-mode switchover after program run was interrupted by switching to the Single Block mode of operation, and canceled by <b>INTERNAL STOP</b>	When you return to the Program Run mode of operation: Error message <b>Selected block not addressed</b> . Use mid-program startup to select the point of interruption	Switching the operating mode is allowed, modal information is saved, program run can be continued by pressing NC start
<b>GOTO</b> is used to go to FK sequences after program run was interrupted there before switching the operating mode	Error message <b>FK programming: Undefined starting position</b>	GOTO allowed
<b>Mid-program startup:</b>		
<ul style="list-style-type: none"> <li>■ Behavior after restoring the machine status</li> <li>■ Completing positioning for mid-program startup</li> <li>■ Switching the screen layout for mid-program startup</li> </ul>	<ul style="list-style-type: none"> <li>■ The menu for returning must be selected with the <b>RESTORE POSITION</b> soft key</li> <li>■ After position has been reached, positioning mode must be exited with the <b>RESTORE POSITION</b> soft key</li> <li>■ Only possible, if startup position has already been approached</li> </ul>	<ul style="list-style-type: none"> <li>■ Menu for returning is selected automatically</li> <li>■ The positioning mode is automatically exited after the position has been reached</li> <li>■ Possible in all operating states</li> </ul>
Error messages	Error messages are still active after the error has been corrected and must be acknowledged separately	Error messages are sometimes acknowledged automatically after the error has been corrected

## Comparison: Differences in Program Run, traverse movements



### Caution: Check the traverse movements!

NC programs that were created on earlier TNC controls may lead to different traverse movements or error messages on a TNC 640!

Be sure to take the necessary care and caution when running-in programs!

Please find a list of known differences below. The list does not pretend to be complete!

Function	TNC 640	iTNC 530
Handwheel-superimposed traverse with M118	Effective in the active coordinate system (which may also be rotated or tilted), or in the machine-based coordinate system, depending on the setting in the 3-D ROT menu for manual operation	Effective in the machine-based coordinate system
Approach/Departure with <b>APPR/DEP</b> , <b>RO</b> is active, contour element plane is not equal to working plane	If possible, the blocks are executed in the defined <b>contour element plane</b> , error message for <b>APPRLN</b> , <b>DEPLN</b> , <b>APPRCT</b> , <b>DEPCT</b>	If possible, the blocks are executed in the defined <b>working plane</b> ; error message for <b>APPRLN</b> , <b>APPRLT</b> , <b>APPRCT</b> , <b>APPRLCT</b>
Scaling approach/departure movements ( <b>APPR/DEP/RND</b> )	Axis-specific scaling factor is allowed, radius is not scaled	Error message
Approach/departure with <b>APPR/DEP</b>	Error message if <b>RO</b> is programmed for <b>APPR/DEP LN</b> or <b>APPR/DEP CT</b>	Tool radius <b>0</b> and compensation direction <b>RR</b> are assumed
Approach/departure with <b>APPR/DEP</b> if contour elements with length 0 are defined	Contour elements with length 0 are ignored. The approach/departure movements are calculated for the first or last valid contour element	An error message is issued if a contour element with length 0 is programmed after the <b>APPR</b> block (relative to the first contour point programmed in the <b>APPR</b> block) For a contour element with length 0 before a <b>DEP</b> block, the TNC does not issue an error message, but uses the last valid contour element to calculate the departure movement

## Tables and overviews

### 19.5 Functions of the TNC 640 and the iTNC 530 compared

Function	TNC 640	iTNC 530
Effect of Q parameters	<b>Q60 to Q99</b> (or <b>QS60 to QS99</b> ) are always local	<b>Q60 to Q99</b> (or <b>QS60 to QS99</b> ) are local or global, depending on MP7251 in converted cycle programs (.cyc). Nested calls may cause problems
Automatic cancelation of tool radius compensation	<ul style="list-style-type: none"> <li>■ Block with <b>RO</b></li> <li>■ <b>DEP</b> block</li> <li>■ <b>END PGM</b></li> </ul>	<ul style="list-style-type: none"> <li>■ Block with <b>RO</b></li> <li>■ <b>DEP</b> block</li> <li>■ <b>PGM CALL</b></li> <li>■ Programming of Cycle 10 <b>ROTATION</b></li> <li>■ Program selection</li> </ul>
NC blocks with <b>M91</b>	No consideration of tool radius compensation	Consideration of tool radius compensation
Tool shape compensation	Tool shape compensation is not supported, because this type of programming is considered to be axis-value programming, and the basic assumption is that axes do not form a Cartesian coordinate system	Tool shape compensation is supported
Mid-program startup in a point table	The tool is positioned above the next position to be machined	The tool is positioned above the last position that has been completely machined
Empty <b>CC</b> block (pole of last tool position is used) in NC program	Last positioning block in the working plane must contain both coordinates of the working plane	Last positioning block in the working plane does not necessarily need to contain both coordinates of the working plane. Can cause problems with <b>RND</b> or <b>CHF</b> blocks
Axis-specific scaling of <b>RND</b> block	<b>RND</b> block is scaled, the result is an ellipse	Error message is issued
Reaction if a contour element with length 0 is defined before or after a <b>RND</b> or <b>CHF</b> block	Error message is issued	<p>Error message is issued if a contour element with length 0 is located before the <b>RND</b> or <b>CHF</b> block</p> <p>Contour element with length 0 is ignored if the contour element with length 0 is located after the <b>RND</b> or <b>CHF</b> block</p>

## Functions of the TNC 640 and the iTNC 530 compared 19.5

Function	TNC 640	iTNC 530
Circle programming with polar coordinates	The incremental rotation angle <b>IPA</b> and the direction of rotation <b>DR</b> must have the same sign. Otherwise, an error message will be issued	The algebraic sign of the direction of rotation is used if the sign defined for <b>DR</b> differs from the one defined for <b>IPA</b>
Tool radius compensation on circular arc or helix with angular length = 0	The transition between the adjacent elements of the arc/helix is generated. Also, the tool axis motion is executed right before this transition. If the element is the first or last element to be corrected, the next or previous element is dealt with in the same way as the first or last element to be corrected	The equidistant line of the arc/helix is used for generating the tool path
Compensation of tool length in the position display	The values <b>L</b> and <b>DL</b> from the tool table and the value <b>DL</b> from the <b>TOOL CALL</b> are taken into account in the position display	The values <b>L</b> and <b>DL</b> from the tool table are taken into account in the position display
Traverse movement in spacial arc	Error message is issued	No restrictions
<b>SLII Cycles 20 to 24:</b>		
<ul style="list-style-type: none"> <li>■ Number of definable contour elements</li> <li>■ Define the working plane</li> <li>■ Position at end of SL cycle</li> </ul>	<ul style="list-style-type: none"> <li>■ Max. 16384 blocks in up to 12 subcontours</li> <li>■ Tool axis in <b>TOOL CALL</b> block defines the working plane</li> <li>■ End position = clearance height above the last position that is defined before the cycle call</li> </ul>	<ul style="list-style-type: none"> <li>■ Max. 8192 contour elements in up to 12 subcontours, no restrictions for subcontour</li> <li>■ The axes of the first positioning block in the first subcontour define the working plane</li> <li>■ With MP7420, you can define whether the end position is above the last programmed position, or whether the tool moves only to clearance height</li> </ul>

## Tables and overviews

### 19.5 Functions of the TNC 640 and the iTNC 530 compared

Function	TNC 640	iTNC 530
<b>SLII Cycles 20 to 24:</b>		
<ul style="list-style-type: none"> <li>■ Handling of islands which are not contained in pockets</li> <li>■ Set operations for SL cycles with complex contour formulas</li> <li>■ Radius compensation is active during <b>CYCL CALL</b></li> <li>■ Paraxial positioning blocks in contour subprogram</li> <li>■ Miscellaneous functions <b>M</b> in contour subprogram</li> <li>■ <b>M110</b> (feed-rate reduction for inside corner)</li> </ul>	<ul style="list-style-type: none"> <li>■ Cannot be defined with complex contour formula</li> <li>■ Real set operation possible</li> <li>■ Error message is issued</li> <li>■ Error message is issued</li> <li>■ Error message is issued</li> <li>■ Function does not work within SL cycles</li> </ul>	<ul style="list-style-type: none"> <li>■ Restricted definition in complex contour formula is possible</li> <li>■ Only restricted performance of real set operation possible</li> <li>■ Radius compensation is canceled, program is executed</li> <li>■ Program is executed</li> <li>■ M functions are ignored</li> <li>■ Function also works within SL cycles</li> </ul>
<b>General cylinder surface machining:</b>		
<ul style="list-style-type: none"> <li>■ Contour definition</li> <li>■ Offset definition on cylinder surface</li> <li>■ Offset definition for basic rotation</li> <li>■ Circle programming with C/CC</li> <li>■ <b>APPR/DEP</b> blocks in contour definition</li> </ul>	<ul style="list-style-type: none"> <li>■ With X/Y coordinates, independent of machine type</li> <li>■ With datum shift in X/Y, independent of machine type</li> <li>■ Function available</li> <li>■ Function available</li> <li>■ Function not available</li> </ul>	<ul style="list-style-type: none"> <li>■ Machine-dependent, with existing rotary axes</li> <li>■ Machine-dependent datum shift in rotary axes</li> <li>■ Function not available</li> <li>■ Function not available</li> <li>■ Function available</li> </ul>
<b>Cylinder surface machining with Cycle 28:</b>		
<ul style="list-style-type: none"> <li>■ Complete roughing-out of slot</li> <li>■ Definable tolerance</li> </ul>	<ul style="list-style-type: none"> <li>■ Function available</li> <li>■ Function available</li> </ul>	<ul style="list-style-type: none"> <li>■ Function not available</li> <li>■ Function available</li> </ul>
<b>Cylinder surface machining with Cycle 29</b>		
	Direct plunging to contour of ridge	Circular approach to contour of ridge
<b>Cycles 25x for pockets, studs and slots:</b>		
<ul style="list-style-type: none"> <li>■ Plunging movements</li> </ul>	In limit ranges (geometrical conditions of tool/contour) error messages are triggered if plunging movements lead to unreasonable/critical behavior	In limit ranges (geometrical conditions of tool/contour), vertical plunging is used if required



## Functions of the TNC 640 and the iTNC 530 compared 19.5

Function	TNC 640	iTNC 530
<b>PLANE function:</b>		
<ul style="list-style-type: none"> <li>■ <b>TABLE ROT/COORD ROT</b> not defined</li> <li>■ Machine is configured for axis angle</li> <li>■ Programming an incremental spatial angle according to <b>PLANE AXIAL</b></li> <li>■ Programming an incremental axis angle according to <b>PLANE SPATIAL</b> if the machine is configured for spatial angle</li> </ul>	<ul style="list-style-type: none"> <li>■ Configured setting is used</li> <li>■ All <b>PLANE</b> functions can be used</li> <li>■ Error message is issued</li> <li>■ Error message is issued</li> </ul>	<ul style="list-style-type: none"> <li>■ <b>COORD ROT</b> is used</li> <li>■ Only <b>PLANE AXIAL</b> is executed</li> <li>■ Incremental spatial angle is interpreted as an absolute value</li> <li>■ Incremental axis angle is interpreted as an absolute value</li> </ul>
<b>Special functions for cycle programming:</b>		
<ul style="list-style-type: none"> <li>■ FN17</li> <li>■ FN18</li> </ul>	<ul style="list-style-type: none"> <li>■ Function available, details are different</li> <li>■ Function available, details are different</li> </ul>	<ul style="list-style-type: none"> <li>■ Function available, details are different</li> <li>■ Function available, details are different</li> </ul>
Compensation of tool length in the position display	The <b>DL</b> value from the <b>TOOL CALL</b> and the tool length entries <b>L</b> and <b>DL</b> from the tool table are taken into account in the position display	The tool length entries <b>L</b> and <b>DL</b> from the tool table are taken into account in the position display

### Comparison: Differences in MDI operation

Function	TNC 640	iTNC 530
Execution of connected sequences	Function partially available	Function available
Saving modally effective functions	Function partially available	Function available

## Tables and overviews

### 19.5 Functions of the TNC 640 and the iTNC 530 compared

#### Comparison: Differences in programming station

Function	TNC 640	iTNC 530
Demo version	Programs with more than 100 NC blocks cannot be selected, an error message is issued	Programs can be selected, max. 100 NC blocks are displayed, further blocks are truncated in the display
Demo version	If nesting with PGM CALL results in more than 100 NC blocks, there is no test graphic display; an error message is not issued	Nested programs can be simulated.
Copying NC programs	Copying to and from the directory <b>TNC:\</b> is possible with Windows Explorer	TNCremo or file manager of programming station must be used for copying
Shifting the horizontal soft-key row	Clicking the soft-key bar shifts the soft-key row to the right, or to the left	Clicking any soft-key bar activates the respective soft-key row

## 19.6 DIN/ISO function overview

### DIN/ISO Function Overview TNC 640

#### M functions

M00	STOP program run/Spindle STOP/Coolant OFF
M01	Optional program STOP/Spindle STOP/Coolant OFF
M02	STOP program run/Spindle STOP/Coolant OFF/CLEAR status display (depending on machine parameter)/Return jump to block 1
M03	Spindle ON clockwise
M04	Spindle ON counterclockwise
M05	Spindle STOP
M06	Tool change/STOP program run (depending on machine parameter)/Spindle STOP
M08	Coolant on
M09	Coolant off
M13	Spindle ON clockwise /coolant ON
M14	Spindle ON counterclockwise/coolant on
M30	Same function as M02
M89	Vacant miscellaneous function or cycle call, modally effective (depending on MPs)
M99	Blockwise cycle call
M91	Within the positioning block: Coordinates are referenced to machine datum
M92	Within the positioning block: Coordinates are referenced to position defined by machine tool builder, such as tool change position
M94	Reduce the rotary axis display to a value below 360°
M97	Machine small contour steps
M98	Machine open contours completely
M109	constant contouring speed at cutting edge (feed rate increase and reduction) Constant contouring speed at cutting edge (only feed rate reduction)
M110	Reset M109/M110
M111	
M116	Feed rate for angular axes in mm/min
M117	Reset M116
M118	Superimpose handwheel positioning during program run
M120	Pre-calculate the radius-compensated contour (LOOK AHEAD)
M126	Shorter-path traverse of rotary axes:
M127	Reset M126
M128	Maintaining the position of the tool tip when positioning with tilted axes (TCPM)
M129	Reset M128
M130	Within the positioning block: Points are referenced to the untilted coordinate system
M140	Retraction from the contour in the tool-axis direction
M141	Suppress touch probe monitoring
M143	Delete basic rotation
M148	Automatically retract tool from the contour at an NC stop
M149	Reset M148

## Tables and overviews

### 19.6 DIN/ISO function overview

#### G functions

##### Tool movements

G00	Straight-line interpolation, Cartesian, rapid traverse
G01	Straight-line interpolation, Cartesian
G02	Circle interpolation, Cartesian, clockwise
G03	Circle interpolation, Cartesian, counterclockwise
G05	Circle interpolation, Cartesian, without rotation direction specification
G06	Circle interpolation, Cartesian, tangential contour connection
G07*	Paraxial positioning block
G10	Straight-line interpolation, polar, rapid traverse
G11	Straight-line interpolation, polar
G12	Circle interpolation, polar, clockwise
G13	Circle interpolation, polar, counterclockwise
G15	Circle interpolation, polar, without rotation direction specification
G16	Circle interpolation, polar, tangential contour connection

##### Chamfer/Rounding/Approach contour/Depart contour

G24*	Chamfers with chamfer side length R
G25*	Corner rounding with radius R
G26*	Tangential approach of a contour with radius R
G27*	Tangential exiting of a contour with radius R

##### Tool definition

G99*	With tool number T, length L, radius R
------	--

##### Tool radius compensation

G40	No tool radius compensation
G41	Tool path compensation, left of the contour
G42	Tool path compensation, right of the contour
G43	Paraxial compensation for G07, extension
G44	Paraxial compensation for G07, shortening

##### Blank form definition for graphics

G30	(G17/G18/G19) Min. point
G31	(G90/G91) Max. point

##### Cycles for drilling, tapping and thread milling

G240	Centering
G200	Drilling
G201	Reaming
G202	Boring
G203	Universal drilling
G204	Back boring
G205	Universal pecking
G206	Tapping with floating tap holder
G207	Rigid tapping
G208	Bore milling
G209	Tapping with chip breaking
G241	Single-lip deep-hole drilling

**G functions****Cycles for drilling, tapping and thread milling**

G262	Thread Milling
G263	Thread milling/countersinking
G264	Thread drilling/milling
G265	Helical thread drilling/milling
G267	Outside thread milling

**Cycles for milling pockets, studs and slots**

G251	Rectangular pocket (complete)
G252	Circular pocket (complete)
G253	Slot (complete)
G254	Circular slot (complete)
G256	Rectangular stud
G257	Circular stud

**Cycles for creating point patterns**

G220	Circular point patterns
G221	Linear point patterns

## SL cycles, group 2

G37	Contour, define subcontour subprogram numbers
G120	Define contour data (valid for G121 to G124)
G121	Pilot drilling
G122	Contour-parallel roughing out (roughing)
G123	Floor finishing
G124	Side finishing
G275	Trochoidal contour slot
G125	Contour train (machine open contours)
G127	Cylinder surface
G128	Cylinder surface slot milling

**Coordinate transformation**

G53	Zero point shift from zero point tables
G54	Datum shift in program
G28	Contour mirroring
G73	Rotating the coordinate system
G72	Scaling factor, reducing/magnifying the contour
G80	Tilting the working plane
G247	Datum setting

**Cycles for multipass milling**

G230	Clearing level surfaces
G231	Clearing any inclined surfaces
G232	Face milling
G233	Face milling, new

\*) Non-modal function

**Touch probe cycles for measuring workpiece misalignment**

G400	Basic rotation from two points
G401	Basic rotation from two holes
G402	Basic rotation from two studs
G403	Compensating a basic rotation via a rotary axis
G404	Setting a basic rotation
G405	Compensating misalignment by the C axis

## Tables and overviews

### 19.6 DIN/ISO function overview

#### G functions

##### Touch probe cycles for datum setting

G408	Slot center datum
G409	Ridge center datum
G410	Datum from inside of rectangle
G411	Datum from outside of rectangle
G412	Datum from inside of circle
G413	Datum from outside of circle
G414	Datum at outside corner
G415	Datum at inside corner
G416	Datum at circle center
G417	Datum in touch probe axis
G418	Datum at center of 4 holes
G419	Datum in any axis

##### Touch probe cycles for workpiece measurement

G55	Measuring of any coordinates
G420	Measuring of any angle
G421	Measuring of bore
G422	Measuring of circular stud
G423	Measuring of rectangular pocket
G424	Measuring of rectangular stud
G425	Measuring of slot
G426	Measuring of ridge width
G427	Measuring of any coordinates
G430	Measuring of circle center
G431	Measuring of any plane

##### Touch probe cycles for tool measurement

G480	Calibrating TT
G481	Measuring of tool length
G482	Measuring of tool radius
G483	Measuring of tool length and radius

##### Special cycles

G04*	Dwell time with F seconds
G36	Spindle orientation
G39*	Program call
G62	Tolerance deviation for rapid contour milling
G440	Measuring axis shift
G441	Rapid probing

##### Define machining plane

G17	Plane X/Y, tool axis Z
G18	Plane Z/X, tool axis Y
G19	Plane Y/Z, tool axis X
G20	Tool axis IV

##### Dimensions

G90	Absolute dimensions
G91	Incremental dimensions

##### Unit of measure

G70	Unit of measure: inch (set at start of program)
G71	Unit of measure: millimeter (set at start of program)

**G functions****Other G functions**

G29	Last position nominal value as pole (circle center)
G38	Program run STOP
G51*	Tool preselection (with central tool file)
G79*	Cycle call
G98*	Setting label number

\*) Non-modal function

**Addresses**

%	Program start
%	Program call
#	Datum number with G53
A	Rotation around the X axis
B	Rotation around the Y axis
C	Rotation around the Z axis
D	Q-parameter definitions
DL	Wear compensation length with T
DR	Wear compensation radius with T
E	Tolerance with M112 and M124
F	Feed rate
F	Dwell time with G04
F	Scaling factor with G72
F	Factor F reduction with M103
G	G functions
H	Polar angle
H	Rotation angle with G73
H	Limit angle with M112
I	X coordinate of the circle center/pole
J	Y coordinate of the circle center/pole
K	Z coordinate of the circle center/pole
L	Setting a label number with G98
L	Jumping to a label number
L	Tool length with G99
M	M functions
N	Block number
P	Cycle parameter in machining cycles
P	Value or Q parameter in Q-parameter definition
Q	Q parameter
R	Polar coordinate radius
R	Circle radius with G02/G03/G05
R	Rounding radius with G25/G26/G27
R	Tool radius with G99
S	Spindle speed
S	Spindle orientation with G36

## Tables and overviews

### 19.6 DIN/ISO function overview

#### Addresses

T	Tool definition with G99
T	Tool call
T	Next tool with G51
U	Axis parallel to X axis
V	Axis parallel to Y axis
W	Axis parallel to Z axis
X	X axis
Y	Y axis
Z	Z axis
*	End of block

#### Contour cycles

##### Sequence of program steps for machining with multiple tools

List of subcontour programs	G37 P01 ...
<b>Define contour data</b>	G120 Q1 ...
<b>Drill</b> define/call Contour cycle: Pilot drilling Cycle call	G121 Q10 ...
<b>Roughing mill</b> define/call Contour cycle: Rough-out Cycle call	G122 Q10 ...
<b>Finishing mill</b> define/call Contour cycle: Floor finishing Cycle call	G123 Q11 ...
<b>Finishing mill</b> define/call Contour cycle: Side finishing Cycle call	G124 Q11 ...
End of main program, return	<b>M02</b>
Contour subprograms	G98 ... G98 L0

#### Radius compensation of the contour subprograms

Contour	Programming sequence of the contour elements	Radius compensation
Internal (pocket)	Clockwise (CW)	G42 (RR)
	Counterclockwise (CCW)	G41 (RL)
External (island)	Clockwise (CW)	G41 (RL)
	Counterclockwise (CCW)	G42 (RR)



**Coordinate transformation**

<b>Coordinate transformation</b>	<b>Activate</b>	<b>Cancel</b>
Datum shift	G54 X+20 Y+30 Z+10	G54 X0 Y0 Z0
Mirror image	G28 X	G28
Rotation	G73 H+45	G73 H+0
Scaling factor	G72 F 0.8	G72 F1
Working plane	G80 A+10 B+10 C+15	G80
Working plane	PLANE ...	PLANE RESET

**Q-parameter definitions**

<b>D</b>	<b>Function</b>
00	Assign
01	Addition
02	Subtraction
03	Multiplication
04	Division
05	Root
06	Sine
07	Cosine
08	Root from sum of square $c = \sqrt{a^2+b^2}$
09	If equal, jump to label number
10	If not equal, jump to label number
11	If larger, jump to label number
12	If smaller, jump to label number
13	Angle (angle from c sin a and c cos a)
14	Error number
15	Print
19	PLC assignment

## Index

### 3

3D compensation	
Peripheral Milling.....	420
3-D touch probes	
Calibration.....	490
3-D view.....	526

### A

ACC.....	370
Accessing tables.....	291
Accessories.....	86
Actual position capture.....	100
Adaptive feed control.....	357
Adding comments.....	132, 134
Additional axes.....	91, 91
Adjusting spindle speed.....	469
AFC.....	357
Angle functions.....	270
Approach contour.....	200
ASCII Files.....	373
Automatic program start.....	546
Automatic tool measurement...	167

### B

Basic rotation.....	496
Measuring in Manual Operation	
mode.....	496
Block.....	102
Delete.....	102

### C

Calculating with parentheses...	301
Calculator.....	136
Chamfer.....	211
Chatter Control.....	370
Checking the axis positions.....	472
Circle.....	215, 217, 223
Circle center.....	213
Circular path.....	214, 223
Code numbers.....	560
Collision monitoring.....	351
Comparison.....	605
Compensating workpiece	
misalignment	
By measuring two points on a	
straight surface.....	495
Connecting/removing USB devices.	
129	
Connector pin layout for data	
interfaces.....	590
Context-sensitive help.....	151
Control panel.....	72
Conversational dialog.....	99
Copying program sections 103, 103	
Corner rounding.....	212

### D

D14: Displaying error messages....	275
D18: Reading system data.....	279
D19: Transfer values to the	
PLC.....	288
D20: NC and PLC	
synchronization.....	288
D26: TABOPEN: Open a freely	
definable table.....	380
D27: TABWRITE: Write to a freely	
definable table.....	381
D28: TABREAD: Read from a freely	
definable table.....	382
D29: Transfer values to the	
PLC.....	290
D37 EXPORT.....	290
Data Backup.....	108
Data interface.....	561
Connector pin layouts.....	590
Set up.....	561
Data transfer software.....	565
Data transfer speed....	
561, 562, 562, 562, 562, 563, 563	
Datum management.....	476
Datum setting.....	475
Without a 3-D touch probe....	475
Datum table.....	488
Transferring test results.....	488
DCM.....	351
Defining local Q parameters....	266
Defining nonvolatile Q parameters..	266
Defining the workpiece blank....	97
Depart contour.....	200
Dialog.....	99
Directory.....	109, 113
Copy.....	115
Create.....	113
Delete.....	117
Displaying HTML files.....	122
Displaying Internet files.....	122
Display screen.....	71
Downloading help files.....	156
Dynamic Collision Monitoring...	351

### E

Enter spindle speed.....	176
Error messages.....	145, 145
Help with.....	145
Ethernet interface.....	567
Configuring.....	567
Connecting and disconnecting	
network drives.....	128
Connection options.....	567
Introduction.....	567
External access.....	553
External data transfer	

iTNC 530.....	126
---------------	-----

### F

FCL.....	560
FCL function.....	11
Feature Content Level.....	11
Feed rate.....	468
Adjust.....	469
On rotary axes, M116.....	407
Feed rate control, automatic....	357
Feed rate factor for plunging	
movements M103.....	335
Feed rate in millimeters per spindle	
revolution M136.....	336
File	
Create.....	113
File manager.....	106, 109
Call.....	111
Copying files.....	113
Copying tables.....	115
Delete file.....	117
Directories.....	109
Copy.....	115
Create.....	113
External data transfer.....	126
File	
Create.....	113
File type.....	106
File type	
External file types.....	108
Function overview.....	110
Overwriting files.....	114
Protect file.....	120
Rename file.....	119, 119
Selecting files.....	112
Tagging files.....	118
File status.....	111
Filter for hole positions with DXF	
data update.....	245
Firewall.....	
FN14: ERROR: Displaying error	
messages.....	275
FN18: SYSREAD: Reading system	
data.....	279
FN19: PLC: Transfer values to the	
PLC.....	288
FN27: TABWRITE: Write to a freely	
definable table.....	381
FN28: TABREAD: Read from a	
freely definable table.....	382
Form view.....	379
Freely definable tables.....	
FS, Functional safety.....	470
Full circle.....	214
Functional safety FS.....	470
Fundamentals.....	90



# Index

- Interrupt..... 537
  - Mid-program startup..... 543
  - Optional block skip..... 547
  - Overview..... 535
  - Resuming after interruption... 538
  - Retraction..... 540
  - Program-section repeat..... 251
  - Projection in three planes..... 525
- Q**
- Q parameter
    - Export..... 290
    - Transfer values to PLC..... 288
    - Transfer values to the PLC.... 290
  - Q parameter programming... 264, 305
    - Additional functions..... 274
    - Angle functions..... 270
    - If-then decisions..... 271
    - Mathematical functions..... 268
    - Programming notes...  
265, 306, 307, 308, 310, 312
  - Q parameters..... 264, 305
    - Checking..... 272
    - Local parameters QL..... 264
    - Nonvolatile parameters QR... 264
    - Preassigned..... 316
- R**
- Radius compensation..... 191
    - Entering..... 192
    - Outside corners, inside  
corners..... 193
  - Rapid traverse..... 160
  - Reading out machine parameters... 313
  - Recessing and undercutting.... 441
  - Reference system..... 91, 91
  - Replacing texts..... 105
  - Retraction..... 540
    - After a power interruption.... 540
  - Retraction from the contour.... 342
  - Returning to the contour..... 545
  - Rotary axis..... 407
    - Reduce display M94..... 409
    - Shortest-path traverse: M126. 408
  - Rounding corners M197..... 346
- S**
- Screen layout..... 71
  - Search function..... 104
  - Selecting a contour from DXF.. 237
  - Selecting positions from DXF... 241
  - Selecting the datum..... 94
  - Selecting the unit of measure... 97
  - Select kinematics..... 556
  - Setting the BAUD RATE...  
561, 562, 562, 562, 563, 563
  - Software number..... 560
- SPEC FCT..... 348
  - Special functions..... 348
  - Spindle load monitoring..... 369
  - SQL commands..... 291
  - Status display..... 75, 75
    - Additional..... 76
    - General..... 75
  - Straight line..... 210, 222
  - String parameters..... 305
  - Structuring programs..... 135
  - Subprogram..... 249
  - Superimposing handwheel  
positioning M118..... 340
  - Surface normal vector..... 394
  - Switch-off..... 456
  - Switch-on..... 454
- T**
- TCPM..... 415
    - Reset..... 419
  - Teach In..... 100, 210
  - Teach-in cut..... 362
  - Test Run..... 532
  - Test run
    - Execute..... 534
  - Test Run
    - Overview..... 532
  - test run
    - Setting speed..... 523
  - Text File..... 373
  - Text file
    - Delete functions..... 374
    - Finding text sections..... 376
    - Opening and exiting..... 373
  - Text variables..... 305
  - Tilted axes..... 410
  - Tilting the Working Plane.. 385, 508
  - Tilting the working plane
    - Manual..... 508
  - TNCguide..... 151
  - TNCremo..... 565
  - TNCremoNT..... 565
  - Tool breakage monitoring..... 368
  - Tool change..... 178
  - Tool compensation..... 190
    - Length..... 190
  - Tool Compensation
    - Radius..... 191
  - Tool data..... 162
    - Call..... 176
    - Delta values..... 163
    - Entering into the program.... 163
    - Enter into the table..... 164
  - Tool data
    - Initiating..... 171
  - Tool length..... 162
  - Tool management..... 183
  - Tool measurement..... 167
- Tool name..... 162
  - Tool number..... 162
  - Tool radius..... 162
  - Tool table..... 164
    - edit, exit..... 168
    - Editing functions..... 171, 185, 186
    - Input options..... 164
  - Tool usage file..... 181, 555
  - Tool usage test..... 181
  - Touch probe cycles..... 482
    - Manual Operation mode..... 482
    - See Touch Probe Cycles User's  
Manual
  - Touch probe monitoring..... 343
  - Traversing reference marks.... 454
  - Trigonometry..... 270
  - Turning mode selection..... 429
  - Turning Operations..... 428
    - Feed rate..... 433
  - Turning operations
    - Program spindle speed..... 432
    - Tool data..... 435
  - Turning Operations
    - Tool tip radius compensation.. 440
- U**
- Unbalance Functions..... 449
  - User parameters
    - Machine-specific..... 580
  - Using touch probe functions with  
mechanical probes or measuring  
dials..... 507
- V**
- Version numbers..... 560, 578
  - Virtual tool axis..... 341
- W**
- Window Manager..... 83
  - Wireless handwheel..... 461
    - Assign handwheel holder.... 576
    - Configure..... 576
    - Selecting transmitter power.. 577
    - Setting channel..... 577
    - Statistical data..... 578
  - Working space monitoring 531, 534
  - Workpiece positions..... 93
  - Writing probing values in a datum  
table..... 488
  - Writing probing values in a preset  
table..... 489
- Z**
- ZIP archive..... 123

# HEIDENHAIN

---

## DR. JOHANNES HEIDENHAIN GmbH

Dr.-Johannes-Heidenhain-Straße 5

83301 Traunreut, Germany

☎ +49 8669 31-0

☎ +49 8669 5061

E-mail: info@heidenhain.de

---

**Technical support** ☎ +49 8669 32-1000

**Measuring systems** ☎ +49 8669 31-3104

E-mail: service.ms-support@heidenhain.de

**TNC support** ☎ +49 8669 31-3101

E-mail: service.nc-support@heidenhain.de

**NC programming** ☎ +49 8669 31-3103

E-mail: service.nc-pgm@heidenhain.de

**PLC programming** ☎ +49 8669 31-3102

E-mail: service.plc@heidenhain.de

**Lathe controls** ☎ +49 8669 31-3105

E-mail: service.lathe-support@heidenhain.de

---

[www.heidenhain.de](http://www.heidenhain.de)

---

## Touch probes from HEIDENHAIN

help you reduce non-productive time and improve the dimensional accuracy of the finished workpieces.


### Workpiece touch probes

**TS 220** Signal transmission by cable

**TS 440, TS 444** Infrared transmission

**TS 640, TS 740** Infrared transmission

- Workpiece alignment
- Setting datums
- Workpiece measurement



### Tool touch probes

**TT 140** Signal transmission by cable

**TT 449** Infrared transmission

**TL** Contact-free laser systems

- Tool measurement
- Wear monitoring
- Tool breakage detection

