


HEIDENHAIN



TNC 640

User's Manual Klartext Programming

NC Software 34059x-17

English (en) 10/2022

Controls and displays

Keys

If you are using a TNC 640 with touch control, you can replace some keystrokes with gestures.

Further information: "Operating the touchscreen", Page 607

Keys on the screen

Key	Function
0	Select screen layout
0	Toggle the display between machine operating mode, programming mode, and a third desktop
	Soft keys for selecting functions on screen
$ \bigcirc \bigcirc \bigcirc$	Switch the soft-key rows

Alphabetic keyboard

Key	Function
Q W E	File names, comments
G F S	ISO programming
#	Select the next element, e.g. input field, button, selection option
SHIFT +	Select the previous element
	HEROS menu

Machine operating modes

Key	Function
(m)	Manual operation
	Electronic handwheel
	Positioning with Manual Data Input
	Program Run, Single Block
-	Program Run, Full Sequence

Programming modes

Key	Function	
⇒	Programming	
-	Test Run	

Entering and editing coordinate axes and numbers

Key	Function
X V	Select the coordinate axes or enter them in the NC program
0 9	Numbers
•	Decimal separator / Reverse algebraic sign
PI	Polar coordinate entry / Incremental values
Q	Q parameter programming / Q parameter status
-‡-	Capture actual position
NO ENT	Skip dialog questions, delete words
ENT	Confirm entry and resume dialog
END □	Conclude the NC block, end your input
CE	Clear entries or error message
DEL 🗆	Abort dialog, delete program section

Tool functions

Key	Function
TOOL	Define tool data in the NC program
TOOL	Call tool data

Managing NC programs and files, control functions

Key	Function
PGM MGT	Select or delete NC programs or files, external data transfer
PGM CALL	Define program call, select datum and point tables
MOD	Select MOD functions
HELP	Display help text for NC error messages, call TNCguide
ERR	Display all current error messages
CALC	Show calculator
SPEC FCT	Show special functions
	Currently not assigned

Navigation keys

Key	Function
	Position the cursor
GOTO □	Go directly to NC blocks, cycles, and parameter functions
HOME	Navigate to the beginning of a program or table
END	Navigate to the end of the program or table row
PG UP	Navigate up one page
PG DN	Navigate down one page
	Select the next tab in forms
	Up/down one dialog box or button

Cycles, subprograms and program section repeats

Key		Function
TOUCH		Define touch probe cycles
CYCL	CYCL	Define and call cycles
LBL SET	LBL	Enter and call subprograms and program section repeats
STOP		Enter program stop in an NC program

Programming path contours

Key		Function
APPR DEP		Contour approach and departure
FK		FK free contour programming
L		Straight line
CC +		Circle center/pole for polar coordinates
[c]		Circular arc with center
CR		Circular arc with radius
CT → C		Circular arc with tangential transition
CHF o	RND	Chamfer/rounding arc

Potentiometer for feed rate and spindle speed

Feed rate	Spindle speed
700 50 150 5 W F %	50 (150

3-D mouse

A HEIDENHAIN 3-D mouse is available as a complement to the keyboard unit.

A 3-D mouse allows you to manipulate objects as intuitively as if you were holding them in your hands.

This is made possible through simultaneous six-degree-of-freedom motion:

- 2-D movement in the XY plane
- 3-D rotation around the axes X, Y, and Z
- Zooming in or zooming out







These options increase the ease of use in the following applications in particular:

- CAD import
- Material removal simulation
- 3-D applications of an external PC that you can use on the control based on software option 133 (Remote Desktop Manager)

Contents

1	Basic information	33
2	First steps	49
3	Fundamentals	65
4	Tools	125
5	Programming contours	143
6	Programming aids	197
7	Miscellaneous functions	231
8	Subprograms and program section repeats	253
9	Programming Q parameters	277
10	Special functions	373
11	Multiple-axis machining	457
12	Data transfer from CAD files	525
13	Pallets	551
14	Turning	569
15	Grinding	597
16	Operating the touchscreen	607
17	Tables and overviews	621

1	Basi	c information	33
	1.1	About this manual	34
	4.0		0.6
	1.2	Control model, software and features	36
		Software options	38
		New functions in 34059x-17	43

2	First	steps	49
	0.1		
	2.1	Overview	50
	2.2	Switching on the machine	51
		Acknowledging the power interruption	51
	2.3	Programming the first part	52
		Selecting the operating mode	52
		Important controls and displays	52
		Creating a new NC program / file management	53
		Defining a workpiece blank	54
		Program layout	55
		Programming a simple contour	56
		Creating a cycle program	61

3	Fund	damentals	65
	3.1	The TNC 640	66
	5.1	HEIDENHAIN Klartext and ISO	
		Compatibility	
		Compatibility	00
	3.2	Visual display unit and operating panel	67
		Display screen	67
		Setting the screen layout	67
		Operating panel	68
		Extended Workspace Compact	71
	3.3	Modes of operation	74
		Manual Operation and El. Handwheel	
		Positioning with Manual Data Input	
		Programming	
		Test Run	
		Program Run, Full Sequence and Program Run, Single Block	
	3.4	NC fundamentals	
		Position encoders and reference marks	77
		Programmable axes	77
		Reference systems	
		Designation of the axes on milling machines	
		Polar coordinates	
		Absolute and incremental workpiece positions	
		Selecting the preset	91
	3.5	Creating and entering NC programs	92
		Structure of an NC program in HEIDENHAIN Klartext	92
		Defining the workpiece blank: BLK FORM	93
		Creating a new NC program	
		Programming tool movements in Klartext	99
		Actual position capture	101
		Editing an NC program	102
		The control's search function	106
	3.6	File management	108
		Files	108
		Displaying externally generated files on the control	
		Directories	
		Paths	
		Overview: Functions of the file manager	
		Calling the File Manager	
		Selecting drives, directories and files	
		Creating a new directory	
		Creating new file	

Copying a single file	115
Copying files into another directory	116
Copying a table	117
Copying a directory	118
Choosing one of the last files selected	118
Deleting a file	119
Deleting a directory	119
Tagging files	120
Renaming a file	121
Sorting files	121
Additional functions	122

4	Tool	S	125
	4.1	Entering tool-related data	126
		Feed rate F	126
		Spindle speed S	127
	4.2	Tool data	128
		Requirements for tool compensation	128
		Tool number, tool name	128
		Tool length L	129
		Tool radius R	131
		Delta values for lengths and radii	131
		Entering tool data into the NC program	132
		Calling the tool data	133
		Tool change	135
	4.3	Tool compensation	138
		Introduction	138
		Tool length compensation	138
		Tool radius compensation	139

5	Prog	gramming contours	143
	5.1	Tool movements	144
		Path functions	144
		FK free contour programming	144
		Miscellaneous functions M	144
		Subprograms and program section repeats	145
		Programming with Q parameters	145
	5 0		446
	5.2	Fundamentals of path functions	146
		Programming tool movements for machining	146
	5.3	Approaching and departing a contour	150
		Starting point and end point	150
		Overview: Types of paths for contour approach and departure	152
		Important positions for approach and departure	153
		Approaching on a straight line with tangential connection: APPR LT	155
		Approaching on a straight line perpendicular to the first contour point: APPR LN	155
		Approaching on a circular path with tangential connection: APPR CT	156
		Approaching on a circular path with tangential connection from a straight line to the contour:	
		APPR LCT	157
		Departing in a straight line with tangential connection: DEP LT	158
		Departing in a straight line perpendicular to the last contour point: DEP LN	158
		Departing on a circular path with tangential connection: DEP CT	159
		Departing on a circular arc tangentially connecting the contour and a straight line: DEP LCT	159
	5.4	Path contours - Cartesian coordinates	160
		Overview of path functions	160
		Straight line L	161
		Inserting a chamfer between two straight lines	162
		Rounded corners RND	163
		Circle center CC Circular arc C around circle center CC	164
			165
		Circular arc CR with fixed radius	167
		Circular arc CT with tangential transition	169
		Superimposing a linear motion on a circular contour	170
		Example: Linear movements and chamfers with Cartesian coordinates	171
		Example: Circular movements with Cartesian coordinates	172
		Example: Full circle with Cartesian coordinates	173
	5.5	Path contours - Polar coordinates	174
		Overview	174
		Datum for polar coordinates: pole CC	175
		Straight line LP	175
		Circular path CP around pole CC	176
		Circle CTP with tangential connection	176
		Haliy	177

	Example: Linear movement with polar coordinates	179
	Example: Helix	180
5.6	Path contours - FK free contour programming	181
	Fundamentals	181
	Defining the working plane	182
	FK programming graphics	183
	Initiating the FK dialog	184
	Pole for FK programming	184
	Free straight line programming	185
	Free circular path programming	186
	Input possibilities	187
	Auxiliary points	190
	Relative data	191
	Example: FK programming 1	193
	Example: FK programming 2	194
	Example: FK programming 3	195

6	Prog	ramming aids	197
	6.1	GOTO function	198
		Using the GOTO key	198
	6.2	Display of NC programs	199
	0.2		
		Syntax highlighting	199
		Scrollbar	199
	6.3	Adding comments	200
		Application	200
		Entering comments during programming	200
		Inserting comments after program entry	200
		Entering a comment in a separate NC block	200
		Commenting out an existing NC block	200
		Functions for editing a comment	201
	6.4	Freely editing an NC program	202
	6 5	Chinning NO blocks	202
	6.5	Skipping NC blocks	203
		Insert a slash (/)	203
		Delete the slash (/)	203
	6.6	Structuring NC programs	204
		Definition and applications	204
		Displaying the program structure window / Changing the active window	204
		Inserting a structure block in the program window	205
		Selecting blocks in the program structure window	205
	6.7	Calculator	206
		Operation	206
	6.8	Cutting data calculator	209
	0.0	•	_
		Application	209
		Working with cutting data tables	211
	6.9	Programming graphics	214
		Activating and deactivating programming graphics	214
		Generating a graphic for an existing NC program	215
		Block number display ON/OFF	215
		Erasing the graphic	215
		Showing grid lines	215
		Magnification or reduction of details	216
	6.10	Error messages	217
		Display of errors	217
		Opening the error window	217

	Detailed error messages	218
	INTERNAL INFO soft key	218
	GROUPING soft key	219
	ACTIVATE SAVING soft key	219
	Deleting errors	220
	Error log	221
	Keystroke log	222
	Informational texts	223
	Saving service files	223
	Closing the error window	223
6.11	TNCguide: context-sensitive help	224
	Application	224
	Using TNCguide	225
	Downloading current help files	228

7	Misc	cellaneous functions	231
	7.1	Entering miscellaneous functions M and STOP	232
		Fundamentals	232
	7.2	Miscellaneous functions for program run inspection, spindle and coolant	234
		Overview	234
	7.3	Miscellaneous functions for coordinate entries	235
		Programming machine-referenced coordinates: M91/M92	235
		Moving to positions in a non-tilted input coordinate system with a tilted working plane: M130	237
	7.4	Miscellaneous functions for path behavior	238
		Machining small contour steps: M97	238
		Machining open contour corners: M98	239
		Feed rate factor for plunging movements: M103	240
		Feed rate in millimeters per spindle revolution: M136	241
		Feed rate for circular arcs: M109/M110/M111	241
		Pre-calculating radius-compensated contours (LOOK AHEAD): M120	243
		Superimposing handwheel positioning during program run: M118	245
		Retraction from the contour in the tool-axis direction: M140	247
		Suppressing touch probe monitoring: M141	249
		Deleting basic rotation: M143	249
		Lifting off the tool automatically from the contour at NC stop: M148	250
		Rounding corners: M197	251

8	Sub	programs and program section repeats	253
	8.1	Labeling subprograms and program section repeats	254
		Label	254
	0.0	Outhorn annual	055
	8.2	Subprograms	255
		Operating sequence	255
		Programming notes	255
		Programming the subprogram	255 256
		Calling a subprogram	250
	8.3	Program-section repeats	257
		Label	257
		Operating sequence	257
		Programming notes	257
		Programming a program section repeat	258
		Calling a program section repeat	258
	8.4	Calling an external NC program	259
		Overview of the soft keys	259
		Operating sequence	260
		Programming notes	260
		Calling an external NC program	262
	8.5	Point tables	264
		Creating a point table	264
		Hiding single points for the machining process	265
		Selecting a point table in the NC program	266
		Using point tables	267
		Definition	267
	8.6	Nesting	268
		Types of nesting	268
		Nesting depth	268
		Subprogram within a subprogram	269
		Repeating program section repeats	270
		Repeating a subprogram	271
	8.7	Programming examples	272
		Example: Milling a contour in several infeeds	272
		Example: Groups of holes	273
		Example: Group of holes with multiple tools	274

9	Prog	gramming Q parameters	277
	9.1	Principle and overview of functions	278
		Q parameter types	279
		Programming notes	281
		Calling Q parameter functions	282
			202
	9.2	Part families—Q parameters in place of numerical values	283
		Application	283
	0.0		004
	9.3	Describing contours with mathematical functions	284
		Application	284
		Overview	285
		Programming fundamental operations	286
	9.4	Trigonometric functions	288
		Definitions	288
		Programming trigonometric functions	288
			200
	9.5	Calculation of circles	290
		Application	290
	9.6	If-then decisions with Q parameters	291
		Application	291
		Abbreviations used	291
		Jump conditions	292
		Programming if-then decisions	293
	9.7	Entering formulas directly	294
		Entering formulas	294
		Calculation rules	294
		Overview	296
		Example: Trigonometric function	298
	9.8	Checking and changing Q parameters	299
	7.0	Procedure	299
		T TOCCUUTC	200
	9.9	Additional functions	301
		Overview	301
		FN 14: ERROR output of error messages	302
		FN 16: F-PRINT – Formatted output of text and Q parameter values	308
		FN 18: SYSREAD – Reading system data	317
		FN 19: PLC transferring values to PLC	318
		FN 20: WAIT FOR NC and PLC synchronization	319
		FN 29: PLC transferring values to the PLC	320
		FN 37: EXPORT	320
		FN 38: SEND – Send information from the NC program	321

9.10	String parameters	323
	String processing functions	323
	Assigning string parameters	324
	Chain-linking string parameters	325
	Converting a numerical value to a string parameter	326
	Copying a substring from a string parameter	327
	Reading system data	328
	Converting a string parameter to a numerical value	329
	Testing a string parameter	330
	Determining the length of a string parameter	331
	Comparing the lexical order of two alphanumerical strings	332
	Reading out machine parameters	333
9.11	Preassigned Q parameters	335
	Values from the PLC: Q100 to Q107	335
	Active tool radius: Q108	335
	Tool axis: Q109	336
	Spindle status: Q110	336
	Coolant on/off: Q111	336
	Overlap factor: Q112	336
	Unit of measure in the NC program: Q113	337
	Tool length: Q114	337
	Measurement result from programmable touch-probe cycles: Q115 to Q119	337
	Q parameters Q115 and Q116 for automatic tool measurement	338
	Calculated coordinates of the rotary axes: Q120 to Q122	338
	Measurement results from touch-probe cycles	339
	Checking the setup situation: Q601	343
9.12	Accessing tables with SQL statements	344
	Introduction	344
	Programming SQL commands	346
	Overview of functions	347
	SQL BIND	348
	SQL EXECUTE	349
	SQL FETCH	353
	SQL UPDATE	355
	SQL INSERT	357
	SQL COMMIT	358
	SQL ROLLBACK	359
	SQL SELECT	361
	Examples	363
9.13	Programming examples	365
	Example: Rounding a value	365
	Example: Ellipse	366

Example: Concave cylinder machined with Ball-nose cutter	368
Example: Convex sphere machined with end mill	370

10	Spec	ial functions	373
	10 1	Overview of special functions	374
	10.1	Main menu for SPEC FCT special functions	374
		Program defaults menu	375
		Functions for contour and point machining menu	375
		Menu for defining different Klartext functions	376
	10.2	Function mode	377
		Program function mode	377
		Function Mode Set	377
	10.3	Dynamic Collision Monitoring (option 40)	378
		Function	378
		Activating and deactivating collision monitoring in the NC program	380
	10.4	Adaptive Feed Control (AFC) (option 45)	382
		Application	382
		Defining basic AFC settings	383
		Programming AFC	385
	10.5		222
	10.5	Working with the parallel axes U, V and W	388
		Overview	388
		FUNCTION PARAXCOMP DISPLAYFUNCTION PARAXCOMP MOVE	390 392
		Deactivating FUNCTION PARAXCOMP	394
		FUNCTION PARAXMODE	395
		Deactivating FUNCTION PARAXMODE	397
		Example: Drilling with the W axis	398
	10.6	· .	399
		Overview	399
		Activating FUNCTION POLARKIN	400
		Deactivating FUNCTION POLARKIN Example: SL cycles in the polar kinematics	403 404
		Example. SE cycles in the polar kinematics	404
	10.7	File functions	406
		Application	406
		Defining file functions	406
		OPEN FILE	407
	10.8	NC functions for coordinate transformations	409
		Overview	409
		Datum shift with TRANS DATUM	409
		Mirroring with TRANS MIRROR	411
		Rotations with TRANS ROTATION	415

	Scaling with TRANS SCALE	416
	Selecting a TRANS function	417
10.9	Modifying presets	418
	Activating a preset	418
	Copying a preset	419
	Correcting a preset	420
10.10) Datum table	421
	Application	421
	Description	421
	Creating a datum table	422
	Opening and editing a datum table	422
	Activating the datum table in your NC program	424
	Activating the datum table manually	424
40.44		405
10.11	Compensation table	425
	Application	425
	Types of compensation tables	425
	Creating a compensation table	426
	Activate the compensation table	427
	Editing a compensation table during program run	428
10.12	Accessing table values	429
	Application	429
	Reading a table value	429
	Writing a table value	431
	Adding a table value	432
		100
10.13	Monitoring of configured machine components (option 155)	433
	Application	433
	Starting monitoring	433
10.14	Defining a counter	434
	Application	434
	Defining FUNCTION COUNT	435
10.15	Creating text files	436
	Application	436
	Opening and exiting a text file	436
	Editing texts	437
	Deleting and re-inserting characters, words and lines	437
	Editing text blocks	438
	Finding text sections	439
10.16	Freely definable tables	440
	Fundamentals	440

Creating a freely definable table	440
Editing the table format	441
Switching between table and form view	442
FN 26: TABOPEN opening a freely definable table	443
FN 27: TABWRITE writing to a freely definable table	443
FN 28: TABREAD reading a freely definable table	445
Adapting the table format	446
10.17 Pulsing spindle speed FUNCTION S-PULSE	447
Program pulsing spindle speed	447
Resetting the pulsing spindle speed	449
10.18 Dwell time FUNCTION FEED DWELL	450
Programming a dwell time	450
Resetting the dwell time	451
10.19 Dwell time FUNCTION DWELL	452
Programming a dwell time	452
10.20 Lift off tool at NC stop: FUNCTION LIFTOFF	453
Programming tool lift-off with FUNCTION LIFTOFF	453
Resetting the lift-off function	455

11	Multi	ple-axis machining	457
	11.1	Functions for multi-axis machining	458
	11.2	The PLANE function: Tilting the working plane (option 8)	459
		Introduction	459
		Overview	461
		Defining the PLANE function	462
		Position display	462
		Resetting PLANE function	463
		Defining the working plane with spatial angles: PLANE SPATIAL	464
		Defining the working plane with projection angles: PLANE PROJECTED	467
		Defining the working plane with Euler angles: PLANE EULER	469
		Defining the working plane with two vectors: PLANE VECTOR	471
		Defining the working plane via three points: PLANE POINTS	473
		Defining the working plane via a single incremental spatial angle: PLANE RELATIV	475
		Tilting the working plane through axis angles: PLANE AXIAL	476
		Defining the positioning behavior of the PLANE function	478
		Automatic tilting into position MOVE/TURN/STAY	479
		Selection of tilting possibilities SYM (SEQ) +/	482
		Selection of the transformation type	485
		Tilting the working plane without rotary axes	487
	11.3	Inclined machining (option 9)	488
		Function	488
		Inclined machining via incremental traversing of a rotary axis	488
		Inclined machining using normal vectors	489
	11.4	Miscellaneous functions for rotary axes	490
		Feed rate in mm/min on rotary axes A, B, C: M116 (option 8)	490
		Shorter-path traverse of rotary axes: M126	491
		Reducing display of a rotary axis to a value less than 360°: M94	492
		Retaining the position of the tool tip during the positioning of tilting axes (TCPM): M128 (option 9).	493
		Selecting tilting axes: M138	497
		Compensating the machine kinematics in ACTUAL/NOMINAL positions at end of block: M144	157
		(Option 9)	498
	11.5	Compensating for the tool angle of inclination with FUNCTION TCPM (option 9)	499
		Function	499
		Defining FUNCTION TCPM	500
		Effect of the programmed feed rate	501
		Interpretation of the programmed rotary axis coordinates	502
		Orientation interpolation between the start position and end position	503
		Selection of tool reference point and center of rotation	504
		Limiting the linear-axis feed rate	506
		Resetting FUNCTION TCPM	506
		-	

11.6	Three-dimensional tool compensation (option 9)	507
	Introduction	507
	Suppressing error messages with positive tool oversize: M107	508
	Definition of a normalized vector	509
	Permissible tool shapes	510
	Using other tools: Delta values	510
	3-D compensation without TCPM	511
	Face Milling: 3D compensation with TCPM	512
	Peripheral milling: 3-D radius compensation with TCPM and radius compensation (RL/RR)	514
	Interpretation of the programmed path	515
	3-D radius compensation depending on the tool's contact angle (option 92)	516
11.7	Running CAM programs	519
	From 3-D model to NC program	519
	Considerations required for post processor configuration	520
	Please note the following for CAM programming	522
	Possibilities for intervention on the control	524
	ADP motion control	524

12	Data	transfer from CAD files	525
	12.1	Screen layout of the CAD viewer	526
		CAD Viewer fundamentals	526
	12.2	CAD Import (option 42)	527
		Application	527
		Using the CAD viewer	528
		Opening the CAD file	528
		Basic settings	529
		Setting layers	531
		Setting a preset	533
		Setting the datum	535
		Selecting and saving a contour	539
		Selecting and saving machining positions	544
	12.3	Generating STL files with 3D mesh (option 152)	548
		Positioning the 3D model for rear-face machining	550

13	Palle	ets	551
	13.1	Pallet management	552
		Application	552
		Selecting a pallet table	556
		Inserting or deleting columns	556
		Fundamentals of tool-oriented machining	557
	13.2	Batch Process Manager (option 154)	559
		Application	559
		Fundamentals	559
		Opening Batch Process Manager	563
		Creating a job list	565
		Editing a job list	566

14	Turn	ing	569
	14.1	Turning operations on milling machines (option 50)	570
		Introduction	570
		Tool radius compensation (TRC)	571
	14.2	Basic functions (option 50)	573
		Switching between milling and turning mode	573
		Graphic display of turning operations	575
		Programming the spindle speed	577
		Feed rate	578
	14.3	Turning program functions (option 50)	579
		Tool compensation in the NC program	579
		Blank form update TURNDATA BLANK	581
		Inclined turning	582
		Simultaneous turning	584
		Turning operation with FreeTurn tools	586
		Using a facing slide	588
		Cutting force monitoring with the AFC function	593

15	Grino	ling	597
	15.1	Grinding operations on milling machines (option 156)	598
		Introduction	598
		Jig grinding	599
	15.2	Dressing (option 156)	601
		Dressing function fundamentals	601
		Simplified dressing	602
		Compensation methods	602
		Programming with FUNCTION DRESS	604

16	Oper	ating the touchscreen	607
	16.1	Display unit and operation	608
		Touchscreen	608
		Operating panel	609
	16.2	Gestures	611
		Overview of possible gestures	611
		Navigating in the table and NC programs	612
		Operating the simulation	613
		Operating the CAD viewer	614

17	Tables and overviews						
	17.1	System data	622				
		List of FN 18 functions	622 670				
	17.2	Overview tables	674				
		Miscellaneous functions	674 676				

1

Basic information

1.1 About this manual

Safety precautions

Comply with all safety precautions indicated in this document and in your machine manufacturer's documentation!

Precautionary statements warn of hazards in handling software and devices and provide information on their prevention. They are classified by hazard severity and divided into the following groups:

A DANGER

Danger indicates hazards for persons. If you do not follow the avoidance instructions, the hazard **will result in death or severe injury.**

AWARNING

Warning indicates hazards for persons. If you do not follow the avoidance instructions, the hazard **could result in death or serious injury**.

ACAUTION

Caution indicates hazards for persons. If you do not follow the avoidance instructions, the hazard **could result in minor or moderate injury.**

NOTICE

Notice indicates danger to material or data. If you do not follow the avoidance instructions, the hazard **could result in property damage**.

Sequence of information in precautionary statements

All precautionary statements contain the following four sections:

- Signal word indicating the hazard severity
- Type and source of hazard
- Consequences of ignoring the hazard for example: "There is danger of collision during subsequent machining operations"
- Escape hazard prevention measures

Informational notes

Observe the informational notes provided in these instructions to ensure reliable and efficient operation of the software. In these instructions, you will find the following informational notes:



The information symbol indicates a tip.

A tip provides important additional or supplementary information.



This symbol prompts you to follow the safety precautions of your machine manufacturer. This symbol also indicates machine-dependent functions. Possible hazards for the operator and the machine are described in the machine manual.



The book symbol indicates a cross reference.

A cross reference leads to external documentation for example the documentation of your machine manufacturer or other supplier.

Have you found any errors or would you like to suggest changes?

We continuously strive to improve our documentation for you. Please help us by sending your suggestions to the following e-mail address:

tnc-userdoc@heidenhain.de

Control model, software and features 1.2

This manual describes programming functions provided by controls as of the following NC software numbers.



HEIDENHAIN has simplified the version schema, starting with NC software version 16:

- The publication period determines the version number.
- All control models of a publication period have the same version number.
- The version number of the programming stations corresponds to the version number of the NC software.

Control model	NC software number
TNC 640	340590-17
TNC 640 E	340591-17
TNC 640 Programming Station	340595-17

The suffix E indicates the export version of the control. The following software option is unavailable or only available to a limited extent in the export version:

Advanced Function Set 2 (option 9) limited to four-axis interpolation

The machine manufacturer adapts the usable features of the control to his machine by setting appropriate machine parameters. Some of the functions described in this manual may therefore not be among the features provided by the control on your machine tool.

Control functions that may not be available on your machine include:

Tool measurement with the TT

In order to find out about the actual features of your machine, please contact the machine manufacturer.

Many machine manufacturers, as well as HEIDENHAIN, offer programming courses for the HEIDENHAIN controls. Participation in one of these courses is recommended to familiarize yourself thoroughly with the control's functions.



User's Manual for Programming of Machining Cycles:

All functions provided by the machining cycles are described in the User's Manual for Programming of Machining Cycles. Please contact HEIDENHAIN if you need this User's Manual.

ID: 1303406-xx



User's Manual for Programming of Measuring Cycles for Workpieces and Tools:

All functions provided by the touch-probe cycles are described in the User's Manual for Programming of Measuring Cycles for Workpieces and Tools. Please contact HEIDENHAIN if you need this User's Manual. ID: 1303409-xx



User's Manual for Setup, Testing and Running NC **Programs:**

All information for setting up the machine as well as for testing and running your NC programs is provided in the User's Manual for Setup, Testing and Running NC **Programs**. Please contact HEIDENHAIN if you need this User's Manual.

ID: 1261174-xx

Software options

The TNC 640 features various software options, each of which can be enabled separately by your machine manufacturer. The respective options provide the functions listed below:

Additional Axis (option 0 to option	7)	
Additional axis	Additional control loops 1 to 8	
Advanced Function Set 1 (option 8))	
Advanced functions (set 1)	Machining with rotary tables	
	Cylindrical contours as if in two axes	
	Feed rate in distance per minute	
	Coordinate conversions:	
	Tilting the working plane	
	Interpolation:	
	Circular in 3 axes with tilted working plane	
Advanced Function Set 2 (option 9))	
Advanced functions (set 2)	3D machining:	
Export license required	3D tool compensation through surface-normal vectors	
	 Using the electronic handwheel to change the angle of the swivel head 	
	during program run; the position of the tool point remains unchanged (TCPM = T ool C enter	
	Point M anagement)	
	 Keeping the tool normal to the contour 	
	 Tool radius compensation normal to the tool direction 	
	 Manual traverse in the active tool-axis system 	
	Interpolation:	
	Linear in > 4 axes (export license required)	
HEIDENHAIN DNC (option 18)		
	Communication with external PC applications over COM component	
DCM Collision (option 40)		
Dynamic Collision Monitoring	The machine manufacturer defines objects to be monitored	
	Warning in Manual operation	
	Collision monitoring in the Test Run mode	
	Program interrupt in Automatic operation	
	Includes monitoring of 5-axis movements	
CAD Import (option 42)		
CAD import	Support for DXF, STEP and IGES	
·	Adoption of contours and point patterns	
	Simple and convenient specification of presets	
	 Selecting graphical features of contour sections from conversational programs 	

Global PGM Settings – GPS (option 44) Superimposition of coordinate transformations during program run Global program settings Handwheel superimpositioning Adaptive Feed Control – AFC (option 45) Milling: **Adaptive Feed Control** Recording the actual spindle power by means of a teach-in cut Defining the limits of automatic feed rate control Fully automatic feed control during program run Turning (option 50): Cutting force monitoring during machining KinematicsOpt (option 48) Optimizing the machine kinematics Backup/restore active kinematics Test active kinematics Optimize active kinematics **Turning (option 50)** Milling and turning modes **Functions:** Switching between Milling/Turning mode of operation Constant surface speed ■ Tool-tip radius compensation Turning-specific contour elements Turning cycles **Eccentric Turning** Cycle 880 GEAR HOBBING (options 50 and 131) KinematicsComp (option 52) Three-dimensional compensation Compensation of position and component errors OPC UA NC Server (1 to 6) (options 56 to 61) Standardized interface The OPC UA NC Server provides a standardized interface (OPC UA) for external access to the control's data and functions These software options allow you to create up to six parallel client connections 3D-ToolComp (option 92) 3-D tool radius compensation Compensate the deviation of the tool radius depending on the tool's depending on the tool's contact angle contact angle Export license required Compensation values in a separate compensation value table Prerequisite: Working with surface-normal vectors (LN blocks) option 9)

Python-based expansion of tool management

Program-specific or pallet-specific usage sequence of all tools
 Program-specific or pallet-specific tooling list of all tools

39

Extended Tool Management (option 93)

Extended tool management

Advanced Spindle Interpolation (option 96)				
Interpolating spindle	Interpolation turning:			
	Cycle 291 COUPLG.TURNG.INTERP.			
	Cycle 292 CONTOUR.TURNG.INTRP.			
Spindle Synchronism (option 131)				
Spindle synchronization	Synchronization of milling spindle and turning spindle			
	Cycle 880 GEAR HOBBING (options 50 and 131)			
Remote Desktop Manager (option 1	33)			
Remote operation of external compu	ut- Windows on a separate computer unit			
er units	Incorporated in the control's interface			
Synchronizing Functions (option 135	5)			
Synchronization functions	Real Time Coupling (RTC):			
	Coupling of axes			
Cross Talk Compensation - CTC (op	otion 141)			
Compensation of axis couplings	 Determination of dynamically caused position deviation through axis acceleration 			
	Compensation of the TCP (Tool Center Point)			
	= compensation of the for (fool Center Foility)			
Position Adaptive Control – PAC (op	tion 142)			
Adaptive position control	 Adaptation of the control parameters depending on the position of the axes in the working space 			
	 Adaptation of the control parameters depending on the speed or acceleration of an axis 			
Load Adaptive Control – LAC (option	n 143)			
Adaptive load control	 Automatic determination of workpiece weight and frictional forces 			
	 Adaptation of the control parameters depending on the current mass of the workpiece 			
Active Chatter Control – ACC (option	n 145)			
Active chatter control	Fully automatic function for chatter control during machining			
Machine Vibration Control - MVC (o	ption 146)			
Vibration damping for machines	Damping of machine oscillations for improving the workpiece surface quality through the following functions:			
	Active Vibration Damping (AVD)			
	Frequency Shaping Control (FSC)			
CAD Model Optimizer (option 152)				
Optimization of CAD models	Convert and optimize CAD models			
	Fixtures			
	Workpiece blank			
	Finished part			

Batch Process Manager (option 154)		
Batch process manager	Planning of production orders	
Component Monitoring (option 155)		
Component monitoring without exter- nal sensors	Monitoring configured machine components for overload	
Grinding (option 156)		
Jig grinding	Reciprocating stroke cycles	
	Cycles for dressing	
	Support of the "dressing tool" and "grinding tool" tool types	
Gear Cutting (option 157)		
Machining gear systems	Cycle 285 DEFINE GEAR	
	Cycle 286 GEAR HOBBING	
	Cycle 287 GEAR SKIVING	
Turning v2 (option 158)		
Mill-turning version 2	All functions of software option 50	
	Cycle 882 SIMULTANEOUS ROUGHING FOR TURNING	
	Cycle 883 TURNING SIMULTANEOUS FINISHING	
	The advanced turning functions not only enable you to manufacture	
	undercut workpieces but also to use a larger area of the indexable insert	
	during the machining operation.	
Opt. contour milling (option 167)		
Optimized contour cycles	Cycles for machining any pockets and islands using trochoidal milling	

Further options available



HEIDENHAIN offers further hardware enhancements and software options that can be configured and implemented only by your machine manufacturer. This includes functional safety (FS), for example.

For more information, please refer to your machine manufacturer's documentation or the HEIDENHAIN brochure titled **Options and Accessories**.

ID: 827222-xx



VTC User's Manual

All functions of the software for the VT 121 vision system are described in the **VTC User's Manual**. Please contact HEIDENHAIN if you require a copy of this User's Manual.

ID: 1322445-xx

Intended place of operation

The control complies with the limits for a Class A device in accordance with the specifications in EN 55022, and is intended for use primarily in industrially-zoned areas.

Legal information

The control software contains open-source software that is subject to special terms of use. These special terms of use have priority.

To call further information on the control:

- ▶ Press the **MOD** key
- ▶ Select the **General information** group in the MOD menu
- ▶ Select the **License information** MOD function

Furthermore, the control software contains binary libraries of the **OPC UA** software from Softing Industrial Automation GmbH. For these libraries, the terms of use agreed upon between HEIDENHAIN and Softing Industrial Automation GmbH shall additionally apply and prevail.

When using the OPC UA NC server or DNC server, you can influence the behavior of the control. Therefore, before using these interfaces for productive purposes, verify that the control can still be operated without malfunctions or drops in performance. The manufacturer of the software that uses these communication interfaces is responsible for performing system tests.

New functions in 34059x-17



Overview of new and modified software functions

Further information about the previous software versions is presented in the **Overview of New and Modified Software Functions** documentation. Please contact HEIDENHAIN if you need this documentation.

ID: 1322095-xx

- The **FN 18: SYSREAD** (ISO: **D18**) functions have been extended:
 - FN 18: SYSREAD (D18) ID610 NR49: Mode of filter reduction of one axis (IDX) for M120
 - FN 18: SYSREAD (D18) ID780: Information on the current grinding tool
 - NR60: Active compensation method in the COR_TYPE column
 - NR61: Inclination angle of dressing tool
 - FN 18: SYSREAD (D18) ID950 NR48: Value in the R_TIP column of the tool table for the current tool
 - FN 18: SYSREAD (D18) ID11031 NR101: File name of the log file from Cycle 238 MEASURE MACHINE STATUS

Further information: "System data", Page 622

Further information: User's Manual for **Setup, Testing and Running NC Programs**

- Software option 158 was renamed Turning v2.
 - The **Turning v2** software option includes all functions of **Turning** (software option 50) in addition to Cycle **882 SIMULTANEOUS ROUGHING FOR TURNING** and Cycle **883 TURNING SIMULTANEOUS FINISHING**.
- Visual Setup Control (VSC, software option 136) is no longer available.
- The following tool types have been added:
 - Face milling cutter, MILL_FACE
 - Chamfer mill, MILL_CHAMFER
- Define a database ID for the tool in the **DB_ID** column of the tool table. In a tool database for all machines, you can identify tools with unique database IDs (e.g., within a workshop). This allows you to coordinate the tools of multiple machines more easily.

- You define a radius at the tip of the tool in the R_TIP column of the tool table.
- You define the shape of the stylus in the STYLUS column of the touch probe table. You define an L-shaped stylus with the L-TYPE selection.
- Define the compensation method for dressing operations in the COR_TYPE input parameter for grinding tools (option 156):
 - Grinding wheel with compensation, COR_TYPE_GRINDTOOL
 - Stock removal on the grinding tool
 - Dressing tool with wear, COR_TYPE_DRESSTOOL Stock removal on dressing tool
- A link to the Certificate and keys HEROS function has been added to the External access MOD function. This function can be used to define settings for secure connections via SSH.
- The **OPC UA NC Server** enables client applications to access the tool data of the control. You can read and write tool data.
 - The **OPC UA NC Server** does not provide access to the grinding and dressing tool tables (option 156).

Changed functions in 34059x-16

You can use the TABDATA functions for read- and write-access to the preset table.

Further information: "Accessing table values ", Page 429

- CAD-Viewer has been enhanced:
 - Internally, CAD-Viewer always uses mm for its calculations. If you select inches as the unit of measure, CAD-Viewer will convert all values to inches.
 - The **Show sidebar** icon enlarges the Sidebar window to half the size of the screen.
 - The control always shows the **X**, **Y** and **Z** coordinates in the Element Information window. In 2D mode, the control grays out the Z coordinate.
 - **CAD-Viewer** also recognizes circles that consist of two semicircles as machining positions.
 - You can save the information on the workpiece preset and workpiece datum to a file or to the clipboard without having to resort to CAD Import (software option 42).

Further information: "Data transfer from CAD files", Page 525

Further information: User's Manual for Setup, Testing and Running NC Programs

- The simulation considers the following columns of the tool table:
 - R TIP
 - LU
 - RN
- The control considers the following NC functions in the **Test Run** operating mode.
 - **FN 27: TABWRITE** (DIN/ISO: **D27**)
 - FUNCTION FILE
 - FUNCTION FEED DWELL
- The machine manufacturer can define up to 20 components to be monitored by the control by means of component monitoring.
- If a handwheel is active, the control shows the contouring feed rate in the display during program run. If only the currently selected axis is moving, the control shows the axis feed rate.
- In the form view of the tool management, the HW checkbox for grinding tools (option 156) was removed.
- For grinding tools of the **Cup wheel, GRIND_T** type, you can edit the **ALPHA** parameter.
- The minimum input value of the **FMAX** column in the touch probe table has been changed from −9999 to +10.
- The maximum input range of the **LTOL** and **RTOL** columns of the tool table has been increased. The former range was 0 mm to 0.9999 mm; the new range is 0.0000 mm to 5.0000 mm.
- The maximum input range of the **LBREAK** and **RBREAK** columns of the tool table has been increased. The former range was 0 mm to 0.9999 mm; the new range is 0.0000 mm to 9.0000 mm.
- The control no longer supports the ITC 750 additional operating station.
- The Diffuse HEROS tool was removed.

- In the Certificate and keys window you can select a file with additional public SSH keys in the Externally administered SSH key file area. This allows you to use SSH keys without needing to transmit them to the control.
- You can export and import existing network configurations in the Network settings window.
- The machine manufacturer uses the machine parameters allowUnsecureLsv2 (no. 135401) and allowUnsecureRpc (no. 135402) to define whether the control disables non-secure LSV2 or RPC connections even if user administration is not active. These machine parameters are included in the data object CfgDncAllowUnsecur (135400).

When the control detects a non-secure connection, it displays an informational notice.

New cycle functions in 34059x-17

Further information: User's Manual for **Programming of Measuring Cycles for Workpieces and Tools**

Cycle 1416 INTERSECTION PROBING (ISO: G1416)

This cycle allows you to determine the intersection of two edges. The cycle requires a total of four touch points and two positions per edge. You can use the cycle in the three object planes **XY**, **XZ** and **YZ**.

Cycle 1404 PROBE SLOT/RIDGE (ISO: G1404)

This cycle determines the center and the width of a slot or ridge. The control probes two opposing touch points. You can also define a rotation for the slot or the ridge.

- Cycle 1430 PROBE POSITION OF UNDERCUT (ISO: G1430)
 This cycle determines a single position with an L-shaped stylus.
 - The control can probe undercuts due to the shape of the stylus.
- Cycle 1434 PROBE SLOT/RIDGE UNDERCUT (ISO: G1434)

This cycle determines the center and the width of a slot or ridge with an L-shaped stylus. The control can probe undercuts due to the shape of the stylus. The control probes two opposing touch points.

Changed cycle functions in 34059x-17

Further information: User's Manual for **Programming of Machining Cycles**

- Cycle 277 OCM CHAMFERING (ISO: G277, option 167) monitors contour damage on the floor caused by the tool tip. This tool tip results from the radius R, the radius at the tool tip R_TIP, and the point angle T-ANGLE.
- The parameter **Q592 TYPE OF DIMENSION** has been added to Cycle **292 CONTOUR.TURNG.INTRP.** (ISO: **G292**, option 96). This parameter is used to define whether the contour is programmed with radius dimensions or diameter dimensions.
- The following cycles consider the miscellaneous functions M109 and M110:
 - Cycle 22 ROUGH-OUT (ISO: G122)
 - Cycle 23 FLOOR FINISHING (ISO: G123)
 - Cycle 24 SIDE FINISHING (ISO: G124)
 - Cycle **25 CONTOUR TRAIN** (ISO: G125)
 - Cycle 275 TROCHOIDAL SLOT (ISO: G275)
 - Cycle **276 THREE-D CONT. TRAIN** (ISO: G276)
 - Cycle 274 OCM FINISHING SIDE (ISO: G274, option 167)
 - Cycle 277 OCM CHAMFERING (ISO: G277, option 167)
 - Cycle 1025 GRINDING CONTOUR (ISO: G1025, option 156)

Further information: User's Manual for **Programming of Measuring Cycles for Workpieces and Tools**

- If KinematicsComp (software option 52) is active, the log of Cycle 451 MEASURE KINEMATICS (ISO: G451, option 48) shows the active compensations of the angular position errors (locErrA/locErrB/locErrC).
- The log of Cycles **451 MEASURE KINEMATICS** (ISO: **G451**) and **452 PRESET COMPENSATION** (ISO: **G452**, option 48) contains diagrams with the measured and optimized errors of the individual measuring positions.
- Cycle 453 KINEMATICS GRID (ISO: G453, option 48) allows you to use the mode Q406=0 even without KinematicsComp (software option 52).
- Cycle 460 CALIBRATION OF TS ON A SPHERE (ISO: G460) determines the radius and, if required, the length, the center offset and the spindle angle of an L-shaped stylus.
- Cycles 444 PROBING IN 3-D (ISO: G444) and 14xx support probing with an L-shaped stylus.

2

First steps

2.1 Overview

This chapter is intended to help you quickly learn to handle the most important procedures on the control. For more information on the respective topic, see the section referred to in the text.

The following topics are covered in this chapter:

- Switching on the machine
- Programming the workpiece



The following topics are covered in the User's Manual for Setup, Testing and Running NC Programs:

- Switching on the machine
- Graphically testing the workpiece
- Setting up tools
- Setting up the workpiece
- Machining the workpiece

2.2 Switching on the machine

Acknowledging the power interruption

A DANGER

Caution: hazard to the user!

Machines and machine components always pose mechanical hazards. Electric, magnetic, or electromagnetic fields are particularly hazardous for persons with cardiac pacemakers or implants. The hazard starts when the machine is powered up!

- Read and follow the machine manual
- Read and follow the safety precautions and safety symbols
- ► Use the safety devices



Refer to your machine manual.

Switching on the machine and traversing the reference points can vary depending on the machine tool.

To switch on the machine, proceed as follows:

- Switch on the power supply for the control and the machine
- > The control starts the operating system. This process may take several minutes.
- > The control will then display the "Power interrupted" message in the screen header.



- ▶ Press the **CE** key
- > The control compiles the PLC program.



- Switch on the machine control voltage
- > The control is in the **Manual operation** mode.




Depending on your machine, you may need to carry out further steps in order to run NC programs.

Further information on this topic

Switch on the machine

Further information: User's Manual for **Setup, Testing and Running NC Programs**



2.3 Programming the first part

Selecting the operating mode

You can write NC programs only in the **Programming** operating mode:



- ▶ Press the operating mode key
- > The control switches to the **Programming** operating mode.

Further information on this topic

Operating modes

Further information: "Programming", Page 75

Important controls and displays

Key	Functions for conversational guidance	
ENT	Confirm entry and activate the next dialog prompt	
NO ENT	Ignore the dialog question	
END	End the dialog immediately	
DEL 🗆	Abort dialog, discard entries	
	Soft keys on the screen with which you select functions appropriate to the active operating state	

Further information on this topic

Writing and editing NC programs

Further information: "Editing an NC program", Page 102

Overview of keys

Further information: "Controls and displays", Page 2

Creating a new NC program / file management

To create a new NC program:



- ► Press the **PGM MGT** key
- > The control opens the file manager.

 The file management of the control is arranged much like the file management on a PC with Windows Explorer. The file management enables you to manage data in the control's internal memory.
- ▶ Select a folder
- ▶ Enter the desired file name with the extension .H



- ► Press the **ENT** key
- > The control asks for the unit of measure of the new NC program.



Press the soft key of the desired unit of measure:
MM or INCH

The control automatically generates the first and last NC blocks of the NC program. You will not be able to change these NC blocks at a later time.


Further information on this topic

File management

Further information: "File management", Page 108

Creating a new NC program

Further information: "Creating and entering NC programs", Page 92



Defining a workpiece blank

Once you have opened a new NC program, you can define a workpiece blank. You can define a cuboid by entering the MIN and MAX points relative to the selected preset.

After you have selected the desired shape for the blank with the appropriate soft key, the control automatically initiates the workpiece blank definition process and prompts you to enter the required data. To define a cuboid-shaped blank:

- ▶ Press the soft key for the desired shape of the workpiece blank
- ▶ Working plane in graphic: XY: Enter the active spindle axis. Z is saved as default setting. Accept with the ENT key
- ► Workpiece blank def.: minimum X: Enter the smallest X coordinate of the blank relative to the preset (e.g.: 0), and confirm with the ENT key
- ► Workpiece blank def.: minimum Y: Enter the smallest Y coordinate of the blank relative to the preset (e.g.: 0), and confirm with the ENT key
- ▶ Workpiece blank def.: minimum Z: Enter the smallest Z coordinate of the blank relative to the preset (e.g.: -40), and confirm with the ENT key
- ► Workpiece blank def.: maximum X: Enter the largest X coordinate of the blank relative to the preset (e.g.: 100), and confirm with the ENT key
- ► Workpiece blank def.: maximum Y: Enter the largest Y coordinate of the blank relative to the preset (e.g.: 100), and confirm with the ENT key
- ► Workpiece blank def.: maximum Z: Enter the largest Z coordinate of the blank relative to the preset (e.g.: 0), and confirm with the ENT key
- > The control ends the dialog.



The control's full range of functions is available only if the **Z** tool axis is used (e.g., **PATTERN DEF**).

Restricted use of the tool axes **X** and **Y** is possible when prepared and configured by the machine manufacturer.

Example

0 BEGIN PGM NEW MM


1 BLK FORM 0.1 Z X+0 Y+0 Z-40


2 BLK FORM 0.2 X+100 Y+100 Z+0

3 END PGM NEW MM

Further information on this topic

Define workpiece blank
 Further information: "Creating a new NC program", Page 97





Program layout

NC programs should be arranged consistently in a similar manner. This makes it easier to find your place, accelerates programming and reduces errors.

Recommended program layout for simple, conventional contour machining

Example

0 BEGIN PGM BSPCONT MM		
1 BLK FORM 0.1 Z X Y Z		
2 BLK FORM 0.2 X Y Z		
3 TOOL CALL 5 Z S5000		
4 L Z+250 RO FMAX M3		
5 L X Y RO FMAX		
6 L Z+10 R0 F3000 M8		
7 APPR X YRL F500		
16 DEP X Y F3000 M9		
17 L Z+250 RO FMAX M2		
18 END PGM BSPCONT MM		

- 1 Call tool, define tool axis
- 2 Retract the tool; turn on spindle
- 3 Pre-position the tool in the working plane near the contour starting point
- 4 Pre-position the tool along the tool axis above the workpiece, or pre-position the tool directly to the cutting depth, and turn on coolant as needed
- 5 Contour approach
- 6 Contour machining
- 7 Contour departure
- 8 Retract the tool, end the NC program

Further information on this topic

 Contour programming
 Further information: "Programming tool movements for machining", Page 146

HEIDENHAIN | TNC 640 | Klartext Programming User's Manual | 10/2022

Recommended program layout for simple cycle programs Example

O BEGIN PGM BSBCYC MM

1 BLK FORM 0.1 Z X... Y... Z...

2 BLK FORM 0.2 X... Y... Z...

3 TOOL CALL 5 Z S5000

4 L Z+250 RO FMAX M3

5 PATTERN DEF POS1(X... Y... Z...) ...

6 CYCL DEF...

7 CYCL CALL PAT FMAX M8

8 L Z+250 RO FMAX M2

9 END PGM BSBCYC MM

- 1 Call tool, define tool axis
- 2 Retract the tool; turn on spindle
- 3 Define the machining positions
- 4 Define the machining cycle
- 5 Call the cycle, and switch on the coolant
- 6 Retract the tool, end the NC program

Further information on this topic

Cycle programming

Further information: User's Manual for **Programming of Machining Cycles**

Programming a simple contour

Suppose you want to mill a single time around the contour shown on the right at a depth of 5 mm. You have already defined the workpiece blank.

After you have opened an NC block with a function key, the control will prompt you to enter all of the data in the header using dialog texts

To program the contour:

Call the tool



▶ Press the **TOOL CALL** key

▶ Enter the tool data, e.g., tool number 16



▶ Press the ENT key



- ► Confirm the tool axis **Z** with the **ENT** key
- ► Enter the spindle speed (e.g., 6500)




- ▶ Press the END key
- > The control completes the NC block.



The control's full range of functions is available only if the **Z** tool axis is used (e.g., **PATTERN DEF**).

Restricted use of the tool axes ${\bf X}$ and ${\bf Y}$ is possible when prepared and configured by the machine manufacturer.



Retract the tool

- L
- ▶ Press the L key
- Z
- ► Press the **Z** axis key
- ► Enter the retraction value (e.g., 250 mm)
- ENT
- ► Press the **ENT** key
- ENT
- ► At radius compensation, press **ENT**
- The control applies R0, which means there is no radius compensation.
- ENT
- ► At feed rate **F**, press the **ENT** key
- > The control applies FMAX.
- ▶ If needed, enter a miscellaneous function **M**, such as **M3**, turn on spindle
- END
- ▶ Press the **END** key
- > The control saves the positioning block.

Pre-position the tool in the working plane

- L
- ▶ Press the **L** key
- Х
- ► Press the **X** axis key
- ► Enter the value for the position to be approached (e.g., -20 mm)
- Υ
- ► Press the **Y** axis key
- ► Enter the value for the position to be approached (e.g., -20 mm)
- ENT
- ► Press the **ENT** key
- ENT
- At radius compensation, press ENT
- > The control applies RO.
- ENT
- ► At feed rate **F**, press the **ENT** key
- > The control applies **FMAX**.
- ▶ If needed, enter a miscellaneous function M
- END
- ► Press the **END** key
- > The control saves the positioning block.

Position the tool to the cutting depth

L

▶ Press the L key



- ► Press the **Z** axis key
- ► Enter the value for the position to be approached (e.g., -5 mm)



▶ Press the **ENT** key



- ► At radius compensation, press ENT
- > The control applies R0.
- ► Enter the value for the positioning feed rate (e.g., 3000 mm/min)



- ► Press the **ENT** key
- ► Enter a miscellaneous function **M**, such as **M8** to turn coolant on



- ▶ Press the **END** key
- > The control saves the positioning block.

Approach the contour smoothly



- ► Press the **APPR DEP** key
- > The control displays a soft key row with approach and departure functions.



- Press the APPR CT soft key
- Enter the coordinates of the contour starting point 1



- ▶ Press the ENT key
- ► For the center angle **CCA**, enter the approach angle (e.g., 90°)



- ► Press the **ENT** key
- ► Enter the approach radius (e.g., 8 mm)



▶ Press the **ENT** key



- ▶ Press the **RL** soft key
- > The control applies radius compensation to the
- Enter the value for the machining feed rate (e.g., 700 mm/min)



- ▶ Press the **END** key
- > The control saves the approach movement.

Machine the contour

- L
- ▶ Press the **L** key
- Enter the changing coordinates of contour point 2 (e.g., Y 95)
- END
- ► Press the **END** key
- The control applies the changed value and retains all of the other information from the previous NC block.
- ► Press the **L** key
 - Enter the changing coordinates of contour point 3 (e.g., X 95)
- ▶ Press the **END** key
- CHF o
- ▶ Press the **CHF** key
 - ► Enter the chamfer width (10 mm)
- ▶ Press the **END** key
 - > The control saves the chamfer at the end of the linear block.
- ► Press the **L** key
 - Enter the changing coordinates of contour point 4
- ▶ Press the **END** key
- ► Press the **CHF** key
 - ► Enter the chamfer width (20 mm)
- ▶ Press the **END** key

Complete the contour with a smooth departure

- L
- ▶ Press the **L** key
- Enter the changing coordinates of contour point 1
- END
- Press the END key



► Press the **APPR DEP** key



- ▶ Press the **DEP CT** soft key
- ► For the center angle **CCA**, enter the departure angle (e.g., 90°)
- ENT
- Press the ENT key
- ► Enter the departure radius (e.g., 8 mm)
- ENT
- Press the ENT key
- ► Enter the value for the positioning feed rate (e.g., 3000 mm/min)
- ENT
- ► Press the **ENT** key
- ► If needed, enter a miscellaneous function **M**, such as M9, turn off coolant
- END
- ▶ Press the **END** key
- > The control saves the departure movement.

Retract the tool

L

▶ Press the **L** key



- ► Press the **Z** axis key
- ► Enter the retraction value (e.g., 250 mm)



► Press the **ENT** key



- ► At radius compensation, press ENT
- > The control applies RO.



- ► At feed rate **F**, press the **ENT** key
- > The control applies FMAX.
- ► Enter a miscellaneous function **M**, such as **M30** for program end



- ► Press the **END** key
- > The control saves the positioning block and ends the NC program.

Further information on this topic

Complete example with NC blocks
 Further information: "Example: Linear movements and chamfers with Cartesian coordinates", Page 171

Creating a new NC program

Further information: "Creating and entering NC programs", Page 92

Approaching/departing contours

Further information: "Approaching and departing a contour", Page 150

Programming contours

Further information: "Overview of path functions", Page 160

Programmable feed rates

Further information: "Possible feed rate input", Page 100

■ Tool radius compensation

Further information: "Tool radius compensation", Page 139

Miscellaneous functions M

Further information: "Miscellaneous functions for program run inspection, spindle and coolant", Page 234

Creating a cycle program

Suppose that you are tasked with drilling the holes shown to the right with a standard drilling cycle (depth: 20 mm). You have already defined the workpiece blank.

Call the tool

TOOL CALL

- ▶ Press the **TOOL CALL** key
- ► Enter the tool data, e.g., tool number 5

ENT


▶ Press the ENT key

ENT

- ► Confirm the tool axis **Z** with the **ENT** key
- ► Enter the spindle speed (e.g., 4500)

END

- ▶ Press the **END** key
- > The control completes the NC block.



Retract the tool

L

▶ Press the L key

Ζ

- ► Press the **Z** axis key
- ► Enter the retraction value (e.g., 250 mm)

ENT

► Press the **ENT** key

ENT


- ► At radius compensation, press ENT
- > The control applies **R0**, which means there is no radius compensation.

ENT

- ► At feed rate **F**, press the **ENT** key
- > The control applies FMAX.
- ► If needed, enter a miscellaneous function **M**, such as **M3**, turn on spindle

END

- ► Press the **END** key
- > The control saves the positioning block.



Define a pattern



- ▶ Press the **SPEC FCT** key
- > The control opens the soft key row containing the special functions.



▶ Press the **CONTOUR MACHINING** soft key



Press the PATTERN DEF soft key



- ▶ Press the **POINT** soft key
- ► Enter the coordinates of the first position



Confirm each entry with the ENT key



- ► Press the **ENT** key
- > The control opens the dialog for the next position.
- ▶ Enter the coordinates



- ► Confirm each entry with the **ENT** key
- Enter the coordinates of all positions



- ► Press the **END** key
- > The control saves the NC block.

Define the cycle



▶ Press the **CYCL DEF** key



▶ Press the **DRILLING/ THREAD** soft key



- ▶ Press the **200** soft key
- > The control starts the dialog for cycle definition.
- ► Enter the cycle parameters



- Confirm each entry with the ENT key
- > The control displays a graphic illustrating the respective cycle parameter.

Call the cycle



Press the CYCL CALL key



Press the CYCLE CALL PAT soft key



- ► Press the **ENT** key
- > The control applies FMAX.
- ▶ If needed, enter a miscellaneous function M



- ▶ Press the END key
- > The control saves the NC block.

Retract the tool

- L
- ▶ Press the **L** key
- Z
- ▶ Press the **Z** axis key
- ► Enter the retraction value (e.g., 250 mm)
- ENT
- ▶ Press the ENT key
- ENT
- ► At radius compensation, press **ENT**
- > The control applies **R0**.
- ENT
- ► At feed rate **F**, press the **ENT** key
- > The control applies **FMAX**.
- ► Enter a miscellaneous function **M**, such as **M30** for program end
- END
- ► Press the **END** key
- > The control saves the positioning block and ends the NC program.

Example

0 BEGIN PGM C200 MM		
1 BLK FORM 0.1 Z X+0 Y+0 Z-40		Workpiece blank definition
2 BLK FORM 0.2 X+100 Y+100 Z+0		
3 TOOL CALL 5 Z S4500		Tool call
4 L Z+250 RO FMAX M3		Retract the tool; turn on spindle
5 PATTERN DEF POS1 (X+10 Y+10 Z+0) POS2 (X+10 Y+90 Z+0) POS3 (X+90 Y+90 Z+0) POS4 (X+90 Y+10 Z+0)		Define the machining positions
6 CYCL DEF 200 DRILLING		Define the cycle
Q200=2	;SET-UP CLEARANCE	
Q201=-20	;DEPTH	
Q206=250	;FEED RATE FOR PLNGNG	
Q202=5	;PLUNGING DEPTH	
Q210=0	;DWELL TIME AT TOP	
Q203=-10	;SURFACE COORDINATE	
Q204=20	;2ND SET-UP CLEARANCE	
Q211=0.2	;DWELL TIME AT DEPTH	
Q395=0	;DEPTH REFERENCE	
7 CYCL CALL PAT FA	8M XAM	Turn on coolant; call cycle
8 L Z+250 R0 FMAX	(M30	Retract the tool, end program
9 END PGM C200 MM		

Further information on this topic

Creating a new NC program

Further information: "Creating and entering NC programs", Page 92

Cycle programming

Further information: User's Manual for **Programming of Machining Cycles**

3

Fundamentals

3.1 The TNC 640

HEIDENHAIN TNC controls are workshop-oriented contouring controls that enable you to program conventional milling and drilling operations right at the machine in easy-to-use Klartext conversational language. They are designed for milling, drilling, and boring machines, as well as for machining centers, with up to 24 axes. You can also change the angular position of the spindle under program control.

An integrated hard disk provides storage for as many NC programs as you like, even if they were created off-line. For quick calculations you can call up the on-screen calculator at any time.

The keyboard and screen layout are clearly arranged in such a way that the functions are fast and easy to use.



HEIDENHAIN Klartext and ISO

HEIDENHAIN Klartext, the dialog-guided programming language for workshops, is an especially easy method of writing programs. Programming graphics illustrate the individual machining steps for programming the contour. If no NC-dimensioned drawing is available, then the FK free contour programming will help. Workpiece machining can be graphically simulated either during a test run or during a program run.

It is also possible to program in ISO format.

You can also enter and test one NC program while another NC program is machining a workpiece.

Compatibility

NC programs created on HEIDENHAIN contouring controls (starting from the TNC 150 B) may not always run on the TNC 640. If the NC blocks contain invalid elements, the control will mark these as ERROR blocks or with error messages when the file is opened.

3.2 Visual display unit and operating panel

Display screen

The control is shipped with a 19-inch screen.

1 Header

When the control is on, the screen displays the selected operating modes in the header: The machine operating mode at left and the programming mode at right. The currently active mode is displayed in the larger field of the header, where the dialog prompts and messages also appear (exception: if the control only displays graphics).

2 Soft keys

In the footer the control indicates additional functions in a soft-key row. You can select these functions by pressing the keys immediately below them. The thin bars immediately above the soft-key row indicate the number of soft-key rows that can be called with the keys to the right and left that are used to switch the soft keys. The bar representing the active soft-key row is blue

- **3** Soft-key selection keys
- **4** Keys for switching the soft keys
- **5** Setting the screen layout
- **6** Key for switchover between machine operating modes, programming modes, and a third desktop
- 7 Soft-key selection keys for machine tool builders
- 8 Keys for switching the soft keys for machine tool builders



If you are using a TNC 640 with touch control, you can replace some keystrokes with gestures.

Further information: "Operating the touchscreen", Page 607

Setting the screen layout

You select the screen layout yourself. In the **Programming** operating mode, for example, you can have the control show the NC program blocks in the left window while the right window displays programming graphics. You could also display the program structure in the right window instead, or display only the NC program blocks in one large window. The available screen windows depend on the selected operating mode.

Setting up the screen layout:




 Press the screen layout key: The soft-key row shows the available layout options
 Further information: "Modes of operation", Page 74



Select the desired screen layout with a soft key

HEIDENHAIN | TNC 640 | Klartext Programming User's Manual | 10/2022



Operating panel

The TNC 640 can be delivered with an integrated operating panel. The figure at top right shows the operating elements of the external operating panel:

- 1 Alphabetic keyboard for entering texts and file names, as well as for ISO programming
- **2** File manager
 - Calculator
 - MOD function
 - HELP function
 - Show error messages
 - Toggle between the operating modes
- **3** Programming modes
- 4 Machine operating modes
- **5** Initiating programming dialogs
- 6 Navigation keys and GOTO jump command
- 7 Numerical input and axis selection
- 8 Touchpad
- **9** Mouse buttons
- **10** USB connection

The functions of the individual keys are described on the inside front cover.



If you are using a TNC 640 with touch control, you can replace some keystrokes with gestures.

Further information: "Operating the touchscreen", Page 607



Refer to your machine manual.

Some machine manufacturers do not use the standard HEIDENHAIN operating panel.

External keys, e.g. **NC START** or **NC STOP**, are described in your machine manual.



Cleaning



Use operating gloves to prevent the device from becoming

In order to maintain the functionality of the keyboard, use only cleaners stated to contain anionic or nonionic surfactants.



Do not apply the cleaner directly to the keyboard unit. Slightly dampen a suitable cleaning cloth with the cleaner.

Switch the control off before cleaning the keyboard unit.



Never use the following cleaners or cleaning aids, in order to avoid damage to the keyboard unit:

- Aggressive solvents
- Abrasives
- Compressed air
- Steam blasters



The trackball does not require periodic maintenance. Cleaning is required only if the trackball stops functioning.

If a trackball is embedded in the keyboard, clean the trackball as follows:

- Switch off the control
- Turn the pull-off ring by 100° in counterclockwise direction
- Turning the removable pull-off ring moves it upwards out of the keyboard unit.
- Remove the pull-off ring
- Take out the ball
- Carefully remove sand, chips, or dust from the shell area



Scratches in the shell area may impair the functionality or prevent proper functioning.

Apply a small amount of an isopropyl alcohol cleaner to a lint-free and clean cloth



Please observe the information for the cleaner.

Carefully wipe the shell area clean with the cloth until all smears or stains have been removed

HEIDENHAIN | TNC 640 | Klartext Programming User's Manual | 10/2022

Exchanging keycaps

If you need replacements for the keycaps of the keyboard unit, contact HEIDENHAIN or the machine manufacturer.



The IP54 protection rating cannot be guaranteed if the keyboard is missing any keys.

To exchange the keycaps:



► Slide the keycap puller (ID 1325134-01) over the keycap until the grippers engage



Pressing the key will make it easier to apply the keycap puller.



▶ Pull off the keycap



Place the keycap onto the seal and push it down



The seal must not be damaged; otherwise the IP54 protection rating cannot be guaranteed.

Verify proper seating and correct functioning

Extended Workspace Compact

The 24-inch screen provides additional screen workspace to the left of the control's user interface. The additional space enables you to open further applications in addition to the control's user interface so that you can simultaneously keep an eye on the machining process.

This layout is referred to as **Extended Workspace Compact** or **Side View** and provides many multi-touch functions.


In conjunction with the **Extended Workspace Compact** layout, the control provides the following display options:

- Splitting the screen into the control screen and an additional workspace for other applications
- Full-screen mode of the control's user interface
- Full-screen mode for applications

When you switch to full-screen mode, you can use the HEIDENHAIN keyboard for your external applications.



As an alternative, HEIDENHAIN offers a second screen for the control as **Extended Workspace Comfort**. **Extended Workspace Comfort** provides a full-screen view of the control and of an external application.



Screen areas

Extended Workspace Compact is divided into the following areas:

1 JH Standard

The control's user interface is shown in this area.

2 JH Extended

This area provides configurable quick access to the following HEIDENHAIN applications:

- HEROS menu
- 1st workspace: machine operating mode (e.g., Manual Operation)
- 2nd workspace: programming operating mode (e.g., Programming)
- 3rd and 4th workspaces: freely usable for applications (e.g.,
 CAD Converter
- Collection of frequently used soft keys (called hot keys)



Benefits of JH Extended:

- Each operating mode has its own additional soft-key row
- Navigation through the various rows of HEIDENHAIN soft keys is no longer necessary

3 **OEM**

This area is reserved for applications defined or enabled by the machine manufacturer.

Possible contents of the **OEM** area:

- Machine manufacturer's Python application for displaying functions and machine statuses
- Screen contents of an external PC displayed via Remote
 Desktop Manager (option 133)



With **Remote Desktop Manager** (software option 133), you can start additional applications (e.g., from a Windows PC), on your control and have your control display them in the additional workspace or in full-screen mode of **Extended Workspace Compact**.

In the optional machine parameter **connection** (no. 130001), the machine manufacturer defines the application to which the Side View will establish a connection.

Focus control

You can toggle the keyboard focus between the control's user interface and the application being displayed in the Side View.

You have the following options for toggling the focus:

- Select the area where the respective application is shown
- Select the icon of that workspace



Hot keys

The area **JH Extended** provides context-sensitive hot keys depending on the keyboard focus. Once the focus is on an application shown in the Side View, the hot keys provide functions for switching the view.

If more than one application is open in the Side View, you can toggle between the individual applications using the switchover icon.

You can exit full-screen mode at any time by pressing the screen switchover key or an operating-mode key on the keyboard unit.



3.3 Modes of operation

Manual Operation and El. Handwheel


In the **Manual operation** mode of operation, you can set up the machine. You can position the machine axes manually or incrementally, and you can set presets.

If option 8 is active, you can tilt the working plane.

The **Electronic handwheel** operating mode supports manual traverse of machine axes with the HR electronic handwheel.

Soft keys for selecting the screen layout

Soft key	Window
POSITION	Positions
POSITION + STATUS	Left: positions, right: status display
POSITION + WORKPIECE	Left: positions, right: workpiece
POSITION + MACHINE	Left: positions, right: collision objects and workpiece (option 40)




Positioning with Manual Data Input

This mode of operation is used for programming simple traversing movements, such as for face milling or pre-positioning.

Soft keys for selecting the screen layout

Soft key	Window
PGM	NC program
PROGRAM + STATUS	Left: NC program, right: status display
PROGRAM + WORKPIECE	Left: NC program, right: workpiece
PROGRAM + MACHINE	Left: NC program, right: collision objects and workpiece




Programming

In this mode of operation you create NC programs. The FK free programming feature, the various cycles and the Q parameter functions help you with programming and add necessary information. If desired, you can have the programming graphics show the programmed paths of traverse.

Soft keys for selecting the screen layout

Soft key	Window
PGM	NC program
PROGRAM + SECTS	Left: NC program, right: program structure
PROGRAM + GRAPHICS	Left: NC program, right: programming graphics




Test Run

In the **Test Run** operating mode, the control simulates NC programs and program sections in order to check them for errors, such as geometrical incompatibilities, missing or incorrect data within the NC program, or violations of the working space. This simulation is supported graphically in different display modes.

Soft keys for selecting the screen layout

Soft key	Window
PGM	NC program
PROGRAM + STATUS	Left: NC program, right: status display
PROGRAM + WORKPIECE	Left: NC program, right: workpiece
WORKPIECE	Workpiece
PROGRAM + MACHINE	Left: NC program, right: collision objects and workpiece
MACHINE	Collision objects and workpiece



Program Run, Full Sequence and Program Run, Single Block

In the **Program Run Full Sequence** operating mode, the control runs an NC program continuously to its end or to a manual or programmed stop. You can resume program run after an interruption.


In the **Program Run Single Block** operating mode, you execute each NC block separately by pressing the **NC start** key. With point pattern cycles and **CYCL CALL PAT**, the control stops after each point. The workpiece blank definition will be interpreted as a separate NC block.

Soft keys for selecting the screen layout

Soft key	Window
PGM	NC program
PROGRAM + SECTS	Left: NC program, right: structure
PROGRAM + STATUS	Left: NC program, right: status display
PROGRAM + WORKPIECE	Left: NC program, right: workpiece
WORKPIECE	Workpiece
POSITION + MACHINE	Left: NC program, right: collision objects and workpiece
MACHINE	Collision objects and workpiece

Soft keys for screen layout with pallet tables

Soft key	Window
PALLET	Pallet table
PROGRAM + PALLET	Left: NC program, right: pallet table
PALLET + STATUS	Left: pallet table, right: status display
PALLET + GRAPHICS	Left: pallet table, right: graphics
вРМ	Batch Process Manager



3.4 NC fundamentals


Position encoders and reference marks

The machine axes are equipped with position encoders that register the positions of the machine table or tool. Linear axes are usually equipped with linear encoders, rotary tables and tilting axes with angle encoders.

When a machine axis moves, the corresponding position encoder generates an electrical signal. The control evaluates this signal and calculates the precise actual position of the machine axis.

If there is a power interruption, the calculated position will no longer correspond to the actual position of the machine slide. To recover this assignment, incremental position encoders are provided with reference marks. When a reference mark is crossed over, a signal identifying a machine-based reference point is transmitted to the control. This enables the control to re-establish the assignment of the displayed position to the current machine position. For linear encoders with distance-coded reference marks, the machine axes need to move by no more than 20 mm, for angle encoders by no more than 20°.

With absolute encoders, an absolute position value is transmitted to the control immediately upon switch-on. In this way the assignment of the actual position to the machine slide position is re-established directly after switch-on.



Programmable axes

In the default setting, the programmable axes of the control are in accordance with the axis definitions specified in DIN 66217.

The designations of the programmable axes are given in the table below.


Main axis	Parallel axis	Rotary axis
X	U	А
Y	V	В
Z	W	С



Refer to your machine manual.

The number, designation and assignment of the programmable axes depend on the machine.

Your machine tool builder can define further axes, such as PLC axes.



Reference systems

For the control to move an axis in accordance with a defined path, it requires a **reference system**.

A paraxially mounted linear encoder on a machine tool serves as a simple reference system for linear axes. The linear encoder represents a **number ray**, a one-dimensional coordinate system.

To approach a point on the **plane**, the control requires two axes and therefore a reference system with two dimensions.

To approach a point in **space**, the control requires three axes and therefore a reference system with three dimensions. If these three axes are arranged perpendicularly to each other, this creates a **three-dimensional Cartesian coordinate system**.



According to the right-hand rule the fingertips point in the positive directions of the three principal axes.

For a point to be uniquely determined in space, a **coordinate origin** is needed in addition to the arrangement of the three dimensions. The common intersection serves as the coordinate origin in a 3-D coordinate system. This intersection has the coordinates **X+0**, **Y+0**, and **Z+0**.


In order, for example, for the control to always perform a tool change at the same position, as well as always execute a machining operation referenced to the current workpiece position, the control must be able to differentiate between different reference systems.


The control differentiates between the following reference systems:


- Machine coordinate system M-CS:Machine Coordinate System
- Basic coordinate system B-CS:Basic Coordinate System
- Workpiece coordinate system W-CS:Workpiece Coordinate System
- Working plane coordinate system WPL-CS:Working Plane Coordinate System
- Input coordinate system I-CS: Input Coordinate System
- Tool coordinate system T-CS:Tool Coordinate System



All reference systems build upon each other. They are subject to the kinematic chain of the specific machine tool. The machine coordinate system is the reference system.







Machine coordinate system M-CS


The machine coordinate system corresponds to the description of kinematics and therefore to the actual mechanical design of the machine tool.

Because the mechanics of a machine tool never precisely correspond to a Cartesian coordinate system, the machine coordinate system consists of several one-dimensional coordinate systems. These one-dimensional coordinate systems correspond to the physical machine axes that are not necessarily perpendicular to each other.

The position and orientation of the one-dimensional coordinate systems are defined with the aid of translations and rotations based on the spindle tip in the description of kinematics.

The position of the coordinate origin, the machine datum, is defined by the machine manufacturer during machine configuration. The values in the machine configuration define the zero positions of the encoders and the corresponding machine axes. The machine datum does not necessarily have to be located in the theoretical intersection of the physical axes. It can therefore also be located outside of the traverse range.

Because the machine configuration values cannot be modified by the user, the machine coordinate system is used for determining constant positions, e.g. the tool change point.



Machine datum (MZP)

Soft key Application



The user can define shifts in the machine coordinate system according to the specific axis with use of the **OFFSET** values of the preset table.



The machine tool builder configures the **OFFSET** columns of the preset management in accordance with the machine.


Further information: User's Manual for **Setup, Testing and Running NC Programs**

NOTICE

Danger of collision!

Your control may feature an additional pallet preset table, depending on the machine. In this table the machine tool builder can define **OFFSET** values that take effect before the **OFFSET** values you specify in the preset table become effective. The **PAL** tab of the additional status display indicates whether a pallet preset is active, and which one. Since the **OFFSET** values of the pallet preset table are neither shown nor editable, there is a risk of collision during all movements!

- ▶ Refer to the machine tool builder's documentation
- Use pallet presets only in conjunction with pallets
- ► Check the display of the **PAL** tab before you start machining





The **Global Program Settings** function (option 44) additionally provides the **Additive offset (M-CS)** transformation for the tilting axes. This transformation is added to the **OFFSET** values from the preset table and pallet preset table.



Another feature is **OEM-OFFSET**, which is available only to the machine tool builder. **OEM-OFFSET** can be used to define additive axis shifts for rotary and parallel axes.

The sum of all **OFFSET** values (from all the above **OFFSET** input options) results in the difference between the **ACTL.** position and the **RFACTL** position of an axis.

The control converts all movements in the machine coordinate system, independent of the reference system used for value input. Example of a 3-axis machine tool with a Y axis as oblique axis, not arranged perpendicularly to the ZX plane:

- ► In the **Positioning w/ Manual Data Input** operating mode, run an NC block with **L IY+10**
- > The control determines the required axis nominal values from the defined values.
- > During positioning the control moves the **Y and Z** machine axes.
- > The **RFACTL** and **RFNOML** displays show movements of the Y axis and Z axis in the machine coordinate system.
- > The **ACTL.** and **NOML.** displays only show one movement of the Y axis in the input coordinate system.
- ► In the **Positioning w/ Manual Data Input** operating mode, run an NC block with **L IY-10 M91**
- > The control determines the required axis nominal values from the defined values.
- > During positioning the control only moves the Y machine axis.
- > The **RFACTL** and **RFNOML** displays only show one movement of the Y axis in the machine coordinate system.
- > The **ACTL.** and **NOML.** displays show movements of the Y axis and Z axis in the input coordinate system.

The user can program positions related to the machine datum, e.g. by using the miscellaneous function **M91**.


Basic coordinate system B-CS

The basic coordinate system is a 3-D Cartesian coordinate system. Its coordinate origin is the end of the kinematics model.

The orientation of the basic coordinate system in most cases corresponds to that of the machine coordinate system. There may be exceptions to this if a machine manufacturer uses additional kinematic transformations.

The kinematic model and thus the position of the coordinate origin for the basic coordinate system is defined by the machine manufacturer in the machine configuration. The user cannot modify the machine configuration values.

The basic coordinate system serves to determine the position and orientation of the workpiece coordinate system.



Soft key

Application



The user determines the position and orientation of the workpiece coordinate system by using a 3-D touch probe, for example. The control saves the values determined with respect to the basic coordinate system as **BASE TRANSFORM.** values in the preset management.



The machine tool builder configures the **BASE TRANSFORM.** columns of the preset management in accordance with the machine.


Further information: User's Manual for **Setup, Testing and Running NC Programs**

NOTICE

Danger of collision!

Your control may feature an additional pallet preset table, depending on the machine. In this table the machine tool builder can define **BASE TRANSFORM.** values that take effect before the **BASE TRANSFORM.** values you specify in the preset table become effective. The **PAL** tab of the additional status display indicates whether a pallet preset is active, and which one. Since the **BASE TRANSFORM.** values of the pallet preset table are neither visible nor editable, there is danger of collision during all movements!

- Refer to the machine tool builder's documentation
- Use pallet presets only in conjunction with pallets
- Check the display of the PAL tab before you start machining



Workpiece coordinate system W-CS

The workpiece coordinate system is a 3-D Cartesian coordinate system. Its coordinate origin is the active reference point.

The position and orientation of the workpiece coordinate system depend on the **BASE TRANSFORM.** values of the active line in the preset table.

Soft key

Application



The user determines the position and orientation of the workpiece coordinate system by using a 3-D touch probe, for example. The control saves the values determined with respect to the basic coordinate system as **BASE TRANSFORM.** values in the preset management.

Further information: User's Manual for **Setup, Testing and Running NC Programs**




The **Global Program Settings** function (option 44) additionally provides the following transformations:


- The Additive basic rotat. (W-CS) is added to a basic rotation or a 3-D basic rotation from the preset table and the pallet preset table. The Additive basic rotat. (W-CS) is the first transformation that is possible in the workpiece coordinate system (W-CS).
- Shift (W-CS) is added to the shift (Cycle 7 DATUM SHIFT) that is defined in the NC program before tilting the working plane.
- Mirroring is added to the mirroring (Cycle 8 MIRRORING) that is defined in the NC program before tilting the working plane.
- Shift (mW-CS) is effective in the "modified workpiece coordinate system" after applying the Shift (W-CS) or Mirroring (W-CS) transformation and before tilting the working plane.

In the workpiece coordinate system the user defines the position and orientation of the working plane coordinate system with use of transformations.

Transformations in the workpiece coordinate system:

- 3D ROT functions
 - PLANE functions
 - Cycle 19 WORKING PLANE
- Cycle 7 DATUM SHIFT (shifting before tilting the working plane)
- Cycle 8 MIRRORING (mirroring before tilting the working plane)







The result of transformations built up on each other depends on the programming sequence.

In every coordinate system, program only the specified (recommended) transformations. This applies to both setting and resetting the transformations. Any other use may lead to unexpected or undesired results. Please observe the following programming notes.

Programming notes:

- Transformations (mirroring and shifting) that are programmed before the PLANE functions (except for PLANE AXIAL) will change the position of the tilt datum (origin of the working plane coordinate system WPL-CS) and the orientation of the rotary axes
 - If you just program a shift, then only the position of the tilt datum will change
 - If you just program mirroring, then only the orientation of the rotary axes will change
- When used in conjunction with PLANE AXIAL and Cycle 19, the programmed transformations (mirroring, rotation, and scaling) do not affect the position of the tilt datum or the orientation of the rotary axes



Without active transformations in the workpiece coordinate system, the position and orientation of the working plane coordinate system and workpiece coordinate system are identical.

There are no transformations in the workpiece coordinate system on 3-axis machine tools or with pure 3-axis machining. The **BASE TRANSFORM.** values of the active line of the preset table have a direct effect on the working plane coordinate system with this assumption. Other transformations are of course possible in the working plane coordinate system

Further information: "Working plane coordinate system WPL-CS", Page 84

Working plane coordinate system WPL-CS

The working plane coordinate system is a 3-D Cartesian coordinate system.

The position and orientation of the working plane coordinate system depend on the active transformations in the workpiece coordinate system.



Without active transformations in the workpiece coordinate system, the position and orientation of the working plane coordinate system and workpiece coordinate system are identical.

There are no transformations in the workpiece coordinate system on 3-axis machine tools or with pure 3-axis machining. The **BASE TRANSFORM.** values of the active line of the preset table have a direct effect on the working plane coordinate system with this assumption.

In the working plane coordinate system the user defines the position and orientation of the input coordinate system with use of transformations.



The **Mill-Turning** function (option 50) additionally provides the **OEM rotation** and **precession angle** transformations.

- OEM rotation is available only to the machine tool builder and takes effect before the precession angle
- The precession angle is defined in Cycles 800 ADJUST XZ SYSTEM, 801 RESET ROTARY COORDINATE SYSTEM, and 880 GEAR HOBBING, and takes effect before the other transformations of the working plane coordinate system

The active values of the two transformations (if not equal to 0) are shown on the **POS** tab of the additional status display. Check the values also in milling mode because any active transformations will also remain active in that mode!





Refer to your machine manual.


Your machine tool builder can use the **OEM rotation** and **precession angle** transformations also without the **Mill-Turning** function (option 50).


Transformations in the working plane coordinate system:

- Cycle 7 DATUM SHIFT
- Cycle 8 MIRRORING
- Cycle 10 ROTATION
- Cycle 11 SCALING FACTOR
- Cycle 26 AXIS-SPECIFIC SCALING
- PLANE RELATIVE











As a **PLANE** function, **PLANE RELATIVE** is effective in the workpiece coordinate system and aligns the working plane coordinate system.

The values of additive tilting always relate to the current working plane coordinate system.



The **Global Program Settings** function (option 44) additionally provides the **Rotation (WPL-CS)** transformation. This transformation is added to the rotation (Cycle **10 ROTATION**) that is defined in the NC program.



The result of transformations built up on each other depends on the programming sequence.



Without active transformations in the working plane coordinate system, the position and orientation of the input coordinate system and working plane coordinate system are identical.

In addition, there are no transformations in the workpiece coordinate system on 3-axis machine tools or with pure 3-axis machining. The **BASE TRANSFORM.** values of the active line of the preset table have a direct effect on the input coordinate system with this assumption.

Input coordinate system I-CS

The input coordinate system is a 3-D Cartesian coordinate system. The position and orientation of the input coordinate system depend on the active transformations in the working plane coordinate system.



Without active transformations in the working plane coordinate system, the position and orientation of the input coordinate system and working plane coordinate system are identical.

In addition, there are no transformations in the workpiece coordinate system on 3-axis machine tools or with pure 3-axis machining. The **BASE TRANSFORM.** values of the active line of the preset table have a direct effect on the input coordinate system with this assumption.

With the aid of positioning blocks in the input coordinate system, the user defines the position of the tool and therefore the position of the tool coordinate system.



The **NOML.**, **ACTL.**, **LAG**, and **ACTDST** displays are also based on the input coordinate system.

Positioning blocks in input coordinate system:

- Paraxial positioning blocks
- Positioning blocks with Cartesian or polar coordinates
- Positioning blocks with Cartesian coordinates and surface normal vectors

Example

7 X+48 R+

7 L X+48 Y+102 Z-1.5 R0

7 LN X+48 Y+102 Z-1.5 NX-0.04658107 NY0.00045007 NZ0.8848844 R0



The position of the tool coordinate system is determined by the Cartesian coordinates X, Y and Z also for positioning blocks with surface normal vectors.


In conjunction with 3-D tool compensation, the position of the tool coordinate system can be shifted along the surface normal vectors.





Orientation of the tool coordinate system can be performed in various reference systems.

Further information: "Tool coordinate system T-CS", Page 87









A contour referencing the input coordinate system origin can easily be transformed any way you need.

Tool coordinate system T-CS

The tool coordinate system is a 3-D Cartesian coordinate system. Its coordinate origin is the tool reference point. The values of the tool table, $\bf L$ and $\bf R$ with milling tools and $\bf ZL$, $\bf XL$ and $\bf YL$ with turning tools, reference this point.

Further information: User's Manual for **Setup, Testing and Running NC Programs**



For dynamic collision monitoring (option 40) to correctly monitor the tool, the values in the tool table must correspond to the actual dimensions of the tool.

In accordance with the values from the tool table, the coordinate origin of the tool coordinate system is shifted to the tool center point (TCP).

If the NC program does not reference the tool tip, the tool center point must be shifted. The required shift is implemented in the NC program using the delta values during a tool call.



The position of the TCP as shown in the diagram is obligatory in conjunction with 3D tool compensation.



With the aid of positioning blocks in the input coordinate system, the user defines the position of the tool and therefore the position of the tool coordinate system.

If the **TCPM** function or miscellaneous function **M128** is active, the orientation of the tool coordinate system depends on the tool's current angle of inclination.

The user defines the tool's angle of inclination either in the machine coordinate system or in the working plane coordinate system.

Tool angle of inclination in the machine coordinate system:


Example


7 L X+10 Y+45 A+10 C+5 R0 M128


Tool angle of inclination in the working plane coordinate system:

Example

- **6 FUNCTION TCPM F TCP AXIS SPAT PATHCTRL AXIS**
- 7 L A+0 B+45 C+0 R0 F2500
- 7 LN X+48 Y+102 Z-1.5 NX-0.04658107 NY0.00045007 NZ0.8848844 TX-0.08076201 TY-0.34090025 TZ0.93600126 R0 M128
- 7 LN X+48 Y+102 Z-1.5 NX-0.04658107 NY0.00045007 NZ0.8848844 R0 M128









With the shown positioning blocks with vectors, 3D tool compensation is possible with compensation values \mathbf{DL} , \mathbf{DR} and $\mathbf{DR2}$ from the \mathbf{TOOL} CALL block or from the .tco compensation table.


The methods of function of the compensation values depend on the type of tool.

The control detects the various tool types with the columns ${\bf L}, {\bf R}$ and ${\bf R2}$ of the tool table:

- $R2_{TAB} + DR2_{TAB} + DR2_{PROG} = 0$ \rightarrow end mill
- R2_{TAB} + DR2_{TAB} + DR2_{PROG} = R_{TAB} + DR_{TAB} + DR_{PROG}
 → radius cutter or ball cutter
- 0 < R2_{TAB} + DR2_{TAB} + DR2_{PROG} < R_{TAB} + DR_{TAB} + DR_{PROG} → corner-radius cutter or toroidal cutter



Without the **TCPM** function or miscellaneous function **M128**, orientation of the tool coordinate system and input coordinate system is identical.



Designation of the axes on milling machines

The X, Y and Z axes on your milling machine are also referred to as tool axis, principal axis (1st axis) and secondary axis (2nd axis). The assignment of the tool axis is decisive for the assignment of the principal and secondary axes.

Tool axis	Principal axis	Secondary axis
X	Υ	Z
Y	Z	X
Z	Χ	Υ



The control's full range of functions is available only if the **Z** tool axis is used (e.g., **PATTERN DEF**).

Restricted use of the tool axes ${\bf X}$ and ${\bf Y}$ is possible when prepared and configured by the machine manufacturer.

Polar coordinates

If the production drawing is dimensioned in Cartesian coordinates, you write the NC program using Cartesian coordinates. For parts containing circular arcs or angles, it is often simpler to give the dimensions in polar coordinates.


While the Cartesian coordinates X, Y and Z are three-dimensional and can describe points in space, polar coordinates are two-dimensional and describe points in a plane. Polar coordinates have their datum at a circle center (CC), or pole. A position in a plane can be clearly defined by the:


- Polar Radius, the distance from the circle center CC to the position, and the
- Polar Angle, the value of the angle between the angle reference axis and the line that connects the circle center CC with the position.

Setting the pole and the angle reference axis

The pole is set by entering two Cartesian coordinates in one of the three planes. These coordinates also set the reference axis for the polar angle PA.

Coordinates of the pole (plane)	Angle reference axis
X/Y	+X
Y/Z	+Y
Z/X	+Z






Absolute and incremental workpiece positions

Absolute workpiece positions

Absolute coordinates are position coordinates that are referenced to the datum of the coordinate system (origin). Each position on the workpiece is unambiguously defined by its absolute coordinates.

Example 1: Holes dimensioned in absolute coordinates

Hole 1	Hole 2	Hole 3
X = 10 mm	X = 30 mm	X = 50 mm
Y = 10 mm	Y = 20 mm	Y = 30 mm




X

Incremental workpiece positions

Incremental coordinates are referenced to the last programmed nominal position of the tool, which serves as the relative (imaginary) datum. When you write an NC program in incremental coordinates, you thus program the tool to move by the distance between the previous and the subsequent nominal positions. This is why they are also referred to as chain dimensions.

To program a position in incremental coordinates, enter the letter ${\bf I}$ before the axis.

Example 2: Holes dimensioned in incremental coordinates



10

10

Absolute coordinates of hole 4

Y = 10 mm


X = 10 mm	
Y = 10 mm	
Hole 5, with respect to 4	Hole 6, with respect to 5
X = 20 mm	X = 20 mm

Y = 10 mm

Absolute and incremental polar coordinates

Absolute coordinates always refer to the pole and the angle reference axis.

Incremental polar coordinates always refer to the last programmed nominal position of the tool.



Selecting the preset

A production drawing specifies a certain form element of the workpiece (usually a corner) as the absolute reference point (datum). When setting the preset, first align the workpiece along the machine axes, and move the tool to a known position in each axis relative to the workpiece. For each position, set the display of the control either to zero or to a known position value. You thereby assign the workpiece to the reference system that is applicable for the control's display or your NC program.

If the production drawing is dimensioned in relative reference points, simply use the coordinate transformation cycles.

Further information: User's Manual for **Programming of Machining Cycles**


If the production drawing is not dimensioned for NC programming, then select a position or corner of the workpiece as a reference point from which the dimensions of the remaining workpiece positions can be determined.


A particularly convenient way of setting the presets is with a 3-D touch probe from HEIDENHAIN.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

Example

The workpiece drawing shows holes (1 to 4), whose dimensions are shown relative to an absolute preset with the coordinates X=0 Y=0. The coordinates of holes 5 to 7 refer to the relative preset with the absolute coordinates X=450 Y=750. A **Datum shift** allows you to temporarily shift the datum to the position X=450, Y=750 in order for you to program the holes (5 to 7) without further calculations.





3.5 Creating and entering NC programs

Structure of an NC program in HEIDENHAIN Klartext

An NC program consists of a series of NC blocks. The illustration at right shows the elements of an NC block.

The control numbers the NC blocks of an NC program in ascending sequence.

The first NC block of an NC program is identified by **BEGIN PGM**, the program name, and the active unit of measure.

The subsequent NC blocks contain information on

- The workpiece blank
- Tool calls
- Approaching a safe position
- Feed rates and spindle speeds, as well as
- Path contours, cycles and other functions

The last block of a program is identified by **END PGM**, the program name, and the active unit of measure.

NOTICE

Danger of collision!

The control does not automatically check whether collisions can occur between the tool and the workpiece. There is danger of collision during the approach movement after a tool change!

▶ If necessary, program an additional safe auxiliary position

NC block 10 L X+10 Y+5 R0 F100 M3 Path functions Words Block number

Defining the workpiece blank: BLK FORM

Immediately after creating a new NC program, you define an unmachined workpiece blank. If you wish to define the blank at a later stage, then press the **SPEC FCT** key, the **PROGRAM DEFAULTS** soft key, and then the **BLK FORM** soft key. The control needs this definition for its graphical simulations.



- You only need to define the workpiece blank if you wish to run a graphic test for the NC program.
- To make the control represent the workpiece blank in the simulation, the workpiece blank must have minimum dimensions. The minimum dimensions are 0.1 mm or 0.004 inches in all axes and for the radius.
- The **Advanced checks** function in the simulation uses the information from the workpiece blank definition for workpiece monitoring. Even if several workpieces are clamped in the machine, the control can monitor only the active workpiece blank!

Further information: User's Manual for **Setup, Testing and Running NC Programs**



The control's full range of functions is available only if the **Z** tool axis is used (e.g., **PATTERN DEF**).

Restricted use of the tool axes **X** and **Y** is possible when prepared and configured by the machine manufacturer.

The control can depict various types of blank forms:

Soft key	Function
	Define a rectangular blank
	Define a cylindrical blank
	Define a rotationally symmetric blank of any shape
	Load STL file as workpiece blank Optionally load an additional STL file as finished part

Rectangular blank

The sides of the cuboid lie parallel to the X, Y and Z axes. This blank is defined by two of its corner points:

- MIN point: the smallest X, Y and Z coordinates of the blank form, entered as absolute values.
- MAX point: the largest X, Y and Z coordinates of the blank form, entered as absolute or incremental values

Example

O BEGIN PGM NEW MM	Program beginning, name, unit of measure	
1 BLK FORM 0.1 Z X+0 Y+0 Z-40	Spindle axis, MIN point coordinates	
2 BLK FORM 0.2 X+100 Y+100 Z+0	MAX point coordinates	
3 END PGM NEW MM	Program end, name, unit of measure	

Cylindrical blank

The cylindrical blank form is defined by the dimensions of the cylinder:

- X, Y or Z: Rotation axis
- D, R: Diameter or radius of the cylinder (with positive algebraic sign)
- L: Length of the cylinder (with positive algebraic sign)
- DIST: Shifting along the rotational axis
- DI, RI: Inside diameter or inside radius for a hollow cylinder



The parameters **DIST** and **RI** or **DI** are optional and need not be programmed.

Example

O BEGIN PGM NEW MM	Program begin, name, unit of measure	
1 BLK FORM CYLINDER Z R50 L105 DIST+5 RI10	Spindle axis, radius, length, distance, inside radius	
2 END PGM NEW MM	Program end, name, unit of measure	

Rotationally symmetric blank of any shape

You define the contour of the rotationally symmetric blank in a subprogram. Use X, Y or Z as the rotation axis.

In the workpiece blank definition you refer to the contour description:


- DIM_D, DIM-R: Diameter or radius of the rotationally symmetrical blank form
- LBL: Subprogram with the contour description

The contour description may contain negative values in the rotation axis but only positive values in the reference axis. The contour must be closed, i.e. the contour beginning corresponds to the contour end.

If you define a rotationally symmetric blank with incremental coordinates, the dimensions are then independent of the diameter programming.



The subprogram can be designated with a number, an alphanumeric name, or a QS parameter.



Example

O BEGIN PGM NEW MM	Program begin, name, unit of measure	
1 BLK FORM ROTATION Z DIM_R LBL1	Spindle axis, manner of interpretation, subprogram number	
2 M30	End of main program	
3 LBL 1	Subprogram start	
4 L X+0 Z+1	Starting point of contour	
5 L X+50	Programming in the positive direction of the principal axis	
6 L Z-20		
7 L X+70		
8 L Z-100		
9 L X+0		
10 L Z+1	Contour end	
11 LBL 0	End of subprogram	
12 END PGM NEW MM	Program end, name, unit of measure	

STL files as workpiece blank and optional finished part

Integrating STL files as workpiece blank and finished part is particularly convenient in combination with CAM programs, where the required 3-D models are available in addition to the NC program.



Missing 3D models, such as semifinished parts with multiple, separate machining steps, can be created directly on the control with the **EXPORT WORKPIECE** soft key in the **Test Run** operating mode.

The file size depends on the complexity of the geometry.

Further information: User's Manual for **Setup, Testing and Running NC Programs**



Please note that the STL files are limited in respect of the number of permitted triangles:

- 20,000 triangles per STL file in ASCII format
- 50,000 triangles per STL file in binary format

Binary files are loaded faster by the control.

In the workpiece blank definition you refer to the desired STL files by indicating the path. Use the **SELECT FILE** soft key if you want the control to take over the path information automatically.

If you do not wish to load a finished part, then close the dialog after the workpiece blank definition.



The path of the STL file can also be entered directly as text or with a QS parameter.

Example

O BEGIN PGM NEU MM	Program beginning, name, unit of measure	
1 BLK FORM FILE "TNC:\stl" TARGET "TNC:\stl"	Indication of path to the workpiece blank, path to the optional finished part	
2 END PGM NEU MM	Program end, name, unit of measure	



If the NC program and the 3-D models are in a folder or in a defined folder structure, relative paths make it easier to move the files later.

Further information: "Programming notes", Page 260

Creating a new NC program

An NC program is always entered in **Programming** mode. Example for creating a program:



Operating mode: Press the Programming key



- ► Press the **PGM MGT** key
- > The control opens the file manager.

Select the directory in which you wish to store the new NC program:

FILE NAME = NEW.H



- ► Enter the new program name
- ► Press the **ENT** key



- ▶ Select the unit of measure: Press the **MM** or **INCH** soft key
- > The control switches the screen layout and initiates the dialog for defining the BLK FORM (workpiece blank).



Select a rectangular workpiece blank: Press the soft key for a rectangular blank form

Working plane in graphic: XY




► Enter the spindle axis, e.g. **Z**

HEIDENHAIN | TNC 640 | Klartext Programming User's Manual | 10/2022



The control's full range of functions is available only if the Z tool axis is used (e.g., PATTERN DEF).

Restricted use of the tool axes **X** and **Y** is possible when prepared and configured by the machine manufacturer.



Workpiece blank def.: Minimum



► Enter in sequence the X, Y and Z coordinates of the MIN point and confirm each of your entries with the **ENT** key

Workpiece blank def.: Maximum



Enter in sequence the X, Y and Z coordinates of the MAX point and confirm each of your entries with the ENT key

Example

0 BEGIN PGM NEW MM	Program begin, name, unit of measure	
1 BLK FORM 0.1 Z X+0 Y+0 Z-40	Spindle axis, MIN point coordinates	
2 BLK FORM 0.2 X+100 Y+100 Z+0	MAX point coordinates	
3 END PGM NEW MM	Program end, name, unit of measure	


The control automatically generates the block numbers as well as the **BEGIN** and **END** blocks.



If you do not wish to define a workpiece blank, then cancel the dialog at **Working plane in graphic: XY** using the **DEL** key!

Programming tool movements in Klartext

To program an NC block, initiate the dialog by pressing a function key. In the screen headline, the control then asks you for all the information necessary to program the desired function.



Example of a positioning block



▶ Press the **L** key

COORDINATES?



▶ 10 (enter the target coordinate for the X axis)



▶ 20 (enter the target coordinate for the Y axis)



► Go to the next question with **ENT**.

Radius comp.: RL/RR/no comp.?



Enter No radius compensation and go to the next question with ENT

Feed rate F=? / F MAX = ENT

▶ **100** (enter a feed rate of 100 mm/min for this path contour)



► Go to the next question with **ENT**.

MISCELLANEOUS FUNCTION M?

▶ 3 (enter the miscellaneous function M3 Spindle on)



▶ With the **END** key, the control ends this dialog.

Example

3 L X+10 Y+5 R0 F100 M3

Possible feed rate input

Soft key	Functions for setting the feed rate
F MAX	Rapid traverse, blockwise. Exception: If defined before an APPR block, FMAX also in effect for moving to an auxiliary point
	Further information: "Important positions for approach and departure", Page 153
F AUTO	Traverse feed rate automatically calculated in TOOL CALL
F	Move at the programmed feed rate (unit of measure is mm/min or 1/10 inch/min). With rotary axes, the control interprets the feed rate in degrees/min, regardless of whether the NC program is written in mm or inches
FU	Define the feed per revolution (units in mm/1 or inch/1). Caution: In inch-programs, FU cannot be combined with M136
FZ	Define the tooth feed (units in mm/tooth or inch/tooth). The number of teeth must be defined in the tool table in the CUT column.
Key	Functions for conversational guidance
NO ENT	Ignore the dialog question
END 🗆	End the dialog immediately
DEL	Abort the dialog and erase the block

Actual position capture

The control enables you to transfer the current tool position into the NC program, for example during

- Positioning-block programming
- Cycle programming

To transfer the correct position values:

▶ Place the input box at the position in the NC block where you want to insert a position value



- Select the actual-position-capture function
- > In the soft-key row the control displays the axes whose positions can be transferred.



- Select the axis
- > The control writes the current position of the selected axis into the active input box.



In the working plane the control always captures the coordinates of the tool center, even though tool radius compensation is active.

The control takes the active tool length compensation into account and always captures the coordinate of the tool tip in the tool axis.

The control keeps the soft-key row for axis selection active until the **actual position capture** key is pressed again. This behavior remains in effect even if you save the current NC block or open a new NC block with a path function key. If you have to choose an input alternative via soft key (e.g. for radius compensation), then the control closes the soft-key row for axis selection.

The **Actual position capture** function is not permitted when the **Tilt working plane** function is active.

Editing an NC program



You cannot edit the active NC program while it is being run.

While you are creating or editing a NC program, you can select any desired line in the NC program or individual words in an NC block with the arrow keys or the soft keys:

Soft key / key	Function
	Change the position of the current NC block on the screen. Press this soft key to display additional NC blocks that are programmed before the current NC block
	No function if the NC program is fully visible on the screen
	Change the position of the current NC block on the screen. Press this soft key to display addition- al NC blocks that are programmed after the current NC block
	No function if the NC program is fully visible on the screen
+	Move from one NC block to the next NC block
-	Select individual words in an NC block
GOTO П	Select a specific NC block
	Further information: "Using the GOTO key",

Page 198

Soft key / key	Function
CE	Set the selected word to zero
	Erase an incorrect number
	Delete the (clearable) error message
NO ENT	Delete the selected word
DEL	Delete the selected NC block
	Erase cycles and program sections
INSERT LAST NC BLOCK	Insert the NC block that you last edited or deleted

Inserting an NC block at any desired location

- Select the NC block after which you want to insert a new NC block
- Initiate the dialog

Save changes

The control normally saves changes automatically if you switch the operating mode or if you select the file manager. If you deliberately want to save changes to the NC program:

▶ Select the soft-key row with the saving functions



- ▶ Press the **STORE** soft key
- > The control saves all changes made since the last time you saved the program.

Saving an NC program to a new file

You can save the contents of the currently active NC program under a different program name. Proceed as follows:

▶ Select the soft-key row with the saving functions



- Press the SAVE AS soft key
- > The control opens a window in which you can enter the directory and the new file name.
- Select the target directory if required with the SWITCH soft key
- ► Enter the file name
- Confirm with the OK soft key or the ENT key, or abort the process by pressing the CANCEL soft key



The file saved with **SAVE AS** can also be found in the file manager by pressing the **LAST FILES** soft key.

Undoing changes

You can undo all changes made since the last time you saved the program. Proceed as follows:

Select the soft-key row with the saving functions



- ▶ Press the **CANCEL CHANGE** soft key
- > The control opens a window in which you can confirm or cancel this action.
- Confirm with the YES soft key or cancel with the ENT key, or press the NO soft key to abort

Editing and inserting words

- Select a word in an NC block
- Overwrite it with the new value
- > The dialog is available while the word is highlighted.
- ► To accept the change, press the **END** key

If you want to insert a word, press the horizontal arrow key repeatedly until the desired dialog appears. You can then enter the desired value.

Looking for the same words in different NC blocks



► Select a word in an NC block: Press the arrow key repeatedly until the desired word is highlighted



- Select an NC block with the arrow keys
 - Arrow down: search forwards
 - Arrow up: search backwards

The word that is highlighted in the new NC block is the same as the one you selected previously.



If you start a search in a very long NC program, the control shows a progress indicator. You can cancel the search at any time, if necessary.

Marking, copying, cutting and inserting program sections

The control provides the following functions for copying program sections within an NC program or into another NC program:

Soft key	Function
SELECT BLOCK	Switch the marking function on
CANCEL SELECTION	Switch the marking function off
CUT OUT BLOCK	Cut the marked block
INSERT BLOCK	Insert the block that is stored in the buffer memory
COPY	Copy the marked block



To copy a program section:

- Select the soft key row containing the marking functions
- Select the first NC block of the section you wish to copy
- ▶ Mark the first NC block: Press the **SELECT BLOCK** soft key.
- > The control highlights the block in color and displays the **CANCEL SELECTION** soft key.
- ▶ Place the cursor on the last NC block of the program section you wish to copy or cut.
- > The control shows the marked NC blocks in a different color You can end the marking function at any time by pressing the CANCEL SELECTION soft key.
- Copy the selected program section: Press the COPY BLOCK soft key. Cut the selected program section: Press the CUT BLOCK soft key.
- > The control stores the selected block.



If you want to transfer a program section to another NC program, you now need to select the desired NC program in the file manager.

- Use the arrow keys to select the NC block after which you want to insert the copied/cut section
- ► Insert the saved program section: Press the INSERT BLOCK soft kev
- ▶ End the marking function: Press the **CANCEL SELECTION** soft key


The control's search function

The search function of the control enables you to search for any text within an NC program and replace it by a new text, if required.

Finding any text



- Select the search function
- The control superimposes the search window and displays the available search functions in the softkey row.
- ► Enter the text to be searched for, e.g.: **TOOL**
- Select forwards search or backwards search
- Start the search process
- > The control moves to the next NC block containing the text you are searching for
- Repeat the search process
- > The control moves to the next NC block containing the text you are searching for
- Terminate the search function: Press the END soft key









Finding/Replacing any text

NOTICE

Caution: Data may be lost!

The **REPLACE** and **REPLACE ALL** functions overwrite all of the found syntax elements without a confirmation prompt. The original file is not automatically backed up by the control before the replacement process. As a result, NC programs may be irreversibly damaged.

- ► Back up the NC programs, if required, before you start the replacement
- Be appropriately careful when using REPLACE and REPLACE ALL



The **FIND** and **REPLACE** functions cannot be used in the active NC program while the program is running. These functions are also not available if write protection is active.

Select the NC block containing the word you wish to find



- Select the search function
- The control superimposes the search window and displays the available search functions in the softkey row.
- ► Press the **CURRENT WORD** soft key
- The control loads the first word of the current NC block. If required, press the soft key again to load the desired word.

FIND

- Start the search process
- > The control moves to the next occurrence of the text you are searching for.

REPLACE

➤ To replace the text and then move to the next occurrence of the text, press the **REPLACE** soft key. Or, to replace all text occurrences, press the **REPLACE ALL** soft key. Or, to skip the text and move to its next occurrence, press the **FIND** soft key



Terminate the search function: Press the END soft key

3.6 File management

Files

Files in the control	Туре
NC programs in HEIDENHAIN format in ISO format	.H .l
Compatible NC programs HEIDENHAIN unit programs HEIDENHAIN contour programs	.HU .HC
Tables for Tools Tool changers Datums Points Presets Touch probes Backup files Dependent data (e.g. structure items) Freely definable tables Pallets Turning tools Tool compensation	.T .TCH .D .PNT .PR .TP .BAK .DEP .TAB .P .TRN .3DTC
Texts as ASCII files Text files HTML files, e.g. result logs of touch probe cycles Help files	.A .TXT .HTML .CHM
CAD files as ASCII files	.DXF .IGES .STEP

When you write an NC program on the control, you must first enter a program name. The control saves the NC program to the internal memory as a file with the same name. The control can also save texts and tables as files.

The control provides a special file management window in which you can easily find and manage your files. Here you can call, copy, rename and erase files.

You can manage an almost unlimited number of files with the control. The available memory is at least **21 GB**. A single NC program can be up to **2 GB** in size.



Depending on the setting, the control generates backup files with the file name extension *.bak after editing and saving NC programs. This reduces the available memory space.

File names

When you store NC programs, tables and texts as files, the control adds an extension to the file name, separated by a point. This extension indicates the file type.

File name	File type
PROG20	.H

File names, drive names and directory names on the control must comply with the following standard: The Open Group Base Specifications Issue 6 IEEE Std 1003.1, 2004 Edition (POSIX Standard).

The following characters are permitted:

ABCDEFGHIJKLMNOPQRSTUVWXYZabcdefghijklmnopqrstuvwxyz0123456789_-

The following characters have special meanings:

Character Meaning		
	The last period (dot) in a file name is the extension separator	
\ and /	Directory separators	
:	Separates the drive name from the directory	

Do not use any other characters. This helps to prevent file transfer problems, etc.



The names of tables and table columns must start with a letter and must not contain an arithmetic operator (e.g., +). Due to SQL commands, these characters can cause problems when data are input or read.



The maximum permitted path length is 255 characters. The path length consists of the drive characters, the directory name and the file name, including the extension.

Further information: "Paths", Page 110

Displaying externally generated files on the control

The control features several software tools which you can use to display the files shown in the table below. Some of the files can also be edited.

File types	Туре
PDF files Excel tables	pdf xls
Internet files	csv html
Text files	txt ini
Graphic files	bmp gif jpg png

Further information: User's Manual for **Setup, Testing and Running NC Programs**

Directories

To ensure that you can easily find your NC programs and files, we recommend that you organize your internal memory into directories (folders). You can divide a directory into further directories, which are called subdirectories. With the **-/+** key or **ENT** you can show or hide the subdirectories.

Paths

A path indicates the drive and all directories and subdirectories under which a file is saved. The individual names are separated by a backslash \mathbf{L}




The maximum permitted path length is 255 characters. The path length consists of the drive characters, the directory name and the file name, including the extension.

Example

The directory AUFTR1 was created on the **TNC** drive. Then, in the AUFTR1 directory, the directory NCPROG was created and the NC program PROG1.H was copied into it. The NC program now has the following path:

TNC:\AUFTR1\NCPROG\PROG1.H

The chart at right illustrates an example of a directory display with different paths.



Overview: Functions of the file manager

Soft key	Function	Page
COPY ABC XYZ	Copy a single file	115
SELECT TYPE	Display a specific file type	113
NEW FILE	Create new file	115
LAST	Display the last 10 files that were selected	118
DELETE	Delete a file	119
TAG	Tag a file	120
RENAME ABC = XYZ	Rename file	121
PROTECT	Protect a file against editing and erasure	122
UNPROTECT	Cancel file protection	122
ADAPT NC PGM / TABLE	Import file of an iTNC 530	See the User's Manual for Setup, Testing and Running NC Programs
	Customize table view	446
NET	Manage network drives	See the User's Manual for Setup, Testing and Running NC Programs
SELECT EDITOR	Select the editor	122
SORT	Sort files by properties	121
COPY DIR	Copy a directory	118
DELETE	Delete directory with all its subdirectories	
UPDATE LES TREE	Refresh directory	
RENAME ABC = XYZ	Rename a directory	
NEW DIRECTORY	Create a new directory	

Calling the File Manager



- ▶ Press the **PGM MGT** key
- The control displays the file management window (see figure for default setting. If the control displays a different screen layout, press the WINDOW soft key).



If you exit an NC program by pressing the **END** key, the control opens the file manager. The cursor is on the NC program that was just closed.

If you press the **END** key again, the control opens the original NC program again with the cursor on the last selected line. With large files this behavior can cause a delay.


If you press the **ENT** key, the control always opens an NC program with the cursor on line 0.

The narrow window on the left shows the available drives and directories. Drives designate devices with which data are stored or transferred. A drive is the internal memory of the control. Other drives are the interfaces (RS232, Ethernet) to which you can connect a PC for example. A directory is always identified by a folder symbol to the left and the directory name to the right. Subdirectories are shown to the right of and below their parent directories. If there are subdirectories, you can show or hide them using the -/+ key.

If the directory tree is longer than the screen, navigate using the scroll bar or a connected mouse.

The wide window on the right shows you all files that are stored in the selected directory. Each file is shown with additional information, illustrated in the table below.

display	Meaning		
File name File name and file type			
Bytes	File size in bytes		
Status	File properties:		
E	The file has been selected in the Program-ming mode of operation		
S	File is selected in the Test Run operating mode		
M	The file is selected in a Program Run mode of operation		
+	File has non-displayed dependent files with the extension DEP, e.g. with use of the tool usage test		
<u> </u>	File is protected against erasing and editing		
<u> </u>	File is protected against deletion and editing, because it is being run		
Date	Date that the file was last edited		
Time	Time that the file was last edited		





To display the dependent files, set the machine parameter **dependentFiles** (no. 122101) to **MANUAL**.

Selecting drives, directories and files



Call the file manager by pressing the PGM MGT key

Navigate with a connected mouse or use the arrow keys or the soft keys to move the cursor to the desired position on the screen:



► Moves the cursor from the left to the right window, and vice versa





Moves the cursor up and down within a window





Moves the cursor one page up or down within a window



Step 1: Select drive

Move the highlight to the desired drive in the left window



Select a drive: Press the SELECT soft key, or



▶ Press the **ENT** key

Step 2: Select a directory

- Move the highlight to the desired directory in the left window
- > The right-hand window automatically shows all files stored in the highlighted directory

Step 3: Select a file



▶ Press the **SELECT TYPE** soft key



- ▶ Press the **SHOW ALL** soft key
- Move the highlight to the desired file in the right window



▶ Press the **SELECT** soft key, or



- ► Press the **ENT** key
- > The control opens the selected file in the operating mode from which you called the file manager.



If you enter the first letter of the file you are looking for in the file manager, the cursor automatically jumps to the first NC program with the same letter.

Filtering the display

To filter the displayed files:



▶ Press the **SELECT TYPE** soft key



Press the soft key for the desired file type

Alternative:



- ▶ Press the **SHOW ALL** soft key
- > The control displays all files in this folder.

Alternative:



- ▶ Use wildcards, such as 4*.H
- > The control will show all files of file type .h whose name starts with 4.

Alternative:



- ► Enter the file name extension, e.g. *.H;*.D
- > The control will show all files of file type .h and .d.

Any display filter you have set will remain effective even after a control restart,

Creating a new directory

Move the highlight in the left window to the directory in which you want to create a subdirectory



- ▶ Press the **NEW DIRECTORY** soft key
- ► Enter a directory name



Press the ENT key



Press the **OK** soft key to confirm or



▶ Press the **CANCEL** soft key to abort

Creating new file

- Select the directory in the left window in which you wish to create the new file
- ▶ Position the cursor in the right window



- ▶ Press the **NEW FILE** soft key
- ▶ Enter the file name with extension



► Press the **ENT** key


Copying a single file

Move the cursor to the file you wish to copy



- Press the COPY soft key to select the copying function
- > The control opens a pop-up window.

Copying files into the current directory





- ▶ Press the **ENT** key or the **OK** soft key
- > The control copies the file to the active directory. The original file is retained.

Copying files into another directory



Press the Target Directory soft key to select the target directory from a pop-up window



- ▶ Press the **ENT** key or the **OK** soft key
- The control copies the file under the same name to the selected directory. The original file is retained.



When you start the copying process with the **ENT** key or the **OK** soft key, the control displays a pop-up window with a progress indicator.

Copying files into another directory

- ► Select a screen layout with two equally sized windows In the right window
- Press the SHOW TREE soft key
- Move the cursor to the directory into which you wish to copy the files, and display the files in this directory with the ENT key

In the left window

- ▶ Press the **SHOW TREE** soft key
- Select the directory with the files that you want to copy, and display the files with the SHOW FILES soft key



Press the Tag soft key: Call the file tagging functions



Press the Tag soft key: Position the cursor on the file you wish to copy and tag. You can tag several files in this way, if desired



Press the Copy soft key: Copy the tagged files into the target directory

Further information: "Tagging files", Page 120

If you have tagged files in both the left and right windows, the control copies from the directory in which the cursor is located.

Overwriting files

If you copy files to a directory in which other files are stored under the same name, the control will ask whether the files in the target directory should be overwritten:

- Overwrite all files (Existing files field selected): Press the OK soft key, or
- To leave the files as they are, press the **CANCEL** soft key

If you want to overwrite a protected file, select the **Protected files** field, or cancel the process.

Copying a table

Importing lines to a table

If you are copying a table into an existing table, you can overwrite individual lines with the **REPLACE FIELDS** soft key. Prerequisites:

- The target table must exist
- The file to be copied must only contain the lines you want to replace
- Both tables must have the same file extension

NOTICE

Caution: Data may be lost!

The **REPLACE FIELDS** function overwrites all lines of the target file that are contained in the copied table without a confirmation prompt. The original file is not automatically backed up by the control before the replacement process. As a consequence, tables may be irreversibly damaged.

- Back up the tables, if required, before you start the replacement
- ▶ Be accordingly careful when using **REPLACE FIELDS**

Example

With a tool presetter you have measured the length and radius of ten new tools. The tool presetter then generates the TOOL_Import.T tool table with 10 lines (for the 10 tools).

Proceed as follows:

- Copy this table from the external data medium to any directory
- Copy the externally created table to the existing table TOOL.T using the control's file manager.
- > The control asks you whether you want to overwrite the existing TOOL.T tool table.
- ▶ Press the **YES** soft key
- The control will completely overwrite the current TOOL.T tool table. After this copying process the new TOOL.T table consists of 10 lines.
- ▶ Alternative: Press the **REPLACE FIELDS** soft key
- > The control overwrites the 10 lines in the TOOL.T file. The data of the other lines is not changed.

Extracting lines from a table

You can select one or more lines in a table and save them in a separate table.

Proceed as follows:

- Open the table from which you want to copy lines
- Use the arrow keys to select the first line to be copied
- ▶ Press the **MORE FUNCTIONS** soft key
- Press the TAG soft key
- Select additional lines, if required
- ▶ Press the **SAVE AS** soft key
- Enter a name for the table in which the selected lines are to be saved

Copying a directory

- Move the highlight in the right window onto the directory you want to copy
- ► Press the **COPY** soft key
- > The control opens the window for selecting the target directory.
- ► Select the target directory and confirm with the **ENT** key or the **OK** soft key
- > The control copies the selected directory and all its subdirectories to the selected target directory.

Choosing one of the last files selected



▶ Call the file manager: Press the **PGM MGT** key.



Display the last ten files selected: Press the LAST FILES soft key

Press the arrow keys to move the cursor to the file you wish to select:



▶ Moves the cursor up and down within a window






▶ Select the file: Press the **OK** soft key, or



▶ Press the **ENT** key



The **COPY FIELD** soft key allows you to copy the path of a marked file. You can reuse the copied path later (e.g., when calling a program with the **PGM CALL** key).



Deleting a file

NOTICE

Caution: Data may be lost!

The **DELETE** function permanently deletes the file. The control does not perform an automatic backup of the file prior to deletion (e.g., there is no recycle bin). Files are thereby irreversibly deleted.

Regularly back up important data to external drives

Proceed as follows:

Move the cursor to the file you want to delete



- ▶ Press the **DELETE** soft key
- > The control asks whether you want to delete the file
- ► Press the **OK** soft key
- > The control deletes the file.
- ► Alternative: Press the **CANCEL** soft key
- > The control aborts the procedure.

Deleting a directory

NOTICE

Caution: Data may be lost!

The **DELETE ALL** function permanently deletes all files of the directory. The control does not perform an automatic backup of the files prior to deletion (e.g., there is no recycle bin). Files are thereby irreversibly deleted.

Regularly back up important data to external drives

Proceed as follows:

Move the cursor to the directory you want to delete



- ▶ Press the **DELETE ALL** soft key
- The control inquires whether you really intend to delete the directory and all its subdirectories and files.
- ► Press the **OK** soft key
- > The control deletes the directory.
- ▶ Alternative: Press the **CANCEL** soft key
- > The control aborts the procedure.

Tagging files

Soft key	Tagging function
TAG FILE	Tag a single file
TAG ALL FILES	Tag all files in the directory
UNTAG FILE	Untag a single file
UNTAG ALL FILES	Untag all files
COPY ABC → XYZ	Copy all tagged files

Some functions, such as copying or erasing files, can not only be used for individual files, but also for several files at once. To tag several files, proceed as follows:

Move the cursor to the first file



- ► To display the tagging functions, press the **TAG** soft key
- TAG FILE
- ► To tag a file, press the **TAG FILE** soft key



Move the cursor to other files





► To tag another file, press the TAG FILE soft key, etc.

To copy tagged files:



Leave the active soft-key row



► Press the **COPY** soft key

To delete tagged files:



Leave the active soft-key row



▶ Press the **DELETE** soft key

Renaming a file

▶ Move the cursor to the file you wish to rename



- Select the function for renaming: Press the RENAME soft key
- ► Enter the new file name; the file type cannot be changed
- ► To rename: Press the **OK** soft key or the **ENT** key

Sorting files

Select the folder in which you wish to sort the files



- ▶ Press the **SORT** soft key
- Select the soft key with the corresponding display criterion
 - SORT BY NAME
 - SORT BY SIZE
 - SORT BY DATE
 - SORT BY TYPE
 - SORT BY STATUS
 - UNSORTED

Additional functions

Protecting a file and canceling file protection

Place the cursor on the file you want to protect



Select the miscellaneous functions: Press the MORE FUNCTIONS soft key



Activate file protection: Press the **PROTECT** soft key



> The file is tagged with the "protected" symbol.



Cancel file protection: Press the **UNPROTECT** soft key

Selecting the editor

▶ Place the cursor on the file you want to open



► Select the additional functions: Press the **MORE FUNCTIONS** soft key



Select the editor: Press the **SELECT EDITOR** soft key

- Mark the desired editor
 - **TEXT EDITOR** for text files (e.g., .A or .TXT)
 - PROGRAM EDITOR for NC programs .H and .I
 - TABLE EDITOR for tables (e.g., .TAB or .T)
 - BPM EDITOR for pallet tables .P
- ► Press the **OK** soft key

Connecting and removing USB storage devices

The control automatically detects connected USB devices with a supported file system.

To remove a USB device, proceed as follows:



- Move the cursor to the left-hand window
- ▶ Press the **MORE FUNCTIONS** soft key



▶ Remove the USB device

Further information: User's Manual for **Setup, Testing and Running NC Programs**

ADVANCED ACCESS RIGHTS

The **ADVANCED ACCESS RIGHTS** function can only be used in connection with user administration. This function requires the **public** directory.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

Upon the first activation of user administration, the **public** directory below the **TNC:** drive will be connected.



Access rights can only be defined for files located in the **public** directory.

For all files stored on the **TNC:** drive instead of the **public** directory, the **user** function user will automatically be assigned as the owner.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

Displaying hidden files

The control hides system files, as well as files and folders whose name begins with a period.

NOTICE

Caution: Possible loss of data!

The control's operating system uses certain hidden folders and files. These folders and files are hidden by default. Any manipulation of the system data within the hidden folders might damage the control's software. If you save your own files to these folders, the system will create invalid paths.

- ► Always leave hidden folders and files hidden
- Do not use hidden folders and files for saving your own data

If required, you can show the hidden files and folders temporarily, e.g., if a file whose name begins with a period is transferred inadvertently.

To show hidden files and folders:



Press the MORE FUNCTIONS soft key




- ▶ Press the **SHOW FILES** soft key
- > The control displays the files and folders.

Tools

4.1 Entering tool-related data

Feed rate F

The feed rate **F** is the speed at which the tool center point moves. The maximum feed rates can be different for the individual axes and are set in machine parameters.



Input

You can enter the feed rate in the **TOOL CALL** block and in every positioning block.

Further information: "Creating the NC blocks with the path function keys", Page 148

You enter the feed rate **F** in mm/min in millimeter programs, and in 1/10 inch/min in inch-programs, for resolution reasons. Alternatively, with the corresponding soft keys, you can also define the feed rate in mm per revolution (mm/1) **FU** or in mm per tooth (mm/tooth) **FZ**.

Rapid traverse

If you wish to program rapid traverse, enter **FMAX**. To enter **FMAX**, press the **ENT** key or the **FMAX** soft key when the dialog question **FEED RATE F = ?** appears on the control's screen.



Make sure to program rapid traverse movements exclusively with the **FMAX** NC function instead of entering extremely high numerical values. This is the only way to ensure that rapid traverse is active on a block-by-block basis and that you can control rapid traverse independently of the machining feed rate.

Duration of effect

A feed rate entered as a numerical value remains in effect until an NC block with a different feed rate is reached. **FMAX** is only effective in the NC block in which it is programmed. After the NC block with **FMAX** is executed, the feed rate will return to the last feed rate entered as a numerical value.

Changing during program run

You can adjust the feed rate during the program run with the feed rate potentiometer F.

The feed-rate potentiometer only reduces the programmed feed rate, and not the feed rate calculated by the control.

Spindle speed S

The spindle speed S is entered in revolutions per minute (rpm) in a **TOOL CALL** block (tool call). Instead, you can also define the cutting speed Vc in meters per minute (m/min).

Programmed change

In the NC program, you can change the spindle speed in a **TOOL CALL** block by entering only the new spindle speed.

Proceed as follows:



- ▶ Press the **TOOL CALL** key
- ► Ignore the dialog question for **Tool number ?** with the **NO ENT** key
- ► Ignore the dialog question for Working spindle axis X/Y/Z ? with the NO ENT key
- Enter the new spindle speed at the Spindle speed
 S=? prompt, or switch to entry of the cutting speed by pressing the VC soft key



► Confirm your input with the **END** key



- In the following cases the control changes only the speed:
- TOOL CALL block without tool name, tool number, and tool axis
- TOOL CALL block without tool name, tool number, with the same tool axis as in the previous TOOL CALL block

In the following cases the control runs the tool-change macro and inserts a replacement tool if necessary:

- TOOL CALL block with tool number
- TOOL CALL block with tool name
- **TOOL CALL** block without tool name or tool number, with a changed tool axis direction

Changing during program run


You can adjust the spindle speed during program run with the spindle speed potentiometer S.

4.2 Tool data

Requirements for tool compensation

You usually program the coordinates of path contours as they are dimensioned in the workpiece drawing. To allow the control to calculate the tool center path (i.e. the tool compensation) you must also enter the length and radius of each tool you are using.

You can enter tool data either directly in the NC program with **TOOL DEF** or separately in a tool tables. In a tool table, you can also enter additional data for the specific tool. The control will consider all the data entered for the tool when executing the NC program.



Tool number, tool name

Each tool is identified by a number between 0 and 32767. If you are working with tool tables, you can also enter a tool name for each tool. Tool names can have up to 32 characters.



Permitted characters: #\$%&,-_.0123456789@ABCDEFGHIJKLMNOPQRSTUVWXYZ

The control automatically replaces lowercase letters with corresponding uppercase letters during saving.

The tool number 0 is automatically defined as the zero tool with the length L=0 and the radius R=0. In tool tables, tool T0 should also be defined with L=0 and R=0.

Assign unique tool names!

If the control, for example, finds multiple available tools in the tool magazine, it inserts the tool with least remaining tool life.

- Tool that is in the spindle
- Tool that is in the magazine



Refer to your machine manual.

If there are multiple magazines, the machine manufacturer can specify the search sequence of the tools in the magazines.

 Tool that is defined in the tool table but is currently not in the magazine

If the control, for example, finds multiple available tools in the tool magazine, it inserts the tool with least remaining tool life.


Tool length L

Always enter the tool length ${\bf L}$ as an absolute value based on the tool reference point.



The absolute tool length is essential for the control in order to perform numerous functions (e.g., material removal simulation or).

The absolute length of the touch probe is always referenced to the tool reference point. The machine tool builder usually defines the spindle nose as the tool reference point.



Measuring the tool length

You can measure your tools in the machine (e.g., with a tool touch probe) or externally with a tool presetter. If such measurements are not possible, you can determine the tool length.

You have the following options for determining the tool length:

- With a gauge block
- With a calibration pin (inspection tool)



Before you determine tool length, you have to set the preset in the spindle axis.

Determining the tool length with a gauge block



You can only set the preset with a gauge block if the tool reference point is at the spindle nose.


Place the preset on the surface you want to touch off with the tool. This surface might have to be created first.

To set the datum with a gauge block:

- Place the gauge block on the machine table
- Position the spindle nose next to the gauge block
- ► Gradually move in **Z+** direction until you can just slide the gauge block under the spindle nose
- Set the datum in Z

To determine the tool length:

- ► Insert the tool
- ► Touch off the surface
- > The control displays the absolute tool length as the actual position in the position display.




Determining the tool length with a calibration pin and a tool setter

To set the preset with a calibration pin and a tool setter:

- ► Clamp the tool setter onto the machine table.
- ▶ Bring the flexible inner ring of the tool setter to the same height as the fixed outer ring.
- Set the gauge to 0
- ▶ Move the calibration pin onto the flexible inner ring.
- ▶ Set the datum in **Z**

To determine the tool length:

- ▶ Insert the tool
- Move the tool onto the flexible inner ring until the gauge displays
 0
- > The control displays the absolute tool length as the actual position in the position display.



Tool radius R

You can enter the tool radius R directly.

Delta values for lengths and radii

Delta values are offsets in the length and radius of a tool.

A positive delta value represents a tool oversize (**DL**, **DR**>0). For a machining operation with an oversize, enter the value for the oversize in the NC program with **TOOL CALL** or with the help of a compensation table.

A negative delta value describes a tool undersize (**DL**, **DR**<0). An undersize is entered in the tool table for wear.

Delta values are usually entered as numerical values. In a **TOOL CALL** block, you can also assign the values to Q parameters. Input range: You can enter a delta value with up to \pm 99.999 mm.



Delta values from the tool table influence the graphical representation of the clearing simulation.

Delta values from the NC program do not change the depicted size of the **tool** in the simulation. However, the programmed delta values move the **tool** in the simulation by the amount of the defined value.



Delta values from the **TOOL CALL** block influence the position display depending on the optional machine parameter **progToolCallDL** (no. 124501; branch **CfgPositionDisplay** no. 124500).

Tool-specific Q parameters used as delta values

The control calculates all tool-specific Q parameters while a tool call is being executed. The respective Q parameters cannot be used as delta values until the tool call has been completed.

Tool-specific Q parameters that can be used:


Q parameters	Function
Q108	ACTIVE TOOL RADIUS
Q114	ACTIVE TOOL LENGTH

To be able to use tool-specific Q parameters as delta values, you need to program a second tool call.

Example of ball-nose cutter:

You can use **Q108** (active tool radius) to correct the length of a ball-nose cutter to its center (**DL - Q108**).

1 TOOL CALL "BALL_MILL_D4" Z S10000
2 TOOL CALL DL-Q108



Entering tool data into the NC program



Refer to your machine manual.

The machine tool builder determines the scope of functions of the **TOOL DEF** function.

The number, length, and radius of a specific tool are defined in the **TOOL DEF** block of the NC program:

Proceed as follows for the definition:



▶ Press the **TOOL DEF** key.



- Press the appropriate soft key
 - **TOOL NUMBER**
 - TOOL NAME
 - QS
- ► **Tool length**: Compensation value for the tool length
- ► **Tool radius**: Compensation value for the tool radius

Example

4 TOOL DEF 5 L+10 R+5

Calling the tool data

Before you can call the tool, you have to define it in a **TOOL DEF** block or in the tool table.

A **TOOL CALL** in the NC program is programmed with the following data:



- ▶ Press the **TOOL CALL** key
- ▶ **Tool call**: Enter the number or name of the tool. With the **TOOL NAME** soft key, you can enter a name. With the **QS** soft key, you enter a string parameter. The control automatically puts the tool name in quotation marks. You must first assign a tool name to a string parameter. The names refer to an entry in the active tool table TOOL.T.



- ▶ Alternative: Press the **SELECT** soft key
- > The control opens a window where you can select a tool directly from the TOOL.T tool table.
- ➤ To call a tool with other compensation values, enter a decimal point followed by the index you defined in the tool table.
- ► Working spindle axis X/Y/Z: Enter the tool axis
- ➤ **Spindle speed S**: Enter the spindle speed S in revolutions per minute (rpm). Alternatively, you can define the cutting speed Vc in meters per minute (m/min). Press the **VC** soft key
- ▶ Feed rate F: Enter feed rate F in millimeters per minute (mm/min). Alternatively, you can define the feed rate in millimeters per revolution (mm/1) by pressing the FU soft key or in millimeters per tooth (mm/tooth) by pressing FZ. The feed rate is effective until you program a new feed rate in a positioning block or in a TOOL CALL block
- ► Tool length oversize DL: Enter the delta value for the tool length
- Tool radius oversize DR: Enter the delta value for the tool radius
- ► **Tool radius oversize DR2**: Enter the delta value for the tool radius 2



The control's full range of functions is available only if the **Z** tool axis is used (e.g., **PATTERN DEF**).

Restricted use of the tool axes ${\bf X}$ and ${\bf Y}$ is possible when prepared and configured by the machine manufacturer.



In the following cases the control changes only the speed:

- **TOOL CALL** block without tool name, tool number, and tool axis
- **TOOL CALL** block without tool name, tool number, with the same tool axis as in the previous **TOOL CALL** block

In the following cases the control runs the tool-change macro and inserts a replacement tool if necessary:

- TOOL CALL block with tool number
- TOOL CALL block with tool name
- **TOOL CALL** block without tool name or tool number, with a changed tool axis direction

Tool selection in the pop-up window

If you open a pop-up window for tool selection, the control marks all tools available in the tool magazine green.

You can search for a tool in the pop-up window:



- ► Press the **GOTO** key
- ► Alternative: Press the **FIND** soft key
- ► Enter the tool name or tool number



- ▶ Press the ENT key
- > The control goes to the first tool that matches the entered search string.

The following functions can be used with a connected mouse:

- You can sort the data in ascending or descending order by clicking a column of the table head.
- You can arrange the columns in any sequence you want by clicking a column of the table head and then moving it with the mouse key pressed down

The pop-up windows displayed for a tool number search and a tool name search can be configured separately. The sort order and the column widths are retained when the control is switched off.

Tool call

Call tool number 5 in the tool axis Z with a spindle speed of 2500 rpm and a feed rate of 350 mm/min. The tool length and tool radius 2 are to be programmed with an oversize of 0.2 and 0.05 mm, the tool radius with an undersize of 1 mm.

Example

20 TOOL CALL 5.2 Z S2500 F350 DL+0.2 DR-1 DR2+0.05

The character **D** preceding **L**, **R** and **R2** designates delta values.

Preselection of tools



Refer to your machine manual.

The preselection of tools with **TOOL DEF** can vary depending on the individual machine tool.

If you are working with tool tables, use a **TOOL DEF** block to preselect the next tool. Simply enter the tool number, or a Q or QS parameter, or type the tool name in quotation marks.

Tool change

Automatic tool change



Refer to your machine manual.

The tool change function can vary depending on the individual machine tool.

If your machine tool has automatic tool changing capability, the program run is not interrupted. When the control reaches a tool call with **TOOL CALL**, it replaces the inserted tool by another from the tool magazine.

Automatic tool change if the tool life expires: M101



Refer to your machine manual.

The function of **M101** can vary depending on the individual machine tool.

When the specified tool life has expired, the control can automatically insert a replacement tool and continue machining with it. Activate the miscellaneous function **M101** for this. **M101** is reset with **M102**.

Enter the respective tool life after which machining is to be continued with a replacement tool in the **TIME2** column of the tool table. In the **CUR_TIME** column the control enters the current tool life.

If the current tool life is higher than the value entered in the **TIME2** column, a replacement tool will be inserted at the next possible point in the program no later than one minute after expiration of the tool life. The change is made only after the NC block has been completed.

NOTICE

Danger of collision!

During an automatic tool change with **M101**, the control always retracts the tool in the tool axis first. There is danger of collision when retracting tools for machining undercuts, such as side milling cutters or T-slot milling cutters!

- ▶ Use **M101** only for machining operations without undercuts
- ▶ Deactivate the tool change with **M102**

After the tool change the control positions the tool according to the following logic, unless otherwise specified by the machine tool builder:

- If the target position in the tool axis is below the current position, the tool axis is positioned last
- If the target position in the tool axis is above the current position, the tool axis is positioned first

Input parameter BT (block tolerance)

Depending on the NC program, the machining time can increase as a result of the tool life verification and calculation of the automatic tool change. You can influence this with the optional input parameter **BT** (block tolerance).

If you enter the **M101** function, the control continues the dialog by requesting **BT**. Here you define the number of NC blocks (1 to 100) by which the automatic tool change may be delayed. The resulting time period by which the tool change is delayed depends on the content of the NC blocks (e.g. feed rate, path). If you do not define **BT**, the control uses the value 1 or, if applicable, a default value defined by the machine manufacturer.



The higher the value of **BT**, the smaller will be the effect of an extended program duration through **M101**. Please note that this will delay the automatic tool change!

To calculate a suitable initial value for **BT**, use the following formula:

 $BT = 10 \div t$

t: average machining time of an NC block in seconds Round the result up to an integer value. If the calculated result is greater than 100, use the maximum input value of 100.

If you want to reset the current age of a tool (e.g. after changing the indexable inserts), enter the value 0 in the **CUR_TIME** column.

The **M101** miscellaneous function is not available for turning tools and in turning mode (option 50).

Prerequisites for a tool change with M101



As replacement tools, use only tools with the same radius. The control does not automatically check the radius of the tool

If you want the control to check the radius of the replacement tool, enter **M108** in the NC program.

The control performs the automatic tool change at a suitable point in the program. The automatic tool change is not performed:

- During execution of machining cycles
- While radius compensation (RR/RL) is active
- Directly after an approach function **APPR**
- Directly before a departure function **DEP**
- Directly before and after **CHF** and **RND**
- During execution of macros
- During execution of a tool change
- Directly after a TOOL CALL or TOOL DEF
- During execution of SL cycles

Overtime for tool life



This function must be enabled and adapted by the machine manufacturer.

The tool condition at the end of planned tool life depends on e.g. the tool type, machining method and workpiece material. In the **OVRTIME** column of the tool table, enter the time in minutes for which the tool is permitted to be used beyond the tool life.

The machine manufacturer specifies whether this column is enabled and how it is used during tool search.

Prerequisites for NC blocks with surface-normal vectors and 3-D compensation

The active radius $(\mathbf{R} + \mathbf{DR})$ of the replacement tool must not deviate from the radius of the original tool. You can enter the delta values (\mathbf{DR}) either in the tool table or in the NC program (compensation table or **TOOL CALL** block). If deviations occur, the control displays a message and does not replace the tool. You can suppress this message with the M function **M107**, and reactivate it with **M108**.

Further information: "Three-dimensional tool compensation (option 9)", Page 507


4.3 Tool compensation

Introduction

The control adjusts the tool path by the compensation value for the tool length in the spindle axis. In the machining plane, it compensates the tool radius.

If you are writing the NC program directly on the control, the tool radius compensation is effective only in the working plane.

The control accounts for the compensation value in up to six axes including the rotary axes.



Tool length compensation

Length compensation automatically becomes active as soon as a tool is called. It is canceled as soon as a tool is called with the length L=0 (e.g., **TOOL CALL 0**).

NOTICE

Danger of collision!

The control uses the defined tool length from the tool table for compensating for the tool length. Incorrect tool lengths will result in an incorrect tool length compensation. The control does not perform tool length compensation or a collision check for tools with a length of **0** and after a **TOOL CALL 0**. There is a risk of collision during subsequent tool positioning movements!

- Always define the actual tool length of a tool (not just the difference)
- ▶ Use **TOOL CALL 0** only to empty the spindle

With length compensation, delta values from both the NC program and the tool table are considered.

Compensation value = $\mathbf{L} + \mathbf{D}\mathbf{L}_{TAB} + \mathbf{D}\mathbf{L}_{Prog}$ with

L: Tool length L from **TOOL DEF** block or tool table

DL TAB: Oversize for length **DL** in the tool table

DL Prog: Oversize **DL** for length from **TOOL CALL** block or

from the compensation table

The most recently programmed value becomes active.

Further information: "Compensation table",

Page 425

Tool radius compensation

An NC block can contain the following types of tool radius compensation:

- **RL** or **RR** for radius compensation of any contouring function
- **R0**, if there is no radius compensation
- R+ lengthens a paraxial movement by the amount of the tool radius
- R- shortens a paraxial movement by the amount of the tool radius



The control shows an active tool compensation in the general status display.

Radius compensation takes effect as soon as a tool is called and is moved with one of the abovementioned types of tool radius compensation within a straight-line block or within a paraxial movement in the working plane.



The control automatically cancels radius compensation in the following cases:

- Straight-line block with R0
- **DEP** function for departing from the contour
- Selection of a new NC program via PGM MGT

For radius compensation, the control takes the delta values from both the **TOOL CALL** block and the tool table into account:

Compensation value = $\mathbf{R} + \mathbf{D}\mathbf{R}_{TAB} + \mathbf{D}\mathbf{R}_{Prog}$ with

R: Tool radius **R** from **TOOL DEF** block or tool table

DR TAB: Oversize for radius **DR** in the tool table

 $\mathbf{DR}_{\mathsf{Prog}}$: Oversize \mathbf{DR} for radius from \mathbf{TOOL} \mathbf{CALL} block or

from the compensation table


Further information: "Compensation table",


Page 425


Movements without radius compensation: R0

The tool center moves in the working plane to the programmed coordinate.

Applications: Drilling and boring, pre-positioning







Contouring with radius compensation: RR and RL

RR: The tool moves to the right of the programmed contour

RL: The tool moves to the left of the programmed contour


The tool center moves along the contour at a distance equal to the radius. **Right** or **left** are to be understood as based on the direction of tool movement along the workpiece contour.




Between two NC blocks, each with a different tool radius compensation $\bf RR$ and $\bf RL$, there must be at least one traversing block in the working plane without tool radius compensation $\bf R0$.

The control does not put radius compensation into effect until the end of the NC block in which it is first programmed.

When radius compensation is activated with **RR/RL**, and in the case of cancellation with **R0**, the control always positions the tool perpendicularly to the programmed start or end point. Position the tool before the first contour point or after the last contour point such that the contour does not incur damage.





Entering radius compensation within path contours

Radius compensation is entered in an $\bf L$ block. Enter the coordinates of the target point, and confirm your entry with the $\bf ENT$ key.

Radius comp.: RL/RR/no comp.?



► Select tool movement to the left of the contour: Press the **RL** soft key, or



Select tool movement to the right of the contour: Press the RR soft key, or



 Select tool movement without radius compensation, or cancel radius compensation: Press the ENT key



► Terminate the NC block: Press the **END** key

Entering radius compensation within paraxial movements

Radius compensation is entered in a positioning block. Enter the coordinates of the target point, and confirm your entry with the **ENT** key.

TOOL RADIUS COMP: R+/R-/NO COMP?



► The TNC lengthens the traverse path of the tool by the amount of the tool radius



► The TNC shortens the traverse path of the tool by the amount of the tool radius




 Select tool movement without radius compensation, or cancel radius compensation: Press the ENT key



► Terminate the NC block: Press the **END** key

Radius compensation: Machining corners

- Outside corners:
 - If you program radius compensation, the control moves the tool around outside corners on a transitional arc. If necessary, the control reduces the feed rate at outside corners during, for example, large changes in direction
- Inside corners:
 - The control calculates the intersection of the tool center paths at inside corners under radius compensation. Starting at this point, the tool moves along the next contour element. This prevents damage to the workpiece at the inside corners. As a result, the tool radius for a certain contour cannot be selected to be just any size.




NOTICE

Danger of collision!

The control needs safe positions for contour approach and departure. These positions must enable the control to perform compensating movements when radius compensation is activated and deactivated. Incorrect positions can lead to contour damage. Danger of collision during machining!

- Program safe approach and departure positions at a sufficient distance from the contour
- Consider the tool radius
- Consider the approach strategy




5

Programming contours

5.1 Tool movements


Path functions

A workpiece contour is usually composed of several contour elements such as straight lines and circular arcs. With the path functions, you can program the tool movements for **straight lines** and **circular arcs**.



FK free contour programming

If a production drawing is not dimensioned for NC and the dimensions given are not sufficient for creating a part program, you can program the workpiece contour with the FK free contour programming. The control calculates the missing data. With FK programming, you also program tool movements for **straight lines** and **circular arcs**.



Miscellaneous functions M

With the control's miscellaneous functions you can affect

- the program run, e.g., a program interruption
- the machine functions, such as switching spindle rotation and coolant supply on and off
- the path behavior of the tool

Subprograms and program section repeats

If a machining sequence occurs several times in a program, you can save time and reduce the chance of programming errors by entering the sequence once and then defining it as a subprogram or program-section repeat. If you wish to execute a specific NC program section only under certain conditions, you also define this machining sequence as a subprogram. In addition, you can have an NC program call a separate NC program for execution.

Further information: "Subprograms and program section repeats", Page 253

Programming with Q parameters

Instead of programming numerical values in an NC program, you enter markers called Q parameters. You can use the Q parameters for programming mathematical functions that control program execution or describe a contour.

In addition, programming with Q parameters enables you to measure with the 3-D touch probe during the program run.

Further information: "Programming Q parameters", Page 277

5.2 Fundamentals of path functions

Programming tool movements for machining

You create an NC program by programming the path functions for the individual contour elements in sequence. You do this by entering the coordinates of the end points of the contour elements given in the production drawing. The control calculates the actual path of the tool from these coordinates, and from the tool data and radius compensation.

The control moves all machine axes programmed in the NC block of a path function simultaneously.

Movement parallel to the machine axes

If the NC block contains one coordinate, the control moves the tool parallel to the programmed machine axis.

Depending on the individual machine, the machining program is executed by movement of either the tool or the machine table on which the workpiece is clamped. Path contours are programmed as if the tool were moving.

Example

50 L X+100

50 Block number

L Path function **straight line** X+100 Coordinate of the end point

The tool retains the Y and Z coordinates and moves to the position X=100.


Movement in the main planes


If the NC block contains two coordinates, the control moves the tool in the programmed plane.

Example

L X+70 Y+50

The tool retains the Z coordinate and moves on the XY plane to the position X=70, Y=50.





Three-dimensional movement

If the NC block contains three coordinates, the control moves the tool spatially to the programmed position.

Example

L X+80 Y+0 Z-10

You can program up to six axes in a straight line block according to the kinematics of your machine.

Example

L X+80 Y+0 Z-10 A+15 B+0 C-45

Circles and circular arcs

The control moves two machine axes simultaneously on a circular path relative to the workpiece. You can define a circular movement by entering the circle center **CC**.

Use the path functions for circular arcs to program circles in the working plane. You define the main plane based on the spindle axis in the **TOOL CALL**.

Spindle axis	Main plane
Z	XY, also UV, XV, UY
Υ	ZX , also WU, ZU, WX
X	YZ, also VW, YW, VZ

Circular motion in another plane

You can also use the **Tilt the working plane** function or Q parameters to program circular motions that do not lie in the main plane.



Further information: "The PLANE function: Tilting the working plane (option 8)", Page 459


Further information: "Principle and overview of functions", Page 278


Direction of rotation DR for circular movements


When a circular path has no tangential transition to another contour element, enter the direction of rotation as follows:

Clockwise direction of rotation: DR-

Counterclockwise direction of rotation: DR+







Radius compensation

The radius compensation must be in the NC block in which you move to the first contour element. You cannot activate radius compensation in an NC block for a circular path. It must be activated beforehand in a straight-line block.

Further information: "Path contours — Cartesian coordinates",

Page 160

Further information: "Approaching and departing a contour",

Page 150

Pre-positioning

NOTICE


Danger of collision!

The control does not automatically check whether collisions can occur between the tool and the workpiece. Incorrect prepositioning can also lead to contour damage. There is danger of collision during the approach movement!

- Program a suitable pre-position
- ► Check the sequence and contour with the aid of the graphic simulation

Creating the NC blocks with the path function keys

The gray path function keys initiate the dialog. The control asks you successively for all the necessary information and inserts the program block into the NC program.



Example - programming a straight line



▶ Initiate the programming dialog, e.g. for a straight

COORDINATES?



► Enter the coordinates of the straight-line end point, e.g. -20 in X

COORDINATES?



► Enter the coordinates of the straight-line end point (e.g., 30 in Y) and confirm with the **ENT** key

Radius comp.: RL/RR/no comp.?



Select the radius compensation: Press the R0 soft key for the tool to move without compensation, for example.

Feed rate F=? / F MAX = ENT



► Enter **100** (e.g., a feed rate of 100 mm/min; for programming in inches: an input of 100 corresponds to a feed rate of 10 inches/min) and confirm your entry with the **ENT** key, or



Move at rapid traverse: Press the FMAX soft key; or



▶ Traverse at the feed rate defined in the TOOL CALL block: Press the F AUTO soft key.

MISCELLANEOUS FUNCTION M?



► Enter **3** (miscellaneous function e.g. M3) and terminate the dialog with the **END** key

Example

L X-20 Y+30 R0 FMAX M3

5.3 Approaching and departing a contour


Starting point and end point

The tool approaches the first contour point from the starting point. The starting point must be:

- Programmed without radius compensation
- Approachable without danger of collision
- Close to the first contour point


Example in the figure on the right:

If you set the starting point in the dark gray area, the contour will be damaged when the first contour element is approached.



First contour point

You need to program a radius compensation for the tool movement to the first contour point.




Approaching the starting point in the spindle axis

When the starting point is approached, the tool must be moved to the working depth in the spindle axis. If danger of collision exists, approach the starting point in the spindle axis separately.

Example

30 L Z-10 R0 FMAX

31 L X+20 Y+30 RL F350



End point

The end point should be selected so that it is:

- Approachable without danger of collision
- Near to the last contour point
- In order to make sure the contour will not be damaged, the optimal ending point should lie on the extended tool path for machining the last contour element

Example in the figure on the right:

If you set the end point in the dark gray area, the contour will be damaged when the end point is approached.


Departing the end point in the spindle axis:


Program the departure from the end point in the spindle axis separately.

Example

50 L X+60 Y+70 R0 F700

51 L Z+250 RO FMAX






Common starting and end points

Do not program any radius compensation if the starting point and end point are the same.

In order to make sure the contour will not be damaged, the optimal starting point should lie between the extended tool paths for machining the first and last contour elements.

Example in the figure on the right:


If you set the end point in the dark gray area, the contour will be damaged when the contour is approached/departed.



Overview: Types of paths for contour approach and departure

The functions for contour approach **APPR** and departure **DEP** are activated with the **APPR/DEP** key. You can then select the following path forms with the corresponding soft keys:

Approach	Departure	Function
APPR LT	DEP LT	Straight line with tangential connection
APPR LN	DEP LN	Straight line perpendicular to a contour point
APPR CT	DEP CT	Circular arc with tangential connection
APPR LCT	DEP LCT	Circular arc with tangential connection to the contour. Approach and departure to an auxiliary point outside the contour on a tangentially connecting line



Approaching and departing a helix

The tool approaches and departs a helix on its extension by moving in a circular arc that connects tangentially to the contour. You program helical approach and departure with the **APPR CT** and **DEP CT** functions.

Important positions for approach and departure


NOTICE

Danger of collision!

The control traverses from the current position (starting point P_S) to the auxiliary point P_H at the last feed rate entered. If you programmed **FMAX** in the last positioning block before the approach function, the control also approaches the auxiliary point P_H at rapid traverse.

- ► Program a feed rate other than **FMAX** before the approach function
- Starting point P_S
 You program this position in the block before the APPR block.
 P_S lies outside the contour and is approached without radius compensation (R0).
- Auxiliary point P_H Some of the paths for approach and departure go through an auxiliary point P_H that the control calculates from your input in the APPR or DEP block.
- First contour point P_A and last contour point P_E
 You program the first contour point P_A in the APPR block. The
 last contour point P_E can be programmed with any path function.
 If the APPR block also includes the Z coordinate, the control moves the tool simultaneously to the first contour point P_A.
- $\begin{tabular}{ll} \hline \textbf{End point P_N} \\ \hline \textbf{The position P_N lies outside of the contour and results from} \\ \hline \textbf{your input in the DEP block. If the DEP block also includes the Z} \\ \hline \textbf{coordinate, the control moves the tool simultaneously to the end point P_N.} \\ \hline \end{tabular}$

Designation	Meaning
APPR	Approach
DEP	Departure
L	Line
С	Circle
Т	Tangential (smooth connection)
N	Normal (perpendicular)



NOTICE

Danger of collision!

The control does not automatically check whether collisions can occur between the tool and the workpiece. Incorrect prepositioning and incorrect auxiliary points P_H can also lead to contour damage. There is danger of collision during the approach movement!

- Program a suitable pre-position
- Check the auxiliary point P_H, the sequence and the contour with the aid of the graphic simulation



With the APPR LT, APPR LN and APPR CT functions, the control moves the tool to the auxiliary point P_H at the last programmed feed rate (which can also be **FMAX**). With the APPR LCT function, the control moves to the auxiliary point P_H at the feed rate programmed with the APPR block. If no feed rate is programmed yet before the approach block, the control generates an error message.

Polar coordinates

You can also program the contour points for the following approach/departure functions over polar coordinates:

- APPR LT becomes APPR PLT
- APPR LN becomes APPR PLN
- APPR CT becomes APPR PCT
- APPR LCT becomes APPR PLCT
- DEP LCT becomes DEP PLCT

Select by soft key an approach or departure function, then press the orange ${\bf P}$ key.

Radius compensation

The tool radius compensation is programmed together with the first contour point P_A in the APPR block. The DEP blocks automatically discard the tool radius compensation.



If you program **APPR LN** or **APPR CT** with **R0**, the control stops the machining/simulation with an error message. This method of function differs from the iTNC 530 control!


Approaching on a straight line with tangential connection: APPR LT

The tool moves on a straight line from the starting point P_S to an auxiliary point P_H . It then moves to the first contour point P_A on a straight line that connects tangentially to the contour. The auxiliary point P_H is separated from the first contour point P_A by the distance **LEN**.

- Use any path function to approach the starting point P_S
- ▶ Initiate the dialog with the **APPR DEP** key and **APPR LT** soft key



- Coordinates of the first contour point P_A
- ► **LEN**: Distance from the auxiliary point P_H to the first contour point P_A
- Radius compensation RR/RL for machining



Example


11 L X+40 Y+10 R0 F300 M3	; Approach P _S with R0
12 APPR LT X+20 Y+20 Z-10 LEN15 RR F100	; Approach P _A with RR , distance P _H to P _A : LEN15
13 L X+35 Y+35	; Complete the first contour element

Approaching on a straight line perpendicular to the first contour point: APPR LN

- ▶ Use any path function to approach the starting point P_s.
- ▶ Initiate the dialog with the **APPR DEP** key and **APPR LN** soft key:



- Coordinates of the first contour point P_A
- ► Length: Distance to the auxiliary point P_H. Always enter **LEN** as a positive value
- ▶ Radius compensation **RR/RL** for machining



11 L X+40 Y+10 R0 F300 M3	; Approach P _S with R0
12 APPR LN X+10 Y+20 Z-10 LEN+15 RR F100	; Approach P _A with RR ; distance: P _H to P _A : LEN+15
13 L X+20 Y+35	; Complete the first contour element

Approaching on a circular path with tangential connection: APPR CT


The tool moves on a straight line from the starting point P_S to an auxiliary point P_H . It then moves from PH to the first contour point PA following a circular arc that is tangential to the first contour element.

The arc from P_H to P_A is determined through the radius R and the center angle **CCA**. The direction of rotation of the circular arc is automatically derived from the tool path for the first contour element.

- \blacktriangleright Use any path function to approach the starting point P_S.
- ▶ Initiate the dialog with the **APPR DEP** key and **APPR CT** soft key



- Coordinates of the first contour point P_A
- Radius R of the circular arc
 - If the tool should approach the workpiece in the direction defined by the radius compensation: Enter R as a positive value
 - If the tool should approach the workpiece opposite to the radius compensation: Enter R as a negative value
- ► Center angle **CCA** of the arc
 - CCA can be entered only as a positive value
 - Maximum input value 360°
- ▶ Radius compensation **RR/RL** for machining



11 L X+40 Y+10 R0 F300 M3	; Approach P _S with R0
12 APPR CT X+10 Y+20 Z-10 CCA180 R+10 RR F100	; Approach P_A with CCA180 and RR ; distance P_H to P_A : R+10
13 L X+20 Y+35	; Complete the first contour element

Approaching on a circular path with tangential connection from a straight line to the contour: APPR LCT

The tool moves on a straight line from the starting point P_S to an auxiliary point P_H . It then moves to the first contour point P_A on a circular arc. The feed rate programmed in the APPR block is effective for the entire path that the control traversed in the approach block (path P_S to P_A).


If you have programmed the coordinates of all three principal axes X, Y and Z in the approach block, the control moves the tool from the position defined before the APPR block to the auxiliary point $P_{\rm H}$ on all three axes simultaneously. Then the control moves the tool from $P_{\rm H}$ to $P_{\rm A}$ only in the working plane.

The arc is connected tangentially both to the line P_S - P_H as well as to the first contour element. Once these lines are known, the radius then suffices to completely define the tool path.

- ▶ Use any path function to approach the starting point P_S.
- Initiate the dialog with the APPR DEP key and APPR LCT soft key:



- Coordinates of the first contour point P_A
- Radius R of the circular arc. Enter R as a positive value
- ▶ Radius compensation **RR/RL** for machining



11 L X+40 Y+10 R0 F300 M3	; Approach P _S with R0
12 APPR LCT X+10 Y+20 Z-10 R10 RR F100	; Approach P _A with RR ; distance P _H to P _A : R10
13 L X+20 Y+35	; Complete the first contour element


Departing in a straight line with tangential connection: DEP LT

The tool moves on a straight line from the last contour point P_E to the end point P_N . The line lies on the extension of the last contour element. P_N is separated from P_E by the distance **LEN**.

- Program the last contour element with the end point P_E and radius compensation
- ► Initiate the dialog with the **APPR DEP** key and **DEP LT** soft key



▶ LEN: Enter the distance from the last contour element P_E to the end point P_N .



Example

11 L Y+20 RR F100	; Approach the last contour element P_{E} with $\boldsymbol{R}\boldsymbol{R}$	
12 DEP LT LEN12.5 F100	; Approach P _N ; distance P _E to P _N : LEN12.5	


Departing in a straight line perpendicular to the last contour point: DEP LN

The tool moves on a straight line from the last contour point P_E to the end point P_N . The line departs on a perpendicular path from the last contour point P_E . P_N is separated from P_E by the distance **LEN** plus the tool radius.

- ► Program the last contour element with the end point P_E and radius compensation
- ▶ Initiate the dialog with the **APPR DEP** key and **DEP LN** soft key



► **LEN**: Enter the distance from the last contour element to P_N. Important: Enter a positive value in **LEN**



11 L Y+20 RR F100	; Approach the last contour element P _E with RR
12 DEP LN LEN+20 F100	; Approach P_N ; distance P_E to P_N : LEN+20


Departing on a circular path with tangential connection: DEP CT

The tool moves on a circular arc from the last contour point P_E to the end point P_N . The circular arc connects tangentially to the last contour element.

- Program the last contour element with the end point P_E and radius compensation
- Initiate the dialog with the APPR DEP key and DEP CT soft key



- ► Center angle **CCA** of the arc
- ▶ Radius R of the circular arc
 - If the tool should depart the workpiece in the direction opposite to the radius compensation: Enter R as a positive value.
 - If the tool should depart the workpiece in the direction **opposite** to the radius compensation: Enter R as a negative value.



Example

11 L Y+20 RR F100	; Approach the last contour element P_E with \textbf{RR}
12 DEP CT CCA180 R+8 F100	; Approach P _N with CCA180 ; distance P _E to P _N : R+8


Departing on a circular arc tangentially connecting the contour and a straight line: DEP LCT

The tool moves on a circular arc from the last contour point P_S to an auxiliary point P_H . It then moves on a straight line to the end point P_N . The arc is tangentially connected both to the last contour element and to the line from P_H to P_N . Once these lines are known, the radius R suffices to unambiguously define the tool path.

- ► Program the last contour element with the end point P_E and radius compensation
- ▶ Initiate the dialog with the APPR/DEP key and DEP LCT soft key



- Enter the coordinates of the end point P_N
- ▶ Radius R of the circular arc. Enter R as a positive value



11 L Y+20 RR F100	; Approach the last contour element P _E with RR
12 DEP LCT X+10 Y+12 R8 F100	; Approach P_N ; distance P_E to P_N : R8

5.4 Path contours — Cartesian coordinates

Overview of path functions


Key	Function	Tool movement	Required input	Page
L	Straight line L	Straight line	Coordinates of the end point	161
CHF	Chamfer CHF	Chamfer between two straight lines	Chamfer side length	162
CC +	Circle center CC	None	Coordinates of the circle center or pole	164
C P	Circular arc C	Circular arc around a circle center CC to an arc end point	Coordinates of the arc end point, direction of rotation	165
CR	Circular arc CR	Circular arc with a certain radius	Coordinates of the arc end point, arc radius, direction of rotation	167
CT	Circular arc CT	Circular arc with tangen- tial connection to the preceding and subsequent contour elements	Coordinates of the arc end point	169
RND	Corner rounding RND	Circular arc with tangen- tial connection to the preceding and subsequent contour elements	Rounding radius R	163
FK	FK free contour programming	Straight line or circular path with any connection to the preceding contour element	Input depends on the function	184

Straight line L

The control moves the tool in a straight line from its current position to the straight-line end point. The starting point is the end point of the preceding NC block.



- ► Press the **L** key to open a program block for a linear movement
- Coordinates of the end point of the straight line, if necessary
- ► Radius compensation RL/RR/R0
- ▶ Feed rate F
- Miscellaneous function M



Example

11 L Z+100 R0 FMAX M3
12 L X+10 Y+40 RL F200
13 L IX+20 IY-15
14 L X+60 IY-10

Actual position capture

You can also generate a straight-line block (**L** block) by using the **actual position capture** key:

- ► In **Manual Operation** mode, move the tool to the position you want to capture
- Switch the screen display to programming
- Select the NC block after which you want to insert the straight line block



- Press the actual position capture key
- > The control generates a straight-line block with the actual position coordinates.


Inserting a chamfer between two straight lines

The chamfer enables you to cut off corners at the intersection of two straight lines.

- The line blocks before and after the **CHF** block must be in the same working plane as the chamfer.
- The radius compensation before and after the **CHF** block must be the same
- The chamfer must be machinable with the current tool



- ► Chamfer side length: Length of the chamfer, and if necessary:
- ► **Feed rate F** (effective only in **CHF** block)



8 L X+40 IY+5

9 CHF 12 F250

10 L IX+5 Y+0




You cannot start a contour with a CHF block.

A chamfer is possible only in the working plane.

The corner point is cut off by the chamfer and is not part of the contour.

A feed rate programmed in the **CHF** block is effective only in that CHF block. After the **CHF** block, the previous feed rate becomes effective again.



Rounded corners RND


The RND function creates rounding arcs at contour corners.

The tool moves on an arc that connects tangentially to both the preceding and subsequent contour elements.

The rounding arc must be machinable with the called tool.



- Rounding radius: Enter the radius, and if necessary:
- ► **Feed F** (effective only in the **RND** block)



8 L X+10 Y+5




In the preceding and subsequent contour elements, both coordinates must lie in the plane of the rounding arc. If you machine the contour without tool-radius compensation, you must program both coordinates in the plane.

The tool will not move to the corner point.

A feed rate programmed in the **RND** block is effective only in that **RND** block. After the **RND** block, the previous feed rate becomes effective again.

You can also use an $\mbox{\bf RND}$ block for a tangential contour approach.




Circle center CC

You can define a circle center for circles that you program with the C key (circular path C). This is done in the following ways:

- Enter the Cartesian coordinates of the circle center in the working plane, or
- Use the position last programmed, or
- Take over the coordinates with the **Actual-position-capture** key



► Enter coordinates for the circle center or, if you want to use the last programmed position, enter no coordinates



5 CC X+25 Y+25

or

10 L X+25 Y+25

11 CC



The program blocks 10 and 11do not refer to the illustration.

Validity

The circle center definition remains in effect until you program a new circle center.

Entering the circle center incrementally

If you enter the circle center with incremental coordinates, you have programmed it relative to the last programmed position of the tool.



The only effect of **CC** is to define a position as circle center: The tool does not move to this position.

The circle center is also the pole for polar coordinates.

Circular arc C around circle center CC

Before programming a circular arc C, you must first specify the circle center **CC**. The last programmed tool position will be the starting point of the arc.

▶ Move the tool to the starting point of the circle




▶ Enter the **coordinates** of the circle center



- ► Enter the **coordinates** of the arc end point, if necessary:
- Direction of rotation DR
- ▶ Feed F
- ► Miscellaneous function M

5 CC X+25 Y+25
6 L X+45 Y+25 RR F200 M3
7 C X+45 Y+25 DR+



Circular motion in another plane

The control normally makes circular movements in the active working plane. However, you can also program circular arcs that do not lie in the active working plane.

Example

3 TOOL CALL 1 Z S4000

4 ...

5 CC X+25 Z+25

6 L X+45 Y+25 Z+25 RR F200 M3

7 C X+45 Z+25 DR+

By simultaneously rotating these circular movements you can create spatial arcs (arcs in three axes).

Full circle

For the end point, program the same coordinates as for the starting point.



The starting and end points of the arc must lie on the circle. The maximum value for input tolerance is 0.016 mm. Set the input tolerance in the machine parameter **circleDeviation** (no. 200901).


Smallest possible circle that the control can traverse: 0.016 mm.

Circular arc CR with fixed radius

The tool moves on a circular path with the radius R.



- ► Coordinates of the arc end point
- ▶ Note on **Radius R**: The algebraic sign determines the size of the arc!
- ▶ Note on **Direction of rotation DR**: The algebraic sign determines whether the arc is concave or convex.
- Miscellaneous function M
- ▶ Feed F



Full circle

For a full circle, program two semicircle blocks in succession:

The end point of the first semicircle is the starting point of the second. The end point of the second semicircle is the starting point of the first.

Central angle CCA and arc radius R

The starting and end points on the contour can be connected with four arcs of the same radius:

Smaller arc: CCA<180°

Enter the radius with a positive sign, i.e. R>0

Larger arc: CCA>180°

Enter the radius with a negative sign, i.e. R<0

The direction of rotation determines whether the arc is curving

outward (convex) or curving inward (concave):

Convex: Direction of rotation DR- (with radius compensation RL) Concave: Direction of rotation DR+ (with radius compensation RL)




The distance from the starting and end points of the arc diameter cannot be greater than the diameter of the arc.

The maximum radius is 99.9999 m.

You can also enter rotary axes A, B and C.

The control normally makes circular movements in the active working plane. However, you can also program circular arcs that do not lie in the active working plane. By simultaneously rotating these circular movements you can create spatial arcs (arcs in three axes).




40

40

X

10 L X+40 Y+40 RL F200 M3	
11 CR X+70 Y+40 R+20 DR-	; Circular path 1
or	
11 CR X+70 Y+40 R+20 DR+	; Circular path 2
or	
11 CR X+70 Y+40 R-20 DR-	; Circular path 3
or	
11 CR X+70 Y+40 R-20 DR+	; Circular path 4



Circular arc CT with tangential transition


The tool moves on an arc that connects tangentially to the previously programmed contour element.

A connection between two contour elements is called tangential when there is no kink or corner at the intersection between the two contours—the transition is smooth.

The contour element to which the tangential arc connects must be programmed immediately before the **CT** block. This requires at least two positioning blocks.




- Coordinates of the arc end point, and if necessary:
- ▶ Feed F
- Miscellaneous function M





A tangential arc is a two-dimensional operation: the coordinates in the **CT** block and in the contour element preceding it must be in the same plane of the arc!



Superimposing a linear motion on a circular contour

It is possible to superimpose a linear motion on a circular contour defined in Cartesian coordinates, e.g. in order to create a helix.

Superimposed linear motions are possible for the following types of circular contours:

■ Circular contour **C**

Further information: "Circular arc C around circle center CC", Page 165

■ Circular contour CR

Further information: "Circular arc CR with fixed radius", Page 167

Circular contour CT

Further information: "Circular arc CT with tangential transition", Page 169



The tangential transition is effective only for the axes in the circular plane, and not also for the superimposed linear motion.

As an alternative, you can superimpose a circular contour defined in polar coordinates on a linear motion.

Further information: "Helix", Page 177

Input notes

To superimpose a linear motion on a circular contour defined in Cartesian coordinates, program the additional **LIN** syntax element. You can define a linear, rotary, or parallel axis, e.g. **LIN_Z**.


The $\boldsymbol{\mathsf{LIN}}$ syntax element can be defined using free syntax input.

Further information: "Freely editing an NC program", Page 202

Example


11 CR X+50 Y+50 R+50 LIN_Z-3 DR- ; Circular contour with linear Z-axis superimposition

Example: Linear movements and chamfers with Cartesian coordinates




0 BEGIN PGM LINEAR MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-20	Define the workpiece blank for machining simulation
2 BLK FORM 0.2 X+100 Y+100 Z+0	
3 TOOL CALL 1 Z S4000	Call the tool in the spindle axis and with spindle speed
4 L Z+250 R0 FMAX	Retract the tool in the spindle axis at rapid traverse FMAX
5 L X-10 Y-10 R0 FMAX	Pre-position the tool
6 L Z-5 RO F1000 M3	Move to working depth at feed rate F = 1000 mm/min
7 APPR LT X+5 Y+5 LEN10 RL F300	Approach the contour at point 1 on a straight path with tangential connection
8 L Y+95	Move to point 2
9 L X+95	Program the first straight line for corner 3
10 CHF 10	Program a chamfer with length 10 mm
11 L Y+5	Program the second straight line for corner 3 and the first straight line for corner 4
12 CHF 20	Program a chamfer with length 20 mm
13 L X+5	Program the second straight line for corner 4 and approach the last contour point
14 DEP LT LEN10 F1000	Depart the contour on a straight line with tangential connection
15 L Z+250 R0 FMAX M2	Retract the tool, end program
16 END PGM LINEAR MM	

Example: Circular movements with Cartesian coordinates



0 BEGIN PGM CIRCULAR MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-20	Define the workpiece blank for the machining simulation
2 BLK FORM 0.2 X+100 Y+100 Z+0	
3 TOOL CALL 1 Z S4000	Tool call with spindle axis and spindle speed
4 L Z+250 RO FMAX	Retract the tool in the spindle axis at rapid traverse FMAX
5 L X-10 Y-10 R0 FMAX	Pre-position the tool
6 L Z-5 RO F1000 M3	Move to working depth at feed rate F = 1000 mm/min
7 APPR LCT X+5 Y+5 R5 RL F300	Approach the contour at point 1 on a circular path with tangential connection
8 L X+5 Y+85	Program the first straight line for corner 2
9 RND R10 F150	Program a rounding with R = 10 mm, feed rate F = 150 mm/ min
10 L X+30 Y+85	Move to point 3: starting point of the circular path CR
11 CR X+70 Y+95 R+30 DR-	Move to point 4: end point of the circular path CR, with radius R = 30 mm
12 L X+95	Move to point 5
13 L X+95 Y+40	Move to point 6: starting point of the circular path CT
14 CT X+40 Y+5	Move to point 7: end point of the circular path CT, arc with tangential connection to point 6; the control calculates the radius automatically
15 L X+5	Move to last contour point 1
16 DEP LCT X-20 Y-20 R5 F1000	Depart contour on a circular path with tangential connection
17 L Z+250 RO FMAX M2	Retract the tool, end program
18 END PGM CIRCULAR MM	

Example: Full circle with Cartesian coordinates



0 BEGIN PGM C-CC MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-20	Workpiece blank definition
2 BLK FORM 0.2 X+100 Y+100 Z+0	
3 TOOL CALL 1 Z S3150	Tool call
4 CC X+50 Y+50	Define the circle center
5 L Z+250 RO FMAX	Retract the tool
6 L X-40 Y+50 R0 FMAX	Pre-position the tool
7 L Z-5 R0 F1000 M3	Move to working depth
8 APPR LCT X+0 Y+50 R5 RL F300	Approach the start of circle on a circular path with tangential connection
9 C X+0 DR-	Move to the circle end point (= circle starting point)
10 DEP LCT X-40 Y+50 R5 F1000	Depart the contour on a circular path with tangential connection
11 L Z+250 R0 FMAX M2	Retract the tool, end program
12 END PGM C-CC MM	

5.5 Path contours - Polar coordinates

Overview

With polar coordinates you can define a position in terms of its angle ${\bf PA}$ and its distance ${\bf PR}$ relative to a previously defined pole ${\bf CC}$.

Polar coordinates are useful with:

- Positions on circular arcs
- Workpiece drawing dimensions in degrees, e.g. bolt hole circles

Overview of path functions with polar coordinates


Key	Tool movement	Required input	Page
+ P	Straight line	Polar radius, polar angle of the straight- line end point	175
с + Р	Circular path around circle center/pole to arc end point	Polar angle of the arc end point, direction of rotation	176
СТ Р Р	Circular arc with tangential connection to the preceding contour element	Polar radius, polar angle of the arc end point	176
C + P	Combination of a circular and a linear movement	Polar radius, polar angle of the arc end point, coordinate of the end point in the tool axis	177


Datum for polar coordinates: pole CC

You can set the pole CC at any point in the NC program, before indicating positions in polar coordinates. Set the pole in the same way as you would program the circle center.



▶ Coordinates: Enter Cartesian coordinates for the pole or, if you want to use the last programmed position, do not enter any coordinates. Before programming polar coordinates, define the pole. You can only define the pole in Cartesian coordinates. The pole remains in effect until you define a new pole.





Straight line LP

The tool moves in a straight line from its current position to the straight-line end point. The starting point is the end point of the preceding NC block.




▶ **Polar coordinate radius PR**: Enter the distance from the pole CC to the straight-line end point




Polar-coordinates angle PA: Angular position of the straight-line end point between −360° and +360°

The sign of **PA** depends on the angle reference axis:

- If the angle from the angle reference axis to **PR** is counterclockwise: **PA**>0
- If the angle from the angle reference axis to **PR** is clockwise: **PA**<0






Circular path CP around pole CC


The polar coordinate radius **PR** is also the radius of the arc. **PR** is defined by the distance from the starting point to the pole **CC**. The last programmed tool position will be the starting point of the arc.



Р








19 CC X+25 Y+25

20 CP PA+180 DR+



With incremental entries you must use the same algebraic sign for **DR** and **PA**.

Consider this behavior when importing NC programs from earlier controls, and adapt the NC programs if necessary.



Circle CTP with tangential connection

The tool moves on a circular path, starting tangentially from a preceding contour element.




▶ Polar coordinate radius PR: Distance between the arc end point and the pole CC



▶ **Polar coordinate angle PA**: Angular position of the arc end point.



The pole is **not** the center of the contour circle!




13 CC X+40 Y+35

14 LP PR+25 PA+120

15 CTP PR+30 PA+30

16 L Y+0




Helix

A helix is a combination of a circular motion defined in polar coordinates and a linear motion perpendicular to this plane. Program the circular path in a main plane.

As an alternative, you can superimpose a circular contour defined in Cartesian coordinates on a linear motion.

Further information: "Superimposing a linear motion on a circular contour", Page 170



Application

- Large-diameter internal and external threads
- Lubrication grooves

Calculating the helix

To program a helix, you must enter the total angle through which the tool is to move on the helix in incremental dimensions, and the total height of the helix.

Thread revolutions n: Thread revolutions + thread overrun at

the start and end of the thread

Thread pitch P times thread revolutions Total height h:

Incremental total angle

IPA:

Thread revolutions x 360° + angle for beginning of thread + angle for thread

overrun

Starting coordinate Z: Pitch P times (thread revolutions +

thread overrun at start of thread)

Shape of the helix

The table below illustrates in which way the shape of the helix is determined by the work direction, direction of rotation and radius compensation.

Internal thread	Work direction	Direction of rotation	Radius compensation
Right-hand	Z+	DR+	RL
Left-hand	Z+	DR-	RR
Right-hand	Z-	DR-	RR
Left-hand	Z-	DR+	RL
External thread			
Right-hand	Z+	DR+	RR
Left-hand	Z+	DR-	RL
Right-hand	Z-	DR-	RL
Left-hand	Z-	DR+	RR


Programming a helix




Define the same algebraic sign for the direction of rotation **DR** and the incremental total angle **IPA**. The tool may otherwise move on a wrong path.

For the total angle **IPA** you can enter a value of -99 999.9999° to +99 999.9999°.








- ► **Coordinate**: Enter the coordinate for the height of the helix in incremental dimensions
- Direction of rotation DR Clockwise helix: DR-Counterclockwise helix: DR+
- ► Enter the radius compensation according to the table







13 CC X+40 Y+25

14 LP PR+3 PA+270 RL F50

15 CP IPA-1800 IZ+5 DR-




Example: Linear movement with polar coordinates



0 BEGIN PGM LINEARPO MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-20	Workpiece blank definition
2 BLK FORM 0.2 X+100 Y+100 Z+0	
3 TOOL CALL 1 Z S4000	Tool call
4 CC X+50 Y+50	Define the preset for polar coordinates
5 L Z+250 RO FMAX	Retract the tool
6 LP PR+60 PA+180 RO FMAX	Pre-position the tool
7 L Z-5 R0 F1000 M3	Move to working depth
8 APPR PLCT PR+45 PA+180 R5 RL F250	Approach the contour at point 1 on a circular path with tangential connection
9 LP PA+120	Move to point 2
10 LP PA+60	Move to point 3
11 LP PA+0	Move to point 4
12 LP PA-60	Move to point 5
13 LP PA-120	Move to point 6
14 LP PA+180	Move to point 1
15 DEP PLCT PR+60 PA+180 R5 F1000	Depart the contour on a circular path with tangential connection
16 L Z+250 RO FMAX M2	Retract the tool, end of program
17 END PGM LINEARPO MM	

Example: Helix



0 BEGIN PGM HELIX MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-20	Workpiece blank definition
2 BLK FORM 0.2 X+100 Y+100 Z+0	
3 TOOL CALL 1 Z S1400	Tool call
4 L Z+250 RO FMAX	Retract the tool
5 L X+50 Y+50 R0 FMAX	Pre-position the tool
6 CC	Transfer the last programmed position as the pole
7 L Z-12.75 RO F1000 M3	Move to working depth
8 APPR PCT PR+32 PA-182 CCA180 R+2 RL F100	Approach the contour on a circular path with tangential connection
9 CP IPA+3240 IZ+13.5 DR+ F200	Helical interpolation
10 DEP CT CCA180 R+2	Depart the contour on a circular path with tangential connection
11 L Z+250 R0 FMAX M2	Retract the tool, end of program
12 END PGM HELIX MM	

5.6 Path contours – FK free contour programming

Fundamentals

Workpiece drawings that are not dimensioned for NC often contain unconventional coordinate data that cannot be entered with the gray path function keys.

You can enter such dimensional data directly by using the free contour programming function FK, e.g.

- If there are known coordinates on or in proximity to the contour element
- If coordinate data refers to another contour element
- If directional data and data regarding the course of the contour are known

The control derives the contour from the known coordinate data and supports the programming dialog with the interactive FK programming graphics. The figure at upper right shows a workpiece drawing for which FK programming is the most convenient programming method.



Programming notes

You must enter all available data for every contour element. Even the data that does not change must be entered in every NC block—otherwise it will not be recognized.

Q parameters are permissible in all FK elements, except in elements with relative references (e.g. **RX** or **RAN**), or in elements that are referenced to other NC blocks.

If both FK blocks and conventional blocks are entered in an NC program, the FK contour must be fully defined before you can return to conventional programming.


Program all of the contours before combining them (e.g., with the SL cycles). You thereby ensure that the contours are correctly defined and avoid unnecessary error messages.

The control needs a fixed point that it can use as the basis for all calculations. Use the gray path function keys to program a position that contains both coordinates of the working plane immediately before programming the FK contour. Do not enter any Q parameters in this NC block.

If the first NC block of an FK contour is an **FCT** or **FLT** block, you must program at least two NC blocks with the gray path function keys before it. This fully defines the approach direction.

Do not program an FK contour immediately after a **LBL** command.

You cannot combine the cycle call **M89** with FK programming.



Defining the working plane

The FK free contour programming feature can only be used for programming contour elements that lie in the working plane.

The control defines the working plane for FK programming according to the following hierarchy:

- 1 Through the plane defined in an **FPOL** block
- 2 In the Z/X plane if the FK sequence is performed in turning mode
- 3 Through the working plane specified and defined in the **TOOL CALL** (e.g., **TOOL CALL 1 Z** = X/Y plane)
- 4 If none of this applies, then the standard X/Y plane is active Display of the FK soft key depends on the spindle axis specified when defining the workpiece blank. If for example you enter spindle axis ${\bf Z}$ in the workpiece blank definition, the control only shows FK soft keys for the X/Y plane.



The control's full range of functions is available only if the **Z** tool axis is used (e.g., **PATTERN DEF**).

Restricted use of the tool axes **X** and **Y** is possible when prepared and configured by the machine manufacturer.

Switch the working plane

If you need a different working plane from the currently active plane, then proceed as follows:



- Press the PLANE XY ZX YZ soft key
- > The control then displays the FK soft keys in the newly selected plane.

FK programming graphics



To use graphical support during FK programming, select the **PROGRAM + GRAPHICS** screen layout.

Further information: "Programming", Page 75



Program all of the contours before combining them (e.g., with the SL cycles). You thereby ensure that the contours are correctly defined and avoid unnecessary error messages.

Incomplete coordinate data often is not sufficient to fully define a workpiece contour. In this case, the control indicates the possible solutions in the FK graphic. You can then select the contour that matches the drawing.

The control uses various colors in the FK graphics:

- blue: uniquely specified contour element
 The last FK element is only shown in blue after the departure movement.
- violet: not yet uniquely specified contour element
- ocher: tool midpoint path
- red: rapid traverse
- **green:** more than one solution is possible

If the data permit several possible solutions and the contour element is displayed in green, select the correct contour element as follows:



 Press the SHOW SOLUTION soft key repeatedly until the correct contour element is displayed.
 Use the zoom function if you cannot distinguish between possible solutions in the standard view



▶ If the displayed contour element matches the drawing, then select this contour element with the SELECT SOLUTION soft key

If you do not yet wish to define a green contour element, then press the **START SINGLE** soft key to continue the FK dialog.




You should define the green contour elements as soon as possible with **SELECT SOLUTION** to limit ambiguity for the subsequent contour elements.

Showing block numbers in the graphic window

To show a block number in the graphic window:



▶ Set the **SHOW BLOCK NO.** soft key to **ON**



Initiating the FK dialog

To open the FK dialog:



- ▶ Press the **FK** key
- > The control then displays the soft-key row with the FK functions.

If you initiate the FK dialog with one of these soft keys, the control shows additional soft-key rows. You can use them to enter known coordinates, directional data, and data regarding the course of the contour.

Soft key	FK element	
FLT	Straight line with tangential connection	
FL	Straight line without tangential connection	
FCT	Circular arc with tangential connection	
FC	Circular arc without tangential connection	
FPOL	Pole for FK programming	
PLANE XY ZX YZ	Select the working plane	

Terminating the FK dialog

To exit the soft-key row for FK programming:



▶ Press the **END** soft key

Alternative:



▶ Press the **FK** key again

Pole for FK programming



► To display the soft keys for free contour programming, press the **FK** key



- To initiate the dialog for defining the pole, press the FPOL soft key
- > The control displays the axis soft keys of the active working plane.
- ▶ Enter the pole coordinates using these soft keys



The pole for FK programming remains active until you define a new one using FPOL.

Free straight line programming

Straight line without tangential connection



► To display the soft keys for free contour programming, press the **FK** key



- ► To initiate the dialog for free programming of straight lines, press the **FL** soft key
- > The control displays additional soft keys.
- Enter all known data in the NC block by using these soft keys
- > The FK graphic displays the programmed contour element in violet until sufficient data is entered. If the entered data describes several solutions, the graphic will display the contour element in green. **Further information:** "FK programming graphics", Page 183

Straight line with tangential connection

If the straight line connects tangentially to another contour element, initiate the dialog with the **FLT** soft key:



► To display the soft keys for free contour programming, press the **FK** key



- ► To initiate the dialog, press the **FLT** soft key
- ► Enter all known data in the NC block by using the soft keys

Free circular path programming

Circular arc without tangential connection



► To display the soft keys for free contour programming, press the **FK** key



- To initiate the dialog for free programming of circular arcs, press the FC soft key
- > The control displays soft keys with which you can enter direct data on the circular arc or data on the circle center.
- Enter all known data in the NC block by using these soft keys
- > The FK graphic displays the programmed contour element in violet until sufficient data is entered. If the entered data describes several solutions, the graphic will display the contour element in green. Further information: "FK programming graphics", Page 183

Circular arc with tangential connection

If the circular arc connects tangentially to another contour element, initiate the dialog with the **FCT** soft key:



► To display the soft keys for free contour programming, press the **FK** key



- ► To initiate the dialog, press the **FCT** soft key
- Enter all known data in the NC block by using the soft keys

Input possibilities

End point coordinates

Soft keys		Known data
X	Y	Cartesian coordinates X and Y
PR	PA	Polar coordinates referenced to FPOL


Example

7 FPOL X+20 Y+30
8 FL IX+10 Y+20 RR F100
9 FCT PR+15 IPA+30 DR+ R15

30 R15 20 X

Direction and length of contour elements

Soft keys	Known data
LEN	Length of a straight line
AN	Gradient angle of a straight line
LEN	Chord length LEN of an arc
AN	Gradient angle AN of an entry tangent
CCA	Center angle of an arc




NOTICE

Danger of collision!

Incremental gradient angles **IAN** are referenced by the control to the direction of the previous traversing block. NC programs from previous control models (including iTNC 530) are not compatible. There is danger of collision during the execution of imported NC programs!

- Check the sequence and contour with the aid of the graphic simulation
- ► Adapt imported NC programs if required



27 FLT X+25 LEN 12.5 AN+35 RL F200
28 FC DR+ R6 LEN 10 AN-45
29 FCT DR- R15 LEN 15


Circle center CC, radius and direction of rotation in the FC/FCT block

The control calculates a circle center for free-programmed arcs from the data you enter. This makes it possible to program full circles in an NC block with FK programming.

If you wish to define the circle center in polar coordinates you must use FPOL, not **CC**, to define the pole. FPOL is entered in Cartesian coordinates and remains in effect until the TNC encounters an NC block in which another **FPOL** is defined.



A programmed or automatically calculated circle center or pole is effective only in connected conventional or FK sections. If an FK section splits up two conventionally programmed sections, the information about a circle center or pole will be lost. The two conventionally programmed sections must each have their own (if necessary, identical) CC blocks. Conversely, this information will also be lost if there is a conventional section between two FK sections.



Soft keys		Known data
_ccx	CCY	Circle center in Cartesian coordinates
CC	CC PA	Center point in polar coordinates
DR- DR+		Rotational direction of the arc
R		Radius of an arc


•	
10 FC CCX+20 CCY+15 DR+ R15	
11 FPOL X+20 Y+15	
12 FL AN+40	
13 FC DR+ R15 CCPR+35 CCPA+40	

Closed contours

You can identify the beginning and end of a closed contour with the **CLSD** soft key. This reduces the number of possible solutions for the last contour element.

Enter **CLSD** as an addition to another contour data entry in the first and last NC blocks of an FK section.

Soft key	Known data		
CLSD	Beginning of contour:	CLSD+	
	End of contour:	CLSD-	



12 L X+5 Y+35 RL F500 M3
13 FC DR- R15 CLSD+ CCX+20 CCY+35
17 FC DR- R+15 CLSD-


Auxiliary points

For both free-programmed straight lines and free-programmed circular arcs, you can enter the coordinates of auxiliary points that are located on the contour or in its proximity.

Auxiliary points on a contour

The auxiliary points are located on the straight line, the extension of the straight line, or on the circular arc.

Soft keys	,	Known data
P1X	P2X	X coordinate of an auxiliary point P1 or P2 of a straight line
P1Y	P2Y	Y coordinate of an auxiliary point P1 or P2 of a straight line
P1X	P2X	X coordinate of an auxiliary point P1, P2 or P3 of a circular path
P1Y	P2Y	Y coordinate of an auxiliary point P1, P2 or P3 of a circular path



Auxiliary points near a contour

Soft keys		Known data
PDX	PDY	X and Y coordinates of the auxiliary point near a straight line
₽		Distance of auxiliary point to straight line
PDX	PDY	X and Y coordinates of an auxiliary point near a circular arc
₽		Distance of auxiliary point to circular arc

13 FC DR- R10 P1X+42.929 P1Y+60.071	
14 FLT AN-70 PDX+50 PDY+53 D10	

Relative data

Relative data are values based on another contour element. The soft keys and program words for relative entries begin with the letter ${\bf R}$. The figure on the right shows the dimensional data that should be programmed as relative data.



The coordinates and angles for relative data are always programmed in incremental dimensions. You must also enter the NC block number of the contour element on which the data are based.

The block number of the contour element on which the relative data are based can only be located up to 64 positioning blocks before the NC block in which you program the reference.

If you delete an NC block on which relative data are based, the control will display an error message. Change the NC program first before you delete this NC block.

Y 20 20 90° 35 X


Data relative to NC block N: End point coordinates

Soft keys		Known data
RX N	RY N	Cartesian coordinates relative to NC block N
RPR N	RPA N	Polar coordinates relative to NC block N

12 FPOL X+10 Y+10
13 FL PR+20 PA+20
14 FL AN+45
15 FCT IX+20 DR- R20 CCA+90 RX 13
16 FL IPR+35 PA+0 RPR 13

Data relative to NC block N: Direction and distance of the contour element

Soft key	Known data
RAN N	Angle between a straight line and another element or between the entry tangent of the arc and another element
PAR N	Straight line parallel to another contour element
DP	Distance from a straight line to a parallel contour element




Example


17 FL LEN 20 AN+15
18 FL AN+105 LEN 12.5
19 FL PAR 17 DP 12.5
20 FSELECT 2
21 FL LEN 20 IAN+95
22 FL IAN+220 RAN 18

Data relative to NC block N: Circle center CC


Soft key		Known data
RCCX N	RCCY N	Cartesian coordinates of the circle center relative to NC block N
RCCPR N	RCCPA N	Polar coordinates of the circle center relative to NC block N








Example: FK programming 1




0 BEGIN PGM FK1 MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-20	Workpiece blank definition
2 BLK FORM 0.2 X+100 Y+100 Z+0	
3 TOOL CALL 1 Z S500	Tool call
4 L Z+250 RO FMAX	Retract the tool
5 L X-20 Y+30 R0 FMAX	Pre-position the tool
6 L Z-10 RO F1000 M3	Move to working depth
7 APPR CT X+2 Y+30 CCA90 R+5 RL F250	Approach the contour on a circular arc with tangential connection
8 FC DR- R18 CLSD+ CCX+20 CCY+30	FK contour section:
9 FLT	Program all known data for each contour element
10 FCT DR- R15 CCX+50 CCY+75	
11 FLT	
12 FCT DR- R15 CCX+75 CCY+20	
13 FLT	
14 FCT DR- R18 CLSD- CCX+20 CCY+30	
15 DEP CT CCA90 R+5 F1000	Depart the contour on a circular arc with tangential connection
16 L X-30 Y+0 R0 FMAX	
17 L Z+250 R0 FMAX M2	Retract the tool, end of program
18 END PGM FK1 MM	

Example: FK programming 2



0 BEGIN PGM FK2 MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-20	Workpiece blank definition
2 BLK FORM 0.2 X+100 Y+100 Z+0	
3 TOOL CALL 1 Z S4000	Tool call
4 L Z+250 RO FMAX	Retract the tool
5 L X+30 Y+30 R0 FMAX	Pre-position the tool
6 L Z+5 R0 FMAX M3	Pre-position the tool
7 L Z-5 R0 F100	Move to working depth
8 APPR LCT X+0 Y+30 R5 RR F350	Approach the contour on a circular arc with tangential connection
9 FPOL X+30 Y+30	FK contour section:
10 FC DR- R30 CCX+30 CCY+30	Program all known data for each contour element
11 FL AN+60 PDX+30 PDY+30 D10	
12 FSELECT 3	
13 FC DR- R20 CCPR+55 CCPA+60	
14 FSELECT 2	
15 FL AN-120 PDX+30 PDY+30 D10	
16 FSELECT 3	
17 FC X+0 DR- R30 CCX+30 CCY+30	
18 FSELECT 2	
19 DEP LCT X+30 Y+30 R5	Depart the contour on a circular arc with tangential connection
20 L Z+250 R0 FMAX M2	Retract the tool, end of program
21 END PGM FK2 MM	

Example: FK programming 3



0 BEGIN PGM FK3 MM	
1 BLK FORM 0.1 Z X-45 Y-45 Z-20	Workpiece blank definition
2 BLK FORM 0.2 X+120 Y+70 Z+0	
3 TOOL CALL 1 Z S4500	Tool call
4 L Z+250 R0 FMAX	Retract the tool
5 L X-70 Y+0 R0 FMAX	Pre-position the tool
6 L Z-5 R0 F1000 M3	Move to working depth
7 APPR CT X-40 Y+0 CCA90 R+5 RL F250	Approach the contour on a circular arc with tangential connection
8 FC DR- R40 CCX+0 CCY+0	FK contour section:
9 FLT	Program all known data for each contour element
10 FCT DR- R10 CCX+0 CCY+50	
11 FLT	
12 FCT DR+ R6 CCX+0 CCY+0	
13 FCT DR+ R24	
14 FCT DR+ R6 CCX+12 CCY+0	
15 FSELECT 2	
16 FCT DR- R1.5	
17 FCT DR- R36 CCX+44 CCY-10	
18 FSELECT 2	
19 FCT DR+ R5	
20 FLT X+110 Y+15 AN+0	
21 FL AN-90	
22 FL X+65 AN+180 PAR21 DP30	
23 RND R5	
24 FL X+65 Y-25 AN-90	
25 FC DR+ R50 CCX+65 CCY-75	
26 FCT DR- R65	
27 FSELECT 1	
28 FCT Y+0 DR- R40 CCX+0 CCY+0	
29 FSELECT 4	

30 DEP CT CCA90 R+5 F1000	Depart the contour on a circular arc with tangential connection
31 L X-70 RO FMAX	
32 L Z+250 RO FMAX M2	Retract the tool, end of program
33 END PGM FK3 MM	

6

Programming aids

6.1 GOTO function

Using the GOTO key

Jumping with the GOTO key

Use the **GOTO** key to jump to a specific location in the NC program, regardless of the active operating mode.

Proceed as follows:



- ► Press the **GOTO** key
- > The control opens a pop-up window.
- ► Enter a number



 Select the jump statement by soft key, e.g. move down the number of lines entered

The control provides the following options:

Soft key	Function
N LINES	Move up the number of lines entered
N LINES	Move down the number of lines entered
GOTO LINE NUMBER	Jump to the block number entered



Use the **GOTO** function only during programming and testing of NC programs. Use the **Block scan** function during program run.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

Quick selection with the GOTO key

With the **GOTO** key, you can open the Smart Select window that makes it easy for you to select special functions or cycles.

To select special functions:



► Press the **SPEC FCT** key



- ► Press the **GOTO** key
- > The control displays a pop-up window showing a structural view of the special functions
- Select the desired function

Further information: User's Manual for **Programming of Machining Cycles**

Opening the selection window with the GOTO key

When the control provides a selection menu, you can use the **GOTO** key to open the selection window. This allows you to view the available entries.


6.2 Display of NC programs

Syntax highlighting

The control displays syntax elements with various colors according to their meaning. Color-highlighting makes the NC programs easier to read and clearer.

Color highlighting of syntax elements

Use	Color
Standard color	Black
Display of comments	Green
Display of numerical values	Blue
Display of the block number	Violet
Display of FMAX	Orange
Display of the feed rate	Brown



Scrollbar

Screen content can be shifted with the mouse using the scroll bar at the right edge of the program window. In addition, the size and position of the scrollbar indicates program length and cursor position.

6.3 Adding comments

Application


You can add comments to an NC program to explain program steps or make general notes.



The control shows long comments in different ways, depending on the machine parameter **lineBreak** (no. 105404). It either wraps the comment lines or displays the >> symbol to indicate additional content.

The last character in a comment block must not be a tilde sign (\sim) .

You can add comments in different ways.



Entering comments during programming

- ► Enter the data for an NC block
- Press the semicolon key; on the alphabetic keyboard
- > The control displays the dialog prompt Comment?
- Enter the comment
- ▶ Press the **END** key to conclude the NC block

Inserting comments after program entry

- Select the NC block to which you want to add the comment
- ▶ Select the last word in the NC block with the right arrow key:
- ▶ Press the semicolon key; on the alphabetic keyboard
- > The control displays the dialog prompt Comment?
- ► Enter the comment
- ▶ Press the **END** key to conclude the NC block

Entering a comment in a separate NC block

- Select the NC block after which you want to insert the comment
- ► Initiate the programming dialog with the semicolon key (;) on the alphabetic keyboard
- Enter your comment and conclude the NC block by pressing the END key

Commenting out an existing NC block

Proceed as follows to change an existing NC block to a comment:

Select the NC block to be commented out



- Press the INSERT COMMENT soft key Alternative:
- Press the < key on the alphabetic keyboard</p>
- > The control inserts a semicolon; at the beginning of the block.
- ► Press the **END** key

Changing a comment for an NC block

Proceed as follows to change a commented-out NC block to an active NC block:

▶ Select the comment block you want to change



- ► Press the **REMOVE COMMENT** soft key Alternative:
- Press the > key on the alphabetic keyboard
- > The control removes the semicolon; at the beginning of the block.
- ▶ Press the **END** key

Functions for editing a comment

Soft key	Function
BEGIN	Jump to beginning of comment
END	Jump to end of comment
MOVE WORD	Jump to the beginning of a word. Use a space to separate words
MOVE WORD	Jump to the end of a word. Use a space to separate words
INSERT OVERWRITE	Switch between insert and overwrite mode

6.4 Freely editing an NC program

Certain syntax elements, such as LN blocks, cannot be entered directly in the NC editor by using the available keys and soft keys.

To prevent the use of an external text editor, the control offers the following possibilities:

- Free syntax input using the control's integrated text editor
- Free syntax input using the ? key in the NC editor

Free syntax input using the control's integrated text editor

To add syntax to an existing NC program:



- ► Press the **PGM MGT** key
- > The control opens the file manager.



Press the MORE FUNCTIONS soft key



- ► Press the **SELECT EDITOR** soft key
- > The control opens a selection window.
- Select the TEXT EDITOR option
- ► Confirm your selection with **OK**
- Add the desired syntax



The control does not check the syntax in the text editor. Check your entries in the NC editor when you are finished.

Free syntax input using the ? key in the NC editor

To add syntax to an existing, open NC program:



- ► Enter?
- > The control opens a new NC block.





- Add the desired syntax
- ► Confirm your entry with **END**



After confirmation, the control checks the syntax. Errors will result in **ERROR** blocks.

6.5 Skipping NC blocks

Insert a slash (/)

You can optionally hide NC blocks.

To hide NC blocks in the **Programming** mode:



► Select the desired NC block



- ▶ Press the **INSERT** soft key
- > The control inserts a slash (/).

Delete the slash (/)

To show NC blocks again in the **Programming** mode:



► Select the hidden NC block



- ▶ Press the **REMOVE** soft key
- > The control removes the slash (/).

6.6 Structuring NC programs

Definition and applications

The control enables you to comment NC programs in structuring blocks. Structuring blocks are texts with up to 252 characters and are used as comments or headlines for the subsequent program lines.

With the aid of appropriate structuring blocks, you can organize long and complex NC programs in a clear and comprehensible manner.

This function is particularly convenient if you want to change the NC program later. Structuring blocks can be inserted into the NC program at any point.

Structure blocks can also be displayed in a separate window, and be edited or added to, as desired. Use the appropriate screen layout for this.

The control manages the inserted structure items in a separate file (extension: .SEC.DEP). This speeds navigation in the program structure window.

The **PROGRAM SECTS** screen layout can be selected in the following operating modes:

- Program run, single block
- Program run, full sequence
- Programming


Displaying the program structure window / Changing the active window



▶ Display structure window: For this screen layout press the **PROGRAM SECTS** soft key



Change the active window: Press the CHANGE WINDOW soft key



Inserting a structure block in the program window

Select the NC block after which you want to insert the structuring block



▶ Press the **SPEC FCT** key



► Press the **PROGRAMAIDS** soft key



- ▶ Press the **INSERT SECTION** soft key
- ▶ Enter the structuring text



Change the structuring depth (indenting) via soft key



You can indent structure items only during editing.



You can also insert structure blocks with the key combination **Shift + 8**.

Selecting blocks in the program structure window

If you are scrolling through the program structure window block by block, the control at the same time automatically moves the corresponding NC blocks in the program window. This way you can quickly skip large program sections.


6.7 Calculator

Operation

The control features a calculator with the most important mathematical functions.

- ► To show the calculator, press the **CALC** key
- Select the arithmetic functions: Select the command via soft key or enter it with an alphanumeric keyboard
- ► To close the calculator, press the **CALC** key

Calculator function	Command (soft key)
Addition	+
Subtraction	_
Multiplication	*
Division	/
Calculating with parentheses	()
Arc cosine	ARC
Sine	SIN
Cosine	COS
Tangent	TAN
Exponent	X^Y
Square root	SQRT
Inverted function	1/x
PI (3.14159265359)	PI
Add value to buffer memory	M+
Save value to buffer memory	MS
Retrieve buffer memory contents	MR
Delete buffer memory contents	MC
Natural logarithm	LN
Logarithm	LOG
Exponential function	e^x
Check the algebraic sign	SGN
Calculate the absolute value	ABS



Calculator function	Command (soft key)
Truncate decimal places	INT
Truncate digits before the decimal point	FRAC
Modulo	MOD
Select view	View
Delete value	CE
Unit of measure	MM or INCH
Show angular value in radians (default: angular value in degrees)	RAD
Select numerical value notation	DEC (decimal) or HEX (hexadecimal)

Transferring the calculated value into the NC program

- ▶ With the arrow keys, select the word into which the calculated value is to be transferred
- ► Show the calculator by pressing the **CALC** key, and perform the desired calculation
- ▶ Press the **CONFIRM VALUE** soft key
- > The control transfers the value into the active input field and closes the calculator.



You can also transfer values from an NC program into the calculator. When you press the **GET VALUE** soft key or the **GOTO** key, the control transfers the value from the active input field to the calculator.

The calculator remains in effect even after a change in operating modes. Press the **END** soft key to close the calculator.

Functions in the pocket calculator

Soft key	Function
AX. VALUES	Transfer the nominal or reference value of the respective axis position into the calculator
GET CURRENT VALUE	Transfer the numerical value from the active input field into the calculator
CONFIRM VALUE	Transfer the numerical value from the calculator into the active input field
COPY	Copy the numerical value from the calculator
PASTE FIELD	Insert the copied numerical value into the calculator
CUTTING DATA CALCULATOR	Open the cutting data calculator



You can also move the calculator with the arrow keys of your alphabetic keyboard. If you have connected a mouse you can also position the calculator with this.

6.8 Cutting data calculator


Application

With the cutting data calculator you can calculate the spindle speed and the feed rate for a machining process. Then you can load the calculated values into an opened feed rate or spindle speed dialog box in the NC program.



You cannot perform any cutting data calculation in turning mode with the cutting data calculator because the feed rate and spindle speed data are different in turning mode from milling mode.

Feed rates in turning operations are often defined in millimeters per revolution (mm/1) (M136), whereas the cutting data calculator always calculates feed rates in millimeters per minute (mm/min). Furthermore, the radius in the cutting data calculator is referenced to the tool; turning operations, however, require the workpiece diameter.



To open the cutting data calculator, press the

CUTTING CALCULATOR soft key.

The control shows the soft key if you

- Press the **CALC** key
- Define spindle speeds
- Define feed rates
- Press the **F** soft key in **Manual Operation** mode
- Press the **S** soft key in **Manual Operation** mode

Display modes of the cutting data calculator

The cutting data calculator is displayed with different input fields depending on whether you calculate a spindle speed or a feed rate:

Window for spindle speed calculation:

Abbrev.	Meaning	
T:	Tool number	
D:	Diameter of the tool	
VC:	Cutting speed	
S=	Result for spindle speed	

If you open the speed calculator in a dialog where the tool is already defined, the speed calculator automatically applies the tool number and diameter. You only need to enter \mathbf{VC} in the dialog field.

Window for feed rate calculation:

Abbrev.	Meaning		
T:	Tool number		
D:	Diameter of the tool		
VC:	Cutting speed		
S:	Spindle speed		
Z:	Number of teeth		
FZ:	Feed per tooth		
FU:	Feed per revolution		
F=	Result for feed rate		



You can transfer the feed rate from the **TOOL CALL** block into subsequent NC blocks by pressing the **F AUTO** soft key. If you have to change the feed rate later, you only need to adjust the feed rate value in the **TOOL CALL** block.

Functions of the cutting data calculator

You have the following possibilities depending on where you open the cutting data calculator:

Soft key	Function		
APPLY	Transfer the value from the cutting data calculator into the NC program		
CALCULATE FEEDRATE F SPEED S	Toggle between feed-rate calculation and spindle- speed calculation		
ENTER FEED RATE FZ FU	Toggle between feed per tooth and feed per revolution		
CUTTING DATA TABLE OFF ON	Activate or deactivate working with cutting data tables		
SELECT	Select a tool from the tool table		
•	Move the cutting data calculator in the direction of the arrow		
POCKET CALCULATOR	Switch to the calculator		
INCH	Use inch values in the cutting data calculator		
END	Close the cutting data calculator		

Working with cutting data tables

Application

If you store tables for materials, cutting materials, and cutting data on the control, then the cutting data calculator can use the values in these tables.

Proceed as follows before working with automatic calculation of the spindle speed and feed rate:

- ▶ Enter the type of workpiece material in the table WMAT.tab
- ▶ Enter the type of cutting material in the file TMAT.tab
- ► Enter the combination of workpiece material and cutting material in a cutting data table
- Define the tool with the necessary values in the tool table
 - Tool radius
 - Number of teeth
 - Cutting material
 - Cutting data table

Workpiece material WMAT

Define the workpiece materials in the WMAT.tab table. You must save this table in the directory **TNC:\table**.

This table contains the **WMAT** column for material and a **MAT_CLASS** column where you can categorize the materials by material classes with the same cutting conditions, e.g. according to DIN EN 10027-2.

Enter the workpiece material as follows in the cutting data calculator:

- Select the cutting data calculator
- ▶ Select **Activate cutting data from table** in the pop-up window
- ► Select **WMAT** from the selection menu

NR 4	WMAT	MAT_CLASS
1		10
2	1.0038	10
3	1.0044	10
4	1.0114	10
5	1.0177	10
6	1.0143	1.0
7	St 37-2	10
8	St 37-3 N	1.0
9	X 14 CrMo S 17	20
10	1.1404	20
11	1.4305	20
12	V2A	2
13	1.4301	2
14	A1Cu4PBMg	10
15	Aluminium	10
16	PTFE	20

Cutting material TMAT

Cutting materials are defined in the TMAT.tab table. You must save this table in the directory **TNC:\table**.

You assign the cutting material in the **TMAT** column of the tool table. You can create columns with other names, such as **ALIAS1** and **ALIAS2** in order to enter alternative names for the same cutting material.

Cutting data table

Define the combinations of workpiece material and cutting material with the corresponding cutting data in a table with the file extension .CUT. You must save this table in the directory **TNC:** \system\Cutting-Data.

You assign the appropriate cutting data table in the **CUTDATA** column of the tool table.



Using the simplified cutting data table, you can determine speeds and feed rates using cutting data that are independent of the tool radius (e.g., **VC** and **FZ**).

If you require specific cutting data depending on the tool radius for your calculations, use the diameter-dependent cutting data table.

Further information: "Diameter-dependent cutting data table ", Page 213

The cutting data table contains the following columns:

- MAT_CLASS: Material class
- MODE: Machining mode, such as finishing
- **TMAT**: Cutting material
- **VC**: Cutting speed
- **FTYPE**: Type of feed rate **FZ** or **FU**
- **F**: Feed rate

NR	A WAT_CLASS	MODE	TMAT	VC	FTYPE
	0 1	Rough	HSS	28	
	1 1	Rough	VHM	70	
	2 1	D Finish	HSS	30	
	3 1	9 Finish	VHM	70	
	4 1	Rough	HSS coated	78	
	5 1	D Finish	HSS coated	82	
	6 2	9 Rough	VHM	90	
	7 2	Finish	VHM	82	
	8 10	Rough	HSS	150	
	9 10	Finish	HSS	145	
	10 10	Rough	VHM	450	
	11 10	0 Finish	VHM	440	
	12				
	13				
	14				

Diameter-dependent cutting data table

In many cases the diameter of the tool determines which cutting data you can use. Use the cutting data table with the file extension .CUTD for this purpose. You must save this table in the directory TNC:\system\Cutting-Data.

You assign the appropriate cutting data table in the **CUTDATA** column of the tool table.

The diameter-dependent cutting data table contains the following additional columns:


- **F_D_0**: Feed rate for Ø 0 mm
- **F_D_0_1**: Feed rate for Ø 0.1 mm
- **F_D_0_12**: Feed rate for Ø 0.12 mm



You don't need to fill in all columns. If a tool diameter is between two defined columns, the control linearly interpolates the feed rate.

Note

In the corresponding folders, the control provides sample tables for automatic cutting data calculation. You can customize theses tables and specify your own data, i.e. materials and tools to be used.



6.9 Programming graphics

Activating and deactivating programming graphics

While you are writing an NC program, you can have the control generate a 2-D pencil-trace graphic of the programmed contour.

- Press the Screen layout key
- ► Press the **PROGRAM + GRAPHICS** soft key
- > The control shows the NC program to the left and graphics to the right.



- Set the AUTO DRAW soft key to ON
- > While you are entering the program lines, the control generates each programmed movement in the graphics window in the right screen half.

If you do not want the control to generate graphics during programming, then set the **AUTO DRAW** soft key to **OFF**.



If **AUTO DRAW** is set to **ON**, then the control ignores the following program content when creating 2-D pencil-trace graphics:

- Program section repetitions
- Jump commands
- M functions, such as M2 or M30
- Cycle calls
- Warnings due to locked tools


Therefore, only use automatic drawing during contour programming.

The control resets the tool data when you reopen an NC program or press the **RESET START** soft key.

The control uses various colors in the programming graphics:

- blue: completely defined contour element
- violet: not yet completely defined contour element, can still be modified by e.g. an RND
- **light blue:** holes and threads
- ocher: tool midpoint path
- red: rapid traverse

Further information: "FK programming graphics", Page 183



Generating a graphic for an existing NC program

Use the arrow keys to select the NC block up to which you want the graphic to be generated, or press GOTO and enter the desired block number



Reset previously active tool data, and generate graphic: Press the RESET START soft key

Additional functions:

Soft key	ft key Function			
RESET + START	Reset previously active tool data. Generate programming graphics			
START SINGLE	Generate programming graphic blockwise			
START	Generate a complete programming graphic, or complete it after RESET START			
STOP	Stop the programming graphics. This soft key only appears while the control is generating the programming graphics			
VIEWS	Selecting views Plan view Front view Side view			
SHOW TOOL PATHS OFF ON	Display or hide tool paths			
SHOW FMAX PATHS OFF ON	Display or hide tool paths in rapid traverse			

Block number display ON/OFF



► Shift the soft-key row



- ► Show block numbers: Set the **SHOW BLOCK NO.** soft key to **ON**
- ► Hide block numbers: Set the **SHOW BLOCK NO.** soft key to **OFF**

Erasing the graphic



► Shift the soft-key row



► Erase the graphic: Press the **CLEAR GRAPHICS** soft key

Showing grid lines



► Shift the soft-key row



► Show grid lines: Press the **Show grid lines** soft key

Magnification or reduction of details

You can select the graphics display

► Shift the soft-key row

The following functions are available:

Soft key		Function	
←	1	Shift section	
₽			
		Reduce section	
		Enlarge section	
1:1		Reset section	

| OMANUAL OPERATION | OPERATIO

The **RESET FORM** soft key allows you to restore the original section. You can also use the mouse to change the graphic display. The following functions are available:

- To shift the displayed model, hold down the center mouse button or the mouse wheel, and move the mouse. If you press the shift key at the same time, then you will be able to shift the model only horizontally or vertically.
- To zoom in on a certain area, mark a zoom area by holding the left mouse button down. After you release the left mouse button, the control zooms in on the defined area.
- To rapidly magnify or reduce any area, rotate the mouse wheel backwards or forwards.

6.10 Error messages

Display of errors

The control displays error messages in the following cases, for example:

- Incorrect input
- Logical errors in the NC program
- Contour elements that are impossible to machine
- Incorrect use of touch probes
- Hardware updates

When an error occurs, the control displays it in the header.

The control uses the following icons and text colors for different error classes:

lcon	Text color	Error class	Meaning
i?	Red	Error Prompt	The control displays a dialog with several options you can select from.
			Further information: "Detailed error messages", Page 218
(4)	Red	Reset error	The control must be restarted.
			This message cannot be cleared.
-	Red	Error	To continue, you must clear this message.
w			An error message can only be cleared after the cause has been eliminated.
Δ	Yellow	Warning	You can continue without clearing the message.
			Most warnings can be cleared at any time; in some cases, the cause has to be eliminated first.
0	Blue	Information	You can continue without clearing the message.
U			You can clear the information at any time.
Λ	Green	Note:	You can continue without clearing the message.
			The control displays the note until you press the next valid key.

The table rows are ordered by priority. The control displays a message in the header until it is cleared or replaced by a higher-priority message (higher error class).

The control displays long and multi-line error messages in abbreviated form. The complete information on all pending errors is shown in the error window.

An error message that contains an NC block number was caused by an error in the indicated NC block or in the preceding NC block.

Opening the error window

When you open the error window, the complete information on all pending errors will be shown.



- ▶ Press the ERR key
- > The control opens the error window and displays all accumulated error messages.

Detailed error messages


The control displays possible causes of the error and suggestions for solving the problem:

- Open the error window
- Position the cursor on the corresponding error message



MORE

- ▶ Press the **MORE INFO** soft key
- > The control opens a window with information on the error cause and corrective action.
- ► Exit the info: Press the **MORE INFO** soft key again



High-priority error messages

When an error message occurs at switch-on of the control due to hardware changes or updates, the control will automatically open the error window. The control displays an error of the question type.

You can correct this error only by pressing the corresponding soft key to acknowledge the question. If necessary, the control continues the dialog until the cause or correction of the error has been clearly determined.

Further information: User's Manual for Setup, Testing and Running NC Programs

If a rare **processor check error** should occur, the control will automatically open the error window. You cannot correct such an error.

Proceed as follows:

- Shut down the control
- Restart

INTERNAL INFO soft key

The **INTERNAL INFO** soft key supplies information on the error message. This information is only required if servicing is needed.

- Open the error window
- Position the cursor on the corresponding error message



- Press the INTERNAL INFO soft key
- > The control opens a window with internal information about the error.



Exit the detailed information: Press the INTERNAL INFO soft key again



GROUPING soft key

If you activate the **GROUPING** soft key, the control displays all warnings and error messages with the same error number in the same line of the error window. This makes the list of messages shorter and easier to read.

To group the error messages:



Open the error window



▶ Press the **MORE FUNCTIONS** soft key



- ▶ Press the **GROUPING** soft key
- The control groups identical warnings and error messages.
- > The number of occurrences of the individual messages is indicated in parentheses in the respective line.



Press the GO BACK soft key

ACTIVATE SAVING soft key

Using the **ACTIVATE SAVING** soft key, you can specify error numbers that cause the control to save a service file if an error with that number occurs.



Open the error window



▶ Press the **MORE FUNCTIONS** soft key



- Press the ACTIVATE SAVING soft key
- The control opens the ACTIVATE AUTOMATIC SAVING pop-up window.
- Define the entries
 - **Error number**: Enter the desired error number
 - active: Enable this option to automatically create the service file
 - Comment: Enter a comment on this error number, if required



- ▶ Press the **STORE** soft key
- > If an error with the specified error number occurs, a service file will be saved automatically.



▶ Press the **GO BACK** soft key

Deleting errors



The control can automatically clear pending warning or error messages when an NC program is selected or restarted. The machine tool builder specifies in the optional machine parameter **CfgClearError** (no. 130200) whether these messages will automatically be cleared.

The factory default setting of the control defines that warning and error messages in the **Test Run** and **Programming** operating modes will be cleared automatically from the error window. Messages issued in the machine operating modes will not be cleared.

Clearing errors outside of the error window



- ▶ Press the **CE** key
- > The control clears the errors or notes being displayed in the header.



In certain situations you cannot use the **CE** key for clearing the errors because the key is used for other functions.

Clearing errors

- Open the error window
- Position the cursor on the corresponding error message



▶ Press the **DELETE** soft key



As an alternative, clear all errors: Press the DELETE ALL soft key



If the cause of the error has not been corrected, the error message cannot be cleared. In this case, the error message remains in the window.

Error log

The control stores errors occurred and important events (e.g., system start) in an error log. The capacity of the error log is limited. When the log is full, the control uses a second file. When this is also full, the first error log is deleted and newly written etc. If required, switch from **CURRENT FILE** to **PREVIOUS FILE** to view the history.

Open the error window



▶ Press the **LOG FILES** soft key



Open the error log file: Press the ERROR LOG soft key



Set the previous error log if required: Press the PREVIOUS FILE soft key



Set the current error log if required: Press the CURRENT FILE soft key

The oldest entry is at the beginning of the log file, and the most recent entry is at the end.

Keystroke log

The control stores each key pressed and important events (e.g., system start) in a keystroke log. The capacity of the keystroke log is limited. When the keystroke log is full, the control switches to a second keystroke log. When this is also full, the first keystroke log is deleted and newly written, etc. If required, switch from **CURRENT FILE** to **PREVIOUS FILE** to view the history of the inputs.



▶ Press the **LOG FILES** soft key



Open the keystroke log file: Press the KEYSTROKE LOG soft key



Set the previous keystroke log if required: Press the PREVIOUS FILE soft key



► Set the current keystroke log if required: Press the **CURRENT FILE** soft key

The control saves each key pressed during operation in a keystroke log. The oldest entry is at the beginning, and the most recent entry is at the end of the file.

Overview of the keys and soft keys for viewing the log

Soft key/ Keys	Function
BEGIN	Go to beginning of keystroke log
END	Go to end of keystroke log
FIND	Find text
CURRENT	Current keystroke log
PREVIOUS FILE	Previous keystroke log
1	Up/down one line
ŧ	
	Return to main menu

Informational texts

If an operating error occurred, e.g. pressing an impermissible key or entering a value outside of a validity range, the control displays an information text in the header to inform you of the operating error. The control deletes this information text with the next valid entry.

Saving service files

If necessary, you can save the current status of the control and make it available to a service technician for evaluation. A group of service files is saved (error and keystroke logs as well as other files that contain information about the current status of the machine and the machining).



In order to facilitate sending service files via email, the control will only save active NC programs with a size of up to 10 MB in the service file. If the NC program is larger, it will not be added to the created service file.

If you repeat the **SAVE SERVICE FILES** function with the same file name, the previously saved group of service files will be overwritten. Therefore, use a different file name when re-executing the function.

Saving service files



Open the error window



▶ Press the **LOG FILES** soft key



- ▶ Press the **SAVE SERVICE FILES** soft key
- > The control opens a pop-up window in which you can enter a file name or a complete path for the service file.



- ► Press the **OK** soft key
- > The control saves the service file.

Closing the error window

To close the error window:



▶ Press the **END** soft key



- ► Alternative: Press the **ERR** key
- > The control closes the error window.

6.11 TNCguide: context-sensitive help

Application



Before you can use **TNCguide**, you need to download the help files from the HEIDENHAIN home page.

Further information: "Downloading current help files", Page 228

The **TNCguide** context-sensitive help system contains the user documentation in HTML format. To call **TNCguide**, press the **HELP** key. The control often immediately displays the information specific to the situation in which the help was called (context-sensitive call). If you are editing an NC block and press the **HELP** key, you are usually taken to the exact place in the documentation that describes the corresponding function.



The control tries to start **TNCguide** in the language that you have selected as the user interface language. If the required language version is not available, the control automatically uses the English version.


The following user documentation is available in TNCguide:

- User's Manual for Klartext Programming (BHBKlartext.chm)
- User's Manual for ISO programming (BHBIso.chm)
- User's Manual for Setup, Testing and Running NC Programs (BHBoperate.chm)
- User's Manual for Programming of Machining Cycles (BHBcycle.chm)
- User's Manual for Programming of Measuring Cycles for Workpieces and Tools (BHBtchprobe.chm)
- User's Manual for the TNCdiag application, if necessary (TNCdiag.chm)
- List of All Error Messages (errors.chm)

In addition, the **main.chm** "book" file is available, in which all existing .chm files are shown in one place.



As an option, your machine manufacturer can embed machine-specific documentation in **TNCguide**. These documents then appear as a separate book in the **main.chm** file.



Using TNCguide

Calling TNCguide

You have several options for starting **TNCguide**:

- Use the **HELP** key
- First click the help symbol in the lower right-hand corner of the screen, then click the appropriate soft key
- Open a help file (.chm file) via the file management. The control can open any .chm file, even if it is not saved in the control's internal memory



On the Windows programming station, **TNCguide** is opened in the internally defined standard browser.


For many soft keys there is a context-sensitive call through which you can go directly to the description of the soft key's function. This functionality requires using a mouse.

Proceed as follows:

- Select the soft-key row containing the desired soft key
- ► Click with the mouse on the help symbol that the control displays just above the soft-key row
- > The mouse pointer turns into a question mark.
- Move the question mark to the soft key for which you want an explanation
- > The control opens **TNCguide**. If there is no entry point for the selected soft key, then the control opens the book file **main.chm**. You can search for the desired explanation using full text search or by using the navigation.

Even if you are editing an NC block, context-sensitive help is available:

- Select any NC block
- Select the desired word
- ► Press the **HELP** key.
- > The control opens the Help system and shows the description of the active function. This does not apply for miscellaneous functions or cycles from your machine tool builder.



Navigating in TNCguide

It's easiest to use the mouse to navigate in **TNCguide**. A table of contents appears on the left side of the screen. Clicking on the rightward pointing triangle opens subordinate sections, and clicking on the respective entry opens the corresponding page. You can use it in the same way as Windows Explorer.

Linked text positions (cross references) are shown underlined and in blue. Clicking the link opens the associated page.

Of course you can also operate TNCguide through keys and soft keys. The following table contains an overview of the corresponding key functions.

Soft key/ Keys	Function
ł	 If the table of contents at left is active: Select the entry above it or below it
+	 If the text window at right is active: Move the page downward or upward if texts or graphics are not shown completely
-	 If the table of contents at left is active: Expand the table of contents
	If the text window at right is active: No function
-	 If the table of contents at left is active: Collapse the table of contents
	If the text window at right is active: No function
ENT	If the table of contents at left is active: Use the cursor key to show the selected page
	If the text window at right is active: If the cursor is on a link, jump to the linked page
	If the table of contents at left is active: Switch the tab between the display of the table of contents, display of the subject index, and the full-text search function and switching to the right side of the window
	 If the text window at right is active: Jump back to the left side of the window
□ ↑	 If the table of contents at left is active: Select the entry above it or below it
	If the text window at right is active: Jump to next link
BACK	Select the page last shown
FORWARD	Page forward if you have used the Select page last shown function
PAGE	Go back one page
PAGE	Go forward one page

Soft key/ Keys	Function
DIRECTORY	Display or hide table of contents
WINDOW	Switch between full-screen display and reduced display. With the reduced display you can see some of the rest of the control window
SWITCH	The focus is returned to the control application so that you can operate the control while TNCguide is open. If the full screen is active, the control reduces the window size automatically before the focus changes
END	Exit TNCguide

Subject index

The most important subjects in the Manual are listed in the subject index (**Index** tab). You can select them directly by mouse or with the arrow keys.

The left side is active.



- ▶ Select the **Index** tab
- Use the arrow keys or the mouse to select the desired keyword

Alternative:

- Enter the first few characters
- > The control synchronizes the subject index and creates a list in which you can find the subject more easily.
- Use the ENT key to call the information on the selected keyword

Full-text search

On the **Find** tab, you can search all of **TNCguide** for a specific word. The left side is active.



- Select the Find tab
- Activate the Find: entry field
- ▶ Enter the search word
- ► Press the **ENT** key
- > The control lists all sources containing the word.
- Use the arrow keys to navigate to the desired source
- ▶ Press the **ENT** key to go to the selected source



The full-text search only works for single words.

If you activate the **Search only in titles** function, the control searches only through headings and ignores the body text. To activate the function, use the mouse or select it and then press the space bar to confirm.

Downloading current help files

You'll find the help files for your control software on the HEIDENHAIN homepage:

http://content.heidenhain.de/doku/tnc_guide/html/en/index.html

Navigate to the suitable help file as follows:

- ► TNC Controls
- ► Series, e.g. TNC 600
- ▶ Desired NC software number; for example TNC 640 (34059x-17)



HEIDENHAIN has simplified the version schema, starting with NC software version 16:

- The publication period determines the version number.
- All control models of a publication period have the same version number.
- The version number of the programming stations corresponds to the version number of the NC software.
- ► Select the desired language version from the **TNCguide online** help (CHM files) table
- ▶ Download the ZIP file
- Extract the ZIP file
- ► Move the extracted CHM files to the **TNC:\tncguide\en** directory or the respective language subdirectory on the control



When using **TNCremo** to transfer the CHM files to the control, select the binary mode for files with the .chm extension.

Language	TNC directory
German	TNC:\tncguide\de
English	TNC:\tncguide\en
Czech	TNC:\tncguide\cs
French	TNC:\tncguide\fr
Italian	TNC:\tncguide\it
Spanish	TNC:\tncguide\es
Portuguese	TNC:\tncguide\pt
Swedish	TNC:\tncguide\sv
Danish	TNC:\tncguide\da
Finnish	TNC:\tncguide\fi
Dutch	TNC:\tncguide\nl
Polish	TNC:\tncguide\pl
Hungarian	TNC:\tncguide\hu
Russian	TNC:\tncguide\ru
Chinese (simplified)	TNC:\tncguide\zh

Language	TNC directory	
Chinese (traditional)	TNC:\tncguide\zh-tw	
Slovenian	TNC:\tncguide\sl	
Norwegian	TNC:\tncguide\no	
Slovak	TNC:\tncguide\sk	
Korean	TNC:\tncguide\kr	
Turkish	TNC:\tncguide\tr	
Romanian	TNC:\tncguide\ro	

Miscellaneous functions

7.1 Entering miscellaneous functions M and STOP

Fundamentals

With the control's miscellaneous functions—also called M functions—you can affect:

- the program run, e.g. a program interruption
- the machine functions, such as switching spindle rotation and coolant supply on and off
- the path behavior of the tool

You can enter up to four M (miscellaneous) functions at the end of a positioning block or in a separate NC block. The control displays the following dialog question: **Miscellaneous function M?**

You usually enter only the number of the miscellaneous function in the programming dialog. With some miscellaneous functions, the dialog is extended so that you can enter the required parameters for this function.

In the **Manual operation** and **Electronic handwheel** operating modes, the M functions are entered with the **M** soft key.

Effectiveness of miscellaneous functions

Some miscellaneous functions take effect at the start of the NC block and others at the end, regardless of the sequence in which they were programmed.

Miscellaneous functions come into effect in the NC block in which they are called.

Some miscellaneous functions are effective block-by-block, i.e. only in the NC block in which the miscellaneous function has been programmed. When a miscellaneous function takes effect modally, you have to cancel this miscellaneous function again in a subsequent NC block (e.g., by using **M9** to switch off coolant that was switched on with **M8**). If miscellaneous functions are still active at the end of the program, the control will rescind the miscellaneous functions.



If multiple M functions were programmed in a single NC block, the execution sequence is as follows:

- M functions taking effect at the start of the block are executed before those taking effect at the end of the block
- If all M functions are effective at the start or end of the block, execution takes place in the sequence as programmed

Entering a miscellaneous function in a STOP block

If you program a **STOP** block, the program run or test run is interrupted at the block, e.g. for a tool inspection. You can also enter an M (miscellaneous) function in a **STOP** block:



- ► To program an interruption of program run, press the **STOP** key
- ► Enter a miscellaneous function **M** if required

Example

87 STOP

7.2 Miscellaneous functions for program run inspection, spindle and coolant

Overview



Refer to your machine manual.

The machine manufacturer can influence the behavior of the miscellaneous functions described below.


М	Effect	Effective at block	Start	End
M0	Program STOP Spindle STOP			•
M1				•
M2	STOP program ru Spindle STOP Coolant off Return jump to bl Clear status displ Functional scope parameter resetAt (no. 100	lock 1 lay depends on machine		•
М3	Spindle ON clock	wise		
M4	Spindle ON count	terclockwise		
M5	Spindle STOP			
M8	Coolant ON		-	
М9	Coolant OFF			
M13	Spindle ON clock Coolant ON	wise	•	
M14	Spindle ON count Coolant ON	terclockwise	•	
M30	Same as M2			

7.3 Miscellaneous functions for coordinate entries

Programming machine-referenced coordinates: M91/M92

Scale datum

On the scale, a reference mark indicates the position of the scale datum.



Machine datum

The machine datum is required for the following tasks:

- Define the axis traverse limits (software limit switches)
- Approach machine-referenced positions (such as tool change positions)
- Set a workpiece preset

The distance in each axis from the scale datum to the machine datum is defined by the machine tool builder in a machine parameter.

Standard behavior

The control references the coordinates to the workpiece datum.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

Behavior with M91-Machine datum

If you want the coordinates in a positioning block to be referenced to the machine datum, enter M91 into these NC blocks.



If you program incremental coordinates in an NC block with the miscellaneous function **M91**, then these coordinates are relative to the last position programmed with **M91**. If the active NC program does not contain a position programmed with **M91**, the coordinates reference the current tool position.

The coordinate values on the control's screen are referenced to the machine datum. Switch the display of coordinates in the status display to REF.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

Behavior with M92 - Additional machine reference point



Refer to your machine manual.

In addition to the machine datum, the machine manufacturer can also define an additional machine-based position as a reference point (machine preset).

For each axis, the machine manufacturer defines the distance between the machine preset and the machine datum.

If you want the coordinates in positioning blocks to be based on the machine preset, enter M92 into these NC blocks.



Radius compensation remains the same in blocks that are programmed with **M91** or **M92**. The tool length will **not** be taken into account.

Effect

M91 and M92 are effective only in the blocks in which M91 and M92 have been programmed.


M91 and M92 take effect at the start of block.

Workpiece preset

If you want the coordinates to always be referenced to the machine datum, you can inhibit presetting for one or more axes.

If presetting is inhibited for all axes, the control does not display the **SET PRESET** soft key in the **Manual operation** operating mode.

The figure shows coordinate systems with the machine and workpiece datum.



M91/M92 in the Test Run mode

In order to be able to graphically simulate M91/M92 movements, you need to activate working space monitoring and display the workpiece blank referenced to the defined preset.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

Moving to positions in a non-tilted input coordinate system with a tilted working plane: M130

Standard behavior with a tilted working plane

The control references the coordinates in the positioning blocks to the tilted working plane coordinate system.

Further information: "Working plane coordinate system WPL-CS", Page 84

Behavior with M130

Despite an active tilted working plane, the control references the coordinates in straight line blocks to the non-tilted input coordinate system.

M130 ignores only the **Tilt working plane** function, but takes into account active transformations before and after tilting. This means that, when calculating the position, the control considers the axis angles of the rotary axes that are not in their zero position.

Further information: "Input coordinate system I-CS", Page 86

NOTICE

Danger of collision!

The miscellaneous function **M130** is effective only blockwise. The control executes the subsequent machining operations in the tilted working plane coordinate system **WPL-CS** again. Danger of collision during machining!

▶ Use the simulation to check the sequence and positions

Programming notes

- The function **M130** is allowed only if the **Tilt working plane** function is active.
- If the function M130 is combined with a cycle call, the control will interrupt machining with an error message.

Effect

M130 functions blockwise in straight-line blocks without tool radius compensation.


7.4 Miscellaneous functions for path behavior

Machining small contour steps: M97

Standard behavior

The control inserts a transition arc at outside corners. For very small contour steps, the tool would damage the contour.

In such cases, the control interrupts the program run and generates the **Tool radius too large** error message.




Behavior with M97

The control determines a path intersection for the contour elements—such as inner corners—and moves the tool above this point.

Program M97 in the same NC block as the outside corner.



Instead of **M97**, HEIDENHAIN recommends using the more powerful function **M120** (option 21). **Further information:** "Pre-calculating radius-compensated contours (LOOK AHEAD): M120 ", Page 243



Effect

M97 is effective only in the NC block in which M97 is programmed.



The control does not completely finish the corner when it is machined with **M97**. You may need to rework the contour corner with a smaller tool.


Example

5 TOOL DEF L R+20	Large tool radius
13 L X Y R F M97	Move to contour point 13
14 L IY-0.5 R F	Machine small contour steps 13 to 14
15 L IX+100	Move to contour point 15
16 L IY+0.5 R F M97	Machine small contour steps 15 to 16
17 L X Y	Move to contour point 17

Machining open contour corners: M98


Standard behavior

The control calculates the intersections of the cutter paths at inside corners and moves the tool in the new direction at those points. If the contour is open at the corners, however, this will result in incomplete machining.



Behavior with M98

With the **M98** miscellaneous function, the control temporarily suspends radius compensation to ensure that both corners are completely machined:



Effect

M98 is effective only in the NC blocks in which **M98** is programmed. **M98** becomes effective at the end of the block.

Example: Move to the contour points 10, 11 and 12 in succession

10 L X... Y... RL F 11 L X... IY... M98 12 L IX+ ...

Feed rate factor for plunging movements: M103

Standard behavior

The control moves the tool at the last programmed feed rate, regardless of the direction of traverse.

Behavior with M103

The control reduces the feed rate when the tool moves in the negative direction of the tool axis. The feed rate for plunging FZMAX is calculated from the last programmed feed rate FPROG and a factor F%:

FZMAX = FPROG x F%

Programming M103

If you program **M103** in a positioning block, the control continues the dialog by prompting you for the F factor.

Effect

M103 becomes effective at the start of the block.
Cancel M103: Program M103 once again without a factor.



M103 is also in effect with an active tilted working plane coordinate system **WPL-CS**. The feed rate reduction is then active during infeed movements in the virtual tool axis **VT**.

Example

The feed rate for plunging is to be 20% of the feed rate in the plane.

	Actual contouring feed rate (mm/min):
17 L X+20 Y+20 RL F500 M103 F20	500
18 L Y+50	500
19 L IZ-2.5	100
20 L IY+5 IZ-5	141
21 L IX+50	500
22 L Z+5	500

Feed rate in millimeters per spindle revolution: M136

Standard behavior

The control moves the tool at the feed rate F in mm/min programmed in the NC program

Behavior with M136



In NC programs based on inch units, M136 is not allowed in combination with FU or FZ.

The workpiece spindle is not permitted to be controlled when **M136** is active.

It is not possible to combine **M136** with an oriented spindle stop. The control cannot calculate the feed rate because the spindle does not rotate during an oriented spindle stop.

With **M136**, the control does not move the tool in mm/min, but rather at the feed rate F in millimeters per spindle revolution programmed in the NC program. If you change the spindle speed by using the potentiometer, the control changes the feed rate accordingly.

Effect

M136 becomes effective at the start of the block.

You can cancel M136 by programming M137.

Feed rate for circular arcs: M109/M110/M111

Standard behavior

The control applies the programmed feed rate to the path of the tool center.

Behavior for circular arcs with M109

For inside and outside machining of circular arcs, the control keeps the feed rate at the cutting edge constant.

NOTICE

Caution: Danger to the tool and workpiece!

If the **M109** function is active, the control might significantly increase the feed rate when machining very small outside corners (acute angles). There is a risk of tool breakage or workpiece damage during machining.

▶ Do not use M109 for machining very small outside corners (acute angles)

Behavior for circular arcs with M110

With circular arcs, the control only keeps the feed rate constant for inside machining operations. The feed rate will not be adjusted for outside machining of circular arcs.



If you program **M109** or **M110** with a number > 200 before calling a machining cycle, the adjusted feed rate will also be effective for circular contours within these machining cycles. The initial state is restored after finishing or canceling a machining cycle.

Effect

M109 and M110 become effective at the start of the block. M109 and M110 can be canceled with M111.

Pre-calculating radius-compensated contours (LOOK AHEAD): M120

Standard behavior

If the tool radius is larger than the contour step that needs to be machined with radius compensation, then the control interrupts program run and issues an error message. **M97** inhibits the error message, but this results in dwell marks and will also move the corner.


Further information: "Machining small contour steps: M97", Page 238

The control might damage the contour in case of undercuts.

Behavior with M120

The control checks radius-compensated contours for undercuts and tool path intersections, and calculates the tool path in advance from the current NC block. Areas of the contour that would be damaged by the tool will not be machined (shown darker in the figure). You can also use **M120** to calculate the tool radius compensation for digitized data or data from an external programming system. This means that you can compensate for deviations from the theoretical tool radius.

The number of NC blocks (99 max.) to be calculated in advance can be defined with **LA** (**L**ook **A**head) following **M120**. Note that the larger the number of NC blocks you choose, the higher the block processing time will be.



Input

If you define **M120** in a positioning block, the control continues the dialog and prompts you for the number of **LA** NC blocks to be calculated in advance.

Effect

Program the function **M120** in an NC block that also contains an **RL** or **RR** radius compensation. This way, you can achieve consistent programming, resulting in clearly structured programs. You can deactivate the function **M120** with the following NC syntax:

- R0
- M120 LA0
- M120 without LA
- PGM CALL
- Cycle **19** or **PLANE** functions

M120 becomes effective at the start of the block and remains effective beyond the milling cycles.

Restrictions

- After an external or internal stop, you have to use a block scan to be able to re-approach the contour. Before the block scan, you need to cancel M120— otherwise the control will issue an error message.
- If you want to approach the contour on a tangential path, you must use the function APPR LCT. The NC block with APPR LCT must contain only the coordinates of the working plane.
- If you want to depart the contour on a tangential path, you must use the function **DEP LCT**. The NC block with **DEP LCT** must contain only the coordinates of the working plane.
- Before using the following functions, you have to cancel **M120** and the radius compensation:
 - Cycle 32 TOLERANCE
 - Cycle 19 WORKING PLANE
 - **PLANE** function
 - M114
 - M128
 - TCPM FUNCTION

Superimposing handwheel positioning during program run: M118

Standard behavior



Refer to your machine manual.

Your machine manufacturer must have prepared the control for this function.

In the Program Run operating modes, the control moves the tool as defined in the NC program.

Behavior with M118

M118 permits manual corrections by handwheel during the program run. For this purpose, you program **M118** and enter an axis-specific value (linear or rotary axis).



The M118 handwheel superimpositioning function can only be used at a standstill when combined with the function.

In order to use **M118** without restrictions, either deselect the function using the soft key in the menu or activate a kinematic model without collision objects (CMOs).

■ M118 cannot be used with clamped axes. If you want to use M118 with axes that are clamped then you must unclamp them first.

Input

If you enter **M118** in a positioning block, the control continues the dialog for this block by prompting you for the axis-specific values. Use the orange axis keys or the alphabetic keyboard for entering the coordinates.

Effect

To cancel handwheel positioning, program M118 once again without coordinate input or end the NC program with M30 / M2.



If the program aborts, handwheel positioning will also be canceled.

M118 becomes effective at the start of the block.

Example

You want to be able to use the handwheel during program run to move the tool in the working plane X/Y by ± 1 mm and in the rotary axis B by $\pm 5^{\circ}$ from the programmed value:

L X+0 Y+38.5 RL F125 M118 X1 Y1 B5



When programmed in an NC program, **M118** is always effective in the machine coordinate system.

If the Global Program Settings option (option 44) is active, the function **Handwheel superimposed** is effective in the last selected coordinate system. The coordinate system active for the function Handwheel superimposed is shown on the **POS HR** tab of the additional status display.

The **POS HR** tab also indicates whether the **Max. val.** have been defined via **M118** or via the Global Program Settings.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

The function **Handwheel superimposed** is also effective in the **Positioning w/ Manual Data Input** operating mode!

Virtual tool axis (VT)(Option 44)



Refer to your machine manual.

Your machine manufacturer must have prepared the control for this function.

With the virtual tool axis, you can also traverse with the handwheel in the direction of an inclined tool on a machine with swivel heads. To traverse in a virtual tool axis direction, select the **VT** axis on the display of your handwheel.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

When using an HR 5xx handwheel, you can select the virtual axis directly with the orange ${\bf VI}$ axis key, if necessary.

In conjunction with the M118 function, it is also possible to carry out handwheel superimpositioning in the currently active tool axis direction. For this purpose, program at least the spindle axis with its permitted range of traverse in the M118 function (e.g. M118 Z5) and select the VT axis on the handwheel.

Retraction from the contour in the tool-axis direction: M140

Standard behavior

In the **Program Run Single Block** and **Program Run Full Sequence** operating modes, the control moves the tool as defined in the NC program.

Behavior with M140

With **M140 MB** (move back), you can retract the tool from the contour by a programmable distance in the direction of the tool axis.

NOTICE

Danger of collision!

The machine manufacturer has various options for configuring the Dynamic Collision Monitoring (DCM, option 40) function. Depending on the machine, the control can continue with the NC program without an error message despite the detected collision. The control stops the tool at the last position without a collision and continues the NC program from this position. This configuration of DCM results in movements that are not defined in the program. **This behavior occurs no matter whether collision monitoring is active or inactive.** There is a danger of collision during these movements!

- Refer to your machine manual.
- ▶ Check the behavior at the machine.

Input

If you enter **M140** in a positioning block, the control continues the dialog and prompts you for the path the tool should use for retracting from the contour. Enter the desired path that the tool should follow when retracting from the contour, or press the **MB MAX** soft key to move to the limit of the traverse range.



In the optional machine parameter **moveBack** (no. 200903), the machine tool builder defines how far before a limit switch or a collision object a retraction movement **MB MAX** should end.

In addition, you can program the feed rate at which the tool traverses the entered path. If you do not enter a feed rate, the control moves the tool along the entered path at rapid traverse.

Effect

M140 is effective only in the NC block in which it is programmed.

M140 becomes effective at the start of the block.

Example

NC block 250: Retract the tool by 50 mm from the contour NC block 251: Move the tool to the limit of the traverse range

250 L X+0 Y+38.5 F125 M140 MB 50 F750

251 L X+0 Y+38.5 F125 M140 MB MAX



M140 is also in effect with a tilted working plane. For machines with head rotation axes the control moves the tool in the tool coordinate system **T-CS**.

With **M140 MB MAX** the control retracts the tool only in the positive direction in the tool axis.

The control gleans the necessary information about the tool axis for **M140** from the tool call.

NOTICE

Danger of collision!

If you use **M118** to modify the position of a rotary axis with the handwheel and then execute **M140**, the control ignores the superimposed values during the retraction movement. This results in unwanted and unpredictable movements, especially when using machines with head rotation axes. There is a danger of collision during these retraction movements!

Do not combine M118 with M140 when using machines with head rotation axes.

Suppressing touch probe monitoring: M141

Standard behavior

If the stylus is deflected, the control issues an error message as soon as you want to move a machine axis.

Behavior with M141

The control moves the machine axes even if the touch probe is deflected. This function is required if you wish to write your own measuring cycle in connection with Cycle **3** in order to retract the touch probe by means of a positioning block after it has been deflected

NOTICE

Danger of collision!

The miscellaneous function **M141** suppresses the corresponding error message if the stylus is deflected. The control does not perform an automatic collision check with the stylus. Based on these two types of behavior, you must check whether the touch probe can retract safely. There is a risk of collision if you choose the wrong direction for retraction.

► Carefully test the NC program or program section in the **Program run, single block** operating mode



M141 works only for movements with straight-line blocks.

Effect

M141 is effective only in the NC block in which **M141** is programmed.

M141 becomes effective at the start of the block.

Deleting basic rotation: M143

Standard behavior

The basic rotation remains in effect until it is reset or is overwritten with a new value.

Behavior with M143

The control deletes a basic rotation from the NC program.



The function **M143** is not permitted with mid-program startup.

Effect

M143 is effective only from the NC block in which it is programmed.

M143 becomes effective at the start of the block.



M143 clears the entries from the SPA, SPB and SPC columns in the preset table. When the corresponding line is reactivated, the basic rotation is 0 in all columns.

Lifting off the tool automatically from the contour at NC stop: M148

Standard behavior

In case of an NC stop, the control stops all traverse movements. The tool stops moving at the point of interruption.

Behavior with M148



Refer to your machine manual.

This function must be configured and enabled by your machine manufacturer.

In machine parameter **CfgLiftOff** (no. 201400), the machine manufacturer defines the path the tool is supposed to traverse for a **LIFTOFF** command. You can also use machine parameter **CfgLiftOff** to deactivate the function.

Set the **Y** parameter in the **LIFTOFF** column of the tool table for the active tool. The control then retracts the tool from the contour by 2 mm max. in the direction of the tool axis.

Further information: User's Manual for Setup, Testing and Running NC Programs

LIFTOFF takes effect in the following situations:

- An NC stop triggered by you
- An NC stop triggered by the software, e.g. if an error occurred in the drive system
- When a power interruption occurs



When lifting the tool off with **M148**, the control will not necessarily lift it off in the tool axis direction.

The control uses the **M149** function to deactivate the **FUNCTION LIFTOFF** function without resetting the lift-off direction. If you program **M148**, the control will activate the automatic lift-off of the tool in the lift-off direction defined by the **FUNCTION LIFTOFF** function.

Effect

M148 remains in effect until deactivated with M149 or FUNCTION LIFTOFF RESET.

M148 becomes effective at the start of the block, M149 at the end of the block.

Rounding corners: M197

Standard behavior

With active radius compensation, the control inserts a transition arc at outside corners. This may lead to rounding of that edge.

Behavior with M197

With the M197 function, the contour at the corner is tangentially extended and a smaller transition arc is then inserted. When you program the M197 function and then press the ENT key, the control opens the DL input field. In DL, you define the length the control by which the control extends the contour elements. With M197, the corner radius is reduced, the corner is rounded less and the traverse movement is still smooth.

Effect

The **M197** function acts blockwise and is only effective on outside corners.

Example

L X... Y... RL M197 DL0.876

8

Subprograms and program section repeats

8.1 Labeling subprograms and program section repeats

Subprograms and program section repeats enable you to program a machining sequence once and then run it as often as necessary.

Label

Subprograms and program section repeats start with **LBL** in the NC program (an abbreviation for LABEL).

A LABEL contains a number between 1 and 65535 or a name to be defined by you. LABEL names can have up to 32 characters.



Permitted characters: #\$%&,-_.0123456789@abcdefghijkImnopqrstuvwxyz-ABCDEFGHIJKLMNOPQRSTUVWXYZ

Impermissible characters: <blank>! " '() * + : ; < = >? [/] ^ `{|} ~

You may assign each LABEL number, or each LABEL name, only once in the NC program using the **LABEL SET**. The quantity of label names that may be entered is limited only by the amount of internal memory.



Do not use a label number or label name more than once!

Label 0 (**LBL 0**) is used exclusively to mark the end of a subprogram and can therefore be used as often as desired.



Before creating your NC program, compare the subprogram and program section repeat programming techniques using if-then decisions.


You can thereby avoid possible misunderstandings and programming errors.

Further information: "If-then decisions with Q parameters", Page 291

8.2 Subprograms

Operating sequence

- 1 The control executes the NC program up to the block in which a subprogram is called with **CALL LBL**
- 2 The subprogram is then executed until the subprogram end **LBL 0**
- 3 The control then resumes the NC program from the NC block after the subprogram call **CALL LBL**



Programming notes

- A main program can contain any number of subprograms
- You can call subprograms in any sequence and as often as desired
- A subprogram cannot call itself
- Write subprograms after the NC block with M2 or M30
- If subprograms are located in the NC program before the NC block with M2 or M30, they will be executed at least once even if they are not called

Programming the subprogram



- ▶ To mark the beginning: Press the **LBL SET** key
- Enter the subprogram number. If you want to use a label name, press the LBL NAME soft key to switch to text entry.
- Enter the text
- Mark the end: Press the LBL SET key and enter the label number 0

Calling a subprogram



- ► Call a subprogram: Press the **LBL CALL** key
- ▶ Enter the subprogram number of the subprogram you wish to call. If you want to use a label name, press the **LBL NAME** soft key to switch to text entry.
- ▶ If you want to enter the number of a string parameter as target address, press the QS soft key
- > The control then jumps to the label name that is specified in the string parameter defined.
- ▶ Ignore repeats REP by pressing the NO ENT key. Repeat REP is used only for program section repeats




CALL LBL 0 is not permitted (Label 0 is only used to mark the end of a subprogram).

8.3 Program-section repeats

Label

The beginning of a program section repeat is marked by the label **LBL**. The end of a program section repeat is identified by **CALL LBL n REPn**.



Operating sequence

- 1 The control executes the NC program up to the end of the program section (CALL LBL n REPn)
- 2 Then the program section between the called LABEL and the label call **CALL LBL n REPn** is repeated the number of times entered after **REP**
- 3 The control then resumes the NC program after the last repetition.

Programming notes

- You can repeat a program section up to 65 534 times in succession
- The total number of times the program section is executed is always one more than the programmed number of repeats, because the first repeat starts after the first machining process.

Programming a program section repeat



- ➤ To mark the beginning, press the **LBL SET** key and enter a LABEL NUMBER for the program section you wish to repeat. If you want to use a label name, press the **LBL NAME** soft key to switch to text entry.
- ► Enter the program section

Calling a program section repeat



- ► Call a program section: Press the **LBL CALL** key
- Enter the program section number of the program section to be repeated. If you want to use a LABEL name, press the LBL NAME soft key to switch to text entry
- ► Enter the number of repeats **REP** and confirm with the **ENT** key.

8.4 Calling an external NC program

Overview of the soft keys

When you press the **PGM CALL** key, the control displays the following soft keys:


Soft key	Function	Description
CALL PROGRAM	Call an NC program with PGM CALL	Page 262
SELECT DATUM TABLE	Select a datum table with SEL TABLE	Page 424
SELECT POINT TABLE	Select a point table with SEL PATTERN	Page 266
SELECT	Select a contour program with SEL CONTOUR	See the User's Manual for Programming of Machining Cycles
SELECT PROGRAM	Select an NC program with SEL PGM	Page 263
CALL SELECTED PROGRAM	Call the last selected file with CALL SELECTED PGM	Page 263
SELECT CYCLE	Select any NC program with SEL CYCLE as a machining cycle	See the User's Manual for Programming of Machining Cycles

Operating sequence

- 1 The control executes the NC program up to the block in which another NC program is called with **CALL PGM**.
- 2 Then the other NC program is run from beginning to end.
- 3 The control then resumes the calling NC program with the NC block behind the program call.



If you want to program variable program calls in connection with string parameters, use the **SEL PGM** function.



Programming notes

- The control does not require any labels to call an NC program.
- The called NC program must not use **CALL PGM** to call the calling NC program (an endless loop would ensue).
- The called NC program must not contain the miscellaneous function M2 or M30. If you have defined subprograms with labels in the called NC program, then you can replace M2 or M30 with the jump function FN 9: If +0 EQU +0 GOTO LBL 99.
- If you want to call an ISO program, enter the file type .I after the program name.
- You can also call an NC program with Cycle 12 PGM CALL.
- You can also call any NC program with the Select the cycle function (SEL CYCLE).
- As a rule, Q parameters are active globally with a PGM CALL. So please note that changes to Q parameters in the called NC program can also influence the calling NC program.



While the control is executing the calling NC program, editing of all called NC programs is disabled.

Checking the called NC programs

NOTICE

Danger of collision!

The control does not automatically check whether collisions can occur between the tool and the workpiece. If you do not specifically rescind the coordinate transformations in the called NC program, these transformations will also take effect in the calling NC program. Danger of collision during machining!

- Reset used coordinate transformations in the same NC program
- Check the machining sequence using a graphic simulation if required

The control checks the called NC programs:

- If the called NC program contains the miscellaneous functions M2 or M30, then the control displays a warning. The control automatically clears the warning as soon as you select another NC program.
- The control checks the called NC programs for completeness before execution. If the **END PGM** NC block is missing, the control aborts with an error message.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

Path information

If the NC program you want to call is located in the same directory as the NC program you are calling it from, then you only need to enter the program name.

If the called NC program is not located in the same directory as the NC program you are calling it from, you must enter the complete path, e.g. TNC:\ZW35\HERE\PGM1.H

Alternatively, you can program relative paths:

- Starting from the folder of the calling NC program, one folder level up ..\PGM1.H
- Starting from the folder of the calling NC program, one folder level down DOWN\PGM1.H
- Starting from the folder of the calling NC program, one folder level up and in another folder ..\THER\PGM3.H

Use the **SYNTAX** soft key to place paths within quotation marks. The quotation marks define the beginning and the end of the path. This enables the control to identify any special characters as a part of the path.

Further information: "File names", Page 109

If the complete path is enclosed in quotation marks, you can use both \ and \forall to separate the folders and files.

Calling an external NC program

Calling a program with PGM CALL

You can call an external NC program with the **PGM CALL** function. The control runs the external NC program from the position where it was called in the NC program.

Proceed as follows:



► Press the **PGM CALL** key



- ▶ Press the **CALL PROGRAM** soft key
- > The control starts the dialog for defining the NC program to be called.
- Enter the path name with the keyboard

Alternative:



- ▶ Press the **SELECT FILE** soft key
- > The control displays a selection window in which you can select the NC program to be called.
- ► Press the **ENT** key



If the called file is located in the same directory as the file you are calling it from, you can also integrate the file name without the path. The **APPLY FILE NAME** soft key provided in the selection window of the **SELECT FILE** soft key is available for this.

Call with SEL PGM and CALL SELECTED PGM

The function **SEL PGM** allows you to select an external NC program that you can separately call at a different position in the NC program. The control runs the external NC program from the position at which you called it in the NC program using **CALL SELECTED PGM**.

The **SEL PGM** function is also permitted with string parameters, so that you can dynamically control program calls.

To select the NC program, proceed as follows:



▶ Press the **PGM CALL** key



- ▶ Press the **SELECT PROGRAM** soft key
- > The control starts the dialog for defining the NC program to be called.



- ▶ Press the **SELECT FILE** soft key
- > The control displays a selection window in which you can select the NC program to be called.
- ► Press the **ENT** key



If the called file is located in the same directory as the file you are calling it from, you can also integrate the file name without the path. The **APPLY FILE NAME** soft key provided in the selection window of the **SELECT FILE** soft key is available for this.

To call the selected NC program, proceed as follows:



Press the PGM CALL key



- Press the CALL PROGRAM soft key
- > The control uses **CALL SELECTED PGM** to call the NC program that was selected last.



If an NC program that was called using **CALL SELECTED PGM** is missing, then the control interrupts the execution or simulation with an error message. In order to avoid undesired interruptions during program run, you can use the function **FN 18 (ID10 NR110** and **NR111)** to check all paths at the beginning of the program.

Further information: "FN 18: SYSREAD – Reading system data", Page 317

8.5 Point tables

Application

With a point table you can execute one or more cycles in sequence on an irregular point pattern.

Related topics

Creating a point table

To create a point table:



Select the **PROGRAMMING** operating mode



- ► Press the **PGM MGT** key
- > The control opens the file manager.
- ▶ Select the desired folder in your folder structure
- ► Enter the name and file type (*.pnt)



► Confirm with the **ENT** key



- ▶ Press the **MM** or **INCH** soft key.
- > The control opens the table editor and shows an empty point table.



- ▶ Press the **INSERT LINE** soft key
- > The control inserts a new row in the point table.
- Enter the coordinates of the desired machining position
- Repeat the process until all desired coordinates have been entered



If you intend to use the point table in SQL queries later, the table name must begin with a letter.

Configuring the point table display

To configure the display of a point table:

Open the desired point table

Further information: "Creating a point table", Page 264



- ▶ Press the **SORT/ HIDE COLUMNS** soft key
- The control opens the Column sequence window.
- Configure how the table will be displayed



- ▶ Press the **OK** soft key
- > The control will display the table as defined in the selected configuration.



If you enter the code number 555343, the control will display the **EDIT FORMAT** soft key. With this soft key, you can change the table properties.

Hiding single points for the machining process

In the **FADE** column of the point table, you can specify if the defined point is to be hidden during the machining process.

To hide points:

- Select the desired point from the table
- ► Select the **FADE** column



► Activate hiding with the **ENT** key



▶ Deactivate hiding with the **NO ENT** key

Selecting a point table in the NC program

To select a point table in your NC program:

▶ In the **Programming** operating mode, select the NC program for which you want to activate the point table.



► Press the **PGM CALL** key



► Press the **SELECT TABLE** soft key



- ▶ Press the **SELECT FILE** soft key
- ▶ Select the point table from the folder structure
- ► Press the **OK** soft key

If the point table is not stored in the same directory as the NC program, you must enter the complete path.



If the called file is located in the same directory as the file you are calling it from, you can also integrate the file name without the path. The **APPLY FILE NAME** soft key provided in the selection window of the **SELECT FILE** soft key is available for this.

Example

7 SEL PATTERN "TNC:\nc_prog\Positions.PNT"

Using point tables

To call a cycle at the points defined in the point table, program the cycle call with **CYCL CALL PAT**.

With **CYCL CALL PAT**, the control will process the point table that you defined last.

To use a point table:



▶ Press the **CYCL CALL** key



- ▶ Press the CYCL CALL PAT soft key
- ► Enter the feed rate, e.g. **F MAX**



The control will use this feed rate to traverse between the points of the point table. If you do not define a feed rate, the control will use the feed rate that was defined last.

- ► Enter a miscellaneous function if required
- ► Press the **END** key

Notes

- In the GLOBAL DEF 125 function you can use the setting Q435=1 to force the control to always move to the 2nd set-up clearance from the cycle during the positioning between the points.
- If you want to move at reduced feed rate when pre-positioning in the tool axis, program the **M103** miscellaneous function.
- With CYCL CALL PAT the control runs the point table that you last defined, even if you defined the point table with an NC program that was nested with CALL PGM.

Definition

File type	Definition	
*.pnt	Points table	

8.6 Nesting

Types of nesting

- Subprogram calls in subprograms
- Program-section repeats within a program-section repeat
- Subprogram calls within program-section repeats
- Program-section repeats within subprograms



Subprograms and program-section repeats can call external NC programs as well.

Nesting depth

The nesting depth defines, among other things, how often program sections or subprograms may contain further subprograms or program section repeats.

- Maximum nesting depth for subprograms: 19
- Maximum nesting depth for external NC programs: 19, for which a CYCL CALL has the effect of calling an external program
- You can nest program section repeats as often as desired

Subprogram within a subprogram

Example

O BEGIN PGM UPGMS MM	
17 CALL LBL "UP1"	Call the subprogram marked with LBL UP1
35 L Z+100 R0 FMAX M2	Last program block of the main program with M2
36 LBL "UP1"	Beginning of subprogram UP1
39 CALL LBL 2	Call the subprogram marked with LBL 2
45 LBL 0	End of subprogram 1
46 LBL 2	Beginning of subprogram 2
62 LBL 0	End of subprogram 2
63 END PGM SUBPGMS MM	

Program execution

- 1 Main program UPGMS is executed up to NC block 17
- 2 Subprogram UP1 is called, and executed up to NC block 39
- 3 Subprogram 2 is called, and executed up to NC block 62. End of subprogram 2 and return jump to the subprogram from which it was called.
- 4 Subprogram UP1 is called, and executed from NC block 40 up to NC block 45. End of subprogram 1 and return jump to the main program UPGMS.
- 5 Main program UPGMS is executed from NC block 18 up to NC block 35. Return jump to NC block 1 and end of program

Repeating program section repeats

Example

0 BEGIN PGM REPS MM	
•••	
15 LBL 1	Beginning of program section repeat 1
•••	
20 LBL 2	Beginning of program section repeat 2
•••	
27 CALL LBL 2 REP 2	Program section call with two repeats
35 CALL LBL 1 REP 1	The program section between this NC block and LBL 1
	(NC block 15) is repeated once
50 END PGM REPS MM	

Program execution

- 1 Main program REPS is executed up to NC block 27
- 2 The program section between NC block 27 and NC block 20 is repeated twice
- 3 Main program REPS is executed from NC block 28 up to NC block 35
- 4 The program section between NC block 35 and NC block 15 is repeated once (including the program section repeat between NC block 20 and NC block 27)
- 5 Main program REPS is executed from NC block 36 up to NC block 50. Return jump to NC block 1 and end of program

Repeating a subprogram

Example

O BEGIN PGM UPGREP MM	
10 LBL 1	Beginning of program section repeat 1
11 CALL LBL 2	Subprogram call
12 CALL LBL 1 REP 2	Program section call with two repeats
19 L Z+100 R0 FMAX M2	Last NC block of the main program with M2
20 LBL 2	Beginning of subprogram
28 LBL 0	End of subprogram
29 END PGM UPGREP MM	

Program execution


- 1 Main program UPGREP is executed up to NC block 11
- 2 Subprogram 2 is called and executed.
- 3 The program section between NC block 12 and NC block 10 is repeated twice. This means that subprogram 2 is repeated twice
- 4 Main program UPGREP is executed from NC block 13 up to NC block 19. Return jump to NC block 1 and end of program

8.7 Programming examples

Example: Milling a contour in several infeeds

Program run:

- Pre-position the tool to the workpiece surface
- Enter the infeed depth in incremental values
- Contour milling
- Repeat infeed and contour-milling




0 BEGIN PGM PGMWDH MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-40	
2 BLK FORM 0.2 X+100 Y+100 Z+0	
3 TOOL CALL 1 Z S500	Tool call
4 L Z+250 R0 FMAX	Retract the tool
5 L X-20 Y+30 R0 FMAX	Pre-position in the working plane
6 L Z+0 R0 FMAX M3	Pre-position to the workpiece surface
7 LBL 1	Set label for program section repeat
8 L IZ-4 RO FMAX	Incremental downfeed (in the air)
9 APPR CT X+2 Y+30 CCA90 R+5 RL F250	Contour approach
10 FC DR- R18 CLSD+ CCX+20 CCY+30	Contour
11 FLT	
12 FCT DR- R15 CCX+50 CCY+75	
13 FLT	
14 FCT DR- R15 CCX+75 CCY+20	
15 FLT	
16 FCT DR- R18 CLSD- CCX+20 CCY+30	
17 DEP CT CCA90 R+5 F1000	Contour departure
18 L X-20 Y+0 R0 FMAX	Retract tool
19 CALL LBL 1 REP 4	Return jump to LBL 1; section is repeated a total of 4 times
20 L Z+250 R0 FMAX M2	Retract the tool, end of program
21 END PGM PGMWDH MM	

Example: Groups of holes

Program run:

- Approach the groups of holes in the main program
- Call the group of holes (subprogram 1) in the main program
- Program the group of holes only once in subprogram 1




0 BEGIN PGM UP1 MM		
1 BLK FORM 0.1 Z X+0 Y+0 Z-20		
2 BLK FORM 0.2 X+100 Y+100 Z+0		
3 TOOL CALL 1 Z S500	00	Tool call
4 L Z+250 R0 FMAX		Retract the tool
5 CYCL DEF 200 DRIL	LING	Cycle definition: Drilling
Q200=2	;SET-UP CLEARANCE	
Q201=-10	;DEPTH	
Q206=250	;FEED RATE FOR PLNGNG	
Q202=5	;PLUNGING DEPTH	
Q210=0	;DWELL TIME AT TOP	
Q203=+0	;SURFACE COORDINATE	
Q204=10	;2ND SET-UP CLEARANCE	
Q211=0.25	;DWELL TIME AT DEPTH	
Q395=0	;DEPTH REFERENCE	
6 L X+15 Y+10 R0 FM	AX M3	Move to starting point for group 1
7 CALL LBL 1		Call the subprogram for the group
8 L X+45 Y+60 R0 FMAX		Move to starting point for group 2
9 CALL LBL 1		Call the subprogram for the group
10 L X+75 Y+10 R0 FA	MAX	Move to starting point for group 3
11 CALL LBL 1		Call the subprogram for the group
12 L Z+250 RO FMAX	M2	End of main program
13 LBL 1		Beginning of subprogram 1: Group of holes
14 CYCL CALL		Hole 1
15 L IX+20 R0 FMAX M99		Move to 2nd hole, call cycle
16 L IY+20 R0 FMAX M99		Move to 3rd hole, call cycle
17 L IX-20 RO FMAX M99		Move to 4th hole, call cycle
18 LBL 0		End of subprogram 1
19 END PGM UP1 MM		

Example: Group of holes with multiple tools

Program run:

- Program the fixed cycles in the main program
- Call the complete hole pattern (subprogram 1) in the main program
- Approach the groups of holes (subprogram 2) in subprogram 1
- Program the group of holes only once in subprogram 2



0 BEGIN PGM UP2 M	MM	
1 BLK FORM 0.1 Z X+0 Y+0 Z-20		
2 BLK FORM 0.2 X+	100 Y+100 Z+0	
3 TOOL CALL 1 Z S5	5000	Centering drill tool call
4 L Z+250 R0 FMAX		Retract the tool
5 CYCL DEF 200 DR	RILLING	Cycle definition: Centering
Q200=2	;SET-UP CLEARANCE	
Q201=-3	;DEPTH	
Q206=250	;FEED RATE FOR PLNGNG.	
Q202=3	;PLUNGING DEPTH	
Q210=0	;DWELL TIME AT TOP	
Q203=+0	;SURFACE COORDINATE	
Q204=10	;2ND SET-UP CLEARANCE	
Q211=0.25	;DWELL TIME AT DEPTH	
Q395=0	;DEPTH REFERENCE	
6 CALL LBL 1		Call subprogram 1 for the entire hole pattern
7 L Z+250 RO FMAX		
8 TOOL CALL 2 Z S4000		Drill tool call
9 FN 0: Q201 = -25		New depth for drilling
10 FN 0: Q202 = +5		New plunging depth for drilling
11 CALL LBL 1		Call subprogram 1 for the entire hole pattern
12 L Z+250 R0 FMAX		
13 TOOL CALL 3 Z S500		Reamer tool call

14 CYCL DEF 201	REAMING	Cycle definition: Reaming
Q200=2	;SET-UP CLEARANCE	
Q201=-15	;DEPTH	
Q206=250	;FEED RATE FOR PLNGNG.	
Q211=0.5	;DWELL TIME AT DEPTH	
Q208=400	;RETRACTION FEED RATE	
Q203=+0	;SURFACE COORDINATE	
Q204=10	;2ND SET-UP CLEARANCE	
15 CALL LBL 1		Call subprogram 1 for the entire hole pattern
16 L Z+250 R0 FMA	AX M2	End of main program
17 LBL 1		Beginning of subprogram 1: Entire hole pattern
18 L X+15 Y+10 R0	FMAX M3	Move to starting point for hole group 1
19 CALL LBL 2		Call subprogram 2 for the hole group
20 L X+45 Y+60 RO FMAX		Move to starting point for hole group 2
21 CALL LBL 2		Call subprogram 2 for the hole group
22 L X+75 Y+10 R0 FMAX		Move to starting point for hole group 3
23 CALL LBL 2		Call subprogram 2 for the hole group
24 LBL 0		End of subprogram 1
25 LBL 2		Beginning of subprogram 2: Group of holes
26 CYCL CALL		Hole 1 with active machining cycle
27 L IX+20 R0 FMAX M99		Move to 2nd hole, call cycle
28 L IY+20 R0 FMAX M99		Move to 3rd hole, call cycle
29 L IX-20 RO FMAX M99		Move to 4th hole, call cycle
30 LBL 0		End of subprogram 2
31 END PGM SP2 M	M	

Programming Q parameters

9.1 Principle and overview of functions


With Q parameters you can program entire families of parts in a single NC program by programming variable Q parameters instead of fixed numerical values.

Q parameters can be used in the following ways:

- Coordinate values
- Feed rates
- Spindle speeds
- Cycle data

The control offers more ways to use Q parameters:

- Program contours that are defined through mathematical functions
- Making the execution of machining steps dependent on logical conditions
- Variably design FK programs



Q parameter types

Q parameters for numerical values

Variables always consist of letters and numbers. The letters determine the type of variable and the numbers its range. For more information, see the table below:

Variable type	Variable range	Meaning	
Q parameters:		Q parameters affect all NC programs in the control's memory.	
	0 to 99	User-defined Q parameters, if there are no overlaps with the HEIDENHAIN SL cycles	
		Q parameters have a local effect within macros and machine manufacturer cycles. This means that the control will not return changes to the NC program.	
		For this reason, use the Q parameter range 1200 to 1399 for machine manufacturer cycles!	
	100 to 199	Q parameters for special functions on the control that can be read by user-defined NC programs or by cycles	
	200 to 1199	Q parameters for functions defined by HEIDENHAIN (e.g., cycles)	
	1200 to 1399	Q parameters for functions defined by the machine manufacturer (e.g., cycles)	
	1400 to 1999	User-defined Q parameters	
QL parameters:		QL parameters are active locally within an NC program.	
	0 to 499	User-defined QL parameters	

QR parameter affect all NC programs in the control's memory; they

QR parameters for functions defined by HEIDENHAIN (e.g., cycles)

QR parameters for functions defined by the machine manufacturer

are retained even after a restart of the control.

User-defined QR parameters

(e.g., cycles)



QR parameters:

QR parameters will be included in backups.

0 to 99

100 to 199 200 to 499

If the machine manufacturer did not define a specific path, the control saves the QR parameters in the following path: **SYS:\runtime\sys.cfg**. The **SYS:** partition will only be backed up in full backups.

Machine manufacturers can use the following optional machine parameters to specify the paths:

- pathNcQR (no. 131201)
- **pathSimQR** (no. 131202)

If the machine manufacturer used the optional machine parameters to specify a path on the **TNC:** partition, you can perform a backup with the **NC/PLC Backup** functions without entering a code number.

Q parameters for texts

Additionally, QS parameters ($\bf S$ stands for string) are available and enable you to process texts on the control.

Variable type	Variable range	Meaning
QS parameters:		QS parameters affect all NC programs in the control's memory.
	0 to 99	User-defined QS parameters, if there are no overlaps with the HEIDENHAIN SL cycles
		QS parameters have a local effect within macros and the machine manufacturer cycles. This means that the control will not return changes to the NC program. For this reason, use the QS parameter range 1200 to 1399 for machine manufacturer cycles!
	100 to 199	QS parameters for special functions on the control that can be read by user-defined NC programs or by cycles
	200 to 1199	QS parameters for functions defined by HEIDENHAIN (e.g., cycles)
	1200 to 1399	QS parameters for functions defined by the machine manufacturer (e.g., cycles)
	1400 to 1999	User-defined QS parameters

Programming notes

NOTICE

Danger of collision!

HEIDENHAIN cycles, manufacturer cycles and third-party functions use Q parameters. You can also program Q parameters within NC programs. If, when using Q parameters, the recommended Q parameter ranges are not used exclusively, then this can lead to overlapping (reciprocal effects) and thus cause undesired behavior. Danger of collision during machining!

- Only use Q parameter ranges recommended by HEIDENHAIN.
- ► Comply with the documentation from HEIDENHAIN, the machine tool builder, and suppliers.
- ▶ Check the machining sequence using a graphic simulation

You can mix Q parameters and numerical values within an NC program.

Variables can be assigned numerical values between $-999\,999\,999$ and $+999\,999\,999$. The input range is limited to 16 digits, of which 9 may be before the decimal point. The control can calculate numerical values up to 10^{10} .

You can assign a maximum of 255 characters to **QS** parameters.



The control automatically assigns some Q and QS parameters the same data, e.g., the Q parameter **Q108** is automatically assigned the current tool radius.

Further information: "Preassigned Q parameters", Page 335

The control saves numerical values internally in a binary number format (standard IEEE 754). Due to the standardized format used, some decimal numbers cannot be represented with a binary value that is 100% exact (rounding error). If you use calculated variable values for jump commands or positioning moves, you must keep this in mind.

You can reset variables to the **Undefined** status. For example, if you program a position using an undefined Q parameter, the control ignores this movement.

Calling Q parameter functions

When you are writing an NC program, press the $\bf Q$ key (in the numeric keypad for numerical input and axis selection, below the +/-key). The control then displays the following soft keys:

Soft key	Function group	Page
BASIC ARITHM.	Basic arithmetic (assign, add, subtract, multiply, divide, square root)	284
TRIGO- NOMETRY	Trigonometric functions	288
CIRCLE CALCU- LATION	Function for calculating circles	290
JUMP	If/then conditions, jumps	291
DIVERSE FUNCTION	Other functions	301
FORMULA	Entering formulas directly	294
CONTOUR	Function for machining complex contours	See the User's Manual for Programming of Machining Cycles



If you define or assign a Q parameter, then the control shows the $\bf Q$, $\bf QL$ and $\bf QR$ soft keys. You can use these soft keys to select the desired parameter type. Then you define the parameter number.

9.2 Part families—Q parameters in place of numerical values

Application

The Q parameter function **FN 0: Assign** allows you to assign numerical values to Q parameters. You then use a Q parameter in place of the numerical value in the NC program.

Example


15 FN 0: Q10=25	Assign
	Q10 is assigned the value 25
25 L X +Q10	Means L X +25

You need write only one program for a whole family of parts, entering the characteristic dimensions as Q parameters.

To program a particular part, you then assign the appropriate values to the individual Q parameters.

Example: Cylinder with Q parameters

Cylinder radius: R = Q50Cylinder height: H = Q51Cylinder Z1: Q50 = +30 Q51 = +10Cylinder Z2: Q50 = +10Q51 = +50



9.3 Describing contours with mathematical functions

Application

The Q parameters listed below enable you to program basic mathematical functions in an NC program:



- ► Select the Q parameter function: Press the **Q** key in the numeric keypad
- > The Q parameter functions are displayed in the soft key row.



- ▶ Press the **BASIC ARITHM.** soft key
- > The control displays the soft keys for basic mathematical functions

Overview

FN 0: Assignment Example: FN 0: Q5 = +60 Q5 = 60	
Example. FN 0: Q5 = +60	
05 - 60	
Q5 - 00	
Assign a value or the Undefin	ed status
FN 1: Addition	
Example: FN 1: Q1 = -Q2 + -5	5
Q1 = -Q2 + (-5)	
Calculate and assign the sum	of two values
FN 2: Subtraction	
Example: FN 2: Q1 = +10 - +5	5
Q1 = +10-(+5)	
Calculate and assign the differ	rence of two values.
FN 3: Multiplication	
Example: FN 3: Q2 = +3 * +3	
Q2 = 3*3	
Calculate and assign the produ	uct of two values.
FN 4: Division	
Example: FN 4: Q4 = +8 DIV	+Q2
Q4 = 8/Q2	
Calculate and assign the quoti	ient of two values
Restriction: You cannot divide	by 0
FN 5: Square root	
Example: FN 5: Q20 = SQRT 4	4
$Q20 = \sqrt{4}$	
Calculate and assign the squa	re root of a number
Restriction: You cannot calculation from a negative value	ate a square root

You can enter the following to the right of the **=** sign:

- Two numbers
- Two Q parameters
- A number and a Q parameter

The Q parameters and numerical values in the equations can be entered with positive or negative signs.

Programming fundamental operations

Example: Assignment

16 FN 0: Q5 = +10

17 FN 3: Q12 = +Q5 * +7



Select the Q parameter function: Press the Q key



Select basic mathematical functions by pressing the BASIC ARITHM. soft key



- ► To select the **ASSIGN** Q parameter function: Press the **FN 0 X = Y** soft key
- > The control asks you for the number of the result parameter.
- ► Enter **5** (number of Q parameter)



- Confirm with the ENT key
- > The control asks you for the value or parameter.
- ► Enter 10 (value)



- ► Confirm with the **ENT** key
- > As soon as the control reads the NC block, the value **10** is assigned to the parameter **Q5**.

Example: Multiplication



Select the Q parameter function: Press the Q key



Select basic mathematical functions by pressing the BASIC ARITHM. soft key



- To select the MULTIPLICATION Q parameter function, press the FN 3 X * Y soft key
- > The control asks you for the number of the result parameter.
- ► Enter **12** (number of Q parameter)



- ► Confirm with the **ENT** key
- > The control asks you for the first value or parameter.
- ► Enter **Q5** (parameter)



- ► Confirm with the **ENT** key
- The control asks you for the second value or parameter.
- ▶ Enter **7** for the second value



► Confirm with the **ENT** key

Resetting Q parameters

Example

16 FN 0: Q5 SET UNDEFINED

17 FN 0: Q1 = Q5



▶ Select the Q parameter function: Press the **Q** key



Select basic mathematical functions by pressing the BASIC ARITHM. soft key



- ► To select the ASSIGN Q parameter function: Press the FN 0 X = Y soft key
- > The control asks you for the number of the result parameter.
- ► Enter **5** (number of Q parameter)



- ► Confirm with the **ENT** key
- > The control asks you for the value or parameter.



▶ Press **SET UNDEFINED**



The **FN 0** function also supports transfer of the value **Undefined**. If you try to transfer the undefined Q parameter without **FN 0**, the control shows the error message **Invalid value**.

9.4 Trigonometric functions

Definitions

Sine: $\sin \alpha = \text{opposite side/hypotenuse}$

 $\sin \alpha = a/c$

Cosine: $\cos \alpha = \text{adjacent side/hypotenuse}$

 $\cos \alpha = b/c$

Tangent: $\tan \alpha = \text{opposite side/adjacent side}$

 $\tan \alpha = a/b$ or $\tan \alpha = \sin \alpha/\cos \alpha$

where

- c is the side opposite the right angle
- \blacksquare a is the side opposite the angle α
- b is the third side.

The control can find the angle from the tangent:

 α = arctan(a/b) or α = arctan(sin α /cos α)

Example:

 $a = 25 \, \text{mm}$

b = 50 mm

 $\alpha = \arctan(a/b) = \arctan 0.5 = 26.57^{\circ}$

Furthermore:

 $a^2+b^2 = c^2$ (where $a^2 = a*a$)

 $c = \sqrt{(a^2+b^2)}$

Programming trigonometric functions


You can also calculate trigonometric functions with Q parameters.



- ► Select the Q parameter function: Press the **Q** key in the numeric keypad
- > The Q parameter functions are displayed in the soft key row.



- ► Press the **TRIGONOMETRY** soft key
- The control displays the soft keys for trigonometric functions.



Overview

Soft key	Function
FN6	FN 6: Sine
SIN(X)	Example: FN 6: Q20 = SIN -Q5
	$Q20 = \sin(-Q5)$
	Calculate and assign the sine of an angle in degrees
FN7	FN 7: Cosine
COS(X)	Example: FN 7: Q21 = COS -Q5
	$Q21 = \cos(-Q5)$
	Calculate and assign the cosine of an angle in degrees
FN8	FN 8: Root of the sum of squares
X LEN Y	Example: FN 8: Q10 = +5 LEN +4
	$Q10 = \sqrt{(5^2 + 4^2)}$
	Calculate and assign the length based on two values (e.g., to calculate the third side of a triangle).
FN13	FN 13: angle
X ANG Y	Example: FN 13: Q20 = +25 ANG -Q1
	$Q20 = \arctan(25/-Q1)$
	Calculate and assign the angle from the opposite side and the adjacent side using arctan or from the sine and cosine of the angle (0 < angle < 360°)

9.5 Calculation of circles

Application

The control can use the functions for calculating circles to calculate the circle center and the circle radius from three or four given points on the circle. The calculation is more accurate if four points are used.

Application: These functions can be used, for example, if you wish to determine the location and size of a hole or a pitch circle using the programmable probing function.

Soft key	Function
FN23 3 POINTS	FN 23: Circle data from three points on the circle
OF CIRCLE	Example: FN 23: Q20 = CDATA Q30
	The control saves the determined values in the Q parameters Q20 to Q22 .

The control checks the values in the Q parameters **Q30** to **Q35** and determines the circle data.

The control saves the results in the following Q parameters:

- Circle center on the main axis in the Q parameter Q20
 For the tool axis Z, the main axis is X
- Circle center on the secondary axis in the Q parameter Q21
 For the tool axis Z, the secondary axis is Y
- Circle radius in the Q parameter **Q22**

Soft key	Function
FN24 4 POINTS	FN 24: Circle data from four points on the circle
OF CIRCLE	Example: FN 24: Q20 = CDATA Q30
	The control saves the determined values in the Q parameters Q20 to Q22 .

The control checks the values in the Q parameters **Q30** to **Q37** and determines the circle data.

The control saves the results in the following Q parameters:

- Circle center on the main axis in the Q parameter Q20
 For the tool axis Z, the main axis is X
- Circle center on the secondary axis in the Q parameter Q21
 For the tool axis Z, the secondary axis is Y
- Circle radius in the Q parameter **Q22**



FN 23 and **FN 24** not only assign a value to the results variable to the left of the equal sign, but also to the subsequent variables.

9.6 If-then decisions with Q parameters

Application

In if-then decisions, the control compares a variable or fixed value with another variable or fixed value. If the condition is fulfilled, the control jumps to the label programmed for the condition.



Before creating your NC program, compare the if-then decisions with the subprogram and program section repeat programming techniques.

You can thereby avoid possible misunderstandings and programming errors.

Further information: "Labeling subprograms and program section repeats", Page 254

If the condition is not fulfilled, the control continues with the next NC block.

If you want to call an NC program, then program a program call with **PGM CALL** after the label.

Abbreviations used

IF	If
EQU	Equal to
NE	Not equal to
GT	Greater than
LT	Less than
GOTO	Go to
UNDEFINED	Undefined
DEFINED	Defined

Jump conditions

Unconditional jump

An unconditional jump is programmed by entering a conditional jump whose condition is always true. Example:

FN 9: IF+10 EQU+10 GOTO LBL1

You can use such jumps, for example, in a called NC program in which you work with subprograms. In an NC program without **M30** or **M2**, you can prevent the control from executing subprograms without a call with **LBL CALL**. As the jump address, program a label that is located directly before the program end.

Conditioning jumps with counters

The jump function allows you to repeat a machining operation any number of times. A Q parameter serves as a counter that increments by 1 at every program section repeat.

The jump function allows you to compare the counter with the number of desired machining operations.



These jumps differ from the subprogram and program section repeat programming techniques.

On the one hand, for example, jumps require no completed program section ending with LBL 0. On the other hand, jumps do not take these return jump labels into consideration!

Example

0 BEGIN PGM COUNTER MM	
1;	
2 Q1 = 0	Loaded value: Initialize counter
3 Q2 = 3	Loaded value: Number of jumps
4;	
5 LBL 99	Label
6 Q1 = Q1 + 1	Initialize counter: New Q1 value = Old Q1 value + 1
7 FN 12: IF +Q1 LT +Q2 GOTO LBL 99	Run program jumps 1 and 2
8 FN 9: IF +Q1 EQU +Q2 GOTO LBL 99	Run program jump 3
9;	
10 END PGM COUNTER MM	

Programming if-then decisions

Possibilities for jump inputs

The following inputs are possible for the condition ${\bf IF}$:

- Numbers
- Texts
- Q, QL, QR
- **QS** (string parameter)

You have three possibilities for entering the jump address **GOTO**:

- LBL NAME
- LBL NUMBER
- QS

The if-then decisions appear when the **JUMP** soft key is pressed. The control displays the following soft keys:

Soft key	Function
FN9 IF X EQ Y GOTO	FN 9: jump if equal
	Example: FN 9: IF +Q1 EQU +Q3 GOTO LBL "UPCAN25"
EQU	If both values are equal, the control jumps to the defined label.
FN9	FN 9: jump if undefined
IF X EQ Y GOTO	Example: FN 9: IF +Q1 IS UNDEFINED GOTO LBL "UPCAN25"
IS UNDEFINED	If the variable is undefined, the control jumps to the defined label.
FN9 IF X EQ Y GOTO IS DEFINED	FN 9: jump if defined
	Example: FN 9: IF +Q1 IS DEFINED GOTO LBL "UPCAN25"
	If the variable is defined, the control jumps to the defined label.
FN10	FN 10: jump if not equal
IF X NE Y GOTO	Example: FN 10: IF +10 NE -Q5 GOTO LBL 10
	If both values are not equal, the control jumps to the defined label.
FN11 IF X GT Y	FN 11: jump if greater than
GOTO	Example: FN 11: IF+Q1 GT+10 GOTO LBL QS5
	If the first value is greater than the second value, the control jumps to the defined label.
FN12	FN 12: jump if less than
GOTO	Example: FN 12: IF+Q5 LT+0 GOTO LBL "ANYNAME"
	If the first value is less than the second value, the control jumps to the defined label.

9.7 Entering formulas directly

Entering formulas

Using soft keys, you can enter mathematical formulas containing multiple calculation operations directly into the NC program.



Select Q parameter function



- Press the FORMULA soft key
- Select Q, QL, or QR
- > The control displays the available mathematical operations in the soft-key row.

Calculation rules

Evaluation order for different operators

If a formula includes arithmetic operations involving a combination of different operators, the control evaluates the operations in a certain order. A familiar example of this is the rule that multiplication/division takes precedence over addition/subtraction (higher-level operations are performed first).

The control evaluates the arithmetic operations in the following order:

Order	Arithmetic operation	Operator	Arithmetic operator
1	Perform operations in parentheses first	Parentheses	()
2	Note the algebraic sign	Algebraic sign	-
3	Calculate functions	Function	SIN, COS, LN, etc.
4	Exponentiation	Power	^
5	Multiplication and division	Point	*, /
6	Addition and subtraction	Line	+, -

Order in the evaluation of equivalent operators

The control evaluates arithmetic operations with equivalent operators from left to right.

Example: 2 + 3 - 2 = (2 + 3) - 2 = 3

Exception: Concatenated powers are evaluated from right to left.

Example: $2^3 - 2 = 2^3 + 2 = 2^3 =$

Example: Perform multiplication/division before addition/subtraction

12 Q1 = 5 * 3 + 2 * 10

= 35

- 1st calculation: 5 * 3 = 152nd calculation: 2 * 10 = 20
- 3rd calculation: 15 + 20 = 35

Example: Calculate power before addition/subtraction

13 Q2 = SQ 10 - 3³

= 73

- 1st calculation: 10 squared = 100
- 2nd calculation: 3 to the power of 3 = 27
- 3rd calculation: 100 27 = 73

Example: Calculate function before power

14 Q4 = SIN 30 ^ 2

= 0.25

- 1st calculation: Calculate sine of 30 = 0.5
- 2nd calculation: 0.5 squared = 0.25

Example: Evaluate expression in parentheses before function

15 Q5 = SIN (50 - 20)

= 0.5

- 1st calculation: Perform operations in parentheses first: 50 20 = 30
- 2nd calculation: Calculate sine of 30 = 0.5

Overview

The control displays the following soft keys:

Soft key	Logical function	Operator
	Addition	Line
•	Example: Q10 = Q1 + Q5	
	Subtraction	Line
	Example: Q25 = Q7 - Q108	
	Multiplication	Point
	Example: Q12 = 5 * Q5	
,	Division	Point
,	Example: Q25 = Q1 / Q2	
,	Open parenthesis	Expression in parentheses
(Example: Q12 = Q1 * (Q2 + Q3)	
	Close parenthesis	Parentheses
	Example: Q12 = Q1 * (Q2 + Q3)	
SQ	Square (square)	Function
SU	Example: Q15 = SQ 5	
SQRT	Calculate square root (square root)	Function
SURT	Example: Q22 = SQRT 25	
SIN	Calculate sine	Function
	Example: Q44 = SIN 45	
cos	Calculate cosine	Function
COS	Example: Q45 = COS 45	
TAN	Calculate tangent	Function
IAN	Example: Q46 = TAN 45	
ASIN	Calculate arcsine	Function
ASIN	Inverse function of sine	
	The control determines the angle from the ratio of the opposite side	
	to the hypotenuse. Example: Q10 = ASIN (Q40 / Q20)	
	Calculate arccosine	Function
ACOS	Inverse function of cosine	i unction
	The control determines the angle from the ratio of the adjacent side	
	to the hypotenuse.	
	Example: Q11 = ACOS Q40	
ATAN	Calculate arctangent	Function
ATAN	Inverse function of tangent	
	The control determines the angle from the ratio of the opposite side	
	to the adjacent side.	
	Example: Q12 = ATAN Q50	D
A	Exponentiation	Power
	Example: Q15 = 3 ^ 3	

Soft key	Logical function	Operator
PI	Use the "pi" constant	
F1	$\pi = 3.14159$	
	Example: Q15 = PI	
LN	Calculate the natural logarithm (LN)	Function
	Base = e = 2.7183	
	Example: Q15 = LN Q11	
LOG	Calculate the logarithm	Function
	Base = 10	
	Example: Q33 = LOG Q22	
EXP	Use the exponential function (e ^ n)	Function
	Base = e = 2.7183	
	Example: Q1 = EXP Q12	
NEG	Negate	Function
	Multiply by −1	
	Example: Q2 = NEG Q1	
INT	Calculate an integer	Function
	Truncate decimal places	
	Example: Q3 = INT Q42	
	The INT function does not round off—it simply truncates]
	the declinal places.	
	Further information: "Example: Rounding a value", Page 365	
	raye 303	
	Calculate the absolute value	Function
ABS	Example: Q4 = ABS Q22	
	Calculate a fraction	Function
FRAC	Truncate the digits before the decimal point	
	Example: Q5 = FRAC Q23	
001	Check the algebraic sign	Function
SGN	Example: Q12 = SGN Q50	
	If Q50 = 0 , then SGN Q50 = 0	
	If Q50 < 0, then SGN Q50 = -1	
	If Q50 > 0 , then SGN Q50 = 1	
	Calculate the modulo value (division remainder)	Function
%	Example: Q12 = 400 % 360 Result: Q12 = 40	

Example: Trigonometric function

The lengths of the opposite side a in parameter **Q12** and the adjacent side b in **Q13** are given.

The angle α is to be calculated.

Calculate the angle α from the opposite side a and the adjacent side b by means of the arc tangent; assign result **Q25**:



▶ Press the **Q** key



- ▶ Press the **FORMULA** soft key
- > The control asks you for the number of the result parameter.
- ► Enter **25**



▶ Press the **ENT** key



Scroll through the soft-key row



Press the ATAN arc tangent function soft key



Scroll through the soft-key row



Press the Opening parenthesis soft key



► Enter **12** (the parameter number)



Select division



Enter 13 (the parameter number)




▶ Press the **Closing parenthesis** soft key



▶ Press the **END** key to conclude the formula entry

Example

37 Q25 = ATAN (Q12/Q13)



9.8 Checking and changing Q parameters

Procedure

You can check Q parameters in all operating modes, and also edit them.

► If needed, interrupt the program run (e.g., by pressing the **NC STOP** key and the **INTERNAL STOP** soft key), or stop the test run



- ➤ To call the Q parameter functions, press the Q INFO soft key or the Q key
- The control lists all of the parameters and their corresponding current values.
- Use the arrow keys or the GOTO key to select the desired parameter.
- ▶ If you want to change the value, then press the EDIT FIELD soft key, enter the new value, and confirm with the ENT key
- If you want to leave the value unchanged, then press the PRESENT VALUE soft key or close the dialog with the END key



If you want to check or edit local, global or string parameters, press the **SHOW PARAMETERS Q QL QR QS** soft key. The control then displays the specific parameter type. The functions previously described also apply.

While the control is executing an NC program, you cannot edit the variables using the **Q parameter list** window. Changes are only possible while a program run has been interrupted or aborted.


Further information: User's Manual for **Setup, Testing and Running NC Programs**

This status is reached after an NC block has been executed, for example in the **Program run, single block** mode

The following Q and QS parameters cannot be edited in the **Q parameter list** window:

- Variable range from 100 to 199, because there might be interferences with special functions in the control.
- Variable range from 1200 to 1399, because there might be interferences with machine manufacturer-specific functions.

All of the parameters with displayed comments are used by the control within cycles or as transfer parameters.





You can have Q parameters also be displayed in the additional status display in all operating modes (except **Programming** mode).

▶ If needed, interrupt the program run (e.g., by pressing the NC STOP key and the INTERNAL STOP soft key), or stop the test run



Display the soft key row for screen layout



- Select the layout option for the additional status display
- > In the right half of the screen, the control shows the **Overview** status form.
- ▶ Press the **STATUS OF Q PARAM.** soft key



PARAMETER

- ▶ Press the **Q PARAMETER LIST** soft key
- > The control opens a pop-up window.
- ► For each parameter type (Q, QL, QR, QS), define the parameter numbers you wish to check. Separate single Q parameters with a comma, and connect sequential Q parameters with a hyphen, e.g. 1,3,200-208. The input range per parameter type is 132 characters



The display in the **QPARA** tab always contains eight decimal places. The result of **Q1 = COS 89.999** is shown by the control as 0.00001745, for example. Very large or very small values are displayed by the control in exponential notation. The result of **Q1 = COS 89.999 * 0.001** is shown by the control as +1.74532925e-08, where e-08 corresponds to the factor of 10-8.

9.9 Additional functions

Overview

The additional functions appear when the **DIVERSE FUNCTION** soft key is pressed. The control displays the following soft keys:

Soft key	Function	Page
FN14 ERROR=	FN 14: ERROR Display error messages	302
FN16 F-PRINT	FN 16: F-PRINT Formatted output of texts or Q parameter values	308
FN18 SYS-DATUM READ	FN 18: SYSREAD Read system data	317
FN19 PLC=	FN 19: PLC Transfer values to the PLC	318
FN20 WAIT FOR	FN 20: WAIT FOR NC and PLC synchronization	319
FN26 OPEN TABLE	FN 26: TABOPEN Open a freely definable table	443
FN27 WRITE TO TABLE	FN 27: TABWRITE Write to a freely definable table	443
FN28 READ FROM TABLE	FN 28: TABREAD Read from a freely definable table	445
FN29 PLC LIST=	FN 29: PLC Transfer up to eight values to the PLC	320
FN37 EXPORT	FN 37: EXPORT Export local Q parameters or QS parameters to a calling NC program	320
FN38 SEND	FN 38: SEND Send information from the NC program	321

FN 14: ERROR output of error messages

With the **FN 14: ERROR** function, you can output error messages under program control. The messages are predefined by the machine manufacturer or by HEIDENHAIN.

If, during program run or during simulation, the control executes the **FN 14: ERROR** function, it will interrupt program run and display the defined message. You must then restart the NC program.

Error number range	Error message	
0 999	Machine-dependent dialog	
1000 1199	Control-dependent dialog	

Example

The control is intended to display a message if the spindle is not switched on.

180 FN 14: ERROR = 1000

The following is a complete list of the **FN 14: ERROR** error messages. Please be aware that not all error messages might be available, depending on the model of your control.

Error message predefined by HEIDENHAIN

Error number	Text
1000	Spindle?
1001	Tool axis is missing
1002	Tool radius too small
1003	Tool radius too large
1004	Range exceeded
1005	Start position incorrect
1006	ROTATION not permitted
1007	SCALING FACTOR not permitted
1008	MIRROR IMAGE not permitted
1009	Datum shift not permitted
1010	Feed rate is missing
1011	Input value incorrect
1012	Incorrect sign
1013	Entered angle not permitted
1014	Touch point inaccessible
1015	Too many points
1016	Contradictory input
1017	CYCL incomplete
1018	Plane wrongly defined
1019	Wrong axis programmed
1020	Wrong rpm
1021	Radius comp. undefined

Error number	Text
1022	Rounding-off undefined
1023	Rounding radius too large
1024	Program start undefined
1025	Excessive nesting
1026	Angle reference missing
1027	No fixed cycle defined
1028	Slot width too small
1029	Pocket too small
1030	Q202 not defined
1031	Q205 not defined
1032	Q218 must be greater than Q219
1033	CYCL 210 not permitted
1034	CYCL 211 not permitted
1035	Q220 too large
1036	Q222 must be greater than Q223
1037	Q244 must be greater than 0
1038	Q245 must not equal Q246
1039	Angle range must be under 360°
1040	Q223 must be greater than Q222
1041	Q214: 0 not permitted
1042	Traverse direction not defined
1043	No datum table active
1044	Position error: center in axis 1
1045	Position error: center in axis 2
1046	Hole diameter too small
1047	Hole diameter too large
1048	Stud diameter too small
1049	Stud diameter too large
1050	Pocket too small: rework axis 1
1051	Pocket too small: rework axis 2
1052	Pocket too large: scrap axis 1
1053	Pocket too large: scrap axis 2
1054	Stud too small: scrap axis 1
1055	Stud too small: scrap axis 2
1056	Stud too large: rework axis 1
1057	Stud too large: rework axis 2
1058	TCHPROBE 425: length exceeds max
1059	TCHPROBE 425: length below min
1060	TCHPROBE 426: length exceeds max

Error number	Text
1061	TCHPROBE 426: length below min
1062	TCHPROBE 430: diameter too large
1063	TCHPROBE 430: diameter too small
1064	No measuring axis defined
1065	Tool breakage tolerance exceeded
1066	Enter Q247 unequal to 0
1067	Enter Q247 greater than 5
1068	Datum table?
1069	Enter Q351 unequal to 0
1070	Thread depth too large
1071	Missing calibration data
1072	Tolerance exceeded
1073	Block scan active
1074	ORIENTATION not permitted
1075	3-D ROT not permitted
1076	Activate 3-D ROT
1077	Enter depth as negative
1078	Q303 in meas. cycle undefined!
1079	Tool axis not allowed
1080	Calculated values incorrect
1081	Contradictory meas. points
1082	Incorrect clearance height
1083	Contradictory plunge type
1084	This fixed cycle not allowed
1085	Line is write-protected
1086	Oversize greater than depth
1087	No point angle defined
1088	Contradictory data
1089	Slot position 0 not allowed
1090	Enter an infeed not equal to 0
1091	Switchover of Q399 not allowed
1092	Tool not defined
1093	Tool number not permitted
1094	Tool name not permitted
1095	Software option not active
1096	Kinematics cannot be restored
1097	Function not permitted
1098	Contradictory workpc. blank dim.
1099	Measuring position not allowed

Error number	Text
1100	Kinematic access not possible
1101	Meas. pos. not in traverse range
1102	Preset compensation not possible
1103	Tool radius too large
1104	Plunging type is not possible
1105	Plunge angle incorrectly defined
1106	Angular length is undefined
1107	Slot width is too large
1108	Scaling factors not equal
1109	Tool data inconsistent
1110	MOVE not possible
1111	Presetting not allowed!
1112	Thread angle too small!
1113	3-D ROT status is contradictory!
1114	Configuration is incomplete
1115	No turning tool is active
1116	Tool orientation is inconsistent
1117	Angle not possible!
1118	Radius too small!
1119	Thread runout too short!
1120	Contradictory meas. points
1121	Too many limits
1122	Machining strategy with limits not possible
1123	Machining direction not possible
1124	Check the thread pitch!
1125	Angle cannot be calculated
1126	Eccentric turning not possible
1127	No milling tool is active
1128	Insufficient length of cutting edge
1129	Gear definition is inconsistent or incomplete
1130	No finishing allowance provided
1131	Line does not exist in table
1132	Probing process not possible
1133	Coupling function not possible
1134	Machining cycle is not supported by this NC software
1135	Touch probe cycle is not supported by this NC software
1136	NC program aborted

Error number	Text
1137	Touch probe data incomplete
1138	LAC function not possible
1139	Rounding radius or chamfer is too large!
1140	Axis angle not equal to tilt angle
1141	Character height not defined
1142	Excessive character height
1143	Tolerance error: Workpiece rework
1144	Tolerance error: Workpiece scrap
1145	Faulty dimension definition
1146	Illegal entry in compensation table
1147	Transformation not possible
1148	Tool spindle incorrectly configured
1149	Offset of the turning spindle unknown
1150	Global program settings are active
1151	Faulty configuration of OEM macros
1152	The combination of programmed oversizes is not possible
1153	Measured value not captured
1154	Check the monitoring of the tolerance
1155	Hole is smaller than the stylus tip
1156	Preset cannot be set
1157	Alignment of a rotary table is not possible
1158	Alignment of rotary axes is not possible
1159	Infeed limited to length of cutting edge
1160	Machining depth defined as 0
1161	Tool type is unsuitable
1162	Finishing allowance not defined
1163	Machine datum could not be written
1164	Spindle for synchronization could not be ascertained
1165	Function is not possible in the active operating mode
1166	Oversize defined too large
1167	Number of teeth not defined
1168	Machining depth does not increase monotonously
1169	Infeed does not decrease monotonously
1170	Tool radius not defined correctly
1171	Mode for retraction to clearance height not possible
-	Gear wheel definition incorrect

	Tana
Error number	Text
1173	Probing object contains different types of dimension definition
1174	Dimension definition contains impermissible characters
1175	Actual value in dimension definition faulty
1176	Starting point of hole too deep
1177	Dimension def.: Nominal value missing for manual pre-positioning
1178	A replacement tool is not available
1179	OEM macro is not defined
1180	Measurement not possible with auxiliary axis
1181	Start position not possible with modulo axis
1182	Function only possible if door is closed
1183	Number of possible records exceeded
1184	Inconsistent machining plane due to axis angle with basic rotation
1185	Transfer parameter contains an impermissible value
1186	Tooth width RCUTS is defined too large
1187	Usable length LU of the tool is too small
1188	The defined chamfer is too large
1189	Chamfer angle cannot be machined with the active tool
1190	The allowances do not define any stock removal
1191	Spindle angle not unique

FN 16: F-PRINT – Formatted output of text and Q parameter values

Fundamentals

With the function **FN 16: F-PRINT**, you can output formatted fixed and variable numbers and texts (e.g., in order to save measuring logs).

You can output the values as follows:

- Save them to a file on the control
- Display them in a window on the screen
- Save them to a file on an external drive or USB device
- Print them to a connected printer

Procedure

In order to output fixed or variable numbers and texts, the following is required:

Source file

The source file determines the contents and formatting.

■ NC function FN 16: F-PRINT

The control creates the output file using the NC function ${\bf FN}$ 16.

The maximum size of the output file is 20 kB.

Creating a text file

In order to output formatted text and the values of the Q parameters, use the control's text editor to create a text file. In this file, you can define the format and Q parameters to be output.

Proceed as follows:



► Press the **PGM MGT** key



- ▶ Press the **NEW FILE** soft key
- ► Create a file with the extension .A

Available functions

Use the following formatting functions for creating a text file:



Please note that the input is case-sensitive.

Formatting characters	Function	
	Identifies the formatting of the contents to be output	
	For text output, you can use the UTF-8 character set.	
%F , %D or %I	Initiate the formatted output of Q, QL and QR parameters • F: Float (32-bit floating-point number)	
	 D: Double (64-bit floating-point number) I: Integer (32-bit integer) 	

Formatting characters	Function
9.3	Define the number of digits for the output of numerical values
	9: Total number of digits, including decimal separator
	3: Number of decimal places
%S or %RS	Initiate the formatted or unformatted output of a QS parameter
	■ S : String
	■ RS : Raw String
	The control takes over the following text without any changes and formatting.
,	Separate the input within a source file line (e.g., data type and variable)
;	End of the source file line
*	Initiate a comment line within the source file
	Comments are not included in the output file
%"	Output quotation marks in the output file
%%	Output a percentage sign in the output file
//	Output a backslash in the output file
\n	Output a line break in the output file
+	Output the variable value right-aligned in the output file
-	Output the variable value left-aligned in the output file

Example

Input	Meaning
"X1 = %+9.3 F", Q31;	Format for the Q parameter:
	X1 =: Output the text X1 =
	%: Specify the format
	+: Number right-aligned
	9.3: Total of 9 characters;3 of them are decimal places
	F: Floating (decimal number)
	Q31: Output the value from Q31
	■ ;: End of block

The following functions allow you to include the following additional information in the protocol log file:

Keyword	Function
CALL_PATH	Output the path name of the NC program that contains the FN 16 function (e.g., "TouchProbe: %S",CALL_PATH;)
M_CLOSE	Close the file written to with FN 16
M_APPEND	Upon renewed output, append the contents of the output file to the existing output file
M_APPEND_MAX	Upon renewed output, append the contents of the output file to the existing output file until the maximum file size of 20 kB is reached (e.g., M_APPEND_MAX20;)
M_TRUNCATE	Upon renewed output, overwrite the output file
M_EMPTY_HIDE	Do not output blank lines for undefined or empty QS parameters in the output file
M_EMPTY_SHOW	Output blank lines for undefined or empty QS parameters and reset M_EMPTY_HIDE
L_ENGLISH	Outputs text only for English conversational language
L_GERMAN	Outputs text only for German conversational language
L_CZECH	Outputs text only for Czech conversational language
L_FRENCH	Outputs text only for French conversational language
L_ITALIAN	Outputs text only for Italian conversational language
L_SPANISH	Outputs text only for Spanish conversational language
L_PORTUGUE	Outputs text only for Portuguese conversational language
L_SWEDISH	Outputs text only for Swedish conversational language
L_DANISH	Outputs text only for Danish conversational language
L_FINNISH	Outputs text only for Finnish conversational language
L_DUTCH	Outputs text only for Dutch conversational language
L_POLISH	Outputs text only for Polish conversational language
L_HUNGARIA	Outputs text only for Hungarian conversational language
L_RUSSIAN	Outputs text only for Russian conversational language
L_CHINESE	Outputs text only for Chinese conversational language

Keyword	Function
L_CHINESE_TRAD	Outputs text only for Chinese (traditional) conversational language
L_SLOVENIAN	Outputs text only for Slovenian conversational language
L_KOREAN	Outputs text only for Korean conversational language
L_NORWEGIAN	Outputs text only for Norwegian conversational language
L_ROMANIAN	Outputs text only for Romanian conversational language
L_SLOVAK	Outputs text only for Slovakian conversational language
L_TURKISH	Outputs text only for Turkish conversational language
L_ALL	Display text independently of the conversational language
HOUR	Output the hours of the current time
MIN	Output the minutes of the current time
SEC	Output the seconds of the current time
DAY	Output the day of the current date
MONTH	Output the month of the current date
STR_MONTH	Output the month of the current date in short form
YEAR2	Output the year of the current date in two- digit format
YEAR4	Output the year of the current date in four- digit format

Example

Example of a text file to define the output format:

```
"MEASURING LOG OF IMPELLER CENTER OF GRAVITY";
```

"DATE: %02d.%02d.%04d", DAY, MONTH, YEAR4;

"TIME: %02d:%02d:%02d",HOUR,MIN,SEC;

"NO. OF MEASURED VALUES: = 1";

"X1 = %9.3F", Q31;

"Y1 = %9.3F", Q32;

"Z1 = %9.3F", Q33;

L_GERMAN;

"Werkzeuglänge beachten";

L_ENGLISH;

"Remember the tool length";

Example

Example of a source file that generates an output file with variable content:

"TOUCHPROBE";

```
"%S",QS1;
M_EMPTY_HIDE;
"%S",QS2;
"%S",QS3;
M_EMPTY_SHOW;
"%S",QS4;
M_CLOSE;
```

Example of an NC program that defines only **QS3**:

11 Q1 = 100	; Assign the value 100 to Q1
12 QS3 = "Pos 1: " TOCHAR(DAT+Q1)	; Convert the numerical value of Q1 to an alphanumeric value and assign it to the defined string
13 FN 16: F-PRINT TNC: \fn16.a / SCREEN:	; Display the output file with FN 16 on the control screen

Example of a screen output with two empty lines resulting from ${\bf QS1}$ and ${\bf QS4}$:



Activating FN 16 output in an NC program

Use the function FN 16 to define the output file.

The control creates the output file in the following cases:

- End of program END PGM
- Cancellation of program with the NC STOP key
- **M_CLOSE** keyword in the source file

Enter the path to the text file and the path to the output file in the FN 16 function.

Proceed as follows:



Press the Q key.



▶ Press the **DIVERSE FUNCTION** soft key



▶ Press the FN16 F-PRINT soft key



- ▶ Press the **SELECT FILE** soft key
- Select the source, i.e. the text file in which the output file is defined



- ► Confirm with the **ENT** key
- Select the target, i.e. the output path

There are two ways to define the output path:

- Directly in the **FN 16** function
- In the machine parameters, under **CfgUserPath** (no. 102200)



If the called file is located in the same directory as the file you are calling it from, you can also integrate the file name without the path. The **APPLY FILE NAME** soft key provided in the selection window of the **SELECT FILE** soft key is available for this.

Specifying the path in the FN 16 function

If you enter only the file name as the path for the log file, the control saves the log file in the directory in which the NC program with the **FN 16** function is located.

As an alternative to complete paths, you can program relative paths:

- Starting from the folder of the calling file one folder level down FN 16: F-PRINT MASKE\MASKE1.A/ PROT\PROT1.TXT
- Starting from the folder of the calling file one folder level up and in another folder FN 16: F-PRINT ..\MASKE\MASKE1.A/ .. \PROT1.TXT

Use the **SYNTAX** soft key to place paths within quotation marks. The quotation marks define the beginning and the end of the path. This enables the control to identify any special characters as a part of the path.

Further information: "File names", Page 109

If the complete path is enclosed in quotation marks, you can use both \ and \forall to separate the folders and files.



Operating and programming notes:

- If you define a path both in the machine parameters and in the FN 16 function, the path in the FN 16 function has priority.
- If you output the same file more than once in the NC program, the control appends the current output to the end of the contents of the output file.
- In the **FN 16** block, program the format file and the log file, each with the extension for the file type.
- The file name extension of the log file determines the file type of the output (e.g., TXT, A, XLS, HTML).
- Use FN 18 to retrieve information that is relevant and interesting in log files, such as the number of the touchprobe cycle last used.

Further information: "FN 18: SYSREAD – Reading system data", Page 317

Defining the output path in machine parameters

If you wish to save the measurement results to a certain directory, you can define the output path for the log file in the machine parameters.

To change the output path:



- ► Press the **MOD** key
- ▶ Enter the code number 123



► Select the machine parameter **CfgUserPath** (no. 102200)



- ► Select the machine parameter **fn16DefaultPath** (no. 102202)
- > The control opens a pop-up window.
- Select the output path for the machine operating modes



- Select the machine parameter fn16DefaultPathSim (no. 102203)
- > The control opens a pop-up window.
- Select the output path for the Programming and Test Run operating modes

Enter the source or the target with parameters

You can enter the paths of the source and the output files as variable values. For this purpose, the desired variables must have been defined in the NC program.

Further information: "Assigning string parameters", Page 324 If you want to define variable paths, use the following syntax to enter the QS parameters:

Syntax element	Meaning
:'QS1'	Enter QS parameters with a preceding colon and between single quotation marks
:'QL3'.txt	Specify the file name extension of the target file, if required



If you want use a QS parameter to output a path to a log file, then use the function **%RS**. This ensures that the control does not interpret the special characters as formatting characters.

Example

96 FN 16: F-PRINT TNC:\MASKE\MASKE1.A/ TNC:\PROT1.TXT

The control creates the PROT1.TXT file:

MEASURING LOG OF IMPELLER CENTER OF GRAVITY

DATE: 15.07.2015 TIME: 08:56:34

NO. OF MEASURED VALUES: = 1

X1 = 149.360 Y1 = 25.509

Z1 = 37.000

Remember the tool length

Displaying messages on the control screen

You can use the **FN 16** function to display messages in a window on the control screen. This allows you to display explanatory texts in such a way that the user cannot continue without reacting to them. The contents of the output text and the position in the NC program can be chosen freely. You can also output variable values.

In order to display the message on the control screen, enter **SCREEN:** as the output path.

Example

11 FN 16: F-PRINT TNC:\MASKE-\WASKE1.A / SCREEN:

; Display the output file with **FN 16** on the control screen

If the message has more lines than can fit in the pop-up window, you can use the arrow keys to scroll through the window.



If you program the same output multiple times in the NC program, the control appends the current output to the end of the contents already output within the target file. If you want to overwrite the previous pop-up window, program the **M_CLOSE** or **M_TRUNCATE** keyword.

Closing the pop-up window

You can close the window in the following ways:

- By pressing the **CE** key
- Defining the SCLR: output path (Screen Clear)

Example

96 FN 16: F-PRINT TNC:\MASKE\MASKE1.A / SCLR:

You can also use the **FN 16: F-PRINT** function to close the pop-up window. In this case, no text file is required.

Example

96 FN 16: F-PRINT / SCLR:

Exporting messages

With the **FN 16** function, you can save the output files to a drive or a USB device.

To save the output file, define the path including the drive in the **FN 16** function.

Example

11 FN 16: F-PRINT TNC:\MSK-\MSK1.A / PC325:\LOG-\PRO1.TXT ; Save output file with FN 16



If you program the same output multiple times in the NC program, the control appends the current output to the end of the contents already output within the target file.

Printing messages

You can use the **FN 16** function to print output files to a connected printer.



The connected printer must be PostScript-enabled.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

The control will only print the output file if the source file ends with the **M_CLOSE** keyword.

To use the default printer, enter **Printer:**\ as the target path and a file name.

If you do not use the default printer, enter the path to the respective printer (e.g., **Printer:\PR0739**) and a file name.

The control saves the file using the defined file name and the defined path. The control will not print the file name.

The control saves the file temporarily until printing is complete.

Example

11 FN 16: F-PRINT TNC:WASKE-WASKE1.A / PRINTER:-PRINT1 ; Print output file with ${\bf FN}~{\bf 16}$

FN 18: SYSREAD – Reading system data

With the **FN 18: SYSREAD** function, you can read system data and save them to Q parameters. The selection of the system datum occurs via a group number (ID no.), a system data number, and, if necessary, an index.



The read values of the function **FN 18: SYSREAD** are always output by the control in **metric** units regardless of the NC program's unit of measure.

As an alternative, you can use **TABDATA READ** to read out data from the active tool table. In this case, the control will automatically convert the table values to the unit of measure used in the NC program.

Further information: "System data", Page 622

Example: Assign the value of the active scaling factor for the Z axis to Q25.

55 FN 18: SYSREAD Q25 = ID210 NR4 IDX3

FN 19: PLC transferring values to PLC

NOTICE

Danger of collision!

Changes to the PLC can result in undesired behavior and serious errors (e.g., the control becomes inoperable). For this reason, access to the PLC is password-protected. This function allows HEIDENHAIN, the machine manufacturer, and third-party providers to communicate with the PLC from within an NC program. It is not recommended that machine operators or NC programmers use this function. There is risk of collision during the execution of the function and during the subsequent machining!

- Only use the function in consultation after checking with HEIDENHAIN, the machine manufacturer, or the third-party provider.
- ► Comply with the documentation from HEIDENHAIN, the machine manufacturer, and third-party providers

The **FN 19: PLC** function transfers up to two fixed or variable values to the PLC.

FN 20: WAIT FOR NC and PLC synchronization

NOTICE

Danger of collision!

Changes to the PLC can result in undesired behavior and serious errors (e.g., the control becomes inoperable). For this reason, access to the PLC is password-protected. This function allows HEIDENHAIN, the machine manufacturer, and third-party providers to communicate with the PLC from within an NC program. It is not recommended that machine operators or NC programmers use this function. There is risk of collision during the execution of the function and during the subsequent machining!

- Only use the function in consultation after checking with HEIDENHAIN, the machine manufacturer, or the third-party provider.
- ► Comply with the documentation from HEIDENHAIN, the machine manufacturer, and third-party providers

With the **FN 20: WAIT FOR** function, you can synchronize the NC and the PLC during program run. The control stops program run until the condition you specified in the **FN 20: WAIT FOR-** block has been met.

The **SYNC** function is used whenever you read system data (e.g., with **FN 18: SYSREAD**). The system data need to be synchronized with the current date and time. Use the **FN 20: WAIT FOR** to stop the look-ahead calculation. When the control encounters **FN 20**, it will only calculate the NC block after it has executed the NC block that contains **FN 20**.

Example: Pause internal look-ahead calculation, read current position in the X axis

11 FN 20: WAIT FOR SYNC	; Stop internal look-ahead calculation with FN 20
12 FN 18: SYSREAD Q1 = ID270 NR1 IDX1	; Determine the position of the X axis with FN 18

FN 29: PLC transferring values to the PLC

NOTICE

Danger of collision!

Changes to the PLC can result in undesired behavior and serious errors (e.g., the control becomes inoperable). For this reason, access to the PLC is password-protected. This function allows HEIDENHAIN, the machine manufacturer, and third-party providers to communicate with the PLC from within an NC program. It is not recommended that machine operators or NC programmers use this function. There is risk of collision during the execution of the function and during the subsequent machining!

- Only use the function in consultation after checking with HEIDENHAIN, the machine manufacturer, or the third-party provider.
- Comply with the documentation from HEIDENHAIN, the machine manufacturer, and third-party providers

The **FN 29: PLC** function transfers up to eight fixed or variable values to the PLC.

FN 37: EXPORT

NOTICE

Danger of collision!

Changes to the PLC can result in undesired behavior and serious errors (e.g., the control becomes inoperable). For this reason, access to the PLC is password-protected. This function allows HEIDENHAIN, the machine manufacturer, and third-party providers to communicate with the PLC from within an NC program. It is not recommended that machine operators or NC programmers use this function. There is risk of collision during the execution of the function and during the subsequent machining!

- Only use the function in consultation after checking with HEIDENHAIN, the machine manufacturer, or the third-party provider.
- ► Comply with the documentation from HEIDENHAIN, the machine manufacturer, and third-party providers

You need the **FN 37: EXPORT** function if you want to create your own cycles and integrate them in the control.

FN 38: SEND - Send information from the NC program

The function **FN 38: SEND** enables you to retrieve fixed or variable values from the NC program and write them to the log or send them to an external application (e.g., StateMonitor).

The syntax consists of two parts:

■ Format of transmitted text: Output text with optional placeholders for variable values (e.g., %f)



Input may be in the form of QS parameters. Both fixed and variable numbers and texts are casesensitive, so enter them correctly.

■ **Datum for placeholder in text**: List of up to seven Q, QL, or QR variables (e.g., **Q1**)

Data transmission is through a standard TCP/IP computer network.



For more detailed information, consult the RemoTools SDK manual.

Example

Document the values from Q1 and Q23 in the log.

FN 38: SEND /"Q-Parameter Q1: %f Q23: %f" / +Q1 / +Q23

Example

Define the output format for the variable values.

FN 38: SEND /"Q-Parameter Q1: %05.1f" / +Q1

> The control outputs the variable value as a five-digit number, of which one digit is a decimal place. The output will be padded with leading zeroes as needed.

FN 38: SEND /"Q-Parameter Q1: % 1.3f" / +Q1

> The control outputs the variable value as a seven-digit number, of which three digits are decimal places. The output will be padded with blank spaces as needed.



To obtain % in the output text, enter %% at the desired position.

Example

In this example, you will send information to StateMonitor.

With the function FN 38, you can, for example, enter job data.

The following requirements must be met in order to use this function:

- StateMonitor version 1.2
 Job management with JobTerminal (option 4) is possible with StateMonitor version 1.2 or higher
- The job has been entered in StateMonitor
- Machine tool has been assigned

The following stipulations apply to this example:

- Job number 1234
- Working step 1

FN 38: SEND /"JOB:1234_STEP:1_CREATE"	Create job
FN 38: SEND /"JOB:1234_STEP:1_CREATE_ITEMNAME: HOLDER_ITEMID:123_TARGETQ:20"	Alternative: Create job with part name, part number, and required quantity
FN 38: SEND /"JOB:1234_STEP:1_START"	Start job
FN 38: SEND /"JOB:1234_STEP:1_PREPARATION"	Start preparation
FN 38: SEND /"JOB:1234_STEP:1_PRODUCTION"	Production
FN 38: SEND /"JOB:1234_STEP:1_STOP"	Stop job
FN 38: SEND /"JOB:1234_STEP:1_ FINISH"	Finish job

You can also report the quantity of workpieces of the job.

With the **OK**, **S**, and **R** placeholders, you can specify whether the quantity of reported workpieces has been machined correctly or not.

With $\bf A$ and $\bf I$ you define how StateMonitor interprets the response. If you transfer absolute values, StateMonitor overwrites the previously valid values. If you transfer incremental values, StateMonitor increments the quantity.

FN 38: SEND /"JOB:1234_STEP:1_OK_A:23"	Actual quantity (OK) absolute
FN 38: SEND /"JOB:1234_STEP:1_OK_I:1"	Actual quantity (OK) incremental
FN 38: SEND /"JOB:1234_STEP:1_S_A:12"	Scrap (S) absolute
FN 38: SEND /"JOB:1234_STEP:1_S_I:1"	Scrap (S) incremental
FN 38: SEND /"JOB:1234_STEP:1_R_A:15"	Rework (R) absolute
FN 38: SEND /"JOB:1234_STEP:1_R_I:1"	Rework (R) incremental

9.10 String parameters

String processing functions

You can use the **QS** parameters to create variable character strings. You can output such character strings for example through the **FN 16:F-PRINT** function to create variable logs.

You can assign a linear sequence of characters (letters, numbers, special characters and spaces) up to a length of 255 characters to a string parameter. You can also check and process the assigned or imported values using the functions described below. As in Q parameter programming, you can use a total of 2000 QS parameters.

Further information: "Principle and overview of functions", Page 278 The **STRING FORMULA** and **FORMULA** Q parameter functions contain various functions for processing the string parameters.

Soft key	Functions of the STRING FORMULA	Page
DECLARE STRING	Assigning string parameters	324
CFGREAD	Read out the machine parameter values	333
STRING FORMULA	Chain-linking string parameters	325
TOCHAR	Converting a numerical value to a string parameter	326
SUBSTR	Copy a substring from a string parameter	327
SYSSTR	Read system data	328
Soft key	Formula string functions	Page
TONUMB	Converting a string parameter to a numerical value	329
INSTR	Checking a string parameter	330
STRLEN	Finding the length of a string parameter	331
STRCOMP	Compare alphabetic priority	332



If you use the **STRING FORMULA** function, the result is always an alphanumeric value. If you use the **FORMULA** function, the result is always an alphanumeric value.

Assigning string parameters

Before using string variables, you must first assign the variables. Use the **DECLARE STRING** command to do so.



▶ Press the **SPEC FCT** key



Press the PROGRAM FUNCTIONS soft key



▶ Press the **STRING FUNCTIONS** soft key



▶ Press the **DECLARE STRING** soft key

Example

11 DECLARE STRING QS10 = "workpiece"

; Assign alphanumeric value to **QS10**

Chain-linking string parameters

With the concatenation operator (string parameter | | string parameter) you can make a chain of two or more string parameters.



▶ Press the **SPEC FCT** key



Press the PROGRAM FUNCTIONS soft key



▶ Press the **STRING FUNCTIONS** soft key



ENT

- ▶ Press the **STRING FORMULA** soft key
- ► Enter the number of the string parameter in which the control is to save the concatenated string. Confirm with the **ENT** key.
- ► Enter the number of the string parameter in which the **first** substring is saved. Confirm with the **ENT** key
- > The control shows the concatenation symbol | |
- ▶ Press the **ENT** key
- Enter the number of the string parameter in which the **second** substring is saved. Confirm with the ENT key
- Repeat the process until you have selected all the required substrings. Conclude with the END key

Example: QS10 is to include the complete text of QS12 and QS13

11 QS10 = QS12 || QS13

; Concatenate contents of **QS12** and **QS13** and assign them to the QS parameter **QS10**

Parameter contents:

QS12: Status:

QS13: Scrap

QS10: Status: Scrap

Converting a numerical value to a string parameter

With the **TOCHAR** function, the control converts a numerical value into a string parameter. This enables you to chain numerical values with string variables.



Show the soft-key row with special functions



Open the function menu



Press the String functions soft key



▶ Press the **STRING FORMULA** soft key



- Select the function for converting a numerical value to a string parameter
- ► Enter the number or the desired Q parameter to be converted by the control, and confirm with the ENT key
- ▶ If desired, enter the number of digits after the decimal point that the control should convert, and confirm with the ENT key
- ► Close the parenthetical expression with the **ENT** key and confirm your entry with the **END** key

Example: Convert parameter Q50 to string parameter QS11, use 3 decimal places

11 QS11 = TOCHAR (DAT+Q50 DECIMALS3)

; Convert a numerical value from **Q50** to an alphanumeric value and assign it to the QS parameter **QS11**

Copying a substring from a string parameter

The **SUBSTR** function copies a definable range from a string parameter.



► Show the soft-key row with special functions



Open the function menu



Press the String functions soft key



- ▶ Press the **STRING FORMULA** soft key
- ► Enter the number of the string parameter in which the control is to save the character string. Confirm with the **ENT** key.



- Select the function for copying a substring
- Enter the number of the QS parameter from which the substring is to be copied. Confirm with the ENT key
- Enter the number of the place starting from which to copy the substring, and confirm with the ENT key
- ► Enter the number of characters to be copied, and confirm with the **ENT** key
- Close the parenthetical expression with the ENT key and confirm your entry with the END key



The first character of a text string starts internally at the 0-position

Example: A four-character substring (LEN4) is read from the string parameter QS10 beginning with the third character (BEG2)

11 QS13 = SUBSTR (SRC_QS10 BEG2 LEN4)

; Assign substring from **QS10** to the QS parameter **QS13**

Reading system data

With the **SYSSTR** NC function, you can read system data and save the contents in QS parameters. Select the system datum by means of a group number **(ID)** and a number **(NR)**.

Optionally, you can enter **IDX** and **DAT**.

Group name, ID no.	Number	Meaning
Program information, 10010	1	Path of the current main program or pallet program
	2	Path of the currently executed NC program
	3	Path of the NC program selected with Cycle 12 PGM CALL
	10	Path of the NC program selected with SEL PGM
Channel data, 10025	1	Name of the current channel (e.g., CH_NC)
Values programmed in the tool call, 10060	1	Current tool name
can, roocc		The NC function saves the tool name only if the tool has been called using its tool name.
Kinematics, 10290	10	Kinematics programmed in the last FUNCTION MODE NC function
Current system time, 10321	1 to 16, 20	■ 1: D.MM.YYYY h:mm:ss
		2: D.MM.YYYY h:mm
		3: D.MM.YY hh:mm
		4: YYYY-MM-DD hh:mm:ss
		5: YYYY-MM-DD hh:mm
		■ 6: YYYY-MM-DD h:mm
		■ 7: YY-MM-DD h:mm
		■ 8: DD.MM.YYYY
		■ 9: D.MM.YYYY
		■ 10: D.MM.YY
		■ 11: YYYY-MM-DD
		■ 12: YY-MM-DD
		■ 13: hh:mm:ss
		■ 14: h:mm:ss
		■ 15: h:mm
		■ 16: DD.MM.YYYY hh:mm
		 20: XX "XX" stands for the two-digit number of the current calendar week that—in accordance with ISO 8601—is characterized by the following:
		It comprises seven days
		It begins with Monday
		It is numbered sequentially
		The first calendar week (week 01) is the week with the first Thursday of the Gregorian year.
Touch-probe data, 10350	50	Type of the active TS workpiece touch probe
	70	Type of the active TT tool touch probe

Group name, ID no.	Number	Meaning
	73	Name of the active TT workpiece touch probe from the activeTT machine parameter
Data for pallet machining, 10510	1	Name of the pallet being machined
	2	Path of the currently selected pallet table
NC software version, 10630	10	Number of the NC software version
Information for unbalance cycle,	1	Path of the unbalance calibration table
10855		The unbalance calibration table is part of the active kinematics.
Tool data, 10950	1	Current tool name
	2	Content of the DOC column of the current tool
	3	AFC control settings of the current tool
	4	Tool-carrier kinematics of the current tool

Converting a string parameter to a numerical value

The **TONUMB** function converts a string parameter to a numerical value. The value to be converted should be only numerical.



The QS parameter to be converted must contain only one numerical value. Otherwise, the control will output an error message.



► Select Q parameter function



- ▶ Press the **FORMULA** soft key
- ▶ Enter the number of the string parameter in which the control is to save the numerical value. Confirm with the **ENT** key.



► Shift the soft-key row



- Select the function for converting a string parameter to a numerical value
- Enter the number of the QS parameter to be converted by the control, and confirm with the ENT key
- ► Close the parenthetical expression with the **ENT** key and confirm your entry with the **END** key

Example: Convert string parameter QS11 to a numerical parameter Q82

11 Q82 = TONUMB (SRC_QS11)

; Convert alphanumeric value from **Q511** to a numerical value and assign it to **Q82**

Testing a string parameter

The **INSTR** function checks whether (and where) a string parameter is contained in another string parameter.



Select Q parameter function



- Press the FORMULA soft key
- ► Enter the number of the Q parameter for the result and confirm with the **ENT** key
- > The control saves the place at which the text to be searched for begins. It is saved in the parameter.



► Shift the soft-key row



- Select the function for checking a string parameter
- ► Enter the number of the QS parameter in which the text to be searched for is saved. Confirm with the **ENT** key
- Enter the number of the QS parameter to be searched for by the control, and confirm with the ENT key
- ► Enter the number of the place at which the control is to start search the substring, and confirm with the **ENT** key.
- Close the parenthetical expression with the ENT key and confirm your entry with the END key



The first character of a text string starts internally at the 0-position

If the control cannot find the required substring, it will save the total length of the string to be searched (counting starts at 1) in the result parameter.

If the substring to be searched for appears multiple times, then the control returns the first place at which it finds the substring.

Example: Search through QS10 for the text saved in parameter QS13. Begin the search at the third place.

37 Q50 = INSTR (SRC_QS10 SEA_QS13 BEG2)

; Search ${\bf QS10}$ for substring from ${\bf QS13}$

Determining the length of a string parameter

The **STRLEN** function returns the length of the text saved in a selectable string parameter.



Select Q parameter function



- ▶ Press the **FORMULA** soft key
- ► Enter the number of the Q parameter in which the control is to save the determined string length, and confirm with the **ENT** key



► Shift the soft-key row



- Select the function for finding the text length of a string parameter
- Enter the number of the QS parameter whose length is to be determined, and confirm with the ENT key
- ► Close the parenthetical expression with the **ENT** key and confirm your input with the **END** key

Example: Find the length of QS15

11 Q52 = STRLEN (SRC_QS15)

; Determine the number of characters in **QS15** and assign it to **Q52**



If the selected QS parameter has not been defined, the control returns the value **-1**.

Comparing the lexical order of two alphanumerical strings

With the **STRCOMP** NC function, you can compare the lexical order of the content of two QS parameters.



Select Q parameter function



- ▶ Press the **FORMULA** soft key
- ► Enter the number of the Q parameter in which the control is to save the result of comparison, and confirm with the **ENT** key.



Shift the soft-key row



- Select the function for comparing string parameters
- Enter the number of the first QS parameter that the control is to compare, and confirm with the ENT key
- ► Enter the number of the second QS parameter that the control is to compare, and confirm with the **ENT** key
- Close the parenthetical expression with the ENT key and confirm your input with the END key



The control returns the following results:

- **0**: The content of the two parameters is identical
- -1: In the lexical order, the content of the first QS parameter comes **before** the content of the second QS parameter
- +1: In the lexical order, the content of the first QS parameter comes **after** the content of the second QS parameter

The lexical order is as follows:

- 1 Special characters (e.g., ?_)
- 2 Numerals (e.g., 123)
- 3 Uppercase letters (e.g., ABC)
- 4 Lowercase letters (e.g., abc)



Starting from the first character, the control proceeds until the contents of the QS parameters differ from each other. If the contents differ starting from, for example, the fourth digit, the control aborts the check at this point.

Shorter contents with identical strings are displayed first in the order (e.g., abc before abcd).

Example: Compare the lexical order of QS12 and QS14

11 Q52 = STRCOMP (SRC_QS12 SEA_QS14)

; Compare the lexical order of the values of **QS12** and **QS14**

Reading out machine parameters

With the **CFGREAD** NC function, you can read out machine parameter contents of the control as numerical or alphanumeric values. The read-out numerical values are always given in metric form.

To read a machine parameter, you need to determine the following contents in the configuration editor of the control:

lcon	Туре	Meaning	Example
⊕ <mark>K</mark>	Key	Group name of the machine parameter The group name can be specified optionally	CH_NC
⊕ <mark>£</mark>	Entity	Parameter object The name always begins with Cfg	CfgGeoCycle
	Attribute	Name of the machine parameter	displaySpindleErr
# ©	Index	List index of the machine parameter The list index can be specified optionally	[0]



You can change the display of the existing parameters in the configuration editor for the machine parameter. By default, the parameters are displayed with short, explanatory texts.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

Each time you want to read out a machine parameter with the **CFGREAD** NC function, you must first define a QS parameter with attribute, entity and key.

The control queries the following parameters in the **CFGREAD** NC function:

- **KEY_QS**: Group name (key) of the machine parameter
- TAG_QS: Object name (entity) of the machine parameter
- **ATR_QS**: Name (attribute) of the machine parameter
- **IDX**: Index of the machine parameter

Reading a numerical value of a machine parameter

Store the value of a machine parameter as a numerical value in a Q parameter:



► Select Q parameter function



- ▶ Press the **FORMULA** soft key
- ► Enter the number of the Q parameter in which the control is to save the machine parameter
- ► Press the **ENT** key
- ► Select the **CFGREAD** function
- ► Enter the numbers of the string parameters for key, entity, and attribute
- ▶ Press the **ENT** key
- ► Enter the number for the index, or skip the dialog with **NO ENT**, whichever applies
- Close the parenthesized expression with the ENT key
- ▶ Press the **END** key to conclude entry

Example: Read overlap factor as Q parameter

Parameter settings in the configuration editor

ChannelSettings

CH_NC

CfgGeoCycle

pocketOverlap

Example

11 QS11 = "CH_NC"	; Assign the key to the QS parameter QS11
12 QS12 = "CfgGeoCycle"	; Assign the entity to the QS parameter QS12
13 QS13 = "pocketOverlap"	; Assign the attribute to the QS parameter QS13
14 Q50 = CFGREAD(KEY_QS11 TAG_QS12 ATR_QS13)	Read out the contents of the machine parameter

9.11 Preassigned Q parameters

For example, the control assigns the following values to the Q parameters **Q100** to **Q199**:

- Values from the PLC
- Tool and spindle data
- Data on operating status
- Measurement results from touch-probe cycles

The control saves the values of the Q parameters **Q108** and **Q114** to **Q117** in the unit of measure used by the active NC program.

NOTICE

Danger of collision!

HEIDENHAIN cycles, manufacturer cycles and third-party functions use Q parameters. You can also program Q parameters within NC programs. If, when using Q parameters, the recommended Q parameter ranges are not used exclusively, then this can lead to overlapping (reciprocal effects) and thus cause undesired behavior. Danger of collision during machining!

- ▶ Only use Q parameter ranges recommended by HEIDENHAIN.
- ► Comply with the documentation from HEIDENHAIN, the machine tool builder, and suppliers.
- ▶ Check the machining sequence using a graphic simulation



Preassigned variables, such as Q and QS parameters in the range of 100 to 199, must not be used as calculated parameters in NC programs.

Values from the PLC: Q100 to Q107

The control assigns values from the PLC to the Q parameters ${\bf Q100}$ to ${\bf Q107}$.

Active tool radius: Q108

The control assigns the value of the active tool radius to the Q parameter **Q108**.

The active tool radius is calculated from the following values:

- Tool radius R from the tool table
- Delta value DR from the tool table
- Delta value DR from the NC program, if a compensation table or tool call is used

Further information: "Delta values for lengths and radii", Page 131



The control will remember the active tool radius even after a restart of the control.

Tool axis: Q109

The value of the Q parameter **Q109** depends on the current tool axis:

Q parameters	Tool axis
Q109 = -1	No tool axis defined
Q109 = 0	X axis
Q109 = 1	Y axis
Q109 = 2	Z axis
Q109 = 6	U axis
Q109 = 7	V axis
Q109 = 8	W axis

Spindle status: Q110

The value of the Q parameter **Q110** depends on the M function last activated for the spindle:

Q parameters	M function
Q110 = -1	No spindle status defined
Q110 = 0	M3
	Switch spindle on clockwise
Q110 = 1	M4
	Switch spindle on counterclockwise
Q110 = 2	M5 after M3
	Stop the spindle
Q110 = 3	M5 after M4
	Stop the spindle

Coolant on/off: Q111

The value of the Q parameter **Q111** depends on the M function for the coolant on/off function that was last activated:

Q parameters	M function
Q111 = 1	M8
	Switch coolant supply on
Q111 = 0	M9
	Switch coolant supply off

Overlap factor: Q112

The control assigns the overlap factor for pocket milling to the Q parameter ${\bf Q112}$.

Unit of measure in the NC program: Q113

The value of the Q parameter **Q113** depends on the unit of measure selected in the NC program. In case of program nesting with **PGM CALL**, the control uses the unit of measure defined for the main program:

Q parameters	Unit of measure of the main program
Q113 = 0	Metric system (mm)
Q113 = 1	Imperial system (inch)

Tool length: Q114

The control assigns the value of the active tool length to the Q parameter **Q114**.

The active tool length is calculated from the following values:

- Tool length **L** from the tool table
- Delta value **DL** from the tool table
- Delta value DL from the NC program, if a compensation table or tool call is used



The control remembers the active tool length even after a restart of the control.

Measurement result from programmable touch-probe cycles: Q115 to Q119

The control assigns the measurement result of a programmable touch-probe cycle to the following Q parameters.

For these Q parameters, the control does not take the radius and length of the stylus into account.



The help graphics of the touch-probe cycles show whether the control saves a measurement result in a variable or not.

The control assigns the coordinate axis values after probing to the Q parameters **Q115** to **Q119**:

Q parameters	Axis coordinates
Q115	TOUCH POINT IN X
Q116	TOUCH POINT IN Y
Q117	TOUCH POINT IN Z
Q118	TOUCH POINT 4TH AXIS (e.g., A axis)
	The machine manufacturer defines the 4th axis
Q119	TOUCH POINT 5TH AXIS (e.g., B axis)
	The machine manufacturer defines the 5th axis

Q parameters Q115 and Q116 for automatic tool measurement

The control assigns the deviation of the actual value from the nominal value in automatic tool measurements (e.g., with a TT 160) to the Q parameters **Q115** and **Q116**:

Q parameters	Deviation of actual from nominal value
Q115	Tool length
Q116	Tool radius



After probing, the Q parameters **Q115** and **Q116** might contain other values.

Calculated coordinates of the rotary axes: Q120 to Q122

The control assigns the calculated coordinates of the rotary axes to the Q parameters **Q120** to **Q122**:

Q parameters	Rotary axis coordinates
Q120	AXIS ANGLE IN THE A AXIS
Q121	AXIS ANGLE IN THE B AXIS
0122	AXIS ANGLE IN THE C AXIS

Measurement results from touch-probe cycles

Further information: User's Manual for **Programming of Measuring Cycles for Workpieces and Tools**

The control assigns the measured actual values to the Q parameters **Q150** to **Q160**:

Q parameters	Measured actual values
Q150	MEASURED ANGLE
Q151	ACTL. VALUE, REF AXIS
Q152	ACTL.VALUE, MINOR AXIS
Q153	ACTUAL VALUE, DIAMETER
Q154	ACT.VAL. PCKT REF AX.
Q155	ACT.VAL. PKT MINOR AX.
Q156	ACTUAL VALUE OF LENGTH
Q157	ACTL.VAL., CENTERLINE
Q158	Projectd. angle A axis
Q159	Projectd. angle B axis
Q160	COORD., MEASURING AXIS
	Coordinate of the axis selected in the cycle

The control assigns the calculated deviation values to the Q parameters **Q161** to **Q167**:

Q parameters	Calculated deviation	
Q161	ERROR, CENTR, REF AX.	
	Deviation of center in main axis	
Q162	ERROR, CENTR, MINOR AX	
	Deviation of center in the secondary axis	
Q163	ERROR OF DIAMETER	
Q164	ERROR, PCKT., REF AX.	
	Deviation of pocket length in the main axis	
Q165	ERROR, CENTR, MINOR AX	
	Deviation of pocket width in the secondary axis	
Q166	ERROR OF LENGTH	
	Deviation of the measured length	
Q167	ERROR OF CENTERLINE	
	Deviation of the centerline position	

The control assigns the determined spatial angle values to the Q parameters ${\bf Q170}$ to ${\bf Q172}$:

Q parameters	Determined spatial angles	
Q170	SPATIAL ANGLE A	
Q171	SPATIAL ANGLE B	
Q172	SPATIAL ANGLE C	

The control assigns the determined workpiece status to the Q parameters $\bf Q180$ to $\bf Q182$:

Q parameters	Workpiece status	
Q180	WORKPIECE IS GOOD	
Q181	WORKPIECE NEEDS REWORK	
Q182	WORKPIECE IS SCRAP	

The control reserves the Q parameters **Q190** to **Q192** for the results of tool measurements with a laser measuring system.

The control reserves the Q parameters ${\bf Q195}$ to ${\bf Q198}$ for internal use:

Q parameters	Reserved for internal use	
Q195	MARKER FOR CYCLES	
Q196	MARKER FOR CYCLES	
Q197 MARKER FOR CYCLES		
	Cycles with position pattern	
Q198	NO., LAST TCH-PRB CYC	
	Number of the last active touch-probe cycle	

The value of the Q parameter **Q199** depends on the status of tool measurement with a tool touch probe:

Q parameters	Status of tool measurement with a tool touch probe
Q199 = 0.0	Tool is within tolerance
Q199 = 1.0	Tool is worn (LTOL/RTOL is exceeded)
Q199 = 2.0	Tool is broken (LBREAK/RBREAK is exceeded)

Measurement results from 14xx touch-probe cycles

The control assigns the measured actual values resulting from the **14xx** touch-probe cycles to the Q parameters **Q950** to **Q967**:

Q parameters	Measured actual values	
Q950	P1 measured main axis	
Q951	P1 measured minor axis	
Q952	P1 measured tool axis	
Q953	P2 measured main axis	
Q954	P2 measured minor axis	
Q955	P2 measured tool axis	
Q956	P3 measured main axis	
Q957	P3 measured minor axis	
Q958	P3 measured tool axis	
Q961	Measured SPA	
	Spatial angle SPA in the working plane coordinate system WPL-CS	
Q962	Measured SPB	
	Spatial angle SPB in the WPL-CS	
Q963	Measured SPC	
	Spatial angle SPC in the WPL-CS	
Q964	Meas. basic rotation	
	Rotational angle in the input coordinate system I- CS	
Q965	Meas. table rotation	

Q parameters	Measured actual values	
Q966	Measured diameter 1	
Q967	Measured diameter 2	

The control assigns the calculated deviations resulting from the **14xx** touch-probe cycles to the Q parameters **Q980** to **Q997**:

Q parameters	Measured deviations	
Q980	P1 error main axis	
Q981	P1 error minor axis	
Q982	P1 error tool axis	
Q983	P2 error main axis	
Q984	P2 error minor axis	
Q985	P2 error tool axis	
Q986	P3 error main axis	
Q987	P3 error minor axis	
Q988	P3 error tool axis	
Q994	Error: basic rotation	
	Angle in the input coordinate system I-CS	
Q995	Meas. table rotation	
Q996	Error: diameter 1	
Q997	Error: diameter 2	

The value of the Q parameter **Q183** depends on the workpiece status as measured by the 14xx touch-probe cycles:

Q parameters	Workpiece status
Q183 = -1	Not defined
Q183 = 0	Pass
Q183 = 1	Rework
Q183 = 2	Scrap

Checking the setup situation: Q601

The value of the parameter **Q601** indicates the status of the camerabased monitoring of the VSC setup situation.

Parameter value	Status
Q601 = 1	No error
Q601 = 2	Error
Q601 = 3	No monitoring area defined or not enough reference images
0601 = 10	Internal error (no signal, camera error, etc.)

9.12 Accessing tables with SQL statements

Introduction

If you would like to access numerical or alphanumerical content in a table or manipulate the table (e.g., rename columns or rows), then use the available SQL commands.

The syntax of the SQL commands available on the control is strongly influenced by the SQL programming language but does not conform with it entirely. In addition, the control does not support the full scope of the SQL language.



The names of tables and table columns must start with a letter and must not contain an arithmetic operator (e.g., +). Due to SQL commands, these characters can cause problems when data are input or read.



Testing of the SQL functions is only possible in the **Program run, single block**, **Program run, full sequence**, and **Positioning with Manual Data Input** operating modes.



Read- and write-accesses to individual values in a table can likewise be carried out using the functions FN 26:

TABOPEN, FN 27: TABWRITE, and FN 28: TABREAD.

Further information: "Freely definable tables", Page 440

HEIDENHAIN recommends that you use SQL functions instead of FN 26, FN 27, or FN 28 in order to achieve maximum HDR hard-disk speeds for table applications and to reduce the amount of computing power used.

The following terms will be used (along with others) below:

- "SQL command" refers to the available soft keys
- "SQL statements" describe miscellaneous functions that are entered manually as part of the syntax
- A **HANDLE** in the syntax identifies a certain transaction (followed by the parameter for its identification)
- A **result set** contains the result of the query

SOL transaction

In the NC software, table accesses occur through an SQL server. This server is controlled via the available SQL commands. The SQL commands can be defined directly in an NC program.

The server is based on a transaction model. A **transaction** consists of multiple steps that are executed together, thereby ensuring that the table entries are processed in an orderly and well-defined manner.

Example of transaction:

- Assign Q parameters to table columns for read or write access using SQL BIND
- Select data using SQL EXECUTE with the SELECT instruction
- Read, change, or add data using SQL FETCH, SQL UPDATE, or SQL INSERT
- Confirm or discard interaction using SQL COMMIT or SQL ROLLBACK
- Approve bindings between table columns and Q parameters using SQL BIND



You must conclude all transactions that have been started —even exclusively reading accesses. Concluding the transaction is the only way to ensure that changes and additions are transferred, that locks are removed, and that used resources are released.

Result set and handle

The **result set** contains a subset of a table file. It results from a **SELECT** query performed on the table.

The **result set** is created when a query is executed in the SQL server, thereby occupying resources there.

This query has the same effect as applying a filter to the table, so that only part of the data records become visible. To perform this query, the table file must be read at this point.

The SQL server assigns a **handle** to the **result set**, which enables you to identify the result set for reading or editing data and completing the transaction. The **handle** shows the query result that is visible in the NC program. The value 0 indicates an **invalid handle**, i.e. it was not possible to create a **result set** for that query. If no rows are found that satisfy the specified condition, an empty **result set** is created and assigned a valid **handle**.

Programming SQL commands



This function is not enabled until the code number **555343** is entered.

You can program SQL commands in the **Programming** or **Positioning with MDI** operating modes:



▶ Press the **SPEC FCT** key



▶ Press the **PROGRAM FUNCTIONS** soft key



► Shift the soft-key row



- ► Press the **SQL** soft key
- Select the SQL command via soft key

NOTICE

Danger of collision!

Read and write accesses performed with the help of SQL commands always occur in metric units, regardless of the unit of measure selected for the table or the NC program.

If, for example, you save a length from a table to a Q parameter, then the value is thereafter always in metric units. If this value is

then the value is thereafter always in metric units. If this value is then used for the purpose of positioning in an inch program (**L X** +Q1800), then an incorrect position will result.

▶ In inch programs, convert the read value prior to use

Overview of functions

Overview of soft keys


The control offers the following ways of working with SQL commands:

Soft key	Function	Page
SQL	SQL BIND creates or disconnects a binding between table columns and Q or QS parameters	348
SQL EXECUTE	SQL EXECUTE opens a transaction for selected table columns and table rows or enables the use of other SQL instructions (miscellaneous functions).	349
SQL FETCH	SQL FETCH transfers the values to the bound Q parameters	353
SQL ROLLBACK	SQL ROLLBACK discards all changes and concludes the transaction	359
SQL	SQL COMMIT saves all changes and concludes the transaction	358
SQL UPDATE	SQL UPDATE expands the transaction to include the change of an existing row	355
SQL	SQL INSERT creates a new table row	357
SQL SELECT	SQL SELECT reads out a single value from a table and does not open any transaction	361

SQL BIND

SQL BIND links a Q parameter to a table column. The SQL commands **FETCH**, **UPDATE**, and **INSERT** evaluate this binding (assignment) during data transfer between the **result set** and the NC program.

An **SQL BIND** command without a table name or column name cancels the binding. At the latest, the binding is terminated at the end of the NC program or subprogram.





Programming notes:

- Program any number of bindings with SQL BIND..., before using the FETCH, UPDATE, or INSERT commands.
- During the read and write operations, the control considers only those columns that you have specified by means of the **SELECT** command. If you specify columns without a binding in the **SELECT** command, then the control interrupts the read or write operation with an error message.



- ▶ **Parameter no. for result**: Define Q parameter for binding to the table column
- ▶ **Database: column name**: Define table name and table column (separate with .)
 - **Table name**: Synonym or path with filename of the table
 - **Column name**: Name displayed in the table editor

Example: Binding Q parameters to table columns

11 SQL BIND Q881 "Tab_Example.Position_Nr"	
12 SQL BIND Q882 "Tab_Example.Measure_X"	
13 SQL BIND Q883 "Tab_Example.Measure_Y"	
14 SQL BIND Q884 "Tab_Example.Measure_Z"	

Example: Remove binding

•	•	
91 SQL BIND Q881		
92 SQL BIND Q882		
93 SQL BIND Q883		
94 SQL BIND Q884		

SQL EXECUTE


SQL EXECUTE can be used in conjunction with various SQL instructions.

The following SQL instructions are used in the SQL command \mathbf{SQL} **EXECUTE**.

Instruction	Function	
SELECT	Select data	
CREATE SYNONYM	Create synonym (replace long path names with short names)	
DROP SYNONYM	Delete synonym	
CREATE TABLE	Generate a table	
COPY TABLE	Copy table	
RENAME TABLE	Rename table	
DROP TABLE	Delete a table	
INSERT	Insert table rows	
UPDATE	Update table rows	
DELETE	Delete table rows	
ALTER TABLE	Add table columns using ADD	
	Delete table columns using DROP	
DENIAME COLUMN	D	

RENAME COLUMN Rename table columns

Example for the SQL EXECUTE command



Remarks

- The gray arrows and associated syntax do not directly belong to the SQL EXECUTE command
- Black arrows and associated syntax indicate internal processes of SQL EXECUTE

SQL EXECUTE with the SQL instruction SELECT

The SQL server places the data in the **result set** row-by-row. The rows are numbered in ascending order, starting with 0. The SQL commands **FETCH** and **UPDATE** use these row numbers (the **INDEX**).

SQL EXECUTE, in conjunction with the SQL instruction **SELECT**, selects the table values, transfers them to the **result set**, and always opens a transaction in the process. Unlike the SQL command **SQL SELECT**, the combination of **SQL EXECUTE** and the **SELECT** instruction allows multiple columns and rows to be selected at the same time.

In the function **SQL** ... "**SELECT...WHERE...**", you can enter the search criteria. You thereby restrict the number of rows to be transferred. If you do not use this option, then all of the rows in the table are loaded.

In the function **SQL** ... "**SELECT...ORDER BY...**", you can enter the ordering criterion. This entry consists of the column designation and the keyword **ASC** for ascending or **DESC** for descending order. If you do not use this option, then rows will be stored in a random order.

With the function **SQL** ... "**SELECT...FOR UPDATE**", you can lock the selected rows for other applications. Other applications can continue to read these rows but are unable to change them. If you make changes to the table entries, then it is absolutely necessary to use this option.

Empty result set: If no rows meet the search criterion, then the SQL server returns a valid **HANDLE** without table entries.



▶ Define Parameter number for result

- The return value serves as an identifying feature of a successfully opened transaction
- The return value is used to control the read operation

In the specified parameters, the control stores the **HANDLE** under which the read operation will subsequently occur. The **HANDLE** is valid until you confirm or reject the transaction.

- **0**: Faulty read operation
- Unequal to 0: Return value of the **HANDLE**
- ▶ Database: SQL instruction: Program an SQL instruction
 - SELECT: Table columns to be transferred (separate multiple columns with ,)
 - **FROM**: Synonym or absolute path of the table (path in single quotation marks)
 - WHERE (optional): Column names, condition, and comparison value (Q parameters after: in single quotation marks)
 - ORDER BY (optional): Column names and type of ordering (ASC for ascending and DESC for descending order)
 - **FOR UPDATE** (optional): To lock other processes from performing a write access to the selected rows

Conditions for WHERE entries

Condition	Programming
Equals	= ==
Not equal to	!= <>
Less than	<
Less than or equal to	<=
Greater than	>
Greater than or equal to	>=
Empty	IS NULL
Not empty	IS NOT NULL
Linking multiple conditions:	
Logical AND	AND
Logical OR	OR

Example: selection of table rows

11 SQL BIND Q881 "Tab_Example.Position_Nr"	
12 SQL BIND Q882 "Tab_Example.Measure_X"	
13 SQL BIND Q883 "Tab_Example.Measure_Y"	
14 SQL BIND Q884 "Tab_Example.Measure_Z"	
•••	
20 SQL Q5 "SELECT Position_Nr,Measure_X,Measure_Y, Measure_Z FROM Tab_Example"	

Example: Select table rows with the WHERE function

```
20 SQL Q5 "SELECT Position_Nr,Measure_X,Measure_Y,
Measure_Z FROM Tab_Example WHERE
Position_Nr<20"
```

Example: Select table rows with the WHERE function and Q parameter

```
20 SQL Q5 "SELECT Position_Nr,Measure_X,Measure_Y,
Measure_Z FROM Tab_Example WHERE
Position_Nr==:'Q11'"
```

Example: Define the table name with absolute path information

```
20 SQL Q5 "SELECT Position_Nr,Measure_X,Measure_Y,
Measure_Z FROM 'V:\table\Tab_Example' WHERE
Position_Nr<20"
```

Example: Generate a table with CREATE TABLE

0 BEGIN PGM SQL_CREATE_TAB MM	
1 SQL Q10 "CREATE SYNONYM NEW FOR 'TNC:\table \NewTab.TAB"	; Create synonym
2 SQL Q10 "CREATE TABLE NEW AS SELECT X,Y,Z FROM 'TNC:\prototype_for_NewTab.tab"	; Create table
3 END PGM SQL_CREATE_TAB MM	



You can also define synonyms for tables that have not yet been generated.



The sequence of the columns in the created file corresponds to the sequence within the **AS SELECT** instruction.

Example: Generate a table with CREATE TABLE and QS



For the instructions within the SQL command, you can likewise use single or combined QS parameters.

If you check the content of a QS parameter in the additional status indicator (**QPARA** tab), then you will see only the first 30 characters and therefore not the entire content.

- O BEGIN PGM SQL_CREATE_TABLE_QS MM
- 1 DECLARE STRING QS1 = "CREATE TABLE"
- 2 DECLARE STRING QS2 = ""TNC:\nc_prog\demo\Doku
 \NewTab.t' "
- 3 DECLARE STRING QS3 = "AS SELECT"
- 4 DECLARE STRING QS4 = "DL,R,DR,L"
- 5 DECLARE STRING QS5 = "FROM"
- 6 DECLARE STRING QS6 = "'TNC:\table\tool.t"
- 7 QS7 = QS1 || QS2 || QS3 || QS4 || QS5 || QS6
- 8 SQL Q1800 QS7
- 9 END PGM SQL_CREATE_TABLE_QS MM

Examples

The following examples do not result in a cohesive NC program. The NC blocks show only possible uses of the SQL command **SQL EXECUTE**.


9 SQL Q1800 "CREATE SYNONYM my_table FOR 'TNC:- \table\WMAT.TAB'"	Create synonym	
9 SQL Q1800 "DROP SYNONYM my_table"	Delete synonym	
9 SQL Q1800 "CREATE TABLE my_table (NO,WMAT)"	Create table with the rows NO and WMAT.	
9 SQL Q1800 "COPY TABLE my_table TO 'TNC:\table-\WMAT2.TAB"	Copy table	
9 SQL Q1800 "RENAME TABLE my_table TO 'TNC:\table-\WMAT3.TAB'"	Rename table	
9 SQL Q1800 "DROP TABLE my_table"	Delete table	
9 SQL Q1800 "INSERT INTO my_table VALUES (1,'ENAW',240)"	Insert table row	
9 SQL Q1800 "DELETE FROM my_table WHERE NR==3"	Delete table row	
9 SQL Q1800 "ALTER TABLE my_table ADD (WMAT2)"	Insert table rows	
9 SQL Q1800 "ALTER TABLE my_table DROP (WMAT2)"	Delete table row	
9 SQL Q1800 "RENAME COLUMN my_table (WMAT2) TO (WMAT3)"	Rename table column	

SQL FETCH

SQL FETCH reads a row from the **result set**. The values of the individual cells are stored by the control in the bound Q parameters. The transaction is defined through the **HANDLE** to be specified, and the row is defined by the **INDEX**.

SQL FETCH takes all of the columns into consideration that contain the **SELECT** instruction (SQL command **SQL EXECUTE**).

Example for the SQL FETCH command



Remarks:

- The gray arrows and associated syntax do not directly belong to the SQL FETCH command
- Black arrows and associated syntax indicate internal processes of SQL FETCH



- ▶ Define **Parameter number for result** (return values for the control):
 - **0**: Successful read operation
 - 1: Faulty read operation
- ▶ **Database: SQL access ID**: Define Q parameter for the **HANDLE** (for identifying the transaction)
- Define Database: Index for SQL result (row number within the result set)
 - Row number
 - Q parameter with the index
 - None defined: access to row 0



The optional syntax elements **IGNORE UNBOUND** and **UNDEFINE MISSING** are intended for the machine manufacturer.

Example: Transfer row number in the Q parameter

11 SQL BIND Q881 "Tab_Example.Position_Nr"

12 SQL BIND Q882 "Tab_Example.Measure_X"

13 SQL BIND Q883 "Tab_Example.Measure_Y"

14 SQL BIND Q884 "Tab_Example.Measure_Z"

...

20 SQL Q5 "SELECT Position_Nr,Measure_X,Measure_Y,
 Measure_Z FROM Tab_Example"

...

30 SQL FETCH Q1 HANDLE Q5 INDEX+Q2

Example: Program the row number directly


30 SQL FETCH Q1 HANDLE Q5 INDEX5

SQL UPDATE

SQL UPDATE changes a row in the **result set**. The new values of the individual cells are copied by the control from the bound Q parameters. The transaction is defined through the **HANDLE** to be specified, and the row is defined by the **INDEX**. The control completely overwrites the already existing rows in the **result set**.

SQL UPDATE takes all of the columns into consideration that contain the **SELECT** instruction (SQL command **SQL EXECUTE**).

Example for the SQL UPDATE command



The gray arrows and associated syntax do not directly belong to the **SQL UPDATE**

Black arrows and associated syntax show internal processes of $\ensuremath{\mathbf{SQL}}$ $\ensuremath{\mathbf{UPDATE}}$




- ▶ Define **Parameter number for result** (return values for the control):
 - 0: Change was successful
 - 1: Change failed
- ▶ **Database: SQL access ID**: Define Q parameter for the **HANDLE** (for identifying the transaction)
- Define Database: Index for SQL result (row number within the result set)
 - Row number
 - Q parameter with the index
 - None defined: access to row 0



When writing to tables, the control checks the lengths of the string parameters. If the entries exceed the length of the columns to be described, then the control outputs an error message.

Example: Transfer row number in the Q parameter



Example: Program the row number directly


40 SQL UPDATE Q1 HANDLE Q5 INDEX5

SQL INSERT

SQL INSERT creates a new row in the **result set**. The values of the individual cells are copied by the control from the bound Q parameters. The transaction is defined via the **HANDLE** to be specified.

SQL INSERT takes all of the columns into consideration that contain the **SELECT** instruction (SQL command **SQL EXECUTE**). Table columns without a corresponding **SELECT** instruction (not contained in the query result) are described by the control with default values.

Example for the SQL INSERT command



Remarks:

- The gray arrows and associated syntax do not directly belong to the SQL INSERT command
- Black arrows and associated syntax indicate internal processes of SQL INSERT




- ▶ Define **Parameter number for result** (return values for the control):
 - 0: Transaction successful
 - 1: Transaction failed
- ▶ **Database: SQL access ID**: Define Q parameter for the **HANDLE** (for identifying the transaction)



When writing to tables, the control checks the lengths of the string parameters. If the entries exceed the length of the columns to be described, then the control outputs an error message.

Example: Transfer row number in the Q parameter




SQL COMMIT

SQL COMMIT simultaneously transfers all of the rows that have been changed and added in a transaction back into the table. The transaction is defined via the **HANDLE** to be specified. In this context, a lock that has been set with **SELECT...FOR UPDATE** resets the control.

The assigned **HANDLE** (operation) loses its validity.

Example for the SQL COMMIT command




Remarks:

- The gray arrows and associated syntax do not directly belong to the SQL COMMIT command
- Black arrows and associated syntax indicate internal processes of SQL COMMIT



- ▶ Define **Parameter number for result** (return values for the control):
 - **0**: Transaction successful
 - 1: Transaction failed
- ▶ **Database: SQL access ID**: Define Q parameter for the **HANDLE** (for identifying the transaction)

Example




SQL ROLLBACK

SQL ROLLBACK discards all of the changes and additions of a transaction. The transaction is defined via the **HANDLE** to be specified.

The function of the SQL command \mathbf{SQL} $\mathbf{ROLLBACK}$ depends on the \mathbf{INDEX} :

- Without INDEX:
 - The control discards all changes and additions of the transaction
 - The control resets a lock set with **SELECT...FOR UPDATE**
 - The control completes the transaction (the **HANDLE** loses its validity)
- With **INDEX**:
 - Only the indexed row remains in the result set (the control removes all of the other rows)
 - The control discards any changes and additions that may have been made in the non-specified rows
 - The control locks only those rows indexed with SELECT...FOR UPDATE (the control resets all of the other locks)
 - The specified (indexed) row is then the new Row 0 of the result set
 - The control does **not** complete the transaction (the **HANDLE** keeps its validity)
 - The transaction must be completed manually with SQL ROLLBACK or SQL COMMIT at a later time

Example for the SQL ROLLBACK command



Remarks:

- The gray arrows and associated syntax do not directly belong to the SQL ROLLBACK command
- Black arrows and associated syntax indicate internal processes of SQL ROLLBACK



- Define Parameter number for result (return values for the control):
 - **0**: Transaction successful
 - 1: Transaction failed
- ▶ **Database: SQL access ID**: Define Q parameter for the **HANDLE** (for identifying the transaction)
- ▶ Define Database: Index for SQL result (row that remains in the result set)
 - Row number
 - Q parameter with the index

Example

11 SQL BIND Q881 "Tab_Example.Position_Nr"	
12 SQL BIND Q882 "Tab_Example, Measure_X"	
13 SQL BIND Q883 "Tab_Example, Measure_Y"	
14 SQL BIND Q884 "Tab_Example.Measure_Z"	
•••	
20 SQL Q5 "SELECT Position_Nr,Measure_X,Measure_Y, Measure_Z FROM Tab_Example"	
30 SQL FETCH Q1 HANDLE Q5 INDEX+Q2	
•••	
50 SQL ROLLBACK Q1 HANDLE Q5	

SQL SELECT

SQL SELECT reads a single value from a table and saves the result in the defined Q parameter.




You can select multiple values or multiple columns using the SQL command **SQL EXECUTE** and the **SELECT** instruction.

Further information: "SQL EXECUTE", Page 349

With **SQL SELECT**, there is neither a transaction nor a binding between the table column and Q parameter. The control does not consider any bindings that may exist to the specified column. The control copies the read value only into the parameter specified for the result.

Example for the SQL SELECT command



Remark:

 Black arrows and associated syntax show internal processes of SQL SELECT



- ▶ Define **Parameter number for result** (Q parameter for saving the value)
- Database: SQL command text: Program the SQL instruction
 - SELECT: Table column of the value to be transferred
 - **FROM**: Synonym or absolute path of the table (path in single quotation marks)
 - WHERE: Column designation, condition, and comparison value (Q parameter after: in single quotation marks)

Example: Read and save a value

20 SQL SELECT Q5 "SELECT Mess_X FROM Tab_Example WHERE Position_NR==3"

Comparison

The results of the following NC programs are identical.

0 BEGIN PGM SQL_READ_WMAT MM	
1 SQL Q1800 "CREATE SYNONYM my_table FOR 'TNC: \table\WMAT.TAB'"	Create synonym
2 SQL BIND QS1800 "my_table.WMAT"	Bind QS parameters
3 SQL QL1 "SELECT WMAT FROM my_table WHERE NR==3"	Define search
3 COL SELECT OC1800 "SELECT WMAT EDOM my table	Pood and savo a value

3 SQL SELECT QS1800 "SELECT WMAT FROM my_table WHERE NR==3"

...



For the instructions within the SQL command, you can likewise use single or combined QS parameters.

If you check the content of a QS parameter in the additional status indicator (**QPARA** tab), then you will see only the first 30 characters and therefore not the entire content.

3 DECLARE STRING QS1 = "SELECT "	
4 DECLARE STRING QS2 = "WMAT "	
5 DECLARE STRING QS3 = "FROM"	
6 DECLARE STRING QS4 = "my_table "	
7 DECLARE STRING QS5 = "WHERE "	
8 DECLARE STRING QS6 = "NR==3"	
9 QS7 = QS1 QS2 QS3 QS4 QS5 QS6	
10 SQL SELECT QL1 QS7	
11	

Examples

In the following example, the defined material is read from the table (**WMAT.TAB**) and is stored as a text in a QS parameter. The following example shows a possible application and the necessary program steps.



You can use the **FN 16** function, for example, in order to reuse QS parameters in your own log files.

Further information: "Fundamentals", Page 308

Example: Use a synonym

0 BEGIN PGM SQL_READ_WMAT MM	
1 SQL Q1800 "CREATE SYNONYM my_table FOR 'TNC:- \table\WMAT.TAB'"	Create synonym
2 SQL BIND QS1800 "my_table.WMAT"	Bind QS parameters
3 SQL QL1 "SELECT WMAT FROM my_table WHERE NO==3"	Define search
4 SQL FETCH Q1900 HANDLE QL1	Execute search
5 SQL ROLLBACK Q1900 HANDLE QL1	Complete transaction
6 SQL BIND QS1800	Remove parameter binding
7 SQL Q1 "DROP SYNONYM my_table"	Delete synonym
8 END PGM SQL_READ_WMAT MM	

St	ер	Explanation
1	Create	Assign a synonym to a path (replace long paths with short names)
	synonym	■ The path TNC:\table\WMAT.TAB is always placed in single quotes
		■ The selected synonym is my_table
2	Bind QS	Bind a QS parameter to a table column
	parameters	Q\$1800 is freely available in NC programs
		 The synonym replaces the entry of the complete path
		■ The defined column from the table is called WMAT
3	Define search	A search definition contains the entry of the transfer value
		 The QL1 local parameter (freely selectable) serves to identify the transaction (multiple transactions are possible simultaneously)
		The synonym defines the table
		■ The WMAT entry defines the table column of the read operation
		■ The entries NR and ==3 define the table rows of the read operation
		 Selected table columns and rows define the cells of the read operation
4	Execute search	The control performs the read operation
		■ SQL FETCH copies the values from the result set into the bound Q or QS parameter
		0 successful read operation
		■ 1 faulty read operation
		■ The syntax HANDLE QL1 is the transaction designated by the parameter QL1
		■ The parameter Q1900 is a return value for checking whether the data have been read
5	Complete transaction	The transaction is concluded and the used resources are released

St	ер	Explanation
6	Remove binding	The binding between table columns and QS parameters is removed (release of necessary resources)
7	Delete synonym	The synonym is deleted (release of necessary resources)



Synonyms are an alternative only to the required absolute paths. Relative path entries are not possible.

The following NC program shows the entry of an absolute path.

Example: Use an absolute path

0 BEGIN PGM SQL_READ_WMAT_2 MM	
1 SQL BIND QS 1800 "'TNC:\table\WMAT.TAB'.WMAT"	Bind QS parameters
2 SQL QL1 "SELECT WMAT FROM 'TNC:\table\WMAT.TAB' WHERE NR ==3"	Define search
3 SQL FETCH Q1900 HANDLE QL1	Execute search
4 SQL ROLLBACK Q1900 HANDLE QL1	Complete transaction
5 SQL BIND QS 1800	Remove parameter binding
6 END PGM SQL_READ_WMAT_2 MM	

9.13 Programming examples

Example: Rounding a value

The **INT** function truncates the decimal places.

In order for the control to round correctly, rather than simply truncating the decimal places, add the value 0.5 to a positive number. For a negative number you must subtract 0.5.


The control uses the ${\bf SGN}$ function to detect whether a number is positive or negative.

0 BEGIN PGM ROUND MM	
1 FN 0: Q1 = +34.789	First number to be rounded
2 FN 0: Q2 = +34.345	Second number to be rounded
3 FN 0: Q3 = -34.432	Third number to be rounded
4;	
5 Q11 = INT (Q1 + 0.5 * SGN Q1)	Add the value 0.5 to Q1, then truncate the decimal places
6 Q12 = INT (Q2 + 0.5 * SGN Q2)	Add the value 0.5 to Q2, then truncate the decimal places
7 Q13 = INT (Q3 + 0.5 * SGN Q3)	Subtract the value 0.5 from Q3, then truncate the decimal places
8 END PGM ROUND MM	

Example: Ellipse

Program run

- The contour of the ellipse is approximated by many short line segments (defined in Q7). The more calculation steps you define for the lines, the smoother the curve becomes.
- The milling direction is determined with the starting angle and end angle in the plane:
 Machining direction is clockwise:
 Starting angle > end angle
 Machining direction is counterclockwise:
 Starting angle < end angle
- The tool radius is not taken into account




0 BEGIN PGM ELLIPSE MM	
1 FN 0: Q1 = +50	Center in X axis
2 FN 0: Q2 = +50	Center in Y axis
3 FN 0: Q3 = +50	Semiaxis in X
4 FN 0: Q4 = +30	Semiaxis in Y
5 FN 0: Q5 = +0	Starting angle in the plane
6 FN 0: Q6 = +360	End angle in the plane
7 FN 0: Q7 = +40	Number of calculation steps
8 FN 0: Q8 = +0	Rotational position of the ellipse
9 FN 0: Q9 = +5	Milling depth
10 FN 0: Q10 = +100	Feed rate for plunging
11 FN 0: Q11 = +350	Feed rate for milling
12 FN 0: Q12 = +2	Set-up clearance for pre-positioning
13 BLK FORM 0.1 Z X+0 Y+0 Z-20	Workpiece blank definition
14 BLK FORM 0.2 X+100 Y100 Z+0	
15 TOOL CALL 1 Z S4000	Tool call
16 L Z+250 R0 FMAX	Retract the tool
17 CALL LBL 10	Call machining operation
18 L Z+100 R0 FMAX M2	Retract the tool, end program
19 LBL 10	Subprogram 10: Machining operation
20 CYCL DEF 7.0 DATUM SHIFT	Shift datum to center of ellipse
21 CYCL DEF 7.1 X+Q1	
22 CYCL DEF 7.2 Y+Q2	
23 CYCL DEF 10.0 ROTATION	Account for rotational position in the plane
24 CYCL DEF 10.1 ROT+Q8	
25 Q35 = (Q6 -Q5) / Q7	Calculate angle increment
26 Q36 = Q5	Copy starting angle
27 Q37 = 0	Set counter

28 Q21 = Q3 *COS Q36	Calculate X coordinate for starting point
29 Q22 = Q4 *SIN Q36	Calculate Y coordinate for starting point
30 L X+Q21 Y+Q22 R0 FMAX M3	Move to starting point in the plane
31 L Z+Q12 R0 FMAX	Pre-position in spindle axis to set-up clearance
32 L Z-Q9 R0 FQ10	Move to working depth
33 LBL1	
34 Q36 = Q36 +Q35	Update the angle
35 Q37 = Q37 +1	Update the counter
36 Q21 = Q3 *COS Q36	Calculate the current X coordinate
37 Q22 = Q4 *SIN Q36	Calculate the current Y coordinate
38 L X+Q21 Y+Q22 R0 FQ11	Move to next point
39 FN 12: IF +Q37 LT +Q7 GOTO LBL 1	Unfinished? If not finished, return to LBL 1
40 CYCL DEF 10.0 ROTATION	Reset the rotation
41 CYCL DEF 10.1 ROT+0	
42 CYCL DEF 7.0 DATUM SHIFT	Reset the datum shift
43 CYCL DEF 7.1 X+0	
44 CYCL DEF 7.2 Y+0	
45 L Z+Q12 R0 FMAX	Move to set-up clearance
46 LBL 0	End of subprogram
47 END PGM ELLIPSE MM	

Example: Concave cylinder machined with Ball-nose cutter

Program run

- This NC program works only with a Ball-nose cutter. The tool length is measured from the sphere center
- The contour of the cylinder is approximated by many short line segments (defined in Q13). The more line segments you define, the smoother the contour becomes.
- The cylinder is milled in longitudinal cuts (here: parallel to the Y axis).
- The milling direction is determined with the starting angle and end angle in space:
 Machining direction clockwise:
 Starting angle > end angle
 Machining direction counterclockwise:
 Starting angle < end angle
- The tool radius is compensated automatically




0 BEGIN PGM CYLIN MM	
1 FN 0: Q1 = +50	Center in X axis
2 FN 0: Q2 = +0	Center in Y axis
3 FN 0: Q3 = +0	Center in Z axis
4 FN 0: Q4 = +90	Starting angle in space (Z/X plane)
5 FN 0: Q5 = +270	End angle in space (Z/X plane)
6 FN 0: Q6 = +40	Cylinder radius
7 FN 0: Q7 = +100	Length of the cylinder
8 FN 0: Q8 = +0	Rotational position in the X/Y plane
9 FN 0: Q10 = +5	Allowance for cylinder radius
10 FN 0: Q11 = +250	Feed rate for plunging
11 FN 0: Q12 = +400	Feed rate for milling
12 FN 0: Q13 = +90	Number of cuts
13 BLK FORM 0.1 Z X+0 Y+0 Z-50	Workpiece blank definition
14 BLK FORM 0.2 X+100 Y+100 Z+0	
15 TOOL CALL 1 Z S4000	Tool call
16 L Z+250 R0 FMAX	Retract the tool
17 CALL LBL 10	Call machining operation
18 FN 0: Q10 = +0	Reset allowance
19 CALL LBL 10	Call machining operation
20 L Z+100 R0 FMAX M2	Retract the tool, end program

22 Q16 = Q6 -Q10 - Q108 23 FN 0: Q20 = +1 24 FN 0: Q24 = +Q4 25 Q25 = (Q5 -Q4) / Q13 26 CYCL DEF 7.0 DATUM SHIFT 27 CYCL DEF 7.1 X+Q1 28 CYCL DEF 7.3 Z+Q2 29 CYCL DEF 7.3 Z+Q3 30 CYCL DEF 10.0 ROTATION Account for rotational position in the plane 31 CYCL DEF 10.1 ROT+Q8 32 L X+0 Y+0 R0 FMAX 31 L Z+5 R0 F1000 M3 34 LBL 1 35 CC Z+0 X+0 36 LP PR+Q16 PA+Q24 FQ11 37 L Y+Q7 R0 FQ12 38 FN 1: Q20 = +Q20 ++1 39 FN 1: Q24 = +Q24 ++Q25 40 FN 11: IF +Q20 GT +Q13 GOTO LBL 1 41 FN 12: IF +Q20 LT +Q13 GOTO LBL 1 46 LBL 99 47 CYCL DEF 10.1 ROTATION Reset the datum shift 8c CYCL DEF 10.0 ROTATION Reset the datum shift 8c CYCL DEF 10.1 ROT+Q8 9c CYCL DEF 10.1 ROT+Q8 9c CYCL DEF 10.2 ROTATION Account for rotational position in the plane Account for allowance and tool, based on the cylinder canter Shift datum to center of cylinder (X axis) Account for allowance and tool, based on the cylinder canter Shift datum to center of cylinder (X axis) Account for allowance and tool, based (Z/X plane) Account for allowance and tool, based (Z/X plane) Account for allowance and tool, based (Z/X plane) Account for allowance (Z/X plane) Account for allowance and tool, based (Z/X plane) Account for allowance (Z/X plane) Account for alowance (Z/X plane) Account for alowance (Z/X plane) Account for rotational position in the plane to the cylinder (X axis) Account for alowance (Z/X plane) Account for alowance	21 LBL 10	Subprogram 10: Machining operation
24 FN 0: Q24 = +Q4 Copy starting angle in space (Z/X plane) 25 Q25 = (Q5 -Q4) / Q13 Calculate angle increment Shift datum to center of cylinder (X axis) 27 CYCL DEF 7.1 X+Q1 28 CYCL DEF 7.2 Y+Q2 29 CYCL DEF 7.3 Z+Q3 30 CYCL DEF 10.0 ROTATION Account for rotational position in the plane 31 CYCL DEF 10.1 ROT+Q8 32 L X+0 Y+0 RO FMAX Pre-position in the plane to the cylinder center 33 L Z+5 RO F1000 M3 Pre-position in the spindle axis 34 LBL 1 35 CC Z+O X+0 Set pole in the Z/X plane 36 LP PR+Q16 PA+Q24 FQ11 Move to starting position on cylinder, plunge-cutting obliquely into the material 37 L Y+Q7 RO FQ12 Longitudinal cut in Y+ direction 38 FN 1: Q24 = +Q20 + +1 Update the counter 40 FN 11: IF +Q20 GT +Q13 GOTO LBL 99 Finished? If finished, jump to end 41 LP PR+Q16 PA+Q24 FQ11 Move on an approximated arc for the next longitudinal cut 42 L Y+0 RO FQ12 Longitudinal cut in Y- direction 43 FN 1: Q24 = +Q24 + +Q25 Update beloanter 44 FN 1: Q24 = +Q20 + +1 Update the counter 45 FN 12; IF +Q20 LT +Q13 GOTO LBL 1 46 LBL 99 47 CYCL DEF 7.0 DATUM SHIFT Reset the datum shift Pset the datum shift SC CYCL DEF 7.1 X+0 51 CYCL DEF 7.2 Y+0 52 CYCL DEF 7.3 Z+0 53 LBL 0 End of subprogram	22 Q16 = Q6 -Q10 - Q108	Account for allowance and tool, based on the cylinder radius
25 Q25 = (Q5 -Q4) / Q13 26 CYCL DEF 7.0 DATUM SHIFT 27 CYCL DEF 7.1 X+Q1 28 CYCL DEF 7.2 Y+Q2 29 CYCL DEF 7.3 Z+Q3 30 CYCL DEF 10.0 ROTATION Account for rotational position in the plane 31 CYCL DEF 10.1 ROT+Q8 32 L X+0 Y+0 R0 FMAX Pre-position in the plane to the cylinder center 33 L Z+5 R0 F1000 M3 Pre-position in the spindle axis 34 LBL 1 35 CC Z+0 X+0 36 LP PR+Q16 PA+Q24 FQ11 Move to starting position on cylinder, plunge-cutting obliquely into the material 37 L Y+Q7 R0 FQ12 Longitudinal cut in Y+ direction 38 FN 1: Q20 = +Q20 + +1 Update the counter 40 FN 11: IF +Q20 GT +Q13 GOTO LBL 99 41 LP PR+Q16 PA+Q24 FQ11 Move on an approximated arc for the next longitudinal cut 42 L Y+0 R0 FQ12 Longitudinal cut in Y - direction 41 LP PR+Q16 PA+Q24 FQ11 Move on an approximated arc for the next longitudinal cut 42 L Y+0 R0 FQ12 Longitudinal cut in Y - direction 43 FN 1: Q20 = +Q20 + +1 Update the counter Update the counter 44 FN 1: Q20 = +Q20 + +1 Update solid angle 45 FN 12: IF +Q20 LT +Q13 GOTO LBL 1 46 LBL 99 47 CYCL DEF 7.0 DATUM SHIFT Reset the datum shift 8 CYCL DEF 7.1 X+0 51 CYCL DEF 7.1 X+0 51 CYCL DEF 7.3 Z+0 53 LBL 0 End of subprogram	23 FN 0: Q20 = +1	Set counter
26 CYCL DEF 7.0 DATUM SHIFT 27 CYCL DEF 7.1 X+Q1 28 CYCL DEF 7.2 Y+Q2 29 CYCL DEF 7.3 Z+Q3 30 CYCL DEF 10.1 ROTHQ8 31 CYCL DEF 10.1 ROTHQ8 32 L X+O Y+O RO FMAX 33 L Z+S RO F1000 M3 34 LBL 1 35 CC Z+O X+O 36 LP PR+Q16 PA+Q24 FQ11 37 L Y+Q7 RO FQ12 38 FN 1: Q20 = +Q20 + +1 39 FN 1: Q24 = +Q24 + +Q25 40 FN 11: IF +Q20 GT +Q13 GOTO LBL 99 41 LP PR+Q16 PA+Q24 FQ11 Move to starting position on cylinder, plunge-cutting obliquely into the material 42 L Y+O RO FQ12 43 FN 1: Q20 = +Q20 + +1 44 FN 1: Q20 = +Q20 + +1 45 FN 12: IF +Q20 LT +Q13 GOTO LBL 1 46 LBL 99 47 CYCL DEF 7.1 X+O 51 CYCL DEF 7.0 DATUM SHIFT 50 CYCL DEF 7.0 DATUM SHIFT 50 CYCL DEF 7.3 Z+O 53 LBL 0 End of subprogram	24 FN 0: Q24 = +Q4	Copy starting angle in space (Z/X plane)
27 CYCL DEF 7.1 X+Q1 28 CYCL DEF 7.2 Y+Q2 29 CYCL DEF 7.3 Z+Q3 30 CYCL DEF 10.0 ROTATION Account for rotational position in the plane 31 CYCL DEF 10.1 ROT+Q8 32 L X+O Y+O RO FMAX Pre-position in the plane to the cylinder center 33 L Z+S RO F1000 M3 Pre-position in the spindle axis 34 LBL 1 35 CC Z+O X+O Set pole in the Z/X plane 36 LP PR+Q16 PA+Q24 FQ11 Move to starting position on cylinder, plunge-cutting obliquely into the material 37 L Y+Q7 RO FQ12 Longitudinal cut in Y+ direction 38 FN 1: Q20 = +Q20 + +1 Update the counter 40 FN 11: IF +Q20 GT +Q13 GOTO LBL 99 Finished? If finished, jump to end 41 LP PR+Q16 PA+Q24 FQ11 Move on an approximated arc for the next longitudinal cut 42 L Y+O RO FQ12 Longitudinal cut in Y- direction 43 FN 1: Q20 = +Q20 + +1 Update the counter 44 FN 1: Q24 = +Q24 + +Q25 Update solid angle 45 FN 12: IF +Q20 LT +Q13 GOTO LBL 1 Unfinished? If finished, return to LBL 1 46 LBL 99 47 CYCL DEF 10.0 ROTATION Reset the rotation 48 CYCL DEF 10.0 ROTATION Reset the datum shift 50 CYCL DEF 7.0 DATUM SHIFT Reset the datum shift 50 CYCL DEF 7.0 DATUM SHIFT Reset the datum shift 50 CYCL DEF 7.1 X+O 51 CYCL DEF 7.3 Z+O 52 CYCL DEF 7.3 Z+O 53 LBL 0 End of subprogram	25 Q25 = (Q5 -Q4) / Q13	Calculate angle increment
28 CYCL DEF 7.2 Y+Q2 29 CYCL DEF 7.3 Z+Q3 30 CYCL DEF 10.0 ROTATION Account for rotational position in the plane 31 CYCL DEF 10.1 ROT+Q8 32 L X+O Y+O RO FMAX Pre-position in the plane to the cylinder center 33 L Z+5 RO F1000 M3 Pre-position in the spindle axis 34 LBL 1 35 CC Z+O X+O Set pole in the Z/X plane Move to starting position on cylinder, plunge-cutting obliquely into the material 37 L Y+Q7 RO FQ12 Longitudinal cut in Y+ direction 38 FN 1: Q20 = +Q20 + +1 Update the counter Update the counter Update the counter 41 LP PR+Q16 PA+Q24 FQ11 Move on an approximated arc for the next longitudinal cut 42 L Y+O RO FQ12 Longitudinal cut in Y- direction 43 FN 1: Q20 = +Q20 + +1 Update the counter Update the CULT TY direction	26 CYCL DEF 7.0 DATUM SHIFT	Shift datum to center of cylinder (X axis)
29 CYCL DEF 7.3 Z+Q3 30 CYCL DEF 10.0 ROTATION Account for rotational position in the plane 31 CYCL DEF 10.1 ROT+Q8 32 L X+0 Y+0 R0 FMAX Pre-position in the plane to the cylinder center 33 L Z+5 R0 F1000 M3 Pre-position in the spindle axis 34 LBL 1 35 CC Z+0 X+0 Set pole in the Z/X plane 36 LP PR+Q16 PA+Q24 FQ11 Move to starting position on cylinder, plunge-cutting obliquely into the material 37 L Y+Q7 R0 FQ12 Longitudinal cut in Y+ direction 38 FN 1: Q20 = +Q20 + +1 Update the counter Update solid angle 40 FN 11: IF +Q20 GT +Q13 GOTO LBL 99 Finished? If finished, jump to end 41 LP PR+Q16 PA+Q24 FQ11 Move on an approximated arc for the next longitudinal cut 42 L Y+0 R0 FQ12 Longitudinal cut in Y- direction 43 FN 1: Q20 = +Q20 + +1 Update the counter 44 FN 1: Q24 = +Q24 + +Q25 Update solid angle 45 FN 12: IF +Q20 LT +Q13 GOTO LBL 1 Unfinished? If not finished, return to LBL 1 46 LBL 99 47 CYCL DEF 10.0 ROTATION Reset the rotation 48 CYCL DEF 10.1 ROT+0 49 CYCL DEF 7.0 DATUM SHIFT Reset the datum shift 50 CYCL DEF 7.1 X+0 51 CYCL DEF 7.3 Z+0 52 CYCL DEF 7.3 Z+0 53 LBL 0 End of subprogram	27 CYCL DEF 7.1 X+Q1	
30 CYCL DEF 10.0 ROTATION 31 CYCL DEF 10.1 ROT+Q8 32 L X+0 Y+0 RO FMAX Pre-position in the plane to the cylinder center 33 L Z+5 RO F1000 M3 Pre-position in the spindle axis 34 LBL 1 35 CC Z+0 X+0 Set pole in the Z/X plane 36 LP PR+Q16 PA+Q24 FQ11 Move to starting position on cylinder, plunge-cutting obliquely into the material 37 L Y+Q7 RO FQ12 Longitudinal cut in Y+ direction 39 FN 1: Q20 = +Q20 + +1 Update the counter Update solid angle 40 FN 11: IF +Q20 GT +Q13 GOTO LBL 99 Finished? If finished, jump to end 41 LP PR+Q16 PA+Q24 FQ11 Move on an approximated arc for the next longitudinal cut 42 L Y+0 RO FQ12 Longitudinal cut in Y- direction Update the counter Update the counter Update the counter Update the counter Update solid angle Update for the next longitudinal cut 42 L Y+0 RO FQ12 Update solid angle Update the counter Update the counter Update the counter Update solid angle Update solid angle Update solid angle Update solid angle 45 FN 12: IF +Q20 LT +Q13 GOTO LBL 1 Update Solid angle Update Solid angle Update Solid angle Finished? If not finished, return to LBL 1 46 LBL 99 47 CYCL DEF 10.0 ROTATION Reset the rotation 48 CYCL DEF 10.1 ROT+0 49 CYCL DEF 7.0 DATUM SHIFT For CYCL DEF 7.1 X+0 51 CYCL DEF 7.3 Z+0 52 CYCL DEF 7.3 Z+0 End of subprogram	28 CYCL DEF 7.2 Y+Q2	
31 CYCL DEF 10.1 ROT+Q8 32 L X+0 Y+0 RO FMAX Pre-position in the plane to the cylinder center 33 L Z+5 RO F1000 M3 Pre-position in the spindle axis 34 LBL 1 35 CC Z+0 X+0 Set pole in the Z/X plane 36 LP PR+Q16 PA+Q24 FQ11 Move to starting position on cylinder, plunge-cutting obliquely into the material 37 L Y+Q7 RO FQ12 Longitudinal cut in Y+ direction 38 FN 1: Q20 = +Q20 + +1 Update the counter Update solid angle 40 FN 11: IF +Q20 GT +Q13 GOTO LBL 99 Finished? If finished, jump to end 41 LP PR+Q16 PA+Q24 FQ11 Move on an approximated arc for the next longitudinal cut 42 L Y+0 RO FQ12 Longitudinal cut in Y- direction 43 FN 1: Q20 = +Q20 + +1 Update the counter Update the counter Update solid angle 45 FN 12: IF +Q20 LT +Q13 GOTO LBL 1 Unfinished? If not finished, return to LBL 1 46 LBL 99 47 CYCL DEF 10.0 ROTATION Reset the rotation 48 CYCL DEF 7.0 DATUM SHIFT Reset the datum shift 50 CYCL DEF 7.1 X+0 51 CYCL DEF 7.3 Z+0 53 LBL 0 End of subprogram	29 CYCL DEF 7.3 Z+Q3	
32 L X+0 Y+0 R0 FMAX 33 L Z+5 R0 F1000 M3 34 LBL 1 35 CC Z+0 X+0 36 LP PR+Q16 PA+Q24 FQ11 Move to starting position on cylinder, plunge-cutting obliquely into the material 37 L Y+Q7 R0 FQ12 38 FN 1: Q20 = +Q20 + +1 39 FN 1: Q24 = +Q24 + +Q25 40 FN 11: IF +Q20 GT +Q13 GOTO LBL 99 41 LP PR+Q16 PA+Q24 FQ11 Move on an approximated arc for the next longitudinal cut approximated arc for the ne	30 CYCL DEF 10.0 ROTATION	Account for rotational position in the plane
33 L Z+5 R0 F1000 M3 34 LBL 1 35 CC Z+0 X+0 36 LP PR+Q16 PA+Q24 FQ11 Move to starting position on cylinder, plunge-cutting obliquely into the material 37 L Y+Q7 R0 FQ12 38 FN 1: Q20 = +Q20 + +1 39 FN 1: Q24 = +Q24 + +Q25 40 FN 11: IF +Q20 GT +Q13 GOTO LBL 99 41 LP PR+Q16 PA+Q24 FQ11 Move on an approximated arc for the next longitudinal cut 42 L Y+0 R0 FQ12 43 FN 1: Q20 = +Q20 + +1 Update the counter Wove on an approximated arc for the next longitudinal cut 42 L Y+0 R0 FQ12 Longitudinal cut in Y- direction 43 FN 1: Q20 = +Q20 + +1 Update the counter Update solid angle 44 FN 1: Q24 = +Q24 + +Q25 Update solid angle 45 FN 12: IF +Q20 LT +Q13 GOTO LBL 1 Unfinished? If not finished, return to LBL 1 46 LBL 99 47 CYCL DEF 10.0 ROTATION Reset the rotation Reset the datum shift 50 CYCL DEF 7.0 DATUM SHIFT Reset the datum shift 51 CYCL DEF 7.3 X+0 53 LBL 0 End of subprogram	31 CYCL DEF 10.1 ROT+Q8	
34 LBL 1 35 CC Z+0 X+0 Set pole in the Z/X plane Move to starting position on cylinder, plunge-cutting obliquely into the material 37 L Y+Q7 R0 FQ12 Longitudinal cut in Y+ direction 38 FN 1: Q20 = +Q20 + +1 Update the counter Update solid angle 40 FN 11: IF +Q20 GT +Q13 GOTO LBL 99 Finished? If finished, jump to end 41 LP PR+Q16 PA+Q24 FQ11 Move on an approximated arc for the next longitudinal cut 42 L Y+0 R0 FQ12 Longitudinal cut in Y- direction 43 FN 1: Q20 = +Q20 + +1 Update the counter Update solid angle 44 FN 1: Q24 = +Q24 + +Q25 Update solid angle Unfinished? If not finished, return to LBL 1 46 LBL 99 47 CYCL DEF 10.0 ROTATION Reset the rotation Reset the rotation Reset the datum shift 50 CYCL DEF 7.0 DATUM SHIFT Reset the datum shift 51 CYCL DEF 7.2 Y+0 52 CYCL DEF 7.3 Z+0 End of subprogram	32 L X+0 Y+0 R0 FMAX	Pre-position in the plane to the cylinder center
36 LP PR+Q16 PA+Q24 FQ11 Move to starting position on cylinder, plunge-cutting obliquely into the material 37 L Y+Q7 R0 FQ12 Longitudinal cut in Y+ direction 38 FN 1: Q20 = +Q20 + +1 Update the counter Update solid angle 40 FN 11: IF +Q20 GT +Q13 GOTO LBL 99 Finished? If finished, jump to end 41 LP PR+Q16 PA+Q24 FQ11 Move on an approximated arc for the next longitudinal cut 42 L Y+0 R0 FQ12 Longitudinal cut in Y- direction Update the counter Update the counter Update solid angle 45 FN 1: Q20 = +Q20 + +1 Update solid angle Reset the rotation Reset the rotation Reset the rotation Reset the datum shift To CYCL DEF 7.0 DATUM SHIFT Reset the datum shift Fernal Reset the datum shift End of subprogram	33 L Z+5 RO F1000 M3	Pre-position in the spindle axis
36 LP PR+Q16 PA+Q24 FQ11 Move to starting position on cylinder, plunge-cutting obliquely into the material 37 L Y+Q7 R0 FQ12 Longitudinal cut in Y+ direction Update the counter Update solid angle 40 FN 11: IF +Q20 GT +Q13 GOTO LBL 99 Finished? If finished, jump to end 41 LP PR+Q16 PA+Q24 FQ11 Move on an approximated arc for the next longitudinal cut 42 L Y+0 R0 FQ12 Longitudinal cut in Y- direction Update the counter Update the counter Update the counter Update solid angle Update solid angle Update solid angle Update solid angle Update he counter Update solid angle Update solid angle When the provide he counter Update solid angle Update solid angle Update solid angle Reset the totation Reset the rotation Reset the rotation Reset the datum shift O CYCL DEF 7.0 DATUM SHIFT Reset the datum shift TO CYCL DEF 7.2 Y+0 SI CYCL DEF 7.3 Z+0 End of subprogram	34 LBL 1	
into the material 37 L Y+Q7 R0 FQ12 38 FN 1: Q20 = +Q20 + +1 39 FN 1: Q24 = +Q24 + +Q25 40 FN 11: IF +Q20 GT +Q13 GOTO LBL 99 41 LP PR+Q16 PA+Q24 FQ11 Move on an approximated arc for the next longitudinal cut 42 L Y+0 R0 FQ12 Longitudinal cut in Y- direction 43 FN 1: Q20 = +Q20 + +1 44 FN 1: Q24 = +Q24 + +Q25 Update solid angle 45 FN 12: IF +Q20 LT +Q13 GOTO LBL 1 Unfinished? If not finished, return to LBL 1 46 LBL 99 47 CYCL DEF 10.0 ROTATION Reset the rotation 48 CYCL DEF 7.0 DATUM SHIFT FO CYCL DEF 7.1 X+0 51 CYCL DEF 7.3 Z+0 53 LBL 0 End of subprogram	35 CC Z+0 X+0	Set pole in the Z/X plane
38 FN 1: Q20 = +Q20 + +1 39 FN 1: Q24 = +Q24 + +Q25 40 FN 11: IF +Q20 GT +Q13 GOTO LBL 99 41 LP PR+Q16 PA+Q24 FQ11 42 L Y+0 R0 FQ12 43 FN 1: Q20 = +Q20 + +1 44 FN 1: Q20 = +Q20 + +1 45 FN 12: IF +Q20 LT +Q13 GOTO LBL 1 46 LBL 99 47 CYCL DEF 10.0 ROTATION 48 CYCL DEF 7.0 DATUM SHIFT 50 CYCL DEF 7.2 Y+0 52 CYCL DEF 7.3 Z+0 53 LBL 0 Update solid angle Update the counter Update the counter Update solid angle Unfinished? If not finished, return to LBL 1 Unfinished? If not finished, return to LBL 1 End of subprogram	36 LP PR+Q16 PA+Q24 FQ11	
Update solid angle 40 FN 11: IF +Q20 GT +Q13 GOTO LBL 99 41 LP PR+Q16 PA+Q24 FQ11 Move on an approximated arc for the next longitudinal cut 42 L Y+0 R0 FQ12 Longitudinal cut in Y- direction Update the counter Update solid angle Update solid angle Update solid angle Update the counter Update solid angle Update solid angle Update solid angle Update solid angle Vipdate solid angle Update solid angle Update solid angle Reset the rotation Reset the rotation Reset the rotation Reset the datum shift To CYCL DEF 7.0 DATUM SHIFT So CYCL DEF 7.1 X+0 To CYCL DEF 7.3 Z+0 End of subprogram	37 L Y+Q7 R0 FQ12	Longitudinal cut in Y+ direction
40 FN 11: IF +Q20 GT +Q13 GOTO LBL 99 41 LP PR+Q16 PA+Q24 FQ11 Move on an approximated arc for the next longitudinal cut 42 L Y+0 R0 FQ12 Longitudinal cut in Y- direction 43 FN 1: Q20 = +Q20 + +1 Update the counter Update solid angle 45 FN 12: IF +Q20 LT +Q13 GOTO LBL 1 Unfinished? If not finished, return to LBL 1 46 LBL 99 47 CYCL DEF 10.0 ROTATION Reset the rotation 48 CYCL DEF 10.1 ROT+0 49 CYCL DEF 7.0 DATUM SHIFT 50 CYCL DEF 7.1 X+0 51 CYCL DEF 7.3 Z+0 End of subprogram	38 FN 1: Q20 = +Q20 + +1	Update the counter
### AT LP PR+Q16 PA+Q24 FQ11 ### AT LP PR+Q16 PA+Q24 FQ12 ### Longitudinal cut in Y - direction ### Update the counter ### Update solid angle ### Update solid angle ### Unfinished? If not finished, return to LBL 1 ### AT LP PR+Q16 PA+Q24 FQ11 ### Update the counter ### Update solid angle ### Unfinished? If not finished, return to LBL 1 ### AT LP PR+Q16 PA+Q24 FQ11 ### Update the counter ### Update	39 FN 1: Q24 = +Q24 + +Q25	Update solid angle
Longitudinal cut in Y- direction 43 FN 1: Q20 = +Q20 + +1 Update the counter Update solid angle Update solid angle Update solid angle Unfinished? If not finished, return to LBL 1 46 LBL 99 47 CYCL DEF 10.0 ROTATION Reset the rotation 48 CYCL DEF 10.1 ROT+0 49 CYCL DEF 7.0 DATUM SHIFT FO CYCL DEF 7.1 X+0 51 CYCL DEF 7.3 Z+0 End of subprogram	40 FN 11: IF +Q20 GT +Q13 GOTO LBL 99	Finished? If finished, jump to end
43 FN 1: Q20 = +Q20 + +1 44 FN 1: Q24 = +Q24 + +Q25 Update solid angle 45 FN 12: IF +Q20 LT +Q13 GOTO LBL 1 Unfinished? If not finished, return to LBL 1 46 LBL 99 47 CYCL DEF 10.0 ROTATION Reset the rotation 48 CYCL DEF 10.1 ROT+0 49 CYCL DEF 7.0 DATUM SHIFT Reset the datum shift 50 CYCL DEF 7.1 X+0 51 CYCL DEF 7.3 Z+0 53 LBL 0 End of subprogram	41 LP PR+Q16 PA+Q24 FQ11	Move on an approximated arc for the next longitudinal cut
44 FN 1: Q24 = +Q24 + +Q25 45 FN 12: IF +Q20 LT +Q13 GOTO LBL 1 46 LBL 99 47 CYCL DEF 10.0 ROTATION 48 CYCL DEF 10.1 ROT+0 49 CYCL DEF 7.0 DATUM SHIFT 50 CYCL DEF 7.1 X+0 51 CYCL DEF 7.2 Y+0 52 CYCL DEF 7.3 Z+0 End of subprogram	42 L Y+0 R0 FQ12	Longitudinal cut in Y- direction
45 FN 12: IF +Q20 LT +Q13 GOTO LBL 1 46 LBL 99 47 CYCL DEF 10.0 ROTATION A8 CYCL DEF 10.1 ROT+0 49 CYCL DEF 7.0 DATUM SHIFT For CYCL DEF 7.1 X+0 51 CYCL DEF 7.2 Y+0 52 CYCL DEF 7.3 Z+0 End of subprogram	43 FN 1: Q20 = +Q20 + +1	Update the counter
46 LBL 99 47 CYCL DEF 10.0 ROTATION Reset the rotation 48 CYCL DEF 10.1 ROT+0 49 CYCL DEF 7.0 DATUM SHIFT Reset the datum shift 50 CYCL DEF 7.1 X+0 51 CYCL DEF 7.2 Y+0 52 CYCL DEF 7.3 Z+0 End of subprogram	44 FN 1: Q24 = +Q24 + +Q25	Update solid angle
47 CYCL DEF 10.0 ROTATION 48 CYCL DEF 10.1 ROT+0 49 CYCL DEF 7.0 DATUM SHIFT Feset the datum shift 50 CYCL DEF 7.1 X+0 51 CYCL DEF 7.2 Y+0 52 CYCL DEF 7.3 Z+0 End of subprogram	45 FN 12: IF +Q20 LT +Q13 GOTO LBL 1	Unfinished? If not finished, return to LBL 1
48 CYCL DEF 10.1 ROT+0 49 CYCL DEF 7.0 DATUM SHIFT 50 CYCL DEF 7.1 X+0 51 CYCL DEF 7.2 Y+0 52 CYCL DEF 7.3 Z+0 End of subprogram	46 LBL 99	
49 CYCL DEF 7.0 DATUM SHIFT 50 CYCL DEF 7.1 X+0 51 CYCL DEF 7.2 Y+0 52 CYCL DEF 7.3 Z+0 End of subprogram	47 CYCL DEF 10.0 ROTATION	Reset the rotation
50 CYCL DEF 7.1 X+0 51 CYCL DEF 7.2 Y+0 52 CYCL DEF 7.3 Z+0 53 LBL 0 End of subprogram	48 CYCL DEF 10.1 ROT+0	
51 CYCL DEF 7.2 Y+0 52 CYCL DEF 7.3 Z+0 53 LBL 0 End of subprogram	49 CYCL DEF 7.0 DATUM SHIFT	Reset the datum shift
52 CYCL DEF 7.3 Z+0 53 LBL 0 End of subprogram	50 CYCL DEF 7.1 X+0	
53 LBL 0 End of subprogram	51 CYCL DEF 7.2 Y+0	
	52 CYCL DEF 7.3 Z+0	
54 END PGM CYLIN	53 LBL 0	End of subprogram
	54 END PGM CYLIN	

Example: Convex sphere machined with end mill

Program run

- NC program requires an end mill.
- The contour of the sphere is approximated by many short line segments (in the Z/X plane, defined in Q14). The smaller you define the angle increment, the smoother the curve becomes.
- You can determine the number of contour cuts through the angle increment in the plane (defined in Q18).
- The tool moves upward in three-dimensional cuts.
- The tool radius is compensated automatically



0 BEGIN PGM SPHERE MM	
1 FN 0: Q1 = +50	Center in X axis
2 FN 0: Q2 = +50	Center in Y axis
3 FN 0: Q4 = +90	Starting angle in space (Z/X plane)
4 FN 0: Q5 = +0	End angle in space (Z/X plane)
5 FN 0: Q14 = +5	Angle increment in space
6 FN 0: Q6 = +45	Sphere radius
7 FN 0: Q8 = +0	Starting angle of rotational position in the X/Y plane
8 FN 0: Q9 = +360	End angle of rotational position in the X/Y plane
9 FN 0: Q18 = +10	Angle increment in the X/Y plane for roughing
10 FN 0: Q10 = +5	Allowance in sphere radius for roughing
11 FN 0: Q11 = +2	Set-up clearance for pre-positioning in the spindle axis
12 FN 0: Q12 = +350	Feed rate for milling
13 BLK FORM 0.1 Z X+0 Y+0 Z-50	Workpiece blank definition
14 BLK FORM 0.2 X+100 Y+100 Z+0	
15 TOOL CALL 1 Z S4000	Tool call
16 L Z+250 RO FMAX	Retract the tool
17 CALL LBL 10	Call machining operation
18 FN 0: Q10 = +0	Reset allowance
19 FN 0: Q18 = +5	Angle increment in the X/Y plane for finishing
20 CALL LBL 10	Call machining operation
21 L Z+100 R0 FMAX M2	Retract the tool, end program
22 LBL 10	Subprogram 10: Machining operation
23 FN 1: Q23 = +q11 + +q6	Calculate Z coordinate for pre-positioning
24 FN 0: Q24 = +Q4	Copy starting angle in space (Z/X plane)
25 FN 1: Q26 = +Q6 + +Q108	Compensate sphere radius for pre-positioning
26 FN 0: Q28 = +Q8	Copy rotational position in the plane
27 FN 1: Q16 = +Q6 + -Q10	Account for allowance in the sphere radius
28 CYCL DEF 7.0 DATUM SHIFT	Shift datum to center of sphere
29 CYCL DEF 7.1 X+Q1	
30 CYCL DEF 7.2 Y+Q2	

22 CVCL DEE 40.0 POTATION	
32 CYCL DEF 10.0 ROTATION	Account for starting angle of rotational position in the plane
33 CYCL DEF 10.1 ROT+Q8	
34 LBL 1	Pre-position in the spindle axis
35 CC X+0 Y+0	Set pole in the X/Y plane for pre-positioning
36 LP PR+Q26 PA+Q8 R0 FQ12	Pre-position in the plane
37 CC Z+0 X+Q108	Set pole in the Z/X plane, offset by the tool radius
38 L Y+0 Z+0 FQ12	Move to working depth
39 LBL 2	
40 LP PR+Q6 PA+Q24 FQ12	Move upward on an approximated arc
41 FN 2: Q24 = +Q24 - +Q14	Update solid angle
42 FN 11: IF +Q24 GT +Q5 GOTO LBL 2	Inquire whether an arc is finished. If not finished, return to LBL 2
43 LP PR+Q6 PA+Q5	Move to the end angle in space
44 L Z+Q23 R0 F1000	Retract in the spindle axis
45 L X+Q26 R0 FMAX	Pre-position for next arc
46 FN 1: Q28 = +Q28 + +Q18	Update rotational position in the plane
47 FN 0: Q24 = +Q4	Reset solid angle
48 CYCL DEF 10.0 ROTATION	Activate new rotational position
49 CYCL DEF 10.0 ROT+Q28	
50 FN 12: IF +Q28 LT +Q9 GOTO LBL 1	
51 FN 9: IF +Q28 EQU +Q9 GOTO LBL 1	Unfinished? If not finished, return to LBL 1
52 CYCL DEF 10.0 ROTATION	Reset the rotation
53 CYCL DEF 10.1 ROT+0	
54 CYCL DEF 7.0 DATUM SHIFT	Reset datum shift
55 CYCL DEF 7.1 X+0	
56 CYCL DEF 7.2 Y+0	
57 CYCL DEF 7.3 Z+0	
58 LBL 0	End of subprogram
59 END PGM SPHERE MM	

Special functions

10.1 Overview of special functions

The control provides the following powerful special functions for a large number of applications:

Function	Description
Dynamic Collision Monitoring with integrated fixture management (option 40)	Page 378
Adaptive Feed Control AFC (option 45)	Page 382
Active Chatter Control (option 145)	See the User's Manual for Setup, Testing and Running NC Programs
Working with text files	Page 436
Working with freely definable tables	Page 440

Press the **SPEC FCT** key and the corresponding soft keys to access further special functions of the control. The following tables give you an overview of which functions are available.

Main menu for SPEC FCT special functions




▶ Press the **SPEC FCT** key to select the special functions

0.41	F	D
Soft key	Function	Description
FUNCTION MODE	Select machining mode or kinematics	Page 377
PROGRAM DEFAULTS	Define program defaults	Page 375
CONTOUR + POINT MACHINING	Functions for contour and point machining	Page 375
TILT MACHINING PLANE	Define the PLANE function	Page 462
PROGRAM FUNCTIONS	Define different conversational functions	Page 376
TURNING PROGRAM FUNCTIONS	Define turning functions	Page 573
PROGRAM- MING AIDS	Programming aids	Page 197




After pressing the **SPEC FCT** key, you can open the **smartSelect** selection window with the **GOTO** key. The control displays a structure overview with all available functions. You can rapidly navigate with the cursor or mouse and select functions in the tree diagram. The control displays online help for the selected function in the window on the right.



Program defaults menu

PROGRAM DEFAULTS Press the Program Defaults soft key

Soft key	Function	Description
BLK FORM	Define workpiece blank	Page 93
PRESET	Modifying the preset	Page 418
SELECT DATUM TABLE	Select datum table	Page 424
SELECT COMPENS. TABLE	Select compensation table	Page 427
GLOBAL DEF	Define global cycle parameters	See the User's Manual for Programming of Machining Cycles




Functions for contour and point machining menu

CONTOUR + POINT MACHINING Press the soft key for functions for contour and point machining

Soft key	Function
DECLARE	Assign contour description
CONTOUR	Define a simple contour formula
SEL CONTOUR	Select a contour definition
CONTOUR	Define a complex contour formula
PATTERN DEF	Define regular machining pattern
SEL PATTERN	Select the point file with machining positions


Further information: User's Manual for Programming of Machining Cycles



Menu for defining different Klartext functions

▶ Press the **PROGRAM FUNCTIONS** soft key

Soft key	Function	Description
FUNCTION TCPM	Define the positioning behavior for rotary axes	Page 499
FUNCTION FILE	Define file functions	Page 406
FUNCTION PARAX	Define the positioning behavior for parallel axes U, V, W	Page 388
FUNCTION AFC	Define Adaptive Feed Control	Page 382
TRANSFORM / CORRDATA	Define coordinate transformations Activate compensation values	Page 409 Page 427
FUNCTION COUNT	Define the counter	Page 434
STRING FUNCTIONS	Define string functions	Page 323
FUNCTION DRESS	Define dressing mode	Page 604
FUNCTION SPINDLE	Define pulsing spindle speed	Page 447
FUNCTION FEED	Define recurring dwell time	Page 450
FUNCTION DCM	Define Dynamic Collision Monitoring DCM	Page 378
FUNCTION DWELL	Define dwell time in seconds or revolutions	Page 452
FUNCTION LIFTOFF	Lift off tool at NC stop	Page 453
INSERT	Add comments	Page 200
TABDATA	Write and read table values	Page 429
POLARKIN	Define polar kinematics	Page 399
MONITORING	Activate component monitoring	Page 433
FUNCTION PROG PATH	Choose path interpretation	Page 515



10.2 Function mode

Program function mode



Refer to your machine manual.

Your machine manufacturer enables this function.

To switch between milling and turning operations, you must switch to the respective mode.

If your machine manufacturer has enabled the selection of various kinematic models, then you can switch between them using the **FUNCTION MODE** soft key.

Procedure

To switch the kinematic model, proceed as follows:



▶ Show the soft-key row for special functions



▶ Press the **FUNCTION MODE** soft key



▶ Press the **MILL** soft key



- ▶ Press the **SELECT KINEMATICS** soft key
- Select the desired kinematic model

Function Mode Set



Refer to your machine manual.

This function must be enabled and adapted by the machine manufacturer.

Your machine tool builder defines the available options in the machine parameter **CfgModeSelect** (no. 132200).

FUNCTION MODE SET allows you to activate settings defined by the machine tool builder (e.g., changes to the range of traverse) from within the NC program

To select a setting:



Show the soft-key row with special functions



Press the FUNCTION MODE soft key



▶ Press the **SET** soft key



- ▶ Press the **SELECT** soft key, if required
- > The control opens a selection window.
- Select the desired setting

10.3 Dynamic Collision Monitoring (option 40)

Function



Refer to your machine manual.

The machine manufacturer needs to adapt the (Dynamic Collision Monitoring) function to the control.

The machine manufacturer can define machine components and minimum distances that are to be monitored by the control during all machine movements. If two objects monitored for collision come within a defined minimum distance of each other, the control generates an error message and terminates the movement.

The control also monitors the active tool for collision and displays the situation graphically. The control always assumes cylindrical tools. The control likewise monitors stepped tools according to their definition in the tool table.

The control takes into account the following definitions from the tool table:

- Tool lengths
- Tool radii
- Tool oversizes
- Tool carrier kinematics

NOTICE


Danger of collision!

Even if **Dynamic Collision Monitoring (DCM)** is active, the control does not automatically monitor the workpiece for collisions, be it with the tool or with other machine components. There is a danger of collision during machining!

- ▶ Check the machining sequence using a graphic simulation
- Perform a Test Run with extended collision monitoring
- Carefully test the NC program or program section in Program run, single block operating mode

Collision monitoring is activated separately for the following operating modes:

- Program Run
- Manual Operation
- Test Run



NOTICE

Danger of collision!

If the **Dynamic Collision Monitoring (DCM)** function is inactive, the control does not perform any automatic collision checking. This means that movements that might cause collisions will not be prevented. There is a danger of collision during all movements!

- ▶ Make sure to activate collision monitoring whenever possible
- Make sure to always re-activate collision monitoring after a temporary deactivation
- With collision monitoring deactivated, carefully test the NC program or program section in the **Program run, single block** operating mode



Generally valid constraints:

- The function helps reduce the danger of collision.
 However, the control cannot consider all possible constellations during operation.
- The control can protect only those machine components from collision that your machine manufacturer has defined correctly with regard to dimensions, orientation, and position.
- The control can only monitor tools for which you have defined **positive tool radii** and **positive tool lengths** in the tool table.
- DL and DR tool oversizes from the tool table are taken into account by the control. Tool oversizes from the TOOL CALL block are not accounted for.
- For certain tools (such as face milling cutters), the radius that would cause a collision can be greater than the value defined in the tool table.
- When a touch probe cycle starts, the control no longer monitors the stylus length and ball-tip diameter so that you can also probe collision objects.

Activating and deactivating collision monitoring in the NC program

In some cases it is necessary to temporarily deactivate collision monitoring:

- To reduce the distance between two objects monitored for collision
- To prevent stops during program runs

NOTICE

Danger of collision!

If the function is inactive, the control will not perform any automatic check for collisions. This means that movements that might cause collisions will not be prevented. There is a danger of collision during all movements!

- ▶ Make sure to activate collision monitoring whenever possible
- Make sure to always re-activate collision monitoring after a temporary deactivation
- With collision monitoring deactivated, carefully test the NC program or program section in the **Program run, single block** operating mode

Temporarily activating and deactivating collision monitoring via program control

- ▶ Open the NC program in **Programming** operating mode
- ► Place the cursor at the desired position (e.g., before Cycle **800**) to enable eccentric turning



▶ Press the **SPEC FCT** key



Press the PROGRAM FUNCTIONS soft key



► Shift the soft-key row



▶ Press the **FUNCTION DCM** soft key



Select the condition with the corresponding soft key:



- FUNCTION DCM OFF: This NC command temporarily deactivates collision monitoring. The deactivation is effective only until the end of the main program or until the next FUNCTION DCM ON. When another NC program is called, DCM is active again.
- **FUNCTION DCM ON**: This NC command cancels an existing **FUNCTION DCM OFF**.



The settings applied with the **FUNCTION DCM** function are only effective in the active NC program.

After terminating the program run or selecting a new NC program, the settings made for **Program run** and **Manual operation** with the **COLLISION** soft key become effective again.



Further information: User's Manual for **Setup, Testing and Running NC Programs**

10.4 Adaptive Feed Control (AFC) (option 45)

Application



This function must be enabled and adapted by the machine manufacturer.

Your machine tool builder may also specify whether the spindle power or any other value is used as input quantity by the control.

If you have enabled the software option for turning (Option 50), you can use AFC in turning mode as well.



Adaptive feed control is not intended for tools with diameters less than 5 mm. If the rated power consumption of the spindle is very high, the limit diameter of the tool may be larger.

Do not work with adaptive feed control in operations in which the feed rate and spindle speed must be adapted to each other, such as tapping.


In adaptive feed control the control automatically controls the feed rate during NC program run as a function of the current spindle power. The spindle power required for each machining step is to be determined in a teach-in cut and saved by the control in a file belonging to the NC program. At the start of each machining step, usually when the spindle is switched on, the control controls the feed rate so that it remains within the limits that you have defined.



If the cutting conditions do not change, you can define the spindle power consumption, which has been determined in a teach-in cut, as permanent tool-dependent reference power. Use the **AFC-LOAD** column in the tool table to do this. If you enter a value manually in this column, the control does not execute any more teach-in cuts.

This makes it possible to avoid negative effects on the tool, the workpiece, and the machine that might be caused by changing cutting conditions. Cutting conditions are changed particularly by:

- Tool wear
- Fluctuating cutting depths that occur especially with cast parts
- Fluctuating hardness caused by material flaws



Adaptive feed control (AFC) has the following advantages:

- Optimization of machining time By controlling the feed rate, the control tries to maintain the previously recorded maximum spindle power or the reference power specified in the tool table (AFC-LOAD column) during the entire machining time. It shortens the machining time by increasing the feed rate in machining zones with little material removal.
- Tool monitoring

 If the spindle power exceeds the recorded or specified maximum value (AFC-LOAD column of the tool table), the control decreases the feed rate until the reference spindle power is reached again. If the maximum spindle power is exceeded during machining and at the same time the feed rate falls below the minimum that you
- Protection of the machine's mechanical elements
 Timely feed rate reduction and shutdown responses help to avoid machine overload.

have defined, the control reacts by shutting down. This helps to prevent further damage after a tool breaks or is worn out.

Defining basic AFC settings

In the **AFC.TAB** table, you can enter the feed rate control settings to be used by the control. This table must be saved in the **TNC:\table** directory.

The data in this table are default values that are copied into a file belonging to the respective NC program during a teach-in cut. The values act as the basis for feedback control.



If you define a tool-specific feedback-control reference power using the **AFC-LOAD** column in the tool table, the control generates the associated file for the relevant NC program without a teach-in cut. The file is created shortly before feedback control becomes effective.

Overview

Enter the following data in the table:

Column	Function
NR	Consecutive row number in the table (has no other functions)
AFC	Name of the control setting. Enter this name in the AFC column of the tool table. It specifies the assignment of control parameters to the tool.
FMIN	Feed rate at which the control is to conduct a overload reaction. Enter the value in percent with respect to the programmed feed rate. Input range: 50 to 100 %
FMAX	Maximum feed rate in the material up to which the control can automatically increase the feed rate. Enter the value in percent of the programmed feed rate.
FIDL	Feed rate for traverse if the tool is not cutting. Enter the value in percent of the programmed feed rate.
FENT	Feed rate for traverse if the tool moves into or out of the material. Enter the value in percent with respect to the programmed feed rate. Maximum input value: 100 %
OVLD	Desired reaction of the control to overload:
	■ M: Execution of a macro defined by the machine manufacturer
	■ S: Immediate NC stop
	F: NC stop once the tool has been retracted
	■ E: Just display an error message on the screen
	■ L: Disable active tool
	-: No overload response
	If the maximum spindle power is exceeded for more than one second and the feed rate falls below the defined minimum during that time, the control will conduct an overload response.
	In conjunction with the cut-related tool wear monitoring function, the control will only evaluate the options ${\bf M}, {\bf E},$ and ${\bf L}!$
	Further information: User's Manual for Setup, Testing and Running NC Programs
POUT	Spindle power at which the control is to detect that the tool moves out of the workpiece. Enter the value in percent of the learned reference load. Recommended input value: 8 %
SENS	Sensitivity (aggressiveness) of regulation. A value between 50 and 200 can be entered. 50 is for slow control, 200 for a very aggressive control. An aggressive control reacts quickly and with strong changes to the values, but it tends to overshoot. Recommended value: 100
PLC	Value that the control is to transfer to the PLC at the beginning of a machining step. The machine manufacturer defines the function, so refer to your machine manual.

Creating the AFC.TAB table

If the AFC.TAB table does not yet exist, you need to create it.



In the **AFC.TAB** table you can define as many control settings (lines) as desired.

If there is no AFC.TAB table in the **TNC:\table** directory, the control uses a permanently defined, internal control setting for the teach-in cut. If, alternatively, a tool-dependent reference power value exists, the control uses it immediately. HEIDENHAIN recommends using the AFC.TAB table in order to ensure safe and well-defined operation.

To create the AFC. TAB table:

- ▶ Select the **Programming** operating mode
- ▶ Press the **PGM MGT** key to select the file manager
- ▶ Select the **TNC:** drive
- ▶ Select the **table** directory
- ► Create a new **AFC.TAB** file
- ► Confirm with the **ENT** key
- > The control displays a list with table formats.
- Select the AFC.TAB table format and confirm with the ENT key
- > The control creates the table that contains the control settings.

Programming AFC

NOTICE

Caution: Danger to the tool and workpiece!

If you activate the **FUNCTION MODE TURN** machining mode, the control will clear the current **OVLD** values. This means that you need to program the machining mode before the tool call! If the programming sequence is not correct, no tool monitoring will take place, which might result in damage to the tool or workpiece!

 Program the FUNCTION MODE TURN machining mode before the tool call

To program the AFC functions for starting and ending the teach-in cut:



▶ Press the **SPEC FCT** key



▶ Press the **PROGRAM FUNCTIONS** soft key



- Press the FUNCTION AFC soft key
- Select the function

The control provides several functions that enable you to start and stop AFC:

- **FUNCTION AFC CTRL**: The **AFC CTRL** function activates feedback control mode starting with this NC block, even if the learning phase has not been completed yet.
- FUNCTION AFC CUT BEGIN TIME1 DIST2 LOAD3: The control starts a sequence of cuts with active AFC. The changeover from the teach-in cut to feedback control mode begins as soon as the reference power has been determined in the teach-in phase, or once one of the TIME, DIST or LOAD conditions has been met.
 - With **TIME**, you define the maximum duration of the teach-in phase in seconds.
 - **DIST** defines the maximum distance for the teach-in cut.
 - With LOAD, you can set a reference load directly. If you enter a reference load > 100 %, the control automatically limits the value to 100 %.
- **FUNCTION AFC CUT END**: The **AFC CUT END** function deactivates the AFC control.



The **TIME**, **DIST** and **LOAD** defaults are modally effective. They can be reset by entering **0**.



You can define a feedback-control reference power with the AFC LOAD tool table column and the LOAD input in the NC program. You can activate the AFC LOAD value via the tool call and the LOAD value with the FUNCTION AFC CUT BEGIN function.

If you program both values, the control will use the value programmed in the NC program!

Opening the AFC table

With a teach-in cut, the control at first copies the basic settings for each machining step, as defined in the AFC.TAB table, to a file called <name>.H.AFC.DEP. <name> is the name of the NC program for which you have recorded the teach-in cut. In addition, the control measures the maximum spindle power consumed during the teach-in cut and saves this value in the table.

You can change the <name>.H.AFC.DEP file in Programming operating mode.

If necessary, you can even delete a machining step (entire line) there.



The **dependentFiles** machine parameter (no. 122101) must be set to **MANUAL** so that you can view the dependent files in the file manager.

In order to edit the <name>.H.AFC.DEP file, you must first configure the file manager to display all file types (SELECT TYPE soft key).

Further information: "Files", Page 108



Further information: User's Manual for **Setup, Testing and Running NC Programs**

10.5 Working with the parallel axes U, V and W

Overview




Refer to your machine manual.

Your machine must be configured by the machine manufacturer if you want to use parallel-axis functions. The number, designation and assignment of the programmable axes depend on the machine.

In addition to the main axes X, Y, and Z, the parallel axes U, V, and W, are available.

Main axes and parallel axes are usually assigned to each other as follows:

Main axis	Parallel axis	Rotary axis
X	U	A
Υ	V	В
Z	W	С



The control provides the following functions for machining with the parallel axes U, V and W:

Soft key	Function	Meaning	Page
FUNCTION PARAXCOMP	PARAXCOMP	Define the control's behavior when positioning parallel axes	394
FUNCTION PARAXMODE	PARAXMODE	Define the axes the control will use for machining	395



You must deactivate the parallel-axis functions before switching the machine kinematics.

You can deactivate the programming of parallel axes with the machine parameter **noParaxMode** (no. 105413).



Automatic offsetting of parallel axes



In the machine parameter **parAxComp** (no. 300205), your machine manufacturer specifies whether the parallel axis function is active by default.

After the control has booted, the configuration defined by the machine manufacturer is in effect.

Check whether one of the icons for PARAXCOMP DISPLAY or PARAXCOMP MOVE is shown in the status display:



or



If the machine manufacturer has already enabled the parallel axis in the configuration, the control takes this axis into account in the calculations, without you having to program **PARAXCOMP**.

Since the control then continuously offsets the parallel axis, you can for example probe a workpiece even with any position of the W axis.



Please note that **PARAXCOMP OFF** does not deactivate the parallel axis in this case, but the control reactivates the standard configuration.

The control deactivates automatic calculation only if you include the axis in the NC block (e.g. **PARAXCOMP OFF W**).

FUNCTION PARAXCOMP DISPLAY

Use the **PARAXCOMP DISPLAY** function to activate the display function for parallel axis movements. The control includes movements of the parallel axis in the position display of the associated main axis (sum display). Therefore, the position display of the main axis always displays the relative distance from the tool to the workpiece, regardless of whether you move the main axis or the parallel axis.

To program this behavior:



Show the soft-key row with special functions



Press the PROGRAM FUNCTIONS soft key



▶ Press the **FUNCTION PARAX** soft key



▶ Press the **FUNCTION PARAXCOMP** soft key



- Select the FUNCTION PARAXCOMP DISPLAY function
- Define the parallel axis whose movements the control is to take into account in the position display of the associated main axis

Example

13 FUNCTION PARAXCOMP DISPLAY W

When **FUNCTION PARAXCOMP DISPLAY** is active, the control displays an icon in the status display.

lcon	Mode
	FUNCTION PARAXCOMP DISPLAY is active
**	The PARAXMODE icon hides the active PARAXCOMP DISPLAY icon.
	In the additional status display, the control also shows (D) for DISPLAY after the designations of the affected axes.
No icon	Standard kinematics is active



The machine manufacturer uses the optional machine parameter **presetToAlignAxis** (no. 300203) to define for each axis how the control is to interpret offset values. For **FUNCTION PARAXCOMP**, the machine parameter applies to the parallel axes (**U_OFFS**, **V_OFFS**, and **W_OFFS**) only. If there are no offsets, the control behaves as described in the functional description.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

- If the machine parameter has not been defined for the parallel axis or has been defined with FALSE, the offset is only active in the parallel axis. The preset of the programmed parallel-axis coordinates is shifted by the offset value. The coordinates of the main axis still reference the workpiece preset.
- If the machine parameter for the parallel axis has been defined with TRUE, the offset will be active in the parallel and main axes. The presets of the programmed parallel and main axis coordinates are shifted by the offset value.

FUNCTION PARAXCOMP MOVE



The **PARAXCOMP MOVE** function can be used only in connection with straight-line blocks (**L**).

The control uses the **PARAXCOMP MOVE** function to compensate for movements of a parallel axis by performing compensation movements in the associated main axis.

For example, if a parallel-axis movement is performed in the negative W-axis direction, the main axis Z is moved simultaneously in the positive direction by the same value. The relative distance from the tool to the workpiece remains the same. Application in gantry-type milling machines: Retract the spindle sleeve to move the cross beam down simultaneously.

To program this behavior:



► Show the soft-key row with special functions



Press the PROGRAM FUNCTIONS soft key



Press the FUNCTION PARAX soft key



► Press the **FUNCTION PARAXCOMP** soft key



- Select the FUNCTION PARAXCOMP MOVE function
- Define the parallel axis

Example

13 FUNCTION PARAXCOMP MOVE W

When **FUNCTION PARAXCOMP MOVE** is active, the control displays an icon in the status display.

Icon	Mode
	FUNCTION PARAXCOMP MOVE is active
	The PARAXMODE icon hides the active PARAXCOMP MOVE icon.
	In the additional status display, the control also shows (M) for MOVE after the designations of the affected axes.
No icon	Standard kinematics is active



Possible offset values (U_OFFS, V_OFFS, and W_OFFS from the preset table) to be taken into account will be specified by your machine manufacturer in the machine parameter **presetToAlignAxis** (no. 300203).

Further information: User's Manual for **Setup, Testing and Running NC Programs**

- If the machine parameter has not been defined for the parallel axis or has been defined with FALSE, the offset is only active in the parallel axis. The preset of the programmed parallel-axis coordinates is shifted by the offset value. The coordinates of the main axis still reference the workpiece preset.
- If the machine parameter for the parallel axis has been defined with TRUE, the offset will be active in the parallel and main axes. The presets of the programmed parallel and main axis coordinates are shifted by the offset value.

Deactivating FUNCTION PARAXCOMP



After the control has booted, the configuration defined by the machine manufacturer is in effect.

Check whether one of the icons for PARAXCOMP DISPLAY or PARAXCOMP MOVE is shown in the status display:



0



The following actions cause the control to reset the **PARAXCOMP** parallel-axis function:

- Selection of NC program
- PARAXCOMP OFF

You must deactivate the parallel-axis functions before switching the machine kinematics.

Use the **PARAXCOMP OFF** function to switch off the **PARAXCOMP DISPLAY** and **PARAXCOMP MOVE** parallel-axis functions. Proceed as follows for the definition:



Show the soft-key row with special functions



Press the PROGRAM FUNCTIONS soft key



Press the FUNCTION PARAX soft key



▶ Press the **FUNCTION PARAXCOMP** soft key



- ► Select FUNCTION PARAXCOMP OFF
- Enter an axis, if required

Example

13 FUNCTION PARAXCOMP OFF

13 FUNCTION PARAXCOMP OFF W

When **FUNCTION PARAXCOMP** is not active, the control does not display the corresponding icon and the additional information after the axis designations.



In a machine parameter, your machine manufacturer can set the **PARAXCOMP** function to be active by default.

If you want to switch the function off, you must indicate the parallel axis in the NC block, for example **FUNCTION PARAXCOMP OFF W**.

Further information: "Automatic offsetting of parallel axes", Page 389

FUNCTION PARAXMODE



To activate the **PARAXMODE** function, you must always define three axes.

If your machine manufacturer has not yet activated the **PARAXCOMP** function as default, you must activate **PARAXCOMP** before you can work with **PARAXMODE**.

In order for the control to offset the main axis deselected with **PARAXMODE**, enable the **PARAXCOMP** function for this axis.

Use the **PARAXMODE** function to define the axes the control is to use for machining. You program all traverses and contour descriptions in the main axes X, Y and Z, independent of your machine.

Define three axes with the **PARAXMODE** function (e.g., **FUNCTION PARAXMODE X Y W**) to be used by the control for programmed traverses.

To program this behavior:



▶ Show the soft-key row for special functions



▶ Press the **PROGRAM FUNCTIONS** soft key



Press the FUNCTION PARAX soft key



▶ Press the **FUNCTION PARAXMODE** soft key



- Select FUNCTION PARAXMODE
- Define the axes for machining

Example

13 FUNCTION PARAXMODE X Y W

When **FUNCTION PARAXMODE** is active, the control shows an icon in the status display.

Icon

Mode



FUNCTION PARAXMODE is active



The **PARAXMODE** icon hides the active **PARAXCOMP** icon.

The control additionally displays the selected **Principal axes** on the **POS** tab of the additional status display.

No icon

Standard kinematics is active

Moving the main axis and the parallel axis

If the **PARAXMODE** function is active, the control uses the axes defined in the function to execute the programmed traverses. If the control is to move the main axis deselected by **PARAXMODE**, you can identify this axis by additionally entering the & character. The & character then refers to the main axis.

Proceed as follows:



- ▶ Press the **L** key
- > The control opens a linear block.
- Define the required coordinates
- ▶ Define radius compensation



- Press the left arrow key
- > The control displays the & character.
- If applicable, use the axis-direction keys to select the desired axis
- Define the required coordinate



► Press the **ENT** key

Example

13 FUNCTION PARAXMODE X Y W

14 L Z+100 &Z+150 RO FMAX



The & syntax element is only permitted in L blocks.

Additional positioning of a main axis with the & command is done in the REF system. If you have set the position display to display ACTUAL values, this movement will not be shown. If necessary, switch the position display to REF

Your machine manufacturer will define the calculation of possible offset values (X_OFFS, Y_OFFS and Z_OFFS from the preset table) for the axes positioned with the **&** operator in the **presetToAlignAxis** machine parameter (no. 300203).

- If the machine parameter has not been defined for the main axis or has been defined with **FALSE**, the offset only applies to the axis programmed with **&**. The coordinates of the parallel axis still reference the workpiece preset. Despite the offset, the parallel axis will move to the programmed coordinates.
- If the machine parameter for the main axis has been defined with TRUE, the offset applies to the main axis and the parallel axis. The presets of the main and parallel axis coordinates are shifted by the offset value.

Deactivating FUNCTION PARAXMODE



After the control has booted, the configuration defined by the machine manufacturer is in effect.

Check whether one of the icons for PARAXCOMP DISPLAY or PARAXCOMP MOVE is shown in the status display:



OI



The control resets the **PARAXMODE ON** parallel-axis function via the following functions:

- Selection of an NC program
- End of program
- M2 and M30
- PARAXMODE OFF

You must deactivate the parallel-axis functions before switching the machine kinematics.

Use the **PARAXCOMP OFF** function to deactivate the parallelaxis function. The control then uses the main axes defined by the machine manufacturer.

To program this behavior:



Show the soft-key row with special functions



Press the PROGRAM FUNCTIONS soft key



Press the FUNCTION PARAX soft key



▶ Press the **FUNCTION PARAXMODE** soft key



► Select FUNCTION PARAXMODE OFF

Example

13 FUNCTION PARAXMODE OFF

When **FUNCTION PARAXMODE** is not active, the control does not display the corresponding icon or entries on the **POS** tab.



Depending on the configuration by the machine manufacturer, an active **PARAXCOMP** icon that was previously hidden by the **PARAXMODE** icon will then become visible.

Example: Drilling with the W axis

0 BEGIN PGM PAR MM		
1 BLK FORM 0.1 Z X+0 Y+0 Z-20		
2 BLK FORM 0.2 X+100 Y+100 Z+0		
3 TOOL CALL 5 Z S2	222	Call the tool in the spindle axis Z
4 L Z+100 R0 FMAX	M3	Position the principal axis
5 CYCL DEF 200 DRI	LLING	
Q200=+2	;SET-UP CLEARANCE	
Q201=-20	;DEPTH	
Q206=+150	;FEED RATE FOR PLNGNG	
Q202=+5	;PLUNGING DEPTH	
Q210=+0	;DWELL TIME AT TOP	
Q203=+0	;SURFACE COORDINATE	
Q204=+50	;2ND SET-UP CLEARANCE	
Q211=+0	;DWELL TIME AT DEPTH	
Q395=+0	;DEPTH REFERENCE	
6 FUNCTION PARAXO	COMP DISPLAY Z	Activate display compensation
7 FUNCTION PARAXA	AODE X Y W	Positive axis selection
8 L X+50 Y+50 R0 FMAX M99		Infeed in the parallel axis W
9 FUNCTION PARAXMODE OFF		Restore the standard configuration
10 L M30		
11 END PGM PAR MM		

10.6 Machining with polar kinematics

Overview

In a polar kinematic model, the path contours of the working plane are performed by one linear axis and one rotary axis instead of by two linear principal axes. The working plane is defined by the linear principal axis and the rotary axis while the working space is defined by these two axes and the infeed axis.

On turning and grinding machines that have only two linear principal axes, polar kinematics enable milling operations to be performed on the front face.

On milling machines, various linear principal axes can be replaced with suitable rotary axes. For example on large machines, polar kinematics enable you to machine much larger surfaces than with only the principal axes.




Refer to your machine manual.

Your machine must be configured by the machine tool builder so that you can use polar kinematics.

A polar kinematic model consists of two linear axes and one rotary axis. The programmable axes vary depending on the machine.

The polar rotary axis must be installed onto the table side so that it is opposite the selected linear axes and must be configured as a modulo axis. Thus, the linear axes must not be positioned between the rotary axis and the table. The maximum range of traverse of the rotary axis is limited by the software limit switches if necessary.

The principal axes X, Y, and Z as well as the possible parallel axes U, V, and W can be used as radial axes or infeed axes.



The control, combined with polar kinematics, provides the following functions:


Soft key	Function	Meaning	Page
POLARKIN AXES	POLARKIN AXES	Define and activate polar kinematics	400
POLARKIN OFF	POLARKIN OFF	Deactivate polar kinematics	403

Activating FUNCTION POLARKIN

Use the **POLARKIN AXES** function to activate the polar kinematics. The axis data define the radial axis, the infeed axis, and the polar axis. The **MODE** data influence the positioning behavior, whereas the **POLE** data define the machining at the pole. The pole is the center of rotation of the rotary axis in this case.

Notes on the axes to be selected:

- The first linear axis must be radial to the rotary axis.
- The second linear axis defines the infeed axis and must be parallel to the rotary axis.
- The rotary axis defines the polar axis and is defined last.
- Any available modulo axis that is installed at the table opposite to the selected linear axes can be used as the rotary axis.
- The two selected linear axes thus span a plane that also includes the rotary axis.



MODE options:

Syntax	Function
POS	Seen from the center of rotation, the control performs machining in the positive direction of the radial axis.
	The radial axis must be prepositioned correspondingly.
NEG	Seen from the center of rotation, the control performs machining in the negative direction of the radial axis.
	The radial axis must be prepositioned correspondingly.
KEEP	The control remains with the radial axis on that side of the center of rotation on which the axis was positioned when the function was activated.
	If the radial axis is positioned at the center of rotation upon switch-on, POS applies.
ANG	The control remains with the radial axis on that side of the center of rotation on which the axis was positioned when the function was activated.
	If you set POLE to ALLOWED , positioning through the pole is possible. The pole side is changed and a 180-degree rotation of the rotary axis is prevented.

POLE options:

Syntax	Function	
ALLOWED	The control permits machining operations at the pole	
SKIPPED	The control prevents machining operations at the pole	
	The disabled area corresponds to a circular surface with a radius of 0.001 mm (1 µm) around the pole.	

To program this behavior:



▶ Show the soft-key row with special functions



▶ Press the **PROGRAM FUNCTIONS** soft key



Press the POLARKIN soft key



- ▶ Press the **POLARKIN AXES** soft key
- Define the axes of the polar kinematics
- ► Select the **MODE** option
- ► Select the **POLE** option

Example

6 POLARKIN AXES X Z C MODE: KEEP POLE:ALLOWED

If polar kinematics is active, the control displays an icon in the status display.

Icon

Mode



Polar kinematics is active



The **POLARKIN** icon hides the active **PARAXCOMP DISPLAY** icon.

The control additionally displays the selected **Principal axes** on the **POS** tab of the additional status display.

No icon

Standard kinematics is active

Notes

Programming notes:

Before activating the polar kinematics, you must program the function PARAXCOMP DISPLAY with at least the main axes X, Y, and Z.



HEIDENHAIN recommends defining all of the available axes within the **PARAXCOMP DISPLAY** function.

- Position the linear axis that will not be included in the polar kinematics to the coordinate of the pole, before the **POLARKIN** function. Otherwise, a non-machinable area with a radius that corresponds to at least the value of the deselected linear axis would result.
- Avoid performing machining operations at the pole or near the pole, because feed-rate variations may occur in this area. For this reason, ideally use the following POLE option: SKIPPED.
- Polar kinematics cannot be combined with the following functions:
 - Traverses with M91
 - Tilting the working plane
 - FUNCTION TCPM or M128
- The machine manufacturer uses the optional machine parameter **presetToAlignAxis** (no. 300203) to define for each axis how the control is to interpret offset values. For **FUNCTION POLARKIN**, the machine parameter applies only to the rotary axis that rotates about the tool axis (in most cases **C_OFFS**).

Further information: User's Manual for Setup, Testing and Running NC Programs

If the machine parameter axis has not been defined or has been set to TRUE, the offset can be used to compensate a misalignment of the workpiece in the plane. The offset affects the orientation of the workpiece coordinate system W-CS.

Further information: "Workpiece coordinate system W-CS", Page 82

If the machine parameter axis has been defined with FALSE, the offset cannot be used to compensate a misalignment of the workpiece in the plane. The control will not take the offset into account when executing the commands.

Machining information:

The polar kinematics may require continuous motions to be divided into submotions (e.g., a linear motion that is divided into two submotions: a motion for approaching the pole and a motion for departing from the pole). As a result, the distance-to-go display may differ from that of the standard kinematics.

Deactivating FUNCTION POLARKIN

Use the **POLARKIN OFF** function to deactivate the polar kinematics. Program this as follows:



► Show the soft key row with special functions



▶ Press the **PROGRAM FUNCTIONS** soft key



Press the **POLARKIN** soft key



Press the POLARKIN OFF soft key

Example

6 POLARKIN OFF

When the polar kinematics is not active, the control does not display the corresponding icon or entries on the **POS** tab.

Note

The following scenarios lead to deactivation of the polar kinematics:

- Execution of the **POLARKIN OFF** function
- Selection of an NC program
- Reaching the end of the NC program
- Abortion of the NC program
- Selecting a kinematic model
- Restarting the control

Example: SL cycles in the polar kinematics

Example. SE Cycl	es in the polar killematics	
0 BEGIN PGM POLARKIN_SL MM		
1 BLK FORM 0.1 Z X-100 Y-100 Z-30		
2 BLK FORM 0.2 X+100 Y+100 Z+0		
3 TOOL CALL 2 Z S2000 F750		
4 FUNCTION PARAX	COMP DISPLAY X Y Z	; Activate PARAXCOMP DISPLAY
5 L X+0 Y+0.0011	Z+10 A+0 C+0 FMAX M3	; Pre-position outside the disabled pole area
6 POLARKIN AXES Y	Z C MODE:KEEP POLE:SKIPPED	; Activate POLARKIN
*		; Datum shift in polar kinematics
9 TRANS DATUM AXI	S X+50 Y+50 Z+0	
10 CYCL DEF 7.3 Z-	+0	
11 CYCL DEF 14.0 C	ONTOUR	
12 CYCL DEF 14.1 C	ONTOUR LABEL2	
13 CYCL DEF 20 CO	NTOUR DATA	
Q1=-10	;MILLING DEPTH	
Q2=+1	;TOOL PATH OVERLAP	
Q3=+0	;ALLOWANCE FOR SIDE	
Q4=+0	;ALLOWANCE FOR FLOOR	
Q5=+0	;SURFACE COORDINATE	
Q6=+2	;SET-UP CLEARANCE	
Q7=+50	;CLEARANCE HEIGHT	
Q8=+0	;ROUNDING RADIUS	
Q9=+1	;ROTATIONAL DIRECTION	
14 CYCL DEF 22 RO	UGH-OUT	
Q10=-5	;PLUNGING DEPTH	
Q11=+150	;FEED RATE FOR PLNGNG	
Q12=+500	;FEED RATE F. ROUGHNG	
Q18=+0	;COARSE ROUGHING TOOL	
Q19=+0	;FEED RATE FOR RECIP.	
Q208=+99999	;RETRACTION FEED RATE	
Q401=+100	;FEED RATE FACTOR	
Q404=+0	;FINE ROUGH STRATEGY	
15 M99		
16 CYCL DEF 7.0 DA	TUM SHIFT	
17 CYCL DEF 7.1 X+0		
18 CYCL DEF 7.2 Y+0		
19 CYCL DEF 7.3 Z+0		
20 POLARKIN OFF		; Deactivate POLARKIN
21 FUNCTION PARAXCOMP OFF X Y Z		; Deactivate PARAXCOMP DISPLAY
22 L X+0 Y+0 Z+10 A+0 C+0 FMAX		
23 L M30		
24 LBL 2		

25 L X-20 Y-20 RR	
26 L X+0 Y+20	
27 L X+20 Y-20	
28 L X-20 Y-20	
29 LBL 0	
30 END PGM POLARKIN_SL MM	

10.7 File functions

Application

The **FILE FUNCTION** functions are used to perform file operations such as copying, moving, and deleting files from within the NC program.



Programming and operating information:

- You must not use FILE functions on NC programs or files to which you have previously made reference with functions such as CALL PGM or CYCL DEF 12 PGM CALL.
- The FUNCTION FILE function is considered only in the Program run, single block and Program run, full sequence operating modes.

Defining file functions

Proceed as follows:



Press the special functions key



Select the program functions



- Select file operations
- > The control displays the available functions.

Soft key	Function	Meaning
FILE	FILE COPY	Copy file: Enter the name and path of the file to be copied, as well as the target path
FILE	FILE MOVE	Move file: Enter the name and path of the file to be moved, as well as the target path
FILE DELETE	FILE DELETE	Delete file: Enter the path and name of the file to be deleted
OPEN FILE	OPEN FILE	Open the file: Enter the name and path of the file

If you try to copy a file that does not exist, the control generates an error message.

FILE DELETE does not generate an error message if you try to delete a non-existing file.

OPEN FILE

Fundamentals

The **OPEN FILE** function allows you to open various file types directly from within the NC program.

If you define **OPEN FILE**, the control continues the dialog and you can program a **STOP**.

Using this function, the control can open all file types that you can open manually.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

The control opens the file in the software tool last used for this file type. If you have never opened a file of a certain file type and multiple software tools are available, the control will interrupt program run and open the **Application?** window. In the **Application?** window, you can select the software tool the control should use to open the file. The control saves this selection.

Multiple software tools are available for opening the following file types:

- CFG
- SVG
- BMP
- GIF
- JPG/JPEG
- PNG




In order to avoid program run interruptions or having to select an alternative software tool, open a file of the corresponding file type once in the file manager. If the files of a certain file type can be opened in multiple software tools, you can use the file manager to select the software tool to be used for opening files of this file type.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

The **OPEN FILE** function is available in the following operating modes:

- Positioning w/ Manual Data Input
- Test Run
- Program Run Single Block
- Program Run Full Sequence



Programming OPEN FILE

To program the **OPEN FILE** function:



Press the special functions key



Select the program functions



Select file operations



▶ Select the **OPEN FILE** function



The control initiates the dialog.



- ▶ Press the **SELECT FILE** soft key
- ► In the folder structure, select the file to be displayed



- Press the **OK** soft key.
- > The control displays the path of the selected file and the **STOP** function.
- Optionally, program STOP
- The control concludes the entry of the OPEN FILE function.

Automatic display

For the display of some file types, the control provides only one additional tool. With the **OPEN FILE** function, the control then automatically uses this tool to display files of these formats.

Example

1 OPEN FILE "TNC:\CLAMPING_INFORMATION.HTML"

HEROS tool that can be used for displaying:

Mozilla Firefox

10.8 NC functions for coordinate transformations

Overview

The control provides the following **TRANS** functions:

Syntax	Function	Further information
TRANS DATUM	Shift the workpiece datum	Page 409
TRANS MIRROR	Mirror an axis	Page 411
TRANS ROTATION	Rotation about the tool axis	Page 415
TRANS SCALE	Scale contours and positions	Page 416

Define the functions in the sequence in which they are listed in the table and reset them in reverse order. The sequence of programming will have an impact on the result.

For example, if you first shift the workpiece datum and then mirror the contour and then reverse the sequence, the contour will be mirrored at the original workpiece datum.

All **TRANS** functions reference the workpiece datum. The workpiece datum is the origin of the input coordinate system (**I-CS**).

Further information: "Input coordinate system I-CS", Page 86

Related topics

Coordinate transformation cycles

Further information: User's Manual for Programming of Machining Cycles

■ **PLANE** functions (option 8)

Further information: "The PLANE function: Tilting the working plane (option 8)", Page 459

Reference systems

Further information: "Reference systems", Page 78

Datum shift with TRANS DATUM

Application


The **TRANS DATUM** function allows you to shift the workpiece datum by either entering fixed or variable coordinates or by specifying a table row in the datum table.

Use the TRANS DATUM RESET function to reset the datum shift.

Related topics

Activating the datum table

Further information: User's Manual for **Programming of Machining Cycles**



Description of function

TRANS DATUM AXIS

You can define a datum shift by entering values in the respective axis with the **TRANS DATUM AXIS** function. You can define up to nine coordinates in one NC block, and incremental entries are possible.

If a datum shift is active, the control displays it on the **TRANS** tab of the additional status display.

Further information: User's Manual for Setup, Testing and Running NC Programs

The control displays the result of the datum shift in the position display.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

TRANS DATUM TABLE

You can use the **TRANS DATUM TABLE** function to define a datum shift by selecting a row from a datum table.

Optionally, you can set the path to a datum table. If you do not define a path, the control will use the datum table that has been activated with **SEL TABLE**.

Further information: "Activating the datum table in your NC program", Page 424

The control displays the datum shift with **TRANS DATUM TABLE** and the path to the datum table on the **TRANS** tab of the additional status display.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

TRANS DATUM RESET

Use the **TRANS DATUM RESET** function to cancel a datum shift. How you previously defined the datum is irrelevant.

Input

11 TRANS DATUM AXIS X+10 Y	; Shift the workpiece datum in the
+25 Z+42	X, Y and Z axes

The NC function includes the following syntax elements:

Syntax element	Meaning
TRANS DATUM	Start of syntax for a datum shift
AXIS, TABLE or RESET	Datum shift with coordinate input, with a datum table or reset of the datum shift
X, Y, Z, A, B, C, U, V or W	Possible axes for coordinate input Fixed or variable number Only if AXIS has been selected
TABLINE	Row in the datum table Fixed or variable number Only if TABLE has been selected
" " or QS	Path to the datum table Fixed or variable name Optional syntax element Only if TABLE has been selected

Notes

- Absolute values reference the workpiece preset. Incremental values reference the workpiece datum.
- If you execute an absolute data shift with TRANS DATUM or Cycle 7 DATUM SHIFT, then the control overwrites the values of the current datum shift. The control adds the incremental values to the values of the current datum shift.

Further information: User's Manual for **Programming of Machining Cycles**

- In machine parameter transDatumCoordSys (no. 127501), the machine manufacturer defines the reference system referred to by the values in the position display.
- If you have not defined a datum table in the TRANS DATUM TABLE block, then the control uses the datum table previously selected with SEL TABLE or the datum table activated in the Program run, single block or Program run, full sequence operating mode (status M).

Mirroring with TRANS MIRROR

Application

Use the **TRANS MIRROR** function to mirror contours or positions about one or more axes.

The **TRANS MIRROR RESET** function allows you to reset the mirroring.

Related topics

Cycle 8 MIRRORING

Further information: User's Manual for **Programming of Machining Cycles**

 Additive mirroring within the global program settings GPS (option 44)

Further information: User's Manual for Setup, Testing and Running NC Programs

Description of function

Mirroring is a modal function that in effect as soon as it has been defined in the NC program.

The control mirrors contours or positions about the active workpiece datum. If the datum is outside the contour, the control will also mirror the distance to the datum.

If you mirror only one axis, the machining direction of the tool is reversed. The rotational direction defined in a cycle will remain unchanged, such as when defined within one of the OCM cycles (option 167).

Depending on the selected **AXIS** axis values, the control will mirror the following working planes:


- X: The control mirrors the YZ working plane
- Y: The control mirrors the ZX working plane
- **Z**: The control mirrors the **XY** working plane


Further information: "Designation of the axes on milling machines", Page 89


You can select up to three axis values.

If mirroring is active, the control displays it on the **TRANS** tab of the additional status display.

Further information: User's Manual for **Setup, Testing and Running NC Programs**







Input

11 TRANS MIRROR AXIS X	; Mirror X coordinates about the Y
	axis

The NC function includes the following syntax elements:

Syntax element	Meaning
TRANS MIRROR	Start of syntax for mirroring
AXIS or RESET	Enter mirroring of axis values or reset mirroring
X, Y or Z	Axis values to be mirrored
	Only if AXIS has been selected

Notes

■ This function can only be used in the **FUNCTION MODE MILL** machining mode.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

If you execute mirroring with TRANS MIRROR or Cycle
 8 MIRRORING, then the control overwrites the current mirroring.

Further information: User's Manual for **Programming of Machining Cycles**

Notes on using these functions in conjunction with tilting functions

NOTICE

Danger of collision!

The control reacts differently to the various types of transformations as well as their programmed sequence. Unexpected movements or collisions can occur if the functions are not suitable.

- ► Program only the recommended transformations in the respective reference system
- Use tilting functions with spatial angles instead of with axis angles
- Use the Simulation mode to test the NC program

The type of tilting function has the following effects on the result:

- If you tilt using spatial angles (PLANE functions except for PLANE AXIAL or Cycle 19), previously programmed transformations will change the position of the workpiece datum and the orientation of the rotary axes:
 - Shifting with the **TRANS DATUM** function will change the position of the workpiece datum.
 - Mirroring changes the orientation of the rotary axes. The entire NC program, including the spatial angles, will be mirrored.
- If you tilt using axis angles (PLANE AXIAL or Cycle 19), a previously programmed mirroring has no effect on the orientation of the rotary axes. You use these functions for direct positioning of the machine axes.

Further information: "Workpiece coordinate system W-CS", Page 82

Rotations with TRANS ROTATION

Application

With the **TRANS ROTATION** function, you can rotate contours or positions around a rotation angle.

The **TRANS DATUM RESET** function allows you to reset the rotation.

Related topics

■ Cycle 10 ROTATION

Further information: User's Manual for **Programming of Machining Cycles**

Additive rotation within the global program settings (GPS, option 44)

Further information: User's Manual for **Setup, Testing and Running NC Programs**

Description of function

Rotation is a modal function that is in effect as soon as it has been defined in the NC program.

The control rotates machining in the working plane about the active workpiece datum.

The control rotates the input coordinate system (I-CS) as follows:

- Based on the angle reference axis, i.e. the main axis
- About the tool axis

Further information: "Designation of the axes on milling machines", Page 89

A rotation can be programmed as follows:

- Absolute, relative to the positive main axis
- Incremental, relative to the last active rotation

If rotation is active, the control displays it on the **TRANS** tab of the additional status display.


Further information: User's Manual for **Setup, Testing and Running NC Programs**

Input

11 TRANS ROTATION ROT+90	; Rotate machining by 90°

The NC function includes the following syntax elements:

Syntax element	Meaning
TRANS ROTATION	Start of syntax for a rotation
ROT or RESET	Enter an absolute or incremental angle of rotation or reset rotation Fixed or variable number



Notes

This function can only be used in the FUNCTION MODE MILL machining mode.

Further information: "Program function mode", Page 377

If you execute an absolute rotation with TRANS ROTATION or Cycle 10 ROTATION, then the control overwrites the values of the current rotation. The control adds the incremental values to the values of the current rotation.

Further information: User's Manual for **Programming of Machining Cycles**

Scaling with TRANS SCALE

Application

The **TRANS SCALE** lets you change the scale of the contours or distances to the datum, thereby evenly enlarging or shrinking them. This enables you to program shrinkage and oversize allowances, for example.

Use the TRANS SCALE RESET function to reset the scaling.

Related topics

■ Cycle 11 SCALING FACTOR

Further information: User's Manual for Programming of Machining Cycles

Description of function

Scaling is a modal function that is in effect as soon as it has been defined in the NC program.

Depending on the position of the workpiece datum, scaling is carried out as follows:


- Workpiece datum at the center of the contour:
 The contour is scaled uniformly in all directions.
- Workpiece datum at the bottom left of the contour:
 The contour is scaled in the positive X and Y axis directions.
- Workpiece datum at the top right of the contour:
 The contour is scaled in the negative X and Y axis directions.

If you enter a scaling factor **SCL** less than 1, the contour will be reduced in size. If you enter a scaling factor **SCL** greater than 1, the contour will be enlarged.

When scaling, the control takes the coordinate input and dimensions from all cycles into account.

If scaling is active, the control displays it on the **TRANS** tab of the additional status display.

Further information: User's Manual for Setup, Testing and Running NC Programs



Input

11 TRANS SCALE SCL1.5	; Enlarge the contour by the factor
	1.5

The NC function includes the following syntax elements:

Syntax element	Meaning
TRANS SCALE	Start of syntax for scaling
SCL or RESET	Enter the scaling factor or reset scaling Fixed or variable number

Notes

This function can only be used in the FUNCTION MODE MILL machining mode.

Further information: User's Manual for Setup, Testing and Running NC Programs

If you execute a change of scale with TRANS SCALE or Cycle 11 SCALING FACTOR, then the control overwrites the current scaling factor.

Further information: User's Manual for **Programming of Machining Cycles**

If you want to reduce the size of a contour with inside radii, make sure to select an appropriate tool. Otherwise, residual material might remain.

Selecting a TRANS function

To select a **TRANS** function:



▶ Show the soft-key row with special functions



▶ Press the **PROGRAM FUNCTIONS** soft key



Press the TRANSFORM / CORRDATA soft key



- ▶ Press the **TRANSFORMATIONS** soft key
- ▶ Press the soft key for the desired **TRANS** function

10.9 Modifying presets

The control provides the following functions for modifying a preset directly in the NC program after it has been defined in the preset table:

- Activate the preset
- Copy the preset
- Correct the preset

Activating a preset

The **PRESET SELECT** function allows you to use a preset defined in the preset table and activate it as a new preset.

To activate the preset, use the preset number or the entry in the **Doc** column. If the entry in the **Doc** column is not unique, the control will activate the preset with the smallest preset number.



If you program **PRESET SELECT** without optional parameters, then the behavior is identical to Cycle **247 PRESETTING**.

Use the optional parameters to define the following:

- **KEEP TRANS**: Retain simple transformations
 - Cycle 7 DATUM SHIFT
 - Cycle 8 MIRRORING
 - Cycle 10 ROTATION
 - Cycle 11 SCALING FACTOR
 - Cycle 26 AXIS-SPECIFIC SCALING
- **WP**: Any changes apply to the workpiece preset
- PAL: Any changes apply to the pallet preset

Procedure

Go to the definition:



► Press the **SPEC FCT** key



Press the PROGRAM DEFAULTS soft key



Press the PRESET soft key



- ▶ Press the **PRESET SELECT** soft key
- Define the desired preset number
- Alternatively, define the entry from the Doc column
- Retain the transformations where necessary
- If necessary, select the preset to which the change is to apply

Example

13 PRESET SELECT #3 KEEP TRANS WP

Select Preset 3 as the workpiece preset, and retain the transformations

Copying a preset

The function **PRESET COPY** allows you to copy a preset defined in the preset table and activate the preset copied.

To select the preset to be copied, use the preset number or the entry in the **Doc** column. If the entry in the **Doc** column is not unique, the control will select the preset with the smallest preset number.

Use the optional parameters to define the following:

- **SELECT TARGET**: Activate the copied preset
- **KEEP TRANS**: Retain simple transformations

Procedure

Proceed as follows for the definition:



▶ Press the **SPEC FCT** key



▶ Press the **PROGRAM DEFAULTS** soft key



▶ Press the **PRESET** soft key



- ▶ Press the **PRESET COPY** soft key
- ▶ Define the preset number to be copied
- As an alternative, define the entry from the **Doc** column
- Define the new preset number
- Activate the copied preset, if necessary
- ▶ Retain the transformations where necessary

Example

13 PRESET COPY #1 TO #3 SELECT TARGET KEEP TRANS

Copy the preset 1 to line 3, activate the preset 3, and retain the transformations

Correcting a preset

The function **PRESET CORR** allows you to correct the active preset.

If both the basic rotation and a translation are corrected in an NC block, the control will first correct the translation and then the basic rotation.

The compensation values are given with respect to the active coordinate system.

Procedure

Proceed as follows for the definition:



Show the soft key row with special functions



▶ Press the **PROGRAM DEFAULTS** soft key



▶ Press the **PRESET** soft key



- ▶ Press the **PRESET CORR** soft key
- ▶ Define the desired compensation values

13 PRESET CORR X+10 SPC+45	The active preset is corrected by a value of +10 mm in X, and
	by +45° in SPC

10.10 Datum table

Application

You can save the workpiece-related datums in a datum table. To use a datum table, you must activate it.

Description

Datums from a datum table always reference the current preset. The coordinate values from datum tables are only effective as absolute coordinate values.

Use datum tables for the following purposes:

- Frequent use of the same datum shift
- Frequently recurring machining sequences on the workpiece
- Frequently recurring machining sequences at various locations on the workpiece

Further information: User's Manual for **Setup, Testing and Running NC Programs**

The datum table contains the following parameters:

Parameter	Meaning	Input
D	Sequential number of the datums	099999999
X	X coordinate of the datum	-99999.9999999999.99999
Υ	Y coordinate of the datum	-99999.9999999999.99999
Z	Z coordinate of the datum	-99999.9999999999.99999
A		-360.0000000360.0000000
В		-360.0000000360.0000000
С		-360.0000000360.0000000
U	U coordinate of the datum	-99999.9999999999.99999
V	V coordinate of the datum	-99999.9999999999.99999
W	W coordinate of the datum	-99999.9999999999.99999
DOC	Comment column	Max. 16 characters

Creating a datum table

To create a new datum table:



▶ Switch to the **Programming** operating mode



► Press the **PGM MGT** key



- ▶ Press the **NEW FILE** soft key
- > The control opens the **New file** window where you can enter the file name.
- ► Enter the file name with the file type *.d



- ► Confirm with the **ENT** key
- The control opens the **New file** window where you can select the unit of measure.
- ММ
- Press the MM soft key
- > The control opens the datum table.



The names of tables and table columns must start with a letter and must not contain an arithmetic operator (e.g., +). Due to SQL commands, these characters can cause problems when data are input or read.

Further information: "Accessing tables with SQL statements", Page 344

Opening and editing a datum table



After you have changed a value in a datum table, you must save the change with the **ENT** key. Otherwise, the change will not be taken into account when the NC program is executed.

To open and edit a datum table:



- ▶ Press the **PGM MGT** key
- Select the desired datum table
- > The control opens the datum table.
- Select the row you wish to edit



► Save your input, e.g. by pressing the **ENT** key.



To delete the value from the input field, press the **CE** key.

The control displays the following functions in the soft-key row:

Soft key	Function
BEGIN	Select the table start
END	Select the table end

Soft key	Function
PAGE	Go to previous page
PAGE	Go to next page
FIND	Search The control opens a window where you can enter the text or value you are looking for.
RESET	Reset table
BEGIN LINE	Move the cursor to the beginning of the row
END LINE	Move the cursor to the end of the row
COPY	Copy the current value
PASTE FIELD	Paste the copied value
APPEND N LINES AT END	Insert the specified number of rows New rows can only be inserted at the end of the table.
INSERT	Insert row New rows can only be inserted at the end of the table.
DELETE LINE	Delete row
SORT/ HIDE COLUMNS	Sort/hide columns The control opens the Column sequence window with the following options:
	Use standard format
	Display/hide columns Arrange columns
	Arrange columnsFreeze columns (3 max.)
MORE FUNCTIONS	Additional functions, e.g. Delete
RESET	Reset the column
EDIT CURRENT FIELD	Edit the current field
SORT	Sort the datum table A window opens where you can select the sorting order.



If you enter the code number 555343, the control will display the **EDIT FORMAT** soft key. With this soft key, you can change the table properties.

Activating the datum table in your NC program

To activate a workpiece datum table in your NC program:



▶ Press the **PGM CALL** key



▶ Press the **SELECT TABLE** soft key



- ▶ Press the **SELECT FILE** soft key
- > A file selection window opens.
- Select the desired datum table



Confirm with the ENT key



If you enter the datum table name manually, please note the following:

- If the datum table is located in the same directory as the NC program, enter the file name only.
- If the datum table is not located in the same directory as the NC program, enter the complete path.



Program **SEL TABLE** before Cycle **7** or the **TRANS DATUM** function.

Activating the datum table manually



If you do not use **SEL TABLE**, you must activate the desired datum table prior to the test run.

To activate a datum table for the test run:



Switch to the **Test Run** operating mode



- ▶ Press the **PGM MGT** key
- Select the desired datum table
- > The control activates the datum table for the test run and marks the file with the **S** status.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

10.11 Compensation table

Application

With the compensation table, you can save compensations in the tool coordinate system (T-CS) or in the working plane coordinate system (WPL-CS).

The compensation table **.tco** is the alternative to compensating with **DL**, **DR**, and **DR2** in the Tool Call block. As soon as you have activated a compensation table, the control overwrites the compensation value from the Tool Call block.

During turning operations, the compensation table *.tco is an alternative to programming with FUNCTION TURNDATA CORR-TCS; the compensation table *.wco is an alternative to FUNCTION TURNDATA CORR-WPL.

The compensation tables offer the following benefits:

- Values can be changed without adapting the NC program
- Values can be changed during NC program run

If you change a value, then this change does not become active until the compensation is called again.

Types of compensation tables

Via the file name extension, you can determine in which coordinate system the control will perform the compensation.

The control provides the following compensation tables:

- tco (tool correction): Compensation in the tool coordinate system (T-CS)
- wco (workpiece correction): Compensation in the working plane coordinate system (WPL-CS)

Compensation via the table is an alternative to the compensation in the **TOOL CALL** block. Compensation from the table overwrites an already programmed compensation in the **TOOL CALL** block.

Compensation in the tool coordinate system (T-CS)

Any compensation in the compensation tables with the *.tco file name extension applies to the active tool. The table applies to all tool types. Therefore, columns that you may not need for your specific tool type will be displayed during creation.



Enter only those values that are relevant to your tool. If you compensate for values that are not present with the existing tool, the control issues an error message.

The compensations have the following effects:

- In the case of milling cutters, as an alternative to the delta values in the TOOL CALL
- In the case of turning tools, as an alternative to FUNCTION TURNDATA CORR-TCS
- In the case of grinding tools, as compensation for **LO** and **R-OVR**If a shift with the *.tco compensation table is active, the control displays it on the **TOOL** tab of the additional status display.

Further information: User's Manual for Setup, Testing and Running NC Programs

Compensation in the working plane coordinate system (WPL-CS)

The values from the compensation tables with the *.wco file name extension are applied as shifts in the working plane coordinate system (WPL-CS).

The compensations have the following effects:

- For turning operations, as an alternative to FUNCTION TURNDATA CORR-WPL (option 50)
- An X shift affects the radius

The following options are available for a shift in the **WPL-CS**:

- FUNCTION TURNDATA CORR-WPL
- FUNCTION CORRDATA WPL
- Shifting with the turning-tool table
 - Optional **WPL-DX-DIAM** column
 - Optional WPL-DZ column

Further information: User's Manual for Setup, Testing and Running NC Programs

If a shift with the *.wco compensation table is active, the control displays it, including the path, on the **TRANS** tab of the additional status display.

Further information: User's Manual for **Setup, Testing and Running NC Programs**



The shifts programmed with

FUNCTION TURNDATA CORR-WPL and **FUNCTION CORRDATA WPL** are alternative programming options for the same shift.

A shift in the working plane coordinate system (WPL-CS) defined by the turning-tool table is added to the FUNCTION TURNDATA CORR-WPL and FUNCTION CORRDATA WPL functions.

Creating a compensation table

Before you can work with a compensation table, you must first create the respective table.

You can create a compensation table as follows:



Switch to the **Programming** operating mode



► Press the **PGM MGT** key



- Press the **NEW FILE** soft key
- ► Enter a file name with the desired extension (e.g., Corr.tco)



- Confirm by pressing the ENT key
- Select the unit of measure



Confirm by pressing the ENT key



- Press the APPEND AT END soft key
- ► Enter the compensation values

Activate the compensation table

Select compensation table

If you are using compensation tables, then use the function **SEL CORR-TABLE** to activate the desired compensation table from within the NC program.

To add a compensation table to the NC program:



▶ Press the **SPEC FCT** key



Press the PROGRAM DEFAULTS soft key



Press the SELECT COMPENS. TABLE soft key



- Press the soft key of the table type (e.g., TCS)
- Select the table

If you are working without the **SEL CORR-TABLE** function, then you must activate the desired table prior to the test run or program run.

In all operating modes, proceed as follows:

- Select the desired operating mode
- Select the desired table in the file manager
- In the Test Run operating mode, the table receives the status S; in the Program Run Program run, single block and Program run, full sequence operating modes, it receives the status M.

Activating a compensation value

To activate a compensation value in the NC program:



► Press the **SPEC FCT** key



▶ Press the **PROGRAM FUNCTIONS** soft key



Press the TRANSFORM / CORRDATA soft key



Press the FUNCTION CORRDATA soft key



- Press the soft key of the desired compensation (e.g., TCS)
- ► Enter the line number

Duration of active compensation

Activated compensation stays in effect until the end of the program or until a tool change occurs.

With **FUNCTION CORRDATA RESET**, you can program the compensations to reset.

Editing a compensation table during program run

You can change the values in the active compensation table during program run. As long as the compensation table is not yet active, the control dims the soft key.

Proceed as follows:



▶ Press the **SELECT TABLES** soft key



Press the soft key of the desired table (e.g., COMPENS. T-CS)



- ► Set the **EDIT** soft key to **ON**
- Use the arrow keys to navigate to the desired location
- ► Edit the value



The changed data do not take effect until after the compensation has been activated again.

10.12 Accessing table values

Application

The **TABDATA** functions allow you to access table values.

These functions enable automated editing of compensation values from within the NC program, for example.

You can access the following tables:

- Tool table *.t (read-only access)
- Compensation table *.tco (read and write access)
- Compensation table *.wco (read and write access)
- Preset table *.pr (read and write access)

In each case, the active table is accessed. Read-only access is always possible, whereas write access is possible only during program run. Write access during simulation or during a block scan has no effect.

If the unit of measure used in the NC program differs from that used in the table, the control converts the values from **millimeters** to **inches**, and vice versa.

Reading a table value

The function **TABDATA READ** allows you to read a value from a table and save it to a Q parameter.

Depending on the type of column you want to transfer, you can use **Q. QL**, **QR**, or **QS** to save the value. The control automatically converts the table values to the unit of measure used in the NC program.

The control reads from the currently active tool table and preset table. You can read a value from a compensation table only if you have activated the table concerned.

For example, the **TABDATA READ** function enables you to pre-check the data of the tool to be used to prevent error messages from occurring during program run.

Procedure

Proceed as follows:



▶ Press the **SPEC FCT** key



Press the PROGRAM FUNCTIONS soft key



► Press the **TABDATA** soft key



- ▶ Press the **TABDATA READ** soft key
- ► Enter the Q parameter for the result



► Confirm with the **ENT** key



- Press the soft key for the desired table (e.g., CORR-TCS)
- ► Enter the column name



- ► Confirm with the **ENT** key
- ► Enter the row number of the table
- ENT
- ► Press the **ENT** key

12 SEL CORR-TABLE TCS "TNC:\table\corr.tco"	Activate the compensation table
13 TABDATA READ Q1 = CORR-TCS COLUMN "DR" KEY "5"	Save the value of row 5, column DR, from the compensation table to Q1

Writing a table value

The function **TABDATA WRITE** allows you to write a value from a Q parameter into a table.

Depending on the type of column you want to write to, you can use **Q**, **QL**, **QR**, or **QS** as a transfer parameter.

In order to write into a compensation table, you need to activate the table.

You can use the **TABDATA WRITE** function after a touch probe cycle to enter a necessary tool compensation into the compensation table, for example.

Procedure

Proceed as follows:



▶ Press the **SPEC FCT** key



▶ Press the **PROGRAM FUNCTIONS** soft key




Press the TABDATA soft key



▶ Press the **TABDATA WRITE** soft key




Press the soft key for the desired table (e.g., CORR-TCS)





► Confirm with the **ENT** key





► Confirm with the **ENT** key



► Enter the Q parameter



► Confirm with the **ENT** key

12 SEL CORR-TABLE TCS "TNC:\table\corr.tco"	Activate the compensation table
13 TABDATA WRITE CORR-TCS COLUMN "DR" KEY "3" = Q1	Write the value from Q1 into line 3, column DR, of the compensation table

Adding a table value

The function **TABDATA ADD** allows you to add a value from a Q parameter to a value contained in the table.

Depending on the type of column you want to write to, you can use **Q**, **QL**, or **QR** as a transfer parameter.

In order to write into a compensation table, you need to activate the table.

You can use the **TABDATA ADD** function to update a tool compensation value after a measurement has been repeated, for example.

Procedure

Proceed as follows:



▶ Press the **SPEC FCT** key



Press the PROGRAM FUNCTIONS soft key



Press the TABDATA soft key



▶ Press the **TABDATA ADDITION** soft key



- Press the soft key for the desired table (e.g., CORR-TCS)
- ► Enter the column name



- ► Confirm with the **ENT** key
- ▶ Enter the line number of the table



- ► Confirm with the **ENT** key
- Enter the Q parameter



► Confirm with the **ENT** key

12 SEL CORR-TABLE TCS "TNC:\table\corr.tco"	Activate the compensation table
13 TABDATA ADD CORR-TCS COLUMN "DR" KEY "3" = Q1	Add the value from Q1 to line 3, column DR, of the compensation table

10.13 Monitoring of configured machine components (option 155)

Application



Refer to your machine manual.

This function must be enabled and adapted by the machine manufacturer.

The **MONITORING HEATMAP** function allows you to start and stop the workpiece representation in a component heatmap from within the NC program.

The control monitors the selected component and shows the result in a color-coded heatmap on the workpiece.

A component heatmap is similar to the image from an infrared camera.

- Green: component works under conditions defined as safe
- Yellow: component works under warning zone conditions
- Red: Overload condition



To start component monitoring, proceed as follows:



Press the special functions key



Select the program functions



Select Monitoring



▶ Press the **MONITORING HEATMAP START** soft key




Select the component released by the machine manufacturer

Only one component at a time can be monitored with the heatmap. If you start the heatmap several times in a row, monitoring of the previous component is stopped.

Stopping monitoring

Monitoring is stopped with the **MONITORING HEATMAP STOP** function.



10.14 Defining a counter

Application



Refer to your machine manual.

Your machine manufacturer enables this function.

With the **FUNCTION COUNT** NC function, you control a counter from within the NC program. This counter allows you, for example, to define a target count up to which the control is to repeat the NC program.

To program this behavior:



Show the soft-key row with special functions



▶ Press the **PROGRAM FUNCTIONS** soft key



▶ Press the **FUNCTION COUNT** soft key

NOTICE

Caution: Data may be lost!

Only one counter can be managed by the control. If you execute an NC program that resets the counter, any counter progress of another NC program will be deleted.

- ▶ Please check prior to machining whether a counter is active.
- If necessary, note down the counter value and enter it again via the MOD menu after execution.



You can engrave the current counter reading with Cycle **225 ENGRAVING**.

Further information: User's Manual for **Programming of Machining Cycles**

Effect in the Test Run operating mode

You can simulate the counter in the **Test Run** operating mode. Only the counter reading you have defined directly in the NC program is active. The counter reading in the MOD menu remains unaffected.

Effect in the Program Run Single Block and Program Run Full Sequence operating modes

The counter reading from the MOD menu is only active in the **Program Run Single Block** and **Program Run Full Sequence** operating modes.

The counter reading remains the same after a restart of the control.

Defining FUNCTION COUNT

The **FUNCTION COUNT** NC function provides the following counter functions:

Soft key	Function
FUNCTION COUNT INC	Increase the counter by 1
FUNCTION COUNT RESET	Reset the counter
FUNCTION COUNT TARGET	Define the target count to be reached Input value: 0 to 9999
FUNCTION COUNT SET	Assign a defined value to the counter Input value: 0 to 9999
FUNCTION COUNT ADD	Increase the counter by a defined value Input value: 0 to 9999
FUNCTION COUNT REPEAT	Repeat the NC program from the label if the defined target count has not been reached yet

Example

5 FUNCTION COUNT RESET	Reset the counter reading
6 FUNCTION COUNT TARGET10	Enter the target number of parts to be machined
7 LBL 11	Enter the jump label
8 L	Machining operation
51 FUNCTION COUNT INC	Increment the counter reading
52 FUNCTION COUNT REPEAT LBL 11	Repeat the machining operations if more parts are to be machined
53 M30	
54 END PGM	

10.15 Creating text files

Application

You can use the control's text editor to write and edit texts. Typical applications:

- Recording test results
- Documenting working procedures
- Creating formula collections

Text files have the extension .A (for ASCII files). If you want to edit other types of files, you must first convert them into type .A files.

Opening and exiting a text file

- ▶ Operating mode: Press the **Programming** key
- ▶ To call the file manager, press the **PGM MGT** key.
- ▶ Display type .A files: Press the SELECT TYPE soft key and then the SHOW ALL soft key
- Select a file and open it with the SELECT soft key or ENT key, or open a new file by entering the new file name and confirming your entry with the ENT key

To leave the text editor, call the file manager and select a file of a different file type, for example an NC program.

Soft key	Cursor movements
MOVE WORD	Move cursor one word to the right
MOVE WORD	Move cursor one word to the left
PAGE	Go to next screen page
PAGE	Go to previous screen page
BEGIN	Cursor at beginning of file
END	Cursor at end of file

Editing texts

Above the first line of the text editor, there is an information field showing the file name, location and line information:

File: Name of the text file

Line: Line in which the cursor is presently located **Column**: Column in which the cursor is presently located

The text is inserted or overwritten at the location of the cursor. You can move the cursor to any desired position in the text file by pressing the arrow keys.

You can insert a line break with the **RETURN** or **ENT** key.

Deleting and re-inserting characters, words and lines

With the text editor, you can erase words and even lines, and insert them at any desired location in the text.

- ► Move the cursor to the word or line that you wish to erase and insert at a different place in the text
- ▶ Press the **DELETE WORD** or **DELETE LINE** soft key: The text is removed and buffered
- Move the cursor to the location where you wish to insert the text, and press the INSERT WORD soft key

Soft key	Function
DELETE LINE	Delete and temporarily store a line
DELETE WORD	Delete and temporarily store a word
DELETE CHAR	Delete and temporarily store a character
INSERT LINE / WORD	Insert a line or word from temporary storage

Editing text blocks

You can copy and erase text blocks of any size, and insert them at other locations. Before any of these actions, you must first select the desired text block:

► To select a text block: Move the cursor to the first character of the text you wish to select.



- ▶ Press the **SELECT BLOCK** soft key
- Move the cursor to the last character of the text you wish to select. You can select whole lines by moving the cursor up or down directly with the arrow keys—the selected text is shown in a different color.

After selecting the desired text block, you can edit the text with the following soft keys:

Soft key	Function
CUT OUT BLOCK	Delete the selected block and store temporarily
COPY BLOCK	Store the selected block temporarily without erasing (copy)

If desired, you can now insert the temporarily stored block at a different location:

Move the cursor to the location where you want to insert the temporarily stored text block



Press the INSERT BLOCK soft key: The text block is inserted

You can insert the temporarily stored text block as often as desired

Transferring the selected block to a different file

Select the text block as described previously



- ▶ Press the **APPEND TO FILE** soft key.
- > The control displays the **Destination file =** dialog prompt.
- Enter the path and the name of the destination file
- > The control appends the selected text block to the specified file. If no target file with the specified name is found, the control creates a new file with the selected text.

Inserting another file at the cursor position

Move the cursor to the location in the text where you wish to insert another file



- ▶ Press the **READ FILE** soft key.
- > The control displays the **File name** = dialog prompt.
- Enter the path and name of the file you want to insert

Finding text sections

With the text editor, you can search for words or character strings in a text. The control provides the following two options.

Finding the current text

The search function is used for finding the next occurrence of the word in which the cursor is presently located:

- Move the cursor to the desired word.
- ▶ Select the search function: Press the **FIND** soft key
- ▶ Press the **FIND WORD** soft key
- ► Find a word: Press the **FIND** soft key
- ▶ Exit the search function: Press the **END** soft key

Finding any text

- ► Select the search function: Press the **FIND** soft key. The control displays the dialog **Find text**:
- ► Enter the text that you wish to find
- ► Find text: Press the **FIND** soft key
- ▶ Exit the search function: Press the **END** soft key

10.16 Freely definable tables

Fundamentals


In freely definable tables you can save and read any information from the NC program. The Q parameter functions **FN 26** to **FN 28** are provided for this purpose.

You can change the format of freely definable tables, i.e. the columns and their properties, by using the structure editor. They enable you to make tables that are exactly tailored to your application.

You can also toggle between a table view (standard setting) and form view.



The names of tables and table columns must start with a letter and must not contain an arithmetic operator (e.g., +). Due to SQL commands, these characters can cause problems when data are input or read.



Creating a freely definable table

Proceed as follows:



- ► Press the **PGM MGT** key
- ► Enter any desired file name with the extension .TAB



- Confirm with the ENT key
- > The TNC displays a pop-up window with permanently saved table formats.
- Use the arrow key to select a table template, e.g. example.tab



- Confirm with the ENT key
- > The control opens a new table in the predefined format.
- To adapt the table to your requirements you have to edit the table format

Further information: "Editing the table format", Page 441



Refer to your machine manual.

Machine tool builders may define their own table templates and save them in the control. When you create a new table, the control opens a pop-up window listing all available table templates.



You can also save your own table templates in the TNC. To do so, create a new table, change the table format and save the table in the **TNC:\system\proto** directory. If you then create a new table, the control offers your template in the selection window for table templates.

Editing the table format


Proceed as follows:



- ▶ Press the **EDIT FORMAT** soft key
- > The control opens a pop-up window displaying the table structure.
- Adapt the format

The control provides the following options:

Structure command	Meaning	
Available columns:	List of all columns contained in the table	
Move before:	The entry highlighted in Available columns is moved in front of this column	
Name	Column name: Is displayed in the header	
Column type	TEXT: Text entry SIGN: + or - sign BIN: Binary number DEC: Decimal, positive, whole number (cardinal number) HEX: Hexadecimal number INT: Whole number LENGTH: Length (is converted in inch programs) FEED: Feed rate (mm/min or 0.1 inch/min) IFEED: Feed rate (mm/min or inch/min) FLOAT: Floating-point number BOOL: Logical value INDEX: Index TSTAMP: Fixed format for date and time UPTEXT: Text entry in upper case PATHNAME: Path name	
Default value	Default value for the fields in this column	
Width	 Maximum number of characters in the column The column width is limited as follows: Columns for alphanumeric entries allow up to 100 characters Columns for numeric entries allow up to 15 characters In addition to those 15 characters, the control can 	
 Primary key	display an algebraic sign and a decimal separator First table column	
Language-sensitive column name		





Columns with a column type that permits letters, such as **TEXT**, can only be output or written to via QS parameters, even if the content of the cell is a number.

You can use a connected mouse or the navigation keys to move through the form.

Proceed as follows:



- Press the navigation keys to jump to the input fields
- GОТО □
- ▶ Open the selection menus with the **GOTO** key
- f
- Use the arrow keys to navigate within an input field



In a table that already contains lines you can not change the table properties **Name** and **Column type**. Once you have deleted all lines, you can change these properties. If required, create a backup copy of the table beforehand.

With the **CE** and **ENT** key combination, you can reset invalid values in fields with the **TSTAMP** column type.

Closing the structure editor

Proceed as follows:



- ► Press the **OK** soft key
- > The control closes the editing form and applies the changes.
- CANCEL
- ► Alternative: Press the **CANCEL** soft key
- > The control discards all entered changes.

Switching between table and form view

All tables with the **.TAB** extension can be opened in either list view or form view.

Switch the view as follows:



► Press the **Screen layout** key



Press the soft key with the desired view

In the left half of the form view, the control lists the line numbers with the contents of the first column.

You can change the data as follows in the form view:



Press the ENT key in order to switch to the next input field on the right-hand side

Selecting another row to be edited:




- ▶ Press the **Next tab** key
- > The cursor jumps to the left window.



Use the arrow keys to select the desired row



Press the **Next tab** key to switch back to the input window



FN 26: TABOPEN opening a freely definable table

With the **FN 26: TABOPEN** NC function, you open a freely definable table to be written to with **FN 27: TABWRITE** or to be read from with





Only one table can be opened in an NC program at any one time. A new NC block with **FN 26: TABOPEN** automatically closes the last opened table.

The table to be opened must have the extension .TAB.

11 FN 26: TABOPEN TNC:\table \AFC.TAB

; Open table with FN 26

The NC function includes the following syntax elements:

Syntax element	Meaning
FN 26: TABOPEN	Start of syntax for opening a table
TNC:\table \AFC.TAB	Path of the table to be opened Fixed or variable name

Example: Open the table TAB1.TAB, which is saved in the directory TNC:\DIR1.

56 FN 26: TABOPEN TNC:\DIR1\TAB1.TAB

Use the **SYNTAX** soft key to place paths within quotation marks. The quotation marks define the beginning and the end of the path. This enables the control to identify any special characters as a part of the path.

Further information: "File names", Page 109

If the complete path is enclosed in quotation marks, you can use both \ and \forall to separate the folders and files.

FN 27: TABWRITE writing to a freely definable table

With the **FN 27: TABWRITE** NC function, you write to the table that you previously opened with **FN 26: TABOPEN**.

Use the **FN 27** NC function to define the table columns to be written to by the control. Within an NC block, you can specify multiple table columns, but only one table row. The content to be written to the columns must have been defined previously, using variables.



If you write to multiple columns within one NC block, you need to define the values to be written to the columns in consecutive variables.

If you try to write to a locked or a non-existing table cell, the control displays an error message.

Input

11 FN 27: TABWRITE	; Write to table with FN 27
2/"Length,Radius" = Q2	

The NC function includes the following syntax elements:

Syntax element	Meaning
FN 27: TABWRITE	Start of syntax for writing to a table
2	Row number of the table to be written to Fixed or variable number
"Length,Ra- dius"	Column names in the table to be written to Fixed or variable name Use commas to separate multiple column names.
Q2	Variable for the contents to be written

Example

The control writes to the columns **Radius**, **Depth**, and **D** of row **5** of the currently open table. The control writes the values from the Q parameters **Q5**, **Q6**, and **Q7** to the table.

53 Q5 = 3,75	
54 Q6 = -5	
55 Q7 = 7,5	
56 FN 27: TABWRITE 5/"RADIUS,TIEFE,D" = Q5	

FN 28: TABREAD reading a freely definable table

With the **FN 28: TABREAD** NC function, you can read data from the table previously opened with **FN 26: TABOPEN**.

Use the **FN 28** NC function to define the table columns that the control is to read from. Within an NC block, you can specify multiple table columns, but only one table row.



If you specify multiple columns in an NC block, the control saves the read values in consecutive variables of the same type (e.g., **QL1**, **QL2**, and **QL3**).

Input

11 FN 28: TABREAD Q1 = 2 /	; Read table with FN 28
"Length"	

The NC function includes the following syntax elements:

Syntax element	Meaning
FN 28: TABREAD	Start of syntax for reading from a table
Q1	Variable for the source text
	The control uses this variable to save the contents from the table cells to be read.
2	Row number in the table to be read
	Fixed or variable number
"Length"	Column name in the table to be read
	Fixed or variable name
	Use commas to separate multiple column names.

Example

The control reads the values of columns **X**, **Y**, and **D** from row **6** of the currently open table. The control saves the values to the Q parameters **Q10**, **Q11**, and **Q12**.

The content from the **DOC** column of the same row is saved to the **QS1** QS parameter.

56 FN 28: TABREAD Q10 = 6/"X,Y,D"

57 FN 28: TABREAD QS1 = 6/"DOC"

Adapting the table format

NOTICE

Caution: Data may be lost!

The **ADAPT TABLE** function changes the format of all tables permanently. The control does not perform an automatic backup of the files prior to a format change. The files will thus be permanently changed and may no longer be usable.

Only use the function in consultation with the machine tool builder.

Soft key Function



Adapt format of tables present after changing the control software version



The names of tables and table columns must start with a letter and must not contain an arithmetic operator (e.g., +). Due to SQL commands, these characters can cause problems when data are input or read.

10.17 Pulsing spindle speed FUNCTION S-PULSE

Program pulsing spindle speed

Application



Refer to your machine manual.

Read and note the functional description of the machine tool builder.

Follow the safety precautions.

Using the **S-PULSE FUNCTION** you can program a pulsing spindle speed (e.g., to avoid natural oscillations of the machine) when operating at a constant spindle speed.

With the **P-TIME** input value, you define the duration of an oscillation (oscillation period), and with the **SCALE** input value, the spindle speed change in percent. The spindle speed changes in a sinusoidal form around the nominal value.

Use **FROM-SPEED** and **TO-SPEED** to define the upper and lower spindle speed limits of a spindle speed range in which the pulsing spindle speed is effective. Both input values are optional. If you do not define a parameter, the function applies to the entire speed range.

Input

11 FUNCTION S-PULSE P-TIME10 SCALE5 FROM-SPEED4800 TO-SPEED5200

; Spindle speed variation of 5% around the nominal value within 10 seconds (with limit values)

The NC function includes the following syntax elements:

Meaning
Start of syntax for pulsing spindle speed
Define the duration of an oscillation in seconds, or reset the pulsing spindle speed
Spindle speed change in % Only if P-TIME has been selected
Lower speed limit from which the pulsing spindle speed will be effective Only if P-TIME has been selected
Optional syntax element Upper speed limit up to which the pulsing spindle speed will be effective Only if P-TIME has been selected Optional syntax element

To program this behavior:



Show the soft-key row with special functions



Press the PROGRAM FUNCTIONS soft key



► Press the **FUNCTION SPINDLE** soft key



- ▶ Press the **SPINDLE-PULSE** soft key
- ► Define oscillation period **P-TIME**
- ▶ Define speed change **SCALE**




The control never exceeds a programmed speed limit. The spindle speed is maintained until the sinusoidal curve of the **S-PULSE FUNCTION** falls below the maximum speed once more.

Icons

In the status bar, the icon indicates the condition of the pulsing spindle speed:

lcon	Function
S % ✓✓	Pulsing spindle speed active



Resetting the pulsing spindle speed

Example

18 FUNCTION S-PULSE RESET

Use the ${\bf FUNCTION}$ S-PULSE RESET to reset the pulsing spindle speed.

Proceed as follows for the definition:



Show the soft-key row with special functions



Press the PROGRAM FUNCTIONS soft key



▶ Press the **FUNCTION SPINDLE** soft key



▶ Press the **RESET SPINDLE-PULSE** soft key.

10.18 Dwell time FUNCTION FEED DWELL

Programming a dwell time

Application



Refer to your machine manual.

Read and note the functional description of the machine tool builder.

Follow the safety precautions.

The **FUNCTION FEED DWELL** function can be used to program a cyclic dwell time in seconds (e.g., to force chip breaking in a turning cycle).

Program **FUNCTION FEED DWELL** immediately prior to the operation you wish to run with chip breaking.

The defined dwell time from **FUNCTION FEED DWELL** is effective in both milling and turning operations.

The **FUNCTION FEED DWELL** function is not effective with rapid traverse movements and probing motion.

NOTICE

Caution: Danger to the tool and workpiece!

When the **FUNCTION FEED DWELL** function is active, the control will repeatedly interrupt the feed movement. While the feed movement is interrupted, the tool remains at its current position, and the spindle continues to turn. During thread cutting, this behavior will cause the workpiece to become scrap. There is also a risk of tool breakage during execution!

Deactivate the FUNCTION FEED DWELL function before cutting threads

Procedure

Example

13 FUNCTION FEED DWELL D-TIME0.5 F-TIME5

Proceed as follows for the definition:



Show the soft-key row with special functions



Press the PROGRAM FUNCTIONS soft key



Press the FUNCTION FEED soft key



- ▶ Press the **FEED DWELL** soft key
- ▶ Define the interval duration for dwelling **D-TIME**
- ▶ Define the interval duration for cutting **F-TIME**

Resetting the dwell time



Reset the dwell time immediately following the machining with chip breaking.

Example

18 FUNCTION FEED DWELL RESET

Use **FUNCTION FEED DWELL RESET** to reset the recurring dwell time.

Proceed as follows for the definition:



▶ Show the soft-key row with special functions



▶ Press the **PROGRAM FUNCTIONS** soft key



▶ Press the **FUNCTION FEED** soft key



▶ Press the **RESET FEED DWELL** soft key



You can also reset the dwell time by entering **D-TIME 0**. The control automatically resets the **FUNCTION FEED DWELL** function at the end of a program.

10.19 Dwell time FUNCTION DWELL

Programming a dwell time

Application

The **FUNCTION DWELL** function enables you to program a dwell time in seconds or define the number of spindle revolutions for dwelling.

The defined dwell time from **FUNCTION DWELL** is effective in both milling and turning operations.

Procedure

Example

13 FUNCTION DWELL TIME10

Example

23 FUNCTION DWELL REV5.8

Proceed as follows for the definition:



Show the soft-key row with special functions



Press the PROGRAM FUNCTIONS soft key



► FUNCTION DWELL soft key



▶ Press the **DWELL TIME** soft key

Define the duration in seconds



- Alternatively, press the **DWELL REVOLUTIONS** soft key
- ▶ Define the number of spindle revolutions

10.20 Lift off tool at NC stop: FUNCTION LIFTOFF

Programming tool lift-off with FUNCTION LIFTOFF

Requirement



Refer to your machine manual.

This function must be configured and enabled by your machine manufacturer. In machine parameter **CfgLiftOff** (no. 201400), the machine manufacturer defines the path the tool is supposed to traverse for a **LIFTOFF** command. You can also use machine parameter **CfgLiftOff** to deactivate the function.

In the **LIFTOFF** column of the tool table, set the **Y** parameter for the active tool.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

Application

The **LIFTOFF** function is effective in the following situations:

- In case of an NC stop triggered by you
- In case of an NC stop triggered by the software (e.g., if an error has occurred in the drive system).
- In case of a power interruption

The tool retracts from the contour by up to 2 mm. The control calculates the lift off direction based on the input in the **FUNCTION LIFTOFF** block.

You can program the **LIFTOFF** function in the following ways:

- **FUNCTION LIFTOFF TCS X Y Z**: Lift-off in the tool coordinate system (**T-CS**) with the vector resulting from **X**, **Y** and **Z**
- **FUNCTION LIFTOFF ANGLE TCS SPB**: Lift-off in the tool coordinate system (**T-CS**) with a defined spatial angle
- Lift-off in the tool axis direction with M148

Further information: "Lifting off the tool automatically from the contour at NC stop: M148", Page 250

Lift-off in turning mode

NOTICE

Caution: Danger to the tool and workpiece!

Undesired movements of the axes can occur if you use the **FUNCTION LIFTOFF ANGLE TCS** function in turning mode. The behavior of the control depends on the kinematics description and Cycle **800** (**Q498 = 1**).

- Carefully test the NC program or program section in **Program** run, single block operating mode.
- ▶ If necessary, change the algebraic sign of the defined angle

If parameter **Q498** has been set to 1, the control will reverse the tool for machining.

In conjunction with the $\mbox{\bf LIFTOFF}$ function, the control behaves as follows:

- If the tool spindle has been defined as an axis, the LIFTOFF direction will be reversed.
- If the tool spindle has been defined as a kinematic transformation, the LIFTOFF direction will not be reversed.

Further information: User's Manual for **Programming of Machining Cycles**

Programming tool lift-off with a defined vector Example

18 FUNCTION LIFTOFF TCS X+0 Y+0.5 Z+0.5

With **LIFTOFF TCS X Y Z**, you define the lift-off direction as a vector in the tool coordinate system. The control calculates the lift-off height in each axis based on the tool path defined by the machine tool builder.

Proceed as follows for the definition:



Show the soft-key row with special functions



Press the PROGRAM FUNCTIONS soft key



Press the FUNCTION LIFTOFF soft key



- ▶ Press the **LIFTOFF TCS** soft key
- ► Enter X, Y, and Z vector components

Programming tool lift-off with a defined angle Example

18 FUNCTION LIFTOFF ANGLE TCS SPB+20

With **LIFTOFF ANGLE TCS SPB**, you define the lift-off direction as a spatial angle in the tool coordinate system. This function is particularly helpful for turning operations.

The SPB angle you enter describes the angle between Z and X. If you enter 0°, the tool lifts off in the tool Z axis direction.

Proceed as follows for the definition:



Show the soft-key row with special functions



▶ Press the **PROGRAM FUNCTIONS** soft key



Press the FUNCTION LIFTOFF soft key



▶ Press the **LIFTOFF ANGLE TCS** soft key

► Enter the SPB angle

Resetting the lift-off function

Example

18 FUNCTION LIFTOFF RESET

Use **FUNCTION LIFTOFF RESET** to reset the lift-off function.

Proceed as follows for the definition:



Show the soft-key row with special functions



▶ Press the **PROGRAM FUNCTIONS** soft key



Press the FUNCTION LIFTOFF soft key



Press the LIFTOFF RESET soft key



The control uses the **M149** function to deactivate the **FUNCTION LIFTOFF** function without resetting the lift-off direction. If you program **M148**, the control will activate the automatic lift-off of the tool in the lift-off direction defined by the **FUNCTION LIFTOFF** function.

The control automatically resets the **FUNCTION LIFTOFF** function at the end of a program.

Multiple-axismachining

11.1 Functions for multi-axis machining

This chapter summarizes the control functions for machining with multiple axes:

Control function	Description	Page
PLANE	Define machining in the tilted working plane	459
M116	Feed rate of rotary axes	490
PLANE/M128	Inclined-tool machining	488
FUNCTION TCPM	Define the behavior of the control when positioning the rotary axes (enhancement of M128)	499
M126	Shortest-path traverse of rotary axes	491
M94	Reduce display value of rotary axes	492
M128	Define the behavior of the control when positioning the rotary axes	493
M138	Selection of tilted axes	497
M144	Calculate machine kinematics	498
LN blocks	Three-dimensional tool compensation	507

11.2 The PLANE function: Tilting the working plane (option 8)

Introduction



Refer to your machine manual.

The machine manufacturer must enable the functions for tilting the working plane!

You can only use the **PLANE** function in its entirety on machines having at least two rotary axes (table axes, head axes or combined axes). The **PLANE AXIAL** function is an exception. **PLANE AXIAL** can also be used on machines which have only one programmed rotary axis.

The **PLANE** functions provide powerful options to define tilted working planes in various ways.

The parameter definition of the **PLANE** functions is subdivided into two parts:

- The geometric definition of the plane, which is different for each of the available **PLANE** functions.
- The positioning behavior of the PLANE function, which is independent of the plane definition and is identical for all PLANE functions

Further information: "Defining the positioning behavior of the PLANE function", Page 478

NOTICE

Danger of collision!

When the machine is switched on, the control tries to restore the switch-off status of the tilted plane. This is prevented under certain conditions. For example, this applies if axis angles are used for tilting while the machine is configured with spatial angles, or if you have changed the kinematics.

- If possible, reset tilting before shutting the system down
- ▶ Check the tilted condition when switching the machine back on

NOTICE

Danger of collision!

Cycle **8 MIRRORING** can have different effects in conjunction with the **Tilt working plane** function. The programming sequence, the mirrored axes, and the tilting function used are critical in this regard. There is a risk of collision during the tilting operation and subsequent machining!

- ▶ Check the sequence and positions using a graphic simulation
- Carefully test the NC program or program section in the Program run, single block operating mode

Examples

- 1 When Cycle **8 MIRRORING** is programmed before the tilting function without rotary axes:
 - The tilt of the PLANE function used (except PLANE AXIAL) is mirrored
 - Mirroring takes effect after tilting with PLANE AXIAL or Cycle 19
- 2 When Cycle **8 MIRRORING** is programmed before the tilting function with a rotary axis:
 - The mirrored rotary axis has no effect on the tilt specified in the PLANE function used, because only the movement of the rotary axis is mirrored



Operating and programming notes:

- The actual-position-capture function is not possible with an active tilted working plane.
- If you use the PLANE function when M120 is active, the control automatically rescinds the radius compensation, which also rescinds the M120 function.
- Always use PLANE RESET to cancel PLANE functions. Entering 0 in all PLANE parameters (e.g. all three spatial angles) exclusively resets the angles, but not the function.
- If you restrict the number of tilting axes with the M138 function, your machine may provide only limited tilting possibilities. The machine manufacturer will decide whether the control takes the angles of deselected axes into account or sets them to 0.
- The control only supports tilting the working plane with spindle axis Z.

Overview

Most **PLANE** functions (except **PLANE AXIAL**) can be used to describe the desired working plane independently of the rotary axes available on your machine. The following possibilities are available:

Soft key	Function	Required parameters	Page
SPATIAL	SPATIAL	Three spatial angles: SPA , SPB , and SPC	464
PROJECTED	PROJECTED	Two projection angles: PROPR and PROMIN and a rotation angle ROT	467
EULER	EULER	Three Euler angles: precession (EULPR), nutation (EULNU) and rotation (EULROT),	469
VECTOR	VECTOR	Normal vector for defining the plane and base vector for defining the direction of the tilted X axis	471
POINTS	POINTS	Coordinates of any three points in the plane to be tilted	473
REL. SPA.	RELATIVE	Single, incrementally effective spatial angle	475
AXIAL	AXIAL	Up to three absolute or incremental axis angles A,B,C	476
RESET	RESET	Reset the PLANE function	463

Running an animation

To familiarize yourself with the various definition possibilities of each **PLANE** function, you can start animated sequences via soft key. To do so, first enter animation mode and then select the desired **PLANE** function. While the animation plays, the control highlights the soft key of the selected **PLANE** function with a blue color.

Soft key	Function
SELECT ANIMATION OFF ON	Switch on the animation mode
SPATIAL	Select the desired animation (highlighted in blue)


Defining the PLANE function



▶ Show the soft-key row with special functions



- ► Press the **TILT PLANE** soft key
- > The control displays the available **PLANE** functions in the soft-key row.
- ▶ Select the **PLANE** function



Selecting functions

- Press the soft key linked to the desired function
- > The control continues the dialog and prompts you for the required parameters.


Selecting the function while animation is active

- Press the soft key linked to the desired function
- > The control plays the animation.
- ► To apply the currently active function, press the soft key of that function again or press the **ENT** key

Position display

As soon as a **PLANE** function (except **PLANE AXIAL**) is active, the control shows the calculated spatial angle in the additional status display.

During tilting into position (**MOVE** or **TURN** mode), the control shows, in the rotary axis, the distance to go to the calculated final position of the rotary axis in the distance-to-go display (**ACTDST** and **REFDST**).



Resetting PLANE function

Example


25 PLANE RESET MOVE DIST50 F1000



► Show the soft-key row with special functions



- ▶ Press the **TILT PLANE** soft key
- The control displays the available PLANE functions in the soft-key row





 Specify whether the control should automatically move the tilting axes to home position (MOVE or TURN) or not (STAY)
 Further information: "Automatic tilting into position MOVE/TURN/STAY", Page 479



▶ Press the **END** key.



The **PLANE RESET** function resets the active tilt and the angles (**PLANE** function or Cycle **19**) (angle = 0 and function inactive). It does not need to be defined more than once

Deactivate tilting in the **Manual operation** mode in the 3-D ROT menu.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

Defining the working plane with spatial angles: PLANE SPATIAL

Application

Spatial angles define a working plane through up to three rotations in the non-tilted workpiece coordinate system (**tilting sequence A-B-C**).

Most users assume three successive rotations in reverse order (tilting sequence C-B-A).


The result is identical for both perspectives, as the following comparison shows.

Further information: "Comparison of views - Example: chamfer", Page 465



Programming notes:

- You must always define all three spatial angles SPA, SPB and SPC, even if one or more have the value 0.
- Depending on the machine, Cycle 19 requires you to enter spatial angles or axis angles. If the configuration (machine parameter setting) allows the input of spatial angles, the angle definition is the same in Cycle 19 and in the PLANE SPATIAL function.
- You can select the desired positioning behavior. Further information: "Defining the positioning behavior of the PLANE function", Page 478




Input parameters


Example

5 PLANE SPATIAL SPA+27 SPB+0 SPC+45



- ➤ **Spatial angle A?**: Rotational angle **SPA** about the (non-tilted) X axis. Input range from -359.9999 to +359.9999
- ▶ **Spatial angle B?**: Rotational angle **SPB** about the (non-tilted) Y axis. Input range from -359.9999 to +359.9999
- ▶ **Spatial angle C?**: Rotational angle **SPC** about the (non-tilted) Z axis. Input range from -359.9999 to +359.9999
- Continue with the positioning properties Further information: "Defining the positioning behavior of the PLANE function", Page 478







Comparison of views - Example: chamfer Example

11 PLANE SPATIAL SPA+45 SPB+0 SPC+90 TURN MB MAX FMAX SYMTABLE ROT

View A-B-C



Initial state



SPA+45


Orientation of tool axis **Z**Rotation around the X axis of the non-tilted workpiece coordinate system **W-CS**



SPB+0

Rotation around the Y axis of the non-tilted **W-CS**

No rotation with value 0




SPC+90


Orientation of main axis **X**Rotation around the Z axis of the non-tilted **W-CS**



View C-B-A



Initial state




SPC+90

Orientation of main axis **X**Rotation around the Z axis of the workpiece coordinate system **W-CS**, meaning in the non-tilted working plane

SPB+0

Rotation around the Y axis in the working plane coordinate system **WPL-CS**, meaning in the tilted working plane No rotation with value 0



SPA+45

Orientation of tool axis **Z**Rotation around the X axis in **WPL-CS**, meaning in the tilted working plane

Both views have an identical result.

Abbreviations used

Abbreviation	Meaning
SPATIAL	Spatial = in space
SPA	Sp atial A : Rotation about the (non-tilted) X axis
SPB	Sp atial B : Rotation about the (non-tilted) Y axis
SPC	Sp atial C : Rotation about the (non-tilted) Z axis

Defining the working plane with projection angles: PLANE PROJECTED


Application

Projection angles define a machining plane through the entry of two angles that you determine by projecting the first coordinate plane (Z/X plane with tool axis Z) and the second coordinate plane (Y/Z with tool axis Z) onto the machining plane to be defined.



Programming notes:

- The projection angles correspond to the angle projections on the planes of a rectangular coordinate system. The angles at the outer faces of the workpiece only are identical to the projection angles if the workpiece is rectangular. Thus, with workpieces that are not rectangular, the angle specifications from the engineering drawing often differ from the actual projection angles.
- You can select the desired positioning behavior. Further information: "Defining the positioning behavior of the PLANE function", Page 478




PROMIN, +

Input parameters



- ▶ Projection angle on 1st Coordinate plane?: Projected angle of the tilted machining plane in the 1st coordinate plane of the untilted coordinate system (Z/X for tool axis Z). Input range: from -89.9999° to +89.9999°. The 0° axis is the principal axis of the active working plane (X for tool axis Z, positive direction)
- ▶ **Projection angle on 2nd Coordinate plane?**:
 Projected angle in the 2nd coordinate plane of the untilted coordinate system (Y/Z for tool axis Z).
 Input range: from −89.9999° to +89.9999°. The 0° axis is the secondary axis of the active machining plane (Y for tool axis Z)
- ▶ **ROT angle of tilted plane?**: Rotation of the tilted coordinate system around the tilted tool axis (corresponds to a rotation with Cycle **10**). The rotation angle provides an easy way to specify the direction of the principal axis of the working plane (X for tool axis Z, Z for tool axis Y). Input range: −360° to +360°
- Continue with the positioning properties Further information: "Defining the positioning behavior of the PLANE function", Page 478



PROPR

Example

5 PLANE PROJECTED PROPR+24 PROMIN+24 ROT+30

Abbreviations used:

PROJECTEDProjectedPROPRPrincipal planePROMINMinor planeROTRotation



Defining the working plane with Euler angles: PLANE EULER


Application

Euler angles define a machining plane through up to three **rotations about the respectively tilted coordinate system**. The Swiss mathematician Leonhard Euler defined these angles.



You can select the desired positioning behavior.

Further information: "Defining the positioning behavior of the PLANE function", Page 478



Input parameters




- ▶ Rot. angle Main coordinate plane?: Rotary angle EULPR around the Z axis. Please note:
 - Input range: -180.0000° to 180.0000°
 - The 0° axis is the X axis
- ► Tilting angle tool axis?: Tilting angle EULNUT of the coordinate system around the X axis shifted by the precession angle. Please note:
 - Input range: 0° to 180.0000°
 - The 0° axis is the Z axis
- ROT angle of tilted plane?: EULROT rotation of the tilted coordinate system around the tilted Z axis (corresponds to a rotation with Cycle 10). Use the rotation angle to easily define the direction of the X axis in the tilted working plane.

Please note:

- Input range: 0° to 360.0000°
- The 0° axis is the X axis
- Continue with the positioning properties Further information: "Defining the positioning behavior of the PLANE function", Page 478





5 PLANE EULER EULPR45 EULNU20 EULROT22



Abbreviations used

Abbreviation	Meaning	
EULER	Swiss mathematician who defined these angles	
EULPR	Pr ecession angle: angle describing the rotation of the coordinate system around the Z axis	
EULNU	Nu tation angle: angle describing the rotation of the coordinate system around the X axis shifted by the precession angle	
EULROT	Rot ation angle: angle describing the rotation of the tilted machining plane around the tilted Z axis	





Defining the working plane with two vectors: PLANE VECTOR

Application

You can use the definition of a working plane via **two vectors** if your CAD system can calculate the base vector and normal vector of the tilted machining plane. A normalized input is not necessary. The control internally calculates the normal, so you can enter values between -9.999999 and +9.999999.

The base vector required for the definition of the machining plane is defined by the components **BX**, **BY** and **BZ**. The normal vector is defined by the components **NX**, **NY** and **NZ**.



Programming notes:

- The control calculates standardized vectors from the values you enter.
- The normal vector defines the slope and the orientation of the working plane. The base vector defines the orientation of the main axis X in the defined working plane. To ensure that the definition of the working plane is unambiguous, you must program the vectors perpendicular to each other. The machine tool builder defines how the control will behave for vectors that are not perpendicular.
- The programmed normal vector must not be too short, e.g. all directional components having a length of 0 or 0.0000001. In this case, the control would not be able to determine the slope. Machining is aborted and an error message is displayed. This behavior is independent of the configuration of the machine parameters.
- You can select the desired positioning behavior. Further information: "Defining the positioning behavior of the PLANE function", Page 478



Refer to your machine manual.

The machine tool builder configures the behavior of the control with vectors that are not perpendicular.


Alternatively to generating the default error message, the control can correct (or replace) the base vector that is not perpendicular. This correction (or replacement) does not affect the normal vector.

Default correction behavior of the control if the base vector is not perpendicular:

The base vector is projected along the normal vector onto the working plane (defined by the normal vector).

Correction behavior of the control if the base vector is not perpendicular and too short, parallel or antiparallel to the normal vector:

- If the normal vector has no X component, the base vector corresponds to the original X axis
- If the normal vector has no Y component, the base vector corresponds to the original Y axis




Input parameters




- ➤ X component of base vector?: X component BX of the base vector B; input range: from -9.9999999 to +9.9999999
- ➤ Y component of base vector?: Y component BY of the base vector B; input range: from -9.9999999 to +9.9999999
- ► **Z component of base vector?**: Z component **BZ** of the base vector B; input range: from -9.9999999 to +9.9999999
- ➤ X component of normal vector?: X component NX of the normal vector N; input range: from -9.9999999 to +9.9999999
- ► Y component of normal vector?: Y component NY of the normal vector N; input range: from -9.9999999 to +9.9999999
- ➤ **Z component of normal vector?**: Z component **NZ** of the normal vector N; input range: from -9.9999999 to +9.9999999
- Continue with the positioning properties Further information: "Defining the positioning behavior of the PLANE function", Page 478







Abbreviations used

Abbreviation	Meaning	
VECTOR	Vector	
BX, BY, BZ	B ase vector : X , Y , and Z components	
NX, NY, NZ	Normal vector : X, Y, and Z components	







Defining the working plane via three points: PLANE POINTS


Application

A working plane can be uniquely defined by entering **any three points P1 to P3 in this plane**. This possibility is realized in the **PLANE POINTS** function.



Programming notes:

- The three points define the slope and orientation of the plane. The position of the active datum is not changed through **PLANE POINTS**.
- Point 1 and Point 2 determine the orientation of the tilted main axis X (for tool axis Z).
- Point 3 defines the slope of the tilted working plane. In the defined working plane, the Y axis is automatically oriented perpendicularly to the main axis X. The position of Point 3 thus also determines the orientation of the tool axis and consequently the orientation of the working plane. To have the positive tool axis pointing away from the workpiece, Point 3 must be located above the connection line between Point 1 and Point 2 (right-hand rule).
- You can select the desired positioning behavior. Further information: "Defining the positioning behavior of the PLANE function", Page 478



Input parameters




- X coordinate of 1stplane point?: X coordinate P1X of the 1st plane point
- ► Y coordinate of 1stplane point?: Y coordinate P1Y of the 1st plane point
- ► **Z coordinate of 1stplane point**: Z coordinate **P1Z** of the 1st plane point
- ➤ X coordinate of 2ndplane point?: X coordinate P2X of the 2nd plane point
- ► Y coordinate of 2ndplane point?: Y coordinate P2Y of the 2nd plane point
- Z coordinate of 2ndplane point?: Z coordinate P2Z of the 2nd plane point
- X coordinate of 3rdplane point?: X coordinate P3X of the 3rd plane point
- ► Y coordinate of 3rdplane point?: Y coordinate P3Y of the 3rd plane point
- ► **Z coordinate of 3rdplane point?**: Z coordinate **P3Z** of the 3rd plane point
- Continue with the positioning properties Further information: "Defining the positioning behavior of the PLANE function", Page 478





5 PLANE POINTS P1X+0 P1Y+0 P1Z+20 P2X+30 P2Y+31 P2Z+20 P3X+0 P3Y+41 P3Z+32.5



Abbreviation	Meaning
POINTS	Points







Defining the working plane via a single incremental spatial angle: PLANE RELATIV


Application

Use a relative spatial angle when an already active tilted working plane is to be tilted by **another rotation**. Example: machining a 45° chamfer on a tilted plane.



Programming notes:

- The defined angle is always in effect in respect to the active working plane, regardless of the tilting function you used before.
- You can program any number of PLANE RELATIV functions in a row.
- If you want to return the working plane to the orientation that was active before the PLANE RELATIV function, define the same PLANE RELATIV function again but enter the value with the opposite algebraic sign.
- If you use PLANE RELATIV without previous tilting, PLANE RELATIV will be effective directly in the workpiece coordinate system. In this case, you can tilt the original working plane by entering a defined spatial angle in the PLANE RELATIV function.
- You can select the desired positioning behavior. Further information: "Defining the positioning behavior of the PLANE function", Page 478



Input parameters




- ▶ Incremental angle?: Spatial angle by which the active machining plane is to be rotated. Use a soft key to select the axis to be rotated around. Input range: -359.9999° to +359.9999°
- Continue with the positioning properties Further information: "Defining the positioning behavior of the PLANE function", Page 478



5 PLANE RELATIV SPB-45

Abbreviations used

Abbreviation	Meaning
RELATIV	Relative to



Tilting the working plane through axis angles: PLANE AXIAL

Application

The **PLANE AXIAL** function defines both the slope and the orientation of the working plane and the nominal coordinates of the rotary axes.



PLANE AXIAL can also be used on machines that have only one rotary axis.

The input of nominal coordinates (axis angle input) is advantageous in that it provides an unambiguously defined tilting situation based on defined axis positions. Spatial angles entered without an additional definition are often mathematically ambiguous. Without the use of a CAM system, entering axis angles, in most cases, only makes sense if the rotary axes are positioned perpendicularly.




Refer to your machine manual.

If your machine allows spatial angle definitions, you can continue your programming with **PLANE RELATIV** after **PLANE AXIAL**.



Programming notes:

- The axis angles must correspond to the axes present on the machine. If you try to program axis angles for rotary axes that do not exist on the machine, the control will generate an error message.
- Use PLANE RESET to reset the PLANE AXIAL function. Entering 0 only resets the axis angle, but does not deactivate the tilting function.
- The axis angles of the **PLANE AXIAL** function are modally effective. If you program an incremental axis angle, the control will add this value to the currently effective axis angle. If you program two different rotary axes in two successive **PLANE AXIAL** functions, the new working plane is derived from the two defined axis angles.
- SYM (SEQ), TABLE ROT, and COORD ROT have no function in conjunction with PLANE AXIAL.
- The **PLANE AXIAL** function does not take basic rotation into account.




Input parameters

Example

5 PLANE AXIAL B-45



- ➤ Axis angle A?: Axis angle to which the A axis is to be tilted. If entered incrementally, it is the angle by which the A axis is to be tilted from its current position. Input range: -99999.9999° to +99999.9999°
- ▶ **Axis angle B?**: Axis angle **to which** the B axis is to be tilted. If entered incrementally, it is the angle **by which** the B axis is to be tilted from its current position. Input range: ¬99999.9999° to +99999.9999°
- ➤ Axis angle C?: Axis angle to which the C axis is to be tilted. If entered incrementally, it is the angle by which the C axis is to be tilted from its current position. Input range: -99999.9999° to +99999.9999°
- Continue with the positioning properties Further information: "Defining the positioning behavior of the PLANE function", Page 478



Abbreviations used

Abbreviation	Meaning
AXIAL	In the axial direction

Defining the positioning behavior of the PLANE function

Overview

Independently of which PLANE function you use to define the tilted machining plane, the following functions are always available for the positioning behavior:

- Automatic positioning
- Selecting alternate tilting options (not for PLANE AXIAL)
- Selecting the type of transformation (not for PLANE AXIAL)

NOTICE

Danger of collision!

Cycle **8 MIRRORING** can have different effects in conjunction with the **Tilt working plane** function. The programming sequence, the mirrored axes, and the tilting function used are critical in this regard. There is a risk of collision during the tilting operation and subsequent machining!

- ▶ Check the sequence and positions using a graphic simulation
- Carefully test the NC program or program section in the Program run, single block operating mode

- 1 When Cycle **8 MIRRORING** is programmed before the tilting function without rotary axes:
 - The tilt of the **PLANE** function used (except **PLANE AXIAL**) is mirrored
 - Mirroring takes effect after tilting with PLANE AXIAL or Cycle 19
- 2 When Cycle **8 MIRRORING** is programmed before the tilting function with a rotary axis:
 - The mirrored rotary axis has no effect on the tilt specified in the PLANE function used, because only the movement of the rotary axis is mirrored

Automatic tilting into position MOVE/TURN/STAY

After you have entered all of the parameters for the plane definition, you must specify how the control is to tilt the rotary axes to the calculated axis value. This entry is mandatory.

The control offers the following ways of tilting the rotary axes to the calculated axis values:



- ► The PLANE function is to automatically tilt the rotary axes to the calculated axis values, with the relative position between the tool and the workpiece remaining the same.
- > The control carries out a compensating movement in the linear axes.



- ► The PLANE function is to automatically tilt the rotary axes to the calculated axis values, during which only the rotary axes are positioned.
- > The control does **not** carry out a compensating movement in the linear axes.



 You tilt the rotary axes into position in a subsequent, separate positioning block


If you have selected the **MOVE** option (**PLANE** function is to automatically tilt into position with a compensation movement), then the two subsequently declared parameters **Dist. tool tip - center of rot.** and **Feed rate? F=** must still be defined.

If you have selected the **TURN** option (**PLANE** function is to automatically tilt into position without compensation movement), then the subsequently declared **Feed rate?** parameter $\mathbf{F} = \mathbf{must}$ still be defined.


As an alternative to a feed rate **F** defined directly by a numerical value, you can also tilt the axes into position with **FMAX** (rapid traverse) or **FAUTO** (feed rate from the **TOOL CALL** block).





If you use **PLANE** together with **STAY,** you have to position the rotary axes in a separate block after the **PLANE** function.



- ▶ **Dist. tool tip center of rot.** (incremental): The **DIST** parameter shifts the center of rotation of the tilting movement relative to the current position of the tool tip.
 - If the tool is already at the specified distance from the workpiece prior to being tilted into position, then it will be at the same relative position after being tilted into position (see center figure on the right, 1 = DIST)
 - If the tool is not at the specified distance from the workpiece before being tilted into position, then it will be offset relative to the original position after being tilted into position (see lower figure on the right, 1 = DIST)
- > The control tilts the tool (or table) relative to the tool tip.
- ► Feed rate? F=: Contour speed at which the tool is to be tilted into position
- ▶ Retraction length in the tool axis?: The retraction path MB takes effect incrementally from the current tool position in the active tool axis direction that the control approaches before tilting. MB MAX moves the tool to a position just before the software limit switch







Tilting the rotary axes into position in a separate NC block

To tilt the rotary axes into position in a separate positioning block (**STAY** option selected), proceed as follows:

NOTICE

Danger of collision!

The control does not automatically check whether collisions can occur between the tool and the workpiece. Incorrect or no prepositioning before tilting the tool into position can lead to a risk of collision during the tilting movement!

- Program a safe position before the tilting movement
- ► Carefully test the NC program or program section in the **Program run, single block** operating mode
- Select any PLANE function, and define automatic tilting into position with STAY. During program run, the control calculates the position values of the rotary axes present on the machine, and stores them in the system parameters Q120 (A axis), Q121 (B axis), and Q122 (C axis)
- Define the positioning block with the angular values calculated by the control

Example: Tilt a machine with a rotary table C and a tilting table A to a spatial angle of B+45

12 L Z+250 RO FMAX	Position at clearance height
13 PLANE SPATIAL SPA+0 SPB+45 SPC+0 STAY	Define and activate the PLANE function
14 L A+Q120 C+Q122 F2000	Position the rotary axis with the values calculated by the control.
	Define machining in the tilted working plane

Selection of tilting possibilities SYM (SEQ) +/-

Based on the position that you have defined for the working plane, the control must calculate the appropriate position of the rotary axes present on your machine. In general, there are always two possible solutions.

For the selection of one of the possible solutions, the control offers two variants: **SYM** and **SEQ**. You use soft keys to choose the variants. **SYM** is the standard variant.

The entry of **SYM** or **SEQ** is optional.

SEQ assumes that the master axis is in its home position (0°) . Relative to the tool, the master axis is the first rotary axis, or the last rotary axis relative to the table (depending on the machine configuration). If both possible solutions are in the positive or negative range, then the control automatically uses the closer solution (shorter path). If you need the second possible solution, then you must either pre-position the master axis (in the area of the second possible solution) before tilting the working plane, or work with **SYM**.

As opposed to **SEQ. SYM** uses the symmetry point of the master axis as its reference. Every master axis has two symmetry positions, which are 180° apart from each other (sometimes only one symmetry position is in the traverse range).





To determine the symmetry point:

- Perform PLANE SPATIAL with any spatial angle and SYM
- ➤ Save the axis angle of the master axis in a Q parameter (e.g., -80)
- ► Repeat the **PLANE SPATIAL** function with **SYM**-
- ► Save the axis angle of the master axis in a Q parameter (e.g., -100)
- ► Calculate the average value (e.g., -90)
 The average value corresponds to the symmetry point.

Reference for SEQ


Reference for SYM





With the **SYM** function, you select one of the possible solutions relative to the symmetry point of the master axis:

- **SYM+** positions the master axis in the positive half-space relative to the symmetry point
- **SYM-** positions the master axis in the negative half-space relative to the symmetry point



With the **SEQ** function, you select one of the possible solutions relative to the home position of the master axis:

- SEQ+ positions the master axis in the positive tilting range relative to the home position
- **SEQ-** positions the master axis in the negative tilting range relative to the home position

If the solution you have selected with **SYM** (**SEQ**) is not within the machine's range of traverse, then the control displays the **Entered angle not permitted** error message.



If the **PLANE AXIAL** function is used, the **SYM (SEQ)** function has no effect.

If you do not define \mathbf{SYM} (SEQ), then the control determines the solution as follows:

- 1 Check whether both possible solutions are within the traverse range of the rotary axes
- 2 Two possible solutions: Based on the current position of the rotary axes, choose the possible solution with the shortest path
- 3 One possible solution: Choose the only solution
- 4 No possible solution: Issue the error message **Entered angle not permitted**

Examples


Machine with C rotary axis and A tilting table.

Programmed function: PLANE SPATIAL SPA+0 SPB+45 SPC+0

Limit switch	Start position	SYM = SEQ	Resulting axis position
None	A+0, C+0	Not prog.	A+45, C+90
None	A+0, C+0	+	A+45, C+90
None	A+0, C+0	-	A-45, C-90
None	A+0, C-105	Not prog.	A-45, C-90
None	A+0, C-105	+	A+45, C+90
None	A+0, C-105	_	A-45, C-90
-90 < A < +10	A+0, C+0	Not prog.	A-45, C-90
-90 < A < +10	A+0, C+0	+	Error message
-90 < A < +10	A+0, C+0	-	A-45, C-90

Machine with B rotary axis and A tilting table (limit switches: A +180 and -100). Programmed function: PLANE SPATIAL SPA-45 SPB+0 SPC+0

SYM	SEQ	Resulting axis position	Kinematics view
+		A-45, B+0	×½z
-		Error message	No solution in limited range
	+	Error message	No solution in limited range
	-	A-45, B+0	x 1





The position of the symmetry point is contingent on the kinematics. If you change the kinematics (such as switching the head), then the position of the symmetry point changes as well.

Depending on the kinematics, the positive direction of rotation of **SYM** may not correspond to the positive direction of rotation of **SEQ**. Therefore, ascertain the position of the symmetry point and the direction of rotation of **SYM** on each machine before programming.

Selection of the transformation type

The **COORD ROT** and **TABLE ROT** transformation types influence the orientation of the working plane coordinate system through the axis position of a so-called free rotary axis.

The entry of **COORD ROT** or **TABLE ROT** is optional.

Any rotary axis becomes a free rotary axis with the following configuration:


- The rotary axis has no effect on the tool angle of inclination because the rotary axis and the tool axis are parallel in the tilting situation
- The rotary axis is the first rotary axis in the kinematic chain starting from the workpiece

The effect of the **COORD ROT** and **TABLE ROT** transformation types therefore depends on the programmed spatial angles and the machine kinematics.



Programming notes:

- If no free rotary axis arises in a tilting situation, then the COORD ROT and TABLE ROT transformation types have no effect.
- With the **PLANE AXIAL** function, the **COORD ROT** and **TABLE ROT** transformation types have no effect.



Effect with a free rotary axis



Programming notes

- For the positioning behavior with the **COORD ROT** and **TABLE ROT** transformation types, it makes no difference whether the free rotary axis is a table axis or a head axis.
- The resulting axis position of the free rotary axis depends on an active basic rotation, among other factors.
- The orientation of the working plane coordinate system is also dependent on a programmed rotation (e.g., with Cycle 10 ROTATION).

Soft key

Function



COORD ROT:

- > The control positions the free rotary axis to 0
- The control orients the working plane coordinate system in accordance with the programmed spatial angle



TABLE ROT with:

- SPA and SPB equal to 0
- SPC equal or unequal to 0
- The control orients the free rotary axis in accordance with the programmed spatial angle
- The control orients the working plane coordinate system in accordance with the basic coordinate system

TABLE ROT with:

- At least SPA or SPB unequal to 0
- SPC equal or unequal to 0
- The control does not position the free rotary axis. The position prior to tilting the working plane is maintained
- Since the workpiece was not positioned, the control orients the working plane coordinate system in accordance with the programmed spatial angle



If no transformation type was selected, then the control uses the **COORD ROT** transformation type for the **PLANE** functions

Example

The following example shows the effect of the **TABLE ROT** transformation type in conjunction with a free rotary axis.

6 L B+45 R0 FMAX

Pre-position rotary axis

7 PLANE SPATIAL SPA-90 SPB+20 SPC+0 TURN F5000 TABLE ROT

Tilt the working plane


•••

Origin

A = 0, B = 45

A = -90, B = 45







- > The control positions the B axis to the axis angle B+45
- > With the programmed tilting situation with SPA-90, the B axis becomes the free rotary axis
- > The control does not position the free rotary axis. The position of the B axis prior to the tilting of the working plane is maintained
- Since the workpiece was not also positioned, the control orients the working plane coordinate system in accordance with the programmed spatial angle SPB+20

Tilting the working plane without rotary axes



Refer to your machine manual.

This function must be enabled and adapted by the machine manufacturer.

The machine manufacturer must take the precise angle into account (e.g., the angle of a mounted angle head in the kinematics description).

You can also orient the programmed working plane perpendicularly to the tool without defining rotary axes (e.g., when adapting the working plane for a mounted angle head).

Use the **PLANE SPATIAL** function and the **STAY** positioning behavior to swivel the working plane to the angle specified by the machine manufacturer.

Example of mounted angle head with permanent tool direction **Y**:

Example

11 TOOL CALL 5 Z S4500

12 PLANE SPATIAL SPA+0 SPB-90 SPC+0 STAY



The tilt angle must be precisely adapted to the tool angle, otherwise the control will generate an error message.

11.3 Inclined machining (option 9)

Function

In combination with **M128** and the **PLANE** functions, inclined-tool machining is possible in a tilted working plane.


Inclined machining can be implemented using the following functions:

- Inclined machining via incremental traversing of a rotary axis
- Inclined machining via normal vectors



Inclined machining in a tilted plane is only possible when using spherical cutters. When using 45° swivel heads and tilting tables, you can also define the inclination angle as a spatial angle. Use **FUNCTION TCPM** for this purpose.

Further information: "Compensating for the tool angle of inclination with FUNCTION TCPM (option 9)", Page 499



Inclined machining via incremental traversing of a rotary axis

- Retract the tool
- ▶ Define any PLANE function; consider the positioning behavior
- Activate M128
- ▶ Use a straight-line block to incrementally position the tool to the desired inclination angle in the appropriate axis

*	
12 L Z+50 R0 FMAX	; Position at clearance height
13 PLANE SPATIAL SPA+0 SPB-45 SPC+0 MOVE DIST50 F1000	; Define and activate the PLANE function
14 FUNCTION TCPM F TCP AXIS POS PATHCTRL AXIS	; Activate TCPM
15 L IB-17 F1000	; Pre-position the tool
*	

Inclined machining using normal vectors

Application

When operating in inclined machining mode using normal vectors, the control performs a simultaneous movement in three axes. If the miscellaneous function **M128** or the **FUNCTION TCPM** function is used, the position of the tool tip will be maintained during positioning of the rotary axes.

Further information: "Retaining the position of the tool tip during the positioning of tilting axes (TCPM): M128 (option 9)", Page 493

Further information: "Compensating for the tool angle of inclination with FUNCTION TCPM (option 9)", Page 499

To execute an NC program with LN blocks:

- Retract the tool
- ▶ Define any PLANE function; consider the positioning behavior
- ► Activate M128
- Execute NC program with LN blocks in which the tool direction is defined by a vector

*	
12 L Z+50 R0 FMAX	; Position at clearance height
13 PLANE SPATIAL SPA+0 SPB+45 SPC+0 MOVE DIST50 F1000	; Tilt the working plane
14 FUNCTION TCPM F TCP AXIS POS PATHCTRL AXIS	; Activate TCPM
15 LN X+31.737 Y+21,954 Z+33,165 NX+0,3 NY+0 NZ +0,9539 F1000 M3	; Incline the tool with the normal vector
*	

11.4 Miscellaneous functions for rotary axes

Feed rate in mm/min on rotary axes A, B, C: M116 (option 8)

Standard behavior

The control interprets the programmed feed rate of a rotary axis in degrees/min (in mm programs and also in inch programs). The feed rate therefore depends on the distance from the tool center to the center of the rotary axis.

The larger this distance becomes, the greater the contouring feed rate

Feed rate in mm/min on rotary axes with M116



Refer to your machine manual.

When working with angle heads, keep in mind that the machine geometry is defined by the machine manufacturer in a kinematics description. If you use an angle head during machining, then you must select the correct kinematics description.



Programming notes:

- The M116 function can be used with table axes and head axes.
- The M116 function also has an effect if the Tilt working plane function is active.
- It is not possible to combine the M128 or TCPM function with M116. If you want to activate M116 for an axis while the M128 or TCPM function is active, then you must indirectly deactivate the compensating movement for this axis using M138. This is done indirectly because, with M138, you specify the axis for which the M128 or TCPM function takes effect. Thus, M116 automatically affects the axis that was not selected with M138.

 Further information: "Selecting tilting axes: M138", Page 497
- Without the M128 or TCPM function, M116 can take effect for two rotary axes at the same time.

The control interprets the programmed feed rate of a rotary axis in mm/min (or 1/10 inch/min). In this case, the control calculates the feed for the block at the start of each NC block. The feed rate of a rotary axis will not change while the NC block is executed, even if the tool moves toward the center of the rotary axis.

Effect

M116 is effective in the working plane. Reset **M116** with **M117**. At the end of the program, **M116** is automatically canceled.

M116 becomes effective at the start of the block

Shorter-path traverse of rotary axes: M126

Standard behavior



Refer to your machine manual.

The positioning behavior of rotary axes is machinedependent.

M126 has an effect only on modulo axes.

In the case of modulo axes, the axis position begins again at 0° after the modulo length of 0° to 360° has been exceeded. This is the case for rotary axes that are mechanically capable of endless rotation.

In the case of non-modulo axes, the maximum rotation is mechanically limited. The position display of the rotary axis does not switch back to the starting value (e.g., 0° to 540°).

The machine parameter **shortestDistance** (no. 300401) defines the standard behavior for the positioning of rotary axes. It is effective only for rotary axes whose position display is limited to a range of traverse of less than 360°. If the parameter is inactive, then the control traverses the programmed value from the actual position to the nominal position. If the parameter is active, then the control moves to the nominal position on the shortest path (even without **M126**).

Behavior without M126:

Without **M126**, the control moves a rotary axis whose position display is reduced to less than 360° along a long path.

Examples:

Actual position	Target position	Traverse distance
350°	10°	-340°
10°	340°	+330°

Behavior with M126

With **M126**, the control moves a rotary axis whose position display is reduced to less than 360° on the shortest path of traverse.

Examples:

Actual position	Target position	Traverse distance
350°	10°	+20°
10°	340°	-30°

Effect

M126 takes effect at the start of the block.

M127 and a program end reset M126.

Reducing display of a rotary axis to a value less than 360°: M94

Standard behavior

The control moves the tool from the current angular value to the programmed angular value.

Example:

Current angular value: 538°
Programmed angular value: 180°
Actual distance of traverse: -358°

Behavior with M94

At the start of block, the control first reduces the current angular value to a value less than 360° and then moves the tool to the programmed value. If multiple rotary axes are active, **M94** will reduce the display of all rotary axes. As an alternative, you can specify a rotary axis after **M94**. The control then reduces the display of this axis only.

If you entered a traverse limit or a software limit switch is active, **M94** is ineffective for the corresponding axis.

21 L M94	; Reduce the display values of all rotary axes
21 L M94 C	; Reduce the display value of the C axis
21 L C+180 FMAX M94	; Reduce the display values of all active rotary axes and then move in the C axis to the programmed value

Effect

 $\ensuremath{\mathbf{M94}}$ is effective only in the NC block where it is programmed.

M94 becomes effective at the start of the block.

Retaining the position of the tool tip during the positioning of tilting axes (TCPM): M128 (option 9)

Standard behavior

If the inclination angle of the tool changes, this results in an offset of the tool tip compared to the nominal position. The control does not compensate for this offset. If the operator does not take this deviation into account in the NC program, offset machining is executed.

Behavior with M128 (TCPM: Tool Center Point Management)

If the position of a controlled tilting axis changes in the NC program, then the position of the tool tip relative to the workpiece remains unchanged.

NOTICE


Danger of collision!

Rotary axes with Hirth coupling must move out of the coupling to enable tilting. There is a danger of collision while the axis moves out of the coupling and during the tilting operation.

Make sure to retract the tool before changing the position of the rotary axis

After **M128**, you can still enter a maximum feed rate at which the control will carry out the compensating movements in the linear axes.

If you want to change the position of the tilting axis with the handwheel during program run, then use **M128** in conjunction with **M118**. The superimposing of handwheel positioning is performed with active **M128**, depending on the setting in the 3D ROT menu of **Manual operation** mode, in the active coordinate system or in the non-tilted coordinate system.





Programming notes:

- Before positioning with M91 or M92, and before a TOOL
 CALL block, reset the M128 function
- To avoid contour damage, use only radius cutters with M128
- The tool length must be measured from the spherical center of the Ball-nose cutter
- If M128 is active, then the control shows the TCPM symbol in the status display
- The **TCPM** or **M128** functions cannot be used in conjunction with the functions and, additionally, with **M118**
- The machine manufacturer uses the optional machine parameter **presetToAlignAxis** (no. 300203) to define for each axis how the control is to interpret offset values. For **FUNCTION TCPM** and **M128**, the machine parameter applies only to the rotary axis that rotates about the tool axis (in most cases **C_OFFS**).

Further information: User's Manual for **Setup, Testing and Running NC Programs**

- If the machine parameter axis has not been defined or has been set to TRUE, the offset can be used to compensate a misalignment of the workpiece in the plane. The offset affects the orientation of the workpiece coordinate system W-CS.
 - **Further information:** "Workpiece coordinate system W-CS", Page 82
- If the machine parameter axis has been defined with FALSE, the offset cannot be used to compensate a misalignment of the workpiece in the plane. The control will not take the offset into account when executing the commands.

M128 on tilting tables

If you program a tilting table movement while **M128** is active, then the control rotates the coordinate system accordingly. For example, if you rotate the C axis by 90° (through a positioning command or datum shift) and then program a movement in the X axis, the control executes the movement in the machine's Y axis.

The control also transforms the set preset, which has been shifted by the movement of the rotary table.

M128 with three-dimensional tool compensation

If you carry out a three-dimensional tool compensation with active **M128** and active radius compensation **RL/RR**, then the control will automatically position the rotary axes for certain machine geometries (peripheral milling).

Further information: "Three-dimensional tool compensation (option 9)", Page 507

Effect

M128 takes effect at the start of the block, and M129 takes effect at the end of the block. M128 also takes effect in the manual operating modes and remains active even after a change in the operating mode. The feed rate for the compensating movement remains in effect until you program a new feed rate or reset M128 with M129.

You can reset **M128** with **M129**. The control also resets **M128** when you select a new NC program in a program run mode.

Example: Perform compensation movements at a feed rate of no more than 1000 mm/min

L X+0 Y+38.5 IB-15 RL F125 M128 F1000

Inclined-tool machining with non-controlled rotary axes

If your machine has non-controlled rotary axes (also known as counter axes), then you can also perform inclined machining operations with these axes in conjunction with **M128**.

Proceed as follows:

- 1 Manually traverse the rotary axes to the desired positions. **M128** must not be active during this operation
- 2 Activate **M128**: the control reads the actual values of all existing rotary axes, calculates from this the new position of the tool center point, and updates the position display
- 3 The control performs the necessary compensating movement in the next positioning block
- 4 Execute the machining operation
- 5 At program end, reset **M128** with **M129**, and return the rotary axes to their initial positions



As long as **M128** is active, the control monitors the actual positions of the non-controlled rotary axes. If the actual position deviates from the value that is defined by the machine manufacturer, then the control issues an error message and interrupts program run.

Selecting tilting axes: M138

Standard behavior

With the functions M128, TCPM and Tilt working plane, the control considers those rotary axes that have been specified by the machine tool builder in the machine parameters.

Behavior with M138

The control performs the above functions only in those tilting axes that you have defined using **M138**.



Refer to your machine manual.

If you restrict the number of tilting axes with the M138 function, your machine may provide only limited tilting possibilities. The machine manufacturer will decide whether the control takes the angles of deselected axes into account or sets them to 0.

Effect

M138 becomes effective at the start of the block.

You can cancel **M138** by reprogramming it without specifying any axes.

Example

Perform the above-mentioned functions only in the tilting axis C.

11 L Z+100 R0 FMAX M138 C

; Define that the C axis should be taken into account

Compensating the machine kinematics in ACTUAL/ NOMINAL positions at end of block: M144 (Option 9)

Standard behavior

If the kinematics change, e.g. by inserting an adapter spindle or entering an inclination angle, the control will not compensate this modification. If the operator does not consider this modification to the kinematics for the NC program, machining will occur with an offset.

Behavior with M144



Refer to your machine manual.

When working with angle heads, keep in mind that the machine geometry is defined by the machine manufacturer in a kinematics description. If you use an angle head during machining, then you must select the correct kinematics description.

The **M144** function enables the control to consider the modification to the machine kinematics in the position display and compensate the offset of the tool tip in relation to the workpiece.



Programming and operating notes:

- You can use M91 and M92 for positioning even when M144 is active
- The position display in the Program Run Full Sequence and Program Run Single Block operating modes does not change until the tilting axes have reached their final position.

Effect

M144 becomes effective at the start of the block. **M144** does not work in connection with **M128** or the Tilt Working Plane function.

You can cancel M144 by programming M145.

11.5 Compensating for the tool angle of inclination with FUNCTION TCPM (option 9)

Function



Refer to your machine manual.

When working with angle heads, keep in mind that the machine geometry is defined by the machine manufacturer in a kinematics description. If you use an angle head during machining, then you must select the correct kinematics description.

FUNCTION TCPM is an improvement on the **M128** function, with which you can define the behavior of the control during the positioning of rotary axes.

With **FUNCTION TCPM**, you can define the effects of various functions yourself:

- Effect of the programmed feed rate: F TCP / F CONT
- Interpretation of the rotary axis coordinates programmed in the NC program: AXIS POS / AXIS SPAT
- Type of orientation interpolation between the start and end positions: PATHCTRL AXIS / PATHCTRL VECTOR
- Optional selection of a tool reference point and a center of rotation: REFPNT TIP-TIP / REFPNT TIP-CENTER / REFPNT CENTER-CENTER
- Optional feed-rate limit to compensate movements in the linear axes for motions with a rotary-axis component: F


When **FUNCTION TCPM** is active, the control shows the \mathbf{TCPM} icon in the position display.

NOTICE

Danger of collision!

Rotary axes with Hirth coupling must move out of the coupling to enable tilting. There is a danger of collision while the axis moves out of the coupling and during the tilting operation.

Make sure to retract the tool before changing the position of the rotary axis





Programming notes:

- Before positioning axes with M91 or M92, and before a TOOL CALL block, reset the FUNCTION TCPM function.
- Only use ball-nose cutters for face milling in order to avoid contour damage. In combination with other tool shapes, make sure to use graphic simulation to test the NC program for possible contour damages.
- The machine manufacturer uses the optional machine parameter **presetToAlignAxis** (no. 300203) to define for each axis how the control is to interpret offset values. For **FUNCTION TCPM** and **M128**, the machine parameter applies only to the rotary axis that rotates about the tool axis (in most cases **C_OFFS**).

Further information: User's Manual for **Setup, Testing and Running NC Programs**

If the machine parameter axis has not been defined or has been set to TRUE, the offset can be used to compensate a misalignment of the workpiece in the plane. The offset affects the orientation of the workpiece coordinate system W-CS.

Further information: "Workpiece coordinate system W-CS", Page 82

If the machine parameter axis has been defined with FALSE, the offset cannot be used to compensate a misalignment of the workpiece in the plane. The control will not take the offset into account when executing the commands.

Defining FUNCTION TCPM



Select the special functions



Select the programming aids



▶ Select FUNCTION TCPM

Effect of the programmed feed rate


The control provides two functions for defining the effect of the programmed feed rate:



▶ **F TCP** determines that the programmed feed rate is interpreted as the actual relative velocity between the tool tip (tool center point) and the workpiece



▶ **F CONT** determines that the programmed feed rate is interpreted as the contouring feed rate of the axes programmed in the respective NC block.



13 FUNCTION TCPM F TCP	Feed rate refers to the tool tip
14 FUNCTION TCPM F CONT	Feed rate is interpreted as the speed of the tool along the contour

Interpretation of the programmed rotary axis coordinates

Up to now, machines with 45° swivel heads or 45° tilting tables could not easily set the angle of inclination or a tool orientation with respect to the currently active coordinate system (spatial angle). This function could only be realized through externally created NC programs with surface-normal vectors (LN blocks).

The control provides the following functionality:



▶ **AXIS POS** determines that the control interprets the programmed coordinates of rotary axes as the nominal position of the respective axis




► AXIS SPAT determines that the control interprets the programmed coordinates of rotary axes as spatial angles



Programming notes:

- The AXIS POS selection is primarily suitable in conjunction with perpendicularly arranged rotary axes. AXIS POS can only be used with different machine kinematics (e.g., 45° swivel heads) if the programmed rotary axis coordinates define the desired working plane alignment correctly (e.g., using a CAM system).
- The AXIS SPAT selection item defines the spatial angles relative to the I-CS input coordinate system. The defined angles have the effect of incremental spatial angles. In the first traversing block after the function FUNCTION TCPM, always program with AXIS SPAT, SPA, SPB and SPC, including with spatial angles of 0°.




13 FUNCTION TCPM F TCP AXIS POS	Rotary axis coordinates are axis angles
18 FUNCTION TCPM F TCP AXIS SPAT	Rotary axis coordinates are spatial angles
20 L A+0 B+45 C+0 F MAX	Set tool orientation to B+45 degrees (spatial angle). Define spatial angles A and C with 0

Orientation interpolation between the start position and end position

With these functions, you define how the tool orientation between the programmed start position and end position is to be interpolated:







▶ PATHCTRL VECTOR specifies that the tool orientation within the NC block always lies in the plane that is defined through the start orientation and end orientation. If the vector lies between the start position and end position in this plane, then milling with the tool circumference (peripheral milling) will produce a level surface.

In both cases, the programmed tool reference point is moved along a straight line between the start position and end position.



To obtain the most continuous multi-axis movement possible, define Cycle **32** with a **tolerance for rotary axes**.

Further information: User's Manual for **Programming of Machining Cycles**

PATHCTRL AXIS

You can use the **PATHCTRL AXIS** variant for NC programs with small orientation changes per NC block. In this case, the angle **TA** in Cycle **32** can be large.

You can use **PATHCTRL AXIS** both for face milling and also for peripheral milling.


Further information: "Running CAM programs", Page 519




HEIDENHAIN recommends the **PATHCTRL AXIS** variant. This enables smooth motion, which has a beneficial effect on the surface quality.

PATHCTRL VECTOR

You can use the **PATHCTRL VECTOR** variant for peripheral milling with large orientation changes per NC block.





Selection of tool reference point and center of rotation

The control provides the following functions for defining the tool reference point and center of rotation:



▶ **REFPNT TIP-TIP**: the (theoretical) tool tip is the reference point for positioning. The center of rotation is also located at the tool tip



▶ **REFPNT TIP-CENTER**: the tool tip is the reference point for positioning. With a milling cutter, the control references the theoretical tool tip for positioning, with a turning tool, it references the virtual tool tip. The center of rotation is located at the center of the cutting-edge radius.



▶ **REFPNT CENTER**-CENTER: the center of the cutting-edge radius is the reference point for positioning. The center of rotation is also located at the center of the cutting-edge radius.

The reference point is optional. If you do not enter anything, the control uses **REFPNT TIP-TIP**.

REFPNT TIP-TIP


The **REFPNT TIP-TIP** variant corresponds to the default behavior of **FUNCTION TCPM**. You can use all previously allowed cycles and functions.

REFPNT TIP-CENTER

The **REFPNT TIP-CENTER** variant is mainly intended for the use with turning tools. In this case the center of rotation and the positioning point are not coincident. In an NC block, the center of rotation (center of the cutting-edge radius) is kept in position, but at the end of the block, the tool tip will no longer be in its initial position.

The main goal of selecting this reference point is to enable machining of complex contours in turning mode with active radius compensation and simultaneously inclined tilting axes (simultaneous turning).

Further information: "Simultaneous turning", Page 584



REFPNT CENTER-CENTER

You can use the **REFPNT CENTER**-Variant to machine parts with a tool whose tip is used as a reference point when executing NC programs generated in a CAD/CAM software where the paths are referenced to the center of the cutting edge radius instead of the tool tip.

Previously, this functionality could only be achieved by shortening the tool with **DL**. The variant with **REFPNT CENTER** is advantageous in that the control knows the true tool length and can protect it with **DCM**.

If you use **REFPNT CENTER-CENTER** to program pocket milling cycles, the control generates an error message.

Example

13 FUNCTION TCPM F TCP AXIS SPAT PATHCTRL AXIS REFPNT TIP-TIP	Both the tool reference point and the center of rotation are located at the tool tip.
14 FUNCTION TCPM F TCP AXIS POS PATHCTRL AXIS REFPNT CENTER-CENTER	Both the tool reference point and the center of rotation are located at the center of the cutting-edge radius.

Limiting the linear-axis feed rate

The optional input of ${\bf F}$ allows you to limit the feed rate of linear axes for motions with a rotary-axis component.


Thus, you can avoid fast compensation movements (e.g., in case of retraction movement at rapid traverse).



Make sure to select a value for the linear axis feed-rate limit that is not too small because otherwise, large feed-rate variations at the tool center point (TCP) might occur. Feed-rate variations impair the surface quality.

If **FUNCTION TCPM** is active, the feed-rate limit affect only motions with a rotary-axis component, not for entirely linear motions.

The linear axis feed-rate limit remains in effect until you program a new value or reset **FUNCTION TCPM**.



Example

13 FUNCTION TCPM F TCP AXIS POS PATHCTRL AXIS REFPNT CENTER-CENTER F1000

The maximum feed rate for the linear axes compensation motion is 1000 mm/min

Resetting FUNCTION TCPM



► FUNCTION RESET TCPM is to be used if you want to purposely reset the function within an NC program.



When you select a new NC program in the **Program run**, single block or **Program run**, full sequence operating modes, the control automatically resets the **TCPM** function.

Example

25 FUNCTION RESET TCPM	Resetting FUNCTION TCPM


11.6 Three-dimensional tool compensation (option 9)


Introduction

The control can perform a three-dimensional tool compensation (3-D compensation) for straight line blocks. Apart from the X, Y, and Z coordinates of the straight-line end point, these NC blocks must also contain the components NX, NY, and NZ of the surface-normal vector.

Further information: "Definition of a normalized vector", Page 509 For an optional tool angle of inclination, the NC blocks must include an additional tool vector with the components TX, TY and TZ.

Further information: "Definition of a normalized vector", Page 509 The straight-line end point, the components for the surface normals as well as those for the tool orientation must be calculated by a CAM system.





Possible applications

- Use of tools with dimensions that do not correspond with the dimensions calculated by the CAM system (3-D compensation without definition of the tool orientation).
- Face milling: compensation of the cutter geometry in the direction of the surface-normal vector (3-D compensation with and without definition of the tool orientation). Cutting is usually with the end face of the tool.
- Peripheral milling: compensation of the cutter radius perpendicular to the direction of movement and perpendicular to the tool direction (3D radius compensation with definition of the tool orientation). Cutting is usually with the lateral surface of the tool.

Suppressing error messages with positive tool oversize: M107

Standard behavior

With positive tool compensation, programmed contours may be damaged. For NC programs with surface-normal blocks, the control checks whether critical oversizes result from tool compensations, and issues an error message if this is the case.

With Peripheral Milling the control triggers an error message in the following cases:

■ $DR_{Tab} + DR_{Prog} > 0$

With Face Milling the control triggers an error message in the following case:

- $DR_{Tab} + DR_{Prog} > 0$
- $\blacksquare R2 + DR2_{Tab} + DR2_{Prog} > R + DR_{Tab} + DR_{Prog}$
- \blacksquare R2 + DR2_{Tab} + DR2_{Prog} < 0
- $DR2_{Tab} + DR2_{Prog} > 0$

Behavior with M107

With M107 the control suppresses the error message.

Effect

M107 takes effect at the end of block.

You can reset M107 with M108.



With the **M108** function you can also have the radius of a replacement tool be checked even if three-dimensional tool compensation is not active.


Definition of a normalized vector

A normalized vector is a mathematical quantity possessing a magnitude of 1 and a direction. For LN blocks, the control requires up to two normalized vectors: one in order to determine the direction of the surface normals, and another (optional) to determine the direction of the tool orientation. The direction of a surface normal is determined by the components NX, NY, and NZ. In the case of an end mill and a Ball-nose cutter, the direction of the surface normals points away perpendicularly from the workpiece surface toward the tool reference point PT. A toroid cutter offers the possibility PT or PT' (see figure). The direction of tool orientation is determined by the components TX, TY, and TZ.



Programming notes:

- In the NC syntax, the order must be X,Y, Z for the position and NX, NY, NZ as well as TX, TY, TZ for the vectors.
- The NC syntax of LN blocks must always indicate all of the coordinates and all of the surface-normal vectors, even if the values have not changed from the previous NC block.
- Calculate the vectors as exactly as possible and specify them with at least 7 decimal places in order to avoid drastic feed rate decreases during machining.
- The 3D tool compensation using surface normal vectors is effective for the coordinate data specified for the main axes X, Y, Z.
- If you load a tool with oversize (positive delta value), the control generates an error message. You can suppress the error message with the M107 function.
- The control will not warn you if there is a danger of contour damage due to tool oversizes.



Permissible tool shapes

You can describe the permissible tool shapes in the tool table via tool radii **R** and **R2**:

- Tool radius **R**: Distance from the tool center to the tool circumference
- Tool radius 2 R2: Radius of the curvature between the tool tip and tool circumference

The value of **R2** generally determines the shape of the tool:

- **R2** = 0: End mill
- R2 > 0: Toroid cutter with corner radius (R2 = R: Ball-nose cutter)

These data also provide the coordinates of the tool datum PT.

Using other tools: Delta values

If you use tools that have different dimensions from those of the originally programmed tools, then you can enter the difference between the tool lengths and radii as delta values in the tool table or in the NC program:


- Positive delta value **DL**, **DR**: The tool is larger than the original tool (oversize)
- Negative delta value DL, DR: The tool is smaller than the original tool (undersize)

The control then compensates for the tool position by the sum of the delta values from the tool table and the programmed tool compensation (tool call or compensation table).

With **DR 2** you modify the rounding radius of the tool and therefore also the tool shape.

If you work with **DR 2** the following applies:

- $R2 + DR2_{Tab} + DR2_{Prog} = End mill$
- 0 < R2 + DR2_{Tab} + DR2_{Prog} < R: Toroid cutter</p>
- R2 + DR2_{Tab} + DR2_{Prog} = R: Ball-nose cutter




3-D compensation without TCPM

If the NC program includes surface normal vectors, the control performs a 3-D compensation for three-axis machining. In this case, the **RL/RR** radius compensation and **TCPM** or **M128** must be inactive. The control displaces the tool in the direction of the surface-normal vectors by the total of the delta values (from the tool table and **TOOL CALL**).



The control generally uses the defined **delta values** for 3D tool compensation. The entire tool radius (**R** + **DR**) is only taken into account if you have activated the **FUNCTION PROG PATH IS CONTOUR** function.

Further information: "Interpretation of the programmed path", Page 515



Example: Block format with surface-normal vectors

1 LN X+31.737 Y+21.954 Z+33.165NX+0.2637581 NY+0.0078922 NZ-0.8764339 F1000 M3

LN: Straight line with 3-D compensation

X, Y, Z: Compensated coordinates of the straight-line

end point

NX, NY, NZ: Components of the surface-normal vector

F: Feed rate

M: Miscellaneous function


Face Milling: 3D compensation with TCPM

Face milling is a machining operation carried out with the front face of the tool. If the NC program contains surface-normal vectors and **TCPM** or **M128** is active, then 3D compensation is executed with 5-axis machining. Radius compensation RL/RR must not be active in this case. The control displaces the tool in the direction of the surface-normal vectors by the total of the delta values (from the tool table and **TOOL CALL**).



The control generally uses the defined **delta values** for 3D tool compensation. The entire tool radius (**R** + **DR**) is only taken into account if you have activated the **FUNCTION PROG PATH IS CONTOUR** function.

Further information: "Interpretation of the programmed path", Page 515



Further information: "Retaining the position of the tool tip during the positioning of tilting axes (TCPM): M128 (option 9)", Page 493

If a tool orientation **T** is defined in the **LN** block, and **M128** (or **FUNCTION TCPM**) is simultaneously active, then the control automatically positions the rotary axes of the machine such that the tool reaches the defined tool orientation. If you have not activated **M128** (or **TCPM FUNCTION**), then the control ignores the direction vector **T**, even if it is defined in the **LN** block.



Refer to your machine manual.


The control is not able to automatically position the rotary axes on all machines.

NOTICE

Danger of collision!

The rotary axes of a machine may have limited ranges of traverse (e.g., between -90° and $+10^{\circ}$ for the B head axis). Changing the tilt angle to a value of more than $+10^{\circ}$ may result in a 180° rotation of the table axis. There is a danger of collision during the tilting movement!

- Program a safe tool position before the tilting movement, if necessary.
- Carefully test the NC program or program section in the Program run, single block operating mode



Example: Block format with surface-normal vectors without tool orientation

LN X+31.737 Y+21.954 Z+33.165 NX+0.2637581 NY+0.0078922 NZ-0.8764339 F1000 M128

Example: Block format with surface-normal vectors and tool orientation

LN X+31,737 Y+21,954 Z+33,165 NX+0,2637581 NY+0,0078922 NZ-0,8764339 TX+0,0078922 TY-0,8764339 TZ+0,2590319 F1000 M128

LN: Straight line with 3D compensation

X, Y, Z: Compensated coordinates of the straight-line

end point

NX, **NY**, **NZ**: Components of the surface normal vector

TX, **TY**, **TZ**: Components of the tool vector

F: Feed rate

M: Miscellaneous function

Peripheral milling: 3-D radius compensation with TCPM and radius compensation (RL/RR)

The control offsets the tool perpendicularly to the direction of motion and perpendicularly to the direction of the tool by the sum of the delta values **DR** (tool table and NC program). Determine the compensation direction with radius compensation **RL/RR** (see figure, traverse direction Y+). In order for the control to be able to reach the specified tool orientation, you need to activate the function **M128** or **TCPM**.

Further information: "Retaining the position of the tool tip during the positioning of tilting axes (TCPM): M128 (option 9)", Page 493

The control then positions the rotary axes automatically in such a way that the tool can reach the specified tool orientation with the active compensation.



Refer to your machine manual.

This function is only available with spatial angles. Your machine tool builder defines how these can be entered.

The control is not able to automatically position the rate.

The control is not able to automatically position the rotary axes on all machines.



The control generally uses the defined **delta values** for 3D tool compensation. The entire tool radius (**R** + **DR**) is only taken into account if you have activated the **FUNCTION PROG PATH IS CONTOUR** function.

Further information: "Interpretation of the programmed path", Page 515

NOTICE


Danger of collision!

The rotary axes of a machine may have limited ranges of traverse (e.g., between -90° and $+10^{\circ}$ for the B head axis). Changing the tilt angle to a value of more than $+10^{\circ}$ may result in a 180° rotation of the table axis. There is a danger of collision during the tilting movement!

- Program a safe tool position before the tilting movement, if necessary.
- Carefully test the NC program or program section in the Program run, single block operating mode

There are two ways to define the tool orientation:

- In an LN block with the components TX, TY and TZ
- In an L block by indicating the coordinates of the rotary axes



Example: Block format with tool orientation

1 LN X+31.737 Y+21.954 Z+33.165 TX+0.0078922 TY-0.8764339 TZ+0.2590319 RR F1000 M128

LN: Straight line with 3-D compensation

X, Y, Z: Compensated coordinates of the straight-line

end point

TX, TY, TZ: Components of the normalized vector for

workpiece orientation

RR: Tool radius compensation

F: Feed rate

M: Miscellaneous function

Example: Block format with rotary axes

1 L X+31.737 Y+21.954 Z+33.165 B+12.357 C+5.896 RL F1000 M128

L: Straight line

X, Y, Z: Compensated coordinates of the straight-line

end point

B, **C**: Coordinates of the rotary axes for tool orienta-

tion

RL: Radius compensation

F: Feed rate

M: Miscellaneous function

Interpretation of the programmed path

With **FUNCTION PROG PATH**, you decide whether the control will apply the 3D radius compensation only to the delta values, just as before, or rather to the entire tool radius. If you activate **FUNCTION PROG PATH**, the programmed coordinates exactly correspond to the contour coordinates. With **FUNCTION PROG PATH OFF**, you deactivate this special interpretation.

Procedure

Proceed as follows for the definition:



▶ Show the soft key row with special functions



▶ Press the **PROGRAM FUNCTIONS** soft key



▶ Press the **FUNCTION PROG PATH** soft key

You have the following possibilities:

Soft key	Function
IS CONTOUR	Activate the interpretation of the programmed path as the contour
	The control takes the full tool radius R + DR and the full corner radius R2 + DR2 into account for 3D radius compensation.
OFF	Deactivate the special interpretation of the programmed path
	The control only uses the delta values DR and DR2 for 3D radius compensation.

If you activate **FUNCTION PROG PATH**, the interpretation of the programmed path as the contour is active for 3D compensation movements until you deactivate the function.

3-D radius compensation depending on the tool's contact angle (option 92)

Application


Due to the production process, the effective spherical radius of a ball cutter deviates from the ideal form. The maximum form inaccuracy is defined by the tool manufacturer. Common deviations lie between 0.005 mm and 0.01 mm.

The form inaccuracy can be saved in the form of a compensation value table. This table contains angle values and the deviation from the nominal radius **R2** measured on the respective angle value.

The **3D-ToolComp** software (option 92) enables the control to compensate the value defined in the compensation value table depending on the actual contact point of the tool.

3D calibration of the touch probe can also be carried out with the **3D-ToolComp** software option. During this process the deviations determined during touch probe calibration are saved to the compensation value table.

Further information: User's Manual for **Setup, Testing and Running NC Programs**



Requirements

To be able to use the software option **3D-ToolComp** (option 92) the control requires the following preconditions:

- Option 9 is enabled
- Option 92 is enabled
- The **DR2TABLE** column in the TOOL.T tool table is enabled
- The name of the compensation value table (without its extension) is entered in the DR2TABLE column for the tool to be compensated
- 0 is entered in the **DR2** column
- NC program with surface normal vectors (LN blocks)

Compensation value table

If you create the compensation value table yourself, proceed as follows:



► In the file manager, open the path **TNC:\system\3D-ToolComp**



- ▶ Press the **NEW FILE** soft key
- ▶ Enter the file name with extension .3DTC
- > The control opens a table containing the required columns for a compensation value table.

The compensation value table contains three columns:

- NR: Consecutive line number
- **ANGLE**: Measured angle in degrees
- **DR2**: Radius deviation from the nominal value

The control evaluates a maximum of 100 rows in the compensation value table.

Function

If you are executing an NC program with surface-normal vectors and have assigned a compensation value table (DR2TABLE column) to the active tool in the tool table (TOOL.T), the control uses the values from the compensation value table instead of the compensation value DR2 from TOOL.T.

In doing so, the control takes the compensation value from the compensation value table defined for the current contact point of the tool with workpiece into account. If the contact point is between two compensation points, the control interpolates the compensation value linearly between the two closest angles.

Angle value	Compensation value
40°	0.03 mm (measured)
50°	-0.02 mm (measured)
45° (contact point)	+0.005 mm (interpolated)



Operating and programming notes:


- If the control cannot interpolate a compensation value, it displays an error message.
- **M107** (suppress error message for positive compensation values) is not required, even if positive compensation values are determined.
- The control uses either DR2 from TOOL.T or a compensation value from the compensation value table. Additional offsets, such as a surface oversize, can be defined via DR2 in the NC program (compensation table .tco or TOOL CALL block).

NC program

The software option **3D-ToolComp** (option 92) only functions with NC programs containing surface normal vectors.

Pay attention when creating the CAM program how you measure the tools:

- NC program output at the south pole of the sphere requires tools measured on the tool tip
- NC program output at the center of the sphere requires tools measured on the tool center



11.7 Running CAM programs

If you create NC programs externally using a CAM system, you should pay attention to the recommendations detailed below. This will enable you to optimally use the powerful motion control functionality provided by the control and usually create better workpiece surfaces with shorter machining times. Despite high machining speeds, the control still achieves a very high contour accuracy. The basis for this is the HEROS 5 real-time operating system in conjunction with the **ADP** (Advanced Dynamic Prediction) function of the TNC 640. This enables the control to also efficiently process NC programs with high point densities.

From 3-D model to NC program

Here is a simplified description of the process for creating an NC program from a CAD model:

- ► CAD: Model creation
 - Construction departments prepare a 3-D model of the workpiece to be machined. Ideally the 3-D model is designed for the center of tolerance.
- ► CAM: Path generation, tool compensation

The CAM programmer specifies the machining strategies for the areas of the workpiece to be machined. The CAM system uses the surfaces of the CAD model to calculate the paths of the tool movements. These tool paths consist of individual points calculated by the CAM system so that each surface to be machined is approximated as nearly as possible while considering chord errors and tolerances. This way, a machine-neutral NC program is created, known as a CLDATA file (cutter location data). A postprocessor generates a machine- and control-specific NC program, which can be processed by the CNC control. The postprocessor is adapted according to the machine tool and the control. The postprocessor is the link between the CAM system and the CNC control.



In the **BLK FORM FILE** syntax, you can integrate 3-D models in STL format as a workpiece blank and a finished part.

Further information: "Defining the workpiece blank: BLK FORM", Page 93

- ▶ Control: Motion control, tolerance monitoring, velocity profile
 The control uses the points defined in the NC program to
 calculate the movements of each machine axis as well as the
 required velocity profiles. Powerful filter functions then process
 and smooth the contour so that the control does not exceed the
 maximum permissible path deviation.
- ▶ Mechatronics: Feed control, drive technology, machine tool The motions and velocity profiles calculated by the control are realized as actual tool movements by the machine's drive system.



Considerations required for post processor configuration

Take the following points into account with post processor configuration:

- Always set the data output for axis positions to at least four decimal places. This way you improve the quality of the NC data and avoid rounding errors, which can result in defects visible to the naked eye on the workpiece surface. Output of five decimal places may achieve improved surface quality for optical components as well as components with very large radii (i.e. small curvatures), for example molds for the automotive industry
- Always set the data output for the machining of surface normal vectors (LN blocks, only Klartext conversational programming) to exactly seven decimal places
- Avoid using successive incremental NC blocks because this may lead to the tolerances of the individual NC blocks being added together in the output
- Set the tolerance in Cycle 32 so that in standard behavior it is at least twice as large as the chord error defined in the CAM system. Also note the information describing the functioning of Cycle 32
- If the chord error selected in the CAM program is too large, then, depending on the respective curvature of a contour, large distances between NC blocks can result, each with large changes of direction. During machining this leads to drops in the feed rate at the block transitions. Recurring and equal accelerations (i.e. force excitation), caused by feed-rate drops in the heterogeneous NC program, can lead to undesirable excitation of vibrations in the machine structure.
- You can also use arc blocks instead of linear blocks to connect the path points calculated by the CAM system. The control internally calculates circles more accurately than can be defined via the input format
- Do not output any intermediate points on exactly straight lines.
 Intermediate points that are not exactly on a straight line can result in defects visible to the naked eye on the workpiece surface
- There should be exactly one NC data point at curvature transitions (corners)
- Avoid sequences of many short block paths. Short paths between blocks are generated in the CAM system when there are large curvature transitions with very small chord errors in effect.
 Exactly straight lines do not require such short block paths, which are often forced by the continuous output of points from the CAM system
- Avoid a perfectly even distribution of points over surfaces with a uniform curvature, since this could result in patterns on the workpiece surface
- For 5-axis simultaneous programs: avoid the duplicated output of positions if they only differ in the tool's angle of inclination
- Avoid the output of the feed rate in every NC block. This would negatively influence the control's velocity profile

Useful configurations for the machine tool operator:

- In order to enable a realistic graphic simulation, use 3-D models in STL format as a workpiece blank and finished part
 Further information: "Defining the workpiece blank: BLK FORM", Page 93
- In order to improve the structure of large NC programs, use the control's structuring function

Further information: "Structuring NC programs", Page 204

Use the control's commenting function in order to document NC programs

Further information: "Adding comments", Page 200

 Use the comprehensive cycles of the control available for the machining of holes and simple pocket geometries

Further information: User's Manual for **Programming of Machining Cycles**

 For fits, output the contours with RL/RR tool radius compensation. This makes it easy for the machine operator to make necessary compensations

Further information: "Tool compensation", Page 138

 Separate feed rates for pre-positioning, machining, and downfeeds, and define them via Q parameters at the beginning of the program

Example: Variable feed rate definitions

1 Q50 = 7500	FEED RATE FOR POSITIONING
2 Q51 = 750	FEED RATE FOR PLUNGING
3 Q52 = 1350	FEED RATE FOR MILLING
25 L Z+250 RO FMAX	
26 L X+235 Y-25 FQ50	
27 L Z+35	
28 L Z+33.2571 FQ51	
29 L X+321.7562 Y-24.9573 Z+33.3978 FQ52	
30 L X+320.8251 Y-24.4338 Z+33.8311	

Please note the following for CAM programming

Adapting chord errors



Programming notes:

- For finishing operations, do not set the chord error in the CAM system to a value greater than 5 μm. In Cycle **32**, use an appropriate tolerance factor **T** of 1.3 to 3.
- For roughing operations, the total of the chord error and the tolerance **T** must be less than the defined machining oversize. In this way you can avoid contour damage.
- The specific values depend upon the dynamics of your machine.

Adapt the chord error in the CAM program, depending on the machining:

Roughing with preference for speed:

Use higher values for the chord error and the matching tolerance value in Cycle **32**. Both values depend on the oversize required on the contour. If a special cycle is available on your machine, use the roughing mode. In roughing mode the machine generally moves with high jerk values and high accelerations

- Normal tolerance in Cycle **32**: Between 0.05 mm and 0.3 mm
- Normal chord error in the CAM system: Between 0.004 mm and 0.030 mm

Finishing with preference for high accuracy:


Use smaller values for the chord error and a matching low tolerance in Cycle **32**. The data density must be high enough for the control to detect transitions and corners exactly. If a special cycle is available on your machine, use the finishing mode. In finishing mode the machine generally moves with low jerk values and low accelerations

- Normal tolerance in Cycle 32: Between 0.002 mm and 0.006 mm
- Normal chord error in the CAM system: Between 0.001 mm and 0.004 mm

■ Finishing with preference for high surface quality:

Use small values for the chord error and a matching larger tolerance in Cycle **32**. The control is then able to better smooth the contour. If a special cycle is available on your machine, use the finishing mode. In finishing mode the machine generally moves with low jerk values and low accelerations

- Normal tolerance in Cycle 32: Between 0.010 mm and 0.020 mm
- Normal chord error in the CAM system: Approx. 0.005 mm



Further adaptations

Take the following points into account with CAM programming:

- For slow machining feed rates or contours with large radii, define the chord error to be only one-third to one-fifth of tolerance **T** in Cycle **32**. Additionally, define the maximum permissible point spacing to be between 0.25 mm and 0.5 mm. The geometry error or model error should also be specified to be very small (max. 1 µm).
- Even at higher machining feed rates, point spacings of greater than 2.5 mm are not recommended for curved contour areas
- For straight contour elements, one NC point at the beginning of a line and one NC point at the end suffice. Avoid the output of intermediate positions
- In programs with five axes moving simultaneously, avoid large changes in the ratio of path lengths in linear and rotational blocks. Otherwise large reductions in the feed rate could result at the tool reference point (TCP)
- The feed-rate limitation for compensating movements (e.g. via M128 F...) should be used only in exceptional cases. The feed-rate limitation for compensating movements can cause large reductions in the feed rate at the tool reference point (TCP).
- NC programs for 5-axis simultaneous machining with spherical cutters should preferably be output for the center of the sphere. The NC data are then generally more uniform. In Cycle **32**, you can additionally set a higher rotary axis tolerance **TA** (e.g., between 1° and 3°) for an even more constant feed-rate curve at the tool center point (TCP).
- For NC programs for 5-axis simultaneous machining with toroid cutters or spherical cutters, where the NC output is for the south pole of the sphere, choose a lower rotary axis tolerance. 0.1° is a typical value. However, the maximum permissible contour damage is the decisive factor for the rotational axis tolerance. This contour damage depends on the possible tool tilting, tool radius and engagement depth of the tool.

 With 5-axis hobbing with an end mill, you can calculate the maximum possible contour damage T directly from the cutter engagement length L and permissible contour tolerance TA: T ~ K x L x TA with K = 0.0175 [1/°]

 Example: L = 10 mm, TA = 0.1°: T = 0.0175 mm

Possibilities for intervention on the control

Cycle **32 TOLERANCE** is available for influencing the behavior of CAM programs directly on the control. Please note the information describing the functioning of Cycle **32**. Also note the interactions with the chord error defined in the CAM system.

Further information: User's Manual for **Programming of Machining Cycles**



Refer to your machine manual.

Some machine tool builders provide an additional cycle for adapting the behavior of the machine to the respective machining operation (e.g., Cycle **332** Tuning). Cycle **332** can be used to modify filter settings, acceleration settings, and jerk settings.

Example

34 CYCL DEF 32.0 TOLERANCE

35 CYCL DEF 32.1 T0.05

36 CYCL DEF 32.2 HSC MODE:1 TA3

ADP motion control



This function must be enabled and adapted by the machine manufacturer.

An insufficient quality of data in NC programs created on CAM systems frequently causes inferior surface quality of the milled workpieces. The **ADP** (Advanced Dynamic Prediction) feature expands the conventional look-ahead of the permissible maximum feed rate profile and optimizes the motion control of the feed axes during milling. This enables clean surfaces with short machining times to be cut, even with a strongly fluctuating distribution of points in adjacent tool paths. This significantly reduces or eliminates the reworking complexity.

These are the most important benefits of ADP:

- Symmetrical feed-rate behavior on forward and backward paths with bidirectional milling
- Uniform feed rate curves with adjacent cutter paths
- Improved reaction to negative effects (e.g. short, step-like contours, coarse chord tolerances, heavily rounded block endpoint coordinates) in NC programs generated by CAM systems
- Precise compliance to dynamic characteristics even in difficult conditions


Data transfer from CAD files

12.1 Screen layout of the CAD viewer

CAD Viewer fundamentals

Screen display

When you open **CAD-Viewer**, the following screen layout is displayed:



- 1 Menu bar
- 2 Graphics window
- 3 List View window
- 4 Element Information window
- 5 Status bar

File types

CAD-Viewer allows you to open the following standardized file types directly on the control:

File type	Extension	Format
STEP	*.stp and *.step	■ AP 203
		■ AP 214
IGES	*.igs and *.iges	■ Version 5.3
DXF	*.dxf	■ R10 to 2015
STL	*.stl	■ Binary
		ASCII

CAD-Viewer allows you to open CAD models consisting of any number of triangles.

12.2 CAD Import (option 42)

Application

You can open CAD files directly on the control to extract contours or machining positions from them. You can then store them as Klartext programs or as point files. Klartext programs acquired in this manner can also be run on older HEIDENHAIN controls, since these contour programs by default contain only **L** and **CC/C** blocks.



As an alternative to **CC** or **C** blocks, you can configure circular movements to be output as **CR** blocks.

Further information: "Basic settings", Page 529


If you process files in the **Programming** operating mode, the control generates contour programs with the file extension **.H** and point files with the extension **.PNT** by default. You can select the file type in the Save dialog.

To insert a selected contour or a selected machining position directly into an NC program, use the control's clipboard. Using the clipboard, you can even transfer the contents to additional software tools (e.g., **Leafpad** or **Gnumeric**).



Operating notes:

- Contents from the clipboard can only be inserted into additional software tools as long as CAD-Viewer is open.
- Before loading the file into the control, ensure that the name of the file contains only permitted characters.
 Further information: "File names", Page 109
- The control does not support binary DXF format. Save the DXF file in ASCII format in the CAD or drawing program.



Using the CAD viewer



To use the **CAD-Viewer** without a touchscreen, you have to use a mouse or touchpad.

The **CAD-Viewer** runs as a separate application on the third desktop of the control. This enables you to use the screen switchover key to switch between the machine operating modes, the programming modes, and the **CAD-Viewer**. This is particularly useful if you want to add contours or machining positions to a Klartext program using the clipboard.



If you are using a TNC 640 with touch control, you can replace some keystrokes with gestures.

Further information: "Operating the touchscreen", Page 607

Opening the CAD file



Press the Programming key



- ► Press the **PGM MGT** key
- > The control opens the file manager.



- Press the SELECT TYPE soft key
- > The control displays the selectable file types.



Press the SHOW CAD soft key



Alternative: Press the SHOW ALL soft key
 Select the directory in which the CAD file is saved



▶ Select the desired CAD file




- ► Press the **ENT** key
- > The control starts the **CAD-Viewer** and shows the file contents on the screen. The control displays the layers in the List View window and the drawing in the Graphics window.

Basic settings

The basic settings specified below are selected using the icons in the header bar.

Icon	Setting
	Show, enlarge, or hide the List View window
=	Show, enlarge, or flue the List view window
	Display of the various layers
(Set a preset, with optional selection of the plane
?	Set a datum, with optional selection of the plane
<u>-</u>	Select contour
*	Select drilling positions
$\overline{\sim}$	3D mesh
\bowtie	Create a 3D mesh (option 152)
	Further information: "Generating STL files with 3D mesh (option 152)", Page 548
\odot	Set the zoom to the largest possible rendering of the entire graphical representation
[J	Toggle background color (black or white)
77 14	Toggle between 2D and 3D mode. The active mode is highlighted in color
mm inch	Set the unit of measure (mm or inch) for the file. The control then outputs the contour program and the machining positions in this unit of measure. The active unit of measure is highlighted in red. Internally, CAD-Viewer always uses mm for its calculations. If you select inches as the unit of measure, CAD-Viewer will convert all values to inches.
0,01 0,001	Select the resolution. The resolution defines the number of decimal places and the number of positions for linearization. Default setting: 4 decimal places with mm, and 5 decimal places with inch as the unit of measure The CAD-Viewer linearizes all of the contours that are not in the XY plane. The higher the resolution, the more accurately the control displays the contours.



lcon	Setting
	Switch between various views of the model (e.g., Top)
XY	Select the working plane: XY YZ ZX In the ZXØ working plane, you can select turning contours (option 50). If you take over a contour or position, the control outputs the NC program in the selected working plane. Further information: "Selecting and saving a contour", Page 539
	Activate the wire-frame model of a 3D drawing
№	"Select, add, or remove contour elements" mode The icon shows the current mode. Clicking the icon activates the next mode.

The control displays the following icons only in certain modes.

lcon	Setting
5	Undoes the most recent step.
;	Contour transfer mode: The tolerance specifies how far apart neighboring contour elements may be from each other. You can use the tolerance to compensate for inaccuracies that occurred when the drawing was made. The default setting is 0.001 mm
C o CR o	Arc mode: Arc mode defines whether circular arcs are output in C format or CR format (e.g., for cylinder surface interpolation) in the NC program.
W	Point transfer mode: Specify whether the control should display the tool path as a dashed line during selection of machining positions
∱ → †	Path optimization mode: The control optimizes the tool traverse movement so that there are shorter traverse distances between the machining positions. You reset this optimization by selecting the icon again

lcon

Setting



Drilling position mode:

The control opens a pop-up window in which you can filter holes (full circles) based on their size



Operating notes:

- Set the correct unit of measure to make sure that CAD-Viewer displays correct values.
- When creating NC programs for earlier control models, you must limit the resolution to three decimal places.
 In addition, you must remove the comments that CAD-Viewer outputs to the contour program.
- The control displays the active basic settings in the status bar of the screen.

Setting layers

CAD files usually contain multiple layers. The designer uses these layers to create groups of various types of elements, such as the actual workpiece contour, dimensions, auxiliary and design lines, hatching, and texts.


Hiding unneeded layers makes the graphics easier to read and facilitates the extraction of the required information.



Operating notes:

- The CAD file to be processed must contain at least one layer. The control automatically moves all elements not assigned to a layer to the "anonymous" layer.
- If the name of the layer is not shown completely in the window, you can use the **Show sidebar** icon to enlarge this window.
- You can even select a contour if the designer has saved it on different layers.
- If you double-click a layer, the control switches to Contour Transfer mode and selects the first contour element that was drawn. The control highlights the other selectable elements of this contour in green. Especially in case of contours with many short elements, this procedure spares you the effort of running a manual search for the beginning of the contour.

When you open a CAD file in **CAD-Viewer**, all available layers are shown.



Hiding a layer

To hide a layer:



- ▶ Select the **SET LAYER** function
- > In the List View window, the control shows all layers contained in the active CAD file.
- Select the desired layer
- ► Click the check box to deactivate it
- Alternatively, press the space key
- > The control hides the selected layer.

Showing a layer

To show a layer:



- ▶ Select the **SET LAYER** function
- > In the List View window, the control shows all layers contained in the active CAD file.
- Select the desired layer
- Click the check box to activate it
- Alternatively, press the space key
- > The control marks the selected layer in the List View with a x.
- > The selected layer is shown.

Setting a preset

The datum of the drawing in the CAD file is not always located in a manner that lets you use it as a workpiece preset. Therefore, the control provides a function with which you can shift the workpiece preset to a suitable location by clicking an element. You can also define the orientation of the coordinate system.

You can position the preset at the following locations:

- By direct input of numerical values into the List View window
- For straight lines:
 - Starting point
 - Midpoint
 - End point
- For circular arcs:
 - Starting point
 - Center point
 - End point
- For full circles:
 - At the quadrant transitions
 - At the center
- At the intersection between:
 - Two straight lines, even if the point of intersection is actually on the extension of one of the lines
 - Straight line and circular arc
 - Straight line and full circle
 - Two circles (regardless of whether a circular arc or a full circle)



Operating note:


You can change the preset even after you have selected the contour. The control does not calculate the actual contour data until you save the selected contour in a contour program.

NC syntax

The preset and optional orientation are inserted in the NC program as a comment starting with **origin**.

5 ;orgin_plane_spatial = SPA... SPB... SPC...

You can save the information on the workpiece preset and workpiece datum to a file or to the clipboard without having to resort to CAD Import (software option 42).



Setting a preset on a single element

To set a preset on a single element:



- Select the mode for setting a preset
- Place the mouse pointer on the desired element
- > The control indicates possible locations for the preset on the selected element with stars.
- Select the star symbol that matches the desired preset position
- ▶ If necessary, use the zoom function
- > The control sets the preset symbol at the selected location.
- In addition, orient the coordinate system as needed

Further information: "Adjusting the orientation of the coordinate system", Page 535

Setting a preset at the intersection of two elements

To set a preset at the intersection of two elements:



- ▶ Select the mode for setting a preset
- Select the first element (straight line, full circle, or circular arc) using the left mouse button
- > The control highlights the element.
- ► Select the second element (straight line, circle, or circular arc) using the left mouse button
- > The control sets the preset symbol at the point of intersection.
- In addition, orient the coordinate system as needed

Further information: "Adjusting the orientation of the coordinate system", Page 535



Operating notes:

- If there are several possible intersections, the control selects the intersection nearest the mouse-click on the second element.
- If two elements do not intersect directly, the control automatically calculates the intersection of their extensions.
- If the control cannot calculate an intersection, it deselects the previously selected element.

Once a preset has been set, the control displays the preset icon with a yellow quadrant .

Use the following icon to delete a preset that has been set M.

Adjusting the orientation of the coordinate system

The following conditions must be met in order to orient the coordinate system:

- Preset has been defined
- There are elements next to the preset that can be used for the desired orientation

The position of the coordinate system is defined by the orientation of the axes.

To orient the coordinate system:



- ► Select an element located in the positive X direction using the left mouse button
- > The control orients the X axis.
- > The control changes the angle in C.
- Select an element located in the positive Y direction using the left mouse button
- > The control orients the Y and Z axes.
- > The control changes the angles in A and C.




For angles not equal to 0, the control shows the List View in orange.

Element information

The control displays information about the element in an area at the left:

- Distance between the defined preset and the drawing datum
- Orientation of the coordinate system with respect to the drawing




Setting the datum

The workpiece preset is not always located in a manner that lets you machine the entire part. Therefore, the control has a function with which you can define a new datum and a tilting operation.

The datum with the orientation of the coordinate system can be set at the same positions as a preset.

Further information: "Setting a preset", Page 533



NC syntax

The datum and its optional orientation can be inserted as NC block or comments in the NC program by using the **TRANS DATUM AXIS** function for the datum and the **PLANE SPATIAL** function for the orientation.

If you define only one datum and its orientation, then the control inserts the functions in the NC program as an NC block.

4 TRANS DATUM AXIS X... Y... Z...

5 PLANE SPATIAL SPA... SPB... SPC... TURN MB MAX FMAX

If you additionally select contours or points, then the control inserts the functions in the NC program as comments.

4 ;TRANS DATUM AXIS X... Y... Z...

5 ;PLANE SPATIAL SPA... SPB... SPC... TURN MB MAX FMAX

You can save the information on the workpiece preset and workpiece datum to a file or to the clipboard without having to resort to CAD Import (software option 42).

Setting the datum on a single element

To set the datum on a single element, proceed as follows:



- ► Select the mode for specifying the datum
- ▶ Place the mouse pointer on the desired element
- > The control indicates possible locations for the datum on the selected element with stars.
- Select the star symbol that matches the desired datum position
- ▶ If necessary, use the zoom function
- > The control sets the datum icon at the selected location.
- In addition, align the coordinate system as needed Further information: "Adjusting the orientation of the coordinate system", Page 537

Setting a datum at the intersection between two elements

To set a datum at the intersection between two elements:



- Select the mode for specifying the datum
- Select the first element (straight line, full circle, or circular arc) using the left mouse button
- > The control highlights the element.
- Select the second element (straight line, circle, or circular arc) using the left mouse button
- > The control sets the datum icon on the point of intersection.
- In addition, align the coordinate system as needed Further information: "Adjusting the orientation of the coordinate system", Page 537



Operating notes:

- If there are several possible intersections, the control selects the intersection nearest the mouse-click on the second element.
- If two elements do not intersect directly, the control automatically calculates the intersection of their extensions.
- If the control cannot calculate an intersection, it deselects the previously selected element.

Once a datum has been set, the control displays the datum icon with a yellow surface 🔥.

Use the following icon to delete a datum that has been set X.



Adjusting the orientation of the coordinate system

The following conditions must be met in order to align the coordinate system:

- The datum has been set
- There are elements next to the preset that can be used for the desired alignment

The position of the coordinate system is defined by the orientation of

To align the coordinate system, proceed as follows:



- Select an element located in the positive X direction using the left mouse button
- > The control aligns the X axis.
- > The control changes the angle in C.
- Select an element located in the positive Y direction using the left mouse button
- > The control aligns the Y and Z axes.
- > The control changes the angles in A and C.



For angles not equal to 0, the control shows the List View in orange.

Element information


In the Element Information window, the control displays how far away the datum you selected is from the workpiece preset.

The control displays information about the element on the left of the window:

- Distance between the datum that has been set and the workpiece preset
- Orientation of the coordinate system



You can further shift the datum manually after it has been set. To do so, enter the desired axis values into the coordinate field.



Selecting and saving a contour



Operating notes:

- This function is not available if option 42 is not enabled.
- Specify the direction of rotation during contour selection so that it matches the desired machining direction.
- Select the first contour element such that approach without collision is possible.
- If the contour elements are very close to one another, use the zoom function.

The following elements can be selected as a contour:

- Line segment
- Circle
- Circular arc
- Polyline
- Any curves (e.g., splines, ellipses)


Element information

In the Element Information window the control displays a range of information about the last contour element you selected in the List View window or in the Graphics window.

- Layer: specifies the active plane
- **Type**: specifies the type of element (e.g., line)
- **Coordinates**: specify the starting point and end point of an element, and the circle center and radius where appropriate



Ensure that the unit of measure used in the NC program matches with that used in the **CAD-Viewer**. Elements that have been copied from the **CAD-Viewer** to the clipboard do not contain any information about the unit of measure.



Select contour



Operating note:

If you double-click a layer in the list view window, the control switches to Contour Transfer mode and selects the first contour element that was drawn. The control highlights the other selectable elements of this contour in green. Especially in case of contours with many short elements, this procedure spares you the effort of running a manual search for the beginning of a contour.

To select a contour using available contour elements:



- ▶ Select the contour selection mode
- Place the mouse pointer on the desired element
- > The control displays the suggested direction of rotation as a dashed line.
- ► If you need to change the direction of rotation, move the mouse pointer towards the opposite end point
- ► Select the element using the left mouse button
- > The selected contour element turns blue.
- > The control shows the other selectable elements in green.



For branched contours, the control chooses the path with the smallest directional deviation. The control provides an additional mode that allows you to modify the suggested contour path.

Further information: "Creating contour paths independent of available contour elements", Page 542

- Select the last green element of the desired contour using the left mouse button
- > The control changes the color of all selected elements to blue.
- > In the List View, all selected elements are given a check mark in the column **NC**.

Saving a contour



Operating notes:

- The control also transfers two workpiece-blank definitions (BLK FORM) to the contour program. The first definition contains the dimensions of the entire CAD file. The second one, which is the active one, contains only the selected contour elements, so that an optimized size of the workpiece blank results.
- The control only saves elements that have been selected (blue elements), which means that they have been given a check mark in the List View window.

To save a selected contour:



- Select the Save icon
- > The control prompts you to select the target directory, a file name, and the file type.
- ▶ Enter this information



- Confirm your input
- > The control saves the contour program.



 Alternative: Copy the selected contour elements to the clipboard



Ensure that the unit of measure used in the NC program matches with that used in the **CAD-Viewer**. Elements that have been copied from the **CAD-Viewer** to the clipboard do not contain any information about the unit of measure.

Deselecting the contour

To deselect the selected contour elements:



- ▶ Select the Clear function to deselect all elements
- Alternative: Select individual elements by clicking them with the left mouse button while holding the CTRL key

Creating contour paths independent of available contour elements

To select any contours by using the end point, center, or transition points:



▶ Select the contour selection mode



- ► Activate the "Add contour elements" mode
- > The control displays the following icon:
 - +
- Place the mouse pointer on the contour element
- > The control displays selectable points.



Selectable points:


- End point or midpoint of a line or curve
- Quadrant transitions or center of a circle
- Points of intersection between existing elements
- Select the starting point as needed
- Select the starting element
- ▶ Select the subsequent element
- ► Alternative: Select any selectable point
- > The control creates the desired contour path.



Operating notes:

- The contour paths available depend on the selectable contour elements that are shown in green. Without the green elements, the control will display all solutions available. To remove the proposed contour path, select the first green element by pressing the left mouse button while holding the CTRL key down.

 As an alternative, you can switch to the Remove mode:
- If the contour element to be extended or shortened is a straight line, the control will extend or shorten the contour element along the same line. If the contour element to be extended or shortened is a circular arc, the control will extend or shorten the contour element along the same arc.



Selecting a contour for a turning operation

You can also use the CAD viewer (option 50) to select contours for turning. The icon is grayed out if option 50 is not enabled. Before selecting a turning contour, you must set the preset on the rotary axis. If you select a turning contour, it is saved with Z and X coordinates. In addition, all X coordinate values in turning contours are transferred as diameter values, i.e. the drawing dimensions for the X axis are doubled. All contour elements below the rotary axis cannot be selected and are highlighted gray.

To select a turning contour using available contour elements:


- Select the ZXØ working plane for the selection of a turning contour
- > The control shows only the selectable elements above the rotation center.
- Select the contour elements using the left mouse button
- > The control displays the selected contour elements in blue.
- > The control also displays the selected elements in the Sidebar window.



Functions or icons that are not available for turning contours appear dimmed.

You can also use the mouse to change the turning graphic display. The following functions are available:

- To shift the displayed model, hold down the center mouse button or the mouse wheel (depending on your mouse model), and move the mouse.
- To zoom in on a certain area mark a zoom area by holding the left mouse button down
- To rapidly zoom in or out rotate the mouse wheel backwards or forwards
- To restore the standard view, double-click with the right mouse button



For a workpiece blank definition in turning mode, a closed contour is required.

NOTICE

Danger of collision!

Closed contours must completely lie inside the workpiece blank definition. Otherwise, the system will follow closed contours also along the rotary axis when machining, causing collisions.

Select or program only those contour elements that are actually required (for example, within the definition of a finished part).

To select a closed contour:



- ▶ Select Contour
- ► Select all required contour elements
- ► Select the starting point of the first element
- > The control closes the contour.

Selecting and saving machining positions



Operating notes:

- This function is not available if option 42 is not enabled.
- If the contour elements are very close to one another, use the zoom function.
- If required, configure the basic settings so that the control shows the tool paths. Further information: "Basic settings", Page 529

Three possibilities are available in the pattern generator for defining machining positions:


- Single selection: You select the desired machining positions by clicking them individually with the mouse
 - Further information: "Single selection", Page 545
- Multiple selection by drag box: You select multiple machining positions by dragging a box around them with the mouse
 Further information: "Multiple selection by drag box", Page 545
- Multiple selection by search filter: You select all machining positions within a definable diameter range
 Further information: "Multiple selection by search filter",

Page 546



Machining positions are deselected, deleted, or saved in the same manner as contour elements.

- Machining positions are deselected, deleted, or saved in the same manner as contour elements.
- **CAD-Viewer** also recognizes circles that consist of two semi-circles as machining positions.



Select the file type

The following file types are available:

- Point table (.PNT)
- Klartext program (.H)

If you save the machining positions to a Klartext program, the control creates a separate linear block with a cycle call for every machining position (L X... Y... Z... F MAX M99).



The NC syntax used allows you to export NC programs generated by CAD import to older HEIDENHAIN controls and run them there.



The point tables (.PNT) of the TNC 640 and the iTNC 530 are not compatible. Transferring a point table to and running it on the other control model leads to problems and unpredictable behavior.

Single selection

To select individual machining positions:



- Select the mode for choosing a machining position
- ▶ Place the mouse pointer on the desired element
- > The control displays the selectable element in orange.
- Select the circle center as machining position
- ▶ Alternative: Select the circle or a circle segment
- > The control transfers the selected machining position into the List View window.

Multiple selection by drag box

To select multiple machining positions by dragging a box around them:




 Select the mode for choosing a machining position




- Activate the Add function
- > The control displays the following icon:



- Drag a box around the desired area while holding down the left mouse button
- > The control displays the minimum and maximum diameters in a pop-up window.
- Change the filter settings as neededFurther information: "Filter settings", Page 546
- Confirm the diameter range with **OK**
- The control loads all machining positions within the selected diameter range into the List View window.






Multiple selection by search filter


To select multiple machining positions by search filter:







- > The control displays the minimum and maximum diameters in a pop-up window.
- Change the filter settings as neededFurther information: "Filter settings", Page 546
- ► Confirm the diameter range with **OK**
- The control loads all machining positions within the selected diameter range into the List View window.



Filter settings


After you have used the quick selection function to mark drilling positions, a pop-up window appears, showing the smallest diameter found to the left and the largest diameter to the right. With the buttons just below the diameter display you can adjust the diameter so that you can transfer the hole diameters that you want.


The following buttons are available:

Icon	Filter setting for the smallest diameter
1<<	Display the smallest diameter found (default setting)
<	Display the next smaller diameter found
>	Display the next larger diameter found
>>	Display the largest diameter found. The control sets the filter for the smallest diameter to the value set for the largest diameter
Icon	Filter setting of largest diameter
<<	Display the smallest diameter found. The control sets the filter for the largest diameter to the value set for the smallest diameter
<	Display the next smaller diameter found
>	Display the next larger diameter found
>>1	Display the largest diameter found (default setting)

You can show the tool path by selecting the $\textbf{SHOW TOOL PATH}\ \text{icon}.$

Further information: "Basic settings", Page 529






Element information

In the Element Information window, the control displays the coordinates of the machining position selected most recently.

You can also use the mouse to change the rotation of the graphic. The following functions are available:

- To rotate the graphic, move the mouse while holding down the right mouse button.
- To shift the displayed model, hold down the center mouse button or the mouse wheel (depending on your mouse model), and move the mouse
- To zoom in on a certain area, select a zoom area by holding the left mouse button down
- To rapidly zoom in or out, rotate the mouse wheel backwards or forwards
- To restore the standard view, double-click with the right mouse button



12.3 Generating STL files with 3D mesh (option 152)

Application

With the **3D mesh** function, you generate STL files from 3D models. This allows you to repair defective files of fixtures and tool holders, for example, or to position STL files generated from the simulation for another machining operation.

Requirement

CAD Model Optimizer (software option 152)

Description of function

When you select the **3D mesh** icon, the control changes to **3D mesh** mode. The control covers the 3D model displayed in **CAD-Viewer** with a mesh of triangles.


The control simplifies the original model and removes errors, such as small holes in a solid or self-intersections of a surface.

You can save the result and use it for various control functions, for example as a workpiece blank with the **BLK FORM FILE** function.

The simplified model or parts of it may be smaller or larger than the original model. The result depends on the quality of the original model and the selected settings in **3D mesh** mode.

The Sidebar window shows the following information:

Option	Meaning		
Original triangles	Number of triangles in the original model		
Number of triangles:	Number of triangles with active settings in the simplified model		
	If this option is highlighted in green, the number of triangles is in the optimum range.		
	You can further reduce the number of triangles using the available functions.		
	Further information: "Functions for the simplified model", Page 549		
Maximum increase	Maximum increase of the triangle mesh		
Over-limit area	Surface increase in percent compared to the original model		
Maximum decrease	Maximum decrease of the triangle mesh compared to the original model		
Under-limit area	Surface decrease in percent compared to the original model		



3D model in **3D mesh** mode

Option	Meaning
Repairs	Indicates whether the original model has been repaired or not
	If it has been repaired, the control indicates the type of repair (e.g., Hole Int Shells).
	This indication consists of the following items:
	Hole
	CAD-Viewer closed holes in the 3D model.
	Int
	CAD-Viewer removed self-intersections.
	Shells
	CAD-Viewer joined multiple separate solids.

In order to use STL files for control functions, the saved files must meet the following requirements:

- Max. 20 000 triangles
- Triangular mesh forms a closed shell

The greater the number of triangles in an STL file, the greater the processing power required by the control for simulation.

Functions for the simplified model

In order to reduce the number of triangles, you can define further settings for the simplified model.

CAD-Viewer provides the following functions:

Symbol	Function
业	Allowed simplification
香	Use this function to simplify the output model by the specified tolerance. The higher the value, the more the surfaces may deviate from the original.
	Remove holes <= diameter
面ノ	Use this function to remove holes and pockets up to the specified diameter from the original model.
	Only optimized mesh shown
	The control shows the simplified model only.
	Original is displayed
	The control shows the simplified model, superim- posed with the original mesh from the original file. You can use this function to evaluate deviations.
	Save
	Use this function to save the simplified 3D model with the selected settings as an STL file.

Positioning the 3D model for rear-face machining

To position an STL file for rear-face machining:

Export of the simulated workpiece as an STL file

Further information: User's Manual for **Setup, Testing and Running NC Programs**



▶ Select the **Programming** operating mode



- ► Press the **PGM MGT** key
- > The control opens the file manager.
- Select the exported STL file
- > The control opens the CAD files in **CAD-Viewer**.



- ▶ Select Preset
- > In the Sidebar window, the control displays information on the position of the preset.
- ► Enter the value of the new preset under **Preset**, e.g. **Z-40**
- ▶ Confirm your input
- Orient the coordinate system by specifying values under PLANE SPATIAL SP*, e.g. A+180 and C+90
- ► Confirm your input



- ▶ Select 3D mesh
- > The control opens the **3D mesh** mode and simplifies the 3D model using the default settings.
- ► Further simplify the 3D model using the **3D mesh** mode functions, if required.

Further information: "Functions for the simplified model", Page 549



- ▶ Select Save
- > The control opens the **Define file name for 3D mesh** menu.
- ▶ Enter the desired name
- Select Save
- > The control saves the STL file positioned for rearface machining.



The resulting file can then be used for rear-face machining with the **BLK FORM FILE** function.

Further information: "Defining the workpiece blank: BLK FORM", Page 93



13

Pallets

13.1 Pallet management

Application



Refer to your machine manual.

Pallet table management is a machine-dependent function. The standard functional range is described below.

Pallet tables (.p) are mainly used in machining centers with pallet changers. The pallet tables call the different pallets (PAL), fixtures (FIX) optionally, and the associated NC programs (PGM). The pallet tables activate all defined presets and datum tables.

Without a pallet changer, you can use pallet tables to successively run NC programs with different presets with just one press of **NC Start**.



The file name of a pallet table must always begin with a letter.



The machine manufacturer defines a pallet table prototype that opens automatically when you create a pallet table.

The prototype can include the following columns:

	A TYPE		NA.	ME		DATUM	PRESET	LOCATION	LO	
	0 PAL	PAL 100						MA		
	1 PGM	3216.H						MA		
	2 PGM	3217.H					- 3	MA		
allet	ma?									
allet		ND .	PAGE	PAGE	BEGIN	END	Y		-	

Prositioning with m.. Table editing

Column	Meaning	Field type
NR	The control creates the entry automatically.	Mandatory field
	The entry is required for the Line number input field of the BLOCK SCAN function.	
TYPE	The control differentiates between the following entries	Mandatory field
	PAL Pallet	
	■ FIX Fixture	
	■ PGM NC program	
	Select the entries using the ENT key and the arrow keys or by soft key.	
NAME	File name	Mandatory field
	The machine manufacturer specifies the names for pallets and fixtures, if applicable, whereas you define program names. You must specify the complete path if the NC program is not saved in the directory of the pallet table.	
DATUM	Datum	Optional field
	You must specify the complete path if the datum table is not saved in the folder of the pallet table. You activate datums from a datum table in the NC program using Cycle 7 .	This entry is only required if a datum table is used.
PRESET	Workpiece preset	Optional field
	Enter the preset number of the workpiece.	

Column	Meaning	Field type
LOCATION	Location of the pallet	Optional field
	The entry MA indicates that there is a pallet or fixture in the working space of the machine and can be machined. Press the ENT key to enter MA . Press the NO ENT key to remove the entry and thus suppress machining.	If the column exists, the entry is mandatory.
LOCK	Row locked	Optional field
	Using an * you can exclude the row of the pallet table from execution. Press the ENT key to identify the row with the entry *. Press the NO ENT key to cancel the lock. You can lock the execution for individual NC programs, fixtures or entire pallets. Unlocked rows (e.g., PGM) in a locked pallet are also not executed.	
PALPRES	Number of the pallet preset	Optional field This entry is only required if pallet presets are used.
W-STATUS	Execution status	Optional field
		This entry is only required for tool- oriented machining.
METHOD	Machining method	Optional field
		This entry is only required for tool- oriented machining.
CTID	ID for mid-program startup	Optional field
		This entry is only required for tool- oriented machining.
SP-X, SP-Y, SP-Z	Clearance height in the linear axes X, Y, and Z	Optional field
SP-A, SP-B, SP-C	Clearance height in the rotary axes A, B, and C	Optional field
SP-U, SP-V, SP-W	Clearance height in the parallel axes U, V, and W	Optional field
DOC	Comment	Optional field
COUNT	Number of operations	Optional field
	For rows of the PAL type: Current actual value for the pallet counter nominal value defined in the TARGET column.	
	For rows of the PGM type: Value indicating by how much the pallet counter actual value will be incremented after the execution of the NC program.	
TARGET	Total number of operations	Optional field
	Nominal value for the pallet counter in rows of the PAL type The control repeats the NC programs of this pallet until the nominal value has been reached.	



You can remove the **LOCATION** column if you are only using pallet tables in which the control is to machine all rows.

Further information: "Inserting or deleting columns", Page 556

Editing a pallet table

When you create a new pallet table, it is empty at first. Using the soft keys, you can insert and edit rows.

Soft key	Editing function
BEGIN	Select the table start
END	Select the table end
PAGE	Select the previous page in the table
PAGE	Select the next page in the table
INSERT	Insert as last row in the table
DELETE	Delete the last row in the table
APPEND N LINES AT END	Add several rows at end of table
COPY FIELD	Copy the current value
PASTE FIELD	Insert the copied value
BEGIN LINE	Select beginning of line
END LINE	Select end of line
FIND	Find text or value
SORT/ HIDE COLUMNS	Sort or hide table columns
EDIT CURRENT FIELD	Edit the current field
SORT	Sort by column contents
MORE FUNCTIONS	Miscellaneous functions (e.g., saving)
SELECT	Open file path selection

Selecting a pallet table

To select a pallet table or create a new pallet table:



Switch to the **Programming** operating mode or a program run operating mode



► Press the **PGM MGT** key

If no pallet tables are shown:



- ▶ Press the **SELECT TYPE** soft key
- Press the SHOW ALL soft key
- ► Select a pallet table with the arrow keys, or enter a name for a new pallet table (.p)



Press the ENT key



You can select either a list view or form view using the **Screen Layout** key.

Inserting or deleting columns



This function is not enabled until the code number **555343** is entered.

Depending on the configuration, a newly created pallet table may not contain all columns. For tool-oriented machining, for example, you need columns that you have to insert first.

To insert a column in an empty table:

Open the pallet table



▶ Press the **MORE FUNCTIONS** soft key



- ▶ Press the **EDIT FORMAT** soft key
- The control opens a pop-up window displaying the available columns
- Using the arrow keys, select the desired column.



▶ Press the **INSERT COLUMN** soft key



Press the ENT key

You can remove the column with the **DELETE COLUMN** soft key.

Fundamentals of tool-oriented machining

Application



Refer to your machine manual.

Tool-oriented machining is a machine-dependent function. The standard functional range is described below.

Tool-oriented machining allows you to machine several workpieces together even on a machine without pallet changer, which reduces tool-change times.

Limitation

NOTICE

Danger of collision!

Not all pallet tables and NC programs are suitable for tool-oriented machining. With tool-oriented machining, the control no longer executes the NC programs continuously, but divides them at the tool calls. The division of the NC programs allows functions that were not reset to be effective across programs (machine states). This leads to a danger of collision during machining!

- Consider the stated limitations
- Adapt pallet tables and NC programs to the tool-oriented machining
 - Reprogram the program information after each tool in every NC program (e.g. M3 or M4).
 - Reset special functions and miscellaneous functions before each tool in every NC program (e. g., Tilt the working plane or M138)
- Carefully test the pallet table and associated NC programs in the Program run, single block operating mode

The following functions are not permitted:

- FUNCTION TCPM, M128
- M144
- M101
- M118
- Changing the pallet preset

The following functions require special attention, particularly for midprogram startup:

- Changing the machine statuses with a miscellaneous function (e.g. M13)
- Writing to the configuration (e.g. WRITE KINEMATICS)
- Traverse range switchover
- Cycle 32
- Cycle 800
- Tilting the working plane

Pallet table columns for tool-oriented machining

Unless the machine tool builder has made a different configuration, you need the following additional columns for tool-oriented machining:

Column	Meaning
W-STATUS	The machining status defines the machining progress. Enter BLANK for an unmachined (raw) workpiece. The control changes this entry automatically during machining. The control differentiates between the following
	entries
	 BLANK / no entry: Workpiece blank, requires machining
	INCOMPLETE: Partly machined, requires further machining
	ENDED: Machined completely, no further machining required
	■ EMPTY: Empty space, no machining required
-	SKIP: Skip machining
METHOD	Indicates the machining method
	Tool-oriented machining is also possible with a combination of pallet fixtures, but not for multiple pallets.
	The control differentiates between the following entries
	WPO: Workpiece oriented (standard)
	TO: Tool oriented (first workpiece)
	CTO: Tool oriented (further workpieces)
CTID	The control automatically generates the ID number for mid-program startup with block scan. If you delete or change the entry, mid-program startup is no longer possible.
SP-X, SP-Y, SP-Z, SP-A,	The entry for the clearance height in the existing axes is optional.
SP-B, SP-C, SP-U, SP-V, SP-W	You can enter safety positions for the axes. The control only approaches these positions if the machine manufacturer processes them in the NC macros.

13.2 Batch Process Manager (option 154)

Application



Refer to your machine manual.

Your machine tool builder configures and enables the **Batch Process Manager** function.

Batch Process Manager enables you to plan production orders on a machine tool.

You save the planned NC programs in a job list. You use **Batch Process Manager** to open the job list.

The following information is displayed:

- Whether the NC program is free of errors
- Run time of the NC programs
- Availability of the tools
- Times at which manual interventions at the machine are necessary



The tool usage test function has to be enabled and switched on to ensure you get all information!

Further information: User's Manual for **Setup, Testing and Running NC Programs**

Fundamentals

The **Batch Process Manager** is available in the following operating modes:


- Programming
- Program run, single block
- Program run, full sequence

In the **Programming** operating mode, you can create and edit the job list.

The job list is executed in the **Program run, single block** and **Program run, full sequence** operating modes. Changes are possible only to a limited extent.

Screen display

When you open the **Batch Process Manager** in the **Programming** operating mode, the following screen layout is displayed:



- 1 Displays all required manual interventions
- 2 Displays the next manual intervention
- 3 Shows any current soft keys provided by the machine tool builder
- 4 Shows the editable entries in the line highlighted in blue
- 5 Displays the current soft keys
- 6 Displays the job list

Columns in the job list

Column	Meaning
No column name	Status of the Pallet , Clamping , or Program
Program	Name or path of the Pallet , Clamping , or Program
Duration	Run time in seconds This column is only shown if you have a 19-inch screen.
End	 End of the run time Time in Programming mode Actual time in Program run, single block and Program run, full sequence modes
Preset	Status of the workpiece preset
Т	Status of the inserted tools
Pgm	Status of the NC program
Sts	Machining status

The status of the **Pallet**, **Clamping**, and **Program** is shown by means of icons in the first column.

The icons have the following meanings:

Icon	Meaning
	The Pallet , Clamping , or Program is locked
*	The Pallet or Clamping is not enabled for machining
→	This line is currently being executed in Program run, single block or Program run , full sequence mode and cannot be edited
	In this line, the program was interrupted manually

In the **Program** column, the machining method is indicated by means of icons.

The icons have the following meanings:

Icon	Meaning
No icon	Workpiece-oriented machining
	Tool-oriented machining
	Start
L	■ End

The status is shown by means of icons in the $\mbox{\bf Preset}$, $\mbox{\bf T}$, and $\mbox{\bf Pgm}$ columns.

The icons have the following meanings:

lcon	Meaning
√	Test completed
	Test completed
***	Program simulation with active Dynamic Collision Monitoring (DCM) (option 40)
×	Test failed (e.g., because of expired tool life, danger of collision)
$\overline{\mathbb{X}}$	Test not yet completed
?	Incorrect program structure (e.g., pallet does not contain any subprograms)
(Workpiece preset is defined
<u> </u>	Check input
	You can assign a workpiece preset either to the pallet or to all NC subprograms.



Operating notes:

- In Programming operating mode, the T column is always empty because the control first checks the status in the Program run, single block and Program run, full sequence operating modes.
- If the tool usage test function is not enabled or is not switched on for your machine, then no icon is shown in the **Pgm** column

Further information: User's Manual for **Setup, Testing and Running NC Programs**

In the **Sts** columns, the machining status is indicated by icons. The icons have the following meanings:

lcon	Meaning
	Workpiece blank, machining required
	Partially machined, requires further machining
✓ ½	Completely machined, no further machining required
	Skip machining



Operating notes:

- The machining status is automatically adjusted during machining
- The **Sts** column is shown in the **Batch Process Manager** only if the pallet table contains the **W STATUS** column

Further information: User's Manual for **Setup, Testing and Running NC Programs**

Opening Batch Process Manager



Refer to your machine manual.

In machine parameter **standardEditor** (no. 102902), your machine tool builder specifies the standard editor used by the control.

Programming operating mode

If the control does not open the pallet table (.p) in Batch Process Manager as a job list:

Select the desired job list



► Shift the soft-key row



▶ Press the **MORE FUNCTIONS** soft key



- ▶ Press the **SELECT EDITOR** soft key
- > The control opens the **Select editor** pop-up window.



► Select **BPM-EDITOR**



► Confirm with the **ENT** key



- ► Alternative: Press the **OK** soft key
- The control opens the job list in Batch Process Manager.

Program run, single block and Program run, full sequence operating modes

If the control does not open the pallet table (.p) in Batch Process Manager as a job list:



▶ Press the **Screen layout** key



- ▶ Press the **BPM** key
- > The control opens the job list in **Batch Process Manager**.

Soft keys

The following soft keys are available:



Refer to your machine manual.

The machine tool builder can configure his own soft keys.

Soft key	Function
DETAILS OFF ON	Collapse or expand tree structure
EDIT OFF ON	Edit opened job list
INSERT REMOVE	Shows the INSERT BEFORE , INSERT AFTER and REMOVE soft keys

Soft key	Function
MOVE	Move line
TAG	Select line
CANCEL THE MARKING	Cancel marking
INSERT BEFORE	Insert a new Pallet , Clamping , or Program before the cursor position
INSERT AFTER	Insert a new Pallet , Clamping , or Program after the cursor position
REMOVE	Delete line or block
	Switch active windows
SELECT	Select possible entries from a pop-up window
RESET THE STATUS	Reset the machining status to workpiece blank
MACHINING METHOD	Select workpiece-oriented or tool-oriented machining
COLLISION CHECKING	Perform collision checking (Option 40) Further information: "Dynamic Collision Monitoring (option 40)", Page 378
ABORT COLLISION MONITORING	Abort collision checking (Option 40)
ACCESSES OFF ON	Collapse or expand necessary manual interventions
TOOL MANAGEMENT	Open Extended Tool Management
INTERNAL STOP	Interrupt machining



Operating notes:

- The TOOL MANAGEMENT, COLLISION CHECKING, ABORT MONITORING and INTERNAL STOP soft keys are available only in the Program run, single block and Program run, full sequence operating modes.
- If the pallet table contains the W STATUS column, the RESET STATUS soft key is available.
- If the pallet table contains the W STATUS, METHOD, and CTID columns, the MACHINING METHOD soft key is available.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

Creating a job list

You can only create a new job list in the file manager.



The file name of a job list must always begin with a letter.



Press the Programming key




- ► Press the **PGM MGT** key
- > The control opens the file manager.



► Press the **NEW FILE** soft key



- ► Enter the file name with extension (.**p**)
- Confirm with the ENT key





▶ Press the **INSERT REMOVE** soft key



- ▶ Press the **INSERT AFTER** soft key
- > The control displays the various types on the right-hand side.
- Select the desired type
 - Pallet
 - Clamping
 - Program
- > The control inserts an empty line in the job list.
- The control shows the selected type on the righthand side.
- Define the entries
 - **Name**: Enter the name directly or select one by means of the pop-up window, if there is one
 - Datum table: Enter the datum directly, where applicable, or select one by means of the popup window
 - **Preset**: Enter the workpiece preset directly, where applicable
 - Locked: The selected line is excluded from machining
 - Machinable: The selected line is enabled for machining



Confirm your entries by pressing the ENT key.



Repeat the steps if required

Press the EDIT soft key

Editing a job list

You can edit a job list in the **Programming**, **Program run**, **single block**, and **Program run**, **full sequence** operating modes.



Operating notes:

- If a job list is selected in the Program run, single block or Program run, full sequence operating mode, it is not possible to edit the job list in the Programming operating mode.
- The possibilities of changing a job list during machining are limited, because the control defines a protected area.
- NC programs in the protected area are shown in light gray.
- If you edit the job list, the Collision checking completed

 status is reset to Check completed

 .

To edit a line in the job list in **Batch Process Manager**:

▶ Open the desired job list



▶ Press the **EDIT** soft key



- ▶ Place the cursor on the desired line (e.g., **Pallet**)
- > The control displays the selected line in blue.
- > The control displays the editable entries on the right-hand side.



- ▶ Press the **CHANGE WINDOW** soft key if required
- > The control switches the active window.
- The following entries can be changed:
 - Name
 - Datum table
 - Preset
 - Locked
 - Machinable



- Confirm the edited entries by pressing the ENT key.
- > The control adopts the changes.



▶ Press the **EDIT** soft key

To move a line in the job list in **Batch Process Manager**:

Open the desired job list



▶ Press the **EDIT** soft key



- Place the cursor on the desired line (e.g., Program)
- > The control displays the selected line in blue.



▶ Press the **MOVE** soft key




- ▶ Press the **TAG** soft key
- > The control highlights the line in which the cursor is positioned.



- ▶ Place the cursor on the desired position.
- When the cursor is placed at a suitable position, the control shows the INSERT BEFORE and INSERT AFTER soft keys.



- ▶ Press the **INSERT BEFORE** soft key
- > The control inserts the line at the new position.





OFF ON

Press the EDIT soft key

Turning

14.1 Turning operations on milling machines (option 50)

Introduction

Depending on the machine and kinematics, it is possible to perform both milling and turning operations on milling machines. A workpiece can thus be machined completely on one machine, even if complex milling and turning applications are required.

In a turning operation, the tool is in a fixed position, whereas the rotary table and the clamped workpiece rotate.

Depending on the machining direction and task, turning applications can be subdivided into different production processes, e.g.:

- Longitudinal turning
- Face turning
- Recess turning
- Thread cutting



The control provides several cycles for each of the various production processes.

Further information: User's Manual for **Programming of Machining Cycles**

On the control, you can simply switch between milling and turning mode within your NC program. In turning mode, the rotary table serves as lathe spindle, whereas the milling spindle with the tool is fixed. This way, it is possible to machine rotationally symmetric contours. The tool reference point must always be at the center of the lathe spindle.

When managing turning tools, other geometric descriptions than those for milling or drilling tools are required. To execute a tooltip radius compensation, for example, the definition of the cuttingedge radius is required. The control provides a special tool table for turning tools. In tool management, the control displays only the required tool data for the current tool type.

Further information: User's Manual for **Setup, Testing and Running NC Programs**


Different cycles are available for machining. These can also be used with additionally inclined rotary axes.

Further information: "Inclined turning", Page 582

Coordinate plane of turning operations

The assignment of the axes with turning is defined so that the X coordinates describe the diameter of the workpiece and the Z coordinates the longitudinal positions.

Machining is thus always done in the **ZX** working plane. The machine axes to be used for the required movements depend on the respective machine kinematics and are determined by the machine manufacturer. This makes NC programs with turning functions largely exchangeable and independent of the machine model.



Tool radius compensation (TRC)

The tip of a lathe tool has a certain radius (**RS**). During the machining of tapers, chamfers and radii, this results in distortions on the contour because the programmed traverse paths are referenced to the theoretical tool tip S. Tooth radius compensation (TRC) prevents the resulting deviations.

The control determines the theoretical cutting point based on the longest measured values **ZL**, **XL** and **YL**.

In the turning cycles, the control automatically carries out tool radius compensation. In specific traversing blocks and within programmed contours, activate TRC with **RL** or **RR**.

The control checks the cutting geometry with the point angle **P-ANGLE** and the setting angle **T-ANGLE**. Contour elements in the cycle are processed by the control only as far as this is possible with the specific tool.

The control displays a warning when residual material is left behind due to the angle of the secondary cutting edges. You can suppress this warning with the machine parameter **suppressResMatlWar** (no. 201010).




Programming notes:


■ The direction of the radius compensation is not clear when the tool-tip position (TO=2, 4, 6, 8) is neutral. In this case, TRC is only possible within fixed machining cycles.

Tooth radius compensation is also possible during inclined machining.

Active miscellaneous functions limit the possibilities here:


- With M128 tool-tip radius compensation is possible only in combination with machining cycles
- M144 or FUNCTION TCPM with REFPNT TIP-CENTER also allows tooth radius compensation with all positioning blocks, e.g. with RL/RR





Theoretical tool tip

The theoretical tool tip is active in the tool coordinate system. When the tool is inclined, the position of the tool tip rotates with the tool.




Virtual tool tip

To activate the virtual tool tip, use **FUNCTION TCPM** with the **REFPNT TIP-CENTER** selection item. Correct tool data are required for calculating the virtual tool tip.

The virtual tool tip is active in the workpiece coordinate system. When the tool is inclined, the virtual tool tip remains unchanged as long as the tool orientation ${\bf TO}$ is the same. The control automatically switches the status display ${\bf TO}$ and thus also the virtual tool tip if the tool leaves the angle range valid for ${\bf TO}$ 1, for example.

The virtual tool tip enables you to perform inclined paraxial longitudinal and transverse machining operations with high contour accuracy even without radius compensation.

Further information: "Simultaneous turning", Page 584



14.2 Basic functions (option 50)

Switching between milling and turning mode



Refer to your machine manual.

The machine tool builder configures and enables turning and switchover of the machining modes.

To switch between milling and turning operations, you must switch to the specific mode.

You can switch these operating modes with the NC functions **FUNCTION MODE TURN** and **FUNCTION MODE MILL**.

If turning mode is active, the control displays a corresponding icon in the status display.

Icon	Mode
<u>.</u>	Turning mode active: FUNCTION MODE TURN
No icon	Milling mode active: FUNCTION MODE MILL

When the operating modes are switched, the control executes a macro that defines the machine-specific settings for the specific operating mode. With the NC functions **FUNCTION MODE TURN** and **FUNCTION MODE MILL**, you can activate a machine kinematic model that the machine manufacturer has defined and saved in the macro.

AWARNING

Caution: Danger to the operator and machine!

Very high physical forces are generated during turning, for example due to high rotational speeds and heavy or unbalanced workpieces. Incorrect machining parameters, neglected unbalances or improper fixtures lead to an increased risk of accidents during machining!

- ► Clamp the workpiece in the spindle center
- Clamp workpiece securely
- Program low spindle speeds (increase as required)
- ► Limit the spindle speed (increase as required)
- ► Eliminate unbalance (calibrate)



Programming notes:

- If the **Tilt working plane** or **TCPM** functions are active, you cannot switch the operating mode.
- In turning mode, no coordinate conversion cycles are permitted except for the datum shift.
- The orientation of the tool spindle (spindle angle) depends on the machining direction. The tool tip is aligned to the center of the turning spindle for outside machining. For inside machining, the tool points away from the center of the turning spindle.
- The direction of spindle rotation must be adapted when the machining direction (outside/inside machining) is changed.
- During turning, the cutting edge and the center of the turning spindle must be at the same level. During turning, the tool therefore has to be pre-positioned to the Y coordinate of the turning-spindle center.
- By means of M138, you can select the rotary axes for M128 and TCPM.



Operating notes:

- The preset must be in the center of the turning spindle in turning mode.
- In turning mode, diameter values are displayed on the X axis position display. The control then shows an additional diameter symbol.
- In turning mode, the spindle potentiometer is active for the turning spindle (rotary table).
- In turning mode you can use all manual touch probe functions, except the **Probe in plane** and **Intersection probing** cycles. In turning mode, the measured values of the X axis equate to diameter values.
- You can also use the smartSelect function to define the turning functions.
 - **Further information:** "Overview of special functions", Page 374
- In turning mode, the SPA, SPB and SPC transformations from the preset table are not permitted. If you activate one of these transformations while executing the NC program in turning mode, the control will display the Transformation not possible error message.

Specifying the machining mode



▶ Show the soft-key row with special functions



▶ Press the **FUNCTION MODE** soft key



► Function for machining mode: Press the **TURN** (Turning) or **MILL** (Milling) soft key

If the machine manufacturer has enabled the selection of kinematic models:



- ▶ Press the **SELECT KINEMATICS** soft key
- ▶ Select the desired kinematics

Example


11 FUNCTION MODE TURN "AC_TABLE"	Activate turning mode
12 FUNCTION MODE TURN	Activate turning mode
13 FUNCTION MODE MILL "B_HEAD"	Activate milling mode

Graphic display of turning operations

You can simulate turning operations in **Test Run** mode. The requirement for this is a workpiece blank definition suitable for the turning process and option number 20.



The machining times determined using the graphic simulation do not correspond to the actual machining times. Reasons for this during combined milling-turning operations include the switching of operating modes.




Graphic display in the Programming mode of operation

You can graphically simulate turning operations with the line graphic in **Programming** operating mode. To display the traverse movements in turning mode in **Programming** operating mode, change the layout using the soft keys.

Further information: "Generating a graphic for an existing NC program", Page 215

The standard assignment of the axes with turning is defined so that the X coordinates describe the diameter of the workpiece and the Z coordinates the longitudinal positions.

Even if the turning operation takes place in a two-dimensional plane (Z and X coordinates), you have to program the Y values for a rectangular blank in the definition of the workpiece blank.



Example. Rectangular blank

0 BEGIN PGM BLK MM	
1 BLK FORM 0.1Y X+0 Y-1 Z-50	Workpiece blank definition
2 BLK FORM 0.2 X+87 Y+1 Z+2	
3 TOOL CALL 12	Tool call
4 M140 MB MAX	Retract the tool
5 FUNCTION MODE TURN	Activate Turning mode

Programming the spindle speed



Refer to your machine manual.

If you machine at constant cutting speed, the selected gear range limits the possible spindle speed range. The possible gear ranges (if applicable) depend on your machine.

With turning you can machine both at constant spindle speed and constant cutting speed.

If you machine at constant cutting speed **VCONST:ON**, the control modifies the speed according to the distance of the tool tip to the center of the turning spindle. For positioning movements toward the center of rotation, the control increases the table speed; for movements away from the center of rotation, it reduces the table speed.

For processing with constant spindle speed **VCONST:Off**, speed is independent of the tool position.

Use **FUNCTION TURNDATA SPIN** to define the speed. The control provides the following input parameters:

- VCONST: Constant cutting speed on/off (optional)
- VC: Cutting speed (optional)
- S: Nominal speed if no constant cutting speed is active (optional)
- S MAX: Maximum speed with constant cutting speed (optional).
 Reset with S MAX 0
- GEARRANGE: Gear range for the turning spindle (optional)

Defining the spindle speed



Cycle **800** limits the maximum spindle speed during eccentric turning. The control restores a programmed limitation of the spindle speed after eccentric turning.


To reset the speed limitation, program **FUNCTION**

TURNDATA SPIN SMAXO.

When the maximum speed has been reached, the control displays **SMAX** instead of **S** in the status display.

Example

3 FUNCTION TURNDATA SPIN VCONST:ON VC:100 GEARRANGE:2	Definition of a constant cutting speed in gear range 2
3 FUNCTION TURNDATA SPIN VCONST:OFF S550	Definition of a constant spindle speed



Feed rate


With turning, feed rates are often specified in millimeters per revolution. The control thus moves the tool at a defined value for every spindle rotation. The resulting contouring feed rate is thus dependent on the speed of the turning spindle. The control increases the feed rate at high spindle speeds and reduces it at low spindle speeds. This enables you to machine with uniform cutting depth and constant cutting force, thus achieving constant chip thickness



During many turning operations, it is not possible to maintain constant surface speeds (**VCONST: ON**) because the maximum spindle speed is reached first. Use the machine parameter **facMinFeedTurnSMAX** (no. 201009) to define the behavior of the control after the maximum speed has been reached.

By default, the control interprets the programmed feed rate in millimeters per minute (mm/min). If you want to define the feed rate in millimeters per revolution (mm/1), you have to program **M136**. The control then interprets all subsequent feed rate specifications in mm/1 until **M136** is canceled.

M136 is effective modally at the beginning of the block and can be canceled with **M137**.



Example

10 L X+102 Z+2 R0 FMAX Movement at rapid traverse	
15 L Z-10 F200	Movement at a feed rate of 200 mm/min
19 M136	Feed rate in millimeters per revolution
20 L X+154 F0.2	Movement at a feed rate of 0.2 mm/1
•••	

14.3 Turning program functions (option 50)

Tool compensation in the NC program

With **FUNCTION TURNDATA CORR** you can define additional compensation values for the active tool. In the **TURNDATA CORR FUNCTION** you can enter delta values for tool lengths in the X direction **DXL** and in the Z direction **DZL**. The compensation values have an additive effect on the compensation values from the turning tool table.

With **FUNCTION TURNDATA CORR-TCS** you can define a cutter radius oversize **DRS**. This enables you to program an equidistant contour oversize. **DCW** allows you to compensate the recessing width of a recessing tool.

FUNCTION TURNDATA CORR is always in effect for the active tool. A renewed **TOOL CALL** deactivates compensation. When you exit the NC program (e.g. with PGM MGT), the control automatically resets the compensation values.

When you enter the **FUNCTION TURNDATA CORR** function, you can define where tool compensation will be active using soft keys:

- **FUNCTION TURNDATA CORR-TCS**: Tool compensation is active in the tool coordinate system
- **FUNCTION TURNDATA CORR-WPL**: Tool compensation is active in the workpiece coordinate system



Tool compensation **FUNCTION TURNDATA CORR-TCS** is always active in the tool coordinate system, even during inclined machining.



During interpolation turning, the functions **FUNCTION TURNDATA CORR** and **FUNCTION TURNDATA CORR-TCS** are not active.

If you wish to compensate for a turning tool in Cycle **292 CONTOUR.TURNG.INTRP.**, then you must perform this in the cycle or in the tool table.

Further information: User's Manual for **Programming of Machining Cycles**

Defining the tool compensation

To define tool compensation in the NC program:



▶ Press the **SPEC FCT** key



▶ Press the **TURNING FUNCTIONS** soft key



► Press the **FUNCTION TURNDATA** soft key



► Press the **TURNDATA CORR** soft key



As an alternative to tool compensation with **TURNDATA CORR**, you can use compensation tables.

Further information: "Compensation table", Page 425

Example

21 FUNCTION TURNDATA CORR-TCS:Z/X DZL:0.1 DXL:0.05

•••

Blank form update TURNDATA BLANK

The **TURNDATA BLANK** function enables you to use the blank form update feature.

Using the blank form update feature, the control detects the already machined areas and adapts all approach and departure paths to the specific, current machining situation. Thus, air cuts are avoided and the machining time is significantly reduced.

With **TURNDATA BLANK** you call a contour description used by the control as an updated workpiece blank.


Blank form update is only active in conjunction with roughing cycles. In finishing cycles the control always machines the entire contour, for example so that the contour does not have any offset.


Further information: User's Manual for **Programming of Machining Cycles**



Programming notes:

- Blank form update is only possible with cycle machining in turning mode (FUNCTION MODE TURN).
- You must define a closed contour as the workpiece blank for the blank form update (start position = end position). The workpiece blank corresponds to the cross-section of a rotationally symmetrical body.





NOTICE

Danger of collision!

Blank form update is used to optimize machining areas and approach movements. For approach and departure paths, the control takes the specific workpiece blank into account that is being followed. If parts of the finished part extend beyond the workpiece blank, this may damage the workpiece and tool.

▶ Define the workpiece blank to be larger than the finished part.

Define the function TURNDATA BLANK:



▶ Show the soft-key row with special functions



Press the TURNING FUNCTIONS soft key



▶ Press the **FUNCTION TURNDATA** soft key



- ▶ Press the **TURNDATA BLANK** soft key
- Press the soft key for the desired contour call

You can call the contour description in the following ways:

Soft key	Function		
BLANK <file></file>	Contour description in an external NC program Call via file name		
BLANK <file>=QS</file>	Contour description in an external NC program Call via string parameter		

Soft key	Function
BLANK LBL NR	Contour description in a subprogram Call via label number
BLANK LBL NAME	Contour description in a subprogram Call via label name
BLANK LBL QS	Contour description in a subprogram Call via string parameter

Deactivating the blank form update

Deactivate blank form update:



Show the soft-key row with special functions



Press the TURNING FUNCTIONS soft key



Press the FUNCTION TURNDATA soft key



Press the TURNDATA BLANK soft key



▶ Press the **BLANK OFF** soft key

Inclined turning

It may sometimes be necessary for you to bring the swivel axes into a specific position to machine a specific process. This can be necessary, for example, when you can only machine contour elements according to a specific position due to tool geometry.

The control offers the following methods of inclined turning:


- M144
- M128
- FUNCTION TCPM with REFPNT TIP-CENTER
- Cycle 800 ADJUST XZ SYSTEM
 Further information: User's Manual for Programming of Machining Cycles

If you execute turning cycles with **M144**, **FUNCTION TCPM**, or **M128**, then the angles of the tool relative to the contour will change. The control automatically takes these modifications into account and therefore also monitors the inclined machining operation.



Programming notes:

- Threading cycles can be run with inclined machining only if the tool is at a right angle (+90°, or −90°).
- Tool compensation FUNCTION TURNDATA CORR-TCS is always active in the tool coordinate system, even during inclined machining.



M144

Inclining a swivel axis creates an offset from the workpiece to the tool. The function **M144** considers the position of the inclined axes and compensates this offset. In addition the function **M144** aligns the Z direction of the workpiece coordinate system to the direction of the centerline of the workpiece. If an inclined axis is a tilting table, meaning that the workpiece itself is inclined, the control performs traverse movements in the rotated workpiece coordinate system. If the inclined axis is a swivel head (meaning that the tool is inclined), the workpiece coordinate system is not rotated.

After inclining the tilting axis, you may have to again pre-position the tool in the Y coordinate and orient the position of the tool tip with Cycle **800**.

Example

12 M144		Activate inclined machining
13 L A-25 RO FMA	X	Position swivel axis
14 CYCL DEF 800 A	ADJUST XZ SYSTEM	Workpiece coordinate system and align tool
Q497=+90	;PRECESSION ANGLE	
Q498=+0	;REVERSE TOOL	
Q530=+2	;INCLINED MACHINING	
Q531=-25	;ANGLE OF INCIDENCE	
Q532=750	;FEED RATE	
Q533=+1	;PREFERRED DIRECTION	
Q535=3	;ECCENTRIC TURNING	
Q536=0	;ECCENTRIC W/O STOP	
15 L X+165 Y+0 R0 FMAX		Pre-positioning the tool
16 L Z+2 RO FMAX	(Tool at starting position
		Machining with inclined axis

M128

Alternately, you can use the **M128** function. The effect is the same, but the following limitation applies here: if you activate inclined machining with M128 then tool-tip radius compensation without a cycle, i.e. in traversing blocks with **RL/RR**, is not possible. If you activate inclined machining via **M144** or **FUNCTION TCPM** with **REFPNT TIP-CENTER**, then this limitation does not apply.

FUNCTION TCPM with REFPNT TIP-CENTER

Use **FUNCTION TCPM** with the selection **REFPNT TIP-CENTER** to activate the virtual tool tip. If you activate inclined machining with **FUNCTION TCPM** with **REFPNT TIP-CENTER**, then tool-tip radius compensation is also possible without a cycle; that is, in traversing blocks with **RL/RR**.

In **Manual operation** mode, you can also perform inclined turning if you activate **FUNCTION TCPM** with the selection **REFPNT TIP-CENTER** in, for example, the **Positioning w/ Manual Data Input** operating mode.

Machining with cranked recessing tools

When you are working with a cranked recessing tool, you have to incline the axes. Pay attention to the kinematics of your machine.

Example: Machine with AC kinematics

•••		
8 TOOL CALL "RECE	SS_25"	Cranked recessing tool 25°
12 M144		Activate inclined machining
13 L A+25 RO FMA	X	Position swivel axis
14 CYCL DEF 800 AI	DJUST XZ SYSTEM	
Q497=+90	;PRECESSION ANGLE	Align workpiece coordinate system and tool
Q498=+0	;REVERSE TOOL	
Q530=+0	;INCLINED MACHINING	
Q531=+0	;ANGLE OF INCIDENCE	
Q532=750	;FEED RATE	
Q533=+1	;PREFERRED DIRECTION	
Q535=3	;ECCENTRIC TURNING	
Q536=0	;ECCENTRIC W/O STOP	
15 L X+165 Y+0 Z+2 R0 FMAX		Preposition the tool, if required
16 CYCL DEF		Define the recessing cycle or recess-turning cycle
		Machining

Simultaneous turning


You can combine the turning operation with function **M128** or **FUNCTION TCPM** and **REFPNT TIP-CENTER**. This enables you to manufacture contours in one cut, for which you have to change the inclination angle (simultaneous machining).

The simultaneous turning contour is a turning contour for which a rotary axis whose inclination does not violate the contour can be programmed on **CP** polar circles and **L** linear blocks. Collisions with lateral cutting edges or holders are not prevented. This makes it possible to finish contours with one tool in a continuous movement, even though different sections of the contour are accessible only in different tool inclinations.

In the NC program you define how the rotary axis has to be inclined to reach the different contour parts without collisions.

Use the cutter radius oversize **DRS** to leave an equidistant oversize on the contour.

Use **FUNCTION TCPM** and **REFPNT TIP-CENTER** to measure the theoretical tool tip of the turning tools being used for this.



Procedure

To write a simultaneous program:

- ► Activate turning mode
- Insert a turning tool
- ► Adapt the coordinate system with Cycle **800**
- ► Activate **FUNCTION TCPM** with **REFPNT TIP-CENTER**
- ► Activate radius compensation with RL / RRG41/G42
- ► Program simultaneous turning contour
- ► Cancel radius compensation with a departure block or R0
- ► Reset **FUNCTION TCPM**

Example

0 BEGIN PGM TURNSIMULTAN MM		
12 FUNCTION MODE TURN	Activate turning mode	
13 TOOL CALL "TURN_FINISH"	Insert a turning tool	
14 FUNCTION TURNDATA SPIN VCONST:OFF S500		
15 M140 MB MAX		
16 CYCL DEF 800 ADJUST XZ SYSTEM	Adapt the coordinate system	
Q497=+90 ;PRECESSION ANGLE		
Q498=+0 ;REVERSE TOOL		
Q530=+0 ;INCLINED MACHINING		
Q531=+0 ;ANGLE OF INCIDENCE		
Q532= MAX ;FEED RATE		
Q533=+0 ;PREFERRED DIRECTION		
Q535=+3 ;ECCENTRIC TURNING		
Q536=+0 ;ECCENTRIC W/O STOP		
17 FUNCTION TCPM F TCP AXIS POS PATHCTRL AXIS REFPNT TIP-CENTER	Activate FUNCTION TCPM	
18 FUNCTION TURNDATA CORR-TCS:Z/X DRS:-0.1		
19 L X+100 Y+0 Z+10 R0 FMAX M304		
20 L X+45 RR FMAX	Activate radius compensation with RR	
26 L Z-12.5 A-75	Program simultaneous turning contour	
27 L Z-15		
28 CC X+69 Z-20		
29 CP PA-90 A-45 DR-		
30 CP PA-180 A+0 DR-		
47 L X+100 Z-45 R0 FMAX	Cancel radius compensation with R0	
48 FUNCTION RESET TCPM	Reset FUNCTION TCPM	
49 FUNCTION MODE MILL		
71 END PGM TURNSIMULTAN MM		

M128

Alternately, you can use the **M128** function for simultaneous turning. The following constraints apply for M128:

- Only for NC programs programmed on the path of the tool center.
- Only for button turning tools with TO 9
- The tool must be measured at the center of the tool-tip radius

Turning operation with FreeTurn tools

Application

The control makes it possible to define FreeTurn tools and to use them, for example, for inclined or simultaneous turning operations.

FreeTurn tools are lathe tools that are equipped with multiple cutting edges. Depending on the variant, a single FreeTurn tool may be capable of axis-parallel and contour-parallel roughing and finishing.

Thanks to the use of FreeTurn tools, fewer tool changes are required, reducing the machining time. Due to the tool orientation to the workpiece, only outside machining is possible.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

Requirements

- Machine whose tool spindle is perpendicular to the workpiece spindle or can be inclined.
 - Depending on the machine kinematics, a rotary axis is required for the orientation of the spindles to each other.
- Machine with controlled tool spindle
 - The control inclines the cutting edge by means of inclining the tool spindle.
- Combined milling/turning (software option 50)
- Kinematics description
 - The machine manufacturer provides the kinematics description. Based on the kinematics description, the control can take the tool geometry, for example, into account.
- Machine-manufacturer macros for simultaneous turning with FreeTurn tools
- FreeTurn tool with suitable tool carrier
- Tool definition
 - A FreeTurn tool always includes three cutting edges of an indexed tool.

Description of function

To use FreeTurn tools, call only the desired cutting edge of the correctly defined indexed tool in your NC program.

Further information: User's Manual for **Programming of Machining Cycles**



FreeTurn tool in simulation

FreeTurn tools







FreeTurn indexable insert for roughing

FreeTurn indexable insert for finishing

FreeTurn indexable insert for roughing and finishing

The control supports all variants of FreeTurn tools:

- Tool with finishing cutting edge
- Tool with roughing cutting edge
- Tool with finishing and roughing cutting edge

In the **TYP** column of the tool management, select a turning tool (**TURN**) as the tool type. In the **TYPE** column, assign the appropriate technology-specific tool type to each cutting edge, i.e. roughing tool (**ROUGH**) or finishing tool (**FINISH**).

Further information: User's Manual for **Setup, Testing and Running NC Programs**

A FreeTurn tool must be defined as an indexed tool with three cutting edges that are offset by the **ORI** angle of orientation. Each cutting edge has the **TO 18** tool orientation.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

FreeTurn tool carrier

There is a suitable tool carrier for each FreeTurn tool variant. HEIDENHAIN provides ready-to-use tool carrier templates for download that are included in the programming station software. You can then assign the tool-carrier kinematics descriptions generated from the templates to the respective indexed cutting edge.

Further information: User's Manual for **Setup, Testing and Running NC Programs**



Tool carrier template for a FreeTurn tool

Notes

NOTICE

Danger of collision!

The shaft length of the turning tool limits the diameter that can be machined. There is a risk of collision during machining!

- ► Check the machining sequence in the simulation
- Due to the tool orientation to the workpiece, only outside machining is possible.
- Please note that FreeTurn tools can be combined with various machining strategies. Therefore, make sure to observe the specific notes, e.g. in conjunction with the selected machining cycles.

Using a facing slide

Application




Refer to your machine manual.

This function must be enabled and adapted by the machine manufacturer.

With a facing slide, also called boring head, you can perform almost all turning operations with fewer different tools. The slide position of the facing slide in the X direction can be programmed. On the facing slide you mount, for example, a longitudinal turning tool that you call with a TOOL CALL block.

Machining also works with a tilted working plane and on workpieces that are not rotationally symmetric.



Please note while programming

The following constraints apply to the use of a facing slide:

- Miscellaneous functions M91 and M92 cannot be used
- Retraction with **M140** is not possible
- TCPM or M128 are not possible
- **DCM** collision monitoring cannot be used
- Cycles 800, 801, and 880 cannot be used
- Cycles 286 and 287 cannot be used (option 157)

If you are using the facing slide in the tilted working plane, please note the following:

- The control calculates the tilted working plane as in milling mode. The COORD ROT and TABLE ROT functions, as well as SYM (SEQ), reference the XY plane.
- HEIDENHAIN recommends selecting the **TURN** positioning behavior. The **MOVE** positioning behavior is not the best option in combination with the facing slide.

NOTICE

Caution: Danger to the tool and workpiece!

For a facing slide to be used, a kinematic model prepared by the machine manufacturer must be selected by means of the function **FUNCTION MODE TURN**. In this kinematic model, the control implements the programmed X-axis movements of the facing slide as U-axis movements when the **FACING HEAD** function is active. When the **FACING HEAD** function is not active and in **Manual operation** operating mode, this automated implementation does not take place. As a result, **X** axis movements (programmed or via axis key) will be performed in the X axis. In this case, the facing slide has to be moved with the U axis. There is a danger of collision during retraction or manual movements!

- ► Position the facing slide at its home position while the FACING HEAD POS function is active
- ▶ Retract the facing slide while the FACING HEAD POS function is active
- ► In the **Manual operation** operating mode, move the facing slide with the **U** axis key.
- ► As the **Tilt working plane** function can be used, pay attention to the 3-D ROT status

Entering tool data

The tool data correspond to the data from the turning-tool table.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

Please note for tool calls:

- TOOL CALL block without tool axis
- Cutting speed and spindle speed with TURNDATA SPIN
- Switch the spindle on with M3 or M4

To set a spindle-speed limitation, you can use the **NMAX** value from the tool table as well as the **SMAX** value from **FUNCTION TURNDATA SPIN**.

Activating and positioning the facing slide

Before you can activate the facing slide function, you have to select a kinematic model with facing slide by means of **FUNCTION MODE TURN**. The machine manufacturer provides this kinematic model.

Example

5 FUNCTION MODE TURN "FACINGHEAD"

Switchover to turning mode with facing slide



Upon activation, the facing slide automatically moves to the datum in the X and Y axes. Position the spindle axis to clearance height beforehand or enter the clearance height in the **FACING HEAD POS** NC block.

To activate the facing slide function:



► Press the **SPEC FCT** key



► Press the **TURNING FUNCTIONS** soft key



▶ Press the **FACING SLIDE** soft key



- Press the FACING HEAD POS soft key
- ► Enter the clearance height, if required
- Enter the feed rate, if required

Example

7 FACING HEAD POS	Activating without positioning to clearance height
7 FACING HEAD POS HEIGHT+100 FMAX	Activating with positioning to clearance height Z+100 at rapid traverse

Working with the facing slide



Refer to your machine manual.

The machine manufacturer can provide customized cycles for working with a facing slide. The standard functionality is described below.

Your machine manufacturer can provide a feature with which you can specify the position of the facing slide with an offset in X direction. The datum always has to be in the spindle axis, however. Recommended program structure:

- 1 Activate **FUNCTION MODE TURN** with facing slide
- 2 Move to clearance height, if necessary
- 3 Shift the datum to the spindle axis
- 4 Activate and position the facing slide with FACING HEAD POS
- 5 Perform machining in the ZX plane using turning cycles
- 6 Retract the facing slide and move it to its home position
- 7 Deactivate the facing slide
- 8 Switch over the machining mode with **FUNCTION MODE TURN** or **FUNCTION MODE MILL**

The coordinate plane is defined such that the X coordinates describe the diameter of the workpiece and the Z coordinates the longitudinal positions.



The machine manufacturer uses the optional machine parameter **presetToAlignAxis** (no. 300203) to define for each axis how the control is to interpret offset values. If **FACING HEAD POS** is used, the machine parameter applies to the parallel axis (**U** axis) only (**U_OFFS**).

Further information: User's Manual for **Setup, Testing and Running NC Programs**

- If the machine parameter has not been defined or has been set to FALSE, the control does not take the offset into account during machining.
- If the machine parameter axis has been set to TRUE, the offset can be used to compensate a facing slide offset. If you are using a facing slide with multiple tool clamp options, set the offset for the current clamping position. This ensures that you can run NC programs independent of the tool clamping position.

Deactivating the facing slide function

To deactivate the facing slide function:



▶ Press the **SPEC FCT** key



▶ Press the **TURNING FUNCTIONS** soft key



► Press the **FACING SLIDE** soft key



▶ Press the **FUNCTION FACING HEAD** soft key



► Press the **ENT** key

Example

7 FUNCTION FACING HEAD OFF

Deactivating the facing slide

Cutting force monitoring with the AFC function



Refer to your machine manual.

This function must be enabled and adapted by the machine manufacturer.

You can also use the **AFC** function (option 45) in turning mode and thus monitor the complete machining process. In turning mode, the control checks for tool wear and tool breakage. Feed control is deactivated during turning mode.

For this purpose, the control uses the reference load **Pref**, the minimum load **Pmin** and the maximum load **Pmax**.

Cutting force monitoring with **AFC** basically works like adaptive feed control in milling mode. The control requires slightly different data, which you provide via the table AFC.TAB.

The learned reference loads **Pref**< 5 % are automatically raised to the lower limit of 5 % during this process.



Execute the function **AFC CUT BEGIN** only after the starting rotational speed has been reached. If this is not the case, then the control issues an error message, and the AFC cut is not started.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

Defining the AFC basic settings

The table AFC.TAB is valid for milling and turning mode. For turning mode, you define your own monitoring settings (line in the table). Enter the following data in the table:

Column	Function
NR	Consecutive line number in table
AFC	Name of the monitoring setting. You enter this name in the AFC column of the tool table. It specifies the assignment to the tool.
FMIN	Feed rate at which the control is to perform an overload reaction.
	Input value in turning mode: 0 (not required in turning mode)
FMAX	Maximum feed rate in the material up to which the control can automatically increase the feed rate.
	Input value in turning mode: 0 (not required in turning mode)
FIDL	Feed rate for traverse when the tool is not cutting (feed rate in the air).
	Input value in turning mode: 0 (not required in turning mode)
FENT	Feed rate at which the control is to traverse when the tool enters or exits the material.
	Input value in turning mode: 0 (not required in turning mode)
OVLD	Desired reaction of the control to overload:
	■ E : Display an error message on the screen
	■ L: Disable active tool
	-: No overload reaction
	In turning mode it is not possible to insert replacement tools. If you define the overload reaction M , the control outputs an error message.
POUT	Entering the minimum load Pmin for tool breakage monitoring
SENS	Sensitivity of the feed control
	Input value in turning mode: 0 or 1 for monitoring for minimum load Pmin
	SENS 1: Pmin is evaluatedSENS 0: Pmin is not evaluated
PLC	Value that the control is to transfer to the PLC at the beginning of a machining step. The machine tool builder defines the function, so refer to your machine manual.

Defining the monitoring setting for turning tools

Enter a separate monitoring setting for each turning tool. Proceed as follows:

- Open the tool table TOOL.T
- Find turning tool
- Adopt the desired AFC strategy in the column AFC

If you are using the extended tool management, you can also enter the monitoring settings directly in the Tool form.

Performing a teach-in cut

In turning mode, the teach-in phase has to be run completely. The control generates an error message if you enter **TIME** or **DIST** for the **AFC CUT BEGIN** function.

Canceling with the **EXIT LEARNING** soft key is not permitted.

You cannot reset the reference load, the **PREF RESET** soft key is dimmed.

Activating and deactivating AFC

You activate the feed control as in milling mode.

Monitoring tool wear and tool breakage

In turning mode, the control can check for tool wear and tool breakage.

A tool breakage leads to a sudden load decrease. If you want the control to monitor the load decrease, too, enter the value 1 in the SENS column.



Further information: User's Manual for **Setup, Testing and Running NC Programs**

15

Grinding

15.1 Grinding operations on milling machines (option 156)

Introduction



Refer to your machine manual.

Grinding must be configured and enabled by your machine tool builder. Some functions and cycles may not be available on your machine tool.

Special types of milling machines allow performing both milling and grinding operations. A workpiece can thus be machined completely on one machine, even if complex milling and grinding operations are required.

The term grinding encompasses many types of machining that differ in quite a few respects, e.g.:

- Jig grinding
- Cylindrical grinding
- Surface grinding



The TNC 640 currently features jig grinding.



Grinding tools

When managing grinding tools, other geometric descriptions than those for milling or drilling tools are required. The control provides special form-based tool management for grinding and dressing tools.

If grinding is enabled on your milling machine (option 156), the dressing function is also available. This means that you can shape or resharpen the grinding wheel in the machine.

Further information: User's Manual for **Setup, Testing and Running NC Programs**

Jig grinding



The control provides various cycles for the specific jig grinding or dressing movements.

Further information: User's Manual for **Programming of Machining Cycles**

Jig grinding is the grinding of a 2D contour. The tool movement in the plane is optionally superimposed by a reciprocation movement along the active tool axis.

On a milling machine, jig grinding will mainly be used for finishing a pre-machined contour with a grinding tool. There is not much of a difference between jig grinding and milling. Instead of a milling cutter, a grinding tool is used, such as a grinding pin or a grinding wheel. Jig grinding produces more precise results and a better surface quality than milling.

Machining is performed in milling mode, i.e. with **FUNCTION MODE MILL**.

Grinding cycles provide special movements for the grinding tool. A stroke or oscillating movement, the so-called reciprocating stroke, is superimposed with the movement in the working plane.

Grinding is also possible with a tilted working plane. The tool reciprocates along the active tool axis in the current working plane coordinate system (WPL-CS).

Reciprocating stroke

For jig grinding, the movement of the tool in the plane can be superimposed by a stroke movement, the so-called reciprocating stroke. The superimposed stroke movement is applied in the active tool axis.

You define an upper and a lower stroke limit and can start and stop the reciprocating stroke and reset the corresponding values. The reciprocating stroke is active until you stop it. **M2** or **M30** will stop the reciprocating stroke automatically.

The control provides cycles for defining, starting, and stopping reciprocating strokes.

As long as the reciprocating stroke is active in a started NC program, you cannot change to the **Manual Operation** or **Positioning w/ Manual Data Input** operating modes.



Operating notes:

- The reciprocating stroke continues to be effective during a programmed stop with MO and in Program run, single block operating mode even after the end of an NC block
- The control does not support block scans while the reciprocating stroke is active.



Refer to your machine manual.

Your machine tool builder can define which override is to be effective for the reciprocating stroke movement.

Graphic display of the reciprocating stroke

The graphic simulation in the **Program run, single block** and **Program run, full sequence** operating modes shows the superimposed stroke movement.

Structure of the NC program

An NC program for grinding is structured as follows:

- Dressing of the grinding tool, if required
- Defining the reciprocating stroke
- If necessary, explicitly starting the reciprocating stroke
- Moving along the contour
- Stopping the reciprocating stroke

You can use specific machining cycles (e.g., cycles for grinding, for machining pockets or studs, or SL cycles) to define the contour.

With a grinding tool, the control behaves in the same way as with a milling cutter.

- If no cycle has been programmed and a contour is being ground whose smallest inside radius is smaller than the tool radius, the control will display an error message.
- If you machine with SL cycles, only those areas will be ground that are suitable for the given tool radius. In this case, the resulting contour will not be completely finished and may need to be reworked.

Further information: User's Manual for **Programming of Machining Cycles**

Compensation in the grinding process

In order to achieve the required precision, you can use compensation tables during jig grinding.

Further information: "Compensation table", Page 425

15.2 Dressing (option 156)

Dressing function fundamentals



Refer to your machine manual.

For dressing operations, the machine must be prepared accordingly by the machine manufacturer. The machine manufacturer may provide his own cycles.

The term "dressing" refers to the sharpening or trueing up of a grinding tool inside the machine. During dressing, the dresser machines the grinding wheel. Thus, in dressing, the grinding tool is the workpiece.

The dressing operation removes material from the grinding wheel and may cause wear of the dressing tool. The material removal and wear lead to changed tool data that need to be compensated for after dressing.

The COR_TYPE parameter provides the following compensation options for the tool data:

- Grinding wheel with compensation, COR_TYPE_GRINDTOOL
 Compensation method removing material from the grinding tool
 Further information: "Compensation methods", Page 602
- Dressing tool with wear, COR_TYPE_DRESSTOOL
 Compensation method removing material from the dresser
 Further information: "Compensation methods", Page 602

Use the Cycles **1032 GRINDING WHL LENGTH COMPENSATION** and **1033 GRINDING WHL RADIUS COMPENSATION** to compensate the grinding wheel or the dresser, regardless of the compensation method.

Further information: User's Manual for **Programming of Machining Cycles**



Not all grinding tools require dressing. Comply with the information provided by your tool manufacturer.

Coordinate planes for dressing

In dressing, the workpiece datum is located on an edge of the grinding wheel. Select the respective edge by using Cycle **1030 ACTIVATE WHEEL EDGE**.

During dressing, the axes are arranged such that the X coordinates describe positions on the radius of the grinding wheel, and the Z coordinates describe the positions along the axis of the grinding wheel. The dressing programs are thus not contingent on the machine type.

The machine manufacturer defines which machine axes will perform the programmed movements.



Simplified dressing



Refer to your machine manual.

For dressing operations, the machine must be prepared accordingly by the machine manufacturer. The machine manufacturer may provide his own cycles.

Your machine manufacturer can program the entire dressing mode in a macro.

Depending on this macro, you can start the dressing mode with one of the following cycles:

- Cycle 1010 DRESSING DIAMETER
- Cycle 1015 PROFILE DRESSING
- Cycle 1016 DRESSING OF CUP WHEEL
- OEM cycle

It is not necessary to program FUNCTION DRESS BEGIN.

In this case, the machine manufacturer determines the dressing sequence.

Compensation methods

Stock removal on the grinding tool

During dressing, a dressing tool is usually used that is harder than the grinding tool. Due to the difference in hardness, the stock removal during dressing mainly takes place at the grinding tool. The programmed dressing amount is actually removed at the grinding tool, since the dressing tool does not noticeably wear. In this case the compensation method **Grinding wheel with compensation**, **COR_TYPE_GRINDTOOL** is used in the **COR_TYPE** parameter of the grinding tool.

Further information: Setup, Testing and Running NC Programs With this compensation method, the tool data of the dressing tool remain constant. The control compensates only for the grinding tool:

- Programmed dressing amount in the basic data of the grinding tool, e.g. R-OVR
- If applicable, measured deviation between nominal and actual dimension in the compensation data of the grinding tool, e.g. dR-OVR

Stock removal on dressing tool

In contrast to the standard situation, stock removal does not take place only on the grinding tool in certain grinding and dressing combinations. In this case the dressing tool wears noticeably, e.g. with very hard grinding tools in combination with softer dressing tools. To compensate for this noticeable wear on the dressing tool, the control offers the compensation method **Dressing tool with wear, COR_TYPE_DRESSTOOL** in the **COR_TYPE** parameter of the dressing tool.

Further information: Setup, Testing and Running NC Programs With this compensation method the tool data of the dressing tool change significantly. The control compensates for both the grinding tool and the dressing tool:

- Dressing amount in the basic data of the grinding tool, e.g. **R-OVR**
- Measured wear in the compensation data of the dressing tool, e.g. DXL

If you use the compensation method **Dressing tool with wear, COR_TYPE_DRESSTOOL**, the control stores the tool number of the dressing tool used in the **T_DRESS** parameter of the grinding tool after dressing. During future dressing processes, the control monitors whether the defined dressing tool is used. If you use a different dressing tool, the control interrupts the dressing with an error message.

You must recalibrate the grinding tool after each dressing process so that the control can determine and compensate for the wear.



When using the **Dressing tool with wear, COR_TYPE_DRESSTOOL** correction method, inclined dressing tools must not be used.

Programming with FUNCTION DRESS



Refer to your machine manual.

Dressing mode is a machine-dependent function. Your machine manufacturer may provide a simplified procedure for this purpose.

Further information: "Simplified dressing", Page 602

NOTICE

Danger of collision!

When you activate **FUNCTION DRESS BEGIN**, the control switches the kinematics. The grinding wheel becomes the workpiece. The axes may move in the opposite direction. There is a risk of collision during the execution of the function and during the subsequent machining!

- Activate the FUNCTION DRESS dressing mode only in Program run, single block mode or Program run, full sequence mode mode
- ▶ Before starting **FUNCTION DRESS BEGIN**, position the grinding wheel near the dressing tool
- Once you have activated FUNCTION DRESS BEGIN, use exclusively cycles from HEIDENHAIN or from your machine manufacturer
- ▶ In case the NC program is aborted or in case of a power interruption, check the traverse directions of the axes
- ▶ If necessary, program a kinematic switch-over

NOTICE

Danger of collision!

The dressing cycles position the dressing tool at the programmed grinding wheel edge. Positioning occurs simultaneously in two axes of the working plane. The control does not perform collision checking during this movement! There is a danger of collision!

- ▶ Before starting **FUNCTION DRESS BEGIN**, position the grinding wheel near the dressing tool
- Make sure there is no risk of collision
- Verify the NC program by slowly executing it block by block

Operating notes

- The grinding tool must not be assigned a tool carrier kinematic model.
- The control does not graphically depict the dressing operation. The times determined by the simulation do not reflect the actual machining times. One reason for this is the necessary switching of the kinematic model.
- With the switch to dressing mode, the grinding tool remains in the spindle and retains its current rotational speed.

The control does not support a block scan during the dressing process. If, during a block scan, you select the first NC block after the dressing operation, then the control moves to the most recently approached position in the dressing operation.

Programming notes

- The **FUNCTION DRESS BEGIN** function is allowed only if a grinding tool is in the spindle.
- If the "tilt working plane" function or **TCPM** function is active, then you cannot switch to dressing mode.
- No coordinate transformation cycles are permitted in dressing mode
- The **M140** function is not allowed in dressing mode.
- During dressing, the cutting edge of the dresser must be at the same height as the grinding wheel. The programmed Y coordinate must be 0.

Switching between normal operation and dressing mode

For the control to switch to the kinematic model for dressing, you must program the dressing process between the functions **FUNCTION DRESS BEGIN** and **FUNCTION DRESS END**.

If the dressing mode is active, then the control shows a symbol in the status display.

lcon	Mode
	Dressing mode active: FUNCTION DRESS BEGIN
No icon	Normal milling or jig grinding operation is active

You can switch back to normal operation with the function **FUNCTION DRESS END**.

In the event of an NC program abort or a power interruption, the control automatically activates normal operation and the kinematic model that was active prior to dressing mode.

NOTICE

Danger of collision!

With an active dressing kinematics model, the machine movements may be effective in the opposite direction. There is a risk of collision when you move the axes!

- ► In case the NC program is aborted or in case of a power interruption, check the traverse directions of the axes
- ▶ Program a switch in the kinematic model as needed

Activating dressing mode

To activate dressing mode:



▶ Press the **SPEC FCT** key



Press the PROGRAM FUNCTIONS soft key



► Press the **FUNCTION DRESS** soft key



▶ Press the **FUNCTION DRESS BEGIN** soft key

If the machine manufacturer has enabled the selection of kinematic models:



- ▶ Press the **SELECT KINEMATICS** soft key
- Preposition the dresser and the center of the grinding tool in the Y coordinate in proper relation to each other

Example

11 FUNCTION DRESS BEGIN	Activate dressing mode
12 FUNCTION DRESS BEGIN "KINE_DRESS"	Activate dressing mode with kinematic model selection

You can switch back to normal operation with the function **FUNCTION DRESS END**.

Example

18 FUNCTION DRESS END	Deactivate dressing mode
-----------------------	--------------------------

16

Operating the touchscreen

16.1 Display unit and operation

Touchscreen



Refer to your machine manual.

This function must be enabled and adapted by the machine manufacturer.

The touchscreen is distinguished by a black frame and the lack of soft-key selection keys.

As an alternative, the TNC 640 has its operating panel integrated in the screen.

- 1 Header
 - When the control is on, the screen displays the selected operating modes in the header.
- 2 Soft-key row for the machine tool builder
- 3 Soft-key row
 - The control shows further functions in a soft-key row. The active soft-key row is shown as a blue bar.
- 4 Integrated operating panel
- **5** Setting the screen layout
- **6** Switchover between machine operating modes, programming modes, and a third desktop





Operation and cleaning



Avoiding electrostatic discharge when operating touchscreens

Touchscreens are based on a capacitive working principle, i.e. they are sensitive to electrostatic charges generated by the operators.

Users can discharge static electricity from their body by touching grounded metal objects. This problem can be avoided by wearing ESD clothing.

Capacitative sensors detect a contact as soon as a person's finger touches the touchscreen. Touchscreens can even be operated with dirty hands, as long as the touch sensors are able to detect the skin resistance. While small amounts of liquid will not cause a fault, larger quantities of liquid will cause erroneous input.



Use work gloves to prevent the device from becoming dirty. The rubber material of special touchscreen work gloves contains metal ions that transfer the skin resistance to the display.

In order to maintain the functionality of the touchscreen, use the following cleaners only:

- Glass cleaner
- Foaming screen cleaners
- Mild detergents



Do not apply the cleaner directly to screen, but slightly dampen a suitable cleaning cloth with it.

Switch off the control before cleaning the touchscreen. As an alternative, you can use the touchscreen cleaning mode.

Further information: User's Manual for **Setup, Testing and Running NC Programs**



Never use the following cleaners or cleaning aids, in order to avoid damage to the touchscreen:

- Aggressive solvents
- Abrasives
- Compressed air
- Steam cleaners

Operating panel

Depending on the control model, the control can still be operated through the external operating panel. Touch operation with gestures works as well.

If you have a control with integrated operating panel, the following description applies:

Integrated operating panel

The operating panel is integrated in the screen. The content of the operating panel changes depending on the current operating mode.

- **1** Area for showing the following:
 - Alphabetic keyboard
 - HEROS menu
 - Potentiometer for the speed of simulation (only in the **Test Run** operating mode)
- 2 Machine operating modes
- **3** Programming modes

The control shows the active operating mode, to which the screen is switched, with a green background.

The control shows the operating mode in the background through a small white triangle.

- **4** File manager
 - Calculator
 - MOD function
 - HELP function
 - Show error messages
- 5 Shortcut menu

Depending on the operating mode, you'll find the most important functions here at a glance.

- 6 Initiating programming dialogs (only in the **Programming** and **Positioning w/ Manual Data Input** operating modes)
- 7 Numerical input and axis selection
- 8 Navigation
- **9** Arrows and the jump statement **GOTO**
- 10 Task bar

Further information: User's Manual for **Setup, Testing and Running NC Programs**

In addition, the machine manufacturer supplies a machine operating panel.




Refer to your machine manual.

External keys, e.g. **NC START** or **NC STOP**, are described in your machine manual.

Basic operation

The following keys, for example, can easily be replaced by hand gestures:





Operating panel of the Test Run mode



Operating panel in the Manual Operation mode

16.2 Gestures

Overview of possible gestures

The screen of the control is multi-touch capable. That means that it can distinguish various gestures, including with two or more fingers at once.

Symbol	Gesture	Meaning
	Тар	A brief touch by a finger on the screen
	Double tap	Two brief touches on the screen
	Long press	Continuous contact of fingertip on the screen
		If you do not stop holding, the control will automatically cancel the holding gesture after approximately ten seconds. Permanent actuation is thus not possible.
	Swipe	Flowing motion over the screen
←		
↑ →	Drag	A combination of long-press and then swipe, moving a finger over the screen when the starting point is clearly defined
- ↑ →	Two-finger drag	A combination of long-press and then swipe, moving two fingers in parallel over the screen when the starting point is clearly defined
,••′	Spread	Two fingers long-press and move away from each other
	Pinch	Two fingers move toward each other

Navigating in the table and NC programs

You can navigate in an NC program or a table as follows:

Symbol	Gesture	Function
	Тар	Mark the NC block or table line
		Stop scrolling
	Double tap	Activate the table line
	Swipe	Scroll through the NC program or table
← →		

Operating the simulation

The control offers touch operation with the following graphics:

- Programming graphics in the **Programming** operating mode.
- 3-D view in the **Test Run** operating mode.
- 3D view in the **Program Run Single Block** operating mode.
- 3-D view in the **Program Run Full Sequence** operating mode.
- Kinematics view

Rotating, zooming, or moving a graphic

The control supports the following gestures:

Symbol	Gesture	Function		
	Double tap	Set the graphic to its original size		
† + • • • •	Drag	Rotate the graphic (only 3-D graphics)		
↑	Two-finger drag	Move graphics		
	Spread	Magnify the graphic		
• ******	Pinch	Reduce the graphic		

Measuring a graphic

If you have activated measurement in the **Test Run** operating mode, the following additional function is available:

Symbol	Gesture	Function
	Тар	Select the measuring point

Operating the CAD viewer

The control also supports touch operation for working with the **CAD-Viewer**. You have various gestures available depending on the operating mode.

To be able to use all applications, first use the icon to select the desired function:

lcon	Function
R	Default setting
4	Add
•	Works in the selection mode like a pressed Shift key
	Remove
	Works in the selection mode like a pressed CTRL key

Layer setting mode and specifying the workpiece preset

The control supports the following gestures:

Symbol	Gesture	Function
	Tap on an element	Show element information
		Specify the workpiece preset
	Double-tap on the background	Set the graphic or 3-D model to its original size
	Activate Add and double-tap on	Reset the graphic or 3-D model to its original size and
•	the background	angle
<u> </u>	Drag	Rotate the graphic or 3-D model (only in the Layer Setting mode)
←		

Symbol	Gesture	Function
+	Two-finger drag →	Move a graphic or 3-D model
	Spread	Enlarge a graphic or 3-D model
	Pinch	Reduce a graphic or 3-D model

Selecting a contour

The control supports the following gestures:

Symbol	Gesture	Function
	Tap on an element	Select element
	Tap on an element in the list- view window	Select or deselect an element
• +	Activate Add and tap on an element	Part, shorten, or lengthen an element
• -	Activate Remove and tap on an element	Deselect an element
	Double-tap on the background	Reset the graphic to its original size
<u>†</u>	Swipe over an element	Show a preview of selected elements Show element information
← → →		
←	Two-finger drag	Move graphics

Symbol	Gesture	Function	
	Spread	Magnify the graphic	
	Pinch	Reduce the graphic	

Selecting machining positions

The control supports the following gestures:

Symbol	Gesture	Function
	Tap on an element	Select element
		Select an intersection
	Double-tap on the background	Reset the graphic to its original size
	Swipe over an element	Show a preview of selected elements
<u>†</u>	5 · · · F · 5 · · 5 · · · 5 · · · · · · · · · ·	Show element information
←		
	Activate Add and drag	Spread a fast selection area
<u> </u>	•	
<u>†</u>	Activate Remove and drag	Spread an area for deselection of elements
←		
	Two-finger drag	Move graphics
← ↓ −	>	
	Spread	Magnify the graphic

Symbol	Gesture	Function	
	Pinch	Reduce the graphic	
7			

Saving elements and switching to the NC program

When you tap on the appropriate icons, the controls saves the selected elements.

You can switch back to the **Programming** operating mode in the following ways:

- Press the **Programming** key
 The control switches to the **Programming** mode of operation.
- Close the CAD-Viewer The control automatically switches to the Programming operating mode.
- Use the task bar to leave the CAD-Viewer open on the third desktop

The third desktop stays active in the background

Tables and overviews

17.1 System data

List of FN 18 functions

With the **FN 18: SYSREAD** function, you can read system data and save them to Q parameters. The selection of the system datum occurs via a group number (ID no.), a system data number, and, if necessary, an index.



The read values of the function **FN 18: SYSREAD** are always output by the control in **metric** units regardless of the NC program's unit of measure.

The following is a complete list of the **FN 18: SYSREAD** functions. Please be aware that not all functions are available depending on the model of your control.

Group name	Group number ID	System data number NO	Index IDX	Description
Program in	nformation			
	10	3	-	Number of the active machining cycle
		6	-	Number of the most recently executed touch probe cycle –1 = None
		7	-	Type of calling NC program: -1 = None 0 = Visible NC program 1 = Cycle/macro, main program is visible 2 = Cycle/macro, there is no visible main program
		8	1	Unit of measure of the directly calling NC program (may also be a cycle). Return codes: 0 = mm 1 = inch -1 = there is no corresponding program
			2	Unit of measure of the NC program visible in the block display from which the current cycle was called directly or indirectly. Return codes: 0 = mm 1 = inch -1 = there is no corresponding program
		9	-	Within an M function macro: Number of the M function. Otherwise −1
		103	Q parameter number	Relevant within NC cycles; for inquiry as to whether the Q parameter given under IDX was explicitly stated in the associated CYCLE DEF.
		110	QS parameter number	Is there a file with the name QS(IDX)? 0 = No, 1 = Yes This function resolves relative file paths.
		111	QS parameter number	Is there a directory with the name QS(IDX)? 0 = no, 1 = Yes Only absolute directory paths are possible.

Group name	Group number ID	System data number NO	Index IDX	Description
System jui	mp addresses			
	13	1	-	Label number or label name (string or QS) jumped to during M2/M30 instead of ending the current NC program. Value = 0: M2/M30 have the normal effect
		2	_	Label number or label name (string or QS) jumped to in the event of FN14: ERROR with the NC CANCEL reaction instead of aborting the NC program with an error message. The error number programmed in the FN14 command can be read under ID992 NR14. Value = 0: FN14 has the normal effect.
		3	-	Label number or label name (string or QS) jumped to in the event of an internal server error (SQL, PLC, CFG) or with erroneous file operations (FUNCTION FILECOPY, FUNCTION FILEMOVE, or FUNCTION FILEDELETE) instead of aborting the NC program with an error message. Value = 0: Error has the normal effect.
Indexed ac	cess to Q paramete	ers		
	15	11	Q parameter number	Reads Q(IDX)
		12	QL parameter no.	Reads QL(IDX)
		13	QR parameter no.	Reads QR(IDX)
Machine s	tatus			
	20	1	-	Active tool number
		2	-	Prepared tool number
		3	-	Active tool axis 0 = X 6 = U 1 = Y 7 = V 2 = Z 8 = W
		4	-	Programmed spindle speed
		5	-	Active spindle condition -1 = spindle condition not defined 0 = M3 active 1 = M4 active 2 = M5 active after M3 3 = M5 active after M4
		7	-	Active gear range
		8	-	Active coolant status 0 = off, 1 = on
		9	-	Active feed rate
		10	-	Index of prepared tool
		11	_	Index of active tool

Group name	Group number ID	System data number NO	Index IDX	Description
		14	-	Number of active spindle
		20	-	Programmed cutting speed in turning opera- tion
		21	-	Spindle mode in turning mode: 0 = constant speed 1 = constant cutting speed
		22	-	Coolant status M7: 0 = inactive, 1 = active
		23	-	Coolant status M8: 0 = inactive, 1 = active

Group name	Group number ID	System data number NO	Index IDX	Description
Channel da	ata			
	25	1	-	Channel number
Cycle para	meters			
	30	1	-	Set-up clearance
		2	-	Hole depth / milling depth
		3	-	Plunging depth
		4	-	Feed rate for plunging
		5	-	First side length of pocket
		6	-	Second side length of pocket
		7	-	First side length of slot
		8	-	Second side length of slot
		9	-	Radius of circular pocket
		10	-	Feed rate for milling
		11	-	Rotational direction of the milling path
		12	-	Dwell time
		13	-	Thread pitch for Cycles 17 and 18
		14	-	Finishing allowance
		15	-	Roughing angle
		21	-	Probing angle
		22	-	Probing path
		23	-	Probing feed rate
		48	-	Tolerance
		49	-	HSC mode (Cycle 32 Tolerance)
		50	-	Tolerance for rotary axes (Cycle 32 Tolerance)
		52	Q parameter number	Type of transfer parameter for user cycles: -1: Cycle parameter not programmed in CYCL DEF 0: Cycle parameter numerically programmed in CYCL DEF (Q parameter) 1: Cycle parameter programmed as string in CYCL DEF (Q parameter)
		60	-	Clearance height (touch probe cycles 30 to 33)
		61	-	Inspection (touch probe cycles 30 to 33)
		62	-	Cutting edge measurement (touch probe cycles 30 to 33)
		63	-	Q parameter number for the result (touch probe cycles 30 to 33)
		64	-	Q parameter type for the result (touch probe cycles 30 to 33) 1 = Q, 2 = QL, 3 = QR
		70	_	Multiplier for feed rate (cycles 17 and 18)

Group name	Group number ID	System data number NO	Index IDX	Description
Modal stat	us			
	35	1	-	Dimensions: 0 = absolute (G90) 1 = incremental (G91)
		2	-	Radius compensation: 0 = R0 1 = RR/RL 10 = Face milling 11 = Peripheral milling
ata for SC	QL tables			
	40	1	-	Result code for the last SQL command. If the last result code was 1 (=error), the error code is transferred as the return code.
ata from	the tool table			
	50	1	Tool no.	Tool length L
		2	Tool no.	Tool radius R
		3	Tool no.	Tool radius R2
		4	Tool no.	Oversize for tool length DL
		5	Tool no.	Tool radius oversize DR
		6	Tool no.	Tool radius oversize DR2
		7	Tool no.	Tool locked TL 0 = not locked, 1 = locked
		8	Tool no.	Number of the replacement tool RT
		9	Tool no.	Maximum tool age TIME1
		10	Tool no.	Maximum tool age TIME2
		11	Tool no.	Current tool age CUR.TIME
		12	Tool no.	PLC status
		13	Tool no.	Maximum tooth length LCUTS
		14	Tool no.	Maximum plunge angle ANGLE
		15	Tool no.	TT: Number of tool teeth CUT
		16	Tool no.	TT: Wear tolerance for length, LTOL
		17	Tool no.	TT: Wear tolerance for radius, RTOL
		18	Tool no.	TT: Direction of rotation DIRECT 0 = positive, -1 = negative
		19	Tool no.	TT: Offset in plane R-OFFS R = 99999.9999
		20	Tool no.	TT: Offset in length L-OFFS
		21	Tool no.	TT: Breakage tolerance for length, LBREAK
		22	Tool no.	TT: Breakage tolerance for radius, RBREAK
		28	Tool no.	Maximum speed NMAX
		32	Tool no.	Point angle TANGLE

Group name	Group number ID	System data number NO	Index IDX	Description
		34	Tool no.	LIFTOFF allowed (0 = No, 1 = Yes)
		35	Tool no.	Wear tolerance for radius R2TOL
		36	Tool no.	Tool type TYPE (miller = 0, grinder = 1, touch probe = 21)
		37	Tool no.	Corresponding line in the touch-probe table
		38	Tool no.	Timestamp of last use
		39	Tool no.	ACC
		40	Tool no.	Pitch for thread cycles
		41	Tool no.	AFC: reference load
		42	Tool no.	AFC: overload early warning
		43	Tool no.	AFC: overload NC stop
		44	Tool no.	Exceeding the tool life
		45	Tool no.	Front-face width of indexable insert (RCUTS)
		46	Tool no.	Usable length of the milling cutter
		47	Tool no.	Neck radius of the milling cutter (RN)

Group name	Group number ID	System data number NO	Index IDX	Description
Data from	the pocket table			
	51	1	Pocket number	Tool number
		2	Pocket number	0 = no special tool 1 = special tool
		3	Pocket number	0 = no fixed pocket 1 = fixed pocket
		4	Pocket number	0 = pocket not locked 1 = pocket locked
		5	Pocket number	PLC status
Determine	the tool pocket			
	52	1	Tool no.	Pocket number
		2	Tool no.	Tool magazine number
File inform	ation			
	56	1	-	Number of lines of the tool table
		2	-	Number of lines of the active datum table
		4	-	Number of lines in a freely definable table that has been opened with FN26: TABOPEN
Tool data f	or T and S strobes			
	57	1	T code	Tool number IDX0 = T0 strobe (store tool), IDX1 = T1 strobe (load tool), IDX2 = T2 strobe (prepare tool)
		2	T code	Tool index IDX0 = T0 strobe (store tool), IDX1 = T1 strobe (load tool), IDX2 = T2 strobe (prepare tool)
		5	-	Spindle speed IDX0 = T0 strobe (store tool), IDX1 = T1 strobe (load tool), IDX2 = T2 strobe (prepare tool)
Values pro	grammed in TOOL	CALL		
	60	1	-	Tool number T
		2	-	Active tool axis 0 = X 1 = Y 2 = Z 6 = U 7 = V 8 = W
		3	-	Spindle speed S
		4	-	Oversize for tool length DL
		5		Tool radius oversize DR
		6	-	Automatic TOOL CALL 0 = Yes, 1 = No
		7	-	Tool radius oversize DR2
		8	-	Tool index
		9		Active feed rate

Group name	Group number ID	System data number NO	Index IDX	Description
		10	-	Cutting speed [mm/min]
Values pro	grammed in TOOL I	DEF		
	61	0	Tool no.	Read the number of the tool change sequence: 0 = Tool already in spindle, 1 = Change between external tools, 2 = Change from internal to external tool, 3 = Change from special tool to external tool, 4 = Load external tool, 5 = Change from external to internal tool, 6 = Change from internal to internal tool, 7 = Change from special tool to internal tool, 8 = Load internal tool, 9 = Change from external tool to special tool, 10 = Change from special tool to internal tool, 11 = Change from special tool to special tool, 12 = Load special tool, 13 = Unload external tool, 14 = Unload internal tool, 15 = Unload special tool
		1	-	Tool number T
		2	-	Length
		3	-	Radius
		4	-	Index
		5	-	Tool data programmed in TOOL DEF 1 = Yes, 0 = No

Group name	Group number ID	System data number NO	Index IDX	Description
Values pro	ogrammed with FUN	CTION TURNDAT	-A	
	62	1	-	Tool length oversize DXL
		2	-	Tool length oversize DYL
		3	-	Tool length oversize DZL
		4	-	Cutting radius oversize DRS
/alues for	LAC and VSC			
	71	0	0	Index of the NC axis for which the LAC weighing run will be performed or was last performed (X to W = 1 to 9)
			2	Total inertia determined by the LAC weighing run in [kgm²] (with A/B/C rotary axes) or total mass in [kg] (with X/Y/Z linear axes)
		1	0	Cycle 957 Retraction from thread
nformatio	on about HEIDENHAI	N cycles		
	71	20	0	Configuration information for dressing: (CfgDressSettings) Maximum search path / set-up clearance
			1	Configuration information for dressing: (CfgDressSettings) Search speed (with acoustic emission sensor
			2	Configuration information for dressing: (CfgDressSettings) Feed-rate factor (contact-free motion)
			3	Configuration information for dressing: (CfgDressSettings) Feed-rate factor at wheel side
			4	Configuration information for dressing: (CfgDressSettings) Feed-rate factor at wheel radius
			5	Tool information for dressing: (toolgrind.grd) Set-up clearance in Z (inside)
			6	Tool information for dressing: (toolgrind.grd) Set-up clearance in Z (outside)
			7	Machining information for dressing: Set-up clearance in X (diameter)
			8	Machining information for dressing: Ratio of cutting speed
			9	Machining information for dressing: Programmed number of dressing tool
			10	Machining information for dressing: Programmed number of dressing kinematics
			11	Machining information for dressing: TCPM active/inactive

Group name	Group number ID	System data number NO	Index IDX	Description
			12	Machining information for dressing: Programmed position of rotary axis
			13	Machining information for dressing: Cutting speed of the grinding wheel
			14	Machining information for dressing: Rotational speed of dressing spindle
			15	Machining information for dressing: Magazine number of dresser
			16	Machining information for dressing: Pocket number of dresser
		21	0	Configuration information for grinding: (CfgGrindSettings) Infeed velocity (synchronous reciprocation)
			1	Configuration information for grinding: (CfgGrindSettings) Search speed (with acoustic emission sensor)
			2	Configuration information for grinding: (CfgGrindSettings) Relief amount
			3	Configuration information for grinding: (CfgGrindSettings) Dimensional control offset
		22	0	Configuration information for behavior when the sensor has not responded. (CfgGrindEvents/sensorNotReached) IDX: Sensor
		23	0	Configuration information for behavior when the sensor is already active at the start. (CfgGrindEvents/sensorActiveAtStart) IDX: Sensor
		24	1	Configuration information for the event additionally used by a sensor function: (CfgGrindEvents/sensorSource2) Sensor function = Infeed with touch probe
			2	Configuration information for the event additionally used by a sensor function: (CfgGrindEvents/sensorSource2) Sensor function = Infeed with acoustic emission sensor
			3	Configuration information for the event additionally used by a sensor function: (CfgGrindEvents/sensorSource2) Sensor function = Infeed with dimensional control
			9	Configuration information for the event additionally used by a sensor function: (CfgGrindEvents/sensorSource2) Sensor function = OEM-specific interaction 1

Group name	Group number ID	System data number NO	Index IDX	Description
			10	Configuration information for the event additionally used by a sensor function: (CfgGrindEvents/sensorSource2) Sensor function = OEM-specific interaction 2
			11	Configuration information for the event additionally used by a sensor function: (CfgGrindEvents/sensorSource2) Sensor function = Intermediate dressing
			12	Configuration information for the event additionally used by a sensor function: (CfgGrindEvents/sensorSource2) Sensor function = Teach button
		25	1	Configuration information for the relief amount of a sensor function (CfgGrindEvents/sensorReleave) Sensor function = Infeed with touch probe
			2	Configuration information for the relief amount of a sensor function (CfgGrindEvents/sensorReleave) Sensor function = Infeed with acoustic emission sensor
			3	Configuration information for the relief amount of a sensor function (CfgGrindEvents/sensorReleave) Sensor function = Infeed with dimensional control
			9	Configuration information for the relief amount of a sensor function (CfgGrindEvents/sensorReleave) Sensor function = OEM-specific interaction 1
			10	Configuration information for the relief amount of a sensor function (CfgGrindEvents/sensorReleave) Sensor function = OEM-specific interaction 2
			11	Configuration information for the relief amount of a sensor function (CfgGrindEvents/sensorReleave) Sensor function = Intermediate dressing
			12	Configuration information for the relief amount of a sensor function (CfgGrindEvents/sensorReleave) Sensor function = Teach button
		26	1	Configuration information for the type of reaction to an event of a sensor function (CfgGrindEvents/sensorReaction) Sensor function = Infeed with touch probe

Group name	Group number ID	System data number NO	Index IDX	Description
			2	Configuration information for the type of reaction to an event of a sensor function (CfgGrindEvents/sensorReaction) Sensor function = Infeed with acoustic emission sensor
			3	Configuration information for the type of reaction to an event of a sensor function (CfgGrindEvents/sensorReaction) Sensor function = Infeed with dimensional control
			9	Configuration information for the type of reaction to an event of a sensor function (CfgGrindEvents/sensorReaction) Sensor function = OEM-specific interaction 1
			10	Configuration information for the type of reaction to an event of a sensor function (CfgGrindEvents/sensorReaction) Sensor function = OEM-specific interaction 2
			11	Configuration information for the type of reaction to an event of a sensor function (CfgGrindEvents/sensorReaction) Sensor function = Intermediate dressing
			12	Configuration information for the type of reaction to an event of a sensor function (CfgGrindEvents/sensorReaction) Sensor function = Teach button
		27	1	Configuration information for the event additionally used by a sensor function (CfgGrindEvents/sensorSource) Sensor function = Infeed with touch probe
			2	Configuration information for the event additionally used by a sensor function (CfgGrindEvents/sensorSource) Sensor function = Infeed with acoustic emission sensor
			3	Configuration information for the event additionally used by a sensor function (CfgGrindEvents/sensorSource) Sensor function = Infeed with dimensional control
			9	Configuration information for the event additionally used by a sensor function (CfgGrindEvents/sensorSource) Sensor function = OEM-specific interaction 1
			10	Configuration information for the event additionally used by a sensor function: (CfgGrindEvents/sensorSource) Sensor function = OEM-specific interaction 2

Group name	Group number ID	System data number NO	Index IDX	Description
			11	Configuration information for the event additionally used by a sensor function (CfgGrindEvents/sensorSource) Sensor function = Intermediate dressing
			12	Configuration information for the event additionally used by a sensor function (CfgGrindEvents/sensorSource) Sensor function = Teach button
		28	0	Configuration information for the assignment of override sources to grinding functions: (CfgGrindOverrides) Cylindrical grinding: override source for reciprocating movement
			1	Configuration information for the assignment of override sources to grinding functions: (CfgGrindOverrides) Cylindrical grinding: override source for infeed movement
			2	Configuration information for the assignment of override sources to grinding functions: (CfgGrindOverrides) Surface grinding: override source for reciprocating movement
			3	Configuration information for the assignment of override sources to grinding functions: (CfgGrindOverrides) Surface grinding: override source for infeed movement
			4	Configuration information for the assignment of override sources to grinding functions: (CfgGrindOverrides) Special grinding: override source for reciprocating movement
			5	Configuration information for the assignment of override sources to grinding functions: (CfgGrindOverrides) Special grinding: override source for infeed movement
			6	Configuration information for the assignment of override sources to grinding functions: (CfgGrindOverrides) Jig grinding (reciprocating stroke)
			7	Configuration information for the assignment of override sources to grinding functions: (CfgGrindOverrides) General movements in the infeed generator (example: general movement with/without sensor)

Group name	Group number ID	System data number NO	Index IDX	Description
			8	Configuration information for the assignment of override sources to grinding functions: (CfgGrindOverrides) General movements in the infeed generator (example: movement with acoustic emission sensor)
			9	Configuration information for the assignment of override sources to grinding functions: (CfgGrindOverrides) General movements in the infeed generator (example: movement with touch probe)

Group name	Group number ID	System data number NO	Index IDX	Description
Freely ava	ilable memory area	for OEM cycles		
	72	0-39	0 to 30	Freely available memory area for OEM cycles. The values are only reset by the control during a control reboot (= 0). With "Cancel," the values are not reset to the value that they had at the time of execution. Up to and including 597110-11: only NR 0-9 and IDX 0-9 Starting with 597110-12: NR 0-39 and IDX 0-30
Freely ava	ilable memory area	for user cycles		
	73	0-39	0 to 30	Freely available memory area for user cycles The values are only reset by the control during a control reboot (= 0). With "Cancel," the values are not reset to the value that they had at the time of execution. Up to and including 597110-11: only NR 0-9 and IDX 0-9 Starting with 597110-12: NR 0-39 and IDX 0-30
Read mini	mum and maximum	spindle speed		
	90	1	Spindle ID	Minimum spindle speed of the lowest gear stage. If no gear stages are configured, CfgFeedLimits/minFeed of the first parameter set of the spindle is evaluated. Index 99 = active spindle
		2	Spindle ID	Maximum spindle speed from the highest gear stage. If no gear stages are configured, CfgFeedLimits/maxFeed of the first parameter set of the spindle is evaluated. Index 99 = active spindle
Tool comp	ensation			
	200	1	1 = without oversize 2 = with oversize 3 = with oversize and oversize from TOOL CALL	Active radius
		2	1 = without oversize 2 = with oversize 3 = with oversize and oversize from TOOL CALL	Active length
		3	1 = without oversize 2 = with oversize 3 = with oversize	Rounding radius R2

Group name	Group number ID	System data number NO	Index IDX	Description
			and oversize from TOOL CALL	
		6	Tool no.	Tool length Index 0= active tool
Coordinate	e transformations			
	210	1	-	Basic rotation (manual)
		2	_	Programmed rotation
		3	-	Active mirror axis. Bits 0 to 2 and 6 to 8: Axes X, Y, Z and U, V, W
		4	Axis	Active scaling factor Index: 1 - 9 (X, Y, Z, A, B, C, U, V, W)
		5	Rotary axis	3D-ROT Index: 1 - 3 (A, B, C)
		6	-	Tilt working plane in Program Run operating modes 0 = Not active -1 = Active
		7	-	Tilt working plane in Manual operating modes 0 = Not active -1 = Active
		8	QL parameter no.	Angle of misalignment between spindle and tilted coordinate system. Projects the angle specified in the QL parameter from the input coordinate system to the tool coordinate system. If IDX is omitted, the angle 0 is used for projection.
		10	-	Type of definition of the active tilt: 0 = no tilt—is returned if, both in Manual Operation and in the automatic modes, no tilt is active. 1 = axial 2 = spatial angle
		11	-	Coordinate system for manual movements: 0 = Machine coordinate system M-CS 1 = Working plane coordinate system WPL-CS 2 = Tool coordinate system T-CS 4 = Workpiece coordinate system W-CS
		12	Axis	Correction in working plane coordinate system WPL-CS (FUNCTION TURNDATA CORR WPL or FUNCTION CORRDATA WPL) Index: 1 to 9 (X, Y, Z, A, B, C, U, V, W)

Group name	Group number ID	System data number NO	Index IDX	Description
Active cod	ordinate system			
	211	_	-	1 = input system (default) 2 = REF system 3 = tool change system
Special tra	ansformations in tur	ning mode		
	215	1	- 	Angle for the precession of the input system in the XY plane in turning mode. To reset the transformation the value 0 must be entered for the angle. This transformation is used in connection with Cycle 800 (parameter Q497).
		3	1-3	Reading out of the spatial angle written with NR2 Index: 1 - 3 (rotA, rotB, rotC)
Current da	atum shift			
	220	2	Axis	Current datum shift in [mm] Index: 1 - 9 (X, Y, Z, A, B, C, U, V, W)
		3	Axis	Read the difference between reference point and preset. Index: 1 - 9 (X, Y, Z, A, B, C, U, V, W)
		4	Axis	Read values for OEM offset. Index: 1 - 9 (X_OFFS, Y_OFFS, Z_OFFS,)
Traverse r	ange			
	230	2	Axis	Negative software limit switches Index: 1 - 9 (X, Y, Z, A, B, C, U, V, W)
		3	Axis	Positive software limit switches Index: 1 - 9 (X, Y, Z, A, B, C, U, V, W)
		5		Software limit switch on or off: 0 = on, 1 = off For modulo axes, either both the upper and lower limits or no limit at all must be set.
Read the r	nominal position in t	he REF system		
	240	1	Axis	Current nominal position in the REF system
Read the r	nominal position in t	he REF system, i	ncluding offsets ((handwheel, etc.)
	241	1	Axis	Current nominal position in the REF system
Read the c	current position in th	ne active coordina	ate system	
	270	1	Axis	Current nominal position in the input system When called while tool radius compensation is active, the function supplies the uncompensated positions for the principal axes X, Y, and Z. If the function is called for a rotary axis and tool radius compensation is active, an error message is issued. Index: 1 to 9 (X, Y, Z, A, B, C, U, V, W)
Read the c	current position in th	ne active coordina	ate system, inclu	ding offsets (handwheel, etc.)
	271	1	Axis	Current nominal position in the input system

Group name	Group number ID	System data number NO	Index IDX	Description
Read infor	mation to M128			
	280	1	-	M128 active: -1 = Yes, 0 = No
		3	-	Condition of TCPM after Q No.: Q No. + 0: TCPM active, 0 = no, 1 = yes Q No. + 1: AXIS, 0 = POS, 1 = SPAT Q No. + 2: PATHCTRL, 0 = AXIS, 1 = VECTOR Q No. + 3: Feed rate, 0 = F TCP, 1 = F CONT
/lachine k	inematics			
	290	5	-	0: Temperature compensation not active 1: Temperature compensation active
		10	-	Index of the machine kinematics from Channels/ChannelSettings/CfgKin-List/kinCompositeModels programmed in FUNCTION MODE MILL or FUNCTION MODE TURN -1 = Not programmed.
ead data	of the machine kine	ematics		
	295	1	QS parameter no.	Read the axis names of the active 3-axis kinematics. The axis names are written according to QS(IDX), QS(IDX+1), and QS(IDX+2). 0 = Operation successful
		2	0	Is FACING HEAD POS function active? 1 = Yes, 0 = No
		4	Rotary axis	Read whether the defined rotary axis participates in the kinematic calculation. 1 = Yes, 0 = No (A rotary axis can be excluded from the kinematics calculating using M138.) Index: 4, 5, 6 (A, B, C)
		5	Secondary axis	Read whether the given secondary axis is used in the kinematics model. -1 = Axis not in the kinematics model 0 = Axis is not included in the kinematics calculation:
		6	Axis	Angle head: Displacement vector in the basic coordinate system B-CS through angle head Index: 1, 2, 3 (X, Y, Z)
		7	Axis	Angle head: Direction vector of the tool in the basic coordinate system B-CS Index: 1, 2, 3 (X, Y, Z)
		10	Axis	Determine programmable axes. Determine the axis ID associated with the specified axis index (index from CfgAxis/axisList). Index: 1 - 9 (X, Y, Z, A, B, C, U, V, W)

Group name	Group number ID	System data number NO	Index IDX	Description
		11	Axis ID	Determine programmable axes. Determine the index of the axis (X = 1, Y = 2,) for the specified axis ID Index: Axis ID (index from CfgAxis/axisList)

-	Group number ID	System data number NO	Index IDX	Description
Modify the ged	ometrical behavi	ior		
	310	20	Axis	Diameter programming: –1 = on, 0 = off
		126	-	M126: –1 = on, 0 = off
Current system	n time			
	320	1	0	System time in seconds that have elapsed since 01.01.1970, 00:00:00 (real time).
			1	System time in seconds that have elapsed since 01.01.1970, 00:00:00 (look-ahead calculation).
		3	-	Read the processing time of the current NC program.
ormatting of	system time			
	321	0	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: DD.MM.YYYY hh:mm:ss
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: DD.MM.YYYY hh:mm:ss
		1	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: D.MM.YYYY h:mm:ss
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: D.MM.YYYY h:mm:ss
		2	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: D.MM.YYYY h:mm
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: D.MM.YYYY h:mm
		3	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: D.MM.YY h:mm
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: D.MM.YY h:mm
		4	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: YYYY-MM-DD hh:mm:ss
M2				TOTAL TELEVISION DO HILITHILOS

Group name	Group number ID	System data number NO	Index IDX	Description
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: YYYY-MM-DD hh:mm:ss
		5	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: YYYY-MM-DD hh:mm
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: YYYY-MM-DD hh:mm
		6	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: YYYY-MM-DD h:mm
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: YYYY-MM-DD h:mm
		7	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: YY-MM-DD h:mm
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: YY-MM-DD h:mm
		8	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: DD.MM.YYYY
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: DD.MM.YYYY
		9	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: D.MM.YYYY
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: D.MM.YYYY
		10	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: D.MM.YY

Group name	Group number ID	System data number NO	Index IDX	Description
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: D.MM.YY
		11	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: YYYY-MM-DD
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: YYYY-MM-DD
		12	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: YY-MM-DD
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: YY-MM-DD
		13	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: hh:mm:ss
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: hh:mm:ss
		14	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: h:mm:ss
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: h:mm:ss
		15	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: h:mm
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: h:mm
		16	0	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (real time) Format: DD.MM.YYYY hh:mm

Group name	Group number ID	System data number NO	Index IDX	Description
			1	Formatting of: System time in seconds that have elapsed since 00:00:00 UTC on January 1, 1970 (look-ahead calculation) Format: DD.MM.YYYY hh:mm
		20	0	The current calendar week number according to ISO 8601 (real time)
			1	The current calendar week number according to ISO 8601 (look-ahead calculation)
Global Pro	gram Settings (GPS	s): Global activation	on status	
	330	0	-	0 = No GPS setting is active 1 = Any GPS setting is active
Global Pro	gram Settings (GPS	S): Individual activ	ation status	
	331	0	-	0 = No GPS setting is active 1 = Any GPS setting is active
		1	-	GPS: Basic rotation 0 = Off, 1 = On
		3	Axis	GPS: Mirroring 0 = Off, 1 = On Index: 1 - 6 (X, Y, Z, A, B, C)
		4	-	GPS: Shift in the modified workpiece system 0 = Off, 1 = On
		5	-	GPS: Rotation in input system 0 = Off, 1 = On
		6	-	GPS: Feed rate factor 0 = Off, 1 = On
		8	-	GPS: Handwheel superimpositioning 0 = Off, 1 = On
		10	-	GPS: Virtual tool axis VT 0 = Off, 1 = On
		15	-	GPS: Selection of the handwheel coordinate system 0 = Machine coordinate system M-CS 1 = Workpiece coordinate system W-CS 2 = Modified workpiece coordinate system mW-CS 3 = Working plane coordinate system WPL-CS
		16	-	GPS: Shift in the workpiece system 0 = Off, 1 = On
		17	-	GPS: Axis offset 0 = Off, 1 = On

Group name	Group number ID	System data number NO	Index IDX	Description
Global Prog	gram Settings (GPS	;)		
	332	1	-	GPS: Angle of a basic rotation
		3	Axis	GPS: Mirroring 0 = Not mirrored, 1 = Mirrored Index: 1 - 6 (X, Y, Z, A, B, C)
		4	Axis	GPS: Shift in the modified workpiece coordinate system mW-CS Index: 1 - 6 (X, Y, Z, A, B, C)
		5	-	GPS: Angle of rotation in input coordinate system I-CS
		6	-	GPS: Feed rate factor
		8	Axis	GPS: Handwheel superimpositioning Maximum value Index: 1 - 10 (X, Y, Z, A, B, C, U, V, W, VT)
		9	Axis	GPS: Value for handwheel superimpositioning Index: 1 - 10 (X, Y, Z, A, B, C, U, V, W, VT)
		16	Axis	GPS: Shift in the workpiece coordinate system W-CS Index: 1 - 3 (X, Y, Z)
		17	Axis	GPS: Axis offset Index: 4 - 6 (A, B, C)
TS touch tr	igger probe			
	350	50	1	Touch probe type: 0: TS120, 1: TS220, 2: TS440, 3: TS630, 4: TS632, 5: TS640, 6: TS444, 7: TS740
			2	Line in the touch-probe table
		51	-	Effective length
		52	1	Effective radius of the stylus tip
			2	Rounding radius
		53	1	Center offset (reference axis)
			2	Center offset (minor axis)
		54	-	Spindle-orientation angle in degrees (center offset)
		55	1	Rapid traverse
			2	Measuring feed rate
			3	Feed rate for pre-positioning: FMAX_PROBE or FMAX_MACHINE
		56	1	Maximum measuring range
			2	Set-up clearance
		57	1	Spindle orientation possible 0=No, 1=Yes
			2	Angle of spindle orientation in degrees

Group name	Group number ID	System data number NO	Index IDX	Description
TT tool tou	ıch probe for tool m	easurement		
	350	70	1	TT: Touch probe type
			2	TT: Line in the tool touch probe table
			3	TT: Designation of the active line in the touch- probe table
			4	TT: Touch probe input
		71	1/2/3	TT: Touch probe center (REF system)
		72	-	TT: Touch probe radius
		75	1	TT: Rapid traverse
			2	TT: Measuring feed rate with stationary spindle
			3	TT: Measuring feed rate with rotating spindle
		76	1	TT: Maximum probing path
			2	TT: Safety clearance for linear measurement
			3	TT: Safety clearance for radius measurement
			4	TT: Distance from the lower edge of the cutter to the upper edge of the stylus
		77	-	TT: Spindle speed
		78	_	TT: Probing direction
		79	-	TT: Activate radio transmission
			-	TT: Stop probing movement upon stylus deflection
		100	-	Distance after which the probe is deflected during touch probe simulation

Group name	Group number ID	System data number NO	Index IDX	Description
Preset fro	m touch probe cycle	(probing results)		
	360	1	Coordinate	Last preset of a manual touch probe cycle, or last touch point from Cycle 0 (input coordinate system). Compensations: length, radius, and center offset
		2	Axis	Last preset of a manual touch probe cycle, or last touch point from Cycle 0 (machine coordinate system, only axes from the active 3D kinematics are allowed as index). Compensation: only center offset
		3	Coordinate	Result of measurement in the input system of touch probe Cycles 0 and 1. The measurement result is read out in the form of coordinates. Compensation: only center offset
		4	Coordinate	Last preset of a manual touch probe cycle, or last touch point from Cycle 0 (workpiece coordinate system). The measurement result is read in the form of coordinates. Compensation: only center offset
		5	Axis	Axis values, not compensated
		6	Coordinate / axis	Readout of the measurement results in the form of coordinates / axis values in the input system from probing operations. Compensation: only length
		10	-	Oriented spindle stop
		11	-	Error status of probing: 0: Probing was successful -1: Touch point not reached -2: Touch probe already deflected at the start of the probing process

Group name	Group number ID	System data number NO	Index IDX	Description
Settings fo	or touch probe cycle	s		
	370	2	-	Rapid traverse for measurement
		3	-	Machine rapid traverse as rapid traverse for measurement
		5	-	Angle tracking on/off
		6	-	Automatic measuring cycles: interruption with info about on/off
Read value	es from or write valu	es to the active o	datum table	
	500	Row number	Column	Read values
Read value	es from or write valu	es to the preset	table (basic trans	formation)
	507	Row number	1-6	Read values
Read axis	offsets from or write	e axis offsets to t	the preset table	
	508	Row number	1-9	Read values
Data for pa	allet machining			
	510	1	-	Active line
		2	-	Current pallet number. Read value of the NAME column of the last PAL-type entry. If the column is empty or does not contain a numerical value, a value of -1 is returned.
		3	-	Active row of the pallet table.
		4	-	Last line of the NC program for the current pallet.
		5	Axis	Tool-oriented editing: Clearance height is programmed: 0 = No, 1 = Yes Index: 1 - 9 (X, Y, Z, A, B, C, U, V, W)
		6	Axis	Tool-oriented editing: Clearance height The value is invalid if ID510 NR5 returns the value 0 with the corresponding IDX. Index: 1 - 9 (X, Y, Z, A, B, C, U, V, W)
		10	-	Row number up to which the pallet table is to be searched during block scan.
		20	-	Type of pallet editing? 0 = Workpiece-oriented 1 = Tool oriented
		21	-	Automatic continuation after NC error: 0 = Locked 1 = Active 10 = Abort continuation 11 = Continuation with the rows in the pallet table that would have been executed next if not for the NC error 12 = Continuation with the row in the pallet table in which the NC error arose 13 = Continuation with the next pallet

Group name	Group number ID	System data number NO	Index IDX	Description
Read data	from the point table	•		
	520	Row number	10	Read value from active point table.
			11	Read value from active point table.
			1-3 X/Y/Z	Read value from active point table.
Read or wr	ite the active prese	t		
	530	1	-	Number of the active preset in the active preset table.
Active pall	et preset			
	540	1	-	Number of the active pallet preset. Returns the number of the active preset. If no pallet preset is active, the function returns the value –1.
		2	-	Number of the active pallet preset. As with NR1.
Values for	the basic transform	nation of the palle	et preset	
	547	Row number	Axis	Read values of the basic transformation from the pallet preset table. Index: 1 to 6 (X, Y, Z, SPA, SPB, SPC)
Axis offset	ts from the pallet pr	eset table		
	548	Row number	Offset	Read values of the axis offsets from the palle preset table. Index: 1 - 9 (X_OFFS, Y_OFFS, Z_OFFS,)
OEM offse	t			
	558	Row number	Offset	Read values for OEM offset. Index: 1 - 9 (X_OFFS, Y_OFFS, Z_OFFS,)
Read and v	vrite the machine st	tatus		
	590	2	1-30	Freely available; not deleted during program selection.
		3	1-30	Freely available; not deleted during a power failure (persistent storage).
Read/write	look-ahead parame	eter of a single a	xis (at machine le	evel)
	610	1	-	Minimum feed rate (MP_minPathFeed) in mm/min
		2	-	Minimum feed rate at corners (MP_min- CornerFeed) in mm/min
		3	-	Feed-rate limit for high speeds (MP_maxG1Feed) in mm/min
		4	-	Max. jerk at low speeds (MP_maxPathJerk) in m/s^3
		5	-	Max. jerk at high speeds (MP_maxPath- JerkHi) in m/s ³
		6	-	Tolerance at low speeds (MP_pathTolerance in mm

Group name	Group number ID	System data number NO	Index IDX	Description
		7	-	Tolerance at high speeds (MP_pathToler-anceHi) in mm
		8	-	Max. derivative of jerk (MP_maxPathYank) in m/s ⁴
		9	-	Tolerance factor for curve machining (MP_curveTolFactor)
		10	-	Factor for max. permissible jerk at curvature changes (MP_curveJerkFactor)
		11	-	Maximum jerk with probing movements (MP_pathMeasJerk)
		12	-	Angle tolerance for machining feed rate (MP_angleTolerance)
		13	-	Angle tolerance for rapid traverse (MP_angle-ToleranceHi)
		14	-	Max. corner angle for polygons (MP_max-PolyAngle)
		18	-	Radial acceleration with machining feed rate (MP_maxTransAcc)
		19	-	Radial acceleration with rapid traverse (MP_maxTransAccHi)
		20	Index of physical axis	Max. feed rate (MP_maxFeed) in mm/min
		21	Index of physical axis	Max. acceleration (MP_maxAcceleration) in m/s ²
		22	Index of physical axis	Maximum transition jerk of the axis in rapid traverse (MP_axTransJerkHi) in m/s ²
		23	Index of physical axis	Maximum transition jerk of the axis during machining free rate (MP_axTransJerk) in m/s ³
		24	Index of physical axis	Acceleration feedforward control (MP_com- pAcc)
		25	Index of physi- cal axis	Axis-specific jerk at low speeds (MP_axPath-Jerk) in m/s ³
		26	Index of physi- cal axis	Axis-specific jerk at high speeds (MP_axPath-JerkHi) in m/s ³
		27	Index of physical axis	More precise tolerance examination in corners (MP_reduceCornerFeed) 0 = deactivated, 1 = activated
		28	Index of physical axis	DCM: Maximum tolerance for linear axes in mm (MP_maxLinearTolerance)
		29	Index of physical axis	DCM: Maximum angle tolerance in [°] (MP_maxAngleTolerance)
		30	Index of physical axis	Tolerance monitoring for successive threads (MP_threadTolerance)

Group name	Group number ID	System data number NO	Index IDX	Description
		31	Index of physical axis	Form (MP_shape) of the axisCutterLoc filter 0: Off 1: Average 2: Triangle 3: HSC 4: Advanced HSC
		32	Index of physical axis	Frequency (MP_frequency) of the axisCutter-Loc filter in Hz
		33	Index of physical axis	Form (MP_shape) of the axisPosition filter 0: Off 1: Average 2: Triangle 3: HSC 4: Advanced HSC
		34	Index of physi- cal axis	Frequency (MP_frequency) of the axisPosition filter in Hz
		35	Index of physi- cal axis	Order of the filter for Manual operating mode (MP_manualFilterOrder)
		36	Index of physi- cal axis	HSC mode (MP_hscMode) of the axisCutter- Loc filter
		37	Index of physi- cal axis	HSC mode (MP_hscMode) of the axisPosition filter
		38	Index of physi- cal axis	Axis-specific jerk for probing movements (MP_axMeasJerk)
		39	Index of physi- cal axis	Weighting of the filter error for calculating filter deviation (MP_axFilterErrWeight)
		40	Index of physical axis	Maximum filter length of position filter (MP_maxHscOrder)
		41	Index of physical axis	Maximum filter length of CLP filter (MP_maxHscOrder)
		42	-	Maximum feed rate of the axis at machining feed rate (MP_maxWorkFeed)
		43	-	Maximum path acceleration at machining feed rate (MP_maxPathAcc)
		44	-	Maximum path acceleration at rapid traverse (MP_maxPathAccHi)
		45	-	Shape of the smoothing filter (CfgSmoothingFilter/shape) 0 = Off 1 = Average 2 = Triangle
		46	-	Order of smoothing filter (only odd-numbered values) (CfgSmoothingFilter/order)

Group name	Group number ID	System data number NO	Index IDX	Description
		47	-	Type of acceleration profile (CfgLaPath/profileType) 0 = Bellshaped 1 = Trapezoidal 2 = Advanced Trapezoidal
		48	-	Type of acceleration profile for rapid traverse (CfgLaPath/profileTypeHi) 0 = Bellshaped 1 = Trapezoidal 2 = Advanced Trapezoidal
		49	-	Filter reduction mode (CfgPositionFilter/timeGainAtStop) 0 = Off 1 = NoOvershoot 2 = FullReduction
		51	Index of physical axis	Compensation of following error in the jerk phase (MP_lpcJerkFact)
		52	Index of physical axis	kv factor of the position controller in 1/s (MP_kvFactor)

Group name	Group number ID	System data number NO	Index IDX	Description
Read or wr	ite look-ahead para	meters of a singl	e axis (at cycle lev	el)
	613	see ID610	see ID610	Same as ID610 but is only effective at the cycle level. Overwrite values from the machine configuration and values at the machine level. Further information: "FN functions ID610, ID611, ID613", Page
Measure th	ne maximum utilizat	tion of an axis		
	621	0	Index of physical axis	Conclude measurement of the dynamic load and save the result in the specified Q parameter.
Read SIK c	ontents			
	630	0	Option no.	You can explicitly determine whether the SIK option given under IDX has been set or not. 1 = option is enabled 0 = option is not enabled
		1	-	You can determine whether a Feature Content Level (for upgrade functions) is set, and which one. -1 = No FCL is set <no.> = FCL that is set</no.>
		2	-	Read serial number of the SIK -1 = No valid SIK in the system
		10	-	Define the type of control: 0 = iTNC 530 1 = NCK-based control (TNC7, TNC 640, TNC 620, TNC 320, TNC 128, PNC 610,)
General da	ta of the grinding w	heel		
	780	2	-	Width
		3	-	Overhang
		4	-	Alpha angle (optional)
		5	-	Gamma angle (optional)
		6	_	Depth (optional)
		7	-	Rounding radius at the "Further" edge (optional)
		8	-	Rounding radius at the "Nearer" edge (optional)
		9	-	Rounding radius at the "Nearest" edge (optional)
		10	-	Active edge:
		11	-	Type of grinding wheel (straight / angular)
		12	-	External or internal wheel?
		13	-	Compensation angle of the B axis (with respect to the base angle of the location)
		14	-	Type of angular wheel
		15	-	Total length of the grinding wheel

Group name	Group number ID	System data number NO	Index IDX	Description
		16	-	Length of the inner edge of the grinding whee
		17	-	Minimum wheel diameter (wear limit)
		18	-	Minimum wheel width (wear limit)
		19	-	Tool number
		20	-	Cutting speed
		21	-	Maximum permissible cutting speed
		27	-	Wheel basic type: with relief cut
		28	-	Relief cut on the outside
		29	-	Relief cut on the inside
		30	-	Definition status
		31	-	Radius compensation
		32	-	Compensation of total length
		33	-	Compensation of overhang
		34	-	Compensation for the length to the innermos edge
		35	-	Radius of the shaft of the grinding wheel
		36	-	Initial dressing performed?
		37	-	Dresser location for initial dressing
		38	-	Dresser tool for initial dressing
		39	-	Has the grinding wheel been measured?
		51	-	Dresser tool for dressing on the diameter
		52	-	Dresser tool for dressing on the outer edge
		53	-	Dresser tool for dressing on the inner edge
		54	-	Dressing of the diameter according to the number of calls
		55	-	Dressing of the outer edge according to the number of calls
		56	-	Dressing of the inner edge according to the number of calls
		57	-	Dressing counter of the diameter
		58	-	Dressing counter of the outer edge
		59	-	Dressing counter of the inner edge
		60	-	Selection of compensation method
		61	-	Inclination angle of dressing tool
		101	-	Radius of grinding wheel

Group name	Group number ID	System data number NO	Index IDX	Description
Datum shif	ft for the grinding w	heel		
	781	1	Axis	Datum shift from calibrating the front edges
		2	Axis	Datum shift from calibrating the rear edges
		3	Axis	Datum shift from setup
		4	Axis	Programmed wheel-specific datum shift
		5-9	Axis	Additional wheel-specific datum shift
eometry	of the grinding whee	el		
	782	1	-	Wheel shape
		2	-	Overrun on the outer side
		3	-	Overrun on the inner side
		4	-	Overrun diameter
etailed ge	eometry (contour) o	f the grinding wh	eel	
	783	1	1	Chamfer width of the outer side of the wheel
			2	Chamfer width of the inner side of the wheel
	2	2	1	Chamfer angle of the outer side of the wheel
			2	Chamfer angle of the inner side of the wheel
		3	1	Corner radius of the outer side of the wheel
			2	Corner radius of the inner side of the wheel
		4	1	Side length of the outer side of the wheel
			2	Side length of the inner side of the wheel
		5	1	Relief length of the outer side of the wheel
			2	Relief length of the inner side of the wheel
		6	1	Relief angle of the outer side of the wheel
			2	Relief angle of the inner side of the wheel
		7	1	Recess length of the outer side of the wheel
			2	Recess length of the inner side of the wheel
		8	1	Departing radius of the outer side of the whee
			2	Departing radius of the inner side of the whee
		9	1	Total depth on the outside
			2	Total depth on the inside

Group name	Group number ID	System data number NO	Index IDX	Description
Data for di	ressing the grinding	wheel	1	
	784	1	-	Number of safety positions
		5	-	Dressing method
		6	-	Number of the dressing program
		7	-	Amount of infeed for dressing
		8	-	Angle of infeed / infeed direction for dressing
		9	-	Number of repetitions for dressing
		10	-	Number of idle strokes for dressing
		11	-	Feed rate for dressing on the diameter
		12	-	Feed rate factor for dressing the side (with respect to NR11)
		13	-	Feed rate factor for dressing radii (with respect to NR11)
		14	-	Feed rate factor for dressing angular wheels (with respect to NR11)
		15	-	Feed rate outside the wheel, for pre-profiling
		16	-	Feed rate factor inside the wheel (with respect to NR15), for pre-profiling
		25	-	Dressing method for intermediate dressing
		26	-	Number of the program for intermediate dressing
		27	-	Amount of infeed for intermediate dressing
		28	-	Angle of infeed / infeed direction for intermediate dressing
		29	-	Number of repetitions for intermediate dressing
		30	-	Number of idle strokes for intermediate dressing
		31	-	Feed rate for intermediate dressing

Group name	Group number ID	System data number NO	Index IDX	Description
Safety pos	itions for the grindi	ng wheel		
	785	1	Axis	Safety position no. 1
		2	Axis	Safety position no. 2
		3	Axis	Safety position no. 3
		4	Axis	Safety position no. 4
Data of the	dressing tool for th	ne grinding wheel		
	789	1	-	Туре
		2	-	Length L1
		3	-	Length L2
		4	-	Radius
		5	-	Orientation: 1=RadType1, 2=RadType2, 3=RadType3
		10	-	Rotational speed of the dressing spindle

Group name	Group number ID	System data number NO	Index IDX	Description
Read Func	tional Safety (FS) in	formation		
	820	1	-	FS limitations: 0 = No Functional Safety (FS) 1 = Guard door open (SOM1) 2 = Guard door open (SOM2) 3 = Guard door open (SOM3) 4 = Guard door open (SOM4) 5 = All guard doors closed
Write data	for unbalance moni	toring		
	850	10	-	Activate and deactivate unbalance monitoring 0 = unbalance monitoring not active 1 = unbalance monitoring active
Counter				
	920	1	-	Planned workpieces. In Test Run operating mode the counter generally generates the value 0.
		2	-	Already machined workpieces. In Test Run operating mode the counter generally generates the value 0.
		12	-	Workpieces still to be machined. In Test Run operating mode the counter generally generates the value 0.
Read and v	write data of current	tool		
	950	1	-	Tool length L
		2	-	Tool radius R
		3	-	Tool radius R2
		4		Oversize for tool length DL
		5	-	Tool radius oversize DR
		6	-	Tool radius oversize DR2
		7	-	Tool locked TL 0 = not locked, 1 = locked
		8		Number of the replacement tool RT
		9	-	Maximum tool age TIME1
		10	-	Maximum tool age TIME2 at TOOL CALL
		11	-	Current tool age CUR.TIME
		12	-	PLC status
		13	_	Tooth length in the tool axis LCUTS
		14	-	Maximum plunge angle ANGLE
		15	-	TT: Number of tool teeth CUT
		16	-	TT: Wear tolerance for length LTOL
		17	-	TT: Wear tolerance for radius RTOL
		18	-	TT: Direction of rotation DIRECT 0 = positive, -1 = negative

Group name	Group number ID	System data number NO	Index IDX	Description
		19	-	TT: Offset in plane R-OFFS R = 99999.9999
		20	-	TT: Offset in length L-OFFS
		21	-	TT: Break tolerance for length LBREAK
		22	-	TT: Break tolerance for radius RBREAK
		28	-	Maximum spindle speed [rpm] NMAX
		32	-	Point angle TANGLE
		34	-	LIFTOFF allowed (0 = No, 1 = Yes)
		35	-	Wear tolerance for radius R2TOL
		36	-	Tool type TYPE (miller = 0, grinder = 1, touch probe = 21)
		37	-	Corresponding line in the touch-probe table
		38	-	Timestamp of last use
		39	-	ACC
		40	-	Pitch for thread cycles
		41	-	AFC: reference load
		42	-	AFC: overload early warning
		43	-	AFC: overload NC stop
		44	-	Exceeding the tool life
		45	-	Front-face width of indexable insert (RCUTS)
		46	-	Usable length of the milling cutter
		47	-	Neck radius of the milling cutter (RN)
		48	-	Radius at the tool tip (R_TIP)

Group name	Group number ID	System data number NO	Index IDX	Description
Read and	write data of current	turning tool		
	951	1	-	Tool number
		2	-	Tool length XL
		3	-	Tool length YL
		4	-	Tool length ZL
		5	-	Tool length oversize DXL
		6	-	Oversize in tool length DYL
		7	-	Tool length oversize DZL
		8	-	Tooth radius (RS)
		9	-	Tool orientation (TO)
		10	-	Angle of spindle orientation (ORI)
		11	-	Tool angle P_ANGLE
		12	-	Point angle T_ANGLE
		13	-	Recessing width CUT_WIDTH
		14	-	Type (e.g. roughing, finishing, threading, recessing or button tool)
		15	-	Length of cutting edge CUT_LENGTH
		16	-	Compensation of workpiece diameter WPL-DX-DIAM in the working plane coordinate system WPL-CS
		17	-	Compensation of workpiece diameter WPL-DZL in the working plane coordinate system WPL-CS
		18	-	Recessing width oversize
		19	-	Cutting radius oversize
		20	-	Rotation around spatial angle B for offset recessing tools

Group name	Group number ID	System data number NO	Index IDX	Description
Data of the	e currently active dr	esser		
	952	1	-	Tool number
		2	-	Tool length XL
		3	-	Tool length YL
		4	-	Tool length ZL
		5	-	Oversize for tool length DXL
		6	-	Oversize for tool length DYL
		7	-	Oversize for tool length DZL
		8	-	Cutter radius
		9	-	Cutting position
		13	-	Cutter width for plate or roll
		14	-	Type (e.g. diamond, plate, spindle, roll)
		19	-	Cutter radius oversize
		20	-	Shaft speed of a dressing spindle or roll
ransform	ation data for gener	al tools		
	960	1	-	Position within the tool system explicitly defined:
		2	-	Position defined by directions:
		3	-	Shift in X
		4	-	Shift in Y
		5	-	Shift in Z
		6	-	X component of the Z direction
		7	-	Y component of the Z direction
		8	-	Z component of the Z direction
		9	-	X component of the X direction
		10	-	Y component of the X direction
		11	-	Z component of the X direction
		12	-	Type of angle definition:
		13	-	Angle 1
		14	-	Angle 2
		15	-	Angle 3

Group name	Group number ID	System data number NO	Index IDX	Description
Tool usage	e and tooling			
	975	1	-	Tool usage test for the current NC program: Result –2: Test not possible, function disabled in the configuration Result –1: Test not possible, tool usage file missing Result 0: Test OK, all tools available Result 1: Test not OK
		2	Line	Check availability of the tools required in the pallet from line IDX in the current pallet table. -3 = No pallet is defined in row IDX, or function was called outside of pallet editing -2 / -1 / 0 / 1 see NR1
Touch pro	be cycles and coord	inate transformat	tions	
	990	1	-	Approach behavior: 0 = Standard behavior 1 = Approach probing position without compensation. Effective radius, set-up clearance is zero
		2	16	Automatic / Manual machine operating modes
		4	-	0 = Stylus not deflected 1 = Stylus deflected
		6	-	TT tool touch probe active? 1 = Yes 0 = No
		8	-	Momentary spindle angle in [°]
		10	QS parameter no.	Determine the tool number from the tool name. The return value depends on the rules configured for the search of the replacement tool. If there are multiple tools with the same name the first tool from the tool table will be selected. If the tool selected by these rules is locked, a replacement tool will be returned. —1: No tool with the specified name found in the tool table or all qualifying tools are locked.
		16	0	0 = Transfer control over the channel spindle to the PLC,1 = Assume control over the channel spindle
			1	0 = Pass tool spindle control to the PLC, 1 = Take control of the tool spindle
		19	-	Suppress touch prove movement in cycles: 0 = Movement will be suppressed (CfgMachineSimul/simMode parameter not equal to FullOperation or Test Run operating mode is active) 1 = Movement will be performed (CfgMa-

Group name	Group number ID	System data number NO	Index IDX	Description
				chineSimul/simMode parameter = FullOpera- tion, can be programmed for testing purpos- es)

Group name	Group number ID	System data number NO	Index IDX	Description
Status of e	xecution			
	992	10	-	Block scan active 1 = yes, 0 = no
		11	-	Block scan—information on block scan: 0 = NC program started without block scan 1 = Iniprog system cycle is run before block scan 2 = Block scan is running 3 = Functions are being updated -1 = Iniprog cycle was canceled before block scan -2 = Cancellation during block scan -3 = Cancellation of the block scan after the search phase, before or during the update of functions -99 = Implicit cancellation
		12	-	Type of canceling for interrogation within the OEM_CANCEL macro: 0 = No cancellation 1 = Cancellation due to error or emergency stop 2 = Explicit cancellation with internal stop after stop in the middle of the block 3 = Explicit cancellation with internal stop after stop at the end of a block
		14	-	Number of the last FN14 error
		16	-	Real execution active? 1 = execution, 0 = simulation
		17	-	2D graphics during programming active? 1 = Yes 0 = No
		18	-	Live programming graphics (AUTO DRAW soft key) active? 1 = Yes 0 = No
		20	-	Information on combined milling/turning mode of operation: 0 = Milling (after FUNCTION MODE MILL) 1 = Turning (after FUNCTION MODE TURN) 10 = Execute the operations for the turning-to-milling transition 11 = Execute the operations for the milling-to-turning transition
		21	-	Cancellation during dressing operation for querying within the OEM_CANCEL macro: 0 = Cancellation was not during dressing operation 1 = Cancellation during dressing operation

Group name	Group number ID	System data number NO	Index IDX	Description
		30	-	Interpolation of multiple axes permitted? 0 = No (e.g. for straight cut control) 1 = yes
		31	-	R+/R- possible/permitted in MDI mode? 0 = No 1 = Yes
		32	Cycle number	Single cycle enabled: 0 = No 1 = Yes
		33	-	Write-access enabled for DNC (Python scripts) for executed entries in the pallet table: 0 = No 1 = Yes
		40	-	Copy tables in Test Run operating mode? Value 1 will be set when a program is selected and when the RESET+START soft key is pressed. The iniprog.h system cycle will then copy the tables and reset the system datum. 0 = no 1 = yes
		101	-	M101 active (visible condition)? 0 = no 1 = yes
		136	-	M136 active? 0 = no 1 = yes

Group name	Group number ID	System data number NO	Index IDX	Description
Activate m	achine parameter s	ubfile		
	1020	13	QS parameter no.	Has a machine parameter subfile with path from QS number (IDX) been loaded? 1 = Yes 0 = No
Configurat	tion settings for cyc	les		
	1030	1	-	Display the Spindle does not rotate error message? (CfgGeoCycle/displaySpindleErr) 0 = no, 1 = yes
		2	-	Display the Check the algebraic sign for depth! error message? (CfgGeoCycle/displayDepthErr) 0 = no, 1 = yes
Data trans	fer between HEIDEN	IHAIN cycles and	OEM macros	
	1031	1	0	Component monitoring: counter of the measurement. Cycle 238 Measure machine data automatically increments this counter.
			1	Component monitoring: Type of measurement -1 = No measurement. Writing of the value with FN17 concludes Cycle 238. 0 = Circular test 1 = Waterfall diagram 2 = Frequency response 3 = Envelope curve spectrum
			2	Component Monitoring: Index of the axis from CfgAxes\MP_axisList
			3 – 9	Component monitoring: further arguments depend on the measurement
		100	-	Component monitoring: optional names of the monitoring tasks, as specified in System \Monitoring\CfgMonComponent . After completion of the measurement, the monitoring tasks stated here are executed consecutively. When assigning the input parameters, remember to separate the listed monitoring tasks by commas.
User settir	ngs for the user inte	rface		
	1070	1	-	Feed rate limit of soft key FMAX; 0 = FMAX is inactive
Bit test				
	2300	Number	Bit number	This function checks whether a bit has been set in a number. The number to be checked is transferred as NR, the bit to be searched for as IDX, with IDX0 designating the least significant bit. To call this function for large numbers, make sure to transfer NR as a Q

Group name	Group number ID	System data number NO	Index IDX	Description
				parameter. 0 = Bit not set 1 = Bit set
Read prog	ram information (sy	stem string)		
	10010	1	-	Path of the current main program or pallet program.
		2	-	Path of the NC program shown in the block display.
		3	-	Path of the cycle selected with SEL CYCLE or CYCLE DEF 12 PGM CALL , or path of the currently active cycle
		10	-	Path of the NC program selected with SEL PGM "" .
ndexed a	cess to QS paramet	ters		
	10015	20	QS parameter no.	Reads QS(IDX)
		30	QS parameter no.	Returns the string that you obtain if you replace anything except for letters and digits in QS(IDX) by '_'.
Read chan	nel data (system sti	ring)		
	10025	1	-	Name of machining channel (key)
Read data	for SQL tables (syst	tem string)		
	10040	1	-	Symbolic name of the preset table.
		2	-	Symbolic name of the datum table.
		3	-	Symbolic name of the pallet preset table.
		10	-	Symbolic name of the tool table.
		11	-	Symbolic name of the pocket table.
		12	-	Symbolic name of the turning tool table
		13	-	Symbolic name of the grinding tool table
		14	-	Symbolic name of the dressing tool table
		21	-	Symbolic name of the compensation table i the T-CS tool coordinate system
		22	-	Symbolic name of the compensation table i the WPL-CS working plane coordinate syste

Group name	Group number ID	System data number NO	Index IDX	Description
/alues pro	grammed in the too	l call (system str	ing)	
	10060	1	-	Tool name
ead mach	nine kinematics (sys	stem strings)		
	10290	10	-	Symbolic name of the machine kinematics from Channels/ChannelSettings/CfgKin-List/kinCompositeModels programmed in FUNCTION MODE MILL or FUNCTION MODE TURN.
raverse r	ange switchover (sy	stem string)		
	10300	1	-	Key name of the last active range of traverse
ead curre	ent system time (sys	stem string)		
Read data	10321	0 - 16, 20	-	1: DD.MM.YYYY hh:mm 2: D.MM.YYYY h:mm 3: DD.MM.YY hh:mm 4: YYYY-MM-DD hh:mm 6: YYYY-MM-DD h:mm 7: YY-MM-DD h:mm 8: DD.MM.YYYY 9: D.MM.YYYY 10: D.MM.YYYY 11: YYYY-MM-DD 12: YY-MM-DD 13: hh:mm:ss 14: h:mm:ss 15: h:mm 16: DD.MM.YYYY hh:mm 20: Calender week as per ISO 8601 As an alternative, you can use DAT in SYSSTR() to specify a system time in seconds that is to be used for formatting.
leau uata	10350	50	- -	Type of TS probe from TYPE column of the touch probe table (tchprobe.tp)
		51	-	Shape of stylus from column STYLUS in the touch probe table (tchprobe.tp).
		70	-	Type of TT tool touch probe from CfgTT/type
		73	-	Key name of the active tool touch probe TT from CfgProbes/activeTT .
		74	-	Serial number of the active tool touch probe TT from CfgProbes/activeTT .
ead the d	lata for pallet machi	ning (system stri	ng)	
	10510	1	-	Pallet name
		2	-	Path of the selected pallet table.

Group name	Group number ID	System data number NO	Index IDX	Description
	10630	10	-	The string corresponds to the format of the version ID shown (e.g., 340590 09 or 817601 05 SP1)
General da	ata of the grinding w	heel		
	10780	1	-	Name of wheel
Read info	rmation on unbalanc	e cycle (system s	tring)	
	10855	1	-	Path of the unbalance calibration table belonging to the active kinematics
Read data	of the current tool (system string)		
	10950	1	-	Current tool name
		2	-	Entry from the DOC column of the active tool
		3	-	AFC control setting
		4	-	Tool-carrier kinematics
		5	-	Entry from the DR2TABLE column – file name of the compensation value table for 3D- ToolComp
Read info	rmation from OEM m	nacros and HEIDE	NHAIN cycles (sy	ystem string)
	11031	10	-	Returns the selection of the FUNCTION MODE SET <oem mode=""> macro as a string.</oem>
		100	-	Cycle 238: list of key names for component monitoring
		101	-	Cycle 238: file names for log file

Comparison: FN 18 functions

The following table lists the FN 18 functions from previous controls, which were not implemented in this manner in the TNC 640. In most cases, this function has been replaced by another function.

No. **IDX Contents** Replacement function **ID 10 Program information** 1 mm/inch condition Q113 2 Overlap factor for pocket milling CfgRead 4 ID 10 no. 3 Number of the active fixed cycle **ID 20 Machine status** 15 Log. axis Assignment between logic and geometric axes 16 Feed rate for transition arcs 17 Currently selected range of traverse SYSTRING 10300 19 Maximum spindle speed for current gear Maximum gear range: ID 90 No. stage and spindle 2 ID 50 Data from the tool table 23 1) Tool no. PLC value

No.	IDX	Contents	Replacement function
24	Tool no.	Probe center offset in reference axis (CAL- OF1)	ID 350 NR 53 IDX 1
25	Tool no.	Probe center offset in minor axis (CALOF-2)	ID 350 NR 53 IDX 2
26	Tool no.	Spindle angle during calibration (CAL-ANG)	ID 350 NR 54
27	Tool no.	Tool type for pocket table (PTYP)	2)
29	Tool no.	Position P1	1)
30	Tool no.	Position P2	1)
31	Tool no.	Position P3	1)
33	Tool no.	Thread pitch (Pitch)	ID 50 NR 40
ID 51 Data	from the pocket table		
6	Pocket no.	Tool type	2)
7	Pocket no.	P1	2)
8	Pocket no.	P2	2)
9	Pocket no.	P3	2)
10	Pocket no.	P4	2)
11	Pocket no.	P5	2)
12	Pocket no.	Pocket reserved 0 = No, 1 = Yes	2)
13	Pocket no.	Box magazine: Pocket above occupied: 0 = No, 1 = Yes	2)
14	Pocket no.	Box magazine: Pocket below occupied: 0 = No, 1 = Yes	2)
15	Pocket no.	Box magazine: Pocket to the left occupied: 0 = No, 1 = Yes	2)
16	Pocket no.	Box magazine: Pocket to the right occupied: 0 = No, 1 = Yes	2)
ID 56 File i	nformation		
1	-	Number of lines of the tool table	
2	-	Number of lines of the active datum table	
3	Q parameters	Number of active axes that are programmed in the active datum table	
4	-	Number of lines in a freely definable table that has been opened with FN 26: TABOPEN	
ID 214 Cur	rent contour data		
1	-	Contour transition mode	
2	-	Max. linearization error	
3	-	Mode for M112	
4	-	Character mode	
5	-	Mode for M124	1)
6	-	Specification for contour pocket machining	
7	-	Filter for control loop	

No.	IDX	Contents	Replacement function
8	-	Tolerance programmed with Cycle 32	ID 30 no. 48
ID 240 Nom	inal positions in th	e REF system	
8	-	ACTUAL position in the REF system	
ID 280 Infor	mation on M128		
2	-	Feed rate that was programmed with M128	ID 280 NR 3
ID 290 Swite	ch the kinematics		
1	-	Line of the active kinematics table	SYSSTRING 10290
2	Bit no.	Interrogate the bits in MP7500	Cfgread
3	-	Status of collision monitoring (old)	Can be activated and deactivated in the NC program
4	-	Status of collision monitoring (new)	Can be activated and deactivated in the NC program
ID 310 Modi	ifications of geom	etrical behavior	
116	-	M116: -1 = On, 0 = Off	
126	-	M126: -1 = On, 0 = Off	
ID 350 Touc	h-probe data		
10	-	TS: Touch-probe axis	ID 20 NR 3
11	-	TS: Effective ball radius	ID 350 NR 52
12	-	TS: Effective length	ID 350 NR 51
13	-	TS: Ring gauge radius	
14	1/2	TS: Center offset in reference/minor axis	ID 350 NR 53
15	-	TS: Direction of center offset relative to 0° position	ID 350 NR 54
20	1/2/3	TT: Center point X/Y/Z	ID 350 NR 71
21	-	TT: Plate radius	ID 350 NR 72
22	1/2/3	TT: 1st probing position X/Y/Z	Cfgread
23	1/2/3	TT: 2nd probing position X/Y/Z	Cfgread
24	1/2/3	TT: 3rd probing position X/Y/Z	Cfgread
25	1/2/3	TT: 4th probing position X/Y/Z	Cfgread
ID 370 Touc	h probe cycle sett	ings	
1	-	Do not move to set-up clearance in Cycle 0.0 and 1.0 (as with ID990 NR1)	ID 990 NR 1
2	-	MP 6150 Rapid traverse for measurement	ID 350 NR 55 IDX 1
3	-	MP 6151 Machine rapid traverse as rapid traverse for measurement	ID 350 NR 55 IDX 3
4	-	MP 6120 Feed rate for measurement	ID 350 NR 55 IDX 2
5	-	MP 6165 Angle tracking on/off	ID 350 NR 57
ID 501 Datu	m table (REF syste	em)	
Line	Column	Value in datum table	Preset table
ID 502 Pres	et tahle		

No.	IDX	Contents	Replacement function
Line	Column	Read the value from preset table, taking into account the active machining system	
ID 503 Preset	table		
Line	Column	Read the value directly from the preset table	ID 507
ID 504 Preset	table		
Line	Column	Read the basic rotation from the preset table	ID 507 IDX 4-6
ID 505 Datum	table		
1	-	0 = No datum table selected 1 = Datum table selected	
ID 510 Data fo	r pallet machining		
7	-	Test the insertion of a fixture from the PAL line	
ID 530 Active	preset		
2	Line	Write-protect the line in the active preset table:	FN 26 and FN 28: read out the Locked column
		0 = No, 1 = Yes	
ID 990 Approa	ch behavior		
2	10	0 = No execution in block scan 1 = Execution in block scan	ID 992 NR 10 / NR 11
3	Q parameters	Number of axes that are programmed in the selected datum table	
ID 1000 Machi	ine parameter		
MP number	MP index	Value of the machine parameter	CfgRead
ID 1010 Machi	ine parameter is de	fined	
MP number	MP index	0 = Machine parameter does not exist 1 = Machine parameter exists	CfgRead

¹⁾ Function or table column no longer exists

²⁾ Use FN 26 and FN 28 or SQL to read out the table cell

17.2 Overview tables

Miscellaneous functions

М	Effect Effective at bloc	k Start	End	Page
М0	Program STOP/Spindle STOP/Coolant OFF			234
M1	Optional program STOP/Spindle STOP/Coolant OFF			234
M2	Program STOP/Spindle STOP/Coolant OFF/ CLEAR status display (depending on machine parameter)/Return jump to block 1		•	234
M3 M4 M5	Spindle ON clockwise Spindle ON counterclockwise Spindle STOP	:		234
M8 M9	Coolant ON Coolant OFF	•		234
M13 M14	Spindle ON clockwise/Coolant ON Spindle ON counterclockwise/Coolant ON	:		234
M30	Same function as M2			234
M89	Vacant miscellaneous function or cycle call, modally effective (depending on machine parameter)	•		Cycles Manual
M91	Within the positioning block: Coordinates are referenced to machine datum			235
M92	Within the positioning block: Coordinates are referenced to a position defined by machine manufacturer, e.g. tool change position	•		235
M94	Reduce the rotary axis display to a value below 360°			492
M97	Machine small contour steps			238
M98	Machine open contours completely			239
M99	Blockwise cycle call		•	Cycles Manual
M101 M102	Automatic tool change with replacement tool if maximum tool life has expired Reset M101			135
M103	Feed rate factor for plunging movements			240
M107 M108	Suppress error message for replacement tools with oversize Reset M107		:	508
M109 M110 M111	Constant contouring speed at cutting edge (feed rate increase and reduction) Constant contouring speed at cutting edge (only feed rate reduction) Reset M109/M110	:		241
M116 M117	Feed rate in mm/min on rotary axes Reset M116	•		490
M118	Superimpose handwheel positioning during program run			245
M120	Pre-calculate the radius-compensated contour (LOOK AHEAD)	-		243
M126 M127	Shorter-path traverse of rotary axes Reset M126	-		491
M128 M129	Maintaining the position of the tool tip when positioning with tilted axes (TCPM) Reset M128	•		493
M130	Within the positioning block: Points are referenced to the untilted coordinate system		-	237

М	Effect Eff	ective at block	Start	End	Page
M136 M137	Feed rate F in millimeters per spindle revolution Reset M136		•		241
M138	Selection of tilted axes				497
M140	Retraction from the contour in the tool-axis direction				247
M141	Suppress touch probe monitoring				249
M143	Delete basic rotation				249
M144	Compensating the machine's kinematic configuration for ACTUA positions at end of block	L/NOMINAL	•		498
M145	Reset M144				
M148 M149	Automatically retract tool from the contour at an NC stop Reset M148		•		250
M197	Corner rounding			-	251

User functions

User functions		
Short description		Basic version: 3 axes plus closed-loop spindle
		A total of 14 additional NC axes or 13 additional NC axes plus second spindle
		Digital current and speed control
Program entry		In HEIDENHAIN Klartext format and ISO (G codes)
	X	Importing of contours or machining positions from CAD files (STP, IGS, DXF) and saving them as a Klartext contour program or Klartext point table
Position entry		Nominal positions for lines and arcs in Cartesian coordinates or polar coordinates
		Incremental or absolute dimensions
		Display and entry in mm or inches
Tool compensation		Tool radius in the working plane and tool length
		Radius-compensated contour look-ahead for up to 99 NC blocks (M120)
	2	Three-dimensional tool-radius compensation for changing tool data without having to recalculate an existing NC program
Tool tables	Mul	tiple tool tables with any number of tools
Constant contour speed		With respect to the path of the tool center
		With respect to the cutting edge
Parallel operation		ating an NC program with graphical support while another NC program is ng run
3D machining		Motion control with highly smoothed jerk
	2	3-D tool compensation through surface-normal vectors
	2	Using the electronic handwheel to change the angle of the swivel head during program run without affecting the position of the tool location point, i.e. the tool tip or tool center point (TCPM = tool center point management)
	2	Keeping the tool normal to the contour
	2	Tool radius compensation perpendicular to traversing and tool direction
	X	3D radius compensation depending on the tool's contact angle
Rotary table machining	1	Programming of cylindrical contours as if in two axes
(Advanced Function Set 1)	1	Feed rate in distance per minute

User functions		
Contour elements		Straight line
	-	Chamfer
	-	Circular path
		Circle center
		Circle radius
		Tangentially connected arc
		Rounded corners
Approaching and departing the	-	Via straight line: tangential or perpendicular
contour	-	Via circular arc
FK free contour programming	-	FK free contour programming in HEIDENHAIN Klartext format with graphic support for workpiece drawings not dimensioned for NC
Program jumps		Subprograms
		Program section repeats
		Calling any NC program
Machining cycles		Cycles for drilling, and conventional and rigid tapping
		Cycles for pecking, reaming, boring, and counterboring
		Cycles for milling internal and external threads
		Roughing and finishing rectangular and circular pockets
		Roughing and finishing rectangular and circular studs
		Point patterns for circles, lines, and DataMatrix codes
	-	Cycles for clearing level and inclined surfaces
	-	Cycles for milling linear and circular slots
		Engraving
		Contour pocket
		Contour train
	X	Cycles for turning operations
	X	Cycles for jig grinding and dressing
	•	OEM cycles (special machining cycles developed by the machine tool builder) can also be integrated
Coordinate transformation		Datum shift, rotation, mirroring
		Scaling factor (axis-specific)
	1	Tilting the working plane (Advanced Function Set 1)

User functions		
Q parameters		Mathematical functions: =, +, -, *, $\sin \alpha$, $\cos \alpha$, root
Programming with variables		Logical operations (=, ≠, <, >)
		Calculating with parentheses
	•	tan α , arc sin, arc cos, arc tan, a^n , e^n , In, log, absolute value of a number, constant π , negation, truncation of digits before or after the decimal point
		Functions for calculation of circles
		Functions for text processing
Programming aids		Calculator
		Color highlighting of syntax elements
		Complete list of all current error messages
		Context-sensitive help function
		Graphic support for the programming of cycles
		Comment and structure blocks in the NC program
Teach-In		Actual positions can be transferred directly to the NC program
Test graphics Display modes	•	Graphic simulation before a program run, even while another NC program is being run
• •		Plan view / projection in 3 planes / 3-D view / 3-D line graphic
		Detail enlargement
Programming graphics	•	In the Programming mode, the contours of the NC blocks are drawn on screen while they are being entered (2-D pencil-trace graphics), even while another NC program is being run
Program-run graphics Display modes	•	Graphic simulation of real-time machining in plan view / projection in 3 planes / 3-D view
Machining time		Calculation of machining time in the Test Run operating mode
-	•	Display of the current machining time in the Program Run operating modes
Preset management		For saving any datums
Returning to the contour		Block scan in any NC block in the NC program, returning the tool to the calculated nominal position to continue machining
		NC program interruption, contour departure and return
Datum tables		Multiple datum tables for storing workpiece-specific datums
Touch probe cycles		Calibrating the touch probe
		Compensation of workpiece misalignment, manual or automatic
		Presetting, manual or automatic
		Automatically measuring workpieces
		Cycles for automatic tool measurement
		Cycles for automatic kinematics measurement

Index		Compensation	507	282	
		Cartesian coordinates		Defining the workpiece blank	
3		Circular arc around circle cent		Dialog	
3D compensation	507	CC	165	Directory 110,	
Delta values		Circular arc with specified	1.67	Copy	
Face Milling		radius	16/	Create	
Peripheral Milling		Circular arc with tangential	1.60	Delete	
Tool orientation		transition		Display of the NC program	
3-D compensation		Linear motion superimposed of		Display screen	. 6/
Normalized vector	509	circular contour		DNC	
Tool shapes		Straight line		Information from NC program	٦
·		Chamfer		321	000
A		Circle		Downloading help files	
About this manual	34	Circle center	164	Dressing	
Actual position capture	. 101	Circular arc	1.6.5	Fundamentals	60 I
Adaptive Feed Control	382	around circle center CC		Drilling position, selecting	_ 4 _
Automatic	382	With fixed radius		Drag box	
Adding comments 199	, 200	with tangential transition	169	lcon	
Additional axes	89	Circular contour	70	Single selection	545
Additional axes for rotary axes.	. 490	Superimposed linear motion. 1	70	Drilling positions	Г16
ADP	524	Circular path	176	Filter for CAD data transfer	546
AFC	382	Around pole		Dwell time	450
basic settings	383	Collision monitoring	3/8	cyclic	
In turning mode	. 593	Compensation table	106	once	
programming	385	Creating		resetting	
Align tool axis	487	Type4		Dynamic Collision Monitoring	3/8
ASCII files	436	Component Monitoring		E	
		Components, monitoring			217
В		Context-sensitive help	224	Error messagedeleting	
Batch Process Manager		Contour	1.50	filtering	
application		Approaching		-	
creating a job list		Departing		help with Output	
editing a job list		Selecting from DXF file		Extended Workspace	
fundamentals		Coordinate transformation		Exterided Workspace	. / I
job list		Datum shift		F	
opening		Mirroring		Facing slide, using	588
Block	. 103		415	Feed rate	000
Delete		Scaling		Input options	100
Inserting and modifying	. 103	Copying program sections		On rotary axes, M116	
С		Counter	434	Feed rate factor for plunging	150
	F07	Cutting force monitoring	E02	movements M103	240
CAD Import		In turning mode	393	Feed rate in millimeters per spin-	
CAD viewer		D		revolution M136	
Basic settings		Data output		Feed-rate limit	
defining the plane		Displaying	216	TCPM	506
Filter for drilling positions		To server		File	
Preset, setting		Datum shift		Copying	115
Selecting a contour		Coordinate input		create	
Setting layers	531	Resetting		Overwriting	
CAD Viewer	~ E / /	Via the datum table		protecting	
Machining position, selecting		Datum table		Sorting	
Calculating with parentheses		Columns		File functions	
Calculation of circles		Creating		File management	- 0
Calculator	∠UO	Selecting		Copying a table	117
Calling a program	250	DCM		External file types	
CAM programming		Defining local Q parameters		File manager	-
CAM programming	519	Defining nonvolatile Q parameters		Calling	112

Delete file	110	FUNCTION TCPM	400	Mades of Operation	71
Directories	119	Fundamentals		Modes of Operation	/4
	110	Fundamentals	/ /	Monitoring	270
Copy		G		Collision	
Create		Gestures	611	motion control	
Directory		GOTO		Multi-axis machining	458
File type			198	N	
Function overview		Graphics	01.4		010
Hidden files		With programming		NC and PLC synchronization	
Rename file		Magnification of details		NC block	
Selecting files	113	Grinding		NC error message	
Files		Dressing		NC program	
Tagging	120	Jig grinding	. 599	Editing	
File status	112	Н		structuring	
FK programming	181		100	Nesting	. 268
Auxiliary points	190	Hard disk		0	
Circle data	188	Heatmap			
Circular paths	186	Helical interpolation		Open contour corners M98	
Closed contours	189	Helix		Operating panel	
Dialog initiation	184	Help system		Option	38
Direction and length of cor	ntour	Help with error message		P	
elements	187	Hidden files	123		
End point	187			Pallet table	
Fundamentals				Application	
Graphics	183	Import		Columns	
Relative data		Table from iTNC 530		Editing	
Straight lines		Inclined machining		inserting a column	
Working plane		Inclined-tool machining		selecting and exiting	
Fluctuating spindle speed		Inclined turning		tool-oriented	
FN 14: ERROR: error message		iTNC 530	66	Parallel axes	
output		J		Paraxcomp	
FN 16: F-PRINT: formatted ou				Paraxmode	
text		Jig grinding		Part families	
FN 18: SYSREAD: reading sys		Jump conditions	292	Path	
data		Jumping		Path contours	
FN 19: PLC: Transfer values t		with GOTO	198	Cartesian coordinates	
PLC		K		Overview	
FN 20: WAIT FOR: NC and PL			70	Polar coordinates	
synchronization		Keyboard focus		Circular path with tangen	
FN 23: CIRCLE DATA: Calcula		Klartext	99	connection	
circle from 3 points		L		Overview	
FN 24: CIRCLE DATA: Calcula		Lift-off 250	153	Straight line	175
circle from 4 points		Log, writing to	-	Path functions	
FN 26: TABOPEN: Table, freel		Look ahead		Fundamentals	
definable, opening		LOOK affead	. 243	Circles and circular arcs	
FN 27: TABWRITE: Table, free		M		Pre-positioning	
definable, writing		M91, M92	235	PLANE function	
FN 28: TABREAD: Table, freel		Mesh		Automatic tilting into position	n
definable, reading	•	Message	. 540	479	
FN 29: PLC: Transfer values t		Screen output	316	Axis angle definition	476
PLC		Message, printing		Euler angle definition	469
FN 37: EXPORT		Mirroring	. 017	Incremental definition	475
FN 38: SEND: Send information		NC function	⊿ 11	Overview	
Form view		Miscellaneous functions		Point definition	473
FreeTurn		entering		positioning behavior	
Full circle		For coordinate entries	_	Projection angle definition	467
FUNCTION COUNT		For path behavior		Resetting	
FUNCTION DWELL		For program run inspection		Selection of possible solution	ns
FUNCTION FEED DWELL		For spindle and coolant		482	
		i or opiniale and coolant	∠∪⊤		

Spatial angle definition		Rapid traverse Reading out machine para		positioning M118 Surface normal vector 47	
Vector definition 4		333	11101013	Surface-normal vector 48	
PLC and NC synchronization 3		Reading system data	317 328	System data	J, 007
Point tables 2		Recessing tool	017,020	list	622
Polar coordinates		Cranked	584	1100	022
Circular path around pole CC 17		Reference system		T	
Fundamentals		Basic		TABDATA	429
Programming 1		Input		Table, freely definable	
Polar kinematics 3		Machine		Opening	443
Position, selecting from CAD		Tool		Reading	
files5	44	Working plane		Writing	
Positioning		Workpiece		Table access	
with tilted working plane 237, 49	98	Replacing texts		SQL	344
Post processor 5		Resonance vibration		TABDATA	
Preset		Retraction from the contou		TABWRITE	443
Selecting	91	Rotary axes		TCPM	499
Principal axes		Rotary axis		Resetting	506
Process chain 5		Reduce display M94	492	Teach In 10	
Program		Shorter-path traverse: M		Text editor	
Opening a new program		Rotation	1120 151	Text file	
structuring2		NC function	415	Creating	
Program defaults 3		Rounded corners		Delete functions	
Programm	, 0	Rounding corners M197		Finding text sections	
Structure	92	Rounding of values		Formatted output	
Programming graphics 1		reducing or values		Opening and exiting	
Programming tool movement		S		Text variables	
Program-section repeat 2		Saving service files	223	Tilting	
Pulsing spindle speed 4		Scaling		Resetting	463
Tuising spiriale speed	17	Screen		Working plane	
Q		touchscreen	608	Tilting axes	
Q parameter programming		Screen layout		Tilting without rotary axes	
Additional functions 3	01	CAD viewer		Tilt working plane	
Calculation of circles2		Search function		Programmed	459
If-then decision 2		Selecting the unit of measu		TNCguide	
Mathematical functions 2		SEL TABLE		Tool angle of inclination	
Q-parameter programming		Simultaneous turning	584	Compensating	499
Programming notes 2	81	Software option		TOOL CALL	
Trigonometric functions 2		SPEC FCT		Tool change	135
Q parameters 278, 2		Special functions	374	Tool compensation	
checking2		Spindle speed		3D	
Export 3		Entering	133	Length	138
Formatted output 3		SQL statement		Radius	
Local parameters Q 2		STL file		Table	425
Local parameters QL 2		Optimizing	548	Tool data	128
Preassigned3		Straight line		Calling	133
programming 278, 3		String parameter		Delta values	
Residual parameters QR 278, 27	79	Converting	329	Entering into the program	132
String parameters QS 3		Copying a substring		Replacing	
Transfer values to PLC 3		Determine length		TOOL DEF	
Q parameters		Testing		Tool length	129
Transfer values to PLC 3	18	String parameters		Tool name	
		Assign		Tool number	
R		Chain-linking		Tool-oriented machining	
Radius compensation 1	39	Reading system data		Tool oversize	
Entering 140, 1	41	Structuring NC programs		Suppress error: M107	508
Outside corners, inside		Subprogram		Tool radius	
corners1	41	Superimposing handwheel		Touch gestures	

Touch operating panel	609
Touch probe monitoring	
Touchscreen	608
TRANS DATUM	
Transformation	
Datum shift	409
Mirroring	411
Rotation	415
Scaling	416
Trigonometric functions	288
Trigonometry	288
Turning	
Facing slide	588
feed rate	578
inclined	582
simultaneous	584
Switching	
tool radius compensation	571
Turning mode	
programming the spindle	
speed	577
Turning mode, selecting	573
Turning operation	
FreeTurn	586
Turning Operations	570
T vector	509
V	
Vector	471
Virtual tool axis	
W	
	00
Workpiece positions	90

HEIDENHAIN

DR. JOHANNES HEIDENHAIN GmbH

Dr.-Johannes-Heidenhain-Straße 5

FAX +49 8669 32-5061

info@heidenhain.de

service.ms-support@heidenhain.de

NC programming ② +49 8669 31-3103 service.nc-pgm@heidenhain.de

PLC programming ② +49 8669 31-3102

service.plc@heidenhain.de

APP programming ② +49 8669 31-3106

service.app@heidenhain.de

www.heidenhain.com

www.klartext-portal.com

The Information Site for HEIDENHAIN Controls

Klartext App

Klartext on your mobile device

Google Play Store Apple App Store





Touch probes from HEIDENHAIN

help you reduce non-productive time and improve the dimensional accuracy of the finished workpieces.

Workpiece touch probes

TS 150, TS 260,


Signal transmission by cable

TS 750

TS 460, TS 760 Radio or infrared transmission

TS 642, TS 740 Infrared transmission

- Workpiece alignment
- Preset setting
- Workpiece measurement



Tool touch probes

TT 160 Signal transmission by cable
TT 460 Infrared transmission

- Tool measurement
- Wear monitoring
- Tool breakage detection

