

TNC7 basic

User's Manual
Setup and Program Run

NC Software
81762x-18

English (en)
10/2023

Table of contents

1	About the User's Manual.....	33
2	About the Product.....	43
3	First Steps.....	83
4	Status Displays.....	95
5	Powering On and Off.....	125
6	Manual Operation.....	133
7	NC Fundamentals.....	139
8	Tools.....	145
9	Coordinate Transformation.....	179
10	Collision Monitoring.....	205
11	Control Functions.....	235
12	Opening CAD files with CAD Viewer.....	247
13	User aids.....	269
14	The MDI Application.....	279
15	Touch Probes.....	285
16	Touch Probe Functions in the Manual Operating Mode (#17 / #1-05-1).....	289
17	Program Run.....	323
18	Tables.....	349
19	Electronic Handwheel.....	401
20	Override Controller.....	415
21	Embedded Workspace and Extended Workspace.....	423
22	Integrated Functional Safety (FS).....	427
23	The Settings Application.....	435
24	User Administration.....	499
25	HEROS Operating System.....	525
26	Overviews.....	547

1	About the User's Manual.....	33
1.1	Target group: Users.....	34
1.2	Available user documentation.....	35
1.3	Types of notes used.....	36
1.4	Notes on using NC programs.....	37
1.5	User's Manual as integrated product aid: TNCguide.....	38
1.5.1	Search in TNCguide.....	41
1.5.2	Copying NC examples to clipboard.....	42
1.6	Contacting the editorial staff.....	42

2	About the Product.....	43
2.1	The TNC7 basic.....	44
2.1.1	Proper and intended use.....	45
2.1.2	Intended place of operation.....	45
2.2	Safety precautions.....	46
2.3	Software.....	49
2.3.1	Software options.....	50
2.3.2	Information on licensing and use.....	56
2.4	Hardware.....	56
2.4.1	Touchscreen and keyboard unit.....	57
2.4.2	Hardware enhancements.....	61
2.5	Areas of the control's user interface.....	63
2.6	Overview of the operating modes.....	64
2.7	Workspaces.....	66
2.7.1	Operating elements within the workspaces.....	66
2.7.2	Symbols within the workspaces.....	67
2.7.3	Overview of workspaces.....	67
2.8	Operating elements.....	70
2.8.1	Common gestures for the touchscreen.....	70
2.8.2	Operating elements of the keyboard unit.....	70
2.8.3	Keyboard shortcuts for operating the control.....	77
2.8.4	Icons on the control's user interface.....	78
2.8.5	The Desktop menu workspace.....	80

3	First Steps.....	83
3.1	Chapter overview.....	84
3.2	Switching on the machine and the control.....	84
3.3	Configuring a tool.....	85
3.3.1	Selecting the Tables operating mode.....	85
3.3.2	Configuring the control's user interface.....	86
3.3.3	Preparing and measuring tools.....	86
3.3.4	Editing within tool management.....	87
3.3.5	Editing the pocket table.....	88
3.4	Setting up a workpiece.....	89
3.4.1	Selecting an operating mode.....	89
3.4.2	Clamping the workpiece.....	89
3.4.3	Workpiece presetting with a touch probe.....	89
3.5	Machining a workpiece.....	92
3.5.1	Selecting an operating mode.....	92
3.5.2	Opening an NC program.....	92
3.5.3	Starting an NC program.....	92
3.6	Switching the machine off.....	93

4	Status Displays.....	95
4.1	Overview.....	96
4.2	The Positions workspace.....	97
4.3	Status overview on the TNC bar.....	103
4.4	The Status workspace.....	105
4.5	The Simulation status workspace.....	118
4.6	Display of the program run time.....	119
4.7	Position displays.....	120
4.7.1	Switching the position display mode.....	122
4.8	Defining the contents of the QPARA tab.....	123

5	Powering On and Off.....	125
5.1	Powering on.....	126
5.1.1	Powering the machine and the control on.....	127
5.2	The Referencing workspace.....	129
5.2.1	Axis reference run.....	129
5.3	Powering off.....	130
5.3.1	Shutting down the control and powering-off the machine.....	131

6	Manual Operation.....	133
6.1	The Manual operation application.....	134
6.2	Moving the machine axes.....	135
6.2.1	Using axis keys to move the axes.....	136
6.2.2	Incremental jog positioning of axes.....	137

7	NC Fundamentals.....	139
7.1	NC fundamentals.....	140
7.1.1	Programmable axes.....	140
7.1.2	Designation of the axes of milling machines.....	140
7.1.3	Position encoders and reference marks.....	141
7.1.4	Presets in the machine.....	142

8	Tools.....	145
8.1	Fundamentals.....	146
8.2	Presets on the tool.....	147
8.2.1	Tool carrier reference point.....	147
8.2.2	Tool tip TIP	148
8.2.3	Tool center point (TCP, tool center point).....	148
8.2.4	Tool location point (TLP, tool location point).....	149
8.2.5	Tool rotation point (TRP, tool rotation point).....	149
8.2.6	Tool radius 2 center (CR2, center R2).....	150
8.3	Tool data.....	150
8.3.1	Tool ID number.....	150
8.3.2	Tool name.....	150
8.3.3	Database ID.....	151
8.3.4	Indexed tool.....	152
8.3.5	Tool types.....	155
8.3.6	Tool data for the tool types.....	158
8.4	Tool management.....	163
8.4.1	Importing and exporting tool data.....	164
8.5	Tool carrier management.....	167
8.5.1	Assigning a tool carrier.....	168
8.6	Customizing tool carrier templates with ToolHolderWizard.....	170
8.6.1	Parameterizing tool carrier templates.....	171
8.7	Tool model (#140 / #5-03-2).....	171
8.7.1	Assigning a tool model.....	173
8.8	Tool usage test.....	173
8.8.1	Performing the tool usage test.....	176

9	Coordinate Transformation.....	179
9.1	Reference systems.....	180
9.1.1	Overview.....	180
9.1.2	Basics of coordinate systems.....	181
9.1.3	Machine coordinate system M-CS.....	182
9.1.4	Basic coordinate system B-CS.....	184
9.1.5	Workpiece coordinate system W-CS.....	186
9.1.6	Working plane coordinate system WPL-CS.....	187
9.1.7	Input coordinate system I-CS.....	191
9.1.8	Tool coordinate system T-CS.....	192
9.2	Preset management.....	194
9.2.1	Setting a preset manually.....	197
9.2.2	Activating a preset manually.....	198
9.3	Tilting the working plane (#8 / #1-01-1).....	199
9.3.1	Fundamentals.....	199
9.3.2	The 3-D rotation window (#8 / #1-01-1).....	201

10 Collision Monitoring	205
10.1 Dynamic Collision Monitoring (DCM) (#40 / #5-03-1)	206
10.2 Fixture management	213
10.2.1 Fundamentals.....	213
10.2.2 Integrating fixtures into collision monitoring (#140 / #5-03-2).....	216
10.2.3 Editing CFG files with KinematicsDesign.....	226
10.2.4 Combining fixtures in the New Fixture window.....	231

11 Control Functions.....	235
11.1 Adaptive feed control (AFC) (#45 / #2-31-1).....	236
11.1.1 Fundamentals.....	236
11.1.2 Activating and deactivating AFC.....	239
11.1.3 AFC teach-in cut.....	242
11.1.4 Monitoring tool wear and tool load.....	244
11.2 Active Chatter Control (ACC) (#145 / #2-30-1).....	245

12 Opening CAD files with CAD Viewer.....	247
12.1 Fundamentals.....	248
12.2 Workpiece preset in the CAD file.....	253
12.2.1 Setting the workpiece preset or workpiece datum and orienting the coordinate system.....	255
12.3 Workpiece datum in the CAD file.....	256
12.4 Loading contours and positions to NC programs with CAD Import (#42 / #1-03-1).....	258
12.4.1 Selecting and saving a contour.....	261
12.4.2 Selecting positions.....	262
12.5 Generating STL files with 3D mesh (#152 / #1-04-1).....	264
12.5.1 Positioning the 3D model for rear-face machining.....	267

13 User aids.....	269
13.1 Virtual keyboard of the control bar.....	270
13.1.1 Opening and closing the virtual keyboard.....	273
13.2 Message menu on the information bar.....	274
13.2.1 Creating a service file manually.....	276
13.2.2 Creating a service file automatically.....	277

14 The MDI Application..... 279

15 Touch Probes.....	285
15.1 Setting up touch probes.....	286

16 Touch Probe Functions in the Manual Operating Mode (#17 / #1-05-1)	289
16.1 Fundamentals	290
16.1.1 Setting a preset in a linear axis	298
16.1.2 Determining the circle center point of a stud using the automatic probing method	300
16.1.3 Determining and compensating the rotation of a workpiece	302
16.1.4 Using touch probe functions with mechanical probes or dial gages	303
16.2 Calibrating the workpiece touch probe	304
16.2.1 Calibrating the length of the workpiece touch probe	307
16.2.2 Calibrating the radius of the workpiece touch probe	308
16.3 Setting up the workpiece with graphical support (#159 / #1-07-1)	309
16.3.1 Setting up the workpiece	315
16.4 Measuring the tool by scratching	316
16.4.1 Tool measurement by scratching	318
16.5 Suppressing touch probe monitoring	319
16.5.1 Deactivating touch probe monitoring	319
16.6 Comparison of offset and 3D basic rotation	320

17 Program Run.....	323
17.1 The Program Run operating mode.....	324
17.1.1 Fundamentals.....	324
17.1.2 Navigation path in the Program workspace.....	332
17.1.3 Manual traverse during an interruption.....	334
17.1.4 Block scan for mid-program startup.....	335
17.1.5 Returning to the contour.....	343
17.2 Compensation during program run.....	344
17.2.1 Opening tables from within the Program Run operating mode.....	345
17.3 The Retract application.....	346

18 Tables.....	349
18.1 The Tables operating mode.....	350
18.1.1 Editing the contents of tables.....	352
18.2 The Create new table window.....	352
18.3 The Table workspace.....	354
18.4 The Form workspace for tables.....	360
18.4.1 Adding a column in the workspace.....	362
18.5 Tool tables.....	362
18.5.1 Overview.....	362
18.5.2 Tool table tool.t.....	363
18.5.3 Touch probe table tchprobe.tp (#17 / #1-05-1).....	373
18.5.4 Creating a tool table in inches.....	377
18.6 Pocket table tool_p.tch.....	377
18.7 Tool usage file.....	380
18.8 T usage order (#93 / #2-03-1).....	382
18.9 Tooling list (#93 / #2-03-1).....	384
18.10 Preset table *.pr.....	385
18.10.1 actual position capture in the preset table.....	390
18.10.2 Activating write protection.....	391
18.10.3 Removing write protection.....	391
18.10.4 Creating a preset table in inches.....	393
18.11 Tables for AFC (#45 / #2-31-1).....	394
18.11.1 Basic AFC settings in AFC.tab.....	394
18.11.2 AFC.DEP settings file for teach-in cuts.....	397
18.11.3 Log file AFC2.DEP.....	399
18.11.4 Editing the tables for AFC.....	400

19 Electronic Handwheel.....	401
19.1 Fundamentals.....	402
19.1.1 Entering spindle speed S.....	407
19.1.2 Entering the feed rate F.....	407
19.1.3 Entering miscellaneous functions M.....	407
19.1.4 Creating a positioning block.....	408
19.1.5 Incremental jog positioning.....	408
19.2 HR 550FS wireless handwheel.....	410
19.3 The Configuration of wireless handwheel window.....	411
19.3.1 Assigning a handwheel to a handwheel holder.....	413
19.3.2 Selecting the transmission power.....	413
19.3.3 Setting the radio channel.....	414
19.3.4 Reactivating the handwheel.....	414

20	Override Controller.....	415
-----------	---------------------------------	------------

21 Embedded Workspace and Extended Workspace.....	423
21.1 Embedded Workspace (#133 / #3-01-1).....	424
21.2 Extended Workspace.....	426

22 Integrated Functional Safety (FS).....	427
22.1 Checking axis positions manually.....	433

23 The Settings Application.....	435
23.1 Overview.....	436
23.2 Code numbers.....	439
23.3 The Machine Settings menu item.....	439
23.4 The General Information menu item.....	442
23.5 The SIK menu item.....	443
23.5.1 Viewing of software options.....	444
23.6 The Machine Times menu item.....	446
23.7 The Adjust system time window.....	447
23.8 Conversational language of the control.....	448
23.8.1 Changing the language.....	449
23.9 SELinux security software.....	449
23.10 Network drives on the control.....	450
23.11 Ethernet interface.....	453
23.11.1 The Network settings window.....	455
23.12 PKI Admin.....	460
23.13 OPC UA NC Server (#56-61 / #3-02-1*).....	462
23.13.1 Fundamentals.....	462
23.13.2 The OPC UA (#56-61 / #3-02-1*) menu item.....	465
23.13.3 The OPC UA connection assistant function (#56-61 / #3-02-1*).....	466
23.13.4 The OPC UA license settings function (#56-61 / #3-02-1*).....	467
23.14 The DNC menu item.....	468
23.15 Printers.....	470
23.15.1 Creating a printer.....	473
23.16 The VNC menu item.....	473
23.17 The Remote Desktop Manager window (#133 / #3-01-1).....	477
23.17.1 Configuring an external computer for Windows Terminal Service (RemoteFX).....	481
23.17.2 Establishing and starting a connection.....	481
23.17.3 Exporting and importing connections.....	482

23.18 Firewall.....	483
23.19 Portscan.....	487
23.20 Backup and restore.....	487
23.20.1 Backing up data.....	488
23.20.2 Restoring data.....	489
23.21 TNCdiag.....	490
23.22 Update the documentation.....	490
23.22.1 Transferring TNCguide.....	491
23.23 Machine parameters.....	491
23.23.1 Note.....	496
23.24 Configuring the control's user interface.....	496
23.24.1 Exporting and importing configurations.....	498

24 User Administration.....	499
24.1 Fundamentals.....	500
24.1.1 Configuring user administration.....	504
24.1.2 Deactivating user administration.....	507
24.2 The User administration window.....	508
24.3 The Active user window.....	508
24.4 Saving user data.....	509
24.4.1 Overview.....	509
24.4.2 Local LDAP database.....	510
24.4.3 LDAP database on a remote computer.....	511
24.4.4 Connection to Windows domain.....	512
24.5 Autologin in user administration.....	518
24.6 Logging on with user administration.....	518
24.6.1 Logging on a user with password.....	519
24.6.2 Assigning a smartcard to a user.....	520
24.7 Window for requesting additional rights.....	520
24.8 SSH-secured DNC connection.....	521
24.8.1 Setting up SSH-secured DNC connections.....	523
24.8.2 Removing a secure connection.....	524

25 HEROS Operating System.....	525
25.1 Fundamentals.....	526
25.2 HEROS menu.....	526
25.3 Serial data transfer.....	531
25.4 PC software for data transfer.....	533
25.5 File transfer with SFTP (SSH File Transfer Protocol).....	535
25.5.1 Setting up an SFTP connection with CreateConnections.....	536
25.6 Secure Remote Access.....	537
25.7 Data backup.....	539
25.8 Opening files with additional software.....	539
25.8.1 Opening tools.....	540
25.9 Network configuration with Advanced Network Configuration.....	541
25.9.1 The Editing network connection window.....	542

26	Overviews.....	547
26.1	Pin layout and cables for data interfaces.....	548
26.1.1	V.24/RS-232-C interface for HEIDENHAIN devices.....	548
26.1.2	Ethernet interface RJ45 socket.....	548
26.2	Machine parameters.....	548
26.2.1	List of user parameters.....	549
26.3	User administration roles and rights.....	558
26.3.1	List of roles.....	558
26.3.2	List of rights.....	562
26.4	Special functions defining the machine behavior.....	564

1

**About the
User's Manual**

1.1 Target group: Users

A user is anyone who uses the control to perform at least one of the following tasks:

- Operating the machine
 - Setting up tools
 - Setting up workpieces
 - Machining workpieces
 - Eliminating possible errors during program run
- Creating and testing NC programs
 - Creating NC programs at the control or externally using a CAM system
 - Using the Simulation mode to test the NC programs
 - Eliminating possible errors during program test

The depth of information in the User's Manual results in the following qualification requirements on the user:

- Basic technical understanding (e.g., spatial imagination and the ability to read technical drawings)
- Basic knowledge in the field of metal cutting (e.g., understanding the meaning of material-specific parameters)
- Safety instructions (e.g., understanding possible dangers and how to avoid them)
- Training on the machine (e.g., comprehending axis directions and the machine configuration)



HEIDENHAIN offers separate information products for other target groups:

- Leaflets and overview of the product portfolio for potential buyers
- Service Manual for service technicians
- Technical Manual for machine manufacturers

Additionally, HEIDENHAIN provides users and lateral entrants with a wide range of training opportunities in the field of NC programming.

HEIDENHAIN training portal

In line with the target group, this User's Manual only contains information on the operation and use of the control. The information products for other target groups contain information on further product life phases.

1.2 Available user documentation

User's Manual

HEIDENHAIN refers to this information product as User's Manual, regardless of the output or transport medium. Well-known designations with the same meaning include operator's manual and operating instructions.

The User's Manual for the control is available in the variants below:

- As a printed version, sub-divided into the modules below:
 - The **Setup and Program Run** User's Manual contains all information needed for setting up the machine and for running NC programs.
ID:
 - The **Programming and Testing** User's Manual contains all information needed for creating and testing NC programs. Touch probe and machining cycles are not included.
ID for Klartext programming:
 - The **Machining Cycles** User's Manual contains all functions of the machining cycles.
ID:
 - The **Measuring Cycles for Workpieces and Tools** User's Manual contains all functions of the touch probe cycles.
ID:
- As PDF files, sub-divided according to the printed versions or as a **Complete edition** User's Manual, containing all modules
ID:
TNCguide
- As an HTML file used as the **TNCguide** product aid integrated directly into the control.
TNCguide

The User's Manual supports you in the safe handling of the control according to its intended use.

Further information: "Proper and intended use", Page 45

Further information products for users

The following information products are available to you:

- **Overview of new and modified software functions** informs you about the innovations of specific software versions.
TNCguide
- **HEIDENHAIN brochures** inform you about products and services by HEIDENHAIN (e.g., software options of the control).
HEIDENHAIN brochures
- The **NC solutions** database offers solutions for frequently occurring tasks.
HEIDENHAIN NC solutions

1.3 Types of notes used

Safety precautions

Comply with all safety precautions indicated in this document and in your machine manufacturer's documentation!

Precautionary statements warn of hazards in handling software and devices and provide information on their prevention. They are classified by hazard severity and divided into the following groups:

⚠ DANGER
Danger indicates hazards for persons. If you do not follow the avoidance instructions, the hazard will result in death or severe injury .
⚠ WARNING
Warning indicates hazards for persons. If you do not follow the avoidance instructions, the hazard could result in death or serious injury .
⚠ CAUTION
Caution indicates hazards for persons. If you do not follow the avoidance instructions, the hazard could result in minor or moderate injury .
NOTICE
Notice indicates danger to material or data. If you do not follow the avoidance instructions, the hazard could result in property damage .

Sequence of information in precautionary statements


All precautionary statements comprise the following four sections:


- Signal word indicating the hazard severity
- Type and source of hazard
- Consequences of ignoring the hazard, e.g.: "There is danger of collision during subsequent machining operations"
- Escape – Hazard prevention measures


Informational notes

Observe the informational notes provided in these instructions to ensure reliable and efficient operation of the software.

In these instructions, you will find the following informational notes:

 The information symbol indicates a **tip**.
A tip provides important additional or supplementary information.

 This symbol prompts you to follow the safety precautions of your machine manufacturer. This symbol also indicates machine-dependent functions. Possible hazards for the operator and the machine are described in the machine manual.

 The book symbol indicates a **cross reference**.
A cross reference leads to external documentation for example the documentation of your machine manufacturer or other supplier.

1.4 Notes on using NC programs


NC programs contained in this User's Manual are suggestions for solutions. The NC programs or individual NC blocks must be adapted before being used on a machine.

Change the following contents as needed:

- Tools
- Cutting parameters
- Feed rates
- Clearance height or safe position
- Machine-specific positions, positions (e.g., with **M91**)
- Paths of program calls

Some NC programs depend on the machine kinematics. Adapt these NC programs to your machine kinematics before the first test run.

In addition, test the NC programs using the simulation before the actual program run.

 With a program test you determine whether the NC program can be used with the available software options, the active machine kinematics and the current machine configuration.

1.5 User's Manual as integrated product aid: TNCguide

Application

The integrated product aid **TNCguide** offers the full content of all User's Manuals.

Further information: "Available user documentation", Page 35

The User's Manual supports you in the safe handling of the control according to its intended use.

Further information: "Proper and intended use", Page 45

Related topics

- The **Help** workspace

Further information: User's Manual for Programming and Testing

Requirement

In the factory default setting, the control offers the integrated product aid **TNCguide** in German and English language versions.

If the control cannot find a **TNCguide** language version matching the selected dialog language, it opens **TNCguide** in English.

If the control cannot find a **TNCguide** language version, it opens an information page with instructions. With the link available there and the steps provided, you can supplement the files missing in the control.



You can also open the information page manually by selecting the **index.html** file (for example, at **TNC:\tncguide\en\readme**). The path depends on the desired language version (e.g., **en** for English).

With the steps provided you can also update the **TNCguide** version. Updating may be required (e.g., after a software update).

Description of function

The integrated product aid **TNCguide** can be selected within the **Help** application or in the **Help** workspace.


Further information: "The Help application", Page 39

Further information: User's Manual for Programming and Testing

Operation of **TNCguide** is identical in both cases.

Further information: "Icons", Page 40

The Help application



Open **TNCguide** in the **Help** workspace






TNCguide includes the following areas:

- 1 Title bar of the **Help** workspace
Further information: "The Help workspace", Page 40
- 2 Title bar of the integrated product aid **TNCguide**
Further information: "TNCguide ", Page 40
- 3 Content column of **TNCguide**
- 4 Separator between the columns of **TNCguide**
Adjust the column width by means of the separator.
- 5 Navigation column of **TNCguide**

Icons






The Help workspace

The **Help** workspace within the **Help** application includes the following icons:

Icon	Meaning
	Open or close the Search results column Further information: "Search in TNCguide", Page 41
	Open Home page The start page displays all available documentation. Select the desired documentation using navigation tiles (e.g., TNCguide). If only one piece of documentation is available, the control opens the content directly. When a documentation is open, you can use the search function.
	Open Tutorials
	Navigate Navigate between the contents opened recently
	Refresh

TNCguide



The integrated **TNCguide** product aid includes the following icons:

Icon	Meaning
	Open Structure The structure consists of the content headings. The structure serves for main navigation within the documentation.
	Open Index The index consists of important keywords. The index serves as an alternative navigation within the documentation.
	Navigate Display previous or next page within the documentation
	Open or close Display or hide the navigation
	Copy Copy NC examples to the clipboard Further information: "Copying NC examples to clipboard", Page 42

Context-sensitive help

You can open **TNCguide** for the current context. Context-sensitive help means that the relevant information is displayed directly (e.g., for the selected item or the current NC function).

To call context-sensitive help, the following elements are available:

Icon or key	Meaning
	<p>Help icon</p> <p>If you select the icon and then one of the items in the user interface, the control will open the associated information in TNCguide.</p>
	<p>HELP key</p> <p>If you press the HELP key while editing an NC block, the control will display the associated information in TNCguide.</p>

If you call TNCguide in a certain context, the control opens the contents in a pop-up window. If you select the **Show more** button, the control will open **TNCguide** in the **Help** application.

Further information: "The Help application", Page 39

If the **Help** workspace is already open, the control displays **TNCguide** there and will not open a pop-up window.


Further information: User's Manual for Programming and Testing

1.5.1 Search in TNCguide

Using the search function, you can search for the entered search terms within the open documentation.

Use the search function as follows:

- ▶ Enter a character string

 The entry field is located in the title bar, to the left of the Home symbol that you use for navigating to the start page.

The search starts automatically after you enter a character.

If you wish to delete the entry, use the X symbol within the entry field.

- > The control opens the column containing the search results.
- > The control marks references also within open content pages.
- ▶ Select the reference
- > The control opens the selected content.
- > The control continues displaying the results of the last search.
- ▶ Select an alternative reference if necessary
- ▶ Enter a new character string if required

1.5.2 Copying NC examples to clipboard

Use the copy function to copy NC examples from the documentation to the NC editor.

To use the copy function:

- ▶ Navigate to the desired NC example
- ▶ Expand **Notes on using NC programs**
- ▶ Read and follow **Notes on using NC programs**

Further information: "Notes on using NC programs", Page 37



- ▶ Copy NC example to clipboard



- > The button switches colors while copying.
 - > The clipboard contains the entire content of the copied NC example.
 - ▶ Insert the NC example into the NC program
 - ▶ Adapt the inserted content according to the **Notes on using NC programs**
 - ▶ Use the Simulation mode to test the NC program
- Further information:** User's Manual for Programming and Testing

1.6 Contacting the editorial staff

Have you found any errors or would you like to suggest changes?

We are continuously striving to improve our documentation for you. Please help us by sending your suggestions to the following e-mail address:

tnc-userdoc@heidenhain.de

2

About the Product

2.1 The TNC7 basic

Every HEIDENHAIN control supports you with dialog-guided programming and finely detailed simulation. The TNC7 basic additionally offers you graphical or form-based programming so that you can attain the desired results with speed and reliability.

Software options and optional hardware extensions can be used for flexibly increasing the range of functions and ease of use.

Operation is made easier, for example, by using touch probes, handwheels or a 3D mouse.

Further information: "Hardware enhancements", Page 61

Definitions

Abbreviation	Definition
TNC	TNC is derived from the acronym CNC (computerized numerical control). The T (tip or touch) stands for the capability of entering NC programs directly at the control or to program them graphically using gestures.
7	The product number indicates the control generation. The range of functions depends on the enabled software options.
basic	The addition basic indicates that the control provides all required basic functions for universal milling or drilling.

2.1.1 Proper and intended use

The information about proper and intended use supports you in safely handling a product such as a machine tool.

The control is a machine component but not a complete machine. This User's Manual describes the use of the control. Before using the machine including the control, take the OEM documentation to inform yourself about the safety-related aspects, the necessary safety equipment as well as the requirements on the qualified personnel.

i HEIDENHAIN sells controls designed for milling and turning machines as well as for machining centers with up to 24 axes. If you as a user face a different constellation, then contact the owner immediately.

HEIDENHAIN contributes additionally to enhancing your safety and that of your products, notably by taking into consideration the customer feedback. This results, for example, in function adaptations of the controls and safety precautions in the information products.

i Contribute actively to increasing the safety by reporting any missing or misleading information.
Further information: "Contacting the editorial staff", Page 42

2.1.2 Intended place of operation

In accordance with the DIN EN 50370-1 standard for electromagnetic compatibility (EMC), the control is approved for use in industrial environments.

Definitions

Guideline	Definition
DIN EN 50370-1:2006-02	This standard deals, among other things, with interference emissions and immunity to interference of machine tools.

2.2 Safety precautions

Comply with all safety precautions indicated in this document and in your machine manufacturer's documentation!

The following safety precautions refer exclusively to the control as an individual component but not to the specific complete product, i.e. the machine tool.



Refer to your machine manual.

Before using the machine including the control, take the OEM documentation to inform yourself about the safety-related aspects, the necessary safety equipment as well as the requirements on the qualified personnel.

The following overview contains exclusively the generally valid safety precautions. Pay attention to additional safety precautions that may vary with the configuration and are given in the following chapters.



For ensuring maximum safety, all safety precautions are repeated at the relevant places within the chapters.

DANGER

Caution: hazard to the user!

Unsecured connections, defective cables, and improper use are always sources of electrical dangers. The hazard starts when the machine is powered up!

- ▶ Devices should be connected or removed only by authorized service technicians
- ▶ Only switch on the machine via a connected handwheel or a secured connection

DANGER

Caution: hazard to the user!

Machines and machine components always pose mechanical hazards. Electric, magnetic, or electromagnetic fields are particularly hazardous for persons with cardiac pacemakers or implants. The hazard starts when the machine is powered up!

- ▶ Read and follow the machine manual
- ▶ Read and follow the safety precautions and safety symbols
- ▶ Use the safety devices

WARNING

Caution: hazard to the user!

Manipulated data records or software can lead to an unexpected behavior of the machine. Malicious software (viruses, Trojans, malware, or worms) can cause changes to data records and software.

- ▶ Check any removable memory media for malicious software before using them
- ▶ Start the internal web browser only from within the sandbox

NOTICE**Danger of collision!**

Failure to notice deviations between the actual axis positions and those expected by the control (saved at shutdown) can lead to undesirable and unexpected axis movements. There is risk of collision during the reference run of further axes and all subsequent movements!

- ▶ Check the axis positions
- ▶ Only confirm the pop-up window with **YES** if the axis positions match
- ▶ Despite confirmation, at first only move the axis carefully
- ▶ If there are discrepancies or you have any doubts, contact your machine manufacturer

NOTICE**Caution: Danger to the tool and workpiece!**

A power failure during the machining operation can cause uncontrolled "coasting" or braking of the axes. In addition, if the tool was in effect prior to the power failure, then the axes cannot be referenced after the control has been restarted. For non-referenced axes, the control takes over the last saved axis values as the current position, which can deviate from the actual position. Thus, subsequent traverse movements do not correspond to the movements prior to the power failure. If the tool is still in effect during the traverse movements, then the tool and the workpiece can sustain damage through tension!

- ▶ Use a low feed rate
- ▶ Please keep in mind that the traverse range monitoring is not available for non-referenced axes

NOTICE**Danger of collision!**

The control does not automatically check whether collisions can occur between the tool and the workpiece. Incorrect pre-positioning or insufficient spacing between components can lead to a risk of collision when referencing the axes.

- ▶ Pay attention to the information on the screen
- ▶ If necessary, move to a safe position before referencing the axes
- ▶ Watch out for possible collisions

NOTICE**Danger of collision!**

The control uses the defined tool length from the tool table for compensating for the tool length. Incorrect tool lengths will result in an incorrect tool length compensation. The control does not perform tool length compensation or a collision check for tools with a length of **0** and after a **TOOL CALL 0**. There is a risk of collision during subsequent tool positioning movements!

- ▶ Always define the actual tool length of a tool (not just the difference)
- ▶ Use **TOOL CALL 0** only to empty the spindle

NOTICE**Caution: Significant property damage!**

Undefined fields in the preset table behave differently from fields defined with the value **0**: Fields defined with the value **0** overwrite the previous value when activated, whereas with undefined fields the previous value is kept. If the previous value is kept, there is a danger of collision!

- ▶ Before activating a preset, check whether all columns contain values.
- ▶ For undefined columns, enter values (e.g., **0**)
- ▶ As an alternative, have the machine manufacturer define **0** as the default value for the columns

NOTICE**Danger of collision!**

NC programs that were created on older controls can lead to unexpected axis movements or error messages on current control models. Danger of collision during machining!

- ▶ Check the NC program or program section using the graphic simulation
- ▶ Carefully test the NC program or program section in the **Program run, single block** operating mode

NOTICE**Caution: Data may be lost!**

If you do not properly remove a connected USB device during a data transfer, then data may be damaged or deleted!

- ▶ Use the USB port only for transferring or backing up data do not use it for editing and executing NC programs
- ▶ Use the **Eject** soft key to remove a USB device when data the transfer is complete

NOTICE**Caution: Data may be lost!**

The control must be shut down so that running processes can be concluded and data can be saved. Immediate switch-off of the control by turning off the main switch can lead to data loss regardless of the control's status!

- ▶ Always shut down the control
- ▶ Only operate the main switch after being prompted on the screen

NOTICE


Danger of collision!

If you select an NC block in program run using the **GOTO** function and then execute the NC program, the control ignores all previously programmed NC functions (e.g., transformations). This means that there is a risk of collision during subsequent traversing movements!


- ▶ Use **GOTO** only when programming and testing NC programs
- ▶ Only use **Block scan** when executing NC programs

2.3 Software

This User's Manual describes the functions for setting up the machine as well as for programming and running your NC programs. These functions are available for a control featuring the full range of functions.


 The actual range of functions depends, among other things, on the enabled software options.
Further information: "Software options", Page 50

The table shows the NC software numbers described in this User's Manual.

 HEIDENHAIN has simplified the version schema, starting with NC software version 16:

- The publication period determines the version number.
- All control models of a publication period have the same version number.
- The version number of the programming stations corresponds to the version number of the NC software.

NC software number	Product
817620-18	TNC7 basic
817625-18	TNC7 basic Programming Station

 Refer to your machine manual.

This User's Manual describes the basic functions of the control. The machine manufacturer can adapt, enhance or restrict the control functions to the machine.

Check, on the basis of the machine tool manual, whether the machine manufacturer has adapted the functions of the control.

If later customization of the machine configuration by the machine manufacturer is intended, the machine operator might incur additional costs.

2.3.1 Software options

Software options define the range of functions of the control. The optional functions are either machine- or application-specific. The software options give you the possibility of adapting the control to your individual needs.

You can check which software options are enabled on your machine.

Further information: "Viewing of software options", Page 444

The TNC7 basic features various software options that the machine manufacturer may enable separately, even at a later point in time. The following overview includes only those software options that are relevant for you.

The software options are saved on the **SIK** (System Identification Key) plug-in board. The TNC7 basic can be equipped with a **SIK1** or **SIK2** plug-in board. Depending on which one is used, the numbers of the software options differ.



The option numbers in parentheses given in the User's Manual show you that a function is not included in the standard range of available functions. The parentheses enclose the **SIK1** and **SIK2** option numbers, separated by a slash, for example: (#18 / #3-03-1). The Technical Manual informs about additional software options that are relevant to the machine manufacturer.

SIK2 definitions

SIK2 option numbers are structured by <class>-<option>-<version>:

Class	The function is effective for the following areas: <ul style="list-style-type: none"> ■ 1: Programming, simulation, and process setup ■ 2: Part quality and productivity ■ 3: Interfaces ■ 4: Technology functions and quality assessment ■ 5: Process stability and monitoring ■ 6: Machine configuration ■ 7: Developer tools
Option	Sequential number within each class
Version	New versions of software options are released if, for example, its features have been changed.

You can order some software options with **SIK2** more than once in order to obtain multiple variants of the same function (e.g., if you need to enable multiple control loops for the axes). In the User's Manual, these software option numbers are identified by an asterisk (*).

The control indicates in the **SIK** menu item of the **Settings** application whether a software option has been enabled, and if so, how often.

Further information: "The SIK menu item", Page 443

Overview



Keep in mind that particular software options also require hardware extensions.

Further information: "Hardware", Page 56

Software option	Definition and application
Control Loop Qty. (#0-3 / #6-01-1*)	<p>Additional control loop</p> <p>A control loop is required for each axis or spindle moved to a programmed nominal value by the control.</p> <p>Additional control loops are required, for example, for detachable and motor-driven tilting tables.</p> <p>If your control features a SIK2, you can order this software option multiple times and enable up to 8 control loops.</p>
Adv. Function Set 1 (#8 / #1-01-1)	<p>Advanced functions (set 1)</p> <p>On machines with rotary axes this software option enables the machining of multiple workpiece sides in a single setup.</p> <p>The software option includes the following functions:</p> <ul style="list-style-type: none"> ■ Tilting the working plane (e.g., with PLANE SPATIAL) Further information: User's Manual for Programming and Testing ■ Programming of contours on a developed cylindrical surface (e.g., with Cycle 27 CYLINDER SURFACE) Further information: User's Manual for Machining Cycles ■ Programming the rotary axis feed rate in mm/min with M116 Further information: User's Manual for Programming and Testing ■ 3-axis circular interpolation with a tilted working plane <p>The advanced functions (set 1) reduce the setup effort and increase the workpiece accuracy.</p>
Adv. Function Set 2 (#9 / #4-01-1)	<p>Advanced functions (set 2)</p> <p>On machines with rotary axes, this software option enables simultaneous 4-axis machining of workpieces.</p> <p>The software option includes the following functions:</p> <ul style="list-style-type: none"> ■ TCPM (tool center point management): Automatic tracking of linear axes during rotary axis positioning Further information: User's Manual for Programming and Testing ■ Running of NC programs with vectors, including optional 3D tool compensation Further information: User's Manual for Programming and Testing ■ Manual moving of axes in the active tool coordinate system T-CS
Touch Probe Function (#17 / #1-05-1)	<p>Touch-probe functions</p> <p>This software option is used to program and execute automatic probing processes.</p> <p>If you are using a HEIDENHAIN touch probe with EnDat interface, then the software option Touch Probe Functions (#17 / #1-05-1) is automatically enabled.</p> <p>The software option includes the following functions:</p> <ul style="list-style-type: none"> ■ Automatic compensation of workpiece misalignment ■ Automatic setting of workpiece presets ■ Automatic measurement of workpieces ■ Automatic measurement of tools <p>The touch-probe functions reduce the setup effort and increase accuracy when machining workpieces.</p> <p>Further information: "Tastsystemfunktionen in der Betriebsart Manuell", Page</p>

Software option	Definition and application
HEIDENHAIN DNC (#18 / #3-03-1)	<p>HEIDENHAIN DNC</p> <p>This software option enables external Windows applications to access data of the control via the TCP/IP protocol.</p> <p>Potential fields of application include:</p> <ul style="list-style-type: none"> ■ Connection to higher-level ERP or MES systems ■ Capture of machine and operating data <p>HEIDENHAIN DNC is required in conjunction with external Windows applications.</p>
Adv. Function Set 3 (#21 / #4-02-1)	<p>Advanced functions (set 3)</p> <p>This software option offers additional ease of use with two powerful miscellaneous functions.</p> <p>The software option includes the following miscellaneous functions:</p> <ul style="list-style-type: none"> ■ M120 for machining small contour steps without error message and contour damage Further information: User's Manual for Programming and Testing ■ M118 for superimposed handwheel positioning during program run Further information: User's Manual for Programming and Testing <p>The advanced functions (set 3) reduce the setup effort and increase flexibility during program run.</p>
Collision Monitoring (#40 / #5-03-1)	<p>Dynamic Collision Monitoring (DCM)</p> <p>The machine manufacturer can use this software option to define machine components as collision objects. The control monitors the defined collision objects during all machine movements.</p> <p>The software option includes the following functions:</p> <ul style="list-style-type: none"> ■ Automatic interruption of program run whenever a collision is imminent ■ Warnings in case of manual axis movements ■ Collision monitoring in Test Run mode <p>With DCM you can prevent collisions and thus avoid additional costs resulting from material damage or machine downtime.</p> <p>Further information: "Dynamic Collision Monitoring (DCM) (#40 / #5-03-1)", Page 206</p>
CAD Import (#42 / #1-03-1)	<p>CAD Import</p> <p>This software option is used to select positions and contours from CAD files and to transfer them into an NC program.</p> <p>With the CAD Import option you reduce the programming effort and prevent typical errors such as the incorrect entry of values. In addition, CAD Import contributes to paperless manufacturing.</p> <p>Further information: "Loading contours and positions to NC programs with CAD Import (#42 / #1-03-1)", Page 258</p>
Adaptive Feed Contr. (#45 / #2-31-1)	<p>Adaptive Feed Control (AFC)</p> <p>This software option enables an automatic feed control that depends on the current spindle load. The control increases the feed rate as the load decreases and reduces the feed rate as the load increases.</p> <p>With AFC you can shorten machining times without adapting the NC program, while at the same time preventing machine damage from overload.</p> <p>Further information: "Adaptive feed control (AFC) (#45 / #2-31-1)", Page 236</p>

Software option	Definition and application
KinematicsOpt (#48 / #2-01-1)	<p>KinematicsOpt</p> <p>This software option uses automatic probing processes to check and optimize the active kinematics.</p> <p>With KinematicsOpt the control can correct position errors on rotary axes and thus increase the accuracy of machining operations in the tilted working plane and of simultaneous machining operations. In part, the control can compensate for temperature-induced deviations through repeated measurements and corrections.</p> <p>Further information: User's Manual for Measuring Cycles for Workpieces and Tools</p>
OPC UA NC Server Qty. (#56-61 / #3-02-1*)	<p>OPC UA NC Server</p> <p>These software options include OPC UA, a standardized interface for remote access to the control's data and functions.</p> <p>Potential fields of application include:</p> <ul style="list-style-type: none"> ■ Connection to higher-level ERP or MES systems ■ Capture of machine and operating data <p>Each software option enables one client connection. If more than one parallel connection is required, you need to enable multiple of these software options. If your control features a SIK2, you can order this software option multiple times and enable up to six connections.</p> <p>Further information: "OPC UA NC Server (#56-61 / #3-02-1*)", Page 462</p>
4 Additional Axes (#77 / #6-01-1*)	<p>Four additional control loops</p> <p>Further information: "Control Loop Qty. (#0-3 / #6-01-1*)", Page 51</p>
Ext. Tool Management (#93 / #2-03-1)	<p>Extended tool management</p> <p>This software option extends tool management by the two tables Tooling list and T usage order.</p> <p>The tables show the following contents:</p> <ul style="list-style-type: none"> ■ The Tooling list shows the tool requirements of the NC program or pallet to be run Further information: "Tooling list (#93 / #2-03-1)", Page 384 ■ The T usage order shows the tool order of the NC program or pallet to be run Further information: "T usage order (#93 / #2-03-1)", Page 382 <p>Extended tool management enables you to detect the tool requirements in time and thus prevent interruptions during program run.</p>
Remote Desktop Manager (#133 / #3-01-1)	<p>Remote Desktop Manager</p> <p>This software option is used to display and operate externally linked computer units.</p> <p>With Remote Desktop Manager you reduce the distances covered between several workplaces and as a result increase the efficiency.</p> <p>Further information: "The Remote Desktop Manager window (#133 / #3-01-1)", Page 477</p>

Software option	Definition and application
Collision Monitoring (#140 / #5-03-2)	<p>Dynamic Collision Monitoring DCM version 2</p> <p>This software option includes all functions of the Dynamic Collision Monitoring DCM (#40 / #5-03-1) software option.</p> <p>In addition, this software option provides the following features:</p> <ul style="list-style-type: none"> ■ Collision monitoring of fixtures <p>Further information: "Integrating fixtures into collision monitoring (#140 / #5-03-2)", Page 216</p> <ul style="list-style-type: none"> ■ Define reduced minimum distance between fixture and tool
Cross Talk Comp. (#141 / #2-20-1)	<p>Compensation of axis couplings (CTC)</p> <p>Using this software option, the machine manufacturer can, for example, compensate for acceleration-induced deviations at the tool and thus increase accuracy and dynamic performance.</p>
Position Adapt. Contr. (#142 / #2-21-1)	<p>Position Adaptive Control (PAC)</p> <p>Using this software option, the machine manufacturer can, for example, compensate for position-induced deviations at the tool and thus increase accuracy and dynamic performance.</p>
Load Adapt. Contr. (#143 / #2-22-1)	<p>Load Adaptive Control (LAC)</p> <p>Using this software option, the machine manufacturer can, for example, compensate for load-induced deviations at the tool and thus increase accuracy and dynamic performance.</p>
Motion Adapt. Contr. (#144 / #2-23-1)	<p>Motion Adaptive Control (MAC)</p> <p>Using this software option, the machine manufacturer can, for example, change speed-dependent machine settings and thus increase the dynamic performance.</p>
Active Chatter Contr. (#145 / #2-30-1)	<p>Active Chatter Control (ACC)</p> <p>With this software option the chatter tendency of a machine used for heavy machining can be reduced.</p> <p>The control can use ACC to improve the surface quality of the workpiece, increase the tool life and reduce the machine load. Depending on the type of machine, the metal-removal rate can be increased by more than 25%.</p> <p>Further information: "Active Chatter Control (ACC) (#145 / #2-30-1)", Page 245</p>
Machine Vibr. Contr. (#146 / #2-24-1)	<p>Vibration damping for machines (MVC)</p> <p>Damping of machine oscillations for improving the workpiece surface quality through the following functions:</p> <ul style="list-style-type: none"> ■ AVD Active Vibration Damping ■ FSC Frequency Shaping Control
CAD Model Optimizer (#152 / #1-04-1)	<p>Optimization of CAD models</p> <p>This software option can be used, for example, to repair faulty files of fixtures and tool holders or to position STL files generated from the simulation for a different machining operation.</p> <p>Further information: "Generating STL files with 3D mesh (#152 / #1-04-1)", Page 264</p>

Software option	Definition and application
Batch Process Mngr. (#154 / #2-05-1)	<p data-bbox="539 360 911 394">Batch Process Manager (BPM)</p> <p data-bbox="539 398 1417 465">This software option makes it easy to plan and execute multiple production jobs.</p> <p data-bbox="539 470 1461 566">By extending and combining the pallet management and extended tool management functions (#93 / #2-03-1), the BPM offers the following additional data, for example:</p> <ul data-bbox="539 571 1123 723" style="list-style-type: none"> <li data-bbox="539 571 759 604">■ Machining time <li data-bbox="539 609 922 642">■ Availability of necessary tools <li data-bbox="539 647 962 680">■ Manual interventions to be made <li data-bbox="539 685 1123 719">■ Program test results of assigned NC programs <p data-bbox="539 723 1307 763">Further information: User's Manual for Programming and Testing</p>
Component Monitoring (#155 / #5-02-1)	<p data-bbox="539 779 818 813">Component monitoring</p> <p data-bbox="539 817 1417 884">This software option enables the automatic monitoring of machine components configured by the machine manufacturer.</p> <p data-bbox="539 889 1453 954">Component monitoring assists the control in preventing machine damage due to overload by way of hazard warnings and error messages.</p>
Model Aided Setup (#159 / #1-07-1)	<p data-bbox="539 969 879 1003">Graphically supported setup</p> <p data-bbox="539 1008 1417 1133">This software option is used to determine the position and misalignment of a workpiece with only one touch-probe function. You can probe complex workpieces with, for example, free-form surfaces or undercuts, which is not possible with all of the other touch-probe functions.</p> <p data-bbox="539 1137 1430 1205">The control supports you additionally by showing the setup situation and possible touch points in the Simulation workspace by means of a 3D model.</p>
Opt. Contour Milling (#167 / #1-02-1)	<p data-bbox="539 1220 979 1254">Optimized contour machining (OCM)</p> <p data-bbox="539 1258 1445 1361">This software option enables trochoidal milling of closed or open pockets and islands of any shape. During trochoidal milling, the full cutting edge is used under constant cutting conditions.</p> <p data-bbox="539 1366 1118 1400">The software option includes the following cycles:</p> <ul data-bbox="539 1404 1410 1626" style="list-style-type: none"> <li data-bbox="539 1404 956 1438">■ Cycle 271 OCM CONTOUR DATA <li data-bbox="539 1442 895 1476">■ Cycle 272 OCM ROUGHING <li data-bbox="539 1480 1410 1514">■ Cycle 273 OCM FINISHING FLOOR and Cycle 274 OCM FINISHING SIDE <li data-bbox="539 1518 927 1552">■ Cycle 277 OCM CHAMFERING <li data-bbox="539 1556 1390 1626">■ In addition, the control offers OCM STANDARD FIGURES for frequently needed contours <p data-bbox="539 1630 1433 1697">With OCM you can shorten machining times while at the same time reducing tool wear.</p> <p data-bbox="539 1702 1206 1736">Further information: User's Manual for Machining Cycles</p>

2.3.2 Information on licensing and use

Open-source software

The control software contains open-source software whose use is subject to explicit licensing terms. These special terms of use have priority.

To get to the licensing terms on the control:



- ▶ Select the **Home** operating mode

- ▶ Select the **Settings** application
- ▶ Select the **Operating system** tab



- ▶ Double-tap or double-click **About HeROS**
- > The control opens the **HEROS Licence Viewer** window.

OPC UA

The control software contains binary libraries, to which the terms of use agreed between HEIDENHAIN and Softing Industrial Automation GmbH additionally and preferentially apply.

The control's behavior can be influenced by means of the OPC UA NC Server (#56-61 / #3-02-1*) and HEIDENHAIN DNC (#18 / #3-03-1). Before using these interfaces for productive purposes, system tests must be performed to exclude the occurrence of any malfunctions or performance failures of the control. The manufacturer of the software product that uses these communication interfaces is responsible for performing these tests.

Further information: "OPC UA NC Server (#56-61 / #3-02-1*)", Page 462


2.4 Hardware

This User's Manual describes functions for setting up and operating the machine. These functions primarily depend on the installed software.

Further information: "Software", Page 49

The actual range of functions also depends on hardware enhancements and the enabled software options.

2.4.1 Touchscreen and keyboard unit



16" MC 345 with TE 340 (FS)

The TNC7 basic is delivered with a 16-inch screen.

The control is operated by means of touchscreen gestures and with the controls of the keyboard unit.

Further information: "Common gestures for the touchscreen", Page 70

Further information: "Operating elements of the keyboard unit", Page 70

The machine operating panel is machine-dependent.



MB 340 (FS)

Operating and cleaning the touchscreen

Touchscreens can even be operated with dirty hands, as long as the touch sensors are able to detect the skin resistance. Small amounts of liquid do not affect the function of the touchscreen, but large amounts may cause incorrect input.

Switch off the control before cleaning the touchscreen. As an alternative, you can use the touchscreen cleaning mode.

Further information: "The Settings Application", Page 435

Do not apply the cleaning agent directly to the screen, but slightly dampen a clean, lint-free cleaning cloth with it.

The following cleaning agents are permitted for the screen:

- Glass cleaner
- Foaming screen cleaners
- Mild detergents

The following cleaning agents are prohibited for the screen:

- Aggressive solvents
- Abrasives
- Compressed air
- Steam cleaners



- Touchscreens are sensitive to electrostatic charges from the user. Dissipate the static charge by touching metallic, grounded objects or wear ESD clothing.
- Wear operating gloves to prevent the screen from getting dirty.
- You can operate the touchscreen with special touchscreen operating gloves.

Cleaning the keyboard unit

Switch the control off before cleaning the keyboard unit.

NOTICE

Caution: danger of property damage

Incorrect cleaning agents and incorrect cleaning procedures can damage the keyboard unit or parts of it.


- ▶ Use permitted cleaning agents only
- ▶ Use a clean, lint-free cleaning cloth to apply the cleaning agent

The following cleaners are permitted for the keyboard unit:

- Cleaning agents containing anionic surfactants
- Cleaning agents containing nonionic surfactants

The following cleaning agents are prohibited for the keyboard unit:


- Cleaning agents for machines
- Acetone
- Aggressive solvents
- Abrasives
- Compressed air
- Steam cleaners

 Wear work gloves to prevent the keyboard unit from getting dirty.

If a trackball is embedded in the keyboard, you need to clean it only if it no longer works properly.

To clean a trackball (if needed):

- ▶ Shut down the control
- ▶ Turn the pull-off ring by 100° in counterclockwise direction
- > Turning the removable pull-off ring moves it upwards out of the keyboard unit.
- ▶ Remove the pull-off ring
- ▶ Take out the ball
- ▶ Carefully remove sand, chips, or dust from the shell area

 Scratches in the shell area may impair the functionality or prevent proper functioning.

- ▶ Apply a small amount of the cleaning agent onto a cleaning cloth
- ▶ Carefully wipe the shell area clean with the cloth until all smears or stains have been removed

Exchanging keycaps


If you need replacements for the keycaps of the keyboard unit, contact HEIDENHAIN or the machine manufacturer.

Further information: "Keycaps for keyboard units and machine operating panels", Page



IP54 protection cannot be guaranteed if the keyboard is missing any keys.


To exchange the keycaps:




- ▶ Slide the keycap puller (ID 1325134-01) over the keycap until the grippers engage



Pressing the key will make it easier to apply the keycap puller.



- ▶ Pull off the keycap



- ▶ Place the keycap onto the seal and push it down



The seal must not be damaged; otherwise IP54 protection cannot be guaranteed.

- ▶ Verify proper seating and correct functionality



2.4.2 Hardware enhancements

The hardware enhancements give you the possibility of adapting the machine tool to your individual needs.


The TNC7 basic features various hardware extensions that the machine manufacturer may add separately, even at a later point in time. The following overview includes only those extensions that are relevant to you.

i Keep in mind that particular hardware enhancements require additional software options.
Further information: "Software options", Page 50

Hardware enhancements	Definition and application
Electronic handwheels	<p>You use this enhancement for exact manual positioning of machine axes. The wireless portable variants improve ergonomics and increase versatility. The handwheels have the following differing features:</p> <ul style="list-style-type: none"> ■ Portable or installed in the machine operating panel ■ With or without display ■ With or without functional safety <p>Electronic handwheels, for example, greatly simplify workpiece setup. Further information: "Electronic Handwheel", Page 401</p>
Workpiece touch probes	<p>With this extension, the control can determine locations on the workpiece and misalignments automatically and precisely (#17 / #1-05-1). The workpiece touch probes have the following differing features:</p> <ul style="list-style-type: none"> ■ With radio or infrared transmission ■ With or without cable <p>Workpiece touch probes, for example, are useful for quick workpiece setup and for automatic correction of dimensions during program run. Further information: "Touch Probe Functions in the Manual Operating Mode (#17 / #1-05-1)", Page 289</p>
Tool touch probes	<p>With this extension, the control can measure tools automatically and precisely, directly in the machine (#17 / #1-05-1). Tool touch probes have the following differing features:</p> <ul style="list-style-type: none"> ■ Contact-free or tactile measurement ■ With radio or infrared transmission ■ With or without cable <p>Tool touch probes, for example, are useful for quick workpiece setup and for automatic correction of dimensions and breakage control during program run. Further information: User's Manual for Measuring Cycles for Workpieces and Tools</p>

Hardware enhancements	Definition and application
Vision systems	<p>Use this enhancement to inspect the tools used.</p> <p>With the VT 121 vision system, you can visually inspect the cutting edges during program run without removing the tool.</p> <p>The vision systems help to avoid damage during program run, thus preventing unnecessary costs.</p> <div data-bbox="539 589 1461 797" style="border: 1px solid black; padding: 5px;"> <p> VTC User's Manual</p> <p>All functions of the software for the VT 121 vision system are described in the VTC User's Manual. Please contact HEIDENHAIN if you require a copy of this User's Manual.</p> <p>ID: 1322445-xx</p> </div>
Additional operating stations	<p>This enhancement adds a second screen, to facilitate operation of the control. The additional ITC (industrial thin client) operating stations are differentiated by their intended use:</p> <ul style="list-style-type: none"> ■ The ITC 755 is a compact, additional operating station that mirrors the control's main screen, making it possible to operate the control. ■ The ITC 860 is an auxiliary screen that increases the area of the main screen. This allows multiple applications to be viewed simultaneously. <div data-bbox="576 1066 1461 1167" style="border: 1px solid black; padding: 5px;"> <p> By adding a keyboard unit, the ITC 860 can be used as a full-fledged additional operating station.</p> </div> <p>The additional operating stations increase operator comfort, especially on large machining centers.</p>
Industrial PC	<p>You use this enhancement to install and run Windows-based applications. With Remote Desktop Manager (#133 / #3-01-1), you can display applications on the control screen.</p> <p>Further information: "The Remote Desktop Manager window (#133 / #3-01-1)", Page 477</p> <p>The industrial PC is a secure and powerful alternative to external PCs.</p>
Override controller	<p>This extension allows you to define breakpoints at which the control stops during program run (e.g., before a tilting function). The override controller enables the feed rate or rapid traverse value to be changed as well as starting or continuing the NC program.</p> <p>Further information: "Override Controller", Page 415</p>

2.5 Areas of the control's user interface



User interface of the control in the **Manual operation** application

The control's user interface shows the following areas:

- 1 TNC bar
 - Back

Use this function to go backwards in the application history since booting the control.
 - Operating modes

Further information: "Overview of the operating modes", Page 64
 - Status overview

Further information: "Status overview on the TNC bar", Page 103
 - Calculator

Further information: User's Manual for Programming and Testing
 - Screen keyboard

Further information: "Virtual keyboard of the control bar", Page 270
 - Settings

The Settings menu enables you to change the control interface:

 - **Left-hand mode**

The control swaps the positions of the TNC bar and the machine manufacturer bar.
 - **Dark Mode**

In the machine parameter **darkModeEnable** (no. 135501), the machine manufacturer defines whether **Dark Mode** is available for selection.
 - **Font size**
 - Date and time

- 2 Information bar
 - Active operating mode
 - Message menu

Further information: "Message menu on the information bar", Page 274
 - **Help** icon for context-sensitive help

Further information: "Context-sensitive help", Page 41
 - Symbols
- 3 Application bar
 - Tabs of opened applications

The maximum number of simultaneously opened applications is limited to ten tabs. If you try to open an eleventh tab, the control shows a message.
 - Selection menu for workspaces

With the selection menu you define which workspaces are open in the active application.
- 4 Workspaces

Further information: "Workspaces", Page 66
- 5 Machine manufacturer bar




The machine manufacturer configures the machine manufacturer bar.
- 6 Function bar
 - Selection menu for buttons






With the selection menu you define which buttons the control displays in the function bar.
 - Button

With the buttons you activate individual functions of the control.

2.6 Overview of the operating modes


The control provides the following operating modes:

Icon	Operating modes	Further information
	<p>The Home operating mode contains the following applications:</p> <ul style="list-style-type: none"> ■ The Start/Login application <p>During the startup process, the control is in the Start/Login application.</p> ■ The Settings application ■ The Help application ■ Applications for machine parameters 	<p>Page 435</p> <p>See the User's Manual for Programming and Testing</p> <p>Page 491</p>
	<p>In the Files operating mode the control displays drives, folders and files. You can, for example, create or delete folders or files and can also connect drives.</p>	<p>See the User's Manual for Programming and Testing</p>
	<p>In the Tables operating mode you can open various tables and edit them as necessary.</p>	<p>Page 350</p>

Icon	Operating modes	Further information
	<p>In the Editor operating mode you can do the following:</p> <ul style="list-style-type: none"> ■ Create, edit and simulate NC programs ■ Create and edit contours ■ Create and edit pallet tables 	See the User's Manual for Programming and Testing
	<p>The Manual operating mode contains the following applications:</p> <ul style="list-style-type: none"> ■ The Manual operation application ■ The MDI Application ■ The Setup application ■ The Move to ref. point application ■ The Retract application <p>You can move the tool away from the workpiece, for example after a power failure.</p>	<p>Page 134</p> <p>Page 279</p> <p>Page 289</p> <p>Page 129</p> <p>Page 346</p>
	<p>In the Program Run operating mode you produce workpieces by having the control execute NC programs either one block at a time or in full sequence.</p> <p>You also execute pallet tables in this operating mode.</p>	Page 324
	<p>If the machine manufacturer has defined an embedded workspace, then you can open full-screen mode with this operating mode. The machine manufacturer defines the name of the operating mode.</p> <p>Refer to your machine manual.</p>	Page 423
	<p>In the Machine operating mode the machine manufacturer defines his own functions, such as diagnostic functions for spindle and axes, or other applications.</p> <p>Refer to your machine manual.</p>	

2.7 Workspaces

2.7.1 Operating elements within the workspaces






The control in the **MDI** application with three open workspaces

The control displays the following operating elements:

- 1 Gripper
Use the gripper in the title bar to change positions of the workspaces. You can also align two workspaces vertically above each other.
- 2 Title bar
In the title bar the control shows the title of the workspace, and different symbols or settings, depending on the workspace.
- 3 Selection menu for workspaces
Use the selection menu for workspaces in the application bar to open individual workspaces. The available workspaces depend on the active application.
- 4 Separator
You use the separator between two workspaces to change the scaling of the workspaces.
- 5 Action bar
In the action bar the control shows selection possibilities for the current dialog; for example, an NC function.

2.7.2 Symbols within the workspaces

If more than one workspace is open, the title bar contains the following symbols:

Symbol	Function
	Maximize workspace
	Reduce workspace
	Close workspace

If you maximize a workspace, the control shows the workspace over the application's entire area. If you reduce the workspace, then all other workspaces return to their previous position.

2.7.3 Overview of workspaces

The control offers the following workspaces:

Workspace	Further information
<p>Probing function (#17 / #1-05-1)</p> <p>In the Probing function workspace you set presets on the workpiece and determine and compensate for workpiece misalignment and rotations. You can also calibrate the touch probe, measure tools, and set up fixtures.</p>	Page 289
<p>Job list</p> <p>In the Job list workspace, you edit and execute pallet tables.</p>	See the User's Manual for Programming and Testing
<p>Open File</p> <p>In the Open File workspace you select or create files, for example.</p>	See the User's Manual for Programming and Testing
<p>Files</p> <p>In the file management, the control displays drives, folders, and files. You can, for example, create or delete folders or files and can also connect drives.</p> <p>The Files workspace is part of the Files operating mode.</p>	See the User's Manual for Programming and Testing
<p>Details</p> <p>In the Details workspace, the control displays information on the selected machine parameter or the last change you made.</p>	Page 496
<p>Document</p> <p>You can open files for viewing in the Document workspace, for example a technical drawing.</p>	See the User's Manual for Programming and Testing
<p>Settings</p> <p>In the Settings workspace, you can display and edit, if required, various settings of the control (e.g., set up the traverse limits).</p> <p>The Settings workspace is part of the Settings application.</p>	Page 435
<p>The Form for tables</p> <p>In the Form workspace, the control shows all contents of a selected table row. Depending on the table, you can edit the values in the form.</p>	Page 360
<p>The Form for pallets</p> <p>In the Form workspace the control shows the contents of the pallet table for the selected row.</p>	See the User's Manual for Programming and Testing

Workspace	Further information
<p>Retract</p> <p>In the Retract workspace, you can disengage the tool after a power interruption.</p>	Page 346
<p>Desktop menu</p> <p>In the Desktop menu workspace, the control displays selected control and HEROS functions.</p>	Page 80
<p>Help</p> <p>In the Help workspace, the control displays a help graphic for the current syntax element of an NC function or the integrated product aid TNCguide.</p>	See the User's Manual for Programming and Testing
<p>Contour graphics</p> <p>In the Contour graphics workspace, you can use lines and arcs to draw a 2D sketch and then generate a Klartext contour from it. You can also import program sections with contours from an NC program to the Contour graphics workspace for graphical editing.</p>	See the User's Manual for Programming and Testing
<p>List</p> <p>In the List workspace, the control shows the machine parameter structure; you might be able to edit some of the parameters.</p>	Page 493
<p>Positions</p> <p>In the Positions workspace, the control displays information about the status of various functions of the control and about current axis positions.</p>	Page 97
<p>Program</p> <p>The control displays the NC program in the Program workspace.</p>	See the User's Manual for Programming and Testing
<p>Referencing</p> <p>On machines with incremental linear and angle encoders, the control shows in the Referencing workspace which axes need to be referenced.</p>	Page 129
<p>Remote Desktop Manager (#133 / #3-01-1)</p> <p>If the machine manufacturer has defined an embedded workspace, you can see and operate the screen of an external computer on the control.</p> <p>The machine manufacturer can change the name of the workspace. Refer to your machine manual.</p>	Page 423
<p>Quick selection</p> <p>In the Quick selection new table and Quick selection new file workspaces, you can create files or open existing files, depending on the active operating mode.</p>	See the User's Manual for Programming and Testing
<p>Simulation</p> <p>In the Simulation workspace, the control shows the simulated or current movements, depending on the operating mode.</p>	See the User's Manual for Programming and Testing
<p>Simulation status</p> <p>In the Simulation status workspace the control shows data based on the simulation of the NC program.</p>	Page 118









Workspace	Further information
<p>Start/Login</p> <p>In the Start/Login workspace, the control shows the steps that are performed during startup.</p>	Page 84
<p>Status</p> <p>In the Status workspace, the control shows the status and values of individual functions.</p>	Page 105
<p>Table</p> <p>In the Table workspace, the control shows the contents of a table. The control displays a column with filters and a search function on the left side of some tables.</p>	Page 354
<p>The Table for machine parameters</p> <p>In the Table workspace the control shows the machine parameters; you might be able to edit some of them.</p>	Page 493
<p>Keyboard</p> <p>In the Keyboard workspace, you can enter NC functions, letters and numbers, and also navigate.</p>	Page 270
<p>Overview</p> <p>In the Overview workspace, the control displays information on the status of individual functional safety (FS) safety functions.</p>	Page 430

2.8 Operating elements

2.8.1 Common gestures for the touchscreen

The screen of the control is multi-touch capable. That means the control can distinguish various gestures, even with two or more fingers at once.

You can use the following gestures:

Symbol	Gesture	Meaning
	Tap	A brief touch by a finger on the screen
	Double tap	Two brief touches on the screen
	Long press	Continuous contact of finger tip on the screen
<div style="border: 1px solid black; padding: 5px; display: inline-block;"> <p>i If you do not stop holding, the control will automatically cancel the holding gesture after approximately ten seconds. Permanent actuation is thus not possible.</p> </div>		
	Swipe	Flowing motion over the screen
	Drag	A combination of long-press and then swipe, moving a finger over the screen when the starting point is clearly defined
	Two-finger drag	A combination of long-press and then swipe, moving two fingers in parallel over the screen when the starting point is clearly defined
	Spread	Two fingers long-press and move away from each other
	Pinch	Two fingers move toward each other

2.8.2 Operating elements of the keyboard unit

Application


You operate the TNC7 basic primarily through the touchscreen, meaning with gestures.

Further information: "Common gestures for the touchscreen", Page 70




In addition, the control's keyboard unit offers keys and other elements for alternative operating sequences.

Description of function







The tables below describe the keyboard unit's operating elements.

 If there are deviations from the virtual keyboard, the table also indicates the corresponding keys on the virtual keyboard.
Further information: "Virtual keyboard of the control bar", Page 270

Keycaps for alphabetic keyboard









Key	Meaning
<div style="display: flex; gap: 5px;"> <div style="border: 1px solid gray; padding: 2px 5px;">A</div> <div style="border: 1px solid gray; padding: 2px 5px;">B</div> <div style="border: 1px solid gray; padding: 2px 5px;">C</div> </div>	Enter texts (e.g., file names)
<div style="border: 1px solid gray; padding: 2px 5px; display: inline-block;">Q</div>	<p>Q</p> <p>With an open NC program, enter a Q parameter formula in the Editor operating mode, or in the Manual operating mode open the Q parameter list window</p> <p>Further information: User's Manual for Programming and Testing</p> <p>By selecting the Q key multiple times, you can switch between Q, QL, and QR.</p>
<div style="display: flex; gap: 5px;"> <div style="border: 1px solid gray; padding: 2px 5px;">Q</div> <div style="border: 1px solid gray; padding: 2px 5px;">QL</div> <div style="border: 1px solid gray; padding: 2px 5px;">QR</div> </div>	
<div style="border: 1px solid gray; padding: 2px 5px; display: inline-block;">ESC</div>	Close windows and context menus
<div style="border: 1px solid gray; padding: 2px 5px; display: inline-block;"></div>	Select the next element; for example, an input field, button, or selection option
<p>SHIFT + TAB</p>	Select the previous element
<div style="border: 1px solid gray; padding: 2px 5px; display: inline-block;">PRT SC</div>	Create screenshot
<div style="border: 1px solid gray; padding: 2px 5px; display: inline-block;"></div>	<p>The DIADUR keys provide the following functions:</p> <ul style="list-style-type: none"> ■ Left DIADUR key Open the HEROS menu ■ Right DIADUR key Open the Remote Desktop Manager connection in the defined desktop <p>Further information: "Connection settings", Page 479</p>
<div style="border: 1px solid gray; padding: 2px 5px; display: inline-block;"></div>	Open the context menu in the Klartext editor or in the text editor

Keycaps for operating aids


Key	Meaning
	Open the Open File workspace in the Editor and Program Run operating modes Further information: User's Manual for Programming and Testing
	Currently no function
	Open and close the message menu Further information: "Message menu on the information bar", Page 274
	Open and close the calculator Further information: User's Manual for Programming and Testing
	Open the Settings application Further information: "The Settings Application", Page 435
	Open the online help Further information: "User's Manual as integrated product aid: TNCguide", Page 38




















Operating modes

i On the TNC7 basic the operating modes of the control are allocated differently than on the TNC 640. For reasons of compatibility and to facilitate ease of operation, the keys on the keyboard unit remain the same. Keep in mind that particular keys no longer activate a change of operating modes but, for example, instead activate a toggle switch.

Key	Meaning
	Open the Manual operation application in the Manual operating mode Further information: "The Manual operation application", Page 134
	Activate and deactivate the electronic handwheel in the Manual operating mode Further information: "Electronic Handwheel", Page 401
	Open the Tool Management tab in the Tables operating mode Further information: "Tool management ", Page 163
	Open the MDI application in the Manual operating mode Further information: "The MDI Application ", Page 279
	Open the Program Run operating mode in Single Block mode Further information: "The Program Run operating mode", Page 324
	Open the Program Run operating mode Further information: "The Program Run operating mode", Page 324
	Open the Editor operating mode Further information: User's Manual for Programming and Testing
	While the NC program is running, open the Simulation workspace in the Editor operating mode Further information: User's Manual for Programming and Testing


















Keycaps for NC dialog

 The following functions are valid for the **Editor** operating mode and the **MDI** application.













Key	Meaning
	In the Insert NC function window, open the Path contour folder in order to select an approach or departure function
	Open the Contour workspace (e.g., to draw a milling contour) Only in the Editor operating mode
	Program a chamfer
	Program a straight line segment
	Program a circular arc with radius entry
	Program a rounding arc
	Program a circular arc with tangential connection to the preceding contour element
	Program a circle center or pole
	Program a circular arc with reference to the circle center
	In the Insert NC function window, open the Setup folder in order to select a touch probe cycle Further information: User's Manual for Measuring Cycles for Workpieces and Tools
	In the Insert NC function window, open the Fixed cycles folder in order to select a cycle Further information: User's Manual for Machining Cycles
	In the Insert NC function window, open the Cycle call folder in order to select a machining cycle Further information: User's Manual for Machining Cycles
	Program a jump label
	Program a subprogram or a program section repeat
	Program an intentional stop
	Pre-select a tool in the NC program
	Call the tool data in the NC program
	In the Insert NC function window, open the Special functions folder (e.g., for later programming of a workpiece blank)
	In the Insert NC function window, open the Selection folder (e.g., to call an external NC program)

Further information: User's Manual for Programming and Testing



Keycaps for axis input and value input

Key	Meaning
 ... 	Select axes in the Manual operating mode, or enter them in the Editor operating mode
 ... 	Enter numbers (e.g., coordinate values)
	Insert a decimal separator during entry
	Invert algebraic sign of entered value
	Delete values during entry
	Open position display of the status overview to copy axis values Further information: "Status overview on the TNC bar", Page 103 In the Editor operating mode and the MDI application, program a straight line L with the actual positions of all axes
	In the Editor operating mode, open the FN folder in the Insert NC function window
	
	Clear entries or delete messages
	Delete NC block or cancel a dialog during programming
	Skip or remove optional syntax elements during programming
	Confirm entries and continue dialogs
	Conclude entry (e.g., finish an NC block)
	Switch between entry of polar and Cartesian coordinates
	Switch between entry of incremental and absolute coordinates

Keycaps for navigation









Key	Meaning
 ... 	Position the cursor
 ... 	
	<ul style="list-style-type: none"> ■ Position the cursor by using the block number of an NC block ■ Open the selection menu while editing
	Jump to first line of an NC program or first column of a table
	Jump to last line of an NC program or last column of a table
	Go one page up in an NC program or table
	Go one page down in an NC program or table
	Mark the active application in order to navigate between applications
 	Navigate between areas of an application

Potentiometers

Poten-tiometer	Function
	<p>Increase or reduce the feed rate</p> <p>Further information: User's Manual for Programming and Testing</p>
	<p>Increase or reduce the spindle speed</p> <p>Further information: User's Manual for Programming and Testing</p>

2.8.3 Keyboard shortcuts for operating the control

With a keyboard unit or a USB keyboard, you can use keyboard shortcuts in your control. In the User's Manual, the labels of the keys are used when indicating keyboard shortcuts. Keys without a label are indicated as follows:



















Key	Designation
	SHIFT
	SPACE
	RETURN
	TAB
	UP
	DOWN
	RIGHT
	LEFT














2.8.4 Icons on the control's user interface

Overview of icons not specific to any operating mode

This overview describes icons that are used in more than one operating mode or that are available regardless of operating mode.

Icons that are specific to individual workspaces are described there.

Icon or shortcut	Meaning
	Back
	Select the Home operating mode
	Select the Files operating mode
	Select the Tables operating mode
	Select the Editor operating mode
	Select the Manual operating mode
	Select the Program Run operating mode
	Select the Machine operating mode
	Open or close the Calculator
	Open or close the Screen keyboard
	Open or close the Settings selection menu
>>	Open or close <ul style="list-style-type: none"> ■ White: expand the TNC bar or machine manufacturer's bar ■ Green: collapse the TNC bar or machine manufacturer's bar ■ Gray: Confirm message
	Add
	Open
	Close
	Maximize
	Reduce
	Move Change the position of workspaces or windows
	Scale Resize windows
...	File functions are available

Icon or shortcut	Meaning
	<ul style="list-style-type: none"> ■ Black: Add favorite ■ Yellow: Remove favorite
 CTRL + S	Save
	Save as
 CTRL + F	Find
 CTRL+X	Cut
 CTRL + C	Copy
 CTRL + V	Paste
 CTRL + Z	Undo
 CTRL + Y	Redo
	Open or close the selection menu
<p> The control groups the icons of the title bar depending on the size of the workspace in a selection menu.</p>	
	Open or close the Workspaces selection menu
	Show the Message menu

2.8.5 The Desktop menu workspace

Application

In the **Desktop menu** workspace, the control displays selected control and HEROS functions.


Description of function

The title bar of the **Desktop menu** workspace includes the following functions:

- The **Active Configuration** selection menu
Using the selection menu, you can activate a configuration of the control interface.
Further information: "Configuring the control's user interface", Page 496
- Full-text search
Search for functions in the workspace with the full-text search.
Further information: "Adding and removing favorites", Page 81

The **Desktop menu** workspace contains the following areas:

- **Control**
In this area you can open operating modes or applications.
Further information: "Overview of the operating modes", Page 64
Further information: "Overview of workspaces", Page 67
- **Tools**
In this area you can open some tools from the HEROS operating system.
Further information: "HEROS Operating System", Page 525
- **Help**
In this area you can open training videos or **TNCguide**.
Further information: "User's Manual as integrated product aid: TNCguide", Page 38
- **Favorites**
In this area you will find the favorites that you have chosen.
Further information: "Adding and removing favorites", Page 81



The **Desktop menu** workspace

The **Desktop menu** workspace is available in the **Start/Login** application.

Showing or hiding an area

To show or hide an area in the **Desktop menu** workspace:

- ▶ Hold or right-click anywhere within the workspace
- > The control displays a plus sign or minus sign within each area.
- ▶ Select a plus sign
- > The controls shows that area.



Use the minus sign to hide an area.

Adding and removing favorites

Adding favorites

To add favorites in the **Desktop menu** workspace:

- ▶ Use the full-text search
- ▶ Hold or right-click the function's icon
- > The control displays the icon for **adding favorites**.



- ▶ Select **Add favorite**
- > The control adds the function to the **Favorites** area.

Removing favorites

To remove favorites from the **Desktop menu** workspace:

- ▶ Hold or right-click the function's icon
- > The control displays the icon for **removing favorites**.



- ▶ Select **Remove favorite**
- > The control removes the function from the **Favorites** area.

3

First Steps


3.1 Chapter overview

This chapter uses an example workpiece to explain how to operate the control: from switching the machine on to the finished workpiece.

The chapter covers the following topics:

- Switching the machine on
- Setting up tools
- Setting up the workpiece
- Machining the workpiece
- Switching the machine off

3.2 Switching on the machine and the control



The **Start/Login** workspace

DANGER

Caution: hazard to the user!

Machines and machine components always pose mechanical hazards. Electric, magnetic, or electromagnetic fields are particularly hazardous for persons with cardiac pacemakers or implants. The hazard starts when the machine is powered up!

- ▶ Read and follow the machine manual
- ▶ Read and follow the safety precautions and safety symbols
- ▶ Use the safety devices



Refer to your machine manual.

Switching on the machine and traversing the reference points can vary depending on the machine tool.

To switch the machine on:

- ▶ Switch the power supply of the control and of the machine on
- > The control is in start-up mode and shows the progress in the **Start/Login** workspace.
- > The control shows the **Power interrupted** dialog in the **Start/Login** workspace.



- ▶ Press **OK**
 - > The control compiles the PLC program.
 - ▶ Switch the machine control voltage on
 - > The control checks the functioning of the emergency stop circuit.
 - > If the machine is equipped with absolute linear and angle encoders, the control is now ready for operation.
 - > If the machine is equipped with incremental linear and angle encoders, the control opens the **Move to ref. point** application.
- Further information:** "The Referencing workspace", Page 129



- ▶ Press the **NC Start** key
 - > The control moves to all necessary reference points.
 - > The control is ready for operation and the **Manual operation** application is open.
- Further information:** "The Manual operation application", Page 134

More detailed information

- Switching on and off
- Position encoders
 - Further information:** "Position encoders and reference marks", Page 141
- Axis reference run

3.3 Configuring a tool

3.3.1 Selecting the Tables operating mode

You can configure tools in the **Tables** operating mode.

To select the **Tables** operating mode:



- ▶ Select the **Tables** operating mode
- > The control displays the **Tables** operating mode.

More detailed information

- The **Tables** operating mode
 - Further information:** "The Tables operating mode", Page 350

3.3.2 Configuring the control's user interface

The **Form** workspace in the **Tables** operating mode

In the **Tables** operating mode you open and edit the various tables of the control either in the **Table** workspace or in the **Form** workspace.



The first steps describe the procedure with the **Form** workspace open.

To open the **Form** workspace:

- ▶ In the application bar, select **Workspaces**
- ▶ Select **Form**
- > The control opens the **Form** workspace.

More detailed information

- The **Form** workspace
Further information: "The Form workspace for tables", Page 360
- The **Table** workspace
Further information: "The Table workspace", Page 354

3.3.3 Preparing and measuring tools

To prepare tools:

- ▶ Clamp the required tools in their tool holders
- ▶ Measure the tools
Further information: "Measuring the tool by scratching", Page 316
- ▶ Write down the length and the radius or transfer these directly to the control

3.3.4 Editing within tool management

T	MAGAZIN	P	NAME
0			NULLWERKZEUG
1	Main	1.1	MILL_D2_ROUGH
2	Main	1.2	MILL_D4_ROUGH
3	Main	1.3	MILL_D6_ROUGH
4	Main	1.4	MILL_D8_ROUGH
5	Main	1.5	MILL_D10_ROUGH
6	Spindle	0.0	MILL_D12_ROUGH
7	Main	1.7	MILL_D14_ROUGH
8	Main	1.8	MILL_D16_ROUGH
9	Main	1.9	MILL_D18_ROUGH
10	Main	1.10	MILL_D20_ROUGH
11	Main	1.11	MILL_D22_ROUGH
12	Main	1.12	MILL_D24_ROUGH
13	Main	1.13	MILL_D26_ROUGH
14	Main	1.14	MILL_D28_ROUGH

The **Tool management** application in the **Table** workspace

Tool management allows you to save tool data, such as the length and radius as well as other tool-specific information.

The control displays the tool data for all tool types in tool management. In the **Form** workspace the control displays only the relevant tool data for the current tool type.

To enter the tool data in tool management:

- ▶ Select **Tool management**
- > The control displays the **Tool management** application.
- ▶ Open the **Form** workspace



- ▶ Enable **Edit**
- ▶ Select the desired tool number (e.g., **16**)
- > The control displays the tool data of the selected tool in the form.
- ▶ Define the required tool data in the form; for example, the length **L** and the tool radius **R**

More detailed information

- The **Tables** operating mode
Further information: "The Tables operating mode", Page 350
- The **Form** workspace
Further information: "The Form workspace for tables", Page 360
- Tool management
Further information: "Tool management ", Page 163
- Tool types
Further information: "Tool types", Page 155

3.3.5 Editing the pocket table



Refer to your machine manual!

Access to the **tool_p.tch** pocket table is machine-dependent.

P	T	NAME	TOOL_LIFE
1.1	1	MILL_D2_ROUGH	?
1.2	2	MILL_D4_ROUGH	?
1.3	3	MILL_D6_ROUGH	?
1.4	4	MILL_D8_ROUGH	?
1.5	5	MILL_D10_ROUGH	?
1.6	6	MILL_D12_ROUGH	?
1.7	7	MILL_D14_ROUGH	?
1.8	8	MILL_D16_ROUGH	?
1.9	9	MILL_D18_ROUGH	?
1.10	10	MILL_D20_ROUGH	?
1.11	11	MILL_D22_ROUGH	?
1.12	12	MILL_D24_ROUGH	?
1.13	13	MILL_D26_ROUGH	?
1.14	14	MILL_D28_ROUGH	?
1.15	15	MILL_D30_ROUGH	?

The **Pocket table** application in the **Table** workspace

The control assigns a pocket in the tool magazine to each tool that is in the tool table. This assignment, as well as the load situation of each tool, is shown in the pocket table.

There are various ways of accessing the pocket table:

- Functions of the machine manufacturer
- Third-party tool-management system
- Manual access to the control

To enter the data in the pocket table:

- ▶ Select **Pocket table**
- ▶ The control displays the **Pocket table** application.
- ▶ Open the **Form** workspace



- ▶ Enable **Edit**
- ▶ Select the desired pocket number
- ▶ Define the tool number
- ▶ Define any additional tool data if necessary, such as whether the pocket is reserved

More detailed information

- Pocket table

Further information: "Pocket table tool_p.tch", Page 377

3.4 Setting up a workpiece

3.4.1 Selecting an operating mode

You set up workpieces in the **Manual** operating mode.

To select the **Manual** operating mode:



- ▶ Select the **Manual** operating mode
- > The control displays the **Manual** operating mode.

More detailed information

- Operating mode: **Manual**

Further information: "Overview of the operating modes", Page 64

3.4.2 Clamping the workpiece

Mount the workpiece with a fixture on the machine table.

3.4.3 Workpiece presetting with a touch probe

Inserting a workpiece touch probe

Use a workpiece touch probe to set up the workpiece with the aid of the control and set the workpiece preset.

To insert a workpiece touch probe:



- ▶ Select **T**



- ▶ Enter the tool number of the workpiece touch probe (e.g., **600**)
- ▶ Press the **NC Start** key
- > The controls inserts the workpiece touch probe.

Setting a workpiece preset

To set a workpiece preset at a corner:

- ▶ Select the **Setup** application



- ▶ Select **Intersection point (P)**
 - > The control opens the probing cycle.
 - ▶ Manually position the touch probe near the first touch point of the first workpiece edge



- ▶ In the **Choose the probing direction** area, select the direction of probing (e.g., **Y+**)



- ▶ Press the **NC Start** key
 - > The control moves the touch probe in the probing direction to the workpiece edge and then back to the starting point.
 - ▶ Manually position the touch probe near the second touch point of the first workpiece edge



- ▶ Press the **NC Start** key
 - > The control moves the touch probe in the probing direction to the workpiece edge and then back to the starting point.
 - ▶ Manually position the touch probe near the first touch point of the second workpiece edge




- ▶ In the **Choose the probing direction** area, select the direction of probing (e.g., **X+**)



- ▶ Press the **NC Start** key
 - > The control moves the touch probe in the probing direction to the workpiece edge and then back to the starting point.
 - ▶ Manually position the touch probe near the second touch point of the second workpiece edge



- ▶ Press the **NC Start** key
 - > The control moves the touch probe in the probing direction to the workpiece edge and then back to the starting point.
 - > The control then displays the coordinates of the determined corner point in the **Measuring result** area.



- ▶ Select **Compensate the active preset**
 - > The control applies the calculated results to the workpiece preset.
 - > The control highlights the line with a preset symbol.



- ▶ Select **Exit probing**
 - > The control closes the probing cycle.



The **Probing function** workspace with an open manual probing function

More detailed information

- The **Probing function** workspace
Further information: "Touch Probe Functions in the Manual Operating Mode (#17 / #1-05-1)", Page 289
- Reference points in the machine
Further information: "Presets in the machine", Page 142
- Tool change in the **Manual operation** application
Further information: "The Manual operation application", Page 134

3.5 Machining a workpiece

3.5.1 Selecting an operating mode

You can machine workpieces in the **Program Run** operating mode.

To select the **Program Run** operating mode:



- ▶ Select the **Program Run** operating mode
- > The control displays the **Program Run** operating mode and the most recently executed NC program.

More detailed information

- The **Program Run** operating mode

Further information: "The Program Run operating mode", Page 324

3.5.2 Opening an NC program


To open an NC program:



- ▶ Select **Open File**
- > The control displays the **Open File** workspace.



- ▶ Select an NC program



- ▶ Select **Open**
- > The control opens the NC program.

More detailed information

- The **Open File** workspace

Further information: User's Manual for Programming and Testing

3.5.3 Starting an NC program

To start an NC program:



- ▶ Press the **NC Start** key
- > The control runs the active NC program.

3.6 Switching the machine off



Refer to your machine manual.
Switching off is a machine-dependent function.

NOTICE

Caution: Data may be lost!

The control must be shut down so that running processes can be concluded and data can be saved. Immediate switch-off of the control by turning off the main switch can lead to data loss regardless of the control's status!

- ▶ Always shut down the control
- ▶ Only operate the main switch after being prompted on the screen

To power-off the machine:



- ▶ Select the **Home** operating mode

Shut down

- ▶ Select **Shut down**
- > The control opens the **Shut down** window.

Shut down

- ▶ Select **Shut down**
- > If NC programs or contours contain any unsaved changes, the control displays the **Close file** window.
- ▶ If necessary, save unsaved NC programs with **Save** or **Save as**
- > The control shuts down.
- > After completion of the shutdown process, the control displays the text **Now you can switch off.**
- ▶ Switch off the main power switch of the machine

4

Status Displays

4.1 Overview

The control shows the status or values of individual functions in the status displays.

The control offer the following status displays:


- General status display and position display in the **Positions** workspace
Further information: "The Positions workspace", Page 97
- Status overview on the TNC bar
Further information: "Status overview on the TNC bar", Page 103
- Additional status displays for specific areas in the **Status** workspace
Further information: "The Status workspace", Page 105
- Additional status displays in the **Editor** operating mode in the **Simulation status** workspace, based on the machining status of the simulated workpiece
Further information: "The Simulation status workspace", Page 118

4.2 The Positions workspace

Application

The general status display in the **Positions** workspace provides information about the status of various functions of the control and about current axis positions.

Description of function



Positions		Nominal pos. (NOML)	
12: CLIMBING-PLATE			
S1			
T	8 Z	MILL_D16_ROUGH	
F	0 mm/min	100 %	100 %
S	12000 rpm	100 %	M5
X	12.000		
Y	-3.000		
Z	40.000		
A	0.000		
C	0.000		
m	?	0.000	
S1	20.000		

The **Positions** workspace with general status display

You can open the **Positions** workspace in the following operating modes:

- **Manual**
- **Program Run**

Further information: "Overview of the operating modes", Page 64

The **Positions** workspace provides the following information:

- Icons of active and inactive functions (e.g., Dynamic Collision Monitoring DCM (#40 / #5-03-1))
- Active tool
- Technology values
- Settings of the spindle and feed-rate potentiometers
- Active miscellaneous functions for the spindle
- Axis values and statuses, such as "Axis not referenced"










Further information: "Test status of the axes", Page 432

Axis display and position display





Refer to your machine manual.











In the machine parameter **axisDisplay** (no. 100810) you define the quantity and sequence of the displayed axes.












Icon	Meaning
IST	Position display mode (e.g., actual or nominal coordinates of the current tool position) You can select the mode in the title bar of the workspace. Further information: "Position displays", Page 120
	Axes The X axis is selected. You can move the selected axis.
	The auxiliary axis m is not selected. The control displays auxiliary axes, such as the tool magazine, as lowercase letters. Further information: "Definition", Page 102
?	The axis is not referenced.
	The axis is not in safe mode. Further information: "Checking axis positions manually", Page 433
Δ	The axis is moving the distance-to-go shown next to the symbol.
	The axis is clamped.
	You can move the axis with the handwheel.
	You cannot move the axis with the handwheel. <div style="border: 1px solid black; padding: 5px; margin-top: 10px;">  Refer to your machine manual. The machine manufacturer defines which axes you can move with the handwheel. </div>
	Feed status when stopped Further information: "Functional safety FS in the Positions workspace", Page 430
	Spindle status when stopped Further information: "Functional safety FS in the Positions workspace", Page 430

Presets and technology values

Icon	Meaning
	<p>Number and comment of the active workpiece preset</p> <p>The number corresponds to the active row number of the preset table. The comment corresponds to the content of the DOC column.</p> <p>Further information: "Preset management", Page 194</p>
	<p>Number of the active pallet preset</p> <p>The number corresponds to the active row number in the pallet preset table.</p> <p>Further information: User's Manual for Programming and Testing</p>
T	<p>In the T area, the control shows the following information:</p> <ul style="list-style-type: none"> ■ Number of the active tool ■ Tool axis of the active tool ■ Symbol of the defined tool type ■ Name of the active tool
F	<p>In the F area, the control shows the following information:</p> <ul style="list-style-type: none"> ■ Active feed rate in mm/min <p>You can program the feed rate in various units of measurement. The control always converts the programmed feed rate in this display to mm/min.</p> <ul style="list-style-type: none"> ■ If M136 is active: active feed rate in mm/rev <p>Further information: User's Manual for Programming and Testing</p> <ul style="list-style-type: none"> ■ Setting of the rapid-traverse potentiometer in percent ■ Setting of the feed-rate potentiometer in percent <p>Further information: "Potentiometers", Page 76</p> <p>If a feed-rate limitation has been activated with the F LIMIT button, the area is labeled F LIMIT instead of F. The control displays the text F LIMIT and the feed-rate value in orange.</p> <p>Further information: "Feed rate limit F LIMIT", Page 328</p>
S	<p>In the S area, the control shows the following information:</p> <ul style="list-style-type: none"> ■ Active shaft speed in rpm <p>If you have programmed a cutting speed instead of a rotational speed, the control automatically converts this value to a rotational speed.</p> <ul style="list-style-type: none"> ■ Setting of the spindle potentiometer in percent ■ Active miscellaneous function for the spindle

Active functions

Icon	Meaning
	The Manual traverse function is active.
	The Manual traverse function is not active. Further information: "The Program Run operating mode", Page 324
	RL tool radius compensation is active. Further information: User's Manual for Programming and Testing
	RR tool radius compensation is active. Further information: User's Manual for Programming and Testing
	These symbols are transparent while the Block scan function of the control is active. Further information: "Block scan for mid-program startup", Page 335
	R+ tool radius compensation is active. Further information: User's Manual for Programming and Testing
	R- tool radius compensation is active. Further information: User's Manual for Programming and Testing
	These symbols are transparent while the Block scan function of the control is active. Further information: "Block scan for mid-program startup", Page 335
	3D tool compensation is active (#9 / #4-01-1). Further information: User's Manual for Programming and Testing
	This symbol is transparent while the Block scan function of the control is active. Further information: "Block scan for mid-program startup", Page 335
	A basic rotation is defined in the active preset. Further information: "Basic rotation and 3D basic rotation", Page 196
	The basic rotation will be taken into account while moving the axes. Further information: "Selection item Basic rotation", Page 203
	A 3D basic rotation is defined in the active preset. Further information: "Basic rotation and 3D basic rotation", Page 196

Icon	Meaning
	<p>The tilted working plane will be taken into account while moving the axes.</p> <p>Further information: User's Manual for Programming and Testing</p> <p>Further information: "The 3D ROT selection item", Page 204</p>
	<p>The Tool axis function is active (#21 / #4-02-1).</p> <p>Further information: "The Tool axis selection item", Page 204</p>
	<p>Either the TRANS MIRROR function or Cycle 8 MIRRORING is active. The axes programmed in the function or cycle are mirrored and moved.</p> <p>Further information: User's Manual for Machining Cycles</p> <p>Further information: User's Manual for Programming and Testing</p>
	<p>The pulsing spindle speed function S-PULSE is active.</p> <p>Further information: User's Manual for Programming and Testing</p>
	<p>The PARAXCOMP DISPLAY function is active.</p>
	<p>The PARAXCOMP MOVE function is active.</p> <p>Further information: User's Manual for Programming and Testing</p>
	<p>The PARAXMODE function is active.</p> <p>This icon might be superimposed on the icons for PARAXCOMP DISPLAY and PARAXCOMP MOVE.</p> <p>Further information: User's Manual for Programming and Testing</p>
TCPM	<p>The function M128 or FUNCTION TCPM is active (#9 / #4-01-1).</p> <p>Further information: User's Manual for Programming and Testing</p>
	<p>The Dynamic Collision Monitoring function (DCM) is active (#40 / #5-03-1).</p>
	<p>The Dynamic Collision Monitoring function (DCM) is not active (#40 / #5-03-1).</p> <p>Further information: "Dynamic Collision Monitoring (DCM) (#40 / #5-03-1)", Page 206</p>
	<p>The Dynamic Collision Monitoring function (DCM) is active with a reduced minimum distance (#140 / #5-03-2).</p> <p>Further information: User's Manual for Programming and Testing</p>
AFC 	<p>The Adaptive Feed Control function (AFC) is active in teach-in cut mode (#45 / #2-31-1).</p>

Icon	Meaning
AFC	The Adaptive Feed Control function (AFC) is active in closed-loop mode (#45 / #2-31-1). Further information: "Adaptive feed control (AFC) (#45 / #2-31-1)", Page 236
ACC	The Active Chatter Control function (ACC) is active (#145 / #2-30-1). Further information: "Active Chatter Control (ACC) (#145 / #2-30-1)", Page 245



In the optional machine parameter **iconPrioList** (no. 100813), you can change the sequence in which the control displays these symbols. The symbol for Dynamic Collision Monitoring (DCM) (#40 / #5-03-1) is always visible and cannot be configured.

Definition

Auxiliary axes

Auxiliary axes are controlled by the PLC and are not included in the kinematics description. Auxiliary axes are driven, for example, hydraulically, electrically, or by an external motor. The machine manufacturer can define the tool magazine, for example, as an auxiliary axis.


4.3 Status overview on the TNC bar

Application

On the TNC bar, the control shows a status overview with the execution status, the current technology values, and the axis positions.

Description of function

General information



		Actual pos. (ACT)	
		X	325.196
		Y	-273.196
		Z	273.196
		A	760.000
		C	0.000
		m	0.000
		S1	74.130
Current block no.	N 10		
Tool in spindle	T 8		
Current feed rate	F 28284		
Spindle speed	S 12000		
Active preset	⊕ 12		
CLIMBING-PLATE			
00:08			
00:09			

Status overview of the TNC bar with open position display

While an NC program or individual NC blocks are being executed, the control displays the following information in the status overview:

- **Control-in-operation:** current machining status
Further information: "Definition", Page 104
- Symbol of the application used for machining
- Remaining run time of the NC program
- Program run time

The control displays the run times of the NC program in mm:ss format. As soon as an NC program run time exceeds 59:59, the control changes the format to hh:mm.



The control displays the same value for the program run time as on the **PGM** tab of the **Status** workspace.

In the **Status** workspace the control shows the program run time in hh:mm:ss format.

Further information: "Display of the program run time", Page 119

- Active tool
- Active feed rate
- Current spindle speed
- Number and comment of the active workpiece preset
- Position display

Position display

If you select the status overview area, the control opens or closes the position display with the current axis positions. The position display mode can be selected independently of the **Positions** workspace (e.g., **Actual pos. (ACT)**).

Further information: "The Positions workspace", Page 97

If you select an axis line, the control copies the current value of this line to the clipboard.

Press the **actual position capture** key to open the position display. The control prompts you to select the value to be copied to the clipboard. During programming, you can thus transfer the values directly into a programming dialog.

Definition

Control-in-operation:

The control uses the **Control-in-operation** symbol to show the machining status of the NC program or NC block:

- White: no movement command
- Green: active machining, axes are moving
- Orange: NC program interrupted
- Red: NC program stopped

Further information: "Interrupting, stopping or canceling program run", Page 329

When the control bar is expanded, the control shows additional information about the current status, such as **Active, feed rate at zero**.

4.4 The Status workspace

Application

In the **Status** workspace the control shows the additional status display. The additional status display shows the current status of various functions on specific tabs. You can use the additional status display to better monitor the running of an NC program by receiving real-time information about active functions and accesses.

Description of function






You can open the **Status** workspace in the following operating modes:

- **Manual**
- **Program Run**

Further information: "Overview of the operating modes", Page 64

Icons

The following icons are shown in the **Status** workspace:

Icon	Meaning
	<p>Configure the layout</p> <p>You can make the following layout adaptations:</p> <ul style="list-style-type: none"> ■ Add or remove areas to the Favorites view ■ Rearrange areas using the gripper ■ Add or remove columns
	<p>Settings</p> <p>Some areas have their own settings. Use this icon to customize the contents of the area (e.g., by defining the variable range to be displayed).</p>
	<p>Favorite</p> <p>Further information: "The Favorites tab", Page 106</p>
	<p>Add</p> <p>The control only shows this icon when you are adapting the layout.</p> <p>With this icon you can add the following elements:</p> <ul style="list-style-type: none"> ■ Column You can divide the workspace into several columns. Further information: "Adding a column in the workspace", Page 362 ■ Area In the Favorites view you can add another area.
	<p>Remove</p> <p>The control only shows this icon when you are adapting the layout.</p> <p>You can delete an empty column with this icon.</p>

The Favorites tab

On the **Favorites** tab, you can arrange your own status display with contents from the other tabs.

The screenshot shows the 'Status' workspace with the 'Favorites' tab selected. The interface is divided into several sections:

- Feed and Speed:** A table with parameters like Feed rate (0), Feed-rate override (100), Programmed feed rate (FMAX), Spindle speed (8000), Spindle override (100), and Miscellaneous function (M5).
- Tool ages:** A table showing current and maximum tool life for different tools.
- Shift (W-DS):** A table showing the current status (Inactive) and coordinates (X, Y, Z) all at 0.000.
- Program run time:** A table showing Runtime (00:00:02) and Dwell time (Not specified).
- Tool geometry:** A table showing Tool Length (200.0000), Tool radius (12.0000), and Tool radius 2 (0.0000). A large '1' is overlaid on this section.
- Nominal reference position (RFNOML):** A table showing coordinates X (-25.000), Y (-25.000), Z (-110.000), A (0.000), C (0.000), H (0.000), and S1 (163.465). A large '2' is overlaid on this section.

The **Favorites** tab


- 1 Area
- 2 Contents

Each area of the status display has its own **Favorites** icon. If you select the icon, the control adds that area to the **Favorites** tab.

The AFC tab (#45 / #2-31-1)

The control displays information on the Adaptive Feed Control function (AFC) (#45 / #2-31-1) on the **AFC** tab.

Further information: "Adaptive feed control (AFC) (#45 / #2-31-1)", Page 236



AFC tab

Area	Contents
Tool information	<ul style="list-style-type: none"> ■ T Tool number ■ Name Tool name ■ Doc Comment about the tool from the tool management
AFC status	<ul style="list-style-type: none"> ■ AFC If AFC is being used to control the feed rate, then Control is displayed in this area. If the control is not controlling the feed rate, then Inactive is displayed in this area. ■ CUT Counts the quantity of cuts that have been performed with FUNCTION AFC CUT BEGIN, starting from zero. ■ FOVR (%) Active factor of the feed-rate potentiometer in percent ■ SACT (%) Current spindle load in percent ■ SREF (%) Reference load of the spindle in percent Define the reference load of the spindle in the syntax element LOAD of the FUNCTION AFC CUT BEGIN function. Further information: "NC functions for AFC (#45 / #2-31-1)", Page 239 ■ S (rpm) Spindle shaft speed in rpm ■ SDEV (%) Current deviation of the speed in percent

Area	Contents
AFC graph	<p>The AFC graph visualizes the relationship between the elapsed Time [sec] and the Spindle load/Feed-rate override [%].</p> <p>The green line in the graph shows the feed-rate override and the blue line shows the spindle load.</p>

CYC tab

On the **CYC** tab the control shows information about machining cycles.

Area	Contents
Active cycle definition	When you use the CYCL DEF function to define a cycle, the control shows the cycle number in this area.
Cycle 32 TOLERANCE	<ul style="list-style-type: none"> ■ Status <ul style="list-style-type: none"> Shows whether Cycle 32 TOLERANCE is active or inactive ■ Values of Cycle 32 TOLERANCE ■ Values from the machine manufacturer for path and angle tolerance, such as predefined machine-specific roughing or finishing filters ■ Values of Cycle 32 limited by Dynamic Collision Monitoring (DCM) TOLERANCE (#40 / #5-03-1)



The machine manufacturer defines the tolerance limits using Dynamic Collision Monitoring (DCM) (#40 / #5-03-1).

In the optional machine parameter **maxLinearTolerance** (no. 205305) the machine manufacturer defines the maximum permissible linear tolerance. In the optional machine parameter **maxAngleTolerance** (no. 205303) the machine manufacturer defines the maximum permissible angle tolerance. If DCM is active, the control restricts the tolerance defined in **32 TOLERANCE** to these values.

If the tolerance is restricted by DCM, the control displays a gray warning triangle as well as the restricted values.

The FN 16 tab

On the **FN 16** tab, the control displays the contents of a file output to the screen with **FN 16: F-PRINT**.

Further information: User's Manual for Programming and Testing

Area	Contents
Output	<p>Contents of an output file that was output with FN 16: F-PRINT, such as measured values or texts.</p> <p>To stop the output:</p> <ul style="list-style-type: none"> ■ Defining the SCLR: output path (Screen Clear) ■ Select the Clear button ■ Select the Reset program button ■ Select a new NC program

LBL tab

On the **LBL** tab the control shows information about program section repeats and subprograms.


Further information: User's Manual for Programming and Testing

Area	Contents
Subprogram calls	<ul style="list-style-type: none"> ■ Blk. no. Block number of the call ■ LBL no./Name Called label
Repetitions	<ul style="list-style-type: none"> ■ Blk. no. ■ LBL no./Name ■ Program-section repeat Number of repetitions still to be performed (e.g., 4/5)

M tab

On the **M** tab the control shows information about active miscellaneous functions.

Further information: User's Manual for Programming and Testing

Area	Contents
Active M functions	<ul style="list-style-type: none"> ■ Function Active miscellaneous functions, such as M3 ■ Description Descriptive text about the respective miscellaneous function. <div style="border: 1px solid black; padding: 5px; margin-top: 10px;">  Refer to your machine manual. Only the machine manufacturer can create a descriptive text for machine-specific miscellaneous functions. </div>

The MON tab (#155 / #5-02-1)


On the **MON** tab, the control displays information on monitoring of defined machine components using the Component monitoring function (#155 / #5-02-1).

Further information: User's Manual for Programming and Testing



Refer to your machine manual.

The machine manufacturer specifies which machine components are monitored, and to what extent.



The **MON** tab with configured spindle speed monitoring

Area	Contents
Monitoring Overview	<p>The control displays the machine components defined for monitoring. By selecting a component, you hide or show whether it is being monitored.</p> <p>If a component cannot be monitored, the control displays a gray icon. A component cannot be monitored, for example, if its configuration is missing or is wrong.</p>
Monitoring Relative	<p>The control displays the monitoring information for the components being shown in the Monitoring Overview area.</p> <ul style="list-style-type: none"> ■ Green: component works under conditions defined as safe ■ Yellow: component works under warning zone conditions ■ Red: component is overloaded <p>In the Display settings window, you can select which component will be shown by the control.</p>
Monitoring Histogram	<p>The control shows a graphical evaluation of previous monitoring sessions.</p>

Use the **Settings** symbol to open the **Display settings** window. You can define the height of the graphical representation for each area.

PGM tab

On the **PGM** tab the control shows information about the program run.

Area	Contents
Parts counter	<ul style="list-style-type: none"> ■ Quantity Actual value and nominal value of the parts counter defined with the FUNCTION COUNT function Further information: User's Manual for Programming and Testing
Program run time	<ul style="list-style-type: none"> ■ Runtime Run time of the NC program in hh:mm:ss format ■ Dwell time Countdown of the waiting time in seconds from the following functions: <ul style="list-style-type: none"> ■ FUNCTION DWELL ■ Cycle 9 DWELL TIME ■ Parameter Q210 DWELL TIME AT TOP ■ Parameter Q211 DWELL TIME AT DEPTH ■ Parameter Q255 DWELL TIME <p>Further information: "Display of the program run time", Page 119</p>
Programs called	Path of the main program as well as called NC programs including the path
Pole/circle center	Programmed axes and values of the circle center point CC
Radius compensation	Programmed tool radius compensation
Program run options	Active breakpoints in connection with the override controller Further information: "Override Controller", Page 415

POS tab

On the **POS** tab the control shows information about positions and coordinates.

Area	Contents
Position display, for example Actual reference position (RFACTL)	<p>In this area the control shows the current position of all axes that are present.</p> <p>You can choose between the following views in the position display:</p> <ul style="list-style-type: none"> ■ Nominal pos. (NOML) ■ Actual pos. (ACT) ■ Nominal reference position (RFNOML) ■ Actual reference position (RFACTL) ■ Servo lag (LAG) ■ Handwheel superimposed (M118) <p>Further information: "Position displays", Page 120</p>
Feed and Speed	<ul style="list-style-type: none"> ■ Active Feed in mm/min If a feed rate limit is active, the control displays the line in orange. If the feed rate is limited using the F LIMIT button, the control displays LIMIT in square brackets. Further information: "Feed rate limit F LIMIT", Page 328 If the feed rate is limited using the F limited button, the control displays the active safety function in square brackets. Further information: "Safety functions", Page 429 ■ Active Feed-rate override in % ■ Active Rapid-traverse override in % ■ Active Programmed feed rate in mm/min If M136 is active: active feed rate in mm/rev Further information: User's Manual for Programming and Testing ■ Active Spindle speed in rpm ■ Active Spindle override in % ■ Active Miscellaneous function in reference to the spindle, such as M3
Orientation of the working plane	<p>Spatial angles or axis angles for the active working plane</p> <p>Further information: User's Manual for Programming and Testing</p> <p>If axis angles are active, the control displays in this area only the values of the physically present axes.</p> <p>Defined values in the 3-D rotation window</p> <p>Further information: "The 3D ROT selection item", Page 204</p>
Basic transformations	<p>In this area the control shows the values of the active workpiece preset and active transformations in linear and rotary axes, such as a transformation in the X axis with the function TRANS DATUM.</p> <p>Further information: "Preset management", Page 194</p>

Area	Contents
Active traverse ranges	Active traverse range, such as Limit 1 for traverse range 1 Traverse ranges are machine-specific. If no traverse range is active, then Traverse range not defined is displayed in this area.
Active kinemat.	Name of the active machine kinematics

POS HR tab

On the **POS HR** tab the control shows information about handwheel superimpositioning.

Area	Contents
Coordinate system	<ul style="list-style-type: none"> ■ Machine (M-CS) If you use M118 (#21 / #4-02-1), handwheel superimpositioning is always effective in the machine coordinate system M-CS. Further information: User's Manual for Programming and Testing
Handwheel superimp.	<ul style="list-style-type: none"> ■ Max. val. Maximum value of the individual axes, programmed in M118 (#21 / #4-02-1) ■ Actl.val. Current superimpositioning

QPARA tab

On the **QPARA** tab the control shows information about the defined variables.

Further information: User's Manual for Programming and Testing

You can use the **Parameter list** window to define which variables the control shows in the individual areas. Up to 22 variables can be displayed in each area.

Further information: "Defining the contents of the QPARA tab", Page 123

Area	Contents
Q parameter	Shows the values of the selected Q parameters
QL parameter	Shows the values of the selected QL parameters
QR parameter	Shows the values of the selected QR parameters
QS parameter	Shows the contents of the selected QS parameters

The Tables tab

On the **Tables** tab, the control shows information about the active tables for program run or the simulation.

Area	Contents
Active tables	In this area the control shows the path for the following active tables: <ul style="list-style-type: none"> ■ Tool table ■ Preset table ■ Datum table ■ Pocket table ■ Touch-probe table (#17 / #1-05-1)

TRANS tab


On the **TRANS** tab the control shows information about active transformations in the NC program.

Area	Contents
Active datum	<ul style="list-style-type: none"> ■ Path of the selected datum table ■ Row number of the selected datum table ■ DOC Contents of the DOC column of the datum table
Active datum shift	Datum shift that was defined with the TRANS DATUM function Further information: User's Manual for Programming and Testing
Mirrored axes	Axes mirrored with either the TRANS MIRROR function or Cycle 8 MIRRORING Further information: User's Manual for Programming and Testing Further information: User's Manual for Machining Cycles
Active angle of rotation	Rotation angle defined with either the TRANS ROTATION function or Cycle 10 ROTATION Further information: User's Manual for Programming and Testing Further information: User's Manual for Machining Cycles
Orientation of the working plane	Spatial angles or axis angles for the active working plane Further information: User's Manual for Programming and Testing
Center of scaling	Center of scaling that was defined with Cycle 26 AXIS-SPECIFIC SCALING Further information: User's Manual for Machining Cycles
Active scaling factors	Scaling factors that were defined for the individual linear axes with the TRANS SCALE function, Cycle 11 SCALING FACTOR or Cycle 26 AXIS-SPECIFIC SCALING Further information: User's Manual for Programming and Testing Further information: User's Manual for Machining Cycles
Shift (WPL-CS)	Active shift in the working plane coordinate system WPL-CS by means of the FUNCTION CORRDATA function Further information: User's Manual for Programming and Testing
Table	<ul style="list-style-type: none"> ■ Path of the selected compensation table *.wco ■ Row number of the selected compensation table *.wco ■ Content of the DOC column of the active row Further information: User's Manual for Programming and Testing

TT tab

On the **TT** tab the control shows information about measurements performed with a TT tool touch probe.

Further information: "Hardware enhancements", Page 61

Area	Contents
<p>TT: tool measurement</p>	<ul style="list-style-type: none"> <li data-bbox="483 528 1228 600">■ T Tool number <li data-bbox="483 607 1228 678">■ Name Tool name <li data-bbox="483 685 1228 792">■ Measuring method Selected measurement method for tool measurement (e.g., Length) <li data-bbox="483 799 1228 907">■ Min (mm) When measuring milling cutters, in this area the control shows the smallest measured value of a cutting edge. Further information: "Definitions", Page 117 <li data-bbox="483 913 1228 1021">■ Max (mm) When measuring milling cutters, in this area the control shows the greatest measured value of a cutting edge. <li data-bbox="483 1028 1228 1142">■ DYN Rotation (mm) When measuring milling cutters with a rotating spindle, the control shows values in this area. <div data-bbox="518 1171 1211 1368" style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p> In the optional machine parameter tippingTolerance (no. 114206) you define the tipping angle tolerance. The control will determine the tipping angle automatically only if a tolerance is defined.</p> </div>
<p>TT: measurement of individual teeth</p>	<p>Number List of the measurements performed and the measured values of the individual cutting edges</p>

The Tool tab

On the **Tool** tab, the control shows information about the active tool, depending on the tool type.

Further information: "Tool types", Page 155

Contents for milling tools

Area	Contents
Tool information	<ul style="list-style-type: none"> ■ T Tool number ■ Name Tool name ■ Doc Note on the tool
Tool geometry	<ul style="list-style-type: none"> ■ L Tool length ■ R Tool radius ■ R2 Corner radius of the tool
Tool allowances	<ul style="list-style-type: none"> ■ DL Delta value for the tool length ■ DR Delta value for the tool radius ■ DR2 Delta value for the corner radius of the tool <p>With Program, the control displays the values from a tool call with TOOL CALL or from a tool compensation with a compensation table *.tcs.</p> <p>Further information: User's Manual for Programming and Testing</p> <p>With Table, the control displays the values from the tool management.</p> <p>Further information: "Tool management ", Page 163</p>
Tool ages	<ul style="list-style-type: none"> ■ Cur. time (h:m) Time in hours and minutes the tool has been engaged ■ Time 1 (h:m) Service life of the tool ■ Time 2 (h:m) Maximum service life at tool call
Replacement tool	<ul style="list-style-type: none"> ■ RT Tool number of the replacement tool ■ Name Tool name of the replacement tool
Tool type	<ul style="list-style-type: none"> ■ Tool Axis Tool axis programmed in the tool call (e.g., Z) ■ Type Tool type of the active tool (e.g., DRILL)

Definitions

Tipping angle

If a TT tool touch probe with a cuboid contact cannot be clamped to a machine table so that it is level, the angular offset must be compensated for. This offset is the tipping angle.

Angle of misalignment

In order to exactly measure with TT tool touch probes with a cuboid contact, the misalignment on the machine table relative to the main axis must be compensated for. This offset is the angle of misalignment.

4.5 The Simulation status workspace

Application

You can call additional status displays in the **Editor** operating mode in the **Simulation status** workspace. In the **Simulation status** workspace, the control shows data based on the simulation of the NC program.

Description of function

The following tabs are available in the **Simulation status** workspace:

- **Favorites**
Further information: "The Favorites tab", Page 106
- **CYC**
Further information: "CYC tab", Page 108
- **FN 16**
Further information: "The FN 16 tab", Page 108
- **LBL**
Further information: "LBL tab", Page 109
- **M**
Further information: "M tab", Page 109
- **PGM**
Further information: "PGM tab", Page 111
- **POS**
Further information: "POS tab", Page 112
- **QPARA**
Further information: "QPARA tab", Page 113
- **Tables**
Further information: "The Tables tab", Page 113
- **TRANS**
Further information: "TRANS tab", Page 114
- **TT**
Further information: "TT tab", Page 115
- **Tool**
Further information: "The Tool tab", Page 116

4.6 Display of the program run time

Application

The control calculates the duration of all traverse movements and displays them together as the **Program run time**. The control takes traversing movements and dwell times into account.

In addition, the control calculates the remaining run time of the NC program.

Description of function

The control displays the program run time in the following areas:

- **PGM** tab of the **Status** workspace
- Status overview on the control bar
- **PGM** tab of the **Simulation status** workspace
- The **Simulation** workspace in the **Editor** operating mode

Use the **Settings** button in the **Program run time** area to influence the calculated program run time.

Further information: "PGM tab", Page 111

The control opens a selection menu with the following functions:

Function	Meaning
Save	Save the current value under Runtime
Addition	Add the saved time to the value under Runtime
Resetting	Reset the saved time and the contents of the Program run time area to zero

The control counts the time during which the **Control-in-operation** symbol is green. The control adds the time from the **Program Run** operating mode and the **MDI** application.

The following functions reset the program run time:

- Selecting a new NC program for program run
- The **Reset program** button
- The **Resetting** function in the **Program run time** area

Remaining run time of the NC program

If a tool usage file is available, the control calculates for the **Program Run** operating mode the duration of executing the active NC program. During program run, the control updates the remaining run time.

Further information: "Tool usage test", Page 173

The control shows the remaining run time in the status overview on the TNC bar.

The control does not take the feed-rate potentiometer setting into account, but calculates with a feed rate of 100%.

The following functions reset the remaining run time:

- Selecting a new NC program for program run
- **Internal stop** button
- Generate new tool usage file

Notes

- In the machine parameter **operatingTimeReset** (no. 200801) the machine manufacturer defines whether the control resets the program run time when the program is started.
- The control cannot simulate the run time of machine-specific functions such as tool changing. That is why this function is only partially suitable for calculating the production time in the **Simulation** workspace.
- In the **Program Run** operating mode, the control displays the exact time of the NC program while taking all machine-specific actions into account.

Definition

Control-in-operation:

The control uses the **Control-in-operation** symbol to show the machining status of the NC program or NC block:

- White: no movement command
- Green: active machining, axes are moving
- Orange: NC program interrupted
- Red: NC program stopped

Further information: "Interrupting, stopping or canceling program run", Page 329

When the control bar is expanded, the control shows additional information about the current status, such as **Active, feed rate at zero**.

4.7 Position displays

Application

The control offers various modes in the position display, for example values from different reference systems. You can choose one of the modes available based on the application.



Description of function


The control has position displays in the following areas:

- The **Positions** workspace
- Status overview on the control bar
- The **POS** tab of the **Status** workspace
- The **POS** tab of the **Simulation status** workspace

On the **POS** tab of the **Simulation status** workspace the control always shows the **Nominal pos. (NOML)** mode. In the **Status** and **Positions** workspaces you can choose the mode of the position display.

The control offers the following modes for the position display:

Mode	Meaning
Nominal pos. (NOML)	<p>This mode shows the value of the currently calculated target position in the input coordinate system I-CS.</p> <p>When the machine moves the axes, the control compares the coordinates of the measured actual position with the calculated nominal position in predefined time intervals. The nominal position is the position at which the axes should be located at the time of comparison, based on the calculation.</p>
<div style="border: 1px solid black; padding: 5px;"> <p> The Nominal pos. (NOML) and Actual pos. (ACT) modes differ solely with regard to the servo lag.</p> </div>	
Actual pos. (ACT)	<p>This mode shows the currently measured tool position in the input coordinate system I-CS.</p> <p>The actual position is the measured position of the axes, as determined by encoders at the time of comparison.</p>
Nominal reference position (RFNOML)	<p>This mode shows the calculated target position in the machine coordinate system M-CS.</p>
<div style="border: 1px solid black; padding: 5px;"> <p> The Nominal reference position (RFNOML) and Actual reference position (RFACTL) modes differ solely with regard to the servo lag.</p> </div>	
Actual reference position (RFACTL)	<p>This mode shows the currently measured tool position in the machine coordinate system M-CS.</p>
Servo lag (LAG)	<p>This mode shows the difference between the calculated nominal position and the measured actual position. The control determines the difference in predefined time intervals.</p>
Handwheel superimposed (M118)	<p>This mode shows the values that you move using the M118 miscellaneous function.</p> <p>Further information: User's Manual for Programming and Testing</p>

 Refer to your machine manual.

In the machine parameter **progToolCallDL** (no. 124501), the machine manufacturer defines whether the position display takes the delta value **DL** from the tool call into account. The modes **NOML.** and **ACTL.** as well as **RFNOML** and **RFACTL** then differ from each other by the value **DL**.

4.7.1 Switching the position display mode

To switch the position display mode in the **Status** workspace:

- ▶ Select the **POS** tab



- ▶ Select **Settings** in the position display area
- ▶ Select the desired mode for the position display (e.g., **Actual pos. (ACT)**)
- > The control displays the positions in the selected mode.

Notes

- The machine parameter **CfgPosDisplayPace** (no. 101000) defines the display accuracy by the number of decimal places.
- When the machine moves the axes, the control displays the distances-to-go of the individual axes with a symbol and the appropriate value next to the current position.

Further information: "Axis display and position display", Page 98

4.8 Defining the contents of the QPARA tab


On the **QPARA** tab of the **Status** and **Simulation status** workspaces, you can define which variables the control will show.

Further information: "QPARA tab", Page 113

To define the contents of the **QPARA** tab:



- ▶ Select the **QPARA** tab
- ▶ Select the **Settings** in the desired area, such as QL parameters
- > The control opens the **Parameter list** window.
- ▶ Enter numbers, such as **1,3,200-208**
- ▶ Press **OK**
- > The control displays the values of the defined variables.



- Use commas to separate single variables and connect sequential variables with a hyphen.
- The control always shows eight decimal places on the **QPARA** tab. For example, the control shows the result of **Q1 = COS 89.999** as 0.00001745. Very large and very small values are shown in exponential notation. The control shows the result of **Q1 = COS 89.999 * 0.001** as +1.74532925e-08, with e-08 corresponding to the factor of 10^{-8} .
- For variable texts in QS parameters the control shows the first 30 characters, i.e. the contents might be truncated.

5

**Powering On and
Off**

5.1 Powering on

Application

After using the main switch to power on the machine, the control's boot process begins. The following steps may differ depending on the machine; for example, whether absolute or incremental position encoders are used.



Refer to your machine manual.

Switching on the machine and traversing the reference points can vary depending on the machine tool.

Related topics

- Absolute and incremental position encoders

Further information: "Position encoders and reference marks", Page 141

Description of function

DANGER

Caution: hazard to the user!

Machines and machine components always pose mechanical hazards. Electric, magnetic, or electromagnetic fields are particularly hazardous for persons with cardiac pacemakers or implants. The hazard starts when the machine is powered up!

- ▶ Read and follow the machine manual
- ▶ Read and follow the safety precautions and safety symbols
- ▶ Use the safety devices

Power-on of the control begins with the power supply.

After booting, the controls checks the machine status, e.g.:

- Positions identical to before switching off the machine
- Safety features are ready, such as the emergency stop
- Functional safety

If the control registers an error during or after booting, it issues an error message.

The following step differs depending on position encoders on the machine:

- Absolute position encoders

If the machine has absolute position encoders, the control opens the **Start/Login** application after power-on.

- Incremental position encoders

If the machine has incremental position encoders, you must traverse the reference points in the **Move to ref. point** application. Once all axes have been referenced, the control is in the **Manual operation** application.

Further information: "The Referencing workspace", Page 129

Further information: "The Manual operation application", Page 134

5.1.1 Powering the machine and the control on

To switch the machine on:

- ▶ Switch the power supply of the control and of the machine on
- > The control is in start-up mode and shows the progress in the **Start/Login** workspace.
- > The control shows the **Power interrupted** dialog in the **Start/Login** workspace.



- ▶ Press **OK**
- > The control compiles the PLC program.
- ▶ Switch the machine control voltage on
- > The control checks the functioning of the emergency stop circuit.
- > If the machine is equipped with absolute linear and angle encoders, the control is now ready for operation.
- > If the machine is equipped with incremental linear and angle encoders, the control opens the **Move to ref. point** application.

Further information: "The Referencing workspace",
Page 129



- ▶ Press the **NC Start** key
- > The control moves to all necessary reference points.
- > The control is ready for operation and the **Manual operation** application is open.

Further information: "The Manual operation application",
Page 134



If startup is delayed by functional safety, the control displays the text **Functional safety requires input**. When you select the **FS** button, the control switches to the **Functional safety** application.

Further information: "The Functional safety application", Page 430

Notes

NOTICE

Danger of collision!

When the machine is switched on, the control tries to restore the switch-off status of the tilted plane. This is prevented under certain conditions. For example, this applies if axis angles are used for tilting while the machine is configured with spatial angles, or if you have changed the kinematics.

- ▶ If possible, reset tilting before shutting the system down
- ▶ Check the tilted condition when switching the machine back on

NOTICE

Danger of collision!

Failure to notice deviations between the actual axis positions and those expected by the control (saved at shutdown) can lead to undesirable and unexpected axis movements. There is risk of collision during the reference run of further axes and all subsequent movements!

- ▶ Check the axis positions
- ▶ Only confirm the pop-up window with **YES** if the axis positions match
- ▶ Despite confirmation, at first only move the axis carefully
- ▶ If there are discrepancies or you have any doubts, contact your machine manufacturer


5.2 The Referencing workspace

Application

On machines with incremental linear and angle encoders, the control shows in the **Referencing** workspace which axes need to be referenced.

Description of function

The **Referencing** workspace is always open in the **Move to ref. point** application. If reference points are to be traversed when powering-on the machine, then the control opens this application automatically.



The **Referencing** workspace with axes to be referenced

The control displays a question mark behind all axes that need to be referenced. Once all axes have been referenced, the control closes the **Move to ref. point** application and switches to the **Manual operation** application.

5.2.1 Axis reference run

To reference the axes in the prescribed sequence:



- ▶ Press the **NC start** key
- > The control moves to the reference points.
- > The control switches to the **Manual operation** application.

To reference the axes in any sequence:



- ▶ Press and hold the axis direction button for each axis until the reference point has been traversed
- > The control switches to the **Manual operation** application.

Notes

NOTICE

Danger of collision!

The control does not automatically check whether collisions can occur between the tool and the workpiece. Incorrect pre-positioning or insufficient spacing between components can lead to a risk of collision when referencing the axes.

- ▶ Pay attention to the information on the screen
- ▶ If necessary, move to a safe position before referencing the axes
- ▶ Watch out for possible collisions

- You cannot switch to the **Program Run** operating mode as long as reference points still need to be traversed.
- If you intend only to edit or simulate NC programs, you can switch to the **Editor** operating mode without referencing the axes. You can still traverse the reference points at a later time.

Notes about traversing reference points in a tilted working plane

If the **Tilt working plane** (#8 / #1-01-1) function was active before the control was shut down, then the control will automatically reactivate this function after the restart. This means that movements via the axis keys take place in the tilted working plane.

Before traversing the reference points, you must deactivate the **Tilt working plane** function; otherwise, the control will interrupt the process with a warning. You can also home axes that are not activated in the current kinematic model without needing to deactivate **Tilt working plane**, such as a tool magazine.

Further information: User's Manual for Programming and Testing

5.3 Powering off

Application

To avoid losing data, shut down the control before powering-off the machine.

Description of function

You can shut down the control in the **Start/Login** application of the **Home** operating mode.

If you select the **Shut down** button, the control opens the **Shut down** window. You choose whether to shut down the control or restart it.

If NC programs or contours contain any unsaved changes, the control displays the unsaved changes in the **Close file** window. You can save the changes, discard them, or cancel the shutdown.

5.3.1 Shutting down the control and powering-off the machine

To power-off the machine:



- ▶ Select the **Home** operating mode



- ▶ Select **Shut down**
- > The control opens the **Shut down** window.



- ▶ Select **Shut down**
- > If NC programs or contours contain any unsaved changes, the control displays the **Close file** window.
- ▶ If necessary, save unsaved NC programs with **Save** or **Save as**
- > The control shuts down.
- > After completion of the shutdown process, the control displays the text **Now you can switch off.**
- ▶ Switch off the main power switch of the machine

Notes

NOTICE

Caution: Data may be lost!

The control must be shut down so that running processes can be concluded and data can be saved. Immediate switch-off of the control by turning off the main switch can lead to data loss regardless of the control's status!

- ▶ Always shut down the control
- ▶ Only operate the main switch after being prompted on the screen

- Different machines have different power-off procedures.
Refer to your machine manual.
- Applications that are active on the control might delay the shutdown, such as a connection to **Remote Desktop Manager** (#133 / #3-01-1)

Further information: "The Remote Desktop Manager window (#133 / #3-01-1)",
Page 477

6

Manual Operation

6.1 The Manual operation application

Application

In the **Manual operation** application you can manually move the axes and set up the machine.

Related topics

- Moving the machine axes
Further information: "Moving the machine axes", Page 135
- Incremental jog positioning of machine axes
Further information: "Incremental jog positioning of axes", Page 137

Description of function

The **Manual operation** application offers the following workspaces:

- Positions
- Simulation
- Status

The function bar in the **Manual operation** application contains the following buttons:

Button	Meaning
Handwheel	The control displays this toggle switch if a handwheel is configured for the control. If the handwheel is active, the operating mode's icon in the sidebar changes. Further information: "Electronic Handwheel", Page 401
M	Define a miscellaneous function M or use the selection menu to choose one and activate it with the NC start key. Further information: User's Manual for Programming and Testing The machine manufacturer uses the optional machine parameter forbidManual (no. 103917) to define which miscellaneous functions are allowed in the Manual operation application and are available in the selection menu.
S	Define the spindle speed S , activate it with the NC start key, and also switch on the spindle. Further information: User's Manual for Programming and Testing
F	Define the feed rate F and activate it with the OK button. Further information: User's Manual for Programming and Testing
T	Define a tool T or use the selection window to choose one and insert it with the NC start key. Further information: User's Manual for Programming and Testing
3D ROT	The control opens a window for the 3D rotation settings (#8 / #1-01-1). Further information: User's Manual for Programming and Testing
Q info	The control opens the Q parameter list window, where you can see and edit the current values and descriptions of the variables. Further information: User's Manual for Programming and Testing
DCM	The control opens the Dyna. Coll. Monitoring (DCM) window where you can activate or deactivate Dynamic Collision Monitoring (DCM (#40 / #5-03-1)). Further information: "Activating Dynamic Collision Monitoring (DCM) for the Manual and Program Run operating modes", Page 211

Button	Meaning
Manual cycles	The machine manufacturer can define manual cycles that you can use by means of this button.
F limited	Use this option to activate or deactivate the feed-rate limit for functional safety (FS). Only on machines with functional safety (FS). Further information: "Feed-rate limiting with functional safety (FS)", Page 432
Jog increment	Define the jog increment Further information: "Incremental jog positioning of axes", Page 137
Set the preset	Enter and set a preset Further information: "Preset management", Page 194
Tools	The control opens the Tool management application in the Tables operating mode. Further information: "Tool management ", Page 163
Internal stop	If an NC program is interrupted due to an error or a stop, the control activates this button. Use this button to abort program run. Further information: "Tool management ", Page 163

6.2 Moving the machine axes

Application

You can use the control to move the machine axes manually, such as pre-positioning for a manual touch probe function.

Further information: "Touch Probe Functions in the Manual Operating Mode (#17 / #1-05-1)", Page 289

Related topics

- Programming traverse movements
Further information: User's Manual for Programming and Testing
- Executing traverse movements in the **MDI** application
Further information: "The MDI Application ", Page 279

Description of function

The control offers the following methods for moving axes manually:

- Axis-direction keys
- Incremental jog positioning with the **Jog increment** button
- Traversing with electronic handwheels

Further information: "Electronic Handwheel", Page 401

The control displays the current contouring feed rate in the status display while the machine axes are in motion.

Further information: "Status Displays", Page 95

You can change the contouring feed rate with the **F** button in the **Manual operation** application and with the feed-rate potentiometer.

A traverse job is active on the control as soon as an axis moves. The control shows the status of the traverse job with the **Control-in-operation** icon in the status overview.

Further information: "Status overview on the TNC bar", Page 103

6.2.1 Using axis keys to move the axes

To move an axis manually with the axis keys:



- ▶ Select an operating mode (e.g., **Manual**)

- ▶ Select an application (e.g., **Manual operation**)



- ▶ Press the axis key of the desired axis
- ▶ The control moves the axis as long as you press the key.




If you hold the axis key pressed down and simultaneously press the **NC start** key, the control moves the axis at a continuous feed rate. You have to end traverse movement with the **NC stop** key.

You can move more than one axis at a time.

6.2.2 Incremental jog positioning of axes

Incremental jog positioning allows you to move a machine axis by a preset distance. The input range for the infeed is from 0.001 mm to 10 mm.



To position an axis incrementally:



- ▶ Select the **Manual** operating mode

Jog increment

- ▶ Select the **Manual operation** application
- ▶ Select **Jog increment**
- ▶ The control opens the **Positions** workspace, if necessary, and shows the **Jog increment** area.

X+


- ▶ Enter the jog increment for linear axes and rotary axes
- ▶ Press the axis key of the desired axis
- ▶ The control positions the axis in the selected direction by the defined jog increment.

Jog increment On

- ▶ Select **Jog increment On**
- ▶ The control ends incremental jog positioning and closes the **Jog increment** area in the **Positions** workspace.



You can also end incremental jog positioning with the **Off** button in the **Jog increment** area.



The **Positions** workspace with active **Jog increment** area

Note


When positioning an axis, the control checks whether the defined speed has been reached. The control does not check the speed in positioning blocks where **FMAX** is the feed rate.

7

NC Fundamentals

7.1 NC fundamentals

7.1.1 Programmable axes



The programmable axes of the control are in accordance with the axis definitions specified in DIN 66217.

The programmable axes are designated as follows:

Main axis	Parallel axis	Rotary axis
X	U	A
Y	V	B
Z	W	C



Refer to your machine manual.

The number, designation and assignment of the programmable axes depend on the machine.

Your machine manufacturer can define further axes, such as PLC axes.



The TNC7 basic can move up to four axes simultaneously. If an NC block commands movement of more than four axes, the control displays an error message.

If the axis position does not change, you can nevertheless program more than four axes.

7.1.2 Designation of the axes of milling machines

The axes **X**, **Y** and **Z** on your milling machine are designated as the main axis (1st axis), secondary axis (2nd axis) and tool axis. The main axis and secondary axis define the working plane.

The axes are associated as follows:

Main axis	Secondary axis	Tool axis	Working plane
X	Y	Z	XY, also UV, XV, UY
Y	Z	X	YZ, also WU, ZU, WX
Z	X	Y	ZX, also VW, YW, VZ




The control's full range of functions is available only if the **Z** tool axis is used (e.g., **PATTERN DEF**).

Restricted use of the tool axes **X** and **Y** is possible when prepared and configured by the machine manufacturer.

7.1.3 Position encoders and reference marks

Fundamentals



The position of the machine axes is ascertained with position encoders. As a rule, linear axes are equipped with linear encoders. Rotary tables and rotary axes feature angle encoders.

The position encoders detect the positions of the tool or machine table by generating an electrical signal during movement of an axis. The control ascertains the position of the axis in the current reference system from this electrical signal.

Further information: "Reference systems", Page 180

Position encoders can measure these positions through different methods:

- Absolutely
- Incrementally

The control cannot determine the position of the axes while the power is interrupted. Absolute and incremental position encoders behave differently once power is restored.

Absolute position encoders


On absolute position encoders, every position on the encoder is uniquely identified. The control can thus immediately determine the association between the axis position and the coordinate system after a power interruption.

Incremental position encoders

Incremental position encoders need to find the distance between the current position and a reference mark in order to determine the actual position. Reference marks indicate a machine-based reference point. A reference mark must be traversed in order to determine the current position after a power interruption.

If the position encoders feature distance-coded reference marks, then you need to move the linear encoders of the axes by no more than 20 mm. On angle encoders this distance is no more than 20 °.

Further information: "Axis reference run", Page 129







7.1.4 Presets in the machine


The following table contains an overview of the presets in the machine or on the workpiece.

Related topics

- Presets on the tool

Further information: "Presets on the tool", Page 147

Icon	Preset
	<p>Machine datum</p> <p>The machine datum is a fixed point defined in the machine configuration by the machine manufacturer.</p> <p>The machine datum is the origin of the machine coordinate system M-CS.</p> <p>Further information: "Machine coordinate system M-CS", Page 182</p> <p>If you program M91 in an NC block, the defined values are referenced to the machine datum.</p> <p>Further information: User's Manual for Programming and Testing</p>
	<p>M92 datum M92-ZP (zero point)</p> <p>The M92 datum is a fixed point defined relative to the machine datum by the machine manufacturer in the machine configuration.</p> <p>The M92 datum is the origin of the M92 coordinate system. If you program M92 in an NC block, the defined values are referenced to the M92 datum.</p> <p>Further information: User's Manual for Programming and Testing</p>
	<p>Tool change position</p> <p>The tool change position is a fixed point defined relative to the machine datum by the machine manufacturer in the tool-change macro.</p>
	<p>Reference point</p> <p>The reference point is a fixed point for initializing position encoders.</p> <p>Further information: "Position encoders and reference marks", Page 141</p> <p>If the machine has incremental position encoders, the axes must traverse the reference point after booting.</p> <p>Further information: "Axis reference run", Page 129</p>
	<p>Workpiece preset</p> <p>With the workpiece preset you define the origin of the workpiece coordinate system W-CS.</p> <p>Further information: "Workpiece coordinate system W-CS", Page 186</p> <p>The workpiece preset is defined in the active row of the preset table. You determine the workpiece preset with a 3D touch probe, for example.</p> <p>Further information: "Preset management", Page 194</p> <p>Further information: User's Manual for Programming and Testing</p> <p>If no transformations are defined, the entries in the NC program refer to the workpiece preset.</p>

Icon	Preset
	<p data-bbox="413 360 627 389">Workpiece datum</p> <p data-bbox="413 400 1414 524">You define the workpiece datum with transformations in the NC program, for example with TRANS DATUM or a datum table. The entries in the NC program refer to the workpiece datum. If no transformations are defined in the NC program, the workpiece datum corresponds to the workpiece preset.</p> <p data-bbox="413 535 1455 600">If you tilt the working plane (#8 / #1-01-1), the workpiece datum is the point around which the workpiece is rotated.</p>

8

Tools

8.1 Fundamentals

To use the control's functions, you must define the tools for the control using real data (e.g., the radius). This makes programming easier and improves process reliability.

To add a tool to the machine, follow the sequence below:

- Prepare your tool and clamp the tool into a suitable tool holder.
- To measure the tool dimensions, starting from the tool carrier preset, measure the tool (e.g., using a tool presetter). The control needs these dimensions for calculating the paths.

Further information: "Tool carrier reference point", Page 147

- Further tool data are needed to completely define the tool. Take these tool data from the manufacturer's tool catalog, for example.

Further information: "Tool data for the tool types", Page 158

- Save all collected tool data of this tool in the tool management.

Further information: "Tool management ", Page 163

- As needed, assign a tool carrier to the tool in order to achieve realistic simulation and collision protection.

Further information: "Tool carrier management", Page 167

- After finishing tool definition, program a tool call within an NC program.

Further information: User's Manual for Programming and Testing

- If your machine is equipped with a chaotic tool changer system and a double gripper, the tool change time may be shortened by pre-selecting the tool.

Further information: User's Manual for Programming and Testing

- If needed, perform a tool usage test before starting the program. This process checks if the tools are available in the machine and have sufficient remaining tool life.

Further information: "Tool usage test", Page 173

- After machining a workpiece and measuring it, you may correct the tools.

Further information: User's Manual for Programming and Testing

8.2 Presets on the tool


The control distinguishes the following presets on the tool for different calculations or applications.

Related topics

- Presets in the machine or on the workpiece

Further information: "Presets in the machine", Page 142

8.2.1 Tool carrier reference point




The tool carrier reference point is a fixed point defined by the machine manufacturer. The tool carrier reference point is usually located on the spindle nose.

Starting from the tool carrier reference point, define the tool dimensions in the tool management (e.g., length **L** and radius **R**).

Further information: "Tool management ", Page 163

Further information: "Measuring the tool by scratching", Page 316

8.2.2 Tool tip TIP



The tool tip has the greatest distance from the tool carrier reference point. The tool tip is the origin of the tool coordinate system **T-CS**.

Further information: "Tool coordinate system T-CS", Page 192

In case of milling cutters, the tool tip is at the center of the tool radius **R** and at the longest point of the tool on the tool axis.

You define the tool tip with the following columns of the tool management relative to the tool carrier reference point:


- L
- DL

Further information: "Tool data for the tool types", Page 158

The tool tip is an auxiliary point for illustration purposes. The coordinates in the NC program reference the tool location point.

Further information: "Tool location point (TLP, tool location point)", Page 149

8.2.3 Tool center point (TCP, tool center point)



The tool center point is the center of the tool radius **R**. If a second tool radius (**R2**) is defined, the tool center point is offset from the tool tip by this value.


Making entries in the tool management relative to the tool carrier reference point defines the tool center point.

Further information: "Tool data for the tool types", Page 158

The tool center point is an auxiliary point for illustration purposes. The coordinates in the NC program reference the tool location point.

Further information: "Tool location point (TLP, tool location point)", Page 149

8.2.4 Tool location point (TLP, tool location point)




The control positions the tool on the tool location point. By default, the tool location point is at the tool tip.

In the function **FUNCTION TCPM** (#9 / #4-01-1), you can also choose the tool location point to be at the tool center point.

Further information: User's Manual for Programming and Testing

8.2.5 Tool rotation point (TRP, tool rotation point)



When applying the tilting function with **MOVE** (#8 / #1-01-1), the control tilts the tool about the tool center of rotation. By default, the tool center of rotation is at the tool tip.


When selecting **MOVE** in **PLANE** functions, the syntax element **DIST** is used to define the relative position between the workpiece and the tool. The control shifts the tool rotation point from the tool tip by this value. When **DIST** is not defined, the control keeps the tool tip constant.

Further information: User's Manual for Programming and Testing

In the function **FUNCTION TCPM** (#9 / #4-01-1), you can also choose the tool center of rotation to be at the tool center point.

Further information: User's Manual for Programming and Testing

8.2.6 Tool radius 2 center (CR2, center R2)



The control uses the tool radius 2 center in conjunction with 3D tool compensation (#9 / #4-01-1). In the case of straight lines **LN**, the surface-normal vector points to that point and defines the direction of the 3D tool compensation.

Further information: User's Manual for Programming and Testing

The tool radius 2 center is offset from the tool tip and the cutting edge by the **R2** value.

The tool radius 2 center is an auxiliary point for illustration purposes. The coordinates in the NC program reference the tool location point.

Further information: "Tool location point (TLP, tool location point)", Page 149

8.3 Tool data

8.3.1 Tool ID number

Application

Each tool has a unique number which equals the row number of the tool management. Each tool ID number is unique.

Further information: "Tool management ", Page 163

Description of function

The tool ID numbers can be defined in a range from 0 to 32,767.

The tool with the number 0 is defined as the zero tool with the length and the radius 0. Upon a TOOL CALL 0, the control unloads the currently used tool and inserts no new tool.

Further information: User's Manual for Programming and Testing

8.3.2 Tool name

Application

A tool name can be assigned in addition to the tool ID number. Contrary to the tool ID number, a tool name is not unique.

Description of function

The tool name allows identifying tools easier within the tool management. To this end, key features can be defined such as the diameter or the type of machining (e.g., **MILL_D10_ROUGH**).

As tool names are not unique, assign names that clearly identify the tools.

A tool name may contain up to 32 characters.

Permitted characters

You can use the following characters for the tool name:

A B C D E F G H I J K L M N O P Q R S T U V W X Y Z 0 1 2 3 4 5 6 7 8 9 # \$ % & , - _ .

When entering lowercase letters, the control will substitute them by uppercase letters upon saving.

In conjunction with AFC (#45 / #2-31-1), the following characters are not permitted in the tool name: # \$ & , .

Further information: "Adaptive feed control (AFC) (#45 / #2-31-1)", Page 236

Note

- Assign unique tool names!

If you define identical tool names for multiple tools, the control will look for the tool in the following sequence:

- Tool that is in the spindle
- Tool that is in the magazine



Refer to your machine manual.

If there are multiple magazines, the machine manufacturer can specify the search sequence of the tools in the magazines.

- Tool that is defined in the tool table but is currently not in the magazine

If the control, for example, finds multiple available tools in the tool magazine, it inserts the tool with the least remaining tool life.

8.3.3 Database ID

Application

In a tool database for all machines, you can identify tools with unique database IDs (e.g., within a workshop). This allows you to coordinate the tools of multiple machines more easily.

The database ID is entered in the **DB_ID** column of the tool management.

Related topics

- **DB_ID** column of tool management

Further information: "Tool table tool.t", Page 363

Description of function

The database ID is stored in the **DB_ID** column of the tool management.

For indexed tools, you can define the database ID either only for the physically existing main tool or as an ID for the data record at each index.

For indexed tools, HEIDENHAIN recommends that you assign the database ID to the main tool.

Further information: "Indexed tool", Page 152

A database ID may contain a maximum of 40 characters and is unique in the tool management.

The control does not allow a tool call with the database ID.

8.3.4 Indexed tool

Application

Using an indexed tool, several different sets of tool data can be stored for one physically available tool. This feature enables indication of a certain point on the tool by means of the NC program which does not necessarily have to correspond with the maximum tool length.

Requirement

- Main tool has been defined

Description of function

Tools with multiple lengths and radii cannot be defined in one row of the tool management table. Additional table rows are required, specifying the full definitions of the indexed tools. The lengths of the indexed tools, starting from the maximum tool length, approach the tool carrier preset as the index increases.

Further information: "Tool carrier reference point", Page 147

Further information: "Creating an indexed tool", Page 153

Examples of an application of indexed tools:

- Step drill
The tool data of the main tool contain the drill tip, which corresponds to the maximum length. The tool steps are defined as indexed tools. This makes the lengths equal the actual tool dimensions.
- NC center drill
The main tool is used for defining the theoretical tool tip as the maximum length. This can be used for centering, for example. The indexed tool defines a point along the tool tooth. This can be used for deburring, for example.
- Cut-off milling cutter or T-slot milling cutter
The main tool is used for defining the lower point of the cutting edge, which equals the maximum length. The indexed tool defines the upper point of the cutting edge. When using the indexed tool for cutting-off, the specified workpiece height can be directly programmed.

Creating an indexed tool

To create an indexed tool:



- ▶ Select the **Tables** operating mode



- ▶ Select **Tool management**
- ▶ Enable **Edit**
- > The control enables tool management for editing.



- ▶ Select **Insert tool**
- > The control opens the **Insert tool** window.
- ▶ Select the desired tool type
- ▶ Define the tool number of the main tool (e.g., **T5**)



- ▶ Press **OK**
- > The control adds table row **5**.
- ▶ Define any required tool data, including the maximum tool length

Further information: "Tool data for the tool types", Page 158



- ▶ Select **Insert tool**
- > The control opens the **Insert tool** pop-up window.
- ▶ Enable the **Index** check box
- > The control adds the next free index number for the currently selected tool (e.g., **T5.1**).



- ▶ Press **OK**
- > The control inserts table row **5.1** with the tool data of the main tool.
- ▶ Correct any deviating tool data

Further information: "Tool data for the tool types", Page 158



The lengths of the indexed tools approach the tool carrier preset as the index rises, starting from the maximum tool length.

Further information: "Tool carrier reference point", Page 147

Notes

- The control describes some parameters automatically, for example the current tool age **CUR_TIME**. The control describes these parameters separately for each table row.

Further information: "Tool table tool.t", Page 363


- When you create an indexed tool, the control will copy the tool data from the previous table row. The previous table row may be the main tool or an existing indexed tool.
- Index numbers do not need to be sequential. It is possible, for example, to create the tools **T5**, **T5.1** and **T5.3**.
- If you delete a main tool, the control will delete all associated indexed tools as well.
- If you copy or cut indexed tools only, you can use **Append** to add the indices to the currently selected tool.

Further information: User's Manual for Programming and Testing

- Up to nine indexed tools can be added to each main tool.
- If you define a replacement tool **RT**, this applies to the respective table row exclusively. When an indexed tool is worn and consequently blocked, this also does not apply to all other indices. This means, for example, that the main tool can still be used.

Further information: User's Manual for Programming and Testing

Example of T-slot milling cutter



In this example, you program a T-slot with dimensions referring to the top and bottom edges as viewed from the coordinates surface. The height of the T-slot is larger than the length of the cutting edge of the tool used. This requires two steps. Two tool definitions are required for producing the T-slot.

- The main tool dimension refers to the lower point of the cutting edge, which equals the maximum tool length. This can be used for machining the bottom edge of the T-slot.
- The dimension of the indexed tool refers to the upper point of the cutting edge. This can be used for machining the top edge of the T-slot.



Please ensure that all required tool data are defined both for the main tool and for the indexed tool! In case of a rectangular tool, the radius remains identical in both table lines.

The T-slot is programmed in two machining steps:

- The 10 mm depth is programmed with the main tool.
- The 5 mm depth is programmed with the indexed tool.

11 TOOL CALL 7 Z S2000	; Call the main tool
12 L X+0 Y+0 Z+10 R0 FMAX	; Pre-position the tool
13 L Z-10 R0 F500	; Move to machining depth
14 CALL LBL "CONTOUR"	; Machine the bottom edge of the T-slot with the main tool
* - ...	
21 TOOL CALL 7.1 Z F2000	; Call the indexed tool
22 L X+0 Y+0 Z+10 R0 FMAX	; Pre-position the tool
23 L Z-5 R0 F500	; Move to machining depth
24 CALL LBL "CONTOUR"	; Machine the top edge of the T-slot with the indexed tool

8.3.5 Tool types

Application

Depending on the selected tool type, the control displays the editable tool data in the tool management.























Related topics


- Editing the tool data in the tool management
Further information: "Tool management ", Page 163

Description of function

A number is additionally assigned to each tool type.

The following tool types can be selected in the **TYPE** column of the tool management:

Icon	Tool type	Number
	Milling cutter (MILL)	0
	Rough cutter (MILL_R)	9
	Finishing cutter (MILL_F)	10
	Face mill (MILL_FACE)	14
	Ball-nose cutter (BALL)	22
	Toroid cutter (TORUS)	23
	Chamfer mill (MILL_CHAMFER)	24
	Side milling cutter (MILL_SIDE)	25
	Drill (DRILL)	1
	Tap (TAP)	2
	NC center drill (CENT)	4
	Touch probe (TCHP) (#17 / #1-05-1)	21
	Reamer (REAM)	3
	Countersink (CSINK)	5
	Piloted counterbore (TSINK)	6
	Boring tool (BOR)	7
	Back boring tool (BCKBOR)	8
	Thread miller (GF)	1
	Thread miller with chamfer (GSF)	16
	Thread mill with single thread (EP)	17
	Thread mill with indexable insert (WSP)	18
	Thread drilling/milling cutter (BGF)	19

Icon	Tool type	Number
	Circular thread mill (ZBGF)	20

These tool types allow filtering the tools in the tool management.

Further information: "Tool management ", Page 163

8.3.6 Tool data for the tool types

Application

The tool data provide the control with all information necessary for calculating and checking the required movements.

The necessary data depend on the technology and the tool type.

Related topics

- Editing the tool data in the tool management
Further information: "Tool management ", Page 163
- Tool types
Further information: "Tool types", Page 155

Description of function

Some of the necessary tool data can be determined using the following options:

- You can measure your tools in the machine (e. g., with a tool touch probe) or externally with a tool presetter.
Further information: User's Manual for Measuring Cycles for Workpieces and Tools
- Take further tool information from the manufacturer's tool catalog (e.g., the material or the number of teeth).












In the tables below, the relevance of the parameters is sub-divided into the optional, recommended and required categories.




The control takes recommended parameters into account for at least one of the functions below:

- Simulation
Further information: User's Manual for Programming and Testing
- Machining or touch probe cycles
Further information: User's Manual for Machining Cycles
Further information: User's Manual for Measuring Cycles for Workpieces and Tools
- Dynamic Collision Monitoring (DCM (#40 / #5-03-1))
Further information: "Dynamic Collision Monitoring (DCM) (#40 / #5-03-1)", Page 206

Tool data for milling and drilling tools

The control offers the following parameters for milling and drilling tools:

Icon and parameter	Meaning	Intended use
 L	Length	Required for all milling and drilling tool types
 R	Radius	Required for all milling and drilling tool types
 R2	Radius 2	Required for the following milling and drilling tool types: <ul style="list-style-type: none"> ■ Ball-nose cutter ■ Toroid cutter
 DL	Delta value of length	Optional The control describes this parameter in connection with touch probe cycles.
 DR	Delta value of radius	Optional The control describes this parameter in connection with touch probe cycles.
 DR2	Delta value of radius 2	Optional The control describes this parameter in connection with touch probe cycles.
 LCUTS	Tooth length	Recommended
 RCUTS	Tooth width	Recommended
 LU	Useful length	Recommended
 RN	Neck radius	Recommended
 ANGLE	Plunge angle	Recommended for the following milling and drilling tool types: <ul style="list-style-type: none"> ■ Milling tool ■ Roughing mill ■ Finishing cutter ■ Ball-nose cutter ■ Toroid cutter

Icon and parameter	Meaning	Intended use
 PITCH	Thread pitch	Recommended for the following milling and drilling tool types: <ul style="list-style-type: none"> ■ Tapping tools ■ Thread mill ■ Thread miller with chamfer ■ Thread mill with single thread ■ Thread mill w/ indexable insert ■ Thread drilling/milling cutter ■ Circular thread mill
 T-ANGLE	Point angle	Recommended for the following milling and drilling tool types: <ul style="list-style-type: none"> ■ Drill ■ NC center drill ■ Countersink ■ Chamfer cutter
 NMAX	Maximum spindle speed	Optional
R_TIP	Radius at the tip	Recommended for the following milling and drilling tool types: <ul style="list-style-type: none"> ■ Face mill ■ Countersink ■ Chamfer cutter



- All tool types listed in the **TYP** column are milling and drilling tools except for:
 - **Touch probe** (#17 / #1-05-1)
Further information: "Tool types", Page 155
- The parameters are described in the tool table.
Further information: "Tool table tool.t", Page 363










Tool data for touch probes (#17 / #1-05-1)






NOTICE**Danger of collision!**

The control cannot protect L-shaped styli from collisions using Dynamic Collision Monitoring DCM (#40 / #5-03-1). When using a touch probe with an L-shaped stylus there is a risk of collision!

- ▶ Carefully run in the NC program or program section in the **Program Run Single Block** operating mode
- ▶ Watch out for possible collisions!

The control offers the following parameters for touch probes:

Icon and parameter	Meaning	Intended use
 L	Length	Required
 R	Radius	Required
TP_NO	Number in the touch probe table	Required
 TYPE	Type of touch probe	Required
 F	Probing feed rate	Required
 FMAX	Rapid traverse in probing cycle	Optional
 F_PREPOS	Pre-positioning at rapid traverse	Required
 TRACK	Orienting the touch probe in each probing process	Required When selecting L-TYPE in the STYLUS parameter, ON must be selected
 REACTION	Trigger NCSTOP or EMERGSTOP in case of collision	Required
 SET_UP	Set-up clearance	Recommended

Icon and parameter	Meaning	Intended use
 DIST	Maximum measuring range	Recommended
 CAL_OF1	Center offset in the main axis	Required when ON is selected in parameter TRACK The control describes this value in connection with the calibration cycle.
 CAL_OF2	Center offset in the secondary axis	Required when ON is selected in parameter TRACK The control describes this value in connection with the calibration cycle.
 CAL_ANG	Spindle angle during calibration	Required when ON is selected in parameter TRACK
 STYLUS	Shape of the stylus	Required If you do not define the parameter, the control uses SIMPLE



- You define touch probes by selecting the **Touch probe** tool type in the **TYPE** column and the touch probe model in the **TYPE** column.
Further information: "Tool types", Page 155
- The parameters are described in the touch probe table.
Further information: "Touch probe table tchprobe.tp (#17 / #1-05-1)", Page 373

8.4 Tool management

Application

The control displays the tool definitions of all technologies as well as the tools currently present in the tool magazine in the **Tool management** application of the **Tables** operating mode.

The tool management allows adding tools, editing tool data and deleting tools.

Related topics

- Creating new tools
Further information: "Configuring a tool", Page 85
- Table workspace
Further information: "The Table workspace", Page 354
- Form workspace
Further information: "The Form workspace for tables", Page 360

Description of function

You can define up to 32,767 tools in the tool management; this is the maximum number of available table rows.

The control displays all tool data of the tool tables below in the tool management:

- Tool table **tool.t**
Further information: "Tool table tool.t", Page 363
- Touch-probe table **tchprobe.tp** (#17 / #1-05-1)
Further information: "Touch probe table tchprobe.tp (#17 / #1-05-1)", Page 373

The control additionally displays the pockets occupied in the magazine from pocket table **tool_p.tch** in the tool management.

Further information: "Pocket table tool_p.tch", Page 377

Tool data can be edited in the **Table** workspace or in the **Form** workspace. In the **Form** workspace the control shows the correct tool data for each tool type.

Further information: "Tool data", Page 150

Notes

- When creating a new tool, the length **L** and radius **R** columns are empty at first. The control will not insert a tool whose length and radius are missing and will display an error message.
- The tool data of tools still stored in the pocket table cannot be deleted. The tools must be removed from the magazine first.
- When editing tool data, bear in mind that the current tool may have been entered in column **RT** as a replacement tool of another tool!
- Make sure to keep the tool table as short and clear as possible so that it does not impair the computing speed of your control. Use a maximum of 10,000 tool entries in tool management. For example, you can delete all unused tool numbers; tool numbers need not be sequential.
- If the cursor is within the **Table** workspace and the **Edit** toggle switch is deactivated, a search using the keyboard can be started. The control opens a separate window with an input field and automatically searches for the entered string. If the controls finds a tool with the entered characters, it selects this tool. If it finds several tools with this string of characters, you can scroll up and down in the window.
- The machine manufacturer uses the machine parameter **CfgTableCellLock** (no. 135600) to define whether and in which cases individual table cells are locked or write-protected. On some machines, you cannot change the tool type once a tool has been inserted into the machine.

8.4.1 Importing and exporting tool data

Application

The control can import and export tool data. This avoids manual editing efforts and possible typing errors. Importing tool data is particularly useful in connection with a tool presetter. Exported tool data can be used for the tool database of your CAM system, for example.

Description of function

The control transmits tool data as a CSV file.

Further information: User's Manual for Programming and Testing

The tool data transfer file is structured as follows:

- The first row contains the tool table column names that are transferred.
- The other rows contain the tool data to be transferred. The order of the data must match the order of the column names in row 1. A period is used as decimal separator.

The column names and the tool data stand between double quotation marks and are separated by semicolons.

Please note the following regarding the transfer file:

- The tool number must be present.
- Any tool data can be imported. The data record does not need to contain all tool table column names or all tool data.
- Missing tool data contain no value between the quotation marks.
- The column names can be arranged in any order. The order of tool data must match the order of column names.

Importing tool data

To import tool data:




- ▶ Select the **Tables** operating mode



- ▶ Select **Tool management**
- ▶ Enable **Edit**
- > The control enables tool management for editing.



- ▶ Select **Import**
- > The control opens a selection window.



- ▶ Select the desired CSV file
- ▶ Select **Import**
- > The control adds the tool data to the tool management.
- > If required, the control opens the **Confirm import** window (e.g., in case of identical tool numbers).
- ▶ Selecting the procedure:
 - **Append**: the control adds the tool data as new rows at the end of the table.
 - **Overwrite**: the control overwrites the initial tool data with the tool data from the transfer file.
 - **Cancel**: the control cancels the import process.

NOTICE

Caution: Data may be lost!

When overwriting existing tool data with the **Overwrite** function, the control will permanently delete the initial tool data!

- ▶ Use this function only with tool data that are no longer needed

Exporting tool data


To export tool data:



- ▶ Select the **Tables** operating mode



- ▶ Select **Tool management**
- ▶ Enable **Edit**
 - > The control enables tool management for editing.
- ▶ Mark the tool to be exported
- ▶ Open the context menu with a long press or by right-clicking
 - Further information:** User's Manual for Programming and Testing



- ▶ Select **Mark row**
- ▶ Mark further tools if required
- ▶ Select **Export**
 - > The control opens the **Save as** window.
- ▶ Select a path




By default, the control saves the transfer file under **TNC:\table**.

- ▶ Enter the file name
- ▶ Select the file type



You can export the following CSV formats:

- **TNC7 (semicolon-separated)**
- **iTNC 530 / TNC 640 (comma-separated)**



- ▶ Select **Create**
 - > The control will save the file using the selected path.

Notes

NOTICE

Caution: Possible material damage!

If the transfer file contains unknown column names, the control will not accept the data from this column! In this case, the control will perform the operations with an incompletely defined tool.

- ▶ Check whether the column names are correct
- ▶ After importing, check the tool data and adapt them if required.

- The transfer file must be saved under **TNC:\table**.
- The control creates an output of the CSV files with the following formatting:
 - **TNC7 (semicolon-separated)** encloses the values in double quotation marks, the individual values are separated by semicolons
 - **iTNC 530 / TNC 640 (comma-separated)** encloses the values in double curly brackets, the individual values are separated by commas

Most table calculation programs use the semicolon as the default separator.

The control is able to import and export data in both formats.

8.5 Tool carrier management

Application

With tool carrier management, you can assign the 3D model of a tool carrier to a tool.

The tool carrier model will be used for the following functions:

- Representation in the **Simulation** workspace
- Consideration in Dynamic Collision Monitoring (DCM (#40 / #5-03-1))

Related topics

- The **Simulation** workspace
Further information: User's Manual for Programming and Testing
- Dynamic Collision Monitoring (DCM (#40 / #5-03-1))
Further information: "Dynamic Collision Monitoring (DCM) (#40 / #5-03-1)", Page 206
- Adding a tool model to the tool definition (#140 / #5-03-2)
Further information: "Tool model (#140 / #5-03-2)", Page 171
- Validating a 3D model for the tool carrier (#56-61 / #3-02-1*)
Further information: "OPC UA NC Server (#56-61 / #3-02-1*)", Page 462

Requirements

- Kinematics description
The machine manufacturer creates the kinematics description
- Insertion point defined
The machine manufacturer defines the insertion point for the tool carrier.
- Tool carrier model exists
You must save the tool carrier model in the **Toolkinematics** folder.
Path: **TNC:\system\Toolkinematics**
- The tool carrier model has been assigned to the tool
Further information: "Assigning a tool carrier", Page 168

Description of function

The tool carrier model must meet the following requirements:

- Use permitted characters for the file name
Further information: User's Manual for Programming and Testing
- Use a supported format
 - CFG file
 - M3D file
 - STL file
 - Max. 20 000 triangles
 - Triangular mesh forms a closed shell**Further information:** "Generating STL files with 3D mesh (#152 / #1-04-1)", Page 264



For tool carriers, the same requirements with respect to STL and M3D files apply as for fixtures.

Further information: "Options for fixture files", Page 214

If you are using CFT or CFX files, you must edit the templates in the **ToolHolderWizard** window.

Further information: "Customizing tool carrier templates with ToolHolderWizard", Page 170

8.5.1 Assigning a tool carrier

To assign a tool carrier to a tool:



▶ Select the **Tables** operating mode

▶ Select **Tool management**

▶ Select the tool you want to use

▶ Enable **Edit**




▶ If applicable, open the **Form** workspace

▶ In the **Additional geometry data** area, select the **KINEMATIC** parameter

> The control displays the available tool carriers in the **Tool-carrier kinematics** window.

▶ Select the desired tool carrier

▶ Select **OK**



> The control assigns the 3D model of the tool carrier to the tool.



The tool carrier will only be taken into account after the next tool call.

Notes

- Sample files for tool carrier templates are available on the programming station in the **TNC:\system\Toolkinematics** folder.
- In the simulation, the tool carriers can be checked for collisions with the workpiece.
Further information: User's Manual for Programming and Testing
- On 3-axis machines with rectangular angle heads, tool carriers of angle heads are advantageous in connection with the tool axes **X** and **Y** because the control takes the dimensions of the angle heads into account.
HEIDENHAIN recommends machining in the **Z** tool axis. Using the software option Advanced Functions Set 1 (#8 / #1-01-1), you can tilt the working plane to the angle of the removable angled heads and thus keep working with the **Z** tool axis.
- The control monitors the tool carriers by means of Dynamic Collision Monitoring (DCM (#40 / #5-03-1)). Thus, the tool carriers are protected against collisions with fixtures or machine components.
Further information: "Dynamic Collision Monitoring (DCM) (#40 / #5-03-1)", Page 206
- Even if the inch unit of measure is active in the control or NC program, the control will interpret dimensions of 3D files in mm.

8.6 Customizing tool carrier templates with ToolHolderWizard

i Many tool carriers only differ from others in terms of their dimensions, but their geometric shape is identical. HEIDENHAIN provides ready-to-use tool carrier templates for downloading. Tool carrier templates are 3D models with fixed geometries but editable dimensions.

They can be downloaded through the following link:











HEIDENHAIN NC solutions

If you need further tool carrier templates, please contact your machine manufacturer or third-party vendor.

If you would like to use a CFX or CFT file, you need to parameterize the tool carrier template (i.e., to define the required dimensions). The tool carrier templates can be parameterized in the **ToolHolderWizard** window.

Further information: "Parameterizing tool carrier templates", Page 171

The **ToolHolderWizard** window contains the following icons:

Icon	Meaning
	Close the application
	Open file
	Switch between wire frame model and solid object view
	Switch between shaded and transparent view
	Show or hide Transformation vectors
	Show or hide Names of collision objects
	Show or hide Test points
	Show or hide Measuring points
	Redo (restore) the initial view
	Orientations (e.g., top view)

8.6.1 Parameterizing tool carrier templates

To parameterize a tool carrier template:



- ▶ Select the **Files** operating mode



- ▶ Open the **TNC:\system\Toolkinematics** folder
- ▶ Double-tap or double-click desired tool carrier template with the ***.cft** extension
- > The control opens the **ToolHolderWizard** window.
- ▶ Define the dimensions in the **Parameter** area
- ▶ Define a name with the ***.cfx** extension in the **Output file** area
- ▶ Select **Generate file**
- > The control shows the message that the tool carrier template was successfully generated and saves the file in the folder **TNC:\system\Toolkinematics**.
- ▶ Select **OK**



- ▶ Select **Close the application**



Parameterized tool carriers can consist of several subfiles. If the subfiles are incomplete, the control will display an error message.
Only use fully parameterized tool carriers and error-free STL or M3D files!

8.7 Tool model (#140 / #5-03-2)

Application

With the tool model, you can add to a tool definition (e.g., for forward or reverse deburring tools).

The tool model will be used in the following functions only:

- Representation in the **Simulation** workspace
- Consideration in Dynamic Collision Monitoring (DCM (#40 / #5-03-1))



The control will not use the tool model for path contours (e.g., for radius compensation or the **FUNCTION TCPM** function).

Related topics

- The **Simulation** workspace
- Dynamic Collision Monitoring (DCM (#40 / #5-03-1))
Further information: "Dynamic Collision Monitoring (DCM) (#40 / #5-03-1)", Page 206
- Tool carrier management
Further information: "Tool carrier management", Page 167
- Validating 3D models with **OPC UA NC Server** (#56-61 / #3-02-1*)
Further information: "OPC UA NC Server (#56-61 / #3-02-1*)", Page 462

Requirements

- Software option Dynamic Collision Monitoring (DCM) version 2 (#140 / #5-03-2)
- The tool has been defined in tool management
Further information: "Tool management ", Page 163
- A suitable tool model exists
 You must save the tool model in the **Toolshapes** folder.
 Path: **TNC:\system\Toolshapes**
Further information: "Tool model requirements", Page 172
- The tool model has been assigned to the tool
Further information: "Assigning a tool model", Page 173

Description of function

You can use the tool model for the following tool types:

- Milling tools
- Drilling tools
- Touch probes

Further information: "Tool types", Page 155

Tool model requirements

General requirements

The tool model must meet the following general requirements:

- Use permitted characters for the file name
Further information: User's Manual for Programming and Testing
- Use a supported format
 - M3D file
 - STL file
 - Max. 20 000 triangles
 - Triangular mesh forms a closed shell**Further information:** "Generating STL files with 3D mesh (#152 / #1-04-1)", Page 264



For tool models, the same requirements with respect to STL and M3D files apply as for fixtures.

Further information: "Options for fixture files", Page 214

Coordinate system requirements

The coordinate system of the tool model must meet the following requirements:

- The Z axis is the rotary axis of the tool model.
 The control will align the tool model parallel to the tool coordinate system **T-CS**.
Further information: "Tool coordinate system T-CS", Page 192
- The coordinate origin of the 3D model must be identical to the measured point of the tool. If you measure the tool at the tool tip, you also need to set the coordinate origin of the 3D model to the tool tip.



If you measured a spherical cutter at the center of the sphere, you need to set the coordinate origin to the center of the sphere as well.

Further information: "Tool tip TIP ", Page 148

Further information: User's Manual for Programming and Testing

8.7.1 Assigning a tool model

To assign a tool model to a tool:




- ▶ Select the **Tables** operating mode

- ▶ Select **Tool management**
- ▶ Select the tool you want to use



- ▶ Activate **Edit**

- ▶ If applicable, open the **Form** workspace
- ▶ In the **Additional geometry data** area, select the **TSHAPE** parameter
- > The control displays the available tool models in the **3D tool model** window.



- ▶ Select the desired tool model
- ▶ Select **OK**
- > The control assigns the tool model to the tool.



The tool model will only be taken into account after the next tool call.

Notes

- The control will always take an assigned tool model into account (e.g., for the tool radius **R=0**). The simulation shows the correct shape of the tool model (e.g., in conjunction with a CAM output (center path)).
- When you delete a tool, make sure to remove the tool model from the **Toolshapes** folder as well. This way, you can avoid that the tool model is accidentally referenced for another tool.
- The **LCUTS** column of the tool table is independent of the datum of the tool model. The value is measured from the tool tip of the tool and is effective in the positive Z axis direction.
Further information: "Tool table tool.t", Page 363
- Even if the inch unit of measure is active in the control or NC program, the control will interpret dimensions of 3D files in mm.

8.8 Tool usage test

Application

The tool usage test allows checking the tools used in the NC program before starting the program. The control checks if the tools used are available in the machine magazine and have sufficient remaining tool life. Any missing tools can be stored in the machine or tools can be exchanged due to insufficient remaining tool life before starting the program. This avoids interruptions while the program is running.

Related topics

- Contents of the tool usage file
Further information: "Tool usage file", Page 380
- Tool usage test in Batch Process Manager (#154 / #2-05-1)
Further information: User's Manual for Programming and Testing

Requirements

- To perform a tool usage test, you need a tool usage file
In the machine parameter **createUsageFile** (no. 118701), the machine manufacturer defines whether the **Generate tool-usage file** function will be enabled.
Further information: "Tool usage file", Page 380
- The **Generate tool-usage file** setting is set to **Once** or **Always**
Further information: "Channel Settings", Page 440
- Use the same tool table for the simulation as for the program run
Further information: User's Manual for Programming and Testing

Description of function

Creating the tool usage file

A tool usage file must be generated for performing the tool usage test.


When setting the **Generate tool-usage file** setting to **once** or **always**, the control will generate a tool usage file in the following cases:

- Simulating the NC program completely
- Executing the NC program completely
- Select the **Refresh** icon in the **Tool usage** area of the **Tool check** column

The control saves the tool usage file with the ***.t.dep** extension in the same folder where the NC program is stored.

Further information: "Tool usage file", Page 380

The Tool check column in the Program workspace



The **Tool check** column in the **Program** workspace

In the **Tool check** column of the **Program** workspace, the control displays the following areas:

- **Tool usage**
Further information: "The Tool usage area", Page 175
- **Tool check**
Further information: "The Tool check area", Page 176
- **Perform conditional stop**
Further information: "Override Controller", Page 415

Further information: User's Manual for Programming and Testing

The Tool usage area

If no tool-usage file has been created yet, the **Tool usage** area is empty.

Further information: "Creating the tool usage file", Page 174

Further information: "Tool usage file", Page 380

The control displays the chronological order of all tool calls in the **Tool usage** area, along with the following information:

- Path of NC program in which the tool is called
- Tool number and possibly tool name
- Row number of tool call in NC program
- Tool usage time between the tool changes

Select the **Refresh** icon to create a tool-usage file for your NC program.

The Tool check area

The **Tool check** area is empty until you perform a tool usage test with the **Refresh** icon.

Further information: "Performing the tool usage test", Page 176

When performing the tool usage test, the control checks the following:







- The tool is defined in the tool management
Further information: "Tool management ", Page 163
- The tool is defined in the pocket table
Further information: "Pocket table tool_p.tch", Page 377
- The tool has sufficient remaining tool life
The control checks if the remaining tool life **TIME1** minus **CUR_TIME** is sufficient for the machining process. To meet this requirement, the remaining tool life must be longer than the tool usage time **WTIME** from the tool usage file.
Further information: "Tool table tool.t", Page 363
Further information: "Tool usage file", Page 380

The control displays the following information in the **Tool check** area:

- **OK:** All tools are available and have sufficient remaining tool life
- **No suitable tool:** The tool is not defined in the tool management
In this case, check if the correct tool is selected in the tool call. Otherwise, create the tool in the tool management.
- **External tool:** The tool is defined in the tool management, but not in the pocket table
If your machine is equipped with a magazine, position the missing tool in the magazine.
- **Insufficient remaining tool life:** The tool is blocked or does not have sufficient remaining tool life
Change the tool or use a replacement tool.
Further information: User's Manual for Programming and Testing

8.8.1 Performing the tool usage test

To perform a tool usage test:

-  ▶ Select the **Editor** operating mode
-  ▶ Select **Add**
▶ Select the desired NC program
-  ▶ Select **Open**
▶ The control opens the NC program in a new tab.
-  ▶ Open the **Tool check** column
-  ▶ In the **Tool usage** area, select **Refresh**
▶ The control generates a tool usage file and displays the tools used in the **Tool usage** area.
Further information: "Tool usage file", Page 380
-  ▶ In the **Tool check** area, select **Refresh**
▶ The control performs the tool usage test.
▶ The **Tool check** area shows whether all tools are available and have sufficient remaining tool life.

Notes

- If you double-tap or double-click a tool entry in the **Tool usage** or **Tool check** areas, the control switches to the tool selected in tool management. You can make modifications as needed.
- The **Simulation settings** window allows selecting when the control generates a tool usage file for the simulation.
Further information: User's Manual for Programming and Testing
- The control saves the tool usage file as a dependent file (***.dep**).
Further information: "Tool usage file", Page 380
- In the settings of the **Files** operating mode, you can specify whether the control displays dependent files in the file management.
Further information: User's Manual for Programming and Testing
- The control displays the order of tool calls of the currently running NC program in the **T usage order** (#93 / #2-03-1) table.
Further information: "T usage order (#93 / #2-03-1)", Page 382
- An overview of all tool calls of the NC program active in the program run is displayed by the control in the **Tooling list** table (#93 / #2-03-1).
Further information: "Tooling list (#93 / #2-03-1)", Page 384
- The function **FN 18: SYSREAD ID975 NR1** allows querying the tool usage test for an NC program.
- The function **FN 18: SYSREAD ID975 NR2 IDX** allows querying the tool usage test for a pallet table. After **IDX** you define the pallet table row.
- The machine manufacturer uses the machine parameter **autoCheckPrg** (no. 129801) to define whether the control automatically generates a tool usage file upon selecting an NC program.
- The machine manufacturer uses the machine parameter **autoCheckPal** (no. 129802) to define whether the control automatically generates a tool usage file upon selecting a pallet table.

9

Coordinate Transformation

9.1 Reference systems

9.1.1 Overview

A control requires unambiguous coordinates in order to move an axis to a defined position correctly. For coordinates to be unambiguous, they not only require the values but also a reference system in which these values are valid.

The control differentiates between the following reference systems:

Abbrevia- tion	Meaning	Further information
M-CS	Machine coordinate system machine coordinate system	Page 182
B-CS	Basic coordinate system basic coordinate system	Page 184
W-CS	Workpiece coordinate system workpiece coordinate system	Page 186
WPL-CS	Working plane coordinate system working plane coordinate system	Page 187
I-CS	Input coordinate system input coordinate system	Page 191
T-CS	Tool coordinate system tool coordinate system	Page 192

The control uses different reference systems for different purposes. For example, this makes it possible to always exchange tools at the exact same position while maintaining the possibility of adapting an NC program to the workpiece position.

The reference systems build upon each other. The machine coordinate system **M-CS** is the fundamental reference system. The position and orientation of the following reference systems are determined by transformations of the M-CS.

Definition

Transformations

Translatory transformations each enable a shift along a number line. Rotatory transformations enable a rotation around a point.

9.1.2 Basics of coordinate systems


Types of coordinate systems

For coordinates to be unambiguous they must define one point in all axes of the coordinate system:

Axes	Function
One	In a one-dimensional coordinate system, one coordinate defines one point on a number line. Example: on a machine tool, a linear encoder represents a number line.
Two	In a two-dimensional coordinate system, two coordinates define one point in a plane.
Three	In a three-dimensional coordinate system, three coordinates define one point in space.


If the axes are arranged perpendicularly to each other, they create a Cartesian coordinate system.

Using the right-hand rule you can recreate a three-dimensional Cartesian coordinate system. The fingertips point in the positive directions of the three axes.



Origin of the coordinate system

Unambiguous coordinates require a defined reference point to which the values refer, starting from zero. This point is the coordinate origin, which lies at the intersection of the axes for all three-dimensional Cartesian coordinate systems of the control. The coordinate origin has the coordinates **X+0, Y+0, and Z+0**.



9.1.3 Machine coordinate system M-CS

Application


In the machine coordinate system **M-CS** you program constant positions, such as a safe position for retraction. The machine manufacturer also defines constant positions in the **M-CS**, such as the tool-change point.

Description of function

Properties of M-CS machine coordinate system


The machine coordinate system **M-CS** corresponds to the kinematics description and therefore to the actual mechanical design of the machine tool. The physical axes of a machine tool are not necessarily always exactly perpendicular to each other, and therefore do not represent a Cartesian coordinate system. The **M-CS** thus consists of multiple one-dimensional coordinate systems that correspond to the axes of the machine.

The machine manufacturer defines the position and orientation of the one-dimensional coordinate systems in the kinematics description.



The machine datum is the coordinate origin of the **M-CS**. The machine manufacturer defines the machine datum in the machine configuration.

The values in the machine configuration define the zero positions of the position encoders and the corresponding machine axes. The machine datum does not necessarily have to be located in the theoretical intersection of the physical axes. It can also be located outside of the traverse range.




Position of the machine datum in the machine

Transformations in the machine coordinate system M-CS

The following transformations can be defined in the **M-CS** machine coordinate system:

- Axis-specific shifts in the **OFFS** columns of the preset table

Further information: "Preset table *.pr", Page 385




The machine manufacturer configures the **OFFS** columns of the preset table in accordance with the machine.

- Axis-specific shifts in the rotary and parallel axes using the datum table

Further information: User's Manual for Programming and Testing

- Axis-specific shifts in the rotary and parallel axes using the **TRANS DATUM** function

Further information: User's Manual for Programming and Testing



The machine manufacturer can also define further transformations.
Further information: "Note", Page 183

Position display

The following modes of the position display are referenced to the machine coordinate system **M-CS**:

- **Nominal reference position (RFNOML)**
- **Actual reference position (RFACTL)**

The difference between the values for the **RFACTL** and **ACTL** modes of an axis result from all stated offsets as well as all active transformations in other reference systems.

Programming coordinate entry in machine coordinate system M-CS

With miscellaneous function **M91** you program the coordinates relative to the machine datum.

Further information: User's Manual for Programming and Testing

Note

The machine manufacturer can define the following further transformations in the machine coordinate system **M-CS**:

- Additive axis shifts for parallel axes with the **OEM-offset**
- Axis-specific shifts in the **OFFS** columns of the pallet preset table

NOTICE

Danger of collision!

The control may feature an additional pallet preset table, depending on the machine. Values that the machine manufacturer defined in the pallet preset table take effect before values that you defined in the preset table. The control indicates in the **Positions** workspace whether a pallet preset is active and if yes, which one. Since the values of the pallet preset table are neither visible nor editable outside the **Setup** application, there is a risk of collision during any movement!

- ▶ Refer to the machine manufacturer's documentation
- ▶ Use pallet presets only in conjunction with pallets
- ▶ Change pallet presets only after discussion with the machine manufacturer
- ▶ Check the pallet preset in the **Setup** application before you start machining

Example

This example illustrates the difference between traverse movements with and without **M91**. The example shows the behavior with a Y axis as oblique axis that is not arranged perpendicularly to the ZX plane.

Traverse movement without M91

```
11 L IY+10
```

You use the Cartesian input coordinate system **I-CS** for programming. The **ACTL.** and **NOML.** modes of the position display show only a movement of the Y axis in the **I-CS**.

The control uses the defined values to determine the required traverse paths of the machine axes. Since the machine axes are not arranged perpendicularly to each other, the control moves the axes **Y** and **Z**.

Since the machine coordinate system **M-CS** is a projection of the machine axes, the **RFACTL** and **RFNOML** modes of the position display show movements of the Y axis and Z axis in the **M-CS**.

Traverse movement with M91

```
11 L IY+10 M91
```

The control moves the machine axis **Y** by 10 mm. The **RFACTL** and **RFNOML** modes of the position display show only a movement of the Y axis in the **M-CS**.

In contrast to the **M-CS**, the **I-CS** is a Cartesian coordinate system; the axes of the two reference systems do not coincide. The **ACTL.** and **NOML.** modes of the position display show movements of the Y axis and Z axis in the **I-CS**.

9.1.4 Basic coordinate system B-CS

Application

In the basic coordinate system **B-CS** you define the position and orientation of the workpiece. You determine these values by using a 3D touch probe, for example. The control saves the values in the preset table.

Description of function

Properties of the basic coordinate system B-CS

The basic coordinate system **B-CS** is a three-dimensional Cartesian coordinate system. Its coordinate origin is the end of the kinematics description.

The machine manufacturer defines the coordinate origin and orientation of the **B-CS**.


Transformations in the basic coordinate system B-CS


The following columns of the preset table have an effect in the basic coordinate system **B-CS**:

- X
- Y
- Z
- SPA
- SPB
- SPC

You determine the position and orientation of the workpiece coordinate system **W-CS** by using a 3D touch probe, for example. The control saves the determined values as basic transformations in the **B-CS** in the preset table.

Further information: "Preset management", Page 194



 The machine manufacturer configures the **BASE TRANSFORM.** columns of the preset table in accordance with the machine.

Further information: "Note", Page 185

Note

The machine manufacturer can define additional basic transformations in the pallet preset table.

NOTICE

Danger of collision!

The control may feature an additional pallet preset table, depending on the machine. Values that the machine manufacturer defined in the pallet preset table take effect before values that you defined in the preset table. The control indicates in the **Positions** workspace whether a pallet preset is active and if yes, which one. Since the values of the pallet preset table are neither visible nor editable outside the **Setup** application, there is a risk of collision during any movement!

- ▶ Refer to the machine manufacturer's documentation
- ▶ Use pallet presets only in conjunction with pallets
- ▶ Change pallet presets only after discussion with the machine manufacturer
- ▶ Check the pallet preset in the **Setup** application before you start machining

9.1.5 Workpiece coordinate system W-CS

Application

In the workpiece coordinate system **W-CS** you define the position and orientation of the working plane. You do this by programming transformations and tilting the working plane.


Description of function

Properties of the workpiece coordinate system W-CS

The workpiece coordinate system **W-CS** is a three-dimensional Cartesian coordinate system. Its coordinate origin is the active workpiece preset from the preset table.

Both the position and orientation of the **W-CS** are defined by basic transformations in the preset table.

Further information: "Preset management", Page 194



Transformations in the workpiece coordinate system (W-CS)


HEIDENHAIN recommends using the following transformations in the workpiece coordinate system **W-CS**:

- Axes **X, Y, Z** of the **TRANS DATUM** function before tilting the working plane
Further information: User's Manual for Programming and Testing
- Columns **X, Y, Z** of the datum table before tilting the working plane
Further information: User's Manual for Programming and Testing
- The **TRANS MIRROR** function or Cycle **8 MIRRORING** before tilting the working plane with spatial angles
Further information: User's Manual for Programming and Testing
Further information: User's Manual for Machining Cycles
- **PLANE** functions for tilting the working plane (#8 / #1-01-1)
Further information: User's Manual for Programming and Testing



You can still run NC programs from earlier controls that contain Cycle **19 WORKING PLANE**.

With these transformations, the position and orientation of the working plane coordinate system **WPL-CS** are changed.



NOTICE**Danger of collision!**

The control reacts differently to the various types of transformations as well as their programmed sequence. Unexpected movements or collisions can occur if the functions are not suitable.

- ▶ Program only the recommended transformations in the respective reference system
- ▶ Use tilting functions with spatial angles instead of with axis angles
- ▶ Use the Simulation mode to test the NC program



In the machine parameter **planeOrientation** (no. 201202), the machine manufacturer defines whether the control interprets input values of Cycle **19 WORKING PLANE** as spatial angles or as axis angles.

The type of tilting function has the following effects on the result:

- If you tilt using spatial angles (**PLANE** functions except for **PLANE AXIAL** or Cycle **19**), previously programmed transformations will change the position of the workpiece datum and the orientation of the rotary axes:
 - Shifting with the **TRANS DATUM** function will change the position of the workpiece datum.
 - Mirroring changes the orientation of the rotary axes. The entire NC program, including the spatial angles, will be mirrored.
- If you tilt using axis angles (**PLANE AXIAL** or Cycle **19**), a previously programmed mirroring has no effect on the orientation of the rotary axes. You use these functions for direct positioning of the machine axes.

Notes

- The programmed values in the NC program refer to the input coordinate system **I-CS**. If you do not program any transformations in the NC program, then the origin and position of the workpiece coordinate system **W-CS**, the working plane coordinate system **WPL-CS**, and the **I-CS** are identical.

Further information: "Input coordinate system I-CS", Page 191
- During pure 3-axis machining, the workpiece coordinate system **W-CS** and the working plane coordinate system **WPL-CS** are identical. In this case, all transformations influence the input coordinate system **I-CS**.

Further information: "Working plane coordinate system WPL-CS", Page 187
- The result of transformations built upon each other depends on the programming sequence.

9.1.6 Working plane coordinate system WPL-CS**Application**

In the working plane coordinate system **WPL-CS** you define the position and orientation of the input coordinate system **I-CS** and therefore the reference for the coordinate system in the NC program. You do this by programming transformations after having tilted the working plane.

Further information: "Input coordinate system I-CS", Page 191


Description of function

Properties of the working plane coordinate system WPL-CS

The working plane coordinate system **WPL-CS** is a three-dimensional Cartesian coordinate system. You use transformations in the workpiece coordinate system **W-CS** to define the coordinate origin of the **WPL-CS**.

Further information: "Workpiece coordinate system W-CS", Page 186

If no transformations are defined in the **W-CS**, then the position and orientation of the **W-CS** and **WPL-CS** are identical.




Transformations in the working plane coordinate system WPL-CS

HEIDENHAIN recommends using the following transformations in the working plane coordinate system **WPL-CS**:

- Axes **X, Y, Z** of the **TRANS DATUM** function
Further information: User's Manual for Programming and Testing
- The **TRANS MIRROR** function or Cycle **8 MIRRORING**
Further information: User's Manual for Programming and Testing
Further information: User's Manual for Machining Cycles
- The **TRANS ROTATION** function or Cycle **10 ROTATION**
Further information: User's Manual for Programming and Testing
Further information: User's Manual for Machining Cycles
- The **TRANS SCALE** function or Cycle **11 SCALING FACTOR**
Further information: User's Manual for Programming and Testing
Further information: User's Manual for Machining Cycles
- Cycle **26 AXIS-SPECIFIC SCALING**
Further information: User's Manual for Machining Cycles
- The **PLANE RELATIV** function (#8 / #1-01-1)
Further information: User's Manual for Programming and Testing

With these transformations you modify the position and orientation of the input coordinate system **I-CS**.



NOTICE

Danger of collision!

The control reacts differently to the various types of transformations as well as their programmed sequence. Unexpected movements or collisions can occur if the functions are not suitable.

- ▶ Program only the recommended transformations in the respective reference system
- ▶ Use tilting functions with spatial angles instead of with axis angles
- ▶ Use the Simulation mode to test the NC program

Notes

- The programmed values in the NC program refer to the input coordinate system **I-CS**. If you do not program any transformations in the NC program, then the origin and position of the workpiece coordinate system **W-CS**, the working plane coordinate system **WPL-CS**, and the **I-CS** are identical.
Further information: "Input coordinate system I-CS", Page 191
- During pure 3-axis machining, the workpiece coordinate system **W-CS** and the working plane coordinate system **WPL-CS** are identical. In this case, all transformations influence the input coordinate system **I-CS**.
- The result of transformations built upon each other depends on the programming sequence.
- As a **PLANE** function (#8 / #1-01-1), **PLANE RELATIV** is in effect in the workpiece coordinate system **W-CS** and orients the working plane coordinate system **WPL-CS**. The values of additive tilting always relate to the current **WPL-CS**.

9.1.7 Input coordinate system I-CS

Application

The programmed values in the NC program refer to the input coordinate system **I-CS**. You use positioning blocks to program the position of the tool.


Description of function

Properties of the input coordinate system I-CS

The input coordinate system **I-CS** is a three-dimensional Cartesian coordinate system. You use transformations in the working plane coordinate system **WPL-CS** to define the coordinate origin of the **I-CS**.

Further information: "Working plane coordinate system WPL-CS", Page 187

If no transformations are defined in the **WPL-CS**, then the position and orientation of the **WPL-CS** and **I-CS** are identical.



Positioning blocks in the input coordinate system I-CS

In the input coordinate system **I-CS** you use positioning blocks to define the position of the tool. The position of the tool defines the position of the tool coordinate system **T-CS**.

Further information: "Tool coordinate system T-CS", Page 192

You can define the following positioning blocks:

- Paraxial positioning blocks
- Path functions with Cartesian or polar coordinates
- Straight lines **LN** with Cartesian coordinates and surface normal vectors (#9 / #4-01-1)
- Cycles

11 X+48 R+	; Paraxial positioning block
11 L X+48 Y+102 Z-1.5 R0	; Path function L
11 LN X+48 Y+102 Z-1.5 NX-0.04658107 NY0.00045007 NZ0.8848844 R0	; Straight line LN with Cartesian coordinates and surface normal vector

Position display

The following modes of the position display are referenced to the input coordinate system **I-CS**:

- **Nominal pos. (NOML)**
- **Actual pos. (ACT)**

Notes

- The programmed values in the NC program refer to the input coordinate system **I-CS**. If you do not program any transformations in the NC program, then the origin and position of the workpiece coordinate system **W-CS**, the working plane coordinate system **WPL-CS**, and the **I-CS** are identical.
- During pure 3-axis machining, the workpiece coordinate system **W-CS** and the working plane coordinate system **WPL-CS** are identical. In this case, all transformations influence the input coordinate system **I-CS**.

Further information: "Working plane coordinate system WPL-CS", Page 187

9.1.8 Tool coordinate system T-CS

Application

In the tool coordinate system **T-CS** the control implements tool compensations and tool inclinations.

Description of function

Properties of the tool coordinate system T-CS

The tool coordinate system **T-CS** is a three-dimensional Cartesian coordinate system. Its coordinate origin is the tool tip TIP.

You make entries in the tool management to define the tool tip relative to the tool carrier reference point. The machine manufacturer usually defines the tool carrier reference point on the spindle tip.

Further information: "Presets in the machine", Page 142

You define the tool tip with the following columns of the tool management relative to the tool carrier reference point:

- L
- DL

Further information: "Tool carrier reference point", Page 147

You use positioning blocks in the input coordinate system **I-CS** to define the position of the tool and therefore the position of the **T-CS**.

Further information: "Input coordinate system I-CS", Page 191

You can use miscellaneous functions to also program in other reference systems, such as **M91** for the machine coordinate system **M-CS**.


Further information: User's Manual for Programming and Testing

The orientation of the **T-CS** in most cases is identical to that of the **I-CS**.

If the following functions are active, the orientation of the **T-CS** depends on the tool angle of inclination:

- Miscellaneous function **M128** (#9 / #4-01-1)
- The **FUNCTION TCPM** function (#9 / #4-01-1)

Further information: User's Manual for Programming and Testing



Use the miscellaneous function **M128** to define the tool angle of inclination in the machine coordinate system **M-CS** using axis angles. The effects of the tool angle of inclination depend on the machine kinematics:

Further information: User's Manual for Programming and Testing

11 L X+10 Y+45 A+10 C+0 R0 M128	; Straight line with miscellaneous function M128 and axis angles
--	---

You can also define a tool angle of inclination in the working plane coordinate system **WPL-CS**, for example with **FUNCTION TCPM** or a straight line **LN**.

11 FUNCTION TCPM F TCP AXIS SPAT PATHCTRL AXIS	; FUNCTION TCPM with spatial angles
---	--

12 L A+0 B+45 C+0 R0 F2500	
-----------------------------------	--

11 LN X+48 Y+102 Z-1.5 NX-0.04658107 NY0.00045007 NZ0.8848844 TX0 TY-0.34090025 TZ0.93600126 R0 M128	; Straight line LN with surface normal vector and tool orientation
---	---

Transformations in the tool coordinate system T-CS

The following tool compensations have an effect in the tool coordinate system **T-CS**:

- Compensation values from the tool management
Further information: User's Manual for Programming and Testing
- Compensation values from the tool call
Further information: User's Manual for Programming and Testing
- Values of the compensation tables ***.tco**
Further information: User's Manual for Programming and Testing
- 3D tool compensation with surface normal vectors (#9 / #4-01-1)
Further information: User's Manual for Programming and Testing

9.2 Preset management

Application

The preset management allows setting and activating single presets. The presets to be saved may include, for example, the position and the misalignment of a workpiece in the preset table. The active row of the preset table serves as the workpiece preset in the NC program and as the origin of workpiece coordinate system **W-CS**.

Further information: "Presets in the machine", Page 142

Use the preset management in the following cases:

- To tilt the working plane of a machine with table or head rotation axes (#8 / #1-01-1)
- To work on a machine with a head change system
- To machine several workpieces that are clamped down at different misaligned positions
- If REF-based datum tables were used on previous control models

Related topics

- Contents of preset table, write protection
Further information: "Preset table *.pr", Page 385

Description of function

Setting presets

Presets can be set in the following ways:


- Setting axis positions manually
Further information: "Setting a preset manually", Page 197
- Touch probe cycles in the **Setup** application
Further information: "Touch Probe Functions in the Manual Operating Mode (#17 / #1-05-1)", Page 289
- Touch probe cycles in the NC program (#17 / #1-05-1)

If you try to write a value in a write-protected preset table row, the control cancels this process with an error message. Write-protection for this row must be rescinded first.

Further information: "Removing write protection", Page 391

Setting a preset with milling cutters

If no workpiece touch probe is available, the preset can also be set by using a milling cutter. In this case, the values are not obtained by probing, but by scratching.



When scratching with a milling cutter, the tool is slowly moved to the workpiece edge in the **Manual operation** application while the spindle is rotating.

As soon as the tool produces chips on the workpiece, the preset is manually set in the desired axis.

Further information: "Setting a preset manually", Page 197

Activating presets

NOTICE

Caution: Significant property damage!

Undefined fields in the preset table behave differently from fields defined with the value **0**: Fields defined with the value **0** overwrite the previous value when activated, whereas with undefined fields the previous value is kept. If the previous value is kept, there is a danger of collision!

- ▶ Before activating a preset, check whether all columns contain values.
- ▶ For undefined columns, enter values (e.g., **0**)
- ▶ As an alternative, have the machine manufacturer define **0** as the default value for the columns

Presets can be activated in the following ways:

- Activating manually in the **Tables** operating mode
Further information: "Activating a preset manually", Page 198
- Cycle **247 PRESETTING**
Further information: User's Manual for Machining Cycles
- **PRESET SELECT** function
Further information: User's Manual for Programming and Testing

When activating a preset, the control resets the following transformations:

- Datum shift with the **TRANS DATUM** function
- Mirroring with the **TRANS MIRROR** function or cycle **8 MIRRORING**
- Rotation with the **TRANS ROTATION** function or cycle **10 ROTATION**
- Scaling with the **TRANS SCALE** function or cycle **11 SCALING FACTOR**
- Axis-specific scaling with Cycle **26 AXIS-SPECIFIC SCALING**

Tilting the working plane by using **PLANE** functions or Cycle **19 WORKING PLANE** will not be reset by the control.

Basic rotation and 3D basic rotation

The **SPA**, **SPB** and **SPC** columns define a spatial angle for orienting the workpiece coordinate system **W-CS**. This spatial angle defines the basic rotation or 3D basic rotation of the preset.

Further information: "Workpiece coordinate system W-CS", Page 186

When a rotation around the tool axis is defined, the preset contains a basic rotation (e.g., **SPC** for tool axis **Z**). If one of the remaining columns is defined, the preset contains a 3D basic rotation. If the workpiece preset contains a basic rotation or 3D basic rotation, the control takes these values into account when executing an NC program.


You can use the **3D ROT (#8 / #1-01-1)** button to define whether the control takes a basic rotation or 3D basic rotation into account in the **Manual operation** application.

Further information: User's Manual for Programming and Testing

When a basic rotation or 3D basic rotation is active, the control displays a symbol in the **Positions** workspace.

Further information: User's Manual for Programming and Testing

9.2.1 Setting a preset manually




The **Set a preset** window in the **Positions** workspace

When setting the preset manually, the values can be written either in row 0 of the preset table or in the active row.

To set a preset manually in an axis:



- ▶ Select the **Manual operation** application in the **Manual** operating mode
- ▶ Open the **Positions** workspace
- ▶ Traverse the tool to the desired position (e.g., for scratching)
- ▶ Select the row of the desired axis
- ▶ The control opens the **Set a preset** window.
- ▶ Enter the value of the current axis position, relating to the new preset (e.g., **0**)
- ▶ The control activates the **Preset 0** and **Active preset** buttons for selection.
- ▶ Select an option (e.g., **Active preset**)
- ▶ The control saves the value in the selected preset table row and closes the **Set a preset** window.
- ▶ The control updates the values in the **Positions** workspace.



i

- The **Set the preset** button in the function bar opens the **Set a preset** window for the row marked in green.
- When selecting **Preset 0**, the control automatically activates row 0 of the preset table as the workpiece preset.

9.2.2 Activating a preset manually

NOTICE

Caution: Significant property damage!

Undefined fields in the preset table behave differently from fields defined with the value **0**: Fields defined with the value **0** overwrite the previous value when activated, whereas with undefined fields the previous value is kept. If the previous value is kept, there is a danger of collision!

- ▶ Before activating a preset, check whether all columns contain values.
- ▶ For undefined columns, enter values (e.g., **0**)
- ▶ As an alternative, have the machine manufacturer define **0** as the default value for the columns

To activate a preset manually:



- ▶ Select the **Tables** operating mode
- ▶ Select the **Presets** application
- ▶ Select the desired row
- ▶ Select **Activate the preset**
- > The control activates the preset.
- > The control displays the number and comment of the active preset in the **Positions** workspace and in the status overview.

Activate
the preset

Further information: "Description of function", Page 97

Further information: "Status overview on the TNC bar", Page 103

Notes

- In the optional machine parameter **initial** (no. 105603), the machine manufacturer defines a default value for every column of a new row.
- In the optional machine parameter **CfgPresetSettings** (no. 204600), the machine manufacturer can block the setting of a preset in individual axes.
- When setting a preset, the positions of the rotary axes must match the tilting situation in the **3-D rotation** window (#8 / #1-01-1). If the rotary axes are positioned differently than is defined in the **3-D rotation** window, then, by default, the control aborts with an error message.

Further information: User's Manual for Programming and Testing

In the optional machine parameter **chkTiltingAxes** (no. 204601) the machine manufacturer defines the control reaction.

- When scratching a workpiece with the radius of a milling cutter, the radius value must be taken into account in the preset.
- Even if the current preset contains a basic rotation or a 3D basic rotation, the **PLANE RESET** function will position the rotary axes at 0° in the **MDI** application.

Further information: "The MDI Application", Page 279

- The control may feature a pallet preset table, depending on the machine. When a pallet preset is active, the presets in the preset table are referenced to this pallet preset.

Further information: User's Manual for Programming and Testing

9.3 Tilting the working plane (#8 / #1-01-1)


9.3.1 Fundamentals

Machines with rotary axes allow machining of, for example, several workpiece sides after one clamping process, by tilting the working plane. The tilting functions also allow aligning a workpiece clamped at an incorrect angle.

The working plane can be tilted only when tool axis **Z** is active.

The control functions for tilting the working plane are coordinate transformations. The working plane is always perpendicular to the direction of the tool axis.

Further information: "Working plane coordinate system WPL-CS", Page 187



Two functions are available for tilting the working plane:

- Manual tilting with the **3-D rotation** window in the **Manual operation** application
- Tilting under program control with the **PLANE** functions in the NC program

Further information: User's Manual for Programming and Testing



You can still run NC programs from earlier controls that contain Cycle **19 WORKING PLANE**.

Notes concerning different machine kinematics

When no transformations are active and the working plane is not tilted, the linear machine axes move in parallel with the basic coordinate system **B-CS**. In this process, machines behave almost identically, regardless of the kinematics.

Further information: "Basic coordinate system B-CS", Page 184


When tilting the working plane, the control moves the machine axes according to the kinematics.

Please observe the aspects below regarding the machine kinematics:

- Machine with table rotary axes

With this kinematic model, the table rotary axes execute the tilting movement and the position of the workpiece in the work envelope changes. The linear machine axes move in the tilted working plane coordinate system **WPL-CS** just as they do in the non-tilted **B-CS**.


Further information: "Working plane coordinate system WPL-CS", Page 187



- Machine with head rotary axes

With this kinematic model, the head rotary axes execute the tilting movement and the position of the workpiece in the work envelope remains the same. In the tilted **WPL-CS**, at least two linear machine axes no longer move in parallel with the non-tilted **B-CS**, depending on the rotary angle.

Further information: "Working plane coordinate system WPL-CS", Page 187



9.3.2 The 3-D rotation window (#8 / #1-01-1)

Application

The **3-D rotation** window allows activating and deactivating tilting of the working plane for the **Manual** and **Program Run** operating modes. This allows restoring the tilted working plane and retracting the tool (e.g., after program cancellation in the **Manual operation** application).

Related topics

- Tilting the working plane in the NC program
Further information: User's Manual for Programming and Testing
- Reference systems of the control
Further information: "Reference systems", Page 180


Requirements

- Machine with rotary axes
- Kinematics description
To calculate the tilting angles, the control requires a kinematics description prepared by the machine manufacturer.
- Software option Advanced Functions Set 1 (#8 / #1-01-1)
- Function enabled by the machine manufacturer
In the machine parameter **rotateWorkPlane** (no. 201201), the machine manufacturer defines whether tilting the working plane is allowed on the machine.
- Tool with tool axis **Z**

Description of function

The **3-D rotation** window can be opened with the **3D ROT** button in the **Manual operation** application.

Further information: "The Manual operation application", Page 134



The **3-D rotation** window

The **3-D rotation** window contains the following information:

Area	Contents
Info	Information about the machine: <ul style="list-style-type: none"> ■ Name of the active machine kinematics ■ Coordinate system in which handwheel superimpositioning is active Further information: "Reference systems", Page 180 Further information: User's Manual for Programming and Testing

Area	Contents
Manual Operation	<p>Effect of the tilting function in the Manual operating mode:</p> <ul style="list-style-type: none"> ■ None The control will not take the rotary axes positions that are not equal to 0 into account. Traverses take place in the W-CS workpiece coordinate system. Further information: "Workpiece coordinate system W-CS", Page 186 ■ Basic rotation The control takes the columns SPA, SPB and SPC into account, but no rotary axis positions that are not equal to 0. Traverses take place in the W-CS workpiece coordinate system. Further information: "Selection item Basic rotation", Page 203 ■ Tool axis This is relevant only for head rotary axes. The traverses take place in the T-CS tool coordinate system. Further information: "The Tool axis selection item", Page 204 ■ 3D ROT The control takes the positions of rotary axes and columns SPA, SPB and SPC of the preset table into account. The traverses take place in the WPL-CS working plane coordinate system. Further information: "The 3D ROT selection item", Page 204
Program run	<p>When activating the Tilt working plane function for the Program run operating mode, the entered angle of rotation applies starting from the first NC block of the NC program to be run.</p> <p>If you use Cycle 19 WORKING PLANE or the PLANE function in the NC program, then the angular values defined there become active. The control will reset the entered angular values to 0.</p>
3D ROT Spa. angle	<p>Currently active angle for the 3D ROT selection item</p> <p>The machine manufacturer uses the machine parameter planeOrientation (no. 201202) to define whether the control calculates with spatial angles SPA, SPB and SPC or with the axis values of the existing rotary axes.</p>

Confirm the selection with **OK**. If a selection item is active in the **Manual Operation** or **Program run** areas, then the control highlights the area in green.

If a selection item is active in the **3-D rotation** window, then the control displays the appropriate symbol in the **Positions** workspace.

Further information: "The Positions workspace", Page 97

Selection item Basic rotation

If you select **Basic rotation**, then the axes move, taking into account a basic rotation or a 3D basic rotation.

Further information: "Basic rotation and 3D basic rotation", Page 196

The axis movements take effect in the **W-CS** workpiece coordinate system.

Further information: "Workpiece coordinate system W-CS", Page 186

If the active workpiece preset contains a basic rotation or 3D basic rotation, the control additionally displays the corresponding icon in the **Positions** workspace.

Further information: "The Positions workspace", Page 97

With this selection item, the **3D ROT Spa. angle** area has no function.

The Tool axis selection item

If you select **Tool axis**, then you can move in the positive or negative direction of the tool axis. The control locks all other axes. This selection item makes sense only for machines with rotary head axes.

The traverse movement is active in the **T-CS** tool coordinate system.

Further information: "Tool coordinate system T-CS", Page 192

This selection item can be used, for example, in the following cases:

- When retracting the tool in the direction of the tool axis during an interruption of a 5-axis machining program.
- When traversing with the axis keys or the handwheel with a pre-positioned tool.

With this selection item, the **3D ROT Spa. angle** area has no function.

The 3D ROT selection item

If you select **3D ROT**, then all axes move in the tilted machining plane. The traversing movements are active in the **WPL-CS** working plane coordinate system.

Further information: "Working plane coordinate system WPL-CS", Page 187

If a basic rotation or 3D basic rotation has additionally been saved to the preset table, then it will automatically be taken into account.

In the **3D ROT Spa. angle** area, the control shows the currently active angle. The spatial angle can also be edited.



If you edit the values in the **3D ROT Spa. angle** area, then you must position the rotary axes (e.g., in the **MDI** application).

Notes

- The control uses the **COORD ROT** transformation type in the following situations:
 - if a **PLANE** function was previously executed with **COORD ROT**
 - after **PLANE RESET**
 - with corresponding configuration of the machine parameter **CfgRot-WorkPlane** (no. 201200) by the machine manufacturer



COORD ROT is only possible with a free rotary axis.

Further information: User's Manual for Programming and Testing

- The control uses the **TABLE ROT** transformation type in the following situations:
 - if a **PLANE** function was previously executed with **TABLE ROT**
 - with corresponding configuration of the machine parameter **CfgRot-WorkPlane** (no. 201200) by the machine manufacturer
- When setting a preset, the positions of the rotary axes must match the tilting situation in the **3-D rotation** window (#8 / #1-01-1). If the rotary axes are positioned differently than is defined in the **3-D rotation** window, then, by default, the control aborts with an error message.

In the optional machine parameter **chkTiltingAxes** (no. 204601) the machine manufacturer defines the control reaction.

- A tilted working plane will remain active even after a control restart.

Further information: "The Referencing workspace", Page 129

- PLC positionings defined by the machine manufacturer are not allowed when the working plane is tilted.

10


Collision Monitoring

10.1 Dynamic Collision Monitoring (DCM) (#40 / #5-03-1)

Fundamentals

Application

Dynamic Collision Monitoring (DCM, dynamic collision monitoring) can be used for collision monitoring of machine components defined by the machine manufacturer. When the collision objects come closer to each other than a defined minimum distance, the control stops and displays an error message. This procedure reduces the risk of collision.



Dynamic Collision Monitoring (DCM) including collision warning

Related topics

- Fundamentals of fixture management
Further information: "Fixture management", Page 213
- Extended tests in the simulation
Further information: User's Manual for Programming and Testing
- Fundamentals of tool carrier management
Further information: "Tool carrier management", Page 167
- Reduce the minimum clearance between two collision objects (#140 / #5-03-2)
Further information: User's Manual for Programming and Testing

Requirements

- Dynamic Collision Monitoring (DCM) software option (#40 / #5-03-1)
- Control prepared by the machine manufacturer
The machine manufacturer must define a kinematics model of the machine, insertion point for fixtures and the safety distance between collision objects.
Further information: "Fixture management", Page 213
- Tools with a positive radius **R** and length **L**.
Further information: "Tool table tool.t", Page 363
- The values in the tool management equal the actual tool dimensions
Further information: "Tool management ", Page 163

Description of function



Refer to your machine manual.

The machine manufacturer adapts the Dynamic Collision Monitoring (DCM) function to the control.

The machine manufacturer can define machine components and minimum distances to be monitored by the control during all machine movements. If two collision objects come closer to each other than a defined minimum distance, the control generates an error message and terminates the movement.



Error message for Dynamic Collision Monitoring (DCM)

NOTICE

Danger of collision!

If Dynamic Collision Monitoring (DCM) is deactivated, the control will not perform any automatic collision checking. This means that movements that might cause collisions will not be prevented. There is a risk of collision during all movements!

- ▶ Make sure to activate DCM whenever possible
- ▶ Make sure to always re-activate DCM immediately after a temporary deactivation
- ▶ Carefully test your NC program or program section in **Single Block** mode while DCM is deactivated

The control displays the collision objects graphically in the following operating modes:

- **Editor** operating mode
- **Manual** operating mode
- **Program Run** operating mode

The control also monitors the tools, as defined in tool management, for collision.

NOTICE

Danger of collision!

Even if Dynamic Collision Monitoring (DCM) is active, the control will not automatically monitor the workpiece for collisions, neither with the tool nor with other machine components. There is a risk of collision during machining!

- ▶ Activate the **Advanced checks** toggle switch for the simulation
- ▶ Check the machining sequence using a simulation
- ▶ Carefully test your NC program or program section in the **Single Block** mode

Further information: User's Manual for Programming and Testing

Dynamic Collision Monitoring (DCM) in the Manual and Program Run operating modes

Dynamic Collision Monitoring (DCM) is activated separately for the **Manual** and **Program Run** operating modes, using the **DCM** button.

Further information: "Activating Dynamic Collision Monitoring (DCM) for the Manual and Program Run operating modes", Page 211

In the **Manual** and **Program Run** operating modes, the control stops the movement if two collision objects approach each other by less than a minimum clearance. In this case, the control displays an error message naming the two objects causing collision.



Refer to your machine manual.

The machine manufacturer can define the minimum distance between two collision-monitored objects.

Before the collision warning, the control dynamically reduces the feed rate of movements. This ensures that the axes stop in good time before a collision occurs. When the collision warning is triggered, the control displays the colliding objects in red in the **Simulation** workspace.



When a collision warning has been issued, machine movements via the axis direction keys or the handwheel are only possible if they increase the distance between the collision objects.

With active collision monitoring and a simultaneous collision warning, no movements are permitted that reduce the distance or leave it unchanged.

Dynamic Collision Monitoring (DCM) in the Editor operating mode

Dynamic Collision Monitoring (DCM) is activated for simulation in the **Simulation** workspace.

Further information: User's Manual for Programming and Testing

In the **Editor** operating mode, an NC program can be collision-monitored even prior to execution. In case of collision, the control stops the simulation and displays an error message naming the two objects causing collision.

HEIDENHAIN recommends the use of Dynamic Collision Monitoring (DCM) in the **Editor** operating mode only in addition to DCM in the **Manual** and **Program Run** operating modes.



The enhanced collision monitoring shows collisions between the workpiece and tools or tool holders.

Further information: User's Manual for Programming and Testing

To obtain a simulation result that is similar to the program run, the following aspects must match:

- Workpiece preset
- Basic rotation
- Offsets of each axis
- Tilting condition
- Active kinematic model

The active workpiece preset for the simulation must be selected. The active workpiece preset from the preset table can be adopted into the simulation.

Further information: User's Manual for Programming and Testing

In a simulation, the following aspects may differ from the actual machine or may not be available at all:

- The simulated tool change position may differ from the tool change position in the machine.
- Changes in the kinematics may have a delayed effect in the simulation.
- PLC positioning movements are not displayed in the simulation.
- Handwheel override (#21 / #4-02-1) is not available
- Editing of job lists is not available
- Traverse range limits from the **Settings** application are not available.

Activating Dynamic Collision Monitoring (DCM) for the Manual and Program Run operating modes

NOTICE

Danger of collision!

If Dynamic Collision Monitoring (DCM) is deactivated, the control will not perform any automatic collision checking. This means that movements that might cause collisions will not be prevented. There is a risk of collision during all movements!

- ▶ Make sure to activate DCM whenever possible
- ▶ Make sure to always re-activate DCM immediately after a temporary deactivation
- ▶ Carefully test your NC program or program section in **Single Block** mode while DCM is deactivated

To activate Dynamic Collision Monitoring (DCM) for the **Manual** and **Program Run** operating modes:



- ▶ Select the **Manual** operating mode

DCM

- ▶ Select the **Manual** application
- ▶ Select **DCM**
- > The control opens the **Dyna. Coll. Monitoring (DCM)** window.
- ▶ Activate DCM in the desired operating modes, using the toggle switches


OK

- ▶ Press **OK**
- > The control activates DCM in the selected operating modes.



The control displays the status of Dynamic Collision Monitoring (DCM) in the **Positions** workspace. When deactivating DCM, the control displays an icon in the information bar.

Activating the graphic display of the collision objects



Simulation in the **Machine** mode

To activate the graphic display of the collision objects:



- ▶ Select an operating mode (e.g., **Manual**)

- ▶ Select **Workspaces**
- ▶ Select the **Simulation** workspace
- > The control opens the **Simulation** workspace.



- ▶ Select the **Visualization options** column
- ▶ Select the **Machine** mode
- > The control displays a graphic representation of the machine and the workpiece.

Changing the representation

To change the graphic display of the collision objects:

- ▶ Activate the graphic display of the collision objects



- ▶ Select the **Visualization options** column



- ▶ Change the graphic display of the collision objects (e.g., **Original**)

Notes

- Dynamic Collision Monitoring (DCM) helps you reduce the risk of collision. However, the control cannot consider all possible constellations during operation.
- The control can protect only those machine components from collision that your machine manufacturer has defined correctly with regard to dimensions, orientation, and position.
- The control takes the **DL** and **DR** delta values from the tool management into account. Delta values from the **TOOL CALL** block or a compensation table are not taken into account.
- For certain tools (e.g., face-milling cutters) the radius that would cause a collision can be greater than the value defined in the tool management.
- When a touch probe cycle starts, the control no longer monitors the stylus length and ball-tip diameter, so you can still probe collision objects.

10.2 Fixture management

10.2.1 Fundamentals

Application

You can integrate fixtures as 3D models in the control in order to represent clamping situations for simulation or execution.

When DCM is active, the control checks during simulation or machining if the fixture collides (#40 / #5-03-1).

Related topics

- Dynamic Collision Monitoring (DCM (#40 / #5-03-1))
Further information: "Dynamic Collision Monitoring (DCM) (#40 / #5-03-1)", Page 206
- Integrating an STL file as workpiece blank
Further information: User's Manual for Programming and Testing


Requirements

- Kinematics description
The machine manufacturer creates the kinematics description
- Insertion point defined
Using the insertion point, the machine manufacturer defines the preset for positioning the fixtures. The insertion point is often located at the end of the kinematic chain (e.g., at the center of a rotary table). For information about the position of the insertion point, please refer to your machine manual.
- Fixtures of suitable format:
 - STL file
 - 20,000 triangles maximum
 - Triangular mesh forms a closed shell
 - CFG file
 - M3D file

Description of function

To use fixture monitoring, the steps below are needed:

- Creating a fixture or loading it into the control
 - **Further information:** "Options for fixture files", Page 214
- Fixture placement
 - The **Set up fixtures** function in the **Setup** (#140 / #5-03-2) application
 - **Further information:** "Integrating fixtures into collision monitoring (#140 / #5-03-2)", Page 216
 - Manual fixture placement
- When changing fixtures, load or remove the fixture in the NC program
 - **Further information:** User's Manual for Programming and Testing



Three-jaw chuck loaded as fixture

Options for fixture files

If you use the **Set up fixtures** function to integrate fixtures, then only STL files are possible (#140 / #5-03-2).

Alternatively, CFG and M3D files can be set up manually.

You can use the function **3D mesh** (#152 / #1-04-1) to create STL files from other file types and adapt STL files to the requirements of your control.

Further information: "Generating STL files with 3D mesh (#152 / #1-04-1)", Page 264

Fixtures from STL files

STL files allow you to map both individual components and entire assemblies as an immobile fixture. The STL format is useful, in particular, for datum clamping systems and recurring setups.

If an STL file does not meet the requirements of the control, then the control issues an error message.

With the software option CAD Model Optimizer (#152 / #1-04-1), you can adapt STL files that do not meet the requirements and then use them for fixtures.

Further information: "Generating STL files with 3D mesh (#152 / #1-04-1)", Page 264

Fixtures from CFG files

CFG files are configuration files. You can integrate the STL and M3D files available in a CFG file. This enables you to map complex setups.

The **Set up fixtures** function can be used to create a CFG file for the fixture, using the measured value.

In CFG files, you can correct the orientation of the fixture files to be in effect on the control. **KinematicsDesign** can be used to create and edit CFG files on the control.

Further information: "Editing CFG files with KinematicsDesign", Page 226

Fixtures from M3D files

M3D is a file type designed by HEIDENHAIN. The paid M3D Converter software from HEIDENHAIN allows you to create M3D files from STL or STEP files.

In order to use an M3D file as a fixture, you need to use the M3D Converter software to create and check the file.

Notes

NOTICE

Danger of collision!

The setup situation defined for fixture monitoring must match the actual machine status. Otherwise, there is a risk of collision.

- ▶ Measure the position of the fixture in your machine
- ▶ Use the measured values for positioning the fixture
- ▶ Test the NC programs in the simulation

- When using a CAM system, use a postprocessor to output the fixture situation.
- Note the orientation of the coordinate system in the CAD system. Use the CAD system to adapt the orientation of the coordinate system to the desired orientation of the fixture in the machine.
- You can choose any orientation of the fixture model in the CAD system, and therefore the orientation does not always match the orientation of the fixture in the machine.
- Define the coordinate origin in the CAD system such that the fixture can be directly attached to the point of insertion of the kinematics.
- Create a central directory for your fixtures (e.g., **TNC:\system\Fixture**).
- When DCM is active, the control checks during simulation or machining if the fixture collides (#40 / #5-03-1).

By storing multiple fixtures, you can choose the appropriate fixture for your machining operation without needing to configure it.

- Example files for setups used in everyday manufacturing are provided in the NC database of the Klartext Portal:

HEIDENHAIN NC solutions

- Even if the inch unit of measure is active in the control or NC program, the control will interpret dimensions of 3D files in mm.

10.2.2 Integrating fixtures into collision monitoring (#140 / #5-03-2)

Application

The **Set up fixtures** function determines the position of a 3D model in the **Simulation** workspace, matching the real fixture in the workspace. Once the fixture has been set-up, the control considers it in Dynamic Collision Monitoring (DCM).

Related topics

- The **Simulation** workspace
Further information: User's Manual for Programming and Testing
- Dynamic Collision Monitoring (DCM)
Further information: "Dynamic Collision Monitoring (DCM) (#40 / #5-03-1)", Page 206
- Fixture monitoring
Further information: "Fixture management", Page 213
- Setting up a workpiece with graphical support (#159 / #1-07-1)
Further information: "Setting up the workpiece with graphical support (#159 / #1-07-1)", Page 309

Requirements

- If you are using a HEIDENHAIN touch probe with EnDat interface, then the software option Touch Probe Functions (#17 / #1-05-1) is automatically enabled.
Further information: "Calibrating the workpiece touch probe", Page 304
If you are using a HEIDENHAIN touch probe with EnDat interface, then the software option Touch Probe Functions (#17 / #1-05-1) is automatically enabled.
- Software option Dynamic Collision Monitoring (DCM) version 2 (#140 / #5-03-2)
- Workpiece touch probe
- Permitted fixture file matching the real fixture
Further information: "Options for fixture files", Page 214

Description of function

The **Set up fixtures** function is available as a touch probe function in the **Setup** application of the **Manual** operating mode.

The **Set up fixtures** function determines the fixture position using various probing processes. First, one point on the fixture is probed in every linear axis. The position of the fixture is defined in this way. After probing one point in all linear axes, further points can be integrated in order to improve positioning accuracy. After defining the position in one axis direction, the control changes the status of that axis from red to green.

The error estimate diagram shows the estimated distance of the 3D model from the real fixture for each probing point.

Further information: "Error estimate diagram", Page 221

The scope of the **Set up fixtures** function depends on the Extended Functions Group 1 (#8 / #1-01-1) and Extended Functions Group 2 (#9 / #4-01-1) software options as follows:

- Both software options enabled:
You can tilt before probing, and incline the tool while probing, in order to probe even complex fixtures.
- Only Extended Functions Group 1 (#8 / #1-01-1) enabled:
You can tilt before probing. The working plane must be consistent. If you move the rotary axes between the touch points, the control will display an error message.



If the current coordinates of the rotary axes and the defined tilt angles (**3D ROT** window) match, the working plane is consistent.


- None of the two software options is enabled:
You cannot tilt before probing. If you move the rotary axes between the touch points, the control will display an error message.

Further information: "Tilting the working plane (#8 / #1-01-1)", Page 199

Further information: User's Manual for Programming and Testing

Extension of the Simulation workspace

In addition to the **Probing function** workspace, the **Simulation** workspace offers graphic support for setting up the fixture.








The **Set up fixtures** function with the **Simulation** workspace open

When the **Set up fixtures** function is active, the **Simulation** workspace shows the content below:

- Current position of fixture as viewed by the control
 - Probed points on the fixture
 - Possible direction of probing by means of an arrow:
 - No arrow
Probing is not possible. The workpiece touch probe is too distant from the fixture or the workpiece touch probe is positioned within the fixture, as seen by the control.
In this case, you can adjust the position of the 3D model in the simulation, if applicable.
 - Red arrow
Probing in the direction of the arrow is not possible.
- i** Probing on edges, corners or heavily curved fixture areas fails to deliver precise measuring results. This is why the control blocks probing in these areas.
- Yellow arrow
Probing in the direction of the arrow is possible under certain conditions. Probing is done in a deselected direction or might cause collisions.
 - Green arrow
Probing in the direction of the arrow is possible.

Icons and buttons

The **Set up fixtures** function contains the following icons and buttons:

Icon or button	Meaning
XY Clamping plane	<p>This selection menu defines the plane in which the fixture is in contact with the machine.</p> <p>The control offers the following planes:</p> <ul style="list-style-type: none"> ■ XY clamping plane ■ XZ clamping plane ■ YZ clamping plane <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>i Depending on the selected clamping plane, the control displays the corresponding axis directions. In the XY Clamping plane, for example, the control displays the axes X, Y, Z and C.</p> </div>
<input type="text" value="1265390_60.cfg"/>	<p>Name of fixture file</p> <p>The control automatically saves the fixture file in the initial folder.</p> <p>The fixture file name can be edited before saving.</p>
	<p>Shifts the position of the virtual fixture by 10 mm or 10° in the negative axis direction</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>i Shifts the fixture in mm in a linear axis and in degrees in a rotary axis.</p> </div>
	<p>Shifts the position of the virtual fixture by 1 mm or 1° in the negative axis direction</p>
<input type="text" value="-15.982 ± 0.017"/>	<ul style="list-style-type: none"> ■ Enter the position of the virtual fixture directly ■ Value and estimated accuracy after probing
	<p>Shifts the position of the virtual fixture by 1 mm or 1° in the positive axis direction</p>
	<p>Shifts the position of the virtual fixture by 10 mm or 10° in the positive axis direction</p>
	<p>Status of axis</p> <p>The control displays the following colors:</p> <ul style="list-style-type: none"> ■ Gray The axis direction is deselected for this set-up process and will not be taken into account. ■ White No probing points have been determined yet. ■ Red The control cannot determine the fixture position in this axis direction. ■ Yellow The position of the fixture in this axis direction already contains information. The information is not meaningful yet. ■ Green The control can determine the fixture position in this axis direction.

Icon or button	Meaning
Save and activate	This function saves all obtained data in a CFG file and activates the measured fixture in Dynamic Collision Monitoring (DCM).



When using a CFG file as the data source for the measuring process, the existing CFG file can be overwritten by **Save and activate** at the end of the measuring process.

When creating a new CFG file, enter a different file name next to the button.

When using a datum clamping system and for this reason you do not want to consider one axis direction (such as **Z**) when setting up the fixture, the axis in question can be deselected by a toggle switch. The control will not take deselected axis directions into account in the set-up process and positions the fixture by considering the remaining axis directions only.

Error estimate diagram


Every probing point further restricts the possible positioning of the fixture and puts the 3D model closer to the actual position in the machine.

The error estimate diagram shows the estimated distance of the 3D model from the real fixture. The control not only considers the probing points, but also the entire fixture.

As soon as the error estimate diagram shows green circles and the desired accuracy, the set-up process is completed.

The factors below influence the accuracy that can be achieved when measuring fixtures:

- Accuracy of workpiece touch probe
- Repeatability of workpiece touch probe
- Accuracy of 3D model
- Condition of the actual fixture (e.g., existing wear or score marks)





Error estimate diagram in the **Set up fixtures** function

The error estimate diagram of the **Set up fixtures** function displays the following information:

- **Mean deviation (RMS)**
This area shows the average distance of the measured probing points from the 3D model in mm.
- **Error estimate [mm]**
This axis shows the course of the revised model position by means of the individual probing points. Red circles are shown until the values for all axis directions are determined. From then on, the control displays green circles.
- **No. of probe point**
This axis shows the numbers of the individual probing points.

Example of sequence of fixture probing points

Below are some of the probing points that can be set for different fixtures:

Chucking equipment/fixtures	Possible sequence
	<p>The following probing points can be set when measuring a vice:</p> <ol style="list-style-type: none"> 1 Touching the fixed vice jaw in Z- 2 Touching the fixed vice jaw in X+ 3 Touching the fixed vice jaw in Y+ 4 Touching the second value in Y+ for rotation 5 To improve accuracy, touching the check point in X-
	<p>The following probing points can be set when measuring a three-point chuck:</p> <ol style="list-style-type: none"> 1 Touching the jaw chuck body in Z- 2 Touching the jaw chuck body in X+ 3 Touching the jaw chuck body in Y+ 4 Touching the jaw in Y+ for rotation 5 Touching the second value at the jaw in Y+ for rotation

Probing points for a vice with a fixed vice jaw

Probing points with a three-jaw chuck

Measuring the fixed-jaw vice



The desired 3D model must meet the requirements of the control.

Further information: "Options for fixture files", Page 214

To measure a vise using the **Set up fixtures** function:

- ▶ Affix a real vise in the working space



- ▶ Select the **Manual** operating mode
- ▶ Insert the workpiece touch probe
- ▶ Manually position the workpiece touch probe above the fixed vice jaw at a notable point



This step makes the subsequent steps easier.



Open

++

- ▶ Select the **Setup** application
- ▶ Select **Set up fixtures**
- ▶ The control opens the **Set up fixtures** menu.
- ▶ Select a 3D model matching the real vise
- ▶ Select **Open**
- ▶ The control opens the selected 3D model in the simulation.
- ▶ Pre-position the 3D model by using the buttons for the individual axes within the virtual working space



For pre-positioning the vise, use the workpiece touch probe as a point of reference.

At this point in time, the control does not know the precise position of the fixture, but of the workpiece touch probe. Pre-positioning the 3D model in accordance with the position of the workpiece touch probe and by using, for example, the table's T-slots produces values close to the position of the real vise.

Even after recording the first measuring points, the shifting functions are still available for correcting the fixture position manually.

- ▶ Specify the clamping plane (e. g., **XY**)
- ▶ Position the workpiece touch probe until a green down arrow appears



As the 3D model is only pre-positioned at this point in time, the green arrow cannot provide any reliable information about whether the desired surface of the fixture will actually be touched. Check if the fixture position in the simulation and in the machine match and if touching in the direction of the arrow is possible on the machine.

Do not touch directly near edges, chamfers and roundings.



- ▶ Press the **NC Start** key
- > The control probes in the direction of the arrow.
- > The control displays the status of the **Z** axis in green and shifts the fixture to the touched position. The control marks the touched position by a point in the simulation.
- ▶ Repeat this process in axis directions **X+** and **Y+**
- > The status of the axes turns green.
- ▶ Touch another point in axis direction **Y+** for the basic rotation



To achieve maximum accuracy when touching the basic rotation, the probing points should be as far apart from one another as possible.

- > The control changes the status of the **C** axis to green.
- ▶ Touch the check point in axis direction **X-**



Additional check points at the end of the measuring process improve the matching accuracy and minimize the faults between the 3D model and the real fixture.

Save and activate

- ▶ Select **Save and activate**
- > The control closes the **Set up fixtures** function, saves a CFG file with the measured values at the path specified above, and integrates the measured fixture into Dynamic Collision Monitoring (DCM).

Notes

NOTICE

Danger of collision!

To probe the clamping situation in the machine exactly, the workpiece touch probe must be properly calibrated and the value **R2** properly defined in the tool management. Otherwise, incorrect tool data of the workpiece touch probe may cause inaccurate measurement and possibly a collision.

- ▶ Calibrate the workpiece touch probe at regular intervals
- ▶ Enter parameter **R2** in the tool management

- The control cannot identify modeling differences between the 3D model and the real fixture.
- At the time of set-up, Dynamic Collision Monitoring (DCM) does not know the exact position of the fixture. In this condition, collisions with the fixture, the tool or other non-machine components such as fixing clamps in the work envelope may occur. The non-machine components can be modeled on the control using a CFG file.

Further information: "Editing CFG files with KinematicsDesign", Page 226

- If you cancel the **Set up fixtures** function, DCM will not monitor the fixture. In this case, any fixtures previously set up are also removed from the scope of monitoring. The control displays a warning.
- Only one fixture can be measured at a time. To monitor several fixtures simultaneously by DCM, the fixtures must be integrated into a CFG file.

Further information: "Editing CFG files with KinematicsDesign", Page 226

- When measuring a jaw chuck, the coordinates of the axes **Z**, **X** and **Y** are determined just as when measuring a vice. The rotation is determined from one single jaw.
- The saved fixture file can be integrated into the NC program with the **FIXTURE SELECT** function. This can be used for simulating and executing the NC program, considering the real setup situation.

Further information: User's Manual for Programming and Testing

10.2.3 Editing CFG files with KinematicsDesign

Application

KinematicsDesign allows editing CFG files in the control. In this process, **KinematicsDesign** displays the fixtures graphically and thus supports troubleshooting and removal of errors.

Related topics

- Combine fixtures into complex clamping arrangements

Further information: "Combining fixtures in the New Fixture window", Page 231


Description of function

When opening a CFG file in the control, the control makes **KinematicsDesign** available as a selection item.

KinematicsDesign offers the following functions:

- Editing of fixtures with graphic support
- Feedback in case of incorrect entries
- Integration of transformations
- Addition of new elements
 - 3D model (M3D or STL files)
 - Cylinder
 - Prism
 - Cuboid
 - Truncated cone
 - Hole

You can integrate both STL files and M3D files into CFG files more than once.




Syntax in CFG files

The following syntax elements are used within the various CFG functions:

Function	Description
<code>key:= ""</code>	Name of the function
<code>dir:= ""</code>	Direction of a transformation (e.g., X)
<code>val:= ""</code>	Value
<code>name:= ""</code>	Name displayed if a collision occurs (optional input)
<code>filename:= ""</code>	File name
<code>vertex:= []</code>	Position of a cube
<code>edgeLengths:= []</code>	Dimensions of a cuboid
<code>bottomCenter:= []</code>	Center of a cylinder
<code>radius:= []</code>	Radius of a cylinder
<code>height:= []</code>	Height of a geometric object
<code>polygonX:= []</code>	Line of a polygon in X
<code>polygonY:= []</code>	Line of a polygon in Y
<code>origin:= []</code>	Starting point of a polygon

Each element is assigned its own **key**. A **key** must be unambiguous and unique, meaning that it must not occur more than once in the description of a fixture. Based on the **key**, the elements are referenced to each other.

The following functions are available if you wish to use CFG functions to describe a fixture in the control:

Function	Description
<code>CfgCMOMesh3D(key:="Fixture_body", filename:="1.STL",name:="")</code>	Definition of fixture component
	<div style="border: 1px solid black; padding: 5px;">  You can also enter an absolute path for the defined fixture component (e.g., TNC:\nc_prog\1.STL) </div>
<code>CfgKinSimpleTrans(key:="XShiftFixture", dir:=X, val:=0)</code>	Shift in X axis Inserted transformations, such as a shift or rotation, are effective for all of the elements following in the kinematic chain.
<code>CfgKinSimpleTrans(key:="CRot0", dir:=C, val:=0)</code>	Rotation in C axis
<code>CfgCMO (key:="fixture", primitives:= ["XShiftFixture", "CRot0", "Fixture_body"], active :=TRUE, name :="")</code>	Describes all of the transformations contained in the fixture. The parameter active := TRUE activates collision monitoring for the fixture. The CfgCMO contains collision objects and transformations. The fixture is combined based on the arrangement of the different transformations. Here, the transformation XShiftFixture shifts the center of rotation of the transformation CRot0 .

Function	Description
<code>CfgKinFixModel(key:="Fix_Model", kinObjects:["fixture"])</code>	Fixture designation CfgKinFixModel contains one or more CfgCMO elements.

Geometric shapes

You can add simple geometric objects to your collision object either directly in the CFG file or by using **KinematicsDesign**.

All integrated geometric shapes are subelements of the higher-order **CfgCMO**, in which they are listed as **primitives**.

The following geometric objects are available:

Function	Description
<code>CfgCMOCuboid (key:="FIXTURE_Cub", vertex:= [0, 0, 0], edgeLengths:= [0, 0, 0], name:="")</code>	Definition of a cuboid
<code>CfgCMOCylinder (key:="FIXTURE_Cyl", dir:=Z, bottomCenter:= [0, 0, 0], radius:=0, height:=0, name:="")</code>	Definition of a cylinder
<code>CfgCMOPrism (key:="FIXTURE_Pris_002", height:=0, polygonX:=[], polygonY:=[], name:="", origin:= [0, 0, 0])</code>	Definition of a prism A prism is described by entering the height and several polygonal lines.

Creating a fixture entry with a collision object

The content below describes the procedure with **KinematicsDesign** opened.

To create a fixture entry with a collision object:



- ▶ Select **Insert chucking equipment**
- > **KinematicsDesign** creates a new fixture entry within the CFG file.
- ▶ Enter a **keyname** for the fixture (e.g., **clamping jaw**)
- ▶ Confirm your input
- > **KinematicsDesign** loads the input.



- ▶ Move cursor down one level




- ▶ Select **Insert collision object**
- ▶ Confirm your input
- > **KinematicsDesign** creates a new collision object.

Defining geometric shapes

KinematicsDesign allows you to define various geometric shapes. You can construct simple fixtures by combining several geometric shapes.


To define a geometric shape:

- ▶ Create a fixture entry with a collision object
- ⇒
- ▶ Select the cursor key beneath the collision object
- 
- ▶ Select the desired geometric shape (e.g., a cuboid)
 - ▶ Define the position of the cuboid (e.g., **X = 0, Y = 0, Z = 0**)
 - ▶ Define the dimensions of the cuboid (e.g., **X = 100, Y = 100, Z = 100**)
 - ▶ Confirm your input
 - > The control displays the defined cuboid in the graphic.

Integrating 3D models

The integrated 3D models must meet the requirements of the control.


To integrate a 3D model as a fixture:

- ▶ Create a fixture entry with a collision object
- ⇒
- ▶ Select the cursor key beneath the collision object
- 
- ▶ Select **Insert 3D model**
 - > The control opens the **Open File** window.
 - ▶ Select the desired STL or M3D file
 - ▶ Press **OK**
 - > The control integrates the selected file and displays the file in the graphic window.

Fixture placement

You can place the integrated fixture at any position (e.g., for correcting the orientation of an external 3D model). For this purpose, insert transformations for all axes you wish to use.

To position a fixture with **KinematicsDesign**:

- ▶ Define the fixture
- ⇒
- ▶ Select the cursor key beneath the element to be positioned
- 
- ▶ Select **Insert transformation**
 - ▶ Enter a **key name** for the transformation (e.g., **Z shift**)
 - ▶ Select the **axis** for the transformation (e.g., **Z**)
 - ▶ Select the **value** for the transformation (e.g., **100**)
 - ▶ Confirm your input
 - > **KinematicsDesign** inserts the transformation.
 - > **KinematicsDesign** depicts the transformation in the graphic.

Notes

- If one of the transformations contains the ? character in the key, you can enter the value of the transformation within the **Combine fixtures** function. This allows easy positioning of clamping jaws, for example.
Further information: "Combining fixtures in the New Fixture window", Page 231
- As an alternative to using **KinematicsDesign**, you can also create fixture files directly from the CAM system or by using the appropriate code in a text editor.

Example

The example below describes the syntax of a CFG file for a vise with two movable jaws.

Files used

Various STL files are used to describe the vise. Since the jaws of the vise are dimensionally identical, they are defined using the same STL file.

Code	Explanation
<pre>CfgCMOMesh3D (key:="Fixture_body", filename:="vice_47155.STL", name:=" ")</pre>	Body of the vise
<pre>CfgCMOMesh3D (key:="vice_jaw_1", filename:="vice_jaw_47155.STL", name:=" ")</pre>	First jaw of the vise
<pre>CfgCMOMesh3D (key:="vice_jaw_2", filename:="vice_jaw_47155.STL", name:=" ")</pre>	Second jaw of the vise

Definition of jaw opening width

In this example, the opening width of the vise is defined using two mutually dependent transformations.

Code	Explanation
<pre>CfgKinSimpleTrans (key:="TRANS_opening_width", dir:=Y, val:=-60)</pre>	Jaw opening width of the vise in Y direction: 60 mm
<pre>CfgKinSimpleTrans (key:="TRANS_opening_width_2", dir:=Y, val:=30)</pre>	Position of the first jaw of the vise in Y direction: 30 mm

Positioning of the fixture within the working space

The defined fixture components are positioned using various transformations.

Code	Explanation
<pre>CfgKinSimpleTrans (key:="TRANS_X", dir:=X, val:=0) CfgKinSimpleTrans (key:="TRANS_Y", dir:=Y, val:=0) CfgKinSimpleTrans (key:="TRANS_Z", dir:=Z, val:=0) CfgKinSimpleTrans (key:="TRANS_Z_vice_jaw", dir:=Z, val:=60) CfgKinSimpleTrans (key:="TRANS_C_180", dir:=C, val:=180) CfgKinSimpleTrans (key:="TRANS_SPC", dir:=C, val:=0) CfgKinSimpleTrans (key:="TRANS_SPB", dir:=B, val:=0) CfgKinSimpleTrans (key:="TRANS_SPA", dir:=A, val:=0)</pre>	<p>Positioning of the fixture components</p> <p>In this example, a rotation by 180° is inserted for rotating the defined jaw of the vise. This is necessary because the same initial model is used for both jaws of the vise.</p> <p>The rotation inserted applies to all subsequent components in the transformation chain.</p>

Description of the fixture

You need to combine all objects and transformations in the CFG file in order to ensure that the fixture is correctly depicted in the simulation.

Code	Explanation
<pre>CfgCMO (key:="FIXTURE", primitives:= ["TRANS_X", "TRANS_Y", "TRANS_Z", "TRANS_SPC", "TRANS_SPB", "TRANS_SPA", "Fixture_body", "TRANS_Z_vice_jaw", "TRANS_opening_width_2", "vice_jaw_1", "TRANS_opening_width", "TRANS_C_180", "vice_jaw_2"], active:=TRUE, name:="")</pre>	<p>Combining the transformations and objects contained in the fixture</p>

Fixture designation

You need to assign a designation to the combined fixture.

Code	Explanation
<pre>CfgKinFixModel (key:="FIXTURE1", kinObjects:=["FIXTURE"])</pre>	<p>Designation of the combined fixture</p>

10.2.4 Combining fixtures in the New Fixture window

Application

The **New Fixture** window allows combining several fixtures and saving them as a new fixture. This enables realizing and monitoring complex clamping situations.

Related topics

- Fundamentals of fixtures
 - Further information:** "Fundamentals", Page 213
- Integrating fixtures into the NC program
 - Further information:** User's Manual for Programming and Testing
- Set up fixtures (#140 / #5-03-2)
 - Further information:** "Integrating fixtures into collision monitoring (#140 / #5-03-2)", Page 216

Requirement


- Fixtures of suitable format:
 - STL file
 - 20,000 triangles maximum
 - Triangular mesh forms a closed shell
 - CFG file
 - M3D file

Description of function

To navigate to this function:

Tools ► Combine fixtures

The control also makes this function available as a selection option for opening CFG files.



Combined fixture with variable transformations

The **Add fixture** button selects all required fixtures one by one.

If one of the transformations contains the **?** character in the key, you can enter the value of the transformation within the **Combine fixtures** function. This allows easy positioning of clamping jaws, for example.

The control displays a preview of the combined fixture and the total number of all triangles.

The **Save as** button saves the combined fixture as a CFG file.

Notes

- For optimum performance, HEIDENHAIN recommends that combined fixtures contain no more than 20,000 triangles.
- If the position or the size of a fixture must be adapted, use **KinematicsDesign**.
Further information: "Editing CFG files with KinematicsDesign", Page 226

11

Control Functions

11.1 Adaptive feed control (AFC) (#45 / #2-31-1)

11.1.1 Fundamentals

Application

Adaptive Feed Control (AFC) saves time when processing NC programs and reduces wear on the machine. The control regulates the contouring feed rate during program run depending on the spindle power. In addition, the control responds to overloading of the spindle.

Related topics

- Tables related to AFC

Further information: "Tables for AFC (#45 / #2-31-1)", Page 394

Requirements

- Adaptive Feed Control software option (AFC (#45 / #2-31-1))
- Enabled by the machine manufacturer

The machine manufacturer uses the optional machine parameter **Enable** (no. 120001) to define whether you can use AFC.

Description of function

To regulate the feed rate during program run with AFC:

- Define basic settings for AFC in the **AFC.tab** table
Further information: "Basic AFC settings in AFC.tab", Page 394
- Define settings for AFC for each tool in the tool management
Further information: "Tool table tool.t", Page 363
- Define AFC in the NC program
Further information: "NC functions for AFC (#45 / #2-31-1)", Page 239
- Define AFC in the **Program Run** operating mode with the **AFCtoggle** switch.
Further information: "The AFC toggle switch in the Program Run operating mode", Page 241
- Prior to automatic control, determine the reference spindle power with a teach-in cut
Further information: "AFC teach-in cut", Page 242

If AFC is active in the teach-in cut or in control mode, the control displays an icon in the **Positions** workspace.

Further information: "The Positions workspace", Page 97

Detailed information about the function is provided by the control on the **AFC** tab of the **Status** workspace.

Further information: "The AFC tab (#45 / #2-31-1)", Page 107

Benefits of AFC

Adaptive feed control (AFC) has the following advantages:

- Optimization of machining time
By controlling the feed rate, the control tries to maintain the previously recorded maximum spindle power or the reference power specified in the tool table (**AFC-LOAD** column) during the entire machining time. It shortens the machining time by increasing the feed rate in machining zones with little material removal.
- Tool monitoring
If the spindle power exceeds the taught-in or specified maximum value, the control reduces the feed until the reference spindle power is reached. If the minimum feed rate is exceeded, the control executes a shutdown response. AFC can also use the spindle power to monitor the tool for wear and breakage without changing the feed rate.
Further information: "Monitoring tool wear and tool load", Page 244
- Protection of the machine's mechanical elements
Timely feed rate reduction and shutdown reactions help to avoid machine overload.

Tables related to AFC

The control offers the following tables in conjunction with AFC:

- **AFC.tab**
In the **AFC.tab** table, you define the feed-rate control settings to be used by the control. This table must be saved in the **TNC:\table** directory.
Further information: "Basic AFC settings in AFC.tab", Page 394
- ***.H.AFC.DEP**
With a teach-in cut, the control at first copies the basic settings for each machining step, as defined in the AFC.TAB table, to a file called **<name>.H.AFC.DEP**. The string **<name>** is identical to the name of the NC program for which you have recorded the teach-in cut. In addition, the control measures the maximum spindle power consumed during the teach-in cut and saves this value to the table.
Further information: "AFC.DEP settings file for teach-in cuts", Page 397
- ***.H.AFC2.DEP**
During a teach-in cut, the control stores information for each machining step in the **<name>.H.AFC2.DEP** file. The string **<name>** is identical to the name of the NC program for which you are performing the teach-in cut.
In control mode, the control updates the data in this table and performs evaluations.
Further information: "Log file AFC2.DEP", Page 399

You can open and, if necessary, edit the tables for AFC during program run. The control provides only the tables of the active NC program.

Further information: "Editing the tables for AFC", Page 400

Notes

NOTICE

Caution: Danger to the tool and workpiece!

As soon as Adaptive Feed Control (AFC) is deactivated, the control immediately switches back to the programmed machining feed rate. If AFC decreased the feed rate (e.g., due to wear) before it was deactivated, the control accelerates the feed rate up to the programmed value. This behavior applies regardless of how the function is deactivated. This feed acceleration may result in damage to the tool and/or the workpiece!

- ▶ If the feed rate is about to fall below the **FMIN** value, stop the machining operation (instead of deactivating the AFC function)
 - ▶ Define the overload response for cases in which the feed rate falls below the **FMIN** value
- If Adaptive Feed Control is active in **Control** mode, the control executes a shutdown response independent of the programmed overload response.
 - If, with the reference spindle load, the value falls below the minimum feed factor
 - The control executes the shutdown response from the **OVLD** column of the **AFC.tab** table.
 - Further information:** "Basic AFC settings in AFC.tab", Page 394
 - If the programmed feed rate falls below the 30% threshold
 - The control executes an NC stop.
 - Adaptive feed control is not intended for tools with diameters less than 5 mm. If the rated power consumption of the spindle is very high, the limit diameter of the tool may be larger.
 - Do not work with adaptive feed control in operations in which the feed rate and spindle speed must be adapted to each other, such as tapping.
 - In NC blocks containing **FMAX**, the adaptive feed control is **not active**.
 - In the settings of the **Files** operating mode, you can specify whether the control displays dependent files in the file management.
- Further information:** User's Manual for Programming and Testing

11.1.2 Activating and deactivating AFC

NC functions for AFC (#45 / #2-31-1)

Application

Adaptive Feed Control (AFC) is activated and deactivated from the NC program.

Requirements

- Adaptive Feed Control software option (AFC (#45 / #2-31-1))
- Control settings defined in the **AFC.tab** table
 - **Further information:** "Basic AFC settings in AFC.tab", Page 394
- Desired control setting defined for all tools
 - **Further information:** "Tool table tool.t", Page 363
- **AFC** toggle switch active
 - **Further information:** "The AFC toggle switch in the Program Run operating mode", Page 241

Description of function

The control provides several functions that enable you to start and stop AFC:

- **FUNCTION AFC CTRL:** The **AFC CTRL** function activates feedback control mode starting with this NC block, even if the learning phase has not been completed yet.
- **FUNCTION AFC CUT BEGIN TIME1 DIST2 LOAD3:** The control starts a sequence of cuts with active **AFC**. The changeover from the teach-in cut to feedback control mode begins as soon as the reference power has been determined in the teach-in phase, or once one of the **TIME**, **DIST** or **LOAD** conditions has been met.
- **FUNCTION AFC CUT END:** The **AFC CUT END** function deactivates AFC control.

Input

FUNCTION AFC CTRL

11 FUNCTION AFC CTRL	; Start AFC in control mode
----------------------	-----------------------------

The NC function includes the following syntax elements:

Syntax element	Meaning
FUNCTION AFC CTRL	Syntax initiator for the start of control mode

FUNCTION AFC CUT

**11 FUNCTION AFC CUT BEGIN TIME10
DIST20 LOAD80**

; Start AFC machining step, limit the duration of the teach-in phase

The NC function includes the following syntax elements:

Syntax element	Meaning
FUNCTION AFC CUT	Syntax initiator for an AFC machining step
BEGIN or END	Start or end machining step
TIME	End teach-in phase after the defined time in seconds Optional syntax element Only if BEGIN has been selected
DIST	End teach-in phase after the defined distance in mm Optional syntax element Only if BEGIN has been selected
LOAD	Enter the reference load of the spindle directly, max. 100% Optional syntax element Only if BEGIN has been selected

Notes

- The **TIME**, **DIST** and **LOAD** defaults are modally effective. They can be reset by entering **0**.
- Execute the function **AFC CUT BEGIN** only after the starting rotational speed has been reached. If this is not the case, then the control issues an error message, and the AFC cut is not started.
- You can define a feedback-control reference power with the **AFC LOAD** tool table column and the **LOAD** input in the NC program. You can activate the **AFC LOAD** value via the tool call and the **LOAD** value with the **FUNCTION AFC CUT BEGIN** function.

If you program both values, the control will use the value programmed in the NC program!

The AFC toggle switch in the Program Run operating mode

Application

The **AFC** toggle switch allows you to activate or deactivate Adaptive Feed Control (AFC) in the **Program Run** operating mode.

Related topics

- Activating AFC in the NC program

Further information: "NC functions for AFC (#45 / #2-31-1)", Page 239

Requirements

- Adaptive Feed Control software option (AFC (#45 / #2-31-1))
- Enabled by the machine manufacturer

The machine manufacturer uses the optional machine parameter **Enable** (no. 120001) to define whether you can use AFC.

Description of function

The **AFC** toggle switch must be activated for the NC functions for AFC to have an effect.

If you do not specifically deactivate AFC using the toggle switch, AFC remains active. The control remembers the setting of the toggle switch even if the control is restarted.

If the **AFC** toggle switch is active, the control displays an icon in the **Positions** workspace. In addition to the current setting of the feed rate potentiometer, the control shows the controlled feed value as a percentage (%).

Further information: "The Positions workspace", Page 97

Notes

NOTICE

Caution: Danger to the tool and workpiece!

As soon as the AFC function is deactivated, the control immediately switches back to the programmed machining feed rate. If AFC decreased the feed rate (e.g. due to wear) before it was deactivated, the control accelerates the feed rate up to the programmed value. This applies regardless of how the function is deactivated (e.g. feed rate potentiometer). This acceleration may result in damages to the tool or the workpiece!

- ▶ If the feed rate is about to fall below the **FMIN** value, stop the machining operation (instead of deactivating the **AFC** function)
 - ▶ Define the overload response for cases in which the feed rate falls below the **FMIN** value
- If Adaptive Feed Control is active in **Control** mode, the control internally sets the spindle override to 100%. Then you can no longer change the spindle speed.
 - If Adaptive Feed Control is active in **Control** mode, the control assumes the value from the feed rate override function.
 - Increasing the feed-rate override has no influence on the control.
 - If you reduce the feed override with the potentiometer by more than 10% in relation to the position at the start of the program, the control switches AFC off.
You can reactivate control with the **AFC** toggle switch.
 - Potentiometer values of up to 50% always have an effect, even with active control.
 - Mid-program startup is allowed during active feed control. The control takes the cutting number of the startup block in account.

11.1.3 AFC teach-in cut

Fundamentals

Application

With the teach-in cut, the control determines the reference power of the spindle for the machining step. Based on the reference power, the control adjusts the feed rate in control mode.

If you have already determined the reference power for a machining operation, you can specify the value for the machining operation. For this, the control provides the **AFC-LOAD** column in the tool management and the **LOAD** syntax element in the **FUNCTION AFC CUT BEGIN** function. In this case, the control no longer performs a teach-in cut, but uses the specified value immediately for control.

Related topics

- Enter the known reference power in the **AFC-LOAD** column in the tool management
Further information: "Tool table tool.t", Page 363
- Define the known reference power in the **FUNCTION AFC CUT BEGIN** function
Further information: "NC functions for AFC (#45 / #2-31-1)", Page 239

Requirements

- Adaptive Feed Control software option (AFC (#45 / #2-31-1))
- Control settings defined in the **AFC.tab** table
 - Further information:** "Basic AFC settings in AFC.tab", Page 394
- Desired control setting defined for all tools
 - Further information:** "Tool table tool.t", Page 363
- Desired NC program selected in the **Program Run** operating mode
- **AFC** toggle switch active
 - Further information:** "The AFC toggle switch in the Program Run operating mode", Page 241

Description of function

With a teach-in cut, the control at first copies the basic settings for each machining step, as defined in the AFC.TAB table, to a file called **<name>.H.AFC.DEP**.

Further information: "AFC.DEP settings file for teach-in cuts", Page 397

When you are performing a teach-in cut, the control shows the spindle reference power determined until this time in a pop-up window.

When the control has determined the control reference power, it ends the teach-in cut and switches to control mode.

Notes

- When you record a teach-in cut, the control internally sets the spindle override to 100%. Then you can no longer change the spindle speed.
- During the teach-in cut, you can influence the measured reference load by using the feed rate override to make any changes to the contouring feed rate.
- You can repeat a teach-in cut as often as desired. Manually change the status from **ST** back to **L**. If the programmed feed rate value is far too high and forces you to sharply decrease the feed rate override during the machining step, you will have to repeat the teach-in cut.
- If the determined reference load is greater than 2%, the control changes the status from teach-in (**L**) to controlling (**C**). Adaptive feed control is not possible for smaller values.

The AFC settings button

Application

The **AFC settings** button in the **Program Run** operating mode allows terminating a teach-in cut or opening the tables for AFC.

Related topics

- Fundamentals for the teach-in cut
 - Further information:** "Fundamentals", Page 242
- Tables for AFC
 - Further information:** "Tables for AFC (#45 / #2-31-1)", Page 394

Requirements

- Adaptive Feed Control software option (AFC (#45 / #2-31-1))
- Enabled by the machine manufacturer
 - The machine manufacturer uses the optional machine parameter **Enable** (no. 120001) to define whether you can use AFC.

Description of function

This button offers the following select options:

Button	Meaning
AFC.TAB	<p>Editing the factory default settings</p> <p>When selecting this button, the control will open the AFC.TAB table in the Tables operating mode.</p> <p>Further information: "Basic AFC settings in AFC.tab", Page 394</p>
AFC.DEP	<p>Editing the settings file for teach-in cuts</p> <p>When selecting this button, the control will open the AFC.DEP table for the current NC program in the Tables operating mode.</p> <p>Further information: "AFC.DEP settings file for teach-in cuts", Page 397</p>
AFC2.DEP	<p>Editing the log file for evaluation</p> <p>When selecting this button, the control will open the AFC2.DEP table for the current NC program in the Tables operating mode.</p> <p>Further information: "Log file AFC2.DEP", Page 399</p>
Stop Teach	<p>Terminating a teach-in cut</p> <ul style="list-style-type: none"> ■ The control terminates the teach-in cut and changes to control mode <p>Further information: "AFC teach-in cut", Page 242</p> <ul style="list-style-type: none"> ■ In the AFC.DEP table, the control changes the status of the ST column from teaching-in (L) to controlling (C). <p>Further information: "AFC.DEP settings file for teach-in cuts", Page 397</p> <ul style="list-style-type: none"> ■ In the Positions workspace, the control changes the icon for the teaching-in cut into the control mode icon. <p>Further information: "The Positions workspace", Page 97</p>



In a milling operation, you do not have to run the entire machining step in teaching-in mode. If the cutting conditions do not change significantly, you can switch to control mode immediately.

11.1.4 Monitoring tool wear and tool load

Application

With Adaptive Feed Control (AFC), you can monitor the tool for wear or breakage. To do this, use columns **AFC-OVLD1** or **AFC-OVLD2** in the tool management.

Related topics

- **AFC-OVLD1** and **AFC-OVLD2** columns in the tool management

Further information: "Tool table tool.t", Page 363

Description of function

If the **AFC.TAB** columns **FMIN** and **FMAX** each have a value of 100%, Adaptive Feed Control is deactivated, but cut-related tool wear monitoring and tool load monitoring remain active.

Further information: "Basic AFC settings in AFC.tab", Page 394

Tool wear and tool breakage cannot be monitored at the same time. If the **AFC_OVLD2** column contains a value, the control will ignore the **AFC_OVLD1** column.

Tool wear monitoring

Activate cut-related tool wear monitoring by entering a value not equal to 0 in the **AFC-OVLD1** column in the tool table.

The overload response depends on the **AFC.TAB** column **OVLD**.

In conjunction with cut-related tool wear monitoring, the control only evaluates the options **M**, **E**, and **L** in the **OVLD** column. The following responses are possible:

- Pop-up window
- Lock current tool
- Insert replacement tool

Tool load monitoring

Activate cut-related tool load monitoring (tool breakage control) by entering a value not equal to 0 in the **AFC-OVLD2** column in the tool table.

As overload response, the control always executes a machining stop and locks the momentary tool.

Example

The entries in columns **AFC-OVLD1** and **AFC-OVLD2** are added to the feedback-control reference power **AFC-LOAD**.

Further information: "AFC teach-in cut", Page 242

Example input for tool wear and tool load monitoring:

Column	Input
AFC-LOAD	30%
AFC-OVLD1	5%
AFC-OVLD2	10%

In this example, the control adds the 5% and 10% to the 30% in each case.

As soon as a value is defined in column **AFC-OVLD1**, the tool will monitor tool wear. When the control used in the example reaches a spindle power of 35% in total, it executes the defined reaction.

11.2 Active Chatter Control (ACC) (#145 / #2-30-1)

Application

Chatter marks can be caused during heavy-duty machining, in particular. **ACC** reduces chattering, thereby reducing wear on the tool and machine. In addition, **ACC** increases metal removal rates.

Related topics

- **ACC** column in the tool table

Further information: "Tool table tool.t", Page 363

Requirements

- Active Chatter Control software option (ACC) (#145 / #2-30-1)
- Control adapted by the machine manufacturer
- **ACC** column in the tool management defined with **Y**
- Number of tool cutting edges defined in the **CUT** column

Description of function

Strong forces come into play during roughing (power milling). Depending on the tool spindle speed, the resonances in the machine tool and the chip volume (metal-removal rate during milling), the machine can sometimes begin to **chatter**. This chattering places heavy strain on the machine, and causes ugly marks on the workpiece surface. The tool, too, is subject to heavy and irregular wear from chattering. In extreme cases it can result in tool breakage.

In order to reduce a machine's tendency to chatter, HEIDENHAIN offers an effective control function known as Active Chatter Control (**ACC**). The use of this control function is particularly advantageous during heavy machining. ACC makes substantially higher metal removal rates possible. Depending on the type of machine, the metal-removal rate can often be increased by more than 25%. You reduce the mechanical load on the machine and increase the life of your tools at the same time.

ACC was developed especially for roughing and heavy machining and is particularly effective in this area. You need to conduct appropriate tests to see whether ACC will also be advantageous on your machine and with your tool.

ACC is activated and deactivated using the **ACC** toggle switch in the **Program Run** operating mode or the **MDI** application.

Further information: "The Program Run operating mode", Page 324

Further information: "The MDI Application ", Page 279

If ACC is active, the control shows a corresponding icon in the **Positions** workspace.

Further information: "The Positions workspace", Page 97

Notes

- ACC reduces or prevents vibrations in the range of 20 Hz to 150 Hz. If ACC does not appear to have an effect, the vibrations may be outside of this range.
- The Machine Vibration Control software option (MVC) (#146 / #2-24-1) allows influencing the result even more positively.

12

**Opening CAD files
with CAD Viewer**

12.1 Fundamentals

Application

CAD Viewer supports the following standard file types that can be opened directly in the control:

File type	Extension	Format
STEP	*.stp and *.step	<ul style="list-style-type: none"> ■ AP 203 ■ AP 214
IGES	*.igs and *.iges	<ul style="list-style-type: none"> ■ Version 5.3
DXF	*.dxf	<ul style="list-style-type: none"> ■ R10 to 2015 ■ ASCII
STL	*.stl	<ul style="list-style-type: none"> ■ Binary ■ ASCII

CAD Viewer runs as a separate application on the third desktop of the control.


Related topics

- Creating 2D sketches on the control

Further information: User's Manual for Programming and Testing

Description of function

Screen layout














CAD file open in **CAD Viewer**


CAD Viewer consists of the following areas:

- 1 Menu bar
Further information: "Menu bar icons", Page 250
- 2 Graphics area
The CAD model is displayed in the graphics window.
- 3 Status bar
The status bar contains the active settings.
- 4 Element information area
Further information: "Element Information area", Page 251
- 5 List View area
The List View area displays information on the active function (e.g., available layers or the position of the workpiece preset).

Menu bar icons

The menu bar contains the following icons:

Icon	Meaning
	Show sidebar Show, enlarge, or hide the List View area
	Display the layer Display the layer(s) in the List View area Further information: "Layer", Page 252
	Preset Define the workpiece preset Workpiece preset has been defined Delete the defined workpiece preset Further information: "Workpiece preset in the CAD file", Page 253
	Datum Set the datum Datum has been set Further information: "Workpiece datum in the CAD file", Page 256
	Contour Select contour (#42 / #1-03-1) Further information: "Loading contours and positions to NC programs with CAD Import (#42 / #1-03-1)", Page 258
	Positions Select positions (#42 / #1-03-1) Further information: "Loading contours and positions to NC programs with CAD Import (#42 / #1-03-1)", Page 258
	3D mesh Create a 3D mesh (#152 / #1-04-1) Further information: "Generating STL files with 3D mesh (#152 / #1-04-1)", Page 264
	Show all Set the zoom to the largest possible view of the complete graphics
	Inverted colors Change the background color (black or white)
	Toggle between 2D and 3D modes
	Set the unit of measure (mm or inches) CAD Viewer performs all internal calculations in mm. If you select the inch unit of measure, the CAD Viewer converts all values to inches. Further information: "Loading contours and positions to NC programs with CAD Import (#42 / #1-03-1)", Page 258

Icon	Meaning
	<p>Number of decimal places</p> <p>Select the resolution. The resolution defines the number of decimal places and the number of positions for linearization.</p> <p>Further information: "Loading contours and positions to NC programs with CAD Import (#42 / #1-03-1)", Page 258</p> <p>Default setting: 4 decimal places with mm, and 5 decimal places with inch as the unit of measure</p>
	<p>Set perspective</p> <p>Switch between various views of the model (e.g., Top)</p>
	<p>Axes</p> <p>Select the working plane:</p> <ul style="list-style-type: none"> ■ XY ■ YZ ■ ZX ■ ZXØ <p>If you take over a contour or position, the control outputs the NC program in the selected working plane.</p> <p>Further information: "Loading contours and positions to NC programs with CAD Import (#42 / #1-03-1)", Page 258</p>
	<p>Toggle a 3D model between a solid model and a wire-frame model.</p>
	<p>"Select, add, or remove contour elements" mode</p>
	<div style="border: 1px solid black; padding: 5px;"> <p> The icon shows the current mode. Clicking the icon activates the next mode.</p> </div>
	<p>Further information: "Loading contours and positions to NC programs with CAD Import (#42 / #1-03-1)", Page 258</p>
	<p>Undo</p>
	<p>Delete entire list</p>
	<p>Save entire list content to a file</p>
	<p>Copy entire list contents to clipboard</p> <p>The control retains the content of the clipboard only as long as CAD Viewer is open.</p>

Element Information area

In the Element Information area, the following information is displayed for the selected element of the CAD file:

- Associated layer
- Element type
- Point type:
 - Point coordinates
- Line type:
 - Coordinates of the starting point
 - Coordinates of the end point

- Circular arc or circle type:
 - Coordinates of the starting point
 - Coordinates of the end point
 - Coordinates of the center point
 - Radius

The control always shows the **X**, **Y**, and **Z** coordinates. In 2D mode, the Z coordinate is dimmed.

Layer

CAD files usually contain multiple layers. The designer uses these layers to create groups of various types of elements, such as the actual workpiece contour, dimensions, auxiliary and design lines, hatching, and texts.

The CAD file to be processed must contain at least one layer. The control automatically moves all elements not assigned to a layer to the "anonymous" layer.

If the name of the layer is not shown completely in the List View area, you can use the **Show sidebar** icon to enlarge this area.

Use the **Display the layer** icon to display all the layers of the file in the List View area. Use the check box in front of the name to show and hide individual layers.

When you open a CAD file in **CAD Viewer**, all available layers are shown.

If you hide unnecessary layers, the graphic becomes clearer.

Notes

- Before loading the file into the control, ensure that the name of the file contains only permitted characters.
 - Further information:** User's Manual for Programming and Testing
- When you select a layer in the List View area, you can press the spacebar to show and hide the layer.
- **CAD Viewer** allows you to open CAD files consisting of any number of triangles.

12.2 Workpiece preset in the CAD file

Application

The datum of the drawing in the CAD file is not always located in a manner that lets you use it as a workpiece preset. Therefore, the control provides a function with which you can shift the workpiece preset to a suitable location by clicking an element. You can also define the orientation of the coordinate system.

Related topics

- Presets in the machine


Further information: "Presets in the machine", Page 142

Description of function

When you select the **Preset** icon, the control displays the following information in the list view area:

- Distance between the defined preset and the drawing datum
- Orientation of the working plane

The control displays values not equal to 0 in orange.



Workpiece preset in the CAD file

You can position the preset at the following locations:

- By direct numerical input in the List View area
- For lines:
 - Starting point
 - Midpoint
 - End point
- For circular arcs:
 - Starting point
 - Midpoint
 - End point
- For full circles:
 - At the quadrant transitions
 - At the center
- At the intersection between:
 - Two lines, even if the point of intersection is actually on the extension of one of the lines
 - Line and circular arc
 - Line and full circle
 - Two circles (regardless of whether a circular arc or a full circle)

If you have set a workpiece preset, the control displays the **Preset** icon in the menu bar with a yellow quadrant.

The preset and optional orientation are inserted in the NC program as a comment starting with **origin**.

```
4 ;origin = X... Y... Z...
```

```
5 ;origin_plane_spatial = SPA... SPB... SPC...
```

You can save the workpiece preset and workpiece datum information to a file or to the clipboard, even when the software option CAD Import (#42 / #1-03-1) is not available.



The control retains the content of the clipboard only as long as **CAD Viewer** is open.

You can change the preset even after you have selected the contour. The control does not calculate the actual contour data until you save the selected contour in a contour program.

12.2.1 Setting the workpiece preset or workpiece datum and orienting the coordinate system



- The following instructions apply when using a mouse. You can also perform these steps with touch gestures.
Further information: "Common gestures for the touchscreen", Page 70
- The following instructions also apply to the workpiece datum. In this case, start by selecting the **Datum** icon.

Setting the workpiece preset or workpiece datum on an individual element

To set the workpiece preset on an individual element:



- ▶ Select **Preset**
- ▶ Position the cursor on the desired element
- ▶ If you are using a mouse, the control displays selectable presets for the element using gray icons.
- ▶ Click the icon at the desired position
- ▶ The control sets the workpiece preset to the selected position. The control turns the icon green.
- ▶ Orient the working plane, if required

Setting the workpiece preset or workpiece datum at the intersection of two elements

You can set the workpiece preset at the intersection of lines, full circles, and arcs.

To set the workpiece preset at the intersection of two elements:



- ▶ Select **Preset**
- ▶ Click on the first element
- > The control highlights the element in color.
- ▶ Click on the second element
- > The control sets the workpiece preset at the point of intersection of the two elements. The control marks the workpiece preset with a green symbol.
- ▶ Orient the working plane, if required



- If there are several possible intersections, the control selects the intersection nearest the mouse-click on the second element.
- If two elements do not intersect directly, the control automatically calculates the intersection of their extensions.
- If the control cannot calculate an intersection, it deselects the previously selected element.

Orienting the working plane

The following requirements must be met in order to orient the working plane:

- Preset has been defined
- There are elements next to the preset that can be used for the desired orientation

To orient the working plane:

- ▶ Select an element in the positive direction of the X axis
- > The control orients the X axis.
- > The control changes the **C** angle in the List View area.
- ▶ Select an element in the positive direction of the Y axis
- > The control orients the Y and Z axes.
- > The control changes the **A** and **C** angles in the List View area.

12.3 Workpiece datum in the CAD file

Application

The workpiece preset is not always located in a manner that lets you machine the entire part. Therefore, the control provides a function to define a new datum and a working plane.

Related topics

- Presets in the machine

Further information: "Presets in the machine", Page 142


Description of function

When you select the **Datum** icon, the control displays the following information in the list view area:

- Distance between the datum that has been set and the workpiece preset
- Orientation of the working plane

You can apply a workpiece datum set in CAD Viewer and shift it, if required by entering values directly in the List View area.

The control displays values not equal to 0 in orange.



Workpiece datum for tilted machining

You can set the datum and the working plane orientation at the same locations as a preset.

Further information: "Workpiece preset in the CAD file", Page 253

If you have set a workpiece datum, the control displays the **Datum** icon in the menu bar with a yellow area.

Further information: "Setting the workpiece preset or workpiece datum and orienting the coordinate system", Page 255

The datum and its optional orientation can be inserted as NC block or comments in the NC program by using the **TRANS DATUM AXIS** function for the datum and the **PLANE SPATIAL** function for the orientation.

If you define only one datum and its orientation, then the control inserts the functions in the NC program as an NC block.

```
4 TRANS DATUM AXIS X... Y... Z...
```

```
5 PLANE SPATIAL SPA... SPB... SPC... TURN MB MAX FMAX
```

If you additionally select contours or points, then the control inserts the functions in the NC program as comments.

```
4 ;TRANS DATUM AXIS X... Y... Z...
```

```
5 ;PLANE SPATIAL SPA... SPB... SPC... TURN MB MAX FMAX
```

You can save the workpiece preset and workpiece datum information to a file or to the clipboard, even when the software option CAD Import (#42 / #1-03-1) is not available.



The control retains the content of the clipboard only as long as **CAD Viewer** is open.

12.4 Loading contours and positions to NC programs with CAD Import (#42 / #1-03-1)

Application

You can open CAD files directly on the control to extract contours or machining positions from them. You can then store them as Klartext programs or as point files. Klartext programs acquired in this manner can also be run on older HEIDENHAIN controls, since these contour programs by default contain only **L** and **CC/C** blocks.

Related topics

- Using point tables

Further information: User's Manual for Machining Cycles


Requirement

- Software option CAD Import (#42 / #1-03-1)

Description of function

To insert a selected contour or a selected machining position directly into an NC program, use the control's clipboard. Using the clipboard, you can even transfer the contents to additional software tools (e.g., **Leafpad** or **Gnumeric**).










Further information: "Opening files with additional software", Page 539



CAD model with marked contour

Icons in the CAD Import

With the CAD Import, the control shows the following additional functions in the menu bar:

Icon	Meaning					
	<p>Set the transition tolerance</p> <p>The tolerance specifies how far apart neighboring contour elements may be from each other. You can use the tolerance to compensate for inaccuracies that occurred during drawing creation. The default setting is 0.001 mm.</p>					
	<p>C or CR</p> <p>You can select whether the control will output circular contours C or CR in the NC program.</p>					
			<p>Show connections between two positions</p> <p>The control hides and displays the tool paths between the positions.</p>		<p>Apply path optimization</p> <p>The control optimizes the tool traverse movement between the machining positions. When you select the icon again, the control will discard the optimization.</p>	
	<p>Show connections between two positions</p> <p>The control hides and displays the tool paths between the positions.</p>					
	<p>Apply path optimization</p> <p>The control optimizes the tool traverse movement between the machining positions. When you select the icon again, the control will discard the optimization.</p>					
	<p>Find circles according to diameter range. Load center coordinates to the position list</p> <p>The control opens the Find circle centers by diameter range window. You can filter the displayed data by diameter or depth values.</p>					

Applying contours

The following elements can be selected as a contour:

- Line segment
- Full circle
- Pitch circle
- Polyline
- Any curves (e.g., splines, ellipses)

Linearization

CAD Viewer linearizes all of the contours that are not in the working plane.

During linearization, **CAD Viewer** subdivides a contour into individual segments. From these segments, CAD Import creates straight lines **L** and circular arcs **C** or **CR** that are as long as possible.

Thanks to linearization, it is also possible to import contours with CAD Import that cannot be programmed with the path functions of the control, such as splines.

The higher you define the resolution by specifying decimal places, the lower is the deviation from the imported contour.

Further information: "Screen layout", Page 249



You can prevent the linearization, for example of circles that are not in the working plane. Select the working plane in which the circle has been defined.

Applying positions

You can also use the CAD Import to save positions (e.g., for holes).

Three possibilities are available in the pattern generator for defining machining positions:

- Single selection
- Multiple selection within a range
- Multiple selection using search filters

Further information: "Selecting positions", Page 262

The following file types are available:

- Point table (.PNT)
- Klartext program (.H)

If you save the machining positions to a Klartext program, the control creates a separate linear block with a cycle call for every machining position (**L X... Y... Z... F MAX M99**).



CAD Viewer also recognizes circles as machining positions that consist of two semicircles.


Multi-selection filter settings

If you use the quick-selection function to mark positions, the **Find circle centers by diameter range** window opens. You can filter the diameter or depth values, referencing the workpiece datum, by means of the buttons below the displayed value. The control will only load the selected diameter or depth values.

The **Find circle centers by diameter range** window provides the following buttons:

Button	Meaning
<<<	<ul style="list-style-type: none"> ■ The control shows the smallest diameter found. ■ The control shows the smallest depth found. This filter is active by default.
<<<	<ul style="list-style-type: none"> ■ The control sets the filter for the largest diameter to the value selected for the smallest diameter. ■ The control sets the filter for the largest depth to the value selected for the smallest depth.
<	<ul style="list-style-type: none"> ■ The control shows the next smaller diameter found. ■ The control shows the next smaller depth found.
>	<ul style="list-style-type: none"> ■ The control shows the next larger diameter found. ■ The control shows the next larger depth found.
>>>	<ul style="list-style-type: none"> ■ The control sets the filter for the smallest diameter to the value selected for the largest diameter. ■ The control sets the filter for the smallest depth to the value selected for the largest depth.
>>>	<ul style="list-style-type: none"> ■ The control shows the largest diameter found. ■ The control shows the largest depth found. This filter is active by default.

12.4.1 Selecting and saving a contour


 ■ The following instructions apply to the use of a mouse. You can also perform these steps with touch gestures.


Further information: "Common gestures for the touchscreen", Page 70


■ Deselecting, deleting, and saving of elements works in the same way for applying contours and positions.


Selecting a contour with existing contour elements

To select and save a contour with existing contour elements:

-  ▶ Select **Contour**
- ▶ Place the cursor on the first contour element
- > The control shows the suggested direction of rotation as a dashed line.
- ▶ If necessary, move the cursor towards the more distant end point.
- > The control changes the suggested direction of rotation.
- ▶ Select the contour element
- > The selected contour element is displayed in blue and is marked in the List View area.
- > Other contour elements are shown in green.

 The control suggests the contour that deviates least from the suggested direction. To change the suggested contour path, you can select paths independently of the existing contour elements

- ▶ Select the last desired contour element
- > All contour elements up to the selected element are shown in blue and are marked in the List View area.
-  ▶ Select **Save entire list content to a file**
- > The control opens the **Define file name for contour program** window.
- ▶ Enter the desired name
- ▶ Select the path to the storage location
- ▶ Select **Save**
- > The selected contour is saved as an NC program.

 ■ Alternatively, you can use the **Copy entire list contents to clipboard** icon to copy the selected contour to the clipboard and then paste it into an existing NC program.

■ If you select an element with the CTRL key pressed, it is deselected for export.

Selecting paths independent of existing contour elements

To select a path independent of existing contour elements:



- ▶ Select **Contour**



- ▶ Select **Select**
 - > The icon changes, and the control activates the **Add** mode.
 - ▶ Place the cursor relative to the desired contour element
 - > The control displays selectable points:
 - End point or center point of a line or curve
 - Quadrant transitions or center of a circle
 - Points of intersection between existing elements
 - ▶ Select the desired point
 - ▶ Select more contour elements



If the contour element to be extended or shortened is a straight line, the control will extend or shorten the contour element along the same line. If the contour element to be extended or shortened is a circular arc, the control will extend or shorten the contour element along the same arc.

12.4.2 Selecting positions



- The following instructions apply to the use of a mouse. You can also perform these steps with touch gestures.
 - Further information:** "Common gestures for the touchscreen", Page 70
- Deselecting, deleting, and saving of elements works in the same way for applying contours and positions.
 - Further information:** "Selecting and saving a contour", Page 261

Individual selection

To select individual positions (e.g., holes):



- ▶ Select **Positions**
 - ▶ Position the cursor on the desired element
 - > The control shows the circumference and center point of the element in orange.
 - ▶ Select the desired element
 - > The control highlights the selected element in blue and displays it in the List View area.

Multiple selection within an area

To select multiple positions within an area:



- ▶ Select **Positions**



- ▶ Select **Select**
 - > The icon changes, and the control activates the **Add** mode.
 - ▶ Drag a box around the area while holding down the left mouse button
 - > The control opens the **Find circle centers by diameter range** window. The window shows the identified diameter and depth values.
 - ▶ Change the filter settings as needed
 - ▶ Select **OK**
 - > The control loads all positions within the selected diameter and depth ranges into the List View area.
 - > The control shows the traverse distance between the positions.

Multiple selection by search filter

To select multiple positions using a search filter:



- ▶ Select **Positions**



- ▶ Select **Find circles according to diameter range. Load center coordinates to the position list**
 - > The control opens the **Find circle centers by diameter range** window. The window shows the identified diameter and depth values.
 - ▶ Change the filter settings as needed
 - ▶ Select **OK**
 - > The control loads all positions within the selected diameter and depth ranges into the List View area.
 - > The control shows the traverse distance between the positions.

Notes

- Set the correct unit of measure so that **CAD Viewer** shows the correct values.
- Ensure that the unit of measure used in the NC program matches that used in **CAD Viewer**. Elements that have been copied from **CAD Viewer** to the clipboard do not contain any information about the unit of measure.
- The control retains the content of the clipboard only as long as **CAD Viewer** is open.
- **CAD Viewer** also recognizes circles as machining positions that consist of two semicircles.
- The control also transfers two workpiece-blank definitions (**BLK FORM**) to the contour program. The first definition contains the dimensions of the entire CAD file. The second one, which is the active one, contains only the selected contour elements, so that an optimized size of the workpiece blank results.
- CAD Import outputs the radii of the circular arcs as comments. At the end of the generated NC blocks, CAD Import displays the smallest radius to help you select the most suitable tool.

Notes on Contour Transfer

- If you double-click a layer in the List View area, the control switches to Contour Transfer mode and selects the first contour element that was drawn. The control highlights the other selectable elements of this contour in green. Especially in case of contours with many short elements, this procedure spares you the effort of running a manual search for the beginning of a contour.
- Select the first contour element such that approach without collision is possible.
- You can even select a contour if the designer has saved it on different layers.
- Specify the direction of rotation during contour selection so that it matches the desired machining direction.
- The contour paths available depend on the selectable contour elements that are shown in green. Without the green elements, the control will display all solutions available. To remove the proposed contour path, select the first green element by pressing the left mouse button while holding the **CTRL** key down.
As an alternative, you can switch to the Remove mode:

—

12.5 Generating STL files with 3D mesh (#152 / #1-04-1)**Application**

With the **3D mesh** function, you generate STL files from 3D models. This allows you to repair defective fixture and tool holder files, for example, or to position STL files generated from the simulation for another machining operation.

Related topics

- Fixture management
- Export the simulated workpiece as an STL file
- Using an STL file as workpiece blank

Further information: User's Manual for Programming and Testing

Requirement


- Software option CAD Model Optimizer (#152 / #1-04-1)

Description of function

When you select the **3D mesh** icon, the control changes to **3D mesh** mode. The control covers the 3D model displayed in **CAD Viewer** with a mesh of triangles.

The control simplifies the original model and removes errors, such as small holes in a solid or self-intersections of a surface.

You can save the result and use it for various control functions, for example as a workpiece blank with the **BLK FORM FILE** function.



3D model in **3D mesh** mode

The simplified model or parts of it may be smaller or larger than the original model. The result depends on the quality of the original model and the settings selected in **3D mesh** mode.

The List View area shows the following information:

Option	Meaning
Original triangles	Number of triangles in the original model
Number of triangles:	Number of triangles with active settings in the simplified model
<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;"> <p>i If this option is highlighted in green, the number of triangles is in the optimum range. You can further reduce the number of triangles using the available functions.</p> <p>Further information: "Functions for the simplified model", Page 266</p> </div>	
Maximum increase	Maximum increase of the triangle mesh
Over-limit area	Surface increase in percent compared to the original model
Maximum decrease	Maximum decrease of the triangle mesh compared to the original model
Under-limit area	Surface decrease in percent compared to the original model

Option	Meaning
Repairs	<p>Indicates whether the original model has been repaired or not. If it has been repaired, the control indicates the type of repair (e.g., Hole Int Shells).</p> <p>This indication consists of the following items:</p> <ul style="list-style-type: none"> ■ Hole CAD Viewer closed holes in the 3D model. ■ Int CAD Viewer removed self-intersections. ■ Shells CAD Viewer joined multiple separate solids.

In order to use STL files for control functions, the saved files must meet the following requirements:






- Max. 20 000 triangles
- Triangular mesh forms a closed shell

The greater the number of triangles in an STL file, the greater the processing power required by the control for simulation.

Functions for the simplified model

In order to reduce the number of triangles, you can define further settings for the simplified model.

CAD Viewer provides the following functions:

Icon	Meaning
	<p>Allowed simplification</p> <p>Use this function to simplify the output model by the specified tolerance. The higher the value, the more the surfaces may deviate from the original.</p>
	<p>Remove holes <= diameter</p> <p>Use this function to remove holes and pockets up to the specified diameter from the original model.</p>
	<p>Only optimized mesh shown</p> <p>The control shows the simplified model only.</p>
	<p>Original is displayed</p> <p>The control shows the simplified model, superimposed with the original mesh from the original file. You can use this function to evaluate deviations.</p>
	<p>Save</p> <p>Use this function to save the simplified 3D model with the selected settings as an STL file.</p>

12.5.1 Positioning the 3D model for rear-face machining

To position an STL file for rear-face machining:

- ▶ Export the simulated workpiece as an STL file

Further information: User's Manual for Programming and Testing




- ▶ Select the **Files** operating mode

- ▶ Select the exported STL file
- ▶ The control opens the STL file in **CAD Viewer**.



- ▶ Select **Preset**
- ▶ The control displays information on the preset position in the List View area.
- ▶ Enter the value of the new preset in the **Preset** area (e.g., **Z-40**)
- ▶ Confirm your input
- ▶ Orient the coordinate system by specifying values under **PLANE SPATIAL SP*** (e.g., **A+180** and **C+90**)
- ▶ Confirm your input



- ▶ Select **3D mesh**
- ▶ The control opens the **3D mesh** mode and simplifies the 3D model using the default settings.
- ▶ Further simplify the 3D model using the **3D mesh** mode functions, if required.

Further information: "Functions for the simplified model", Page 266



- ▶ Select **Save**
- ▶ The control opens the **Define file name for 3D mesh** window.
- ▶ Enter the desired name
- ▶ Select **Save**
- ▶ The control saves the STL file positioned for rear-face machining.



The resulting file can then be used for rear-face machining with the **BLK FORM FILE** function.

Further information: User's Manual for Programming and Testing

13

User aids

13.1 Virtual keyboard of the control bar

Application

You can use the virtual keyboard for entering NC functions, letters, and numbers, and for navigation.

The virtual keyboard offers the following modes:

- NC input
- Text input
- Formula entry

Description of function


The control opens NC input mode by default after the start procedure.

You can move the keyboard on the screen. The keyboard remains active, even when the operating mode is switched, until the keyboard is closed.

The control remembers the position and mode of the virtual keyboard until it is shut down.

The **Keyboard** workspace provides the same functions as the virtual keyboard.

NC input areas



Virtual keyboard in NC input mode


NC input mode contains the following areas:

- 1 File functions
 - Define favorites
 - Copy
 - Paste
 - Add comment
 - Add structure item
 - Hide NC block
- 2 NC functions
- 3 Axis keys and numerical input
- 4 Q parameters
- 5 Navigation and dialog keys
- 6 Switch to text input

i If you press the **Q** button in the NC functions area repeatedly, the control cycles through the syntax in the following sequence:

- **Q**
- **QL**
- **QR**

Text input areas




Virtual keyboard in text input mode

The text input contains the following areas:

- 1 Input
- 2 Navigation and dialog keys
- 3 Copying and pasting
- 4 Switch to formula input

Formula input areas



Virtual keyboard in formula input mode

The formula input contains the following areas:

- 1 Input
- 2 Q parameters
- 3 Navigation and dialog keys
- 4 Copying and pasting
- 5 Switch to NC input

13.1.1 Opening and closing the virtual keyboard

To open the virtual keyboard:



- ▶ Select the **virtual keyboard** on the control bar
- > The control opens the virtual keyboard.

To close the virtual keyboard:



- ▶ Select the **virtual keyboard** when the virtual keyboard is open



- ▶ Or press **Close** in the virtual keyboard
- > The control closes the virtual keyboard.









13.2 Message menu on the information bar

Application

In the message menu of the information bar, the control shows pending errors and notes. When opened, the control displays detailed information about the messages.

Description of function

The control uses the following symbols to differentiate between the types of messages:


Symbol	Message type	Meaning
	Error Question type	The control displays a dialog with several options you can select from. You cannot clear this error message: you can only choose one of the possible responses. If necessary, the control continues the dialog until the cause or correction of the error has been clearly determined.
	Error Reset type	The control must be restarted. This message cannot be cleared.
	Error Emergency-stop type	The control performs an emergency stop. An error message can only be cleared after the cause has been eliminated.
	Error	To continue, you must clear this message. An error message can only be cleared after the cause has been eliminated.
	Warning	You can continue without clearing the message. Most warnings can be cleared at any time; in some cases, the cause has to be eliminated first.
	Information	You can continue without clearing the message. You can clear the information at any time.
	Note	You can continue without clearing the message. The control displays the note until you press the next valid key.
		No pending messages

The message menu is collapsed by default.

The control displays messages upon various events, for example:

- Logical errors in the NC program
- Impossible contour elements
- Improper touch-probe inserts
- Hardware updates

Content



Collapsed message menu on the information bar


When the control displays a new message, the arrow to the left of the message blinks. Click or tap this arrow to confirm acknowledgment of the message; the control then minimizes the message.

The control displays the following information in the collapsed message menu:

- Message type
- Message
- Quantity of pending errors, warnings, and informational messages

Detailed messages

If you tap or click the symbol or within the message, the control expands the message menu.



Expanded message menu with pending messages

The control displays all pending messages in chronological order.

The message menu shows the following information:

- Message type
- Error number
- Message
- Date
- Additional information (root cause, correction, information on the NC program)

Deleting messages

Messages can be deleted in the following ways:

- **CE** key
- **CE** button in the message menu
- **Delete all** button in the message menu

Details

Press the **Details** button to show or hide internal information about the message. This information is of importance in case servicing is necessary.

Group

If you activate the **Group** toggle switch, the control displays all messages with the same error number in one row. This makes the list of messages shorter and easier to read.

Under the error number, the control displays the quantity of messages. Use **CE** to clear all messages of a group.

Service file

Click the **Save service files** button to open the **Save service files** window.

In the **Save service files** window, you can create service files in the following ways:

- If an error occurs, you can create a service file manually.
 - Further information:** "Creating a service file manually", Page 276
- If an error occurs repeatedly, a service file can be created automatically by means of the error number. Once the respective error occurs, the control saves a service file.

Further information: "Creating a service file automatically", Page 277


Service files help service technicians in troubleshooting the problem. The control saves data that provide information about the current machine and operation status, such as active NC programs up to 10 MB, tool data, and keystroke logs.

The file name of each service file consists of a user-defined name and a timestamp.

If you create multiple service files with the same name, the control saves a maximum of five files and then deletes the file with the oldest timestamp, if necessary. Make a backup of the service files you created (e.g., by moving them to a different folder).

13.2.1 Creating a service file manually

To create a service file manually:





- ▶ Expand the message menu
- ▶ Select **Save service files**
- > The control opens the **Save service file** window.
- ▶ Enter the file name
- ▶ Press **OK**
- > The control saves the service file in the **TNC:\service** directory.

13.2.2 Creating a service file automatically

You can specify up to five error numbers for which the control will automatically create a service file if one of these errors occurs.

To specify a new error number:



- ▶ Expand the message menu
- ▶ Select **Save service files**
- > The control opens the **Save service file** window.
- ▶ Select **Setting for autosave**
- > The control opens a table of error numbers.
- ▶ Enter the desired error number
- ▶ Enable the **Active** check box
- > If the error occurs, the control automatically creates a service file.
- ▶ Enter a comment, if applicable (e.g., to describe the problem)

14

The MDI Application

Application

The **MDI** application allows you to execute individual NC blocks outside of the context of an NC program (e.g., **PLANE RESET**). When you press the **NC Start** key, the control will run the NC blocks separately.


You can also create an NC program step by step. The control remembers modally effective program information.

Related topics

- Creating NC programs
Further information: User's Manual for Programming and Testing
- Running NC programs
Further information: "Program Run", Page 323

Description of function

If you program using the millimeter unit of measurement, the control will use the NC program **\$mdi.h** by default. If you program using the inch unit of measurement, the control will use the NC program **\$mdi_inch.h**.




The **Program** workspace in the **MDI** application

The **MDI** application provides the following workspaces:

- **Help**
- **Positions**
Further information: "The Positions workspace", Page 97
- **Program**
Further information: User's Manual for Programming and Testing
- **Simulation**
Further information: User's Manual for Programming and Testing
- **Status**
Further information: "The Status workspace", Page 105
- **Keyboard**
Further information: "Virtual keyboard of the control bar", Page 270

Icons and buttons

In the **MDI** application, the function bar provides the following buttons:

Icon or button	Meaning
	Execution cursor The execution cursor shows which NC block is currently being executed or is marked for execution.
Klartext editor	If this toggle switch is active, then you are using dialog-guided programming. If this toggle switch is not active, then you are programming in the text editor. Further information: User's Manual for Programming and Testing
Insert NC function	The control opens the Insert NC function window. Further information: User's Manual for Programming and Testing
Q info	The control opens the Q parameter list window, where you can see and edit the current values and descriptions of the variables. Further information: User's Manual for Programming and Testing
GOTO block number	Mark an NC block to be run without considering any previous NC blocks Further information: User's Manual for Programming and Testing
/ Skip block Off/On	Hide NC blocks with /. NC blocks hidden with a / character will be ignored during program run as soon as the Skip block toggle switch is active. Further information: User's Manual for Programming and Testing
Skip block	If the toggle switch is active, then the control does not execute any NC blocks dimmed with the / character. If the toggle switch is active, then the control dims the NC blocks to be skipped. Further information: User's Manual for Programming and Testing
; Comment Off/On	Insert or remove a ; character in front of an NC block. If an NC block begins with a ; character, then the block is a comment. Further information: User's Manual for Programming and Testing
F LIMIT	Use this function to activate a feed-rate limit and define its value. Further information: "Feed rate limit F LIMIT", Page 328
F limited	Use this option to activate or deactivate the feed-rate limit for functional safety (FS). Only on machines with functional safety (FS). Further information: "Feed-rate limiting with functional safety (FS)", Page 432
ACC	If this toggle switch is active, the control activates Active Chatter Control (ACC, option 145). Further information: "Active Chatter Control (ACC) (#145 / #2-30-1)", Page 245
Tool Retract	If the NC program is stopped during a thread cycle, you can retract the tool. Further information: User's Manual for Machining Cycles
Edit	The control opens the context menu. Further information: User's Manual for Programming and Testing
Tools	The control opens the Tool management application in the Tables operating mode. Further information: "Tool management ", Page 163

Icon or button	Meaning
Internal stop	<p>If an NC program is interrupted due to an error or a stop, the control activates this button.</p> <p>Use this button to abort program run.</p> <p>Further information: "Interrupting, stopping or canceling program run", Page 329</p>
Reset program	<p>If you select Internal stop, the control activates this button.</p> <p>The control resets any modally active program information as well as the program run-time.</p>

Modally effective program information

In the **MDI** application, you always execute NC blocks in **Single Block** mode. After the control has executed an NC block, the program run is considered to be interrupted.

Further information: "Interrupting, stopping or canceling program run", Page 329

The block numbers of all NC blocks that you have successively run are shown in green.

The control saves the following data in this state:

- The last tool that was called
- Current coordinate transformations (e.g., datum shift, rotation, mirroring)
- The coordinates of the circle center that was last defined

Notes

NOTICE

Danger of collision!

Certain manual interactions may lead to the control losing the modally effective program information (i.e., the contextual reference). Loss of this contextual reference may result in unexpected and undesirable movements. There is a risk of collision during the subsequent machining operation!

- ▶ Do not perform the following interactions:
 - Cursor movement to another NC block
 - The jump command **GOTO** to another NC block
 - Editing an NC block
 - Modifying the values of variables by using the **Q parameter list** window
 - Switching the operating modes
 - ▶ Restore the contextual reference by repeating the required NC blocks
-
- In the **MDI** application, you can create and execute NC programs step by step. Then you can use **Save as** to save the current contents with a different file name.
 - The following functions are not available in the **MDI** application:
 - Calling of an NC program with **PGM CALL**
 - Test run in the **Simulation** workspace
 - **Manual traverse** and **Approach position** functions while program run is interrupted
 - **Block scan** function
 - The execution cursor is always displayed in the foreground. The execution cursor may cover or hide other icons.

15

Touch Probes

15.1 Setting up touch probes

Application

The **Device configuration** window allows you to create and manage all the workpiece and tool touch probes of the control.

Touch probes with radio transmission can be created and managed only in the **Device configuration** window.

Related topics

- Creating a workpiece touch probe with cable or infrared transmission by using the touch probe table
Further information: "Touch probe table tchprobe.tp (#17 / #1-05-1)", Page 373
- Creating a tool touch probe with cable or infrared transmission by using the machine parameter **CfgTT** (no. 122700)
Further information: "Machine parameters", Page 491

Description of function


You open the **Device configuration** window in the **Machine Settings** group of the **Settings** application. Double-tap or double-click the **Set Up Touch Probes** menu item.

Further information: "The Settings Application", Page 435

Touch probes with radio transmission can be created and managed only in the **Device configuration** window.

In order for the control to recognize the touch probe with radio transmission, you will require an **SE 661** transceiver with EnDat interface.

You define the new values in the **Work data** area.



Areas of the Device configuration window

The Touch probes area

In the **Touch probes** area, the control displays all of the defined workpiece and tool touch probes, as well as the transceiver units. All other areas provide detailed information about the selected entry.

The Work data area

For a workpiece touch probe, the control displays the values from the touch-probe table in the **Work data** area.

For a tool touch probe, the control displays the values from the machine parameter **CfgTT** (no. 122700).

You can select and edit the displayed values. Under **Touch probes**, the control displays information about the active value (e.g., selection options). You can change the values of the tool touch probes only after entering the code number 123.

The Properties area

In the **Properties** area, the control displays the connection data and diagnostic functions.

For touch probes with radio connection, the control displays the following information in **Current radio touch probe data**:

Display	Meaning
NO.	Number in the touch probe table
Type	Type of touch probe
Status	Touch probe active or inactive
Signal strength	Display of the signal strength in the bar graphic The control shows the currently best-known connection as a complete bar
Deflection	Stylus deflected or not deflected
Collision	Collision or no collision recognized
Battery status	Display of the battery quality If the charge is less than the displayed bar, then the control outputs a warning.

The **Switching on/off** connection setting is preset based on the type of touch probe. Under **Deflection**, you can select how the touch probe is to transmit the signal when probing.

Deflection	Meaning
IR	Infrared probe signal
Radio	Radio probe signal
Radio + IR	The control selects the probe signal



If you activate the touch probe's radio connection by using the connection setting **Switch on/off**, then the signal will be retained even after a tool change. You need to use this connection setting to deactivate the radio connection.

Buttons

The control provides the following buttons:

Button	Function
CREATE TS ENTRY	Create a new workpiece touch probe You define the new values in the Work data area.
CREATE TT ENTRY	Create a new tool touch probe You define the new values in the Work data area.
SELECT DEFLECTION	Select the probe signal
SELECT CHANNEL	Select the radio channel Select the channel with the best radio transmission and pay attention to overlaps with other machines or wireless handwheels.
CHANGE CHANNEL	Change the radio channel
REMOVE TCH. PROBE	Delete the touch probe data The control deletes the entry from the Device configuration window and from the touch-probe table or the machine parameters.
EXCHANGE TCH. PROBE	Save a new touch probe in the current row The control automatically overwrites the serial number of the replaced touch probe with the new number.
SELECT SE	Select the SE transceiver
SELECT IR POWER	Select the strength of the infrared signal You only need to change the signal strength if there is interference.
SELECT RADIO POWER	Select the strength of the radio signal You only need to change the signal strength if there is interference.

Note

In the machine parameter **CfgHardware** (no. 100102), the machine manufacturer defines whether the control will show or hide the touch probes in the **Device configuration** window. Refer to your machine manual.

16

**Touch Probe
Functions in
the Manual
Operating Mode
(#17 / #1-05-1)**

16.1 Fundamentals

Application

The touch probe functions allow you to set presets on the workpiece, measure the workpiece, and determine and compensate for workpiece misalignment.

Related topics

- Automatic touch probe cycles for the workpiece
Further information: User's Manual for Measuring Cycles for Workpieces and Tools
- Preset table
Further information: "Preset table *.pr", Page 385
- Datum table
Further information: User's Manual for Programming and Testing
- Reference systems
Further information: "Reference systems", Page 180
- Preassigned variables
Further information: User's Manual for Programming and Testing

Requirements

- Software option Touch-probe functions (#17 / #1-05-1)



If you are using a HEIDENHAIN touch probe with EnDat interface, then the software option Touch Probe Functions (#17 / #1-05-1) is automatically enabled.

- Calibrated workpiece touch probe
Further information: "Calibrating the workpiece touch probe", Page 304


Description of function

The control provides the following functions for setting up the machine in the **Manual** operating mode in the **Setup** application:

- Define the workpiece preset
- Determine and compensate for workpiece misalignment
- Calibrate the workpiece touch probe
- Calibrate the tool touch probe
- **Measure the tool**
- **Set up fixtures** (#140 / #5-03-2)
Further information: "Integrating fixtures into collision monitoring (#140 / #5-03-2)", Page 216
- **Set up the workpiece** (#159 / #1-07-1)
Further information: "Setting up the workpiece with graphical support (#159 / #1-07-1)", Page 309

Within the functions, the control provides the following probing methods:

- Manual probing method
 You position and start individual probing processes manually within a touch probe function.
Further information: "Setting a preset in a linear axis", Page 298
- Automatic probing method
 You manually position the touch probe to the first probing point before the start of the probing routine and fill out a form with the individual parameters for the respective touch probe function. When you start the touch probe function, the control automatically positions and automatically performs probing.
Further information: "Determining the circle center point of a stud using the automatic probing method ", Page 300







The **Probing function** workspace

Overview

The touch probe functions are structured in the following groups:

Probe the angle

The **Probe the angle** group contains the following touch probe functions:

Button	Function
	<p>Use the Plane (PL) function to determine the solid angle of a plane.</p> <p>You then save the values in the preset table or align the plane.</p>
	<p>Use the Plane over cylinder (PLC) function to probe one or two cylinders, each at two different heights. The control calculates the solid angle of a plane from the points probed.</p> <p>You then save the values in the preset table or align the plane.</p>
	<p>Use the Rotation (ROT) function to determine the skew of a workpiece using a straight line.</p> <p>Then save the determined skew as a basic transformation or offset in the preset table.</p> <p>Further information: "Determining and compensating the rotation of a workpiece", Page 302</p>
	<p>Use the Intersection point (P) function to probe four probing objects. The probing objects can be either positions or circles. The control determines the intersection of the axes and the skew of the workpiece from the objects that have been probed.</p> <p>You can set the intersection point as a preset. You can transfer the determined skew to the preset table as a basic transformation or as an offset.</p>



The control interprets a basic transformation as a basic rotation, and an offset as a table rotation.





Further information: "Preset table *.pr", Page 385

You can compensate for the workpiece misalignment by rotating the table only if the machine is designed with a rotary table axis that is oriented perpendicularly with respect to the workpiece coordinate system **W-CS**.

Further information: "Comparison of offset and 3D basic rotation", Page 320





Probe the position

The **Probe the position** group contains the following touch probe functions:

Button	Function
	<p>You can use the Position (POS) function to probe a position in the X axis, Y axis or Z axis.</p> <p>Further information: "Setting a preset in a linear axis", Page 298</p>
	<p>The Circle (CC) function is used to determine the coordinates of a circle center point (e.g., for a hole or for a stud).</p> <p>Further information: "Determining the circle center point of a stud using the automatic probing method ", Page 300</p>
	<p>The Circle pattern (CPAT) function is used to determine the center point coordinates of a circle pattern.</p>
	<p>The Centerline (CL) function is used to determine the center point of a ridge or slot.</p>

The Additional functions group









The **Additional functions** group contains the following touch probe functions:

Button	Function
	<p>The Calibrate touch probe function is used to determine the length and radius of a workpiece touch probe.</p> <p>Further information: "Calibrating the workpiece touch probe", Page 304</p>
	<p>The Measure tool function allows you to measure tools by scratching.</p> <p>In this function, the control supports milling tools, drilling tools and turning tools.</p> <p>Further information: "Werkzeug vermessen mit Ankratzen", Page</p>
	<p>The Set up fixtures function is used to determine the position of a clamping device in the working space using a workpiece touch probe (#140 / #5-03-2).</p> <p>Further information: "Integrating fixtures into collision monitoring (#140 / #5-03-2)", Page 216</p>
	<p>The Set up the workpiece function is used to determine the position of a workpiece in the working space using a workpiece touch probe (#159 / #1-07-1).</p> <p>Further information: "Setting up the workpiece with graphical support (#159 / #1-07-1)", Page 309</p>

Icons and buttons



General icons and buttons in the touch probe functions

The following buttons are available, depending on the selected touch probe function:

Icon or button	Meaning
	Exit probing
	Select the workpiece preset and the pallet preset and edit the values if required Further information: "The Change the preset window", Page 297 Further information: "Preset table *.pr", Page 385
	Display help graphics for the selected touch probe function
	Select the probing direction
	Apply the actual position
	Manually approach and probe points on a straight surface
	Manually approach and probe points on a stud or in a hole
	Automatically approach and probe points on a stud or in a hole After the last touching process and if the opening angle contains the value 360°, the control positions the workpiece touch probe back to the position it had prior to starting the probing function.
Tools	The control opens the Tool management application in the Tables operating mode. Further information: "Tool management ", Page 163
Internal stop	If an NC program is interrupted due to an error or a stop, the control activates this button. Use this button to abort program run. Further information: "Interrupting, stopping or canceling program run", Page 329

Symbols and buttons for calibration




The control offers the following functions for calibrating a 3D touch probe:

Icon or button	Meaning
	Calibrating the length of a 3D touch probe
	Calibrating the radius of a 3D touch probe
Apply calibration data	Transferring values from the calibration process into tool management

Further information: "Calibrating the workpiece touch probe", Page 304

You can calibrate a 3D touch probe by using a calibration standard, such as a calibrating ring.

The control provides the following options:

Icon	Meaning
	Measure the radius and the center offset using a calibration ring
	Measure the radius and the center offset using a stud or a calibration pin
	Measure the radius and the center offset using a calibration sphere

Buttons in the Working plane is inconsistent! window

If the positions of the rotary axes do not match the tilting situation in the **3-D rotation** window, the control opens the **Working plane is inconsistent!** window.

The control offers the following functions in the **Working plane is inconsistent!** window:

Button	Meaning
3-D ROT Apply status	The 3-D ROT Apply status function transfers the position of the rotary axes into the 3-D rotation window. Further information: "The 3-D rotation window (#8 / #1-01-1)", Page 201
3-D ROT Ignore status	The 3-D ROT Ignore status function makes the control calculate the probing results, assuming that the rotary axes are in their zero position.
Align the rotary axes	The Align the rotary axes function aligns the rotary axes to the active tilting situation in the 3-D rotation window.

Buttons for measured values

After executing a touch probe function, you select the desired control reaction.

The control provides the following functions:

Button	Meaning
Compensate the active preset	The Compensate the active preset function transfers the measuring result into the active line of the preset table. Further information: "Preset table *.pr", Page 385
Correct the datum	The Correct the datum function transfers the measuring result into a desired line of the datum table. Further information: User's Manual for Programming and Testing
Align rotary table	The Align rotary table function aligns the rotary axes mechanically according to the measuring result.
Correct the pallet reference point	The Correct the pallet reference point function transfers the measuring result into the active line of the pallet preset table. Further information: User's Manual for Programming and Testing

NOTICE

Danger of collision!

The control may feature an additional pallet preset table, depending on the machine. Values that the machine manufacturer defined in the pallet preset table take effect before values that you defined in the preset table. The control indicates in the **Positions** workspace whether a pallet preset is active and if yes, which one. Since the values of the pallet preset table are neither visible nor editable outside the **Setup** application, there is a risk of collision during any movement!



- ▶ Refer to the machine manufacturer's documentation
- ▶ Use pallet presets only in conjunction with pallets
- ▶ Change pallet presets only after discussion with the machine manufacturer
- ▶ Check the pallet preset in the **Setup** application before you start machining

The Change the preset window

In the **Change the preset** window you can select a preset or edit the values of a preset.

Further information: "Preset management", Page 194

The **Change the preset** window provides the following buttons:

Icon or button	Meaning
	The control shows the preset table. Further information: User's Manual for Programming and Testing
	The control shows the pallet preset table. Further information: User's Manual for Programming and Testing
Reset basic rotation	The control resets the values from the columns SPA , SPB and SPC .
Reset offsets	The control resets the values from the columns A_OFFS , B_OFFS and C_OFFS .
Apply changes and delete existing probe objects	The control activates the selected preset and rejects the touch points used so far. Then the control closes the window.
Apply	The control saves the changes and the selected preset. Then the control closes the window.
Reset	The control cancels the changes and restores the initial condition.
Cancel	The control closes the window without saving.



If you change a value, the control marks this value with a blue dot.

NOTICE

Danger of collision!

The control may feature an additional pallet preset table, depending on the machine. Values that the machine manufacturer defined in the pallet preset table take effect before values that you defined in the preset table. The control indicates in the **Positions** workspace whether a pallet preset is active and if yes, which one. Since the values of the pallet preset table are neither visible nor editable outside the **Setup** application, there is a risk of collision during any movement!

- ▶ Refer to the machine manufacturer's documentation
- ▶ Use pallet presets only in conjunction with pallets
- ▶ Change pallet presets only after discussion with the machine manufacturer
- ▶ Check the pallet preset in the **Setup** application before you start machining

Log file of touch probe cycles

After executing the respective touch-probe cycle, the control writes the measured values to the TCHPRMAN.html file.

You can check the readings of past measurements in the **TCHPRMAN.html** file.

If you have not defined a path in the machine parameter **FN16DefaultPath** (no. 102202), the control will store the TCHPRMAN.html file directly under **TNC:.**


If you run several touch probes cycles in a row, the control stores the measured values below each other.

16.1.1 Setting a preset in a linear axis

To probe the preset in any axis:



- ▶ Select the **Manual** operating mode



- ▶ Call the workpiece touch probe as a tool
- ▶ Select the **Setup** application
- ▶ Select the **Position (POS)** touch probe function
- > The control opens the **Position (POS)** touch probe function.



- ▶ Select **Change the preset**
- > The control opens the **Change the preset** window.
- ▶ Select the desired row of the preset table
- > The control highlights the selected line in green.



- ▶ Press **Apply**
- > The control activates the selected line as the workpiece preset.
- ▶ Use the axis keys to position the workpiece touch probe at the desired probing position (e.g., above the workpiece in the workspace)



- ▶ Select the probing direction (e.g., **Z-**)



- ▶ Press the **NC start** key
- > The control performs the probing process and then automatically retracts the workpiece touch probe to the starting point.
- > The control shows the measurement results.
- ▶ In the **Nominal value** area, enter the new preset of the probed axis (e.g., **1**)

Compensate the active preset


- ▶ Select **Compensate the active preset**
- > The control enters the defined nominal value in the preset table.
- > The control marks the row with an icon.



If you use the **Correct the datum** function, the control also marks this row with an icon.
When you have completed the probing process in the first axis, you can probe up to two additional axes using the **Position (POS)** probing function.



- ▶ Select **Exit probing**
- > The control closes the **Position (POS)** probing function.



16.1.2 Determining the circle center point of a stud using the automatic probing method

To probe a circle center point:



- ▶ Select the **Manual** operating mode

- ▶ Call the workpiece touch probe as a tool

Further information: "The Manual operation application", Page 134



- ▶ Select the **Setup** application

- ▶ Select **Circle (CC)**

- ▶ The control opens the **Circle (CC)** probing function.

- ▶ If necessary, select another preset for the probing process



- ▶ Select measuring method **A**



- ▶ Select **Type of contour** (e.g., stud)

- ▶ Enter **Diameter** (e.g., 60 mm)

- ▶ Enter **Safety clearance (min. value = SET_UP)** if required



The control suggests the total of the value in the **SET_UP** column of the touch probe table and the ball tip radius as a safety distance.

- ▶ Enter **Starting angle** (e.g., -180°)

- ▶ Enter **Angular length** (e.g., 360°)

- ▶ Position the 3D touch probe at the desired probing position next to the workpiece and below the workpiece surface

- ▶ Select the probing direction (e.g., **X+**)

- ▶ Turn the feed rate potentiometer to zero

- ▶ Press the **NC start** key



- ▶ Slowly turn on the feed rate potentiometer

- ▶ The control executes the touch probe function based on the data entered.

- ▶ The control shows the measurement results.

- ▶ In the **Nominal value** area, enter the new preset of the scanned axes (e.g., **0**)

Compensate the active preset




- ▶ Select **Compensate the active preset**
- > The control sets the preset to the entered nominal value.
- > The control marks the row with an icon.



If you use the **Correct the datum** function, the control also marks this row with an icon.



- ▶ Select **Exit probing**
- > The control closes the **Circle (CC)** probing function.



16.1.3 Determining and compensating the rotation of a workpiece

To probe the rotation of a workpiece:



- ▶ Select the **Manual** operating mode



- ▶ Call the 3D touch probe as a tool

- ▶ Select the **Setup** application

- ▶ Select **Rotation (ROT)**

- ▶ The control opens the **Rotation (ROT)** probing function.

- ▶ If necessary, select another preset for the probing process



- ▶ Position the 3D touch probe at the desired probing position in the workspace



- ▶ Select the probing direction (e.g., **Y+**)



- ▶ Press the **NC start** key


- ▶ The control executes the first probing process and limits the subsequently selectable probing directions.

- ▶ Position the 3D touch probe at the second probing position in the workspace



- ▶ Press the **NC start** key

- ▶ The control executes the probing process and then shows the measurement results.



- ▶ Select **Compensate the active preset**

- ▶ The control transfers the determined basic rotation to the **SPC** column of the active line of the preset table.

- ▶ The control marks the row with an icon.




Depending on the tool axis, the measurement result can also be written to another column of the preset table (e.g., **SPA**).



- ▶ Select **Exit probing**

- ▶ The control closes the **Rotation (ROT)** probing function.



16.1.4 Using touch probe functions with mechanical probes or dial gages

If your machine does not have an electronic 3D touch probe, you can use all manual touch probe functions with manual probing methods with mechanical buttons or with scratching.

For this, the control provides the **Accept position** button.

To determine a basic rotation with a mechanical probe:



- ▶ Select the **Manual** operating mode



- ▶ Insert the tool, such as an analog 3D probe or feeler lever gage
- ▶ Select the **Setup** application
- ▶ Select the **Rotation (ROT)** probing function




- ▶ Select the probing direction (e.g., **Y+**)
- ▶ Move the mechanical probe to the first position to be captured by the control.



- ▶ Select **Accept position**
- > The control saves the current position.
- ▶ Move the mechanical probe to the next position to be captured by the control.



- ▶ Select **Accept position**
- > The control saves the current position.



- ▶ Select **Compensate the active preset**
- > The control transfers the determined basic rotation to the active line of the preset table.



- > The control marks the row with an icon.



The determined angles have different effects depending on whether they are transferred as an offset or as a basic rotation to the corresponding table.

Further information: "Comparison of offset and 3D basic rotation", Page 320



- ▶ Select **Exit probing**
- > The control closes the **Rotation (ROT)** probing function.

Notes

- If you use a non-contacting tool touch probe (such as a laser touch probe), then you are using touch-probe functions from a third-party supplier. Refer to your machine manual.
- The accessibility of the pallet preset table in the touch-probe functions depends on the machine manufacturer's configuration. Refer to your machine manual.
- When probing while the guard door is open and spindle orientation to probing direction is active, the number of spindle revolutions is limited. When the maximum permitted number of spindle revolutions is reached, the direction of spindle rotation changes and the control may no longer orient the spindle on the shortest path.
- If you try to set a preset in a locked axis, the control will issue either a warning or an error message, depending on what the machine manufacturer has defined.
- When writing into an empty line of the preset table, the control automatically fills the other columns with values. To define a preset completely, you must determine the values in all axes and write them into the preset table.
- If no tool touch probe is inserted, the actual position can be captured with **NC START**. The control displays a warning that no probing movement is carried out in that case.
- Recalibrate the workpiece touch probe in the cases below:
 - Initial configuration
 - Broken stylus
 - Stylus replacement
 - Change in the probe feed rate
 - Irregularities caused, for example, when the machine heats up
 - Change of active tool axis
- If the touch point is not reached during the touching process, the control will display a warning. The probing process can be continued with **NC Start**.

Definition

Spindle tracking

If the **Track** parameter in the touch probe table is active, the control orients the workpiece probing system so that the same position is always used for probing. By deflecting in the same direction, you can reduce the measurement error to the repeatability of the workpiece probing system. This behavior is called spindle tracking.

16.2 Calibrating the workpiece touch probe


Application

The touch probe must be calibrated in order to enable determining precisely the actual switching point of a 3D touch probe. Otherwise, the control cannot ascertain exact measuring results.

Related topics

- Calibrate the workpiece touch probe automatically
Further information: User's Manual for Measuring Cycles for Workpieces and Tools
- Touch probe table
Further information: "Touch probe table tchprobe.tp (#17 / #1-05-1)", Page 373

Description of function



During calibration, the control finds the effective length of the stylus and the effective radius of the ball tip. To calibrate the 3D touch probe, clamp a ring gauge or a stud of known height and known radius to the machine table.

The effective length of the workpiece touch probe refers to the tool carrier preset.

Further information: "Tool carrier reference point", Page 147

You can calibrate the workpiece touch probe with various tools. For example, the workpiece touch probe can be calibrated using an overmilled surface in length and a calibration ring in the radius. This creates a reference between the workpiece touch probe and the tools in the spindle. In this procedure, measured tools and the calibrated workpiece touch probe correspond using the tool presetting device.

Calibrating an L-shaped stylus

Before you calibrate an L-shaped stylus you first must define the parameters in the touch probe table. Based on these approximate values, the control can align the touch probe during the calibration and determine the actual values.

At first, define the following parameters in the touch probe table:

Parameter	Value to be defined
CAL_OF1	Length of extension The extension is the angled length of the L-shaped stylus.
CAL_OF2	0
CAL_ANG	Spindle angle at which the extension is parallel to the main axis For this, manually position the extension in the direction of the main axis and read the value from the position display.

After the calibration, the control overwrites the previously defined values in the touch probe table with the determined values.

Further information: "Touch probe table tchprobe.tp (#17 / #1-05-1)", Page 373

When calibrating the length, the control aligns the touch probe with the calibration angle defined in the **CAL_ANG** column.

While calibrating the touch probe, ensure that the feed rate override is 100%. That way you can always use the same feed rate for the subsequent probing processes as was used for the calibration. Hence, you can exclude inaccuracies during the probing caused by modified feed rates.

Reversal measurement

When calibrating the ball-tip radius, the control executes an automatic probing routine. In the first run the control finds the midpoint of the calibration ring or pin (approximate measurement) and positions the touch probe in the center. Then, in the actual calibration process (fine measurement), the radius of the ball tip is ascertained. If the touch probe allows probing from opposite orientations, the center offset is determined during another cycle.

HEIDENHAIN touch probes are predefined as to whether or how a touch probe can be oriented. Other touch probes are configured by the machine manufacturer.

When calibrating the radius, up to three circular measurements can be taken depending on the possible orientation of the workpiece touch probe. The first two circular measurements determine the center offset of the workpiece touch probe. The third circular measurement determines the effective stylus tip radius. If orientation of the spindle is not possible or only a certain orientation is possible due to the workpiece touch probe, circular measurements are omitted.

16.2.1 Calibrating the length of the workpiece touch probe

To calibrate a workpiece touch probe using an overmilled surface in length:

- ▶ Measure the end milling cutter on the tool presetting device
- ▶ Store the measured end milling cutter in the tool magazine of the machine
- ▶ Enter the tool data of the end milling cutter in tool management
- ▶ Clamp the workpiece blank



- ▶ Select the **Manual** operating mode

- ▶ Replace the end milling cutter in the machine
- ▶ Switch on spindle (e.g., with **M3**)
- ▶ Use the handwheel to scratch the workpiece blank

Further information: "Setting a preset with milling cutters", Page 195

- ▶ Set preset in the tool axis (e.g., with **Z**)
- ▶ Position the end milling cutter next to the workpiece blank
- ▶ Set a small value in the tool axis (e.g., **-0.5 mm**)
- ▶ Overmill the workpiece blank using the handwheel
- ▶ Set the preset again in the tool axis (e.g., with **Z=0**)
- ▶ Switch off spindle (e.g., with **M5**)
- ▶ Replace the tool touch probe
- ▶ Select the **Setup** application
- ▶ Select **Calibrate touch probe**




- ▶ Select the **Length calibration** measurement method
- ▶ The control displays the current calibration data.
- ▶ Enter the reference surface position (e.g., with **0**)
- ▶ Position the workpiece touch probe close to the surface of the overmilled area



Check that the area to be probed is flat and free of chips before you start the touch probe function.



- ▶ Press the **NC Start** key
- ▶ The control performs the probing process and then automatically retracts the workpiece touch probe to the starting point.
- ▶ Check results



- ▶ Select **Apply calibration data**
- ▶ The control transfers the calibrated length of the 3D touch probe to the tool table.



- ▶ Select **Exit probing**
- ▶ The control closes the **Calibrate touch probe** function.

16.2.2 Calibrating the radius of the workpiece touch probe

To calibrate a workpiece touch probe using a setting ring in the radius:

- ▶ Clamp the setting ring on the machine table (e.g., with clamps)



- ▶ Select the **Manual** operating mode
- ▶ Position the 3D touch probe in the hole of the setting ring



Make sure that the stylus tip is completely recessed into the calibration ring. This causes the control to probe with the largest point of the stylus tip.



- ▶ Select the **Setup** application
- ▶ Select **Calibrate touch probe**



- ▶ Select **Radius** measurement method




- ▶ Select **Setting ring** calibration standard

- ▶ Enter the diameter of the ring gauge
- ▶ Enter the start angle
- ▶ Enter the number of touch points



- ▶ Press the **NC Start** key
- > The 3D touch probe probes all required touch points in an automatic probing routine. The control calculates the effective stylus tip radius. If probing from opposite orientations is possible, the control calculates the center offset.



- ▶ Check results
- ▶ Select **Apply calibration data**
- > The control stores the calibrated radius of the 3D touch probe in the tool table.



- ▶ Select **Exit probing**
- > The control closes the **Calibrate touch probe** function.

Instructions for calibration

- In order to be able to determine ball-tip center misalignment, the control needs to be specially prepared by the machine manufacturer.
- If you press the **OK** button after the calibration process, the control accepts the calibration values for the active touch probe. The updated tool data then becomes immediately effective, and it is not necessary to repeat the tool call.
- HEIDENHAIN guarantees the proper operation of the touch probe cycles only in conjunction with HEIDENHAIN touch probes.
- If you want to calibrate using the outside of an object, you need to pre-position the touch probe above the center of the calibration sphere or calibration pin. Ensure that the probing points can be approached without collisions.
- The control saves the effective length and effective radius of the touch probe in the tool table. The control saves the touch probe center offset in the touch probe table. The control uses the **TP_NO** parameter to link the data from the touch probe table with the data from the tool table.

Further information: "Touch probe table tchprobe.tp (#17 / #1-05-1)", Page 373

16.3 Setting up the workpiece with graphical support (#159 / #1-07-1)

Application

Use the **Set up the workpiece** function to determine the position and misalignment of a workpiece with only one touch-probe function and save it as a workpiece preset. During setup, you can probe curved surfaces.


The control supports you additionally by showing the setup situation and possible touch points in the **Simulation** workspace by means of a 3D model.

Related topics

- Touch-probe functions in the **Setup** application
Further information: "Touch Probe Functions in the Manual Operating Mode (#17 / #1-05-1)", Page 289
- Generating an STL file of a workpiece
Further information: User's Manual for Programming and Testing
- **Simulation** workspace
Further information: User's Manual for Programming and Testing
- Setting fixtures with graphical support (#140 / #5-03-2)
Further information: "Integrating fixtures into collision monitoring (#140 / #5-03-2)", Page 216

Requirements

- Software option Touch-probe functions (#17 / #1-05-1)

 If you are using a HEIDENHAIN touch probe with EnDat interface, then the software option Touch Probe Functions (#17 / #1-05-1) is automatically enabled.

- Graphically supported setup software option (#159 / #1-07-1)
- Touch probe properly defined in the tool management:
 - Spherical radius in the **R2** column
Further information: "Tool data for touch probes (#17 / #1-05-1)", Page 161
- Workpiece touch probe calibrated
Further information: "Calibrating the workpiece touch probe", Page 304
- 3D model of the workpiece as STL file
 The STL file may contain up to 300,000 triangles. The more the 3D model corresponds to the actual workpiece, the higher the possible workpiece setup accuracy.
 If required, optimize the 3D model with the **3D mesh** (#152 / #1-04-1) function.
Further information: User's Manual for Programming and Testing

Description of function

The **Set up the workpiece** function is available as a touch probe function in the **Setup** application of the **Manual** operating mode.

The scope of the **Set up the workpiece** function depends on the Extended Functions Group 1 (#8 / #1-01-1) and Extended Functions Group 2 (#9 / #4-01-1) software options as follows:

- Both software options enabled:
You can tilt before setting up and incline the tool while setting up in order to probe even complex workpieces (e.g., shaped parts).
- Only Extended Functions Group 1 (#8 / #1-01-1) enabled:
You can tilt before setting up. The working plane must be consistent. If you move the rotary axes between the touch points, the control will display an error message.



If the current coordinates of the rotary axes and the defined tilt angles (**3D ROT** window) match, the working plane is consistent.


- None of the two software options is enabled:
You cannot tilt before setting up. If you move the rotary axes between the touch points, the control will display an error message.

Further information: "Tilting the working plane (#8 / #1-01-1)", Page 199

Further information: User's Manual for Programming and Testing

Extension of the Simulation workspace

In addition to the **Probing function** workspace, the **Simulation** workspace offers graphical support for setting up the workpiece.



The **Set up the workpiece** function with the **Simulation** workspace open

When the **Set up the workpiece** function is active, the **Simulation** workspace displays the content below:

- Current position of workpiece as viewed by the control
- Probed points on the workpiece
- Possible direction of probing by means of an arrow:
 - No arrow
Probing is not possible. The workpiece touch probe is too distant from the workpiece or the workpiece touch probe is positioned within the workpiece, as seen by the control.

In this case you can correct the position of the 3D model in the simulation, if required.










- Red arrow
Probing in the direction of the arrow is not possible.

i Probing on edges, corners or heavily curved workpiece areas fails to deliver precise measuring results. This is why the control blocks probing in these areas.

- Yellow arrow
Probing in the direction of the arrow is possible to a limited extent. The probing is performed in a deselected direction or could cause collisions.
- Green arrow
Probing in the direction of the arrow is possible.

Icons and buttons

The **Set up the workpiece** function contains the following icons and buttons:

Icon or button	Meaning
	<p>Open the Change the preset window</p> <p>You can select the workpiece preset and the pallet preset and edit values if required.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p> After the first point has been probed, the control dims the icon.</p> </div>
XY Clamping plane	<p>Use this selection menu to define the probing mode. Depending on the probing mode, the control displays the respective axis directions and spatial angles.</p> <p>Further information: "Probing mode", Page 313</p>
<input type="text" value="1_plate_blk.stl"/>	File name of 3D model
	<p>Shifts the position of the virtual workpiece by 10 mm or 10° in the negative axis direction</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p> Shifts the workpiece in mm in a linear axis and in degrees in a rotary axis.</p> </div>
	Shifts the position of the virtual workpiece by 1 mm or 1° in the negative axis direction
	<ul style="list-style-type: none"> ■ Enter the position of the virtual workpiece directly ■ Value and estimated accuracy of the value after the probing
	Shifts the position of the virtual workpiece by 1 mm or 1° in the positive axis direction
	Shifts the position of the virtual workpiece by 10 mm or 10° in the positive axis direction
	<p>Status of direction</p> <p>The control displays the following colors:</p> <ul style="list-style-type: none"> ■ Gray The axis direction is deselected in this setup process and is not considered. ■ White No touch points have been determined yet. ■ Red The control cannot locate the workpiece position in this axis direction. ■ Yellow The position of the workpiece in this axis already contains information. The information is not meaningful yet. ■ Green The control can locate the workpiece position in this axis direction.
Compensate the active preset	The control saves the determined values in the active row of the preset table.

Probing mode

The following modes for probing the workpiece are available to you:

- **XY Clamping plane**
X, Y and Z axis directions as well as spatial angle **SPC**
- **XZ Clamping plane**
X, Y and Z axis directions as well as spatial angle **SPB**
- **YZ Clamping plane**
X, Y and Z axis directions as well as spatial angle **SPA**
- **6D**
X, Y and Z axis directions as well as spatial angles **SPA, SPB** and **SPC**

Depending on the probing mode, the control displays the respective axis directions and spatial angles. In the **XY**, **XZ** and **YZ** clamping planes a toggle switch allows you to deselect the respective tool axis and spatial angle, if required. The control will not take deselected axis directions into account in the setup process and positions the workpiece by considering the remaining axis directions only.

HEIDENHAIN recommends executing the setup process as follows:

- 1 Pre-position a 3D model in the machine's working space
At this point in time, the control does not know the precise position of the workpiece, but of the workpiece touch probe. Pre-positioning the 3D model in accordance with the position of the workpiece touch probe produces values close to the position of the real workpiece.
- 2 Set the first touch points in the **X**, **Y** and **Z** axis directions
If the control can determine the position in one axis direction, it will change the status of that axis to green.
- 3 Determine the spatial angle by setting further touch points
To achieve maximum accuracy when probing the spatial angles, the touch points should be as far apart from one another as possible.
- 4 Increase the accuracies by additional check points
Additional check points at the end of the measuring process improve the matching accuracy and minimize the misalignment between the 3D model and the real workpiece. Perform as many probing processes as necessary until the control displays the desired accuracy beneath the current value.

The error estimate diagram shows for each touch point the approximate distance of the 3D model from the real workpiece.

Further information: "Error estimate diagram", Page 314

Error estimate diagram


Every additional touch point gradually restricts the possible positioning of the workpiece and puts the 3D model closer to the actual position in the machine.

The error estimate diagram shows the estimated value of the distance of the 3D model from the real workpiece. For this purpose, the control considers not only the touch points, but the whole workpiece.

When the error estimate diagram shows green circles and the desired accuracy, the setup process will be complete.

The following factors influence the accuracy that can be achieved when measuring workpieces:

- Accuracy of workpiece touch probe
- Accuracy of the machine kinematic configuration
- Deviations of the 3D model from the real workpiece
- Condition of the actual workpiece (e.g., unmachined areas)



Error estimate diagram in the **Set up the workpiece** function

The error estimate diagram of the **Set up the workpiece** function shows the following information:

- **Mean deviation (RMS)**
This area shows the average distance of the real workpiece from the 3D model in mm.
- **Error estimate [mm]**
This axis shows the course of the error estimate based on the individual touch points. The control shows red circles until it can determine all axis directions. From then on the control will show green circles.
- **No. of probe point**
This axis shows the numbers of the individual probing points.


16.3.1 Setting up the workpiece


Use the **Set up the workpiece** function to set the preset:

- ▶ Affix a real workpiece in the machine's working space




- ▶ Select the **Manual** operating mode
- ▶ Insert the workpiece touch probe
- ▶ Manually position the workpiece touch probe above the workpiece at a notable point (e.g., a corner)


 This step makes the subsequent steps easier.



- ▶ Select the **Setup** application
- ▶ Select **Set up the workpiece**
- ▶ The control opens the **Set up the workpiece** menu.
- ▶ Select a 3D model matching the real workpiece
- ▶ Select **Open**
- ▶ The control opens the selected 3D model in the simulation.
- ▶ If necessary, open the **Change the preset** window
- ▶ Select a new preset if necessary
- ▶ Select the **Apply** function if necessary
- ▶ Pre-position the 3D model by using the buttons for the individual axis directions within the virtual working space of the machine

 For pre-positioning the workpiece, use the workpiece touch probe as a point of reference. Even during the setup process, the shift functions are available for correcting the fixture position manually. Then, probe a new point.

- ▶ Specify the probing mode (e.g., **XY Clamping plane**)
- ▶ Position the workpiece touch probe until the control shows a green arrow pointing downward

 As the 3D model is only pre-positioned at this point in time, the green arrow cannot provide any reliable information about whether the desired surface of the workpiece will actually be probed. Check if the workpiece position in the simulation and in the machine match each other and if probing in the direction of the arrow is possible on the machine. Do not probe directly near edges, chamfers and roundings.



- ▶ Press the **NC Start** key
- ▶ The control probes in the direction of the arrow.
- ▶ The control displays the status of the **Z** axis in green and shifts the workpiece to the probed position. The control marks the probed position with a point in the simulation.

- ▶ Repeat this process in axis directions **X+** and **Y+**
- ▶ The control changes the status of the axes to green.
- ▶ Probe another point in axis direction **Y+** for the basic rotation
- ▶ The control changes the status of the **SPC** spatial angle to green.
- ▶ Probe the check point in axis direction **X-**
- ▶ Select **Compensate the active preset**
- ▶ The control saves the determined values in the active row of the preset table.
- ▶ Exit the **Set up the workpiece** function

Compensate the active preset



Notes

NOTICE

Danger of collision!

To probe the clamping situation in the machine exactly, the workpiece touch probe must be properly calibrated and the value **R2** properly defined in the tool management. Otherwise, incorrect tool data of the workpiece touch probe may cause inaccurate measurement and possibly a collision.

- ▶ Calibrate the workpiece touch probe at regular intervals
- ▶ Enter parameter **R2** in the tool management

- The control cannot identify modeling differences between the 3D model and the workpiece.
- Collisions might be more easily detected, if a tool carrier is assigned to the workpiece touch probe.
- HEIDENHAIN recommends probing check points for one axis direction on both sides of the workpiece. As a result, the control will correct the position of the 3D model in the simulation uniformly.

16.4 Measuring the tool by scratching

Application

Not all machines are equipped with a tool touch probe for measuring a tool. The **Tool measured** touch probe function enables determining the tool dimensions by scratching a workpiece.

Related topics

- Touch probe functions in the **Setup** application
Further information: "Touch Probe Functions in the Manual Operating Mode (#17 / #1-05-1)", Page 289
- Measuring the tool automatically with cycles
Further information: User's Manual for Measuring Cycles for Workpieces and Tools

Requirement

- Software option Touch-probe functions (#17 / #1-05-1)



If you are using a HEIDENHAIN touch probe with EnDat interface, then the software option Touch Probe Functions (#17 / #1-05-1) is automatically enabled.

Description of function

You do not use a 3D touch probe for scratching, but the tool to be measured. In the scratching process, approach the tool carefully to a workpiece surface until you can see a thin chip being removed. The handwheel allows obtaining a higher accuracy.

In the **X** or **Y** probing directions, the tool radius can be determined. When selecting probing direction **Z**, the tool length is measured.

Buttons in the Measure the tool function

The control offers the following options for writing the measured radius or length values into the tool table:

Button	Meaning
Write basic values	The control transfers the values into columns R or L . The control resets existing delta values in columns DR or DL .
Write delta values	The control enters the delta values in columns DR or DL .

Further information: "Tool tables", Page 362

16.4.1 Tool measurement by scratching

The dimensions of an end mill can be determined by using the **Tool measured** function as follows:



- ▶ Select the **Manual** operating mode
- ▶ Set the workpiece preset if required



Position the workpiece preset on the surfaces to be scratched in order to obtain a clear reference.

- ▶ Insert the tool to be measured
- ▶ Define the speed if required
- ▶ Start the tool spindle
- ▶ Select the **Setup** application
- ▶ Select the **Measure tool** probing function




- ▶ Scratch the workpiece in the desired axis direction (e.g., **X+**)



- ▶ Select the associated probing direction **X+**



- ▶ Select **actual position capture**
- > The control transfers the actual X axis position into the **Actual value** column.
- > The control shows the measurement results.
- ▶ Enter a **Nominal value** (e.g., **0**)
- ▶ Select **Write basic values**
- > The control transfers the value into column **R** of the tool table.
- > The control resets the existing delta value in the **DR** column.



When selecting **Write delta values**, the control will enter only one delta value in column **DR**.



- ▶ Scratch another axis direction if required (e.g., **Z-**)



- ▶ Select **Exit probing**
- > The control closes the **Measure tool** probing function.

16.5 Suppressing touch probe monitoring

Application

If you move a workpiece touch probe too close to the workpiece, you can accidentally deflect the workpiece touch probe. You cannot retract a deflected workpiece touch probe in the monitored state. You can retract a deflected workpiece touch probe by suppressing touch probe monitoring.

Description of function

If the control does not receive a stable signal from the probe, the button displays **Suppress touch probe monitoring**.

As long as touch-probe monitoring is switched off, the control displays the error message **The touch probe monitor is deactivated for 30 seconds**. This error message remains active only for 30 seconds.

16.5.1 Deactivating touch probe monitoring

To deactivate touch probe monitoring:



- ▶ Select the **Manual** operating mode
- ▶ Select **Suppress touch probe monitoring**
- ▶ The control disables touch-probe monitoring for 30 seconds.
- ▶ If required, move the touch probe so that the control receives a stable signal from it.

Notes

NOTICE

Danger of collision!

While touch-probe monitoring is deactivated, the control will not perform collision checking. Thus, you must ensure that the touch probe can be positioned safely. There is a risk of collision if you choose the wrong direction of traverse!

- ▶ Carefully move the axes in the **Manual** operating mode


If the touch probe sends a stable signal within the 30 seconds, then touch-probe monitoring reactivates itself automatically and the error message is cleared.

16.6 Comparison of offset and 3D basic rotation

The following example shows how the two functions differ.

Offset

Initial state



Position display:


- Actual position
- **B** = 0
- **C** = 0

Preset table:

- **SPB** = 0
- **B_OFFS** = -30
- **C_OFFS** = +0

3D basic rotation

Initial state




Position display:

- Actual position
- **B** = 0
- **C** = 0


Preset table:

- **SPB** = -30
- **B_OFFS** = +0
- **C_OFFS** = +0

Movement in +Z without tilting




Movement in +Z without tilting



Offset

Movement in +Z with tilting

PLANE SPATIAL with **SPA+0 SPB+0 SPC+0**




> The orientation **is not correct!**

3D basic rotation

Movement in +Z with tilting

PLANE SPATIAL with **SPA+0 SPB+0 SPC+0**



> The orientation is correct!
> The next machining step will be **correct.**



HEIDENHAIN recommends using 3D basic rotation because of its greater flexibility.

17

Program Run

17.1 The Program Run operating mode

17.1.1 Fundamentals

Application

In the **Program Run** operating mode you produce workpieces by having the control execute NC programs either one block at a time or in full sequence.

You also execute pallet tables in this operating mode.

Related topics

- Executing individual NC blocks in the **MDI** application
Further information: "The MDI Application ", Page 279
- Creating NC programs
Further information: User's Manual for Programming and Testing
- Pallet tables
Further information: User's Manual for Programming and Testing

NOTICE

Caution: Danger due to manipulated data!

If you execute NC programs directly from a network drive or a USB device, you have no control over whether the NC program has been changed or manipulated. In addition, the network speed can slow down the execution of the NC program. Undesirable machine movements or collisions may result.

- ▶ Copy the NC program and all called files to the **TNC:** drive

NOTICE

Danger of collision!

When you edit NC programs outside the **Program** workspace, you have no control over whether the control will identify the changes. Undesirable machine movements or collisions may result.

- ▶ Edit NC programs in the **Program** workspace only

Description of function



The following information also applies to pallet tables and job lists.

When you select a new NC program or when an NC program has been completely executed, the cursor is at the beginning of the program.

If you want to start machining at a different NC block, you first need to select the desired NC block by using the **Block scan** function.

Further information: "Block scan for mid-program startup", Page 335

By default, the control runs NC programs in Full Sequence mode after the **NC Start** key has been pressed. In this mode, the control runs an NC program continuously up to its end, or up to a manual or programmed interruption.

In **Single Block** mode you execute each NC block separately by pressing the **NC Start** key.

The control shows the status of the machining process with the **Control-in-operation** icon in the status overview.

Further information: "Status overview on the TNC bar", Page 103

The **Program Run** operating mode provides the following workspaces:

- **Positions**

Further information: "The Positions workspace", Page 97

- **Program**

Further information: User's Manual for Programming and Testing

- **Simulation**

Further information: User's Manual for Programming and Testing

- **Status**



Further information: "The Status workspace", Page 105

When opening a pallet table, the control displays the **Job list** workspace. You cannot modify this workspace.

Further information: User's Manual for Programming and Testing

Icons and buttons

The **Program Run** operating mode contains the following icons and buttons:

Icon or button	Meaning
	<p>Open file</p> <p>Open file allows you to open a file, such as an NC program. When you open a file, the control closes the file that was already open.</p>
	<p>Execution cursor</p> <p>The execution cursor shows which NC block is currently being executed or is marked for execution.</p>
Single Block	<p>If this toggle switch is active, then you run each NC block separately with the NC start key.</p> <p>If Single Block mode is selected, then the operating mode's icon in the control bar changes.</p>
Q info	<p>The control opens the Q parameter list window, where you can see and edit the current values and descriptions of the variables.</p> <p>Further information: User's Manual for Programming and Testing</p>
Compensation tables	<p>The control opens a selection menu with the following tables:</p> <ul style="list-style-type: none"> ■ D ■ T-CS ■ WPL-CS <p>Further information: "Compensation during program run", Page 344</p>
GOTO Cursor	<p>The control marks the table row currently selected for execution.</p> <p>Active only if a pallet table is open (option 22)</p> <p>Further information: User's Manual for Programming and Testing</p>
F limited	<p>Use this option to activate or deactivate the feed-rate limit for functional safety (FS).</p> <p>Only on machines with functional safety (FS).</p> <p>Further information: "Feed-rate limiting with functional safety (FS)", Page 432</p>
AFC	<p>Use this option to activate or deactivate Adaptive Feed Control (AFC, option 45).</p> <p>Further information: "The AFC toggle switch in the Program Run operating mode", Page 241</p>
AFC settings	<p>The control opens a selection menu with the following tables for AFC (option 45):</p> <ul style="list-style-type: none"> ■ AFC.TAB for AFC basic settings ■ AFC.DEP settings file for teach-in cuts of the active NC program ■ AFC2.DEP log file of the active NC program <p>Further information: "Adaptive feed control (AFC) (#45 / #2-31-1)", Page 236</p>
ACC	<p>If this toggle switch is active, the control activates Active Chatter Control (ACC, option 145).</p> <p>Further information: "Active Chatter Control (ACC) (#145 / #2-30-1)", Page 245</p>
F LIMIT	<p>Use this function to activate a feed-rate limit and define its value.</p> <p>Further information: "Feed rate limit F LIMIT", Page 328</p>

Icon or button	Meaning
Breakpoints	<p>If you select this button, the control opens the Breakpoints window with the following options for selection:</p> <ul style="list-style-type: none"> ■ Permit start with override If the toggle switch is active, then you can continue the NC program after a conditional stop with the Override Controller. Further information: "The Program run options window", Page 418 ■ Feed F LIMIT Use this function to activate a feed-rate limit and define its value. Further information: "Feed rate limit F LIMIT", Page 328 ■ Perform conditional stop The control provides the following breakpoints: <ul style="list-style-type: none"> ■ Before switch to rapid traverse ■ Before switch to feed rate ■ Between two rapid traverses ■ Before tool call ■ Before tilting the working plane ■ Before cycle call ■ In cycle call Further information: "Breakpoints", Page 419 ■ Skip block If the toggle switch is active, then the control does not execute any NC blocks dimmed with the / character. If the toggle switch is active, then the dims the NC blocks to be skipped. Further information: User's Manual for Programming and Testing ■ Pause at M1 If the toggle switch is active, then the control stops the execution at every NC block with M1. If the toggle switch is inactive, then the control dims the M1 syntax element. Further information: User's Manual for Programming and Testing
Skip block	<p>If the toggle switch is active, then the control does not execute any NC blocks dimmed with the / character. If the toggle switch is active, then the dims the NC blocks to be skipped. Further information: User's Manual for Programming and Testing</p>
Pause at M1	<p>If the toggle switch is active, then the control stops the execution at every NC block with M1. If the toggle switch is inactive, then the control dims the M1 syntax element. Further information: User's Manual for Programming and Testing</p>
GOTO block number	<p>Mark an NC block to be run without considering any previous NC blocks Further information: User's Manual for Programming and Testing</p>
Manual traverse	<p>While a program run is interrupted, you can move the axes manually. If Manual traverse is active, then the operating mode's icon in the control bar changes. Further information: "Manual traverse during an interruption", Page 334</p>
Edit	<p>If this toggle switch is active, then you can edit the pallet table. Active only if a pallet table is open Further information: User's Manual for Programming and Testing</p>

Icon or button	Meaning
3D ROT	While a program run is interrupted, you can move the axes manually in the tilted working plane (option 8). Further information: "Manual traverse during an interruption", Page 334
Approach position	Return to contour after manual traverse of the machine axes during an interruption Further information: "Returning to the contour", Page 343
Block scan	The Block scan function allows you to start program run at any desired NC block. The control takes the preceding parts of the NC program up to this NC block into account mathematically; for example, whether the spindle was switched on with M3 . Further information: "Block scan for mid-program startup", Page 335
Open in the editor	The control opens the active NC program in the Editor operating mode, even if it is a called NC program. Active only if an NC program is open Further information: User's Manual for Programming and Testing
Internal stop	If an NC program is interrupted due to an error or a stop, the control activates this button. Use this button to abort program run.
Reset program	If you select Internal stop , the control activates this button. The control places the cursor back to the beginning of the program and resets any modally active program information as well as the program run-time.

Feed rate limit F LIMIT

The **F LIMIT** button allows you to reduce the feed rate for all operating modes. The reduction applies to all rapid traverse and feed rate movements. The value you have entered remains active across power cycles.

The **F LIMIT** button is available in the **MDI** application and in **Editor** operating mode. When you select the **F LIMIT** button in the function bar, the control will open the **Feed rate F LIMIT** window.

If a feed rate limit is active, the control highlights the **F LIMIT** button in color and displays the defined value. In the **Positions** and **Status** workspaces, the feed rate is displayed in orange.

Further information: "Statusanzeigen", Page

You deactivate the feed rate limit by entering a value of 0 in the **Feed rate F LIMIT** window.

Interrupting, stopping or canceling program run

There are several ways to stop a program run:

- Interrupt program run (e.g., with the miscellaneous function **M0**)
- Stop the program run (e.g., with the **NC Stop** key)
- Cancel the program run (e.g., with the **NC stop** key and the **Internal stop** button)
- Terminate program run (e.g., with the miscellaneous functions **M2** or **M30**)

Upon major errors, the control automatically aborts program run (e.g., during a cycle call with stationary spindle).

Further information: "Message menu on the information bar", Page 274

If you run your NC program in **Single Block** mode or in the **MDI** application, the control will switch to the interrupted state after the execution of each NC block.

The control shows the current program run status with the **Control-in-operation** icon.

Further information: "Status overview on the TNC bar", Page 103

Below are some of the functions you can execute in an interrupted or canceled state:

- Selecting an operating mode
- Manual traverse of axes
- Checking Q parameters and changing these if necessary using the **Q INFO** function
- Changing the setting for the optional programmed interruption with **M1**
- Changing the setting for the programmed skipping of NC blocks with **/**

NOTICE

Danger of collision!

Certain manual interactions may lead to the control losing the modally effective program information (i.e., the contextual reference). Loss of this contextual reference may result in unexpected and undesirable movements. There is a risk of collision during the subsequent machining operation!

- ▶ Do not perform the following interactions:
 - Cursor movement to another NC block
 - The jump command **GOTO** to another NC block
 - Editing an NC block
 - Modifying the values of variables by using the **Q parameter list** window
 - Switching the operating modes
- ▶ Restore the contextual reference by repeating the required NC blocks

Programmed interruptions

You can set interruptions directly in the NC program. The control interrupts the program run in the NC block containing one of the following inputs:

- Programmed stop **STOP** (with and without miscellaneous function)
- Programmed stop **M0**
- Conditional stop **M1**

Resuming program run

After stopping the program with the **NC Stop** key or a programmed interruption, you can resume program run by pressing the **NC Start** key.

After canceling the program run with an **Internal stop**, you must start the program run at the beginning of the NC program or use the **Block scan** function.

After an interruption of the program run within a subprogram or program section repeat, you need to use the **Block scan** function for mid-program startup.

Further information: "Block scan for mid-program startup", Page 335

Modally effective program information

The control saves the following data during a program interruption:

- The last tool that was called
- Current coordinate transformations (e.g., datum shift, rotation, mirroring)
- The coordinates of the circle center that was last defined

The control uses the stored data for returning the tool to the contour (**Approach position** button).

Further information: "Returning to the contour", Page 343



The saved data remains active until it is reset (e.g., by selecting a program).

Notes

NOTICE
<p>Danger of collision!</p> <p>Program cancellation, manual intervention, forgotten resetting of NC functions or transformations can lead to the control performing unexpected or undesirable movements. This can lead to workpiece damage or collision.</p> <ul style="list-style-type: none"> ▶ Rescind all programmed NC functions and transformations within the NC program ▶ Run a simulation before executing an NC program ▶ Check both the general as well as the additional status display for NC functions and transformations, such as an active basic rotation, before executing an NC program ▶ Carefully verify the NC program in Single Block mode

- In the **Program Run** operating mode, the control marks active files with the status **M**, such as a selected NC program or tables. If you open such a file in another operating mode, the controls shows the status on the tab of the application bar.
- When positioning an axis, the control checks whether the defined speed has been reached. The control does not check the speed in positioning blocks where **FMAX** is the feed rate.
- You can adjust the feed rate and the spindle speed during program run with the potentiometers.
- If you modify the workpiece preset during a program run interruption, you must re-select the NC block to resume.

Further information: "Block scan for mid-program startup", Page 335
- HEIDENHAIN recommends switching the spindle on with **M3** or **M4** after every tool call. That way you avoid problems during program run, such as when restarting after an interruption.
- The execution cursor is always displayed in the foreground. The execution cursor may cover or hide other icons.

Definitions

Abbreviation	Definition
GPS (global program settings)	Global program settings
ACC (active chatter control)	Active Chatter Control

17.1.2 Navigation path in the Program workspace

Application

If you execute an NC program or a pallet table or if you test it in the opened **Simulation** workspace, the control will display a navigation path in the file information bar of the **Program** workspace.

The control displays the names of all the NC programs used in the navigation path and opens the contents of all NC programs in the workspace. This makes it easier to keep an overview of the execution when calling programs and allows navigating between the NC programs when the program run is interrupted.

Related topics

- Program call
Further information: User's Manual for Programming and Testing
- **Program** workspace
Further information: User's Manual for Programming and Testing
- **Simulation** workspace
Further information: User's Manual for Programming and Testing
- Interrupted program run
Further information: "Interrupting, stopping or canceling program run", Page 329

Requirement

- The **Program** and **Simulation** workspaces are both opened
In the **Editor** operating mode you need both workspaces to use the function.


Description of function

The control shows the name of the NC program as a path element in the file information bar. As soon as the control calls a different NC program, the control adds a new path element with the name of the called NC program to the bar.

Additionally, the control displays the contents of the called NC program in a new pane in the **Program** workspace. The control displays as many NC programs side by side as the size of the workspace permits. If necessary, newly opened NC programs will cover previously opened NC programs. The control displays the covered NC programs in a narrow band at the left edge of the workspace.

When execution is interrupted, you can navigate between the NC programs. When you select the path element of an NC program, the control opens the content.

When you select the last path element, the control automatically marks the active NC block with the execution cursor. When you press the **NC Start** key, the control resumes execution of the NC program from this position.



Called NC programs in the **Program** workspace in the **Program Run** operating mode

Depiction of path elements

The control displays the path elements of the navigation path as follows:

Format	Meaning
Black frame	The NC program is visible in the Program workspace and is not covered by other NC programs.
Highlighted in green	The NC program at the current cursor position is active or is considered for program run. If, for example, the cursor is positioned in the called NC program, the calling NC program will be considered for program run.
Highlighted in gray	The NC program is active for execution but will not be considered for program run at the current cursor position. If, for example, you stop the execution and navigate into the calling NC program, the control displays the path element of the called NC program in gray.

Note

In the **Program Run** operating mode, the **Structure** column contains all structuring items, even those of the called NC programs. The control indents the structure of the called NC programs.

The structure items allow you to navigate into every NC program. The control displays the associated NC programs in the **Program** workspace. The navigation path always remains at the current point of execution.

Further information: User's Manual for Programming and Testing

17.1.3 Manual traverse during an interruption

Application

During a program run interruption you can move the machine axes manually.

The **Tilt the working plane (3D ROT)** window allows selecting the reference system in which you move the axes (#8 / #1-01-1).

Related topics





- Manual traverse of machine axes
Further information: "Moving the machine axes", Page 135
- Tilting the working plane manually (#8 / #1-01-1)
Further information: User's Manual for Programming and Testing

Description of function

When you select **Manual traverse**, you can move the axes with the axis keys of the control.

Further information: "Using axis keys to move the axes ", Page 136

In the **Tilt the working plane (3D ROT)** window, you can select the following functions:

Icon	Function	Meaning
	M-CS machine	Traversing in the machine coordinate system M-CS Further information: "Machine coordinate system M-CS", Page 182
	W-CS workpiece	Traversing in the workpiece coordinate system W-CS Further information: "Workpiece coordinate system W-CS", Page 186
	WPL-CS working plane	Traversing in the working plane coordinate system WPL-CS Further information: "Working plane coordinate system WPL-CS", Page 187
	T-CS tool	Traversing in the tool coordinate system T-CS Further information: "Working plane coordinate system WPL-CS", Page 187

When you select one of the functions, the control will display the associated icon in the **Positions** workspace. The control additionally shows the active coordinate system on the **3D ROT** button.

If **Manual traverse** is active, then the operating mode's icon in the control bar changes.

Notes

NOTICE

Danger of collision!

During a program interruption, you can move the axes manually (e.g., in order to retract from a hole when the working plane is tilted). Selecting an incorrect **3D ROT** setting or moving the tool in the wrong direction involves risk of collision!

- ▶ It is better to use the **T-CS** function
- ▶ Check the direction of movement
- ▶ Move at slow feed rate

- On some machines, you may have to press the **NC Start** key while **Manual traverse** is active in order to enable the axis keys.
Refer to your machine manual.

17.1.4 Block scan for mid-program startup

Application

The **BLOCK SCAN** function allows you to start an NC program at any desired NC block. The control factors workpiece machining up to this NC block into the calculations. For example, the control will switch on the spindle before the start.

Related topics

- Creating NC programs
Further information: User's Manual for Programming and Testing
- Pallet tables and job lists
Further information: User's Manual for Programming and Testing

Requirement

- The function must be enabled by your machine manufacturer.
The **Block scan** function must be enabled and configured by your machine manufacturer.

Description of function

If the NC program was interrupted under the following conditions, the control saves the interruption point:

- The **Internal stop** button
- Emergency stop
- Power failure


If, while restarting, the control finds a saved point of interruption, then it outputs a message. You can then execute a block scan directly to the point of interruption. The control displays the message when you switch to **Program Run** operating mode for the first time.

You have the following options for a block scan:

- Block scan in the main program, with repetitions if necessary
Further information: "Performing a single-level block scan", Page 338
- Multi-level block scan in subprograms and touch probe cycles
Further information: "Performing a multi-level block scan", Page 339
- Block scan in a point table
Further information: "Block scan in point tables", Page 340
- Block scan in pallet programs
Further information: "Block scan in pallet tables", Page 341

At the start of the block scan, the control resets the data, as with a selection of a new NC program. During the block scan you can activate or deactivate **Single Block** mode.

The Block scan window



The **Block scan** window with saved interruption point and open **Point table** area

The **Block scan** window provides the following data:

Row	Meaning
Pallet number	Row number in the pallet table
Program	Path of the active NC program
Block number	Number of the NC block at which program run should start Use the search icon to select the NC block in the NC program.
Repetitions	Number of the repetition for mid-program startup if the desired NC block is located within a program-section repeat.
Last pallet number	Pallet number that is active at the time of interruption Select the interruption point by using the Select last button.
Last program	Path of the NC program that is active at the time of interruption Select the interruption point by using the Select last button.
Last block	Number of the NC block that was active at the time of interruption Select the interruption point by using the Select last button.
Point file	Path of the point table In the Point table area
Point number	Row in the point table In the Point table area

Performing a single-level block scan

To start in an NC program by using a single-level block scan:



- ▶ Select the **Program Run** operating mode

Block scan

- ▶ Select **Block scan**
- > The control opens the **Block scan** window. The fields **Program**, **Block number** and **Repetitions** contain the current values.
- ▶ Enter the **Program** as needed
- ▶ Enter the **Block number**
- ▶ Enter the **Repetitions** as needed
- ▶ If required, use **Select last** to start at a saved interruption point

Select last



- ▶ Press the **NC Start** key
- > The control starts the block scan and calculates up to the entered NC block.
- > If you have changed the machine status, the control displays the **Restore machine status** window.



- ▶ Press the **NC Start** key
- > The control restores the machine status (e.g., **TOOL CALL** or M functions).
- > If you have changed the axis positions, the control displays the **Axis sequence for return to contour:** window.



- ▶ Press the **NC Start** key
- > Using the displayed positioning logic, the control moves to the required positions.



You can also position the axes individually in a self-selected sequence.

Further information: "Positioning the axes in a self-selected sequence", Page 344



- ▶ Press the **NC Start** key
- > The control resumes execution of the NC program.

Performing a multi-level block scan

If you, for example, start in a subprogram that is called several times by the main program, then use the multi-level block scan. For this, you first go to the desired subprogram call and then continue the block scan. The same procedure is used for called NC programs.

To start in an NC program by using a multi-level block scan:

- ▶ Select the **Program Run** operating mode
 - ▶ Select **Block scan**
 - ▶ The control opens the **Block scan** window. The fields **Program**, **Block number** and **Repetitions** contain the current values.
 - ▶ Perform a block scan to the first start-up point:
 - ▶ **Further information:** "Performing a single-level block scan", Page 338
 - ▶ Activate the **Single Block** toggle switch as needed
 - ▶ Press the **NC Start** key to execute individual NC blocks as needed
 - ▶ Select **Continue block scan**
 - ▶ Define the NC block for mid-program startup
 - ▶ Press the **NC Start** key
 - ▶ The control starts the block scan and calculates up to the entered NC block.
 - ▶ If you have changed the machine status, the control displays the **Restore machine status** window.
 - ▶ Press the **NC Start** key
 - ▶ The control restores the machine status (e.g., **TOOL CALL** or M functions).
 - ▶ If you have changed the axis positions, the control displays the **Axis sequence for return to contour:** window.
 - ▶ Press the **NC Start** key
 - ▶ Using the displayed positioning logic, the control moves to the required positions.
- i** You can also position the axes individually in a self-selected sequence.

Further information: "Positioning the axes in a self-selected sequence", Page 344
- ▶ Select **Continue block scan** again as needed
 - ▶ Repeat the steps
 - ▶ Press the **NC Start** key
 - ▶ The control resumes execution of the NC program.

Block scan in point tables

To start in a point table:



- ▶ Select the **Program Run** operating mode

Block scan

- ▶ Select **Block scan**
- The control opens the **Block scan** window. The fields **Program**, **Block number** and **Repetitions** contain the current values.

- ▶ Select **Point table**

- The control opens the **Point table** area.

- ▶ **Point file:** Enter the path of the point table

- ▶ **Point number:** Select the row number of the point table for mid-program startup



- ▶ Press the **NC Start** key

- The control starts the block scan and calculates up to the entered NC block.

- If you have changed the machine status, the control displays the **Restore machine status** window.



- ▶ Press the **NC Start** key

- The control restores the machine status (e.g., **TOOL CALL** or M functions).

- If you have changed the axis positions, the control displays the **Axis sequence for return to contour:** window.



- ▶ Press the **NC Start** key

- Using the displayed positioning logic, the control moves to the required positions.



You can also position the axes individually in a self-selected sequence.

Further information: "Positioning the axes in a self-selected sequence", Page 344



If you would like to use the block scan function to start in a point pattern, then use the same procedure. Define the desired point for mid-program startup in the **Point number** field. The first point in the point pattern has the number 0.

Further information: User's Manual for Machining Cycles

Block scan in pallet tables


To start in a pallet table:



- ▶ Select the **Program Run** operating mode



- ▶ Select **Block scan**
- The control opens the **Block scan** window.
- ▶ **Pallet number**: Enter the row number of the pallet table
- ▶ Enter the **Program** as needed
- ▶ Enter the **Block number**
- ▶ Enter the **Repetitions** as needed
- ▶ If required, use **Select last** to start at a saved interruption point



- ▶ Press the **NC Start** key
- The control starts the block scan and calculates up to the entered NC block.
- If you have changed the machine status, the control displays the **Restore machine status** window.



- ▶ Press the **NC Start** key
- The control restores the machine status (e.g., **TOOL CALL** or M functions).
- If you have changed the axis positions, the control displays the **Axis sequence for return to contour** window.



- ▶ Press the **NC Start** key
- Using the displayed positioning logic, the control moves to the required positions.



You can also position the axes individually in a self-selected sequence.

Further information: "Positioning the axes in a self-selected sequence", Page 344



If the program run of a pallet table has been canceled, the control will suggest the most recently selected NC block of the most recently executed NC program as a point of interruption.

Notes

NOTICE

Danger of collision!

If you select an NC block in program run using the **GOTO** function and then execute the NC program, the control ignores all previously programmed NC functions (e.g., transformations). This means that there is a risk of collision during subsequent traversing movements!

- ▶ Use **GOTO** only when programming and testing NC programs
- ▶ Only use **Block scan** when executing NC programs

NOTICE

Danger of collision!

The **Block scan** function skips over the programmed touch probe cycles. As a result, the result parameters contain no values or, possibly, incorrect values. If the subsequent machining operation uses these result parameters, then there is a risk of collision!

- ▶ Use the **Block scan** function in multiple steps

- The TNC7 basic can move up to four axes simultaneously. If an NC block commands movement of more than four axes, the control displays an error message. When the control reads such a NC block during the **Block scan**, it will also display an error message.
- The control only displays the dialogs required by the process in the pop-up window.
- If you use the block scan to start in a pallet table, the control will always execute the chosen row in the pallet table as a workpiece-oriented process. After the pallet table line selected in the **Block scan**, the control resumes machining according to the defined machining method.

Further information: User's Manual for Programming and Testing

- Even after an internal stop, the control shows the number of repetitions on the **LBL** tab of the **Status** workspace.

Further information: "LBL tab", Page 109

- The **Block scan** function must not be used in conjunction with the following functions:
 - Touch probe cycles **0**, **1**, **3**, and **4** during the block scan search phase
- HEIDENHAIN recommends switching the spindle on with **M3** or **M4** after every tool call. That way you avoid problems during program run, such as when restarting after an interruption.

17.1.5 Returning to the contour

Application

With the **RESTORE POSITION** function, the control moves the tool to the workpiece contour in the following situations:

- Return to the contour after the machine axes were moved during a program interruption that was not performed with the **INTERNAL STOP** function.
- Return to the contour after a block scan (e.g., after an interruption with **INTERNAL STOP**)
- Depending on the machine, if the position of an axis has changed after the control loop has been opened during a program interruption

Related topics


- Manual traverse during program run interruptions
Further information: "Manual traverse during an interruption", Page 334
- The **Block scan** function
Further information: "Block scan for mid-program startup", Page 335

Description of function

If you have selected the **Manual traverse** button, this button will change to **Approach position**.

When you select **Approach position**, the control will open the **Axis sequence for return to contour:** window.

The Axis sequence for return to contour: window



The **Axis sequence for return to contour:** window

In the **Axis sequence for return to contour:** window, the control displays all of the axes that are not yet located at the correct position for program execution.

The control suggests a positioning logic for the sequence of the traversing movements. If the tool is located in the tool axis below the position to be approached, then the control offers the tool axis as the first traverse direction. You can also traverse the axes in a self-selected sequence.



Further information: "Positioning the axes in a self-selected sequence", Page 344

If manual axes are included in the axes to be returned to the contour, then the control will not suggest a positioning logic. As soon as you have correctly positioned the manual axis, the control will suggest a positioning logic for the remaining axes.

Further information: "Positioning manual axes", Page 344


Positioning the axes in a self-selected sequence

To position the axes in a self-selected sequence:

-  
- ▶ Select **Approach position**
 - > The control displays the **Axis sequence for return to contour:** window and the axes to be positioned.
 - ▶ Select the desired axis (e.g., **X**)
 - ▶ Press the **NC Start** key
 - > The control moves the axis to the required position.
 - > When the axis has reached the correct position, the control shows a check mark for **Target**.
 - ▶ Position the remaining axes
 - > When all axes have reached their positions, the control closes the window.

Positioning manual axes

To position manual axes:

- 
- ▶ Select **Approach position**
 - > The control displays the **Axis sequence for return to contour:** window and the axes to be positioned.
 - ▶ Select the manual axis (e.g., **W**)
 - ▶ Position the manual axis to the value shown in the window
 - > When a manual axis with encoder has reached the position, the control automatically clears the value.
 - ▶ Select **Axis in position**
 - > The control saves the position.

Note

In the machine parameter **restoreAxis** (no. 200305), the machine manufacturer defines in which sequence of axes the control approaches the contour again.

Definition

Manual axis

Manual axes are non-driven axes that need to be positioned by the machine operator.

17.2 Compensation during program run

Application

During program run, you can open the selected compensation tables and the active datum table, and edit the values.

Related topics

- Using compensation tables
Further information: User's Manual for Programming and Testing
- Editing compensation tables in the NC program
Further information: User's Manual for Programming and Testing
- Contents and creation of compensation tables
Further information: User's Manual for Programming and Testing
- Contents and creation of a datum table
Further information: User's Manual for Programming and Testing
- Activating a datum table in the NC program
Further information: User's Manual for Programming and Testing

Description of function

The control opens the selected tables in the **Tables** operating mode.
The changed values do not take effect until the compensation or the datum has been activated again.

17.2.1 Opening tables from within the Program Run operating mode

To open the compensation tables from within the **Program Run** operating mode:

- Compensation tables

 - ▶ Select **Compensation tables**
 - The control displays a selection menu.
 - ▶ Select the desired table
 - **D**: Datum table
 - **T-CS**: Compensation table ***.tco**
 - **WPL-CS**: Compensation table ***.wco**
 - The control opens the selected table in the **Tables** operating mode.

Notes

NOTICE

Danger of collision!

The control does not consider the changes made to a datum table or compensation table until the values have been saved. You need to activate the datum or compensation value in the NC program again; otherwise, the control will continue using the previous values.

- ▶ Make sure to confirm any changes made to the table immediately (e.g., by pressing the **ENT** key)
- ▶ Activate the datum or compensation value in the NC program again
- ▶ Carefully test the NC program after changing the table values

- When opening a table in the **Program Run** operating mode, the control will display the **M** status in the table tab. This status means that this table is active for the program run.
- The clipboard allows you to transfer axis positions from the position display to the datum table.
Further information: "Status overview on the TNC bar", Page 103

17.3 The Retract application

Application

The **Retract** application allows you to disengage the tool from the workpiece after an interruption in power (e.g., retraction of a tap engaged in the workpiece).

You can also retract a tool when the working plane is tilted or retract an inclined tool.

Requirement

- This application must be enabled by your machine manufacturer.
The machine parameter **retractionMode** (no. 124101) allows the machine manufacturer to define whether the control will display the **Retract** toggle switch during start-up.

Description of function

The **Retract** application provides the following workspaces:

- **Retract**
Further information: "The Retract workspace", Page 347
- **Positions**
Further information: "The Positions workspace", Page 97
- **Status**
Further information: "The Status workspace", Page 105

The **Retract** application provides the following buttons in the function bar:

Button	Meaning
Retract	Retract the tool with the axis keys or the electronic handwheel
End retraction	Close the Retract application The control opens the End retraction? window and prompts you to answer a confirmation request.
Start values	Reset the entries in the A, B, C, and Thread pitch fields to their original values

You select the **Retract** application by using the **Retract** toggle switch if the following conditions apply during start-up:

- Power interrupted
- No control voltage for the relay
- The **Move to ref. point** application

If you have activated a feed rate limit before the power failure occurred, this feed rate limit will still be active. When you select the **Retract** button, the control will display a pop-up window: This window allows you to deactivate the feed rate limit.

Further information: "Feed rate limit F LIMIT", Page 328

The Retract workspace

The **Retract** workspace provides the following contents:

Row	Meaning
Traversing mode	Traverse mode for retraction: <ul style="list-style-type: none"> ■ Machine axes: Move in the machine coordinate system M-CS ■ Tilted system: Move in the working plane coordinate system WPL-CS (#8 / #1-01-1) ■ Tool axis: Move in the working plane coordinate system T-CS (#8 / #1-01-1) ■ Thread: Move in the tool coordinate system T-CS with compensating movements of the spindle Further information: "Reference systems", Page 180
Kinematics	Name of the active machine kinematics
A, B, C	Current position of the rotary axes Effective in the Tilted system traverse mode
Thread pitch	Thread pitch from the PITCH column of tool management Effective in the Thread traverse mode
Direct. of rotation	Direction of rotation of the thread-turning tool: <ul style="list-style-type: none"> ■ Right-hand thread ■ Left-hand thread Effective in the Thread traverse mode
Coordinate system for handwheel superimposition	Coordinate system in which handwheel superimpositioning takes effect Effective in the Tool axis traverse mode

The control selects the mode of traverse and the associated parameters automatically. If the traverse mode or the parameters have not been correctly preselected, you are able to reset them manually.

Note

NOTICE

Caution: Danger to the tool and workpiece!

A power failure during the machining operation can cause uncontrolled "coasting" or braking of the axes. In addition, if the tool was in effect prior to the power failure, then the axes cannot be referenced after the control has been restarted. For non-referenced axes, the control takes over the last saved axis values as the current position, which can deviate from the actual position. Thus, subsequent traverse movements do not correspond to the movements prior to the power failure. If the tool is still in effect during the traverse movements, then the tool and the workpiece can sustain damage through tension!

- ▶ Use a low feed rate
- ▶ Please keep in mind that the traverse range monitoring is not available for non-referenced axes

Example

The power failed while a thread cutting cycle in the tilted working plane was being performed. You have to retract the tap:

- ▶ Switch on the power supply for control and machine
- > The control starts the operating system. This process may take several minutes.
- > The control displays the **Power interrupted** dialog in the **Start/Login** workspace




- ▶ Activate the **Retract** toggle switch



- ▶ Press **OK**
- > The control compiles the PLC program.



- ▶ Switch the machine control voltage on
- > The control checks the functioning of the emergency stop circuit
- > The control opens the **Retract** application and displays the **Assume position values?** window.
- ▶ Compare the displayed position values with the actual position values




- ▶ Select **OK**
- > The control closes the **Assume position values?** window
- ▶ Select the **Thread** traverse mode as needed
- ▶ Enter the thread pitch as needed
- ▶ Enter the direction of rotation as needed



- ▶ Select **Retract**
- ▶ Retract the tool with the axis keys or the handwheel



- ▶ Select **End retraction**
- > The control opens the **End retraction?** window and prompts you to answer a confirmation request.



- ▶ If the tool was correctly retracted, select **Yes**
- > The control closes the **End retraction?** window and the **Retract** application.

18

Tables

18.1 The Tables operating mode

Application

In the **Tables** operating mode you can open various tables and edit them as necessary.

Description of function

If you select **Add**, the control displays the **Quick selection new table** and **Open File** workspaces.

In the **Quick selection new table** workspace you can create a new table and open some tables directly.

Further information: User's Manual for Programming and Testing

In the **Open File** workspace, you can open an existing table or create a new table.

Further information: User's Manual for Programming and Testing

Multiple tables can be open at the same time. The control displays each table in a separate workspace.

If a table is selected for program run or simulation, the control shows the status **M** or **S** on the tab of the application. The status of the active application is highlighted in color and for the remaining applications in gray.

You can open the **Table** and **Form** workspaces in every application.

Further information: "The Table workspace", Page 354

Further information: "The Form workspace for tables", Page 360

You can select various functions by using the context menu (e.g., **Copy**).

Further information: User's Manual for Programming and Testing

Buttons

In the **Tables** operating mode, the function bar contains the following buttons that can be used for any table:

Button	Meaning
Undo	The control undoes the last change.
Redo	The control restores the change that was undone.
GOTO record	The control opens the GOTO jump instruction window. The control jumps to the row number you have defined.
Edit	If the toggle switch is active, you can edit the table.
Reset row	The control resets all data contained in the row.
Mark row	The control marks the currently selected row.

Depending on the selected table, the control provides the following additional buttons in the function bar:

Button	Meaning
Insert rows	The control opens the Insert rows window where you can insert one or more new rows. If you enable the Append checkbox, the control will insert the rows after the last table row.
Delete rows	The control deletes the currently selected row.
Insert tool	The control opens the Insert tool window where you can define the following: <ul style="list-style-type: none"> ■ Type: Further information: "Tool types", Page 155 ■ Line number (Tool number?) ■ Number of rows ■ Index Further information: "Indexed tool", Page 152 ■ Append Append rows at the end of the table Further information: "Tool management ", Page 163
Delete tool	The control deletes the tool selected in the tool management. You cannot delete any tools that have been entered into the pocket table. The button is dimmed. Further information: "Tool management ", Page 163
Import	The control imports tool data. Further information: "Importing tool data", Page 165
Inspect	The control inspects a tool.
Unload	The control unloads a tool.
Load	The controls loads a tool.
Activate the preset	The control activates the currently selected row of the preset table as preset. Further information: "Preset table *.pr", Page 385
Lock record	The control locks the currently selected row of the preset table and thus protects the contents from changes. Further information: "Write-protection for table rows", Page 390



Refer to your machine manual.
If necessary, the machine manufacturer adapts the buttons.

18.1.1 Editing the contents of tables

To edit the contents of a table:

- ▶ Select the desired table cell



- ▶ Enable **Editing**
- > The control enables the values for editing.



To edit the contents of a table, you can also double-tap or double-click the table cell. The control displays the **Editing disabled. Enable?** window. You can enable the values for editing or abort the process.



If the **Editing** toggle switch is enabled, you can edit the contents both in the **Table** workspace and in the **Form** workspace.

Notes

- The control enables you to transfer tables from previous controls to the TNC7 basic and to adapt them automatically, if needed.
- When you open a table where columns are missing, for example in case of a tool table from a previous control, the control will display the **Incomplete table layout** window.

When you create a new table in the file manager, the table does not contain information on the required columns yet. When you open the table for the first time, the **Incomplete table layout** window will open in the **Tables** operating mode.

In the **Incomplete table layout** window, a selection menu allows you to select a table template. The control shows which table columns are added or removed, if applicable.

- If you, for example, have processed tables in a text editor, the control offers the **Update TAB / PGM** function. Use this function to complete an incorrect table format.



Edit tables only by using the table editor in the **Tables** operating mode to avoid errors (e.g., format errors).

- Refer to your machine manual.

Using the optional machine parameter **CfgTableCellCheck** (no. 141300), the machine manufacturer can define rules for table columns. This machine parameter allows to define columns as required fields or to reset them automatically to a default value. If a rule is violated, the control displays a note icon.

18.2 The Create new table window


Application

You can create tables using the **Create new table** window in the **Quick selection new table** workspace.

Related topics

- The **Quick selection new table** workspace
 - Further information:** User's Manual for Programming and Testing
- Available file types for tables
 - Further information:** User's Manual for Programming and Testing

Description of function



The **Create new table** window

The **Create new table** window shows the following areas:

- 1 Navigation path

In the navigation path the control shows the position of the current folder in the folder structure. Use the individual elements of the navigation path to move to a higher folder level.
- 2 Searching

You can search for any strings. The control displays the results under **Search Result**.
- 3 The control shows the following information and functions:
 - Add or remove a favorite
 - Preview
- 4 Content columns

The control shows a folder and the available prototypes for each table type.
- 5 Path of the table to be created
- 6 Navigation column

The navigation column contains the following areas:

 - **Search Result**
 - **Favorites**

The control displays all folders and prototypes that you have marked as favorites.
 - **Last functions**

The control shows the eleven most recently used prototypes.
 - **All functions**

The control shows all available table types in the folder structure.

Notes

- The names of tables and table columns must start with a letter and must not contain an arithmetic operator (e.g., +). Due to SQL commands, these characters can cause problems when data are input or read.
- With the optional machine parameter **CfgTableCreate** (no. 140900), the machine manufacturer can provide additional areas in the navigation column (e.g., tables for the user).
- With the optional machine parameter **dialogText** (no. 105506), the machine manufacturer can define other names for the table types (e.g., tool table instead of **t**).

18.3 The Table workspace

Application

In the **Table** workspace, the control shows the contents of a table. The control displays a column with filters and a search function on the left side of some tables.

Description of function

T	MAGAZIN	P	NAME
0			NULLWERKZEUG
1	Main	1.1	MILL_D2_ROUGH
2	Main	1.2	MILL_D4_ROUGH
3	Main	1.3	MILL_D6_ROUGH
4	Main	1.4	MILL_D8_ROUGH
5	Main	1.5	MILL_D10_ROUGH
6	Spindle	0.0	MILL_D12_ROUGH
7	Main	1.7	MILL_D14_ROUGH
8	Main	1.8	MILL_D16_ROUGH
9	Main	1.9	MILL_D18_ROUGH
10	Main	1.10	MILL_D20_ROUGH
11	Main	1.11	MILL_D22_ROUGH
12	Main	1.12	MILL_D24_ROUGH
13	Main	1.13	MILL_D26_ROUGH
14	Main	1.14	MILL_D28_ROUGH

The **Table** workspace

In the Tables operating mode, the **Table** workspace is open in every application by default.

The control displays the name and path of the file above the header of the table.

When you select the title of a column, the control will sort the table contents by this column.

If the table allows it, you can also edit the table contents in this workspace.









Refer to your machine manual.

If necessary, the machine manufacturer adapts the contents displayed (e.g., the titles of table columns).

Icons and shortcuts

The **Table** workspace contains the following icons or shortcuts:

Icon or shortcut	Meaning
	Open or close the Filter column Further information: "The Filter column in the Table workspace", Page 355
 CTRL + F	Open or close the Search column Further information: "The Search column in the Table workspace", Page 358
	Enable or disable Change column width
	Edit table characteristics Further information: User's Manual for Programming and Testing
100%	Current size of the content Open or close the Scaling selection menu
	Reset scaling Set the font size of the table to 100%
	Open or close settings in the Tables window Further information: "Settings in the Table workspace", Page 358
CTRL + A	Mark all rows
CTRL+SPACE	Mark the active row or end the marking function
SHIFT + UP	Additionally mark the row above
SHIFT + DOWN	Additionally mark the row below

The Filter column in the Table workspace

You can filter the following table types:

- **Tool management**
- **Pocket table**
- **Presets**
- **Tool table**

When you tap or click a filter once, the control activates the selected filter in addition to the currently active filters. When you double-tap or double-click a filter, the control activates only the selected filter and deactivates all other filters.

Filtering in the Tool management

The control provides the following default filters in the **Tool management**:

- **All tools**
- **Magazine tools**

According to the selection of **All tools** or **Magazine tools**, the control additionally offers the following default filters in the filter column:

- **All types**
- **Milling cutters**
- **Drills**
- **Taps**
- **Thread cutters**
- **Touch probes** (#17 / #1-05-1)
- **Undefined tools**

Filtering in the Pocket table

The control provides the following default filters in the **Pocket table**:

- **all pockets**
- **spindle**
- **main magazine**
- **empty pockets**
- **occupied pockets**

Filtering in the Presets table



The control provides the following default filters in the **Presets** table:

- **Base transformations**
- **Offsets**
- **SHOW ALL**

User-defined filters

You can additionally create user-defined filters.

The control provides the following icons for each user-defined filter:

Icon	Meaning
	If you click Edit , the control opens the Search column. You can edit and save the selected filter or save a filter under a new name. Further information: "The Search column in the Table workspace", Page 358
	You can delete the selected filter.

If you want to deactivate the user-defined filters, you have to double-tap or double-click the **All** filter.



Refer to your machine manual.

This User's Manual describes the basic functions of the control. The machine manufacturer can adapt, enhance or restrict the control functions to the machine.

Logical connective operations between requirements and filters

The control connects the filters as follows:

- AND operation for several requirements within one filter
You create, for example, a user-defined filter that contains the requirements **R = 8** and **L > 150**. The control filters the table rows when you activate this filter. The control displays only the table rows that meet both requirements at the same time.
- OR operation between filters of the same type
When you activate the default filters **Milling cutters** and **Lathe tools**, for example, the control filters the table rows. The control displays only the table rows that meet at least one of the requirements. The table row must contain either a milling cutter or a turning tool.
- AND operation between filters of different types
You create, for example, a user-defined filter that contains the requirement **R > 8**. When you activate this filter and the default filter **Milling cutters**, the control filters the table rows. The control displays only the table rows that meet both requirements at the same time.

The Search column in the Table workspace

You can search the following table types:

- **Tool management**
- **Pocket table**
- **Presets**
- **Tool table**

You can define multiple search conditions in the search function.

Each condition includes the following information:

- Table column, such as **T** or **NAME**
Use the **Search in** selection menu to select the column.
- Operator if applicable (e.g., **Contains** or **Equal to (=)**)
Use the **Operator** selection menu to select the operator.
- Search term in the **Search for** input field



If you search the columns using predefined selection values, the control offers a selection menu instead of the input field.

The control provides the following buttons:

Button	Meaning
+	Use Add to add several conditions. The conditions will have a combined effect when you perform the search. You can save several conditions in a user-defined filter.
Search	The control searches the table.
Reset	The control resets the entered conditions and removes any additional conditions.
Save	You can save the entered conditions as a filter. You can assign any name to the filter.



Refer to your machine manual.

This User's Manual describes the basic functions of the control. The machine manufacturer can adapt, enhance or restrict the control functions to the machine.

Settings in the Table workspace

In the **Tables** window, you can influence the contents shown in the **Table** workspace.

The **Tables** window consists of the following areas:


- **General**
- **Column sequence**

The General area

The setting selected in the **General** area is modally effective.

If the **Synchronize table and form** toggle switch is active, the cursor will move synchronously. If, for example, you select a different table column in the **Table** workspace, the control moves the cursor synchronously in the **Form** workspace.

The Column sequence area



The **Tables** window

The **Column sequence** area contains the following settings:

Setting	Meaning
Use standard format	If you activate the toggle switch, the control shows all table columns, indicating them in the standard sequence. If you deactivate the toggle switch, the control restores the previous setting.
User format	If you select the Reset button, the control resets the adaptations to the settings of the standard format.
Toggle all	If you activate the toggle switch, the control shows all table columns. If you deactivate the toggle switch, the control hides all table columns. The first column in each table cannot be hidden.
Number of frozen columns	You define how many table columns the control freezes at the left table edge. You can freeze up to four table columns. These table columns will remain visible even when you navigate further to the right within the table.
Columns of the currently opened table	The control displays all table columns below each other. Use the toggle switches to separately hide or show each table column. The control displays a line below the selected number of frozen columns. When you select a table column, the control displays up and down arrows. Use these arrows to change the sequence of the columns. The respective first column in the table cannot be shifted.

The settings in the **Column sequence** area only apply to the currently opened table.

18.4 The Form workspace for tables

Application

In the **Form** workspace, the control shows all contents of a selected table row. Depending on the table, you can edit the values in the form.

Description of function

The **Form** workspace in the **Favorites** view

The control displays the following information for each parameter:

- Icon of the parameter, if applicable
- Parameter name
- Unit of measure as needed
- Parameter description
- Current value

The control displays the contents of specific tables in groups within the **Form** workspace.









Refer to your machine manual.

If necessary, the machine manufacturer adapts the contents displayed (e.g., the titles of table columns).


Buttons and icons

The **Form** workspace contains the following buttons, icons or shortcuts:

Buttons, icons or shortcuts	Meaning
 SHIFT + UP  SHIFT + DOWN	Navigate Navigate between table rows
	Configure the layout You can make the following layout adaptations: <ul style="list-style-type: none"> ■ Add or remove areas to the Favorites view ■ Rearrange areas using the gripper ■ Add or remove columns
Favorites	In this view, the control shows the areas that are marked as favorites. You can create a user-defined view using the favorites.
All	In this view the control shows all areas.
	Settings <ul style="list-style-type: none"> ■ Open the settings in the Tables window Further information: "Settings in the Form workspace", Page 362 ■ Change the size of the graphic in the Tool Icon area
	Add The control only shows this icon when you are adapting the layout. With this icon you can add the following elements: <ul style="list-style-type: none"> ■ Column You can divide the workspace into several columns. Further information: "Adding a column in the workspace", Page 362 ■ Area In the Favorites view you can add another area.
	Remove The control only shows this icon when you are adapting the layout. You can delete an empty column with this icon.

Settings in the Form workspace

In the **Tables** window, you can select whether the control will show the parameter descriptions. The selected setting is modally effective.



18.4.1 Adding a column in the workspace

To add a column:

- ☰
 - ▶ Select **Configure the layout**
 - > The control enables all functions for adapting the layout of the workspace.
 - ▶ In the workspace, swipe to the left
- +
 - ▶ Select **Add**
 - > The control adds a new column.
- ⋮
 - ▶ Move the areas if required
- ☑
 - ▶ Select **Configure the layout**
 - > The control saves your changes.

Notes

- The control displays an icon of the selected tool type in the **Tool Icon** area.
Further information: "Tool types", Page 155

18.5 Tool tables

18.5.1 Overview

This chapter describes the tool tables of the control.

- Tool table **tool.t**
Further information: "Tool table tool.t", Page 363
- Touch probe table **tchprobe.tp** (#17 / #1-05-1)
Further information: "Touch probe table tchprobe.tp (#17 / #1-05-1)", Page 373

You can edit the tools, except for the touch probes, in tool management only.

Further information: "Tool management ", Page 163

18.5.2 Tool table tool.t

Application

The tool table **tool.t** contains the data specific to drilling and milling tools. The tool table also contains all tool data that are independent of the technology, such as the tool life **CUR_TIME**.

Related topics





- Editing tool data in tool management
Further information: "Tool management ", Page 163
- Tool data required for milling or drilling tools
Further information: "Tool data for milling and drilling tools", Page 159




Description of function





The file name of the tool table is **tool.t** and this table must be stored in the folder **TNC:\table**.







The **tool.t** tool table provides the following parameters:








Parameter	Meaning
T	<p>Tool number?</p> <p>Row number in the tool table</p> <p>The tool number allows you to identify each tool unambiguously (e.g., for calling a tool).</p> <p>Further information: User's Manual for Programming and Testing You can define an index after the period.</p> <p>Further information: "Indexed tool", Page 152</p> <p>This parameter applies to all tools, regardless of technology.</p> <p>Input: 0.0...32767.9</p>
NAME	<p>Tool name?</p> <p>The tool name identifies a tool, for example when calling it.</p> <p>Further information: User's Manual for Programming and Testing You can define an index after the period.</p> <p>Further information: "Indexed tool", Page 152</p> <p>This parameter applies to all tools, regardless of technology.</p> <p>Input: Text width 32</p>
L	<p>Tool length?</p> <p>Length of tool, with respect to the tool carrier reference point</p> <p>Further information: "Tool carrier reference point", Page 147</p> <p>Input: -99999.9999...+99999.9999</p>
R	<p>Tool radius?</p> <p>Tool radius, with respect to the tool carrier reference point</p> <p>Further information: "Tool carrier reference point", Page 147</p> <p>Input: -99999.9999...+99999.9999</p>
R2	<p>Tool radius 2?</p> <p>Corner radius for the exact definition of the tool for three-dimensional radius compensation, graphic representation and collision monitoring of, for example, ball-nose cutters or toroid cutters.</p> <p>Further information: User's Manual for Programming and Testing</p> <p>Input: -99999.9999...+99999.9999</p>




Parameter	Meaning
DL 	Tool length oversize? Delta value of tool length as a compensation value in connection with touch probe cycles. The control enters compensation values automatically after measuring the workpiece. Further information: User's Manual for Measuring Cycles for Workpieces and Tools Is added to the parameter L Input: -999.9999...+999.9999
DR 	Tool radius oversize? Delta value of tool radius as a compensation value in connection with touch probe cycles. The control enters compensation values automatically after measuring the workpiece. Further information: User's Manual for Measuring Cycles for Workpieces and Tools Is added to parameter R Input: -999.9999...+999.9999
DR2 	Tool radius oversize 2? Delta value of tool radius 2 as a compensation value in connection with touch probe cycles. The control enters compensation values automatically after measuring the workpiece. Further information: User's Manual for Measuring Cycles for Workpieces and Tools Is added to parameter R2 Input: -999.9999...+999.9999
TL 	Tool locked? Tool is enabled or locked for machining: <ul style="list-style-type: none"> ■ No value entered: Enabled ■ L: Locked The control locks the tool after exceeding maximum tool age TIME1 , maximum tool age 2 TIME2 or after exceeding one of the parameters for automatic tool measurement. This parameter applies to all tools, regardless of technology. Selection by means of a selection window Input: No value, L



Parameter	Meaning
RT 	<p>Replacement tool?</p> <p>Number of the replacement tool</p> <p>If the control calls a tool in a TOOL CALL and the tool is not available or locked, the control inserts the replacement tool.</p> <p>If M101 is active and the current tool age CUR_TIME exceeds the TIME2 value, the control locks the tool and inserts the replacement tool at a suitable location.</p> <p>Further information: User's Manual for Programming and Testing</p> <p>If the replacement tool is not available or locked, the control inserts the replacement tool of the replacement tool.</p> <p>You can define an index after the period.</p> <p>Further information: "Indexed tool", Page 152</p> <p>If you define the value 0, the control will not use a replacement tool.</p> <p>This parameter applies to all tools, regardless of technology.</p> <p>Selection by means of a selection window</p> <p>Input: 0.0...32767.9</p>
TIME1 	<p>Maximum tool age?</p> <p>Maximum tool age in minutes</p> <p>If the current tool age CUR_TIME exceeds the TIME1 value, the control locks the tool and displays an error message when the tool is called the next time.</p> <p>The behavior depends on the machine. Refer to your machine manual.</p> <p>This parameter applies to all tools, regardless of technology.</p> <p>Input: 0...99999</p>
TIME2 	<p>Max. tool age for TOOL CALL?</p> <p>Maximum tool age 2 in minutes</p> <p>The control inserts a replacement tool in the cases below:</p> <ul style="list-style-type: none"> When the current tool age CUR_TIME exceeds the TIME2 value, the control locks the tool. The control no longer inserts the tool when the tool is called. If a replacement tool RT is defined and available in the magazine, the control inserts the replacement tool. If no replacement tool is available, the control will display an error message. If M101 is active and the current tool age CUR_TIME exceeds the TIME2 value, the control locks the tool and inserts the replacement tool RT at a suitable location. <p>Further information: User's Manual for Programming and Testing</p> <p>The behavior depends on the machine. Refer to your machine manual.</p> <p>This parameter applies to all tools, regardless of technology.</p> <p>Input: 0...99999</p>




Parameter	Meaning
CUR_TIME 	Current tool age? <p>The current tool age equals the time during which the tool is cutting a workpiece. The tool is cutting a workpiece when the spindle is switched on and the control moves the tool at the machining feed rate. The control counts this time automatically and enters the current tool age in minutes.</p> <p>You can edit the tool age of an active tool during program run after you have inserted an indexable insert, for example. The control will directly apply the value to tool life monitoring.</p> <p>The control updates the value cyclically during NC program run, as well as during a tool call and at the end of the program.</p> <p>This parameter applies to all tools, regardless of technology.</p> <p>Input: 0...99999.99</p>
TYP	Tool type? <p>Depending on the selected tool type, the control displays the suitable tool parameters in the Form workspace of the tool management.</p> <p>Further information: "Tool types", Page 155</p> <p>Further information: "Tool management ", Page 163</p> <p>This parameter applies to all tools, regardless of technology.</p> <p>Selection by means of a selection window</p> <p>Input: MILL, MILL_R, MILL_F, MILL_FACE, BALL, TORUS, MILL_CHAMFER, DRILL, TAP, CENT, TURN, TCHP, REAM, CSINK, TSINK BOR, BCKBOR, GF, GSF, EP, WSP, BGF, ZBGF, GRIND, and DRESS</p>
DOC	Tool description <p>This parameter applies to all tools, regardless of technology.</p> <p>Input: Text width 32</p>
PLC	PLC status? <p>Tool information for the PLC</p> <p>Refer to your machine manual.</p> <p>This parameter applies to all tools, regardless of technology.</p> <p>Entry: %00000000...%11111111</p>
LCUTS 	Tooth length in the tool axis? <p>Length of cutting edge for exact definition of the tool for graphical simulation, automatic calculation within cycles and collision monitoring.</p> <p>Input: -99999.9999...+99999.9999</p>
LU 	Usable length of the tool? <p>Usable length of the tool for exact definition of the tool for graphical simulation, automatic calculation within cycles and collision monitoring (e.g., of necks of end mills).</p> <p>Input: 0.0000...999.9999</p>
RN 	Neck radius of the tool? <p>Neck radius for the exact definition of the tool for graphic simulation and collision monitoring of, for example, necks of end mills or side milling cutters.</p> <p>The tool can contain a neck radius RN only if the useful length LU is longer than the LCUTS length of the cutting edge.</p> <p>Input: 0.0000...999.9999</p>

Parameter	Meaning
ANGLE 	Maximum plunge angle? Maximum plunge angle of the tool for reciprocating plunge-cutting in the cycles. Input: -360.00...+360.00
CUT 	Number of teeth? Number of teeth of the tool for automatic tool measurement or cutting data calculation. Further information: User's Manual for Measuring Cycles for Workpieces and Tools Further information: User's Manual for Programming and Testing Input: 0...99
TMAT 	Tool material? Tool material from the tool material table TMAT.tab for cutting data calculation. Further information: User's Manual for Programming and Testing Selection by means of a selection window Input: Text width 32
CUTDATA 	Cutting data table? Select the cutting data table with the *.cut or *.cutd file extension for cutting data calculation. Further information: User's Manual for Programming and Testing Selection by means of a selection window Entry: Text width 20
LTOL 	Wear tolerance: length? Permitted tool length deviation in wear detection for automatic tool measurement. Further information: User's Manual for Measuring Cycles for Workpieces and Tools If the entered value is exceeded, the control locks the tool in column TL . Input: 0.0000...5.0000
RTOL 	Wear tolerance: radius? Permitted tool radius deviation in wear detection for automatic tool measurement. Further information: User's Manual for Measuring Cycles for Workpieces and Tools If the entered value is exceeded, the control locks the tool in column TL . Input: 0.0000...5.0000
R2TOL	Wear tolerance: Radius 2? Permitted tool radius 2 deviation in wear detection for automatic tool measurement. Further information: User's Manual for Measuring Cycles for Workpieces and Tools If the entered value is exceeded, the control locks the tool in column TL . Input: 0...9.9999

Parameter	Meaning
DIRECT 	Cutting direction? Cutting direction of the tool for automatic tool measurement with a rotating tool: <ul style="list-style-type: none"> ■ -: M3 ■ +: M4 Further information: User's Manual for Measuring Cycles for Workpieces and Tools Input: -, +
R-OFFS 	Tool offset: radius? Position of tool upon length measurement, offset between the center of the tool touch probe and the tool center for automatic tool measurement. Further information: User's Manual for Measuring Cycles for Workpieces and Tools Input: -99999.9999...+99999.9999
L-OFFS 	Tool offset: length? Position of tool upon radius measurement, distance between the top edge of the tool touch probe and the tool tip for automatic tool measurement. Further information: User's Manual for Measuring Cycles for Workpieces and Tools Is added to the machine parameter offsetToolAxis (no. 122707) Input: -99999.9999...+99999.9999
LBREAK 	Breakage tolerance: length? Permitted tool length deviation in breakage detection for automatic tool measurement. Further information: User's Manual for Measuring Cycles for Workpieces and Tools If the entered value is exceeded, the control locks the tool in column TL . Input: 0.0000...9.0000
RBREAK 	Breakage tolerance: radius? Permitted tool radius deviation in breakage detection for automatic tool measurement. Further information: User's Manual for Measuring Cycles for Workpieces and Tools If the entered value is exceeded, the control locks the tool in column TL . Input: 0.0000...9.0000
NMAX 	Maximum speed [rpm] Limitation of spindle speed for the programmed value including control by the potentiometer. Input: 0...999999
LIFTOFF 	Lift-off allowed? Allow automatic tool lift-off with active M148 or FUNCTION LIFTOFF : <ul style="list-style-type: none"> ■ Y: Activate LIFTOFF ■ N: Deactivate LIFTOFF Further information: User's Manual for Programming and Testing Selection by means of a selection window Input: Y, N

Parameter	Meaning
TP_NO	<p>Number of the touch probe</p> <p>Number of touch probe in the touch probe table tchprobe.tp</p> <p>Further information: "Touch probe table tchprobe.tp (#17 / #1-05-1)", Page 373</p> <p>Input: 0...99</p>
 T-ANGLE	<p>Point angle</p> <p>Point angle of the tool for exact definition of the tool for graphical simulation, automatic calculation within cycles and collision monitoring of drills, for example.</p> <p>Further information: User's Manual for Machining Cycles</p> <p>Input: -180...+180</p>
 LAST_USE	<p>Date/time of last tool usage</p> <p>The time at which the tool was last used</p> <p>The control updates the value cyclically during NC program run, as well as during a tool call and at the end of the program.</p> <p>This parameter applies to all tools, regardless of technology.</p> <p>Input: 00:00:00 01.01.1971...23:59:59 31.12.2030</p>
PTYP	<p>Tool type for pocket table?</p> <p>Tool type for evaluation in the pocket table</p> <p>Further information: "Pocket table tool_p.tch", Page 377</p> <p>Refer to your machine manual.</p> <p>This parameter applies to all tools, regardless of technology.</p> <p>Input: 0...99</p>
AFC	<p>Feedback-control strategy</p> <p>Control setting for adaptive feed control (AFC (#45 / #2-31-1)) from the AFC.tab table</p> <p>Further information: "Adaptive feed control (AFC) (#45 / #2-31-1)", Page 236</p> <p>Selection by means of a selection window</p> <p>Entry: Text width 10</p>
ACC	<p>ACC active?</p> <p>Activate or deactivate active chatter control (ACC (#145 / #2-30-1)):</p> <ul style="list-style-type: none"> ■ Y: Activate ■ N: Deactivate <p>Further information: "Active Chatter Control (ACC) (#145 / #2-30-1)", Page 245</p> <p>Selection by means of a selection window</p> <p>Input: Y, N</p>
 PITCH	<p>Tool thread pitch?</p> <p>Thread pitch of the tool for automatic calculations within cycles. A positive sign means a right-hand thread.</p> <p>Further information: User's Manual for Machining Cycles</p> <p>Input: -9.9999...+9.9999</p>

Parameter	Meaning
AFC-LOAD	<p>Reference power for AFC [%]</p> <p>Tool-dependent reference power for AFC (#45 / #2-31-1).</p> <p>The input in percent refers to the rated spindle power. The control immediately uses the value given for feedback control, meaning a teach-in cut is dropped. Calculate the value beforehand with a teach-in step.</p> <p>Further information: "AFC teach-in cut", Page 242</p> <p>Input: 1.0...100.0</p>
AFC-OVLD1	<p>AFC overload warning level [%]</p> <p>Cut-related tool wear monitoring for AFC (#45 / #2-31-1).</p> <p>The input in percent refers to the reference power. The value 0 deactivates the monitoring function. An empty field has no effect.</p> <p>Further information: "Monitoring tool wear and tool load", Page 244</p> <p>Input: 0.0...100.0</p>
AFC-OVL2	<p>AFC overload switch-off level [%]</p> <p>Cut-related tool load monitoring for AFC (#45 / #2-31-1).</p> <p>The input in percent refers to the reference power. The value 0 deactivates the monitoring function. An empty field has no effect.</p> <p>If this column contains a value, the control will ignore the column AFC-OVLD1.</p> <p>Further information: "Monitoring tool wear and tool load", Page 244</p> <p>Input: 0.0...100.0</p>
KINEMATIC 	<p>Tool-carrier kinematics</p> <p>Assigning a tool carrier for exact definition of the tool for graphical simulation and collision monitoring.</p> <p>Further information: "Tool carrier management", Page 167</p> <p>Selection by means of a selection window</p> <p>This parameter applies to all tools, regardless of technology.</p> <p>Entry: Text width 20</p>
TSHAPE 	<p>3D tool model</p> <p>Assigning a 3D model for exact definition of the tool for graphical simulation and collision monitoring.</p> <p>Further information: "Tool model (#140 / #5-03-2)", Page 171</p> <p>Selection by means of a selection window</p> <p>Input: Text width 50</p>
DR2TABLE	<p>Compensation val. table for DR2</p> <p>Assigning a compensation value table *.3drc for 3D tool radius compensation depending on the contact angle. This allows the control to compensate for inaccuracies in the shape of a ball-nose cutter or the deflection behavior of a touch probe, for example.</p> <p>Selection by means of a selection window</p> <p>Entry: Text width 16</p>

Parameter	Meaning
OVRTIME 	Tool life expired Time in minutes during which the tool may be used beyond the tool life defined in column TIME2 . The machine manufacturer defines the function of this parameter. The machine manufacturer defines how the control will use the parameter when searching for tool names. Refer to your machine manual. This parameter applies to all tools, regardless of technology. Input: 0...99
RCUTS 	Width of the indexable insert Front-face width of cutting edge for exact definition of the tool for graphical simulation, automatic calculation within cycles and collision monitoring (e.g., for indexable inserts). Input: 0...99999.9999
DB_ID	ID for central tool management The database-ID allows you to identify a tool (e.g., within a tool management system by using client applications). Further information: "Database ID", Page 151 For indexed tools, HEIDENHAIN recommends that you assign the database ID to the main tool. Further information: "Indexed tool", Page 152 This parameter applies to all tools, regardless of technology. Input: Text width 40
R_TIP 	Radius at the tip Radius at the tool tip for exact definition of the tool for graphical simulation, automatic calculation within cycles and collision monitoring of tools such as countersinks. Input: 0.0000...999.9999

Notes

- Use the machine parameter **unitOfMeasure** (no. 101101) to define inches as the unit of measure. This does not automatically change the unit of measure in the tool table!

Further information: "Creating a tool table in inches", Page 377

- If you want to archive tool tables or use them for simulation, save them with different file names and the corresponding file extension.
- The control shows delta values from the tool management graphically in the simulation. For delta values from the NC program or from compensation tables, the control changes only the position of the tool in the simulation.
- Assign unique tool names!

If you define identical tool names for multiple tools, the control will look for the tool in the following sequence:

- Tool that is in the spindle
- Tool that is in the magazine



Refer to your machine manual.

If there are multiple magazines, the machine manufacturer can specify the search sequence of the tools in the magazines.

- Tool that is defined in the tool table but is currently not in the magazine

If the control, for example, finds multiple available tools in the tool magazine, it inserts the tool with the least remaining tool life.

- In the machine parameter **offsetToolAxis** (no. 122707), the machine manufacturer defines the distance between the upper edge of the tool touch probe and the tool tip.

The parameter **L-OFFS** is added to this defined distance.

- In the machine parameter **zeroCutToolMeasure** (no. 122724), the machine manufacturer defines whether the control takes the parameter **R-OFFS** into account for automatic tool measurement.

18.5.3 Touch probe table `tchprobe.tp` (#17 / #1-05-1)

Application

The touch probe table `tchprobe.tp` defines the touch probe and data for the probing process, such as the probing feed rate. If you use several touch probes, you can save separate data for each touch probe.

Related topics

- Editing tool data in tool management
Further information: "Tool management ", Page 163
- Touch probe functions
Further information: "Touch Probe Functions in the Manual Operating Mode (#17 / #1-05-1)", Page 289
- Calibrating touch probe cycles for the workpiece touch probe
Further information: User's Manual for Measuring Cycles for Workpieces and Tools
- Calibrating touch probe cycles for the tool touch probe
Further information: User's Manual for Measuring Cycles for Workpieces and Tools
- Automatic touch probe cycles for the workpiece
Further information: User's Manual for Measuring Cycles for Workpieces and Tools
- Automatic touch probe cycles for the tool
Further information: User's Manual for Measuring Cycles for Workpieces and Tools
- Automatic touch probe cycles for measuring the kinematics
Further information: User's Manual for Measuring Cycles for Workpieces and Tools

Description of function

NOTICE


Danger of collision!









The control cannot protect L-shaped styli from collisions using Dynamic Collision Monitoring DCM (#40 / #5-03-1). When using a touch probe with an L-shaped stylus there is a risk of collision!

- ▶ Carefully run in the NC program or program section in the **Program Run Single Block** operating mode
- ▶ Watch out for possible collisions!

The file name of the touch probe table is **tchprobe.tp** and this table must be stored in the folder **TNC:\table**.

The touch probe table **tchprobe.tp** provides the following parameters:

Parameter	Meaning
NO	<p>Sequential number of touch probe</p> <p>You use this number to assign the touch probe to the data in the tool management column TP_NO.</p> <p>Input: 1...99</p>
TYPE	<p>Selection of the touch probe?</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p> The following values are available for the TS 642 touch probe:</p> <ul style="list-style-type: none"> ■ TS642-3: The touch probe is activated by a conical switch. This mode is not supported. ■ TS642-6: The touch probe is activated by an infrared signal. Select this mode. </div> <p>Input: TS120, TS220, TS249, TS260, TS440, TS444, TS460, TS630, TS632, TS640, TS642-3, TS642-6, TS649, TS740, TS 760, KT130, OEM</p>
CAL_OF1	<p>TS center misalignmt. ref. axis? [mm]</p> <p>According to the selection of the STYLUS column, this parameter has the following function:</p> <ul style="list-style-type: none"> ■ SIMPLE: Offset of the touch probe axis to the spindle axis in the main axis ■ L-TYPE: Length of extension on an L-shaped stylus <p>Input: -99999.9999...+99999.9999</p>
CAL_OF2	<p>TS center misalignmt. aux. axis? [mm]</p> <p>Offset of the touch probe axis to the spindle axis in the secondary axis</p> <p>Input: -99999.9999...+99999.9999</p>
CAL_ANG	<p>Spindle angle for calibration?</p> <p>According to the selection of the STYLUS column, this parameter has the following function:</p> <ul style="list-style-type: none"> ■ SIMPLE: Prior to calibrating or probing, the control orients the touch probe with this spindle angle (if possible). ■ L-TYPE: The control orients the extension using the spindle angle. Prior to calibrating or probing, the control aligns the touch probe with the spindle orientation angle (if possible). <p>Input: 0.0000...359.9999</p>

Parameter	Meaning
F 	Probing feed rate? [mm/min] In the machine parameter maxTouchFeed (no. 122602), the machine manufacturer defines the maximum probing feed rate. If F is greater than the maximum probing feed rate, then the maximum probing feed rate will be used. Input: 0...9999
FMAX 	Rapid traverse in probing cycle? [mm/min] Feed rate at which the control pre-positions the touch probe and positions it between the measuring points Input: +10...+99999
DIST 	Maximum measuring range? [mm] If the stylus is not deflected in a probing process within the defined value, the control will display an error message. Input: 0.00100...99999.99999
SET_UP 	Set-up clearance? [mm] Distance of touch probe from the defined touch point when pre-positioning The smaller this value is, the more exactly you must define the touch point position. Safety clearances defined in the touch probe cycle are added to this value. Input: 0.00100...99999.99999
F_PREPOS 	Pre-position at rapid? ENT/NOENT Speed for pre-positioning: <ul style="list-style-type: none"> ■ FMAX_PROBE: Pre-position at the speed from FMAX ■ FMAX_MACHINE: Pre-position at machine rapid traverse Input: FMAX_PROBE, FMAX_MACHINE
TRACK 	Probe oriented? Yes=ENT/No=NOENT Orienting the infrared touch probe in each probing process: <ul style="list-style-type: none"> ■ ON: The control orients the touch probe in the defined probing direction. In this way, the stylus is always deflected in the same direction, improving measuring accuracy. ■ OFF: The control will not orient the touch probe. If you change the TRACK parameter, you must recalibrate the touch probe. Input: ON, OFF
SERIAL 	Serial number? The control automatically edits this parameter of touch probes with an EnDat interface. Input: Text width 15
REACTION 	Reaction? EMERGSTOP=ENT/NCSTOP=NOENT As soon as touch probes with a collision protection adapter detect a collision, they react by resetting the ready signal. Reaction to resetting the ready signal: <ul style="list-style-type: none"> ■ NCSTOP: Interrupt NC program ■ EMERGSTOP: Emergency stop, quick braking of the axes Input: NCSTOP, EMERGSTOP

Parameter	Meaning
STYLUS	Shape of the stylus <ul style="list-style-type: none"> ■ SIMPLE: Straight stylus ■ L-TYPE: L-shaped stylus

Editing the touch probe table


To edit the touch probe table:



- ▶ Select the **Tables** operating mode



- ▶ Select **Add**
- > The control opens the **Quick selection** and the **Open File** workspaces.
- ▶ Select the **tchprobe.tp** file in the **Open File** workspace



- ▶ Select **Open**
- > The control opens the **Touch probes** application.














- ▶ Activate **Edit**
- ▶ Select the desired value
- ▶ Edit the value

Notes

- You can also edit the touch probe table values in the tool management.
- If you want to archive tool tables or use them for simulation, save them with different file names and the corresponding file extension.
- In the machine parameter **overrideForMeasure** (no. 122604), the machine manufacturer defines whether you will be allowed to change the feed rate with the feed-rate potentiometer during probing.

18.5.4 Creating a tool table in inches

To create a tool table in inches:

-  ▶ Select the **Manual** operating mode
-  ▶ Select **T**
-  ▶ Select the tool **T0**
-  ▶ Press the **NC Start** key
 - The control removes the current tool and does not insert a new tool.
-  ▶ Restart the control
 - ▶ Do not acknowledge **Power interrupted**
-  ▶ Select the **Files** operating mode
 - ▶ Open the **TNC:\table** folder
 - ▶ Rename the original file (e.g., **tool.t** as **tool_mm.t**)
-  ▶ Select the **Tables** operating mode
-  ▶ Select **Create new table**
 - The control opens the **Create new table** window.
 - ▶ Select a folder with the corresponding table type (e.g., **t**)
 - ▶ Select the desired prototype
 - ▶ Select a path
 - The control opens the **Save as** window.
 - ▶ Select the **table** folder
 - ▶ Enter a name (e.g., **tool**)
 - ▶ Select **Create** twice
 - The control opens the **Tool table** tab in the **Tables** operating mode.
-  ▶ Restart the control
-  ▶ Acknowledge **Power interrupted** with the **CE** key
-  ▶ Select the **Tool table** tab in the **Tables** operating mode
 - The control uses the newly created table as a tool table.



To use the **Tool management** application you have to create all existing tool tables in inches.

18.6 Pocket table tool_p.tch

Application

The **tool_p.tch** pocket table provides the pocket assignment of the tool magazine. The control needs the pocket table in order to change the tool.

Related topics

- Tool call
Further information: User's Manual for Programming and Testing
- Tool table
Further information: "Tool table tool.t", Page 363

Requirement

- The tool is defined in the tool management.
Further information: "Tool management ", Page 163

Description of function

The file name of the pocket table is **tool_p.tch** and this table must be stored in the folder **TNC:\table**.

The **tool_p.tch** pocket table provides the following parameters:

Parameter	Meaning
P	Pocket number? Pocket number of the tool in the tool magazine Input: 0.0...99.9999
T	Tool number? Row number of the tool from the tool table With the machine parameter deleteLoadedTool (no. 125301) you define whether you are allowed to edit the T column. The machine manufacturer enables this parameter. Further information: "Tool table tool.t", Page 363 Input: 1...99999
TNAME	Tool name? Name of the tool from the tool table When you define the tool number, the control will automatically load the tool name. Further information: "Tool table tool.t", Page 363 Input: Text width 32
RSV	Reserve pocket? When a tool is in the spindle, the control reserves the pocket of this tool in the box magazine. To reserve the pocket for the tool: <ul style="list-style-type: none"> ■ No value entered: Pocket is not reserved ■ R: Pocket is reserved Input: No value, R
ST	Special tool? Define the tool as a special tool (e.g., with oversize tools): <ul style="list-style-type: none"> ■ No value entered: No special tool ■ S: Special tool Input: No value, S

Parameter	Meaning
F	<p>Fixed pocket?</p> <p>Always return the tool to the same pocket in the tool magazine (e.g., with special tools)</p> <p>To define a fixed pocket for the tool:</p> <ul style="list-style-type: none"> ■ No value entered: No fixed pocket ■ F: Fixed pocket <p>Input: No value, F</p>
L	<p>Locked pocket?</p> <p>To lock a pocket for tools (e.g., the pockets next to special tools):</p> <ul style="list-style-type: none"> ■ No value entered: Do not lock ■ L: Lock <p>Input: No value, L</p>
DOC	<p>Pocket comment?</p> <p>The control automatically loads the tool comment from the tool table.</p> <p>Further information: "Tool table tool.t", Page 363</p> <p>Input: Text width 32</p>
PLC	<p>PLC status?</p> <p>Information about this tool pocket, which is transferred to the PLC</p> <p>The machine manufacturer defines the function of this parameter. Refer to your machine manual.</p> <p>Entry: %00000000...%11111111</p>
P1 ... P5	<p>Value?</p> <p>The machine manufacturer defines the function of this parameter. Refer to your machine manual.</p> <p>Input: -99999.9999...+99999.9999</p>
PTYP	<p>Tool type for pocket table?</p> <p>Tool type for evaluation in the pocket table</p> <p>The machine manufacturer defines the function of this parameter. Refer to your machine manual.</p> <p>Input: 0...99</p>
LOCKED_ABOVE	<p>Lock pocket above?</p> <p>Box magazine: Lock the pocket above</p> <p>This parameter depends on the machine. Refer to your machine manual.</p> <p>Input: 0...99999</p>
LOCKED_BELOW	<p>Lock pocket below?</p> <p>Box magazine: Lock the pocket below</p> <p>This parameter depends on the machine. Refer to your machine manual.</p> <p>Input: 0...99999</p>
LOCKED_LEFT	<p>Lock pocket at left?</p> <p>Box magazine: Lock the pocket at left</p> <p>This parameter depends on the machine. Refer to your machine manual.</p> <p>Input: 0...99999</p>

Parameter	Meaning
LOCKED_RIGHT	<p>Lock pocket at right?</p> <p>Box magazine: Lock the pocket at right</p> <p>This parameter depends on the machine. Refer to your machine manual.</p> <p>Input: 0...99999</p>
LAST_USE	<p>LAST_USE</p> <p>The control automatically loads the date and time of the last tool call from the tool table.</p> <p>Further information: "Tool table tool.t", Page 363</p> <p>Refer to your machine manual.</p> <p>Entry: Text width 20</p>
S1	<p>S1</p> <p>Value for evaluation in the PLC</p> <p>The machine manufacturer defines the function of this parameter. Refer to your machine manual.</p> <p>Entry: Text width 16</p>
S2	<p>S2</p> <p>Value for evaluation in the PLC</p> <p>The machine manufacturer defines the function of this parameter. Refer to your machine manual.</p> <p>Entry: Text width 16</p>

18.7 Tool usage file

Application

The control saves information about the tools of an NC program in a tool usage file (e.g., all the required tools and the tool usage times). The control needs this file for the tool usage test.

Related topics

- Using the tool usage test
Further information: "Tool usage test", Page 173
- Working with a pallet table
Further information: User's Manual for Programming and Testing
- Tool data from the tool table
Further information: "Tool table tool.t", Page 363

Requirements

- **Generate tool-usage file** is enabled by your machine manufacturer
In the machine parameter **createUsageFile** (no. 118701), the machine manufacturer defines whether the **Generate tool-usage file** function will be enabled.
Further information: "Creating the tool usage file", Page 174
- The **Generate tool-usage file** setting is set to **Once** or **Always**
Further information: "Channel Settings", Page 440

Description of function

The tool usage file provides the following parameters:

Parameter	Meaning
NR	Row number in the tool usage file Input: 0...99999
TOKEN	In the TOKEN column, the control uses one word to show which information is contained in the respective row: <ul style="list-style-type: none"> ■ TOOL: Data per tool call; listed in chronological order ■ TTOTAL: All data of a tool; listed in alphabetical order ■ STOTAL: Called NC programs; listed in chronological order ■ TIMETOTAL: Total tool usage time of an NC program ■ TOOLFILE: Path of the tool table This enables the control during the tool usage test to detect whether you have performed the simulation with the tool table tool.t Input: Text width 17
TNR	Tool number If the control has not yet inserted a tool, the column contains the value -1 . Input: -1...32767
IDX	Tool index Input: 0...9
NAME	Tool name Input: Text width 32
TIME	Tool usage time in seconds Time during which the tool is cutting a workpiece (excluding rapid traverse movements) Input: 0...9999999
WTIME	Total tool usage time in seconds Total time between the tool changes, during which the tool is cutting a workpiece Input: 0...9999999
RAD	Sum of the tool radius R and the delta radius DR from the tool table Input: -999999.9999...999999.9999
BLOCK	NC block number of the tool call Input: 0...999999999
PATH	Path of the NC program, the pallet table, or the tool table Input: Text width 300
T	Tool number, including the tool index If the control has not yet inserted a tool, the column contains the value -1 . Input: -1...32767.9

Parameter	Meaning
OVRMAX	Maximum feed-rate override If you only simulate the machining operation, then the control will enter the value 100 . Input: 0...32767
OVRMIN	Minimum feed rate override If you only simulate the machining operation, then the control will enter the value -1 . Input: -1...32767
NAMEPRG	Type of tool definition during a tool call: <ul style="list-style-type: none"> ■ 0: The tool number is programmed ■ 1: The tool name is programmed Input: 0, 1
LINENR	Row number of the pallet table in which the NC program is defined Input: -1...99999

Note

The control saves the tool usage file as a dependent file (*.dep).

In the settings of the **Files** operating mode, you can specify whether the control displays dependent files in the file management.

Further information: User's Manual for Programming and Testing

18.8 T usage order (#93 / #2-03-1)

Application

In the **T usage order** table, the control displays the tool call sequence in an NC program. Before starting the program, you can see, for example, when a manual tool change will take place.

Requirements

- Software option Advanced Tool Management (#93 / #2-03-1)
- Tool-usage file has been created

Further information: "Creating the tool usage file", Page 174

Further information: "Tool usage file", Page 380

Description of function

When you select an NC program in the **Program Run** operating mode, the control will automatically create the **T usage order** table. The control displays the table in the **T usage order** application in **Tables** operating mode. The control lists all the tools called within the active NC program and all the tools called within called NC programs in chronological order. You cannot edit the table.

The **T usage order** table provides the following parameters:

Parameter	Meaning
NR	Sequential number of the table rows
T	Number of the tool used, including an index as needed Further information: "Indexed tool", Page 152 May differ from the programmed tool (e.g., when a replacement tool is used)
NAME	Name of the tool used, including an index as needed Further information: "Indexed tool", Page 152 May differ from the programmed tool (e.g., when a replacement tool is used)
TOOL INFO	The control displays the following tool information: <ul style="list-style-type: none"> ■ OK: Tool is in order ■ Locked: Tool is locked ■ Not found: Tool is not defined in the pocket table Further information: "Pocket table tool_p.tch", Page 377 ■ T no. missing: Tool is not defined in the tool management Further information: "Tool management ", Page 163
T PROG	Number or name of the programmed tool, including an index as needed Further information: "Indexed tool", Page 152
USAGE	Total tool usage time from the WTIME column of the tool usage file (in seconds) Total time between the tool changes, during which the tool is cutting a workpiece Further information: "Tool usage file", Page 380
TOOL TIME	Estimated time of tool change
M3/M4 TIME	Tool usage time from the TIME column of the tool usage file (in seconds) Time during which the tool is cutting a workpiece (excluding rapid traverse movements) Further information: "Tool usage file", Page 380
MIN OVRD	Minimum value of the feed-rate potentiometer during program run (in percent)
MAX OVRD	Maximum value of the feed-rate potentiometer during program run (in percent)
NC PGM	Path of the NC program in which the tool is programmed
MAGAZINE	In this column, the control writes whether the tool is currently in the magazine or in the spindle. This column remains empty if the tool is a zero tool or not defined in the pocket table. Further information: "Pocket table tool_p.tch", Page 377

18.9 Tooling list (#93 / #2-03-1)

Application

In the **Tooling list** table, the control displays information about all the tools called within an NC program. Before starting the program, you can check, for example, whether all tools are contained in the magazine.

Requirements

- Software option Advanced Tool Management (#93 / #2-03-1)
- Tool-usage file has been created
 - Further information:** "Creating the tool usage file", Page 174
 - Further information:** "Tool usage file", Page 380

Description of function

When you select an NC program in the **Program Run** operating mode, the control will automatically create the **Tooling list** table. The control displays the table in the **Tooling list** application in **Tables** operating mode. The control lists all the tools called within the active NC program and all the tools called within called NC programs in numerical order. You cannot edit the table.

The **Tooling list** table provides the following parameters:

Parameter	Meaning
T	Number of the tool used, including an index as needed Further information: "Indexed tool", Page 152 May differ from the programmed tool (e.g., when a replacement tool is used)
TOOL INFO	The control displays the following tool information: <ul style="list-style-type: none"> ■ OK: Tool is in order ■ Locked: Tool is locked ■ Not found: Tool is not defined in the pocket table Further information: "Pocket table tool_p.tch", Page 377 ■ T no. missing: Tool is not defined in the tool management Further information: "Tool carrier management", Page 167
T PROG	Number or name of the programmed tool, including an index as needed Further information: "Indexed tool", Page 152
M3/M4 TIME	Tool usage time from the TIME column of the tool usage file (in seconds) Time during which the tool is cutting a workpiece (excluding rapid traverse movements) Further information: "Tool usage file", Page 380
MAGAZINE	In this column, the control writes whether the tool is currently in the magazine or in the spindle. This column remains empty if the tool is a zero tool or not defined in the pocket table. Further information: "Pocket table tool_p.tch", Page 377

18.10 Preset table *.pr

Application

The **preset.pr** preset table allows you to manage presets, such as the position and misalignment of a workpiece in the machine. The active row in the preset table is used as a workpiece preset in the NC program and as the coordinate origin of the workpiece coordinate system **W-CS**.

Further information: "Presets in the machine", Page 142

Related topics

- Setting and activating presets

Further information: "Preset management", Page 194

Description of function

By default, the preset table has the name **preset.pr**, and is saved in the **TNC:\table** directory. The preset table is open in the **Tables** operating mode by default.





Refer to your machine manual.

The machine manufacturer can define a different path for the preset table.


In the optional machine parameter **basisTrans** (no. 123903), the machine manufacturer defines a specific preset table for each range of traverse.

Icons and buttons of the preset table

The preset table contains the following icons:

Icon	Meaning
	Active row
	Write-protected row

When you define a preset, the control opens a window with the following input options:

Icon or button	Function
	<p>actual position capture</p> <p>The control opens or closes the position display of the status overview.</p> <p>When you select an axis, the control applies the selected value at Set a preset.</p> <p>Further information: "actual position capture in the preset table", Page 390</p>
Set a preset	<p>The control interprets the entered value as desired display value for the actual position. The control calculates the required table value from this.</p> <p>The entered value is active in the basic coordinate system B-CS.</p> <p>Further information: "Basic coordinate system B-CS", Page 184</p> <p>When you activate the edited preset, the control displays the entered value as actual position in the position display.</p>
Correct	<p>The control offsets the entered value against the actual table value. You can enter either a positive or a negative value.</p> <p>The entered value is active incrementally in the basic coordinate system B-CS.</p>
Edit	<p>The control accepts the entered value unchanged as table value.</p> <p>The entered value refers to the coordinate origin of the basic coordinate system B-CS.</p>

Parameters of the preset table

The preset table contains the following parameters:

Parameter	Meaning
NO	Number of preset table row Input: 0...99999999
DOC	Comment Entry: Text width 16
X	X coordinate of preset Basic transformation relating to the basic coordinate system B-CS Further information: "Basic coordinate system B-CS", Page 184 Input: -99999.99999...+99999.99999
Y	Y coordinate of preset Basic transformation relating to the basic coordinate system B-CS Further information: "Basic coordinate system B-CS", Page 184 Input: -99999.99999...+99999.99999
Z	Z coordinate of preset Basic transformation relating to the basic coordinate system B-CS Further information: "Basic coordinate system B-CS", Page 184 Input: -99999.99999...+99999.99999
SPA	Spatial angle of preset in the A axis Basic transformation relating to the basic coordinate system B-CS Further information: "Basic coordinate system B-CS", Page 184 Has the effect of a 3D basic rotation for tool axis Z Further information: "Basic rotation and 3D basic rotation", Page 196 Input: -99999.99999999...+99999.99999999
SPB	Spatial angle of preset in the B axis Basic transformation relating to the basic coordinate system B-CS Further information: "Basic coordinate system B-CS", Page 184 Has the effect of a 3D basic rotation for tool axis Z Further information: "Basic rotation and 3D basic rotation", Page 196 Input: -99999.99999999...+99999.99999999
SPC	Spatial angle of preset in the C axis Basic transformation relating to the basic coordinate system B-CS Further information: "Basic coordinate system B-CS", Page 184 Has the effect of a basic rotation for tool axis Z Further information: "Basic rotation and 3D basic rotation", Page 196 Input: -99999.99999999...+99999.99999999
X_OFFS	Position of the X axis for the preset Offset relating to the machine coordinate system M-CS Further information: "Machine coordinate system M-CS", Page 182 Input: -99999.99999...+99999.99999
Y_OFFS	Position of the Y axis for the preset Offset relating to the machine coordinate system M-CS Further information: "Machine coordinate system M-CS", Page 182 Input: -99999.99999...+99999.99999

Parameter	Meaning
Z_OFFS	Position of the Z axis for the preset Offset relating to the machine coordinate system M-CS Further information: "Machine coordinate system M-CS", Page 182 Input: -99999.99999...+99999.99999
A_OFFS	Axis angle of the A axis for the preset Offset relating to the machine coordinate system M-CS Further information: "Machine coordinate system M-CS", Page 182 Input: -99999.9999999...+99999.9999999
B_OFFS	Axis angle of the B axis for the preset Offset relating to the machine coordinate system M-CS Further information: "Machine coordinate system M-CS", Page 182 Input: -99999.9999999...+99999.9999999
C_OFFS	Axis angle of the C axis for the preset Offset relating to the machine coordinate system M-CS Further information: "Machine coordinate system M-CS", Page 182 Input: -99999.9999999...+99999.9999999
U_OFFS	Position of the U axis for the preset Offset relating to the machine coordinate system M-CS Further information: "Machine coordinate system M-CS", Page 182 Input: -99999.99999...+99999.99999
V_OFFS	Position of the V axis for the preset Offset relating to the machine coordinate system M-CS Further information: "Machine coordinate system M-CS", Page 182 Input: -99999.99999...+99999.99999
W_OFFS	Position of the W axis for the preset Offset relating to the machine coordinate system M-CS Further information: "Machine coordinate system M-CS", Page 182 Input: -99999.99999...+99999.99999
ACTNO	Active workpiece preset The control automatically enters 1 in the active row. Input: 0, 1
LOCKED	Write-protection of the table row Entry: Text width 16



Refer to your machine manual.

In the optional machine parameter **CfgPresetSettings** (no. 204600), the machine manufacturer can block the setting of a preset in individual axes.

Basic transformation and offset

The control interprets the basic transformations **SPA**, **SPB** and **SPC** as basic rotation or 3D basic rotation in the workpiece coordinate system **W-CS**. During program execution, the control moves the linear axes in accordance with the basic rotation without any change in the workpiece position.

Further information: "Basic rotation and 3D basic rotation", Page 196

The control interprets all offsets for each respective axis as a shift in the machine coordinate system **M-CS**. The effect that offsets have is contingent on the kinematics.

Further information: "Machine coordinate system M-CS", Page 182



HEIDENHAIN recommends using 3D basic rotation because of its greater flexibility.

Application example

Use the **Rotation (ROT)** probing function to determine the misalignment of a workpiece. You can transfer the result to the preset table either as a basic transformation or as an offset.

Further information: "Determining and compensating the rotation of a workpiece", Page 302

Calculated results	Actual value	Nominal value
<input checked="" type="checkbox"/> Basic rotation	-360	<input type="text" value="0.00000"/>
<input type="checkbox"/> Table rotation	0	0.00000

Compensate the active preset

Align rotary table

Correct the pallet reference point

Results of the **Rotation (ROT)** probing function

If you activate the **Basic rotation** toggle switch, the control interprets the misalignment as a basic transformation. When using the **Compensate the active preset** button, the control saves the result in the columns **SPA**, **SPB** and **SPC** of the preset table. The **Align rotary table** button has no function in this case.

If you activate the **Table rotation** toggle switch, the control interprets the misalignment as an offset. When using the **Compensate the active preset** button, the control saves the result in the columns **A_OFFS**, **B_OFFS** and **C_OFFS** of the preset table. To move the rotary axes to the position of the offset, use the **Align rotary table** button.

Write-protection for table rows

The **Lock record** button allows protecting any rows of the preset table against overwriting. The control enters the value **L** in the **LOCKED** column.

Further information: "Protecting table rows without a password", Page 391

Alternatively, the row can be protected with a password. The control enters the value **###** into the **LOCKED** column.

Further information: "Protecting table rows with a password", Page 391

The control displays an icon ahead of write-protected rows.



If the control displays the value **OEM** in the **LOCKED** column, this column has been locked by the machine manufacturer.

NOTICE

Caution: Data may be lost!

Rows protected by a password can be unlocked by entering the selected password exclusively. Forgotten passwords cannot be reset. This would lock the protected rows permanently.

- ▶ Protecting table rows without a password is recommended
- ▶ Note down your passwords

18.10.1 actual position capture in the preset table


To load the actual position of an axis into the preset table:



- ▶ Activate the **Edit** toggle switch



- ▶ Double-tap or double-click the table row to be changed (e.g., in the **X** column)
- ▶ The control opens a window with input options.
- ▶ Select **actual position capture**
- ▶ The control opens the position display of the status overview.
- ▶ Select the desired value
- ▶ The control loads the value into the window and activates the **Set a preset** button.



- ▶ Select **OK**
- ▶ The control calculates the table value that is needed and enters the value in the table.
- ▶ If required, close the position display of the status overview

18.10.2 Activating write protection

Protecting table rows without a password

To protect a table row without a password:



- ▶ Activate the **Edit** toggle switch



- ▶ Select the desired row
- ▶ Activate the **Lock record** toggle switch
- > The control enters the value **L** in the **LOCKED** column.



- > The control activates write-protection and displays an icon ahead of the row.

Protecting table rows with a password

NOTICE

Caution: Data may be lost!

Rows protected by a password can be unlocked by entering the selected password exclusively. Forgotten passwords cannot be reset. This would lock the protected rows permanently.

- ▶ Protecting table rows without a password is recommended
- ▶ Note down your passwords

To protect a table row with a password:



- ▶ Activate the **Edit** toggle switch



- ▶ Double-tap or double-click the **LOCKED** column of the desired row
- ▶ Enter the password
- ▶ Confirm your input
- > The control enters the value **###** in the **LOCKED** column.



- > The control activates write-protection and displays an icon ahead of the row.

18.10.3 Removing write protection

Unlocking table rows that are protected without a password

To unlock a table row that is protected without a password:



- ▶ Activate the **Edit** toggle switch



- ▶ Deactivate the **Lock record** toggle switch
- > The control removes the value **L** from the **LOCKED** column.
- > The control deactivates the write protection and removes the icon ahead of the row.

Unlocking table rows that are protected with a password

NOTICE

Caution: Data may be lost!

Rows protected by a password can be unlocked by entering the selected password exclusively. Forgotten passwords cannot be reset. This would lock the protected rows permanently.

- ▶ Protecting table rows without a password is recommended
- ▶ Note down your passwords

To unlock a table row that is protected with a password:























- ▶ Activate the **Edit** toggle switch
- ▶ Double-tap or double-click the **LOCKED** column of the desired row
- ▶ Delete ###
- ▶ Enter the password
- ▶ Confirm your input
- > The control deactivates write-protection and removes the icon ahead of the row.

18.10.4 Creating a preset table in inches

If you define inches as the unit of measure in the **Machine Settings** menu item, the unit of measure of the preset table will not be adjusted automatically.

Further information: "The Machine Settings menu item", Page 439

To create a preset table in inches:

-  ▶ Restart the control
-  ▶ Do not acknowledge the **Power interrupted** message
-  ▶ Select the **Files** operating mode
-  ▶ Open the **TNC:\table** folder
-  ▶ Rename the original file (e.g., **preset.pr** as **preset_mm.pr**)
-  ▶ Select the **Tables** operating mode
-  ▶ Select **Create new table**
-  > The control opens the **Create new table** window.
-  ▶ Select the **pr** folder
-  ▶ Select the desired prototype
-  ▶ Select a path
-  > The control opens the **Save as** window.
-  ▶ Select the **table** folder
-  ▶ Enter the name **preset.pr**
-  ▶ Select **Create** twice
-  > The control opens the **Presets tab in the Tables** operating mode.
-  ▶ Restart the control
-  ▶ Acknowledge **Power interrupted** with the **CE** key
-  ▶ Select the **Presets** tab in the **Tables** operating mode
-  > The control uses the newly created table as a preset table.

Notes

NOTICE

Caution: Significant property damage!

Undefined fields in the preset table behave differently from fields defined with the value **0**: Fields defined with the value **0** overwrite the previous value when activated, whereas with undefined fields the previous value is kept. If the previous value is kept, there is a danger of collision!

- ▶ Before activating a preset, check whether all columns contain values.
- ▶ For undefined columns, enter values (e.g., **0**)
- ▶ As an alternative, have the machine manufacturer define **0** as the default value for the columns

- To optimize the file size and the processing speed, keep the preset table as short as possible.
- New rows can be inserted only at the end of the preset table.
- If you edit the value of the **DOC** column, then the preset must be reactivated. Only then does the control apply the new value.

Further information: "Activating presets", Page 196

- The control may feature a pallet preset table, depending on the machine. When a pallet preset is active, the presets in the preset table are referenced to this pallet preset.

Further information: User's Manual for Programming and Testing
- If a manual probing process or an NC program is interrupted or stopped, you cannot edit the preset table. When you double-tap or double-click a table cell the control shows the **Editing not possible. Perform internal stop?** window. If you select **Yes**, the control may lose touch points or modally active program information.

Notes about machine parameters

- In the optional machine parameter **initial** (no. 105603), the machine manufacturer defines a default value for every column of a new row.
- If the unit of measure of the preset table does not match the unit of measure defined in the machine parameter **unitOfMeasure** (no. 101101), the control displays a message in the dialog bar of the **Tables** operating mode.
- The machine manufacturer uses the optional machine parameter **preset-ToAlignAxis** (no. 300203) to define for each axis how the control is to interpret offsets in the following NC functions:
 - **FUNCTION PARAXCOMP**
 - **FUNCTION POLARKIN** (#8 / #1-01-1)
 - **FUNCTION TCPM** or **M128** (#9 / #4-01-1)

Further information: User's Manual for Programming and Testing

18.11 Tables for AFC (#45 / #2-31-1)

18.11.1 Basic AFC settings in AFC.tab

Application

In the **AFC.tab** table, you define the feed-rate control settings to be used by the control. This table must be saved in the **TNC:\table** directory.

Related topics

- Programming AFC

Further information: "Adaptive feed control (AFC) (#45 / #2-31-1)", Page 236

Requirement

- Adaptive Feed Control software option (AFC (#45 / #2-31-1))

Description of function

The data in this table are default values that, during a teach-in cut, are copied into an associated dependent file of the relevant NC program. The values are the basis for feedback control.

Further information: "Description of function", Page 398



If you define a tool-specific reference power in the **AFC-LOAD** column in the tool table, the control will create the associated dependent file for the respective NC program without a teach-in cut. The file is created shortly before feedback control becomes effective.

Parameter

The **AFC.tab** table provides the following parameters:

Parameter	Meaning
NR	Row number in the table Input: 0...9999
AFC	Name of the control setting Enter this name in the AFC tool management column. It specifies the assignment of the control parameters to the tool. Input: Text width 10
FMIN	Feed rate at which the control will perform an overload response Enter the value in percent of the programmed feed rate If the AFC.TAB columns FMIN and FMAX each have a value of 100%, Adaptive Feed Control is deactivated, but cut-related tool wear monitoring and tool load monitoring remain active. Further information: "Monitoring tool wear and tool load", Page 244 Input: 0...999
FMAX	Maximum feed rate within the material up to which the control can automatically increase the feed rate Enter the value in percent of the programmed feed rate If the AFC.TAB columns FMIN and FMAX each have a value of 100%, Adaptive Feed Control is deactivated, but cut-related tool wear monitoring and tool load monitoring remain active. Further information: "Monitoring tool wear and tool load", Page 244 Input: 0...999
FIDL	Feed rate at which the control will traverse the tool outside of the material Enter the value in percent of the programmed feed rate Input: 0...999
FENT	Feed rate at which the control will move the tool into and out of the material Enter the value in percent of the programmed feed rate Input: 0...999
OVLD	Desired reaction of the control to overload: <ul style="list-style-type: none"> ■ M: Execution of a macro defined by the machine manufacturer ■ S: Immediate NC stop ■ F: Execute NC stop when the tool is no longer in the material ■ E: Just display an error message on the screen ■ L: Disable active tool ■ -: No overload reaction <p>If the maximum spindle power is exceeded for more than one second and the feed rate falls below the defined minimum while feedback control is active, the control will conduct an overload reaction.</p> <p>In conjunction with the cut-related tool wear monitoring function, the control will evaluate only the options M, E, and L!</p> <p>For tool-load monitoring with the column AFC_OVLD2, this parameter has no function.</p> <p>Input: M, S, F, E, L, or -</p>

Parameter	Meaning
POUT	Spindle power at which the control will detect that the tool exits the workpiece Enter the value in percent of the learned reference load Recommended input value: 8% Input: 0...100
SENS	Sensitivity (aggressiveness) of feedback control 50 is for slow feedback control, 200 for a very aggressive feedback control. An aggressive feedback control responds quickly and significantly changes the values, but it tends to overshoot. Input: 0...999
PLC	Value that the control will transfer to the PLC at the beginning of a machining step The machine manufacturer defines whether and which function will be performed by the control. Input: 0...999

Notes

- If there is no AFC.TAB table in the **TNC:\table** directory, the control uses a permanently defined, internal control setting for the teach-in cut. If, alternatively, a tool-dependent reference power value exists, the control uses it immediately. HEIDENHAIN recommends using the AFC.TAB table in order to ensure safe and well-defined operation.
- The names of tables and table columns must start with a letter and must not contain an arithmetic operator (e.g., +). Due to SQL commands, these characters can cause problems when data are input or read.

Further information: User's Manual for Programming and Testing

18.11.2 AFC.DEP settings file for teach-in cuts

Application

With a teach-in cut, the control at first copies the basic settings for each machining step, as defined in the AFC.TAB table, to a file called **<name>.H.AFC.DEP**. The string **<name>** is identical to the name of the NC program for which you have recorded the teach-in cut. In addition, the control measures the maximum spindle power consumed during the teach-in cut and saves this value to the table.

Related topics

- AFC basic settings in the table **AFC.tab**
Further information: "Basic AFC settings in AFC.tab", Page 394
- Setting up and using AFC
Further information: "Adaptive feed control (AFC) (#45 / #2-31-1)", Page 236

Requirement


- Adaptive Feed Control software option (AFC (#45 / #2-31-1))

Description of function

Each row in the **<name>.H.AFC.DEP** file stands for a machining section, that you start with **FUNCTION AFC CUT BEGIN** and complete with **FUNCTION AFC CUT END**. You can edit all data of the **<name>.H.AFC.DEP** file for optimization purposes. If you have optimized the values from the AFC.TAB table, the control places a ***** in front of these control settings in the AFC column.

Further information: "Basic AFC settings in AFC.tab", Page 394

In addition to the contents from the **AFC.tab** table, the **AFC.DEP** file provides the following information:

Column	Function
NR	Number of the machining step
TOOL	Number or name of the tool with which the machining step was performed (not editable)
	<div style="border: 1px solid black; padding: 5px;">  In conjunction with AFC (#45 / #2-31-1), the following characters are not permitted in the tool name: # \$ & , . </div>
IDX	Index of the tool with which the machining step was performed (not editable)
N	Difference for tool call: <ul style="list-style-type: none"> ■ 0: Tool was called by its tool number ■ 1: Tool was called by its tool name
PREF	Reference load of the spindle. The control measures the value in percent with respect to the rated spindle power
ST	Status of the machining step: <ul style="list-style-type: none"> ■ L: In the next program run, a teach-in cut is recorded for this machining step. The control overwrites any existing values in this row ■ C: The teach-in cut was completed successfully. The next program run can be conducted with automatic feed control
AFC	Name of the control setting

Notes

- Note that the **<name>.H.AFC.DEP** file is locked against editing as long as the NC program **<name>.H** is running.

The control does not remove the editing lock until one of the following functions has been executed:

- **M2**
- **M30**
- **END PGM**
- In the settings of the **Files** operating mode, you can specify whether the control displays dependent files in the file management.

Further information: User's Manual for Programming and Testing

18.11.3 Log file AFC2.DEP

Application

The control stores various pieces of information for each machining step of a teach-in cut in the **<name>.H.AFC2.DEP** file. The string **<name>** is identical to the name of the NC program for which you have recorded the teach-in cut. During feedback control, the control updates the data and performs various evaluations.

Related topics

- Setting up and using AFC

Further information: "Adaptive feed control (AFC) (#45 / #2-31-1)", Page 236

Requirement

- Adaptive Feed Control software option (AFC (#45 / #2-31-1))

Description of function

The **AFC2.DEP** file provides the following information:

Column	Function
NR	Number of the machining step
TOOL	Number or name of the tool with which the machining step was performed
IDX	Index of the tool with which the machining step was performed
SNOM	Nominal spindle speed [rpm]
SDIFF	Maximum difference of the spindle speed in % of the nominal speed
CTIME	Machining time (tool in effect)
FAVG	Average feed rate (tool in effect)
FMIN	Smallest occurring feed factor. The control shows the value as a percentage of the programmed feed rate
PMAX	Maximum recorded spindle power during machining. The control shows the value as a percentage of the spindle's rated power
PREF	Reference load of the spindle. The control shows the value as a percentage of the spindle's rated power
OVL	Overload reaction performed by the control: <ul style="list-style-type: none"> ■ M: A macro defined by the machine manufacturer has been run ■ S: Immediate NC stop was conducted ■ F: NC stop was performed once the tool was no longer in the material ■ E: An error message was displayed ■ L: The current tool was locked ■ -: There was no overload response
BLOCK	Block number at which the machining step begins



During feedback control, the control determines the current machining time as well as the resulting time saving in percent. The control enters the results of the evaluation between the key words **total** and **saved** in the last line of the log file. Where the time balance is positive, the percentage value is also positive.

Note

In the settings of the **Files** operating mode, you can specify whether the control displays dependent files in the file management.

Further information: User's Manual for Programming and Testing

18.11.4 Editing the tables for AFC

You can open and, if necessary, edit the tables for AFC during program run. The control provides only the tables of the active NC program.

To open a table for AFC:



- ▶ Select the **Program Run** operating mode



- ▶ Select **AFC settings**
- > The control displays a selection menu. The control displays all the tables available for this NC program.
- ▶ Select a file (e.g., **AFC.TAB**)
- > The control opens the file in the **Tables** operating mode.

19

**Electronic
Handwheel**

19.1 Fundamentals

Application

If you want to approach a position in the machine's working space while the guard door is open or if you execute a small infeed movement, you can use the electronic handwheel. The electronic handwheel allows you to traverse the axes and perform various functions provided by the control.

Related topics

- Incremental jog positioning
Further information: "Incremental jog positioning of axes", Page 137
- Handwheel superimpositioning with **M118** (#21 / #4-02-1)
Further information: User's Manual for Programming and Testing
Further information: User's Manual for Programming and Testing
- Touch probe functions in **Manual** (#17 / #1-05-1) operating mode
Further information: "Touch Probe Functions in the Manual Operating Mode (#17 / #1-05-1)", Page 289

Requirement

- Electronic handwheel (e.g., HR 550FS)
The control supports the following electronic handwheels:
 - HR 410: Cable-bound handwheel without display
 - HR 420: Cable-bound handwheel with display
 - HR 510: Cable-bound handwheel without display
 - HR 520: Cable-bound handwheel with display
 - HR 550FS: Wireless handwheel with display, data transmission via radio

Description of function

You can use electronic handwheels in **Manual** or **Program Run** operating mode.

The HR 520 and HR 550FS portable handwheels feature a display that allows the control to show different types of information. You can use the handwheel soft keys for setup functions, such as the setting of presets or the activation of miscellaneous functions.

Once you have activated the handwheel with the handwheel activation key or the **Handwheel** toggle switch, you can operate the control only by using the handwheel. If you press the axis keys in this state, the control will display the message **Handwheel active: Handwheel-1, MB0**.

If you select **Manual** operating mode, the control deactivates the handwheel.

If more than one handwheel is connected to a control, you can activate or deactivate a handwheel only by pressing the handwheel activation key on the respective handwheel. You need to deactivate the active handwheel in order to be able to select another handwheel.

Functions in Program Run operating mode


You can perform the following functions in **Program Run** operating mode:

- The **NC Start** key (**NC Start** handwheel key)
- The **NC Stop** key (**NC Stop** handwheel key)
- After you have pressed the **NC Stop** key: Internal stop (handwheel soft keys **MOP** and then **Stop**)
- After you have pressed the **NC Stop** key: Manual traverse of axes (handwheel soft keys **MOP** and then **MAN**)
- Return to the contour after axes were manually traversed during an interruption of the program run (handwheel soft keys **MOP** and then **REPO**). The handwheel soft keys are used for operating.

Further information: "Returning to the contour", Page 343

- Switch on/off the "Tilt working plane" function (handwheel soft keys **MOP** and then **3D**)

Operating elements of an electronic handwheel




An electronic handwheel provides the following operating elements:

- 1 **EMERGENCY STOP** key
- 2 Handwheel display for status and for selecting functions
- 3 Handwheel soft keys
- 4 Axis keys; can be exchanged by the machine manufacturer depending on the axis configuration
- 5 Permissive button
The permissive button is on the rear side of the handwheel.
- 6 Arrow keys for defining the handwheel resolution
- 7 Handwheel activation key
You can activate or deactivate the handwheel.

- 8 Axis-direction key
Key for the direction of the traverse motion
- 9 Rapid traverse override for the traverse motion
- 10 Spindle switch-on (machine-dependent function, key can be exchanged by the machine manufacturer)
- 11 **Generate NC block** key (machine-dependent function, key can be exchanged by the machine manufacturer)
- 12 Spindle switch-off (machine-dependent function, key can be exchanged by the machine manufacturer)
- 13 **CTRL** key for special functions (machine-dependent function, key can be exchanged by the machine manufacturer)
- 14 **NC Start** key (machine-dependent function, key can be exchanged by the machine manufacturer)
- 15 **NC Stop** key
Machine-dependent function; key can be exchanged by the machine manufacturer
- 16 Handwheel
- 17 Spindle speed potentiometer
- 18 Feed rate potentiometer
- 19 Cable connection; not required for the HR 550FS wireless handwheel

Contents of an electronic handwheel display



The display of an electronic handwheel consists of the following areas:

- 1 Handwheel is in the docking station or radio mode is active
Only with HR 550FS wireless handwheel
- 2 Field strength
Six bars = maximum field strength
Only with HR 550FS wireless handwheel
- 3 Charging condition of battery
Six bars = maximum charging condition. A bar moves from the left to the right during recharging.
Only with HR 550FS wireless handwheel
- 4 **X+50.000**: Position of the selected axis

- 5 *: Control in operation; program run has been started or axis is in motion
- 6 Handwheel superimpositioning from **M118** (#21 / #4-02-1)
Further information: User's Manual for Programming and Testing
- 7 **S1000:** Current spindle speed
- 8 Feed rate at which the selected axis is moving
 The control displays the current contouring feed rate while the program is running.
- 9 **E:** Error message
 If an error message appears on the control, the handwheel display shows the **ERROR** message for three seconds. Then the letter **E** is shown in the display as long as the error is pending on the control.
- 10 Active setting in the **3-D rotation** window:
 ■ **VT:** function **Tool axis**
 ■ **WP:** function **Basic rotation**
 ■ **WPL:** **3D ROT** function
Further information: "The 3-D rotation window (#8 / #1-01-1)", Page 201
- 11 Handwheel resolution
 Distance that the selected axis moves per handwheel revolution
Further information: "Handwheel resolution", Page 406
- 12 Incremental jog active or inactive
 If the function is active, the control will display the active traverse step.
- 13 Soft-key row
 The soft key row provides the following functions:
 ■ **AX:** Select the machine axis
Further information: "Creating a positioning block", Page 408
 ■ **STEP:** Incremental jog positioning
Further information: "Incremental jog positioning", Page 408
 ■ **MSF:** Execute various functions of the **Manual** operating mode (e.g., entering the feed rate **F**)
Further information: "Entering miscellaneous functions M", Page 407
 ■ **OPM:** Select the operating mode
 ■ **MAN:** **Manual** operating mode
 ■ **MDI:** **MDI** application in **Manual** operating mode
 ■ **RUN:** **Program Run** operating mode
 ■ **SGL:** **Single Block** mode of the **Program Run** operating mode
 ■ **MA:** Switching the magazine pockets

Handwheel resolution

The handwheel sensitivity specifies the distance an axis moves per handwheel revolution. The handwheel sensitivity results from the defined handwheel speed of the axis and the speed level used internally by the control. The speed level describes a percentage of the handwheel speed. The control calculates a specific handwheel sensitivity value for each speed level. The resulting handwheel sensitivity values are directly selectable with the handwheel arrow keys (only if incremental jog is not active).

The handwheel speed indicates the increment (e.g., 0.01 mm) traversed per handwheel detent position. You can change the handwheel speed with the handwheel's arrow keys.

If you have defined a handwheel speed of 1, the following handwheel resolutions are available:

Resulting handwheel sensitivity levels in mm/revolution and degrees/revolution:
0.0001/0.0002/0.0005/0.001/0.002/0.005/0.01/0.02/0.05/0.1/0.2/0.5/1

Resulting handwheel sensitivity levels in inches/revolution:

0.000127/0.000254/0.000508/0.00127/0.00254/0.00508/0.0127/0.0254/0.0508/0.127/0.254/0.508

Examples for resulting handwheel sensitivity values:

Defined handwheel speed	Speed level	Resulting handwheel sensitivity
10	0.01%	0.001 mm/revolution
10	0.01%	0.001 degrees/revolution
10	0.0127%	0.00005 inches/revolution

Effect of the feed-rate potentiometer when handwheel is active

NOTICE

Caution: Possible damage to the workpiece!

When toggling between the machine operating panel and the handwheel, the feed rate may be reduced. This can cause visible marks on the workpiece.

- ▶ Make sure to retract the tool before toggling between the handwheel and the machine operating panel.

The settings of the feed-rate potentiometer on the handwheel may differ from those on the machine operating panel. When you activate the handwheel, the control automatically activates the feed-rate potentiometer of the handwheel. When you deactivate the handwheel, the control automatically activates the feed-rate potentiometer of the machine operating panel.

In order to make sure that the feed rate does not increase while you switch between the potentiometers, the feed rate is either frozen or reduced.

If the feed rate before switching is higher than the feed rate after switching, the control automatically reduces the feed rate to the smaller value.

If the feed rate before switching is less than the feed rate after switching, the control automatically freezes the feed rate. In this case, you must turn the feed-rate potentiometer back to the previous value because the activated feed-rate potentiometer will only then be effective.

19.1.1 Entering spindle speed S

To enter the spindle speed **S** by using an electronic handwheel:

- ▶ Press the handwheel soft key **F3 (MSF)**
- ▶ Press the handwheel soft key **F2 (S)**
- ▶ Select the desired spindle speed by pressing the **F1** or **F2** key
- ▶ Press the **NC Start** key
- > The control activates the entered spindle speed.

i If you press and hold the **F1** or **F2** key, the control will increase the counting increment by a factor of 10 each time it reaches a decimal value of 0.

By additionally pressing the **CTRL** key, you can increase the counting increment by a factor of 100 when pressing **F1** or **F2**.

19.1.2 Entering the feed rate F

To enter the feed rate **F** by using an electronic handwheel:

- ▶ Press the handwheel soft key **F3 (MSF)**
- ▶ Press the handwheel soft key **F3 (F)**
- ▶ Select the desired feed rate by pressing the **F1** or **F2** key
- ▶ Load the new feed rate **F** with the handwheel soft key **F3 (OK)**

i If you press and hold the **F1** or **F2** key, the control will increase the counting increment by a factor of 10 each time it reaches a decimal value of 0.

By additionally pressing the **CTRL** key, you can increase the counting increment by a factor of 100 when pressing **F1** or **F2**.

19.1.3 Entering miscellaneous functions M

To enter a miscellaneous function by using an electronic handwheel:

- ▶ Press the handwheel soft key **F3 (MSF)**
- ▶ Press the handwheel soft key **F1 (M)**
- ▶ Select the desired M function number by pressing the **F1** or **F2** key
- ▶ Press the **NC Start** key
- > The control activates the miscellaneous function

Further information: User's Manual for Programming and Testing

19.1.4 Creating a positioning block



Refer to your machine manual.

Your machine manufacturer can assign any function to the **Generate NC block** handwheel key.

To create a positioning block by using an electronic handwheel:



- ▶ Select the **Manual** operating mode
- ▶ Select the **MDI** application
- ▶ If necessary, select the NC block after which the positioning block should be inserted
- ▶ Activate the handwheel



- ▶ Press the **Generate NC block** key on the handwheel
- > The control inserts a straight line **L**, including all of the axis positions.

19.1.5 Incremental jog positioning

Incremental jog positioning allows you to move the selected axis by a preset value.

To incrementally position an axis by using an electronic handwheel:

- ▶ Press the handwheel soft key F2 (**STEP**)
- ▶ Press the handwheel soft key 3 (**ON**)
- > The control activates incremental jog positioning.
- ▶ Set the desired jog increment by using the **F1** or **F2** keys



The smallest possible increment is 0.0001 mm (0.00001 inches). The largest possible increment is 10 mm (0.3937 inches).

- ▶ Confirm the selected jog increment by pressing the handwheel soft key F4 (**OK**)
- ▶ Use the **+** or **-** handwheel key to move the active handwheel axis in the corresponding direction
- > The control moves the active axis by the entered increment every time the handwheel key is pressed.



If you press and hold the **F1** or **F2** key, the control will increase the counting increment by a factor of 10 each time it reaches a decimal value of 0.

By additionally pressing the **CTRL** key, you can increase the counting increment by a factor of 100 when pressing **F1** or **F2**.

Notes

⚠ DANGER

Caution: hazard to the user!

Unsecured connections, defective cables, and improper use are always sources of electrical dangers. The hazard starts when the machine is powered up!

- ▶ Devices should be connected or removed only by authorized service technicians
- ▶ Only switch on the machine via a connected handwheel or a secured connection

NOTICE


Caution: Danger to the tool and workpiece!

The wireless handwheel triggers an emergency stop reaction if the radio transmission is interrupted, the battery is fully empty, or if there is a defect. Emergency stop reactions during machining can cause damage to the tool or workpiece.

- ▶ Place the handwheel in the handwheel holder when it is not in use
- ▶ Keep the distance between the handwheel and the handwheel holder small (pay attention to the vibration alarm)
- ▶ Test the handwheel before machining

- The machine manufacturer can provide additional functions for the HR5xx handwheels.
Refer to your machine manual.
- You can use the axis keys to activate the **X**, **Y**, and **Z** axes, as well as three other axes that can be defined by the machine manufacturer. Your machine manufacturer can also place the virtual axis **VT** on one of the free axis keys.
- If the handwheel is active, the control shows a symbol next to the selected axis in the **Positions** workspace. The symbol indicates whether you can move the axis with the handwheel.

Further information: "The Positions workspace", Page 97

 Refer to your machine manual.
The machine manufacturer defines which axes you can move with the handwheel.

19.2 HR 550FS wireless handwheel

Application

With the HR 550FS wireless handwheel and its radio transmission characteristics, you can move farther away from the machine operating panel than with other handwheels. The HR 550FS wireless handwheel thus provides an important benefit, in particular for large machines.

Description of function

The HR 550FS wireless handwheel comes fitted with a rechargeable battery. The battery starts charging when you place the handwheel into the holder.

The HRA 551FS handwheel holder and the HR 550FS handwheel together form one function unit.



HR 550FS handwheel



HRA 551FS handwheel holder

The HR 550FS handwheel can be operated by battery for up to eight hours before it needs recharging. A completely discharged handwheel takes approx. three hours for a full charge. When you do not use the HR 550FS, always place it into the handwheel holder. This charges the handwheel battery constantly and a direct connection with the emergency-stop circuit is provided.

When the handwheel is in its holder, it provides the same functionality as during radio mode. This allows you to use a completely discharged handwheel.



Clean the contacts of the handwheel holder and handwheel regularly to ensure their proper functioning.

If the control has triggered an emergency stop, you must reactivate the handwheel.

Further information: "Reactivating the handwheel", Page 414

If you happen to get close to the limit of the transmission range, the HR 550FS will set off a vibrating alarm. If this occurs, you must reduce the distance to the handwheel holder.

Note

DANGER

Caution: hazard to the user!

Wireless handwheels, due to their rechargeable batteries and the influence of other wireless devices, are more susceptible to interference than cable-bound connections are. Ignoring the requirements for and information about safe operation leads to endangerment of the user, for example during installation or maintenance work.

- ▶ Check the radio connection of the handwheel for possible overlapping with other wireless devices
- ▶ Switch off the wireless handwheel and the handwheel holder after an operating time of 120 hours at the latest so that the control can run a functional test when it is restarted
- ▶ If more than one wireless handwheel is being used in a workshop, then ensure an unambiguous assignment between the handwheels and the handwheel holders (such as with color-coded stickers)
- ▶ If more than one wireless handwheel is being used in a workshop, then ensure an unambiguous assignment between the handwheels and the respective machine (such as with a functional test)

19.3 The Configuration of wireless handwheel window

Application


The **Configuration of wireless handwheel** window shows the connection data of the HR 550FS wireless handwheel and provides various functions for optimizing the radio connection, such as setting the radio channel.

Related topics

- Electronic handwheel
Further information: "Electronic Handwheel", Page 401
- HR 550FS wireless handwheel
Further information: "HR 550FS wireless handwheel", Page 410

Description of function

Use the **Set Up Wireless Handwheel** menu item to open the **Configuration of wireless handwheel** window. The menu item is in the **Machine Settings** group of the **Settings** application.



Areas of the Configuration of wireless handwheel window

The Configuration area

In the **Configuration** area, the control displays different types of information about the connected wireless handwheel, such as the serial number.

The Statistics area

In the **Statistics** area, the control displays information about the transmission quality.

If the received signal quality is impaired and no longer ensures a perfect, safe stop of the axes, the wireless handwheel will perform an emergency stop.

A high value under **Max. successive lost** is an indication of a limited quality of reception. If the control repeatedly displays values greater than 2 during normal operation of the wireless handwheel within the desired range of use, there is a high risk of undesired disconnection.

If this occurs, try to improve the transmission quality by selecting a different channel or by increasing the transmitter power.

Further information: "Setting the radio channel", Page 414

Further information: "Selecting the transmission power", Page 413

The Status area

In the **Status** area, the control displays the current status of the handwheel, such as **HANDWHEEL ONLINE** and pending error messages concerning the connected handwheel.

19.3.1 Assigning a handwheel to a handwheel holder

In order to assign a handwheel to a handwheel holder, the handwheel holder must be connected to the control hardware.

To assign a handwheel to a handwheel holder:

- ▶ Place the handwheel into the handwheel holder



- ▶ Select the **Home** operating mode



- ▶ Select the **Settings** application



- ▶ Select the **Machine Settings** group



- ▶ Double-tap or double-click the **Set Up Wireless Handwheel** menu item
- > The control opens the **Configuration of wireless handwheel** window.
- ▶ Select the **Connect HW** button
- > The control saves the serial number of the inserted wireless handwheel and displays it in the configuration window to the left of the **Connect HW** button.
- ▶ Select the **END** button
- > The control saves the configuration.

19.3.2 Selecting the transmission power

If you reduce the transmission power, the range of the wireless handwheel will decrease.


To set the transmission power of the handwheel:



- ▶ Open the **Configuration of wireless handwheel** window
- ▶ Select the **Set power** button
- > The control displays the three available power settings.
- ▶ Select the desired transmission power setting
- ▶ Select the **END** button
- > The control saves the configuration.

19.3.3 Setting the radio channel

If the wireless handwheel is started automatically, then the control tries to select the radio channel providing the best radio signal.



To set the radio channel manually:



- ▶ Open the **Configuration of wireless handwheel** window
- ▶ Select the **Frequency spectrum** tab
- ▶ Select the **Stop HW** button
- ▶ The control stops the connection to the wireless handwheel and determines the current frequency spectrum for all 16 available channels.
- ▶ Note the number of the channel with the least amount of radio traffic



The smallest bar indicates the channel with the least amount of radio traffic.

- ▶ Select the **Start handwheel** button
- ▶ The control restores the connection to the wireless handwheel.
- ▶ Select the **Properties** tab
- ▶ Select the **Select channel** button
- ▶ The controls shows all available channel numbers.
- ▶ Select the number of the channel with the least amount of radio traffic
- ▶ Select the **END** button
- ▶ The control saves the configuration.

19.3.4 Reactivating the handwheel

To reactivate the handwheel:



- ▶ Open the **Configuration of wireless handwheel** window
- ▶ Use the **Start handwheel** button to reactivate the wireless handwheel
- ▶ Select the **END** button

20 Override Controller

Application

The override controller is an operating element with additional functions compared to a usual override potentiometer.

In conjunction with the override controller, the control gives you the following possibilities:


- Use the dial to manipulate the feed rate and/or rapid traverse
- Start NC programs with the integrated **NC Start** button
- Receive tactile responses through vibrations
- Use breakpoints to define conditional stops
- Resume the NC program by increasing the override

Requirements

- Override controller OC 310
The availability of the Override Controller depends on the machine.
Refer to your machine manual.
- Control is fully booted
The control only detects the override controller once the machine control voltage has been acknowledged.
- Tool inspection has been performed
Further information: "The Tool check column in the Program workspace",
Page 175

Description of function

Elements of the override controller



The override controller consists of the following elements:

- 1 Override scale
The override scale is illuminated in color up to the current override value.
Further information: "Visual feedback from the override controller", Page 416
- 2 The **NC Start** button
The **NC Start** button starts the NC program.
Depending on the setting in the **Program run options** window, the NC program can be continued with the **NC Start** button.
- 3 Dial
Use the dial to change the override for the feed rate and/or rapid traverse.
Depending on the setting in the **Program run options** window, the NC program can be continued with the Override.

Visual feedback from the override controller

The override controller uses the following visual feedback:

Status	Override scale
Override Controller not active (e.g., because of an emergency stop)	Not illuminated
Override value of 0%	Not illuminated
Override value between 0% and 99.5%	White
Override value of 100%	Green
Override value greater than 100.5%	Blue


The **NC Start** button lights up green. The actual color may differ, depending on the machine.

Tactile feedback from the override controller

The override controller uses the following tactile feedback:

Status	Acknowledgment
Minimum or maximum override value	The override controller vibrates as soon as the minimum or maximum override value is reached.
Override value of 100%	The override controller vibrates as soon as the override value is at 100%.
Stop at the breakpoint	The override controller vibrates as soon as the control stops at a breakpoint.

The Program run options window







The **Program run options** window

You can open the **Program run options** window as follows:


- In the **Program Run** operating mode with the **Program run options** button
Further information: "Icons and buttons", Page 326
- In the **Simulation** workspace with the **Program run options** toggle switch in the **Visualization options** column
Further information: User's Manual for Programming and Testing

The following settings of the **Program run options** window are relevant for the override controller:

Icon or button	Meaning
	<p>Feed rate retained, press to resume</p> <p>When this button is active, the control does not change the override value when stopping at a breakpoint. Continue the NC program by pushing the NC Start button.</p>
	<p>Feed rate set to 0%, press and turn to resume</p> <p>When this button is active, the control changes the override value to 0% when stopping at a breakpoint. Continue the NC program by pushing the NC Start button and increasing the override value.</p>

Icon or button	Meaning
	<p>Feed rate set to 0%, turn to resume</p> <p>When this button is active, the control changes the override value to 0% when stopping at a breakpoint. Continue the NC program by increasing the override value.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p> Refer to your machine manual. The machine manufacturer uses the optional machine parameter resumeByTurning (no. 141801) to define if this button is available.</p> </div>



Perform conditional stop Toggle switch for activating and deactivating breakpoints
Further information: "Breakpoints", Page 419

 The following functions are available also without the override controller:

- **Feed rate F LIMIT**
Further information: "Feed rate limit F LIMIT", Page 328
- **Skip block**
Further information: User's Manual for Programming and Testing
- **Pause at M1**
Further information: User's Manual for Programming and Testing

Breakpoints

The control offers the following breakpoints:

Breakpoint	Meaning
Before switch to rapid traverse	The control stops at each change from the feed rate F to rapid traverse FMAX .
Before switch to feed rate	The control stops at each change from rapid traverse FMAX to the feed rate F .
Between two rapid traverses	The control stops between two directly sequential FMAX rapid traverse movements.
Before tool call	The control stops before every physical tool call with TOOL CALL . <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p> The control does not stop, for example, before a TOOL CALL that simply changes the spindle speed.</p> </div>
Before tilting the working plane	The control stops before NC blocks with the following syntax elements: <ul style="list-style-type: none"> ■ PLANE functions (#8 / #1-01-1) ■ M128 (#9 / #4-01-1) ■ FUNCTION TCPM (#9 / #4-01-1) ■ Cycle 19 WORKING PLANE (#8 / #1-01-1) <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p> You can still run NC programs from earlier controls that contain Cycle 19 WORKING PLANE.</p> </div>



Breakpoint	Meaning
Before cycle call	<p>The control stops before NC blocks with the following syntax elements:</p> <ul style="list-style-type: none"> ■ M89 The control stops before each machining position. ■ M99 ■ CYCL CALL ■ CYCL CALL POS ■ CYCL CALL PAT The control stops before each machining position. ■ Cycles 220 POLAR PATTERN, 221 CARTESIAN PATTERN, 224 DATAMATRIX CODE PATTERN The control stops before each machining position.
In cycle call	<p>Stop before the first infeed</p> <p>In the cycles below, the control stops before the first infeed:</p> <ul style="list-style-type: none"> ■ Cycles for drilling and thread machining Further information: User's Manual for Machining Cycles ■ Cycle 255 ENGRAVING Further information: User's Manual for Machining Cycles
	<p>Stop before every infeed</p> <p>In the cycles below, the control stops before every infeed:</p> <ul style="list-style-type: none"> ■ Milling Cycles Further information: User's Manual for Machining Cycles
	<p>No stop</p> <p>The control will not stop in the following cycles:</p> <ul style="list-style-type: none"> ■ Programmable touch probe cycles (#17 / #1-05-1) Further information: User's Manual for Measuring Cycles for Workpieces and Tools ■ Cycle 239 ASCERTAIN THE LOAD (#143 / #2-22-1) Further information: User's Manual for Machining Cycles ■ Cycle 238 MEASURE MACHINE STATUS (#155 / #5-02-1) Further information: User's Manual for Machining Cycles

The control displays active breakpoints on the **PGM** tab of the **Status** workspace.

Further information: "PGM tab", Page 111

Displaying breakpoints

The control displays breakpoints with the following icons:

Icon	Meaning
	<p>Active stop</p> <p>The control has detected a breakpoint and stops program run or the simulation at this point.</p>
	<p>Inactive stop</p> <p>The control has detected a breakpoint but does not stop program run or the simulation at this point. In order to stop before this NC block, you must first activate the corresponding toggle switch in the Program run options window.</p> <p>Further information: "The Program run options window", Page 418</p>

The control displays the icons for breakpoints in the NC program before the block number as soon as at least one conditional stop is active in the **Program run options** window.

When you select an icon, the control displays the name of the associated breakpoint.

Notes

- The override controller is also effective as a feed rate and/or rapid traverse override in the **Manual** operating mode.
- If the NC program contains breakpoints, the control displays a check mark in the **Perform conditional stop** area of the **Tool check** column.
Further information: "The Tool check column in the Program workspace", Page 175
- If you turn the override controller down with a sudden jerk, the control will automatically set the override value to 0%, even if the override controller has not reached that position.
- When the execution cursor reaches a breakpoint, the two icons overlap so you can see why the control stops.
- If the **Feed rate set to 0%, turn to resume** button is active, the control reacts as follows:
 - You can continue the NC program only following a conditional stop and by increasing the override value. Otherwise an **NC Start** is necessary (e.g., when starting a program).
 - When the NC program includes two subsequent conditional stops, the 0% override value cannot be changed for 0.3 seconds. This way, the control ensures that you will not continue beyond both conditional stops by just one movement of the Override Controller.
 - After a conditional stop with a manual tool change you must press the **NC Start** button. You can't continue the NC program by increasing the override value.

Notes about machine parameters

Refer to your machine manual.

- The machine manufacturer defines the maximum override value for rapid traverse. If the maximum override value is, for example, 100% and you enter a rapid-traverse override value greater than 100%, the control still calculates with 100%. If you turn the dial down in this case, then there is no immediate effect. Only once the override controller actually reaches 100% will the control change the override value.
- The machine manufacturer can use the optional machine parameter **ocWaitTime** (no. 103412) to define whether a waiting time will be effective in the cases below:
 - When the program is continued at 0% after a breakpoint
 - When 100% of the override value is reached

21

**Embedded
Workspace
and Extended
Workspace**

21.1 Embedded Workspace (#133 / #3-01-1)

Application

You use Embedded Workspace to operate a Windows PC and display its screen contents on the control's user interface. You use Remote Desktop Manager to connect the Windows PC (#133 / #3-01-1).

Related topics

- Remote Desktop Manager (#133 / #3-01-1)
Further information: "The Remote Desktop Manager window (#133 / #3-01-1)", Page 477
- Using Extended Workspace to operate a Windows PC through an additional connected monitor
Further information: "Extended Workspace", Page 426

Requirements

- Established RemoteFX connection to the Windows PC through Remote Desktop Manager (#133 / #3-01-1)
- Connection defined in the machine parameter **CfgRemoteDesktop** (no. 133500)
In the optional machine parameter **connections** (no. 133501), the machine manufacturer enters the name of the RemoteFX connection.
Refer to your machine manual.

Description of function

Embedded Workspace is available on the control as an operating mode and as a workspace. If the machine manufacturer does not define a name, then the operating mode and workspace are both named **RDP**.


Entries cannot be made through the Windows PC as long as the RemoteFX connection is active. This avoids the problem of conflicting operation.

Further information: "Windows Terminal Service (RemoteFX)", Page 478

If you open Embedded Workspace as an operating mode, the control displays a full-screen version of the Windows PC user interface in it.

If you open Embedded Workspace as a workspace, you can change the size and position of the workspace as you wish. The control rescales the user interface of the Windows PC after each modification.

Further information: "Workspaces", Page 66



Embedded Workspace as workspace with opened PDF file

The RDP settings window

If Embedded Workspace is open as a workspace, you can open the **RDP settings** window.

The **RDP settings** window contains the following buttons:

Button	Meaning
Reconnect	If the control could not establish a connection to the Windows PC, for example due to a timeout, press this button to try again. The control can also display this button in the operating mode and the workspace.
Adjust resolution	With this button the control rescales the user interface of the Windows PC to the size of the workspace.

21.2 Extended Workspace

Application

With Extended Workspace you can use an additional attached monitor as a second screen of the control. That way you can use the additional monitor independently of the control's user interface and also to show the control's applications.

Related topics

- Using Embedded Workspace to operate a Windows PC within the control's user interface (#133 / #3-01-1)

Further information: "Embedded Workspace (#133 / #3-01-1)", Page 424

- ITC hardware expansion

Further information: "Hardware enhancements", Page 61

Requirement

- Additional attached monitor configured by the machine manufacturer as Extended Workspace
Refer to your machine manual.

Description of function

Here are some functions you can perform with Extended Workspace:

- Opening files from the control (e.g., drawings)
- Opening windows from HEROS functions in addition to the control's user interface

Further information: "HEROS menu", Page 526

- Displaying and operating computers connected through Remote Desktop Manager (#133 / #3-01-1)

Further information: "The Remote Desktop Manager window (#133 / #3-01-1)", Page 477

22

**Integrated
Functional Safety
(FS)**

Application

The safety concept of integrated functional safety (FS) for machines with HEIDENHAIN controls offers supplementary software safety functions in addition to the mechanical safety features of the machine. For example, the integrated safety concept automatically reduces the feed rate when you perform operations with open guard doors. The machine manufacturer can modify or expand the FS safety concept.

Requirements

- On controls with **SIK1**:
 - Integrated functional safety (FS, basic version; software option 160) or Integrated functional safety (FS, full version; software option 161)
 - Software options 162 to 166 or software option 169, if necessary
Whether you need these software options depends on the machine's number of drives.
- On controls with **SIK2**:
 - Software option FS, basic version (#6-30-1)
 - Software option FS, Safe axes (#6-30-2), if applicable
If your control is equipped with **SIK2**, software option #6-30-1 will enable four safe axes. You can order software option #6-30-2* multiple times and thus enable up to six additional safe axes.
- The machine manufacturer must adapt the FS safety concept to the machine.

Description of function

Every machine tool user is exposed to certain risks. While protective devices can prevent access to dangerous locations, the user must also be able to work on the machine without this protection (e.g., guard door opened).

Safety functions

To ensure that the requirements for operator protection are met, integrated functional safety (FS) provides standardized safety functions. The machine manufacturer uses the standardized safety functions for implementing functional safety (FS) for the machine in question.

You can track the active safety functions in the axis status of functional safety (FS).


Further information: "The Axis status menu item", Page 431

Description	Meaning	Short description
SS0, SS1, SS1D, SS1F, SS2	Safe Stop	Safe stopping of drives using different methods
STO	Safe Torque Off	The power supply to the motor is interrupted. Provides protection against unexpected start of the drives
SOS	Safe Operating Stop	Safe operating stop. Provides protection against unexpected start of the drives
SLS	Safely Limited Speed	Safely limited speed. Prevents the drives from exceeding the specified speed limits when the protective door is opened
SLP	Safely Limited Position	Safely limited position. Monitors safe axes to keep them within the limit values of a defined area
SBC	Safe Brake Control	Dual-channel control of the motor holding brakes

Safety-related operating modes of functional safety (FS)

Functional safety (FS) of a control offers various safety-related operating modes. The safety-related operating mode with the lowest number has the highest safety level.

Depending on how the machine manufacturer implements them, the following safety-related operating modes are available:



Refer to your machine manual.
The machine manufacturer must adapt the safety-related operating modes to each machine.

Icon	Safety-related operating mode	Short description
SOM ₁	Operating mode SOM_1	Safe operating mode 1: Automatic mode, production mode
SOM ₂	Operating mode SOM_2	Safe operating mode 2: Setup mode
SOM ₃	Operating mode SOM_3	Safe operating mode 3: Manual intervention; only for qualified users
SOM ₄	Operating mode SOM_4 This function must be enabled and adapted by the machine manufacturer.	Safe operating mode 4: Advanced manual intervention, process monitoring, only for qualified users

Functional safety FS in the Positions workspace

On a control with functional safety (FS), the monitored operating states of the speed **S** and feed rate **F** are displayed in the **Positions** workspace. If a safety function is triggered while in a monitored state, the control stops the feed movement and the spindle or reduces the speed (e.g., if a guard door is opened).

Further information: "Axis display and position display", Page 98

The Functional safety application

Refer to your machine manual.

The machine manufacturer configures the safety functions in this application.

In the **Functional safety** application in the **Home** operating mode, the control provides information about the status of the individual safety functions. In this application you can see whether individual safety functions are active and have been accepted by the control.


DB ID	Key name	Accepted	CRC	Active
59	CtgSafety	✗	0xd9e682f	✓
60	CtgPksSafety	✗	0x77c09a9b	✓
58	CtgAxParSafety HSE-V9_X_K00_E00	✗	0xd1c39f10	✓
62	CtgMotParSafety HSE-V9_X_K00_E00	✗	0x55a79a2b	✓
85	CtgAxParSafety HSE-V9_Y_K00_E00	✓	0xd43a109f	✓
64	CtgMotParSafety HSE-V9_Y_K00_E00	✓	0x42531a0	✓
65	CtgAxParSafety HSE-V9_Z_K00_E00	✓	0xd8299386	✓
66	CtgMotParSafety HSE-V9_Z_K00_E00	✓	0x92afa208	✓
67	CtgAxParSafety HSE-V9_B_K00_E00	✓	0x649b9c9e	✓
68	CtgMotParSafety HSE-V9_B_K00_E00	✓	0x2ca641d3	✓
69	CtgAxParSafety HSE-V9_C_K00_E00	✗	0xbdd5c095	✓
70	CtgMotParSafety HSE-V9_C_K00_E00	✗	0x851b0a7d	✓
71	CtgAxParSafety HSE-V9_LL_K00_E00	✓	0x4a21405b	✓
72	CtgMotParSafety HSE-V9_LL_K00_E00	✓	0x69f65508	✓

The **Overview** workspace in the **Functional safety** application

The Axis status menu item

In the **Axis status** menu item of the **Settings** application, the control provides the following information about the status of the individual axes:

Field	Meaning
Axis	Configured axes of the machine
State	Active safety function
Stop	Stop reaction Further information: "Functional safety FS in the Positions workspace", Page 430
SLS2	Maximum speed or feed-rate values for SLS in the SOM_2 operating mode
SLS3	Maximum speed or feed-rate values for SLS in the SOM_3 operating mode
SLS4	Maximum speed or feed-rate values for SLS in the SOM_4 operating mode This function must be enabled and adapted by the machine manufacturer.
Vmax_act	Currently valid speed or feed-rate limit These are either values from the SLS settings or from the SPLC If values are greater than 999 999, the control displays MAX .



The **Axis status** menu item in the **Settings** application

Test status of the axes




In order for the control to ensure safe operation of the axes, it checks all monitored axes when the machine is switched on.

The control checks whether the position of an axis matches the position directly after shutdown. If a deviation is detected, the control marks the respective axis in the position display with a red warning triangle.

If checking of individual axes fails when starting the machine, you can check the axes manually.

Further information: "Checking axis positions manually", Page 433

The control indicates the test status of the individual axes with the following icons:

Icon	Meaning
	The axis has been tested or does not need to be tested.
	The axis has not been tested, but must be tested to ensure safe operation. Further information: "Checking axis positions manually", Page 433
	The axis is not monitored by functional safety (FS) or is not configured as a safe axis. The axis is monitored by functional safety (FS), but the SLP safety function is deactivated. In machine parameter safeAbsPosition (no. 403130), the machine manufacturer defines whether the SLP safety function is activated for an axis.

Feed-rate limiting with functional safety (FS)



Refer to your machine manual.

This function must be adapted by your machine manufacturer.

With the **F limited** toggle switch you can prevent the SS1 reaction for safe stopping of drives when the guard door is opened.

With the **F limited** toggle switch the control limits the speed of the axes and rotational speed of the spindle to the values defined by the machine manufacturer. The limitation depends on the active safety-related SOM_x operating mode. You can select the safety-related operating mode with the keylock switch.



In the safety-related operating mode SOM_1, the control stops the axes and spindles when the guard door is opened.

In the **Positions** and **Status** workspaces, the feed rate is displayed in orange.

Further information: "POS tab", Page 112

22.1 Checking axis positions manually



Refer to your machine manual.

This function must be adapted by your machine manufacturer.

The machine manufacturer defines the test position.

To check the position of an axis:



- ▶ Select the **Manual** operating mode
- ▶ Select **Approach test position**
- > The control displays the axes that have not been tested in the **Positions** workspace.
- ▶ Select the desired axis in the **Positions** workspace



- ▶ Press the **NC start** key
- > The axis moves to the test position.
- > After the test position has been reached, the control issues a message.
- ▶ Press the **permissive button** on the machine operating panel
- > The control displays the axis as a tested axis.

NOTICE

Danger of collision!

The control does not automatically check whether collisions can occur between the tool and the workpiece. Incorrect pre-positioning or insufficient spacing between components can lead to a risk of collision while approaching the test positions.

- ▶ If necessary, move to a safe position before approaching the test positions
- ▶ Watch out for possible collisions

Notes















Machine tools with HEIDENHAIN controls may be equipped with integrated functional safety (FS) or with external safety. This chapter refers exclusively to machines with integrated functional safety (FS).












23



















**The Settings
Application**

23.1 Overview

The **Settings** application includes the following groups with menu items:

Icon	Category	Icon	Menu item
	Machine Settings		Machine Settings Further information: "The Machine Settings menu item", Page 439
			General Information Further information: "The General Information menu item", Page 442
			SIK Further information: "The SIK menu item", Page 443
			Machine Times Further information: "The Machine Times menu item", Page 446
			Set Up Touch Probes Further information: "Setting up touch probes", Page 286
			Set Up Wireless Handwheel Further information: "HR 550FS wireless handwheel", Page 410
			Operating System
	Language/Keyboards Further information: "Conversational language of the control", Page 448		
	About HeROS Further information: "Information on licensing and use", Page 56		
	SELinux Further information: "SELinux security software", Page 449		
	UserAdmin Further information: "The User administration window", Page 508		
	Current User Further information: "The Active user window", Page 508		
	Touchscreen Configuration You can select the touchscreen sensitivity and define whether touch points should be shown or hidden.		

Icon	Category	Icon	Menu item
	Network/Remote Access		Shares Further information: "Network drives on the control", Page 450
			Network Further information: "Ethernet interface", Page 453
			PKI Admin Manage certificates for the control (e.g., for OPC UA NC Server) Further information: "PKI Admin", Page 460
			OPC UA Further information: "OPC UA NC Server (#56-61 / #3-02-1*)", Page 462
			DNC Further information: "The DNC menu item", Page 468
			Embedded Workspace Show the connection status Further information: "Embedded Workspace (#133 / #3-01-1)", Page 424
			Printer Further information: "Printers", Page 470
		vnc	VNC Further information: "The VNC menu item", Page 473
			Remote Desktop Manager Further information: "The Remote Desktop Manager window (#133 / #3-01-1)", Page 477
			Real VNC Viewer Define settings for external software accessing the control (e.g., for maintenance purposes); for network specialists
			Firewall Further information: "Firewall", Page 483

Icon	Category	Icon	Menu item
	Diagnostics/Maintenance		Terminal program Enter and execute console commands
			HeLogging Define settings for internal diagnostic files
			Portscan Further information: "Portscan", Page 487
			perf2 Check processor load and process load
			NC/PLC Restore Further information: "Backup and restore", Page 487
			TNCdiag Further information: "TNCdiag", Page 490
			TNCscope Software for data recording
			NC/PLC Backup Further information: "Backup and restore", Page 487
			Touchscreen Cleaning The control disables the touchscreen for input for 90 seconds.
			Update the documentation Further information: "Update the documentation", Page 490
	OEM Settings		Settings for the machine manufacturer
	Machine Parameters		The group contains machine parameters that can be edited, depending on your rights (e.g., MPs for setters). Further information: "Machine parameters", Page 491
	Configurations		Configurations Further information: "Configuring the control's user interface", Page 496
	Functional safety		Axis status Further information: "The Axis status menu item", Page 431
			Safety parameters Further information: "The Functional safety application", Page 430

23.2 Code numbers

Application

The top part of the **Settings** application contains the **Code number:** input field. This input field is accessible from every group.

Description of function

You can enable the following functions or areas with code numbers:

Code number	Meaning
123	Editing machine-specific user parameters Further information: "Machine parameters", Page 491
555343	Special functions for programming with variables Further information: User's Manual for Programming and Testing Special functions defining the machine behavior Further information: "Special functions defining the machine behavior", Page 564 Further information: User's Manual for Programming and Testing
0	Resetting active code numbers



The control indicates whether the caps lock key is pressed during entry. This helps to avoid incorrect entries.

23.3 The Machine Settings menu item

Application

In the **Machine Settings** menu item of the **Settings** application, you can define the settings for simulation and program run.

Related topics

- Graphic settings for simulation
Further information: User's Manual for Programming and Testing

Description of function

To navigate to this function:

Settings ► **Machine Settings** ► **Machine Settings**

The Unit of Measure area

In the **Unit of Measure** area you can choose between mm and inch.

- Metric system: e.g. X = 15.789 (mm), the value is displayed to 3 decimal places
- Inch system: e.g. X = 0.6216 (inches), the value is displayed to 4 decimal places

If the display in inches is active, the control also displays the feed rate in inches/min. In an inch-based program, you must multiply the feed rate by 10 before entering it.

Channel Settings

The control displays the channel settings separately for the **Editor** operating mode and the **Manual** and **Program Run** operating modes.

You can define the following settings:

Setting	Meaning
Active Kinematics	<p>Use the Active Kinematics function to change the kinematics model for the machine and the simulation. This way you can test NC programs that, for example, have been programmed for other machines.</p> <p>The control offers a selection menu with all available kinematics models. The machine manufacturer defines which kinematics models you can choose.</p> <p>The control displays the active kinematics model in the Machine mode of the Simulation workspace.</p>
Generate tool-usage file	<p>The control uses the tool-usage file to check tool usage.</p> <p>Further information: "Tool usage test", Page 173</p> <p>You select when the control should generate a tool-usage file:</p> <ul style="list-style-type: none"> ■ Never The control does not generate a tool-usage file. ■ Once The next time you simulate or run an NC program, the control will generate a tool-usage file once. ■ Always When you simulate or run an NC program, the control will generate a tool-usage file each time.

Traverse Limits

Use the **Traverse Limits** function to limit the possible traverse path of an axis. You can define traverse limits for each axis (e.g., to protect an indexing head from collision).

The **Traverse Limits** function consists of a table with the following contents:

Column	Meaning
Axis	The TNC displays each axis of the active kinematics model in a row.
Status	If you have defined one or both limits, the control displays the contents Valid or Invalid .
Lower Limit	You define the lower traverse limit of the axis in this column. You can enter up to four decimal places.
Upper Limit	You define the upper traverse limit of the axis in this column. You can enter up to four decimal places.

The defined traverse limits are valid across power cycles of the control, until you delete all values from the table.

The following general conditions apply to the traverse limit values:

- The lower limit must be smaller than the upper limit.
- The upper and lower limit may not both equal 0.

Other conditions apply to traverse limits for modulo axes.

Further information: User's Manual for Programming and Testing

Notes

NOTICE

Danger of collision!

You can also select any stored kinematics model as the active machine kinematics. The control then executes all manual movements and machining operations using the selected kinematics. All subsequent axis movements pose a risk of collision!

- ▶ Use the **Active Kinematics** function for the simulation only
 - ▶ Use the **Active Kinematics** function for selecting the active machine kinematics only if required
-
- In the optional machine parameter **enableSelection** (no. 205601), the machine manufacturer defines for each kinematics model whether the **Active Kinematics** function can be selected.
 - You can open the tool-usage file in the **Tables** operating mode.
Further information: "Tool usage file", Page 380
 - If the control generated a tool-usage file for an NC program, the **T usage order** and **Tooling list** tables contain data (#93 / #2-03-1).
Further information: "T usage order (#93 / #2-03-1)", Page 382
Further information: "Tooling list (#93 / #2-03-1)", Page 384

23.4 The General Information menu item

Application

In the **General Information** menu item of the **Settings** application, the control provides information about the control and the machine.

Description of function

To navigate to this function:

Settings ▶ **Machine Settings** ▶ **General Information**

The Version Information area

The control displays the following information:

Sub-area	Meaning
HEIDENHAIN	<ul style="list-style-type: none"> ■ Control Model Designation of the control (managed by HEIDENHAIN) ■ NC-SW Number of the NC software (managed by HEIDENHAIN) ■ NCK Number of the NC software (managed by HEIDENHAIN)
PLC	<p>PLC-SW</p> <p>Number or name of the PLC software (managed by the machine manufacturer)</p>

The machine manufacturer can add further software numbers (e.g., that of a connected camera).

The Info about machine manufacturer area

The control shows the contents of the optional machine parameter **CfgOemInfo** (no. 131700). The control displays this area only if the machine manufacturer defines this machine parameter.

Further information: "Machine parameters in conjunction with OPC UA", Page 464

The Machine information area

The control shows the contents of the optional machine parameter **CfgMachineInfo** (no. 131600). The control displays this area only if the machine operator defines this machine parameter.

Further information: "Machine parameters in conjunction with OPC UA", Page 464

23.5 The SIK menu item

Application

Use the **SIK** menu item of the **Settings** application to view control-specific information (e.g., the serial number and the available software options).

Related topics

- Software options on the control
Further information: "Software options", Page 50

Description of function

To navigate to this function:

Settings ► **Machine Settings** ► **SIK**

The SIK Information area

The control displays the following information:

- **Serial Number**
- **ID number**
- **Control Model**
- **Performance Class**
- **Features**
- **Status**
- **Temporarily enable options / Disable options**

The Machine manufacturer key area

In the **Machine manufacturer key** area, the machine manufacturer can define a manufacturer-specific password for the control.

The General key area

In the **General key** area the machine manufacturer can enable all software options once for a period of 90 days (e.g., for testing).

The control indicates the status of the general key:

Status	Meaning
NONE	The general key has not yet been used for this software version.
dd.mm.yyyy	Date up to which all software options will be available. Once the general key has expired, it cannot be used again.
EXPIRED	The general key has expired for this software version.

If the software version of the control is increased (e.g., by an update), then the **General key** can be used again.

The Software Options area

In the **Software Options** area, the control shows all available software options in a table.

Column	Meaning
#	Number of the software option
Option	<p>Name of the software option</p> <p>On controls with SIK2, the part number and the name of the software option are displayed.</p> <p>The control indicates the status of the software option by means of the following symbols:</p> <ul style="list-style-type: none"> ■ No symbol: The software option is not enabled. ■ Checkmark: The software option is enabled permanently with all functions. ■ Clock symbol: The software option has been enabled for a limited period of time or can be ordered again on controls with SIK2. ■ Padlock: The software option has been locked by the machine manufacturer.
Expiration Date or Status	<p>The control displays the following information on the status of the software option:</p> <ul style="list-style-type: none"> ■ Enabled ■ YYYY-MM-DD <p>If a software option has been enabled for a limited period of time, the control shows the date up to which it will be available.</p> <ul style="list-style-type: none"> ■ X of X <p>On controls with SIK2, the control shows how often the software option has been enabled.</p>
Details	Detailed information for the machine manufacturer
Config.	Function that the machine manufacturer can use to lock software options

23.5.1 Viewing of software options

To view enabled software options on the control:



- ▶ Select the **Home** operating mode
- ▶ Select the **Settings** application
- ▶ Select **Machine Settings**
- ▶ Select **SIK**
- ▶ Navigate to the **Software Options** area
- ▶ For enabled software options, the control displays the text **Enabled**.

Definition

Abbreviation	Definition
SIK (System Identification Key)	<p>SIK is the designation of the plug-in board for the control hardware. Each control can clearly be identified by the serial number of the SIK.</p> <p>The software options have been saved on the SIK. The TNC7 basic can be equipped with a SIK1 or SIK2 plug-in board. Depending which one is used, the numbers of the software options differ.</p>

23.6 The Machine Times menu item

Application

In the **Machine Times** menu item of the **Settings** application, the control shows the run times since commissioning.

Related topics

- Date and time of the control

Further information: "The Adjust system time window", Page 447

Description of function

To navigate to this function:

Settings ▶ Machine Settings ▶ Machine Times

The control displays the following machine times:

Machine time	Meaning
Control On	Run time of the control since being put into service
Machine On	Run time of the machine tool since being put into service
Program Run	Run time of all program runs since being put into service



Refer to your machine manual.

The machine manufacturer can define up to 20 additional run times.

23.7 The Adjust system time window

Application

In the **Adjust system time** window, you can set the time zone, date and time manually or by means of NTP server synchronization.

Related topics

- Run times of the machine tool
 - Further information:** "The Machine Times menu item", Page 446

Description of function

To navigate to this function:

Settings ▶ Operating System ▶ Date/Time

The **Adjust system time** window contains the following areas:

Area	Function
Set the time manually	Activate this check box to define the following data: <ul style="list-style-type: none"> ■ Year ■ Month ■ Day ■ Time
Synchronize the time over NTP server	If you activate this check box, the control will automatically synchronize the system time with the defined NTP server. You can add a server with a host name or a URL.
Time zone	You can select your time zone from a list.

23.8 Conversational language of the control

Application

You use the **helocale** window to change the conversational language of the HEROS operating system and the machine parameters to change the NC conversational language of the control's user interface.

The HEROS conversational language only changes after a restart of the control.

Related topics

- Machine parameters of the control

Further information: "Machine parameters", Page 491

Description of function

To navigate to this function:

Settings ▶ Operating System ▶ Language/Keyboards

You can't define two different conversational languages for the operating system and control.

The **helocale** window consists of the following areas:

Area	Function
Language	Choose the HEROS conversational language from a selection menu Only if the machine parameter applyCfgLanguage (no. 101305) is defined as FALSE .
Keyboards	Select the language layout of the keyboard for HEROS functions

23.8.1 Changing the language

By default, the control assumes the NC conversational language for the HEROS conversational language.

To change the NC conversational language:

- ▶ Select the **Settings** application
- ▶ Enter the code number 123
- ▶ Select **OK**
- ▶ Select **Machine Parameters**
- ▶ Double-tap or double-click **MPs for setters**
- > The control opens the **MPs for setters** application.
- ▶ Navigate to the machine parameter **ncLanguage** (no. 101301)
- ▶ Select the desired language
 - ▶ Select **Save**
 - > The control opens the **Configuration data changed. All changes.** window.
 - ▶ Select **Save**
 - > The control opens the notification menu and displays a "Question type" error.
 - ▶ Select **CLOSE CONTROL**
 - > The control restarts.
 - > Once the control has restarted, the NC conversational language and the HEROS conversational language are changed.

Note

Use the machine parameter **applyCfgLanguage** (no. 101305) to define whether the control assumes the setting for the NC conversational language for the HEROS conversational language.

- **TRUE** (default): The control assumes the NC conversational language. You can change the language only in the machine parameters.
Further information: "Changing the language", Page 449
- **FALSE**: The control assumes the HEROS conversational language. You can change the language only in the **helocale** window.

23.9 SELinux security software

Application

SELinux is an extension for Linux-based operating systems in the sense of Mandatory Access Control (MAC). The security software protects the system against the execution of unauthorized processes or functions (such as viruses and other malicious software).

The machine manufacturer defines the **SELinux** settings in the **Security Policy Configuration** window.

Related topics

- Security settings with firewall
Further information: "Firewall", Page 483

Description of function

To navigate to this function:

Settings ► Operating System ► SELinux

By default, **SELinux** access control is implemented as follows:

- The control executes only programs that are installed with the HEIDENHAIN NC software.
- Safety-relevant files, such as **SELinux** system files or HEROS boot files, may only be modified using explicitly selected programs.
- New files created by other programs may not be run.
- USB data carriers can be deselected.
- Only two processes can run new files:
 - Software update: A software update from HEIDENHAIN can replace or modify system files.
 - SELinux configuration: The configuration of **SELinux** in the **Security Policy Configuration** window is usually protected by a password defined by the machine manufacturer. Please refer to the machine manual.

Note

HEIDENHAIN recommends using **SELinux** as additional protection against attacks from outside the network.

Definition

Abbreviation	Definition
MAC (mandatory access control)	MAC means that the control performs only explicitly permitted actions. SELinux is intended as protection in addition to the normal access restriction in Linux. Certain processes and actions can be performed only if the standard functions and access control of SELinux permit it.

23.10 Network drives on the control

Application

Use the **Mount Setup** window to connect network drives to the control. If a network drive is connected to the control, the control displays additional drives in the navigation column of the file management.

Related topics

- File management
 - Further information:** User's Manual for Programming and Testing
- Network settings
 - Further information:** "Ethernet interface", Page 453

Requirements

- Existing network connection
- Control and computer in same network
- Path and access data of drive to be connected are known

Description of function

To navigate to this function:

Settings ▶ Network/Remote Access ▶ Shares

You can define any number of network drives, but only seven can be connected at a time.

The Network drive area

In the **Network drive** area, the control shows a list of all defined network drives, as well as the status of each drive.

The control displays the following buttons:

Button	Meaning
Mount	Connect a network drive The control selects the check box in the Mount column if an active connection exists.
Unmount	Disconnect a network drive
Auto	Automatically connect the network drive when the control is booting. The control selects the check box in the Auto column if an active automatic connection exists.
Add	Define a new connection Further information: "Mount assistant window", Page 452
Remove	Delete an existing connection
Copy	Copy connection Further information: "Mount assistant window", Page 452
Edit	Edit the connection settings Further information: "Mount assistant window", Page 452
Private network drive	User-specific connection if user administration is active The control selects the check box in the Privat column if a user-specific connection exists.

The Status Log area

In the **Status Log** area, the control shows status information and error messages about connections.

Use the **Clear** button to delete the contents of the **Status Log** area.

Mount assistant window

In the **Mount assistant** window you define the settings for a connection with a network drive.

The **Add**, **Copy** and **Edit** buttons open the **Mount assistant** window.

The **Mount assistant** window contains tabs with the following settings:

Tab	Setting
Drive name	<ul style="list-style-type: none"> ■ Drive name: Network drive name in the file management of the control The names must be all uppercase letters, terminated by a colon (:). ■ Private network drive With user administration active, the connection is only visible to the user who created it.
Share type	Transfer protocol <ul style="list-style-type: none"> ■ Windows share (CIFS/SMB) or Samba server ■ UNIX share (NFS)
Server and Share	<ul style="list-style-type: none"> ■ Server name: Server name or IP address ■ Share name: Directory accessed by the control
Automount	Connect automatically (not possible with the "Ask for password?" option) The control connects the network drive automatically during the starting process.
User name and password (only with Windows share)	<ul style="list-style-type: none"> ■ Single Sign On With user administration active, the control automatically connects an encrypted network drive when the user logs in. ■ Windows user name: ■ Ask for password? (not possible with the "Connect automatically" option) Select whether a password is required upon connecting. ■ Password ■ Password verification
Mounting options	Parameters for mount option "-o": Auxiliary parameters for the connection Further information: "Examples of Mounting options", Page 453
Check	The control displays a summary of the defined settings. You can check the settings and save them with Apply .

Examples of Mounting options

Enter options without a space, only separated by a comma

Options for SMB

Example	Meaning
domain=xxx	Name of the domain HEIDENHAIN recommends not to include the domain in the user name, but rather specify it as an option.
vers=3.1.1	Protocol version
sec=ntlmssp	Authentication method ntlm Use this option if the control displays the Permission denied error message upon connecting.

Options for NFS

Example	Meaning
rsize=8192	Packet size in bytes for data reception Input: 512...8192
wsize=4096	Packet size in bytes for data transmission Input: 512...8192
soft,timeo=3	Conditional Mount Time in tenths of a second after which the control will try to connect again
nfsvers=2	Protocol version



If you use the CIMCO NFS software, you must set this option. CIMCO NFS supports NFS only up to version 2.

Notes

- Have a network specialist configure the control.
- To avoid security gaps, prefer the current versions of the **SMB** and **NFS** protocols.

23.11 Ethernet interface**Application**

The control is provided with an Ethernet interface as a standard feature so that you can integrate it into a network.

Related topics


- Firewall settings
Further information: "Firewall", Page 483
- Network drives on the control
Further information: "Network drives on the control", Page 450
- External access
Further information: "The DNC menu item", Page 468

Description of function

The control transfers data via the Ethernet interface using the following protocols:

- **CIFS** (common internet file system) or **SMB** (server message block)
The control supports versions 2, 2.1 and 3 of these protocols.
- **NFS** (network file system)
The control supports versions 2 and 3 of this protocol.

Connection options



You can integrate the Ethernet interface of the control into the network or connect it directly to a PC through the RJ45 connection X26. The connection is electrically isolated from the control electronics.

Use a Twisted Pair cable to connect the control to your network.



The maximum cable length permissible between the control and a node depends on the quality grade of the cable, the sheathing, and the type of network.

Ethernet connection icon

Icon



Meaning

Ethernet connection

The control displays the icon at the bottom right in the taskbar.

Further information: "Taskbar", Page 530

When you click the icon, the control opens a pop-up window. The pop-up window contains the following information and functions:

- Connected networks
You can disconnect the network connection. Select the network name to reconnect.
- Available networks
- VPN connections
Currently no function


Notes

- Protect your data and the control by running the machines in a secure network.
- To avoid security gaps, prefer the current versions of the **SMB** and **NFS** protocols.

23.11.1 The Network settings window

Application

In the **Network settings** window you define the settings for the control's Ethernet interface.

 Have a network specialist configure the control.


Related topics

- Network configuration
Further information: "Network configuration with Advanced Network Configuration", Page 541
- Firewall settings
Further information: "Firewall", Page 483
- Network drives on the control
Further information: "Network drives on the control", Page 450

Description of function

To navigate to this function:

Settings ► **Network/Remote Access** ► **Network**



Network settings

Computer name: TNC7_Dev_M18_KB

Default gateway: 10.3.56.254 on eth0

Use proxy: Address:Port

Name	Connection	Connection status	Configuration Name	Address
eth0	X26	Activated	DHCP-LAN_eth0	10.3.56.32
eth1	X116	Activated	DHCP-VBoxHostOnly_eth1	192.168.56.104

DHCP client

Name	IP address	MAC address	Type	Valid up to

*IP addresses as of:" and *IP addresses up to:" are outside the subnetwork of the configured interface.
The DHCP server will not be started.

OK Apply OEM authorization Export configuration Import the configuration HEIDENHAIN default Cancel

The **Network settings** window

The Status tab

The **Status** tab contains the following information and settings:

Domain	Information or Setting
Computer name	The control displays the name under which the control is visible in the company network. You can change the name.
Default gateway	The control shows the default gateway and the Ethernet interface being used.
Use proxy	You can define the address and the port of a proxy server in the network.
Interfaces	<p>The control shows an overview of available Ethernet interfaces. If there is no network connection, the table is empty.</p> <p>The control displays the following information in the table:</p> <ul style="list-style-type: none"> ■ Name (e.g., eth0) ■ Connection (e.g., X26) ■ Connection status (e.g., CONNECTED) ■ Configuration Name (e.g., DHCP) ■ Address (e.g., 10.7.113.10) <p>Further information: "The Interfaces tab", Page 457</p>
DHCP client	<p>The control displays an overview of the devices that have received a dynamic IP address in the machine network. If there are no connections to other network components of the machine network, the table is empty.</p> <p>The control displays the following information in the table:</p> <ul style="list-style-type: none"> ■ Name <ul style="list-style-type: none"> Host name and connection status of the device. The control shows the following connection status: <ul style="list-style-type: none"> ■ Green: Connected ■ Red: No connection ■ IP address <ul style="list-style-type: none"> Dynamically assigned IP address of the device ■ MAC address <ul style="list-style-type: none"> Physical address of the device ■ Type <ul style="list-style-type: none"> Type of connection The control displays the following connection types: <ul style="list-style-type: none"> ■ TFTP ■ DHCP ■ Valid up to <ul style="list-style-type: none"> Time until which the IP address is valid without being renewed <p>The machine manufacturer can make settings for these devices. Refer to your machine manual.</p>

The Interfaces tab

The control displays the available Ethernet interfaces on the **Interfaces** tab. The **Interfaces** tab contains the following information and settings:

Column	Information or Setting
Name	The control displays the name of the Ethernet interface. You can activate or deactivate the connection by means of a toggle switch.
Connection	The control displays the number of the network connection.
Connection status	<p>The control displays the connection status of the Ethernet interface.</p> <p>The following connection statuses may be displayed:</p> <ul style="list-style-type: none"> ■ CONNECTED Connected ■ DISCONNECTED Connection separated ■ CONFIGURING The IP address is being fetched from the server ■ NOCARRIER No cable present
Configuration Name	<p>You can execute the following functions:</p> <ul style="list-style-type: none"> ■ Select a profile for the Ethernet interface In the factory default setting, two profiles are available: <ul style="list-style-type: none"> ■ DHCP-LAN: Settings for the standard interface for a standard company network ■ MachineNet: Settings for the second, optional Ethernet interface; for configuration of the machine network <p>Further information: "Network configuration with Advanced Network Configuration", Page 541</p> ■ Reconnect the Ethernet interface with Reconnect ■ Edit the selected profile Further information: "Network configuration with Advanced Network Configuration", Page 541



- If you have changed the profile of an active connection, the control will not update the profile being used. Reconnect the corresponding interface with **Reconnect**.
- The control exclusively supports the **Ethernet** connection type.

The DHCP server tab

The machine manufacturer can use the **DHCP server** tab in the control to configure a DHCP server in the machine network. Using this server, the control can establish connections with other network components of the machine network (e.g., with industrial computers).

Refer to your machine manual.

Ping/Routing tab

You can check the network connection on the **Ping/Routing** tab.

The **Ping/Routing** tab contains the following information and settings:

Domain	Information or Setting
Ping	<p>Address:Port and Address:</p> <p>You can enter the IP address of the computer and possibly the port number for checking the network connection.</p> <p>Entry: Four numerical values separated by dots and, if necessary, a port number separated by a colon (e.g., 10.7.113.10:22)</p> <p>As an alternative, you can enter the name of the computer whose connection you want to check.</p> <p>Starting and stopping the test</p> <ul style="list-style-type: none"> ■ Start button: starts the test The control displays status information in the ping field. ■ Stop button: stops the test
Routing	<p>The control displays status information of the operating system about the current routing for network administrators.</p>

The SMB share tab

The **SMB share** tab is included only in connection with a VBox programming station. When the check box is active, the control releases areas or partitions protected by a code number for the Explorer of the Windows PC used, e.g. **PLC**. You can activate or deactivate the check box only by using the machine manufacturer code number.

In the **TNC VBox Control Panel**, select a drive letter within the **NC share** tab for displaying the selected partition and then connect the drive with **Connect**. The host displays the partitions of the programming station.



Further information: Programming station for milling controls

You download the documentation together with the programming station software.

Exporting and importing a network profile

To export a network profile:

- ▶ Opening the **Network settings** window
- ▶ Select **Export configuration**
- > The control opens a window.
- ▶ Select the storage location for the network profile (e.g., **TNC:/etc/sysconfig/net**)
- ▶ Select **Open**
- ▶ Select the desired network profile
- ▶ Select **Export**
- > The control saves the network profile.



You can't export **DHCP** or **eth1** profiles.

To import an exported network profile:

- ▶ Open the **Network settings** window
- ▶ Select **Import the configuration**
- > The control opens a window.
- ▶ Select the storage location of the network profile
- ▶ Select **Open**
- ▶ Select the desired network profile
- ▶ Press **OK**
- > The control opens a window with a prompt.
- ▶ Press **OK**
- > The control imports and activates the selected network profile.
- ▶ You might need to restart the control



Use the **HEIDENHAIN presettings** button to import the default values of the network settings.

Notes

- Preferably restart the control after making changes in the network settings.
- The HEROS operating system manages the **Network settings** window. You must restart the control in order to change the HEROS conversational language.

Further information: "Conversational language of the control", Page 448

23.12 PKI Admin

Application

With **PKI Admin**, you can manage the server and client certificates on the control. To define access rights to the control, you can classify the certificates as trusted or not trusted, for example.

Related topics

- Quickly and easily connecting the OPC UA client application to the control (#56-61 / #3-02-1*)

Further information: "The OPC UA connection assistant function (#56-61 / #3-02-1*)", Page 466

Description of function

To navigate to this function:

Settings ► **Network/Remote Access** ► **PKI Admin**

The **Administration of the PKI Infrastructure** window contains the following tabs:

Tab	Function
Trusted	<p>The server knows the certificate and trusts it after successful validation.</p> <p>For connection to the server, the client certificate must have been specified on this tab.</p> <p>For a OPC UA connection (#56-61 / #3-02-1*), you also need to assign a OPC UA license to the certificate.</p> <p>Further information: "The OPC UA license settings function (#56-61 / #3-02-1*)", Page 467</p>
Issuers	<p>On this tab, you can specify the issuer of the trusted certificates.</p> <p>The server uses the issuer's information to validate the certificate.</p>
Rejected	<p>On this tab, the control specifies client certificates whose connection attempt to the OPC UA NC Server (#56-61 / #3-02-1*) failed.</p> <p>Connection failures can occur in the following situations:</p> <ul style="list-style-type: none"> ■ The client certificate is unknown and has not been classified as trusted. If you want to connect the client application to the server, you can use the Move function to move the certificate to the Trusted tab. ■ A trusted client certificate has expired.
Revocation lists	<p>On this tab, you can specify CRL files that list untrusted certificates.</p> <p>The server prohibits connections that use these certificates.</p>
Own certificates	<p>The control provides the following functions:</p> <ul style="list-style-type: none"> ■ Recreate certificate The control recreates the server's chain of trust. After the next restart of the control, it will use the new certificate. ■ Export certificate chain The control saves the server's chain of trust that you import into the client application. ■ Load certificate You can import a customized certificate. Please note the requirements for self-created certificates for OPC UA (#56-61 / #3-02-1*). Further information: "Required certificates", Page 464 ■ Check the configuration The control checks the validity of the server certificates.
Advanced settings	<p>The tab contains the following areas:</p> <ul style="list-style-type: none"> ■ Certificate settings

Tab	Function
	<p>The control adds static IP addresses to the server certificates. You can select the IP address of the eth0 or eth1 interface or specify the required IP addresses.</p> <ul style="list-style-type: none"> ■ Settings for revocation lists <p>You can permit connections of applications with certificates in a multi-level certificate chain even if no associated CRL files exist.</p>

Definition

PKI

PKI (public key infrastructure) is the management structure for digital certificates that are required for safe communication. A digital certificate has the same purpose as an identity card or passport. With a digital certificate, its owner can encrypt, sign and authenticate the communication.

23.13 OPC UA NC Server (#56-61 / #3-02-1*)

23.13.1 Fundamentals

Open Platform Communications Unified Architecture (OPC UA) describes a collection of specifications. These specifications are used to standardize machine-to-machine communication (M2M) in the field of industrial automation. OPC UA enables the data exchange across operating systems between products from different manufacturers, e.g. between a HEIDENHAIN control system and third-party software. Thus, OPC UA has become the data exchange standard for secure, reliable, manufacturer- and platform-independent industrial communication over the last years.

In 2016, the German Federal Office for Information Security (BSI) published a security analysis related to **OPC UA**. The security analysis was updated in 2022. The specification analysis performed by the BSI determined that **OPC UA** provides a high level of security as compared to most other industrial protocols.

HEIDENHAIN follows the BSI recommendations and provides SignAndEncrypt, which exclusively features up-to-date IT security profiles. For this purpose, OPC UA-based industrial applications and the **OPC UA NC Server** exchange certificates for authentication. In addition, any transferred data is encrypted. This effectively prevents messages between the communication partners from being intercepted or altered.

Application

Both standard and custom software can be used with the **OPC UA NC Server**. Compared to other established interfaces, significantly less development effort is required for OPC UA connection, thanks to the uniform communication technology.

The **OPC UA NC Server** allows you to access the data and functions of the HEIDENHAIN NC information model exposed in the server address space.



Pay attention to the interface documentation of the **OPC UA NC Server** as well as the documentation of the client application.

Related topics

- **Information Model** interface documentation with the specification of the **OPC UA NC Server** in English
ID: 1309365-xx or **OPC UA NC Server Interface Documentation**
- Quickly and easily connecting the OPC UA client application to the control
Further information: "The OPC UA connection assistant function (#56-61 / #3-02-1*)", Page 466

Requirements

- OPC UA NC Server software options (#56-61 / #3-02-1*)
For OPC UA-based communication, the HEIDENHAIN control provides the **OPC UA NC Server**. For each OPC UA client to be connected, you need one of the six available software options (56 to 61).
If your control features a **SIK2**, you can order this software option multiple times and enable up to six connections.
- Firewall configured
Further information: "Firewall", Page 483
- The OPC UA client supports the **security policy** and authentication method of the **OPC UA NC Server**:
 - **Security Mode: SignAndEncrypt**
 - **Algorithm:**
 - **Basic256Sha256**
 - **Aes128Sha256RsaOaep**
 - **Aes256Sha256RsaPss**
 - **User Authentication: X509 certificates**

Description of function

Both standard and custom software can be used with the **OPC UA NC Server**. Compared to other established interfaces, significantly less development effort is required for OPC UA connection, thanks to the uniform communication technology.

The control supports the following OPC UA functions:

- Write and read variables
- Subscribe to value changes
- Run methods
- Subscribe to events
- Creation of service files
- Read and write tool data (the corresponding right is required)
- File system access to the **TNC:** drive
- File system access to the **PLC:** drive (the corresponding right is required)
- Validation of 3D models for tool carriers
Further information: "Tool carrier management", Page 167
- Validate 3D models for tools (#140 / #5-03-2)
Further information: "Tool model (#140 / #5-03-2)", Page 171

Machine parameters in conjunction with OPC UA

The **OPC UA NC Server** enables OPC UA client applications to query general machine information, such as the year of construction of the machine or its location.

The following machine parameters are available for the digital identification of your machine:

- For users: **CfgMachineInfo** (no. 131700)
Further information: "The Machine information area", Page 442
- For the machine tool manufacturer: **CfgOemInfo** (no. 131600)
Further information: "The Info about machine manufacturer area", Page 442

Access to directories

The **OPC UA NC Server** enables read and write access to the **TNC:** and **PLC:** drives.

The following actions are permitted:

- Creation and deletion of folders
- Reading, editing, copying, moving, creating, and deleting of files.

While the NC software is running, the files referenced in the following machine parameters are locked against write access:

- Tables referenced by the machine manufacturer in the machine parameter **CfgTablePath** (no. 102500)
- Files referenced by the machine manufacturer in the machine parameter **dataFiles** (no. 106303, branch **CfgConfigData** no. 106300)

The **OPC UA NC Server** enables access to the control even if the NC software is switched off. As long as the operating system is active, you can create and transmit service files, for example.

NOTICE

Caution: potential damage to property!

The control does not automatically back up the files before editing or deletion. Files that are missing cannot be restored. The removal or editing of system-relevant files, such as the tool table, can negatively affect the control functions.

- ▶ System-relevant files must be edited only by authorized specialists

Required certificates

The **OPC UA NC Server** requires three different types of certificates. The server and the client need two of them, the application instance certificates, in order to establish a secure connection. The third certificate (user certificate) is required for authorization and for starting a session with specific user permissions.

The control automatically generates a two-level certificate chain referred to as the **Chain of Trust** for the server. This certificate chain consists of a self-signed root certificate (including a **revocation list**) and a certificate for the server that is created on the basis of the root certificate.

The client certificate must be added on the **Trusted** tab of the **PKI Admin** function.

All other certificates should be added on the **Issuers** tab of the **PKI Admin** function for verification of the entire certificate chain.

Further information: "PKI Admin", Page 460

User certificate

The control uses the HEROS functions **Current User** or **UserAdmin** for administration of the user certificate. When you initiate a session, the rights of the associated internal user are active.

To assign a user certificate to a user:

- ▶ Open the **Current User** HEROS function
- ▶ Select **SSH keys and certificates**
- ▶ Press the **Import certificate** soft key
- > The control opens a pop-up window.
- ▶ Select the certificate
- ▶ Select **Open**
- > The control imports the certificate.
- ▶ Press the **Use for OPC UA** soft key

Self-generated certificates

You can also create and import all of the required certificates yourself.

Self-generated certificates must fulfill the following requirements:

- General requirements
 - File format: *.der
 - Signature with hash SHA256
 - Validity period of at most 5 years is recommended
- Client certificates
 - Host name of the client
 - Application URI of the client
- Server certificates
 - Host name of the control
 - Application URI of the server according to the following structure:
urn:<hostname>/HEIDENHAIN/OpcUa/NC/Server
 - Validity period of 20 years maximum

Note

OPC UA is a manufacturer/platform-independent, open communication standard. For this reason, an OPC UA client SDK is not included in the **OPC UA NC Server**.

23.13.2 The OPC UA (#56-61 / #3-02-1*) menu item**Application**

In the **OPC UA** menu item of the **Settings** application, you can set up the connections to the control and check the status of the **OPC UA NC Server**.

Description of function

To navigate to this function:

Settings ► **Network/Remote Access** ► **OPC UA**

The **OPC UA NC Server** area contains the following functions:

Function	Meaning
Status	Shows with an icon whether the OPC UA NC Server is active: <ul style="list-style-type: none"> ■ Green icon OPC UA NC Server is active ■ Gray icon: OPC UA NC Server is not active or software option not enabled You can manually start or restart the OPC UA NC Server as required. Further information: "Manually starting the OPC UA NC Server", Page 466
OPC UA connection assistant	Open the OPC UA NC Server connection assistant window Further information: "The OPC UA connection assistant function (#56-61 / #3-02-1*)", Page 466
OPC UA license settings	Open the OPC UA NC Server - License Settings window Further information: "The OPC UA license settings function (#56-61 / #3-02-1*)", Page 467
PKI Admin	Open the Administration of the PKI Infrastructure window Further information: "PKI Admin", Page 460
Host computer operation	Activate or deactivate host computer operation with a toggle switch Further information: "The DNC area", Page 469

Manually starting the OPC UA NC Server

You can manually start or restart the **OPC UA NC Server** as required. Thus, you can apply changes made to the machine parameters or the certificates, which are relevant to the server, without having to shut down the control.

While an OPC UA connection is active, the control displays a confirmation prompt before the restart. During the restart, the control will disconnect active connections automatically.

For this function, you need the HEROS.SetNetwork permission.

Further information: "User administration roles and rights", Page 558

23.13.3 The OPC UA connection assistant function (#56-61 / #3-02-1*)

Application

For quick and easy setup of an OPC UA client application, you can use the **OPC UA NC Server connection assistant** window. This assistant guides you through the steps that are required to connect an OPC UA client application to the control.

Related topics

- Assigning the OPC UA client application to a software option 56 to 61 or #3-02-1 to #3-02-6 using the **OPC UA NC Server - License Settings** window
Further information: "The OPC UA license settings function (#56-61 / #3-02-1*)", Page 467
- Managing certificates with the **PKI Admin** menu
Further information: "PKI Admin", Page 460

Description of function

Use the **OPC UA** menu item to open the **OPC UA NC Server connection assistant** window.

Further information: "The OPC UA (#56-61 / #3-02-1*) menu item", Page 465

The assistant features the following steps:

- Export **OPC UA NC Server** certificates
- Import the certificates of the OPC UA client application
- Assign each of the available **OPC UA NC Server** software options to an OPC UA client application
- Import user certificates
- Assign user certificates to users
- Configure the firewall

If at least one software option is active for the OPC UA NC Server, the control will generate the server certificate as a part of a self-generated certificate chain during the first start-up. The client application or the manufacturer of the application creates the client certificate. The user certificate is linked to the user account. Please contact your IT department.

Note

The **OPC UA NC Server connection assistant** also helps you create test or sample certificates for users and the OPC UA client application. Do not use the user and client application certificates created at the control for other purposes than development at the programming station.

23.13.4 The OPC UA license settings function (#56-61 / #3-02-1*)

Application

You can use the **OPC UA NC Server - License Settings** window to assign an OPC UA client application to a software option 56 to 61 or #3-02-1 to #3-02-6.

Related topics

- Setting up the OPC UA client application with the **OPC UA connection assistant** function

Further information: "The OPC UA connection assistant function (#56-61 / #3-02-1*)", Page 466

- Managing certificates with **PKI Admin**

Further information: "PKI Admin", Page 460

Requirement

- Certificate has been added to the **Trusted** category in **PKI Admin**

Description of function

Use the **OPC UA** menu item to open the **OPC UA license settings** window.

After using the **OPC UA connection assistant** or the **PKI Admin** menu item to import a certificate of an OPC UA client application, you can choose the certificate from a selection window.

If you enable the **Active** check box for a certificate, the control uses a software option for the OPC UA client application.

23.14 The DNC menu item

Application

With the **DNC** menu item you can grant or restrict access to the control (e.g., connections over a network).

Related topics




- Connecting network drives
Further information: "Network drives on the control", Page 450
- Setting up a network
Further information: "Ethernet interface", Page 453
- TNCremo
Further information: "PC software for data transfer", Page 533
- Remote Desktop Manager (#133 / #3-01-1)
Further information: "The Remote Desktop Manager window (#133 / #3-01-1)", Page 477

Description of function



To navigate to this function:

Settings ► **Network/Remote Access** ► **DNC**

The **DNC** area contains the following symbols:

Icon	Meaning
	Add a computer-specific connection
	Edit a computer-specific connection
	Delete a computer-specific connection

When a connection is active, the control displays a symbol in the information bar:

Icon	Meaning
	Secure connection configuration External access to the control is active; all connections are using a secure connection configuration.
	Non-secure connection configuration An external access to the control is active but at least one connection is using a non-secure connection configuration.

Further information: "Areas of the control's user interface", Page 63

The DNC area

In the **DNC** area you use toggle switches to activate the following functions:

Switches	Meaning
DNC access permitted	Permit or block all accesses to the control through a network or a serial connection
TNCopt full access allowed	Depending on the machine, permit or block access for diagnostics or initial setup software
Host computer operation	<p>Pass command control to an external host computer, for example to transfer data to the control; or end host computer operation</p> <p>If host computer operation is active, the control displays the Host computer is active message in the info bar. You cannot use the Manual and Program Run operating modes.</p> <p>You cannot activate host computer operation while running an NC program.</p>

Secure connections for user

In the **Secure connections for user** area you activate the following functions:

Row	Meaning
Setup permitted	If the toggle switch is active, client applications can establish a secure connection for the current user.
Key management	<p>In this row you, open the Certificate and keys window.</p> <p>Further information: "SSH-secured DNC connection", Page 521</p>

Computer-specific connections

If the machine manufacturer has defined the optional machine parameter **CfgAccessControl** (no. 123400), then in the **Connections** area you can permit or block access for up to 32 connections defined by you.

The control shows the defined information in a table:

Column	Meaning
Name	Host name of the external computer
Description	Additional information
IP address	Network address of the external computer
Access	<ul style="list-style-type: none"> ■ Permit The control permits network access without confirmation. ■ Inquire The control asks for confirmation upon a network access attempt. You can choose whether to permit or block the access once or always. ■ Deny The control does not permit any network access
Type	<ul style="list-style-type: none"> ■ Com1 Serial interface 1 ■ Com2 Serial interface 2 ■ Ethernet Network connection
Active	If a connection is active, the control displays a green circle. If a connection is inactive, the control displays a gray circle.

Notes

- In the machine parameter **allowDisable** (no. 129202) the machine manufacturer defines whether the **Host computer operation** toggle switch is available.
- In the optional machine parameter **denyAllConnections** (no. 123403) the machine manufacturer defines whether the control permits computer-specific connections.

23.15 Printers

Application

You add and manage printers through the **Printer** menu item in the **Heros Printer Manager** window.

Related topics

- Using the **FN 16: F-PRINT** function for printing
Further information: User's Manual for Programming and Testing

Requirement

- PostScript-capable printer

The control can communicate only with printers that understand PostScript emulation such as KPDL3. Some printers enable setting the PostScript emulation in the printer menu.

Further information: "Note", Page 473

Description of function

To navigate to this function:

Settings ► **Network/Remote Access** ► **Printer** ► **Heros Printer Manager**

You can print the following files:

- Text files
- Graphic files
- PDF files

Further information: User's Manual for Programming and Testing

Once you have added a printer, the control shows the **PRINTER:** drive in the file management. The drive contains one folder for each defined printer.

Further information: "Creating a printer", Page 473

There are various methods to start printing:


- Copying the file to be printed to the **PRINTER** drive
The file to be printed is automatically forwarded to the default printer and deleted from the directory after the print job has been executed.
You may also copy the file into the printer sub-directory if you wish to use a printer other than the default printer.
- Using the **FN 16: F-PRINT** function

Buttons

The **Heros Printer Manager** window contains the following buttons:

Button	Meaning
CREATE	Creates a printer
CHANGE	Adapts the properties of the selected printer
COPY	Creates a copy of the selected printer setting At first the copy has the same properties as the copied setting. This can be useful if printing both portrait and landscape formats on the same printer
DELETE	Deletes the selected printer
UP	Selects a printer
DOWN	
STATUS	Displays the status information of the selected printer
PRINT A TEST PAGE	Prints a test page on the selected printer

The Change the printer window



For each printer, the following properties can be set:

Setting	Meaning
Name of the printer	Customizes the printer name
Connection	Selects the connection <ul style="list-style-type: none"> ■ USB: The control automatically displays the name ■ Network: Network name or IP address of the printer Port for the network printer (default: 9001) ■ Printer %1 not connected
Timeout	Delays the printing process The control delays the printing process by the pre-set number of seconds after the last change has been made to the file to be printed in PRINTER: . Use this setting if the file to be printed is populated with FN functions (e.g., when probing).
Standard printer	Selects the default printer The control automatically assigns this setting to the first printer added.
Settings for printing of text	These settings are applicable when printing text documents: <ul style="list-style-type: none"> ■ Paper size ■ Number of copies ■ Job name ■ Font size ■ Header ■ Print options (black and white, color, duplex)
Orientation	Portrait or landscape for all printable files
Expert options	Available only to authorized specialists

23.15.1 Creating a printer

To create a new printer:

- ▶ Enter the printer name in the name dialog
- ▶ Select **CREATE**
- > The control creates a new printer.
- ▶ Press **CHANGE**
- > The control opens the **Change the printer** window.
- ▶ Define the properties
- ▶ Select **Save**
- > The control applies the settings and displays the defined printer in the list.

Note

If your printer does not permit PostScript emulation, change the printer settings if possible.

23.16 The VNC menu item

Application

VNC is software that shows the screen contents of a remote computer on a local computer, and also sends keyboard actions and mouse movements of the local computer to the remote computer.

Related topics

- Firewall settings
Further information: "Firewall", Page 483
- Remote Desktop Manager (#133 / #3-01-1)
Further information: "The Remote Desktop Manager window (#133 / #3-01-1)", Page 477




Description of function

To navigate to this function:

Settings ▶ Network/Remote Access ▶ VNC

Buttons and icons

The **VNC settings** window contains the following buttons and icons:

Button and icon	Meaning
Add	Add new VNC viewer or client
Remove	Delete the selected client Only possible with manually entered clients.
Edit	Edit the configuration of the selected client
Update	Refresh view Required with connection attempts during which the dialog is open.
Set preferred owner of the focus	Enable the Preferred owner of the focus check box
	Another client owns the focus Mouse and keyboard are disabled
	You own the focus Entries can be made
	Prompt by another client to receive the focus Mouse and keyboard are disabled until the focus is assigned.

The VNC participant settings area

In the **VNC participant settings** area, the control shows a list of all clients.

The control displays the following contents:

Column	Contents
Computer name	IP address or computer name
VNC	Connection of the client to the VNC viewer
VNC Focus	The client participates in the focus assignment
Type	<ul style="list-style-type: none"> ■ Manual Manually entered client ■ Denied This client is not permitted to connect. ■ Enable TeleService and IPC Client via a TeleService connection ■ DHCP Other computer that retrieves an IP address from this computer.

The Global settings area

In the **Global settings** area, you can define the following settings:

Function	Meaning
Enable RemoteAccess and IPC	If the check box is selected, the connection is always permitted.
Password verification	Client must enter a password for verification The control opens a window when you select the check box. In this window you define the password for this client. The client must enter the password when establishing the connection.

The Enabling other VNC area

In the **Enabling other VNC** area, you can define the following settings:

Function	Meaning
Deny	Other VNC clients are not permitted.
Inquire	A dialog opens when another VNC client wants to connect. You must grant permission for this connection.
Permitted	Other VNC clients are permitted.

The VNC Focus Settings area

In the **VNC Focus Settings** area, you can define the following settings:

Function	Meaning
Enabling VNC focus	Enables focus assignment for this system When the check box is inactive, the focus owner actively gives away the focus by using the focus symbol. The remaining clients can request the focus only after it was given away.
Reset the CapsLock key when changing the focus	When the check box is active and the focus owner has activated the CapsLock key, the CapsLock key is deactivated if the focus changes. Only if the Enabling VNC focus check box is enabled
Enable Concurrency VNC Focus	When the check box is active, every client can request the focus at any time. The focus owner does not need to give away the focus before to enable that. When a client requests the focus, a pop-up window opens for all clients. If no client objects to the request within the pre-set period of time, the focus changes after the defined time limit. Only if the Enabling VNC focus check box is enabled
Timeout Concurrency VNC Focus	Period of time after requesting the focus during which the focus owner can object to the focus change (at most 60 seconds). This period of time is set by moving a slider. When a client requests the focus, a pop-up window opens for all clients. If no client objects to the request within the pre-set period of time, the focus changes after the defined time limit. Only if the Enabling VNC focus check box is enabled



Enable the **Enabling VNC focus** check box only in connection with HEIDENHAIN devices provided especially for this purpose (e.g., ITC industrial computers).

Notes

- The machine manufacturer defines the procedure for assigning the focus with multiple clients or operating units. Focus assignment depends on the setup and operating situation of the machine tool.
Refer to your machine manual.
- The control displays a message if the firewall settings of the control do not permit the VNC protocol for all clients.

Definition

Abbreviation	Definition
VNC (virtual network computing)	VNC is software with which another computer can be controlled over a network connection.

23.17 The Remote Desktop Manager window (#133 / #3-01-1)

Application

With Remote Desktop Manager you can display external computer units on the control screen that are connected via Ethernet, and operate them through the control. You can also shut down a Windows computer together with the control.

Related topics

- External access

Further information: "The DNC menu item", Page 468

Requirements

- Software option Remote Desktop Manager (#133 / #3-01-1)
- Existing network connection

Further information: "Ethernet interface", Page 453


Description of function

To navigate to this function:

Settings ► Network/Remote Access ► Remote Desktop Manager

Remote Desktop Manager grants the following connection options:

- **Windows Terminal Service (RemoteFX):** Display the desktop of an external Windows computer on the control
Further information: "Windows Terminal Service (RemoteFX)", Page 478
- **VNC:** Display the desktop of an external Windows, Apple or Unix computer on the control
Further information: "VNC", Page 478
- **Switch-off/restart of a computer:** Automatically shut down a Windows computer together with the control
- **World Wide Web:** Available only to authorized specialists
- **SSH:** Available only to authorized specialists
- **XDMCP:** Available only to authorized specialists
- **User-defined connection:** Available only to authorized specialists



HEIDENHAIN offers the IPC 6641 as a Windows computer. With the IPC 6641 you can start and operate Windows-based applications directly from within the control.

If the desktop of the external connection or the external computer is active, all inputs from the mouse and the alphabetic keyboard are transmitted there.

When the operating system is shut down, the control automatically terminates all connections. Please note that only the connection is terminated, whereas the external computer or the external system is not shut down automatically.

Buttons

Remote Desktop Manager contains the following buttons:

Button	Function
New connection	Create a new connection in the Edit the connection window Further information: "Establishing and starting a connection", Page 481
Delete connection	Delete the selected connection
Start the connection	Start the selected connection Further information: "Establishing and starting a connection", Page 481
Terminate the connection	Terminate the selected connection
Edit the connection	Edit the selected connection in the Edit the connection window Further information: "Connection settings", Page 479
Exit	Close Remote Desktop Manager
Import connections	Restore the selected connection Further information: "Exporting and importing connections", Page 482
Export the connections	Back-up the selected connection Further information: "Exporting and importing connections", Page 482

Windows Terminal Service (RemoteFX)

You don't need any additional software on a computer for a RemoteFX connection, but you might need to change some settings on the computer.

Further information: "Configuring an external computer for Windows Terminal Service (RemoteFX)", Page 481

For integrating the IPC 6641, HEIDENHAIN recommends using a RemoteFX connection.

With RemoteFX, a separate window opens for the screen of the external computer. The active desktop on the external computer is then locked and the user logged off. This prevents two users from accessing the control simultaneously.

VNC

You need an additional **VNC** server for your external computer when connecting through VNC. Install and configure the VNC server (e.g., TightVNC server) before establishing the connection.


VNC mirrors the screen of the external computer. The active desktop on the external computer is not locked automatically.

With a **VNC** connection you can shut down the external computer through the Windows menu. The computer cannot be restarted through the connection.

Connection settings

General settings

The following settings apply to all connection options:

Setting	Meaning	Usage
Connection name	Name of the connection in Remote Desktop Manager	Required
	<div style="border: 1px solid black; padding: 5px;">  You can use the following characters in the name of the connection: A B C D E F G H I J K L M N O P Q R S T U V W X Y Z a b c d e f g h i j k l m n o p q r s t u v w x y z 0 1 2 3 4 5 6 7 8 9 _ </div>	
Restarting after end of connection	Behavior after disconnection: <ul style="list-style-type: none"> ■ Always restart ■ Never restart ■ Always after an error ■ Ask after an error 	Required
Automatic starting upon login	Connect automatically when starting	Required
Add to favorites	The control displays the connection's icon in the taskbar. Tap or click the icon to start the connection directly.	Required
Move to the following workspace	Number of the desktop for the connection; desktops 0 and 1 are reserved for the NC software. Default setting: Third desktop	Required
Release USB mass memory	Permit access to connected USB mass memory devices	Required
Private connection	Connection can be seen and used only by its creator	Required
Computer	Host name or IP address of the external computer HEIDENHAIN recommends the IPC6641.machine.net setting for the IPC 6641. The host name IPC6641 must be assigned to the IPC in the Windows operating system for this setting.	Required
Password	Password of the user	Required
Entries in the Advanced options area	Available only to authorized specialists	Optional

Additional settings for Windows Terminal Service (RemoteFX)

The control offers the following additional connection settings for the **Windows Terminal Service (RemoteFX)** option:

Setting	Meaning	Usage
User name	Name of the user	Required
Windows domain	Domain of the external computer	Optional
Full-screen mode or User-defined window size	Size of the connection window on the control	Required

Additional settings for VNC

The control offers the following additional connection settings for the **VNC** option:

Setting	Meaning	Usage
Full-screen mode or User-defined window size:	Size of the connection window on the control	Required
Permit further connections (share)	Additionally grant other VNC connections access to the VNC server	Required
View only	In display mode, the external computer cannot be operated.	Required

Additional settings for Switch-off/restart of a computer

The control offers the following additional connection settings for the **Switch-off/restart of a computer** option:

Setting	Meaning	Usage
User name	User name with which the connection should log in.	Required
Windows domain:	If required, domain of the target computer	Optional
Max. waiting time (seconds):	A shutdown of the control causes the Windows computer to shut down as well. Before the control displays the Now you can switch off. message, it waits for the number of seconds defined here. While waiting, the control checks whether the Windows computer is still accessible (port 445). If the Windows computer is switched off before the defined number of seconds have expired, the control will wait no longer.	Required
Additional waiting time:	Waiting time after the Windows computer has stopped being accessible. Windows applications may delay the shutdown of the computer after port 445 has been closed.	Required
Force	Close all programs on the Windows computer, even if dialogs are still open. If Force is not selected, Windows waits up to 20 seconds. This delays the shutdown process or the Windows computer is switched off before Windows has shut down.	Required
Restart	Restart the windows computer	Required
Run during restart	When the control restarts, restart the Windows computer as well. Effective only if the control is restarted using the shutdown icon at the bottom right in the taskbar or if it is restarted as a result of a change in the system settings (e.g. network settings).	Required
Run during switch-off	Shut down the Windows computer (no restart) when shutting down the control. This is the default behavior. Even the END key will then not trigger a restart.	Required

23.17.1 Configuring an external computer for Windows Terminal Service (RemoteFX)

To configure the external computer (e.g., in Windows 10 operating systems):

- ▶ Press the Windows key
- ▶ Select **Control Panel**
- ▶ Select **System and Security**
- ▶ Select **System**
- ▶ Select **Remote Settings**
- > The computer opens a pop-up window.
- ▶ Under **Remote Assistance**, enable **Allow Remote Assistance connections to this computer**
- ▶ In the **Remote Desktop** area, enable **Allow Remote connections to this computer**
- ▶ Press **OK** to confirm your settings

23.17.2 Establishing and starting a connection

To establish and start a connection:

- ▶ Open **Remote Desktop Manager**
- ▶ Select **New connection**
- > The control displays a selection menu.
- ▶ Select a connection option
- ▶ Under **Windows Terminal Service (RemoteFX)**, select the operating system
- > The control opens the **Edit the connection** window.
- ▶ Define the connection settings
- ▶ **Further information:** "Connection settings", Page 479
- ▶ Press **OK**
- > The control saves the settings and closes the window.
- ▶ Select connection
- ▶ Select **Start the connection**
- > The control starts the connection.

23.17.3 Exporting and importing connections

To export a connection:

- ▶ Open **Remote Desktop Manager**
- ▶ Select the desired connection
- ▶ Select the right arrow icon in the menu bar
- > The control displays a selection menu.
- ▶ Select **Export the connections**
- > The control opens the **Select export file** window.
- ▶ Define the name of the saved file
- ▶ Select the target file
- ▶ Select **Save**
- > The control saves the connection data under the name defined in the window.

To import a connection:

- ▶ Open **Remote Desktop Manager**
- ▶ Select the right arrow icon in the menu bar
- > The control displays a selection menu.
- ▶ Select **Import connections**
- > The control opens the **Select file to import** window.
- ▶ Select file
- ▶ Select **Open**
- > The control creates the connection under the name that was defined originally in the **Remote Desktop Manager**.

Notes

NOTICE

Caution: Data may be lost!

If you do not shut down external computers properly, data may be irreversibly damaged or deleted.

- ▶ Configure the automatic shutdown of the Windows computer

- When you edit an existing connection, the control will automatically delete all impermissible characters from the name.

Notes in connection with the IPC 6641

- HEIDENHAIN assures a functioning connection between HEROS 5 and the IPC 6641. No guarantee is given for other combinations and connections.
- If you use the computer name **IPC6641.machine.net** to connect an IPC 6641, it is important to enter **.machine.net**.

With this entry, the control automatically searches the Ethernet interface **X116**, and not the interface **X26**; this reduces the time needed for access.

23.18 Firewall

Application

With the control you can set up a firewall for the primary network interface, and for a sandbox if needed. You can block incoming network traffic for specific senders and services.

Related topics




- Existing network connection
Further information: "Ethernet interface", Page 453
- SELinux security software
Further information: "SELinux security software", Page 449

Description of function


To navigate to this function:

Settings ► **Network/Remote Access** ► **Firewall**

If you activate the firewall, the **Firewall settings** window displays a symbol at the bottom right of the taskbar. The control displays the following symbols, depending on the security level:



Icon	Meaning
	<p>Firewall protection does not yet exist although it has been activated.</p> <p>Example: A dynamic IP address is used in the network interface configuration, but the DHCP server has not yet assigned an IP address.</p> <p>Further information: "The DHCP server tab", Page 457</p>
	<p>Firewall active with medium security level.</p>
	<p>Firewall active with high security level. All services except for SSH are blocked.</p>

Firewall settings



The **Firewall settings** window contains the following settings:

Setting	Meaning
Active	Activate or deactivate firewall
Interface	Select the interface <ul style="list-style-type: none"> ■ eth0: X26 of the control ■ eth1: X116 of the control ■ brsb0: Sandbox (optional) If a control has two Ethernet interfaces, then by default the DHCP server for the machine network is active for the second interface. With this setting you cannot activate the firewall for eth1 because the firewall and DHCP server mutually exclude each other.
Report other inhibited packets	Activate the firewall with a high security level All services except for SSH are blocked.
Inhibit ICMP echo answer	If this check box is selected, the control does not respond to a ping request.

Setting	Meaning
Service	<p data-bbox="539 360 1437 421">Brief designation of services configured with the firewall. You can change the settings even if the services are not started.</p> <ul style="list-style-type: none"> <li data-bbox="539 432 1437 533"> <p data-bbox="539 432 630 461">■ DNC</p> <p data-bbox="572 472 1390 533">DNC server using the RPC protocol for external applications that were developed with RemoTools SDK (port 19003)</p> <div data-bbox="576 544 1461 640" style="border: 1px solid black; padding: 5px;"> <p data-bbox="587 555 1358 616"> For more detailed information, consult the RemoTools SDK manual.</p> </div> <li data-bbox="539 656 1299 723"> <p data-bbox="539 656 655 685">■ LDAPS</p> <p data-bbox="572 696 1299 723">Server with user data and configuration of user administration</p> <li data-bbox="539 734 1437 835"> <p data-bbox="539 734 639 763">■ LSV2</p> <p data-bbox="572 775 1426 835">Functionality for TNCremo, TeleService, and other HEIDENHAIN PC tools (port 19000)</p> <div data-bbox="576 846 1461 1182" style="border: 1px solid black; padding: 5px;"> <p data-bbox="587 857 1430 1043"> The control might not support connection configurations that use the LSV2 protocol. When the control detects a non-secure connection, it displays a warning message with additional information. In this case, please contact the provider of the corresponding application. HEIDENHAIN recommends the use of the OPC UA or DNC application for access to the control.</p> <p data-bbox="667 1055 1385 1115">Further information: "OPC UA NC Server (#56-61 / #3-02-1*)", Page 462</p> <p data-bbox="667 1126 1289 1155">Further information: "The DNC menu item", Page 468</p> </div> <li data-bbox="539 1193 1222 1261"> <p data-bbox="539 1193 671 1223">■ OPC UA</p> <p data-bbox="572 1234 1222 1261">Service provided by the OPC UA NC Server (port 4840).</p> <li data-bbox="539 1272 1450 1406"> <p data-bbox="539 1272 628 1301">■ SMB</p> <p data-bbox="572 1312 1450 1406">Only incoming SMB connections, meaning a Windows share on the control. Outgoing SMB connections are not influenced, meaning a Windows share connected to the control.</p> <li data-bbox="539 1417 1417 1518"> <p data-bbox="539 1417 624 1447">■ SSH</p> <p data-bbox="572 1458 1417 1518">SecureShell protocol (port 22) for secure LSV2 handling with active user administration; starting with HEROS 504</p> <li data-bbox="539 1529 1406 1731"> <p data-bbox="539 1529 628 1559">■ VNC</p> <p data-bbox="572 1570 1406 1693">Access to screen contents. If you block this service, then not even TeleService programs from HEIDENHAIN can access the control. If you block this service, the control displays a warning in the VNC settings window.</p> <p data-bbox="572 1704 1198 1731">Further information: "The VNC menu item", Page 473</p>
Method	<p data-bbox="539 1749 802 1778">Configure accessibility</p> <ul style="list-style-type: none"> <li data-bbox="539 1789 1090 1818">■ Prohibit all: Cannot be accessed by anyone <li data-bbox="539 1830 1054 1859">■ Permit all: Can be accessed by everyone <li data-bbox="539 1870 1214 1899">■ Permit some: Can be accessed only by specific clients <p data-bbox="572 1910 1450 2002">In the Computer column you must define the computer for which access is permitted. If you do not define a computer, the control activates Prohibit all.</p>

Setting	Meaning
Log	The control shows the following messages when transmitting network packets: <ul style="list-style-type: none"> ■ Red: Network packet blocked ■ Blue: Network packet accepted
Computer	IP address or host name of the computers with access rights. Separated by commas, if there are multiple computers The control converts the host name to an IP address when the control starts. If the IP address changes, you must restart the control or change the setting. The control issues an error message if it cannot convert the host name to an IP address. Only for the Permit some method
Advanced options	Only for network specialists
Set standard values	Reset the settings to the default values recommended by HEIDENHAIN

Notes

- Have your network specialist check and, if necessary, change the standard settings.
- When user administration is active, you can set up only secure network connections via SSH. The control automatically disables the LSV2 connections via the serial interfaces (COM1 and COM2) and the network connections without user authentication.
- The firewall does not protect the second network interface **eth1**. Connect only trustworthy hardware to this interface, and do not use this interface for Internet connections.

23.19 Portscan

Application

With the **Portscan** function, the control checks all open, incoming TCP and UDP listen ports at defined intervals or when commanded. The control shows a message if a port is not listed.

Related topics

- Firewall settings
Further information: "Firewall", Page 483
- Network settings
Further information: "Network configuration with Advanced Network Configuration", Page 541

Description of function

To navigate to this function:

Settings ► **Diagnostics/Maintenance** ► **Portscan**

The control searches for all open, incoming TCP and UDP listen ports on the system and compares them to the following whitelists:

- System-internal whitelists **/etc/sysconfig/portscan-whitelist.cfg** and **/mnt/sys/etc/sysconfig/portscan-whitelist.cfg**
- Whitelist for ports with machine-manufacturer-specific functions: **/mnt/plc/etc/sysconfig/portscan-whitelist.cfg**
- Whitelist for ports with customer-specific functions: **/mnt/tnc/etc/sysconfig/portscan-whitelist.cfg**

Each whitelist contains the following information:

- Port type (TCP/UDP)
- Port number
- Offering program
- Comments (optional)

Start the portscan manually by selecting the **Start** button in the **Manual Execution** area. In the **Automatic Execution** area, you can use the **Automatic update on** function to specify that the control will perform the portscan automatically in the selected interval. You define the interval with a slider.

If the control performs the portscan automatically, then only ports listed in the whitelists may be open. The control shows a message window if a port is not listed.

23.20 Backup and restore

Application

With the **NC/PLC Backup** and **NC/PLC Restore** functions you can back up and restore individual folders or the entire **TNC:** drive. You can save the backup files to various types of memory media.

Related topics

- File management, **TNC:** drive
Further information: User's Manual for Programming and Testing

Description of function

To navigate to this function:

Settings ▶ **Diagnostics/Maintenance** ▶ **NC/PLC Backup**

Settings ▶ **Diagnostics/Maintenance** ▶ **NC/PLC Restore**

The backup function creates a ***.tncbck** file. The restore function can restore these files as well as files from existing TNCbackup programs. If you double-tap or double-click a ***.tncbck** file in the file manager, the control starts the restore function.

Further information: User's Manual for Programming and Testing

Within the backup function you can chose between the following types of backups:

- **Back up the “TNC:” partition**
Back-up all data on the **TNC:** drive
- **Back up the directory tree**
Back-up the selected folders and their subfolders on the **TNC:** drive
- **Back up the machine configuration**
Only for the machine manufacturer
- **Complete backup (TNC: and machine configuration)**
Only for the machine manufacturer

Backup and restore is subdivided into several steps. Navigate between these steps with the **FORWARD** and **BACK** buttons.

23.20.1 Backing up data

To back-up the data of the **TNC:** drive:

- ▶ Select the **Settings** application
- ▶ Select **Diagnostics/Maintenance**
- ▶ Double-tap or double-click **NC/PLC Backup**
- > The control opens the **Back up the “TNC:” partition** window.
- ▶ Specify the type of backup
- ▶ Select **Forward**
- ▶ If necessary, pause the control with **Stop NC software**
- ▶ Select any predefined exclusion rules or ones you have defined yourself
- ▶ Select **Forward**
- > The control generates a list of files for backing up.
- ▶ Check list
- ▶ Deselect files if necessary
- ▶ Select **Forward**
- ▶ Enter the name of the backup file
- ▶ Select the storage path
- ▶ Select **Forward**
- > The control generates the backup file.
- ▶ Confirm with **OK**
- > The control concludes the backup process and restarts the NC software.

23.20.2 Restoring data

NOTICE

Caution: Data may be lost!

When you restore data (Restore function), any existing data will be overwritten without a confirmation prompt. Existing data is not automatically backed up by the control before running the restore process. Power failures or other problems can interfere with the data restore process. As a consequence, data may be irreversibly damaged or deleted.

- ▶ Before starting the data restore process, make a backup of the existing data

To restore data:

- ▶ Select the **Settings** application
- ▶ Select **Diagnostics/Maintenance**
- ▶ Double-tap or double-click **NC/PLC Restore**
- > The control opens the **Restore data - %1** window.
- ▶ Select the archive to be restored
- ▶ Select **Forward**
- > The control generates a list of files for restoring.
- ▶ Check list
- ▶ Deselect files if necessary
- ▶ Select **Forward**
- ▶ If necessary, pause the control with **Stop NC software**
- ▶ Select **Extract archive**
- > The control restores the files.
- ▶ Confirm with **OK**
- > The control restarts the NC software.

Note

The TNCbackup PC program can also process *.**tncbck** files. TNCbackup is part of TNCremo.

23.21 TNCdiag

Application

The control displays status and diagnostic information of HEIDENHAIN components in the **TNCdiag** window.

Description of function

To navigate to this function:

Settings ► **Diagnostics/Maintenance** ► **TNCdiag**



Only use this function after consultation with your machine manufacturer.



For more information, please refer to the **TNCdiag** documentation.

23.22 Update the documentation

Application

The **Update the documentation** function can be used, for example, to install or update the integrated **TNCguide** product help.

Related topics

- Integrated product help **TNCguide**
Further information: "User's Manual as integrated product aid: TNCguide", Page 38
- Product help on the HEIDENHAIN website
TNCguide

Description of function

To navigate to this function:

Settings ► **Diagnostics/Maintenance** ► **Update the documentation**

The file manager is located in the **Update the documentation** area. You can select and install the desired documentation from the file manager.

Further information: "Transferring TNCguide", Page 491

The control shows all available documents in the **Help** application.



In the **Update the documentation** area, you can install all HEIDENHAIN-specific documents (e.g., NC error messages).


23.22.1 Transferring TNCguide

You can find and transfer the desired **TNCguide** version as follows:

- ▶ Select the link to the HEIDENHAIN website
https://content.heidenhain.de/doku/tnc_guide/html/de/index.html
- ▶ Select **TNC Controls**
- ▶ Select **TNC7 Series**
- ▶ Select the NC software number
- ▶ Navigate to **Product help (HTML files)**
- ▶ Select **TNCguide** in the desired language
- ▶ Select path to save the file
- ▶ Select **store**
- > The download begins.
- ▶ Transfer the downloaded file to the TNC control



- ▶ Select the **Home** operating mode
- ▶ Select the **Settings** application
- ▶ Select **Diagnostics/Maintenance**
- ▶ Select **Update documentation**
- > The control opens the **Select installation file** area.
- ▶ Select the desired file with extension ***.tncdoc**



- ▶ Select **Open**
- > A pop-up window appears, stating whether the installation was successful or failed.



- ▶ Select the **Help** application
- ▶ Select **home**
- > The control shows all available documentation.

23.23 Machine parameters

Application

You can configure the behavior of the control with machine parameters. For this purpose, the control provides the **MPs for Users** and **MPs for setters** applications. You can open the **MPs for Users** application at any time without having to enter a code number.

The machine manufacturer defines which machine parameters are in which applications. HEIDENHAIN offers a standard scope of parameters for the **MPs for setters** application. The following contents describe only the standard scope of the **MPs for setters** application.

Related topics

- List of machine parameters for the **MPs for setters** application
Further information: "Machine parameters", Page 548

Requirements

- Code number 123
Further information: "Code numbers", Page 439
- The contents of the **MPs for setters** application have been defined by the machine manufacturer

Description of function

To navigate to this function:

Settings ▶ Machine Parameters ▶ MPs for setters

In the **Machine Parameters** group the control shows only those menu items that you can choose with the current access rights.


If you open an application for machine parameters, the control displays the configuration editor.

The configuration editor offers the following workspaces:

- **Details**
- **Document**
- **List**

You cannot close the **List** workspace.

Configuration editor areas



The **MPs for setters** application with a machine parameter selected

The configuration editor shows the following areas:

1 The **Search** column

You can search forward or backward with the following characteristics:

- **Name**
This is the language-neutral name used for machine parameters in the User's Manual.
- **Number**
This is the unique number used for machine parameters in the User's Manual.
- **MP number of the iTNC 530**
- **Value**
- **Key name**
Machine parameters for axes or channels exist more than once. In order to avoid ambiguity, each axis and each channel is identified with a key name (e.g., **X1**)
- **Comment**

The control displays the results.

2 Title bar of the **List** workspace

The title bar of the **List** workspace includes the following functions:

- Open or close the **Search** column
- Filter contents using a selection menu
- Toggle between structure and table views

In the table view, you can compare data objects.

The control displays the following information:

- Name of the objects
- Symbols of the objects
- Machine parameter values
- Open or close the **Details** workspace
Further information: "The Details workspace", Page 496
- Open or close the **Configuration** window
Further information: "Configuration window", Page 496

3 Navigation column

The control provides the following options for navigation:

- Navigation path
- Favorites
- 21 most recent changes
- Structure of the machine parameters

4 Content column

In the content column the control displays objects, machine parameters, or changes that you select using the search function or navigation column.













5 The **Details** workspace

The control displays information on the selected machine parameter or the most recent change you made.

Further information: "The Details workspace", Page 496

Icons and buttons

The configuration editor contains the following icons and buttons:

Icon or button	Meaning
	Activate or deactivate the table view The control toggles between structure and table views. Further information: "Configuration editor areas", Page 493
	Open or close the Details workspace Further information: "The Details workspace", Page 496
	Open or close the Configuration window Further information: "Configuration window", Page 496
	Select Recent changes
	Object exists <ul style="list-style-type: none"> ■ Data object ■ Directory ■ Parameter list
	Object empty
	Machine parameter exists
	Optional machine parameter does not exist
	Machine parameter invalid
	Machine parameter readable but not editable
	Machine parameter not readable and not editable
	Changes to the machine parameter not yet saved
Functions	Open the context menu Further information: User's Manual for Programming and Testing
Check the axis configuration	Only for the machine manufacturer
Calculate controller param.	Only for the machine manufacturer
Attribute information	Only for the machine manufacturer
Save	The control opens a window with all of the changes since the most recent saving. You can save or discard the changes.

Configuration window

The **Configuration** window includes the **Show MP descriptive texts** toggle switch.

If the toggle switch is active, the control displays a description of the machine parameter in the active conversational language.

If the toggle switch is not active, the control displays the language-neutral name of the machine parameter.

The Details workspace

If you select contents from the favorites or the structure, the control will display information in the **Details** workspace, such as:

- Type of object, such as data object list or parameter
- Descriptive text of machine parameter
- Permitted or required input
- Prerequisite for the change (e.g., program run blocked)
- Number of the machine parameter on the iTNC 530
- Machine parameter optional

This information is included if a machine parameter can be enabled optionally.

If you select contents from the most recent changes you made, the control will display the following information in the **Details** workspace:

- Sequential number of the last change
- Previous value
- New value
- Date and time of change
- Descriptive text of machine parameter
- Permitted or required input

23.23.1 Note

The machine manufacturer offers further applications for machine parameters.

If later customization of the machine configuration by the machine manufacturer is intended, the machine operator might incur additional costs.

23.24 Configuring the control's user interface

Application

Each user can create and activate configurations in which the control's user interface is individually adapted.

Related topics

- Workspaces
Further information: "Workspaces", Page 66
- Control interface
Further information: "Areas of the control's user interface", Page 63

Description of function

To navigate to this function:

Settings ▶ Configurations ▶ Configurations

A configuration contains all adaptations to the control's user interface that do not influence the control's actual functions.

- Settings for the TNC bar
- Arrangement of workspaces
- Font size
- Favorites

The **Configurations** area contains the following functions:

Function	Meaning
Active Configuration	Activate a configuration from a selection menu Further information: "The Desktop menu workspace", Page 80
Default configuration	Use the Reset button to apply the settings of the OEM configuration to the active configuration.
Save as OEM Configuration	The machine manufacturer can use the Save button to overwrite the OEM configuration .
Save current settings	With the Save button, you can save the current version of the active configuration.
Restore last configuration	With the Reset button, you can discard any customizations and revert to the saved version of the active configuration.

The control displays the following information about all available configurations in a table:

Column	Meaning
Configuration Name	Name of the configuration
Selectable	If this toggle switch is active, you can select the configuration in the Active configuration selection menu.
Exportable	If this toggle switch is active, you can export the configuration. Further information: "Exporting and importing configurations", Page 498
Edit	This column contains two buttons, for renaming and deleting the configuration.

Press the **Add** button to create a new configuration.

23.24.1 Exporting and importing configurations

To export configurations:

- ▶ Select the **Settings** application
- ▶ Select **Configurations**
- > The control opens the **Configurations** area.
- ▶ Activate the **Exportable** toggle switch for the desired configuration, if necessary

Export

- ▶ Select **Export**
- > The control opens the **Save as** window.
- ▶ Select the target file
- ▶ Enter a file name

Create

- ▶ Select **Create**
- > The control saves the configuration file.

To import configurations:

Import

- ▶ Select **Import**
- > The control opens the **Import configurations** window.
- ▶ Select file

Import configuration

- ▶ Select **Import configuration**
- > If importing a configuration would overwrite a file with the same name, the control displays a prompt.
- ▶ Select the procedure:
 - **Overwrite**: the control overwrites the original configuration.
 - **Keep**: the control does not import the configuration.
 - **Cancel**: the control cancels the import process.

Notes

- Delete only inactive configurations. If you delete an active configuration, the control first activates a default configuration. This can lead to delays.
- The **Overwrite** function permanently replaces existing configurations.

24

User Administration

24.1 Fundamentals

Application

User administration enables you to create and administrate different users with different access rights to various functions of the control. You can assign roles to the various users that reflect their respective tasks, such as machine operator or setup technician.

User administration is inactive in the control's factory default setting. This status is called **Legacy-Mode**.


Description of function

User administration supports you in the following fields of security, based on the requirements of the IEC 62443 series of standards:

- Application security
- Network security
- Platform security

The user administration differentiates between the following terms:

- User
Further information: "Users", Page 500
- Roles
Further information: "Roles", Page 502
- Rights
Further information: "Rights", Page 502



Users

The user administration offers the following types of users:

- Function users pre-defined by HEIDENHAIN
- Function users pre-defined by the machine manufacturer
- Self-defined users

Depending on the task assigned, you can use one of the pre-defined function users or you have to create a new user.

Further information: "Creating a new user", Page 506

If you deactivate user administration, the control saves all configured users. Thus they will be available again when user administration is reactivated.

If you want to delete the configured users upon deactivation, you need to set this explicitly when deactivating user administration.

Further information: "Deactivating user administration", Page 507

HEIDENHAIN function users

HEIDENHAIN function users are pre-defined users that are automatically created upon activation of user administration. Function users cannot be changed.

HEIDENHAIN provides four different function users in the control's factory default setting.

- **useradmin**

The **useradmin** function user is automatically created upon activation of user administration. The **useradmin** function user allows you to configure and edit user administration.

- **sys**

The **sys** function user allows you to access the **SYS:** drive of the control. This function user is reserved for use by HEIDENHAIN service personnel.

- **user**

In **legacy mode**, the **user** function user is automatically logged on to the system during control startup. When user administration is active, the **user** function user has no effect. The logged-on user of the type **user** cannot be changed in **legacy mode**.

- **oem**

The **oem** function user is intended for the machine manufacturer. The **oem** function user allows you to access the **PLC:** drive of the control.

The useradmin function user

The **useradmin** user is comparable to the local administrator of a Windows system.

The **useradmin** account provides the following functions:

- Creating databases
- Assigning the password data
- Activating the LDAP database
- Exporting LDAP server configuration files
- Importing LDAP server configuration files
- Emergency access if the user database was destroyed
- Retroactive change of the database connection
- Deactivating user administration

Function users pre-defined by the machine manufacturer

Your machine manufacturer defines function users who are required for specific tasks such as machine maintenance.

By entering code numbers or passwords that replace code numbers, you can temporarily enable rights of **oem** function users.

Further information: "The Active user window", Page 508

The machine manufacturer's function users can already be active in **legacy mode** and replace code numbers.

Roles

HEIDENHAIN combines several rights for individual task areas to roles. Different pre-defined roles that you can use to assign rights to your users are available. The tables below describe the individual rights of the different roles.

Further information: "List of roles", Page 558

Advantages of classification in roles:

- Simplified administration
- Different rights are compatible between different software versions of the control and different machine manufacturers.

User administration offers roles for the following tasks:

- **Operating system roles:** access to functions of the operating system and interfaces
- **NC operator roles:** access to functions for programming, setting up and running NC programs
- **Machine tool builder (PLC) roles:** access to functions for configuring and checking the control

Every user should have at least one role from the operating system area and at least one role from the programming area.

HEIDENHAIN recommends permitting more than one person to access an account with the HEROS.Admin role. This ensures that necessary changes to user administration can also be made in the administrator's absence.

Local or remote registration

You can enable a role either for local login or for remote login. With local login, the user directly logs on to the control at the control's screen. A remote login (DNC) is a connection via SSH.

Further information: "SSH-secured DNC connection", Page 521

If a role is only enabled for local login, Local. is added to the role name (e.g., Local.HEROS.Admin instead of HEROS.Admin).

If a role is only enabled for remote login, Remote. is added to the role name (e.g., Remote.HEROS.Admin instead of HEROS.Admin).

You can therefore also make the rights of a user dependent on the access used to operate the control.

Rights

The user administration is based on the Unix rights management. Access to the control is controlled by means of rights.

Rights gather various functions of the control (e.g., editing the tool table).

User administration offers rights for the following tasks:

- HEROS rights
- NC rights
- PLC rights (machine manufacturer)

If more than one role is assigned to a user, he will be granted all rights contained in these roles.



Ensure that every user is assigned all access rights he needs. The access rights result from the tasks a user performs on the control.

The access rights of HEIDENHAIN function users are already pre-defined in the control's factory default setting.

Further information: "List of rights", Page 562

Password settings

If you use an LDAP database, users with the HEROS.Admin role can define password requirements. For this, the control provides the **Password settings** tab.

Further information: "Saving user data", Page 509

The following parameters are available:

Password lifetime

- **Validity period of password:**
Here, you can indicate how long the password can be used.
- **Warning before expiration:**
From the defined time, a warning will be issued that the password will soon expire.

Password quality

- **Minimum password length:**
Here, you can indicate the minimum password length.
- **Minimal number of character classes (upper/lower, digits, special):**
Here, you can indicate the minimum number of different character classes required in the password.
- **Maximum number of repeated characters:**
Here, you can indicate the maximum number of identical successive characters in the password.
- **Maximum length of character sequences:**
Here, you can indicate the maximum length of the character sequences to be used in the password (e.g., 123).
- **Dictionary check (number of matching characters):**
Here, you can enable a check whether the password contains known words and specify the allowed number of meaningful characters.
- **Minimum number of characters changed compared to previous password:**
Here, you can specify how many characters in the new password must be different from the previous one.

You define the values for each parameter on a scale.

For reasons of security, passwords should comply with the following criteria:

- Eight characters minimum
- Letters, numbers, and special characters
- Avoid using whole words or a sequence of characters (e.g., Anna or 123)



If you want to use special characters, pay attention to the keyboard layout. HEROS assumes a US keyboard, the NC software assumes a HEIDENHAIN keyboard. External keyboards can be freely configured.

Additional directories

HOME: drive

When user administration is active, a private **HOME:** directory, to which you can save your private programs and files, is available to every user.

The **HOME:** directory can be viewed by the respectively logged-in users as well as users with the HEROS.Admin role.

public directory

Upon the first activation of user administration, the **public** directory below the **TNC:** drive will be connected.

The **public** directory can be accessed by any user.

In the **public** directory you can, for example, make files available to other users.

24.1.1 Configuring user administration

User administration needs to be configured before you can use it.

Perform the following steps for configuration:

- 1 Opening the **User administration** window
- 2 Activating user administration
- 3 Defining the password for the **useradmin** function user
- 4 Setting up a database
- 5 Creating a new user



- You can exit the **User administration** window after each configuration step.
- If you exit the **User administration** window directly after having activated user administration, the control will prompt you for a restart once.

Opening the User administration window

To open the **User administration** window:

- ▶ Select the **Settings** application
- ▶ Select **Operating System**
- ▶ Double-tap or double-click **CurrentUser**
- ▶ The control opens the **User administration** window in the **Settings** tab.

Further information: "The User administration window", Page 508

Activating user administration

To activate user administration:

- ▶ Select **User administration active**
- ▶ The control shows the message **Password for user 'useradmin' missing**.
- ▶ Retain or reactivate the active status of the **Anonymize users in log data** function



- The purpose of the **Anonymize users in log data** function is data privacy; this function is active by default. While this function is active, user data in all log files of the control will be anonymized.
- If you exit the **User administration** window directly after having activated user administration, the control will prompt you for a restart once.

Define the password for the useradmin function user

If you are activating user administration for the first time, you must define a password for the **useradmin** function user.

Further information: "Users", Page 500

To define a password for the **useradmin** function user:

- ▶ Select **Password for useradmin**
- > The control opens the **Password for user 'useradmin'** pop-up window.
- ▶ Enter the password for the **useradmin** function user



Please observe the recommendations for passwords.

Further information: "Password settings", Page 503

- ▶ Repeat the password
- ▶ Select **Set new password**
- > The control shows the message **Settings and password for 'useradmin' were changed.**

Setting up a database

To set up a database:

- ▶ Select the database for saving your user data (e.g., **Local LDAP database**)
- ▶ Select **Configuration**
- > The control opens a window for configuring the corresponding database.
- ▶ Follow the instructions from the control in the window
- ▶ Select **APPLY**



The following options are available for saving your user data:

- **Local LDAP database**
- **LDAP on remote computer**
- **Connection to Windows domain**

Parallel operation of Windows users and users from an LDAP database is possible.

Further information: "Saving user data", Page 509

Creating a new user

To create a new user:

- ▶ Select the **User administration** tab
- ▶ Select **Create new user**
- > The control adds a new user to the **User list**.
- ▶ Change the name as needed
- ▶ Edit a password as needed
- ▶ Define a profile image as needed
- ▶ Enter a description as needed
- ▶ Select **Add role**
- > The control opens the **Add role** window.
- ▶ Select a role
- ▶ Select **Add**



You can also add roles using the **Add external login** and **Add local login** buttons.

Further information: "Roles", Page 502

- ▶ Select **Close**
- > The control closes the **Add role** window.
- ▶ Select **OK**
- ▶ Select **APPLY**
- > The control adopts the changes.
- ▶ Select **END**
- > The control opens the **System reboot required** window.
- ▶ Select **Yes**
- > The control restarts.



The user must change the password when logging in for the first time.

24.1.2 Deactivating user administration

User administration can only be deactivated by the following function users:

- **useradmin**
- **OEM**
- **SYS**

Further information: "Users", Page 500

To deactivate user administration:

- ▶ Log in as a function user
- ▶ Opening the **User administration** window
- ▶ Select **User administration inactive**
- ▶ If desired, check **Delete existing user databases** to delete all configured users and user-specific directories
- ▶ Select **APPLY**
- ▶ Select **END**
- > The control opens the **System reboot required** window.
- ▶ Select **Yes**
- > The control restarts.

Notes

NOTICE

Caution: Unwanted data transfer is possible!

If you deactivate the **Anonymize users in log data** function, the system will show personalized user data in all control log files.

If servicing becomes necessary or if the log files need to be transmitted for another reason, the contracting party will be able to view this user data. In this case, it is your responsibility to ensure that all required data protection provisions have been made at your company.

- ▶ Retain or reactivate the active status of the **Anonymize users in log data** function

- Some user administration areas are configured by the machine manufacturer. Refer to your machine manual.
- HEIDENHAIN recommends activating user administration as part of an IT safety concept.
- If both user administration and a screensaver are active, then the current user's password must be entered to unlock the screen.

Further information: "HEROS menu", Page 526

- If you used **Remote Desktop Manager** to establish private connections before user administration was activated, these connections are no longer available after the activation of user administration. Save your private connections before activating user administration.

Further information: "The Remote Desktop Manager window (#133 / #3-01-1)", Page 477

24.2 The User administration window

Application

In the **User administration** window you can activate and deactivate user administration, as well as define its settings.

Related topics

- The **Active user** window
Further information: "The Active user window", Page 508

Requirement

- If user administration is active, the HEROS.Admin role
Further information: "List of roles", Page 558

Description of function

To navigate to this function:

Settings ► **Operating System** ► **UserAdmin**

The **User administration** window contains the following tabs:

Tab	Meaning
Settings	Configure user administration Further information: "Configuring user administration", Page 504
User administration	Create or remove users, change rights, add profile images Further information: "Creating a new user", Page 506
Password settings	Define password requirements Further information: "Password settings", Page 503
User-defined roles	Roles created for a Windows domain Further information: "Connection to Windows domain", Page 512

24.3 The Active user window

Application

In the **Active user** window, the control displays information about the logged on user, such as assigned rights. You can also manage other user settings, such as keys for SSH-secured DNC connections or smartcards for logon, and change the password.

Related topics

- SSH-secured DNC connections
Further information: "SSH-secured DNC connection", Page 521
- Logon with smartcards
Further information: "Logon with smartcards", Page 519
- Available roles and rights
Further information: "User administration roles and rights", Page 558

Description of function

To navigate to this function:

Settings ► **Operating System** ► **Current User**

When you open the **Active user** window, by default the window shows the **Base rights** tab. On this tab the control displays information about the user and all assigned rights.

The **Base rights** tab contains the following buttons:

Button	Meaning
Add rights	On the Added rights tab, enable rights for another user or function user until the next logoff
Open user administration	Open the User administration window Further information: "The User administration window", Page 508
SSH keys and certificates	Manage keys and certificates for client connections Further information: "SSH-secured DNC connection", Page 521 Further information: "OPC UA NC Server (#56-61 / #3-02-1*)", Page 462
Create token	Manage smartcards for logon with a card reader Further information: "Logon with smartcards", Page 519
Delete token	
Close	Close the Active user window

On the **Change password** tab you can check your password against the current requirements or set a new password.

Further information: "Password settings", Page 503

Note

In legacy mode, the **user** function user is automatically logged on to the system during control startup. When user administration is active, the **user** function user has no effect.


Further information: "Users", Page 500

24.4 Saving user data

24.4.1 Overview

The following options are available for saving your user data:

- **Local LDAP database**
Further information: "Local LDAP database", Page 510
- **LDAP on remote computer**
Further information: "LDAP database on a remote computer", Page 511
- **Connection to Windows domain**
Further information: "Connection to Windows domain", Page 512

 Parallel operation of Windows users and users from an LDAP database is possible.

24.4.2 Local LDAP database

Application

With the **Local LDAP database** setting the control saves the user data locally. That way you can activate user administration even on machines without a network connection.

Related topics

- Using an LDAP database on multiple controls
Further information: "LDAP database on a remote computer", Page 511
- Connecting a Windows domain with user administration
Further information: "Connection to Windows domain", Page 512

Requirements

- User administration is active
Further information: "Activating user administration", Page 504
- **useradmin** user is logged on
Further information: "Users", Page 500

Description of function

A local LDAP database offers the following options:

- Using user administration on one single control
- Setting up a central LDAP server for more than one control
- Exporting an LDAP server configuration file if the exported database is to be used by more than one control

Setting up a Local LDAP database

To set up a **Local LDAP database**:

- ▶ Opening the **User administration** window
- ▶ Select **LDAP user database**
- > The control enables the dimmed area for editing the LDAP user database.
- ▶ Select **Local LDAP database**
- ▶ Select **Configuration**
- > The control opens the **Configure local LDAP database** window.
- ▶ Enter the name of the **LDAP domain**
- ▶ Enter the password
- ▶ Repeat the password
- ▶ Select **OK**
- > The control closes the **Configure local LDAP database** window.

Notes

- Before you can start editing the user administration, the control prompts you to enter the password of your local LDAP database.
Passwords must not be trivial and must be known only to the administrators.
- If the host name or domain name of the control changes, you need to reconfigure the local LDAP databases.

24.4.3 LDAP database on a remote computer

Application

With the **LDAP on remote computer** function you can transmit the configuration of a local LDAP database between controls and computers. That way you can use the same users on multiple controls.

Related topics

- Configuring an LDAP database on a control
Further information: "Local LDAP database", Page 510
- Connecting a Windows domain with user administration
Further information: "Connection to Windows domain", Page 512

Requirements

- User administration is active
Further information: "Activating user administration", Page 504
- **useradmin** user is logged on
Further information: "Users", Page 500
- LDAP database has been set up in the company network
- Server configuration file of an existing LDAP database is stored on the control or a PC in the network
If the configuration file is stored on a PC, the PC must be running and accessible through the network.
Further information: "Providing a server configuration file", Page 511

Description of function

The **useradmin** function user can export the server configuration file of an LDAP database.

Providing a server configuration file

To provide a server configuration file:

- ▶ Opening the **User administration** window
- ▶ Select **LDAP user database**
- > The control enables the dimmed area for editing the LDAP user database.
- ▶ Select **Local LDAP database**
- ▶ Select **Export server configuration**
- > The control opens the **Export LDAP configuration file window**.
- ▶ Enter the name for the server configuration file into the name field
- ▶ Save the file to the desired folder
- > The control exports the server configuration file.

Setting up LDAP on remote computer

To set up **LDAP on remote computer**:

- ▶ Opening the **User administration** window
- ▶ Select **LDAP user database**
- > The control enables the dimmed area for editing the LDAP user database.
- ▶ Select **LDAP on remote computer**
- ▶ Select **Import server configuration**
- > The control opens the **Import LDAP configuration file window**.
- ▶ Select the existing configuration file
- ▶ Select **FILE**
- ▶ Select **APPLY**
- > The control imports the configuration file.

24.4.4 Connection to Windows domain

Application

With the **Connection to Windows domain** function, you can connect the data of a domain controller with the control's user administration.

Ask your IT administrator to configure the connection to the Windows domain.

Related topics

- Configuring an LDAP database on a control
Further information: "Local LDAP database", Page 510
- Using an LDAP database on multiple controls
Further information: "LDAP database on a remote computer", Page 511

Requirements

- User administration is active
Further information: "Activating user administration", Page 504
- **useradmin** user is logged on
Further information: "Users", Page 500
- Windows domain controller present in the network
- Domain controller accessible in the network
- Organizational unit for HEROS roles known
- For logon with computer account:
 - You have access to the password of the domain controller
 - You have access to the user interface of the domain controller or you are supported by an IT administrator
- For logon with function user:
 - User name of the function user
 - Password of the function user

Description of function

The control provides the following options to join a Windows domain:

- Create a separate account for the control
- By means of a function user

Your IT administrator can set up a function user to facilitate connectivity to the Windows domain.

Click the **Configuration** button to open the **Configure Windows domain** window.

Further information: "The Configure Windows domain window", Page 514

The Configure Windows domain window

After the domain search, you can customize the Windows domain information or specify new information in the **Configure Windows domain** window.

Your IT administrator will provide the required information.

The **Configure Windows domain** window contains the following settings:

Setting	Meaning
Domain name:	Server name of the Windows domain Is populated by domain search
Key Distribution Center (KDC):	KDC address Is populated by domain search
Alternative admin server:	Deviating server name where the passwords are managed
Map SIDs to Unix UIDs	Map the Windows user SIDs (Security IDs) in Active Directory to the matching Unix UIDs on the control
Use LDAPs	Transfer data using secure LDAPs. LDAPs encrypts user data and passwords. You can select a certificate or disable certificate validation.
Group for login authorization:	Define a special group of Windows users to whom you want to restrict the connection to this control
Organizational unit for HEROS roles:	Modify the organizational unit in which the HEROS role names are stored Specify the configuration of your domain.
Prefix for HEROS role names:	Change the prefix in order to manage users from different workshops, for example. Each prefix given to a HEROS role name can be changed (e.g., HEROS hall 1 and HEROS hall 2) Is populated by domain search
Separator for HEROS role names:	Modify the separator within the HEROS role names
Advanced configuration of domain section	Only for IT administrators

If you enable the **Active Directory with function user** check box, the window contains the following additional settings:

Setting	Meaning
Function user:	Enter the user name and password of the Active Directory function user
Organizational unit for function user:	Specify the organizational unit of the function user

The function user's user name must not contain blanks. The name and organizational unit form the complete path (Distinguished Name, DN) in the Active Directory.

Groups of the domain

If not all of the required roles have been created in the domain as groups, the control issues a warning.

If the control issues a warning, proceed in one of the two following ways:

- Use the **Add role definition** function to enter a role directly in the domain
- Use the **Export role definition** function to export the roles to an *.ldif file

There are the following ways to create groups corresponding to the different roles:


- Automatically when entering the Windows domain by specifying a user with administrator rights
- By importing an import file in .ldif format to the Windows server

The Windows administrator must add the users manually to the roles (security groups) on the domain controller.

Two suggestions describing how the groups can be structured by the Windows administrator are given by below.


Example 1

The user is a direct or indirect member of the respective group:



Example 2

Users from various sectors (workshops) are members of groups with different prefixes:



Joining a Windows domain with a computer account

To join a Windows domain with a computer account:

- ▶ Opening the **User administration** window
- ▶ Select **Connection to Windows domain**
- ▶ Select the **Join Active Directory domain (with computer account)** check box
- ▶ Select **Find domain**
- > The control selects a domain.
- ▶ Select **Configuration**
- ▶ Check the data for **Domain name:** and **Key Distribution Center (KDC):**
- ▶ Enter **Organizational unit for HEROS roles:**
- ▶ Select **OK**
- ▶ Select **APPLY**
- > The control opens the **Connect to domain** window.



The **Organizational unit for computer account:** function allows you to specify in which of the already existing organizational units you want to create the access, such as

- ou=controls
- cn=computers

The values you enter must match the conditions of the domain. The terms are not exchangeable.

- ▶ Enter the user name of the domain controller
- ▶ Enter the password of the domain controller
- ▶ Confirm your input
- > The control connects to the Windows domain found.
- > The control checks whether all of the required roles have been created in the domain as groups.
- ▶ Add groups, if necessary

Further information: "Groups of the domain", Page 515

Joining a Windows domain with a function user

To join a Windows domain with a function user:

- ▶ Opening the **User administration** window
- ▶ Select **Connection to Windows domain**
- ▶ Select the **Active Directory with function user** check box
- ▶ Select **Find domain**
- > The control selects a domain.
- ▶ Select **Configuration**
- ▶ Check the data for **Domain name:** and **Key Distribution Center (KDC):**
- ▶ Enter **Organizational unit for HEROS roles:**
- ▶ Enter the user name and password of the function user
- ▶ Press **OK**
- ▶ Select **APPLY**
- > The control connects to the Windows domain found.
- > The control checks whether all of the required roles have been created in the domain as groups.

Exporting and importing a Windows configuration file

If you have connected the control to the Windows domain, you can export the required configurations for other controls.

To export the Windows configuration file:

- ▶ Open the **User administration** window
- ▶ Select **Connect to Windows domain**
- ▶ Select **Export the Windows config.**
- > The control opens the **Export the Windows domain configuration** window.
- ▶ Select the directory for the file
- ▶ Enter the name for the file
- ▶ Select the **Export the function user's password?** check box, if required
- ▶ Select **Export**
- > The control saves the Windows configuration as a BIN file.

To import the Windows configuration file of another control:

- ▶ Open the **User administration** window
- ▶ Select **Connect to Windows domain**
- ▶ Select **Import the Windows config.**
- > The control opens the **Import the Windows domain configuration** window.
- ▶ Select the existing configuration file
- ▶ Select the **Import the function user's password?** check box, if required
- ▶ Select **Import**
- > The control adopts the configurations for the Windows domain.

24.5 Autologin in user administration

Application

If the **Autologin** function is enabled, during startup the control automatically logs on a selected user without the need to enter a password.

As opposed to the **legacy mode**, this enables you to restrict a user's rights without entering a password.

Related topics

- User login
Further information: "Logging on with user administration", Page 518
- Configure user administration
Further information: "Configuring user administration", Page 504

Requirements

- User administration has been configured
- The user for **Autologin** has been defined

Description of function

With the **Enable autologin** check box in the **User administration** window, you can define a user for autologin.

Further information: "The User administration window", Page 508

The control then automatically logs this user on and displays the user interface according to the defined rights.

For further authorizations, the control still requires an authentication to be entered.

Further information: "Window for requesting additional rights", Page 520

24.6 Logging on with user administration

Application

The control displays a dialog window for user logon. Within the dialog the user can log on with a password or a smartcard.

Related topics

- Automatic user logon
Further information: "Autologin in user administration", Page 518

Requirements

- User administration has been configured
- For logon with smartcards:
 - Euchner EKS card reader
 - Smartcard assigned to a user
Further information: "Assigning a smartcard to a user", Page 520

Description of function

The control displays the Login dialog in the following cases:

- After the **User logout** function has been executed
- After the **Switch user** function has been executed
- After the screen has been locked by the **screensaver**
- Immediately after control startup if user administration is active and **Autologin** is not enabled

Further information: "HEROS menu", Page 526

The logon dialog gives you the following options:

- Users who logged in at least once
- **Other** user

Logon with smartcards

You can save a user's logon data on a smartcard and then log the user on with a card reader, without needing to enter a password. You can define whether a PIN is necessary for logon.

The card reader is attached over a USB port. You assign the smartcard to a reader as a token.


Further information: "Assigning a smartcard to a user", Page 520

The smartcard also has additional memory space, where the machine manufacturer can store his own user-specific data.

24.6.1 Logging on a user with password

To logon a user the first time:

- ▶ Select **Other** in the login dialog
- > The control enlarges the user icon you selected.
- ▶ Enter the user name
- ▶ Enter the user's password


 The control shows in the Login dialog whether CAPS LOCK is active.

- > The control opens a window with the message **Password expired. Change the password now.**
- ▶ Enter the current password
- ▶ Enter a new password
- ▶ Repeat the new password
- > The control uses the new user to log you in.
- > The control displays this user in the dialog during the next logon procedure.

24.6.2 Assigning a smartcard to a user

To assign a smartcard to a user:

- ▶ Insert a blank smartcard in the card reader
- ▶ Logon the desired smartcard user in user administration
- ▶ Select the **Settings** application
- ▶ Select **Operating System**
- ▶ Double-tap or double-click **Current User**
- > The control opens the **Active user** window.
- ▶ Select **Create token**
- > The control opens the **Write certificate to token** window.
- > The control displays the smartcard in the **Select token** area.
- ▶ Select the smartcard as the token to be written
- ▶ Enable the **PIN protection?** check box, if required
- ▶ Enter user password (and PIN, if desired)
- ▶ Select **Start writing**
- > The control saves the user's logon data on the smartcard.



Notes

- You must restart the control in order for it to detect a card reader.
- You can overwrite smartcards that already contain information.
- If you change a user's password, you must reassign the smartcard.

24.7 Window for requesting additional rights

Application

If you do not have the rights required for a specific **HEROS menu** item, the control opens the window for requesting additional rights.

In this window, you can temporarily obtain more rights by adding another user's rights.

Related topics


- Temporarily granting additional rights in the **Active user** window

Further information: "The Active user window", Page 508

Description of function

In the **Users that have this right:** field, the control lists all existing users that have the right to use this function.

You must enter the password in order to enable user rights.



Window for requesting additional rights

To attain the rights of users that are not shown, enter their user data. The control will then recognize those users that are contained in the user database.

Notes

- If **Connection to Windows domain** is used, only users that were recently logged on are shown in the selection menu.
- You can't use this window to change user administration settings. The user with the HEROS.Admin role must be logged on in order to do so.

24.8 SSH-secured DNC connection

Application

If user administration is active, external applications also need to authenticate a user so that the suitable rights can be assigned.

For DNC connections using the RPC or LSV2 protocol, the connection is routed through an SSH tunnel. This method assigns the remote user to a user set up on the control, granting the remote user this user's rights.

Related topics

- Forbidding non-secure connections
Further information: "Firewall", Page 483
- Roles for remote logon
Further information: "Roles", Page 502

Requirements

- TCP/IP network
- The remote computer acts as SSH client
- The control acts as SSH server
- Key pair consisting of
 - Private key
 - Public key


Description of function

Concept of transmission through an SSH tunnel

An SSH connection is always set up between an SSH client and an SSH server.

A key pair is used to protect the connection. This key pair is generated on the client. The key pair consists of a private key and a public key. The private key remains with the client. During setup, the public key is transferred to the server and assigned to a certain user.

The client tries to connect to the server using the pre-defined user name. The server can use the public key to verify that the requester of the connection holds the associated private key. If yes, the server accepts the SSH connection and assigns it to the user that has been used for the login. Communication can then be "tunneled" through this SSH connection.



Use in external applications

The PC tools available from HEIDENHAIN, such as TNCremo with version **v3.3** or higher, provide all functions for setting up, establishing, and managing secure connections through an SSH tunnel.

When the connection is set up, the required key pair is generated in TNCremo and the public key is transferred to the control.

This also applies to applications that are using the HEIDENHAIN DNC component from RemoTools SDK for communication. There is no need to adapt existing customer applications.



In order to expand the connection configuration using the associated **CreateConnections** tool, you need to update to **HEIDENHAIN DNC v1.7.1**. A modification of the application source code is not required.

24.8.1 Setting up SSH-secured DNC connections

To set up an SSH-secured DNC connection for the logged-on user:

- ▶ Select the **Settings** application
- ▶ Select **Network/Remote Access**
- ▶ Select **DNC**
- ▶ Activate the **Setup permitted** toggle switch
- ▶ Use **TNCremo** to set up the secure connection (TCP secure).



For details, refer to the integrated help system of TNCremo.

- > TNCremo transmits the public key to the control.



In order to ensure maximum security, deactivate the **Allow password authentication** function after the public key has been stored.

- ▶ Deactivate the **Setup permitted** toggle switch

24.8.2 Removing a secure connection

If you delete a private key from the control, that user no longer has the possibility of a secure connection.

To delete a key:

- ▶ Select the **Settings** application
- ▶ Select **Operating System**
- ▶ Double-tap or double-click **Current User**
- > The control opens the **Active user** window.
- ▶ Select **Certificate and keys**
- ▶ Select the key to be deleted
- ▶ Select **Delete SSH key**
- > The control deletes the selected key.

Notes

- The the encryption used with the SSH tunnel protects the communication from attackers.
- For OPC UA connections, a stored user certificate is used for authentication.
Further information: "OPC UA NC Server (#56-61 / #3-02-1*)", Page 462
- When user administration is active, you can set up only secure network connections via SSH. The control automatically disables the LSV2 connections via the serial interfaces (COM1 and COM2) and the network connections without user authentication.

If user administration is inactive, the control also automatically blocks non-secure LSV2 or RPC connections. In the optional machine parameters **allowUnsecureLsv2** (no. 135401) and **allowUnsecureRpc** (no. 135402), the machine manufacturer can define whether the control will permit non-secure connections. These machine parameters are included in the **CfgDncAllowUnsecur** (no. 135400) data object.

- Once the connection configurations have been set up, they can be shared among all HEIDENHAIN PC tools for establishing a connection.
- You can also transfer a public key to the control by using a USB device or network drive.
- In the **Certificate and keys** window, you can select a file with additional public SSH keys in the **Externally administered SSH key file** area. This allows you to use SSH keys without having to transfer them to the control.

25

**HEROS Operating
System**

25.1 Fundamentals

HEROS is the fundamental basis for all NC controls from HEIDENHAIN. The HEROS operating system is based on Linux, and was adapted for the purposes of NC controls.

The TNC7 basic features the version HEROS 5.

25.2 HEROS menu

Application

In the HEROS menu the control shows information about the operating system. You can change settings or use HEROS functions.

By default you open the HEROS menu through the taskbar at the bottom edge of the screen

Related topics


- Opening HEROS functions through the **Settings** application

Further information: "The Settings Application", Page 435

Description of function

You open the HEROS menu with the green DIADUR icon in the taskbar or with the **DIADUR** key.

Further information: "Taskbar", Page 530




Standard view of the HEROS menu


The HEROS menu contains the following functions:

Area	Function
Header	<ul style="list-style-type: none"> <li data-bbox="536 360 703 387">■ User name Further information: "The Active user window", Page 508 <li data-bbox="536 439 826 465">■ User-specific settings <li data-bbox="536 477 986 546">■ Lock display Only if user administration is active <li data-bbox="536 557 986 627">■ Switch user Only if user administration is active <li data-bbox="536 638 660 665">■ Restart <li data-bbox="536 676 699 703">■ Shut down <li data-bbox="536 714 986 784">■ Log out Only if user administration is active Further information: "User Administration", Page 499
Navigation	<ul style="list-style-type: none"> <li data-bbox="536 840 683 866">■ Favorites <li data-bbox="536 878 740 904">■ Recently used
Diagnostic	<ul style="list-style-type: none"> <li data-bbox="536 925 1222 952">■ GSmartControl: Available only to authorized specialists <li data-bbox="536 963 1206 990">■ HeLogging: Define settings for internal diagnostic files <li data-bbox="536 1001 1139 1028">■ HeMenu: Available only to authorized specialists <li data-bbox="536 1039 1114 1066">■ perf2: Check processor load and process load <li data-bbox="536 1077 970 1104">■ Portscan: Test active connections Further information: "Portscan", Page 487 <li data-bbox="536 1160 1206 1187">■ Portscan OEM: Available only to authorized specialists <li data-bbox="536 1198 1235 1267">■ RemoteService: Start and stop remote maintenance Further information: "Secure Remote Access", Page 537 <li data-bbox="536 1279 1145 1305">■ Terminal: Enter and execute console commands <li data-bbox="536 1317 1394 1420">■ TNCdiag: Evaluates status and diagnostic information of HEIDENHAIN components (particularly motors) and presents it graphically Further information: "TNCdiag", Page 490 <li data-bbox="536 1431 896 1500">■ TNCscope Software for data recording

Area	Function
Settings	<ul style="list-style-type: none"> ■ Adjust screen brightness: Adjust screen brightness ■ Screensaver: Screensaver ■ Current User Further information: "The Active user window", Page 508 ■ Date/Time Further information: "The Adjust system time window", Page 447 ■ Firewall Further information: "Firewall", Page 483 ■ HePacketManager: Available only to authorized specialists ■ HePacketManager Custom: Available only to authorized specialists ■ Language/Keyboards Further information: "Conversational language of the control", Page 448 ■ Network Further information: "Ethernet interface", Page 453 ■ OEM Function Users Further information: "User Administration", Page 499 ■ OPC UA NC Server Connection Assistant Further information: "The OPC UA connection assistant function (#56-61 / #3-02-1*)", Page 466 ■ OPC UA NC Server License Further information: "The OPC UA license settings function (#56-61 / #3-02-1*)", Page 467 ■ PKI Admin: Manage certificates for the control, such as for OPC UA NC Server Further information: "OPC UA NC Server (#56-61 / #3-02-1*)", Page 462 ■ Printer Further information: "Printers", Page 470 ■ Screenshot Config In the Screenshot settings window, you can define under which path and file name the control saves screenshots. The file name can contain a placeholder (e.g., %N for sequential numbering). ■ SELinux Further information: "SELinux security software", Page 449 ■ Shares Further information: "Network drives on the control", Page 450 ■ UserAdmin Further information: "The User administration window", Page 508 ■ VNC Further information: "The VNC menu item", Page 473 ■ WindowManagerConfig: Settings for the Window Manager Further information: "Window Manager", Page 531
Info	<ul style="list-style-type: none"> ■ About HeROS: Open information about the operating system of the control ■ About Xfce: Open information on the Window manager

Area	Function
Tools	<ul style="list-style-type: none"> ■ Switch-off: Shut-down or restart ■ Screenshot: Create screenshots ■ File Manager: Available only to authorized specialists ■ Diffuse Merge Tool: Compare and merge text files <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p> To compare NC programs, the control offers the program comparison function. Further information: User's Manual for Programming and Testing</p> </div> <ul style="list-style-type: none"> ■ Document Viewer: Display and print files (e.g., PDF files) ■ Geeqie: Open, manage, and print graphics ■ Gnumeric: Open, edit, and print tables ■ IDS Camera Manager: Manage cameras connected to the control ■ keypad horizontal: Open virtual keyboard ■ keypad vertical: Open virtual keyboard ■ Leafpad: Open and edit text files ■ NC Control: Start or stop the NC software independently of the operating system ■ NC/PLC Backup Further information: "Backup and restore", Page 487 ■ NC/PLC Restore Further information: "Backup and restore", Page 487 ■ QupZilla: Alternative web browser for touch operation ■ Real VNC Viewer: Define the settings for external software accessing the control (e.g., for maintenance purposes) ■ Remote Desktop Manager Further information: "The Remote Desktop Manager window (#133 / #3-01-1)", Page 477 ■ Ristretto: Open graphics files ■ Secure Remote Access Further information: "Secure Remote Access", Page 537 ■ Combine fixtures Further information: "Combining fixtures in the New Fixture window", Page 231 ■ TNCguide: Open help files in CHM format ■ TouchKeyboard: Open keyboard for touch operation ■ Web Browser: Start the web browser ■ Xarchiver: Extract or compress directories
Searching	Full-text search for individual functions

Taskbar



CAD Viewer opened in the third desktop with taskbar shown and active HEROS menu

The taskbar consists of the following areas:

- 1 Workspaces
- 2 HEROS menu
 - Further information:** "Description of function", Page 526
- 3 Opened applications, e.g.:
 - Control interface
 - **CAD Viewer**
 - Window of HEROS functions

You can move the opened applications into any other workspaces.
- 4 Widgets
 - Calendar
 - Status of the firewall
 - Further information:** "Firewall", Page 483
 - Network status
 - Further information:** "Ethernet interface", Page 453
 - Notifications
 - Shut down or restart the operating system

Window Manager

With the Window Manager, you manage functions of the HEROS operating system as well as windows opened in the third desktop, such as **CAD Viewer**.

The control features the Xfce window manager. Xfce is a standard application for UNIX-based operating systems, and is used to manage graphical user interfaces. The following functions are possible with the window manager:

- Display a taskbar for switching between various applications (user interfaces)
- Manage an additional desktop, on which special applications from your machine manufacturer can run
- Control the focus between NC software applications and those of the machine manufacturer
- You can change the size and position of pop-up windows. It is also possible to close, minimize and restore pop-up windows

If a window is opened in the third desktop, the control displays the **Window Manager** icon in the information bar. You can switch between the open applications by selecting the icon.

You can minimize the control's user interface by pulling down from the information bar. The TNC bar and the OEM bar remain visible.

Further information: "Areas of the control's user interface", Page 63

Notes

- If a window is opened in the third desktop, the control displays an icon in the information bar.
Further information: "Areas of the control's user interface", Page 63
- The machine manufacturer determines the scope of function and behavior of the window manager.
- The control shows a star in the upper left of the screen if an application of the window manager or the window manager itself has caused an error. In this case, switch to the window manager and correct the problem. If required, refer to your machine manual.

25.3 Serial data transfer

Application

The TNC7 basic automatically uses the LSV2 transmission protocol for serial data transfer. All parameters of the LSV2 protocol are invariably fixed except for the baud rate in the machine parameter **baudRateLsv2** (no. 106606).

Description of function

The machine parameter **RS232** (no. 106700) allows you to define another transmission type (interface). The settings described below are effective only for the respective newly defined interface.

Further information: "Machine parameters", Page 491

In the machine parameters that then appear you can define the following settings:

Machine parameters	Setting
baudRate (no. 106701)	Data transfer rate (baud rate) Input: BAUD_110, BAUD_150, BAUD_300, BAUD_600, BAUD_1200, BAUD_2400, BAUD_4800, BAUD_9600, BAUD_19200, BAUD_38400, BAUD_57600, BAUD_115200
protocol (no. 106702)	Communications protocol <ul style="list-style-type: none"> ■ STANDARD: Standard data transmission, line-by-line ■ BLOCKWISE: Packet-based data transfer ■ RAW_DATA: Transmission without protocol (purely character-by-character) Input: STANDARD, BLOCKWISE, RAW_DATA
dataBits (no. 106703)	Data bits in each transferred character Input: 7 Bit, 8 Bit
parity (no. 106704)	Parity bit used to check for transmission errors <ul style="list-style-type: none"> ■ NONE: No parity, no error detection ■ EVEN: Even parity, error if the number of bits set is odd ■ ODD: Odd parity, error if the number of bits set is even Input: NONE, EVEN, ODD
stopBits (no. 106705)	The start bit and one or two stop bits enable the receiver to synchronize each transmitted character during serial data transmission. Input: 1 Stop-Bit, 2 Stop-Bits
flowControl (no. 106706)	By handshaking, two devices control data transfer between them. A distinction is made between software handshaking and hardware handshaking. <ul style="list-style-type: none"> ■ NONE: No data-flow check ■ RTS_CTS: Hardware handshaking, transmission stop is active through RTS ■ XON_XOFF: Software handshaking, transmission stop is active through DC3 Input: NONE, RTS_CTS, XON_XOFF
fileSystem (no. 106707)	File system for the serial interface <ul style="list-style-type: none"> ■ EXT: Minimum file system for printers or non-HEIDENHAIN transmission software ■ FE1: Communication with TNCserver or an external floppy disk unit If you require no special file system, this machine parameter is not needed. Input: EXT, FE1
bccAvoidCtrlChar (no. 106708)	The BCC is a block check character. The BCC is optionally added to a transfer block to simplify error detection. <ul style="list-style-type: none"> ■ TRUE: The BCC does not correspond to any control character ■ FALSE: Function not active Input: TRUE, FALSE

Machine parameters	Setting
rtsLow (no. 106709)	This optional parameter determines the level of the RTS line in the idle state. <ul style="list-style-type: none"> ■ TRUE: Level is LOW in idle state ■ FALSE: Level is HIGH in idle state Input: TRUE, FALSE
noEotAfterEtx (no. 106710)	This optional parameter sets whether an EOT character (End of Transmission) is to be transmitted after receiving an ETX character (End of Text). <ul style="list-style-type: none"> ■ TRUE: The EOT character is not sent ■ FALSE: The EOT character is sent Input: TRUE, FALSE

Example

In order to use the TNCserver PC software for data transfer, define the following settings in the machine parameter **RS232** (no. 106700):

Parameters	Selection
Data transfer rate in baud	Has to match the setting in TNCserver
Data transmission protocol	BLOCKWISE
Data bits in each transferred character	7 bits
Type of parity checking	EVEN
Number of stop bits	1 stop bit
Type of handshake	RTS_CTS
File system for file operations	FE1

TNCserver is part of the TNCremo software for PCs.

Further information: "PC software for data transfer", Page 533

25.4 PC software for data transfer

Application


HEIDENHAIN offers the TNCremo software for connecting a Windows PC to a HEIDENHAIN control in order to transfer data.

Requirements

- PC operating system:
 - Windows 8
 - Windows 10
- PC RAM: 2 GB
- Free PC hard-disk space: 15 MB
- A network connection to the control

Description of function

The TNCremo data transfer software provides the following areas:



- 1 **Toolbar**
This area provides the most important TNCremo functions.
- 2 **File list of PC**
In this area, TNCremo displays all of the folders and files of the connected drive (e.g., hard disk of a Windows PC or a USB flash drive).
- 3 **File list of control**
In this area, TNCremo displays all of the folders and files of the connected drive of the control.
- 4 **Status display**
In the status display, TNCremo shows information about the current connection.
- 5 **Connection status**
The connection status indicates whether a connection is currently active.



For more information, refer to the integrated help system of TNCremo.

You can open the context-sensitive help function of the TNCremo software by pressing the **F1** key.

Notes

- When user administration is active, you can set up only secure network connections via SSH. The control automatically disables the LSV2 connections via the serial interfaces (COM1 and COM2) and the network connections without user authentication.
If user administration is inactive, the control also automatically blocks non-secure LSV2 or RPC connections. In the optional machine parameters **allowUnsecureLsv2** (no. 135401) and **allowUnsecureRpc** (no. 135402), the machine manufacturer can define whether the control will permit non-secure connections. These machine parameters are included in the **CfgDncAllowUnsecur** (no. 135400) data object.
- You can download the current version of the TNCremo software from the **HEIDENHAIN website**.

25.5 File transfer with SFTP (SSH File Transfer Protocol)

Application

SFTP (SSH File Transfer Protocol) provides a secure way to connect client applications to the control and to transfer files at high speed from a PC to the control. The connection is routed via an SSH tunnel.

Related topics

- User administration
Further information: "User Administration", Page 499
- Principle of the SSH connection
Further information: "Concept of transmission through an SSH tunnel", Page 522
- Firewall settings
Further information: "Firewall", Page 483

Requirements

- PC software TNCremo with version 3.3 or higher is installed
Further information: "PC software for data transfer", Page 533
- SSH service is permitted in the firewall of the control
Further information: "Firewall", Page 483

Description of function

SFTP is a secure transmission protocol supported by various operating systems for client applications.

To set up the connection, you need a key pair consisting of a public and a private key. You transfer the public key to the control and assign it to a user through the user administration. The private key is required by the client application to set up a connection to the control.

HEIDENHAIN recommends using the CreateConnections application to generate the key pair. CreateConnections is installed together with the PC software TNCremo with version 3.3 and higher. CreateConnections lets you transfer the public key directly to the control and assign it to a user.

You can also use other software to generate the key pair.

25.5.1 Setting up an SFTP connection with CreateConnections

For an SFTP connection using CreateConnections, the following are required:

- Connection with secure protocol, such as **TCP/IP Secure**
- User name and password of the desired user are known



When you transfer the public key to the control, you must enter the user's password twice.

If user administration is inactive, the user **user** is logged in. The password for the user **user** is **user**.

To set up an SFTP connection:

- ▶ Select the **Settings** application
- ▶ Select **Network/Remote Access**
- ▶ Select **DNC**
- ▶ Activate the **Setup permitted** toggle switch
- ▶ Create a key pair with CreateConnections and transfer it to the control



For more information, refer to the integrated help system of TNCremo.

You can open the context-sensitive help function of the TNCremo software by pressing the **F1** key.

- ▶ Deactivate the **Setup permitted** toggle switch
- ▶ Transfer the private key to the client application
- ▶ Connect the client application to the control



Please refer to the manual of the client application.

Notes

- When user administration is active, you can set up only secure network connections via SSH. The control automatically disables the LSV2 connections via the serial interfaces (COM1 and COM2) and the network connections without user authentication. If user administration is inactive, the control also automatically blocks non-secure LSV2 or RPC connections. In the optional machine parameters **allowUnsecureLsv2** (no. 135401) and **allowUnsecureRpc** (no. 135402), the machine manufacturer can define whether the control will permit non-secure connections. These machine parameters are included in the **CfgDncAllowUnsecur** (no. 135400) data object.
- During the connection, the rights of the user to whom the used key is assigned are active. The directories and files displayed, as well as the access options, vary depending on the permissions.
- You can also transfer a public key to the control by using a USB device or network drive. In this case, you do not need to activate the **Allow password authentication** check box.
- In the **Certificate and keys** window, you can select a file with additional public SSH keys in the **Externally administered SSH key file** area. This allows you to use SSH keys without having to transfer them to the control.

25.6 Secure Remote Access

Application

Secure Remote Access SRA allows you to set up an encrypted connection between a PC and your control via the Internet. SRA allows the control to be displayed and operated on a PC, such as for service trainings or remote maintenance.

Related topics

- VNC settings

Further information: "The VNC menu item", Page 473

Requirements

- Existing Internet connection

Further information: "Network configuration with Advanced Network Configuration", Page 541

- The following settings in the **VNC settings** window:

- **Enable RemoteAccess and IPC** check box is active

- In the **Enabling other VNC** area, the **Inquire** or **Permitted** check box is active

Further information: "The VNC menu item", Page 473

- PC with paid RemoteAccess software including the extension **Secure Remote Access**

HEIDENHAIN website



For more information, refer to the integrated help system of RemoteAccess.

You can open the context-sensitive help function of the RemoteAccess software by pressing the **F1** key.


Description of function

To navigate to this function:

Tools ► Secure Remote Access

The PC provides a ten-digit session ID for you to enter in the **HEIDENHAIN Secure Remote Access** window.

SRA enables connection via an VPN server.



In the **Extended** area, the control shows the progress of the connection setup.

The **HEIDENHAIN Secure Remote Access** window provides the following buttons:

Button	Function
Connect	The control starts the connection with the entered session ID.
Update	The control manually searches for updates for SRA. The control automatically searches for available updates when you open the HEIDENHAIN Secure Remote Access window. If an update is available, you can install it. The control restarts during the update.
Config.	The control opens the Network settings window. Only for network specialists
Show log	The control opens the log files of the SRA.

Notes

If, in the **VNC settings** window, you set the **Enabling other VNC** setting to **Inquire**, you can permit or deny any connection.

25.7 Data backup

Application

If you create or modify files on the control, then you should back up these files periodically.

Related topics

- File management

Further information: User's Manual for Programming and Testing

Description of function

With the functions **NC/PLC Backup** and **NC/PLC Restore** you can create back-up files for specific directories or even an entire drive, and restore them as needed. You should store these backup files on an external storage medium.

Further information: "Backup and restore", Page 487

You have the following options for transferring files from the control:

- TNCremo

With TNCremo you can transfer files from the control to a computer.

Further information: "PC software for data transfer", Page 533

- External drive

You can transfer files from the control directly to an external drive.

Further information: "Network drives on the control", Page 450

- External data carriers

You can back-up files to external data carriers or use external data carriers to transfer the files.

Further information: User's Manual for Programming and Testing

Notes

- You should back-up all machine-specific data, such as the PLC program or machine parameters. Consult your machine manufacturer about this.
- You must transmit files with the extensions PDF, XLS, ZIP, BMP, GIF, JPG and PNG in binary format from the PC to the control's hard disk.
- Backing up all files of the internal memory can take several hours. If required, perform the backup during a time when you don't need the machine.
- Periodically delete files that are no longer required. This ensures that the control has enough memory available for system files, such as the tool table.
- HEIDENHAIN recommends having the hard disk inspected after three to five years. After this time, and depending on the operating conditions (e.g., vibration loads), you must expect increased failure rates.

25.8 Opening files with additional software

Application

The control provides several additional software programs for opening and editing standard file types:

Related topics

- File types

Further information: User's Manual for Programming and Testing

Description of function

The control offers tools for the following file types:

File type	Tool
PDF	Document Viewer
XLSX (XLS) CSV	Gnumeric
INI A TXT	Leafpad
HTM/HTML	Web browser
<div style="border: 1px solid black; padding: 5px;"> <p>i For networks and the Internet, the machine manufacturer or network administrator must guarantee that the control is protected against viruses and malware (e.g., by a firewall).</p> </div>	
ZIP	Xarchiver
BMP GIF JPG/JPEG PNG	Ristretto or Geeqie
<div style="border: 1px solid black; padding: 5px;"> <p>i Ristretto can only open graphics files. Geeqie can also edit and print graphics.</p> </div>	
OGG	Parole
<div style="border: 1px solid black; padding: 5px;"> <p>i With Parole you can open the file types OGA, OGG, OGV and OGX. The Fuendo Codec Pack (available for payment) is needed only for other formats, such as MP4 files.</p> </div>	

If you double-tap or double-click a file in the file manager, the control automatically starts the file with the correct tool. If more than one tool is possible for a file, the control displays a selection window.

The control opens the tools in the third desktop.

25.8.1 Opening tools

To open a tool:

- ▶ Select the HEIDENHAIN icon in the taskbar
- > The control opens the HEROS menu.
- ▶ Select **Tools**
- ▶ Select the tool (e.g. **Leafpad**)
- > The control opens the tool in its own workspace.

Notes

- You can also open several tools from the **Desktop menu** workspace.
- Use the **ALT+TAB** key combination to switch between open workspaces.
- More information on how to use the various tools is provided within the respective tool under Help.
- After starting, the **web browser** checks at regular intervals whether updates are available.

If you want to update the **web browser**, then you must deactivate the SELinux security software during this time and establish a connection to the Internet. Reactivate SELinux after the update!

Further information: "SELinux security software", Page 449

25.9 Network configuration with Advanced Network Configuration

Application

Use **Advanced Network Configuration** to edit or remove profiles for the network connection.


Related topics

- Network settings

Further information: "The Editing network connection window", Page 542

Description of function

When you select the **Advanced Network Configuration** application in the HEROS menu, the control opens the **Network Connections** window.



The **Network Connections** window


Symbols in the Network Connections window

The following symbols are shown in the **Network Connections** window:

Icon	Function
+	Add network connection
—	Remove network connection
⚙️	Edit network connection The control opens the Editing network connection window. Further information: "The Editing network connection window", Page 542

25.9.1 The Editing network connection window

In the **Editing network connection** window, the control shows the connection name of the network connection in the upper area. You can change the name.



The Editing network connection window

The General tab

The **General** tab contains the following settings:

Setting	Meaning
Connect automatically	If you are using several profiles, you can define an order of priority for the connection here. The control connects the network with the highest priority first. Input: -999...999
All users may connect to this network	Here you can enable the selected network for all users.
Automatically connect to VPN when using this connection	Currently no function
Bonded connections:	Currently no function

The Ethernet tab

The **Ethernet** tab contains the following settings:

Setting	Meaning
Service:	Here you can select the Ethernet interface. If you do not select an Ethernet interface, this profile can be used for any Ethernet interface. Selection by means of a selection window
Cloned MAC address:	Currently no function
_MTU:	Here you can define the maximum package size in bytes. Input: Automatic, 1...10000
_Private key password:	Currently no function
Wake-on-LAN password	Currently no function
Link negotiation	Here you have to configure the settings for the Ethernet connection: <ul style="list-style-type: none"> ■ Ignore Retain the configurations already existing on the device. ■ Automatic The speed and duplex settings are configured automatically for the connection. ■ Manual Configure the speed and duplex settings for the connection manually. Selection by means of a selection window
Speed	Here you have to select the speed settings: <ul style="list-style-type: none"> ■ 10 Mb/s ■ 100 Mb/s ■ 1 Gb/s ■ 10 Gb/s Only if Link negotiation has been selected Manual Selection by means of a selection window
Full duplex	Here you have to select the duplex setting: <ul style="list-style-type: none"> ■ Half ■ Full Only if Link negotiation has been selected Manual Selection by means of a selection window

The 802.1X Security tab

Currently no function

The DCB tab

Currently no function

The Proxy tab

Currently no function

The IPv4 Settings tab

The **IPv4 Settings** tab contains the following settings:

Setting	Meaning
_Method:	<p>Here you have to select a network connection method:</p> <ul style="list-style-type: none"> ■ Automatic (DHCP) If the network uses a DHCP server for IP address assignment ■ Automatic (DHCP) addresses only If the network uses a DHCP server for IP address assignment, but you are assigning the DNS server manually ■ Manual Assign the IP address manually ■ Link-Local Only Currently no function ■ Shared to other computers Currently no function ■ Disabled Deactivate IPv4 for this connection
Automatic, addresses only	<p>Here you can add static IP addresses that will be set up in addition to the IP addresses that are assigned automatically.</p> <p>Only with _Method: Manual</p>
Additional DNS servers:	<p>Here you can add the IP addresses of DNS servers that are used to resolve computer names.</p> <p>Separate multiple IP addresses by commas.</p> <p>Only with _Method: Manual and Automatic (DHCP) addresses only</p>
Additional search domains:	<p>Here you can add domains used by computer names.</p> <p>Separate multiple domains by commas.</p> <p>Only with _Method: Manual</p>
DHCP client ID:	Currently no function
Require IPv4 addressing for this connection to complete	Currently no function

The IPv6 Settings tab

Currently no function

26

Overviews

26.1 Pin layout and cables for data interfaces

26.1.1 V.24/RS-232-C interface for HEIDENHAIN devices



The interface complies with the requirements of EN 50178 for Secure separation from the power grid.

Control		25-pin: VB 274545-xx			9-pin: VB 366964-xx		
Male	Assignment	Male	Color	Female	Female	Color	Female
1	Do not assign	1	White/Brown	1	1	Red	1
2	RXD	3	Yellow	2	2	Yellow	3
3	TXD	2	Green	3	3	White	2
4	DTR	20	Brown	8	4	Brown	6
5	Signal GND	7	Red	7	5	Black	5
6	DSR	6		6	6	Violet	4
7	RTS	4	Gray	5	7	Gray	8
8	CTR	5	Pink	4	8	White/Green	7
9	Do not assign	8	Violet	20	9	Green	9
Housing	External shield	Housing	External shield	Housing	Housing	External shield	Housing

26.1.2 Ethernet interface RJ45 socket

Maximum cable length:

- 100 m unshielded
- 400 m shielded

Pin	Signal
1	TX+
2	TX-
3	RX+
4	Vacant
5	Vacant
6	RX-
7	Vacant
8	Vacant

26.2 Machine parameters


The following list shows the machine parameters that you can edit with the code number 123.

Related topics


















- Changing machine parameters with the **MPs for setters** application





















Further information: "Machine parameters", Page 491





26.2.1 List of user parameters






















 Refer to your machine manual.

















- The machine manufacturer can make additional machine-specific parameters available as user parameters, so that you can configure the functions that are available.
- The machine manufacturer can adapt the structure and contents of the user parameters. The display on your machine may be different.




















Depiction in the configuration editor	MP number
 DisplaySettings	
 CfgDisplayData Settings for screen displays	100800
 axisDisplay Display sequence and display rules for axes	100810
 x	
 axisKey Key name of the axis	100810. [Index].01501
 name Axis designation	100810. [Index].01502
 rule Display rule for the axis	100810. [Index].01503
 axisDisplayRef Sequence and rules for display axes before crossing the reference marks	100811
 x	
 axisKey Key name of the axis	100811. [Index].01501
 name Axis designation	100811. [Index].01502
 rule Display rule for the axis	100811. [Index].01503
 positionWinDisplay Type of position display in the position window	100803
 statusWinDisplay Type of position display in the Status workspace	100804
 axisFeedDisplay Display of the feed rate in the applications of the Manual operating mode	100806
 spindleDisplay Display of spindle position in the position display	100807
 hidePresetTable Disable the PRESET MANAGEMENT soft key	100808



















Depiction in the configuration editor		MP number
	displayFont Font size for program display in the operating modes Program Run Full Sequence, Program Run Single Block, and Positioning with Manual Data Input.	100812
	iconPrioList Sequence of icons in the display	100813
	compatibilityBits Settings for display behavior	100815
	axesGridDisplay Axes as list or group in the position display.	100806
	dashbrdWinDisplay Type of position display in the status overview of the TNC bar	100817
	CfgPosDisplayPace Display step for the individual axes	101000
	xx	
	displayPace Display step for position display in [mm] or [°]	101001
	displayPaceInch Display step for position display in [inch]	101002
	CfgUnitOfMeasure Definition of unit of measure in effect for display	101100
	unitOfMeasure Unit of measure for display and user interface	101101
	CfgProgramMode Format of the NC programs and cycle display	101200
	programInputMode MDI: Program entry in HEIDENHAIN Klartext format or ISO format	101201
	CfgDisplayLanguage Definition of the NC and PLC conversational language	101300
	ncLanguage NC conversational language	101301
	applyCfgLanguage Load the language of the NC control	101305
	plcDialogLanguage PLC conversational language	101302
	plcErrorLanguage PLC error message language	101303
	helpLanguage Language for online help	101304
	CfgStartupData Behavior during control startup	101500





















Depiction in the configuration editor		MP number
	powerInterruptMsg Acknowledge the Power interrupted message	101501
	opMode Operating mode that is switched to when the control has fully booted	101503
	subOpMode Submode to be activated for the operating mode entered in 'opMode'	101504
	CfgClockView Display mode for time of day	120600
	displayMode Display mode for time of day on the screen	120601
	timeFormat Time format of digital clock	120602
	CfgInfoLine Link row on/off	120700
	infoLineEnabled Enable/disable info line	120701
	CfgGraphics Settings for 3D simulation graphics	124200
	modelType Model type of the 3D simulation graphics	124201
	modelQuality Model quality of the 3D simulation graphics	124202
	clearPathAtBlk Reset tool paths for new BLK FORM	124203
	extendedDiagnosis Write graphics journal files after restart	124204
	CfgPositionDisplay Settings for the digital readout	124500
	progToolCallDL Position display with TOOL CALL DL	124501
	CfgTableEditor Table editor configuration	125300
	deleteLoadedTool Behavior when deleting tools from the pocket table	125301
	indexToolDelete Behavior when deleting a tool's index entries	125302
	CfgDisplayCoordSys Setting the coordinate systems for the display	127500
	transDatumCoordSys Coordinate system for the datum shift	127501






















Depiction in the configuration editor		MP number
	CfgRemoteDesktop Settings for Remote Desktop connections	100800
	connections List of Remote Desktop connections to be displayed	133501
	autoConnect Start connection automatically	133505
	title Name of the OEM operating mode	133502
	dialogRes Name of a text	00501
	text Language-sensitive text	00502
	icon Path/name for optional icon graphic file	133503
	locations List with positions where this Remote Desktop connection is displayed	133504
	x	
	opMode Operating mode	133504. [Index].133401
	subOpMode Optional submode for the operating mode specified in 'opMode'	133504. [Index].133402
	PalletSettings	
	CfgPalletBehaviour Behavior of the pallet control cycle	202100
	failedCheckReact Specify reaction to program check and tool check	202106
	failedCheckImpact Specify effect of program check or tool check	202107
	ProbeSettings	
	CfgTT Configuration of the tool calibration	122700
	TT140_x	
	spindleOrientMode M function for spindle orientation	122704
	probingRoutine Probing routine	122705
	probingDirRadial Probing direction for tool-radius measurement	122706









Depiction in the configuration editor		MP number
	offsetToolAxis Distance from lower edge of tool to upper edge of stylus	122707
	rapidFeed Rapid traverse in probing cycle for TT tool touch probe	122708
	probingFeed Probing feed rate for tool measurement with non-rotating tool	122709
	probingFeedCalc Calculation of the probing feed rate	122710
	spindleSpeedCalc Speed determination method	122711
	maxPeriphSpeedMeas Maximum permissible surface speed of the cutting edge for radius measurement	122712
	maxSpeed Maximum permissible speed during tool measurement	122714
	measureTolerance1 Maximum permissible measuring error for tool measurement with rotating tool (first measuring error)	122715
	measureTolerance2 Maximum permissible measuring error for tool measurement with rotating tool (second measuring error)	122716
	stopOnCheck NC Stop during "tool check"	122717
	stopOnMeasurement NC stop during tool measurement	122718
	adaptToolTable Change the tool table during tool check and tool measurement	122719
	CfgTTRoundStylus Configuration of a round stylus	114200
	TT140_x	
	centerPos Coordinates of the probe-contact center point	114201
	safetyDistToolAx Safety clearance around the probe contact of the TT tool touch probe for pre-positioning in the tool-axis direction	114203

Depiction in the configuration editor		MP number
	safetyDistStylus Safety zone around the stylus for pre-positioning	114204
	CfgTTRectStylus Configuration of a rectangular stylus	114300
	TT140_x	
	centerPos Coordinates of the stylus center	114313
	safetyDistToolAx Set-up clearance above the stylus for pre-positioning	114317
	safetyDistStylus Safety zone around the stylus for pre-positioning	114318
	ChannelSettings	
	CH_xx	
	CfgActivateKinem Active kinematics	204000
	kinemToActivate Kinematics to be activated / active kinematics	204001
	kinemAtStartup The kinematics to be activated during control start-up	204002
	CfgNcPgmBehaviour Specify the behavior of the NC program.	200800
	operatingTimeReset Reset the machining time when program starts.	200801
	plcSignalCycle PLC signal for the number of the pending machining cycle	200803
	plcSignalCycState PLC signal for type of current cycle execution	200805
	CfgGeoTolerance Geometry tolerances	200900
	circleDeviation Permissible deviation of the radius	200901
	threadTolerance Permissible deviation in successive threads	200902
	moveBack Reserve for retraction movements	200903

Depiction in the configuration editor		MP number
	CfgGeoCycle Configuration of the fixed cycles	201000
	pocketOverlap Overlap factor for pocket milling	201001
	posAfterContPocket Traverse after machining the contour pocket	201007
	displaySpindleErr Display the Spindle is not rotating error message if M3/M4 is not active	201002
	displayDepthErr Display the Check the depth sign error message	201003
	apprDepCylWall Behavior when moving to wall of slot in the cylinder surface	201004
	mStrobeOrient M function for spindle orientation in machining cycles	201005
	suppressPlungeErr Do not show 'Plunging type is not possible' error message	201006
	restoreCoolant Behavior of M7 and M8 with Cycles 202 and 204	201008
	facMinFeedTurnSMAX	201009
	suppressResMatlWar Do not show "Residual material" warning	201010
	CfgThreadSpindle Special spindle parameters for threads	113600
	sourceOverride Effective override potentiometer for feed rate during thread cutting	113603
	thrdWaitingTime Waiting time at reversal point in thread base	113601
	thrdPreSwitchTime Advanced switching time of spindle	113602
	limitSpindleSpeed Limit of spindle speed with Cycles 17, 207 and 18	113604
	CfgEditorSettings Settings for the NC editor	105400
	createBackup Generate a backup file *.bak	105401

Depiction in the configuration editor		MP number
	deleteBack Behavior of the cursor after deletion of lines	105402
	lineBreak Line break on NC blocks with more than one line	105404
	stdTNChelp Activate help graphics when entering cycle data	105405
	warningAtDEL Confirmation request when deleting an NC block.	105407
	maxLineGeoSearch Line number up to which a test of the NC program is to be run.	105408
	blockIncrement ISO programming: Block number increment	105409
	useProgAxes Specify programmable axes	105410
	enableStraightCut Allow or lock paraxial positioning blocks	105411
	noParaxMode Hide FUNCTION PARAXCOMP/PARAXMODE	105413
	quotePaths Put all path information in quotation marks	105414
	CfgPgmMgt Settings for the file management	122100
	dependentFiles Display of dependent files	122101
	CfgProgramCheck Settings for tool-usage files	129800
	autoCheckTimeOut Timeout for creation of tool-usage files	129803
	autoCheckPrg Create tool-usage file for NC program	129801
	autoCheckPal Create pallet-usage files	129802
	CfgUserPath Paths for the end user	102200
	ncDir List of drives and/or directories	102201
	fn16DefaultPath Default output path for the FN 16: F-PRINT function in the Program Run operating modes	102202
	fn16DefaultPathSim Default output path for the FN 16: F-PRINT function in the Programming and Test Run operating modes	102203

Depiction in the configuration editor		MP number
	serialInterfaceRS232	
	CfgSerialPorts Data record belonging to the serial port	106600
	activeRs232 Enable the RS-232 interface in the program manager	106601
	baudRateLsv2 Data transfer rate for LSV2 communication in baud	106606
	CfgSerialInterface Definition of data records for the serial ports	106700
	RSxxx	
	baudRate Data transfer rate for communication in baud	106701
	protocol Communications protocol	106702
	dataBits Data bits in each transferred character	106703
	parity Type of parity checking	106704
	stopBits Number of stop bits	106705
	flowControl Type of data-flow checking	106706
	fileSystem File system for file operation via serial interface	106707
	bccAvoidCtrlChar Avoid control characters in the block check character (BCC)	106708
	rtsLow Idle state of the RTS line	106709
	noEotAfterEtx Behavior after reception of an ETX control character	106710
	Monitoring	
	CfgCompMonUser User settings for component monitoring	129400
	enforceReaction The configured error reactions are enforced	129401
	showWarning Display warnings of monitoring tasks	129402
	CfgMachineInfo General information of the machine operator	131700

Depiction in the configuration editor	MP number
 machineNickname Custom name (nickname) of the machine	131701
 inventoryNumber Inventory number or ID	131702
 image Photo or image of the machine	131703
 location Machine location	131704
 department Department or division	131705
 responsibility Responsible for the machine	131706
 contactEmail Contact email address	131707
 contactPhoneNumber Contact phone number	131708

26.3 User administration roles and rights

26.3.1 List of roles



The following contents can change in the following software versions of the control:

- HEROS role names
- Unix groups
- Basic ID number

Further information: "Roles", Page 502

Operating system roles:

Role	Privileges		
	HEROS role name	UNIX group	Basic ID number
HEROS.RestrictedUser	Role for a user with minimum rights on the operating system.		
	■ HEROS.MountShares	■ mnt	■ 335
	■ HEROS.Printer	■ lp	■ 9
HEROS.NormalUser	Role for a normal user with limited rights on the operating system.		
	This role grants the rights of the RestrictedUser role, as well as the following rights:		
	■ HEROS.SetShares	■ mntcfg	■ 334
	■ HEROS.ControlFunctions	■ ctrlfct	■ 340

Role	Privileges		
	HEROS role name	UNIX group	Basic ID number
HEROS.LegacyUser	With the LegacyUser role, the behavior regarding the operating system of the control is identical to that of older software versions without user administration. User administration remains active.		
	This role grants the rights of the NormalUser role, as well as the following rights:		
	<ul style="list-style-type: none"> ■ HEROS.BackupUsers ■ HEROS.PrinterAdmin ■ HEROS.ReadLogs ■ HEROS.SWUpdate ■ HEROS.SetNetwork ■ HEROS.SetTimezone ■ HEROS.VMSharedFolders 	<ul style="list-style-type: none"> ■ userbck ■ lpadmin ■ logread ■ swupdate ■ netadmin ■ tz ■ vboxsf 	<ul style="list-style-type: none"> ■ 337 ■ 16 ■ 342 ■ 341 ■ 336 ■ 333 ■ 1000
HEROS.LegacyUserNoCtrlfct	This role determines the rights for remote log-in when user administration is disabled (e.g., via SSH). The control assigns this role automatically.		
	This role grants the rights of the LegacyUser role, with the exception of the following right:		
	<ul style="list-style-type: none"> ■ HEROS.ControlFunctions 	<ul style="list-style-type: none"> ■ ctrlfct 	<ul style="list-style-type: none"> ■ 340
HEROS.Admin	The configuration of the network and the configuration of the user administration are some of the rights granted by this role.		
	This role grants the rights of the LegacyUser role, as well as the following rights:		
	<ul style="list-style-type: none"> ■ HEROS.BackupMachine ■ HEROS.UserAdmin 	<ul style="list-style-type: none"> ■ backup ■ useradmin 	<ul style="list-style-type: none"> ■ 338 ■ 339
NC operator roles:			
Role	Privileges		
	HEROS role name	UNIX group	Basic ID number
NC.Operator	This role allows you to run NC programs.		
	<ul style="list-style-type: none"> ■ NC.OPModeProgramRun 	<ul style="list-style-type: none"> ■ NCOpPgmRun 	<ul style="list-style-type: none"> ■ 302
NC.Programmer	This role grants the rights of NC programming.		
	This role grants the rights of the Operator role, as well as the following rights:		
	<ul style="list-style-type: none"> ■ NC.EditNCProgram ■ NC.EditPalletTable ■ NC.EditPresetTable ■ NC.EditToolTable ■ NC.OPModeMDi ■ NC.OPModeManual 	<ul style="list-style-type: none"> ■ NCEdNCProg ■ NCEdPal ■ NCEdPreset ■ NCEdTool ■ NCOpMDI ■ NCOpManual 	<ul style="list-style-type: none"> ■ 305 ■ 309 ■ 308 ■ 306 ■ 301 ■ 300

Role	Privileges		
	HEROS role name	UNIX group	Basic ID number
NC.Setter	This role allows you to edit the pocket table.		
	This role grants the rights of the Programmer role, as well as the following rights:		
	■ NC.ApproveFsAxis	■ NCAp- proveFsAxis	■ 319
	■ NC.EditPocketTable	■ NCEdPocket	■ 307
	■ NC.SetupDrive	■ NCSetupDrv	■ 315
	■ NC.SetupProgramRun	■ NCSe- tupPgRun	■ 303
NC.AutoProductionSet- ter	This role allows you to execute all NC functions, including programming a scheduled NC program start.		
	This role grants the rights of the Setter role, as well as the following rights:		
	■ NC.ScheduleProgramRun	■ NCSched- ulePgRun	■ 304
NC.LegacyUser	With the LegacyUser role, the control's behavior regarding NC programming is identical to that of older software versions without user administration. User administration remains active. The LegacyUser has the same rights as the AutoProductionSetter.		
NC.AdvancedEdit	This role allows you to use special functions of the NC and table editors.		
	■ Special functions of Q parameter programming and editing the table header		
	Replacement for code number 555343		
	■ NC.EditNCProgramAdv	■ NCEdit- NCPgmAdv	■ 327
	■ NC.EditTableAdv	■ NCEdit- TableAdv	■ 328
NC.RemoteOperator	This role allows you to start NC programs from an external application.		
	■ NC.RemoteProgramRun	■ NCR- emotePgmRun	■ 329

Machine manufacturer (PLC) roles:

Role	Privileges		
	HEROS role name	UNIX group	Basic ID number
PLC.ConfigureUser	This roles grants the rights on code number 123 .		
	■ NC.ConfigUserAdv	■ NCConfi- gUserAdv	■ 316
	■ NC.SetupDrive	■ NCSetupDrv	■ 315
PLC.ServiceRead	This role allows read-only access during servicing.		
	This role can be used to display various types of diagnostic information		
	■ NC.Data.AccessServiceRead	■ NCDASer- viceRead	■ 324



Refer to your machine manual.

The machine manufacturer can adapt the PLC roles.

When the **Machine manufacturer (PLC) roles:** are adapted by the machine manufacturer, the following contents may change:

- The names of the roles
- The number of roles
- The functionality of the roles

26.3.2 List of rights

The table below lists all of the individual rights.

Further information: "Rights", Page 502

Rights:

HEROS role name	Description
HEROS.Printer	Data output to network printers
HEROS.PrinterAdmin	Configuration of network printers
HEROS.ReadLogs	Currently no function
NC.OPModeManual	Operating the machine in the Manual Operation and Electronic handwheel operating modes.
NC.OPModeMDi	Working in the Positioning w/ Manual Data Input operating mode.
NC.OpModeProgramRun	Execution of NC programs in the Program Run Full Sequence or Program run, single block operating mode.
NC.SetupProgramRun	Probing in the Manual Operation and Electronic handwheel operating modes. Using the AFC and ACC functions.
NC.ScheduleProgramRun	Programming a scheduled NC program start
NC.EditNCProgram	Editing NC programs
NC.EditToolTable	Editing the tool table
NC.EditPocketTable	Editing the pocket table
NC.EditPresetTable	Editing the preset table
NC.EditPalletTable	Editing pallet tables
NC.SetupDrive	Adjustment of drives by the end user
NC.ApproveFsAxis	Confirming test position of safe axes
NC.EditNCProgramAdv	Additional NC functions
NC.EditTableAdv	Additional table programming functions (e.g., editing of the table head)
HEROS.SetTimezone	Adjustment of date and time, time zone and time synchronization via NTP and the HEROS menu .
HEROS.SetShares	Configuration of public network drives mounted on the control
HEROS.MountShares	Connecting and disconnecting network shares with the control
HEROS.SetNetwork	Configuration of network and relevant settings for data security
HEROS.BackupUsers	Data backup on the control—for all users configured on the control
HEROS.BackupMachine	Backup and restoring data of the entire machine configuration
HEROS.UserAdmin	Configuration of user administration on the control This includes creating, deleting, and configuring local users

HEROS role name	Description
HEROS.ControlFunctions	Control function of the operating system <ul style="list-style-type: none"> ■ Auxiliary functions, such as starting and stopping NC software ■ Telemaintenance ■ Advanced diagnostic functions, such as log data
HEROS.SWUpdate	Installation of software updates for the control
HEROS.VMShared-Folders	Access to shared folders of a virtual machine Only relevant when running a programming station within a virtual machine
NC.RemoteProgram-Run	NC program start from an external application (e.g., via the DNC interface)
NC.ConfigUserAdv	Configuration access to the contents that have been enabled through code number 123
NC.DataAccessServiceRead	Read-only access to the PLC: drive during servicing
NC.OpcUaOEMConfiguredDataRead	Read-access through OPC UA NC Server to data defined by the machine manufacturer

26.4 Special functions defining the machine behavior

With code number 555343, you can enable NC functions that are intended for HEIDENHAIN, the machine manufacturer, and third-party providers only.

The following NC functions influence the machine behavior:

- Kinematics functions:
 - **WRITE KINEMATICS**
 - **READ KINEMATICS**
- PLC functions:
 - **FUNCTION SCOPE**
 - **START**
 - **STORE**
 - **STOP**
 - **READ FROM PLC**
 - **WRITE TO PLC**
 - **WRITE CFG**
 - **PREPARE**
 - **COMMIT TO DISK**
 - **COMMIT TO MEMORY**
 - **DISCARD PREPARATION**
- Variable programming:
 - **FN 19: PLC**
 - **FN 20: WAIT FOR**
 - **FN 29: PLC**
 - **FN 37: EXPORT**
- **CYCL QUERY**

NOTICE

Caution: Significant property damage!

The use of special functions for machine behavior might result in undesired behavior and severe errors (e.g., the control might not be operable any longer). With these NC functions, HEIDENHAIN, the machine manufacturer, and third-party providers have the possibility of modifying the machine behavior under program control. It is not recommended that machine operators or NC programmers use this function. There is a danger of collision during the execution of these NC functions and during the subsequent machining operations!

- ▶ Only use special functions for machine behavior after checking with HEIDENHAIN, the machine manufacturer, or the third-party provider
- ▶ Comply with the documentation from HEIDENHAIN, the machine manufacturer, and third-party providers

Index

3

- 3D basic rotation..... 196
- 3D mesh..... 264
- 3D-ROT menu..... 201
- 3D tool model..... 171

A

- About the product..... 43
- About the User's Manual..... 33
- ACC..... 245
- Accessories..... 61
- Active Chatter Control (ACC)..... 245
- Active Directory..... 512
 - Export configuration..... 517
 - Function user..... 516
- Adaptive feed control (AFC)..... 236
- Additional documentation..... 35
- Additional software..... 539
- Additional status display..... 105
- AFC..... 236
 - Basic settings..... 394
 - Programming..... 239
 - Teach-in cut..... 242
- AFC settings..... 243
- Angle encoder..... 141
- Application
 - Configuration editor..... 493
 - Functional safety..... 430
 - Help..... 39
 - Manual operation..... 134
 - MDI..... 279
 - Move to reference position... 129
 - MP for setters..... 491
 - MP for Users..... 491
 - Pocket table..... 377
 - Preset table..... 385
 - Retract..... 346
 - Settings..... 435
 - Setup..... 289
 - Start/Login..... 64
 - Tool management..... 163
- Axes
 - Moving..... 135
 - Referencing..... 129
- Axis designation..... 140
- Axis display..... 98
- Axis key..... 136

B

- Backup..... 487
- Basic coordinate system..... 184
- Basic rotation..... **196**
- Basic transformation..... 389
- B-CS..... 184
- Block scan..... 335
 - Multi-level..... 339

- Pallet table..... 341
- Point table..... 340
- Returning to the contour..... 343
- Single-level..... 338

C

- CAD file..... 247
- CAD Import..... 258
 - Contour, saving..... 259
 - Position, saving..... 260
- CAD Viewer..... 247
- Calibrating..... 304
 - Length..... 307
 - Radius..... 308
- Cartesian coordinate system.... 181
- Certificate..... 460
- CFG file..... 226
- Chatter Control..... 245
- Code number..... 439
- Collision monitoring..... 206
 - Activating..... 211
 - Fixtures..... 213
- Compensation table
 - Program run..... 344
- Configuration editor..... 493
 - List..... 493
 - Table..... 493
- Connecting cable..... 548
- Connection
 - Network..... 453
 - Network drive..... 450
- Connection assistant..... 466
- Contact..... 42
- Context-sensitive help..... 41
- Control
 - Powering off..... 130
 - Powering on..... 126
- Control's user interface..... 63
- Control-in-operation symbol..... 329
- Control user interface
 - User-defined..... 496
- Conversational language..... 448
- Coordinate system..... 180
 - Basics..... 181
 - Coordinate origin..... 181
- CR2..... 150
- CreateConnections..... 536
- Creating a new table..... 352
- Current user..... 508

D

- Data backup..... 487, 539
- Database ID..... 151
- Data interface..... 531
 - OPC UA..... 462
 - pin layout..... 548
- Data transfer
 - Software..... 533

- Date and time..... 447
- Datum table
 - Program run..... 344
- DCM..... 206
 - Activating..... 211
 - Fixtures..... 213
- Directory
 - public..... 504
- Display unit..... 57
- DNC..... 468
 - Secure connection..... 521
- Drive
 - HOME..... 504
- Dynamic Collision Monitoring (DCM)..... 206

E

- Embedded Workspace..... 424
- Encoder..... 141
- Error message..... **274**
- Error window..... 274
- Ethernet interface..... **453**, 548
 - Configuration..... 541
 - Settings..... 455
- Extended Workspace..... 426
- External access..... 468

F

- Feed control..... 236
- Feed rate limit..... 328
- File
 - Backing up..... 539
 - Tools..... 539
- Firewall..... 483
- First steps..... 83
 - Program run..... 92
 - Setup..... 89
 - Tool..... 85
- Fixture monitoring
 - CFG file..... 214
 - Combined..... 231
 - Integrating..... 216
 - M3D file..... 215
 - STL file..... 214
- Fixtures..... 213
 - CFG file..... 226
 - Combining..... 231
- Form
 - For tables..... 360
- Functional safety (FS)..... 427
- Functional safety (FS) operating modes..... 429

G

- General status display..... 97
- Gestures..... 70

- H**
- Handwheel..... 401
 - Operating elements..... 403
 - Wireless handwheel..... 410
 - Handwheel mode..... 134
 - Hardware..... 56
 - HEROS..... 525
 - HEROS function
 - Overview..... 526
 - Settings Application..... 435
 - HEROS menu..... 526
 - HEROS tool..... 539
 - HOME..... 504
 - Host computer operation..... 468
- I**
- Icons, miscellaneous..... 78
 - I-CS..... 191
 - Incremental jog positioning..... 137
 - Indexed tool..... 152
 - Input coordinate system..... 191
 - Integrated product aid
 - TNCguide..... 38
 - Interface..... 63
 - Ethernet..... 453
 - OPC UA..... 462
 - User-defined..... 496
- J**
- Jog increment..... 137
- K**
- Keyboard..... 57
 - Formula..... 272
 - NC functions..... 271
 - Text..... 272
 - Virtual..... 270
 - Keys..... 70
 - Kinematics..... 439
 - KinematicsDesign..... 226
- L**
- Language..... 448
 - Changing..... 449
 - License settings..... 467
 - Licensing terms..... 56
 - Linear encoder..... 141
 - L-shaped stylus..... 305, 305
- M**
- M92 datum M92-ZP..... 142
 - Machine
 - Powering off..... 130
 - Powering on..... 126
 - Machine axes, moving..... 135
 - Machine coordinate system..... 182
 - Machine datum..... 142
 - Machine information..... 442
 - Machine parameters..... 491
 - Editing..... 491
 - List..... 549
 - Overview..... 548
 - Machine parameters for users... 491
 - Machine settings..... 439
 - Machine times..... 446
 - Machining time..... 119
 - Main menu..... 80
 - Manual axis..... 344
 - Manual operation..... 134
 - Manual tilting, activating..... 201
 - Maximum feed rate..... 328
 - M-CS..... 182
 - MDI..... 279
 - Message..... 274
 - Message menu..... 274
 - Mid-program startup..... 335
 - MOD menu..... 435
 - Overview..... 436
 - Move to reference position..... 129
 - Moving
 - Axis key..... 136
 - Incremental jog..... 137
- N**
- NC fundamentals..... 140
 - Network..... 453
 - Configuration..... 541
 - Settings..... 455
 - Network configuration..... 541
 - DCB..... 544
 - Ethernet..... 544
 - General..... 543
 - IPv4 Settings..... 545
 - IPv6 Settings..... 545
 - Proxy..... 545
 - Security..... 544
 - Network drive..... 450
 - Connecting..... 451
 - Network setting
 - Ping..... 458
 - Routing..... 458
 - SMB share..... 458
 - Network settings
 - DHCP Server..... 457
 - Interface..... 457
 - Status..... 456
 - Notes, types of..... 36
- O**
- Offset..... 389
 - OPC UA NC Server..... 462
 - Connection assistant..... 466
 - License settings..... 467
 - Restart..... 466
 - Operating elements..... 70
 - Operating mode
 - Machine..... 64
 - Manual..... 64
 - Overview..... 64
 - Program Run..... 324
 - RDP..... 424
 - Start..... 64
 - Tables..... 350
 - Operating system..... 525
 - Override Controller..... 415
 - Conditional stop..... 418
 - Displaying breakpoints..... 421
- P**
- Pallet table
 - Block scan..... 341
 - Parameter list..... 123
 - Pin layout
 - data interface..... 548
 - PKI admin..... 460
 - Place of operation..... 45
 - Pocket table..... 377
 - Portscan..... 487
 - Position display..... 98
 - Mode..... 120
 - Status overview..... 104
 - Position encoder..... 141
 - Positioning with Manual Data
 - Input..... 279
 - Powering off..... 130
 - Powering on..... 126
 - Powering on and off..... 125
 - Preset..... 194
 - Activating..... 198
 - Inches..... 393
 - Scratching..... 195
 - Setting..... 197
 - Preset management..... 194
 - Preset table..... 385
 - Columns..... 387
 - Inches..... 393
 - Write-protection..... 390
 - Printer..... 470, 470
 - Program call
 - Structure..... 334
 - Program Run..... 324
 - Block scan..... 335
 - Canceling..... 329
 - Compensation table..... 344
 - Contextual reference..... 330
 - Datum table..... 344
 - Manual traverse..... 334
 - Navigation path..... 332
 - Retract..... 346
 - Returning to the contour..... 343
 - Program run time..... 119
 - Proper and intended operation.... 45

Public directory..... 504

Q

Q parameter list..... 123
 Q parameters
 Show..... 123

R

RDP..... 424
 Reference point..... 142
 Reference system..... 180
 Basic coordinate system..... 184
 Input coordinate system..... 191
 Machine coordinate system.. 182
 Tool coordinate system..... 192
 Working plane coordinate
 system..... 187
 Workpiece coordinate system....
 186
 Remaining run time..... 119
 Remote Desktop Manager..... 477
 External computer, shutting
 down..... 477
 VNC..... 478
 Windows Terminal Service.... 478
 Remote maintenance..... 537
 Remote Service..... 537
 Restarting..... 130
 Restore..... 487
 Retract..... 346
 Returning to the contour..... 343
 Run time
 Machine information..... 446
 Program run..... 119

S

Safety precaution..... 46
 Content..... 36
 Scratching..... 195, 316
 Secure connection..... 521
 Secure Remote Access..... 537
 Security software SELinux..... 449
 Selection function
 Structure..... 334
 SELinux..... 449
 Service file..... 274
 Creating..... 276
 Settings
 Network..... 455
 VNC..... 473
 Settings application
 Overview..... 436
 Setting up a vice..... 223
 Setting up fixtures..... 216
 Sequence..... 222
 Vice..... 223
 Setting up the workpiece..... 309
 SFTP..... 535

SIK menu..... 443
 Simulation status..... 118
 Software number..... 49
 Software option..... 50, 443
 Split screen layout of User's
 Manual..... 35
 SRA..... 537
 SSH connection..... 521
 SSH File Transfer Protocol..... 535
 Start/Login..... 84
 Status display..... 95
 Additional status display..... 105
 Axis..... 98
 Overview..... 96
 Position..... 98
 Simulation..... 118
 technology..... 99
 TNC bar..... 103
 Status overview..... 103
 Control-in-operation symbol.. 104
 Remaining run time..... 119
 Step index..... 152
 STL file
 Optimizing..... 264
 System time..... 447

T

Table
 Creating..... 352
 in Configuration editor..... 493
 Preset table..... 385
 Tool tables..... 362
 Workspace..... 354
 Target group..... 34
 Taskbar..... 530
 TCP..... 148
 T-CS..... 192
 The Settings..... 435
 Tilting
 Manual..... 199
 Time..... 447
 Time zone..... 447
 TIP..... 148
 TLP..... 149
 TNCdiag..... 490
 TNCguide..... 39
 TNCremo..... 533
 Tool..... 145
 Database ID..... 151
 Definition..... 163
 Exporting and importing..... 164
 Measuring..... 316
 Overview..... 146
 Preset..... 147
 Table..... 362
 Tool data, required..... 158
 Touch probe..... 373
 Tool carrier management..... 167

Tool carrier reference point..... 147
 Tool center point TCP..... 148
 Tool change position..... 142
 Tool coordinate system..... 192
 Tool data..... 150
 Exporting..... 166
 Importing..... 165
 Required..... 158
 Tool ID number..... 150
 Tooling list..... 384
 Tool location point TLP..... 149
 Tool management..... 163
 Tool model..... 171
 Tool name..... 150
 Tool radius 2 center CR2..... 150
 Tool rotation point TRP..... 149
 Tool table..... 363
 Columns..... 363
 Inches..... 377
 Input options..... 363
 Tool tip TIP..... 148
 Tool type
 Tool data, required..... 158
 Tool types..... 155
 Tool usage file..... 380
 Tool usage test..... 173
 Touch probe
 Calibrating..... 304
 Length, calibrating..... 307
 Radius, calibrating..... 308
 Setting up fixtures..... 216
 Setting up the workpiece..... 309
 Setup..... 286
 Touch probe cycle
 Manual..... 289
 Touch probe data..... 374
 Touch Probe Function..... 289
 Overview..... 292
 Setting up the workpiece..... 309
 Touch probe monitoring..... 319
 Touch probes
 Radio transmission..... 286
 Touch probe table..... 373
 Columns..... 374
 Touchscreen..... 57
 Traverse
 Handwheel..... 401
 Traverse limit..... 439
 TRP..... 149
 T usage order..... 382

U

Unit of measure..... 439
 UserAdmin..... 508
 User administration..... 500
 Activating..... 504
 Autologin..... 518
 Current user..... 508

Database.....	509
Domain.....	509
Export Windows configuration.....	517
Logging on.....	518
Overview of roles and rights..	558
Rights.....	502
Roles.....	502
Settings.....	508
Users.....	500
Windows domain.....	512
User aids.....	269
User interface of the control.....	63
User parameters	
List.....	549

V

Virtual keyboard.....	270
VNC.....	473

W

W-CS.....	186
Window Manager.....	531
Windows domain.....	512
Export configuration.....	517
Function user.....	516
Wireless handwheel.....	410
Configuring.....	411
Working plane.....	140
Working plane, tilting	
Fundamentals.....	199
Head rotary axis.....	200
Manually.....	199
Table rotary axis.....	200
Working plane coordinate	
system.....	187
Workpiece coordinate system..	186
Workpiece datum.....	142
Workpiece preset.....	142, 194
Workspace	
Form for tables.....	360
Keyboard.....	270
List.....	493
Main menu.....	80
Overview.....	67, 430
Positions.....	97
Probing Function.....	289
RDP.....	424
Simulation status.....	118
Start/Login.....	84
Status.....	105
Table in the Tables operating	
mode.....	354
WPL-CS.....	187
Write-protection, preset table....	390
Write protection for preset table	
Activating.....	391
Removing.....	391

HEIDENHAIN

DR. JOHANNES HEIDENHAIN GmbH

Dr.-Johannes-Heidenhain-Straße 5

83301 Traunreut, Germany

☎ +49 8669 31-0

FAX +49 8669 32-5061

info@heidenhain.de

Technical support FAX +49 8669 32-1000

Measuring systems ☎ +49 8669 31-3104
service.ms-support@heidenhain.de

NC support ☎ +49 8669 31-3101
service.nc-support@heidenhain.de

NC programming ☎ +49 8669 31-3103
service.nc-pgm@heidenhain.de

PLC programming ☎ +49 8669 31-3102
service.plc@heidenhain.de

APP programming ☎ +49 8669 31-3106
service.app@heidenhain.de

www.heidenhain.com

www.klartext-portal.com

The Information Site for
HEIDENHAIN Controls

Klartext App

Klartext on your
mobile device

Google
Play Store

Apple
App Store



Touch probes and vision systems

HEIDENHAIN provides universal, high-precision touch probe systems for machine tools, for example for the exact determination of workpiece edge positions and for tool measurement. Proven technology, such as a wear-free optical sensor, collision protection, or integrated blower/flusher jets for cleaning the measuring point ensure the reliability and safety of the touch probes when measuring workpieces and tools. For even higher process reliability, the tools can be monitored conveniently with the vision systems and tool-breakage sensor from HEIDENHAIN.



For more details on touch probes and vision systems:

www.heidenhain.com/products/touch-probes-and-vision-systems

