




HEIDENHAIN



User's Manual
DIN/ISO
Programming

iTNC 530





NC Software
340 490-06
340 491-06
340 492-06
340 493-06
340 494-06

English (en)
6/2010





Controls of the TNC







Keys on visual display unit

Key	Function
	Split screen layout
	Toggle the display between machining and programming modes
	Soft keys for selecting functions on screen
	Shifts between soft-key rows



Alphanumeric keyboard

Key	Function
	File names, comments
	DIN/ISO programming







Machine operating modes

Key	Function
	Manual Operation
	Electronic Handwheel
	smarT.NC
	Positioning with Manual Data Input
	Program Run, Single Block
	Program Run, Full Sequence



Programming modes

Key	Function
	Programming and Editing
	Test Run



Program/file management, TNC functions

Key	Function
	Select or delete programs and files, external data transfer
	Define program call, select datum and point tables
	Select MOD functions
	Display help text for NC error messages, call TNCguide
	Display all current error messages
	Show calculator





Navigation keys

Key	Function
	Move highlight
	Go directly to blocks, cycles and parameter functions

Potentiometer for feed rate and spindle speed



Feed rate	Spindle speed
	

Cycles, subprograms and program section repeats










Key	Function
	Define touch probe cycles
	Define and call cycles
	Enter and call labels for subprogramming and program section repeats
	Program stop in a program






Tool functions

Key	Function
	Define tool data in the program
	Call tool data
















Programming path movements

Key	Function
	Approach/depart contour
	FK free contour programming
	Straight line
	Circle center/pole for polar coordinates
	Circle with center
	Circle with radius
	Circular arc with tangential connection
 	Chamfering/corner rounding

Special functions / smarT.NC

Key	Function
	Show special functions
	smarT.NC: Select next tab on form
	smarT.NC: Select first input field in previous/next frame

Coordinate axes and numbers: Entering and editing

Key	Function
 ... 	Select coordinate axes or enter them into the program
 ... 	Numbers
 	Decimal point / Reverse algebraic sign
 	Polar coordinate input / Incremental values
	Q parameter programming / Q parameter status
	Save actual position or values from calculator
	Skip dialog questions, delete words
	Confirm entry and resume dialog
	Conclude block and exit entry
	Clear numerical entry or TNC error message
	Abort dialog, delete program section





About this Manual

The symbols used in this manual are described below.



This symbol indicates that important notes about the function described must be adhered to.



This symbol indicates that there is one or more of the following risks when using the described function:

- Danger to workpiece
- Danger to fixtures
- Danger to tool
- Danger to machine
- Danger to operator



This symbol indicates that the described function must be adapted by the machine tool builder. The function described may therefore vary depending on the machine.



This symbol indicates that you can find detailed information about a function in another manual.

Would you like any changes, or have you found any errors?

We are continuously striving to improve documentation for you. Please help us by sending your requests to the following e-mail address: tnc-userdoc@heidenhain.de.



TNC Model, Software and Features

This manual describes functions and features provided by TNCs as of the following NC software numbers.

TNC model	NC software number
iTNC 530	340 490-06
iTNC 530 E	340 491-06
iTNC 530	340 492-06
iTNC 530 E	340 493-06
iTNC 530 programming station	340 494-06

The suffix E indicates the export version of the TNC. The export version of the TNC has the following limitations:

- Simultaneous linear movement in up to 4 axes

The machine tool builder adapts the usable features of the TNC to his machine by setting machine parameters. Some of the functions described in this manual may therefore not be among the features provided by the TNC on your machine tool.

TNC functions that may not be available on your machine include:

- Tool measurement with the TT

Please contact your machine tool builder to become familiar with the features of your machine.



Many machine manufacturers, as well as HEIDENHAIN, offer programming courses for the TNCs. We recommend these courses as an effective way of improving your programming skill and sharing information and ideas with other TNC users.



User's Manual for Cycle Programming:

All of the cycle functions (touch probe cycles and fixed cycles) are described in a separate manual. Please contact HEIDENHAIN if you require a copy of this User's Manual. ID: 670 388-xx



smarT.NC user documentation:

The smarT.NC operating mode is described in a separate Pilot. Please contact HEIDENHAIN if you require a copy of this Pilot. ID: 533 191-xx.



Software options

The iTNC 530 features various software options that can be enabled by you or your machine tool builder. Each option is to be enabled separately and contains the following respective functions:

Software option 1

Cylinder surface interpolation (Cycles 27, 28, 29 and 39)

Feed rate in mm/min for rotary axes: **M116**

Tilting the machining plane (Cycle 19, **PLANE** function and 3-D ROT soft key in the Manual operating mode)

Circle in 3 axes with tilted working plane

Software option 2

Block processing time 0.5 ms instead of 3.6 ms

5-axis interpolation

Spline interpolation

3-D machining:

- **M114**: Automatic compensation of machine geometry when working with swivel axes
- **M128**: Maintaining the position of the tool tip when positioning with tilted axes (TCPM)
- **FUNCTION TCPM**: Maintaining the position of the tool tip when positioning with tilted axes (TCPM) in selectable modes
- **M144**: Compensating the machine's kinematic configuration for ACTUAL/NOMINAL positions at end of block
- Additional parameters for **finishing/roughing** and **tolerance for rotary axes** in Cycle 32 (G62)
- **LN** blocks (3-D compensation)

DCM Collision software option	Description
Function that monitors areas defined by the machine manufacturer to prevent collisions.	Page 337

DXF Converter software option	Description
Extract contours and machining positions from DXF files (R12 format).	Page 226

Additional dialog language software option	Description
Function for enabling the conversational languages Slovenian, Slovak, Norwegian, Latvian, Estonian, Korean, Turkish, Romanian, Lithuanian.	Page 584



Global Program Settings software option	Description
Function for superimposing coordinate transformations in the Program Run modes, handwheel superimposed traverse in virtual axis direction.	Page 355
AFC software option	Description
Function for adaptive feed-rate control for optimizing the machining conditions during series production.	Page 366
KinematicsOpt software option	Description
Touch-probe cycles for inspecting and optimizing the machine accuracy.	User's Manual for Cycles
3D-ToolComp software option	Description
3-D radius compensation depending on the tool's contact angle for LN blocks.	Page 366



Feature content level (upgrade functions)

Along with software options, significant further improvements of the TNC software are managed via the Feature Content Level (**FCL**) upgrade functions. Functions subject to the FCL are not available simply by updating the software on your TNC.



All upgrade functions are available to you without surcharge when you receive a new machine.

Upgrade functions are identified in the manual with **FCL n**, where **n** indicates the sequential number of the feature content level.

You can purchase a code number in order to permanently enable the FCL functions. For more information, contact your machine tool builder or HEIDENHAIN.

FCL 4 functions	Description
Graphical depiction of the protected space when DCM collision monitoring is active	Page 341
Handwheel superimposition in stopped condition when DCM collision monitoring is active	Page 340
3-D basic rotation (set-up compensation)	Machine Manual

FCL 3 functions	Description
Touch probe cycle for 3-D probing	User's Manual for Cycles
Touch probe cycles for automatic datum setting using the center of a slot/ridge	User's Manual for Cycles
Feed-rate reduction for the machining of contour pockets with the tool being in full contact with the workpiece	User's Manual for Cycles
PLANE function: Entry of axis angle	Page 406
User documentation as a context-sensitive help system	Page 154
smarT.NC: Programming of smarT.NC and machining can be carried out simultaneously	Page 121
smarT.NC: Contour pocket on point pattern	smarT.NC Pilot

FCL 3 functions	Description
smarT.NC: Preview of contour programs in the file manager	smarT.NC Pilot
smarT.NC: Positioning strategy for machining point patterns	smarT.NC Pilot
FCL 2 functions	Description
3-D line graphics	Page 146
Virtual tool axis	Page 501
USB support of block devices (memory sticks, hard disks, CD-ROM drives)	Page 131
Possibility of assigning different depths to each subcontour in the contour formula	User's Manual for Cycles
DHCP dynamic IP-address management	Page 559
Touch-probe cycle for global setting of touch-probe parameters	User's Manual for Touch Probe Cycles
smarT.NC: Graphic support of block scan	smarT.NC Pilot
smarT.NC: Coordinate transformation	smarT.NC Pilot
smarT.NC: PLANE function	smarT.NC Pilot

Intended place of operation

The TNC complies with the limits for a Class A device in accordance with the specifications in EN 55022, and is intended for use primarily in industrially-zoned areas.

Legal information

This product uses open source software. Further information is available on the control under

- ▶ Programming and Editing operating mode
- ▶ MOD function
- ▶ LEGAL INFORMATION soft key



New functions in 340 49x-01 since the predecessor versions 340 422-xx/340 423-xx

- A new form-based operating mode, smarT.NC, has been introduced. These cycles are described in a separate user's document. In connection with this the TNC operating panel was enhanced. There are some new keys available for quicker navigation within smarT.NC.
- The single-processor versions supports pointing devices (mice) via the USB interface.
- The tooth feed f_z and feed per revolution f_u can now be defined as alternate feed entries.
- New cycle **CENTERING** (see User's Manual for Cycles).
- New M function M150 for suppressing limit switch messages (see "Suppress limit switch message: M150" on page 330).
- M128 is now also permitted for mid-program startup (see "Mid-program startup (block scan)" on page 533).
- The number of available Q parameters was expanded to 2000 (see "Principle and Overview" on page 262).
- The number of available label numbers was expanded to 1000. Now label names can be assigned as well (see "Labeling Subprograms and Program Section Repeats" on page 244).
- In the Q parameter functions FN9 to FN12 you can now also assign label names as jump targets (see "If-Then Decisions with Q Parameters" on page 271).
- Selectively machine points from a point table (see User's Manual for Cycles).
- The current time is also shown in the additional status display window (see "General program information (PGM tab)" on page 86).
- Several columns were added to the tool table (see "Tool table: Standard tool data" on page 166).
- The Test Run can now also be stopped and resumed within machining cycles (see "Executing a test run" on page 523).



New functions with 340 49x-02

- DXF files can be opened directly on the TNC, in order to extract contours into a plain-language program (see "Processing DXF Files (Software Option)" on page 226).
- 3-D line graphics are now available in the Programming and Editing operating mode (see "3-D Line Graphics (FCL2 Function)" on page 146).
- The active tool-axis direction can now be set as the active machining direction for manual operation (see "Setting the current tool-axis direction as the active machining direction (FCL 2 function)" on page 501).
- The machine manufacturer can now define any areas on the machine for collision monitoring (see "Dynamic Collision Monitoring (Software Option)" on page 337).
- Instead of the spindle speed S you can now define the cutting speed Vc in m/min (see "Calling tool data" on page 179).
- The TNC can now display freely definable tables in the familiar table view or as forms.
- The function for converting FK programs to H was expanded. Programs can now also be output in linearized format.
- You can filter contours that were created using external programming systems.
- For contours which you connect via the contour formula, you can now assign separate machining depths for each subcontour (see User's Manual for Cycles).
- The single-processor version now supports not only pointing devices (mice), but also USB block devices (memory sticks, disk drives, hard disks, CD-ROM drives) (see "USB devices on the TNC (FCL 2 function)" on page 137).



New functions with 340 49x-03

- The Adaptive Feed Control function (**AFC**) was introduced (see “Adaptive Feed Control Software Option (AFC)” on page 366).
- The global parameter settings function makes it possible to set various transformations and settings in the program run modes (see “Global Program Settings (Software Option)” on page 355).
- The TNC now features a context-sensitive help system, the **TNCguide** (see “The Context-Sensitive Help System TNCguide (FCL3 Function)” on page 154).
- Now you can extract point files from DXF files (see “Selecting and storing machining positions” on page 236).
- Now, in the DXF converter, you can divide or lengthen laterally joined contour elements (see “Dividing, extending and shortening contour elements” on page 235).
- In the **PLANE** function the working plane can now also be defined directly by its axis angle (see “Tilting the working plane through axis angle: PLANE AXIAL (FCL 3 function)” on page 406).
- In Cycle 22 **ROUGH-OUT**, you can define a feed-rate reduction if the tool is cutting on its entire circumference (FCL3 function, see User's Manual for Cycles).
- In Cycle 208 **BORE MILLING**, you can now choose between climb or up-cut milling (see User's Manual for Cycles).
- String processing has been introduced in Q parameter programming (see “String Parameters” on page 285).
- A screen saver can be activated through machine parameter 7392 (see “General User Parameters” on page 584).
- The TNC now also supports a network connection over the NFS V3 protocol (see “Ethernet Interface” on page 551).
- The maximum manageable number of tools in a pocket table was increased to 9999 (see “Pocket table for tool changer” on page 176).
- Parallel programming is possible with smarT.NC (see “Select smarT.NC programs” on page 121).
- The system time can now be set through the MOD function (see “Setting the System Time” on page 576).



New functions with 340 49x-04

- The global parameter settings function makes it possible to activate handwheel superimposed traverse in the active tool axis direction (virtual axis) (see "Virtual axis VT" on page 365).
- Machining patterns can now easily be defined with PATTERN DEF (see User's Manual for Cycles).
- Program defaults valid globally can now be defined for machining cycles (see User's Manual for Cycles).
- Now, in Cycle 209 **TAPPING WITH CHIP BREAKING**, you can define a factor for the retraction shaft speed, so that you can depart the hole faster (see User's Manual for Cycles).
- In Cycle 22 **ROUGH-OUT**, you can now define the fine-roughing strategy (see User's Manual for Cycles).
- In the new Cycle 270 **CONTOUR TRAIN DATA**, you can define the type of approach of Cycle 25 **CONTOUR TRAIN** (see User's Manual for Cycles).
- New Q-parameter function for reading a system datum was introduced (see "Copying system data to a string parameter", page 290).
- New functions for copying, moving and deleting files from within the NC program were introduced.
- DCM: Collision objects can now be shown three-dimensionally during machining (see "Graphic depiction of the protected space (FCL4 function)", page 341).
- DXF converter: New settings possibility introduced, with which the TNC automatically selects the circle center when loading points from circular elements (see "Basic settings", page 228).
- DXF converter: Element information is shown in an additional info window (see "Selecting and saving a contour", page 233).
- AFC: A line diagram is now shown in the additional AFC status display (see "Adaptive Feed Control (AFC tab, software option)" on page 92).
- AFC: Control settings parameters selectable by machine tool builder (see "Adaptive Feed Control Software Option (AFC)" on page 366).
- AFC: The spindle reference load currently being taught is shown in a pop-up window in the teach-in mode. In addition, the learning phase can be restarted at any time via soft key (see "Recording a teach-in cut" on page 370).
- AFC: The dependent file **<name>.H.AFC.DEP** can now also be modified in the **Programming and Editing** operating mode (see "Recording a teach-in cut" on page 370).
- The maximum path permitted for LIFTOFF was increased to 30 mm (see "Automatically retract tool from the contour at an NC stop: M148" on page 329).



- File management was adapted to the file management of smarT.NC (see “Overview: Functions of the file manager” on page 117).
- New function for generating service files was introduced (see “Generating service files” on page 153).
- A window manager was introduced (see “Window Manager” on page 93).
- The new dialog languages Turkish and Romanian were introduced (software option, Page 584).



New functions with 340 49x-05

- DCM: Integrated fixture management (see "Fixture Monitoring (Software Option)" on page 343)
- DCM: Collision checking in the Test Run mode (see "Collision monitoring in the Test Run mode of operation" on page 342)
- DCM: Management of tool-carrier kinematics has been simplified (see "Tool-carrier kinematics" on page 174)
- Processing DXF data: Fast point selection via mouse area (see "Quick selection of hole positions in an area defined by the mouse" on page 238)
- Processing DXF data: Fast point selection via diameter input (see "Quick selection of hole positions in an area defined by the mouse" on page 238)
- DXF data processing: Polyline support was integrated (see "Processing DXF Files (Software Option)" on page 226)
- AFC: Smallest occurring feed rate will now also be saved in the log file (see "Log file" on page 374)
- AFC: Monitoring for tool breakage/tool wear (see "Tool breakage/tool wear monitoring" on page 376)
- AFC: Direct monitoring of spindle load (see "Spindle load monitoring" on page 376)
- Global program settings: Function also partially effective with M91/M92 blocks (see "Global Program Settings (Software Option)" on page 355)
- Pallet preset table added (see "Pallet datum management with the pallet preset table", page 429 or see "Application", page 426 or see "Storing measured values in the pallet preset table", page 477 or see "Saving the basic rotation in the preset table", page 483)
- The additional status display now has an additional tab, i.e. **PAL**, on which an active pallet preset is displayed (see "General pallet information (PAL tab)" on page 87)
- New tool management (see "Tool management (software option)" on page 186)
- New column **R2TOL** in the tool table (see "Tool table: Tool data required for automatic tool measurement" on page 169)
- Tools can now also be selected during tool call by soft key directly from TOOL.T (see "Calling tool data" on page 179)
- TNCguide: Context sensitivity has been improved in that when the cursor is engaged it jumps to the appropriate description (see "Calling the TNCguide" on page 155)
- Lithuanian dialog added, machine parameter 7230 (see "List of general user parameters" on page 585)
- M116 allowed in combination with M128 (see "Feed rate in mm/min on rotary axes A, B, C: M116 (software option 1)" on page 414)
- Introduction of local and nonvolatile Q parameters **QL** and **QR** (see "Principle and Overview" on page 262)
- The MOD function can now test the data medium (see "Checking the Data Carrier" on page 575)



- New Cycle 241 for Single-Fluted Deep-Hole Drilling (see User's Manual for Cycles)
- Touch probe cycle 404 (SET BASIC ROTATION) was expanded by parameter Q305 (Number in table) in order to write basic rotations to the preset table (see User's Manual for Cycles)
- Touch probe cycles 408 to 419: The TNC now also writes to line 0 of the preset table when the display value is set (see User's Manual for Cycles).
- Touch probe cycle 416 (Datum on Circle Center) was expanded by parameter Q320 (safety clearance) (see User's Manual for Cycles)
- Touch probe cycles 412, 413, 421 and 422: Additional parameter Q365 (type of traverse) (see User's Manual for Cycles)
- Touch probe cycle 425 (Measure Slot) was expanded by parameters Q301 (Move to clearance height) and Q320 (setup clearance) (see User's Manual for Cycles)
- Touch probe cycle 450 (Save Kinematics) was expanded by input option 2 (Display saving status) in parameter Q410 (mode) (see User's Manual for Cycles)
- Touch probe cycle 451 (Measure Kinematics) was expanded by parameters Q423 (number of circular measurements) and Q432 (set preset) (see User's Manual for Cycles)
- New touch probe cycle 452 (Preset Compensation) simplifies the measurement of tool changer heads (see User's Manual for Cycles)
- New touch probe cycle 484 for calibrating the wireless TT 449 tool touch probe (see User's Manual for Cycles)



New functions 340 49x-06

- The new HR 510, HR 520 and HR 550 FS handwheels are supported (see "Traversing with electronic handwheels" on page 452)
- New software option 3-D ToolComp: 3-D tool radius compensation depending on the tool's contact angle on blocks with surface normal vectors (LN blocks)
- 3-D line graphics is now also possible in full-screen mode (see "3-D Line Graphics (FCL2 Function)" on page 146)
- A file selection dialog for selecting files in different NC functions and in the table view of the pallet table is available now (see "Calling any program as a subprogram" on page 248)
- DCM: Saving and restoring of fixture situations
- DCM: The form for test program generation now also contains icons and tooltips (see "Check the position of the measured fixture" on page 348)
- DCM, FixtureWizard: Touch points and probing sequence are shown more clearly now
- DCM, FixtureWizard: Designations, touch points and measuring points can be shown or hidden as desired.(see "Operating FixtureWizard" on page 345)
- DCM, FixtureWizard: Chucking equipment and insertion points can now also be selected by mouse click
- DCM: A library with standard chucking equipment is available now (see "Fixture templates" on page 344)
- DCM: Tool carrier management (see "Tool Holder Management (DCM Software Option)" on page 352)



- In the Test Run mode, the working plane can now be defined manually (see "Setting a tilted working plane for the test run" on page 526)
- On machines without encoders in the rotary axes, the rotary axis coordinates to define the virtual axis direction VT can now be specified via M114 (see "Virtual axis VT" on page 365)
- In Manual mode the RW-3D mode for position display is now also available (see "Position Display Types" on page 567)
- Entries in the tool table TOOL.T (see "Tool table: Standard tool data" on page 166)
 - New **DR2TABLE** column for definition of a compensation table for tool radius compensation depending on the tool's contact angle
 - New **LAST_USE** column, into which the TNC enters the date and time of the last tool call
- Q parameter programming: **QS** string parameters can now also be used for jump addresses of conditional jumps, subprograms or program section repeats (see "Calling a subprogram", page 246, see "Calling a program section repeat", page 247 and see "Programming If-Then decisions", page 272)
- The generation of tool usage lists in the Program Run modes can be configured in a form (see "Settings for the tool usage test" on page 183)
- The behavior during deletion of tools from the tool table can now be influenced via machine parameter 7263 (see "Editing tool tables" on page 172)
- In the positioning mode **TURN** of the **PLANE** function you can now define a clearance height to which the tool is to be retracted before tilting to tool axis direction (see "Automatic positioning: MOVE/TURN/STAY (entry is mandatory)" on page 408)
- The following additional functions are now available in the expanded tool management (see "Tool management (software option)" on page 186):
 - Columns with special functions are also editable now
 - The form view of the tool data can now be exited with or without saving changed values
 - The table view now offers a search function
 - Indexed tools are now shown correctly in the form view
 - The tool sequence list includes more detailed information now
 - The loading and unloading list of the tool magazine can now be loaded and unloaded by drag and drop
 - Columns in the table view can be moved simply by drag and drop
- Several special functions (SPEC FCT) are now available in the MDI operating mode (see "Programming and Executing Simple Machining Operations" on page 504)
- There is a new manual probing cycle that can be used to compensate workpiece misalignments by rotating the rotary table (see "Workpiece alignment using 2 points" on page 486)



- New touch probe cycle for calibrating a touch probe by means of a calibration sphere (see User's Manual for Cycle Programming)
- KinematicsOpt: Better support for positioning of Hirth-coupled axes (see User's Manual for Cycle Programming)
- KinematicsOpt: An additional parameter for determination of the backlash in a rotary axis was introduced (see User's Manual for Cycle Programming)
- New Cycle 275 for Trochoidal Slot Milling (see User's Manual for Cycle Programming)
- In Cycle 241 "Single-Fluted Deep-Hole Drilling" it is now possible to define a dwell depth (see User's Manual for Cycle Programming)
- The approach and departure behavior of Cycle 39 "Cylinder Surface Contour" can now be adjusted (see User's Manual for Cycle Programming)



Changed functions in 340 49x-01 since the predecessor versions 340 422-xx/340 423-xx

- The layouts of the status display and additional status display were redesigned (see “Status Displays” on page 83).
- Software 340 490 no longer supports the small resolution in combination with the BC 120 screen (see “Visual display unit” on page 77).
- New key layout of the TE 530 B keyboard unit (see “Operating panel” on page 79).
- The entry range for the **EULPR** precession angle in the **PLANE EULER** function was expanded (see “Defining the machining plane with Euler angles: EULER PLANE” on page 399).
- The plane vector in the **VECTOR PLANE** function no longer has to be entered in standardized form (see “Defining the working plane with two vectors: VECTOR PLANE” on page 401).
- Positioning behavior of the **CYCL CALL PAT** function has been modified (see User's Manual for Cycles).
- The tool types available for selection in the tool table were increased in preparation for future functions.
- Instead of the last 10, you can now choose from the last 15 selected files (see “Choosing one of the last files selected” on page 126).



Functions changed in 340 49x-02

- Access to the preset table was simplified. There are also new possibilities for entering values in the preset table See table "Manually saving the datums in the preset table".
- In inch-programs, the function M136 (feed rate in 0.1 inch/rev) can no longer be combined with the FU function.
- The feed-rate potentiometers of the HR 420 are no longer switched over automatically when the handwheel is selected. The selection is made via soft key on the handwheel. In addition, the pop-up window for the active handwheel was made smaller, in order to improve the view of the display beneath it.
- The maximum number of contour elements for SL cycles was increased to 8192, so that much more complex contours can be machined (see User's Manual for Cycles).
- **FN16: F-PRINT:** The maximum number of Q-parameter values that can be output per line in the format description file was increased to 32.
- The soft keys START and START SINGLE BLOCK in the Program Test mode of operation were switched, so that the soft-key alignment is the same in all modes of operation (Programming and Editing, smarT.NC, Test) (see "Executing a test run" on page 523).
- The design of the soft keys was revised completely.



Changed functions with 340 49x-03

- In Cycle 22 you can now define a tool name also for the coarse roughing tool (see User's Manual Cycles).
- In the **PLANE** function, an **FMAX** can now be programmed for the automatic rotary positioning (see "Automatic positioning: MOVE/TURN/STAY (entry is mandatory)" on page 408).
- When running programs in which non-controlled axes are programmed, the TNC now interrupts the program run and displays a menu for returning to the programmed position (see "Programming of noncontrolled axes (counter axes)" on page 530).
- The tool usage file now also includes the total machining time, which serves as the basis for the progress display in percent in the Program Run, Full Sequence mode.
- The TNC now also takes the dwell time into account when calculating the machining time in the Test Run mode (see "Measuring the machining time" on page 519).
- Arcs that are not programmed in the active working plane can now also be run as spatial arcs (see "Circular path C around circle center CC" on page 209).
- The EDIT OFF/ON soft key on the pocket table can be deactivated by the machine tool builder (see "Pocket table for tool changer" on page 176).
- The additional status display has been revised. The following improvements have been introduced (see "Additional status displays" on page 85):
 - A new overview page with the most important status displays was introduced.
 - The individual status pages are now displayed as tabs (as in smarT.NC). The individual tabs can be selected with the Page soft keys or with the mouse.
 - The current run time of the program is shown in percent by a progress bar.
 - The tolerance values set in Cycle 32 are displayed.
 - Active global program settings are displayed, provided that this software option was enabled.
 - The status of the Adaptive Feed Control (AFC) is displayed, provided that this software option was enabled.



Changed functions with 340 49x-04

- DCM: Retraction after collision simplified (see "Collision monitoring in the manual operating modes", page 339).
- The input range for polar angles was increased (see "Circular path G12/G13/G15 around pole I, J" on page 219).
- The value range for Q-parameter assignment was increased (see "Programming notes", page 264).
- The pocket-, stud- and slot-milling cycles 210 to 214 were removed from the standard soft-key row (CYCL DEF > POCKETS/STUDS/SLOTS). For reasons of compatibility, the cycles will still be available, and can be selected via the GOTO key.
- The soft-key rows in the Test Run operating mode were modified to those of the smarT.NC operating mode.
- Windows XP is now used on the dual-processor version (see "Introduction" on page 614).
- Conversion from FK to H was moved to the special functions (SPEC FCT).
- Filtering of contours was moved to the special functions (SPEC FCT).
- Loading of values from the pocket calculator was changed (see "To transfer the calculated value into the program" on page 143).



Changed functions with 340 49x-05

- GS global program settings: Form was redesigned (see "Global Program Settings (Software Option)", page 355).
- The menu for network configuration was revised (see "Configuring the TNC" on page 554).



Changed functions 340 49x-06

- In the calibration menus for touch probe length and radius, the number and name of the active tool are also displayed now (if the calibration data from the tool table are to be used, MP7411 = 1, see "Managing more than one block of calibrating data", page 480).
- During tilting in the Distance-To-Go mode, the PLANE function now shows the angle actually left to be traversed until the target position (see "Position display" on page 393).
- The approach behavior during side finishing with Cycle 24 (DIN/ISO: G124) was changed (see User's Manual for Cycle Programming).





Table of Contents

First Steps with the iTNC 530	1
Introduction	2
Programming: Fundamentals, File Management	3
Programming: Programming Aids	4
Programming: Tools	5
Programming: Programming Contours	6
Programming: Miscellaneous Functions	7
Programming: Data Transfer from DXF Files	8
Programming: Subprograms and Program Section Repeats	9
Programming: Q Parameters	10
Programming: Miscellaneous Functions	11
Programming: Special Functions	12
Programming: Multiple Axis Machining	13
Programming: Pallet Editor	14
Positioning with Manual Data Input	15
Test Run and Program Run	16
MOD Functions	17
Tables and Overviews	18
iTNC 530 with Windows XP (Option)	19

1 First Steps with the iTNC 530 55

- 1.1 Overview 56
- 1.2 Machine Switch-On 57
 - Acknowledge the power interruption and move to the reference points 57
- 1.3 Programming the First Part 58
 - Select the correct operating mode 58
 - The most important TNC keys 58
 - Create a new program/file management 59
 - Define a workpiece blank 60
 - Program layout 61
 - Program a simple contour 62
 - Create a cycle program 64
- 1.4 Graphically Testing the Program 66
 - Select the correct operating mode 66
 - Select the tool table for the test run 66
 - Choose the program you want to test 67
 - Select the screen layout and the view 67
 - Start the program test 68
- 1.5 Tool Setup 69
 - Select the correct operating mode 69
 - Prepare and measure tools 69
 - The tool table TOOL.T 69
 - The pocket table TOOL_P.TCH 70
- 1.6 Workpiece Setup 71
 - Select the correct operating mode 71
 - Clamp the workpiece 71
 - Align the workpiece with a 3-D touch probe system 72
 - Set the datum with a 3-D touch probe 73
- 1.7 Running the First Program 74
 - Select the correct operating mode 74
 - Choose the program you want to run 74
 - Start the program 74



2 Introduction 75

- 2.1 The iTNC 530 76
 - Programming: HEIDENHAIN conversational, smarT.NC and ISO formats 76
 - Compatibility 76
- 2.2 Visual Display Unit and Keyboard 77
 - Visual display unit 77
 - Sets the screen layout 78
 - Operating panel 79
- 2.3 Operating Modes 80
 - Manual Operation and Electronic Handwheel 80
 - Positioning with Manual Data Input 80
 - Programming and Editing 81
 - Test Run 81
 - Program Run, Full Sequence and Program Run, Single Block 82
- 2.4 Status Displays 83
 - “General” status display 83
 - Additional status displays 85
- 2.5 Window Manager 93
- 2.6 Accessories: HEIDENHAIN 3-D Touch Probes and Electronic Handwheels 94
 - 3-D touch probes 94
 - HR electronic handwheels 95



3 Programming: Fundamentals, File Management 97

- 3.1 Fundamentals 98
 - Position encoders and reference marks 98
 - Reference system 98
 - Reference system on milling machines 99
 - Polar coordinates 100
 - Absolute and incremental workpiece positions 101
 - Setting the datum 102
- 3.2 Creating and Writing Programs 103
 - Organization of an NC program in DIN/ISO 103
 - Define the blank: G30/G31 103
 - Creating a new part program 104
 - Programming tool movements in DIN/ISO format 106
 - Actual position capture 107
 - Editing a program 108
 - The TNC search function 112
- 3.3 File Management: Fundamentals 114
 - Files 114
 - Data backup 115
- 3.4 Working with the File Manager 116
 - Directories 116
 - Paths 116
 - Overview: Functions of the file manager 117
 - Calling the file manager 118
 - Selecting drives, directories and files 119
 - Creating a new directory (only possible on the drive TNC:\) 122
 - Creating a new file (only possible on the drive TNC:\) 122
 - Copying a single file 123
 - Copying files into another directory 124
 - Copying a table 125
 - Copying a directory 126
 - Choosing one of the last files selected 126
 - Deleting a file 127
 - Deleting a directory 127
 - Marking files 128
 - Renaming a file 130
 - Additional functions 131
 - Working with shortcuts 133
 - Data transfer to or from an external data medium 134
 - The TNC in a network 136
 - USB devices on the TNC (FCL 2 function) 137



4 Programming: Programming Aids 139

- 4.1 Adding Comments 140
 - Function 140
 - Entering comments during programming 140
 - Inserting comments after program entry 140
 - Entering a comment in a separate block 140
 - Functions for editing of the comment 141
- 4.2 Structuring Programs 142
 - Definition and applications 142
 - Displaying the program structure window / Changing the active window 142
 - Inserting a structuring block in the (left) program window. 142
 - Selecting blocks in the program structure window 142
- 4.3 Integrated Pocket Calculator 143
 - Operation 143
- 4.4 Programming Graphics 144
 - Generating / not generating graphics during programming 144
 - Generating a graphic for an existing program. 144
 - Block number display ON/OFF 145
 - Erasing the graphic 145
 - Magnifying or reducing a detail 145
- 4.5 3-D Line Graphics (FCL2 Function) 146
 - Function 146
 - Functions of the 3-D line graphics 146
 - Highlighting NC blocks in the graphics 148
 - Block number display ON/OFF 148
 - Erasing the graphic 148
- 4.6 Immediate Help for NC Error Messages 149
 - Displaying error messages 149
 - Display HELP 149
- 4.7 List of All Current Error Messages 150
 - Function 150
 - Show error list 150
 - Window contents 151
 - Calling the TNCguide help system 152
 - Generating service files 153
- 4.8 The Context-Sensitive Help System TNCguide (FCL3 Function) 154
 - Function 154
 - Working with the TNCguide 155
 - Downloading current help files 159



5 Programming: Tools 161

- 5.1 Entering Tool-Related Data 162
 - Feed rate F 162
 - Spindle speed S 163
- 5.2 Tool Data 164
 - Requirements for tool compensation 164
 - Tool numbers and tool names 164
 - Tool length L 164
 - Tool radius R 164
 - Delta values for lengths and radii 165
 - Entering tool data into the program 165
 - Entering tool data in the table 166
 - Tool-carrier kinematics 174
 - Using an external PC to overwrite individual tool data 175
 - Pocket table for tool changer 176
 - Calling tool data 179
 - Tool change 181
 - Tool usage test 183
 - Tool management (software option) 186
- 5.3 Tool Compensation 190
 - Introduction 190
 - Tool length compensation 190
 - Tool radius compensation 191



6 Programming: Programming Contours 195

- 6.1 Tool Movements 196
 - Path functions 196
 - Miscellaneous functions M 196
 - Subprograms and program section repeats 196
 - Programming with Q parameters 196
- 6.2 Fundamentals of Path Functions 197
 - Programming tool movements for workpiece machining 197
- 6.3 Contour Approach and Departure 200
 - Starting point and end point 200
 - Tangential approach and departure 202
- 6.4 Path Contours—Cartesian Coordinates 204
 - Overview of path functions 204
 - Straight line at rapid traverse G00
 - Straight line with feed rate G01 F 205
 - Inserting a chamfer between two straight lines 206
 - Corner rounding G25 207
 - Circle center I, J 208
 - Circular path C around circle center CC 209
 - Circular path G02/G03/G05 with defined radius 210
 - Circular path G06 with tangential connection 212
- 6.5 Path Contours—Polar Coordinates 217
 - Overview 217
 - Zero point for polar coordinates: pole I, J 218
 - Straight line at rapid traverse G10
 - Straight line with feed rate G11 F 218
 - Circular path G12/G13/G15 around pole I, J 219
 - Circular path G16 with tangential connection 220
 - Helical interpolation 221



7 Programming: Data Transfer from DXF Files 225

7.1 Processing DXF Files (Software Option)	226
Function	226
Opening a DXF file	227
Basic settings	228
Layer settings	230
Specifying the reference point	231
Selecting and saving a contour	233
Selecting and storing machining positions	236
Zoom function	242



8 Programming: Subprograms and Program Section Repeats 243

- 8.1 Labeling Subprograms and Program Section Repeats 244
 - Labels 244
- 8.2 Subprograms 245
 - Operating sequence 245
 - Programming notes 245
 - Programming a subprogram 245
 - Calling a subprogram 246
- 8.3 Program Section Repeats 247
 - Label G98 247
 - Operating sequence 247
 - Programming notes 247
 - Programming a program section repeat 247
 - Calling a program section repeat 247
- 8.4 Separate Program as Subprogram 248
 - Operating sequence 248
 - Programming notes 248
 - Calling any program as a subprogram 248
- 8.5 Nesting 250
 - Types of nesting 250
 - Nesting depth 250
 - Subprogram within a subprogram 251
 - Repeating program section repeats 252
 - Repeating a subprogram 253
- 8.6 Programming Examples 254



9 Programming: Q Parameters 261

- 9.1 Principle and Overview 262
 - Programming notes 264
 - Calling Q-parameter functions 265
- 9.2 Part Families—Q Parameters in Place of Numerical Values 266
 - Function 266
- 9.3 Describing Contours through Mathematical Operations 267
 - Function 267
 - Overview 267
 - Programming fundamental operations 268
- 9.4 Trigonometric Functions 269
 - Definitions 269
 - Programming trigonometric functions 270
- 9.5 If-Then Decisions with Q Parameters 271
 - Function 271
 - Unconditional jumps 271
 - Programming If-Then decisions 272
- 9.6 Checking and Changing Q Parameters 273
 - Procedure 273
- 9.7 Additional Functions 274
 - Overview 274
 - D14: ERROR: Displaying error messages 275
 - D15 PRINT: Output of texts or Q parameter values 279
 - D19 PLC: Transfer values to the PLC 280
- 9.8 Entering Formulas Directly 281
 - Entering formulas 281
 - Rules for formulas 283
 - Programming example 284
- 9.9 String Parameters 285
 - String processing functions 285
 - Assigning string parameters 286
 - Chain-linking string parameters 287
 - Converting a numerical value to a string parameter 288
 - Copying a substring from a string parameter 289
 - Copying system data to a string parameter 290
 - Converting a string parameter to a numerical value 292
 - Checking a string parameter 293
 - Finding the length of a string parameter 294
 - Comparing alphabetic priority 295



9.10 Preassigned Q Parameters	296
Values from the PLC: Q100 to Q107	296
WMAT block: QS100	296
Active tool radius: Q108	296
Tool axis: Q109	297
Spindle status: Q110	297
Coolant on/off: Q111	297
Overlap factor: Q112	297
Unit of measurement for dimensions in the program: Q113	298
Tool length: Q114	298
Coordinates after probing during program run	298
Deviation between actual value and nominal value during automatic tool measurement with the TT 130	299
Tilting the working plane with mathematical angles: rotary axis coordinates calculated by the TNC	299
Measurement results from touch probe cycles (see also User's Manual for Touch Probe Cycles)	300
9.11 Programming Examples	302



10 Programming: Miscellaneous Functions 309

- 10.1 Entering Miscellaneous Functions M and STOP 310
 - Fundamentals 310
- 10.2 Miscellaneous Functions for Program Run Control, Spindle and Coolant 311
 - Overview 311
- 10.3 Miscellaneous Functions for Coordinate Data 312
 - Programming machine-referenced coordinates: M91/M92 312
 - Activating the most recently entered datum: M104 314
 - Moving to positions in a non-tilted coordinate system with a tilted working plane: M130 314
- 10.4 Miscellaneous Functions for Contouring Behavior 315
 - Smoothing corners: M90 315
 - Insert rounding arc between straight lines: M112 315
 - Do not include points when executing non-compensated line blocks: M124 316
 - Machining small contour steps: M97 317
 - Machining open contours corners: M98 319
 - Feed rate factor for plunging movements: M103 320
 - Feed rate in millimeters per spindle revolution: M136 321
 - Feed rate for circular arcs: M109/M110/M111 322
 - Calculating the radius-compensated path in advance (LOOK AHEAD): M120 323
 - Superimposing handwheel positioning during program run: M118 325
 - Retraction from the contour in the tool-axis direction: M140 326
 - Suppressing touch probe monitoring: M141 327
 - Delete modal program information: M142 328
 - Delete basic rotation: M143 328
 - Automatically retract tool from the contour at an NC stop: M148 329
 - Suppress limit switch message: M150 330
- 10.5 Miscellaneous Functions for Laser Cutting Machines 331
 - Principle 331
 - Output the programmed voltage directly: M200 331
 - Output voltage as a function of distance: M201 331
 - Output voltage as a function of speed: M202 332
 - Output voltage as a function of time (time-dependent ramp): M203 332
 - Output voltage as a function of time (time-dependent pulse): M204 332



11 Programming: Special Functions 333

- 11.1 Overview of Special Functions 334
 - Main menu for SPEC FCT special functions 334
 - Program defaults menu 335
 - Functions for contour and point machining menu 335
 - Menu of various DIN/ISO functions 336
- 11.2 Dynamic Collision Monitoring (Software Option) 337
 - Function 337
 - Collision monitoring in the manual operating modes 339
 - Collision monitoring in Automatic operation 340
 - Graphic depiction of the protected space (FCL4 function) 341
 - Collision monitoring in the Test Run mode of operation 342
- 11.3 Fixture Monitoring (Software Option) 343
 - Fundamentals 343
 - Fixture templates 344
 - Setting parameter values for the fixture: FixtureWizard 344
 - Placing the fixture on the machine 346
 - Editing fixtures 347
 - Removing fixtures 347
 - Check the position of the measured fixture 348
 - Manage fixtures 350
- 11.4 Tool Holder Management (DCM Software Option) 352
 - Fundamentals 352
 - Tool-holder templates 352
 - Set the tool holder parameters: ToolHolderWizard 353
 - Removing a tool holder 354
- 11.5 Global Program Settings (Software Option) 355
 - Function 355
 - Technical prerequisites 357
 - Activating/deactivating a function 358
 - Basic rotation 360
 - Swapping axes 361
 - Superimposed mirroring 362
 - Additional, additive datum shift 362
 - Axis locking 363
 - Superimposed rotation 363
 - Feed rate override 363
 - Handwheel superimposition 364



11.6 Adaptive Feed Control Software Option (AFC)	366
Application	366
Defining the AFC basic settings	368
Recording a teach-in cut	370
Activating/deactivating AFC	373
Log file	374
Tool breakage/tool wear monitoring	376
Spindle load monitoring	376
11.7 Creating Text Files	377
Application	377
Opening and exiting text files	377
Editing texts	378
Deleting and inserting characters, words and lines	379
Editing text blocks	380
Finding text sections	381
11.8 Working with Cutting Data Tables	382
Note	382
Applications	382
Table for workpiece materials	383
Table for tool cutting materials	384
Table for cutting data	384
Data required for the tool table	385
Working with automatic speed / feed rate calculation	386
Data transfer from cutting data tables	387
Configuration file TNC.SYS	387



12 Programming: Multiple Axis Machining 389

- 12.1 Functions for Multiple Axis Machining 390
- 12.2 The PLANE Function: Tilting the Working Plane (Software Option 1) 391
 - Introduction 391
 - Define the PLANE function 393
 - Position display 393
 - Reset the PLANE function 394
 - Defining the machining plane with space angles: PLANE SPATIAL 395
 - Defining the machining plane with projection angles: PROJECTED PLANE 397
 - Defining the machining plane with Euler angles: EULER PLANE 399
 - Defining the working plane with two vectors: VECTOR PLANE 401
 - Defining the machining plane via three points: PLANE POINTS 403
 - Defining the Machining Plane with a Single, Incremental Space Angle: PLANE RELATIVE 405
 - Tilting the working plane through axis angle: PLANE AXIAL (FCL 3 function) 406
 - Specifying the positioning behavior of the PLANE function 408
- 12.3 Inclined-Tool Machining in the Tilted Plane 413
 - Function 413
 - Inclined-tool machining via incremental traverse of a rotary axis 413
- 12.4 Miscellaneous Functions for Rotary Axes 414
 - Feed rate in mm/min on rotary axes A, B, C: M116 (software option 1) 414
 - Shorter-path traverse of rotary axes: M126 415
 - Reducing display of a rotary axis to a value less than 360°: M94 416
 - Automatic compensation of machine geometry when working with tilted axes: M114 (software option 2) 417
 - Maintaining the position of the tool tip when positioning with tilted axes (TCPM): M128 (software option 2) 418
 - Exact stop at corners with nontangential transitions: M134 421
 - Selecting tilting axes: M138 421
 - Compensating the machine's kinematics configuration for ACTUAL/NOMINAL positions at end of block: M144 (software option 2) 422
- 12.5 Peripheral milling: 3-D radius compensation with workpiece orientation 423
 - Function 423



13 Programming: Pallet Editor 425

- 13.1 Pallet Editor 426
 - Application 426
 - Selecting a pallet table 428
 - Leaving the pallet file 428
 - Pallet datum management with the pallet preset table 429
 - Executing the pallet file 431
- 13.2 Pallet Operation with Tool-Oriented Machining 432
 - Application 432
 - Selecting a pallet file 437
 - Setting up the pallet file with the entry form 437
 - Sequence of tool-oriented machining 442
 - Leaving the pallet file 443
 - Executing the pallet file 443



- 14.1 Switch-On, Switch-Off 446
 - Switch-on 446
 - Switch-off 449
- 14.2 Moving the Machine Axes 450
 - Note 450
 - Moving the axis using the machine axis direction buttons 450
 - Incremental jog positioning 451
 - Traversing with electronic handwheels 452
- 14.3 Spindle Speed S, Feed Rate F and Miscellaneous Functions M 462
 - Function 462
 - Entering values 462
 - Changing the spindle speed and feed rate 463
- 14.4 Datum Setting without a 3-D Touch Probe 464
 - Note 464
 - Preparation 464
 - Workpiece presetting with axis keys 465
 - Datum management with the preset table 466
- 14.5 Using the 3-D Touch Probe 473
 - Overview 473
 - Selecting probe cycles 473
 - Recording measured values from the touch-probe cycles 474
 - Writing the measured values from touch probe cycles in datum tables 475
 - Writing the measured values from touch probe cycles in the preset table 476
 - Storing measured values in the pallet preset table 477
- 14.6 Calibrating a 3-D Touch Probe 478
 - Introduction 478
 - Calibrating the effective length 478
 - Calibrating the effective radius and compensating center misalignment 479
 - Displaying calibration values 480
 - Managing more than one block of calibrating data 480
- 14.7 Compensating Workpiece Misalignment with a 3-D Touch Probe 481
 - Introduction 481
 - Basic rotation using 2 points: 483
 - Determining basic rotation using 2 holes/studs: 485
 - Workpiece alignment using 2 points 486



14.8 Datum Setting with a 3-D Touch Probe	487
Overview	487
Datum setting in any axis	487
Corner as datum—using points that were already probed for a basic rotation	488
Corner as datum—without using points that were already probed for a basic rotation.	488
Circle center as datum	489
Center line as datum	490
Setting datum points using holes/cylindrical studs	491
Measuring Workpieces with a 3-D Touch Probe	492
Using the touch probe functions with mechanical probes or dial gauges	495
14.9 Tilting the Working Plane (Software Option 1)	496
Application, function	496
Traversing the reference points in tilted axes	498
Setting the datum in a tilted coordinate system	498
Datum setting on machines with rotary tables	498
Datum setting on machines with spindle-head changing systems	499
Position display in a tilted system	499
Limitations on working with the tilting function	499
Activating manual tilting	500
Setting the current tool-axis direction as the active machining direction (FCL 2 function)	501



15 Positioning with Manual Data Input 503

- 15.1 Programming and Executing Simple Machining Operations 504
 - Positioning with Manual Data Input (MDI) 504
 - Protecting and erasing programs in \$MDI 507



- 16.1 Graphics 510
 - Application 510
 - Overview of display modes 512
 - Plan view 512
 - Projection in 3 planes 513
 - 3-D view 514
 - Magnifying details 517
 - Repeating graphic simulation 518
 - Displaying the tool 518
 - Measuring the machining time 519
- 16.2 Functions for Program Display 520
 - Overview 520
- 16.3 Test Run 521
 - Application 521
- 16.4 Program Run 527
 - Application 527
 - Running a part program 528
 - Interrupting machining 529
 - Moving the machine axes during an interruption 531
 - Resuming program run after an interruption 532
 - Mid-program startup (block scan) 533
 - Returning to the contour 536
- 16.5 Automatic Program Start 537
 - Application 537
- 16.6 Optional Block Skip 538
 - Application 538
 - Erasing the "/" character 538
- 16.7 Optional Program-Run Interruption 539
 - Application 539



17 MOD Functions 541

- 17.1 Selecting MOD Functions 542
 - Selecting the MOD functions 542
 - Changing the settings 542
 - Exiting the MOD functions 542
 - Overview of MOD functions 543
- 17.2 Software Numbers 544
 - Application 544
- 17.3 Entering Code Numbers 545
 - Application 545
- 17.4 Loading Service Packs 546
 - Application 546
- 17.5 Setting the Data Interfaces 547
 - Application 547
 - Setting the RS-232 interface 547
 - Setting the RS-422 interface 547
 - Setting the OPERATING MODE of the external device 547
 - Setting the baud rate 547
 - Assignment 548
 - Software for data transfer 549
- 17.6 Ethernet Interface 551
 - Introduction 551
 - Connection possibilities 551
 - Connecting the iTNC directly with a Windows PC 552
 - Configuring the TNC 554
- 17.7 Configuring PGM MGT 562
 - Application 562
 - Changing the PGM MGT setting 562
 - Dependent files 563
- 17.8 Machine-Specific User Parameters 564
 - Application 564
- 17.9 Showing the Workpiece in the Working Space 565
 - Application 565
 - Rotate the entire image 566
- 17.10 Position Display Types 567
 - Application 567
- 17.11 Unit of Measurement 568
 - Application 568
- 17.12 Selecting the Programming Language for \$MDI 569
 - Application 569
- 17.13 Selecting the Axes for Generating G01 Blocks 570
 - Application 570



17.14	Entering the Axis Traverse Limits, Datum Display	571
	Application	571
	Working without additional traverse limits	571
	Find and enter the maximum traverse	571
	Datum display	572
17.15	Displaying HELP Files	573
	Application	573
	Selecting HELP files	573
17.16	Displaying Operating Times	574
	Application	574
17.17	Checking the Data Carrier	575
	Application	575
	Performing the data carrier check	575
17.18	Setting the System Time	576
	Application	576
	Selecting appropriate settings	576
17.19	TeleService	577
	Application	577
	Calling/exiting TeleService	577
17.20	External Access	578
	Application	578
17.21	Configuring the HR 550 FS Wireless Handwheel	580
	Application	580
	Assigning the handwheel to a specific handwheel holder	580
	Setting the transmission channel	581
	Selecting the transmitter power	582
	Statistics	582



18 Tables and Overviews 583

- 18.1 General User Parameters 584
 - Input possibilities for machine parameters 584
 - Selecting general user parameters 584
 - List of general user parameters 585
- 18.2 Pin Layouts and Connecting Cables for the Data Interfaces 599
 - RS-232-C/V.24 interface for HEIDENHAIN devices 599
 - Non-HEIDENHAIN devices 600
 - RS-422/V.11 interface 601
 - Ethernet interface RJ45 socket 601
- 18.3 Technical Information 602
- 18.4 Exchanging the Buffer Battery 611



19 iTNC 530 with Windows XP (Option) 613

- 19.1 Introduction 614
 - End User License Agreement (EULA) for Windows XP 614
 - General 614
 - Changes in the pre-installed Windows system 615
 - Specifications 616
- 19.2 Starting an iTNC 530 Application 617
 - Logging on to Windows 617
- 19.3 Switching Off the iTNC 530 619
 - Fundamentals 619
 - Logging a user off 619
 - Exiting the iTNC application 620
 - Shutting down Windows 621
- 19.4 Network Settings 622
 - Prerequisite 622
 - Adjusting the network settings 622
 - Controlling access 623
- 19.5 Specifics About File Management 624
 - The iTNC drive 624
 - Data transfer to the iTNC 530 625







1

**First Steps with the
iTNC 530**



1.1 Overview

This chapter is intended to help TNC beginners quickly learn to handle the most important procedures. For more information on a respective topic, see the section referred to in the text.

The following topics are included in this chapter

- Machine Switch-On
- Programming the First Part
- Graphically Testing the Program
- Tool Setup
- Workpiece Setup
- Running the First Program



1.2 Machine Switch-On

Acknowledge the power interruption and move to the reference points



Switch-on and crossing the reference points can vary depending on the machine tool. Your machine manual provides more detailed information.

- ▶ Switch on the power supply for control and machine. The TNC starts the operating system. This process may take several minutes. Then the TNC will display the message “Power interruption.”



- ▶ Press the CE key: The TNC converts the PLC program



- ▶ Switch on the control voltage: The TNC checks operation of the emergency stop circuit and goes into the reference run mode




- ▶ Cross the reference points manually in the displayed sequence: For each axis press the machine START button. If you have absolute linear and angle encoders on your machine there is no need for a reference run

The TNC is now ready for operation in the **Manual Operation** mode.

Further information on this topic

- Traversing the reference marks: See “Switch-on” on page 446
- Operating modes: See “Programming and Editing” on page 81



1.3 Programming the First Part

Select the correct operating mode

You can write programs only in the Programming and Editing mode:








- ▶ Press the operating modes key: The TNC goes into the **Programming and Editing** mode

Further information on this topic

- Operating modes: See “Programming and Editing” on page 81

The most important TNC keys

Functions for conversational guidance	Key
Confirm entry and activate the next dialog prompt	
Ignore the dialog question.	
End the dialog immediately.	
Abort dialog, discard entries.	
Soft keys on the screen with which you select functions appropriate to the active state	

Further information on this topic

- Writing and editing programs: See “Editing a program” on page 108
- Overview of keys: See “Controls of the TNC” on page 2



Create a new program/file management


PGM
MGT

- ▶ Press the PGM MGT key: the TNC displays the file management. The file management of the TNC is arranged much like the file management on a PC with the Windows Explorer. The file management enables you to manipulate data on the TNC hard disk
- ▶ Use the arrow keys to select the folder in which you want to open the new file
- ▶ Enter a file name with the extension **.I**: The TNC then automatically opens a program and asks for the unit of measure for the new program. Please note the restrictions regarding special characters in the file name (see "File names" on page 115)
- ▶ To select the unit of measure, press the MM or INCH soft key: The TNC automatically starts the workpiece blank definition (see "Define a workpiece blank" on page 60)

The TNC automatically generates the first and last blocks of the program. Afterwards you can no longer change these blocks.

Further information on this topic

- File management: See "Working with the File Manager" on page 116
- Creating a new program: See "Creating and Writing Programs" on page 103



Define a workpiece blank

Immediately after you have created a new program, the TNC starts the dialog for entering the workpiece blank definition. Always define the workpiece blank as a cuboid by entering the MIN and MAX points, each with reference to the selected reference point.

After you have created a new program, the TNC automatically initiates the workpiece blank definition and asks for the required data:

- ▶ **Spindle axis Z - Plane XY?:** Enter the active spindle axis. G17 is saved as default setting. Accept with the ENT key
- ▶ **Coordinates?:** Smallest X coordinate of the workpiece blank with respect to the reference point, e.g. 0. Confirm with the ENT key
- ▶ **Coordinates?:** Smallest Y coordinate of the workpiece blank with respect to the reference point, e.g. 0. Confirm with the ENT key
- ▶ **Coordinates?:** Smallest Z coordinate of the workpiece blank with respect to the reference point, e.g. -40. Confirm with the ENT key
- ▶ **Coordinates?:** Largest X coordinate of the workpiece blank with respect to the reference point, e.g. 100. Confirm with the ENT key
- ▶ **Coordinates?:** Largest Y coordinate of the workpiece blank with respect to the reference point, e.g. 100. Confirm with the ENT key
- ▶ **Coordinates?:** Largest Z coordinate of the workpiece blank with respect to the reference point, e.g. 0. Confirm with the ENT key

Example NC blocks

```
%NEW G71 *
```


```
N10 G30 G17 X+0 Y+0 Z-40 *
```

```
N20 G31 X+100 Y+100 Z+0 *
```

```
N99999999 %NEW G71 *
```

Further information on this topic

- Defining the workpiece blank: (see page 104)



Program layout

NC programs should be arranged consistently in a similar manner. This makes it easier to find your place and reduces errors.

Recommended program layout for simple, conventional contour machining

- 1 Call tool, define tool axis
- 2 Retract the tool
- 3 Pre-position the tool in the working plane near the contour starting point
- 4 In the tool axis, position the tool above the workpiece, or pre-position immediately to workpiece depth. If required, switch on the spindle/coolant
- 5 Move to the contour
- 6 Machine the contour
- 7 Leave the contour
- 8 Retract the tool, end the program

Further information on this topic:

- Contour programming: See “Tool Movements” on page 196

Recommended program layout for simple cycle programs

- 1 Call tool, define tool axis
- 2 Retract the tool
- 3 Define the fixed cycle
- 4 Move to the machining position
- 5 Call the cycle, switch on the spindle/coolant
- 6 Retract the tool, end the program

Further information on this topic:

- Cycle programming: See User’s Manual for Cycles

Example: Layout of contour machining programs

```
%BSPCONT G71 *
N10 G30 G71 X... Y... Z... *
N20 G31 X... Y... Z... *
N30 T5 G17 S5000 *
N40 G00 G40 G90 Z+250 *
N50 X... Y... *
N60 G01 Z+10 F3000 M13 *
N70 X... Y... RL F500 *
...
N160 G40 ... X... Y... F3000 M9 *
N170 G00 Z+250 M2 *
N99999999 BSPCONT G71 *
```

Example: Program layout for cycle programming

```
%BSBCYC G71 *
N10 G30 G71 X... Y... Z... *
N20 G31 X... Y... Z... *
N30 T5 G17 S5000 *
N40 G00 G40 G90 Z+250 *
N50 G200... *
N60 X... Y... *
N70 G79 M13 *
N80 G00 Z+250 M2 *
N99999999 BSBCYC G71 *
```



Program a simple contour

The contour shown to the right is to be milled once to a depth of 5 mm. You have already defined the workpiece blank. After you have initiated a dialog through a function key, enter all the data requested by the TNC in the screen header.



- ▶ Call the tool: Enter the tool data. Confirm each of your entries with the ENT key. Do not forget the tool axis



- ▶ Retract the tool: Press the orange axis key Z in order to get clear in the tool axis, and enter the value for the position to be approached, e.g. 250. Confirm with the ENT key
- ▶ Confirm **Radius comp.: RL/RR/no comp?** by pressing the ENT key: Do not activate the radius compensation
- ▶ Confirm the **Miscellaneous function M?** with the END key: The TNC saves the entered positioning block



- ▶ Preposition the tool in the working plane: Press the orange X axis key and enter the value for the position to be approached, e.g. -20
- ▶ Press the orange Y axis key and enter the value for the position to be approached, e.g. -20. Confirm with the ENT key
- ▶ Confirm **Radius comp.: RL/RR/no comp?** by pressing the ENT key: Do not activate the radius compensation
- ▶ Confirm the **Miscellaneous function M?** with the END key: The TNC saves the entered positioning block



- ▶ Move the tool to workpiece depth: Press the orange Y axis key and enter the value for the position to be approached, e.g. -5. Confirm with the ENT key
- ▶ Confirm **Radius comp.: RL/RR/no comp?** by pressing the ENT key: Do not activate the radius compensation
- ▶ **Feed rate F=?** Enter the positioning feed rate, e.g. 3000 mm/min and confirm with the ENT key
- ▶ **Miscellaneous function M?** Switch on the spindle and coolant, e.g. **M13**. Confirm with the END key: The TNC saves the entered positioning block



- ▶ Move to the contour: Define the **rounding radius** of the approaching arc




- ▶ Machine the contour and move to contour point **2**: You only need to enter the information that changes. In other words, enter only the Y coordinate 95 and save your entry with the END key








- ▶ Move to contour point **3**: Enter the X coordinate 95 and save your entry with the END key



- ▶ Define the chamfer at contour point **3**: Enter the chamfer width 10 mm and save with the END key



-  ▶ Move to contour point **4**: Enter the Y coordinate 5 and save your entry with the END key
-  ▶ Define the chamfer at contour point **4**: Enter the chamfer width 20 mm and save with the END key
-  ▶ Move to contour point **1**: Enter the X coordinate 5 and save your entry with the END key
-  **27** ▶ Depart the contour: Define the **rounding radius** of the departing arc
-  **0** ▶ Retract the tool: Press the orange axis key Z in order to get clear in the tool axis, and enter the value for the position to be approached, e.g. 250. Confirm with the ENT key
- ▶ Confirm **Radius comp.: RL/RR/no comp?** by pressing the ENT key: Do not activate the radius compensation
- ▶ **Miscellaneous function M?** Enter **M2** to end the program and confirm with the END key: The TNC saves the entered positioning block

Further information on this topic

- **Complete example with NC blocks:** See “Example: Linear movements and chamfers with Cartesian coordinates” on page 213
- Creating a new program: See “Creating and Writing Programs” on page 103
- Approaching/departing contours: See “Contour Approach and Departure” on page 200
- Programming contours: See “Overview of path functions” on page 204
- Tool radius compensation: See “Tool radius compensation” on page 191
- Miscellaneous functions (M): See “Miscellaneous Functions for Program Run Control, Spindle and Coolant” on page 311



Create a cycle program

The holes (depth of 20 mm) shown in the figure at right are to be drilled with a standard drilling cycle. You have already defined the workpiece blank.

TOOL CALL

G 0

- ▶ Call the tool: Enter the tool data. Confirm each of your entries with the ENT key. Do not forget the tool axis
- ▶ Retract the tool: Press the orange axis key Z in order to get clear in the tool axis, and enter the value for the position to be approached, e.g. 250. Confirm with the ENT key
- ▶ Confirm **Radius comp.: RL/RR/no comp?** by pressing the ENT key: Do not activate the radius compensation
- ▶ Confirm the **Miscellaneous function M?** with the END key: The TNC saves the entered positioning block

CYCL DEF

DRILLING/
THREAD

200

- ▶ Call the cycle menu
- ▶ Display the drilling cycles
- ▶ Select the standard drilling cycle 200: The TNC starts the dialog for cycle definition. Enter all parameters requested by the TNC step by step and conclude each entry with the ENT key. In the screen to the right, the TNC also displays a graphic showing the respective cycle parameter

G 0



- ▶ Move to the first drilling position: Enter the **coordinates** of the drilling position, switch on the coolant and spindle, and call the cycle with **M99**

X 0

- ▶ Move to the subsequent drilling positions: Enter the **coordinates** of the respective drilling positions, and call the cycle with **M99**

G 0

- ▶ Retract the tool: Press the orange axis key Z in order to get clear in the tool axis, and enter the value for the position to be approached, e.g. 250. Confirm with the ENT key
- ▶ Confirm **Radius comp.: RL/RR/no comp?** by pressing the ENT key: Do not activate the radius compensation
- ▶ **Miscellaneous function M?** Enter **M2** to end the program and confirm with the END key: The TNC saves the entered positioning block



Example NC blocks

<code>%C200 G71 *</code>	
<code>N10 G30 G17 X+0 Y+0 Z-40 *</code>	Definition of workpiece blank
<code>N20 G31 X+100 Y+100 Z+0 *</code>	
<code>N30 T5 G17 S4500 *</code>	Tool call
<code>N40 G00 G40 G90 Z+250 *</code>	Retract the tool
<code>N50 G200 DRILLING</code>	Define the cycle
<code>Q200=2 ;SETUP CLEARANCE</code>	
<code>Q201=-20 ;DEPTH</code>	
<code>Q206=250 ;FEED RATE FOR PLNGN</code>	
<code>Q202=5 ;PLUNGING DEPTH</code>	
<code>Q210=0 ;DWELL TIME AT TOP</code>	
<code>Q203=-10 ;SURFACE COORDINATE</code>	
<code>Q204=20 ;2ND SETUP CLEARANCE</code>	
<code>Q211=0.2 ;DWELL TIME AT DEPTH</code>	
<code>N60 X+10 Y+10 M13 M99 *</code>	Spindle and coolant on, call cycle
<code>N70 X+10 Y+90 M99 *</code>	Call the cycle
<code>N80 X+90 Y+10 M99 *</code>	Call the cycle
<code>N90 X+90 Y+90 M99 *</code>	Call the cycle
<code>N100 G00 Z+250 M2 *</code>	Retract in the tool axis, end program
<code>N99999999 %C200 G71 *</code>	

Further information on this topic

- Creating a new program: See “Creating and Writing Programs” on page 103
- Cycle programming: See User’s Manual for Cycles



1.4 Graphically Testing the Program

Select the correct operating mode

You can test programs only in the Test Run mode:



- ▶ Press the operating modes key: The TNC goes into the **Test Run** mode

Further information on this topic

- Operating modes of the TNC: See "Operating Modes" on page 80
- Testing programs: See "Test Run" on page 521

Select the tool table for the test run

You only need to execute this step if you have not activated a tool table in the Test Run mode.



- ▶ Press the PGM MGT key: the TNC displays the file management



- ▶ Press the SELECT TYPE soft key: The TNC shows a soft-key menu for selection of the file type to be displayed



- ▶ Press the SHOW ALL soft key: The TNC shows all saved files in the right window



- ▶ Move the highlight to the left onto the directories



- ▶ Move the highlight to the **TNC:** directory



- ▶ Move the highlight to the right onto the files




- ▶ Move the highlight to the file TOOL.T (active tool table) and load with the ENT key: TOOL.T receives that status **S** and is therefore active for the Test Run



- ▶ Press the END key: Leave the file manager

Further information on this topic

- Tool management: See "Entering tool data in the table" on page 166
- Testing programs: See "Test Run" on page 521



Choose the program you want to test



- ▶ Press the PGM MGT key: the TNC displays the file management



- ▶ Press the LAST FILES soft key: The TNC opens a pop-up window with the most recently selected files
- ▶ Use the arrow keys to select the program that you want to test. Load with the ENT key

Further information on this topic

- Selecting a program: See "Working with the File Manager" on page 116

Select the screen layout and the view



- ▶ Press the key for selecting the screen layout. The TNC shows all available alternatives in the soft-key row



- ▶ Press the PROGRAM + GRAPHICS soft key: In the left half of the screen the TNC shows the program; in the right half it shows the workpiece blank

- ▶ Select the desired view via soft key



- ▶ Plan view



- ▶ Projection in three planes



- ▶ 3-D view

Further information on this topic

- Graphic functions: See "Graphics" on page 510
- Running a test run: See "Test Run" on page 521



Start the program test



▶ Press the RESET + START soft key: The TNC simulates the active program up to a programmed break or to the program end

▶ While the simulation is running you can use the soft keys to change views.



▶ Press the STOP soft key: The TNC interrupts the test run



▶ Press the START soft key: The TNC resumes the test run after a break

Further information on this topic

- Running a test run: See “Test Run” on page 521
- Graphic functions: See “Graphics” on page 510
- Adjusting the test speed: See “Setting the speed of the test run” on page 511



1.5 Tool Setup

Select the correct operating mode

Tools are set up in the **Manual Operation** mode:




- ▶ Press the operating modes key: The TNC goes into the **Manual Operation** mode

Further information on this topic

- Operating modes of the TNC: See "Operating Modes" on page 80

Prepare and measure tools

- ▶ Clamp the required tools in their chucks
- ▶ When measuring with an external tool presetter: Measure the tools, note down the length and radius, or transfer them directly to the machine through a transfer program
- ▶ When measuring on the machine: Place the tools into the tool changer (see page 70)



The tool table TOOL.T

In the tool table TOOL.T (permanently saved under **TNC:**), save the tool data such as length and radius, but also further tool-specific information that the TNC needs to conduct its functions.


To enter tool data in the tool table TOOL.T, proceed as follows:



- ▶ Display the tool table



- ▶ Edit the tool table: Set the EDITING soft key to ON
- ▶ With the upward or downward arrow keys you can select the tool number that you want to edit
- ▶ With the rightward or leftward arrow keys you can select the tool data that you want to edit
- ▶ To leave the tool table, press the END key



Further information on this topic

- Operating modes of the TNC: See "Operating Modes" on page 80
- Working with the tool table: See "Entering tool data in the table" on page 166



The pocket table TOOL_P.TCH



The function of the pocket table depends on the machine. Your machine manual provides more detailed information.

In the pocket table TOOL_P.TCH (permanently saved under **TNC:**) you specify which tools your tool magazine contains.

To enter data in the pocket table TOOL_P.TCH, proceed as follows:



- ▶ Display the tool table



- ▶ Display the pocket table
- ▶ Edit the pocket table: Set the EDITING soft key to ON
- ▶ With the upward or downward arrow keys you can select the pocket number that you want to edit
- ▶ With the rightward or leftward arrow keys you can select the data that you want to edit
- ▶ To leave the pocket table, press the END key

Further information on this topic

- Operating modes of the TNC: See "Operating Modes" on page 80
- Working with the pocket table: See "Pocket table for tool changer" on page 176

Pocket table editing
Tool number?

NO	PRG	TOOL	PRG	NO	PRG
0.0		%00000000	D10		0
1.1	4	%00000000	D8	Tool 4	0
1.2		%00000000			0
1.2	0	%00000000	D18		0
1.4		%00000000			4
1.5		%00000000			0
1.5	20	%00000000	D40		0
1.7	18	%00000000	D32		0
1.0		%00000000			0
1.0	3	%00000000	D6	Tool 3	0
1.10	7	%00000000	D14		0
1.11		%00000000			0
1.12	23	%00000000	D46		0
1.13		%00000000			0
1.14		%00000000			0
1.15		%00000000			0
2.1	12	%00000000	D24		0

0% S-IST P0 -T5
0% SCNmJ LIMIT 1 23:50

X +20.249 Y +11.550 Z +100.250
+B +0.000 +C +0.000

S1 0.000

ACTL. P: 20 T 5 Z S 2500 F 5.0 M 5 / 8

BEGIN END PAGE PAGE EDIT RESET TOOL END
OFF ON POCKET TABLE



1.6 Workpiece Setup

Select the correct operating mode

Workpieces are set up in the **Manual Operation** or **Electronic Handwheel** mode



- ▶ Press the operating modes key: The TNC goes into the **Manual Operation** mode

Further information on this topic

- Manual mode: See "Moving the Machine Axes" on page 450

Clamp the workpiece

Mount the workpiece with a fixture on the machine table. If you have a 3-D touch probe on your machine, then you do not need to clamp the workpiece parallel to the axes.

If you do not have a 3-D touch probe available, you have to align the workpiece so that it is fixed with its edges parallel to the machine axes.



Align the workpiece with a 3-D touch probe system

- ▶ Insert the 3-D touch probe: In the Manual Data Input (MDI) operating mode, run a **TOOL CALL** block containing the tool axis, and then return to the **Manual Operation** mode (in MDI mode you can run an individual NC block independently of the others)



- ▶ Select the probing functions: The TNC displays the available functions in the soft-key row
- ▶ Measure the basic rotation: The TNC displays the basic rotation menu. To identify the basic rotation, probe two points on a straight surface of the workpiece
- ▶ Use the axis-direction keys to pre-position the touch probe to a position near the first contact point
- ▶ Select the probing direction via soft key
- ▶ Press NC start: The touch probe moves in the defined direction until it contacts the workpiece and then automatically returns to its starting point.
- ▶ Use the axis-direction keys to pre-position the touch probe to a position near the second contact point
- ▶ Press NC start: The touch probe moves in the defined direction until it contacts the workpiece and then automatically returns to its starting point.
- ▶ Then the TNC shows the measured basic rotation
- ▶ Press the END key to close the menu and then answer the question of whether the basic rotation should be transferred to the preset table by pressing the NO ENT key (no transfer)

Further information on this topic

- MDI operating mode: See "Programming and Executing Simple Machining Operations" on page 504
- Workpiece alignment: See "Compensating Workpiece Misalignment with a 3-D Touch Probe" on page 481



Set the datum with a 3-D touch probe

- ▶ Insert the 3-D touch probe: In the MDI mode, run a **TOOL CALL** block containing the tool axis and then return to the **Manual Operation** mode



- ▶ Select the probing functions: The TNC displays the available functions in the soft-key row



- ▶ Set the reference point at a workpiece corner, for example: The TNC asks whether the prove points from the previously measured basic rotation should be loaded. Press the ENT key to load points
- ▶ Position the touch probe at a position near the first touch point of the side that was not probed for basic rotation
- ▶ Select the probing direction via soft key
- ▶ Press NC start: The touch probe moves in the defined direction until it contacts the workpiece and then automatically returns to its starting point
- ▶ Use the axis-direction keys to pre-position the touch probe to a position near the second contact point
- ▶ Press NC start: The touch probe moves in the defined direction until it contacts the workpiece and then automatically returns to its starting point.
- ▶ Then the TNC shows the coordinates of the measured corner point



- ▶ Set to 0: Press the SET DATUM soft key
- ▶ Press the END to close the menu

Further information on this topic

- Datum setting: See “Datum Setting with a 3-D Touch Probe” on page 487



1.7 Running the First Program

Select the correct operating mode

You can run programs either in the Single Block or the Full Sequence mode:



- ▶ Press the operating mode key: The TNC goes into the **Program Run, Single Block** mode and the TNC executes the program block by block. You have to confirm each block with the NC key



- ▶ Press the operating mode key: The TNC goes into the **Program Run, Full Sequence** mode and the TNC executes the program after NC start up to a program break or to the end of the program

Further information on this topic

- Operating modes of the TNC: See "Operating Modes" on page 80
- Running programs: See "Program Run" on page 527

Choose the program you want to run



- ▶ Press the PGM MGT key: the TNC displays the file management



- ▶ Press the LAST FILES soft key: The TNC opens a pop-up window with the most recently selected files
- ▶ If desired, use the arrow keys to select the program that you want to run. Load with the ENT key

Further information on this topic

- File management: See "Working with the File Manager" on page 116


Start the program



- ▶ Press the NC start button: The TNC executes the active program

Further information on this topic

- Running programs: See "Program Run" on page 527





2

Introduction



2.1 The iTNC 530

HEIDENHAIN TNC controls are workshop-oriented contouring controls that enable you to program conventional machining operations right at the machine in an easy-to-use conversational programming language. They are designed for milling, drilling and boring machines, as well as for machining centers. The iTNC 530 can control up to 12 axes. You can also change the angular position of the spindle under program control.

An integrated hard disk provides storage for as many programs as you like, even if they were created off-line. For quick calculations you can call up the on-screen pocket calculator at any time.

Keyboard and screen layout are clearly arranged in such a way that the functions are fast and easy to use.

Programming: HEIDENHAIN conversational, smarT.NC and ISO formats

The HEIDENHAIN conversational programming format is an especially easy method of writing programs. Interactive graphics illustrate the individual machining steps for programming the contour. If a production drawing is not dimensioned for NC, the FK free contour programming performs the necessary calculations automatically. Workpiece machining can be graphically simulated either during or before actual machining.

The smarT.NC operating mode offers TNC beginners an especially simple possibility to quickly and without much training create structured conversational dialog programs. Separate user documentation is available for smarT.NC.

It is also possible to program the TNCs in ISO format or DNC mode.

You can also enter and test one program while the control is running another.

Compatibility

The TNC can run all part programs that were written on HEIDENHAIN controls TNC 150 B and later. In as much as old TNC programs contain OEM cycles, the iTNC 530 must be adapted to them with the PC software CycleDesign. For more information, contact your machine tool builder or HEIDENHAIN.



2.2 Visual Display Unit and Keyboard

Visual display unit

The TNC is delivered with the BF 250 15-inch color flat-panel screen.


1 Header

When the TNC is on, the selected operating modes are shown in the screen header: the machining mode at the left and the programming mode at right. The currently active mode is displayed in the larger box, where the dialog prompts and TNC messages also appear (unless the TNC is showing only graphics).

2 Soft keys

In the footer the TNC indicates additional functions in a soft-key row. You can select these functions by pressing the keys immediately below them. The lines immediately above the soft-key row indicate the number of soft-key rows that can be called with the black arrow keys to the right and left. The active soft-key row is indicated by brightened bar.

- 3 Soft-key selection keys
- 4 Shifts between soft-key rows
- 5 Setting the screen layout
- 6 Shift key for switchover between machining and programming modes
- 7 Soft-key selection keys for machine tool builder soft keys
- 8 Switches soft-key rows for machine tool builders
- 9 USB connection



Sets the screen layout

You select the screen layout yourself: In the PROGRAMMING AND EDITING mode of operation, for example, you can have the TNC show program blocks in the left window while the right window displays programming graphics. You could also display the program structure in the right window instead, or display only program blocks in one large window. The available screen windows depend on the selected operating mode.

To change the screen layout:



Press the SPLIT SCREEN key: The soft-key row shows the available layout options (see "Operating Modes", page 80).



Select the desired screen layout.



Operating panel

The TNC is delivered with the TE 530 keyboard unit. The figure shows the controls and displays of the TE 530 keyboard unit.


- 1 Alphabetic keyboard for entering texts and file names, and for ISO programming.
- Dual-processor version: Additional keys for Windows operation
- 2 ■ File management
■ Calculator
■ MOD function
■ HELP function
- 3 Programming modes
- 4 Machine operating modes
- 5 Initiation of programming dialog
- 6 Arrow keys and GOTO jump command
- 7 Numerical input and axis selection
- 8 Touchpad: Only for operating the dual-processor version, soft keys and smarT.NC
- 9 smarT.NC navigation keys

The functions of the individual keys are described on the inside front cover.



Some machine manufacturers do not use the standard operating panel from HEIDENHAIN. Please refer to your machine manual in these cases.

Machine panel buttons, e.g. NC START or NC STOP, are also described in the manual for your machine tool.



2.3 Operating Modes

Manual Operation and Electronic Handwheel

The Manual Operation mode is required for setting up the machine tool. In this mode of operation, you can position the machine axes manually or by increments, set the datums, and tilt the working plane.

The Electronic Handwheel mode of operation allows you to move the machine axes manually with the HR electronic handwheel.

Soft keys for selecting the screen layout (select as described previously)



Window	Soft key
Positions	POSITION
Left: positions, right: status display	POSITION + STATUS
Left: positions, right: active collision objects (FCL4 function).	POSITION + KINEMATICS

Positioning with Manual Data Input

This mode of operation is used for programming simple traversing movements, such as for face milling or pre-positioning.

Soft keys for selecting the screen layout

Window	Soft key
Program	PGM
Left: program blocks, right: status display	PROGRAM + STATUS
Left: program blocks, right: active collision objects (FCL4 function). If this view is selected, then the TNC indicates a collision with a red frame around the graphics window.	PROGRAM + KINEMATICS




Programming and Editing

In this mode of operation you can write your part programs. The FK free programming feature, the various cycles and the Q parameter functions help you with programming and add necessary information. If desired, the programming graphics or the 3-D line graphics (FCL 2 function) display the programmed traverse paths.

Soft keys for selecting the screen layout

Window	Soft key
Program	PGM
Left: program, right: program structure	PROGRAM SECTS
Left: program blocks, right: graphics	PROGRAM GRAPHICS
Left: program blocks, right: 3-D line graphics	PROGRAM 3D LINES
3-D line graphics	3-D LINES




Test Run

In the Test Run mode of operation, the TNC checks programs and program sections for errors, such as geometrical incompatibilities, missing or incorrect data within the program or violations of the work space. This simulation is supported graphically in different display modes.

With the dynamic collision monitoring (DCM) software option you can test the program for potential collisions. As during program run, the TNC takes into account all permanent machine components defined by the machine manufacturer as well as all measured fixtures.

Soft keys for selecting the screen layout: see "Program Run, Full Sequence and Program Run, Single Block", page 82.



Program Run, Full Sequence and Program Run, Single Block

In the Program Run, Full Sequence mode of operation the TNC executes a part program continuously to its end or to a manual or programmed stop. You can resume program run after an interruption.



In the Program Run, Single Block mode of operation you execute each block separately by pressing the machine START button.

Soft keys for selecting the screen layout

Window	Soft key
Program	PGM
Left: program, right: program structure	PROGRAM + SECTS
Left: program, right: status	PROGRAM + STATUS
Left: program, right: graphics	PROGRAM + GRAPHICS
Graphics	GRAPHICS
Left: program blocks, right: active collision objects (FCL4 function). If this view is selected, then the TNC indicates a collision with a red frame around the graphics window.	PROGRAM + KINEMATICS
Active collision objects (FCL4 function). If this view is selected, then the TNC indicates a collision with a red frame around the graphics window.	KINEMATICS

Soft keys for selecting the screen layout for pallet tables

Window	Soft key
Pallet table	PALLET
Left: program blocks, right: pallet table	PROGRAM + PALLET
Left: pallet table, right: status	PALLET + STATUS
Left: pallet table, right: graphics	PALLET + GRAPHICS



2.4 Status Displays








“General” status display


The status display in the lower part of the screen informs you of the current state of the machine tool. It is displayed automatically in the following modes of operation:



- Program Run, Single Block and Program Run, Full Sequence, except if the screen layout is set to display graphics only, and
- Positioning with Manual Data Input (MDI).

In the Manual mode and Electronic Handwheel mode the status display appears in the large window.

Information in the status display

Symbol	Meaning
ACTL.	Actual or nominal coordinates of the current position
XYZ	Machine axes; the TNC displays auxiliary axes in lower-case letters. The sequence and quantity of displayed axes is determined by the machine tool builder. Refer to your machine manual for more information.
FSM	The displayed feed rate in inches corresponds to one tenth of the effective value. Spindle speed S, feed rate F and active M functions.
*	Program run started.
	Axis is locked.
	Axis can be moved with the handwheel.
	Axes are moving under a basic rotation.
	Axes are moving in a tilted working plane.
	The M128 function or TCPM FUNCTION is active.
	The Dynamic Collision Monitoring function (DCM) is active.
	The Adaptive Feed Function (AFC) is active (software option).



Symbol	Meaning
	One or more global program settings are active (software option)
	Number of the active presets from the preset table. If the datum was set manually, the TNC displays the text MAN behind the symbol.



Additional status displays

The additional status displays contain detailed information on the program run. They can be called in all operating modes except for the Programming and Editing mode of operation.

To switch on the additional status display:



Call the soft-key row for screen layout.



Screen layout with additional status display: In the right half of the screen, the TNC shows the **Overview** status form.

To select an additional status display:



Shift the soft-key rows until the STATUS soft keys appear.



Either select the additional status display, e.g. positions and coordinates, or



Use the soft keys to select the desired view.

With the soft keys or switch-over soft keys, you can choose directly between the available status displays.




Please note that some of the status information described below is not available unless the associated software option is enabled on your TNC.





Overview

After switch-on, the TNC displays the **Overview** status form, provided that you have selected the PROGRAM+STATUS screen layout (or POSITION + STATUS). The overview form contains a summary of the most important status information, which you can also find on the various detail forms.

Soft key	Meaning
	Position display in up to 5 axes
	Tool information
	Active M functions
	Active coordinate transformations
	Active subprogram
	Active program section repeat
	Program called with PGM CALL
	Current machining time
	Name of the active main program

General program information (PGM tab)

Soft key	Meaning
No direct selection possible	Name of the active main program
	Circle center CC (pole)
	Dwell time counter
	Machining time when the program was completely simulated in the Test Run operating mode
	Current machining time in percent
	Current time
	Current feed rate
	Active programs



General pallet information (PAL tab)




Soft key	Meaning
No direct selection possible	Number of the active pallet preset

Program section repeat/Subprograms (LBL tab)

Soft key	Meaning
No direct selection possible	Active program section repeats with block number, label number, and number of programmed repeats/repeats yet to be run
	Active subprogram numbers with block number in which the subprogram was called and the label number that was called


Information on standard cycles (CYC tab)

Soft key	Meaning
No direct selection possible	Active machining cycle
	Active values of Cycle G62 Tolerance



Active miscellaneous functions M (M tab)

Soft key	Meaning
No direct selection possible	List of the active M functions with fixed meaning
	List of the active M functions that are adapted by your machine manufacturer





Positions and coordinates (POS tab)

Soft key	Meaning
STATUS POS.	Type of position display, e.g. actual position
	Value traversed in virtual axis direction VT (only with "global program settings" software option)
	Tilt angle of the working plane
	Angle of a basic rotation

Information on tools (TOOL tab)

Soft key	Meaning
TOOL STATUS	<ul style="list-style-type: none"> T: Tool number and name RT: Number and name of a replacement tool
	Tool axis
	Tool lengths and radii
	Oversizes (delta values) from the tool table (TAB) and the TOOL CALL (PGM)
	Tool life, maximum tool life (TIME 1) and maximum tool life for TOOL CALL (TIME 2)
	Display of the active tool and the (next) replacement tool



Tool measurement (TT tab)





The TNC only displays the TT tab if the function is active on your machine.

Soft key	Meaning
No direct selection possible	Number of the tool to be measured
	Display whether the tool radius or the tool length is being measured
	MIN and MAX values of the individual cutting edges and the result of measuring the rotating tool (DYN = dynamic measurement)
	Cutting edge number with the corresponding measured value. If the measured value is followed by an asterisk, the allowable tolerance in the tool table was exceeded The TNC displays the measured values of up to 24 teeth.

Coordinate transformations (TRANS tab)

Soft key	Meaning
	Name of the active datum table
	Active datum number (#), comment from the active line of the active datum number (DOC) from Cycle G53
	Active datum shift (Cycle G54); The TNC displays an active datum shift in up to 8 axes
	Mirrored axes (Cycle G28)
	Active basic rotation
	Active rotation angle (Cycle G73)
	Active scaling factor/factors (Cycles G72); The TNC displays an active scaling factor in up to 6 axes
	Scaling datum

For further information, refer to the User's Manual for Cycles, "Coordinate Transformation Cycles."



Global program settings 1 (GPS1 tab, software option)



The TNC only displays the tab if the function is active on your machine.

Soft key	Meaning
----------	---------

No direct selection possible	Swapped axes
	Superimposed datum shift
	Superimposed mirroring



Global program settings 2 (GPS2 tab, software option)



The TNC only displays the tab if the function is active on your machine.

Soft key	Meaning
----------	---------

No direct selection possible	Locked axes
	Superimposed basic rotation
	Superimposed rotation
	Active feed rate factor



Adaptive Feed Control (AFC tab, software option)



The TNC only displays the **AFC** tab if the function is active on your machine.

Soft key	Meaning
No direct selection possible	Active mode in which adaptive feed control is running
	Active tool (number and name)
	Cut number
	Current factor of the feed potentiometer in percent
	Active spindle load in percent
	Reference load of the spindle
	Current spindle speed
	Current deviation of the speed
	Current machining time
	Line diagram, in which the current spindle load and the value commanded by the TNC for the feed-rate override are shown

Program run, full sequence

```

19 L IX-1 R0 FMAX
20 CVCL DEF 11.0 SCALING
21 CVCL DEF 11.1 SCL 0.9995
22 STOP
23 L Z=50 R0 FMAX
24 L X=20 V=20 R0 FMAX
25 CALL LBL 15 REPS
26 PLANE RESET STAY
27 LBL 0
28 END PGM STAT1 MM
  
```

Mode OFF
T: S
DOC:
Cut number 0
Act1 override factor 0%
Actual spindle load 0%
Spindle ref. load
Actual spindle speed 0
Rot. speed deviation 0.0%
00:00:04

0: S-IST P0 -T5
0: SIN(1) .LIMIT 1 23:40

X -2.787 Y -340.071 Z +100.250
+B +0.000 +C +0.000

S1 0.000

ACTL. 2:20 T S 2:5 2500 F 0 M S / E

STATUS OVERVIEW STATUS POS. TOOL STATUS STATUS COORD. TRANSP.



2.5 Window Manager



The machine tool builder determines the scope of function and behavior of the window manager. The machine tool manual provides further information.

The TNC features the Xfce window manager. Xfce is a standard application for UNIX-based operating systems, and is used to manage graphical user interfaces. The following functions are possible with the window manager:

- Display a task bar for switching between various applications (user interfaces).
- Manage an additional desktop, on which special applications from your machine tool builder can run.
- Control the focus between NC-software applications and those of the machine tool builder.
- The size and position of pop-up windows can be changed. It is also possible to close, minimize and restore the pop-up windows.



The TNC shows a star in the upper left of the screen if an application of the window manager or the window manager itself has caused an error. In this case, switch to the window manager and correct the problem. If required, refer to your machine manual.



2.6 Accessories: HEIDENHAIN 3-D Touch Probes and Electronic Handwheels

3-D touch probes

With the various HEIDENHAIN 3-D touch probe systems you can:

- Automatically align workpieces
- Quickly and precisely set datums
- Measure the workpiece during program run
- Measure and inspect tools



All of the touch probe functions are described in the User's Manual for Cycles. Please contact HEIDENHAIN if you require a copy of this User's Manual. ID: 670 388-xx.

TS 220, TS 640 and TS 440 touch trigger probes

These touch probes are particularly effective for automatic workpiece alignment, datum setting and workpiece measurement. The TS 220 transmits the triggering signals to the TNC via cable and is a cost-effective alternative for applications where digitizing is not frequently required.

The TS 640 (see figure) and the smaller TS 440 feature infrared transmission of the triggering signal to the TNC. This makes them highly convenient for use on machines with automatic tool changers.

Principle of operation: HEIDENHAIN triggering touch probes feature a wear resisting optical switch that generates an electrical signal as soon as the stylus is deflected. This signal is transmitted to the control, which stores the current position of the stylus as the actual value.



TT 140 tool touch probe for tool measurement

The TT 140 is a triggering 3-D touch probe for tool measurement and inspection. Your TNC provides three cycles for this touch probe with which you can measure the tool length and radius automatically either with the spindle rotating or stopped. The TT 140 features a particularly rugged design and a high degree of protection, which make it insensitive to coolants and swarf. The triggering signal is generated by a wear-resistant and highly reliable optical switch.

HR electronic handwheels

Electronic handwheels facilitate moving the axis slides precisely by hand. A wide range of traverses per handwheel revolution is available. Apart from the HR 130 and HR 150 integral handwheels, HEIDENHAIN also offers the HR 510 and HR 520 portable handwheels. You will find a detailed description of HR 520 in Chapter 14 of this manual (see "Traversing with electronic handwheels" on page 452).







3

**Programming:
Fundamentals, File
Management**



3.1 Fundamentals

Position encoders and reference marks

The machine axes are equipped with position encoders that register the positions of the machine table or tool. Linear axes are usually equipped with linear encoders, rotary tables and tilting axes with angle encoders.

When a machine axis moves, the corresponding position encoder generates an electrical signal. The TNC evaluates this signal and calculates the precise actual position of the machine axis.

If there is a power interruption, the calculated position will no longer correspond to the actual position of the machine slide. To recover this association, incremental position encoders are provided with reference marks. The scales of the position encoders contain one or more reference marks that transmit a signal to the TNC when they are crossed over. From that signal the TNC can re-establish the assignment of displayed positions to machine positions. For linear encoders with distance-coded reference marks the machine axes need to move by no more than 20 mm, for angle encoders by no more than 20°.




With absolute encoders, an absolute position value is transmitted to the control immediately upon switch-on. In this way the assignment of the actual position to the machine slide position is re-established directly after switch-on.

Reference system

A reference system is required to define positions in a plane or in space. The position data are always referenced to a predetermined point and are described through coordinates.

The Cartesian coordinate system (a rectangular coordinate system) is based on the three coordinate axes X, Y and Z. The axes are mutually perpendicular and intersect at one point called the datum. A coordinate identifies the distance from the datum in one of these directions. A position in a plane is thus described through two coordinates, and a position in space through three coordinates.



Coordinates that are referenced to the datum are referred to as absolute coordinates. Relative coordinates are referenced to any other known position (reference point) you define within the coordinate system. Relative coordinate values are also referred to as incremental coordinate values.



Reference system on milling machines

When using a milling machine, you orient tool movements to the Cartesian coordinate system. The illustration at right shows how the Cartesian coordinate system describes the machine axes. The figure illustrates the right-hand rule for remembering the three axis directions: the middle finger points in the positive direction of the tool axis from the workpiece toward the tool (the Z axis), the thumb points in the positive X direction, and the index finger in the positive Y direction.

The iTNC 530 can control up to 9 axes. The axes U, V and W are secondary linear axes parallel to the main axes X, Y and Z, respectively. Rotary axes are designated as A, B and C. The illustration at lower right shows the assignment of secondary axes and rotary axes to the main axes.



Polar coordinates

If the production drawing is dimensioned in Cartesian coordinates, you also write the NC program using Cartesian coordinates. For parts containing circular arcs or angles it is often simpler to give the dimensions in polar coordinates.



While the Cartesian coordinates X, Y and Z are three-dimensional and can describe points in space, polar coordinates are two-dimensional and describe points in a plane. Polar coordinates have their datum at a circle center (CC), or pole. A position in a plane can be clearly defined by the:

- Polar Radius, the distance from the circle center CC to the position, and the
- Polar Angle, the size of the angle between the reference axis and the line that connects the circle center CC with the position

Setting the pole and the angle reference axis

The pole is set by entering two Cartesian coordinates in one of the three planes. These coordinates also set the reference axis for the polar angle H.

Coordinates of the pole (plane)	Reference axis of the angle
X/Y	+X
Y/Z	+Y
Z/X	+Z




Absolute and incremental workpiece positions

Absolute workpiece positions

Absolute coordinates are position coordinates that are referenced to the datum of the coordinate system (origin). Each position on the workpiece is uniquely defined by its absolute coordinates.

Example 1: Holes dimensioned in absolute coordinates

Hole 1	Hole 2	Hole 3
X = 10 mm	X = 30 mm	X = 50 mm
Y = 10 mm	Y = 20 mm	Y = 30 mm



Incremental workpiece positions

Incremental coordinates are referenced to the last programmed nominal position of the tool, which serves as the relative (imaginary) datum. When you write an NC program in incremental coordinates, you thus program the tool to move by the distance between the previous and the subsequent nominal positions. This is why they are also referred to as a chain dimensions.


To program a position in incremental coordinates, enter the function G91 before the axis.

Example 2: Holes dimensioned in incremental coordinates

Absolute coordinates of hole 4

X = 10 mm
Y = 10 mm


Hole 5, with respect to 4	Hole 6, with respect to 5
G91 X = 20 mm	G91 X = 20 mm
G91 Y = 10 mm	G91 Y = 10 mm



Absolute and incremental polar coordinates

Absolute polar coordinates always refer to the pole and the reference axis.

Incremental coordinates always refer to the last programmed nominal position of the tool.



Setting the datum

A production drawing identifies a certain form element of the workpiece, usually a corner, as the absolute datum. Before setting the datum, you align the workpiece with the machine axes and move the tool in each axis to a known position relative to the workpiece. Set the display of the TNC either to zero or to a known position value for each position. This establishes the reference system for the workpiece, which will be used for the TNC display and your part program.



If the production drawing is dimensioned in relative coordinates, simply use the coordinate transformation cycles (see User's Manual for Cycle Programming, Cycles for Coordinate Transformation).

If the production drawing is not dimensioned for NC, set the datum at a position or corner on the workpiece which is suitable for deducing the dimensions of the remaining workpiece positions.

The fastest, easiest and most accurate way of setting the datum is by using a 3-D touch probe from HEIDENHAIN. See "Setting the Datum with a 3-D Touch Probe" in the Touch Probe Cycles User's Manual.

Example

The workpiece drawing shows holes (1 to 4) whose dimensions are shown with respect to an absolute datum with the coordinates $X=0$ $Y=0$. The holes (5 to 7) are dimensioned with respect to a relative datum with the absolute coordinates $X=450$, $Y=750$. With the **DATUM SHIFT** cycle you can temporarily set the datum to the position $X=450$, $Y=750$, to be able to program the holes (5 to 7) without further calculations.



3.2 Creating and Writing Programs

Organization of an NC program in DIN/ISO

A part program consists of a series of program blocks. The figure at right illustrates the elements of a block.


The TNC numbers the blocks of a part program automatically depending on MP7220. MP7220 defines the block number increment.

The first block of a program is identified by %, the program name and the active unit of measure.

The subsequent blocks contain information on:

- The workpiece blank
- Tool calls
- Approaching a safe position
- Feed rates and spindle speeds, as well as
- Path contours, cycles and other functions

The last block of a program is identified by **N99999999** the program name and the active unit of measure.



Danger of collision!

After each tool call, HEIDENHAIN recommends always traversing to a safe position, from which the TNC can position the tool for machining without causing a collision!

Define the blank: G30/G31

Immediately after initiating a new program, you define a cuboid workpiece blank. If you wish to define the blank at a later stage, press the SPEC FCT key and then the BLK FORM soft key. This definition is needed for the TNC's graphic simulation feature. The sides of the workpiece blank lie parallel to the X, Y and Z axes and can be up to 100 000 mm long. The blank form is defined by two of its corner points:

- MIN point G30: the smallest X, Y and Z coordinates of the blank form, entered as absolute values
- MAX point G31: the largest X, Y and Z coordinates of the blank form, entered as absolute or incremental values



You only need to define the blank form if you wish to run a graphic test for the program!



Creating a new part program

You always enter a part program in the **Programming and Editing** mode of operation. An example of program initiation:



Select the **Programming and Editing** operating mode.



Press the PGM MGT key to call the file manager.

Select the directory in which you wish to store the new program:

FILE NAME = OLD.H



Enter the new program name and confirm your entry with the ENT key.



To select the unit of measure, press the MM or INCH soft key. The TNC switches the screen layout and initiates the dialog for defining the **BLK FORM** (workpiece blank).

WORKING SPINDLE AXIS X/Y/Z?



Enter spindle axis, e.g. Z

DEF BLK FORM: MIN CORNER?



Enter in sequence the X, Y and Z coordinates of the MIN point and confirm each of your entries with the ENT key.

DEF BLK FORM: MAX CORNER?



Enter in sequence the X, Y and Z coordinates of the MAX point and confirm each of your entries with the ENT key.



Example: Display the BLK form in the NC program

%NEW G71 *	Program begin, name, unit of measure
N10 G30 G17 X+0 Y+0 Z-40 *	Spindle axis, MIN point coordinates
N20 G31 X+100 Y+100 Z+0 *	MAX point coordinates
N99999999 %NEW G71 *	Program end, name, unit of measure

The TNC automatically generates the first and last blocks of the program.



If you do not wish to define a blank form, cancel the dialog at **Working spindle axis X/Y/Z** by pressing the DEL key!

The TNC can display the graphics only if the shortest side is at least 50 µm long and the longest side is no longer than 99 999.999 mm.



Programming tool movements in DIN/ISO format

To program a block, select a DIN/ISO function key on the alphabetic keyboard. You can also use the gray contouring keys to get the corresponding G code.



You only need to make sure that capitalization is active.

Example of a positioning block

G 1 **ENT** Start block.

COORDINATES?

X 10 Enter the target coordinate for the X axis.

Y 20 **ENT** Enter the target coordinate for the Y axis, and go to the next question with ENT.

PATH OF THE CUTTER CENTER

G 40 Select tool movement without radius compensation: Confirm with the ENT key or

G41 **G42** To move the tool to the left or to the right of the contour, select function G41 (to the left) or G42 (to the right) by soft key.

FEED RATE F=?

100 **ENT** Enter a feed rate of 100 mm/min for this path contour; go to the next question with ENT.

MISCELLANEOUS FUNCTION M?

3 **ENT** Enter the miscellaneous function **M3** "spindle ON." Pressing the ENT key terminates this dialog.

The program-block window displays the following line:

```
N30 G01 G40 X+10 Y+5 F100 M3 *
```



Actual position capture

The TNC enables you to transfer the current tool position into the program, for example during

- Positioning-block programming
- Cycle programming
- Tool definition with **G99**

To transfer the correct position values, proceed as follows:

- ▶ Place the input box at the position in the block where you want to insert a position value.



- ▶ Select the actual-position-capture function. In the soft-key row the TNC displays the axes whose positions can be transferred



- ▶ Select the axis. The TNC writes the current position of the selected axis into the active input box



In the working plane the TNC always captures the coordinates of the tool center, even though tool radius compensation is active.

In the tool axis the TNC always captures the coordinates of the tool tip and thus always takes the active tool length compensation into account.

The TNC keeps the soft-key row for axis selection active until you deactivate it by pressing the actual-position-capture key again. This behavior remains in effect even if you save the current block and open a new one with a path function key. If you select a block element in which you must choose an input alternative via soft key (e.g. for radius compensation), then the TNC also closes the soft-key row for axis selection.

The actual-position-capture function is not allowed if the tilted working plane function is active.



Editing a program










You cannot edit a program while it is being run by the TNC in a machine operating mode. The TNC allows you to place the cursor in the block, but it does not save the changes and responds instead with an error message.

While you are creating or editing a part program, you can select any desired line in the program or individual words in a block with the arrow keys or the soft keys:

Function	Soft key/Keys
Go to previous page	
Go to next page	
Go to beginning of program.	
Go to end of program.	
Change the position of the current block on the screen. Press this soft key to display additional program blocks that are programmed before the current block.	
Change the position of the current block on the screen. Press this soft key to display additional program blocks that are programmed after the current block.	
Move from one block to the next.	
Select individual words in a block.	
To select a certain block, press the GOTO key, enter the desired block number, and confirm with the ENT key. Or: Enter the block number step and press the N LINES soft key to jump over the entered number of lines upward or downward.	



Function	Soft key/Key
Set the selected word to zero.	
Erase an incorrect number.	
Clear a (non-blinking) error message.	
Delete the selected word.	
Delete the selected block.	
Erase cycles and program sections.	
Insert the block that you last edited or deleted.	

Inserting blocks at any desired location

- ▶ Select the block after which you want to insert a new block and initiate the dialog.

Editing and inserting words

- ▶ Select a word in a block and overwrite it with the new one. The plain-language dialog is available while the word is highlighted.
- ▶ To accept the change, press the END key.

If you want to insert a word, press the horizontal arrow key repeatedly until the desired dialog appears. You can then enter the desired value.



Looking for the same words in different blocks

To use this function, set the AUTO DRAW soft key to OFF.



To select a word in a block, press the arrow keys repeatedly until the highlight is on the desired word.



Select a block with the arrow keys.

The word that is highlighted in the new block is the same as the one you selected previously.



If you have started a search in a very long program, the TNC shows a progress display window. You then have the option of canceling the search via soft key.

Finding any text

- ▶ To select the search function, press the FIND soft key. The TNC displays the **Find text:** dialog prompt.
- ▶ Enter the text that you wish to find.
- ▶ To find the text, press the EXECUTE soft key.



Marking, copying, deleting and inserting program sections

The TNC provides certain functions for copying program sections within an NC program or into another NC program—see the table below.






To copy a program section, proceed as follows:

- ▶ Select the soft-key row containing the marking functions.
- ▶ Select the first (last) block of the section you wish to copy.
- ▶ To mark the first (last) block, press the SELECT BLOCK soft key. The TNC then highlights the first character of the block and the CANCEL SELECTION soft key appears.
- ▶ Move the highlight to the last (first) block of the program section you wish to copy or delete. The TNC shows the marked blocks in a different color. You can end the marking function at any time by pressing the CANCEL SELECTION soft key.
- ▶ To copy the selected program section, press the COPY BLOCK soft key. To delete the selected section, press the DELETE BLOCK soft key. The TNC stores the selected block.
- ▶ Using the arrow keys, select the block after which you wish to insert the copied (deleted) program section.



To insert the section into another program, select the corresponding program using the file manager and then mark the block after which you wish to insert the copied block.

- ▶ To insert the block, press the INSERT BLOCK soft key.
- ▶ To end the marking function, press the CANCEL SELECTION soft key.

Function	Soft key
Switch the marking function on.	
Switch the marking function off.	
Delete the marked block.	
Insert the block that is stored in the buffer memory.	
Copy the marked block.	



The TNC search function

With the search function of the TNC, you can search for any text within a program and replace it by a new text, if required.

Searching for texts

▶ If required, select the block containing the word you wish to find.



▶ Select the search function. The TNC superimposes the search window and displays the available search functions in the soft-key row (see table of search functions).



▶ Enter the text to be searched for. Please note that the search is case-sensitive.



▶ Start the search process: The TNC displays the available search options in the soft-key row (see the table of search options).



▶ If required, change the search options.



▶ Start the search process: The TNC moves to the next block containing the text you are searching for.



▶ Repeat the search process: The TNC moves to the next block containing the text you are searching for.



▶ End the search function.

Search functions	Soft key
Show the pop-up window containing the last search items. Use the arrow keys to select a search item and confirm with the ENT key.	
Show the pop-up window containing possible search items of the current block. Use the arrow keys to select a search item and confirm with the ENT key.	
Show the pop-up window containing a selection of the most important NC functions. Use the arrow keys to select a search item and confirm with the ENT key.	
Activate the Search/Replace function.	



Search options	Soft key
Define the search direction	<div style="display: flex; justify-content: space-around;"> <div style="border: 1px solid black; padding: 2px; text-align: center;">UPWARD DOWNWARD</div> <div style="border: 1px solid black; padding: 2px; text-align: center;">UPWARD DOWNWARD</div> </div>
Define the end of the search: With COMPLETE, the search starts at the current block and continues until it reaches it again.	<div style="display: flex; justify-content: space-around;"> <div style="border: 1px solid black; padding: 2px; text-align: center;">COMPLETE BEGIN/END</div> <div style="border: 1px solid black; padding: 2px; text-align: center;">COMPLETE BEGIN/END</div> </div>
Start a new search.	<div style="border: 1px solid black; padding: 2px; text-align: center;">NEW SEARCH</div>

Find/Replace any text



The find/replace function is not possible if

- a program is protected
- the program is currently being run by the TNC

When using the REPLACE ALL function, ensure that you do not accidentally replace text that you do not want to change. Once replaced, such text cannot be restored.

- ▶ If required, select the block containing the word you wish to find.



- ▶ Select the Search function: The TNC superimposes the search window and displays the available search functions in the soft-key row.



- ▶ Activate the Replace function: The TNC superimposes a window for entering the text to be inserted.



- ▶ Enter the text to be searched for. Please note that the search is case-sensitive. Then confirm with the ENT key.



- ▶ Enter the text to be inserted. Please note that the entry is case-sensitive.



- ▶ Start the search process: The TNC displays the available search options in the soft-key row (see the table of search options).



- ▶ If required, change the search options.



- ▶ Start the search process: The TNC moves to the next occurrence of the text you are searching for.



- ▶ To replace the text and then move to the next occurrence of the text, press the REPLACE soft key. To replace all text occurrences, press the REPLACE ALL soft key. To skip the text and move to its next occurrence press the DO NOT REPLACE soft key.



- ▶ End the search function.



3.3 File Management: Fundamentals

Files

Files in the TNC	Type
Programs	
In HEIDENHAIN format	.H
In DIN/ISO format	.I
smarT.NC files	
Structured unit program	.HU
Contour descriptions	.HC
Point tables for machining positions	.HP
Tables for	
Tools	.T
Tool changers	.TCH
Pallets	.P
Datums	.D
Points	.PNT
Presets	.PR
Cutting data	.CDT
Cutting materials, workpiece materials	.TAB
Dependent data (such as structure items)	.DEP
Texts as	
ASCII files	.A
Help files	.CHM
Drawing data as	
ASCII files	.DXF
Other files	
Fixture templates	.CFT
Parameterized fixtures	.CFX
Dependent data (such as structure items)	.DEP

When you write a part program on the TNC, you must first enter a file name. The TNC saves the program to the hard disk as a file with the same name. The TNC can also save texts and tables as files.

The TNC provides a special file management window in which you can easily find and manage your files. Here you can call, copy, rename and erase files.

You can manage nearly any number of files with the TNC, at least **21 GB** (dual-processor version: **13 GB**). The size of the hard disk depends on the main computer installed in your machine. A single NC program can be up to **2 GB** large.



File names

When you store programs, tables and texts as files, the TNC adds an extension to the file name, separated by a point. This extension indicates the file type.

PROG20	.H
--------	----

File name

File type

File names should not exceed 25 characters, otherwise the TNC cannot display the entire file name. The following characters are not permitted in file names:

. ! " ' () * + / ; < = > ? [] ^ ` { | } ~



The space (HEX 20) and delete (HEX 7F) characters are not permitted in file names, either.

The maximum limit for the path and file name together is 83 characters (see "Paths" on page 116).

Data backup

We recommend saving newly written programs and files on a PC at regular intervals.

The TNCremoNT data transmission freeware from HEIDENHAIN is a simple and convenient method for backing up data stored on the TNC.

You additionally need a data medium on which all machine-specific data, such as the PLC program, machine parameters, etc., are stored. Ask your machine manufacturer for assistance, if necessary.



Saving the contents of the entire hard disk (>2 GB) can take up to several hours. In this case, it is a good idea to save the data outside of work hours, e.g. during the night.

Take the time occasionally to delete any unneeded files so that the TNC always has enough hard-disk space for system files (such as the tool table).



Depending on operating conditions (e.g., vibration load), hard disks generally have a higher failure rate after three to five years of service. HEIDENHAIN therefore recommends having the hard disk inspected after three to five years.



3.4 Working with the File Manager

Directories

To ensure that you can easily find your files, we recommend that you organize your hard disk into directories. You can divide a directory into further directories, which are called subdirectories. With the `-/+` key or `ENT` you can show or hide the subdirectories.



The TNC can manage up to 6 directory levels!

If you save more than 512 files in one directory, the TNC no longer sorts them alphabetically!

Directory names

The maximum limit for the path, including the file name, is 256 characters (see "Paths" on page 116).

Paths

A path indicates the drive and all directories and subdirectories under which a file is saved. The individual names are separated by a backslash "`\`".




The path, including all drive characters, directory and the file name including extension, cannot exceed 83 characters!

Example

The directory `AUFTR1` was created on the `TNC:\` drive. Then, in the `AUFTR1` directory, the directory `NCPROG` was created and the part program `PROG1.H` was copied into it. The part program now has the following path:

`TNC:\AUFTR1\NCPROG\PROG1.H`

The chart at right illustrates an example of a directory display with different paths.



Overview: Functions of the file manager



If you want to use the old file management system, you must use the MOD function to switch to the old file manager (see "Changing the PGM MGT setting" on page 562).

Function	Soft key	Page
Copy (and convert) individual files		Page 123
Select target directory		Page 123
Display a specific file type.		Page 119
Create new file.		Page 122
Display the last 10 files that were selected.		Page 126
Delete a file or directory.		Page 127
Mark a file.		Page 128
Rename a file.		Page 130
Protect a file against editing and erasure.		Page 131
Cancel file protection.		Page 131
Open a smarT.NC program		Page 121
Manage network drives.		Page 136
Copy a directory.		Page 126
Update the directory tree, e.g. to be able to see if a new directory was created while the file manager was opened.		



Calling the file manager


PGM
MGT

Press the PGM MGT key: The TNC displays the file management window (see figure for default setting). If the TNC displays a different screen layout, press the WINDOW soft key.)

The narrow window on the left shows the available drives and directories. Drives designate devices with which data are stored or transferred. One drive is the hard disk of the TNC. Other drives are the interfaces (RS232, RS422, Ethernet), which can be used, for example, to connect a personal computer. A directory is always identified by a folder symbol to the left and the directory name to the right. Subdirectories are shown to the right of and below their parent directories. A triangle in front of the folder symbol indicates that there are further subdirectories, which can be shown with the `-/+` or ENT keys.

The wide window on the right shows you all files that are stored in the selected directory. Each file is shown with additional information, illustrated in the table below.

Display	Meaning
File name	Name with max. 25 characters
Type	File type
Size	File size in bytes
Changed	Date and time that the file was last changed. The date format can be set
Status	File properties: E: Program is selected in the Programming and Editing mode of operation. S: Program is selected in the Test Run mode of operation. M: Program is selected in a Program Run mode of operation. P: File is protected against deletion and editing. + : Dependent files exist (structure file, tool-usage file)



Selecting drives, directories and files



Call the file manager.

Use the arrow keys or the soft keys to move the highlight to the desired position on the screen:



Moves the highlight from the left to the right window, and vice versa.



Moves the highlight up and down within a window.



Moves the highlight one page up or down within a window.

Step 1: Select drive

Move the highlight to the desired drive in the left window:



To select a drive, press the SELECT soft key, or



Press the ENT key

Step 2: Select a directory

Move the highlight to the desired directory in the left-hand window—the right-hand window automatically shows all files stored in the highlighted directory



Step 3: Select a file



Press the SELECT TYPE soft key



Press the soft key for the desired file type, or



Press the SHOW ALL soft key to display all files, or

4* .H



Use wild card characters, e.g. to show all files of the file type .H that begin with 4

Move the highlight to the desired file in the right window:



Press the SELECT soft key, or



Press the ENT key

The TNC opens the selected file in the operating mode from which you called the file manager.



Select smarT.NC programs

Programs created in the smarT.NC operating mode can be opened in the **Programming and Editing** mode with either the smarT.NC editor or the conversational editor. By default the TNC always opens **.HU** and **.HC** programs with the smarT.NC editor. If you want to open the programs in the conversational editor, proceed as follows:



Call the file manager

With the arrow keys or the soft keys you can move the highlight to an **.HU** or **.HC** file:



Moves the highlight from the left to the right window, and vice versa.



Moves the highlight up and down within a window.



Moves the highlight one page up or down within a window.



Shift the soft-key row.



Select the submenu for selecting the editor.



Open the **.HU** or **.HC** program with the conversational editor.



Open the **.HU** program with the smarT.NC editor.



Open the **.HC** program with the smarT.NC editor.



Creating a new directory (only possible on the drive TNC:\)

Move the highlight in the left window to the directory in which you want to create a subdirectory.

NEW

ENT

Enter the new directory name, and confirm with ENT.

CREATE \NEW DIRECTORY?

YES

Press the YES soft key to confirm, or

NO

Abort with the NO soft key.

Creating a new file (only possible on the drive TNC:\)

Select the directory in which you wish to create the new file.

NEW

ENT

Enter the new file name with the file extension, and confirm with ENT.



Open the dialog box for creating a new file.

NEW

ENT

Enter the new file name with the file extension, and confirm with ENT.

Copying a single file

- ▶ Move the highlight to the file you wish to copy.



- ▶ Press the COPY soft key to select the copy function. The TNC displays a soft-key row with soft keys for different functions. You can also start the copy process by pressing CTRL+C.



- ▶ Enter the name of the destination file and confirm your entry with the ENT key or OK soft key: the TNC copies the file to the active directory or to the selected destination directory. The original file is retained, or:



- ▶ Press the Target Directory soft key to call a pop-up window in which you select the target directory by pressing the ENT key or the OK soft key: the TNC copies the file to the selected directory. The original file is retained.



When the copying process has been started with ENT or the OK soft key, the TNC displays a pop-up window with a progress indicator.



Copying files into another directory

- ▶ Select a screen layout with two equally sized windows.
- ▶ To display directories in both windows, press the PATH soft key.

In the right window

- ▶ Move the highlight to the directory into which you wish to copy the files, and display the files in this directory with the ENT key.

In the left window

- ▶ Select the directory with the files that you wish to copy and press ENT to display them.



- ▶ Call the file tagging functions



- ▶ Move the highlight to the file you want to copy and tag it. You can tag several files in this way, if desired



- ▶ Copy the tagged files into the target directory

Additional tagging functions: see "Marking files", page 128.

If you have tagged files in both the left and right windows, the TNC copies from the directory in which the highlight is located.

Overwriting files

If you copy files into a directory in which other files are stored under the same name, the TNC will ask whether the files in the target directory should be overwritten:

- ▶ To overwrite all files, press the YES soft key, or
- ▶ To overwrite no files, press the NO soft key, or
- ▶ To confirm each file separately before overwriting it, press the CONFIRM soft key.

If you wish to overwrite a protected file, this must also be confirmed or aborted separately.



Copying a table

If you are copying tables, you can overwrite individual lines or columns in the target table with the REPLACE FIELDS soft key. Prerequisites:

- The target table must already exist
- The file to be copied must only contain the columns or lines you want to replace.



The **REPLACE FIELDS** soft key does not appear when you want to overwrite the table in the TNC with an external data transfer software, such as TNCremoNT. Copy the externally created file into a different directory, and then copy the desired fields with the TNC file management.

The file extension of the externally created table should be **.A** (ASCII). In these cases the table can contain any number of lines. If you create a file of type *.T, then the table must contain sequential line numbers beginning with 0.

Example

With a tool presetter you have measured the length and radius of ten new tools. The tool presetter then generates the tool table TOOL.A with 10 lines (for the 10 tools) and the columns

- Tool number (column **T**)
 - Tool length (column **L**)
 - Tool radius (column **R**)
- ▶ Copy this table from the external data medium to any directory.
 - ▶ Copy the externally created table over the existing table using the TNC file manager. The TNC asks if you wish to overwrite the existing TOOL.T tool table:
 - ▶ If you press the YES soft key, the TNC will completely overwrite the current TOOL.T tool table. After this copying process the new TOOL.T table consists of 10 lines. The only remaining columns in the table are tool number, tool length and tool radius
 - ▶ Or, if you press the REPLACE FIELDS soft key, the TNC merely overwrites the first 10 lines of the number, length and radius columns in the TOOL.T file. The data of the other lines and columns is not changed.



Copying a directory



In order to copy directories, you must have set the view so that the TNC displays directories in the window on the right (see “Adapting the file manager” on page 132).

Please note that when copying directories, the TNC only copies those files that are displayed by the current filter settings.

- ▶ Move the highlight in the right window onto the directory you want to copy.
- ▶ Press the COPY soft key: the TNC opens the window for selecting the target directory.
- ▶ Select the target directory and confirm with ENT or the OK soft key. The TNC copies the selected directory and all its subdirectories to the selected target directory.

Choosing one of the last files selected



Call the file manager.



Display the last 15 files selected: Press the LAST FILES soft key.

Use the arrow keys to move the highlight to the file you wish to select:




Moves the highlight up and down within a window.



To select the file, press the SELECT soft key, or



Press the ENT key.



Deleting a file

**Caution: Data may be lost!**

Once you delete files they cannot be undeleted!

- ▶ Move the highlight to the file you want to delete.



- ▶ To select the erasing function, press the DELETE soft key. The TNC inquires whether you really intend to delete the file
- ▶ To confirm, press the YES soft key;
- ▶ To cancel deletion, press the NO soft key.

Deleting a directory

**Caution: Data may be lost!**

Once you delete directories they cannot be undeleted!








- ▶ Move the highlight to the directory you want to delete.



- ▶ To select the erasing function, press the DELETE soft key. The TNC inquires whether you really intend to delete the directory and all its subdirectories and files
- ▶ To confirm, press the YES soft key;
- ▶ To cancel deletion, press the NO soft key.



Marking files

Marking function	Soft key
Move cursor upward	
Move cursor downward	
Tag a single file	
Tag all files in the directory	
Untag a single file	
Untag all files	
Copy all tagged files	



Some functions, such as copying or erasing files, can not only be used for individual files, but also for several files at once. To tag several files, proceed as follows:

Move the highlight to the first file.



To display the marking functions, press the TAG soft key.



Mark a file by pressing the TAG FILE soft key.



Move the highlight to the next file you wish to tag:
Only works via soft keys. Do not use the arrow keys!



To mark further files, press the TAG FILE soft key, etc.



To copy the tagged files, press the COPY TAG soft key, or



Delete the tagged files by pressing END to end the marking function, and then the DELETE soft key to delete the tagged files.



Tagging files with shortcuts

- ▶ Move the highlight to the first file.
- ▶ Press and hold the CTRL key.
- ▶ Use the arrow keys to move the cursor frame to other files
- ▶ Press the spacebar to tag a file.
- ▶ When you have tagged all desired files: release the CTRL key and perform the desired file operation.



CTRL+A tags all of the files in the current directory.

If you press the SHIFT key instead of the CTRL key, the TNC automatically tags all files that you select with the arrow keys.

Renaming a file

- ▶ Move the highlight to the file you want to rename.



- ▶ Select the renaming function.
- ▶ Enter the new file name; the file type cannot be changed.
- ▶ To execute renaming, press the ENT key.

Additional functions

Protecting a file / Canceling file protection

- ▶ Move the highlight to the file you want to protect.



- ▶ To select the additional functions, press the MORE FUNCTIONS soft key.



- ▶ To activate file protection, press the PROTECT soft key. The file now has status P.



- ▶ To cancel file protection, press the UNPROTECT soft key.

Connecting/removing a USB device

- ▶ Move the highlight to the left window.



- ▶ To select the additional functions, press the MORE FUNCTIONS soft key.



- ▶ Search for a USB device.

- ▶ In order to remove the USB device, move the cursor to the USB device.



- ▶ Remove the USB device.

For more information: See "USB devices on the TNC (FCL 2 function)" on page 137.



Adapting the file manager

You open the menu for adapting the file manager either by clicking the path name or with soft keys:

- ▶ Select the file manager: Press the PGM MGT key
- ▶ Select the third soft-key row
- ▶ Press the MORE FUNCTIONS soft key
- ▶ Press the OPTIONS soft key: the TNC displays the menu for adapting the file manager
- ▶ Use the arrow keys to move the highlight to the desired setting
- ▶ Activate or deactivate the desired setting with the space bar

You can adapt the file manager as follows:

■ Bookmarks

You can use bookmarks to manage your favorite directories. You can add or delete the current directory to or from the list, or delete all bookmarks. All directories that you have added appear in the bookmark list, making them available for rapid selection

■ View


In the View menu item you specify the type of information the TNC is to display in the file window

■ Date format

In the Date format menu you specify the format in which the TNC displays the date in the **Changed** column

■ Settings

If the cursor is in the directory tree: specify if the TNC is to switch windows when the right arrow key is pressed, or if the TNC is to open any subdirectories



Working with shortcuts

Shortcuts are commands triggered by certain key combinations. Shortcuts always perform a function that you can also trigger via soft key. The following shortcuts are available:

- CTRL+S:
Select a file (see also "Selecting drives, directories and files" on page 119)
- CTRL+N:
Open a dialog box in order to create a new file or directory (see also "Creating a new file (only possible on the drive TNC:\)" on page 122)
- CTRL+C:
Open a dialog box in order to copy selected files or directories (see also "Copying a single file" on page 123)
- CTRL+R:
Open a dialog box in order to rename a selected file or directory (see also "Renaming a file" on page 130)
- DEL key:
Open a dialog box in order to delete selected files or directories (see also "Deleting a file" on page 127)
- CTRL+O:
Open an "Open with" dialog box (see also "Select smarT.NC programs" on page 121)
- CTRL+W:
Switch the split screen layout (see also "Data transfer to or from an external data medium" on page 134)
- CTRL+E:
Show functions for adapting the file manager (see also "Adapting the file manager" on page 132)
- CTRL+M:
Connect USB device (see also "USB devices on the TNC (FCL 2 function)" on page 137)
- CTRL+K:
Disconnect USB device (see also "USB devices on the TNC (FCL 2 function)" on page 137)
- SHIFT + UP or DOWN arrow key:
Mark several files or directories (see also "Marking files" on page 128)
- ESC key:
Cancel the function.



Data transfer to or from an external data medium



Before you can transfer data to an external data medium, you must set up the data interface (see “Setting the Data Interfaces” on page 547).

Depending on the data transfer software you use, problems can occur occasionally when you transmit data over a serial interface. They can be overcome by repeating the transmission.



Call the file manager.



Select the screen layout for data transfer: press the WINDOW soft key. In the left half of the screen the TNC shows all files in the current directory. In the right half of the screen it shows all files saved in the root directory (TNC:\).

Use the arrow keys to highlight the file(s) that you want to transfer:




Moves the highlight up and down within a window



Moves the highlight from the left to the right window, and vice versa.

If you wish to copy from the TNC to the external data medium, move the highlight in the left window to the file to be transferred.



If you wish to copy from the external data medium to the TNC, move the highlight in the right window to the file to be transferred.



To select another drive or directory: press the soft key for choosing the directory. The TNC opens a pop-up window. Select the desired directory in the pop-up window by using the arrow keys and the ENT key.



Transfer a single file: Press the COPY soft key, or



Transfer several files: Press the TAG soft key (in the second soft-key row, see "Marking files", page 128).

Confirm with the OK soft key or with the ENT key. A status window appears on the TNC, informing about the copying progress, or



To end data transfer, move the highlight into the left window and then press the WINDOW soft key. The standard file manager window is displayed again.



To select another directory in the split-screen display, press the soft key for choosing the directory. Select the desired directory in the pop-up window by using the arrow keys and the ENT key.



The TNC in a network



To connect the Ethernet card to your network, see "Ethernet Interface", page 551.

To connect the iTNC with Windows XP to your network, see "Network Settings", page 622.

The TNC logs error messages during network operation see "Ethernet Interface", page 551.

If the TNC is connected to a network, the directory window displays up to 7 additional drives in the directory window to the left (see figure). All the functions described above (selecting a drive, copying files, etc.) also apply to network drives, provided that you have been granted the corresponding rights.


Connecting and disconnecting a network drive



- ▶ To select the program management: Press the PGM MGT key. If necessary, press the WINDOW soft key to set up the screen as it is shown at the upper right.



- ▶ To manage the network drives: Press the NETWORK soft key (second soft-key row). In the right-hand window the TNC shows the network drives available for access. With the soft keys described below you can define the connection for each drive.



Function	Soft key
Establish network connection. If the connection is active, the TNC shows an M in the Mnt column. You can connect up to 7 additional drives with the TNC.	MOUNT DEVICE
Delete the network connection.	UNMOUNT DEVICE
Automatically establish network connection whenever the TNC is switched on. The TNC shows an A in the Auto column if the connection is established automatically.	AUTO MOUNT
Do not establish network connection automatically when the TNC is switched on.	NO AUTO MOUNT

It may take some time to mount a network device. At the upper right of the screen the TNC displays **[READ DIR]** to indicate that a connection is being established. The maximum transmission speed is 2 to 5 Mbps, depending on the type of file being transferred and how busy the network is.



USB devices on the TNC (FCL 2 function)

Backing up data from or loading onto the TNC is especially easy with USB devices. The TNC supports the following USB block devices:

- Floppy disk drives with the FAT/VFAT file system
- Memory sticks with the FAT/VFAT file system
- Hard disks with the FAT/VFAT file system
- CD-ROM drives with the Joliet (ISO 9660) file system

The TNC automatically detects these types of USB devices when connected. The TNC does not support USB devices with other file systems (such as NTFS). The TNC displays the **USB: TNC does not support device** error message when such a device is connected.



The TNC also displays the **USB: TNC does not support device** error message if you connect a USB hub. In this case, simply acknowledge the message with the CE key.

In theory, you should be able to connect all USB devices with the file systems mentioned above to the TNC. If you nevertheless encounter problems, please contact HEIDENHAIN.

The USB devices appear as separate drives in the directory tree, so you can use the file-management functions described in the earlier chapters correspondingly.



Your machine tool builder can assign permanent names for USB devices. Refer to your machine manual.



3.4 Working with the File Manager

To remove a USB device, proceed as follows:



- ▶ Press the PGM MGT soft key to call the file manager.



- ▶ Select the left window with the arrow key.



- ▶ Use the arrow keys to select the USB device to be removed.



- ▶ Scroll through the soft-key row.



- ▶ Select additional functions.



- ▶ Select the function for removing USB devices. The TNC removes the USB device from the directory tree.



- ▶ Exit the file manager.

In order to re-establish a connection with a USB device that has been removed, press the following soft key:



- ▶ Select the function for reconnection of USB devices.





4

**Programming:
Programming Aids**



4.1 Adding Comments

Function

You can add comments to any desired block in the part program to explain program steps or make general notes.



If the TNC cannot show the entire comment on the screen, the >> sign is displayed.

The last character in a comment block must not have any tilde (~).

There are three possibilities for adding comments:

Entering comments during programming


- ▶ Enter the data for a program block, then press the semicolon key “;” on the alphabetic keyboard—the TNC displays the dialog prompt **COMMENT?**
- ▶ Enter your comment and conclude the block by pressing the END key.

Inserting comments after program entry






- ▶ Select the block to which a comment is to be added
- ▶ Select the last word in the block with the right arrow key: A semicolon appears at the end of the block and the TNC displays the dialog prompt **COMMENT ?**
- ▶ Enter your comment and conclude the block by pressing the END key.

Entering a comment in a separate block

- ▶ Select the block after which the comment is to be inserted.
- ▶ Initiate the programming dialog with the semicolon key (;) on the alphabetic keyboard
- ▶ Enter your comment and conclude the block by pressing the END key.



Functions for editing of the comment

Function	Soft key
Jump to beginning of comment.	
Jump to end of comment.	
Jump to the beginning of a word. Words must be separated by a space.	
Jump to the end of a word. Words must be separated by a space.	
Switch between insert mode and overwrite mode.	



4.2 Structuring Programs


Definition and applications

This TNC function enables you to comment part programs in structuring blocks. Structuring blocks are short texts with up to 37 characters and are used as comments or headlines for the subsequent program lines.

With the aid of appropriate structuring blocks, you can organize long and complex programs in a clear and comprehensible manner.

This function is particularly convenient if you want to change the program later. Structuring blocks can be inserted into the part program at any point. They can also be displayed in a separate window, and edited or added to, as desired.

The inserted structure items are managed by the TNC in a separate file (extension: .SEC.DEF). This speeds navigation in the program structure window.



Displaying the program structure window / Changing the active window



- ▶ To display the program structure window, select the screen display PROGRAM + SECTS.



- ▶ To change the active window, press the "Change window" soft key.

Inserting a structuring block in the (left) program window.

- ▶ Select the block after which the structuring block is to be inserted.



- ▶ Press the INSERT SECTION soft key or the * key on the ASCII keyboard.

- ▶ Enter the structuring text with the alphabetic keyboard



- ▶ If necessary, change the structure depth with the soft key.

Selecting blocks in the program structure window

If you are scrolling through the program structure window block by block, the TNC at the same time automatically moves the corresponding NC blocks in the program window. This way you can quickly skip large program sections.



4.3 Integrated Pocket Calculator

Operation


The TNC features an integrated pocket calculator with the basic mathematical functions.

- ▶ Use the CALC key to show and hide the on-line pocket calculator.
- ▶ The calculator is operated with short commands through the alphabetic keyboard. The commands are shown in a special color in the calculator window:

Mathematical function	Command (key)
Addition	+
Subtraction	-
Multiplication	*
Division	:
Sine	S
Cosine	C
Tangent	T
Arc sine	AS
Arc cosine	AC
Arc tangent	AT
Powers	^
Square root	Q
Inversion	/
Calculations in parentheses	()
Pi (3.14159265359)	P
Display result	=

To transfer the calculated value into the program

- ▶ Use the arrow keys to select the word into which the calculated value is to be transferred
- ▶ Superimpose the on-line calculator by pressing the CALC key and perform the desired calculation
- ▶ Press the actual-position-capture key for the TNC to transfer the calculated value into the active input box and to close the calculator



4.4 Programming Graphics

Generating / not generating graphics during programming

While you are writing the part program, you can have the TNC generate a 2-D pencil-trace graphic of the programmed contour.

- ▶ To switch the screen layout to displaying program blocks to the left and graphics to the right, press the SPLIT SCREEN key and PGM + GRAPHICS soft key.



- ▶ Set the AUTO DRAW soft key to ON. While you are entering the program lines, the TNC generates each path contour you program in the graphics window in the right screen half

If you do not wish to have the TNC generate graphics during programming, set the AUTO DRAW soft key to OFF.

Even when AUTO DRAW ON is active, graphics are not generated for program section repeats.

Generating a graphic for an existing program.

- ▶ Use the arrow keys to select the block up to which you want the graphic to be generated, or press GOTO and enter the desired block number.




- ▶ To generate graphics, press the RESET + START soft key.

Additional functions:

Function	Soft key
Generate a complete graphic	
Generate programming graphic blockwise	
Generate a complete graphic or complete it after RESET + START.	
Stop the programming graphics. This soft key only appears while the TNC is generating the interactive graphics.	
Redraw the programming graphics, for example if lines were deleted by intersections	



The programming graphics does not account for tilting functions; in such cases the TNC generates an error message (if applicable).



Block number display ON/OFF



- ▶ Shift the soft-key row: see figure
- ▶ To show block numbers: Set the SHOW OMIT BLOCK NR. soft key to SHOW.
- ▶ To hide block numbers: Set the SHOW OMIT BLOCK NR. soft key to OMIT.



Erasing the graphic



- ▶ Shift the soft-key row: see figure
- ▶ Erase graphic: Press CLEAR GRAPHICS soft key.



Magnifying or reducing a detail

You can select the graphics display, by selecting a detail with the frame overlay. You can now magnify or reduce the selected detail.

- ▶ Select the soft-key row for detail magnification/reduction (second row, see figure)



The following functions are available:

Function	Soft key
Show and move the frame overlay. Press and hold the desired soft key to move the frame overlay	
Reduce the frame overlay—press and hold the soft key to reduce the detail	
Enlarge the frame overlay—press and hold the soft key to magnify the detail	



- ▶ Confirm the selected area with the WINDOW DETAIL soft key.

With the WINDOW BLK FORM soft key, you can restore the original section.



4.5 3-D Line Graphics (FCL2 Function)

Function


Use the 3-D line graphics to have the TNC show the programmed traverse paths in three dimensions. A powerful zoom function is available for recognizing details quickly.

You should especially use the 3-D line graphics to inspect programs created externally for irregularities before machining, in order to avoid undesirable traces of the machining process on the workpiece. Such traces of machining can occur when points are output incorrectly by the postprocessor.

In order to find the error location quickly, the TNC shows the currently active block of the 3-D line graphics in a different color in the left window (default setting: red).

You can use the 3-D line graphics in Split-Screen mode or in Full-Screen mode:












- ▶ To show program blocks to the left and 3-D line graphics to the right, press the SPLIT SCREEN key and PROGRAM + 3D LINES soft key.
- ▶ To show the 3-D line graphics on the entire screen, press the SPLIT SCREEN key and 3D LINES soft key.



Functions of the 3-D line graphics

Function	Soft key
Show and move the zoom frame up. Press and hold the soft key to move the frame	
Show and move the zoom frame down. Press and hold the soft key to move the frame	
Show and move the zoom frame to the left. Press and hold the soft key to move the frame	
Show and move the zoom to the right. Press and hold the soft key to move the frame	
Enlarge the frame overlay—press and hold the soft key to magnify the detail	
Reduce the frame overlay—press and hold the soft key to reduce the detail	
Reset detail magnification so that the workpiece is displayed as it was programmed with BLK FORM.	
Select the isolated detail	



Function	Soft key
Rotate workpiece clockwise	
Rotate workpiece counterclockwise	
Tilt workpiece backward	
Tilt workpiece forward	
Magnify the graphic stepwise. If the view is magnified, the TNC shows the letter Z in the footer of the graphic window.	
Reduce the graphic stepwise. If the view is reduced, the TNC shows the letter Z in the footer of the graphic window.	
Show workpiece at original size	
Show workpiece in the last active view	
Show/hide programmed end points with a dot on the line	
Do or do not highlight the selected NC block of the 3-D line graphics in the left window	
Do or do not show block numbers	



You can also use the mouse with the 3-D line graphics. The following functions are available:

- ▶ In order to rotate the wire model shown in three dimensions: Hold the right mouse button down and move the mouse. The TNC displays a coordinate system showing the currently active orientation of the workpiece. After you release the right mouse button, the TNC orients the workpiece to the defined orientation
- ▶ In order to shift the wire model shown: Hold the center mouse button or the wheel button down and move the mouse. The TNC shifts the workpiece in the corresponding direction. After you release the center mouse button, the TNC shifts the workpiece to the defined position
- ▶ In order to zoom in on a certain area with the mouse: Draw a rectangular zoom area while holding the left mouse button down. After you release the left mouse button, the TNC zooms in on the defined area of the workpiece
- ▶ In order to quickly zoom in and out with the mouse: Rotate the wheel button forward or backward

Highlighting NC blocks in the graphics



- ▶ Shift the soft-key row.



- ▶ To highlight the NC block selected in the left window in the 3-D line graphics in the right window, set the MARK THIS ELEMENT OFF / ON soft key to ON
- ▶ To not highlight the NC block selected in the left window in the 3-D line graphics in the right window, set the MARK THIS ELEMENT OFF / ON soft key to OFF

Block number display ON/OFF



- ▶ Shift the soft-key row.



- ▶ To show block numbers: Set the SHOW OMIT BLOCK NR. soft key to SHOW.
- ▶ To hide block numbers: Set the SHOW OMIT BLOCK NR. soft key to OMIT.

Erasing the graphic



- ▶ Shift the soft-key row.



- ▶ Erase graphic: Press CLEAR GRAPHICS soft key.



4.6 Immediate Help for NC Error Messages

Displaying error messages

The TNC automatically generates error messages when it detects problems such as

- Incorrect data input
- Logical errors in the program
- Contour elements that are impossible to machine
- Incorrect use of touch probes


An error message that contains a program block number was caused by an error in the indicated block or in the preceding block. The TNC error messages can be canceled with the CE key, after the cause of the error has been removed. Error messages causing a control crash must be acknowledged by pressing the END key. The TNC will restart.

If you require more information on a particular error message, press the HELP key. A pop-up window then appears, in which the cause of the error is explained and suggestions are made for correcting the error.

Display HELP

HELP

- ▶ To display Help, press the HELP key.
- ▶ Read the cause of error and any suggestions for possible remedies. The TNC may show additional information that can be helpful to trained HEIDENHAIN personnel during troubleshooting. Close the Help window with the CE key, thus canceling the error message.
- ▶ Remove the cause of the error as described in the Help window



4.7 List of All Current Error Messages

Function

With this function you can show a pop-up window in which the TNC shows all current error messages. The TNC shows errors both from the NC as well as those from the machine tool builder.

Show error list


You can call the list as soon as at least one error message is present:

ERR

- ▶ To display the list, press the ERR key.
- ▶ You can select one of the current error messages with the arrow keys
- ▶ With the CE key or the DEL key you can delete the error message from the pop-up window momentarily selected. When you delete the last error message, the pop-up window closes as well
- ▶ To close the pop-up window, press the ERR key again. Current error messages are retained



Parallel to the error list you can also view the respective help text in a separate window: Press the HELP key.



Window contents

Column	Meaning
Number	Error number (–1: no error number defined), issued by HEIDENHAIN or your machine tool builder
Class	<p>Error class. Defines how the TNC processes this error.</p> <ul style="list-style-type: none"> ■ ERROR Collective error class for errors that can cause various error reactions depending on the condition of the machine or the active operating mode) ■ FEED HOLD The feed-rate release is canceled ■ PGM HOLD The program run is interrupted (the control-in-operation symbol blinks) ■ PGM ABORT The program run is interrupted (INTERNAL STOP) ■ EMERG. STOP EMERGENCY STOP is set off ■ RESET TNC executes a system restart ■ WARNING Warning message, program run resumes ■ INFO Info message, program run resumes
Group	<p>Group. Specifies from which section of the operating system software the error message was generated</p> <ul style="list-style-type: none"> ■ OPERATING ■ PROGRAMMING ■ PLC ■ GENERAL
Error message	Respective error text displayed by the TNC



Calling the TNCguide help system

You can call the TNC's help system via soft key. Immediately the help system shows you the same error explanation that you receive by pressing the HELP soft key.



If your machine manufacturer also provides a help system, the TNC shows an additional MACHINE MANUFACTURER soft key with which you can call this separate help system. There you will find further, more detailed information on the error message concerned.



- ▶ Call the help for HEIDENHAIN error messages.



- ▶ Call the help for HEIDENHAIN error messages, if available



Generating service files

You can use this function to save all files relevant to service purposes in a ZIP file. The appropriate data from the NC and PLC are saved by the TNC in the file **TNC:\service\service<xxxxxxx>.zip**. The TNC determines the name of the file automatically. The character string **<xxxxxxx>** clearly indicates the system time.

The following possibilities exist for generating a service file:

- By pressing the SAVE SERVICE FILES soft key after you have pressed the ERR key
- Externally via the data transmission software TNCremoNT
- If the NC software crashes due to a serious error, the TNC automatically generates a service file
- In addition, your machine tool builder can have service files be generated automatically for PLC error messages.

The following data (and other information) is saved in the service file:

- Log
- PLC log
- Selected files (*.H/*.I/*.T/*.TCH/*.D) of all operating modes
- *.SYS files
- Machine parameters
- Information and log files of the operating system (can be partially activated via MP7691)
- Contents of PLC memory
- NC macros defined in PLC:\NCMACRO.SYS
- Information about the hardware

In addition, the service department can help you save the control file **TNC:\service\userfiles.sys** in ASCII format. The TNC will then include the data defined there in the ZIP file.



The service file contains all NC data needed for troubleshooting. By passing on the service file you declare your consent to your machine tool builder or DR. JOHANNES HEIDENHAIN GmbH to use these data for diagnostic purposes.



4.8 The Context-Sensitive Help System TNCguide (FCL3 Function)

Function



The TNCguide help system is only available if your control hardware has at least 256 MB RAM and FCL3 is enabled.

The **TNCguide** context-sensitive help system includes the user documentation in HTML format. The TNCguide is called with the HELP key, and the TNC often immediately displays the information specific to the condition from which the help was called (context-sensitive call). Even if you are editing an NC block and press the HELP key, you are usually brought to the exact place in the documentation that describes the corresponding function.

The English and German documentation is shipped as standard with each NC software level. HEIDENHAIN provides the remaining conversational languages for cost-free download as soon as the respective translations are available (see "Downloading current help files" on page 159).



The TNC always tries to start the TNCguide in the language that you have selected as the conversational language on your TNC. If the files with this language are not yet available on your TNC, it automatically opens the English version.


The following user documentation is available in the TNCguide:

- Conversational Programming User's Manual (**BHBKlartext.chm**)
- DIN/ISO User's Manual (**BHBiso.chm**)
- User's Manual for Cycles (**BHBcycles.chm**)
- User's Manual for smarT.NC (**BHBsmart.chm**) (same format as a "Pilot")
- List of All Error Messages (**errors.chm**)

In addition, the **main.chm** "book" file is available, with the contents of all existing .chm files.



As an option, your machine tool builder can embed machine-specific documentation in the **TNCguide**. These documents then appear as a separate book in the **main.chm** file.



Working with the TNCguide

Calling the TNCguide


There are several ways to start the TNCguide:

- ▶ Press the HELP key if the TNC is not already showing an error message
- ▶ Click the help symbol at the lower right of the screen beforehand, then click the appropriate soft keys
- ▶ Use the file manager to open a help file (.chm file). The TNC can open any .chm file, even if it is not saved on the TNC's hard disk



If one or more error messages are waiting for your attention, the TNC shows the help directly associated with the error messages. To start the **TNCguide**, you first have to acknowledge all error messages.

When the help system is called on the programming station or the dual-processor version, the TNC starts the internally defined standard browser (usually the Internet Explorer), and on the single-processor version a browser adapted by HEIDENHAIN.



For many soft keys there is a context-sensitive call through which you can go directly to the description of the soft key's function. This functionality requires using a mouse. Proceed as follows:

- ▶ Select the soft-key row containing the desired soft key
- ▶ Click with the mouse on the help symbol that the TNC displays just above the soft-key row: The mouse pointer turns into a question mark
- ▶ Move the question mark to the soft key for which you want an explanation, and click: The TNC opens the TNCguide. If no specific part of the help is assigned to the selected soft key, the TNC opens the book file **main.chm**, in which you can use the search function or the navigation to find the desired explanation manually

Even if you are editing an NC block, context-sensitive help is available:

- ▶ Select any NC block
- ▶ Use the arrow keys to move the cursor to the block
- ▶ Press the HELP key: The TNC starts the help system and shows a description for the active function (does not apply to miscellaneous functions or cycles that were integrated by your machine tool builder)



Navigating in the TNCguide









It's easiest to use the mouse to navigate in the TNCguide. A table of contents appears on the left side of the screen. By clicking the rightward pointing triangle you open subordinate sections, and by clicking the respective entry you open the individual pages. It is operated in the same manner as the Windows Explorer.

Linked text positions (cross references) are shown underlined and in blue. Clicking the link opens the associated page.









Of course you can also operate the TNCguide through keys and soft keys. The following table contains an overview of the corresponding key functions.



The key functions described below are available only on the single-processor version of the TNC.

Function	Soft key
<ul style="list-style-type: none"> ■ If the table of contents at left is active: Select the entry above it or below it ■ If the text window at right is active: Move the page downward or upward if texts or graphics are not shown completely 	 
<ul style="list-style-type: none"> ■ If the table of contents at left is active: Open a branch of the table of contents. If the branch is at its end, jump into the window at right ■ If the text window at right is active: No function 	
<ul style="list-style-type: none"> ■ If the table of contents at left is active: Close a branch of the table of contents ■ If the text window at right is active: No function 	
<ul style="list-style-type: none"> ■ If the table of contents at left is active: Use the cursor key to show the selected page ■ If the text window at right is active: If the cursor is on a link, jump to the linked page 	
<ul style="list-style-type: none"> ■ If the table of contents at left is active: Switch the tab between the display of the table of contents, display of the subject index, and the full-text search function and switching to the screen half at right ■ If the text window at right is active: Jump back to the window at left 	
<ul style="list-style-type: none"> ■ If the table of contents at left is active: Select the entry above it or below it ■ If the text window at right is active: Jump to the next link 	 



Function	Soft key
Select the page last shown	
Page forward if you have used the "select page last shown" function.	
Move up by one page	
Move down by one page	
Display or hide table of contents	
Switch between full-screen display and reduced display. With the reduced display you can see some of the rest of the TNC window	
The focus is switched internally to the TNC application so that you can operate the control when the TNCguide is open. If the full screen is active, the TNC reduces the window size automatically before the change of focus	
Close the TNCguide	



Subject index

The most important subjects in the Manual are listed in the subject index (**Index** tab). You can select them directly by mouse or with the cursor keys.

The left side is active.



- ▶ Select the **Index** tab
- ▶ Activate the **Keyword** input field
- ▶ Enter the word for the desired subject and the TNC synchronizes the index and creates a list in which you can find the subject more easily, or
- ▶ Use the arrow key to highlight the desired keyword.
- ▶ Use the ENT key to call the information on the selected keyword.

Full-text search

In the **Find** tab you can search the entire TNCguide for a specific word.

The left side is active.




- ▶ Select the **Find** tab
- ▶ Activate the **Find:** input field
- ▶ Enter the desired word and confirm with the ENT key: the TNC lists all sources containing the word
- ▶ Use the arrow key to highlight the desired source
- ▶ Press the ENT key to go to the selected source



The full-text search only works for single words.

If you activate the **Search only in titles** function (by mouse or by using the cursor and the space key), the TNC searches only through headings and ignores the body text.



Downloading current help files

You'll find the help files for your TNC software on the HEIDENHAIN home page www.heidenhain.de under:

- ▶ Services and Documentation
- ▶ Software
- ▶ iTNC 530 help system
- ▶ NC software number of your TNC, for example **34049x-05**
- ▶ Select the desired language, for example English: You will see a ZIP file with the appropriate help files
- ▶ Download the ZIP file and unzip it
- ▶ Move the unzipped CHM files to the TNC in the **TNC:\tncguide\en** directory or into the respective language subdirectory (see also the following table)



If you want to use TNCremoNT to transfer the CHM files to the TNC, then in the **Extras>Configuration>Mode>Transfer in binary format** menu item you have to enter the extension **.CHM**.

Language	TNC directory
German	TNC:\tncguide\de
English	TNC:\tncguide\en
Czech	TNC:\tncguide\cs
French	TNC:\tncguide\fr
Italian	TNC:\tncguide\it
Spanish	TNC:\tncguide\es
Portuguese	TNC:\tncguide\pt
Swedish	TNC:\tncguide\sv
Danish	TNC:\tncguide\da
Finnish	TNC:\tncguide\fi
Dutch	TNC:\tncguide\nl
Polish	TNC:\tncguide\pl
Hungarian	TNC:\tncguide\hu
Russian	TNC:\tncguide\ru
Chinese (simplified)	TNC:\tncguide\zh
Chinese (traditional)	TNC:\tncguide\zh-tw
Slovenian (software option)	TNC:\tncguide\s1



Language	TNC directory
Norwegian	<code>TNC:\tncguide\no</code>
Slovak	<code>TNC:\tncguide\sk</code>
Latvian	<code>TNC:\tncguide\lv</code>
Korean	<code>TNC:\tncguide\kr</code>
Estonian	<code>TNC:\tncguide\et</code>
Turkish	<code>TNC:\tncguide\tr</code>
Romanian	<code>TNC:\tncguide\ro</code>
Lithuanian	<code>TNC:\tncguide\lt</code>





5

Programming: Tools



5.1 Entering Tool-Related Data

Feed rate F

The feed rate **F** is the speed (in millimeters per minute or inches per minute) at which the tool center point moves. The maximum feed rates can be different for the individual axes and are set in machine parameters.

Input

You can enter the feed rate in the **T** block and in every positioning block (see "Programming tool movements in DIN/ISO format" on page 106). In millimeter-programs you enter the feed rate in mm/min, and in inch-programs, for reasons of resolution, in 1/10 inch/min.

Rapid traverse


If you wish to program rapid traverse, enter **G00**.

Duration of effect

A feed rate entered as a numerical value remains in effect until a block with a different feed rate is reached. If the new feed rate is **G00** (rapid traverse), the last programmed feed rate is once again valid after the next block with **G01**.

Changing during program run

You can adjust the feed rate during program run with the feed-rate override knob F.



Spindle speed S

The spindle speed S is entered in revolutions per minute (rpm) in a **T** block. Instead, you can also define the cutting speed Vc in m/min.

Programmed change

In the part program, you can change the spindle speed in a **T** block by entering the spindle speed only:

S

- ▶ To program the spindle speed, press the S key on the alphabetic keyboard.
- ▶ Enter the new spindle speed.

Changing during program run

You can adjust the spindle speed during program run with the spindle-speed override knob S.



5.2 Tool Data

Requirements for tool compensation

You usually program the coordinates of path contours as they are dimensioned in the workpiece drawing. To allow the TNC to calculate the tool center path—i.e. the tool compensation—you must also enter the length and radius of each tool you are using.

Tool data can be entered either directly in the part program with **G99** or separately in a tool table. In a tool table, you can also enter additional data for the specific tool. The TNC will consider all the data entered for the tool when executing the part program.

Tool numbers and tool names

Each tool is identified by a number between 0 and 30000. If you are working with tool tables, you can also enter a tool name for each tool. Tool names can have up to 16 characters.



The tool number 0 is automatically defined as the zero tool with the length $L=0$ and the radius $R=0$. In tool tables, tool T0 should also be defined with $L=0$ and $R=0$.

Tool length L

You should always enter the tool length L as an absolute value based on the tool reference point. The entire tool length is essential for the TNC in order to perform numerous functions involving multi-axis machining.

Tool radius R

You can enter the tool radius R directly.



Delta values for lengths and radii

Delta values are offsets in the length and radius of a tool.

A positive delta value describes a tool oversize (**DL**, **DR**, **DR2**>0). If you are programming the machining data with an allowance, enter the oversize value in the **T** block of the part program.

A negative delta value describes a tool undersize (**DL**, **DR**, **DR2**<0). An undersize is entered in the tool table for wear.


Delta values are usually entered as numerical values. In a **T** block, you can also assign the values to Q parameters.

Input range: You can enter a delta value with up to ± 99.999 mm.



Delta values from the tool table influence the graphical representation of the **tool**. The representation of the **workpiece** remains the same in the simulation.

Delta values from the **T** block change the represented size of the **workpiece** during the simulation. The simulated **tool size** remains the same.



Entering tool data into the program

The number, length and radius of a specific tool is defined in the **G99** block of the part program.

► To select tool definition, press the TOOL DEF key.



- **Tool number:** Each tool is uniquely identified by its tool number.
- **Tool length:** Compensation value for the tool length
- **Tool radius:** Compensation value for the tool radius



In the programming dialog, you can transfer the value for tool length and tool radius directly into the input line by pressing the desired axis soft key.

Example

```
N40 G99 T5 L+10 R+5 *
```



Entering tool data in the table

You can define and store up to 30 000 tools and their tool data in a tool table. In Machine Parameter 7260, you can define how many tools are to be stored by the TNC when a new table is set up. Also see the Editing Functions later in this chapter. In order to be able to assign various compensation data to a tool (indexing the tool number), MP7262 must not be equal to 0.

You must use tool tables if

- you wish to use indexed tools such as stepped drills with more than one length compensation value (see page 172)
- your machine tool has an automatic tool changer
- you want to measure tools automatically with the TT 130 touch probe (see the Touch Probe Cycles User's Manual)
- you want to rough-mill the contour with Cycle G122, (see "User's Manual for Cycles, ROUGH-OUT")
- you want to work with Cycles 251 to 254 (see "User's Manual for Cycles," Cycles 251 to 254)
- you want to work with automatic cutting data calculations.

Tool table: Standard tool data

Abbr.	Inputs	Dialog
T	Number by which the tool is called in the program (e.g. 5, indexed: 5.2).	-
NAME	Name by which you call the tool in the program. Input range: 16 characters max., only capital letters, no space characters)	Tool name?
L	Compensation value for tool length L Input range in mm: -99999.9999 to +99999.9999 Input range in inches: -3936.9999 to +3936.9999	Tool length?
R	Compensation value for the tool radius R Input range in mm: -99999.9999 to +99999.9999 Input range in inches: -3936.9999 to +3936.9999	Tool radius R?
R2	Tool radius 2 for toroid cutters (only for 3-D radius compensation or graphical representation of a machining operation with spherical or toroid cutters) Input range in mm: -99999.9999 to +99999.9999 Input range in inches: -3936.9999 to +3936.9999	Tool radius R2?
DL	Delta value for tool length L. Input range in mm: -99.9999 to +99.9999 Input range in inches: -3.937 to +3.937	Tool length oversize?



Abbr.	Inputs	Dialog
DR	Delta value for tool radius R. Input range in mm: -99.9999 to +99.9999 Input range in inches: -3.937 to +3.937	Tool radius oversize?
DR2	Delta value for tool radius R2. Input range in mm: -99.9999 to +99.9999 Input range in inches: -3.937 to +3.937	Tool radius oversize R2?
LCUTS	Tooth length of the tool for Cycle 22. Input range in mm: 0 to +99999.9999 Input range in inches: 0 to +3936.9999	Tooth length in the tool axis?
ANGLE	Maximum plunge angle of the tool for reciprocating plunge-cut in Cycles 22 and 208 and 25x. Input range: 0 to 90°	Maximum plunge angle?
TL	Set tool lock (TL: for Tool Locked) Input range: L or space character	Tool locked? Yes = ENT / No = NO ENT
RT	Number of a replacement tool, if available (RT: for Replacement Tool; see also TIME2). Input range: 0 to 65535	Replacement tool?
TIME1	Maximum tool life in minutes. This function can vary depending on the individual machine tool. Your machine manual provides more information. Input range: 0 to 9999 minutes	Maximum tool age?
TIME2	Maximum tool life in minutes during TOOL CALL: If the current tool age exceeds this value, the TNC changes the tool during the next TOOL CALL (see also CUR.TIME). Input range: 0 to 9999 minutes	Maximum tool age for TOOL CALL?
CUR.TIME	Current age of the tool in minutes: The TNC automatically counts the current tool life (CUR.TIME). A starting value can be entered for used tools. Input range: 0 to 99999 minutes	Current tool life?
DOC	Comment on the tool. Input range: 16 characters max.	Tool description?
PLC	Information on this tool that is to be sent to the PLC. Input range: 8 characters bit-coded	PLC status?
PLC-VAL	Value of this tool that is to be sent to the PLC. Input range: -99999.9999 to +99999.9999	PLC value?



Abbr.	Inputs	Dialog
PTYP	Tool type for evaluation in the pocket table. Input range: 0 to +99	Tool type for pocket table?
NMAX	Limits the spindle speed for this tool. The programmed value is monitored (error message) as well as an increase in the shaft speed via the potentiometer. Function inactive: Enter – Input range: 0 to +99999, if function not active: enter –	Maximum speed [rpm]?
LIFTOFF	Definition of whether the TNC should retract the tool in the direction of the positive tool axis at an NC stop in order to avoid leaving dwell marks on the contour. If Y is entered, the TNC retracts the tool from the contour by up to 30 mm, provided that this function was activated in the NC program with M148 (see "Automatically retract tool from the contour at an NC stop: M148" on page 329) Input : Y and N	Retract tool Y/N ?
P1 ... P3	Machine-dependent function: Transfer of a value to the PLC. Refer to your machine manual Input range: -99999.9999 to +99999.9999	Value?
KINEMATIC	Machine-dependent function: Kinematics description for vertical milling heads, which the TNC adds to the active machine kinematics. Assign available kinematic descriptions by using the ASSIGN KINEMATICS soft key (see also "Tool-carrier kinematics" on page 174) Input range: 16 characters max.	Additional kinematic description?
T-ANGLE	Point angle of the tool. Is used by the Centering cycle (Cycle 240) in order to calculate the centering depth from the diameter entry Input range: -180 to +180°	Point angle (Type DRILL+CSINK)?
PITCH	Thread pitch of the tool (currently without function) Input range in mm: 0 to +99999.9999 Input range in inches: 0 to +3936.9999	Thread pitch (only type TAP)?
AFC	Control setting for the adaptive feed control AFC that you have defined in the NAME column of the AFC.TAB table. Apply the feedback-control strategy with the ASSIGN AFC CONTROL SETTING soft key (3rd soft-key row) Input range: 10 characters max.	Feedback-control strategy?



Abbr.	Inputs	Dialog
DR2TABLE	3D-ToolComp software option: Enter the name of the compensation value table from which the TNC is to take the angle-dependent delta radius values DR2 Input range: Max. 16 characters without file extension	Compensation-value table?
LAST_USE	Date and time at which the TNC inserted the tool for the last time via TOOL CALL . Input range: 16 characters max., format internally specified: Date = yyyy.mm.dd, time = hh.mm	Date/time of last tool call?

Tool table: Tool data required for automatic tool measurement



For a description of the cycles for automatic tool measurement, see the User's Manual for Cycle Programming.

Abbr.	Inputs	Dialog
CUT	Number of teeth (99 teeth maximum) Input range: 0 to 99	Number of teeth?
LTOL	Permissible deviation from tool length L for wear detection. If the entered value is exceeded, the TNC locks the tool (status L). Input range: 0 to 0.9999 mm Input range in mm: 0 to +0.9999 Input range in inches: 0 to +0.03936	Wear tolerance: length?
RTOL	Permissible deviation from tool radius R for wear detection. If the entered value is exceeded, the TNC locks the tool (status L). Input range: 0 to 0.9999 mm Input range in mm: 0 to +0.9999 Input range in inches: 0 to +0.03936	Wear tolerance: radius?
R2TOL	Permissible deviation from tool radius R2 for wear detection. If the entered value is exceeded, the TNC locks the tool (status L). Input range: 0 to 0.9999 mm Input range in mm: 0 to +0.9999 Input range in inches: 0 to +0.03936	Wear tolerance: Radius 2?
DIRECT.	Cutting direction of the tool for measuring the tool during rotation	Cutting direction (M3 = -)?
TT:R-OFFS	Tool length measurement: Tool offset between stylus center and tool center. Preset value: Tool radius R (NO ENT means R). Input range in mm: -99999.9999 to +99999.9999 Input range in inches: -3936.9999 to +3936.9999	Tool offset: radius?



Abbr.	Inputs	Dialog
TT:L-OFFS	<p>Radius measurement: tool offset in addition to MP6530 between upper surface of stylus and lower surface of tool. Default: 0</p> <p>Input range in mm: -99999.9999 to +99999.9999</p> <p>Input range in inches: -3936.9999 to +3936.9999</p>	Tool offset: length?
LBREAK	<p>Permissible deviation from tool length L for breakage detection. If the entered value is exceeded, the TNC locks the tool (status L). Input range: 0 to 0.9999 mm</p> <p>Input range in mm: 0 to 0.9999</p> <p>Input range in inches: 0 to +0.03936</p>	Breakage tolerance: length?
RBREAK	<p>Permissible deviation from tool radius R for breakage detection. If the entered value is exceeded, the TNC locks the tool (status L). Input range: 0 to 0.9999 mm</p> <p>Input range in mm: 0 to 0.9999</p> <p>Input range in inches: 0 to +0.03936</p>	Breakage tolerance: radius?



Tool table: Tool data for automatic speed/feed rate calculation

Abbr.	Inputs	Dialog
TYPE	Tool type: Press the ASSIGN TYPE soft key (3rd soft-key row); the TNC superimposes a window where you can select the type of tool. Functions are currently only assigned to the DRILL and MILL tool types	Tool type?
TMAT	Tool material: Press the ASSIGN MATERIAL soft key (3rd soft-key row): The TNC superimposes a window where you can select the type of cutting material Input range: 16 characters max.	Tool material?
CDT	Cutting data table: Press the SELECT CDT soft key (3rd soft-key row): The TNC displays a pop-up window where you can select a cutting data table Input range: 16 characters max.	Name of cutting data table?

Tool table: Tool data for 3-D touch trigger probe (only when bit 1 is set in MP7411 = 1, also see the Touch Probe Cycles Manual)

Abbr.	Inputs	Dialog
CAL-0F1	During calibration, the TNC stores in this column the center misalignment in the reference axis of the 3-D probe, if a tool number is indicated in the calibration menu Input range in mm: -99999.9999 to +99999.9999 Input range in inches: -3936.9999 to +3936.9999	Center misalignmt. in ref. axis?
CAL-0F2	During calibration, the TNC stores in this column the center misalignment in the minor axis of the 3-D probe, if a tool number is indicated in the calibration menu Input range in mm: -99999.9999 to +99999.9999 Input range in inches: -3936.9999 to +3936.9999	Center misalignment minor axis?
CAL-ANG	During calibration, the TNC stores in this column the spindle angle at which the 3-D probe was calibrated, if a tool number is indicated in the calibration menu Input range: -360° to +360°	Spindle angle for calibration?



Editing tool tables

The tool table that is active during execution of the part program is designated as TOOL.T. You can only edit TOOL.T in one of the machine operating modes. Other tool tables that are to be archived or used for test runs are given different file names with the extension .T.

To open the tool table TOOL.T:

- ▶ Select any machine operating mode.
 - ▶ Press the TOOL TABLE soft key to select the tool table.
- ▶ Set the EDIT soft key to ON.
 - ▶ Set the EDIT soft key to ON.




To open any other tool table

- ▶ Select the Programming and Editing mode of operation.
 - ▶ Call the file manager.
 - ▶ Press the SELECT TYPE soft key to select the file type.
 - ▶ To show type .T files, press the SHOW .T soft key.
 - ▶ Select a file or enter a new file name. Conclude your entry with the ENT key or the SELECT soft key.











When you have opened the tool table, you can edit the tool data by moving the cursor to the desired position in the table with the arrow keys or the soft keys. You can overwrite the stored values, or enter new values at any position. The available editing functions are illustrated in the table below.

If the TNC cannot show all positions in the tool table in one screen page, the highlight bar at the top of the table will display the >> or << symbols.



Editing functions for tool tables	Soft key
Select beginning of table	
Select end of table	
Select previous page in table	
Select next page in table	
Look for the tool name in the table	
Show tool information in columns or show all information on one tool on one screen page	
Move to beginning of line	



Editing functions for tool tables	Soft key
Move to end of line	
Copy highlighted field	
Insert copied field	
Add the entered number of lines (tools) at the end of the table	
Insert a line for the indexed tool number after the active line. The function is only active if you are permitted to store multiple compensation data for a tool (MP7262 not equal to 0). The TNC inserts a copy of the tool data after the last available index and increases the index by 1. Application: e.g. stepped drill with more than one length compensation value	
Delete current line (tool), the TNC will then delete the content of the line in the table. If the tool to be deleted has been entered in the pocket table, the behavior of this function depends on MP 7263, (see "List of general user parameters" on page 585)	
Display / Do not display pocket numbers	
Display all tools / only those tools that are stored in the pocket table	

Leaving the tool table

- Call the file manager and select a file of a different type, such as a part program

Additional notes on tool tables

MP7266.x defines which data can be entered in the tool table and in which sequence the data is displayed.



You can overwrite individual columns or lines of a tool table with the contents of another file. Prerequisites:

- The target file must exist
- The file to be copied must contain only the columns (or lines) you want to replace

To copy individual columns or lines, press the REPLACE FIELDS soft key (see "Copying a single file" on page 123).



Tool-carrier kinematics



The TNC must be adapted by your machine tool builder to be able to account for the tool carrier kinematics. In particular, your machine tool builder must provide the corresponding carrier kinematics or parameterizable tool carriers. Refer to your machine manual.

In the **KINEMATIC** column of the tool table TOOL.T you can assign each tool with an additional tool carrier kinematic description. In the simplest case, this carrier kinematics can simulate the taper shank in order to include it in the dynamic collision monitoring. Also, you can use this function to very easily integrate angle heads into the machine kinematic description.



HEIDENHAIN provides tool-carrier kinematics for HEIDENHAIN touch probes. If required, please contact HEIDENHAIN.

Assigning the tool-carrier kinematics

Follow the procedure below to assign carrier kinematics to a tool:

- ▶ Select any machine operating mode.



- ▶ Press the TOOL TABLE soft key to select the tool table.



- ▶ Set the EDIT soft key to ON.




- ▶ Select the last soft key row.



- ▶ Show the list of available kinematics: The TNC displays all carrier kinematics (.TAB files) and all tool-carrier kinematics you have already parameterized (.CFX files).
- ▶ Select the desired kinematics configuration with the arrow keys and confirm your selection with the OK key.



Please also note the information on tool-carrier management in combination with Dynamic Collision Monitoring (DCM): See "Tool Holder Management (DCM Software Option)" on page 352.



Using an external PC to overwrite individual tool data

The HEIDENHAIN data transfer software TNCremoNT provides an especially convenient way to use an external PC to overwrite tool data (see "Software for data transfer" on page 549). This applies when you measure tool data on an external tool presetter and then want to transfer the data to the TNC. Follow this procedure:

- ▶ Copy the tool table TOOL.T to the TNC, for example to TST.T
- ▶ Start the data transfer software TNCremoNT on the PC
- ▶ Establish a connection with the TNC
- ▶ Transfer the copied tool table TST.T to the PC
- ▶ Use any text editor to reduce TST.T to the lines and columns to be changed (see figure). Make sure that the header is not changed and the data is always flush in the column. The tool number (column T) need not be consecutive
- ▶ In TNCremoNT, select the menu item <Extras> and <TNCcmd>:
This starts TNCcmd
- ▶ To transfer TST.T to the TNC, enter the following command and confirm with the return key (see figure):
put tst.t tool.t /m



During transfer, only the tool data defined in the subfile (e.g. TST.T) is overwritten. All other tool data of the table TOOL.T remains unchanged.

The procedure for copying tool tables using the TNC file manager is described in the section on file management (see "Copying a table" on page 125).

```
BEGIN TST      .T MM
T      NAME          L          R
1          +12.5      +9
3          +23.15     +3.5
[END]
```

```
iTNC530 - TNCcmd
TNCcmd - WIN32 Command Line Client for HEIDENHAIN Controls - Version: 3.06
Connecting with iTNC530 (168.1.100.23)...
Connection established with iTNC530, NC Software 349422 001
TNC:> put tst.t tool.t /m
```



Pocket table for tool changer



The machine tool builder adapts the functional range of the pocket table to the requirements of your machine. The machine tool manual provides further information.

For automatic tool changing you need the pocket table TOOL_P.TCH. The TNC can manage several pocket tables with any file names. To activate a specific pocket table for program run you must select it in the file management of a Program Run mode of operation (status M). In order to be able to manage various magazines in a tool-pocket table (indexing the pocket number), Machine Parameters 7261.0 to 7261.3 must not be equal to 0.

The TNC can control up to **9999 magazine pockets** in the pocket table.

Editing a pocket table in a Program Run operating mode



- ▶ Press the TOOL TABLE soft key to select the tool table.



- ▶ To select the pocket table, press the POCKET TABLE soft key.



- ▶ Set the EDIT soft key to ON. On your machine this might not be necessary or even possible. Refer to your machine manual.

Pocket table editing
Tool number?

File	TOOL_P.TCH	DIR	DIR	DIR	DIR	DIR
0.0		%00000000	D10			0
1.1	4	%00000000	D0		Tool 4	0
1.2		%00000000				0
1.3	0	%00000000	D16			0
1.4		%00000000				4
1.5		%00000000				0
1.6	20	%00000000	D40			0
1.7	16	%00000000	D32			0
1.8		%00000000				0
1.9	3	%00000000	D6		Tool 3	0
1.10	7	%00000000	D14			0
1.11		%00000000				0
1.12	23	%00000000	D46			0
1.13		%00000000				0
1.14		%00000000				0
1.15		%00000000				0
2.1	12	%00000000	D24			0

0% S-IST P0 -T5
0% SCNmJ LIMIT 1 23:50

X +20.249 Y +11.550 Z +100.250
+B +0.000 +C +0.000

S1 0.000

ACTL. :20 T 5 Z S 2500 F 5.0 M 5 / 9

BEGIN END PAGE PAGE EDIT RESET TOOL TABLE END
OFF ON POCKET TABLE











Selecting a pocket table in the Programming and Editing operating mode



- ▶ Call the file manager.
- ▶ Press the SELECT TYPE soft key to select the file type.
- ▶ Press the soft key TCH FILES (second soft-key row) to show files of the type .TCH.
- ▶ Select a file or enter a new file name. Conclude your entry with the ENT key or the SELECT soft key.

Abbr.	Inputs	Dialog
P	Pocket number of the tool in the tool magazine	-
T	Tool number	Tool number?
ST	S pecial T ool with a large radius requiring several pockets in the tool magazine. If your special tool takes up pockets in front of and behind its actual pocket, these additional pockets need to be locked in column L (status L)	Special tool?
F	F ixed tool number. The tool is always returned to the same pocket in the tool magazine	Fixed pocket? Yes = ENT / No = NO ENT
L	L ocked pocket (see also column ST)	Pocket locked Yes = ENT / No = NO ENT
PLC	Information on this tool pocket that is to be sent to the PLC	PLC status?
TNAME	Display of the tool name from TOOL.T	-
DOC	Display of the comment to the tool from TOOL.T	-
PTYP	Tool type. Function is defined by the machine tool builder. The machine tool documentation provides further information.	Tool type for pocket table?
P1 ... P5	Function is defined by the machine tool builder. The machine tool documentation provides further information.	Value?
RSV	Pocket reservation for box magazines	Pocket reserv.: Yes = ENT / No = NOENT
LOCKED_ABOVE	Box magazine: Lock the pocket above	Lock the pocket above?
LOCKED_BELOW	Box magazine: Lock the pocket below	Lock the pocket below?
LOCKED_LEFT	Box magazine: Lock the pocket at left	Lock the pocket at left?
LOCKED_RIGHT	Box magazine: Lock the pocket at right	Lock the pocket at right?
S1 ... S5	Function is defined by the machine tool builder. The machine tool documentation provides further information.	Value?



Editing functions for pocket tables	Soft key
Select beginning of table	
Select end of table	
Select previous page in table	
Select next page in table	
Reset pocket table	
Reset tool number column T	
Go to beginning of next line	
Reset column to original state. Only applies to the columns RSV , LOCKED_ABOVE , LOCKED_BELOW , LOCKED_LEFT and LOCKED_RIGHT	



Calling tool data

A TOOL CALL block in the part program is defined with the following data:

- ▶ Select the tool call function with the TOOL CALL key.



- ▶ **Tool number:** Enter the number or name of the tool. The tool must already be defined in a **G99** block or in the tool table. Press the TOOL NAME soft key to enter the name. The TNC automatically places the tool name in quotation marks. The tool name always refers to the entry in the active tool table TOOL.T. If you wish to call a tool with other compensation values, also enter the index you defined in the tool table after the decimal point. There is a SELECT soft key for calling a window from which you can select a tool defined in the tool table TOOL.T directly without having to enter the number or name: See also "Editing tool data in the selection window" on page 180.
- ▶ **Working spindle axis X/Y/Z:** Enter the tool axis.
- ▶ **Spindle speed S:** Enter the spindle speed directly or allow the TNC to calculate the spindle speed if you are working with cutting data tables. Press the S CALCULATE AUTOMAT. soft key. The TNC limits the spindle speed to the maximum value set in MP 3515. Alternatively, you can define the cutting speed Vc in m/min. Press the VC soft key.
- ▶ **Feed rate F:** Enter the feed rate directly or allow the TNC to calculate the feed rate if you are working with cutting data tables. Press the F CALCULATE AUTOMAT. soft key. The TNC limits the feed rate to the maximum feed rate of the slowest axis (set in MP1010). F is effective until you program a new feed rate in a positioning or TOOL CALL block.
- ▶ **Tool length oversize DL:** Enter the delta value for the tool length.
- ▶ **Tool radius oversize DR:** Enter the delta value for the tool radius.
- ▶ **Tool radius oversize DR2:** Enter the delta value for the tool radius 2.



Editing tool data in the selection window

In the pop-up window for tool selection you can also edit the displayed tool data:

- ▶ Use the arrow keys to select the line and then the column of the value to be edited: The light-blue background marks the editable field
- ▶ Set the EDIT soft key to ON, enter the desired value and confirm with the ENT key
- ▶ If needed, select further columns and repeat the described procedure
- ▶ Press the ENT key to load the selected tool into the program

Example: Tool call


Call tool number 5 in the tool axis Z with a spindle speed of 2500 rpm and a feed rate of 350 mm/min. The tool length is to be programmed with an oversize of 0.2 mm, the tool radius 2 with an oversize of 0.05 mm, and the tool radius with an undersize of 1 mm.

```
N20 T 5.2 G17 S2500 DL+0.2 DR-1
```

The character **D** preceding **L** and **R** designates a delta value.

Tool preselection with tool tables

If you are working with tool tables, use **G51** to preselect the next tool. Simply enter the tool number or a corresponding Q parameter, or type the tool name in quotation marks.



Tool change



The tool change function can vary depending on the individual machine tool. The machine tool manual provides further information.

Tool change position

The tool change position must be approachable without collision. With the miscellaneous functions **M91** and **M92**, you can enter machine-based (rather than workpiece-based) coordinates for the tool change position. If **T 0** is programmed before the first tool call, the TNC moves the tool spindle in the tool axis to a position that is independent of the tool length.

Manual tool change

To change the tool manually, stop the spindle and move the tool to the tool change position:

- ▶ Move to the tool change position under program control.
- ▶ Interrupt program run (see "Interrupting machining", page 529).
- ▶ Change the tool.
- ▶ Resume program run (see "Resuming program run after an interruption", page 532).

Automatic tool change

If your machine tool has automatic tool changing capability, the program run is not interrupted. When the TNC reaches a **T** it replaces the inserted tool by another from the tool magazine.



Automatic tool change if the tool life expires: M101

The function of **M101** can vary depending on the individual machine tool. The machine tool manual provides further information.

An automatic tool change with active radius compensation is not possible if an NC program is used on your machine for the tool change. The machine tool manual provides further information.

The TNC automatically changes the tool if the tool life **TIME2** expires during program run. To use this miscellaneous function, activate **M101** at the beginning of the program. **M101** is reset with **M102**. When **TIME1** is reached, the TNC merely places an internal marker that can be evaluated via the PLC.

You enter the number of the replacement tool in the **RT** column of the tool table. If no tool number is entered there, the TNC inserts a tool that has the same name as the momentarily active one. The TNC starts the search from the beginning of the tool table and inserts the first tool it finds.

The tool is changed automatically

- after the next NC block after expiration of the tool life, or
- at latest one minute plus one NC block after tool life expires (calculation is for a potentiometer setting of 100%).



If the tool life ends during an active **M120** (look ahead), the TNC waits to change the tool until after the block in which you canceled the radius compensation.

The TNC does not execute any automatic tool change if it is currently running a cycle. Exception: During the Pattern Cycles 220 and 221 (circular hole pattern and linear pattern) the TNC can execute an automatic tool change between two machining positions, if required.

The TNC does not automatically change the tool as long as a tool change program is running.

**Caution: Danger to the workpiece and tool!**

Switch off the automatic tool change with **M102** if you are working with special tools (e.g. side mill cutter) as the TNC at first always moves the tool away from the workpiece in tool axis direction.

Prerequisites for standard NC blocks with radius compensation G41, G42

The radius of the replacement tool must be the same as that of the original tool. If the radii are not equal, the TNC displays an error message and does not replace the tool.

On NC programs without radius compensation the TNC does not check the tool radius of the replacement tool during the change.



Tool usage test



The tool usage test function must be enabled by your machine manufacturer. Refer to your machine tool manual.

The following are prerequisites for a tool usage test:

- Bit 2 of the machine parameter must be set to 7246=1
- The machining timer must be active in the **Test Run** operating mode
- A simulation of the plain language program must have been completed in the **Test Run** mode


Settings for the tool usage test

To be able to influence the behavior of the tool usage test, a form is available, which you can call as follows:

- ▶ Select the Program Run, Single Block mode or the Program Run, Full Sequence mode.
- ▶ Press the Tool Usage soft key: The TNC shows a soft-key row with functions for the usage test.
- ▶ Press the SETTINGS soft key: The TNC displays the form with the available settings.

You can define the following settings separately for **Program Run, Full Sequence / Single Block** and the **Test Run**.

- **Do not generate tool-usage file** setting
The TNC does not generate a tool usage file.
- **Generate tool-usage file once** setting
The TNC generates a tool usage file once with the next NC start or start of the simulation. Then the TNC automatically deactivates the **Do not generate tool-usage file** mode to prevent the usage file from being overwritten during further NC starts.
- **Generate new tool usage file after changes or as needed** (basic setting):
The TNC generates a tool usage file with every NC start or every start of the test run. The setting ensures that the TNC also generates a new tool-usage file after program changes.




Applying the tool usage test

With the TOOL USAGE and TOOL USAGE TEST soft keys, you can check before starting a program in a Program Run operating mode whether the tools being used in the selected program have enough service life remaining. Here the TNC compares the actual values for service life in the tool table with the nominal values from the tool requirement file.

After you have clicked the TOOL USAGE TEST soft key, the TNC displays the results of the tool usage test in a pop-up window. Use the CE key to close the pop-up window.

The TNC saves the usage times in a separate file with the extension **pgmname.H.T.DEP** (see “Changing the MOD setting for dependent files” on page 563). The generated tool usage file has the following information:

Column	Meaning
TOKEN	<ul style="list-style-type: none"> ■ TOOL: Tool usage time per TOOL CALL. The entries are listed in chronological order. ■ TTOTAL: Total usage time of a tool ■ STOTAL: Call of a subprogram (including cycles). The entries are listed in chronological order. ■ TIMETOTAL: The total machining time of the NC program is entered in the WTIME column. In the PATH column the TNC saves the path name of the corresponding NC programs. The TIME column shows the sum of all TIME entries (only when the spindle is on, and without rapid traverse). The TNC sets all other columns to 0. ■ TOOLFILE: In the PATH column, the TNC saves the path name of the tool table with which you conducted the Test Run. This enables the TNC during the actual tool usage test to detect whether you performed the test run with the TOOL.T.
TNR	Tool number (-1 : No tool inserted yet)
IDX	Tool index
NAME	Tool name from the tool table
TIME	Tool-usage time in seconds (feed time)
WTIME	Tool-usage time in seconds (total usage time between tool changes)
RAD	Tool radius R + Oversize of tool radius DR from the tool table. The unit is 0.1 μm .



Column	Meaning
BLOCK	Block number in which the TOOL CALL block was programmed
PATH	<ul style="list-style-type: none"> ■ TOKEN = TOOL: Path name of the active main program or subprogram ■ TOKEN = STOTAL: Path name of the subprogram
T	Tool number with tool index
OVRMAX	Maximum feed rate override that occurred during machining. During test run, the TNC enters the value 100 (%)
OVRMIN	Minimum feed rate override that occurred during machining. During test run, the TNC enters the value -1
NAMEPROG	<ul style="list-style-type: none"> ■ 0: The tool number is programmed ■ 1: The tool name is programmed

There are two ways to run a tool usage test for a pallet file:

- The highlight is on a pallet entry in the pallet file:
The TNC runs the tool usage test for the entire pallet.
- The highlight is on a program entry in the pallet file:
The TNC runs the tool usage test for the selected program.



Tool management (software option)



Tool management is a machine-dependent function, which can be partly or completely deactivated. The machine tool builder defines the exact range of functions, so refer to your machine manual.

With the tool management, your machine tool builder can provide many functions with regard to tool handling. Examples:

- Easily readable and, if you desired, adaptable representation of the tool data in fillable forms
- Any description of the individual tool data in the new table view
- Mixed representation of data from the tool table and the pocket table
- Fast sorting of all tool data by mouse
- Use of graphic aids, e.g. color coding of tool or magazine status
- Program-specific list of all available tools
- Program-specific usage sequence of all tools
- Copying and pasting of all tool data pertaining to a tool

Calling tool management



The tool management call can differ as described below; refer to your machine manual!



- ▶ Press the TOOL TABLE soft key to select the tool table



- ▶ Scroll through the soft-key row



- ▶ Select the TOOL MANAGEMENT soft key: The TNC goes into the new table view (see figure at right)

Expanded tool management

T	NAME	PTVP	TL	POCKET	MAGAZINE	Tool life	REMAINING_LI
0	T0	0				Not monitored	0
1	D2	0				Not monitored	0
2	D4	0				Not monitored	0
3	D6	0		9	Main magazine	Not monitored	0
4	D8	0		1	Main magazine	Not monitored	0
5	D10	0			Spindle	Not monitored	0
6							
7	D14	0		10	Main magazine	Not monitored	0
8	D16	0		3	Main magazine	Not monitored	0
9	D18	0				Not monitored	0
10	D20	0				Not monitored	0
11	D22	0				Not monitored	0
12	D24	0		1	Add-on magazine	Not monitored	0
13	D26	0				Not monitored	0
14	D28	0				Not monitored	0
15	D30	0		9		Expired	0
16	D32	0		7	Main magazine	Not monitored	0
17	D34	0				Not monitored	0
18	D36	0		2	Add-on magazine	Not monitored	0
19	D38	0				Not monitored	0
20	D40	0		6	Main magazine	Not monitored	0
21	D42	0				Not monitored	0
22	D44	0				Not monitored	0
23	D46	0		12	Main magazine	Not monitored	0
24	D48	0				Not monitored	0
25	D50	0				Not monitored	0
26	D52	0				Not monitored	0
---	---	---	---	---	---	---	---

Navigation buttons: BEGIN, END, PAGE, PAGE, FORM TOOL, END



In the new view, the TNC presents all tool information in the following four card registers:

- **Tools:**
Tool specific information
- **Tool pockets:**
Pocket-specific information
- **Tooling list:**
List of all tools in the NC program that is selected in the Program Run mode (only if you have already made a tool usage file, see "Tool usage test", page 183)
- **T usage order:**
List of the sequence of all tools that are inserted in the program selected in the Program Run mode (only if you have already made a tool usage file, see "Tool usage test", page 183)



You can edit the tool data only in the fillable form view, which you can activate by pressing the FORM TOOL soft key or the ENT key for the tool that is highlighted on the screen.

Expanded tool management

T	NAME	PTYP	TL	POCKET	MAGAZINE	Tool life	REMAING. LI
0	T0	0				Not monitored	0
1	D2	0				Not monitored	0
2	D4	0				Not monitored	0
3	D6	0		9	Main magazine	Not monitored	0
4	D8	0		1	Main magazine	Not monitored	0
5	D10	0			Spindle	Not monitored	0
6							
7	D14	0		10	Main magazine	Not monitored	0
8	D16	0		2	Main magazine	Not monitored	0
9	D18	0				Not monitored	0
10	D20	0				Not monitored	0
11	D22	0				Not monitored	0
12	D24	0		1	Add-on magazine	Not monitored	0
13	D26	0				Not monitored	0
14	D28	0				Not monitored	0
15	D30	0		5		Expired	0
16	D32	0		7	Main magazine	Not monitored	0
17	D34	0				Not monitored	0
18	D36	0		2	Add-on magazine	Not monitored	0
19	D38	0				Not monitored	0
20	D40	0		6	Main magazine	Not monitored	0
21	D42	0				Not monitored	0
22	D44	0				Not monitored	0
23	D46	0				Not monitored	0
24	D48	0		12	Main magazine	Not monitored	0
25	D50	0				Not monitored	0
26	D52	0				Not monitored	0
27	---					Not monitored	0

Expanded tool management

Tool index #

Basic data | PLC

Information

NAME: T number 2

DDC: Tool 2

Pocket no.: PTPV 0

RT

Basic data	Wear data	Additional data	Tool life data
L 40	DL 0	LCUTS 15	TIME1 0
R 2	DR 0	RANGLE 20	TIME2 0
RZ 0	DR2 0	PITCH 0	CUR TIME 1
		T-ANGLE 0	TL
		NMAX -	

TS data

TS data	Cutting data	Spec. functions
CAL-OF1 0	TYP	RFC Standard
CAL-OF2 0	TRAT	KINEMATIC
CAL-RVG 0	CDT	DR2TABLE
		LAST USE 2010.05.04 12:49
		LIFTOFF











TT data

TT data		
L-OFFS 0	LBREAK	0
R-OFFS R	RBREAK	0
LTOL 0	CUT	0
RTOL 0	DIRECT	-
R2TOL 0		



Operating the tool management

The tool management can be operated by mouse or with the keys and soft keys:










Editing functions for tool management	Soft key
Select beginning of table	
Select end of table	
Select previous page in table	
Select next page in table	
Call the fillable form view for the tool or magazine pocket highlighted in the table. Alternative function: Press the ENT key	
Go to the next tab: Tools, Pockets, Tooling list, T usage order	
Search function (Find): Here you can select the column to be searched and the search term via a list or by entering it	
Show programmed-tools column (if Pockets tab is active)	
Define the settings: <ul style="list-style-type: none"> ■ SORT COLUMN active: Click the column header to sort the content of the column ■ MOVE COLUMN active: The column can be shifted by drag and drop 	
Reset manual settings (shifted columns) to original condition	


In addition, you can perform the following functions by mouse:

- **Sorting function**
By clicking a column of the table head, you sort the data in ascending or descending order (depending on the active setting).
- **Moving columns**
You can arrange the columns in any sequence you want by clicking a column of the table head and then moving it with the mouse key pressed down. The TNC does not save the current column sequence when you exit the tool management (depending on the active setting).
- **Showing additional information in the fillable form view**
The TNC displays tool tips when you leave the mouse pointer on an active input field for more than a second and when you have set the EDIT ON/OFF soft key to ON.



If the form view is active, the following functions are available to you:

Editing functions, form view	Soft key
Select the tool data of the preceding tool	
Select the tool data of the next tool	
Select previous tool index (only active if indexing is enabled)	
Select the next tool index (only active if indexing is enabled)	
Discard all changes made since the form was called ("Undo" function)	
Insert a line (tool index) (2nd soft-key row)	
Delete a line (tool index) (2nd soft-key row)	
Copy the tool data of the selected tool (2nd soft-key row)	
Insert the copied tool data in the selected tool (2nd soft-key row)	



5.3 Tool Compensation

Introduction

The TNC adjusts the spindle path in the spindle axis by the compensation value for the tool length. In the working plane, it compensates the tool radius.

If you are writing the part program directly on the TNC, the tool radius compensation is effective only in the working plane. The TNC accounts for up to five axes including the rotary axes.

Tool length compensation

Length compensation becomes effective automatically as soon as a tool is called and the spindle axis moves. To cancel length compensation, call a tool with the length $L=0$.



Danger of collision!


If you cancel a positive length compensation with **T 0** the distance between tool and workpiece will be reduced.

After **T** the path of the tool in the spindle axis, as entered in the part program, is adjusted by the difference between the length of the previous tool and that of the new one.

For tool length compensation, the control takes the delta values from both the **T** block and the tool table into account:

Compensation value = $L + DL_{TOOL CALL} + DL_{TAB}$ where

- L:** is the tool length **L** from the **G99** block or tool table
- DL_{TOOL CALL}** is the oversize for length **DL** in the **T 0** block (not taken into account by the position display).
- DL_{TAB}** is the oversize for length **DL** in the tool table.



Tool radius compensation

The NC block for programming a tool movement contains:

- **G41** or **G42** for radius compensation
- **G43** or **G44**, for radius compensation in single-axis movements
- **G40** if there is no radius compensation

Radius compensation becomes effective as soon as a tool is called and is moved with a straight line block in the working plane with **G41** or **G42**.



The TNC automatically cancels radius compensation if you:

- program a straight line block with **G40**
- program a **PGM CALL**
- select a new program with PGM MGT.

For radius compensation, the TNC takes the delta values from both the **T** block and the tool table into account:



Compensation value = $R + DR_{\text{TOOL CALL}} + DR_{\text{TAB}}$ where

- R** Tool radius **R** from the **G99** block or tool table
- DR_{TOOL CALL}** Oversize for radius **DR** in the **T** block (not taken into account by the position display)
- DR_{TAB}**: Oversize for radius **DR** in the tool table

Contouring without radius compensation: G40

The tool center moves in the working plane along the programmed path or to the programmed coordinates.

Applications: Drilling and boring, pre-positioning.



Contouring with radius compensation: G42 and G41

G43 The tool moves to the right of the programmed contour.

G42 The tool moves to the left of the programmed contour.

The tool center moves along the contour at a distance equal to the radius. "Right" or "left" are to be understood as based on the direction of tool movement along the workpiece contour. See figures.





Between two program blocks with different radius compensations **G43** and **G42** you must program at least one traversing block in the working plane without radius compensation (that is, with **G40**).

The TNC does not put radius compensation into effect until the end of the block in which it is first programmed.

You can also activate the radius compensation for secondary axes in the working plane. Program the secondary axes too in each following block, since otherwise the TNC will execute the radius compensation in the principal axis again.

In the first block in which radius compensation is activated with **G42/G41** or canceled with **G40** the TNC always positions the tool perpendicular to the programmed starting or end position. Position the tool at a sufficient distance from the first or last contour point to prevent the possibility of damaging the contour.



Entering radius compensation

Radius compensation is entered in a G01 block:

G41

To select tool movement to the left of the programmed contour, select function G41, or

G42

To select tool movement to the right of the contour, select function G42, or

G40

To select tool movement without radius compensation or to cancel radius compensation, select function G40

END
□

To terminate the block, press the END key.



Radius compensation: Machining corners



- Outside corners:
If you program radius compensation, the TNC moves the tool around outside corners either on a transitional arc or on a spline (selectable via MP7680). If necessary, the TNC reduces the feed rate at outside corners to reduce machine stress, for example at very great changes of direction.
- Inside corners:
The TNC calculates the intersection of the tool center paths at inside corners under radius compensation. From this point it then starts the next contour element. This prevents damage to the workpiece. The permissible tool radius, therefore, is limited by the geometry of the programmed contour.

**Caution: Danger to the workpiece!**

To prevent the tool from damaging the contour, be careful not to program the starting or end position for machining inside corners at a corner of the contour.

Machining corners without radius compensation

If you program the tool movement without radius compensation, you can change the tool path and feed rate at workpiece corners with the miscellaneous function **M90**. see "Smoothing corners: M90", page 315.





6

**Programming:
Programming Contours**



6.1 Tool Movements

Path functions

A workpiece contour is usually composed of several contour elements such as straight lines and circular arcs. With the path functions, you can program the tool movements for **straight lines** and **circular arcs**.

Miscellaneous functions M

With the TNC's miscellaneous functions you can affect

- The program run, e.g., a program interruption
- The machine functions, such as switching spindle rotation and coolant supply on and off
- The path behavior of the tool

Subprograms and program section repeats

If a machining sequence occurs several times in a program, you can save time and reduce the chance of programming errors by entering the sequence once and then defining it as a subprogram or program section repeat. If you wish to execute a specific program section only under certain conditions, you also define this machining sequence as a subprogram. In addition, you can have a part program call a separate program for execution.


Programming with subprograms and program section repeats is described in Chapter 8.

Programming with Q parameters

Instead of programming numerical values in a part program, you enter markers called Q parameters. You assign the values to the Q parameters separately with the Q parameter functions. You can use the Q parameters for programming mathematical functions that control program execution or describe a contour.

In addition, parametric programming enables you to measure with the 3-D touch probe during program run.

Programming with Q parameters is described in Chapter 9.



6.2 Fundamentals of Path Functions

Programming tool movements for workpiece machining

You create a part program by programming the path functions for the individual contour elements in sequence. You usually do this by entering **the coordinates of the end points of the contour elements** given in the production drawing. The TNC calculates the actual path of the tool from these coordinates, and from the tool data and radius compensation.

The TNC moves all axes programmed in a single block simultaneously.

Movement parallel to the machine axes

The program block contains only one coordinate. The TNC thus moves the tool parallel to the programmed axis.

Depending on the individual machine tool, the part program is executed by movement of either the tool or the machine table on which the workpiece is clamped. Nevertheless, you always program path contours as if the tool were moving and the workpiece remaining stationary.

Example:

```
N50 G00 X+100 *
```

N50	Block number
G00	Path function "straight line at rapid traverse"
X+100	Coordinate of the end point

The tool retains the Y and Z coordinates and moves to the position X=100. See figure.

Movement in the main planes

The program block contains two coordinates. The TNC thus moves the tool in the programmed plane.

Example:

```
N50 G00 X+70 Y+50 *
```




The tool retains the Z coordinate and moves in the XY plane to the position X=70, Y=50 (see figure).

Three-dimensional movement

The program block contains three coordinates. The TNC thus moves the tool in space to the programmed position.

Example:

```
N50 G01 X+80 Y+0 Z-10 *
```



Entering more than three coordinates

The TNC can control up to 5 axes simultaneously (software option). Machining with 5 axes, for example, moves 3 linear and 2 rotary axes simultaneously.

Such programs are too complex to program at the machine, however, and are usually created with a CAM system.

Example:

```
N123 G01 G40 X+20 Y+10 Z+2 A+15 C+6 F100 M3 *
```

Circles and circular arcs



The TNC moves two axes simultaneously on a circular path relative to the workpiece. You can define a circular movement by entering the circle center CC.

When you program a circle, the control assigns it to one of the main planes. This plane is defined automatically when you set the spindle axis during a TOOL CALL:

Spindle axis	Main plane
(G17)	XY , also UV, XV, UY
(G18)	ZX , also WU, ZU, WX
(G19)	YZ , also VW, YW, VZ



You can program circles that do not lie parallel to a main plane by using the function for tilting the working plane (see User's Manual for Cycles, Cycle 19, WORKING PLANE) or Q parameters (see "Principle and Overview", page 262).



Direction of rotation DR for circular movements

When a circular path has no tangential transition to another contour element, enter the direction of rotation as follows:

Clockwise direction of rotation: **G02/G12**


Counterclockwise direction of rotation: **G03/G13**

Radius compensation

The radius compensation must be in the block in which you move to the first contour element. You cannot activate radius compensation in a circle block. Activate it beforehand in a straight-line block (see "Path Contours—Cartesian Coordinates", page 204).

Pre-positioning

Before running a part program, always pre-position the tool to prevent the possibility of damaging it or the workpiece.



6.3 Contour Approach and Departure

Starting point and end point

The tool approaches the first contour point from the starting point. The starting point must be:

- Programmed without radius compensation
- Approachable without danger of collision
- Close to the first contour point

Example

Figure at upper right: If you set the starting point in the dark gray area, the contour will be damaged when the first contour element is approached.

First contour point

You need to program a radius compensation for the tool movement to the first contour point.




Approaching the starting point in the spindle axis

When the starting point is approached, the tool must be moved to the working depth in the spindle axis. If danger of collision exists, approach the starting point in the spindle axis separately.

Example NC blocks

```
N30 G00 G40 X+20 Y+30 *
```

```
N40 Z-10 *
```



End point

The end point should be selected so that it is:

- Approachable without danger of collision
- Near to the last contour point
- In order to make sure the contour will not be damaged, the optimal ending point should lie on the extended tool path for machining the last contour element

Example

Figure at upper right: If you set the ending point in the dark gray area, the contour will be damaged when the end point is approached.

Depart the end point in the spindle axis:

Program the departure from the end point in the spindle axis separately. See figure at center right.

Example NC blocks

```
N50 G00 G40 X+60 Y+70 *
```

```
N60 Z+250 *
```




Common starting and end points

Do not program any radius compensation if the starting point and end point are the same.

In order to make sure the contour will not be damaged, the optimal starting point should lie between the extended tool paths for machining the first and last contour elements.

Example

Figure at upper right: If you set the starting point in the dark gray area, the contour will be damaged when the first contour element is approached.



Tangential approach and departure

With **G26** (figure at center right), you can program a tangential approach to the workpiece, and with **G27** (figure at lower right) a tangential departure. In this way you can avoid dwell marks.

Starting point and end point

The starting point and the end point lie outside the workpiece, close to the first and last contour points. They are to be programmed without radius compensation.

Approach



- ▶ **G26** is entered after the block in which the first contour element is programmed: This will be the first block with radius compensation **G41/G42**

Departure

- ▶ **G27** after the block in which the last contour element is programmed: This will be the last block with radius compensation **G41/G42**



The radius for **G26** and **G27** must be selected so that the TNC can execute the circular path between the starting point and the first contour point, as well as the last contour point and the end point.










Example NC blocks

N50 G00 G40 G90 X-30 Y+50 *	Starting point
N60 G01 G41 X+0 Y+50 F350 *	First contour point
N70 G26 R5 *	Tangential approach with radius R = 5 mm
. . .	
PROGRAM CONTOUR BLOCKS	
. . .	Last contour point
N210 G27 R5 *	Tangential departure with radius R = 5 mm
N220 G00 G40 X-30 Y+50 *	End point



6.4 Path Contours – Cartesian Coordinates

Overview of path functions

Function	Path function key	Tool movement	Required input	Page
Line L		Straight line	Coordinates of the end points of the straight line	Page 205
Chamfer CHF		Chamfer between two straight lines	Chamfer side length	Page 206
Circle Center CC		None	Coordinates of the circle center or pole	Page 208
Circle C		Circular arc around a circle center CC to an arc end point	Coordinates of the arc end point, direction of rotation	Page 209
Circular arc CR		Circular arc with a certain radius	Coordinates of the arc end point, arc radius, direction of rotation	Page 210
Circular arc CT		Circular arc with tangential connection to the preceding and subsequent contour elements	Coordinates of the arc end point	Page 212
Corner Rounding RND		Circular arc with tangential connection to the preceding and subsequent contour elements	Rounding radius R	Page 207



Straight line at rapid traverse G00

Straight line with feed rate G01 F

The TNC moves the tool in a straight line from its current position to the straight-line end point. The starting point is the end point of the preceding block.



- ▶ **Coordinates** of the end point of the straight line, if necessary
- ▶ **Radius compensation G41/G42/G40**
- ▶ **Feed rate F**
- ▶ **Miscellaneous function M**

Example NC blocks

```
N70 G01 G41 X+10 Y+40 F200 M3 *
```

```
N80 G91 X+20 Y-15 *
```

```
N90 G90 X+60 G91 Y-10 *
```

Actual position capture

You can also generate a straight-line block (**G01** block) by using the ACTUAL-POSITION-CAPTURE key:


- ▶ In the Manual Operation mode, move the tool to the position you wish to capture.
- ▶ Switch the screen display to Programming and Editing.
- ▶ Select the program block after which you want to insert the L block.



- ▶ Press the ACTUAL-POSITION-CAPTURE key: The TNC generates an L block with the actual position coordinates.



In the MOD function, you define the number of axes that the TNC saves in a **G01** block (see "Selecting the Axes for Generating G01 Blocks", page 570).



Inserting a chamfer between two straight lines

The chamfer enables you to cut off corners at the intersection of two straight lines.

- The line blocks before and after the **G24** block must be in the same working plane as the chamfer
- The radius compensation before and after the **G24** block must be the same
- The chamfer must be machinable with the current tool



- ▶ **Chamfer side length:** Length of the chamfer, and if necessary:
- ▶ **Feed rate F** (effective only in **G24** block)

Example NC blocks

```
N70 G01 G41 X+0 Y+30 F300 M3 *
```

```
N80 X+40 G91 Y+5 *
```

```
N90 G24 R12 F250 *
```

```
N100 G91 X+5 G90 Y+0 *
```




You cannot start a contour with a **G24** block.

A chamfer is possible only in the working plane.

The corner point is cut off by the chamfer and is not part of the contour.

A feed rate programmed in the CHF block is effective only in that block. After the **G24** block, the previous feed rate becomes effective again.



Corner rounding G25

The **G25** function is used for rounding off corners.

The tool moves on an arc that is tangentially connected to both the preceding and subsequent contour elements.

The rounding arc must be machinable with the called tool.

- G** 25
- ▶ **Rounding radius:** Enter the radius, and if necessary:
 - ▶ **Feed rate F** (effective only in **G25** block)


Example NC blocks

```
5 L X+10 Y+40 RL F300 M3
```

```
6 L X+40 Y+25
```

```
7 RND R5 F100
```

```
8 L X+10 Y+5
```



In the preceding and subsequent contour elements, both coordinates must lie in the plane of the rounding arc. If you machine the contour without tool-radius compensation, you must program both coordinates in the working plane.

The corner point is cut off by the rounding arc and is not part of the contour.

A feed rate programmed in the **G25** block is effective only in that **G25** block. After the **G25** block, the previous feed rate becomes effective again.

You can also use an RND block for a tangential contour approach.



Circle center I, J

You can define a circle center for circles that you have programmed with the **G02**, **G03** or **G05** function. This is done in the following ways:

- Entering the Cartesian coordinates of the circle center in the working plane, or
- Using the circle center defined in an earlier block, or
- Capturing the coordinates with the ACTUAL-POSITION-CAPTURE key

I

J

- ▶ Enter the coordinates for the circle center, or
If you want to use the last programmed position, enter **G29**

Example NC blocks

```
N50 I+25 J+25 *
```

or

```
N10 G00 G40 X+25 Y+25 *
```

```
N20 G29 *
```

The program blocks 10 and 11 do not refer to the illustration.

Duration of effect

The circle center definition remains in effect until a new circle center is programmed. You can also define a circle center for the secondary axes U, V and W.

Entering the circle center incrementally


If you enter the circle center with incremental coordinates, you have programmed it relative to the last programmed position of the tool.



The only effect of CC is to define a position as circle center: The tool does not move to this position.

The circle center is also the pole for polar coordinates.

If you wish to define the pole in parallel axes, first press the **I** (**J**) key on the ASCII keyboard, and then the orange axis key for the corresponding parallel axis.



Circular path C around circle center CC

Before programming a circular arc, you must first enter the circle center **I**, **J**. The last programmed tool position will be the starting point of the arc.

Direction of rotation

- In clockwise direction: **G02**
- In counterclockwise direction: **G03**
- Without programmed direction: **G05**. The TNC traverses the circular arc with the last programmed direction of rotation

▶ Move the tool to the circle starting point.

- I** **J** ▶ Enter the **coordinates** of the circle center
- G** ₃ ▶ **Coordinates** of the arc end point, and if necessary:
- ▶ **Feed rate F**
 - ▶ **Miscellaneous function M**



The TNC normally makes circular movements in the active working plane. If you program circular arcs that do not lie in the active working plane, for example **G2 Z... X...** with a tool axis Z, and at the same time rotate this movement, then the TNC moves the tool in a spatial circular arc, which means a circular arc in 3 axes.

Example NC blocks

```
N50 I+25 J+25 *
```

```
N60 G01 G42 X+45 Y+25 F200 M3 *
```

```
N70 G03 X+45 Y+25 *
```

Full circle



For the end point, enter the same point that you used for the starting point.



The starting and end points of the arc must lie on the circle.

Input tolerance: up to 0.016 mm (selected with MP7431).

Smallest possible circle that the TNC can traverse:
0.0016 µm.



Circular path G02/G03/G05 with defined radius

The tool moves on a circular path with the radius R.

Direction of rotation


- In clockwise direction: **G02**
- In counterclockwise direction: **G03**
- Without programmed direction: **G05**. The TNC traverses the circular arc with the last programmed direction of rotation

- G** 3
- ▶ **Coordinates** of the arc end point
 - ▶ **Radius R**
Note: The algebraic sign determines the size of the arc!
 - ▶ **Miscellaneous function M**
 - ▶ **Feed rate F**

Full circle

For a full circle, program two blocks in succession:

The end point of the first semicircle is the starting point of the second.
The end point of the second semicircle is the starting point of the first.



Central angle CCA and arc radius R

The starting and end points on the contour can be connected with four arcs of the same radius:

Smaller arc: $CCA < 180^\circ$

Enter the radius with a positive sign $R > 0$

Larger arc: $CCA > 180^\circ$

Enter the radius with a negative sign $R < 0$

The direction of rotation determines whether the arc is curving outward (convex) or curving inward (concave):

Convex: Direction of rotation **G02** (with radius compensation **G41**)

Concave: Direction of rotation **G03** (with radius compensation **G41**)

Example NC blocks

```
N100 G01 G41 X+40 Y+40 F200 M3 *
```

```
N110 G02 X+70 Y+40 R+20 * (ARC 1)
```

or

```
N110 G03 X+70 Y+40 R+20 * (ARC 2)
```

or

```
N110 G02 X+70 Y+40 R-20 * (ARC 3)
```

or



```
N110 G03 X+70 Y+40 R-20 * (ARC 4)
```



The distance from the starting and end points of the arc diameter cannot be greater than the diameter of the arc.

The maximum radius that can be entered directly is 99.9999 m, with Q parameter programming 210 m.

You can also enter rotary axes A, B and C.



Circular path G06 with tangential connection

The tool moves on an arc that starts tangentially to the previously programmed contour element.

A transition between two contour elements is called tangential when there is no kink or corner at the intersection between the two contours—the transition is smooth.

The contour element to which the tangential arc connects must be programmed immediately before the **G06** block. This requires at least two positioning blocks.

- G** 6
- ▶ **Coordinates** of the arc end point, and if necessary:
 - ▶ **Feed rate F**
 - ▶ **Miscellaneous function M**

Example NC blocks

```
N70 G01 G41 X+0 Y+25 F300 M3 *
```


```
N80 X+25 Y+30 *
```

```
N90 G06 X+45 Y+20 *
```


```
G01 Y+0 *
```



A tangential arc is a two-dimensional operation: the coordinates in the **G06** block and in the contour element preceding it must be in the same plane of the arc!




Example: Linear movements and chamfers with Cartesian coordinates



<code>%LINEAR G71 *</code>	
<code>N10 G30 G17 X+0 Y+0 Z-20 *</code>	Define blank form for graphic workpiece simulation
<code>N20 G31 G90 X+100 Y+100 Z+0 *</code>	
<code>N40 T1 G17 S4000 *</code>	Call tool in the spindle axis and with the spindle speed S
<code>N50 G00 G40 G90 Z+250 *</code>	Retract tool in the spindle axis at rapid traverse
<code>N60 X-10 Y-10 *</code>	Pre-position the tool
<code>N70 G01 Z-5 F1000 M3 *</code>	Move to working depth at feed rate F = 1000 mm/min
<code>N80 G01 G41 X+5 Y+5 F300 *</code>	Approach the contour at point 1, activate radius compensation G41
<code>N90 G26 R5 F150 *</code>	Tangential approach
<code>N100 Y+95 *</code>	Move to point 2
<code>N110 X+95 *</code>	Point 3: first straight line for corner 3
<code>N120 G24 R10 *</code>	Program chamfer with length 10 mm
<code>N130 Y+5 *</code>	Point 4: 2nd straight line for corner 3, 1st straight line for corner 4
<code>N140 G24 R20 *</code>	Program chamfer with length 20 mm
<code>N150 X+5 *</code>	Move to last contour point 1, second straight line for corner 4
<code>N160 G27 R5 F500 *</code>	Tangential exit
<code>N170 G40 X-20 Y-20 F1000 *</code>	Retract tool in the working plane, cancel radius compensation
<code>N180 G00 Z+250 M2 *</code>	Retract in the tool axis, end program
<code>N99999999 %LINEAR G71 *</code>	

Example: Circular movements with Cartesian coordinates




<code>%CIRCULAR G71 *</code>	
<code>N10 G30 G17 X+0 Y+0 Z-20 *</code>	Define blank form for graphic workpiece simulation
<code>N20 G31 G90 X+100 Y+100 Z+0 *</code>	
<code>N40 T1 G17 S4000 *</code>	Call tool in the spindle axis and with the spindle speed S
<code>N50 G00 G40 G90 Z+250 *</code>	Retract tool in the spindle axis at rapid traverse
<code>N60 X-10 Y-10 *</code>	Pre-position the tool
<code>N70 G01 Z-5 F1000 M3 *</code>	Move to working depth at feed rate F = 1000 mm/min
<code>N80 G01 G41 X+5 Y+5 F300 *</code>	Approach the contour at point 1, activate radius compensation G41
<code>N90 G26 R5 F150 *</code>	Tangential approach
<code>N100 Y+85 *</code>	Point 2: first straight line for corner 2
<code>N110 G25 R10 *</code>	Insert radius with R = 10 mm, feed rate: 150 mm/min
<code>N120 X+30 *</code>	Move to point 3: Starting point of the arc
<code>N130 G02 X+70 Y+95 R+30 *</code>	Move to point 4: end point of the arc with G02, radius 30 mm
<code>N140 G01 X+95 *</code>	Move to point 5
<code>N150 Y+40 *</code>	Move to point 6
<code>N160 G06 X+40 Y+5 *</code>	Move to point 7: End point of the arc, circular arc with tangential connection to point 6, TNC automatically calculates the radius



N170 G01 X+5 *	Move to last contour point 1
N180 G27 R5 F500 *	Depart the contour on a circular arc with tangential connection
N190 G40 X-20 Y-20 F1000 *	Retract tool in the working plane, cancel radius compensation
N200 G00 Z+250 M2 *	Retract tool in the tool axis, end of program
N99999999 %CIRCULAR G71 *	



Example: Full circle with Cartesian coordinates



<code>%C-CC G71 *</code>	
<code>N10 G30 G17 X+0 Y+0 Z-20 *</code>	Definition of workpiece blank
<code>N20 G31 G90 X+100 Y+100 Z+0 *</code>	
<code>N40 T1 G17 S3150 *</code>	Tool call
<code>N50 G00 G40 G90 Z+250 *</code>	Retract the tool
<code>N60 I+50 J+50 *</code>	Define the circle center
<code>N70 X-40 Y+50 *</code>	Pre-position the tool
<code>N80 G01 Z-5 F1000 M3 *</code>	Move to working depth
<code>N90 G41 X+0 Y+50 F300 *</code>	Approach starting point, radius compensation G41
<code>N100 G26 R5 F150 *</code>	Tangential approach
<code>N110 G02 X+0 *</code>	Move to the circle end point (= circle starting point)
<code>N120 G27 R5 F500 *</code>	Tangential exit
<code>N130 G01 G40 X-40 Y-50 F1000 *</code>	Retract tool in the working plane, cancel radius compensation
<code>N140 G00 Z+250 M2 *</code>	Retract tool in the tool axis, end of program
<code>N99999999 %C-CC G71 *</code>	

6.5 Path Contours – Polar Coordinates











Overview

With polar coordinates you can define a position in terms of its angle **H** and its distance **R** relative to a previously defined pole **I**, **J**.

Polar coordinates are useful with:

- Positions on circular arcs
- Workpiece drawing dimensions in degrees, e.g. bolt hole circles

Overview of path functions with polar coordinates

Function	Path function key	Tool movement	Required input	Page
Straight line G10 , G11	 + 	Straight line	Polar radius, polar angle of the straight-line end point	Page 218
Circular arc G12 , G13	 + 	Circular path around circle center/pole to arc end point	Polar angle of the arc end point,	Page 219
Circular arc G15	 + 	Circular path corresponding to active direction of rotation	Polar angle of the circle end point	Page 219
Circular arc G16	 + 	Circular arc with tangential connection to the preceding contour element	Polar radius, polar angle of the arc end point	Page 220
Helical interpolation	 + 	Combination of a circular and a linear movement	Polar radius, polar angle of the arc end point, coordinate of the end point in the tool axis	Page 221



Zero point for polar coordinates: pole I, J

You can define the pole CC anywhere in the part program before blocks containing polar coordinates. Set the pole in the same way as you would program the circle center.



- **Coordinates:** Enter Cartesian coordinates for the pole or, if you want to use the last programmed position, enter **G29**. Before programming polar coordinates, define the pole. You can only define the pole in Cartesian coordinates. The pole remains in effect until you define a new pole.

Example NC blocks

```
N120 I+45 J+45 *
```

Straight line at rapid traverse G10 Straight line with feed rate G11 F

The tool moves in a straight line from its current position to the straight-line end point. The starting point is the end point of the preceding block.



- **Polar coordinate radius R:** Enter the distance from the pole CC to the straight-line end point
- **Polar coordinate angle H:** Angular position of the straight-line end point between -360° and $+360^\circ$

The sign of **H** depends on the angle reference axis:

- If the angle from the angle reference axis to **R** is counterclockwise: **H**>0
- If the angle from the angle reference axis to **R** is clockwise: **H**<0

Example NC blocks



```
N120 I+45 J+45 *
```

```
N130 G11 G42 R+30 H+0 F300 M3 *
```

```
N140 H+60 *
```

```
N150 G91 H+60 *
```

```
N160 G90 H+180 *
```



Circular path G12/G13/G15 around pole I, J

The polar coordinate radius **R** is also the radius of the arc. **R** is defined by the distance from the starting point to the pole **I, J**. The last programmed tool position will be the starting point of the arc.

Direction of rotation

- In clockwise direction: **G12**
- In counterclockwise direction: **G13**
- Without programmed direction: **G15**. The TNC traverses the circular arc with the last programmed direction of rotation


- G** 13 ▶ **Polar-coordinates angle H:** Angular position of the arc end point between $-99\,999.9999^\circ$ and $+99\,999.9999^\circ$
- ▶ **Direction of rotation DR**

Example NC blocks

```
N180 I+25 J+25 *
```

```
N190 G11 G42 R+20 H+0 F250 M3 *
```

```
N200 G13 H+180 *
```



Circular path G16 with tangential connection

The tool moves on a circular path, starting tangentially from a preceding contour element.

- G16**
- ▶ **Polar coordinate radius R:** Enter the distance from are end point to the pole **I, J**
 - ▶ **Polar coordinates angle H:** Angular position of the arc end point

Example NC blocks

```
N120 I+40 J+35 *
```

```
N130 G01 G42 X+0 Y+35 F250 M3 *
```


```
N140 G11 R+25 H+120 *
```

```
N150 G16 R+30 H+30 *
```

```
N160 G01 Y+0 *
```



The pole is **not** the center of the contour arc!



Helical interpolation

A helix is a combination of a circular movement in a main plane and a linear movement perpendicular to this plane. You program the circular path in a main plane.

A helix is programmed only in polar coordinates.

Application

- Large-diameter internal and external threads
- Lubrication grooves

Calculating the helix

To program a helix, you must enter the total angle through which the tool is to move on the helix in incremental dimensions, and the total height of the helix.


For calculating a helix that is to be cut in an upward direction, you need the following data:

Thread revolutions n	Thread revolutions + thread overrun at thread beginning and end
Total height h	Thread pitch P times thread revolutions n
Incremental total angle H	Number of revolutions times 360° + angle for beginning of thread + angle for thread overrun
Starting coordinate Z	Pitch P times (thread revolutions + thread overrun at start of thread)

Shape of the helix

The table below illustrates in which way the shape of the helix is determined by the work direction, direction of rotation and radius compensation.

Internal thread	Work direction	Direction of rotation	Radius comp.
Right-handed	Z+	G13	G41
Left-handed	Z+	G12	G42
Right-handed	Z-	G12	G42
Left-handed	Z-	G13	G41
External thread			
Right-handed	Z+	G13	G42
Left-handed	Z+	G12	G41
Right-handed	Z-	G12	G41
Left-handed	Z-	G13	G42



Programming a helix



Always enter the same algebraic sign for the direction of rotation and the incremental total angle **G91 H**. The tool may otherwise move in a wrong path and damage the contour.

For the total angle **G91 H** you can enter a value of -99 999.9999° to +99 999.9999°.

G 12

- ▶ **Polar coordinates angle:** Enter the total angle of tool traverse along the helix in incremental dimensions. **After entering the angle, specify the tool axis with an axis selection key.**
- ▶ **Coordinate:** Enter the coordinate for the height of the helix in incremental dimensions.
- ▶ Enter the **radius compensation** according to the table above.


Example NC blocks: Thread M6 x 1 mm with 5 revolutions

N120 I+40 J+25 *


N130 G01 Z+0 F100 M3 *

N140 G11 G41 R+3 H+270 *

N150 G12 G91 H-1800 Z+5 *




Example: Linear movement with polar coordinates



<code>%LINEARPO G71 *</code>	
<code>N10 G30 G17 X+0 Y+0 Z-20 *</code>	Definition of workpiece blank
<code>N20 G31 G90 X+100 Y+100 Z+0 *</code>	
<code>N40 T1 G17 S4000 *</code>	Tool call
<code>N50 G00 G40 G90 Z+250 *</code>	Define the datum for polar coordinates
<code>N60 I+50 J+50 *</code>	Retract the tool
<code>N70 G10 R+60 H+180 *</code>	Pre-position the tool
<code>N80 G01 Z-5 F1000 M3 *</code>	Move to working depth
<code>N90 G11 G41 R+45 H+180 F250 *</code>	Approach the contour at point 1
<code>N100 G26 R5 *</code>	Approach the contour at point 1
<code>N110 H+120 *</code>	Move to point 2
<code>N120 H+60 *</code>	Move to point 3
<code>N130 H+0 *</code>	Move to point 4
<code>N140 H-60 *</code>	Move to point 5
<code>N150 H-120 *</code>	Move to point 6
<code>N160 H+180 *</code>	Move to point 1
<code>N170 G27 R5 F500 *</code>	Tangential exit
<code>N180 G40 R+60 H+180 F1000 *</code>	Retract tool in the working plane, cancel radius compensation
<code>N190 G00 Z+250 M2 *</code>	Retract in the spindle axis, end of program
<code>N99999999 %LINEARPO G71 *</code>	

Example: Helix



<code>%HELIX G71 *</code>	
<code>N10 G30 G17 X+0 Y+0 Z-20 *</code>	Definition of workpiece blank
<code>N20 G31 G90 X+100 Y+100 Z+0 *</code>	
<code>N40 T1 G17 S1400 *</code>	Tool call
<code>N50 G00 G40 G90 Z+250 *</code>	Retract the tool
<code>N60 X+50 Y+50 *</code>	Pre-position the tool
<code>N70 G29 *</code>	Transfer the last programmed position as the pole
<code>N80 G01 Z-12.75 F1000 M3 *</code>	Move to working depth
<code>N90 G11 G41 R+32 H+180 F250 *</code>	Approach first contour point
<code>N100 G26 R2 *</code>	Connection
<code>N110 G13 G91 H+3240 Z+13.5 F200 *</code>	Helical interpolation
<code>N120 G27 R2 F500 *</code>	Tangential exit
<code>N170 G01 G40 G90 X+50 Y+50 F1000 *</code>	Retract in the tool axis, end program
<code>N180 G00 Z+250 M2 *</code>	



7

**Programming: Data
Transfer from DXF Files**



7.1 Processing DXF Files (Software Option)

Function

DXF files created in a CAD system can be opened directly by the TNC, in order to extract contours or machining positions, and save them as conversational programs or as point files. Plain-language programs acquired in this manner can also be run by older TNC controls, since these contour programs contain only **L** and **CC/C** blocks.

If you process DXF files in the **Programming and Editing** operating mode, the TNC generates contour programs with the file extension **.H** and point files with the extension **.PNT**. If you process DXF files in the **smarT.NC** operating mode, the TNC generates contour programs with the file extension **.HC** and point files with the extension **.HP**.



The DXF files to be processed must be stored on the hard disk of your TNC.

Before loading the file to the TNC, ensure that the name of the DXF file does not contain any blank spaces or illegal special characters.(see "File names" on page 115)


The DXF file to be opened must contain at least one layer.

The TNC supports the most common DXF format, R12 (equivalent to AC1009).

The TNC does not support binary DXF format. When generating the DXF file from a CAD or drawing program, make sure that you save the file in ASCII format.

The following DXF elements are selectable as contours:

- LINE (straight line)
- CIRCLE (complete circle)
- ARC (circular arc)
- POLYLINE



Opening a DXF file



- ▶ Select the Programming and Editing operating mode



- ▶ Call the file manager



- ▶ In order to see the soft-key menu for selecting the file type to be displayed, press the SELECT TYPE soft key



- ▶ In order to show all DXF files, press the SHOW DXF soft key









- ▶ Select the directory in which the DXF file is saved
- ▶ Select the desired DXF file, and load it with the ENT key. The TNC starts the DXF converter and shows the contents of the DXF file on the screen. The TNC shows the layers in the left window, and the drawing in the right window.



Basic settings

The third soft-key row has various possibilities for settings:

Setting	Soft key
Show/hide rulers: The TNC shows the rulers at the left and top edges of the drawing. The values shown on the ruler are based on the drawing datum.	
Show/hide status bar: The TNC shows the status bar at the bottom edge of the drawing. The following information is shown in the status bar: <ul style="list-style-type: none"> Active unit of measure (MM or INCH) X and Y coordinates of the current mouse position In the SELECT CONTOUR mode, the TNC shows whether the selected contour is open (open contour) or closed (closed contour). 	
Unit of measure MM/INCH: Enter the unit of measurement of the DXF file. The TNC then outputs the contour program in this unit of measurement.	
The tolerance specifies how far apart neighboring contour elements may be from each other. You can use the tolerance to compensate for inaccuracies that occurred when the drawing was made. The default setting depends on the extent of the entire DXF file.	
The resolution specifies how many decimal places the TNC should use when generating the contour program. Default setting: 4 decimal places (equivalent to resolution of 0.1 µm when the unit of measure MM is active).	



Setting**Soft key**

The mode for point transfer on circles and circle segments determines whether the TNC automatically loads the circle center point when selecting machining positions via mouse click (OFF), or if additional points on the circle should be shown as well.



- OFF

Do not show additional points on the circle. Assume the circle center point directly when a circle or arc is clicked.

- Enable

Do show additional points on the circle. Assume each desired circle point by clicking it

Mode for point assumption: Specify whether the TNC should display the tool path during selection of machining positions.



Please note that you must set the correct unit of measure, since the DXF file does not contain any such information.

If you want to generate programs for older TNC controls, you must limit the resolution to three decimal places. In addition, you must remove the comments that the DXF converter inserts into the contour program.



Layer settings

As a rule, DXF files contain multiple layers, with which the designer organizes the drawing. The designer uses the layers to create groups of various types of elements, such as the actual workpiece contour, dimensions, auxiliary and design lines, shadings, and texts.

So that as little unnecessary information as possible appears on the screen during selection of the contours, you can hide all excessive layers contained in the DXF file.




The DXF file to be processed must contain at least one layer.

You can even select a contour if the designer has saved it on different layers.

SET
LAYER

- ▶ If it has not already been activated, select the mode for the layer settings. In the left window the TNC shows all layers contained in the active DXF file
- ▶ To hide a layer, select the layer with the left mouse button, and click its check box to hide it
- ▶ To show a layer, select the layer with the left mouse button, and click its check box again to show it



Specifying the reference point

The datum of the drawing for the DXF file is not always located in a manner that lets you use it directly as a reference point for the workpiece. Therefore, the TNC has a function with which you can shift the drawing datum to a suitable location by clicking an element.


You can define a reference point at the following locations:

- At the beginning, end or center of a straight line
- At the beginning or end of a circular arc
- At the transition between quadrants or at the center of a complete circle
- At the intersection between:
 - A straight line and a straight line, even if the intersection is actually on the extension of one of the lines
 - A straight line and circular arc
 - A straight line and full circle
 - A circle and circle (regardless of whether a circular arc or a full circle)



You must use the touchpad on the TNC keyboard or a mouse attached via the USB port in order to specify a reference point.

You can also change the reference point once you have already selected the contour. The TNC does not calculate the actual contour data until you save the selected contour in a contour program.



Selecting a reference point on a single element



- ▶ Select the mode for specifying the reference point
- ▶ Click the element on which you want to set the reference point with the left mouse button. The TNC indicates possible locations for reference points on the selected element with stars
- ▶ Click the star you want to select as reference point. The TNC sets the reference-point symbol to the selected location. Use the zoom function if the selected element is too small

Selecting a reference point on the intersection of two elements



- ▶ Select the mode for specifying the reference point
- ▶ Click the first element (straight line, complete circle or circular arc) with the left mouse button. The TNC indicates possible locations for reference points on the selected element with stars
- ▶ Click the second element (straight line, complete circle or circular arc) with the left mouse button. The TNC sets the reference-point symbol on the intersection




The TNC calculates the intersection of two elements even if it is on the extension of one of these elements.

If the TNC calculates multiple intersections, it selects the intersection nearest the mouse-click on the second element.

If the TNC cannot calculate an intersection, it rescinds the marking of the first element.

Element information

At the bottom left of the screen, the TNC shows how far the reference point you haven chosen is located from the drawing datum.



Selecting and saving a contour



You must use the touchpad on the TNC keyboard or a mouse attached via the USB port in order to select a contour.

If you are not using the contour program in the **smarT.NC** operating mode, you must specify the machining sequence when selecting the contour that it matches the desired machining direction.

Select the first contour element such that approach without collision is possible.


If the contour elements are very close to one another, use the zoom function.

SELECT
CONTOUR

- ▶ Select the mode for choosing a contour. The TNC hides the layers shown in the left window, and the right window becomes active for contour selection.
- ▶ To select a contour element, click the desired contour element with the left mouse button. The selected contour element turns blue. At the same time, the TNC marks the selected element with a symbol (circle or line) in the left window.
- ▶ To select the next contour element, click the desired contour element with the left mouse button. The selected contour element turns blue. If further contour elements in the selected machining sequence are clearly selectable, these elements turn green. Click on the last green element to assume all elements into the contour program. The TNC shows all selected contour elements in the left window. The TNC displays elements that are still green in the **NC** column without a check mark. The TNC does not save these elements to the contour program
- ▶ If necessary you can also deselect elements that you already selected, by clicking the element in the right window again, but this time while pressing the CTRL key.



If you have selected polylines, the TNC shows a two-level ID number in the left window. The first number is the serial contour element number, the second element is the element number of the respective polyline from the DXF file.





▶ To save the selected contour elements in a plain-language program, enter any file name in the pop-up window displayed by the TNC. Default setting: Name of the DXF file. If the name of the DXF file contains special characters or spaces, the TNC replaces the characters with underscores



▶ Confirm the entry: The TNC saves the contour program in the directory in which the DXF file is also saved



▶ If you want to select more contours: Press the CANCEL SELECTED ELEMENTS soft key and select the next contour as described above



The TNC also transfers two workpiece-blank definitions (**BLK FORM**) to the contour program. The first definition contains the dimensions of the entire DXF file. The second one, which is the active one, contains only the selected contour elements, so that an optimized size of the workpiece blank results.

The TNC only saves elements that have actually been selected (blue elements), which means that they have been given a check mark in the left window.



Dividing, extending and shortening contour elements

If contour elements to be selected in the drawing connect poorly, then you must first divide the contour element. This function is automatically available if you are in the mode for selecting a contour.

Proceed as follows:

- ▶ The poorly connecting contour element is selected, so it is colored blue.
- ▶ Click the contour element to be divided: The TNC shows the point of intersection with a star in a circle, and the selectable end points with simple stars.
- ▶ Press the CTRL key and click the point of intersection: The TNC divides the contour element at the point of intersection and the stars disappear. If there is a gap, or the elements overlap, the TNC extends or shortens these poorly connecting contour element to the point of intersection of the two elements.
- ▶ Click the divided contour element again: The TNC shows the end points and points of intersection again.
- ▶ Click the desired end point: The TNC now colors the divided element blue.
- ▶ Select the next contour element.





If the contour element to be extended or shortened is a straight line, then the TNC extends the contour element along the same line. If the contour element to be extended or shortened is a circular arc, then the TNC extends/shortens the contour element along the same arc.

In order to use this function, at least two contour elements must already be selected, so that the direction is clearly determined.

Element information

At the bottom left of the screen, the TNC displays information about the contour element that you last selected via mouse click in the left or right window.

- Straight line
End point of the straight line, and the starting point is grayed out
- Circle or arc
Circle center point, circle end point, and direction of rotation. Grayed out: the starting point and circle radius



Selecting and storing machining positions




You must use the touchpad on the TNC keyboard or a mouse attached via the USB port in order to select a machining position.

If the positions to be selected are very close to one another, use the zoom function.

If required, configure the basic settings so that the TNC shows the tool paths (see “Basic settings” on page 228).

Three possibilities are available in the pattern generator for defining machining positions:

- Individual selection:
You select the desired machining position through individual mouse clicks (see “Individual selection” on page 237)
- Quick selection of hole positions in an area defined by the mouse:
By dragging the mouse to define an area, you can select all the hole positions within it (see “Quick selection of hole positions in an area defined by the mouse” on page 238)
- Quick selection of hole positions by entering a diameter:
By entering a hole diameter, you can select all hole positions with that diameter in the DXF file (see “Quick selection of hole positions by entering a diameter” on page 239)



Individual selection


SELECT POSITION

- ▶ Select the mode for choosing a machining position. The TNC hides the layers shown in the left window, and the right window becomes active for position selection.
- ▶ In order to select a machining position, click the desired element with the left mouse button. The TNC indicates possible locations for machining positions on the selected element with stars. Click one of the stars: The TNC loads the selected position into the left window (displays a point symbol). If you click a circle, the TNC adopts the circle center as machining position.
- ▶ If necessary you can also deselect elements that you already selected, by clicking the element in the right window again, but this time while pressing the CTRL key (click inside the marked area).
- ▶ If you want to specify the machining position at the intersection of two elements, click the first element with the right mouse button: the TNC displays stars at the selectable machining positions.
- ▶ Click the second element (straight line, complete circle or circular arc) with the left mouse button. The TNC loads the intersection of the elements into the left window (displays a point symbol).
- ▶ To save the selected machining positions in a points file, enter any file name in the pop-up window displayed by the TNC. Default setting: Name of the DXF file. If the name of the DXF file contains special characters or spaces, the TNC replaces the characters with underscores.
- ▶ Confirm the entry: The TNC saves the contour program in the directory in which the DXF file is also saved.
- ▶ If you want to select more machining positions in order to save them in a different file, press the CANCEL SELECTED ELEMENTS soft key and select as described above.

SAVE SELECTED ELEMENTS

ENT

CANCEL SELECTED ELEMENTS




Quick selection of hole positions in an area defined by the mouse

SELECT
POSITION

- ▶ Select the mode for choosing a machining position. The TNC hides the layers shown in the left window, and the right window becomes active for position selection.
- ▶ Press the shift key on the keyboard and drag the left mouse key to define an area in which the TNC is to adopt all included circle centers as hole positions: the TNC opens a window in which you can filter the holes by size.
- ▶ Configure the filter settings (see “Filter settings” on page 240) and click the **Use** button to confirm: The TNC loads the selected positions into the left window (displays a point symbol).
- ▶ If necessary you can also deselect elements that you already selected, by dragging an area open again, but this time while pressing the CTRL key.
- ▶ To save the selected machining positions in a points file, enter any file name in the pop-up window displayed by the TNC. Default setting: Name of the DXF file. If the name of the DXF file contains special characters or spaces, the TNC replaces the characters with underscores.
- ▶ Confirm the entry: The TNC saves the contour program in the directory in which the DXF file is also saved.
- ▶ If you want to select more machining positions in order to save them in a different file, press the CANCEL SELECTED ELEMENTS soft key and select as described above.

SAVE
SELECTED
ELEMENTS

ENT

CANCEL
SELECTED
ELEMENTS

Quick selection of hole positions by entering a diameter

SELECT POSITION

- ▶ Select the mode for choosing a machining position. The TNC hides the layers shown in the left window, and the right window becomes active for position selection.



SELECT DIAMETERS

- ▶ Select the last soft-key row.
- ▶ Open the dialog for diameter input: enter any diameter in the pop-up window displayed by the TNC.
- ▶ Enter the desired diameter and confirm it with the ENT key: the TNC searches the DXF file for the entered diameter and then shows a pop-up window with the diameter selected that is closest to the diameter you entered. Also, you can retroactively filter the holes according to size.
- ▶ If required, configure the filter settings (see “Filter settings” on page 240) and click the **Use** button to confirm: The TNC loads the selected positions into the left window (displays a point symbol).
- ▶ If necessary you can also deselect elements that you already selected, by dragging an area open again, but this time while pressing the CTRL key.

SAVE SELECTED ELEMENTS


- ▶ To save the selected machining positions in a points file, enter any file name in the pop-up window displayed by the TNC. Default setting: Name of the DXF file. If the name of the DXF file contains special characters or spaces, the TNC replaces the characters with underscores.

ENT

- ▶ Confirm the entry: The TNC saves the contour program in the directory in which the DXF file is also saved.

CANCEL SELECTED ELEMENTS

- ▶ If you want to select more machining positions in order to save them in a different file, press the CANCEL SELECTED ELEMENTS soft key and select as described above.





Filter settings

After you have used the quick selection function to mark hole positions, a pop-up window appears in which the smallest diameter found is to the left and the largest diameter to the right. With the buttons just below the diameter display you can adjust the smallest diameter in the left area and largest in the right area so that you can load the hole diameters that you want.

The following buttons are available:

Filter setting of smallest diameter	Soft key
Display the smallest diameter found (default setting)	<<
Display the next smaller diameter found	<
Display the next larger diameter found	>
Display the largest diameter found. The TNC sets the filter for the smallest diameter to the value set for the largest diameter	>>
Filter setting of largest diameter	Soft key
Display the smallest diameter found. The TNC sets the filter for the largest diameter to the value set for the smallest diameter	<<
Display the next smaller diameter found	<
Display the next larger diameter found	>
Display the largest diameter found (default setting)	>>

With the **apply path optimization** option on (default setting), the TNC sorts the selected machining positions for the most efficient possible tool path. You can have the tool path displayed by clicking the SHOW TOOL PATH soft key (see "Basic settings" on page 228).




Element information

At the bottom left of the screen, the TNC displays the coordinates of the machining position that you last selected via mouse click in the left or right window

Undoing actions








You can undo the four most recent actions that you have taken in the mode for selecting machining positions. The last soft key row provides the following soft keys for this purpose:

Function	Soft key
Undo the most recently conducted action	UNDO ACTION
Repeat the most recently conducted action	REPEAT THE ACTION




Zoom function


The TNC features a powerful zoom function for easy recognition of small details during contour or point selection.

Function	Soft key
Magnify workpiece. The TNC always magnifies the center of the view currently being displayed. Use the scroll bars to position the drawing in the window so that the desired section appears after the soft key has been pressed.	
Reduce workpiece	
Show workpiece at original size	
Move zoomed area upward	
Move zoomed area downward	
Move zoomed area to the left	
Move zoomed area to the right	



If you have a wheel mouse, you can use it to zoom in and out. The zooming center is the location of the mouse pointer.





8

**Programming:
Subprograms and
Program Section
Repeats**



8.1 Labeling Subprograms and Program Section Repeats

Subprograms and program section repeats enable you to program a machining sequence once and then run it as often as desired.

Labels

The beginnings of subprograms and program section repeats are marked in a part program by labels (**G98 L**).

A LABEL is identified by a number between 1 and 999 or by a name you define. Each LABEL number or LABEL name can be set only once in the program with the LABEL SET key or by entering **G98**. The number of label names you can enter is only limited by the internal memory.



If a label name or number is set more than once, the TNC sends an error message at the end of the **G98** block. With very long programs, you can limit the number of blocks to be checked for repeated labels with MP7229.

Label 0 (**G98 L0**) is used exclusively to mark the end of a subprogram and can therefore be used as often as desired.

8.2 Subprograms

Operating sequence

- 1 The TNC executes the part program up to the block in which a subprogram is called with **Ln,0**
- 2 The subprogram is then executed from beginning to end. The subprogram end is marked **G98 L0**
- 3 The TNC then resumes the part program from the block after the subprogram call **Ln,0**


Programming notes

- A main program can contain up to 254 subprograms
- You can call subprograms in any sequence and as often as desired
- A subprogram cannot call itself
- Write subprograms at the end of the main program (behind the block with M2 or M30)
- If subprograms are located before the block with M2 or M30, they will be executed at least once even if they are not called

Programming a subprogram

LBL
SET

- ▶ To mark the beginning, press the LBL SET key
- ▶ Enter the subprogram number. If you want to use a label name, press the LBL NAME soft key to switch to text entry
- ▶ To mark the end, press the LBL SET key and enter the label number "0"



Calling a subprogram



- ▶ To call a subprogram, press the LBL CALL key.
- ▶ **Call subprogram /repeat:** Enter the label number of the subprogram you wish to call. If you want to use a label name, press the LBL NAME soft key to switch to text entry. If you want to enter the number of a string parameter as target address: Press the QS soft key; the TNC will then jump to the label name that is specified in the string parameter defined.



G98 L 0 is not permitted (Label 0 is only used to mark the end of a subprogram).



8.3 Program Section Repeats

Label G98

The beginning of a program section repeat is marked by the label **G98 L**. The end of a program section repeat is identified by **Ln,m**.

Operating sequence

- 1 The TNC executes the part program up to the end of the program section (**Ln,m**)
- 2 Then the program section between the called LBL **Ln,m** is repeated the number of times entered after **M**
- 3 The TNC then resumes the part program after the last repetition

Programming notes

- You can repeat a program section up to 65 534 times in succession
- The total number of times the program section is executed is always one more than the programmed number of repeats

Programming a program section repeat


LBL
SET

- ▶ To mark the beginning, press the LBL SET key and enter a LABEL NUMBER for the program section you wish to repeat. If you want to use a label name, press the LBL NAME soft key to switch to text entry
- ▶ Enter the program section

Calling a program section repeat

LBL
CALL

- ▶ Press the LBL CALL key.
- ▶ **Call subprogram /repeat:** Enter the label number of the subprogram you wish to call. If you want to use a label name, press the LBL NAME soft key to switch to text entry. If you want to enter the number of a string parameter as target address: Press the QS soft key; the TNC will then jump to the label name that is specified in the string parameter defined.
- ▶ **Repeat REP:** Enter the number of repeats, then confirm with the ENT key.



8.4 Separate Program as Subprogram

Operating sequence

- 1 The TNC executes the part program up to the block in which another program is called with %
- 2 Then the other program is run from beginning to end
- 3 The TNC then resumes the first (calling) part program with the block after the program call

Programming notes

- No labels are needed to call any program as a subprogram
- The called program must not contain the miscellaneous functions M2 or M30. If you have defined subprograms with labels in the called program, you can then use M2 or M30 with the **D09 P01 +0 P02 +0 P03 99** jump function to force a jump over this program section
- The called program must not contain a % call into the calling program, otherwise an infinite loop will result

Calling any program as a subprogram



- ▶ To select the functions for program call, press the PGM CALL key.




- ▶ Press the PROGRAM soft key.



- ▶ Press the WINDOW SELECTION soft key: The TNC superimposes a window where you can select the program to be called.
- ▶ Select a program with the arrow keys or by mouse click and confirm by pressing ENT: The TNC enters the complete path name in the **CALL PGM** block.
- ▶ Conclude this function with the END key.

Alternatively you can also enter the program name or the complete path name of the program to be called directly via the keyboard.





The program you are calling must be stored on the hard disk of your TNC.

You need only enter the program name if the program you want to call is located in the same directory as the program you are calling it from.

If the called program is not located in the same directory as the program you are calling it from, you must enter the complete path, e.g. **TNC:\ZW35\SCHRUPP\PGM1.H** or you can select the program via the WINDOW SELECTION soft key.

If you want to call a DIN/ISO program, enter the file type **.I** after the program name.

You can also call a program with **G39**.

As a rule, Q parameters are effective globally with a **%**. So please note that changes to Q parameters in the called program can also influence the calling program.



Danger of collision!

Coordinate transformations that you define in the called program remain in effect for the calling program too, unless you reset them. The setting of machine parameter MP7300 has no influence on this.



8.5 Nesting

Types of nesting

- Subprograms within a subprogram
- Program section repeats within a program section repeat
- Subprograms repeated
- Program section repeats within a subprogram

Nesting depth

The nesting depth is the number of successive levels in which program sections or subprograms can call further program sections or subprograms.

- Maximum nesting depth for subprograms: 8
- Maximum nesting depth for main program calls: 6, where a **G79** acts like a main program call
- You can nest program section repeats as often as desired



Subprogram within a subprogram

Example NC blocks

<code>%SUBPGMS G71 *</code>	
<code>...</code>	
<code>N17 L "UP1",0 *</code>	Subprogram at label G98 L1 is called
<code>...</code>	
<code>N35 G00 G40 Z+100 M2 *</code>	Last program block of the main program (with M2)
<code>N36 G98 L "UP1"</code>	Beginning of subprogram SP1
<code>...</code>	
<code>N39 L2,0 *</code>	Subprogram at label G98 L2 is called
<code>...</code>	
<code>N45 G98 L0 *</code>	End of subprogram 1
<code>N46 G98 L2 *</code>	Beginning of subprogram 2
<code>...</code>	
<code>N62 G98 L0 *</code>	End of subprogram 2
<code>N99999999 %SUBPGMS G71 *</code>	

Program execution

- 1 Main program SUBPGMS is executed up to block 17.
- 2 Subprogram SP1 is called, and executed up to block 39
- 3 Subprogram 2 is called, and executed up to block 62. End of subprogram 2 and return jump to the subprogram from which it was called
- 4 Subprogram 1 is executed from block 40 up to block 45. End of subprogram 1 and return jump to the main program SUBPGMS
- 5 Main program SUBPGMS is executed from block 18 up to block 35. Return jump to block 1 and end of program



Repeating program section repeats

Example NC blocks

0 BEGIN PGM REPS MM	
...	
15 LBL 1	Beginning of program section repeat 1
...	
20 LBL 2	Beginning of program section repeat 2
...	
27 CALL LBL 2 REP 2	The program section between LBL 2 and this block
...	(block 20) is repeated twice
35 CALL LBL 1 REP 1	The program section between LBL 1 and this block
...	(block 15) is repeated once
50 END PGM REPS MM	

%REPS G71 *	
...	
N15 G98 L1 *	Beginning of program section repeat 1
...	
N20 G98 L2 *	Beginning of program section repeat 2
...	
N27 L2,2 *	Program section between this block and G98 L2
...	(block N200) is repeated twice
N35 L1,1 *	Program section between this block and G98 L1
...	(block N150) is repeated once
N99999999 %REPS G71 *	

Program execution

- 1 Main program REPS is executed up to block 27.
- 2 Program section between block 20 and block 27 is repeated twice
- 3 Main program REPS is executed from block 28 to block 35.
- 4 Program section between block 15 and block 35 is repeated once (including the program section repeat between 20 and block 27)
- 5 Main program REPS is executed from block 36 to block 50 (end of program).



Repeating a subprogram

Example NC blocks

<code>%SUBPGREP G71 *</code>	
<code>...</code>	
<code>N10 G98 L1 *</code>	Beginning of program section repeat 1
<code>N11 L2,0 *</code>	Subprogram call
<code>N12 L1,2 *</code>	Program section between this block and G98 L1
<code>...</code>	(block N100) is repeated twice
<code>N19 G00 G40 Z+100 M2 *</code>	Last block of the main program with M2
<code>N20 G98 L2 *</code>	Beginning of subprogram
<code>...</code>	
<code>N28 G98 L0 *</code>	End of subprogram
<code>N99999999 %SUBPGREP G71 *</code>	

Program execution

- 1 Main program UPGREP is executed up to block 11.
- 2 Subprogram 2 is called and executed.
- 3 Program section between block 10 and block 12 is repeated twice. Subprogram 2 is repeated twice.
- 4 Main program SPGREP is executed from block 13 to block 19. End of program.




8.6 Programming Examples

Example: Milling a contour in several infeeds

Program sequence

- Pre-position the tool to the workpiece surface
- Enter the infeed depth in incremental values
- Contour milling
- Repeat infeed and contour-milling



<code>%PGMWDH G71 *</code>	
<code>N10 G30 G17 X+0 Y+0 Z-40 *</code>	
<code>N20 G31 G90 X+100 Y+100 Z+0 *</code>	
<code>N40 T1 G17 S3500 *</code>	Tool call
<code>N50 G00 G40 G90 Z+250 *</code>	Retract the tool
<code>N60 I+50 J+50 *</code>	Set pole
<code>N70 G10 R+60 H+180 *</code>	Pre-position in the working plane
<code>N80 G01 Z+0 F1000 M3 *</code>	Pre-position to the workpiece surface


N90 G98 L1 *	Set label for program section repeat
N100 G91 Z-4 *	Infeed depth in incremental values (in space)
N110 G11 G41 G90 R+45 H+180 F250 *	First contour point
N120 G26 R5 *	Contour approach
N130 H+120 *	
N140 H+60 *	
N150 H+0 *	
N160 H-60 *	
N170 H-120 *	
N180 H+180 *	
N190 G27 R5 F500 *	Contour departure
N200 G40 R+60 H+180 F1000 *	Retract tool
N210 L1.4 *	Return jump to label 1; section is repeated a total of 4 times
N220 G00 Z+250 M2 *	Retract in the tool axis, end program
N99999999 %PGMREP G71 *	



Example: Groups of holes

Program sequence

- Approach the groups of holes in the main program
- Call the group of holes (subprogram 1)
- Program the group of holes only once in subprogram 1



<code>%UP1 G71 *</code>	
<code>N10 G30 G17 X+0 Y+0 Z-40 *</code>	
<code>N20 G31 G90 X+100 Y+100 Z+0 *</code>	
<code>N40 T1 G17 S3500 *</code>	Tool call
<code>N50 G00 G40 G90 Z+250 *</code>	Retract the tool
<code>N60 G200 DRILLING</code>	Cycle definition: drilling
<code>Q200=2 ;SETUP CLEARANCE</code>	
<code>Q201=-30 ;DEPTH</code>	
<code>Q206=300 ;FEED RATE FOR PLNGN</code>	
<code>Q202=5 ;PLUNGING DEPTH</code>	
<code>Q210=0 ;DWELL TIME AT TOP</code>	
<code>Q203=+0 ;SURFACE COORDINATE</code>	
<code>Q204=2 ;2ND SETUP CLEARANCE</code>	
<code>Q211=0 ;DWELL TIME AT DEPTH</code>	


N70 X+15 Y+10 M3 *	Move to starting point for group 1
N80 L1.0 *	Call the subprogram for the group
N90 X+45 Y+60 *	Move to starting point for group 2
N100 L1.0 *	Call the subprogram for the group
N110 X+75 Y+10 *	Move to starting point for group 3
N120 L1.0 *	Call the subprogram for the group
N130 G00 Z+250 M2 *	End of main program
N140 G98 L1 *	Beginning of subprogram 1: Group of holes
N150 G79 *	Call cycle for 1st hole
N160 G91 X+20 M99 *	Move to 2nd hole, call cycle
N170 Y+20 M99 *	Move to 3rd hole, call cycle
N180 X-20 G90 M99 *	Move to 4th hole, call cycle
N190 G98 L0 *	End of subprogram 1
N99999999 %UP1 G71 *	



Example: Group of holes with several tools

Program sequence

- Program the fixed cycles in the main program
- Call the entire hole pattern (subprogram 1)
- Approach the groups of holes in subprogram 1, call group of holes (subprogram 2)
- Program the group of holes only once in subprogram 2




<code>%UP2 G71 *</code>	
<code>N10 G30 G17 X+0 Y+0 Z-40 *</code>	
<code>N20 G31 G90 X+100 Y+100 Z+0 *</code>	
<code>N60 T1 G17 S5000 *</code>	Call tool: center drill
<code>N70 G00 G40 G90 Z+250 *</code>	Retract the tool
<code>N80 G200 DRILLING</code>	Cycle definition: CENTERING
<code>Q200=2 ;SETUP CLEARANCE</code>	
<code>Q201=-3 ;DEPTH</code>	
<code>Q206=250 ;FEED RATE FOR PLNGN</code>	
<code>Q202=3 ;PLUNGING DEPTH</code>	
<code>Q210=0 ;DWELL TIME AT TOP</code>	
<code>Q203=+0 ;SURFACE COORDINATE</code>	
<code>Q204=10 ;2ND SETUP CLEARANCE</code>	
<code>Q211=0.2 ;DWELL TIME AT DEPTH</code>	
<code>N90 L1.0 *</code>	Call subprogram 1 for the entire hole pattern



N100 G00 Z+250 M6 *	Tool change
N110 T2 G17 S4000 *	Call tool: drill
N120 D0 Q201 P01 -25 *	New depth for drilling
N130 D0 Q202 P01 +5 *	New plunging depth for drilling
N140 L1.0 *	Call subprogram 1 for the entire hole pattern
N150 G00 Z+250 M6 *	Tool change
N160 T3 G17 S500 *	Call tool: reamer
N80 G201 REAMING	Cycle definition: REAMING
Q200=2 ;SETUP CLEARANCE	
Q201=-15 ;DEPTH	
Q206=250 ;FEED RATE FOR PLNGNG	
Q211=0.5 ;DWELL TIME AT DEPTH	
Q208=400 ;RETRACTION FEED RATE	
Q203=+0 ;SURFACE COORDINATE	
Q204=10 ;2ND SETUP CLEARANCE	
N180 L1.0 *	Call subprogram 1 for the entire hole pattern
N190 G00 Z+250 M2 *	End of main program
N200 G98 L1 *	Beginning of subprogram 1: Entire hole pattern
N210 G00 G40 G90 X+15 Y+10 M3 *	Move to starting point for group 1
N220 L2.0 *	Call subprogram 2 for the group
N230 X+45 Y+60 *	Move to starting point for group 2
N240 L2.0 *	Call subprogram 2 for the group
N250 X+75 Y+10 *	Move to starting point for group 3
N260 L2.0 *	Call subprogram 2 for the group
N270 G98 L0 *	End of subprogram 1
N280 G98 L2 *	Beginning of subprogram 2: Group of holes
N290 G79 *	Call cycle for 1st hole
N300 G91 X+20 M99 *	Move to 2nd hole, call cycle
N310 Y+20 M99 *	Move to 3rd hole, call cycle
N320 X-20 G90 M99 *	Move to 4th hole, call cycle
N330 G98 L0 *	End of subprogram 2
N340 %UP2 G71 *	







9

**Programming:
Q Parameters**



9.1 Principle and Overview


You can program entire families of parts in a single part program. You do this by entering variables called Q parameters instead of fixed numerical values.

Q parameters can represent information such as:

- Coordinate values
- Feed rates
- Spindle speeds
- Cycle data

Q parameters also enable you to program contours that are defined with mathematical functions. You can also use Q parameters to make the execution of machining steps depend on logical conditions.

Q parameters are designated by letters and a number between 0 and 1999. Parameters that take effect in different manners are available. Please refer to the following table:



Meaning	Range
Freely applicable parameters, as long as no overlapping with SL cycles can occur, globally effective for all programs stored in the TNC memory	Q0 to Q99
Parameters for special TNC functions	Q100 to Q199
Parameters that are primarily used for cycles, globally effective for all programs stored in the TNC memory	Q200 to Q1199
Parameters that are primarily used for OEM cycles, and are globally effective for all programs stored in the TNC memory. This may require coordination with the machine manufacturer or supplier	Q1200 to Q1399
Parameters that are primarily used for call-active OEM cycles, globally effective for all programs that are stored in the TNC memory	Q1400 to Q1499
Parameters that are primarily used for Def-active OEM cycles, globally effective for all programs that are stored in the TNC memory	Q1500 to Q1599
Freely applicable parameters, globally effective for all programs stored in the TNC memory	Q1600 to Q1999
Freely usable QL parameters, only effective locally (within a program)	QL0 to QL499
Freely usable QR parameters that are nonvolatile, i.e. they remain in effect even after a power interruption	QR0 to QR499



QS parameters (the **S** stands for string) are also available on the TNC and enable you to process texts. In principle, the same ranges are available for **QS** parameters as for **Q** parameters (see table above).



Note that for the **QS** parameters the **QS100** to **QS199** range is reserved for internal texts.



Programming notes

You can mix Q parameters and fixed numerical values within a program.

Q parameters can be assigned numerical values between 999 999 999 and +999 999 999, meaning that up to nine digits plus the algebraic sign are permitted. You can set the decimal point at any position. Internally, the TNC can calculate up to a range of 57 bits before and 7 bits after the decimal point (32-bit data width corresponds to a decimal value of 4 294 967 296).

You can assign a maximum of 254 characters to **QS** parameters.



Some Q and QS parameters are always assigned the same data by the TNC. For example, **Q108** is always assigned the current tool radius (see "Preassigned Q Parameters", page 296).








If you are using the parameters **Q60** to **Q99** in encoded OEM cycles, use MP7251 to define whether the parameters are only to be used locally in the OEM cycles (.CYC file), or can be used globally for all programs.

With MP7300 you specify whether the TNC should reset Q parameters at the end of the program, or if the values should be saved. Make sure that this setting does not have any effect on your Q parameter programs!



Calling Q-parameter functions

When you are writing a part program, press the “Q” key (in the numeric keypad for numerical input and axis selection, below the +/- key). The TNC then displays the following soft keys:

Function group	Soft key	Page
Basic arithmetic (assign, add, subtract, multiply, divide, square root)		Page 267
Trigonometric functions		Page 269
If/then conditions, jumps		Page 271
Other functions		Page 274
Entering formulas directly		Page 281
Function for machining complex contours		Cycles Manual
Function for string processing		Page 285



The TNC opens the dialog for formula entry directly when you press the Q key on the ASCII keyboard.

In order to define or assign **QL** local parameters, first press the Q key in any dialog, and then press the L on the ASCII keyboard.

In order to define or assign **QR** nonvolatile parameters, first press the Q key in any dialog, and then press the R on the ASCII keyboard.



9.2 Part Families — Q Parameters in Place of Numerical Values

Function

The Q parameter function **D0: ASSIGN** assigns numerical values to Q parameters. This enables you to use variables in the program instead of fixed numerical values.

Example NC blocks

N150 D00 Q10 P01 +25 *	Assignment
...	Q10 is assigned the value 25
N250 G00 X +Q10 *	Corresponds to G00 X +25

You need write only one program for a whole family of parts, entering the characteristic dimensions as Q parameters.

To program a particular part, you then assign the appropriate values to the individual Q parameters.

Example

Cylinder with Q parameters

Cylinder radius

$$R = Q1$$

Cylinder height

$$H = Q2$$

Cylinder Z1


$$Q1 = +30$$

$$Q2 = +10$$

Cylinder Z2

$$Q1 = +10$$

$$Q2 = +50$$









9.3 Describing Contours through Mathematical Operations

Function

The Q parameters listed below enable you to program basic mathematical functions in a part program:

- ▶ Select a Q-parameter function: Press the Q key (in the numerical keypad at right). The Q parameter functions are displayed in a soft key row
- ▶ To select the mathematical functions, press the BASIC ARITHMETIC soft key. The TNC then displays the following soft keys:

Overview

Function	Soft key
D00: ASSIGN Example: D00 Q5 P01 +60 * Assigns a numerical value.	
D01: ADDITION Example: D01 Q1 P01 -Q2 P02 -5 * Calculates and assigns the sum of two values.	
D02: SUBTRACTION Example: D02 Q1 P01 +10 P02 +5 * Calculates and assigns the difference of two values.	
D03: MULTIPLICATION Example: D03 Q2 P01 +3 P02 +3 * Calculates and assigns the product of two values.	
D04: DIVISION Example: D04 Q4 P01 +8 P02 +Q2 * Calculates and assigns the quotient of two values. Not permitted: Division by 0	
D05: SQUARE ROOT Example: D05 Q50 P01 4 * Calculates and assigns the square root of a number. Not permitted: Calculating the square root of a negative value!	

To the right of the "=" character you can enter the following:

- Two numbers
- Two Q parameters
- A number and a Q parameter

The Q parameters and numerical values in the equations can be entered with positive or negative signs.



Programming fundamental operations

Example:

Q Call the Q parameter functions by pressing the Q key

BASIC ARITHM. To select the mathematical functions, press the BASIC ARITHMETIC soft key

D0 X = Y To select the Q parameter function ASSIGN, press the D0 X = Y soft key

PARAMETER NO. FOR RESULT?

5 **ENT** Enter the number of the Q parameter, e.g. 5

1ST VALUE OR PARAMETER?

10 **ENT** Assign the value 10 to Q5

Q Call the Q parameter functions by pressing the Q key

BASIC ARITHM. To select the mathematical functions, press the BASIC ARITHMETIC soft key

D3 X * Y To select the Q parameter function MULTIPLICATION, press the D3 X * Y soft key

PARAMETER NO. FOR RESULT?

12 **ENT** Enter the number of the Q parameter, e.g. 12

1ST VALUE OR PARAMETER?

Q5 **ENT** Enter Q5 for the first value

2ND VALUE OR PARAMETER?

7 **ENT** Enter 7 for the second value

Example: Program blocks in the TNC

```
N17 D00 Q5 P01 +10 *
```

```
N17 D03 Q12 P01 +Q5 P02 +7 *
```



9.4 Trigonometric Functions

Definitions

Sine, cosine and tangent are terms designating the ratios of sides of right triangles. In this case:

Sine: $\sin \alpha = a / c$

Cosine: $\cos \alpha = b / c$

Tangent: $\tan \alpha = a / b = \sin \alpha / \cos \alpha$

where

- c is the side opposite the right angle
- a is the side opposite the angle α
- b is the third side.

The TNC can find the angle from the tangent:

$$\alpha = \arctan (a / b) = \arctan (\sin \alpha / \cos \alpha)$$

Example:

$$a = 25 \text{ mm}$$


$$b = 50 \text{ mm}$$

$$\alpha = \arctan (a / b) = \arctan 0.5 = 26.57^\circ$$

Furthermore:

$$a^2 + b^2 = c^2 \text{ (where } a^2 = a \times a \text{)}$$





$$c = \sqrt{a^2 + b^2}$$



Programming trigonometric functions

Press the ANGLE FUNCTION soft key to call the trigonometric functions. The TNC then displays the following soft keys:

Programming: Compare "Example: Programming fundamental operations."

Function	Soft key
D06: SINE Example: D06 Q20 P01 -Q5 * Calculates and assigns the sine of an angle in degrees (°)	
D07: COSINE Example: D07 Q21 P01 -Q5 * Calculates and assigns the cosine of an angle in degrees (°)	
D08: ROOT SUM OF SQUARES Example: D08 Q10 P01 +5 P02 +4 * Calculates and assigns length from two values	
D13: ANGLE Example: D13 Q20 P01 +10 P02 -Q1 * Calculates the angle from the arc tangent of two sides or from the sine and cosine of the angle ($0 < \text{angle} < 360^\circ$) and assigns it to a parameter	



9.5 If-Then Decisions with Q Parameters

Function

The TNC can make logical If-Then decisions by comparing a Q parameter with another Q parameter or with a numerical value. If the condition is fulfilled, the TNC continues the program at the label that is programmed after the condition (for information on labels, see "Labeling Subprograms and Program Section Repeats", page 244). If it is not fulfilled, the TNC continues with the next block.

To call another program as a subprogram, enter a % program call after the block with the target label.

Unconditional jumps

An unconditional jump is programmed by entering a conditional jump whose condition is always true. Example:

```
D09 P01 +10 P02 +10 P03 1 *
```



Programming If-Then decisions



There are 3 possibilities to enter the jump address:

- Label number, selectable via LBL NUMBER soft key
- Label number, selectable via LBL NAME soft key
- String number, selectable via QS soft key

Press the JUMP soft key to call the If-Then conditions. The TNC then displays the following soft keys:

Function	Soft key
D09: IF EQUAL, JUMP Example: D09 P01 +Q1 P02 +Q3 P03 "SPCAN25" * If the two values or parameters are equal, jump to the given label.	
D10: IF UNEQUAL, JUMP Example: D10 P01 +10 P02 -Q5 P03 10 * If the two values or parameters are unequal, jump to the given label.	
D11: IF GREATER, JUMP Example: D11 P01 +Q1 P02 +10 P03 Q5 * If the first value or parameter is greater than the second, jump to the given label.	
D12: IF LESS, JUMP Example: D12 P01 +Q5 P02 +0 P03 "ANYNAME" * If the first value or parameter is less than the second, jump to the given label.	



9.6 Checking and Changing Q Parameters

Procedure

You can check and edit Q parameters when writing, testing and running programs in the Programming and Editing, Test Run, Program Run Full Sequence, and Program Run Single Block modes.

- ▶ If you are in a program run, interrupt it if required (for example, by pressing the machine STOP button and the INTERNAL STOP soft key). If you are in a test run, interrupt it




- ▶ To call Q parameter functions: Press the Q key or the Q INFO soft key in the Programming and Editing mode of operation.
- ▶ The TNC lists all parameters and their current values. With the arrow keys or the soft keys, go pagewise to the desired parameters.
- ▶ If you would like to change the value, enter a new value and confirm with the ENT key.
- ▶ To leave the value unchanged, press the PRESENT VALUE soft key or end the dialog with the END key.



The parameters used internally or by the TNC in cycles are provided with comments.




If you want to check or edit local, global or string parameters, press the SHOW PARAMETERS Q QL QR QS soft key. The TNC then displays all respective parameters and the above described also apply.



9.7 Additional Functions

Overview

Press the DIVERSE FUNCTION soft key to call the additional functions. The TNC then displays the following soft keys:

Function	Soft key	Page
D14:ERROR Output of error messages		Page 275
D15:PRINT Unformatted output of texts or Q parameter values		Page 279
D19:PLC Send values to the PLC		Page 280



D14: ERROR: Displaying error messages

With the function **D14** you can call messages under program control. The messages are predefined by the machine tool builder or by HEIDENHAIN. Whenever the TNC comes to a block with **D14** in the Program Run or Test Run mode, it interrupts the program run and displays a message. The program must then be restarted. The error numbers are listed in the table below.

Range of error numbers	Standard dialog text
0 ... 299	FN 14: Error code 0 ... 299
300 ... 999	Machine-dependent dialog
1000 ... 1099	Internal error messages (see table at right)

Example NC block

The TNC is to display the text stored under error number 254:

```
N180 D14 P01 254 *
```

Error message predefined by HEIDENHAIN

Error number	Text
1000	Spindle?
1001	Tool axis is missing
1002	Tool radius too small
1003	Tool radius too large
1004	Range exceeded
1005	Start position incorrect
1006	ROTATION not permitted
1007	SCALING FACTOR not permitted
1008	MIRROR IMAGE not permitted
1009	Datum shift not permitted
1010	Feed rate is missing
1011	Input value incorrect
1012	Incorrect sign
1013	Entered angle not permitted
1014	Touch point inaccessible
1015	Too many points



Error number	Text
1016	Contradictory input
1017	CYCL incomplete
1018	Plane wrongly defined
1019	Wrong axis programmed
1020	Wrong rpm
1021	Radius comp. undefined
1022	Rounding-off undefined
1023	Rounding radius too large
1024	Program start undefined
1025	Excessive nesting
1026	Angle reference missing
1027	No fixed cycle defined
1028	Slot width too small
1029	Pocket too small
1030	Q202 not defined
1031	Q205 not defined
1032	Q218 must be greater than Q219
1033	CYCL 210 not permitted
1034	CYCL 211 not permitted
1035	Q220 too large
1036	Q222 must be greater than Q223
1037	Q244 must be greater than 0
1038	Q245 must not equal Q246
1039	Angle range must be < 360°
1040	Q223 must be greater than Q222
1041	Q214: 0 not permitted



Error number	Text
1042	Traverse direction not defined
1043	No datum table active
1044	Position error: center in axis 1
1045	Position error: center in axis 2
1046	Hole diameter too small
1047	Hole diameter too large
1048	Stud diameter too small
1049	Stud diameter too large
1050	Pocket too small: rework axis 1.A.
1051	Pocket too small: rework axis 2.A.
1052	Pocket too large: scrap axis 1.A.
1053	Pocket too large: scrap axis 2.A.
1054	Stud too small: scrap axis 1.A.
1055	Stud too small: scrap axis 2.A.
1056	Stud too large: rework axis 1.A.
1057	Stud too large: rework axis 2.A.
1058	TCHPROBE 425: length exceeds max
1059	TCHPROBE 425: length below min
1060	TCHPROBE 426: length exceeds max
1061	TCHPROBE 426: length below min
1062	TCHPROBE 430: diameter too large
1063	TCHPROBE 430: diameter too small
1064	No measuring axis defined
1065	Tool breakage tolerance exceeded
1066	Enter Q247 unequal to 0
1067	Enter Q247 greater than 5
1068	Datum table?
1069	Enter Q351 unequal 0
1070	Thread depth too large



Error number	Text
1071	Missing calibration data
1072	Tolerance exceeded
1073	Block scan active
1074	ORIENTATION not permitted
1075	3-D ROT not permitted
1076	Activate 3-D ROT
1077	Enter a negative value for the depth
1078	Q303 not defined in measuring cycle
1079	Tool axis not allowed
1080	Calculated values incorrect
1081	Contradictory measuring points
1082	Clearance height entered incorrectly
1083	Contradictory type of plunging
1084	Machining cycle not permitted
1085	Line is write-protected
1086	Oversize greater than depth
1087	No point angle defined
1088	Contradictory data
1089	Slot position 0 not permitted
1090	Enter infeed unequal to 0
1091	Switchover of Q399 not allowed
1092	Tool not defined
1093	Tool number not permitted
1094	Tool name not allowed
1095	Software option not active
1096	Kinematics cannot be restored
1097	Function not permitted
1098	Contradictory workpc. blank dim.
1099	Measuring position not allowed



Error number	Text
1100	Kinematic access not possible
1101	Meas. pos. not in traverse range
1102	Preset compensation not possible

D15 PRINT: Output of texts or Q parameter values



Setting the data interface: In the menu option PRINT or PRINT-TEST, you must enter the path for storing the texts or Q parameters. See "Assignment" on page 548.

The function **D15** transfers Q parameter values and error messages through the data interface, for example to a printer. When you save the data in the TNC memory or transfer them to a PC, the TNC stores the data in the file %FN 15RUN.A (output in program run mode) or in the file %FN15SIM.A (output in test run mode).

The data are transmitted from a buffer. Data output begins at the latest by program end or when you stop the program. In the Single Block mode of operation, data transfer begins at block end.

To output dialog texts and error messages with FN 15: PRINT "numerical value"

Numerical values from 0 to 99: Dialog texts for OEM cycles

Numerical values 100 and above: PLC error messages

Example: Output of dialog text 20

N67 D15 P01 20 *


Outputting dialog texts and Q parameters with D15 PRINT "Q parameter"

Application example: Recording workpiece measurement.

You can transfer up to six Q parameters and numerical values simultaneously. The TNC separates them with slashes.

Example: Output of dialog text 1 and numerical value for Q1

N70 D15 P01 1 P02 Q1 *



D19 PLC: Transfer values to the PLC

The function **D19** transfers up to two numerical values or Q parameters to the PLC.

Increments and units: 0.1 μm or 0.0001°

Example: Transfer the numerical value 10 (which means 1 μm or 0.001°) to the PLC

```
N56 D19 P01 +10 P02 +Q3 *
```
















9.8 Entering Formulas Directly













Entering formulas

You can enter mathematical formulas that include several operations directly into the part program by soft key.

Press the FORMULA soft key to call the mathematical functions. The TNC displays the following soft keys in several soft-key rows:

Mathematical function	Soft key
Addition Example: Q10 = Q1 + Q5	
Subtraction Example: Q25 = Q7 - Q108	
Multiplication Example: Q12 = 5 * Q5	
Division Example: Q25 = Q1 / Q2	
Opening parenthesis Example: Q12 = Q1 * (Q2 + Q3)	
Closing parenthesis Example: Q12 = Q1 * (Q2 + Q3)	
Square of a value Example: Q15 = SQ 5	
Square root Example: Q22 = SQRT 25	
Sine of an angle Example: Q44 = SIN 45	
Cosine of an angle Example: Q45 = COS 45	
Tangent of an angle Example: Q46 = TAN 45	
Arc sine Inverse of the sine. Determines the angle from the ratio of the side opposite the hypotenuse. Example: Q10 = ASIN 0.75	
Arc cosine Inverse of the cosine. Determines the angle from the ratio of the side adjacent to the hypotenuse. Example: Q11 = ACOS Q40	



Mathematical function	Soft key
Arc tangent Inverse of the tangent. Determines the angle from the ratio of the opposite to the adjacent side. Example: Q12 = ATAN Q50	
Powers of values Example: Q15 = 3^3	
Constant "pi" (3.14159) Example: Q15 = PI	
Natural logarithm (LN) of a number Base 2.7183 Example: Q15 = LN Q11	
Logarithm of a number, base 10 Example: Q33 = LOG Q22	
Exponential function, 2.7183 to the power of n Example: Q1 = EXP Q12	
Negate (multiplication by -1) Example: Q2 = NEG Q1	
Truncate decimal places Form an integer Example: Q3 = INT Q42	
Absolute value of a number Example: Q4 = ABS Q22	
Truncate places before the decimal point Form a fraction Example: Q5 = FRAC Q23	
Check algebraic sign of a number Example: Q12 = SGN Q50 If result for Q12 = 1, then Q50 >= 0 If result for Q12 = -1, then Q50 < 0	
Calculate modulo value (division remainder) Example: Q12 = 400 % 360 Result: Q12 = 40	



Rules for formulas

Mathematical formulas are programmed according to the following rules:

Higher-level operations are performed first

$$12 \quad Q1 = 5 * 3 + 2 * 10 = 35$$

1st calculation: $5 * 3 = 15$

2nd calculation: $2 * 10 = 20$

3rd calculation: $15 + 20 = 35$

or

$$13 \quad Q2 = SQ 10 - 3^3 = 73$$

1st calculation: 10 squared = 100

2nd calculation: 3 to the power of 3 = 27

3rd calculation: $100 - 27 = 73$

Distributive law

Law for calculating with parentheses

$$a * (b + c) = a * b + a * c$$



Programming example

Calculate an angle with the arc tangent from the opposite side (Q12) and adjacent side (Q13); then store in Q25.



FORMULA

To select the formula entering function, press the Q key and the FORMULA soft key, or use the shortcut:



Press the Q key on the ASCII keyboard.

PARAMETER NO. FOR RESULT?



25

Enter the parameter number.



ATAN

Shift the soft-key row and select the arc tangent function.



(

Shift the soft-key row and open the parentheses.



12

Enter Q parameter number 12.



Select division.



13

Enter Q parameter number 13.



END

Close parentheses and conclude formula entry.

Example NC block

```
37 Q25 = ATAN (Q12/Q13)
```











9.9 String Parameters

String processing functions

You can use the **QS** parameters to create variable character strings.

You can assign a linear sequence of characters (letters, numbers, special characters and spaces) up to a length of 256 characters to a string parameter. You can also check and process the assigned or imported values by using the functions described below. As in Q parameter programming, you can use a total of 2000 QS parameters (see also “Principle and Overview” on page 262).

The STRING FORMULA and FORMULA Q parameter functions contain various functions for processing the string parameters.

STRING FORMULA functions	Soft key	Page
Assigning string parameters		Page 286
Chain-linking string parameters		Page 286
Converting a numerical value to a string parameter		Page 288
Copying a substring from a string parameter		Page 289
Copying system data to a string parameter		Page 290
FORMULA string functions	Soft key	Page
Converting a string parameter to a numerical value		Page 292
Checking a string parameter		Page 293
Finding the length of a string parameter		Page 294
Comparing alphabetic priority		Page 295



When you use a STRING FORMULA, the result of the arithmetic operation is always a string. When you use the FORMULA function, the result of the arithmetic operation is always a numeric value.



Assigning string parameters

You have to assign a string variable before you use it. Use the **DECLARE STRING** command to do so.

SPEC
FCT

- ▶ Show the soft-key row with special functions

PROGRAM
FUNCTIONS

- ▶ Select the menu for defining various plain-language functions

STRING
FUNCTIONS

- ▶ Select string functions

DECLARE
STRING

- ▶ Select the **DECLARE STRING** function

Example NC block:

```
N37 DECLARE STRING QS10 = "WORKPIECE"
```



Chain-linking string parameters

With the concatenation operator (string parameter ||) you can make a chain of two or more string parameters.

- ▶ Show the soft-key row with special functions.
 - ▶ Select the menu for defining various plain-language functions
 - ▶ Select string functions
 - ▶ Select the STRING FORMULA function
 - ▶ Enter the number of the string parameter in which the TNC is to save the concatenated string. Confirm with the ENT key
 - ▶ Enter the number of the string parameter in which the **first** substring is saved. Confirm with the ENT key: The TNC displays the concatenation symbol ||
 - ▶ Confirm your entry with the ENT key
 - ▶ Enter the number of the string parameter in which the **second** substring is saved. Confirm with the ENT key
 - ▶ Repeat the process until you have selected all the required substrings. Conclude with the END key

Example: QS10 is to include the complete text of QS12, QS13 and QS14

```
N37 QS10 = QS12 || QS13 || QS14
```

Parameter contents:

- QS12: Workpiece
- QS13: Status:
- QS14: Scrap
- QS10: Workpiece Status: Scrap



Converting a numerical value to a string parameter

With the **TOCHAR** function, the TNC converts a numerical value to a string parameter. This enables you to chain numerical values with string variables.



- ▶ Select Q parameter functions
- ▶ Select the STRING FORMULA function
- ▶ Select the function for converting a numerical value to a string parameter
- ▶ Enter the number or the desired Q parameter to be converted, and confirm with the ENT key
- ▶ If desired, enter the number of decimal places that the TNC should convert, and confirm with the ENT key
- ▶ Close the parenthetical expression with the ENT key and confirm your entry with the END key.

Example: Convert parameter Q50 to string parameter QS11, use 3 decimal places

```
N37 QS11 = TOCHAR ( DAT+Q50 DECIMALS3 )
```



Copying a substring from a string parameter

With the **SUBSTR** function you can copy a definable range from a string parameter.



- ▶ Select Q parameter functions



- ▶ Select the STRING FORMULA function
- ▶ Enter the number of the string parameter in which the TNC is to save the copied string. Confirm with the ENT key



- ▶ Select the function for cutting out a substring
- ▶ Enter the number of the QS parameter from which the substring is to be copied. Confirm with the ENT key
- ▶ Enter the number of the place starting from which to copy the substring, and confirm with the ENT key
- ▶ Enter the number of characters to be copied, and confirm with the ENT key
- ▶ Close the parenthetical expression with the ENT key and confirm your entry with the END key



Remember that the first character of a text sequence starts internally with the zeroth place.

Example: A four-character substring (LEN4) is read from the string parameter QS10 beginning with the third character (BEG2)

```
N37 QS13 = SUBSTR ( SRC_QS10 BEG2 LEN4 )
```



Copying system data to a string parameter

With the **SVSSTR** function you can copy system data to a string parameter. At present only reading of the system time is available.



- ▶ Select Q parameter functions
- ▶ Select the STRING FORMULA function
- ▶ Enter the number of the string parameter in which the TNC is to save the copied string. Confirm with the ENT key
- ▶ Select the function for copying system data
- ▶ Enter the **Number of the system key (ID321** for the system time) that you want to copy, and confirm with the ENT key
- ▶ Enter the **Index for system key**. It defines the format for the system time to be output. Confirm with the ENT key (see description below)
- ▶ **Array index of the source to be read** has no function yet. Confirm with the NO ENT key
- ▶ **Number to be converted to text** has no function yet. Confirm with the NO ENT key
- ▶ Close the parenthetical expression with the ENT key and confirm your entry with the END key



This function is prepared for future expansions. The parameters **IDX** and **DAT** currently have no function.



You can use the following formats to display the date:

- 0: DD.MM.YYYY hh:mm:ss
- 1: D.MM.YYYY h:mm:ss
- 2: D.MM.YYYY h:mm
- 3: D.MM.YY h:mm
- 4: YYYY-MM-DD- hh:mm:ss
- 5: YYYY-MM-DD- hh:mm
- 6: YYYY-MM-DD h:mm
- 7: YY-MM-DD- h:mm
- 8: DD.MM.YYYY
- 9: D.MM.YYYY
- 10: D.MM.YY
- 11: YYYY-MM-DD
- 12: YY-MM-DD
- 13: hh:mm:ss
- 14: h:mm:ss
- 15: h:mm

Example: read out the current system time in the format DD.MM.YYYY hh:mm:ss, and save it in parameter QS13.

```
N70 QS13 = SYSSTR ( ID321 NR0)
```



Converting a string parameter to a numerical value

The **TONUMB** function converts a string parameter to a numerical value. The value to be converted should be only numerical.



The QS parameter must contain only one numerical value. Otherwise the TNC will output an error message.



- ▶ Select Q parameter functions



- ▶ Select the FORMULA function
- ▶ Enter the number of the string parameter in which the TNC is to save the numerical value. Confirm with the ENT key



- ▶ Shift the soft-key row



- ▶ Select the function for converting a string parameter to a numerical value
- ▶ Enter the number of the Q parameter to be converted, and confirm with the ENT key
- ▶ Close the parenthetical expression with the ENT key and confirm your entry with the END key

Example: Convert string parameter QS11 to a numerical parameter Q82

```
N37 Q82 = TONUMB ( SRC_QS11 )
```



Checking a string parameter

With the **INSTR** function you can check whether a string parameter is contained in another string parameter.



- ▶ Select Q parameter functions



- ▶ Select the FORMULA function
- ▶ Enter the number of the Q parameter in which the TNC is to save the place at which the search text begins. Confirm with the ENT key



- ▶ Shift the soft-key row



- ▶ Select the function for checking a string parameter
- ▶ Enter the number of the QS parameter in which the searched-for text is saved. Confirm with the ENT key
- ▶ Enter the number of the QS parameter to be searched, and confirm with the ENT key
- ▶ Enter the number of the place starting from which the TNC is to search the substring, and confirm with the ENT key
- ▶ Close the parenthetical expression with the ENT key and confirm your entry with the END key



Remember that the first character of a text sequence starts internally with the zeroth place.

If the TNC cannot find the required substring, it will save the total length of the string to be searched (counting starts at 1) in the result parameter.

If the substring is found in more than one place, the TNC returns the first place at which it finds the substring.

Example: Search through QS10 for the text saved in parameter QS13. Begin the search at the third place.

```
N37 Q50 = INSTR ( SRC_QS10 SEA_QS13 BEG2 )
```



Finding the length of a string parameter

The **STRLEN** function returns the length of the text saved in a selectable string parameter.



- ▶ Select Q parameter functions



- ▶ Select the FORMULA function
- ▶ Enter the number of the Q parameter in which the TNC is to save the ascertained string length. Confirm with the ENT key



- ▶ Shift the soft-key row



- ▶ Select the function for finding the text length of a string parameter
- ▶ Enter the number of the QS parameter whose length the TNC is to ascertain, and confirm with the ENT key
- ▶ Close the parenthetical expression with the ENT key and confirm your entry with the END key

Example: Find the length of QS15

```
N37 Q52 = STRLEN ( SRC_QS15 )
```



Comparing alphabetic priority

With the **STRCOMP** function you can compare string parameters for alphabetic priority.



▶ Select Q parameter functions



▶ Select the FORMULA function

▶ Enter the number of the Q parameter in which the TNC is to save the result of comparison. Confirm with the ENT key



▶ Shift the soft-key row



▶ Select the function for comparing string parameters

▶ Enter the number of the first QS parameter to be compared, and confirm with the ENT key

▶ Enter the number of the second QS parameter to be compared, and confirm with the ENT key

▶ Close the parenthetical expression with the ENT key and confirm your entry with the END key



The TNC returns the following results:

- **0**: The compared QS parameters are identical.
- **+1**: The first QS parameter **precedes** the second QS parameter alphabetically.
- **-1**: The first QS parameter **follows** the second QS parameter alphabetically.

Example: QS12 and QS14 are compared for alphabetic priority

```
N37 Q52 = STRCOMP ( SRC_QS12 SEA_QS14 )
```



9.10 Preassigned Q Parameters

The Q parameters Q100 to Q199 are assigned values by the TNC. The following are assigned to Q parameters:

- Values from the PLC
- Tool and spindle data
- Data on operating status
- Results of measurements from touch probe cycles etc.



Do not use preassigned Q parameters (or QS parameters) between **Q100** and **Q199** (**QS100** and **QS199**) as calculation parameters in NC programs. Otherwise you might receive undesired results.

Values from the PLC: Q100 to Q107

The TNC uses the parameters Q100 to Q107 to transfer values from the PLC to an NC program.

WMAT block: QS100

The TNC saves the material defined in the WMAT block in parameter **QS100**.

Active tool radius: Q108

The active value of the tool radius is assigned to Q108. Q108 is calculated from:

- Tool radius R (tool table or **G99** block)
- Delta value DR from the tool table
- Delta value DR from the **T** block



The TNC remembers the current tool radius even if the power is interrupted.

Tool axis: Q109

The value of Q109 depends on the current tool axis:

Tool axis	Parameter value
No tool axis defined	Q109 = -1
X axis	Q109 = 0
Y axis	Q109 = 1
Z axis	Q109 = 2
U axis	Q109 = 6
V axis	Q109 = 7
W axis	Q109 = 8

Spindle status: Q110

The value of the parameter Q110 depends on the M function last programmed for the spindle.

M function	Parameter value
No spindle status defined	Q110 = -1
M3: Spindle ON, clockwise	Q110 = 0
M4: Spindle ON, counterclockwise	Q110 = 1
M5 after M3	Q110 = 2
M5 after M4	Q110 = 3

Coolant on/off: Q111

M function	Parameter value
M8: Coolant ON	Q111 = 1
M9: Coolant OFF	Q111 = 0

Overlap factor: Q112

The overlap factor for pocket milling (MP7430) is assigned to Q112.



Unit of measurement for dimensions in the program: Q113

During nesting the PGM CALL, the value of the parameter Q113 depends on the dimensional data of the program from which the other programs are called.

Dimensional data of the main program	Parameter value
Metric system (mm)	Q113 = 0
Inch system (inches)	Q113 = 1

Tool length: Q114

The current value for the tool length is assigned to Q114.

The current value for the tool length is assigned to Q114. Q114 is calculated from:

- The tool length (tool table or **G99** block)
- Delta value DL from the tool table
- Delta value DL from the **T** block



The TNC remembers the current tool length even if the power is interrupted.

Coordinates after probing during program run

The parameters Q115 to Q119 contain the coordinates of the spindle position at the moment of contact during programmed measurement with the 3-D touch probe. The coordinates refer to the datum point that is active in the Manual operating mode.

The length of the stylus and the radius of the ball tip are not compensated in these coordinates.

Coordinate axis	Parameter value
X axis	Q115
Y axis	Q116
Z axis	Q117
4th axis depending on MP100	Q118
5th axis depending on MP100	Q119



Deviation between actual value and nominal value during automatic tool measurement with the TT 130

Deviation of actual from nominal value	Parameter value
Tool length	Q115
Tool radius	Q116

Tilting the working plane with mathematical angles: rotary axis coordinates calculated by the TNC

Coordinates	Parameter value
A axis	Q120
B axis	Q121
C axis	Q122



Measurement results from touch probe cycles (see also User's Manual for Touch Probe Cycles)

Measured actual values	Parameter value
Angle of a straight line	Q150
Center in the reference axis	Q151
Center in the minor axis	Q152
Diameter	Q153
Pocket length	Q154
Pocket width	Q155
Length of the axis selected in the cycle	Q156
Position of the centerline	Q157
Angle of the A axis	Q158
Angle of the B axis	Q159
Coordinate of the axis selected in the cycle	Q160

Measured deviation	Parameter value
Center in reference axis	Q161
Center in the minor axis	Q162
Diameter	Q163
Pocket length	Q164
Pocket width	Q165
Measured length	Q166
Position of the centerline	Q167

Determined space angle	Parameter value
Rotation about the A axis	Q170
Rotation about the B axis	Q171
Rotation about the C axis	Q172



Workpiece status	Parameter value
Good	Q180
Rework	Q181
Scrap	Q182

Measured deviation with Cycle 440	Parameter value
X axis	Q185
Y axis	Q186
Z axis	Q187
Markers for cycles	Q188

Tool measurement with the BLUM laser	Parameter value
Reserved	Q190
Reserved	Q191
Reserved	Q192
Reserved	Q193

Reserved for internal use	Parameter value
Markers for cycles	Q195
Markers for cycles	Q196
Markers for cycles (machining patterns)	Q197
Number of the last active measuring cycle	Q198

Status of tool measurement with TT	Parameter value
Tool within tolerance	Q199 = 0.0
Tool is worn (LTOL/RTOL is exceeded)	Q199 = 1.0
Tool is broken (LBREAK/RBREAK is exceeded)	Q199 = 2.0




9.11 Programming Examples

Example: Ellipse

Program sequence

- The contour of the ellipse is approximated by many short lines (defined in Q7). The more calculation steps you define for the lines, the smoother the curve becomes.
- The machining direction can be altered by changing the entries for the starting and end angles in the plane:
 Clockwise machining direction:
 starting angle > end angle
 Counterclockwise machining direction:
 starting angle < end angle
- The tool radius is not taken into account.



%ELLIPSE G71 *	
N10 Q1 = +50 *	Center in X axis
N20 Q2 = +50 *	Center in the Y axis
N30 Q3 = +50 *	Semiasis in X
N40 Q4 = +30 *	Semiasis in Y
N50 Q5 = +0 *	Starting angle in the plane
N60 Q6 = +360 *	End angle in the plane
N70 Q7 = +40 *	Number of calculation steps
N80 Q8 = +30 *	Rotational position of the ellipse
N90 Q9 = +5 *	Milling depth
N100 Q10 = +100 *	Feed rate for plunging
N110 Q11 = +350 *	Feed rate for milling
N120 Q12 = +2 *	Set-up clearance for pre-positioning
N130 G30 G17 X+0 Y+0 Z-20 *	Definition of workpiece blank
N140 G31 G90 X+100 Y+100 Z+0 *	
N160 T1 G17 S4000 *	Tool call
N170 G00 G40 G90 Z+250 *	Retract the tool
N180 L10.0 *	Call machining operation


N190 G00 Z+250 M2 *	Retract in the tool axis, end program
N200 G98 L10 *	Subprogram 10: Machining operation
N210 G54 X+Q1 Y+Q2 *	Shift datum to center of ellipse
N220 G73 G90 H+Q8 *	Account for rotational position in the plane
N230 Q35 = (Q6 - Q5) / Q7 *	Calculate angle increment
N240 Q36 = +Q5 *	Copy starting angle
N250 Q37 = +0 +0 *	Set counter
N260 Q21 = Q3 * COS Q36 *	Calculate X coordinate for starting point
N270 Q22 = Q4 * SIN Q36 *	Calculate Y coordinate for starting point
N280 G00 G40 X+Q21 Y+Q22 M3 *	Move to starting point in the plane
N290 Z+Q12 *	Pre-position in spindle axis to set-up clearance
N300 G01 Z-Q9 FQ10 *	Move to working depth
N310 G98 L1 *	
N320 Q36 = Q36 + Q35 *	Update the angle
N330 Q37 = Q37 + 1 *	Update the counter
N340 Q21 = Q3 * COS Q36 *	Calculate the current X coordinate
N350 Q22 = Q4 * SIN Q36 *	Calculate the current Y coordinate
N360 G01 X+Q21 Y+Q22 FQ11 *	Move to next point
N370 D12 P01 +Q37 P02 +Q7 P03 1 *	Unfinished? If not finished return to label 1
N380 G73 G90 H+0 *	Reset the rotation
N390 G54 X+0 Y+0 *	Reset the datum shift
N400 G00 G40 Z+Q12 *	Move to set-up clearance
N410 G98 L0 *	End of subprogram
N99999999 %ELLIPSE G71 *	



Example: Concave cylinder machined with spherical cutter

Program sequence

- This program functions only with a spherical cutter. The tool length refers to the sphere center.
- The contour of the cylinder is approximated by many short line segments (defined in Q13). The more line segments you define, the smoother the curve becomes.
- The cylinder is milled in longitudinal cuts (here: parallel to the Y axis).
- The machining direction can be altered by changing the entries for the starting and end angles in space:
 Clockwise machining direction:
 starting angle > end angle
 Counterclockwise machining direction:
 starting angle < end angle
- The tool radius is compensated automatically.



<code>%CYLIN G71 *</code>	
<code>N10 Q1 = +50 *</code>	Center in X axis
<code>N20 Q2 = +0 *</code>	Center in the Y axis
<code>N30 Q3 = +0 *</code>	Center in Z axis
<code>N40 Q4 = +90 *</code>	Starting angle in space (Z/X plane)
<code>N50 Q5 = +270 *</code>	End angle in space (Z/X plane)
<code>N60 Q6 = +40 *</code>	Cylinder radius
<code>N70 Q7 = +100 *</code>	Length of the cylinder
<code>N80 Q8 = +0 *</code>	Rotational position in the X/Y plane
<code>N90 Q10 = +5 *</code>	Allowance for cylinder radius
<code>N100 Q11 = +250 *</code>	Feed rate for plunging
<code>N110 Q12 = +400 *</code>	Feed rate for milling
<code>N120 Q13 = +90 *</code>	Number of cuts
<code>N130 G30 G17 X+0 Y+0 Z-50 *</code>	Definition of workpiece blank
<code>N140 G31 G90 X+100 Y+100 Z+0 *</code>	
<code>N160 T1 G17 S4000 *</code>	Tool call
<code>N170 G00 G40 G90 Z+250 *</code>	Retract the tool
<code>N180 L10.0 *</code>	Call machining operation
<code>N190 Q10 = +0 *</code>	Reset allowance
<code>N200 L10.0</code>	Call machining operation




N210 G00 G40 Z+250 M2 *	Retract in the tool axis, end program
N220 G98 L10 *	Subprogram 10: Machining operation
N230 Q16 = Q6 - Q10 - Q108 *	Account for allowance and tool, based on the cylinder radius
N240 Q20 = +1 *	Set counter
N250 Q24 = +Q4 *	Copy starting angle in space (Z/X plane)
N260 Q25 = (Q5 - Q4) / Q13 *	Calculate angle increment
N270 G54 X+Q1 Y+Q2 Z+Q3 *	Shift datum to center of cylinder (X axis)
N280 G73 G90 H+Q8 *	Account for rotational position in the plane
N290 G00 G40 X+0 Y+0 *	Pre-position in the plane to the cylinder center
N300 G01 Z+5 F1000 M3 *	Pre-position in the tool axis
N310 G98 L1 *	
N320 I+0 K+0 *	Set pole in the Z/X plane
N330 G11 R+Q16 H+Q24 FQ11 *	Move to starting position on cylinder, plunge-cutting obliquely into the material
N340 G01 G40 Y+Q7 FQ12 *	Longitudinal cut in Y+ direction
N350 Q20 = +Q20 + 1 *	Update the counter
N360 Q24 = +Q24 + +Q25 *	Update solid angle
N370 D11 P01 +Q20 P02 +Q13 P03 99 *	Finished? If finished, jump to end
N380 G11 R+Q16 H+Q24 FQ11 *	Move in an approximated "arc" for the next longitudinal cut
N390 G01 G40 Y+0 FQ12 *	Longitudinal cut in Y- direction
N400 D01 Q20 P01 +Q20 P02 +1 *	Update the counter
N410 D01 Q24 P01 +Q24 P02 +Q25 *	Update solid angle
N420 D12 P01 +Q20 P02 +Q13 P03 1 *	Unfinished? If not finished, return to LBL 1
N430 G98 L99 *	
N440 G73 G90 H+0 *	Reset the rotation
N450 G54 X+0 Y+0 Z+0 *	Reset the datum shift
N460 G98 L0 *	End of subprogram
N99999999 %CYLIN G71 *	



Example: Convex sphere machined with end mill

Program sequence

- This program requires an end mill.
- The contour of the sphere is approximated by many short lines (in the Z/X plane, defined in Q14). The smaller you define the angle increment, the smoother the curve becomes.
- You can determine the number of contour cuts through the angle increment in the plane (defined in Q18).
- The tool moves upward in three-dimensional cuts.
- The tool radius is compensated automatically.



%SPHERE G71 *	
N10 Q1 = +50 *	Center in X axis
N20 Q2 = +50 *	Center in Y axis
N30 Q4 = +90 *	Starting angle in space (Z/X plane)
N40 Q5 = +0 *	End angle in space (Z/X plane)
N50 Q14 = +5 *	Winkelschritt im Raum
N60 Q6 = +45 *	Kugelradius
N70 Q8 = +0 *	Starting angle of rotational position in the X/Y plane
N80 Q9 = +360 *	End angle of rotational position in the X/Y plane
N90 Q18 = +10 *	Angle increment in the X/Y plane for roughing
N100 Q10 = +5 *	Allowance in sphere radius for roughing
N110 Q11 = +2 *	Set-up clearance for pre-positioning in the tool axis
N120 Q12 = +350 *	Feed rate for milling
N130 G30 G17 X+0 Y+0 Z-50 *	Definition of workpiece blank
N140 G31 G90 X+100 Y+100 Z+0 *	
N160 T1 G17 S4000 *	Tool call
N170 G00 G40 G90 Z+250 *	Retract the tool

N180 L10.0 *	Call machining operation
N190 Q10 = +0 *	Reset allowance
N200 Q18 = +5 *	Angle increment in the X/Y plane for finishing
N210 L10.0 *	Call machining operation
N220 G00 G40 Z+250 M2 *	Retract in the tool axis, end program
N230 G98 L10 *	Subprogram 10: Machining operation
N240 Q23 = Q11 + Q6 *	Calculate Z coordinate for pre-positioning
N250 Q24 = +Q4 *	Copy starting angle in space (Z/X plane)
N260 Q26 = Q6 + Q108 *	Compensate sphere radius for pre-positioning
N270 Q28 = +Q8 *	Copy rotational position in the plane
N280 Q16 = Q6 + -Q10 *	Account for allowance in the sphere radius
N290 G54 X+Q1 Y+Q2 Z-Q16 *	Shift datum to center of sphere
N300 G73 G90 H+Q8 *	Account for starting angle of rotational position in the plane
N310 G98 L1 *	Pre-position in the tool axis
N320 I+0 J+0 *	Set pole in the X/Y plane for pre-positioning
N330 G11 G40 R+Q26 H+Q8 FQ12 *	Pre-position in the plane
N340 I+Q108 K+0 *	Set pole in the Z/X plane, offset by the tool radius
N350 G01 Y+0 Z+0 FQ12 *	Move to working depth
N360 G98 L2 *	
N370 G11 G40 R+Q6 H+Q24 FQ12 *	Move upward in an approximated "arc"
N380 Q24 = Q24 - Q14 *	Update solid angle
N390 D11 P01 +Q24 P02 +Q5 P03 2 *	Inquire whether an arc is finished. If not finished, return to LBL 2.



N400 G11 R+Q6 H+Q5 FQ12 *	Move to the end angle in space
N410 G01 G40 Z+Q23 F1000 *	Retract in the tool axis
N420 G00 G40 X+Q26 *	Pre-position for next arc
N430 Q28 = Q28 + Q18 *	Update rotational position in the plane
N440 Q24 = +Q4 *	Reset solid angle
N450 G73 G90 H+Q28 *	Activate new rotational position
N460 D12 P01 +Q28 P02 +Q9 P03 1 *	Unfinished? If not finished, return to label 1
N470 D09 P01 +Q28 P02 +Q9 P03 1 *	
N480 G73 G90 H+0 *	Reset the rotation
N490 G54 X+0 Y+0 Z+0 *	Reset the datum shift
N500 G98 L0 *	End of subprogram
N99999999 %SPHERE G71 *	





10

**Programming:
Miscellaneous Functions**



10.1 Entering Miscellaneous Functions M and STOP

Fundamentals

With the TNC's miscellaneous functions—also called M functions—you can affect

- the program run, e.g., a program interruption
- the machine functions, such as switching spindle rotation and coolant supply on and off
- the path behavior of the tool



The machine tool builder may add some M functions that are not described in this User's Manual. Refer to your machine tool manual.

You can enter up to two M functions at the end of a positioning block or in a separate block. The TNC displays the following dialog question:

Miscellaneous function M ?

You usually enter only the number of the M function in the programming dialog. Some M functions can be programmed with additional parameters. In this case, the dialog is continued for the parameter input.

In the Manual Operation and Electronic Handwheel modes of operation, the M functions are entered with the M soft key.



Please note that some M functions become effective at the start of a positioning block, and others at the end, regardless of their position in the NC block.

M functions come into effect in the block in which they are called.

Some M functions are effective only in the block in which they are programmed. Unless the M function is only effective blockwise, either you must cancel it in a subsequent block with a separate M function, or it is automatically canceled by the TNC at the end of the program.

Entering an M function in a STOP block

If you program a STOP block, the program run or test run is interrupted at the block, for example for tool inspection. You can also enter an M function in a STOP block:



- ▶ To program an interruption of program run, press the STOP key.
- ▶ Enter a miscellaneous function M

Example NC blocks

```
N87 G36 M6
```



10.2 Miscellaneous Functions for Program Run Control, Spindle and Coolant

Overview

M	Effect	Effective at block...	Start	End
M0	Stop program run Spindle STOP Coolant OFF			■
M1	Optional program STOP Spindle STOP Coolant OFF (not effective during Test Run)			■
M2	STOP program run Spindle STOP Coolant OFF Go to block 1 Clear the status display (depends on MP7300)			■
M3	Spindle ON clockwise		■	
M4	Spindle ON counterclockwise		■	
M5	Spindle STOP			■
M6	Tool change Spindle STOP Program run STOP (depends on MP7440)			■
M8	Coolant ON		■	
M9	Coolant OFF			■
M13	Spindle ON clockwise Coolant ON		■	
M14	Spindle ON counterclockwise Coolant ON		■	
M30	Same as M2			■



10.3 Miscellaneous Functions for Coordinate Data

Programming machine-referenced coordinates: M91/M92

Scale reference point

On the scale, a reference mark indicates the position of the scale reference point.

Machine datum

The machine datum is required for the following tasks:

- Defining the limits of traverse (software limit switches)
- Moving to machine-referenced positions (such as tool change positions)
- Setting the workpiece datum

The distance in each axis from the scale reference point to the machine datum is defined by the machine tool builder in a machine parameter.

Standard behavior

The TNC references coordinates to the workpiece datum (see "Datum Setting without a 3-D Touch Probe", page 464).


Behavior with M91—Machine datum

If you want the coordinates in a positioning block to be referenced to the machine datum, end the block with M91.



If you program incremental coordinates in an M91 block, enter them with respect to the last programmed M91 position. If no M91 position is programmed in the active NC block, then enter the coordinates with respect to the current tool position.

The coordinate values on the TNC screen are referenced to the machine datum. Switch the display of coordinates in the status display to REF (see "Status Displays", page 83).



Behavior with M92—Additional machine datum



In addition to the machine datum, the machine tool builder can also define an additional machine-based position as a reference point.

For each axis, the machine tool builder defines the distance between the machine datum and this additional machine datum. Refer to the machine manual for more information.

If you want the coordinates in a positioning block to be based on the additional machine datum, end the block with M92.



Radius compensation remains the same in blocks that are programmed with M91 or M92. The tool length, however, is **not** compensated.

Effect

M91 and M92 are effective only in the blocks in which they are programmed.

M91 and M92 take effect at the start of block.

Workpiece datum


If you want the coordinates to always be referenced to the machine datum, you can inhibit datum setting for one or more axes.

If datum setting is inhibited for all axes, the TNC no longer displays the SET DATUM soft key in the Manual Operation mode.

The figure shows coordinate systems with the machine datum and workpiece datum.

M91/M92 in the Test Run mode

In order to be able to graphically simulate M91/M92 movements, you need to activate working space monitoring and display the workpiece blank referenced to the set datum (see "Showing the Workpiece in the Working Space", page 565).



Activating the most recently entered datum: M104

Function

When processing pallet tables, the TNC may overwrite your most recently entered datum with values from the pallet table. With M104 you can reactivate the original datum.

Effect

M104 is effective only in the blocks in which it is programmed.

M104 becomes effective at the end of block.



The TNC does not change the active basic rotation when running the M104 function.

Moving to positions in a non-tilted coordinate system with a tilted working plane: M130

Standard behavior with a tilted working plane

The TNC places the coordinates in the positioning blocks in the tilted coordinate system.

Behavior with M130

The TNC places coordinates in straight line blocks in the untilted coordinate system.

The TNC then positions the (tilted) tool to the programmed coordinates of the untilted system.



Danger of collision!

Subsequent positioning blocks or fixed cycles are carried out in a tilted coordinate system. This can lead to problems in fixed cycles with absolute pre-positioning.

The function M130 is allowed only if the tilted working plane function is active.

Effect

M130 functions blockwise in straight-line blocks without tool radius compensation.



10.4 Miscellaneous Functions for Contouring Behavior

Smoothing corners: M90

Standard behavior

The TNC stops the tool briefly in positioning blocks without tool radius compensation. This is called an exact stop.

In program blocks with radius compensation (RR/RL), the TNC automatically inserts a transition arc at outside corners.

Behavior with M90

The tool moves at corners with constant speed: This provides a smoother, more continuous surface. Machining time is also reduced.

Application example: Surface consisting of a series of straight line segments.

Effect



M90 is effective only in the blocks in which it is programmed.

M90 becomes effective at the start of block. Operation with servo lag must be active.

Insert rounding arc between straight lines: M112

Compatibility

For reasons of compatibility, the M112 function is still available. However, to define the tolerance for fast contour milling, HEIDENHAIN recommends the use of the TOLERANCE cycle (see User's Manual for Cycles, section 32 TOLERANCE).



Do not include points when executing non-compensated line blocks: M124

Standard behavior

The TNC runs all line blocks that have been entered in the active program.

Behavior with M124

When running **non-compensated line blocks** with very small point intervals, you can use parameter **T** to define a minimum point interval up to which the TNC will not include points during execution.

Effect

M124 becomes effective at the start of block.

The TNC automatically resets M124 if you select a new program.

Programming M124

If you enter M124 in a positioning block, the TNC continues the dialog for this block by asking you the minimum distance between points **T**.

You can also define **T** through Q parameters (see "Principle and Overview" on page 262).



Machining small contour steps: M97

Standard behavior

The TNC inserts a transition arc at outside corners. If the contour steps are very small, however, the tool would damage the contour.

In such cases the TNC interrupts program run and generates the error message "Tool radius too large."

Behavior with M97

The TNC calculates the intersection of the contour elements—as at inside corners—and moves the tool over this point.

Program M97 in the same block as the outside corner.





Instead of **M97** you should use the much more powerful function **M120 LA** (see "Calculating the radius-compensated path in advance (LOOK AHEAD): M120" on page 323).

Effect

M97 is effective only in the blocks in which it is programmed.



A corner machined with M97 will not be completely finished. You may wish to rework the contour with a smaller tool.



Example NC blocks

N50 T20 G01 ...*	Tool with large tool radius
...	
N130 X ... Y ... F ... M97 *	Move to contour point 13
N140 G91 Y-0.5 ... F ... *	Machine small contour step 13 to 14
N150 X+100 ... *	Move to contour point 15
N160 Y+0.5 ... F ... M97 *	Machine small contour step 15 to 16
N170 G90 X ... Y ... *	Move to contour point 17



Machining open contours corners: M98

Standard behavior

The TNC calculates the intersections of the cutter paths at inside corners and moves the tool in the new direction at those points.

If the contour is open at the corners, however, this will result in incomplete machining.

Behavior with M98

With the miscellaneous function M98, the TNC temporarily suspends radius compensation to ensure that both corners are completely machined:

Effect

M98 is effective only in the blocks in which it is programmed.

M98 takes effect at the end of block.



Example NC blocks

Move to the contour points 10, 11 and 12 in succession:

```
N100 G01 G41 X ... Y ... F ... *
```

```
N110 X ... G91 Y ... M98 *
```

```
N120 X+ ... *
```



Feed rate factor for plunging movements: M103

Standard behavior

The TNC moves the tool at the last programmed feed rate, regardless of the direction of traverse.

Behavior with M103



The feed rate reduction with M103 is only effective if bit 4 in MP7440 has been set to 1.

The TNC reduces the feed rate when the tool moves in the negative direction of the tool axis. The feed rate for plunging FZMAX is calculated from the last programmed feed rate FPROG and a factor F%:

$$FZMAX = FPROG \times F\%$$

Programming M103

If you enter M103 in a positioning block, the TNC continues the dialog by asking you the factor F.

Effect

M103 becomes effective at the start of block.
To cancel M103, program M103 once again without a factor.



M103 is also effective in an active tilted working plane. The feed rate reduction is then effective during traverse in the negative direction of the **tilted** tool axis.

Example NC blocks

The feed rate for plunging is to be 20% of the feed rate in the plane.

...	Actual contouring feed rate (mm/min):
N170 G01 G41 X+20 Y+20 F500 M103 F20 *	500
N180 Y+50 *	500
N190 G91 Z-2.5 *	100
N200 Y+5 Z-5 *	141
N210 X+50 *	500
N220 G90 Z+5 *	500



Feed rate in millimeters per spindle revolution: M136

Standard behavior

The TNC moves the tool at the programmed feed rate F in mm/min.

Behavior with M136



In inch-programs, M136 is not permitted in combination with the new alternate feed rate FU.

The spindle is not permitted to be controlled when M136 is active.

With M136, the TNC does not move the tool in mm/min, but rather at the programmed feed rate F in millimeters per spindle revolution. If you change the spindle speed by using the spindle override, the TNC changes the feed rate accordingly.

Effect

M136 becomes effective at the start of block.

You can cancel M136 by programming M137.



Feed rate for circular arcs: M109/M110/M111

Standard behavior

The TNC applies the programmed feed rate to the path of the tool center.

Behavior at circular arcs with M109

The TNC adjusts the feed rate for circular arcs at inside and outside contours so that the feed rate at the tool cutting edge remains constant.



Caution: Danger to the workpiece and tool!

On very small outside corners the TNC may increase the feed rate so much that the tool or workpiece can be damaged. Avoid **M109** with small outside corners.

Behavior at circular arcs with M110

The TNC keeps the feed rate constant for circular arcs at inside contours only. At outside contours, the feed rate is not adjusted.



M110 is also effective for the inside machining of circular arcs using contour cycles (special case).

If you define **M109** or **M110** before calling a machining cycle with a number greater than 200, the adjusted feed rate is also effective for circular arcs within these machining cycles. The initial state is restored after finishing or aborting a machining cycle.

Effect

M109 and M110 become effective at the start of block. To cancel M109 and M110, enter M111.



Calculating the radius-compensated path in advance (LOOK AHEAD): M120

Standard behavior

If the tool radius is larger than the contour step that is to be machined with radius compensation, the TNC interrupts program run and generates an error message. M97 (see "Machining small contour steps: M97" on page 317) inhibits the error message, but this results in dwell marks and will also move the corner.

If the programmed contour contains undercut features, the tool may damage the contour.

Behavior with M120

The TNC checks radius-compensated paths for contour undercuts and tool path intersections, and calculates the tool path in advance from the current block. Areas of the contour that might be damaged by the tool are not machined (dark areas in figure). You can also use M120 to calculate the radius compensation for digitized data or data created on an external programming system. This means that deviations from the theoretical tool radius can be compensated.

Use LA (Look Ahead) after M120 to define the number of blocks (maximum: 99) that you want the TNC to calculate in advance. Note that the larger the number of blocks you choose, the higher the block processing time will be.

Input


If you enter M120 in a positioning block, the TNC continues the dialog for this block by asking you the number of blocks LA that are to be calculated in advance.

Effect

M120 must be located in an NC block that also contains radius compensation **G41** or **G42**. M120 is then effective from this block until

- radius compensation is canceled with **G40**
- M120 LA0 is programmed, or
- M120 is programmed without LA, or
- another program is called with %
- the working plane is tilted with Cycle **G80** or the PLANE function

M120 becomes effective at the start of block.



Restrictions

- After an external or internal stop, you can only re-enter the contour with the function RESTORE POS. AT N. Before you start the block scan, you must cancel M120, otherwise the TNC will output an error message.
- When using the path functions **G25** and **G24**, the blocks before and after **G25** or **G24** must contain only coordinates in the working plane.
- Before using the functions listed below, you have to cancel M120 and the radius compensation:
 - Cycle **G60** Tolerance
 - Cycle **G80** Working plane
 - PLANE function
 - M114
 - M128
 - M138
 - M144
 - TCPM FUNCTION (only conversational)
 - WRITE TO KINEMATIC (only conversational format)



Superimposing handwheel positioning during program run: M118

Standard behavior

In the program run modes, the TNC moves the tool as defined in the part program.

Behavior with M118

M118 permits manual corrections by handwheel during program run. Just program M118 and enter an axis-specific value (linear or rotary axis) in millimeters.

Input

If you enter M118 in a positioning block, the TNC continues the dialog for this block by asking you the axis-specific values. The coordinates are entered with the orange axis direction buttons or the ASCII keyboard.

Effect

Cancel handwheel positioning by programming M118 once again without coordinate input.

M118 becomes effective at the start of block.

Example NC blocks

You want to be able to use the handwheel during program run to move the tool in the working plane X/Y by ± 1 mm and in the rotary axis B by $\pm 5^\circ$ from the programmed value:

```
N250 G01 G41 X+0 Y+38.5 F125 M118 X1 Y1 B5 *
```



M118 is always effective in the original coordinate system, even if the working plane is tilted.

In a program with millimeters set as unit of measure, the TNC interprets M118 values for linear axes in millimeters. In an inch program it interprets it as inches.

M118 also functions in the Positioning with MDI mode of operation!

M118 in combination with DCM collision monitoring is only possible in stopped condition (blinking control-in-operation symbol). If you try to move an axis during handwheel superimposition, the TNC will generate an error message.



Retraction from the contour in the tool-axis direction: M140

Standard behavior

In the program run modes, the TNC moves the tool as defined in the part program.

Behavior with M140

With M140 MB (move back) you can enter a path in the direction of the tool axis for departure from the contour.

Input

If you enter M140 in a positioning block, the TNC continues the dialog and asks for the desired path of tool departure from the contour. Enter the requested path that the tool should follow when departing the contour, or press the MB MAX soft key to move to the limit of the traverse range.

In addition, you can program the feed rate at which the tool traverses the entered path. If you do not enter a feed rate, the TNC moves the tool along the entered path at rapid traverse.

Effect

M140 is effective only in the block in which it is programmed.

M140 becomes effective at the start of the block.

Example NC blocks

Block 250: Retract the tool 50 mm from the contour.

Block 251: Move the tool to the limit of the traverse range.

```
N250 G01 X+0 Y+38.5 F125 M140 MB50 *
```

```
N251 G01 X+0 Y+38.5 F125 M140 MB MAX *
```



M140 is also effective if the tilted-working-plane function, M114 or M128 is active. On machines with tilting heads, the TNC then moves the tool in the tilted coordinate system.

With the **FN18: SYSREAD ID230 NR6** function you can find the distance from the current position to the limit of the traverse range in the positive tool axis.

With **M140 MB MAX** you can only retract in positive direction.

Always define a TOOL CALL with a tool axis before entering **M140**, otherwise the direction of traverse is not defined.





Danger of collision!

When dynamic collision monitoring (DCM) is active, the TNC might move the tool only until it detects a collision and, from there, complete the NC program without any error message. This can result in tool paths different from those programmed!

Suppressing touch probe monitoring: M141

Standard behavior

When the stylus is deflected, the TNC outputs an error message as soon as you attempt to move a machine axis.

Behavior with M141

The TNC moves the machine axes even if the touch probe is deflected. This function is required if you wish to write your own measuring cycle in connection with measuring cycle 3 in order to retract the stylus by means of a positioning block after it has been deflected.



Danger of collision!

If you use M141, make sure that you retract the touch probe in the correct direction.

M141 functions only for movements with straight-line blocks.

Effect

M141 is effective only in the block in which it is programmed.

M141 becomes effective at the start of the block.



Delete modal program information: M142

Standard behavior

The TNC resets modal program information in the following situations:

- Select a new program
- Execute a miscellaneous function **M2**, **M30**, or an **N99999999** `%...` block (depending on MP7300)
- Defining cycles for basic behavior with a new value

Behavior with M142

All modal program information except for basic rotation, 3-D rotation and Q parameters is reset.



The function **M142** is not permitted during mid-program startup.

Effect

M142 is effective only in the block in which it is programmed.

M142 becomes effective at the start of the block.

Delete basic rotation: M143

Standard behavior

The basic rotation remains in effect until it is reset or is overwritten with a new value.

Behavior with M143

The TNC erases a programmed basic rotation from the NC program.



The function **M143** is not permitted during mid-program startup.

Effect

M143 is effective only in the block in which it is programmed.

M143 becomes effective at the start of the block.



Automatically retract tool from the contour at an NC stop: M148

Standard behavior

At an NC stop the TNC stops all traverse movements. The tool stops moving at the point of interruption.

Behavior with M148



The M148 function must be enabled by the machine tool builder. The machine tool builder defines in a machine parameter the path that the TNC is to traverse for a **LIFTOFF** command.

The TNC retracts the tool by up to 30 mm in the direction of the tool axis if, in the **LIFTOFF** column of the tool table, you set the parameter **Y** for the active tool (see "Tool table: Standard tool data" on page 166).

LIFTOFF takes effect in the following situations:

- An NC stop triggered by you
- An NC stop triggered by the software, e.g. if an error occurred in the drive system
- When a power interruption occurs



Danger of collision!

Remember that, especially on curved surfaces, the surface can be damaged during return to the contour. Back the tool off before returning to the contour!

Effect

M148 remains in effect until deactivated with M149.

M148 becomes effective at the start of block, M149 at the end of block.



Suppress limit switch message: M150

Standard behavior

The TNC stops program run with an error message if the tool were to leave the active working space during a positioning block. The error message is output before the positioning block is executed.

Behavior with M150

If the end point of a positioning block with M150 is outside the current working space, the TNC moves the tool to the edge of the working space, and then continues the program run without an error message.



Danger of collision!

Keep in mind that the approach path to the position programmed after the M150 block might be changed significantly!

M150 is also effective on traverse range limits defined with the MOD function.

M150 is effective even if you have the handwheel superimposition function active. The TNC then moves the tool by the defined maximum value of the handwheel superimposition away from the limit switch.

When dynamic collision monitoring (DCM) is active, the TNC might move the tool only until it detects a collision and, from there, complete the NC program without any error message. This can result in tool paths different from those programmed!

Effect

M150 is effective only in straight-line blocks and the block in which it is programmed.

M150 becomes effective at the start of block.



10.5 Miscellaneous Functions for Laser Cutting Machines

Principle

The TNC can control the cutting efficiency of a laser by transferring voltage values through the S-analog output. You can influence laser efficiency during program run through the miscellaneous functions M200 to M204.

Entering miscellaneous functions for laser cutting machines

If you enter an M function for laser cutting machines in a positioning block, the TNC continues the dialog by asking you the required parameters for the programmed function.

All miscellaneous functions for laser cutting machines become effective at the start of the block.

Output the programmed voltage directly: M200

Behavior with M200

The TNC outputs the value programmed after M200 as the voltage V .

Input range: 0 to 9999 V

Effect

M200 remains in effect until a new voltage is output through M200, M201, M202, M203 or M204.

Output voltage as a function of distance: M201

Behavior with M201

M201 outputs the voltage in dependence on the distance to be covered. The TNC increases or decreases the current voltage linearly to the value programmed for V .

Input range: 0 to 9999 V

Effect

M201 remains in effect until a new voltage is output through M200, M201, M202, M203 or M204.



Output voltage as a function of speed: M202

Behavior with M202

The TNC outputs the voltage as a function of speed. In the machine parameters, the machine tool builder defines up to three characteristic curves FNR in which specific feed rates are assigned to specific voltages. Use miscellaneous function M202 to select the curve FNR from which the TNC is to determine the output voltage.

Input range: 1 to 3

Effect

M202 remains in effect until a new voltage is output through M200, M201, M202, M203 or M204.

Output voltage as a function of time (time-dependent ramp): M203

Behavior with M203

The TNC outputs the voltage V as a function of the time $TIME$. The TNC increases or decreases the current voltage linearly to the value programmed for V within the time programmed for $TIME$.

Input range

Voltage V : 0 to 9999 Volt
TIME: 0 to 1 999 seconds

Effect

M203 remains in effect until a new voltage is output through M200, M201, M202, M203 or M204.

Output voltage as a function of time (time-dependent pulse): M204

Behavior with M204

The TNC outputs a programmed voltage as a pulse with a programmed duration $TIME$.

Input range

Voltage V : 0 to 9999 Volt
TIME: 0 to 1 999 seconds

Effect

M204 remains in effect until a new voltage is output through M200, M201, M202, M203 or M204.





11

**Programming:
Special Functions**



11.1 Overview of Special Functions

The TNC provides the following powerful special functions for a large number of applications:

Function	Description
Dynamic Collision Monitoring (DCM—software option)	Page 337
Global Program Settings (GS—software option)	Page 355
Adaptive Feed Control Software Option (AFC—software option)	Page 366
Working with text files	Page 377
Working with cutting data tables	Page 382


Press the SPEC FCT and the corresponding soft keys to access further special functions of the TNC. The following tables will give you an overview of which functions are available.

Main menu for SPEC FCT special functions



► Press the Special Functions key

Function	Soft key	Description
Define program defaults	PROGRAM DEFAULTS	Page 335
Functions for contour and point machining	CONTOUR + POINT MACHINING	Page 335
Define the PLANE function	TILT MACHINING PLANE	Page 393
Define different DIN/ISO functions	PROGRAM FUNCTIONS	Page 336
Define structure items	INSERT SECTION	Page 142




Program defaults menu

PROGRAM
DEFAULTS

► Select the program defaults menu

Function	Soft key	Description
Define the workpiece blank	BLK FORM	Page 103
Define the material	MAT	Page 383
Select datum table	DATUM TABLE	See User's Manual for Cycles




Functions for contour and point machining menu

CONTOUR
+ POINT
MACHINING

► Select the menu for functions for contour and point machining.

Function	Soft key	Description
Assign contour description	DECLARE CONTOUR	See User's Manual for Cycles
Select a contour definition	SEL CONTOUR	See User's Manual for Cycles
Define a complex contour formula	CONTOUR FORMULA	See User's Manual for Cycles
Select the point file with machining positions	SEL PATTERN	See User's Manual for Cycles




Menu of various DIN/ISO functions

PROGRAM
FUNCTIONS

- ▶ Select the menu for defining various plain-language functions

Function	Soft key	Description
Define string functions	STRING FUNCTIONS	Page 285



11.2 Dynamic Collision Monitoring (Software Option)

Function



The Dynamic Collision Monitoring (**DCM**) must be adapted by the machine manufacturer for the TNC and for the machine. Refer to your machine tool manual.

The machine manufacturer can define any objects that are monitored by the TNC during all machining operations and even in the Test Run mode. If two objects monitored for collision come within a defined distance of each other, the TNC outputs an error message during test run and machining.

The TNC can display the defined collision objects graphically in all machining modes and during test run (see "Graphic depiction of the protected space (FCL4 function)" on page 341).

The TNC also monitors the current tool with the length and radius entered in the tool table for collision (assuming a cylindrical tool). Provided that you have defined a separate tool holder kinematic description for the respective tool, including a collision body description, and have assigned it to the tool in the KINEMATIC column, the TNC monitors this tool holder also (see "Tool-carrier kinematics" on page 174).

Also, you can integrate simple fixtures in the collision monitoring (see "Fixture Monitoring (Software Option)" on page 343).





Keep these constraints in mind:

- DCM helps to reduce the danger of collision. However, the TNC cannot consider all possible constellations in operation.
- Collisions of defined machine components and the tool with the workpiece are not detected by the TNC.
- DCM can only protect those machine components from collision that your machine tool builder has correctly defined with regard to dimensions and position in the machine coordinate system.
- The TNC can monitor the tool only if a **positive tool radius** has been defined in the tool table. The TNC cannot monitor tools with a radius of 0 (as is often used in drilling tools) and therefore issues an appropriate error message.
- The TNC can only monitor tools for which you have defined **positive tool lengths**.
- For certain tools (such as face milling cutters), the diameter that would cause a collision can be greater than the dimensions defined in the tool-compensation data.
- The handwheel superimpositioning function (M118 and global program settings) in combination with collision monitoring is only possible in stopped condition (blinking control-in-operation symbol). To be able to use M118 without limitations, you have to deselect DCM either by soft key in the **Collision Monitoring (DCM)** menu, or activate a kinematics model without collision monitored objects (CMOs).
- With the rigid-tapping cycles, DCM works only if the exact interpolation of the tool axis with the spindle is activated through MP7160.



Collision monitoring in the manual operating modes

In the **Manual** and **Electronic Handwheel** operating modes, the TNC stops a motion if two objects monitored for collision approach each other within a distance of less than 3 to 5 mm. In this case, the TNC displays an error message naming the two objects causing collision.

If you have selected a screen layout in which positions are displayed on the left and collision objects on the right, then the TNC additionally marks the colliding objects in red.



Once a collision warning is displayed, machine motions via the direction keys or handwheel are possible only if the motion increases the distance between the collision objects. For example, by pressing the axis direction key for the opposite direction.

Motions that reduce the distance or leave it unchanged are not allowed as long as collision monitoring is active.

Deactivating Collision Monitoring



If you have to reduce the distance between collision-monitored objects for lack of space, the collision monitoring function must be deactivated.



Danger of collision!

If you have deactivated the collision monitoring, the symbol for collision monitoring flashes (see following table).

Function	Symbol
Symbol that appears in the operating mode bar when collision monitoring is not active.	



▶ Shift the soft-key row if necessary.



▶ Select the menu for deactivating collision monitoring.



▶ Select the **Manual Operation** menu item.

▶ To deactivate collision monitoring, press the ENT key, and the symbol for collision monitoring in the operating mode display starts to blink.


- ▶ Move axes manually, pay attention to traverse direction
- ▶ To reactivate the collision monitor: Press the ENT key.



Collision monitoring in Automatic operation



The handwheel superimpositioning function with M118 in combination with collision monitoring is only possible in stopped condition (blinking control-in-operation symbol).

If collision monitoring is on, the TNC shows the symbol  in the position display.

If you have deactivated collision monitoring, the symbol for collision monitoring flashes in the operating-mode bar.



Danger of collision!

The M140 (see "Retraction from the contour in the tool-axis direction: M140" on page 326) and M150 (see "Suppress limit switch message: M150" on page 330) functions might cause non-programmed movements if the TNC detects a collision when executing these functions!





The TNC monitors motions blockwise, i.e. it outputs a warning in the block which would cause a collision, and interrupts program run. A reduction of the feed rate, as with Manual Operation, does not occur.




Graphic depiction of the protected space (FCL4 function)

You can use the split-screen layout key to have the machine-based collision objects defined on your machine and measured fixtures be shown in three dimensions (see “Program Run, Full Sequence and Program Run, Single Block” on page 82).

Press the right mouse button to rotate the overall view of the collision objects. You can switch between the various views via soft key:

Function	Soft key
Switch between wire-frame and solid-object view	
Switch between solid and transparent view	
Display/hide the coordinate systems that result from transformations in the kinematics description.	
Functions for rotating in the X and Z axes, and magnifying/reducing	



Collision monitoring in the Test Run mode of operation

Function

With this feature you can test for collisions before actual machining.

Prerequisites



The graphic simulation testing must be enabled by your machine tool builder in order to run.

Conducting a collision test



You specify the datum for the collision test in the "workpiece blank in working space" function (see "Showing the Workpiece in the Working Space" on page 565)!



- ▶ Select the Test Run operating mode
- ▶ Select the program that you want to check for collision



- ▶ Select the screen layout PROGRAM+KINEMATICS or KINEMATICS



- ▶ Shift the soft-key row twice



- ▶ Set the collision testing to ON



- ▶ Shift the soft-key row back twice



- ▶ Start the test run

Press the right mouse button to rotate the overall view of the collision objects. You can switch between the various views via soft key:

Function	Soft key
Switch between wire-frame and solid-object view	
Switch between solid and transparent view	
Display/hide the coordinate systems that result from transformations in the kinematics description.	
Functions for rotating in the X and Z axes, and magnifying/reducing	



11.3 Fixture Monitoring (Software Option)

Fundamentals



Your machine tool builder must define permissible location points in the kinematic description before you can use the fixture monitoring. The machine tool manual provides further information.

Your machine has to feature a 3-D touch probe for workpiece measurement. Otherwise you cannot locate the fixture on the machine.

Using the fixture management in the Manual operating mode, you can place simple fixtures in the working space of the machine in order to implement collision monitoring between the tool and the fixture.

Several work steps are required to place fixtures

■ Model the fixture template

On its Web site, HEIDENHAIN provides fixture templates such as vises or jaw chucks in a fixture template library (see "Fixture templates" on page 344), that were created with the PC program KinematicsDesign. The machine tool builder can model additional fixture templates and provide you with them. The fixture templates have the file name extension **cft**

■ Set the fixture parameter values: FixtureWizard


With the FixtureWizard you define the exact dimensions of the fixture by entering parameter values in the fixture template. The FixtureWizard is available as a component of the TNC fixture management. It generates a placeable fixture with concrete dimensions defined by you, (see "Setting parameter values for the fixture: FixtureWizard" on page 344). Placeable fixture templates have the file name extension **cfx**

■ Place the fixture on the machine

In an interactive menu the TNC guides you through the actual measurement process. The measurement process consists essentially of the performance of various probing functions on the fixture and entering variable sizes, for example the jaw gap of a vise (see "Placing the fixture on the machine" on page 346)

■ Check the position of the measured fixture

After you have placed the fixture, you can have the TNC create a measuring program as needed with which you can have the actual position of the placed fixture compared with the nominal position. If the deviations between the nominal and actual positions are too large, the TNC issues an error message (see "Check the position of the measured fixture" on page 348)



Fixture templates

HEIDENHAIN provides various fixture templates in a fixture library. If you need any of them, please contact HEIDENHAIN (e-mail address service.nc-pgm@heidenhain.de) or your machine tool builder.

Setting parameter values for the fixture: FixtureWizard


With the FixtureWizard you can use a fixture template to create a fixture with exact dimensions. HEIDENHAIN provides templates for standard fixtures. Your machine tool builder may also provide fixture templates.



Before you start the FixtureWizard, you must have copied the fixture template and its parameters to the TNC!



- ▶ Call the fixture management
- ▶ Start the FixtureWizard: The TNC opens the menu for parameterization of fixture templates
- ▶ Select the fixture template: The TNC opens the window for selecting a fixture template (files with extension **CFI**)
- ▶ Use the mouse to select the fixture template for which you want to enter values and confirm with **Open**
- ▶ Enter the values of all the fixture parameters shown in the left window. Use the arrow keys to move the cursor to the next input field. After value entry, the TNC updates the 3-D view of the fixture in the window below. As far as is available, the TNC displays an illustration in the upper right window graphically showing the fixture parameter to be entered.
- ▶ Enter the name of the defined fixture in the **Output file** input field and confirm with the **Generate file** soft key. It is not necessary to enter the file extension (**CFI** for parameterized)
- ▶ Exit FixtureWizard











Operating FixtureWizard

FixtureWizard is operated primarily with the mouse. You can change the screen layout by pulling the separator lines so that the **Parameters**, **Help graphics** and **3-D graphic** are displayed in the size you prefer.

You can change the depiction of the **3-D graphic** as follows:

- Enlarge/reduce the model:
Turning the mouse wheel enlarges or reduces the model
- Move the model:
Pressing the mouse wheel and moving the mouse at the same time moves the model
- Rotate the model:
Pressing the mouse key and moving the mouse at the same time rotates the model

In addition, buttons are available that perform the following function when clicked:

Function	Button
Exit FixtureWizard	
Open a fixture template (files with the extension CFT)	
Switch between wire-frame and solid-object view	
Switch between solid and transparent view	
Show/hide the designations of the collision bodies defined in the fixture	
Show/hide the test points defined in the fixture (no function in the ToolHolderWizard)	
Show/hide the measurement points defined in the fixture (no function in the ToolHolderWizard)	
Restore the initial position of the 3-D view	



Placing the fixture on the machine



Insert a touch probe before you place a fixture!



- ▶ Call the fixture management



- ▶ Select the fixture: The TNC opens the menu for fixture selection and shows in the left window all fixtures available in the active directory. Fixtures have the file name extension **CFX**



- ▶ In the left window, use the mouse or arrow keys to select a fixture. In the right window the TNC shows a preview of the respectively selected fixture



- ▶ Load fixture: The TNC calculates the required **sequence of measurement** and displays it in the left window. In the right window it shows the fixture. Measurement points are marked with a colored datum symbol on the fixture. In addition, there is a sequence of numbers to show you the order for measuring the fixture



- ▶ Start the measurement process: The TNC shows a soft-key row with permitted scanning functions for the respective measuring process



- ▶ Select the required probing function: The TNC is in the menu for manual probing. Description of the probing functions: See "Overview" on page 487

- ▶ At the end of the probing process the TNC displays the measured values



- ▶ Load the measured values: The TNC ends the measuring process, checks it off in the measurement sequence and places the highlight on the subsequent task



- ▶ If input of a value is required in the respective fixture, the TNC shows a highlight at the lower end of the screen. Enter the requested value, e.g. jaw width of a vise, and confirm with the ACCEPT VALUE soft key



- ▶ When all measuring tasks are checked off by the TNC, complete the measuring process with the COMPLETE soft key



The sequence of measurement is specified in the fixture template. You have to run through the sequence of measurements step by step from top to bottom.

With multiple setup you have to place each fixture separately.



Editing fixtures



Only value input is editable. The position of the fixture on the machine table cannot be corrected after placement. To change the position of the fixture you have to remove it first and then place it again!



- ▶ Call the fixture management
- ▶ Use the mouse or the arrow keys to select the fixture that you want to edit. The TNC highlights the selected fixture with color



- ▶ To change the selected fixture, in the **measurement sequence** window the TNC shows the fixture parameters that you can edit
- ▶ Confirm removal with the YES soft key or cancel it with NO

Removing fixtures



Danger of collision!

If you remove a fixture, the TNC no longer monitors it, even if it is still clamped on the machine table!



- ▶ Call the fixture management
- ▶ Use the mouse or the arrow keys to select the fixture that you want to remove. The TNC highlights the selected fixture with color



- ▶ Remove selected fixture
- ▶ Confirm removal with the YES soft key or cancel it with NO



Check the position of the measured fixture


To inspect measured fixtures, you can have the TNC generate a test program. You have to run the inspection program in the Full Sequence operating mode. The TNC probes test points that are specified by the fixture designer in the fixture template and evaluates them. It provides the result of the inspection on screen and in a log file.



The TNC always saves inspection programs in the **TNC:system\Fixture\TpCheck_PGM** directory.



- ▶ Call the fixture management
- ▶ In the **Place fixtures** window, use the mouse to mark the fixture to be inspected. The TNC displays the marked fixture in a different color in the 3-D view
- ▶ Start the dialog for generating the inspection program. The TNC opens the window for entering the **Test program parameters**
- ▶ **Manual positioning:** Specify whether you want to position the touch probe manually or automatically between the individual inspection points:
 - 1:** Manual positioning. You have to move to each inspection point with the axis-direction keys and confirm the measuring process with NC start
 - 0:** After you have manually pre-positioned the touch probe to clearance height, the test program runs automatically
- ▶ **Feed rate for measurement:**
Touch probe feed rate in mm/min for the measuring process. Input range 0 to 3000
- ▶ **Feed rate for pre-positioning:**
Positioning feed rate in mm/min for moving to the individual measurement positions. Input range 0 to 99999.999



- ▶ **Set-up clearance:**
Setup clearance to the measuring point that the TNC should maintain during pre-positioning. Input range 0 to 99999.9999
 - ▶ **Tolerance:**
Maximum permissible deviation between nominal and actual position of the respective test points. Input range 0 to 99999.999. If the test point is out of tolerance, the TNC issues an error message
 - ▶ **Tool number/tool name:**
Tool number (or name) of the touch probe. Input range 0 to 30000.9 if a number is entered; maximum 16 characters if a name is entered. If entering a tool name, enter it between single quotation marks
- ENT
- ▶ Confirm the entries: The TNC generates the test program, shows the name of the test program in a pop-up window and asks whether you want to run the test program
 - ▶ Answer with NO if you want to run the test program later, and with YES if you want to run it now
 - ▶ If you have confirmed with YES, the TNC changes to the Full Sequence mode and automatically selects the generated program
- I
- ▶ Start the test program: The TNC prompts you to manually pre-position the touch probe so that it is located at clearance height. Follow the instructions in the pop-up window
- I
- ▶ Start the measuring process: The TNC moves to each test point one after the other. With a soft key you specify the positioning strategy. Conform with NC start each time
 - ▶ At the end of the test program the TNC displays a pop-up window with the deviations from the nominal position. If a test point is out of tolerance, the TNC issues an error message in the pop-up window








Manage fixtures

You can save and restore measured fixtures via the Archive function. This function is especially useful for integrated fixtures and speeds up the setup procedure considerably.

Manage fixtures

The following functions for fixture management are available:

Function	Soft key
Save fixture	
Load saved fixture	
Copy saved fixture	
Rename saved fixture	
Delete saved fixture	



Save fixture

- ▶ Call the fixture management, if required
- ▶ With the arrow keys, choose the chucking equipment you want to save



- ▶ Select Archive function: The TNC displays a window and shows the fixtures that have been saved



- ▶ Save the active chucking equipment to an archive (zip file): The TNC displays a window in which you can define the name of the archive
- ▶ Enter the file name and confirm with the YES soft key: The TNC saves the zip archive in a fixed archive folder (**TNC:\system\Fixture\Archive**)

Load fixture

- ▶ Call the fixture management, if required
- ▶ If required, use the arrow keys to select an insertion point at which you wish to restore a saved fixture



- ▶ Select Archive function: The TNC displays a window and shows the fixtures that have been saved

- ▶ With the arrow keys, select the fixture you wish to restore



- ▶ Load the fixture: The TNC activates the selected fixture and displays an image of the chucking equipment contained in the fixture



If you restore the fixture to another insertion point, you have to confirm the corresponding dialog question of the TNC with the YES soft key.



11.4 Tool Holder Management (DCM Software Option)

Fundamentals



Your machine tool builder must have prepared the TNC for this function, refer to the machine tool manual.

Just as fixture monitoring, you can also integrate tool holder in the collision monitoring.

Several work steps are required to enable tool holders for collision monitoring:

■ Model the tool holder

On its Web site, HEIDENHAIN provides tool holder templates that were created with a PC software (KinematicsDesign). Your machine tool builder can model additional tool holder templates and provide you with them. The tool holder templates have the file name extension **cft**.

■ Set the tool holder parameters: ToolHolderWizard

With the ToolHolderWizard you define the exact dimensions of the tool holder by entering parameter values in the tool holder template. Call the ToolHolderWizard from the tool table if you wish to assign tool holder kinematics to a tool. Tool holder templates with parameters have the file name extension **cfx**.

■ Activate the tool holder

In the tool table TOOL.T, assign the selected tool holder to a tool in the **KINEMATICS** column (see "Assigning the tool-carrier kinematics" on page 174).

Tool-holder templates

HEIDENHAIN provides various tool holder templates. If you need any of them, please contact HEIDENHAIN (e-mail address **service.nc-pgm@heidenhain.de**) or your machine tool builder.



Set the tool holder parameters: ToolHolderWizard

With the ToolHolderWizard you can use a tool-holder template to create a tool holder with exact dimensions. HEIDENHAIN provides templates for tool holders. Your machine tool builder may also provide tool holder templates.



Before you start the ToolHolderWizard, you must have copied the tool-holder template to be parameterized to the TNC!

Follow the procedure below to assign carrier kinematics to a tool:

- ▶ Select any machine operating mode.



- ▶ Press the **TOOL TABLE** soft key to select the tool table.



- ▶ Set the **EDIT** soft key to **ON**.



- ▶ Select the last soft key row.



- ▶ Show the list of available kinematics: The TNC displays all tool holder kinematics (.TAB files) and all tool-holder kinematics you have already parameterized (.CFX files).



- ▶ Call the ToolHolderWizard



- ▶ Select the tool-holder template: The TNC opens the window for selecting a tool-holder template (files with extension **CFT**)

- ▶ Use the mouse to select the tool-holder template for which you want to enter parameter values and confirm with **Open**

- ▶ Enter all of the parameters shown in the left window. Use the arrow keys to move the cursor to the next input field. After value entry, the TNC updates the 3-D view of the tool holder in the window at bottom right. As far as is available, the TNC displays an illustration in the upper right window graphically showing the parameter to be entered.


- ▶ Enter the name of the defined tool holder in the **Output file** input field and confirm with the **Generate file** soft key. It is not necessary to enter the file extension (**CFX** for parameterized)



- ▶ Exit the ToolHolderWizard

Operating the ToolHolderWizard

The ToolHolderWizard is operated in the same way as the FixtureWizards: (see "Operating FixtureWizard" on page 345)



Removing a tool holder



Danger of collision!

If you remove a tool holder, the TNC no longer monitors it, even if it is still in the spindle

- ▶ Delete the name of the tool holder from the KINEMATICS column in the tool table (TOOL.T).











11.5 Global Program Settings (Software Option)


Function

The **global program settings**, which are used in particular for large molds and dies, are available in the Program Run mode and MDI mode. You can use them to define various coordinate transformations and settings that are globally effective and are superimposed on the respectively selected NC program so that you do not need to edit the NC program.

You can activate and deactivate global program settings, even in mid-program if you have interrupted the program run (see “Interrupting machining” on page 529). The TNC immediately accounts for the values you have defined after you have restarted the NC program. The control might move to the new position over the reapproach menu (see “Returning to the contour” on page 536).

The following global program settings are available:

Functions	Icon	Page
Basic rotation		Page 360
Swapping axes		Page 361
Additional, additive datum shift		Page 362
Superimposed mirroring		Page 362
Superimposed rotation		Page 363
Axis locking		Page 363
Definition of a handwheel superimposition, even in the virtual axis direction VT		Page 364
Definition of a globally effective feed rate factor		Page 363





You cannot use the following global program run settings if you have used the **M91/M92** function (moving to machine-referenced positions) in your NC program:

- Swapping axes
- Locking axes

You can use the look-ahead function **M120** if you have activated the global program settings before starting the program. If **M120** is active and you change global settings during the program, the TNC will show an error message and stop any further machining.

If DCM collision monitoring is active you can only move with handwheel superimposition if you have interrupted the machining program with an external stop.

In the fillable form the TNC grays out any axes that are not active on your machine.

Shift values and values for handwheel superimposition in the fillable form must always be defined in millimeters; angle values for rotations must be defined in degrees.



Technical prerequisites



The **global program settings** function is a software option and must be enabled by your machine tool builder.

To be able to use the handwheel superimposition function, HEIDENHAIN recommends the use of the HR 520 handwheel (see "Traversing with electronic handwheels" on page 452). Direct selection of the virtual tool axis is possible with the HR 520.

In principle, you can then use the HR 410 handwheel, but your machine tool builder must then assign a function key of the handwheel to selection of the virtual tool axis and program it in his PLC program.



To be able to use all functions without limits, the following machine parameters must be set:


- **MP7641, bit 4 = 1:**
Permit selection of the virtual axis on the HR 420
- **MP7503 = 1:**
Traverse in active tool-axis direction is active in the Manual operating mode and during a program interruption
- **MP7682, bit 9 = 1:**
Automatically transfer the tilted condition from the automatic mode to the Manual mode
- **MP7682, bit 10 = 1:**
Permit 3-D compensation with active tilted working plane and active M128 (TCPM)



Activating/deactivating a function



Global program settings remain active until you manually reset them.

If a global program setting is active, the TNC shows the  symbol in the position display.

If you use the file manager to select a program, the TNC displays a warning message if global settings are active. Then you can simply acknowledge the message with the soft key or call the form directly to make the changes.

Global program settings have no effect in the smarT.NC operating mode.



- ▶ Select the Program Run or Manual Data Input operating mode



- ▶ Shift the soft-key row



- ▶ Call the global program settings form
- ▶ Activate the desired functions with the corresponding values













If you activate more than one global program setting, the TNC calculates the transformations internally in the following sequence:

- **1:** Basic rotation
- **2:** Axis swapping
- **3:** Mirror image
- **4:** Shift
- **5:** Superimposed rotation

The remaining functions such as axis locking, handwheel superimposition and feed rate factor act independently.



The following functions help you to navigate in the form. You can also use the mouse to use the form.

Functions	Key/ Soft key
Jump to previous function	
Jump to next function	
Select the next element	
Select the previous element	
Axis swapping function: Open the list of available axes	
Switch the function on/off if the cursor is on a check box	
Reset the global program settings: <ul style="list-style-type: none"> ■ Deactivate all functions ■ Set all entered values to 0, set feed rate factor to 100. Set basic rotation = 0 if no basic rotation is active in the basic rotation menu or in the ROT column of the active preset in the preset table. Otherwise the TNC activates the basic rotation entered there	
Discard all changes since the form was last called	
Deactivate all active functions. The entered or adjusted values remain	
Save all changes and close the form	



Basic rotation

The basic rotation function enables you to compensate a workpiece misalignment. The effect corresponds to the basic rotation function that you can define in the manual mode with the probing functions. The TNC synchronizes the values entered in the basic rotation menu or the ROT column of the preset table with the fillable form.

You can change the basic rotation values in the form, but the TNC does not write them back into the basic rotation menu or the preset table.

If you press the SET STANDARD VALUES soft key, the TNC restores the basic rotation assigned to the active preset.



Remember that you may have to return to the contour after activation of this function. The TNC then automatically calls the return-to-contour menu after the form is closed (see "Returning to the contour" on page 536).

Please note that probing cycles with which you measure and write a basic rotation during program run overwrite the value defined by you in the fillable form.



Swapping axes

With the axis swapping function you can adapt the axes programmed in any NC program to your machine's axis configuration or to the respective clamping situation.



After activation of the axis swapping function, all subsequent transformations are applied to the swapped axes.

Be sure to swap the axes appropriately. Otherwise the TNC will display error messages.

Remember that you may have to return to the contour after activation of this function. The TNC then automatically calls the return-to-contour menu after the form is closed (see "Returning to the contour" on page 536).

- ▶ In the global program settings form, move the cursor to **EXCHANGE ON/OFF**, and use the SPACE key to activate the function.
- ▶ With the downward arrow key, set the cursor to the line showing at left the axis to be swapped
- ▶ Press the GOTO key to display the list of axes with which you can exchange it
- ▶ With the downward arrow key, select the axes with which you wish to exchange, and confirm with the ENT key

If you work with a mouse, you can select the desired axis directly by clicking it in the respective pull-down menu.



Superimposed mirroring

With the superimposed mirroring function you can mirror all active axes.



The mirrored axes defined in the form work in addition to the values already defined in the program through Cycle 8 (mirroring).

Remember that you may have to return to the contour after activation of this function. The TNC then automatically calls the return-to-contour menu after the form is closed (see "Returning to the contour" on page 536).

- ▶ In the global program settings form, move the cursor to **MIRRORING ON/OFF**, and use the SPACE key to activate the function.
- ▶ With the downward arrow key, set the cursor to the axis that you want to mirror
- ▶ Press the SPACE key to mirror the axis. Pressing the SPACE key again cancels the function.

If you work with a mouse, you can select the desired axis directly by clicking it.

Additional, additive datum shift

With the additive datum shift function you can compensate any offsets in all active axes.



The values defined in the form work in addition to the values already defined in the program through Cycle 7 (datum shift).

Please note that the shifts defined when the working plane is tilted are effective in the machine coordinate system.

Remember that you may have to return to the contour after activation of this function. The TNC then automatically calls the return-to-contour menu after the form is closed (see "Returning to the contour" on page 536).



Axis locking

With this function you can lock all active axes. Then when you run a program, the TNC does not move any of the axes you locked.



When you activate this function, ensure that the positions of the locked axes cannot cause any collisions.

- ▶ In the global program settings form, move the cursor to **LOCK ON/OFF**, and activate the function with the SPACE key
- ▶ With the downward arrow key, set the cursor to the axis that you want to lock
- ▶ Press the SPACE key to lock the axis. Pressing the SPACE key again cancels the function.

If you work with a mouse, you can select the desired axis directly by clicking it.

Superimposed rotation

With the superimposed rotation function you can define any rotation of the coordinate system in the presently active working plane.



The superimposed rotation defined in the form works in addition to the values already defined in the program through Cycle 10 (rotation).

Remember that you may have to return to the contour after activation of this function. The TNC then automatically calls the return-to-contour menu after the form is closed (see "Returning to the contour" on page 536).

Feed rate override

With the feed rate override function, you can decrease or increase the programmed feed rate by a percentage. The input range is 1% to 1000%.



Remember that the TNC always applies the feed rate factor to the current feed rate, which you may already have changed through the feed rate override.



Handwheel superimposition

The handwheel superimposition function enables you to use the handwheel to move the axes while the TNC is running a program.

In the **Max. val.** column you define the maximum distance by which you can move the axis by handwheel. As soon as you interrupt the program run (control-in-operation signal is off), the TNC shows the distances actually moved in each axis in the **actual value** column. The actual value remains saved until you delete it, even after a power interruption. You can also edit the **actual value**. If required, the TNC decreases the value that you entered to the respective **Max. val.**



If a **actual value** is shown during activation, then when the window closes, the TNC calls the “Return to contour” function to move by the defined value (see “Returning to the contour” on page 536).

The TNC overwrites a maximum traverse distance, already defined in the NC program with **M118** by the value entered in the form. In turn, the TNC enters distances that have already been traversed with the handwheel using **M118** in the **actual value** column of the form so that there is no jump in the display during activation. If the distance already traversed with **M118** is greater than the maximum permissible value in the form, then when the window closes the TNC calls the “return to contour” function in order to move by the difference value (see “Returning to the contour” on page 536).

If you try to enter a **actual value** greater than the **max. value**, the TNC shows an error message. Never enter an **actual value** greater than the **Max. value**.

Do not enter too large a value for **max. value**. The TNC reduces the useable traverse range in positive and negative direction by the value you enter.



Virtual axis VT

You can also carry out handwheel superimpositioning in the currently active tool axis direction. You can use the Virtual Tool axis line (**VT**).

You can select the VT axis via a HR 5xx handwheel in order to traverse with superimpositioning in the virtual axis direction (see "Selecting the axis to be moved" on page 457). Working with the virtual VT axis is particularly convenient with the HR 550 FS wireless handwheel (see "Traversing with electronic handwheels" on page 452).

The TNC also shows the path traversed in the virtual axis in the additional status display (**POS** tab) in the separate **VT** position display.



To be able to traverse with the handwheel in the virtual axis direction VT you have to enable **M128** or **FUNCTION TCPM**.

You can only move with handwheel superimpositioning in the virtual axis direction if DCM is inactive.

To traverse in the virtual axis direction with a non-controlled swivel head you can use the M114 function and define the position of the rotary axis directly within this function or via Q parameters.



11.6 Adaptive Feed Control Software Option (AFC)

Application



The **AFC** feature must be enabled and adapted by the machine tool builder. Refer to your machine tool manual.

Your machine tool builder may also have specified whether the TNC uses the spindle power or any other value as the input value for the feed control.




Adaptive feed control is not intended for tools with diameters less than 5 mm. This limit diameter might also be greater if the spindle's rated power is very high.

Do not work with adaptive feed control in operations in which the feed rate and spindle speed must be adapted to each other, such as tapping.

In adaptive feed control the TNC automatically controls the feed rate during program run as a function of the current spindle power consumption. The spindle power required for each machining step is to be recorded in a teach-in cut and saved by the TNC in a file belonging to the part program. When each machining step is started, which is normally when the spindle is switched on with **M3**, the TNC controls the feed rate so that it remains within the limits that you have defined.

This makes it possible to avoid negative effects on the tool, the workpiece, and the machine that might be caused by changing cutting conditions. Cutting conditions are changed particularly by:

- Tool wear
- Fluctuating cutting depths that occur especially with cast parts
- Fluctuating hardness caused by material flaws



Adaptive feed control (AFC) offers the following benefits:

- Machining time is optimized
By controlling the feed rate, the TNC tries to maintain the recorded maximum spindle power during the entire machining time. It shortens the machining time by increasing the feed rate in machining zones with little material removal.
- The tool is monitored
If the spindle power exceeds the recorded maximum value, the TNC decreases the feed rate until the reference spindle power is reattained. If the maximum spindle power is exceeded during machining and at the same time the feed rate falls below the minimum that you defined, the TNC reacts by shutting down. This helps to prevent further damage after a tool breaks or is worn out.
- The machine's mechanical elements are protected
Timely feed rate reduction and shutdown responses help to avoid machine overload.



Defining the AFC basic settings

You enter the settings for the TNC feed rate control in the table **AFC.TAB**, which must be saved in the root directory **TNC:**.

The data in this table are default values that were copied during a teach-in cut into a file belonging to the respective program and serve as the basis for control. The following data are to be defined in this table:

Column	Function
NR	Consecutive line number in the table (has no further functions)
AFC	Name of the control setting. You enter this name in the AFC column of the tool table. It specifies the assignment of control parameters to the tool.
FMIN	Feed rate at which the TNC is to conduct a shutdown response. Enter the value in percent with respect to the programmed feed rate. Input range: 50 to 100%
FMAX	Maximum feed rate in the material up to which the TNC can automatically increase the feed rate. Enter the value in percent of the programmed feed rate.
FIDL	Feed rate for traverse when the tool is not cutting (feed rate in the air). Enter the value in percent of the programmed feed rate.
FENT	Feed rate for traverse when the tool moves into or out of the material. Enter the value in percent with respect to the programmed feed rate. Maximum input value: 100%
OVLD	<p>Desired reaction of the TNC to overload:</p> <ul style="list-style-type: none"> ■ M: Execution of a macro defined by the machine tool builder ■ S: Immediate NC stop ■ F: NC stop if the tool has been retracted ■ E: Just display an error message on the screen ■ -: No overload reaction <p>The TNC conducts a shutdown response if the maximum spindle power is exceeded for more than one second and at the same time the feed rate falls below the minimum you defined. Enter the desired function via the ASCII keyboard.</p>
POUT	Spindle power at which the TNC is to detect tool exit from the workpiece. Enter the value in percent of the learned reference load. Recommended input value: 8%



Column	Function
SENS	Sensitivity (aggressiveness) of regulation. A value between 50 and 200 can be entered. 50 is for slow control, 200 for a very aggressive control. An aggressive control reacts quickly and with strong changes to the values, but it tends to overshoot. Recommended value: 100
PLC	Value that the TNC is to transfer to the PLC at the beginning of a machining step. The machine tool builder defines the function, so refer to your machine manual.



In the **AFC.TAB** table you can define as many control settings (lines) as desired.

If there is no AFC.TAB table in the **TNC:** directory, the TNC uses permanently defined internal control settings for the teach-in cut. It is best, however, to work with the AFC.TAB table.

Proceed as follows to create the AFC.TAB file (only necessary if the file does not yet exist):

- ▶ Select the **Programming and Editing** operating mode.
- ▶ Press the PGM MGT soft key to call the file manager.
- ▶ Select the **TNC:** directory.
- ▶ Make the new file **AFC.TAB** and confirm with the ENT key: The TNC shows a list of table formats.
- ▶ Select the **AFC.TAB** table format and confirm with the ENT key: The TNC creates a table with the **Standard** control settings.



Recording a teach-in cut

In a teach-in cut, first the TNC copies for each machining step the basic settings defined in the AFC.TAB table into the **<name>.H.AFC.DEP** file. **<Name>** is the name of the NC program for which you have recorded the teach-in cut. In addition, the TNC measures the maximum spindle power consumed during the teach-in cut and saves this value in the table.

Each line in the **<name>.H.AFC.DEP** file stands for a machining step that you start with **M3** (or **M4**) and end with **M5**. You can edit all data of the **<name>.H.AFC.DEP** file if you wish to optimize them. If you have optimized the values in comparison with the values in the AFC.TAB table, the TNC places an asterisk ***** in front of the control settings in the AFC column. Besides the data from the AFC.TAB table (see "Defining the AFC basic settings" on page 368), the TNC saves the following additional information in the **<name>.H.AFC.DEP** file:

Column	Function
NR	Number of the machining step
TOOL	Number or name of the tool with which the machining step was made (not editable)
IDX	Index of the tool with which the machining step was made (not editable)
N	Difference for tool call: <ul style="list-style-type: none"> ■ 0: Tool was called by its tool number. ■ 1: Tool was called by its tool name.
PREF	Reference load of the spindle. The TNC measures the value in percent with respect to the rated power of the spindle.
ST	Status of the machining step <ul style="list-style-type: none"> ■ L: In the next program run, a teach-in cut is recorded for this machining step. The TNC overwrites any existing values in this line. ■ C: The teach-in cut was successfully completed. The next program run can be conducted with automatic feed control.
AFC	Name of the control setting



Remember the following before you record a teach-in cut:

- If required, adapt the control settings in the AFC.TAB table
- Enter the desired control setting for all tools in the **AFC** column of the tool table TOOL.T.
- Select the program for teach-in.
- Activate the adaptive feed control by soft key (see "Activating/deactivating AFC" on page 373).



When you are performing a teach-in cut, the TNC shows the spindle reference power determined until this time in a pop-up window.

You can reset the reference power at any time by pressing the PREF RESET soft key. The TNC then restarts the learning phase.

When you record a teach-in cut, the TNC internally sets the spindle override to 100%. Then you can no longer change the spindle speed.

During the teach-in cut, you can influence the measured reference load by using the feed rate override to make any changes to the contouring feed rate.

You do not have to run the entire machining step in the learning mode. If the cutting conditions do not change significantly, you can switch to the control mode immediately. Press the EXIT LEARNING soft key, and the status changes from **L** to **C**.

You can repeat a teach-in cut as often as desired. Manually change the status from **ST** back to **L**. It may be necessary to repeat the teach-in cut if the programmed feed rate is far too fast, and forces you to sharply decrease the feed rate override during the machining step.

The TNC changes the status from teach-in (**L**) to controlling (**C**) only when the recorded reference load is greater than 2%. Adaptive feed control is not possible for smaller values.



You can teach any number of machining steps for a tool. Your machine tool builder will either make a function available for this, or will integrate this possibility in the **M3/M4** and **M5** functions. The machine tool manual provides further information.

Your machine tool builder can provide a feature with which the teach-in cut can be automatically ended after a selectable time. The machine tool manual provides further information.

In addition, your machine tool builder can integrate a function with which you can directly enter the reference power of the spindle, if it is known. In this case a teach-in step is not required.



Proceed as follows to select and, if required, edit the `<name>.H.AFC.DEP` file:



- ▶ Select the **Program Run, Full Sequence** operating mode



- ▶ Shift the soft-key row



- ▶ Select the table of AFC settings.
- ▶ Make optimizations if required



Note that the `<name>.H.AFC.DEP` file is locked against editing as long as the NC program `<name>.H` is running. The TNC then displays the data in the table in red.

The TNC removes the editing lock if one of the following functions has been executed:

- M02
- M30
- END PGM

You can also edit the `<name>.H.AFC.DEP` file in the Programming and Editing mode of operation. If necessary, you can even delete a machining step (entire line) there.



In order to edit the `<name>.H.AFC.DEP` file, you must first set the file manager so that the TNC can display dependent files (see “Configuring PGM MGT” on page 562).



Activating/deactivating AFC



- ▶ Select the **Program Run, Full Sequence** operating mode



- ▶ Shift the soft-key row



- ▶ To activate the adaptive feed control: Set the soft key to ON, and the TNC displays the AFC symbol in the position display (see "Status Displays" on page 83)



- ▶ To deactivate the adaptive feed control: Set the soft key to OFF



The adaptive feed control remains active until you deactivate it by soft key. The TNC remembers the setting of the soft key even if the power is interrupted.


If the adaptive feed control is active in the **control** mode, the TNC internally sets the spindle override to 100%. Then you can no longer change the spindle speed.


If the adaptive feed control is active in the **control** mode, the TNC takes over the feed rate override function:

- If you increase the feed rate override, it has no influence on the control.
- If you decrease the feed rate override by more than **10%** with respect to the maximum setting, the TNC switches the adaptive feed control off. In this case the TNC displays a window to inform you.

In NC blocks containing **FMAX**, the adaptive feed control is **not active**.

Mid-program startup is allowed during active feed control and the TNC takes the cut number of the startup point into account.

In the additional status display, the TNC displays various information when the adaptive feed control is active (see "Adaptive Feed Control (AFC tab, software option)" on page 92). In addition, the TNC shows the symbol  in the position display.



Log file

In a teach-in cut, the TNC saves for each machining step relevant data in the **<name>.H.AFC2.DEP** file. **<Name>** is the name of the NC program for which you have recorded the teach-in cut. During control, the TNC updates the data and makes various evaluations. The following data are to be saved in this table:

Column	Function
NR	Number of the machining step
TOOL	Number or name of the tool with which the machining step was made
IDX	Index of the tool with which the machining step was made
SNOM	Nominal spindle speed [rpm]
SDIF	Maximum difference of the spindle speed in % of the nominal speed
LTIME	Machining time for the teach-in cut
CTIME	Machining time for the control cut
TDIFF	Time difference in % between the machining time during teach-in and control
PMAX	Maximum recorded spindle power during machining. The TNC displays the value in percent with respect to the rated power of the spindle.
PREF	Reference load of the spindle. The TNC shows the value as a percent of the spindle's rated power.
FMIN	Smallest occurring feed factor. The TNC shows the value as a percentage of the programmed feed rate.
OVLD	Reaction by the TNC to overload: <ul style="list-style-type: none"> ■ M: A macro defined by the machine tool builder has been run ■ S: Immediate NC stop was conducted ■ F: NC stop was conducted after the tool was been retracted ■ E: An error message was displayed ■ -: There was no overload reaction
BLOCK	Block number at which the machining step begins





The TNC records the total machining time for all teach-in cuts (**LTIME**), all control cuts (**CTIME**) and the total time difference (**TDIFF**), and enters it after the keyword **TOTAL** in the last line of the log file.

The TNC can only calculate the time difference (**TDIFF**) if you have completed the teach-in step. Otherwise the column remains empty.

Proceed as follows to select the **<name>.H.AFC2.DEP** file:



▶ Select the **Program Run, Full Sequence** operating mode.



▶ Shift the soft-key row.

AFC
SETTINGS

▶ Select the table of AFC settings.

TABLE
EVALU-
ATION

▶ Show the log file.



Tool breakage/tool wear monitoring



This feature must be enabled and adapted by the machine tool builder. Refer to your machine tool manual.

With the breakage/wear monitor, a cut-based tool breakage detection during active AFC can be realized.

Through the functions that can be defined by the machine tool builder you can define a percentage value for wear or breakage detection with respect to the rated power.

When the defined limit spindle power range is not maintained, the TNC conducts an NC stop.

Spindle load monitoring



This feature must be enabled and adapted by the machine tool builder. Refer to your machine tool manual.

With the spindle load monitoring function you can easily have the spindle load monitored in order, for example, to detect overloading the spindle power.

The function is independent of AFC, i.e. it is not cut-based and does not depend on teach-in steps. Through the functions that can be defined by the machine tool builder, you only need to define the percentage value for spindle limit power with respect to the rated power.

When the defined limit spindle power range is not maintained, the TNC conducts an NC stop.



11.7 Creating Text Files

Application

You can use the TNC's text editor to write and edit texts. Typical applications:


- Recording test results
- Documenting working procedures
- Creating formula collections







Text files are type .A files (ASCII files). If you want to edit other types of files, you must first convert them into type .A files.

Opening and exiting text files






- ▶ Select the Programming and Editing mode of operation.
- ▶ Press the PGM MGT key to call the file manager.
- ▶ To display type .A files, press the SELECT TYPE and then the SHOW .A soft keys.
- ▶ Select a file and open it with the SELECT soft key or ENT key, or create a new file by entering the new file name and confirming your entry with the ENT key.

To leave the text editor, call the file manager and select a file of a different file type, for example a part program.



Cursor movements	Soft key
Move cursor one word to the right	
Move cursor one word to the left	
Go to next screen page	
Go to previous screen page	
Go to beginning of file	
Go to end of file	



Editing functions	Key
Begin a new line	
Erase the character to the left of the cursor	
Insert a blank space	
Switch between upper and lower case letters	 

Editing texts

The first line of the text editor is an information headline displaying the file name, and the location and writing mode of the cursor:

File:	Name of the text file
Line:	Line in which the cursor is presently located
Column:	Column in which the cursor is presently located
INSERT:	Insert new text, pushing the existing text to the right
OVERWRITE:	Write over the existing text, erasing it by replacing it with new text

The text is inserted or overwritten at the location of the cursor. You can move the cursor to any desired position in the text file by pressing the arrow keys.





The line in which the cursor is presently located is depicted in a different color. A line can have up to 77 characters. To start a new line, press the RET key or the ENT key.



Deleting and inserting characters, words and lines

With the text editor, you can erase words and even lines, and insert them at any desired location in the text.

- ▶ Move the cursor to the word or line that you wish to erase and insert at a different place in the text
- ▶ Press the DELETE WORD or DELETE LINE soft key. The text is placed in the buffer memory
- ▶ Move the cursor to the location where you wish to insert the text, and press the RESTORE LINE/WORD soft key

Function	Soft key
Delete and temporarily store a line	
Delete and temporarily store a word	
Delete and temporarily store a character	
Insert a line or word from temporary storage	



Editing text blocks

You can copy and erase text blocks of any size, and insert them at other locations. Before any of these actions, you must first select the desired text block:

- ▶ To select a text block, move the cursor to the first character of the text you wish to select



- ▶ Press the SELECT BLOCK soft key
- ▶ Move the cursor to the last character of the text you wish to select. You can select whole lines by moving the cursor up or down directly with the arrow keys—the selected text is shown in a different color

After selecting the desired text block, you can edit the text with the following soft keys:

Function	Soft key
Delete the selected text and store temporarily	
Store marked block temporarily without erasing (copy)	

If desired, you can now insert the temporarily stored block at a different location:

- ▶ Move the cursor to the location where you want to insert the temporarily stored text block



- ▶ Press the INSERT BLOCK soft key for the text block to be inserted

You can insert the temporarily stored text block as often as desired

To transfer the selected text to a different file

- ▶ Select the text block as described previously




- ▶ Press the APPEND TO FILE soft key. The TNC displays the dialog prompt **Destination file =**
- ▶ Enter the path and name of the destination file. The TNC appends the selected text to the specified file. If no target file with the specified name is found, the TNC creates a new file with the selected text.

To insert another file at the cursor position,

- ▶ Move the cursor to the location in the text where you wish to insert another file



- ▶ Press the READ FILE soft key. The TNC displays the dialog prompt **File name =**
- ▶ Enter the path and name of the file you want to insert



Finding text sections

With the text editor, you can search for words or character strings in a text. Two functions are available:


Finding the current text

The search function is used for finding the next occurrence of the word in which the cursor is presently located:

- ▶ Move the cursor to the desired word.
- ▶ To select the search function, press the FIND soft key.
- ▶ Press the FIND CURRENT WORD soft key.
- ▶ To leave the search function, press the END soft key.

Finding any text.

- ▶ To select the search function, press the FIND soft key. The TNC displays the dialog prompt **Find text:**
- ▶ Enter the text that you wish to find.
- ▶ To find the text, press the EXECUTE soft key.
- ▶ To leave the search function, press the END soft key.



11.8 Working with Cutting Data Tables

Note



The TNC must be specially prepared by the machine tool builder for the use of cutting data tables.

Some functions or additional functions described here may not be provided on your machine tool. Refer to your machine tool manual.

Applications

In cutting data tables containing various workpiece and cutting material combinations, the TNC can use the cutting speed V_C and the tooth feed z to calculate the spindle speed S and the feed rate F . This calculation is only possible if you defined the workpiece material in the program and various tool-specific features in the tool table.



Before you let the TNC automatically calculate the cutting data, the tool table from which the TNC is to take the tool-specific data must be first be activated in the Test Run mode (status S).

Editing function for cutting data tables	Soft key
Insert line	INSERT LINE
Delete line	DELETE LINE
Go to beginning of next line	NEXT LINE
Sort the table	SORT BLOCK NUMBERS
Copy the highlighted field (2nd soft-key row)	COPY FIELD
Insert the copied field (2nd soft-key row)	PASTE FIELD
Edit the table format (2nd soft-key row)	EDIT FORMAT




Table for workpiece materials

Workpiece materials are defined in the table WMAT.TAB (see figure). WMAT.TAB is stored in the TNC:\ directory and can contain as many materials as you want. The name of the material type can have up to 32 characters (including spaces). The TNC displays the contents of the NAME column when you are defining the workpiece material in the program (see the following section).



If you change the standard workpiece material table, you must copy it into a new directory. Otherwise your changes will be overwritten during a software update by the HEIDENHAIN standard data. Define the path in the TNC.SYS file with the code word WMAT= (see "Configuration file TNC.SYS", page 387).

To avoid losing data, save the WMAT.TAB file at regular intervals.

Manual operation	Program table editing	
	NAME	?
0	142 WU 18	Werkz.-Stahl 1.2519
1	14 NiCr 14	Einsatz-Stahl 1.5752
2	142 WU 18	Werkz.-Stahl 1.2562
3	15 CrNi 6	Einsatz-Stahl 1.5519
4	16 CrMo 4 4	Baustahl 1.7387
5	16 MnCr 5	Einsatz-Stahl 1.7131
6	17 MoV 8 4	Baustahl 1.5406
7	18 CrNi 8	Einsatz-Stahl 1.5926
8	18 Mn 5	Baustahl 1.0402
9	21 MnCr 5	Werkz.-Stahl 1.2162
10	25 CrMo 4	Baustahl 1.7219
11	25 NiCrMo 4	Baustahl 1.6512
12	38 CrMoV 9	Werg.-Stahl 1.7707
13	38 CrNiMo 9	Werg.-Stahl 1.6506
14	31 CrMo 12	Nitrier-Stahl 1.8515
15	31 CrMoV 9	Nitrier-Stahl 1.8519
16	22 CrMo 12	Werg.-Stahl 1.7581
17	34 CrAl 6	Nitrier-Stahl 1.8504
18	34 CrAlMo 5	Nitrier-Stahl 1.8507
19	34 CrAlNi 7	Nitrier-Stahl 1.8508
20	34 CrAlS 5	Nitrier-Stahl 1.8506
21	34 CrMo 4	Werg.-Stahl 1.7226
22	35 NiCr 18	Werg.-Stahl 1.5664
23	35 NiCrMo 16	Werkz.-Stahl 1.2788
24	48 CrMoMo 7	Werkz.-Stahl 1.2911
25	42 CrMo 4	Werg.-Stahl 1.7225
26	56 CrMo 4	Werg.-Stahl 1.7226
27	55 NiCrMoV 6	Werkz.-Stahl 1.2715
28	56 NiCrMoV 7	Werkz.-Stahl 1.2714
29	50 CrV 4	Werg.-Stahl 1.0161

Defining the workpiece material in the NC program

In the NC program select the workpiece material from the WMAT.TAB table using the WMAT soft key:

SPEC
FCT

- ▶ Show the soft-key row with special functions.

WMAT

- ▶ Program the workpiece material: In the Programming and Editing operating mode, press the WMAT soft key.

SELECTION
WINDOW

- ▶ The WMAT.TAB table is superimposed: Press the SELECTION WINDOW soft key, and in a second window the TNC displays the list of materials that are stored in the WMAT.TAB table.
- ▶ Select your workpiece material by using the arrow keys to move the highlight onto the material you wish to select and confirming with the ENT key. The TNC transfers the selected material to the WMAT block.
- ▶ To terminate the dialog, press the END key.



If you change the WMAT block in a program, the TNC outputs a warning. Check whether the cutting data stored in the TOOL CALL block are still valid.



Table for tool cutting materials

Tool cutting materials are defined in the TMAT.TAB table. TMAT.TAB is stored in the TNC:\ directory and can contain as many material names as you want (see figure). The name of the cutting material type can have up to 16 characters (including spaces). The TNC displays the NAME column when you are defining the tool cutting material in the TOOL.T tool table.



If you change the standard tool cutting material table, you must copy it into a new directory. Otherwise your changes will be overwritten during a software update by the HEIDENHAIN standard data. Define the path in the TNC.SYS file with the code word TMAT= (see "Configuration file TNC.SYS", page 387).

To avoid losing data, save the TMAT.TAB file at regular intervals.

NR	NAME	DESCRIPTION
0	HM	HM beschichtet
1	HC-P25	HM beschichtet
2	HC-P35	HM beschichtet
3	HSS	
4	HSSE-Co5	HSS + Kobalt
5	HSSE-Co8	HSS + Kobalt
6	HSSE-Co8-TiN	HSS + Kobalt
7	HSSE/TiCN	TiCN-beschichtet
8	HSSE/TiN	TiN-beschichtet
9	HT-P15	Carbet
10	HT-M15	Carbet
11	HU-K15	HM unbeschichtet
12	HU-K25	HM unbeschichtet
13	HU-P25	HM unbeschichtet
14	HU-P35	HM unbeschichtet
15	Hartmetall	Vollhartmetall

Table for cutting data

Define the workpiece material/cutting material combinations with the corresponding cutting data in a file table with the file name extension .CDT; see figure. You can freely configure the entries in the cutting data table. Besides the obligatory columns NR, WMAT and TMAT, the TNC can also manage up to four cutting speed (V_C) / feed rate (F) combinations.

The standard cutting data table FRAES_2.CDT is stored in the directory TNC:\. You can edit FRAES_2.CDT, or add as many new cutting-data tables as you wish.



If you change the standard cutting data table, you must copy it into a new directory. Otherwise your changes will be overwritten during a software update by the HEIDENHAIN standard data (see "Configuration file TNC.SYS", page 387).

All of the cutting data tables must be stored in the same directory. If the directory is not the standard directory TNC:\, then behind the code word PCDT= you must enter the path in which your cutting data is stored.

To avoid losing data, save your cutting data tables at regular intervals.

NR	WMAT	TMAT	Vc1	F1	Vc2	F2
0	SI 30-1	HSSE/TiCN	40	0.015	55	0.020
1	SI 30-1	HSSE/TiCN	40	0.015	55	0.020
2	SI 30-1	HC-P25	100	0.200	130	0.250
3	SI 37-2	HSSE-Co5	20	0.025	45	0.030
4	SI 37-2	HSSE/TiCN	40	0.015	55	0.020
5	SI 37-2	HC-P25	100	0.200	130	0.250
6	SI 50-2	HSSE/TiCN	40	0.015	55	0.020
7	SI 50-2	HSSE/TiCN	40	0.015	55	0.020
8	SI 50-2	HC-P25	100	0.200	130	0.250
9	SI 50-2	HSSE/TiCN	40	0.015	55	0.020
10	SI 50-2	HSSE/TiCN	40	0.015	55	0.020
11	SI 50-2	HC-P25	100	0.200	130	0.250
12	C 15	HSSE-Co5	20	0.040	45	0.050
13	C 15	HSSE/TiCN	25	0.040	35	0.050
14	C 15	HC-P25	70	0.040	100	0.050
15	C 45	HSSE/TiCN	25	0.040	35	0.050
16	C 45	HSSE/TiCN	25	0.040	35	0.050
17	C 45	HC-P25	70	0.040	100	0.050
18	C 50	HSSE/TiCN	25	0.040	35	0.050
19	C 50	HSSE/TiCN	25	0.040	35	0.050
20	C 50	HC-P25	70	0.040	100	0.050
21	GG-20	HSSE/TiCN	22	0.100	32	0.150
22	GG-20	HSSE/TiCN	40	0.040	50	0.050
23	GG-20	HC-P25	100	0.040	130	0.050
24	GG-40	HSSE/TiCN	22	0.100	32	0.150
25	GG-40	HSSE/TiCN	40	0.040	50	0.050
26	GG-40	HC-P25	100	0.040	130	0.050
27	GG-40	HSSE/TiCN	14	0.045	21	0.040
28	GG-40	HSSE/TiCN	21	0.045	30	0.040
29	GG-40	HC-P25	100	0.040	130	0.050



Creating a new cutting data table

- ▶ Select the Programming and Editing mode of operation
- ▶ Select the file manager: Press the PGM MGT key
- ▶ Select the directory where the cutting data table is to be stored
- ▶ Enter any file name with the file name extension .CDT, and confirm with ENT
- ▶ On the right half of the screen, the TNC opens a standard cutting data table or displays various table formats (machine-dependent). These tables differ from each other in the number of cutting speed/feed rate combinations they allow. In this case use the arrow keys to move the highlight onto the table format you wish to select and confirm with ENT. The TNC generates a new, empty cutting data table

Data required for the tool table

- Tool radius—column R (DR)
- Number of teeth (only with tools for milling)—column CUT
- Tool type—column TYPE
- The tool type influences the calculation of the feed rate:
Milling tool: $F = S \cdot f_z \cdot z$
All other tools: $F = S \cdot f_U$
S: Spindle speed
 f_z : Feed per tooth
 f_U : Feed per revolution
z: Number of teeth
- Tool cutting material—column TMAT
- Name of the cutting data table for which this tool will be used—column CDT
- In the tool table, select the tool type, tool cutting material and the name of the cutting data table via soft key (see "Tool table: Tool data for automatic speed/feed rate calculation", page 171).



Working with automatic speed / feed rate calculation

- 1 If it has not already been entered, enter the type of workpiece material in the file WMAT.TAB.
- 2 If it has not already been entered, enter the type of cutting material in the file TMAT.TAB.
- 3 If not already entered, enter all of the required tool-specific data in the tool table:
 - Tool radius
 - Number of teeth
 - Tool type
 - Tool material
 - The cutting data table for each tool
- 4 If not already entered, enter the cutting data in any cutting data table (CDT file).
- 5 Test Run operating mode: Activate the tool table from which the TNC is to take the tool-specific data (status S).
- 6 In the NC program, set the workpiece material by pressing the WMAT soft key.
- 7 In the NC program, let the **T** block automatically calculate the spindle speed and feed rate via soft key.



Data transfer from cutting data tables

If you output a file type .TAB or .CDT via an external data interface, the TNC also transfers the structural definition of the table. The structural definition begins with the line #STRUCTBEGIN and ends with the line #STRUCTEND. The meanings of the individual code words are shown in the table "Structure Command". Behind #STRUCTEND the TNC saves the actual content of the table.

Configuration file TNC.SYS

You must use the configuration file TNC.SYS if your cutting data tables are not stored in the standard directory TNC:\. In TNC.SYS you must then define the paths in which you have stored your cutting data tables.



The TNC.SYS file must be stored in the root directory TNC:\.

Entries in TNC.SYS	Meaning
WMAT=	Path for workpiece material table
TMAT=	Path for cutting material table
PCDT=	Path for cutting data tables

Example of TNC.SYS


```
WMAT=TNC:\CUTTAB\WMAT_GB.TAB
```

```
TMAT=TNC:\CUTTAB\TMAT_GB.TAB
```

```
PCDT=TNC:\CUTTAB\
```







12

**Programming: Multiple
Axis Machining**



12.1 Functions for Multiple Axis Machining

The TNC functions for multiple axis machining are described in this chapter.

TNC function	Description	Page
PLANE	Define machining in the tilted working plane	Page 391
PLANE/M128	Inclined-tool machining	Page 413
M116	Feed rate of rotary axes	Page 414
M126	Shortest-path traverse of rotary axes	Page 415
M94	Reduce display value of rotary axes	Page 416
M114	Define the behavior of the TNC when positioning the rotary axes	Page 417
M128	Define the behavior of the TNC when positioning the rotary axes	Page 418
M134	Exact stop for positioning with rotary axes	Page 421
M138	Selection of tilted axes	Page 421
M144	Calculate machine kinematics	Page 422



12.2 The PLANE Function: Tilting the Working Plane (Software Option 1)

Introduction











The machine manufacturer must enable the functions for tilting the working plane!

You can only use the **PLANE** function on machines which have at least two rotary axes (head and/or table).

Exception: **PLANE AXIAL** can also be used if only a single rotary axis is present or active on your machine.

The **PLANE** function is a powerful function for defining tilted working planes in various manners.

All **PLANE** functions available on the TNC describe the desired working plane independently of the rotary axes actually present on your machine. The following possibilities are available:

Function	Required parameters	Soft key	Page
SPATIAL	Three space angles: SPA , SPB , and SPC		Page 395
PROJECTED	Two projection angles: PROPR and PROMIN and a rotation angle ROT		Page 397
EULER	Three Euler angles: precession (EULPR), nutation (EULNU) and rotation (EULROT)		Page 399
VECTOR	Norm vector for defining the plane and base vector for defining the direction of the tilted X axis		Page 401
POINTS	Coordinates of any three points in the plane to be tilted		Page 403
RELATIVE	Single, incrementally effective spatial angle		Page 405
AXIAL	Up to three absolute or incremental axis angles A , B , C		Page 406
RESET	Reset the PLANE function		Page 394



In order to make the differences between each definition possibility more clear even before selecting the function, you can start an animated sequence via soft key.



The parameter definition of the **PLANE** function is separated into two parts:

- The geometric definition of the plane, which is different for each of the available **PLANE** functions.
- The positioning behavior of the **PLANE** function, which is independent of the plane definition and is identical for all **PLANE** functions (see “Specifying the positioning behavior of the PLANE function” on page 408).



The actual-position-capture function is not possible with an active tilted working plane.

If you use the **PLANE** function when **M120** is active, the TNC automatically rescinds the radius compensation, which also rescinds the **M120** function.

Always use **PLANE RESET** to reset **PLANE** functions. Entering 0 in all **PLANE** parameters does not completely reset the function.



Define the PLANE function

SPEC
FCT

- ▶ Show the soft-key row with special functions.

TILT
MACHINING
PLANE

- ▶ Select the **PLANE** function: Press the TILT MACHINING PLANE soft key: The TNC displays the available definition possibilities in the soft-key row

Selecting the function while animation is active

- ▶ Activate animation: Set the SELECT ANIMATION ON/OFF soft key to ON
- ▶ Start an animation for one of the definition possibilities: Press one of the available soft keys. The TNC highlights the soft key with a different color and begins the appropriate animation
- ▶ To assume the currently active function: Press the ENT key or press the soft key of the active function again. The TNC continues the dialog and requests the required parameters



Selecting the function while animation is inactive

- ▶ Select the desired function directly via soft key. The TNC continues the dialog and requests the required parameters

Position display

As soon as a **PLANE** function is active, the TNC shows the calculated spatial angle in the additional status display (see figure). As a rule, the TNC internally always calculates with space angles, independent of which **PLANE** function is active.

During tilting (**MOVE** or **TURN** mode) in the Distance-To-Go mode (**DIST**), the TNC shows (in the rotary axis) the distance to go (or calculated distance) to the final position of the rotary axis.



Reset the PLANE function



- ▶ Show the soft-key row with special functions



- ▶ Select special TNC functions: Press the SPECIAL TNC FUNCTIONS soft key



- ▶ Select the PLANE function: Press the TILT MACHINING PLANE soft key: The TNC displays the available definition possibilities in the soft-key row



- ▶ Select the Reset function. This internally resets the **PLANE** function, but does not change the current axis positions



- ▶ Specify whether the TNC should automatically move the rotary axes to the default setting (**MOVE** or **TURN**) or not (**STAY**) (see “Automatic positioning: MOVE/TURN/STAY (entry is mandatory)” on page 408)



- ▶ To terminate entry, press the END key



The **PLANE RESET** function resets the current **PLANE** function—or an active **G80**—completely (angles = 0 and function is inactive). It does not need to be defined more than once.

Example: NC block

```
25 PLANE RESET MOVE SET-UP50 F1000
```

Defining the machining plane with space angles: PLANE SPATIAL

Function

Space angles define a machining plane through up to three **rotations around the fixed machine coordinate system**. The sequence of rotations is firmly specified: first around the A axis, then B, and then C (the function corresponds to Cycle 19, if the entries in Cycle 19 are set to space angles).




Before programming, note the following

You must always define the three space angles **SPA**, **SPB**, and **SPC**, even if one of them = 0.

The sequence of the rotations described above is independent of the active tool axis.

Parameter description for the positioning behavior: See "Specifying the positioning behavior of the PLANE function" on page 408.





Input parameters



- ▶ **Spatial angle A?:** Rotational angle **SPA** around the fixed machine axis X (see figure at top right). Input range from -359.9999° to $+359.9999^\circ$
- ▶ **Spatial angle B?:** Rotational angle **SPB** around the fixed machine axis Y (see figure at top right). Input range from -359.9999° to $+359.9999^\circ$
- ▶ **Spatial angle C?:** Rotational angle **SPC** around the fixed machine axis Z (see figure at center right). Input range from -359.9999° to $+359.9999^\circ$
- ▶ Continue with the positioning properties (see "Specifying the positioning behavior of the PLANE function" on page 408)

Abbreviations used

Abbreviation	Meaning
SPATIAL	S patial = in space
SPA	S patial A : rotation about the X axis
SPB	S patial B : rotation about the Y axis
SPC	S patial C : rotation about the Z axis



Example: NC block

```
5 PLANE SPATIAL SPA+27 SPB+0 SPC+45 .....
```



Defining the machining plane with projection angles: PROJECTED PLANE

Function


Projection angles define a machining plane through the entry of two angles that you determine by projecting the first coordinate plane (Z/X plane with tool axis Z) and the second coordinate plane (Y/Z with tool axis Z) onto the machining plane to be defined.



Before programming, note the following

You can only use projection angles if the angle definitions are given with respect to a rectangular cuboid. Otherwise distortions could occur on the workpiece.

Parameter description for the positioning behavior: See "Specifying the positioning behavior of the PLANE function" on page 408.



Input parameters





- ▶ **Proj. angle 1st coordinate plane?:** Projected angle of the tilted machining plane in the 1st coordinate plane of the fixed machine coordinate system (Z/X for tool axis Z, see figure at top right). Input range: from -89.9999° to $+89.9999^\circ$. The 0° axis is the principal axis of the active working plane (X for tool axis Z. See figure at top right for positive direction).
- ▶ **Proj. angle 2nd coordinate plane?:** Projected angle in the 2nd coordinate plane of the fixed machine coordinate system (Y/Z for tool axis Z, see figure at top right). Input range: from -89.9999° to $+89.9999^\circ$. The 0° axis is the minor axis of the active machining plane (Y for tool axis Z).
- ▶ **ROT angle of the tilted plane?:** Rotation of the tilted coordinate system around the tilted tool axis (corresponds to a rotation with Cycle 10 ROTATION). The rotation angle is used to simply specify the direction of the principal axis of the working plane (X for tool axis Z, Z for tool axis Y; see figure at bottom right). Input range: from 0° to $+360^\circ$.
- ▶ Continue with the positioning properties (see "Specifying the positioning behavior of the PLANE function" on page 408)

NC block

```
5 PLANE PROJECTED PROPR+24 PROMIN+24 ROT+30 .....
```

Abbreviations used

Abbreviation	Meaning
PROJECTED	Projected
PROPR	Principal plane
PROMIN	Minor plane
ROT	Rotation



Defining the machining plane with Euler angles: EULER PLANE

Function

Euler angles define a machining plane through up to three **rotations about the respectively tilted coordinate system**. The Swiss mathematician Leonhard Euler defined these angles. When applied to the machine coordinate system, they have the following meanings:


Precession angle EULPR	Rotation of the coordinate system around the Z axis
Nutation angle EULNU	Rotation of the coordinate system around the X axis already shifted by the precession angle
Rotation angle EULROT	Rotation of the tilted machining plane around the tilted Z axis



Before programming, note the following

The sequence of the rotations described above is independent of the active tool axis.

Parameter description for the positioning behavior: See "Specifying the positioning behavior of the PLANE function" on page 408.



Input parameters



- ▶ **Rot. angle main coordinate plane?:** Rotary angle **EULPR** around the Z axis (see figure at top right). Please note:
 - Input range: -180.0000° to $+180.0000^\circ$
 - The 0° axis is the X axis

- ▶ **Tilting angle tool axis?:** Tilting angle **EULNUT** of the coordinate system around the X axis shifted by the precession angle (see figure at center right). Please note:
 - Input range: 0° to $+180.0000^\circ$
 - The 0° axis is the Z axis

- ▶ **ROT angle of the tilted plane?:** Rotation **EULROT** of the tilted coordinate system around the tilted Z axis (corresponds to a rotation with Cycle 10 ROTATION). Use the rotation angle to simply define the direction of the X axis in the tilted machining plane (see figure at bottom right). Please note:
 - Input range: 0° to 360.0000°
 - The 0° axis is the X axis




- ▶ Continue with the positioning properties (see "Specifying the positioning behavior of the PLANE function" on page 408)

NC block

```
5 PLANE EULER EULPR45 EULNU20 EULROT22 .....
```

Abbreviations used

Abbreviation	Meaning
EULER	Swiss mathematician who defined these angles
EULPR	Precession angle: angle describing the rotation of the coordinate system around the Z axis
EULNU	Nutation angle: angle describing the rotation of the coordinate system around the X axis shifted by the precession angle
EULROT	Rotation angle: angle describing the rotation of the tilted machining plane around the tilted Z axis



Defining the working plane with two vectors: VECTOR PLANE

Function

You can use the definition of a working plane via **two vectors** if your CAD system can calculate the base vector and normal vector of the tilted machining plane. A normalized input is not necessary. The TNC calculates the normal, so you can enter values between -99.999999 and +99.999999.

The base vector required for the definition of the machining plane is defined by the components **BX**, **BY** and **BZ** (see figure at right). The normal vector is defined by the components **NX**, **NY** and **NZ**.




Before programming, note the following

The basis vector defines the direction of the principal axis in the tilted machining plane, and the normal vector determines the direction of the working plane, and at the same time is perpendicular to it.

The TNC calculates standardized vectors from the values you enter.

Parameter description for the positioning behavior: See "Specifying the positioning behavior of the PLANE function" on page 408.



Input parameters






- ▶ **X component of base vector?:** X component **BX** of the base vector B (see figure at top right). Input range: -99.9999999 to +99.9999999
- ▶ **Y component of base vector?:** Y component **BY** of the base vector B (see figure at top right). Input range: -99.9999999 to +99.9999999
- ▶ **Z component of base vector?:** Z component **BZ** of the base vector B (see figure at top right). Input range: -99.9999999 to +99.9999999
- ▶ **X component of normal vector?:** X component **NX** of the normal vector N (see figure at center right). Input range: -99.9999999 to +99.9999999
- ▶ **Y component of normal vector?:** Y component **NY** of the normal vector N (see figure at center right). Input range: -99.9999999 to +99.9999999
- ▶ **Z component of normal vector?:** Z component **NZ** of the normal vector N (see figure at lower right). Input range: -99.9999999 to +99.9999999
- ▶ Continue with the positioning properties (see “Specifying the positioning behavior of the PLANE function” on page 408)

NC block

```
5 PLANE VECTOR BX0.8 BY-0.4 BZ-0.42 NX0.2 NY0.2 NZ0.92 ..
```

Abbreviations used

Abbreviation	Meaning
VECTOR	Vector
BX, BY, BZ	Base vector: X , Y and Z components
NX, NY, NZ	Normal vector: X , Y and Z components



Defining the machining plane via three points: PLANE POINTS

Function

A machining plane can be uniquely defined by entering **any three points P1 to P3 in this plane**. This possibility is realized in the **PLANE POINTS** function.




Before programming, note the following

The connection from Point 1 to Point 2 determines the direction of the tilted main axis (X for tool axis Z).

The direction of the tilted tool axis is determined by the position of Point 3 relative to the connecting line between Point 1 and Point 2. Use the right-hand rule (thumb = X axis, index finger = Y axis, middle finger = Z axis (see figure at right)) to remember: thumb (X axis) points from Point 1 to Point 2, index finger (Y axis) points parallel to the tilted Y axis in the direction of Point 3. Then the middle finger points in the direction of the tilted tool axis.

The three points define the slope of the plane. The position of the active datum is not changed by the TNC.

Parameter description for the positioning behavior: See "Specifying the positioning behavior of the PLANE function" on page 408.



Input parameters






- ▶ **X coordinate of 1st plane point?:** X coordinate **P1X** of the 1st plane point (see figure at top right).
- ▶ **Y coordinate of 1st plane point?:** Y coordinate **P1Y** of the 1st plane point (see figure at top right).
- ▶ **Z coordinate of 1st plane point?:** Z coordinate **P1Z** of the 1st plane point (see figure at top right).
- ▶ **X coordinate of 2nd plane point?:** X coordinate **P2X** of the 2nd plane point (see figure at center right).
- ▶ **Y coordinate of 2nd plane point?:** Y coordinate **P2Y** of the 2nd plane point (see figure at center right).
- ▶ **Z coordinate of 2nd plane point?:** Z coordinate **P2Z** of the 2nd plane point (see figure at center right).
- ▶ **X coordinate of 3rd plane point?:** X coordinate **P3X** of the 3rd plane point (see figure at bottom right).
- ▶ **Y coordinate of 3rd plane point?:** Y coordinate **P3Y** of the 3rd plane point (see figure at bottom right).
- ▶ **Z coordinate of 3rd plane point?:** Z coordinate **P3Z** of the 3rd plane point (see figure at bottom right).
- ▶ Continue with the positioning properties (see "Specifying the positioning behavior of the PLANE function" on page 408)

NC block

```
5 PLANE POINTS P1X+0 P1Y+0 P1Z+20 P2X+30 P2Y+31 P2Z+20
P3X+0 P3Y+41 P3Z+32.5 .....
```

Abbreviations used

Abbreviation	Meaning
POINTS	



Defining the Machining Plane with a Single, Incremental Space Angle: PLANE RELATIVE

Function

Use an incremental space angle when an already active tilted machining plane is to be tilted by **another rotation**. Example: machining a 45° chamfer on a tilted plane.



Before programming, note the following

The defined angle is always in effect in respect to the active working plane, regardless of the function you have used to activate it.

You can program any number of **PLANE RELATIVE** functions in a row.

If you want to return to the machining plane that was active before the **PLANE RELATIVE** function, define the **PLANE RELATIVE** function again with the same angle but with the opposite algebraic sign.

If you use the **PLANE RELATIVE** function in a non-tilted working plane, then you simply rotate the non-tilted plane about the spatial angle defined in the **PLANE** function.

Parameter description for the positioning behavior: See "Specifying the positioning behavior of the PLANE function" on page 408.

Input parameters





- ▶ **Incremental angle?:** Space angle about which the active machining plane is to be rotated additionally (see figure at right). Use a soft key to select the axis to be rotated about. Input range: -359.9999° to $+359.9999^\circ$
- ▶ Continue with the positioning properties (see "Specifying the positioning behavior of the PLANE function" on page 408)

Abbreviations used

Abbreviation	Meaning
--------------	---------

RELATIVE	
----------	--



Example: NC block

```
5 PLANE RELATIVE SPB-45 .....
```



Tilting the working plane through axis angle: PLANE AXIAL (FCL 3 function)

Function

The **PLANE AXIAL** function defines both the position of the working plane and the nominal coordinates of the rotary axes. This function is particularly easy to use on machines with Cartesian coordinates and with kinematics structures in which only one rotary axis is active.



PLANE AXIAL can also be used if you have only one rotary axis active on your machine.

You can use the **PLANE RELATIVE** function after **PLANE AXIAL** if your machine allows spatial angle definitions. The machine tool manual provides further information.



Before programming, note the following


Enter only axis angles that actually exist on your machine. Otherwise the TNC generates an error message.

Rotary axis coordinates defined with **PLANE AXIAL** are modally effective. Successive definitions therefore build on each other. Incremental input is allowed.

Use **PLANE RESET** to reset the **PLANE AXIAL** function. Resetting by entering 0 does not deactivate **PLANE AXIAL**.

SEQ, **TABLE ROT** and **COORD ROT** have no function in conjunction with **PLANE AXIAL**.

Parameter description for the positioning behavior: See "Specifying the positioning behavior of the PLANE function" on page 408.




Input parameters



- ▶ **Axis angle A?:** Axis angle **to which** the A axis is to be tilted. If entered incrementally, it is the angle **by which** the A axis is to be tilted from its current position. Input range: -99999.9999° to $+99999.9999^\circ$
- ▶ **Axis angle B?:** Axis angle **to which** the B axis is to be tilted. If entered incrementally, it is the angle **by which** the B axis is to be tilted from its current position. Input range: -99999.9999° to $+99999.9999^\circ$
- ▶ **Axis angle C?:** Axis angle **to which** the C axis is to be tilted. If entered incrementally, it is the angle **by which** the C axis is to be tilted from its current position. Input range: -99999.9999° to $+99999.9999^\circ$
- ▶ Continue with the positioning properties (see "Specifying the positioning behavior of the PLANE function" on page 408)

Abbreviations used

Abbreviation	Meaning
AXIAL	



Example: NC block

```
5 PLANE AXIAL B-45 .....
```



Specifying the positioning behavior of the PLANE function

Overview

Independently of which PLANE function you use to define the tilted machining plane, the following functions are always available for the positioning behavior:

- Automatic positioning
- Selection of alternate tilting possibilities
- Selection of the Type of Transformation

Automatic positioning: MOVE/TURN/STAY (entry is mandatory)

After you have entered all parameters for the plane definition, you must specify how the rotary axes will be positioned to the calculated axis values:

- | | |
|---|--|
| <div style="border: 1px solid gray; padding: 2px; width: 40px; text-align: center; margin-bottom: 10px;">MOVE</div> | ▶ The PLANE function is to automatically position the rotary axes to the calculated position values. The position of the tool relative to the workpiece is to remain the same. The TNC carries out a compensation movement in the linear axes. |
| <div style="border: 1px solid gray; padding: 2px; width: 40px; text-align: center; margin-bottom: 10px;">TURN</div> | ▶ The PLANE function is to automatically position the rotary axes to the calculated position values, but only the rotary axes are positioned. The TNC does not carry out a compensation movement in the linear axes. |
| <div style="border: 1px solid gray; padding: 2px; width: 40px; text-align: center; margin-bottom: 10px;">STAY</div> | ▶ You will position the rotary axes later in a separate positioning block. |


If you have selected the **MOVE** (PLANE function is to position the axes automatically), the following two parameters must still be defined: **Dist. tool tip – center of rot.** and **Feed rate? F=**.

If you have selected the **TURN** option (PLANE function is to position the axes automatically without any compensating movement), the following parameters must still be defined: **Retraction length MB** and **Feed rate? F=**.

As an alternative to defining a feed rate **F** directly by numerical value, you can also position with **FMAX** (rapid traverse) or **FAUTO** (feed rate from the T block).



If you use **PLANE AXIAL** together with **STAY**, you have to position the rotary axes in a separate block after the **PLANE** function (see "Positioning the rotary axes in a separate block" on page 410).






- ▶ **Dist. tool tip – center of rot.** (incremental): The TNC tilts the tool (or table) relative to the tool tip. The **SET UP** parameter shifts the center of rotation of the tilting movement relative to the current position of the tool tip.



- If the tool is already at the given distance to the workpiece before positioning, then relatively speaking the tool is at the same position after positioning (see figure at center right, **1** = SET UP)
- If the tool is not at the given distance to the workpiece before positioning, then relatively speaking the tool is offset from the original position after positioning (see figure at bottom right, **1** = SET UP)

- ▶ **Feed rate? F=:** Contour speed at which the tool should be positioned
- ▶ **Retraction length in the tool axis?:** Retraction path **MB** is effective incrementally from the current tool position in the active tool axis direction that the TNC approaches **before tilting**. **MB MAX** positions the tool just before the software limit switch.



Positioning the rotary axes in a separate block

Proceed as follows if you want to position the rotary axes in a separate positioning block (option **STAY** selected):

**Danger of collision!**

Pre-position the tool to a position where there is no danger of collision with the workpiece (clamping devices) during positioning.

- ▶ Select any **PLANE** function, and define automatic positioning with the **STAY** option. During program execution the TNC calculates the position values of the rotary axes present on the machine, and stores them in the system parameters Q120 (A axis), Q121 (B axis) and Q122 (C axis)
- ▶ Define the positioning block with the angular values calculated by the TNC

NC example blocks: Position a machine with a rotary table C and a tilting table A to a space angle of B+45°.

...	
12 L Z+250 R0 FMAX	Position at clearance height.
13 PLANE SPATIAL SPA+0 SPB+45 SPC+0 STAY	Define and activate the PLANE function
14 L A+Q120 C+Q122 F2000	Position the rotary axis with the values calculated by the TNC
...	Define machining in the tilted working plane



Selection of alternate tilting possibilities: SEQ +/- (entry optional)

The orientation you define for the machining plane is used by the TNC to calculate the appropriate positioning of the rotary axes present on the machine. In general there are always two solution possibilities.

Use the **SEQ** switch to specify which possibility the TNC should use:

- **SEQ+** positions the master axis so that it assumes a positive angle. The master axis is the 2nd rotary axis from the table, or the 1st axis from the tool (depending on the machine configuration (see figure at top right)).
- **SEQ-** positions the master axis so that it assumes a negative angle.


If the solution you chose with **SEQ** is not within the machine's range of traverse, the TNC displays the **Entered angle not permitted** error message.



When the **PLANE AXIS** function is used, the **SEQ** switch is nonfunctional.

If you do not define **SEQ**, the TNC determines the solution as follows:

- 1 The TNC first checks whether both solution possibilities are within the traverse range of the rotary axes.
- 2 If they are, then the TNC selects the shortest possible solution.
- 3 If only one solution is within the traverse range, the TNC selects this solution.
- 4 If neither solution is within the traverse range, the TNC displays the **Entered angle not permitted** error message.



Example for a machine with a rotary table C and a tilting table A.
 Programmed function: **PLANE SPATIAL SPA+0 SPB+45 SPC+0**

Limit switch	Starting position	SEQ	Resulting axis position
None	A+0, C+0	not prog.	A+45, C+90
None	A+0, C+0	+	A+45, C+90
None	A+0, C+0	-	A-45, C-90
None	A+0, C-105	not prog.	A-45, C-90
None	A+0, C-105	+	A+45, C+90
None	A+0, C-105	-	A-45, C-90
-90 < A < +10	A+0, C+0	not prog.	A-45, C-90
-90 < A < +10	A+0, C+0	+	Error message
None	A+0, C-135	+	A+45, C+90

Selecting the type of transformation (entry optional)

On machines with C-rotary tables, a function is available for specifying the type of transformation:



- ▶ **COORD ROT** specifies that the PLANE function should only rotate the coordinate system to the defined tilting angle. The rotary table is not moved; the compensation is purely mathematical.




- ▶ **TABLE ROT** specifies that the PLANE function should position the rotary table to the defined tilting angle. Compensation results from rotating the workpiece.



When the **PLANE AXIS** function is used, **COORD ROT** and **TABLE ROT** are nonfunctional.

If you use the **TABLE ROT** function in conjunction with a basic rotation and a tilting angle of 0, then the TNC tilts the table to the angle defined in the basic rotation.



12.3 Inclined-Tool Machining in the Tilted Plane


Function

In combination with **M128** and the new **PLANE** functions, **inclined-tool machining** in a tilted machining plane is now possible. Two possibilities are available for definition:

- Inclined-tool machining via incremental traverse of a rotary axis
- Inclined-tool machining via normal vectors



Inclined-tool machining in a tilted machining plane only functions with spherical cutters.



Inclined-tool machining via incremental traverse of a rotary axis

- ▶ Retract the tool
- ▶ Activate M128
- ▶ Define any PLANE function; consider the positioning behavior
- ▶ Via a straight-line block, traverse to the desired incline angle in the appropriate axis incrementally

Example NC blocks:

...	
N12 G00 G40 Z+50 M128 *	Position at clearance height, activate M128
N13 PLANE SPATIAL SPA+0 SPB-45 SPC+0 MOVE ABST50 F900 *	Define and activate the PLANE function
N14 G01 G91 F1000 B-17 *	Set the incline angle
...	Define machining in the tilted working plane



12.4 Miscellaneous Functions for Rotary Axes

Feed rate in mm/min on rotary axes A, B, C: M116 (software option 1)

Standard behavior

The TNC interprets the programmed feed rate of a rotary axis in degrees/min (in mm programs and also in inch programs). The feed rate therefore depends on the distance from the tool center to the center of axis rotation.

The larger this distance becomes, the greater the contouring feed rate.

Feed rate in mm/min on rotary axes with M116



The machine geometry must be specified by the machine tool builder in the description of kinematics.

M116 works only on rotary tables. **M116** cannot be used with swivel heads. If your machine is equipped with a table/head combination, the TNC ignores the swivel-head rotary axes.

M116 is also effective in an active tilted working plane and in combination with M128 if you used the **M138** function to select rotary axes (see "Selecting tilting axes: M138" on page 421). Then **M116** affects only those rotary axes that were not selected with **M138**.

The TNC interprets the programmed feed rate of a rotary axis in degrees/min (or 1/10 inch/min). In this case, the TNC calculates the feed for the block at the start of each block. With a rotary axis, the feed rate is not changed during execution of the block even if the tool moves toward the center of the rotary axis.

Effect

M116 is effective in the working plane. With **M117** you can reset **M116**. **M116** is also canceled at the end of the program.

M116 becomes effective at the start of block.



Shorter-path traverse of rotary axes: M126

Standard behavior

The standard behavior of the TNC while positioning rotary axes whose display has been reduced to values less than 360° depends on Machine Parameter 7682. MP7682 sets whether the TNC should consider the difference between nominal and actual position, or whether the TNC should always (even without M126) choose the shortest path to the programmed position. Examples:

Actual position	Nominal position	Traverse
350°	10°	-340°
10°	340°	$+330^\circ$

Behavior with M126

With M126, the TNC will move the axis on the shorter path of traverse for rotary axes whose display is reduced to values less than 360° . Examples:

Actual position	Nominal position	Traverse
350°	10°	$+20^\circ$
10°	340°	-30°

Effect

M126 becomes effective at the start of block.

To cancel M126, enter M127. At the end of program, M126 is automatically canceled.



Reducing display of a rotary axis to a value less than 360°: M94

Standard behavior

The TNC moves the tool from the current angular value to the programmed angular value.

Example:

Current angular value:	538°
Programmed angular value:	180°
Actual distance of traverse:	-358°

Behavior with M94

At the start of block, the TNC first reduces the current angular value to a value less than 360° and then moves the tool to the programmed value. If several rotary axes are active, M94 will reduce the display of all rotary axes. As an alternative you can enter a rotary axis after M94. The TNC then reduces the display only of this axis.

Example NC blocks

To reduce display of all active rotary axes:

```
N50 M94 *
```

To reduce display of the C axis only:

```
N50 M94 C *
```

To reduce display of all active rotary axes and then move the tool in the C axis to the programmed value:

```
N50 G00 C+180 M94 *
```

Effect

M94 is effective only in the block in which it is programmed.

M94 becomes effective at the start of block.



Automatic compensation of machine geometry when working with tilted axes: M114 (software option 2)

Standard behavior

The TNC moves the tool to the positions given in the part program. If the position of a tilted axis changes in the program, the resulting offset in the linear axes must be calculated by a postprocessor and traversed in a positioning block. As the machine geometry is also relevant, the NC program must be calculated separately for each machine tool.

Behavior with M114



The machine geometry must be specified by the machine tool builder in the description of kinematics.

If the position of a controlled tilted axis changes in the program, the TNC automatically compensates the tool offset by a 3-D length compensation. As the geometry of the individual machine tools is set in machine parameters, the TNC also compensates machine-specific offsets automatically. Programs only need to be calculated by the postprocessor once, even if they are being run on different machines with TNC control.

If your machine tool does not have controlled tilted axes (head tilted manually or positioned by the PLC), you can enter the current valid swivel head position after **M114** (e.g. **M114 B+45**, Q parameters permitted).

The radius compensation must be calculated by a CAD system or by a postprocessor. A programmed radius compensation RL/RR will result in an error message.

If the tool length compensation is calculated by the TNC, the programmed feed rate refers to the point of the tool. Otherwise it refers to the tool datum.



If your machine tool is equipped with a swivel head that can be tilted under program control, you can interrupt program run and change the position of the tilted axis, for example with the handwheel.


With the RESTORE POS. AT N function, you can then resume program run at the block at which the part program was interrupted. If **M114** is active, the TNC automatically calculates the new position of the tilted axis.

If you wish to use the handwheel to change the position of the tilted axis during program run, use **M118** in conjunction with **M128**.

Effect

M114 becomes effective at the start of block, M115 at the end of block. M114 is not effective when tool radius compensation is active.

To cancel M114, enter M115. At the end of program, M114 is automatically canceled.



Maintaining the position of the tool tip when positioning with tilted axes (TCPM): M128 (software option 2)

Standard behavior

The TNC moves the tool to the positions given in the part program. If the position of a tilted axis changes in the program, the resulting offset in the linear axes must be calculated, and traversed in a positioning block.

Behavior with M128 (TCPM: Tool Center Point Management)



The machine geometry must be specified by the machine tool builder in the description of kinematics.

If the position of a controlled tilted axis changes in the program, the position of the tool tip to the workpiece remains the same.

If you wish to use the handwheel to change the position of the tilted axis during program run, use **M128** in conjunction with **M118**. Handwheel positioning in a machine-based coordinate system is possible when **M128** is active.



Caution: Danger to the workpiece!

For tilted axes with Hirth coupling: Do not change the position of the tilted axis until after retracting the tool. Otherwise you might damage the contour when disengaging from the coupling.


After **M128** you can program another feed rate, at which the TNC will carry out the compensation movements in the linear axes. If you program no feed rate here, or if you program a larger feed rate than is defined in MP7471, the feed rate from MP7471 will be effective.




Before positioning with **M91** or **M92** and before a **T** block, reset **M128**.

To avoid contour gouging you must use only spherical cutters with **M128**.

The tool length must refer to the spherical center of the tool tip.

If **M128** is active, the TNC shows the symbol  in the status display.



M128 on tilting tables

If you program a tilting table movement while **M128** is active, the TNC rotates the coordinate system accordingly. If, for example, you rotate the C axis by 90° (through a positioning command or datum shift) and then program a movement in the X axis, the TNC executes the movement in the machine axis Y.

The TNC also transforms the defined datum, which has been shifted by the movement of the rotary table.

M128 with 3-D tool compensation

If you carry out a 3-D tool compensation with active **M128** and active radius compensation **G41/G42**, the TNC will automatically position the rotary axes for certain machine geometrical configurations .

Effect

M128 becomes effective at the start of block, **M129** at the end of block. **M128** is also effective in the manual operating modes and remains active even after a change of mode. The feed rate for the compensation movement will be effective until you program a new feed rate or until you cancel **M128** with **M129**.

Enter **M129** to cancel **M128**. The TNC also cancels **M128** if you select a new program in a program run operating mode.

Example NC blocks

Feed rate of 1000 mm/min for compensation movements.

```
N50 G01 G41 X+0 Y+38.5 IB-15 F125 M128 F1000 *
```

Inclined machining with noncontrolled rotary axes

If you have noncontrolled rotary axes (counting axes) on your machine, then in combination with M128 you can also perform inclined machining operations with these axes.

Proceed as follows:

- 1 Manually traverse the rotary axes to the desired positions. M128 must not be active!
- 2 Activate M128: The TNC reads the actual values of all rotary axes present, calculates from this the new position of the tool center point, and updates the position display.
- 3 The TNC performs the necessary compensating movement in the next positioning block.
- 4 Carry out the machining operation.
- 5 At the end of program, reset M128 with M129, and return the rotary axes to the initial positions.



As long as M128 is active, the TNC monitors the actual positions of the noncontrolled rotary axes. If the actual position deviates from the nominal position by a value greater than that defined by the machine manufacturer, the TNC outputs an error message and interrupts program run.



Overlap between M128 and M114

M128 is a new development of function M114.

M114 calculates necessary compensation movements in the geometry, **before** the respective NC block is executed. The TNC then processes the compensating movement such that it is performed by the end of the respective NC block.

M128 calculates all compensating movements in real time. The TNC performs necessary compensating movements immediately as soon as they become necessary after movement in a rotary axis.



M114 and **M128** may not be active at the same time, since overlaps of the two functions would occur, which could lead to damage of the workpiece. The TNC outputs a corresponding error message.



Exact stop at corners with nontangential transitions: M134

Standard behavior

The standard behavior of the TNC during positioning with rotary axes is to insert a transitional element in nontangential contour transitions. The contour of the transitional element depends on the acceleration, the rate of acceleration (jerk), and the defined tolerance for contour deviation.



With MP7440 you can change the standard behavior of the TNC so that M134 becomes active automatically whenever a program is selected (see "General User Parameters", page 584).

Behavior with M134

The TNC moves the tool during positioning with rotary axes so as to perform an exact stop at nontangential contour transitions.

Effect

M134 becomes effective at the start of block, M135 at the end of block.

You can reset M134 with M135. The TNC also resets M134 if you select a new program in a program run operating mode.

Selecting tilting axes: M138

Standard behavior

The TNC performs M114 and M128, and tilts the working plane, only in those axes for which the machine tool builder has set the appropriate machine parameters.

Behavior with M138

The TNC performs the above functions only in those tilting axes that you have defined using M138.

Effect

M138 becomes effective at the start of block.

You can reset M138 by reprogramming it without entering any axes.

Example NC blocks

Perform the above-mentioned functions only in the tilting axis C:

```
N50 G00 Z+100 R0 M138 C *
```



Compensating the machine's kinematics configuration for ACTUAL/NOMINAL positions at end of block: M144 (software option 2)

Standard behavior

The TNC moves the tool to the positions given in the part program. If the position of a tilted axis changes in the program, the resulting offset in the linear axes must be calculated, and traversed in a positioning block.

Behavior with M144

The TNC calculates into the position value any changes in the machine's kinematics configuration which result, for example, from adding a spindle attachment. If the position of a controlled tilted axis changes, the position of the tool tip to the workpiece is also changed. The resulting offset is calculated in the position display.



Positioning blocks with M91/M92 are permitted if M144 is active.

The position display in the operating modes FULL SEQUENCE and SINGLE BLOCK does not change until the tilting axes have reached their final position.

Effect

M144 becomes effective at the start of the block. M144 does not function in connection with M114, M128 or a tilted working plane.

You can cancel M144 by programming M145.



The machine geometry must be specified by the machine tool builder in the description of kinematics.

The machine tool builder determines the behavior in the automatic and manual operating modes. Refer to your machine tool manual.




12.5 Peripheral milling: 3-D radius compensation with workpiece orientation

Function

With peripheral milling, the TNC displaces the tool perpendicular to the direction of movement and perpendicular to the tool direction by the sum of the delta values **DR** (tool table and **T** block). Determine the compensation direction with radius compensation **G41/G42** (see figure at upper right, traverse direction Y+).

For the TNC to be able to reach the set tool orientation, you need to activate the function **M128** (see "Maintaining the position of the tool tip when positioning with tilted axes (TCPM): M128 (software option 2)" on page 418) and subsequently the tool radius compensation. The TNC then positions the rotary axes automatically so that the tool can reach the orientation defined by the coordinates of the rotary axes with the active compensation.



This function is possible only on machines for which you can define spatial angles for the tilting axis configuration. Refer to your machine tool manual.

The TNC is not able to automatically position the rotary axes on all machines. Refer to your machine manual.

Note that the TNC makes a compensating movement by the defined **delta values**. The tool radius R defined in the tool table has no effect on the compensation.



Danger of collision!

On machines whose rotary axes only allow limited traverse, sometimes automatic positioning can require the table to be rotated by 180°. In this case, make sure that the tool head does not collide with the workpiece or the clamps.

You can define the tool orientation in a G01 block as described below.

Example: Definition of the tool orientation with M128 and the coordinates of the rotary axes

N10 G00 G90 X-20 Y+0 Z+0 B+0 C+0 *	Pre-position
N20 M128 *	Activate M128
N30 G01 G42 X+0 Y+0 Z+0 B+0 C+0 F1000 *	Activate radius compensation
N40 X+50 Y+0 Z+0 B-30 C+0 *	Position rotary axis (tool orientation)



12.5 Peripheral milling: 3-D radius compensation with workpiece orientation





13

**Programming: Pallet
Editor**



13.1 Pallet Editor

Application




Pallet table management is a machine-dependent function. The standard functional range will be described below. Refer to your machine tool manual for more information.

Pallet tables are used for machining centers with pallet changers: The pallet table calls the part programs that are required for the different pallets, and activates datum shifts or datum tables.

You can also use pallet tables to run in succession several programs that have different reference points.

Pallet tables contain the following information:

- **PAL/PGM** (entry obligatory):
Identification for pallet or NC program (select with ENT or NO ENT)
- **NAME** (entry obligatory):
Pallet or program name. The machine tool builder determines the pallet name (see your machine tool manual). The program name must be stored in the same directory as the pallet table. Otherwise you must enter the full path name for the program
- **PALPRES** (entry optional):
Preset number from the pallet preset table. The TNC interprets the preset number defined here as pallet datum (**PAL** entry in **PAL/PGM** column). You can use the pallet preset to compensate mechanical differences between the pallets. A pallet preset can also be activated automatically when a pallet is added
- **PRESET** (entry optional):
Preset number from the preset table. The preset number defined here is interpreted by the TNC either as a pallet datum (**PAL** entry in the **PAL/PGM** column) or as a workpiece datum (**PGM** entry in **PAL/PGM** line). If there is a pallet preset table active on your machine, then use the **PRESET** column only for workpiece datums
- **DATUM** (entry optional):
Name of the datum table. The datum table must be stored in the same directory as the pallet table. Otherwise you must enter the full path name for the datum table. Datums from the datum table can be activated in the NC program with Cycle 7 **DATUM SHIFT**









- **X, Y, Z** (entry optional, other axes also possible):
For pallet names, the programmed coordinates are referenced to the machine datum. For NC programs, the programmed coordinates are referenced to the pallet datum. These entries overwrite the datum that you last set in the Manual mode of operation. With the miscellaneous function M104 you can reactivate the datum that was last set. With the actual-position-capture key, the TNC opens a window that enables you to have the TNC enter various points as datums (see table below):

Position	Meaning
Actual values	Enter the coordinates of the current tool position referenced to the active coordinate system.
Reference values	Enter the coordinates of the current tool position referenced to the machine datum.
ACTL measured values	Enter the coordinates referenced to the active coordinate system of the datum last probed in the Manual operating mode.
REF measured values	Enter the coordinates referenced to the machine datum of the datum last probed in the Manual operating mode.

With the arrow keys and ENT, select the position that you wish to confirm. Then press the ALL VALUES soft key so that the TNC saves the respective coordinates of all active axes in the pallet table. With the PRESENT VALUE soft key, the TNC saves the coordinates of the axis on which the highlight in the pallet table is presently located.



If you have not defined a pallet before an NC program, the programmed coordinates are then referenced to the machine datum. If you do not define an entry, the datum that was set manually remains active.

Editing function	Soft key
Select beginning of table	
Select end of table	
Select previous page in table	
Select next page in table	
Insert as last line in the table	
Delete the last line in the table	



Editing function	Soft key
Go to beginning of next line	NEXT LINE
Add the number of lines that can be entered at the end of the table	APPEND N LINES
Copy the highlighted field (2nd soft-key row)	COPY FIELD
Insert the copied field (2nd soft-key row)	PASTE FIELD

Selecting a pallet table

- ▶ Call the file manager in the Programming and Editing or Program Run mode: Press the PGM MGT key.
- ▶ To display all type .P files, press the soft keys SELECT TYPE and SHOW .P.
- ▶ Select a pallet table with the arrow keys, or enter a new file name to create a new table.
- ▶ Confirm your entry with the ENT key.

Leaving the pallet file

- ▶ Press the PGM MGT soft key to call the file manager.
- ▶ To select a different type of file, press the SELECT TYPE soft key and the soft key for the desired file type, for example SHOW.H.
- ▶ Select the desired file



Pallet datum management with the pallet preset table



The pallet preset table is configured by your machine tool builder, see your machine tool manual.

A preset table for managing pallet datums is available in addition to the preset table for managing workpiece datums. This makes it possible now to manage the pallet datums independently of the workpiece datums.

Pallet datums are an easy way to compensate mechanical differences between individual pallets.

For determining the pallet datums, there is an additional soft key in the manual probing functions with which you can also store the probing results in the pallet preset table (see "Storing measured values in the pallet preset table" on page 477).



Only one workpiece datum and one pallet datum can be active at the same time. Both datums are effective in sum.

The TNC displays the number of the active pallet preset in the additional status display (see "General pallet information (PAL tab)" on page 87).



Working with the pallet preset table












Changes to the pallet reset table must always be made in agreement with your machine tool builder!

If your machine tool builder has enabled the pallet preset table, you can edit the pallet preset table in **Manual** mode:

- ▶ To select the Manual Operation or EI. Handwheel mode of operation
- ▶ Scroll through the soft-key row
- ▶ Open the pallet preset table: Press the PALLET PRESET TBL soft key. The TNC displays additional soft keys (see table below)



The following editing functions are available:

Editing function in table mode	Soft key
Select beginning of table	
Select end of table	
Select previous page in table	
Select next page in table	
Insert a single line as last line in the table	
Delete the last line in the table	
Switch editing on/off	
Activate the pallet datum of the line currently selected (2nd soft-key row)	
Deactivate the currently active pallet datum (2nd soft-key row)	



Executing the pallet file



MP7683 defines whether the pallet table is to be executed blockwise or continuously.



Provided that Machine Parameter 7246 is set so that the tool usage test is active, you can monitor the tool service life for all tools used in a pallet (see "Tool usage test" on page 183).

- ▶ Select the file manager in the Program Run, Full Sequence or Program Run, Single Block operating modes: Press the PGM MGT key.
- ▶ To display all type .P files, press the soft keys SELECT TYPE and SHOW .P.
- ▶ Select the pallet table with the arrow keys and confirm with ENT.
- ▶ To execute the pallet table: Press the NC Start button. The TNC executes the pallets as set in MP7683

Screen layout for executing pallet tables

You can have the TNC display the program contents and pallet file contents on the screen together by selecting the screen layout PGM + PALLET. During execution, the TNC then shows program blocks to the left and the pallet to the right. To check the program contents before execution, proceed as follows:

- ▶ Select a pallet table
- ▶ With the arrow keys, choose the program you would like to check
- ▶ Press the OPEN PGM soft key: the TNC displays the selected program on the screen. You can now page through the program with the arrow keys
- ▶ To return to the pallet table, press the END PGM soft key.



13.2 Pallet Operation with Tool-Oriented Machining

Application




Pallet management in combination with tool-oriented machining is a machine-dependent function. The standard functional range will be described below. Refer to your machine tool manual for more information.

Pallet tables are used for machining centers with pallet changers: The pallet table calls the part programs that are required for the different pallets, and activates datum shifts or datum tables.

You can also use pallet tables to run in succession several programs that have different reference points.

Pallet tables contain the following information:

- **PAL/PGM** (entry obligatory):
The entry **PAL** identifies the pallet, **FIX** marks the fixture level and **PGM** is used to enter the workpiece.
- **W-STATUS** :
Current machining status. The machining status is used to determine the current stage of machining. Enter **BLANK** for an unmachined (raw) workpiece. During machining, the TNC changes this entry to **INCOMPLETE**, and after machining has finished, to **ENDED**. The entry **EMPTY** is used to identify a space at which no workpiece is to be clamped or where no machining is to take place.
- **METHOD** (entry obligatory):
Entry that determines the method of program optimization. Machining is workpiece-oriented if **WPO** is entered. Machining of the piece is tool-oriented if **TO** is entered. In order to include subsequent workpieces in the tool-oriented machining, you must enter **CTO** (continued tool oriented). Tool-oriented machining is also possible with pallet fixtures, but not for multiple pallets.
- **NAME** (entry obligatory):
Pallet or program name. The machine tool builder determines the pallet name (see your machine tool manual). Programs must be stored in the same directory as the pallet table. Otherwise you must enter the full path and name for the program.



- **PALPRESET** (entry optional):
Preset number from the pallet preset table. The TNC interprets the preset number defined here as pallet datum (**PAL** entry in **PAL/PGM** column). You can use the pallet preset to compensate mechanical differences between the pallets. A pallet preset can also be activated automatically when a pallet is added
- **PRESET** (entry optional):
Preset number from the preset table. The preset number defined here is interpreted by the TNC either as a pallet datum (**PAL** entry in the **PAL/PGM** column) or as a workpiece datum (**PGM** entry in the **PAL/PGM** line). If there is a pallet preset table active on your machine, then use the **PRESET** column only for workpiece datums
- **DATUM** (entry optional):
Name of the datum table. The datum table must be stored in the same directory as the pallet table. Otherwise you must enter the full path name for the datum table. Datums from the datum table can be activated in the NC program with Cycle 7 **DATUM SHIFT**
- **X, Y, Z** (entry optional, other axes also possible):
For pallets and fixtures, the programmed coordinates are referenced to the machine datum. For NC programs, the programmed coordinates are referenced to the pallet or fixture datum. These entries overwrite the datum that you last set in the Manual mode of operation. With the miscellaneous function M104 you can reactivate the datum that was last set. With the actual-position-capture key, the TNC opens a window that enables you to have the TNC enter various points as datums (see table below):

Position	Meaning
Actual values	Enter the coordinates of the current tool position referenced to the active coordinate system.
Reference values	Enter the coordinates of the current tool position referenced to the machine datum.
ACTL measured values	Enter the coordinates referenced to the active coordinate system of the datum last probed in the Manual operating mode.
REF measured values	Enter the coordinates referenced to the machine datum of the datum last probed in the Manual operating mode.












With the arrow keys and ENT, select the position that you wish to confirm. Then press the ALL VALUES soft key so that the TNC saves the respective coordinates of all active axes in the pallet table. With the PRESENT VALUE soft key, the TNC saves the coordinates of the axis on which the highlight in the pallet table is presently located.






















If you have not defined a pallet before an NC program, the programmed coordinates are then referenced to the machine datum. If you do not define an entry, the datum that was set manually remains active.

- **SP-X, SP-Y, SP-Z** (entry optional, other axes also possible):
Safety positions can be entered for the axes. These positions can be read with SYSREAD FN18 ID510 NR 6 from NC macros. SYSREAD FN18 ID510 NR 5 can be used to determine if a value was programmed in the column. The positions entered are only approached if these values are read and correspondingly programmed in the NC macros.
- **CTID** (entered by the TNC):
The context ID number is assigned by the TNC and contains instructions about the machining progress. Machining cannot be resumed if the entry is deleted or changed.

Editing function in table mode	Soft key
Select beginning of table	
Select end of table	
Select previous page in table	
Select next page in table	
Insert as last line in the table	
Delete the last line in the table	
Go to beginning of next line	
Add the number of lines that can be entered at the end of the table	
Edit the table format	



Editing function in entry-form mode	Soft key
Select previous pallet	
Select next pallet	
Select previous fixture	
Select next fixture	
Select previous workpiece	
Select next workpiece	
Switch to pallet level	
Switch to fixture level	
Switch to workpiece level	
Select standard pallet view	
Select detailed pallet view	
Select standard fixture view	
Select detailed fixture view	
Select standard workpiece view	
Select detailed workpiece view	
Insert pallet	
Insert fixture	
Insert workpiece	
Delete pallet	



Editing function in entry-form mode	Soft key
Delete fixture	DELETE FIXTURE
Delete workpiece	DELETE WORKPIECE
Delete buffer memory contents	ERASE INTERMED. MEMORY
Tool-optimized machining	TOOL ORIENTAT.
Workpiece-optimized machining	WORKPIECE ORIENTAT.
Connect or separate the types of machining	CONNECTED DIS- CONNECTED
Mark level as being empty	EMPTY POSITION
Mark level as being unmachined	BLANK



Selecting a pallet file

- ▶ Call the file manager in the Programming and Editing or Program Run mode: Press the PGM MGT key.
- ▶ To display all type .P files, press the soft keys SELECT TYPE and SHOW .P.
- ▶ Select a pallet table with the arrow keys, or enter a new file name to create a new table
- ▶ Confirm your entry with the ENT key.

Setting up the pallet file with the entry form

Pallet operation with tool- or workpiece-oriented machining is divided into three levels:

- Pallet level **PAL**
- Fixture level **FIX**
- Workpiece level **PGM**

You can switch to a detail view in each level. Set the machining method and the statuses for the pallet, fixture and workpiece in the standard view. If you are editing an existing pallet file, the updated entries are displayed. Use the detail view for setting up the pallet file.



Set up the pallet file according to the machine configuration. If you only have one fixture with multiple workpieces, then defining one fixture **FIX** with the workpieces **PGM** is sufficient. However, if one pallet contains several fixtures, or if a fixture is machined from more than one side, you must define the pallet **PAL** with the corresponding fixture levels **FIX**.

Use the screen layout button to switch between table view and form view.

Graphic support for form entry is not yet available.

The various levels of the entry form can be reached with the appropriate soft keys. The current level is highlighted in the status line of the entry form. When you switch to table view with the screen layout button, the cursor is placed in the same level as it was in the form view.

Program run full sequence	Program table editing Machining method?
File:TNC:\DUMPPGM\PALETTE.P	
PAL FIX PGM	
Pallet ID:	PAL4-206-4
Method:	WORKPIECE/TOOL-ORIENTED
Status:	BLANK
Pallet ID:	PAL4-208-11
Method:	TOOL-ORIENTED
Status:	BLANK
Pallet ID:	PAL3-208-6
Method:	TOOL-ORIENTED
Status:	BLANK

PALLET
↑

PALLET
↓

VIEW
FIXTURE
PLANE

PALLET
DETAIL OF
PALLET

INSERT
PALLET

DELETE
WORKPIECE

H

S

T

S

S100%

OFF ON

S



Setting up the pallet level

- **Pallet ID:** The pallet name is displayed
- **Method:** You can choose between the **WORKPIECE ORIENTED** and the **TOOL ORIENTED** machining methods. The selected method is assumed for the workpiece level and overwrites any existing entries. In tabular view, **WORKPIECE ORIENTED** appears as **WPO** and **TOOL ORIENTED** appears as **TO**.





The **TOOL/WORKPIECE ORIENT** entry cannot be made via soft key. It only appears when different machining methods were chosen for the workpieces in the workpiece or machining level.

If the machining method was determined in the fixture level, the entries are transferred to the workpiece level, where they overwrite any existing entries.

- **Status:** The soft key **BLANK** identifies the pallet and the corresponding fixtures and workpieces as not yet having been machined, and enters **BLANK** in the Status field. Use the **EMPTY POSITION** soft key if you want to skip the pallet during machining. **EMPTY** appears in the Status field.

Setting up details in the pallet level

- **Pallet ID:** Enter the pallet name
- **Preset No.:** Enter the preset number for the pallet
- **Datum:** Enter the pallet datum
- **Datum table:** Enter the name and path of the datum table of the workpiece. The data is transferred to the fixture and workpiece levels
- **Safe height** (optional): Safe position for the individual axes referenced to the pallet. The positions entered are only approached if these values were read and correspondingly programmed in the NC macros



Setting up the fixture level


- **Fixture:** The number of the fixture is displayed. The number of fixtures within this level is shown after the slash.
- **Method:** You can choose between the **WORKPIECE ORIENTED** and the **TOOL ORIENTED** machining methods. The selected method is assumed for the workpiece level and overwrites any existing entries. In tabular view, **WORKPIECE ORIENTED** appears as **WPO** and **TOOL ORIENTED** appears as **TO**.
Use the **CONNECT/SEPARATE** soft key to mark fixtures that are to be included for calculating the machining process for tool-oriented machining. Connected fixtures are indicated by a dashed line, whereas separated fixtures are indicated by a solid line. Connected workpieces are marked in tabular view with the entry **CTO** in the **METHOD** column.



The **TOOL/WORKPIECE ORIENTED** entry cannot be made via soft key. It only appears when different machining methods were chosen for the workpieces in the workpiece level.

If the machining method was determined in the fixture level, the entries are transferred to the workpiece level, where they overwrite any existing entries.

- **Status:** The soft key **BLANK** identifies the fixture and the corresponding workpieces as not yet having been machined, and enters **BLANK** in the Status field. Use the **EMPTY POSITION** soft key if you want to skip the fixture during machining. **EMPTY** appears in the Status field.




Setting up details in the fixture level

- **Fixture:** The number of the fixture is displayed. The number of fixtures within this level is shown after the slash.
- **Datum:** Enter the fixture datum.
- **Datum table:** Enter the name and path of the datum table valid for machining the workpiece. The data is transferred to the workpiece level.
- **NC macro:** In tool-oriented machining, the macro TCTOOLMODE is carried out instead of the normal tool-change macro.
- **Safe height (optional):** Safe position for the individual axes referenced to the fixture.



Safety positions can be entered for the axes. These positions can be read with SYSREAD FN18 ID510 NR 6 from NC macros. SYSREAD FN18 ID510 NR 5 can be used to determine if a value was programmed in the column. The positions entered are only approached if these values are read and correspondingly programmed in the NC macros.




Setting up the workpiece level

- **Workpiece:** The number of the workpiece is displayed. The number of workpieces within this fixture level is shown after the slash.
- **Method:** You can choose between the WORKPIECE ORIENTED and TOOL ORIENTED machining methods. In tabular view, WORKPIECE ORIENTED appears as **WPO**, and TOOL ORIENTED appears as **TO**.
Use the **CONNECT/SEPARATE** soft key to mark workpieces that are to be included for calculating the machining process for tool-oriented machining. Connected workpieces are indicated by a dashed line, whereas separated workpieces are indicated by a solid line. Connected workpieces are marked in tabular view with the entry **CTO** in the METHOD column.
- **Status:** The soft key **BLANK** identifies the workpiece as not yet having been machined, and enters BLANK in the Status field. Use the soft key **EMPTY POSITION** if you want to skip the workpiece during machining. EMPTY appears in the Status field.




Enter the method and status in the pallet or fixture level. Then the entry will be assumed for all corresponding workpieces.

For several workpiece variants within one level, the workpieces of one variant should be entered together. This way, the workpieces of each variant can be marked with the CONNECT/SEPARATE soft key, and can be machined in groups.



Setting up details in the workpiece level

- **Workpiece:** The number of the workpiece is displayed. The number of workpieces within this fixture or pallet level is shown after the slash.
- **Datum:** Enter the workpiece datum.
- **Datum table:** Enter the name and path of the datum table valid for machining the workpiece. If you use the same datum table for all workpieces, enter the name and path in the pallet or fixture levels. The data is automatically transferred to the workpiece level.
- **NC program:** Enter the path of the NC program that is necessary for machining the workpiece.
- **Safe height (optional):** Safe position for the individual axes referenced to the workpiece. The positions entered are only approached if these values were read and correspondingly programmed in the NC macros.



Sequence of tool-oriented machining



The TNC only carries out tool-oriented machining if the TOOL ORIENTED method was selected, and TO or CTO is entered in the table.

- The entry TO or CTO in the Method field tells the TNC that the oriented machining is valid beyond these lines.
- The pallet management starts the NC program given in the line with the entry TO.
- The first workpiece is machined until the next tool call is pending. Departure from the workpiece is coordinated by a special tool-change macro.
- The entry in the column W-STATUS is changed from BLANK to INCOMPLETE, and the TNC enters a hexadecimal value in the field CTID.



The value entered in the field CTID is a unique identifier of the machining progress for the TNC. If this value is deleted or changed, machining cannot be continued, nor is mid-program startup or resumption of machining possible.

- All lines in the pallet file that contain the entry CTO in the Method field are machined in the same manner as the first workpiece. Workpieces in several fixtures can be machined.
- The TNC uses the next tool for the following machining steps again from the line with the entry TO if one of the following situations applies:
 - If the entry PAL is in the PAL/PGM field in the next line.
 - If the entry TO or WPO is in the Method field in the next line.
 - If in the lines already machined there are entries under Method which do not have the status EMPTY or ENDED.
- The NC program is continued at the stored location based on the value entered in the CTID field. Usually the tool is changed for the first piece, but the TNC suppresses the tool change for the following workpieces.
- The entry in the CTID field is updated after every machining step. If an END PGM or M2 is executed in an NC program, then an existing entry is deleted and ENDED is entered in the Machining Status field.



- If the entries TO or CTO for all workpieces within a group contain the status ENDED, the next lines in the pallet file are run.



In mid-program startup, only one tool-oriented machining operation is possible. Subsequent pieces are machined according to the method entered.

The value entered in the CT-ID field is stored for a maximum of 2 weeks. Within this time the machining process can be continued at the stored location. After this time the value is deleted, in order to prevent large amounts of unnecessary data on the hard disk.

The operating mode can be changed after executing a group of entries with TO or CTO.

The following functions are not permitted:

- Switching the traverse range
- PLC datum shift
- M118

Leaving the pallet file

- ▶ Press the PGM MGT soft key to call the file manager.
- ▶ To select a different type of file, press the SELECT TYPE soft key and the soft key for the desired file type, for example SHOW.H.
- ▶ Select the desired file

Executing the pallet file



In MP7683, set whether the pallet table is to be executed blockwise or continuously (see "General User Parameters" on page 584).

Provided that Machine Parameter 7246 is set so that the tool usage test is active, you can monitor the tool service life for all tools used in a pallet (see "Tool usage test" on page 183).



- ▶ Select the file manager in the Program Run, Full Sequence or Program Run, Single Block operating modes: Press the PGM MGT key.
- ▶ To display all type .P files, press the soft keys SELECT TYPE and SHOW .P.
- ▶ Select the pallet table with the arrow keys and confirm with ENT.
- ▶ To execute the pallet table: Press the NC Start button. The TNC executes the pallets as set in MP7683.



Screen layout for executing pallet tables

You can have the TNC display the program contents and pallet file contents on the screen together by selecting the screen layout PGM + PALLET. During execution, the TNC then shows program blocks to the left and the pallet to the right. To check the program contents before execution, proceed as follows:

- ▶ Select a pallet table
- ▶ With the arrow keys, choose the program you would like to check
- ▶ Press the OPEN PGM soft key: the TNC displays the selected program on the screen. You can now page through the program with the arrow keys
- ▶ To return to the pallet table, press the END PGM soft key





14

**Manual Operation and
Setup**



14.1 Switch-On, Switch-Off

Switch-on



Switch-on and crossing over the reference points can vary depending on the machine tool. Refer to your machine tool manual.

Switch on the power supply for control and machine. The TNC then displays the following dialog:

MEMORY TEST

The TNC memory is checked automatically.

POWER INTERRUPTED



TNC message that the power was interrupted—clear the message.

COMPILE A PLC PROGRAM

The PLC program of the TNC is compiled automatically.

RELY EXT. DC VOLTAGE MISSING



Switch on external dc voltage The TNC checks the functioning of the EMERGENCY STOP circuit.

MANUAL OPERATION TRAVERSE REFERENCE POINTS



Cross the reference points manually in the displayed sequence: For each axis press the machine START button, or



Cross the reference points in any sequence: Press and hold the machine axis direction button for each axis until the reference point has been traversed.





If your machine is equipped with absolute encoders, you can leave out crossing the reference marks. In such a case, the TNC is ready for operation immediately after the machine control voltage is switched on.

If your machine is equipped with incremental encoders, you can activate traverse range monitoring even before reference mark traverse by pressing the SW LIMIT MONITORING soft key. Your machine tool builder can provide this function axis-specifically. Remember that by pressing the soft key, traverse range monitoring is not necessarily active in all axes. The machine tool manual provides further information.

The TNC is now ready for operation in the Manual Operation mode.



The reference points need only be crossed if the machine axes are to be moved. If you intend only to write, edit or test programs, you can select the Programming and Editing or Test Run modes of operation immediately after switching on the control voltage.

You can cross the reference points later by pressing the PASS OVER REFERENCE MARK soft key in the Manual Operation mode.



Crossing the reference point in a tilted working plane

The reference point of a tilted coordinate system can be crossed by pressing the machine axis direction buttons. The "tilting the working plane" function must be active in the Manual Operation mode, see "Activating manual tilting", page 500. The TNC then interpolates the corresponding axes.

**Danger of collision!**

Make sure that the angle values entered in the menu for tilting the working plane match the actual angles of the tilted axis.

If available, you can also traverse the axes in the direction of the current tool axis (see "Setting the current tool-axis direction as the active machining direction (FCL 2 function)" on page 501).

**Danger of collision!**

If you use this function, then for non-absolute encoders you must confirm the positions of the rotary axes, which the TNC displays in a pop-up window. The position displayed is the last active position of the rotary axes before switch-off.

If one of the two functions that were active before is active now, the NC START button has no function. The TNC outputs a corresponding error message.



Switch-off



iTNC 530 with Windows XP: See “Switching Off the iTNC 530” on page 619.

To prevent data from being lost at switch-off, you need to shut down the operating system of the TNC as follows:

- ▶ Select the Manual Operation mode



- ▶ Select the function for shutting down, confirm again with the YES soft key
- ▶ When the TNC displays the message **Now you can switch off the TNC** in a pop-up window, you may cut off the power supply to the TNC



Inappropriate switch-off of the TNC can lead to data loss!

Remember that pressing the END key after the control has been shut down restarts the control. Switch-off during a restart can also result in data loss!



14.2 Moving the Machine Axes

Note



Traversing with the machine axis direction buttons can vary depending on the machine tool. The machine tool manual provides further information.

Moving the axis using the machine axis direction buttons



Select the Manual Operation mode.



Press the machine axis direction button and hold it as long as you wish the axis to move, or



Move the axis continuously: Press and hold the machine axis direction button, then press the machine START button.



To stop the axis, press the machine STOP button.

You can move several axes at a time with these two methods. You can change the feed rate at which the axes are traversed with the F soft key, see "Spindle Speed S, Feed Rate F and Miscellaneous Functions M", page 462.



Incremental jog positioning

With incremental jog positioning you can move a machine axis by a preset distance.



Select the Manual Operation or Electronic Handwheel mode.



Shift the soft-key row.



Select incremental jog positioning: Switch the INCREMENT soft key to ON.

JOG INCREMENT =




Enter the jog increment in mm, and confirm with the ENT key.



Press the machine axis direction button as often as desired.



The maximum permissible value for infeed is 10 mm.



Traversing with electronic handwheels

The iTNC supports traversing with the following new electronic handwheels:

- HR 520:
Handwheel compatible for connection to HR 420 with display, data transfer per cable
- HR 550 FS:
Handwheel with display, radio data transmission

In addition to this, the TNC continues to support the cable handwheels HR 410 (without display) and HR 420 (with display).



Caution: Danger to the operator and handwheel!

All of the handwheel connectors may only be removed by authorized service personnel, even if it is possible without any tools!

Ensure that the handwheel is plugged in before you switch on the machine!

If you wish to operate your machine without the handwheel, disconnect the cable from the machine and secure the open socket with a cap!



Your machine tool builder can make additional functions of the HR 5xx available. Refer to your machine tool manual.



A HR 5xx handwheel is recommended if you want to use the handwheel superimposition in virtual axis function (see "Virtual axis VT" on page 365).


The portable HR 5xx handwheels feature a display on which the TNC shows information. In addition, you can use the handwheel soft keys for important setup functions, e.g. datum setting or entering and running M functions.



As soon as you have activated the handwheel with the handwheel activation key, the operating panel is locked. This is indicated by a pop-up window on the TNC screen.

The HR 5xx handwheels feature the following operating elements:

- 1 EMERGENCY STOP button
- 2 Handwheel display for status display and function selection, for further information, See "Handwheel display" on page 454.
- 3 Soft keys
- 4 Axis selection keys; can be exchanged by the machine manufacturer depending on the axis configuration
- 5 Handwheel activation key
- 6 Arrow keys for defining handwheel sensitivity
- 7 Permissive button
- 8 Key for TNC traverse direction of the selected axis
- 9 Rapid traverse superimposition for direction key
- 10 Spindle switch-on (machine-dependent function, key can be exchanged by the machine manufacturer)
- 11 "Generate NC block" key (machine-dependent function, key can be exchanged by the machine manufacturer)
- 12 Spindle switch-off (machine-dependent function, key can be exchanged by the machine manufacturer)
- 13 CTRL key for special functions (machine-dependent function, key can be exchanged by the machine manufacturer)
- 14 NC start (machine-dependent function, key can be exchanged by the machine manufacturer)
- 15 NC stop (machine-dependent function, key can be exchanged by the machine manufacturer)
- 16 Handwheel
- 17 Spindle speed potentiometer
- 18 Feed rate potentiometer
- 19 Cable connection, not available with the HR 550 FS wireless handwheel



Handwheel display

The handwheel display (see image) consists of a header and 6 status lines in which the TNC shows the following information:

- 1 **Only HR 550 FS wireless handwheel:**
Shows whether the handwheel is in the docking station or whether wireless operation is active
- 2 **Only HR 550 FS wireless handwheel:**
Shows the field strength, 6 bars = maximum field strength
- 3 **Only HR 550 FS wireless handwheel:**
Shows the charge status of the rechargeable battery, 6 bars = fully charged A bar moves from the left to the right during recharging
- 4 **ACTL:** Type of position display
- 5 **Y+129.9788:** Position of the selected axis
- 6 *****: STIB (control in operation); program run has been started or axis is in motion
- 7 **S0:** Current spindle speed
- 8 **F0:** Feed rate at which the selected axis is moving
- 9 **E:** Error message
- 10 **3D:** Tilted-working-plane function is active
- 11 **2D:** Basic rotation function is active
- 12 **RES 5.0:** Active handwheel resolution. Distance in mm/rev (°/rev for rotary axes) that the selected axis moves for one handwheel revolution
- 13 **STEP ON** or **OFF:** Incremental jog active or inactive. If the function is active, the TNC also displays the active jog increment
- 14 **Soft-key row:** Selection of various functions, described in the following sections



Special features of the HR 550 FS wireless handwheel



Due to various potential sources of interference, a wireless connection is not as reliable as a cable connection. Before you use the wireless handwheel it must therefore be checked whether there are any other radio users in the surroundings of the machine. This inspection for presence of radio frequencies or channels is recommended for all industrial radio systems.

When the HR 550 is not needed, always put it in the handwheel holder. This way you can ensure that via the contact strip on the rear side of the wireless handwheel the accumulators are always ready for use due to a recharge control and there is a direct contact connection for the emergency stop circuit.

If an error (interruption of the radio connection, poor reception quality, defective handwheel component) occurs, the handwheel always reacts with an emergency stop.

Please read the notes on the configuration of the HR 550 FS wireless handwheel (see "Configuring the HR 550 FS Wireless Handwheel" on page 580)



Caution: Danger to the operator and machine!

Due to safety reasons you must switch off the wireless handwheel and the handwheel holder after an operating time of 120 hours at the latest so that the TNC can run a functional test when it is restarted!

If you use several machines with wireless handwheels in your workshop you have to mark the handwheels and holders that belong together so that their respective associations are clearly identifiable (e.g. by color stickers or numbers). The markings on the wireless handwheel and the handwheel holder must be clearly visible to the user!

Before every use, make sure that the correct handwheel for your machine is active.



The HR 550 FS wireless handwheel features a rechargeable battery. The battery is recharged when you put the handwheel in the holder (see figure).

You can operate the HR 550 FS with the accumulator for up to 8 hours before it must be recharged again. It is recommended, however, that you always put the handwheel in its holder when you are not using it.

As soon as the handwheel is in its holder, it switches internally to cable operation so that you can always use it even if the battery were completely empty. The functions are the same as with wireless operation.



When the handwheel is completely discharged, it takes about 3 hours until it is fully recharged in the handwheel holder.

Clean the contacts **1** in the handwheel holder and of the handwheel regularly to ensure their proper functioning.

The transmission range is amply dimensioned. If you should nevertheless happen to come near the edge of the transmission area, which is possible with very large machines, the HR 550 FS warns you in time with a plainly noticeable vibration alarm. If this happens you must reduce the distance to the handwheel holder, into which the radio receiver is integrated.



Caution: Danger to the tool and workpiece!

If interruption-free operation is no longer possible within the transmission range the TNC automatically triggers an emergency stop. This can also happen during machining. Try to stay as close as possible to the handwheel holder and put the handwheel in its holder when you are not using it.



If the TNC has triggered an emergency stop you must reactivate the handwheel. Proceed as follows:

- ▶ Select the Programming and Editing mode of operation.
- ▶ Press the MOD key to select the MOD function.
- ▶ Scroll through the soft-key row.

SET UP
WIRELESS
HANDWHEEL

- ▶ Select the configuration menu for the wireless handwheel: Press the SET UP WIRELESS HANDWHEEL soft key.
- ▶ Reactivate the wireless handwheel via the **Start handwheel1** button.
- ▶ To save the configuration and exit the configuration menu, press the **END** button.

The MOD mode of operation includes a function for initial operation and configuration of the handwheel (see "Configuring the HR 550 FS Wireless Handwheel" on page 580).

Selecting the axis to be moved

You can activate directly through the axis address keys the principal axes X, Y, Z and three other axes defined by the machine tool builder. Your machine tool builder can also place the virtual axis VT directly on one of the free axis keys. If the virtual axis VT is not on one of the axis selection keys, proceed as follows:

- ▶ Press the handwheel soft key F1 (**AX**): The TNC displays all active axes on the handwheel display. The currently active axis blinks
- ▶ Select the desired axis (e.g. the VT axis) with the handwheel soft keys F1 (->) or F2 (<-) and confirm with the handwheel soft key F3 (**OK**)

Setting the handwheel sensitivity

The handwheel sensitivity specifies the distance an axis moves per handwheel revolution. The sensitivity levels are pre-defined and are selectable with the handwheel arrow keys (unless incremental jog is not active).

Selectable sensitivity levels: 0.01/0.02/0.05/0.1/0.2/0.5/1/2/5/10/20 [mm/revolution or degrees/revolution]



Moving the axes



Activate the handwheel: Press the handwheel key on the HR 5xx: Now you can only operate the TNC via the HR 5xx ; the TNC shows a pop-up window containing information on the TNC screen.

Select the desired operating mode via the OPM soft key, if necessary (see "Changing Modes of Operation" on page 460).

If required, press and hold the permissive buttons.



Use the handwheel to select the axis to be moved. Select the additional axes via soft key, if required.



Move the active axis in the positive direction, or



Move the active axis in the negative direction.



Deactivate the handwheel: Press the handwheel key on the HR 5xx : Now you can operate the TNC again via the operating panel.



Potentiometer settings

The potentiometers of the machine operating panel continue to be active after you have activated the handwheel. If you want to use the potentiometers on the handwheel, proceed as follows:

- ▶ Press the CTRL and Handwheel keys on the HR 5xx. The TNC shows the soft-key menu for selecting the potentiometers on the handwheel display.
- ▶ Press the HW soft key to activate the handwheel potentiometers.

If you have activated the potentiometers on the handwheel, you must reactivate the potentiometers of the machine operating panel before deselecting the handwheel. Proceed as follows:

- ▶ Press the CTRL and Handwheel keys on the HR 5xx. The TNC shows the soft-key menu for selecting the potentiometers on the handwheel display.
- ▶ Press the KBD soft key to activate the potentiometers of the machine operating panel.

Incremental jog positioning

With incremental jog positioning the TNC moves the currently active handwheel axis by a preset distance defined by you.

- ▶ Press the handwheel soft key F2 (**STEP**).
- ▶ Activate incremental jog positioning: Press handwheel soft key 3 (**ON**).
- ▶ Select the desired jog increment by pressing the F1 or F2 key. If you press and hold the respective key, each time it reaches a decimal value 0 the TNC increases the counting increment by a factor of 10. If in addition you press the CTRL key, the counting increment increases to 1. The smallest possible jog increment is 0.0001 mm. The largest possible is 10 mm.
- ▶ Confirm the selected jog increment with soft key 4 (**OK**).
- ▶ With the + or – handwheel key, move the active handwheel axis in the corresponding direction.

Entering miscellaneous functions M

- ▶ Press the handwheel soft key F3 (**MSF**).
- ▶ Press the handwheel soft key F1 (**M**).
- ▶ Select the desired M function number by pressing the F1 or F2 key.
- ▶ Execute the M function with the NC start key.



Entering the spindle speed S

- ▶ Press the handwheel soft key F3 (**MSF**).
- ▶ Press the handwheel soft key F2 (**S**).
- ▶ Select the desired speed by pressing the F1 or F2 key. If you press and hold the respective key, each time it reaches a decimal value 0 the TNC increases the counting increment by a factor of 10. If in addition you press the CTRL key, the counting increment increases to 1000.
- ▶ Activate the new speed S with the NC start key.

Entering the feed rate F

- ▶ Press the handwheel soft key F3 (**MSF**).
- ▶ Press the handwheel soft key F3 (**F**).
- ▶ Select the desired feed rate by pressing the F1 or F2 key. If you press and hold the respective key, each time it reaches a decimal value 0 the TNC increases the counting increment by a factor of 10. If in addition you press the CTRL key, the counting increment increases to 1000.
- ▶ Confirm the new feed rate F with the handwheel soft key F3 (**OK**).

Datum setting

- ▶ Press the handwheel soft key F3 (**MSF**).
- ▶ Press the handwheel soft key F4 (**PRS**).
- ▶ If required, select the axis in which the datum is to be set.
- ▶ Reset the axis with the handwheel soft key F3 (**OK**), or with F1 and F2 set the desired value and then confirm with F3 (**OK**). By also pressing the CTRL key, you can increase the counting increment to 10.

Changing Modes of Operation

With the handwheel soft key F4 (**OPM**), you can use the handwheel to switch the mode of operation, provided that the current status of the control allows a mode change.

- ▶ Press the handwheel soft key F4 (**OPM**).
- ▶ Select the desired operating mode by handwheel soft key
 - MAN: Manual Operation
 - MDI: Positioning with Manual Data Input
 - SGL: Program Run, Single Block
 - RUN: Program Run, Full Sequence



Generating a complete L Block



Your machine tool builder can assign any function to the "Generate NC block" handwheel key; refer to your machine manual.



Use the MOD function to define the axis values to be taken into an NC block (see "Selecting the Axes for Generating G01 Blocks" on page 570).

If no axes are selected, the TNC displays the error message **No axes selected.**

- ▶ Select the **Positioning with MDI** operating mode
- ▶ If required, use the arrow keys on the TNC keyboard to select the NC block after which the new L block is to be inserted
- ▶ Activate the handwheel
- ▶ Press the "Generate NC block" handwheel key: The TNC inserts a complete L block containing all axis positions selected through the MOD function

Features in the Program Run modes of operation

You can use the following functions in the Program Run modes of operation:

- NC start (handwheel NC-start key)
- NC stop (handwheel NC-stop key)
- After the NC-stop key has been pressed: Internal stop (handwheel soft keys **MOP** and then **STOP**)
- After the NC-stop key has been pressed: Manual axis traverse (handwheel soft keys **MOP** and then **MAN**)
- Returning to the contour after the axes were moved manually during a program interruption (handwheel soft keys **MOP** and then **REPO**). Operation is by handwheel soft keys, which function similarly to the control-screen soft keys (see "Returning to the contour" on page 536)
- On/off switch for the Tilted Working Plane function (handwheel soft keys **MOP** and then **3D**)



14.3 Spindle Speed S, Feed Rate F and Miscellaneous Functions M

Function

In the Manual Operation and Electronic Handwheel operating modes, you can enter the spindle speed S, feed rate F and the miscellaneous functions M with soft keys. The miscellaneous functions are described in Chapter 7 “Programming: Miscellaneous Functions.”



The machine tool builder determines which miscellaneous functions M are available on your control and what effects they have.

Entering values

Spindle speed S, miscellaneous function M



To enter the spindle speed, press the S soft key.

SPINDLE SPEED S =

1000



Enter the desired spindle speed and confirm your entry with the machine START button.

The spindle speed S with the entered rpm is started with a miscellaneous function M. Proceed in the same way to enter a miscellaneous function M.

Feed rate F

After entering a feed rate F, you must confirm your entry with the ENT key instead of the machine START button.

The following is valid for feed rate F:

- If you enter F=0, then the lowest feed rate from MP1020 is effective
- F is not lost during a power interruption



Changing the spindle speed and feed rate

With the override knobs you can vary the spindle speed S and feed rate F from 0% to 150% of the set value.



The override knob for spindle speed is only functional on machines with infinitely variable spindle drive.



14.4 Datum Setting without a 3-D Touch Probe

Note



Datum setting with a 3-D touch probe: (see page 487).

You fix a datum by setting the TNC position display to the coordinates of a known position on the workpiece.

Preparation

- ▶ Clamp and align the workpiece
- ▶ Insert the zero tool with known radius into the spindle
- ▶ Ensure that the TNC is showing the actual position values



Workpiece presetting with axis keys



Protective measure

If the workpiece surface must not be scratched, you can lay a metal shim of known thickness d on it. Then enter a tool axis datum value that is larger than the desired datum by the value d .



Select the **Manual Operation** mode



Move the tool slowly until it touches (scratches) the workpiece surface



Select an axis (all axes can also be selected via the ASCII keyboard)


DATUM SETTING Z=



Zero tool in spindle axis: Set the display to a known workpiece position (here, 0) or enter the thickness d of the shim. In the tool axis, offset the tool radius

Repeat the process for the remaining axes.

If you are using a preset tool, set the display of the tool axis to the length L of the tool or enter the sum $Z=L+d$



Datum management with the preset table



You should definitely use the preset table if:

- Your machine is equipped with rotary axes (tilting table or swivel head) and you work with the function for tilting the working plane
- Your machine is equipped with a spindle-head changing system
- Up to now you have been working with older TNC controls with REF-based datum tables
- You wish to machine identical workpieces that are differently aligned

The preset table can contain any number of lines (datums). To optimize the file size and the processing speed, you should use only as many lines as you need for datum management.

For safety reasons, new lines can be inserted only at the end of the preset table.

Saving the datums in the preset table

The preset table has the name **PRESET.PR**, and is saved in the directory **TNC:\. PRESET.PR** is editable only in the **Manual Operation** and **Electronic Handwheel** modes. In the Programming and Editing mode you can only read the table, not edit it.


It is permitted to copy the preset table into another directory (for data backup). Lines that were written by your machine tool builder are also always write-protected in the copied tables. You therefore cannot edit them.

Never change the number of lines in the copied tables! That could cause problems when you want to reactivate the table.

To activate a preset table copied to another directory you have to copy it back to the directory **TNC:**.

There are several methods for saving datums and/or basic rotations in the preset table:

- Through probing cycles in the **Manual Operation** or **Electronic Handwheel** modes (see Chapter 14)
- Through the probing cycles 400 to 402 and 410 to 419 in automatic mode (see User's Manual, Cycles, Chapters 14 and 15)
- Manual entry (see description below)





Basic rotations from the preset table rotate the coordinate system about the preset, which is shown in the same line as the basic rotation.

When setting a preset, the TNC checks whether the positions of the tilting axes match the corresponding values of the 3D ROT menu (depending on the setting in the kinematics table). Therefore:

- If the “Tilt working plane” function is not active, the position display for the rotary axes must be = 0° (zero the rotary axes if necessary).
- If the “Tilt working plane” function is active, the position displays for the rotary axes must match the angles entered in the 3D ROT menu.

The machine manufacturer can lock any lines in the preset table in order to place fixed datums there (e.g. a center point for a rotary table). Such lines in the preset table are shown in a different color (default: red).

The line 0 in the preset table is write protected. In line 0, the TNC always saves the datum that you most recently set manually via the axis keys or via soft key. If the datum set manually is active, the TNC displays the text **PR MAN (0)** in the status display.

If you automatically set the TNC display with the touch-probe cycles for presetting, then the TNC does not store these values in line 0.



Manually saving the datums in the preset table

In order to set datums in the preset table, proceed as follows:



Select the **Manual Operation** mode.



Move the tool slowly until it touches (scratches) the workpiece surface, or position the measuring dial correspondingly.



Displaying the preset table: The TNC opens the preset table and sets the cursor to the active table row.



Select functions for entering the presets: The TNC displays the available possibilities for entry in the soft-key row. See the table below for a description of the entry possibilities.



Select the line in the preset table that you want to change (the line number is the preset number).








If needed, select the column (axis) in the preset table that you want to change.



Use the soft keys to select one of the available entry possibilities (see the following table).



Function	Soft key
Directly transfer the actual position of the tool (the measuring dial) as the new datum: This function only saves the datum in the axis which is currently highlighted.	
Assign any value to the actual position of the tool (the measuring dial): This function only saves the datum in the axis which is currently highlighted. Enter the desired value in the pop-up window.	
Incrementally shift a datum already stored in the table: This function only saves the datum in the axis which is currently highlighted. Enter the desired corrective value with the correct sign in the pop-up window. If inch display is active: enter the value in inches, and the TNC will internally convert the entered values to mm.	
Directly enter the new datum without calculation of the kinematics (axis-specific). Only use this function if your machine has a rotary table, and you want to set the datum to the center of the rotary table by entering 0. This function only saves the datum in the axis which is currently highlighted. Enter the desired value in the pop-up window. If inch display is active: enter the value in inches, and the TNC will internally convert the entered values to mm.	
Write the currently active datum to a selectable line in the table: This function saves the datum in all axes, and then activates the appropriate row in the table automatically. If inch display is active: enter the value in inches, and the TNC will internally convert the entered values to mm.	






Explanation of values saved in the preset table

- Simple machine with three axes without tilting device
The TNC saves in the preset table the distance from the workpiece datum to the reference point (with the correct algebraic sign).
- Machine with swivel head
The TNC saves in the preset table the distance from the workpiece datum to the reference point (with the correct algebraic sign).
- Machine with rotary table
The TNC saves in the preset table the distance from the workpiece datum to the center of the rotary table (with the correct algebraic sign).
- Machine with rotary table and swivel head
The TNC saves in the preset table the distance from the workpiece datum to the center of the rotary table.















Danger of collision!

Keep in mind that moving an indexing feature on your machine table (realized by changing the kinematics description) requires you to redefine any workpiece-based presets.



Editing the preset table

Editing function in table mode	Soft key
Select beginning of table	
Select end of table	
Select previous page in table	
Select next page in table	
Select the functions for preset entry	
Activate the datum of the selected line of the preset table	
Add the entered number of lines to the end of the table (2nd soft-key row)	
Copy the highlighted field (2nd soft-key row)	
Insert the copied field (2nd soft-key row)	
Reset the selected line: The TNC enters—in all columns (2nd soft-key row)	
Insert a single line at the end of the table (2nd soft-key row)	
Delete a single line at the end of the table (2nd soft-key row)	



Activating a datum from the preset table in the Manual Operation mode



Danger of collision!

When activating a datum from the preset table, the TNC resets the active datum shift.

However, a coordinate transformation that was programmed in Cycle19 Tilted Working Plane, or through the PLANE function, remains active.

If you activate a preset that does not contain values in all coordinates, the last effective reference point remains active in these axes.



Select the **Manual Operation** mode.



Display the preset table.



Select the datum number that you want to activate, or



With the GOTO key, select the datum number that you want to activate. Confirm with the ENT key.



Activate the preset.



Confirm activation of the datum. The TNC sets the display and—if defined—the basic rotation.



Leave the preset table.

Activating the datum from the preset table in an NC program











To activate datums from the preset table during program run, use Cycle 247. In Cycle 247 you define the number of the datum that you want to activate (see User's Manual, Cycles, Cycle 247 SET DATUM).



14.5 Using the 3-D Touch Probe

Overview

The following touch probe cycles are available in the Manual Operation mode:

Function	Soft key	Page
Calibrating the effective length		Page 478
Calibrating the effective radius		Page 479
Measuring a basic rotation using a line		Page 483
Setting the datum in any axis		Page 487
Setting a corner as datum		Page 488
Setting a circle center as datum		Page 489
Setting a center line as datum		Page 490
Measuring a basic rotation using two holes/cylindrical studs		Page 491
Setting the datum using four holes/cylindrical studs		Page 491
Setting a circle center using three holes/cylindrical studs		Page 491

Selecting probe cycles

- ▶ To select the Manual Operation or El. Handwheel mode of operation



- ▶ Select the touch probe functions by pressing the TOUCH PROBE soft key. The TNC displays additional soft keys: see table above.



- ▶ To select the probe cycle, press the appropriate soft key, for example PROBING ROT, and the TNC displays the associated menu.



Recording measured values from the touch-probe cycles



The TNC must be specially prepared by the machine tool builder for use of this function. Refer to your machine tool manual for more information.

After executing any selected probe cycle, the TNC displays the soft key PRINT. If you press this soft key, the TNC will record the current values determined in the active touch probe cycle. You can then use the PRINT function in the menu for setting the data interface (see the User's Manual Chapter 12, "MOD Functions, Setting the Data Interfaces") to define whether the TNC is to

- print the measuring result,
- store the measuring results on the TNC's hard disk, or
- store the measuring results on a PC.


If you store the measuring results, the TNC creates the ASCII file %TCHPRNT.A. Unless you define a specific path and interface in the interface configuration menu, the TNC will store the %TCHPRNT file in the main directory TNC:\.



When you press the PRINT soft key, the %TCHPRNT.A file must not be active in the **Programming and Editing** mode of operation. The TNC will otherwise display an error message.

The TNC stores the measured data in the %TCHPRNT.A file only. If you execute several touch probe cycles in succession and want to store the resulting measured data, you must make a backup of the contents stored in %TCHPRNT.A between the individual cycles by copying or renaming the file.

Format and contents of the %TCHPRNT file are preset by the machine tool builder.



Writing the measured values from touch probe cycles in datum tables



This function is active only if you have datum tables active on your TNC (bit 3 in Machine Parameter 7224.0 =0).

Use this function if you want to save measured values in the workpiece coordinate system. If you want to save measured values in the fixed machine coordinate system (REF coordinates), press the ENTER IN PRESET TABLE soft key (see "Writing the measured values from touch probe cycles in the preset table" on page 476).

With the ENTER IN DATUM TABLE soft key, the TNC can write the values measured during a touch probe cycle in a datum table:



Danger of collision!

Note that during an active datum shift the TNC always bases the probed value on the active preset (or on the reference point most recently set in the Manual operating mode), although the datum shift is included in the position display.

- ▶ Select any probe function
- ▶ Enter the desired coordinates of the datum in the appropriate input boxes (depends on the touch probe cycle being run)
- ▶ Enter the datum number in the **Number in table=** input box
- ▶ Enter the name of the datum table (complete path) in the **Datum table** input box
- ▶ Press the ENTER IN DATUM TABLE soft key. The TNC saves the datum in the indicated datum table under the entered number



Writing the measured values from touch probe cycles in the preset table



Use this function if you want to save measured values in the machine-based coordinate system (REF coordinates). If you want to save measured values in the workpiece coordinate system, press the ENTER IN DATUM TABLE soft key (see "Writing the measured values from touch probe cycles in datum tables" on page 475).

With the ENTER IN PRESET TABLE soft key, the TNC can write the values measured during a probe cycle in the preset table. The measured values are then stored referenced to the machine-based coordinate system (REF coordinates). The preset table has the name PRESET.PR, and is saved in the directory TNC:\.



Danger of collision!

Note that during an active datum shift the TNC always bases the probed value on the active preset (or on the reference point most recently set in the Manual operating mode), although the datum shift is included in the position display.

- ▶ Select any probe function
- ▶ Enter the desired coordinates of the datum in the appropriate input boxes (depends on the touch probe cycle being run)
- ▶ Enter the preset number in the **Number in table:** input box
- ▶ Press the ENTER IN PRESET TABLE soft key. The TNC saves the datum in the preset table under the entered number



If you overwrite the active datum, the TNC shows a warning. If you really want to overwrite it, press the ENT key. If not, press the NO ENT key.



Storing measured values in the pallet preset table



You use this function for determining pallet datums. This function must be enabled by your machine tool builder.

In order to store a measured value in the pallet preset table, you must activate a zero preset before probing. A zero preset consists of the entry 0 in all axes of the preset table!

- ▶ Select any probe function
- ▶ Enter the desired coordinates of the datum in the appropriate input boxes (depends on the touch probe cycle being run)
- ▶ Enter the preset number in the **Number in table:** input box
- ▶ Press the ENTER IN PALLET PRES. TAB. soft key. The TNC saves the datum in the preset table under the number entered



14.6 Calibrating a 3-D Touch Probe

Introduction

In order to precisely specify the actual trigger point of a 3-D touch probe, you must calibrate the touch probe, otherwise the TNC cannot provide precise measuring results.



Always calibrate a touch probe in the following cases:

- Commissioning
- Stylus breakage
- Stylus exchange
- Change in the probe feed rate
- Irregularities caused, for example, when the machine heats up
- Change of active tool axis

During calibration, the TNC finds the “effective” length of the stylus and the “effective” radius of the ball tip. To calibrate the 3-D touch probe, clamp a ring gauge of known height and known internal radius to the machine table.

Calibrating the effective length




The effective length of the touch probe is always referenced to the tool datum. The machine tool builder usually defines the spindle tip as the tool datum.

- ▶ Set the datum in the spindle axis such that for the machine tool table $Z=0$.



- ▶ To select the calibration function for the touch probe length, press the TOUCH PROBE and CAL. L soft keys. The TNC then displays a menu window with four input fields.
- ▶ Enter the tool axis (with the axis key).
- ▶ Datum: Enter the height of the ring gauge.
- ▶ The menu items Effective ball radius and Effective length do not require input.
- ▶ Move the touch probe to a position just above the ring gauge.
- ▶ To change the traverse direction (if necessary), press a soft key or an arrow key.
- ▶ To probe the upper surface of the ring gauge, press the machine START button.



Calibrating the effective radius and compensating center misalignment

After the touch probe is inserted, it normally needs to be aligned exactly with the spindle axis. The calibration function determines the misalignment between touch probe axis and spindle axis and computes the compensation.

The calibration routine varies depending on the setting of Machine Parameter 6165 (spindle orientation active/inactive). If the function for orienting the infrared touch probe to the programmed probe direction is active, the calibration cycle is executed after you have pressed NC Start once. If the function is not active, you can decide whether you want to compensate the center misalignment by calibrating the effective radius.

The TNC rotates the 3-D touch probe by 180° for calibrating the center misalignment. The rotation is initiated by a miscellaneous function that is set by the machine tool builder in Machine Parameter 6160.

Proceed as follows for manual calibration:

- ▶ In the Manual Operation mode, position the ball tip in the bore of the ring gauge




- ▶ To select the calibration function for the ball-tip radius and the touch probe center misalignment, press the CAL. R soft key
- ▶ Select the tool axis and enter the radius of the ring gauge
- ▶ To probe the workpiece, press the machine START button four times. The 3-D touch probe contacts a position on the hole in each axis direction and calculates the effective ball-tip radius
- ▶ If you want to terminate the calibration function at this point, press the END soft key



In order to be able to determine ball-tip center misalignment, the TNC needs to be specially prepared by the machine manufacturer. Refer to your machine tool manual for more information.



- ▶ If you want to determine the ball-tip center misalignment, press the 180° soft key. The TNC rotates the touch probe by 180°
- ▶ To probe the workpiece, press the machine START button four times. The 3-D touch probe contacts a position on the hole in each axis direction and calculates the ball-tip center misalignment



Displaying calibration values

The TNC stores the effective length and radius, as well as the center misalignment, for use when the touch probe is needed again. You can display the values on the screen with the soft keys CAL. L and CAL. R.



If you want to use several touch probes or calibration data blocks: See "Managing more than one block of calibrating data" on page 480.

Managing more than one block of calibrating data


If you use several touch probes or measuring contacts arranged in a cross shape on your machine, you must also use several blocks of calibration data.

To be able to use more than one block of calibration data, you must set Machine Parameter 7411=1. To find the calibration data, proceed in the same way as is done with one single touch probe. When exiting the Calibration menu, press the ENT key to confirm the entry of the calibration data in the tool table and for the TNC to save the calibration data in the tool table. The line of the tool table, to which the TNC saves the data, is determined by the active tool number.



Make sure that you have activated the correct tool number before using the touch probe, regardless of whether you wish to run the touch probe cycle in automatic mode or manual mode.

If MP 7411=1 is set, the TNC shows the tool number and name in the calibration menu.



14.7 Compensating Workpiece Misalignment with a 3-D Touch Probe

Introduction

The TNC electronically compensates workpiece misalignment by computing a “basic rotation.”

For this purpose, the TNC sets the rotation angle to the desired angle with respect to the reference axis in the working plane. See figure at right.

As an alternative, you can also compensate the misalignment by rotating the rotary table.



Select the probe direction perpendicular to the angle reference axis when measuring workpiece misalignment.


To ensure that the basic rotation is calculated correctly during program run, program both coordinates of the working plane in the first positioning block.

You can also use a basic rotation in conjunction with the PLANE function. In this case, first activate the basic rotation and then the PLANE function.




If you change the basic rotation, the TNC asks you if you also want to save the changed basic rotation in the active line of the Preset table when you exit the menu. In this case, confirm with the ENT key.



If your machine has been prepared for it, the TNC can also conduct a real, three-dimensional set-up compensation. If necessary, contact your machine tool builder.



Overview

Cycle	Soft key
<p>Basic rotation using 2 points: The TNC measures the angle between the line connecting the two holes and a nominal position (angle reference axis).</p>	
<p>Basic rotation using 2 holes/studs: The TNC measures the angle between the line connecting the centers of two holes/studs and a nominal position (angle reference axis).</p>	
<p>Workpiece alignment using 2 points: The TNC measures the angle between the line connecting the two points and a nominal position (angle reference axis) and compensates the misalignment by turning the rotary table.</p>	



Basic rotation using 2 points:



- ▶ Select the probe function by pressing the PROBING ROT soft key
- ▶ Position the touch probe at a position near the first touch point
- ▶ Select the probe direction perpendicular to the angle reference axis: Select the axis by soft key
- ▶ To probe the workpiece, press the machine START button
- ▶ Position the touch probe at a position near the second touch point
- ▶ To probe the workpiece, press the machine START button. The TNC determines the basic rotation and displays the angle after the dialog **Rotation angle =**

Saving the basic rotation in the preset table

- ▶ After the probing process, enter the preset number in which the TNC is to save the active basic rotation in the **Number in table:** input box
- ▶ Press the ENTRY IN PRESET TABLE soft key to save the basic rotation in the preset table

Saving the basic rotation in the pallet preset table



In order to store a basic rotation in the pallet preset table, you must activate a zero preset before probing. A zero preset consists of the entry 0 in all axes of the preset table!

- ▶ After the probing process, enter the preset number in which the TNC is to save the active basic rotation in the **Number in table:** input box
- ▶ Press the ENTRY IN PALLET PRES. TAB. soft key to save the basic rotation in the preset table

The TNC shows an active pallet preset in the additional status display (see "General pallet information (PAL tab)" on page 87).




Displaying a basic rotation

The angle of the basic rotation appears after ROTATION ANGLE whenever PROBING ROT is selected. The TNC also displays the rotation angle in the additional status display (STATUS POS.)

In the status display a symbol is shown for a basic rotation whenever the TNC is moving the axes according to a basic rotation.

Canceling a basic rotation

- ▶ Select the probe function by pressing the PROBING ROT soft key.
- ▶ Enter a rotation angle of zero and confirm with the ENT key.
- ▶ Terminate the probe function by pressing the END key.



Determining basic rotation using 2 holes/studs:



- ▶ Select the probe function by pressing the PROBING ROT soft key (soft-key row 2)



- ▶ Circular studs are to be probed. Define by soft key



- ▶ Holes are to be probed. Define by soft key

Probing holes

Pre-position the touch probe approximately in the center of the hole. After you have pressed the external START key, the TNC automatically probes four points on the wall of the hole.

Move the touch probe to the next hole repeat the probing process. and have the TNC repeat the probing procedure until all the holes have been probed to set reference points.

Probing cylindrical studs

Position the ball tip at a starting position near the first touch point of the stud. Select the probing direction by soft key and press the machine START button to start probing. Perform the above procedure four times.

Saving the basic rotation in the preset table

- ▶ After the probing process, enter the preset number in which the TNC is to save the active basic rotation in the **Number in table:** input box
- ▶ Press the ENTRY IN PRESET TABLE soft key to save the basic rotation in the preset table



Workpiece alignment using 2 points



- ▶ Select the probe function by pressing the PROBING ROT soft key (soft-key row 2)
- ▶ Position the touch probe at a position near the first touch point
- ▶ Select the probe direction perpendicular to the angle reference axis: Select the axis by soft key
- ▶ To probe the workpiece, press the machine START button
- ▶ Position the touch probe at a position near the second touch point
- ▶ To probe the workpiece, press the machine START button. The TNC determines the basic rotation and displays the angle after the dialog **Rotation angle =**

Workpiece alignment:



Danger of collision!

Retract the touch probe before alignment so as to exclude a collision with the fixtures or workpieces.

- ▶ Press the POSITION ROTARY TABLE soft key. The TNC will show a warning that the touch probe must be retracted.
- ▶ Start alignment with NC Start: The TNC will position the rotary table.
- ▶ After the probing process, enter the preset number in which the TNC is to save the active basic rotation in the **Number in table:** input box

Saving the misalignment in the preset table





- ▶ After the probing process, enter the preset number in which the TNC is to save the measured misalignment in the **Number in table:** input box.
- ▶ Press the ENTRY IN PRESET TABLE soft key to save the angle value as displacement in the rotary axis in the preset table



14.8 Datum Setting with a 3-D Touch Probe

Overview

The following soft-key functions are available for setting the datum on an aligned workpiece:

Soft key	Function	Page
	Datum setting in any axis	Page 487
	Setting a corner as datum	Page 488
	Setting a circle center as datum	Page 489
	Center line as datum	Page 490




Danger of collision!

Note that during an active datum shift the TNC always bases the probed value on the active preset (or on the reference point most recently set in the Manual operating mode), although the datum shift is included in the position display.

Datum setting in any axis




- ▶ Select the probe function by pressing the PROBING POS soft key.
- ▶ Move the touch probe to a position near the touch point.
- ▶ Use the soft keys to select the probe axis and direction in which you want to set the datum, such as Z in direction Z-.
- ▶ To probe the workpiece, press the machine START button.
- ▶ **Datum:** Enter the nominal coordinate and confirm your entry with the SET DATUM soft key, or write the value to a table (see "Writing the measured values from touch probe cycles in datum tables", page 475, or see "Writing the measured values from touch probe cycles in the preset table", page 476, or see "Storing measured values in the pallet preset table", page 477).
- ▶ To terminate the probe function, press the END key.



Corner as datum—using points that were already probed for a basic rotation



- ▶ Select the probe function by pressing the PROBING P soft key.
- ▶ **Touch points of basic rotation ?:** Press ENT to transfer the touch point coordinates.
- ▶ Position the touch probe at a position near the first touch point of the side that was not probed for basic rotation.
- ▶ Select the probe direction by soft key.
- ▶ To probe the workpiece, press the machine START button.
- ▶ Position the touch probe near the second touch point on the same workpiece edge.
- ▶ To probe the workpiece, press the machine START button.
- ▶ **Datum:** Enter both coordinates of the datum in the menu window, confirm with the SET DATUM soft key, or write the values to a table (see "Writing the measured values from touch probe cycles in datum tables", page 475, or see "Writing the measured values from touch probe cycles in the preset table", page 476, or see "Storing measured values in the pallet preset table", page 477).
- ▶ To terminate the probe function, press the END key.



Corner as datum—without using points that were already probed for a basic rotation.

- ▶ Select the probe function by pressing the PROBING P soft key.
- ▶ **Touch points of basic rotation?:** Press NO ENT to ignore the previous touch points. (The dialog question only appears if a basic rotation was made previously.)
- ▶ Probe both workpiece sides twice.
- ▶ **Datum:** Enter the coordinates of the datum and confirm your entry with the SET DATUM soft key, or write the values to a table (see "Writing the measured values from touch probe cycles in datum tables", page 475, or see "Writing the measured values from touch probe cycles in the preset table", page 476, or see "Storing measured values in the pallet preset table", page 477.)
- ▶ To terminate the probe function, press the END key.



Circle center as datum

With this function, you can set the datum at the center of bore holes, circular pockets, cylinders, studs, circular islands, etc.

Inside circle:

The TNC automatically probes the inside wall in all four coordinate axis directions.

For incomplete circles (circular arcs) you can choose the appropriate probing direction.

- ▶ Position the touch probe approximately in the center of the circle.





- ▶ Select the probe function by pressing the PROBING CC soft key.
- ▶ To probe the workpiece, press the machine START button four times. The touch probe touches four points on the inside of the circle.
- ▶ If you are probing to find the stylus center (only available on machines with spindle orientation, depending on MP6160), press the 180° soft key and probe another four points on the inside of the circle.
- ▶ If you are not probing to find the stylus center, press the END key.
- ▶ **Datum:** In the menu window, enter both coordinates of the circle center, confirm with the SET DATUM soft key, or write the values to a table (see "Writing the measured values from touch probe cycles in datum tables", page 475, or see "Writing the measured values from touch probe cycles in the preset table", page 476.)
- ▶ To terminate the probe function, press the END key.

Outside circle:

- ▶ Position the touch probe at a position near the first touch point outside of the circle.
- ▶ Select the probe direction by soft key.
- ▶ To probe the workpiece, press the machine START button.
- ▶ Repeat the probing process for the remaining three points. See figure at lower right.
- ▶ **Datum:** Enter the coordinates of the datum and confirm your entry with the SET DATUM soft key, or write the values to a table (see "Writing the measured values from touch probe cycles in datum tables", page 475, or see "Writing the measured values from touch probe cycles in the preset table", page 476, or see "Storing measured values in the pallet preset table", page 477.)
- ▶ To terminate the probe function, press the END key.



After the probing procedure is completed, the TNC displays the coordinates of the circle center and the circle radius PR.



Center line as datum



- ▶ Select the probe function by pressing the PROBING soft key.
- ▶ Position the touch probe at a position near the first touch point.
- ▶ Select the probing direction by soft key.
- ▶ To probe the workpiece, press the machine START button.
- ▶ Position the touch probe at a position near the second touch point.
- ▶ To probe the workpiece, press the machine START button.
- ▶ **Datum:** Enter the coordinate of the datum in the menu window, confirm with the SET DATUM soft key, or write the value to a table (see "Writing the measured values from touch probe cycles in datum tables", page 475, or see "Writing the measured values from touch probe cycles in the preset table", page 476, or see "Storing measured values in the pallet preset table", page 477.)
- ▶ To terminate the probe function, press the END key.







Setting datum points using holes/cylindrical studs

A second soft-key row provides soft keys for using holes or cylindrical studs to set a reference point

Define whether a hole or stud is to be probed

The default setting is for probing holes.

-  ▶ Select the probe function by pressing the TOUCH PROBE soft key, shift the soft-key row.
-  ▶ Select the probe function: For example, press the PROBING P soft key.
-  ▶ Circular studs are to be probed. Define by soft key.
-  ▶ Holes are to be probed. Define by soft key.

Probing holes




Pre-position the touch probe approximately in the center of the hole. After you have pressed the external START key, the TNC automatically probes four points on the wall of the hole.


Move the touch probe to the next hole repeat the probing process. and have the TNC repeat the probing procedure until all the holes have been probed to set reference points.

Probing cylindrical studs

Position the ball tip at a starting position near the first touch point of the stud. Select the probing direction by soft key and press the machine START button to start probing. Perform the above procedure four times.

Overview

Cycle	Soft key
Basic rotation using 2 holes: The TNC measures the angle between the line connecting the centers of two holes and a nominal position (angle reference axis).	
Datum using 4 holes: The TNC calculates the intersection of the line connecting the first two probed holes with the line connecting the last two probed holes. You need to probe diagonally opposite holes one after another (as shown on the soft key), as otherwise the datum calculated by the TNC will be incorrect.	
Circle center using 3 holes: The TNC calculates a circle that intersects the centers of all three holes, and finds the center.	



Measuring Workpieces with a 3-D Touch Probe

You can also use the touch probe in the Manual Operation and EI. Handwheel operating modes to make simple measurements on the workpiece. Numerous programmable probe cycles are available for complex measuring tasks (see User's Manual, Cycles, Chapter 16, Checking workpieces automatically). With a 3-D touch probe you can determine:

- Position coordinates, and from them,
- Dimensions and angles on the workpiece.

To find the coordinate of a position on an aligned workpiece:



- ▶ Select the probe function by pressing the PROBING POS soft key.
- ▶ Move the touch probe to a position near the touch point.
- ▶ Select the probe direction and axis of the coordinate. Use the corresponding soft keys for selection.
- ▶ To probe the workpiece, press the machine START button.

The TNC shows the coordinates of the touch point as reference point.

Finding the coordinates of a corner in the working plane

Find the coordinates of the corner point: See "Corner as datum—without using points that were already probed for a basic rotation." on page 488. The TNC displays the coordinates of the probed corner as reference point.



Measuring workpiece dimensions



- ▶ Select the probe function by pressing the PROBING POS soft key.
- ▶ Position the touch probe at a position near the first touch point A.
- ▶ Select the probing direction by soft key.
- ▶ To probe the workpiece, press the machine START button.
- ▶ If you will need the current datum later, write down the value that appears in the Datum display.
- ▶ Datum: Enter "0".
- ▶ To terminate the dialog, press the END key.
- ▶ Select the probe function by pressing the PROBING POS soft key.
- ▶ Position the touch probe at a position near the second touch point B.
- ▶ Select the probe direction with the soft keys: Same axis but from the opposite direction.
- ▶ To probe the workpiece, press the machine START button.

The value displayed as datum is the distance between the two points on the coordinate axis.

To return to the datum that was active before the length measurement:


- ▶ Select the probe function by pressing the PROBING POS soft key.
- ▶ Probe the first touch point again.
- ▶ Set the datum to the value that you wrote down previously.
- ▶ To terminate the dialog, press the END key.

Measuring angles

You can use the 3-D touch probe to measure angles in the working plane. You can measure

- the angle between the angle reference axis and a workpiece edge, or
- the angle between two sides

The measured angle is displayed as a value of maximum 90°.





Finding the angle between the angle reference axis and a workpiece edge



- ▶ Select the probe function by pressing the PROBING ROT soft key.
- ▶ Rotation angle: If you need the current basic rotation later, write down the value that appears under Rotation angle.
- ▶ Make a basic rotation with workpiece edge to be compared (see "Compensating Workpiece Misalignment with a 3-D Touch Probe" on page 481).
- ▶ Press the PROBING ROT soft key to display the angle between the angle reference axis and the workpiece edge as the rotation angle.
- ▶ Cancel the basic rotation, or restore the previous basic rotation.
- ▶ This is done by setting the rotation angle to the value that you previously wrote down.

To measure the angle between two workpiece sides:

- ▶ Select the probe function by pressing the PROBING ROT soft key.
- ▶ Rotation angle: If you need the current basic rotation later, write down the displayed rotation angle.
- ▶ Make a basic rotation with first workpiece edge (see "Compensating Workpiece Misalignment with a 3-D Touch Probe" on page 481).
- ▶ Probe the second edge as for a basic rotation, but do not set the rotation angle to zero!
- ▶ Press the PROBING ROT soft key to display the angle PA between the sides as the rotation angle.
- ▶ Cancel the basic rotation, or restore the previous basic rotation by setting the rotation angle to the value that you wrote down previously.



Using the touch probe functions with mechanical probes or dial gauges

If you do not have an electronic 3-D touch probe on your machine, you can also use all the previously described manual touch probe functions (exception: calibration function) with mechanical probes or by simply touching the workpiece with the tool.

In place of the electronic signal generated automatically by a 3-D touch probe during probing, you can manually initiate the trigger signal for capturing the **probing position** by pressing a key. Proceed as follows:



- ▶ Select any touch probe function by soft key
- ▶ Move the mechanical probe to the first position to be captured by the TNC



- ▶ Confirm the position: Press the actual-position-capture key for the TNC to save the current position
- ▶ Move the mechanical probe to the next position to be captured by the TNC



- ▶ Confirm the position: Press the actual-position-capture key for the TNC to save the current position
- ▶ If required, move to additional positions and capture as described previously
- ▶ **Datum:** In the menu window, enter the coordinates of the new datum, confirm with the SET DATUM soft key, or write the values to a table (see "Writing the measured values from touch probe cycles in datum tables", page 475, or see "Writing the measured values from touch probe cycles in the preset table", page 476)
- ▶ To terminate the probe function, press the END key



14.9 Tilting the Working Plane (Software Option 1)

Application, function




The functions for tilting the working plane are interfaced to the TNC and the machine tool by the machine tool builder. With some swivel heads and tilting tables, the machine tool builder determines whether the entered angles are interpreted as coordinates of the rotary axes or as angular components of a tilted plane. Refer to your machine tool manual.

The TNC supports the tilting functions on machine tools with swivel heads and/or tilting tables. Typical applications are, for example, oblique holes or contours in an oblique plane. The working plane is always tilted around the active datum. The program is written as usual in a main plane, such as the X/Y plane, but is executed in a plane that is tilted relative to the main plane.

There are three functions available for tilting the working plane:

- 3-D ROT soft key in the Manual Operation mode and Electronic Handwheel mode, see "Activating manual tilting", page 500
- Tilting under program control, Cycle **G80** in the part program (see User's Manual, Cycles, Cycle 19 WORKING PLANE)
- Tilting under program control, **PLANE** function in the part program (see "The PLANE Function: Tilting the Working Plane (Software Option 1)" on page 391)

The TNC functions for "tilting the working plane" are coordinate transformations. The working plane is always perpendicular to the direction of the tool axis.



When tilting the working plane, the TNC differentiates between two machine types:

■ **Machine with tilting table**

- You must tilt the workpiece into the desired position for machining by positioning the tilting table, for example with an L block.
- The position of the transformed tool axis **does not change** in relation to the machine-based coordinate system. Thus if you rotate the table—and therefore the workpiece—by 90° for example, the coordinate system **does not rotate**. If you press the Z+ axis direction button in the Manual Operation mode, the tool moves in Z+ direction.
- In calculating the transformed coordinate system, the TNC considers only the mechanically influenced offsets of the particular tilting table (the so-called “translational” components).

■ **Machine with swivel head**

- You must bring the tool into the desired position for machining by positioning the swivel head, for example with an L block.
- The position of the transformed tool axis changes in relation to the machine-based coordinate system. Thus if you rotate the swivel head of your machine—and therefore the tool—in the B axis by 90° for example, the coordinate system rotates also. If you press the Z+ axis direction button in the Manual Operation mode, the tool moves in X+ direction of the machine-based coordinate system.
- In calculating the transformed coordinate system, the TNC considers both the mechanically influenced offsets of the particular swivel head (the so-called “translational” components) and offsets caused by tilting of the tool (3-D tool length compensation).



Traversing the reference points in tilted axes

With tilted axes, you use the machine axis direction buttons to cross over the reference points. The TNC interpolates the corresponding axes. Be sure that the function for tilting the working plane is active in the Manual Operation mode and that the actual angle of the tilted axis was entered in the menu field.

Setting the datum in a tilted coordinate system

After you have positioned the rotary axes, set the datum in the same manner as for a non-tilted system. The behavior of the TNC during datum setting depends on the settings of Machine Parameter 7500 in your kinematics table:

■ MP 7500, bit 5=0

With an active tilted working plane, the TNC checks during datum setting in the X, Y and Z axes whether the current coordinates of the rotary axes agree with the tilt angles that you defined (3D-ROT menu). If the tilted working plane function is not active, the TNC checks whether the rotary axes are at 0° (actual positions). If the positions do not agree, the TNC will display an error message.

■ MP 7500, bit 5=1

The TNC does not check whether the current coordinates of the rotary axes (actual positions) agree with the tilt angles that you defined.



Danger of collision!

Always set a reference point in all three reference axes.

If your machine tool is not equipped with axis control, you must enter the actual position of the rotary axis in the menu for manual tilting: The actual positions of one or several rotary axes must match the entry. Otherwise the TNC will calculate an incorrect datum.

Datum setting on machines with rotary tables

If you use a rotary table to align the workpiece, for example with probing cycle 403, you must set the table position value to zero after alignment and before setting the datum in the linear axes X, Y and Z. Otherwise, the TNC generates an error message. Cycle 403 provides you with an input parameter for this purpose (see User's Manual for Touch Probe Cycles, "Basic Rotation Compensation via Rotary Axis").



Datum setting on machines with spindle-head changing systems

If your machine is equipped with a spindle head changer, you should use the preset table to manage your datums. Datums saved in preset tables account for the active machine kinematics (head geometry). If you exchange heads, the TNC accounts for the new head dimensions so that the active datum is retained.

Position display in a tilted system

The positions displayed in the status window (**ACTL.** and **NOML.**) are referenced to the tilted coordinate system.

Limitations on working with the tilting function

- The probing function for basic rotation is not available if you have activated the working plane function in the Manual Operation mode.
- The actual-position-capture function is not allowed if the tilted working plane function is active.
- PLC positioning (determined by the machine tool builder) is not possible.



Activating manual tilting



To select manual tilting, press the 3-D ROT soft key.



Use the arrow keys to move the highlight to the **Manual Operation** menu item.



To activate manual tilting, press the ACTIVE soft key.




Use the arrow keys to position the highlight on the desired rotary axis.

Enter the tilt angle




To conclude entry, press the END key.

To reset the tilting function, set the desired operating modes in the menu “Tilt working plane” to inactive.

If the tilted working plane function is active and the TNC moves the machine axes in accordance with the tilted axes, the status display shows the  symbol.

If you activate the “Tilt working plane” function for the Program Run operating mode, the tilt angle entered in the menu becomes active in the first block of the part program. If you use Cycle **G80** or the **PLANE** function in the part program, the angle values defined there are in effect. Angle values entered in the menu will be overwritten.




Setting the current tool-axis direction as the active machining direction (FCL 2 function)



This function must be enabled by your machine manufacturer. Refer to your machine tool manual.

In the Manual Operation and Electronic Handwheel modes of operation you can use this function to move the tool via the external direction keys or with the handwheel in the direction that the tool axis is currently pointed. Use this function if

- You want to retract the tool in the direction of the tool axis during program interrupt of a 5-axis machining program.
- You want to machine with an inclined tool using the handwheel or the external direction keys in the Manual Operation mode.



To select manual tilting, press the 3-D ROT soft key.



Use the arrow keys to move the highlight to the **Manual Operation** menu item.




To activate the current tool-axis direction as the active machining direction, press the TOOL AXIS soft key.



To conclude entry, press the END key.

To reset the tilting function, set the **Manual Operation** menu item in the "Tilt working plane" menu to inactive.

The  symbol appears in the status display when the **Move in tool-axis direction** function is active.



This function is even available when you interrupt program run and want to move the axes manually.



14.9 Tilting the Working Plane (Software Option 1)





15

**Positioning with Manual
Data Input**



15.1 Programming and Executing Simple Machining Operations

The Positioning with Manual Data Input mode of operation is particularly convenient for simple machining operations or to pre-position the tool. It enables you to write a short program in HEIDENHAIN conversational programming or in ISO format, and execute it immediately. Fixed cycles, touch-probe cycles and special functions (SPEC FCT key) of the TNC are also available in the MDI mode of operation. The TNC saves the program automatically in the \$MDI file. In the Positioning with MDI mode of operation, the additional status displays can also be activated.

Positioning with Manual Data Input (MDI)



Select the Positioning with MDI mode of operation. Program the \$MDI file with the available functions.



To start program run, press the machine START key.



Constraints:

FK free contour programming, programming graphics and program run graphics cannot be used.


The \$MDI file must not contain a program call (%).



Example 1

A hole with a depth of 20 mm is to be drilled into a single workpiece. After clamping and aligning the workpiece and setting the datum, you can program and execute the drilling operation in a few lines.

First you pre-position the tool with straight-line blocks to the hole center coordinates at a setup clearance of 5 mm above the workpiece surface. Then drill the hole with Cycle **G200**.



%MDI G71 *	
N10 T1 G17 S2000 *	Call tool: tool axis Z
	Spindle speed 2000 rpm
N20 G00 G40 G90 Z+200 *	Retract tool (rapid traverse)
N30 X+50 Y+50 M3 *	Move the tool at rapid traverse to a position above the hole,
	spindle on
N40 G01 Z+2 F2000 *	Position tool to 2 mm above hole
N50 G200 DRILLING *	Define Cycle G200 Drilling
Q200=2 ;SETUP CLEARANCE	Setup clearance of the tool above the hole
Q201=-20 ;DEPTH	Total hole depth (algebraic sign=working direction)
Q206=250 ;FEED RATE FOR PLNGN	Feed rate for drilling
Q202=10 ;PLUNGING DEPTH	Depth of each infeed before retraction
Q210=0 ;DWELL TIME AT TOP	Dwell time at top for chip release (in seconds)
Q203=+0 ;SURFACE COORDINATE	Workpiece surface coordinate
Q204=50 ;2ND SETUP CLEARANCE	Position after the cycle, with respect to Q203
Q211=0.5 ;DWELL TIME AT DEPTH	Dwell time in seconds at the hole bottom
N60 G79 *	Call Cycle G200 PECKING
N70 G00 G40 Z+200 M2 *	Retract the tool
N9999999 %MDI G71 *	End of program

Straight-line function: See "Straight line at rapid traverse G00 Straight line with feed rate G01 F" on page 205, DRILLING cycle: See User's Manual, Cycles, Cycle 200 DRILLING.



Example 2: Correcting workpiece misalignment on machines with rotary tables

Use the 3-D touch probe to rotate the coordinate system. See “Touch Probe Cycles in the Manual and Electronic Handwheel Operating Modes,” section “Compensating workpiece misalignment,” in the Touch Probe Cycles User’s Manual.

Write down the rotation angle and cancel the basic rotation.



Select operating mode: Positioning with MDI.



IV

Select the rotary table axis, enter the rotation angle and feed rate you wrote down, for example: **G01 G40 G90 C+2.561 F50**



Conclude the entry.



Press the machine START button: The rotation of the table corrects the misalignment.



Protecting and erasing programs in \$MDI

The \$MDI file is generally intended for short programs that are only needed temporarily. Nevertheless, you can store a program, if necessary, by proceeding as described below:



Select the Programming and Editing mode of operation.



To call the file manager, press the PGM MGT key (program management).



Mark the \$MDI file.



To select the file copying function, press the COPY soft key.

DESTINATION FILE =

HOLE

Enter the name under which you want to save the current contents of the \$MDI file.



Copy the file.



To close the file manager, press the END soft key.

Erasing the contents of the \$MDI file is done in a similar way: Instead of copying the contents, however, you erase them with the DELETE soft key. The next time you select the Positioning with MDI operating mode, the TNC will display an empty \$MDI file.



If you wish to delete \$MDI, then

- you must not have selected the Positioning with MDI mode (not even in the background)
- you must not have selected the \$MDI file in the Programming and Editing mode.

For more information: see "Copying a single file", page 123.







16

Test Run and Program Run



16.1 Graphics

Application

In the program run modes of operation as well as in the Test Run mode, the TNC graphically simulates the machining of the workpiece. Using soft keys, select whether you desire:

- Plan view
- Projection in three planes
- 3-D view

The TNC graphic depicts the workpiece as if it were being machined with a cylindrical end mill. If a tool table is active, you can also simulate the machining operation with a spherical cutter. For this purpose, enter $R2 = R$ in the tool table.

The TNC will not show a graphic if

- the current program has no valid blank form definition
- no program is selected



Using the new 3-D graphics in the **Test Run** mode, you can now also graphically display machining operations in the tilted working plane as well as multi-sided machining operations, provided that you have already simulated the program in another view. You need at least the MC 422 B hardware in order to use this function. In order to increase the speed of the test graphics on older hardware versions, bit 5 of MP7310 should be set to 1. This deactivates functions which were implemented specifically for the 3-D graphics.

The TNC graphic does not show a radius oversize **DR** that has been programmed in the **T** block.

Graphic simulation for special applications

NC programs usually contain a tool call with a defined tool number, which automatically determines the tool data for graphic simulation.

For special applications that do not require any tool data (e.g. laser cutting, laser drilling or waterjet cutting), you can set Machine Parameters 7315 to 7317 such that the TNC will run a graphic simulation even if no tool data are activated. However, you always need a tool call with the definition of the tool axis orientation (e.g. **G17**). The tool number does not need to be entered.



Setting the speed of the test run



You can set the speed of the test run only if the “Display of machining time” function is active (see “Activating the stopwatch function” on page 519). Otherwise, the TNC always performs the test run at the maximum possible speed.

The most recently set speed remains active, even if the power is interrupted, until you change it.

After you have started a program, the TNC displays the following soft keys with which you can set the simulation speed.

Functions	Soft key
Execute test run at the same speed at which the program will be run (programmed feed rates are taken into account).	
Increase the test speed incrementally.	
Decrease the test speed incrementally.	
Test run at the maximum possible speed (default setting).	

You can also set the simulation speed before you start a program:



- ▶ Switch to the next soft-key row



- ▶ Select the function for setting the simulation speed






- ▶ Select the desired function by soft key, e.g. incrementally increasing the test speed



Overview of display modes

The control displays the following soft keys in the Program Run and Test Run modes of operation:

View	Soft key
Plan view	
Projection in three planes	
3-D view	

Limitations during program run



A graphical representation of a running program is not possible if the microprocessor of the TNC is already occupied with complicated machining tasks or if large areas are being machined. Example: Multipass milling over the entire workpiece blank with a large tool. The TNC interrupts the graphics and displays the text **ERROR** in the graphics window. The machining process is continued, however.

In the test run graphics, the TNC does not depict multi-axis operations during machining. The error message **Axis cannot be shown** appears in the graphics window in such cases.

Plan view


This is the fastest of the graphic display modes.



If your machine has a mouse, the status bar shows the depth of any location on the workpiece when you move the mouse pointer over it.



- ▶ Press the soft key for plan view
- ▶ Regarding depth display, remember: The deeper the surface, the darker the shade



Projection in 3 planes

Similar to a workpiece drawing, the part is displayed with a plan view and two sectional planes. A symbol to the lower left indicates whether the display is in first-angle or third-angle projection method according to ISO 128 (selected with MP7310).

Details can be isolated in this display mode for magnification (see "Magnifying details", page 517).

In addition, you can shift the sectional planes with the corresponding soft keys:




- ▶ Select the soft key for projection in three planes









- ▶ Shift the soft-key row until the soft key for the functions for shifting the sectional plane appears



- ▶ Select the functions for shifting the sectional plane. The TNC offers the following soft keys:



Function	Soft keys
Shift the vertical sectional plane to the right or left	 
Shift the vertical sectional plane forward or backward	 
Shift the horizontal sectional plane upwards or downwards	 

The positions of the sectional planes are visible during shifting.

The default setting of the sectional plane is selected such that it lies in the working plane in the workpiece center and in the tool axis on the top surface.

Coordinates of the line of intersection

At the bottom of the graphics window, the TNC displays the coordinates of the line of intersection, referenced to the workpiece datum. Only the coordinates of the working plane are shown. This function is activated with MP7310.



3-D view

The workpiece is displayed in three dimensions. If you have the appropriate hardware, then with its high-resolution 3-D graphics the TNC can also display machining operations in the tilted working plane as well as multi-sided machining operations.

You can rotate the 3-D display about the vertical and horizontal axes via soft keys. If there is a mouse attached to your TNC, you can also perform this function by holding down the right mouse button and dragging the mouse.

The shape of the workpiece blank can be depicted by a frame overlay at the beginning of the graphic simulation.



In the Test Run mode of operation you can isolate details for magnification, see "Magnifying details", page 517.



- ▶ Press the soft key for 3-D view. Press the soft key twice to switch to the high-resolution 3-D graphics. This switch is only possible once the simulation has finished. The high-resolution graphics show more surface details of the workpiece being machined.



The speed of the 3-D graphics depends on the tooth length (**LCUTS** column in the tool table). If **LCUTS** is defined as 0 (basic setting), the simulation calculates an infinitely long tooth length, which leads to a long processing time. If you do not want to define **LCUTS**, then set MP7312 to a value between 5 and 10. This way the TNC internally limits the tooth length to a value which is calculated from MP7312 times the tool diameter.










Rotating and magnifying/reducing the 3-D view



- ▶ Shift the soft-key row until the soft key for the rotating and magnification/reduction appears



- ▶ Select functions for rotating and magnifying/reducing:

Function	Soft keys
Rotate in 5° steps about the vertical axis	 
Tilt in 5° steps about the horizontal axis	 
Magnify the graphic stepwise. If the view is magnified, the TNC shows the letter Z in the footer of the graphic window.	
Reduce the graphic stepwise. If the view is reduced, the TNC shows the letter Z in the footer of the graphic window.	
Reset image to programmed size	

If there is a mouse attached to your TNC, you can also perform the functions described above with the mouse.

- ▶ In order to rotate the graphic shown in three dimensions: Hold the right mouse button down and move the mouse. In the high resolution 3-D graphics the TNC displays the coordinate system showing the currently active alignment of the workpiece. In the normal 3-D view the entire workpiece rotates as well. After you release the right mouse button, the TNC orients the workpiece to the defined orientation
- ▶ In order to shift the graphic shown: Hold the center mouse button or the wheel button down and move the mouse. The TNC shifts the workpiece in the corresponding direction. After you release the center mouse button, the TNC shifts the workpiece to the defined position
- ▶ In order to zoom in on a certain area with the mouse: Draw a rectangular zoom area while holding the left mouse button down. After you release the left mouse button, the TNC zooms in on the defined area of the workpiece
- ▶ In order to quickly zoom in and out with the mouse: Rotate the wheel button forward or backward



Switch the frame overlay display for the workpiece blank on/off:

- ▶ Shift the soft-key row until the soft key for the rotating and magnification/reduction appears



- ▶ Select functions for rotating and magnifying/reducing:



- ▶ Show the frame for the BLK FORM: Set the highlight in the soft key to SHOW



- ▶ Hide the frame for the BLK FORM: Set the highlight in the soft key to OMIT



Magnifying details

You can magnify details in all display modes in the Test Run mode and a Program Run mode.

The graphic simulation or the program run, respectively, must first have been stopped. A detail magnification is always effective in all display modes.

Changing the detail magnification

The soft keys are listed in the table


- ▶ Interrupt the graphic simulation, if necessary
- ▶ Shift the soft-key row in the Test Run mode, or in a Program Run mode, respectively, until the soft key for detail enlargement appears












- ▶ Shift the soft-key row until the soft-key for the detail magnification functions appears



- ▶ Select the functions for detail magnification
- ▶ Press the corresponding soft key to select the workpiece surface (see table below)
- ▶ To reduce or magnify the workpiece blank, press and hold the MINUS or PLUS soft key, respectively
- ▶ Restart the test run or program run by pressing the START soft key (RESET + START returns the workpiece blank to its original state).



Function	Soft keys
Select the left/right workpiece surface	 
Select the front/back workpiece surface	 
Select the top/bottom workpiece surface	 
Shift the sectional plane to reduce or magnify the workpiece blank	 
Select the isolated detail	



Cursor position during detail magnification



During detail magnification, the TNC displays the coordinates of the axis that is currently being isolated. The coordinates describe the area determined for magnification. To the left of the slash is the smallest coordinate of the detail (MIN point), to the right is the largest (MAX point).

If a graphic display is magnified, this is indicated with **MAGN** at the lower right of the graphics window.

If the workpiece blank cannot be further enlarged or reduced, the TNC displays an error message in the graphics window. To clear the error message, reduce or enlarge the workpiece blank.

Repeating graphic simulation

A part program can be graphically simulated as often as desired, either with the complete workpiece or with a detail of it.



Function	Soft key
Restore workpiece blank to the detail magnification in which it was last shown.	
Reset detail magnification so that the machined workpiece or workpiece blank is displayed as it was programmed with BLK FORM.	



With the WINDOW BLK FORM soft key, you return the displayed workpiece blank to its originally programmed dimensions, even after isolating a detail without TRANSFER DETAIL.

Displaying the tool

You can display the tool during simulation in the plan view and in the projection in 3 planes. The TNC depicts the tool in the diameter defined in the tool table.

Function	Soft key
Do not display the tool during simulation	
Display the tool during simulation	



Measuring the machining time

Program Run modes of operation

The timer counts and displays the time from program start to program end. The timer stops whenever machining is interrupted.

Test Run

The TNC takes the following into account for the time calculation:

- Traverse movements at feed rate
- Dwell times
- Machine dynamics settings (accelerations, filter settings, motion control)

The time calculated by the TNC does not include rapid-traverse movements and times depending on the individual machine tool (e.g. tool change).

If you have switched the "calculate machining time" function on, you can generate a file listing the usage times of all tools used in the program (see "Tool usage test" on page 183).

Activating the stopwatch function




▶ Shift the soft-key row until the soft-key for the stopwatch functions appears.



▶ Select the stopwatch functions.



▶ Select the desired function by soft key, e.g. saving the displayed time.



Stopwatch functions	Soft key
Enable (ON) or disable (OFF) the "calculate the machining time" function.	
Store displayed time	
Display the sum of stored time and displayed time	
Clear displayed time	







During the Test Run, the TNC resets the machining time as soon as a new BLK form **G30/G3** is evaluated.




16.2 Functions for Program Display

Overview

In the program run modes of operation as well as in the Test Run mode, the TNC provides the following soft keys for displaying a part program in pages:

Functions	Soft key
Go back in the program by one screen	
Go forward in the program by one screen	
Go to the beginning of the program	
Go to the end of the program	



16.3 Test Run

Application

In the Test Run mode of operation you can simulate programs and program sections to reduce programming errors during program run. The TNC checks the programs for the following:

- Geometrical incompatibilities
- Missing data
- Impossible jumps
- Violation of the machine's working space
- Collisions between collision-monitored components (DCM software option is required, see "Collision monitoring in the Test Run mode of operation", page 342)

The following functions are also available:

- Blockwise test run
- Interrupt test at any block
- Optional block skip
- Functions for graphic simulation
- Calculating the machining time
- Additional status display



If your machine has the DCM (Dynamic Collision Monitoring) software option, you can check for collisions in the Test Run mode before actually machining a part, (see "Collision monitoring in the Test Run mode of operation" on page 342)



**Danger of collision!**

The TNC cannot graphically simulate all traverse motions actually performed by the machine. These include

- traverse motions during tool change, if the machine manufacturer defined them in a tool-change macro or via the PLC,
- positioning movements that the machine manufacturer defined in an M-function macro,
- positioning movements that the machine manufacturer performs via the PLC.
- positioning movements that lead to a pallet change.

HEIDENHAIN therefore recommends proceeding with caution for every new program, even when the program test did not output any error message, and no visible damage to the workpiece occurred.

After a tool call, the TNC always starts a Test Run at the following position:

- In the machining plane at the position $X=0, Y=0$
- In the tool axis, 1 mm above the **MAX** point defined in the **BLK FORM**.

If you call the same tool, the TNC resumes program simulation from the position last programmed before the tool call.

In order to ensure unambiguous behavior during program run, after a tool change you should always move to a position from which the TNC can position the tool for machining without causing a collision.



Your machine tool builder can also define a tool-change macro for the Test Run operating mode. This macro will simulate the exact behavior of the machine. Please refer to your machine tool manual.



Executing a test run





If the central tool file is active, a tool table must be active (status S) to perform a test run. Select a tool table via the file manager (PGM MGT) in the Test Run mode of operation.

With the MOD function BLANK IN WORK SPACE, you can activate work space monitoring for the test run (see "Showing the Workpiece in the Working Space", page 565).



- ▶ Select the Test Run operating mode
- ▶ Call the file manager with the PGM MGT key and select the file you wish to test, or
- ▶ Go to the program beginning: Select line 0 with the GOTO key and confirm your entry with the ENT key.

The TNC then displays the following soft keys:

Functions	Soft key
Reset the blank form and test the entire program	
Test the entire program	
Test each program block individually	
Halt test run (soft key only appears once you have started the test run)	

You can interrupt the test run and continue it again at any point—even within a machining cycle. In order to continue the test, the following actions must not be performed:

- Selecting another block with the arrow keys or the GOTO key
- Making changes to the program
- Switching the operating mode
- Selecting a new program




Executing a test run up to a certain block

With the STOP AT N function the TNC does a test run only up to the block with block number N.

- ▶ Go to the beginning of program in the Test Run mode of operation
- ▶ To run a program test up to a specific block, press the STOP AT N soft key



- ▶ **Stop at N:** Enter the block number at which you wish the test to stop
- ▶ **Program:** Enter the name of the program that contains the block with the selected block number. The TNC displays the name of the selected program. If the test run is to be interrupted in a program that was called with PGM CALL, you must enter this name
- ▶ **Start-up at: P:** If you want to start in a point table, enter here the line number at which you want to start
- ▶ **Table (PNT):** If you want to start in a point table, enter here the name of the point table in which you want to start
- ▶ **Repetitions:** If N is located in a program section repeat, enter the number of repeats that you want to run
- ▶ To test a program section, press the START soft key. The TNC will test the program up to the entered block



Selecting the kinematics for test run



This function must be enabled by your machine manufacturer.

You can use this function to test programs whose kinematics does not match the active machine kinematics (e.g. on machines with head change or traverse range switchover).

If your machine manufacturer saved different kinematic configurations in your machine, you can activate one of these kinematics configurations with the MOD function and use it for a test run. The active machine kinematics will remain unchanged.



- ▶ Select the Test Run operating mode
- ▶ Choose the program you want to test



- ▶ Select MOD functions



- ▶ Show the available kinematics configurations in a pop-up window (shift the soft-key row, if necessary).
- ▶ Select the desired kinematics configuration with the arrow keys and confirm your selection with the ENT key.



After switching on the control, the machine kinematics is always active in the Test Run mode. After switching on the control, select the desired kinematics for the test run.

If you select a kinematics configuration with the keyword **kinematic**, the TNC switches the machine kinematics **and** the test kinematics.



Setting a tilted working plane for the test run



This function must be enabled by your machine manufacturer.

You can use this function on machines, where you want to define the working plane by manually setting the machine axes.



- ▶ Select the Test Run operating mode
- ▶ Choose the program you want to test



- ▶ Select MOD functions



- ▶ Select the menu for defining the working plane
- ▶ To activate or deactivate the function, press the ENT key



- ▶ Use the active rotary axis coordinates from the machine mode of operation, or
- ▶ Position the highlight on the desired rotary axis with the arrow keys and enter the rotary-axis value to be used by the TNC in the simulation



If the function has been enabled by your machine manufacturer, then the TNC does not deactivate the “Tilt the working plane” function when you select a new program.

If you simulate a program that does not contain a **T** block, then the axis you have activated for manual probing in the Manual Operation mode is used by the TNC as tool axis.

Ensure that the active kinematics in the test run is suitable for the program you want to test. Otherwise, the TNC may issue an error message.



Running a part program

Preparation

- 1 Clamp the workpiece to the machine table.
- 2 Set the datum.
- 3 Select the necessary tables and pallet files (status M).
- 4 Select the part program (status M).



You can adjust the feed rate and spindle speed with the override knobs.

It is possible to reduce the feed rate when starting the NC program using the FMAX soft key. The reduction applies to all rapid traverse and feed rate movements. The value you enter is no longer in effect after the machine has been turned off and on again. In order to re-establish the respectively defined maximum feed rate after switch-on, you need to re-enter the corresponding value.

Program Run, Full Sequence

- ▶ Start the part program with the machine START button

Program Run, Single Block

- ▶ Start each block of the part program individually with the machine START button



Interrupting machining

There are several ways to interrupt a program run:

- Programmed interruptions
- Pressing the machine STOP button
- Switching to "Single Block" program run
- Programming of noncontrolled axes (counter axes)

If the TNC registers an error during program run, it automatically interrupts the machining process.

Programmed interruptions

You can program interruptions directly in the part program. The TNC interrupts the program run at a block containing one of the following entries:

- **G38** (with and without miscellaneous function)
- Miscellaneous functions **M0**, **M2** or **M30**
- Miscellaneous function **M6** (defined by the machine tool builder)

Interrupting the machining process with the machine STOP button

- ▶ Press the machine STOP button: The block which the TNC is currently executing is not completed. The asterisk in the status display blinks
- ▶ If you do not wish to continue the machining process, you can reset the TNC with the INTERNAL STOP soft key. The asterisk in the status display goes out. In this case, the program must be restarted from the program beginning

Interrupting the machining process by switching to the Program Run, Single Block mode of operation

You can interrupt a program that is being run in the Program Run, Full Sequence mode of operation by switching to the Program Run, Single Block mode. The TNC interrupts the machining process at the end of the current block.

Jumps within the program after an interruption

If program run is interrupted with the INTERNAL STOP function, the TNC memorizes the current machining status. You can usually resume machining with NC start. If you select other program lines with the GOTO key, the TNC does not reset modally effective functions (e.g. **M136**). This may have undesired effects, such as incorrect feed rates.



Danger of collision!

Please note that program jumps with the GOTO function do not reset modal functions.

If you want to restart a program after an interruption, always select the program with the PGM MGT key.



Programming of noncontrolled axes (counter axes)



This function must be adapted by your machine manufacturer. Refer to your machine tool manual.

The TNC automatically interrupts the program run as soon as an axis is programmed in a positioning block that was defined by the machine tool builder as an open-loop axis (counter axis). In this condition you can move the open-loop axis manually to the desired position. In the left window, the TNC shows all nominal positions programmed in this block. For open-loop axes the TNC additionally displays the distance remaining.

As soon as all axes are in the correct position, you can use NC Start to resume program run.



- ▶ Select the desired axis sequence and start each with NC Start. Manually position the open-loop axes. The TNC shows the distance remaining to the nominal position in this axis (see “Returning to the contour” on page 536).



- ▶ If required, choose whether the closed-loop axes are to be moved in the tilted or non-tilted coordinate system.



- ▶ If required, move the closed-loop axes by handwheel or with the axis-direction buttons.



Moving the machine axes during an interruption

You can move the machine axes during an interruption in the same way as in the Manual Operation mode.



Danger of collision!

If you interrupt program run while the working plane is tilted, you can switch the coordinate system between tilted and non-tilted, as well as to the active tool axis direction, by pressing the 3-D ROT soft key.

The functions of the axis direction buttons, the electronic handwheel and the positioning logic for returning to the contour are then evaluated by the TNC. When retracting the tool make sure the correct coordinate system is active and the angular values of the tilt axes are entered in the 3-D ROT menu, if necessary.

Application example:

Retracting the spindle after tool breakage

- ▶ Interrupt machining
- ▶ Enable the external direction keys: Press the MANUAL TRAVERSE soft key.
- ▶ If necessary, press the 3-D ROT soft key in order to activate the coordinate system in which you want to traverse.
- ▶ Move the axes with the machine axis direction buttons



On some machines you may have to press the machine START button after the MANUAL TRAVERSE soft key to enable the axis direction buttons. Refer to your machine tool manual.

Your machine tool builder can define whether in a program interruption you always move the axes in the currently active (tilted or non-tilted) coordinate system. Refer to your machine tool manual.



Resuming program run after an interruption



If a program run is interrupted during a fixed cycle, the program must be resumed from the beginning of the cycle. This means that some machining operations will be repeated.

If you interrupt a program run during execution of a subprogram or program section repeat, use the RESTORE POS AT N function to return to the position at which the program run was interrupted.

When a program run is interrupted, the TNC stores:

- The data of the last defined tool
- Active coordinate transformations (e.g. datum shift, rotation, mirroring)
- The coordinates of the circle center that was last defined



Note that the stored data remain active until they are reset (e.g. if you select a new program).

The TNC uses the stored data for returning the tool to the contour after manual machine axis positioning during an interruption (RESTORE POSITION soft key).

Resuming program run with the machine START button

You can resume program run by pressing the machine START button if the program was interrupted in one of the following ways:

- The machine STOP button was pressed
- Programmed interruption

Resuming program run after an error

- ▶ Remove the cause of the error
- ▶ To clear the error message from the screen, press the CE key
- ▶ Restart the program, or resume program run where it was interrupted

After a control software crash,

- ▶ Press and hold the END key for two seconds. This induces a TNC system restart
- ▶ Remove the cause of the error
- ▶ Start again

If you cannot correct the error, write down the error message and contact your repair service agency.



Mid-program startup (block scan)



The RESTORE POS AT N feature (block scan) must be enabled and adapted by the machine tool builder. Refer to your machine tool manual.

With the RESTORE POS AT N feature (block scan) you can start a part program at any block you desire. The TNC scans the program blocks up to that point. Machining can be graphically simulated.

If you have interrupted a part program with an INTERNAL STOP, the TNC automatically offers the interrupted block N for mid-program startup.

If the program was interrupted by one of the conditions listed below, the TNC saves the point of interruption.

- EMERGENCY STOP
- Power interruption
- Control software crash

After you have called the mid-program startup function, you can press the soft key SELECT LAST N to reactivate the point of interruption and approach it with an NC start. After switch-on the TNC shows the message **NC program cancelled**.



Mid-program startup must not begin in a subprogram.


All necessary programs, tables and pallet files must be selected in a program run mode of operation (status M).

If the program contains a programmed interruption before the startup block, the block scan is interrupted. Press the machine START button to continue the block scan.

After a block scan, return the tool to the calculated position with RESTORE POSITION.

Tool length compensation does not take effect until after the tool call and a following positioning block. This also applies if you have only changed the tool length.

The additional functions **M142** (delete modal program information) and **M143** (delete basic rotation) are not permitted during a mid-program startup.





If you are working with nested programs, you can use MP7680 to define whether the block scan is to begin at block 0 of the main program or at block 0 of the last interrupted program.

With the 3-D ROT soft key you can switch the coordinate system between tilted and non-tilted in order to move to the start-up position.

If you want to use the block scan feature in a pallet table, select the program in which a mid-program startup is to be performed from the pallet table by using the arrow keys. Then press the RESTORE POS AT N soft key.

The TNC skips all touch probe cycles in a mid-program startup. Result parameters that are written to from these cycles might therefore remain empty.

The **M142**, **M143** and **M120** functions are not allowed during a mid-program startup.

Before beginning the mid-program start-up, the TNC deletes traverse movements that you performed during the program with **M118** (handwheel superimpositioning).



Danger of collision!

If you perform a mid-program startup in a program containing M128, then the TNC performs any compensation movements necessary. The compensation movements are superimposed over the approach movement.



- ▶ To go to the first block of the current program to start a block scan, enter GOTO "0".



- ▶ To select block scan, press the BLOCK SCAN soft key, or
 - ▶ **Start-up at N:** Enter the block number N at which the block scan should end
 - ▶ **Program:** Enter the name of the program containing block N
 - ▶ **Start-up at: P:** Enter the number P at which the block scan should end if you want to start in a point table
 - ▶ **Table (PNT):** Enter the name of the point table in which the block scan should end
 - ▶ **Repetitions:** If block N is located in a program section repeat or in a subprogram that is to be run repeatedly, enter the number of repetitions to be calculated in the block scan
- ▶ To start the block scan, press the machine START button
- ▶ Contour approach (see following section)

Entering a program with the GOTO key



Danger of collision!

If you use the GOTO block number key for going into a program, neither the TNC nor the PLC will execute any functions that ensure a safe start.


If you use the GOTO block number key for going into a subprogram, the TNC will skip the end of the subprogram (**G98 L0**)! In such cases you must always use the mid-program startup function.



Returning to the contour

With the RESTORE POSITION function, the TNC returns to the workpiece contour in the following situations:

- Return to the contour after the machine axes were moved during a program interruption that was not performed with the INTERNAL STOP function.
- Return to the contour after a block scan with RESTORE POS AT N, for example after an interruption with INTERNAL STOP.
- Depending on the machine, if the position of an axis has changed after the control loop has been opened during a program interruption.
- If an open-loop axis is also programmed in a positioning block (see "Programming of noncontrolled axes (counter axes)" on page 530)
 - ▶ To select a return to contour, press the RESTORE POSITION soft key.
 - ▶ Restore machine status, if required.
 - ▶ To move the axes in the sequence that the TNC suggests on the screen, press the machine START button.
 - ▶ To move the axes in any sequence, press the soft keys RESTORE X, RESTORE Z, etc., and activate each axis with the machine START button.
 - ▶ To resume machining, press the machine START button.



16.5 Automatic Program Start

Application





The TNC must be specially prepared by the machine tool builder for use of the automatic program start function. Refer to your machine tool manual.

In a Program Run operating mode, you can use the AUTOSTART soft key (see figure at upper right) to define a specific time at which the program that is currently active in this operating mode is to be started:



- ▶ Show the window for entering the starting time (see figure at center right).
- ▶ **Time (h:min:sec):** Time of day at which the program is to be started.
- ▶ **Date (DD.MM.YYYY):** Date at which the program is to be started.
- ▶ To activate the start, set the AUTOSTART soft key to ON.



16.6 Optional Block Skip

Application

In a test run or program run, the control can skip over blocks that begin with a slash “/”:



- ▶ To run or test the program without the blocks preceded by a slash, set the soft key to ON.



- ▶ To run or test the program with the blocks preceded by a slash, set the soft key to OFF.



This function does not work for TOOL DEF blocks.

After a power interruption the control returns to the most recently selected setting.

Erasing the “/” character

- ▶ In the **Programming and Editing** mode you select the block in which the character is to be erased



- ▶ Erase the “/” character



16.7 Optional Program-Run Interruption

Application

The TNC optionally interrupts program run at blocks containing **M1**. If you use **M1** in the Program Run mode, the TNC does not switch off the spindle or coolant, if necessary. Your machine tool manual provides more information.



- ▶ Do not interrupt Program Run or Test Run at blocks containing **M1**: Set soft key to OFF



- ▶ Interrupt Program Run or Test Run at blocks containing **M1**: Set soft key to ON



M1 is not effective in the Test Run mode of operation.







17

MOD Functions



17.1 Selecting MOD Functions

The MOD functions provide additional input possibilities and displays. The available MOD functions depend on the selected operating mode.

Selecting the MOD functions

Call the operating mode in which you wish to change the MOD functions.



- ▶ To select the MOD functions, press the MOD key. The figures at right show typical screen menus in Programming and Editing mode (figure at upper right), Test Run mode (figure at lower right) and in a machine operating mode (see figure on next page).

Changing the settings


- ▶ Select the desired MOD function in the displayed menu with the arrow keys

There are three possibilities for changing a setting, depending on the function selected:

- Enter a numerical value directly, e.g. when determining the traverse range limit
- Change a setting by pressing the ENT key, e.g. when setting program input
- Change a setting via a selection window. If more than one possibility is available for a particular setting, you can superimpose a window listing all of the given possibilities by pressing the GOTO key. Select the desired setting directly by pressing the corresponding numerical key (to the left of the colon), or by using the arrow keys and then confirming with ENT. If you don't want to change the setting, close the window again with END

Exiting the MOD functions

- ▶ To exit the MOD functions, press the END key or END soft key



Overview of MOD functions

The functions available depend on the momentarily selected operating mode:

Programming and Editing:


- Display software numbers
- Enter code number
- Set data interface
- Diagnostic functions, if applicable
- Machine-specific user parameters, if applicable
- Display HELP files (if provided)
- Select machine kinematics, if applicable
- Load service packs
- Set the time zone
- Start file-system check
- Configure the HR 550 wireless handwheel
- Legal information

Test run:

- Display software numbers
- Enter code number
- Set the data interface
- Show the workpiece in the working space
- Machine-specific user parameters, if applicable
- Display HELP files (if provided)
- Select machine kinematics, if applicable
- Set 3-D ROT function, if applicable
- Set the time zone
- License info

In all other modes:

- Display software numbers
- Display code digits for installed options
- Select position display
- Define unit of measurement (mm/inches)
- Set the programming language for MDI
- Select the axes for actual position capture
- Set the axis traverse limits
- Display reference points
- Display operating times
- Display HELP files (if provided)
- Set the time zone
- Select machine kinematics, if applicable
- License info



17.2 Software Numbers

Application

The following software numbers are displayed on the TNC screen after the MOD functions have been selected:

- **NC:** Number of the NC software (managed by HEIDENHAIN)
- **PLC:** Number and name of the PLC software (managed by your machine tool builder)
- **Feature Content Level (FCL):** Development level of the software installed on the control (see "Feature content level (upgrade functions)" on page 10). The TNC displays --- on the programming station, since there is no Feature Content Level there.
- **DSP1 to DSP3:** Number of the speed controller software (managed by HEIDENHAIN)
- **ICTL1 and ICTL3:** Number of the current controller software (managed by HEIDENHAIN)



17.3 Entering Code Numbers

Application

The TNC requires a code number for the following functions:

Function	Code number
Select user parameters	123
Configure an Ethernet card (not iTNC 530 with Windows XP)	NET123
Enable special functions for Q parameter programming	555343

In addition, you can use the keyword **version** to create a file containing all current software numbers of your control:

- ▶ Enter the keyword **version** and confirm with the ENT key
- ▶ The TNC displays all current software numbers on the screen
- ▶ To terminate the version overview, press the END key



If necessary, you can output the file **version.a** saved in the directory TNC:, and send it to your machine manufacturer or HEIDENHAIN for diagnostic purposes.



17.4 Loading Service Packs

Application



We strongly recommend contacting your machine tool builder before you install a service pack.

The TNC restarts the system after the installation procedure is completed. Before loading the service pack, put the machine in the EMERGENCY STOP condition.

Connect the network drive from which you want to import the service pack (if not already done).

This function provides a simple way of updating the software of your TNC

- ▶ Select the **Programming and Editing** operating mode.
- ▶ Press the MOD key.
- ▶ To start the software update, press the “Load Service Pack” soft key. The TNC then displays a pop-up window for selecting the update file.
- ▶ Use the arrow keys to select the directory in which the service pack is stored. The respective subdirectories can be shown by pressing the ENT key.
- ▶ To select the file: Press the ENT key twice on the selected directory. The TNC switches from the directory window to the file window.
- ▶ To start the updating process, press the ENT key to select the file. The TNC unpacks all required files and then restarts the control. This process may take several minutes.



17.5 Setting the Data Interfaces

Application

To set up the data interfaces, press the RS-232 / RS-422 SETUP soft key to call a menu for setting the data interfaces:


Setting the RS-232 interface


The mode of operation and baud rates for the RS-232 interface are entered in the upper left of the screen.

Setting the RS-422 interface

The mode of operation and baud rates for the RS-422 interface are entered in the upper right of the screen.




Setting the OPERATING MODE of the external device



 The functions "Transfer all files," "Transfer selected file," and "Transfer directory" are not available in the operating mode EXT.

Setting the baud rate

You can set the BAUD RATE (data transfer speed) from 110 to 115 200 baud.

External device	Operating mode	Symbol
PC with HEIDENHAIN data transfer software TNCremoNT	FE1	
HEIDENHAIN floppy disk units FE 401 B FE 401 from program no. 230 626-03	FE1 FE1	
Non-HEIDENHAIN devices such as printers, scanners, punchers, PC without TNCremoNT	EXT1, EXT2	



Assignment

This function sets the destination for the transferred data.

Applications:

- Transferring values with Q parameter function FN15
- Transferring values with Q parameter function FN16

The TNC mode of operation determines whether the PRINT or PRINT TEST function is used:

TNC mode of operation	Transfer function
Program Run, Single Block	PRINT
Program Run, Full Sequence	PRINT
Test Run	PRINT TEST

You can set PRINT and PRINT TEST as follows:

Function	Path
Output data via RS-232	RS232:\...
Output data via RS-422	RS422:\...
Save data to the TNC's hard disk	TNC:\...
Save data to a server connected to the TNC	servername:\...
Save the data in the same directory as the program with FN15/FN16.	Vacant

File names

Data	Operating mode	File name
Values with D15	Program Run	%FN15RUN.A
Values with D15	Test Run	%FN15SIM.A



Software for data transfer

For transfer of files to and from the TNC, we recommend using the HEIDENHAIN TNCremoNT data transfer software. With TNCremoNT, data transfer is possible with all HEIDENHAIN controls via the serial interface or the Ethernet interface.



You can download the current version of TNCremoNT free of charge from the HEIDENHAIN Filebase (www.heidenhain.de, <Services and Documentation>, <Software>, <PC Software>, <TNCremoNT>).

System requirements for TNCremoNT:

- PC with 486 processor or higher
- Operating system Windows 95, Windows 98, Windows NT 4.0, Windows 2000, Windows XP, Windows Vista
- 16 MB RAM
- 5 MB free memory space on your hard disk
- An available serial interface or connection to the TCP/IP network

Installation under Windows

- ▶ Start the SETUP.EXE installation program with the File Manager (Explorer)
- ▶ Follow the setup program instructions

Starting TNCremoNT under Windows

- ▶ Click <Start>, <Programs>, <HEIDENHAIN Applications>, <TNCremoNT>

When you start TNCremoNT for the first time, TNCremoNT automatically tries to set up a connection with the TNC.



Data transfer between the TNC and TNCremoNT



Before you transfer a program from the TNC to the PC, you must make absolutely sure that you have already saved the program currently selected on the TNC. The TNC saves changes automatically when you switch the mode of operation on the TNC, or when you select the file manager via the PGM MGT key.

Check whether the TNC is connected to the correct serial port on your PC or to the network.

Once you have started TNCremoNT, you will see a list of all files that are stored in the active directory in the upper section of the main window **1**. Using the menu items <File> and <Change directory>, you can change the active directory or select another directory on your PC.

If you want to control data transfer from the PC, establish the connection with your PC in the following manner:

- ▶ Select <File>, <Setup connection>. TNCremoNT now receives the file and directory structure from the TNC and displays this at the bottom left of the main window **2**
- ▶ To transfer a file from the TNC to the PC, select the file in the TNC window with a mouse click and drag and drop the highlighted file into the PC window **1**
- ▶ To transfer a file from the PC to the TNC, select the file in the PC window with a mouse click and drag and drop the highlighted file into the TNC window **2**

If you want to control data transfer from the TNC, establish the connection with your PC in the following manner:


- ▶ Select <Extras>, <TNCserver>. TNCremoNT is now in server mode. It can receive data from the TNC and send data to the TNC
- ▶ You can now call the file management functions on the TNC by pressing the PGM MGT key (see "Data transfer to or from an external data medium" on page 134) and transfer the desired files

Exiting TNCremoNT

Select the menu items <File>, <Exit>



Refer also to the TNCremoNT context-sensitive help texts where all of the functions are explained in more detail. The help texts must be called with the F1 key.



17.6 Ethernet Interface

Introduction

The TNC is shipped with a standard Ethernet card to connect the control as a client in your network. The TNC transmits data via the Ethernet card with

- the **smb** protocol (**s**erver **m**essage **b**lock) for Windows operating systems, or
- the **TCP/IP** protocol family (Transmission Control Protocol/Internet Protocol) and with support from the NFS (Network File System). The TNC also supports the NFS V3 protocol, which permits higher data transfer rates

Connection possibilities


You can connect the Ethernet card in your TNC to your network through the RJ45 connection (X26, 100BaseTX or 10BaseT), or directly to a PC. The connection is metallically isolated from the control electronics.

For a 100BaseTX or 10BaseT connection you need a Twisted Pair cable to connect the TNC to your network.



The maximum cable length between TNC and a node depends on the quality grade of the cable, the sheathing and the type of network (100BaseTX or 10BaseT).

If you connect the TNC directly with a PC, you must use a crossed cable.



Connecting the iTNC directly with a Windows PC




You don't need any large effort or special networking knowledge to attach the iTNC 530 directly to a PC that has an Ethernet card. You simply have to enter some settings on the TNC and the corresponding settings on the PC.

Settings on the iTNC

- ▶ Connect the iTNC (connection X26) and the PC with a crossed Ethernet cable (trade names: crossed patch cable or STP cable)
- ▶ In the Programming and Editing mode of operation, press the MOD key. Enter the keyword NET123. The iTNC will then display the main screen for network configuration (see figure at top right)
- ▶ Press the DEFINE NET soft key to enter the network setting for a specific device (see figure at center right).
- ▶ Enter any network address. Network addresses consist of four numbers separated by periods, e.g. **160.1.180.23**
- ▶ Press the right arrow key to select the next column, and enter the subnet mask. The subnet mask also consists of four numbers separated by periods, e.g. **255.255.0.0**
- ▶ Press the END key to leave the network configuration screen.
- ▶ Press the DEFINE MOUNT soft key to enter the network settings for a specific PC (see figure at bottom right).
- ▶ Define the PC name and drive that you want to access, beginning with two slashes, e.g. **//PC3444/C**
- ▶ Press the right arrow key to select the next column, and enter the name that the iTNC's file manager uses to display the PC, e.g. **PC3444**:
- ▶ Press the right arrow key to select the next column, and enter the file system type **smb**
- ▶ Press the right arrow key to select the next column and enter the following information (depending on the PC operating system):
ip=160.1.180.1,username=abcd,workgroup=SALES,password=uvwx
- ▶ To exit the network configuration, press the END key twice. The iTNC restarts automatically



Not all Windows operating systems require entry of the **username**, **workgroup** and **password** parameters.



Settings on a PC with Windows XP




Prerequisite:

The network card must already be installed on the PC and ready for operation.

If the PC that you want to connect the iTNC to is already integrated in your company network, then keep the PC's network address and adapt the TNC's network address accordingly.

- ▶ To open the Network Connections, click <Start> and then <Network Connections>
- ▶ Right-click the <LAN connection> symbol, and then <Properties> in the menu that appears.
- ▶ Double-click <Internet Protocol (TCP/IP)> to change the IP settings (see figure at top right)
- ▶ If it is not yet active, select the <Use the following IP address> option.
- ▶ In the <IP address> input field, enter the same IP address that you entered for the PC network settings on the iTNC, e.g. 160.1.180.1
- ▶ Enter 255.255.0.0 in the <Subnet mask> input field
- ▶ Confirm the settings with <OK>.
- ▶ Save the network configuration with <OK>. You may have to restart Windows now.



Configuring the TNC




To configure the dual-processor version: See “Network Settings” on page 622.

Make sure that the person configuring your TNC is a network specialist.

Please note that the TNC performs an automatic restart if you change the IP address of the TNC.

- ▶ In the Programming and Editing mode of operation, press the MOD key. Enter the keyword NET123. The TNC will then display the main screen for network configuration





General network settings

- ▶ Press the DEFINE NET soft key to enter the general network settings. The **Computer name** tab is active:

Setting	Meaning
Primary interface	Name of the Ethernet interface to be integrated in your company network. Only active if a second, optional Ethernet interface is available on the control hardware
Computer name	Name displayed for the TNC in your company network
Host file	Only required for special applications: Name of a file in which the assignments of IP addresses to computer names is defined


- ▶ Select the **Interfaces** tab to enter the interface settings:

Setting	Meaning
Interface list	List of the active Ethernet interfaces. Select one of the listed interfaces (via mouse or arrow keys) <ul style="list-style-type: none"> ■ Activate button: Activate the selected interface (an X appears in the Active column) ■ Deactivate button: Deactivate the selected interface (a hyphen (-) appears in the Active column) ■ Configuration button: Open the Configuration menu
IP forwarding	This function must be kept deactivated. Only activate this function if external access via the second, optional Ethernet interface of the TNC is necessary for diagnostic purposes. Only do so after instruction by our Service department



► Press the **Configuration** button to open the Configuration menu:

Setting	Meaning
Status	<ul style="list-style-type: none"> ■ Interface active: Connection status of the selected Ethernet interface ■ Name: Name of the interface you are currently configuring ■ Plug connection: Number of the plug connection of this interface on the logic unit of the control.
Profile	<p>Here you can create or select a profile in which all settings shown in this window are stored. HEIDENHAIN provides two standard profiles:</p> <ul style="list-style-type: none"> ■ LAN-DHCP: Settings for the standard TNC Ethernet interface, should work in a standard company network. ■ MachineNet: Settings for the second, optional Ethernet interface; for configuration of the machine network <p>Press the corresponding buttons to save, load and delete profiles</p>
IP address	<ul style="list-style-type: none"> ■ Automatically procure IP address option: The TNC is to procure the IP address from the DHCP server ■ Set the IP address manually option: Manually define the IP address and subnet mask. Input: Four numerical values separated by points, in each field, e.g. 160.1.180.20 and 255.255.0.0




Setting	Meaning
Domain Name Server (DNS)	<ul style="list-style-type: none">■ Automatically procure DNS option: The TNC is to automatically procure the IP address of the domain name server■ Manually configure the DNS option: Manually enter the IP addresses of the servers and the domain name
Default gateway	<ul style="list-style-type: none">■ Automatically procure default gateway option: The TNC is to automatically procure the default gateway■ Manually configure the default gateway option: Manually enter the IP addresses of the default gateway

- ▶ Apply the changes with the **OK** button, or discard them with the **Cancel** button



- ▶ The **Internet** tab currently has no function.
- ▶ Select the **Ping/Routing** tab to enter the ping and routing settings:


Setting	Meaning
Ping	<p>In the Address: field, enter the IP number for which you want to check the network connection. Input: Four numerical values separated by periods, e.g. 160.1.180.20. As an alternative, you can enter the name of the computer whose connection you want to check</p> <ul style="list-style-type: none"> ■ Press the Start button to begin the test. The TNC shows the status information in the Ping field ■ Press the Stop button to conclude the test
Routing	<p>For network specialists: Status information of the operating system for the current routing</p> <ul style="list-style-type: none"> ■ Update button: Update routing



Network settings specific to the device

▶ Press the DEFINE MOUNT soft key to enter the network settings for a specific device. You can define any number of network settings, but you can manage only seven at one time

Setting	Meaning
MOUNTDEVICE	<ul style="list-style-type: none"> ■ Connection via NFS: Name of the directory that is to be logged on. This is formed by the network address of the server, a colon and the name of the directory to be mounted. Input: Four numerical values separated by periods, ask your network specialist for the proper value, e.g. 160.1.13.4:/PGM directory of the NFS server that you wish to connect to the TNC. Be sure to differentiate between small and capital letters when entering the path ■ Connection via smb: Enter the network name and the share name of the computer, e.g. //PC1791NT/C
MOUNTPOINT	Name that the TNC shows in the file manager for a connected device. Remember that the name must end with a colon. Maximum length = 8 characters; the special characters <code>_ - \$ % & #</code> are permitted
FILESYSTEMTYPE	File system type. NFS: Network File System SMB: Server Message Block (Windows protocol)
OPTIONS for FILESYSTEMTYPE =nfs	<p>Data without spaces, separated by commas, and written in sequence. Switch between upper and lower case letters.</p> <p>RSIZE=: Packet size in bytes for data reception. Input range: 512 to 8192</p> <p>WSIZE=: Packet size in bytes for data transmission. Input range: 512 to 8192</p> <p>TIME0=: Time in tenths of a second, after which the TNC repeats a Remote Procedure Call not answered by the server. Input range: 0 to 100 000. If there is no entry, the standard value 7 is used. Use higher values only if the TNC must communicate with the server through several routers. Ask your network specialist for the proper value.</p> <p>SOFT=: Definition of whether the TNC should repeat the Remote Procedure Call until the NFS server answers. "soft" entered: Do not repeat the Remote Procedure Call. "soft" not entered: Always repeat the Remote Procedure Call.</p>



Setting	Meaning
OPTIONS for FILESYSTEMTYPE =smb for direct connection to Windows networks	Data without spaces, separated by commas, and written in sequence. Switch between upper and lower case letters. ip= : IP address of PC to which the TNC is to be connected username= : User name under which the TNC is to log on workgroup= : Work group under which the TNC is to log on password= : Password with which the TNC is to log on (up to 80 characters)
AM	Definition of whether the TNC upon switch-on should automatically connect with the network drive. 0: Do not automatically connect 1: Connect automatically



The entries **username**, **workgroup** and **password** in the OPTIONS column may not be necessary in Windows 95 and Windows 98 networks.

With the ENCODE PASSWORD soft key, you can encode the password defined under OPTIONS.



Defining a network identification

- ▶ Press the DEFINE UID / GID soft key to enter the network identification.


Setting	Meaning
TNC USER ID	Definition of which user identification the end user uses to access files in the network. Ask your network specialist for the proper value.
OEM USER ID	Definition of which user identification the machine tool builder uses to access files in the network. Ask your network specialist for the proper value.
TNC GROUP ID	Definition of the group identification with which you access files in the network. Ask your network specialist for the proper value. The group identification is the same for end users and machine manufacturers.
UID for mount	Defines the user identification (UID) for the log-on procedure. USER: The user logs on with the USER identification. ROOT: The user logs on with the ID of the ROOT user, value = 0.

Test network connection

- ▶ Press the PING soft key.
- ▶ In the **HOST** line, enter then internet address of the computer for which you want to check the network connection.
- ▶ Confirm your entry with the ENT key. The TNC transmits data packets until you exit the test monitor by pressing the END key.

In the **TRY** line the TNC shows the number of data packets that were transmitted to the previously defined addressee. Behind the number of transmitted data packets the TNC shows the status:

Status display	Meaning
HOST RESPOND	Data packet was received again, connection is OK
TIMEOUT	Data packet was not received, check the connection
CAN NOT ROUTE	Data packet could not be transmitted. Check the Internet address of the server and of the router to the TNC



17.7 Configuring PGM MGT

Application

Use the MOD functions to specify which directories or files are to be displayed by the TNC:

- **PGM MGT** setting: Choose the new, mouse-operated file manager, or the old file manager
- **Dependent files** setting: Specify whether dependent files are displayed. The **Manual** setting shows dependent files, the **Automatic** setting does not



For more information: See “Working with the File Manager” on page 116.

Changing the PGM MGT setting

- ▶ Press the MOD key to select the MOD function.
- ▶ Press the SETUP RS232 RS422 soft key.
- ▶ To select the PGM MGT setting: Using the arrow keys, move the highlight onto the **PGM MGT** setting and use the ENT key to switch between **ENHANCED 1** and **ENHANCED 2**

The new file manager (**Enhanced 2** setting) offers the following benefits:

- The mouse can be used for all operations, in addition to the keyboard
- Sorting function available
- Text input moves the cursor to the next possible file name
- Favorites management.
- Possibility of configuring the information to be displayed
- The date format can be set
- Flexible setting of window sizes
- Keyboard commands for easy operation



Dependent files

In addition to the file extension, dependent files also have the extension **.SEC.DEP** (**SEC**tion, **DEP**endent). The following different types are available:

- **.H.SEC.DEP**
The TNC creates files with the **.SEC.DEP** extension if you work with the structure function. The file contains information needed by the TNC to rapidly jump from one structure point to the next.
- **.T.DEP**: Tool usage file for individual conversational-format programs (see "Tool usage test" on page 183)
- **.P.T.DEP**: Tool usage file for a complete pallet
The TNC creates files with the **.P.T.DEP** ending if, in a Program Run mode, you run the tool usage test (see "Tool usage test" on page 183) for a pallet entry of the active pallet file. This file then lists the sum of all tool usage times of all tools that you use within a pallet.
- **.H.AFC.DEP**: File in which the TNC saves the control parameters for the adaptive feed control (AFC) (see "Adaptive Feed Control Software Option (AFC)" on page 366).
- **.H.AFC2.DEP**: File in which the TNC saves the statistical data of the adaptive feed control (AFC) (see "Adaptive Feed Control Software Option (AFC)" on page 366).

Changing the MOD setting for dependent files

- ▶ To select the file manager in the Programming and Editing mode of operation, press the PGM MGT key.
- ▶ Press the MOD key to select the MOD function.
- ▶ To select the Dependent files setting: Using the arrow keys, move the highlight onto the **Dependent files** setting and use the ENT key to switch between **AUTOMATIC** and **MANUAL**.



Dependent files are only visible in the file manager if you selected the **MANUAL** setting.

If dependent files exist for a file, then the TNC displays a + character in the status column of the file manager (only if **Dependent files** is set to **AUTOMATIC**).



17.8 Machine-Specific User Parameters

Application

To enable you to set machine-specific functions, your machine tool builder can define up to 16 machine parameters as user parameters.



This function is not available on all TNCs. Refer to your machine tool manual.



17.9 Showing the Workpiece in the Working Space

Application

This MOD function enables you to graphically check the position of the workpiece blank in the machine's working space and to activate work space monitoring in the Test Run mode of operation.

The TNC displays a transparent cuboid for the working space. Its dimensions are shown in the **Traverse range** table (default color is green). The TNC takes the dimensions for the working space from the machine parameters for the active traverse range. Since the traverse range is defined in the reference system of the machine, the datum of the cuboid is also the machine datum. You can see the position of the machine datum in the cuboid by pressing the soft key M91 in the 2nd soft-key row (default color is white).


Another transparent cuboid represents the workpiece blank. Its dimensions are shown in the **BLK FORM** table (default color is blue). The TNC takes the dimensions from the workpiece blank definition of the selected program. The workpiece cuboid defines the coordinate system for input. Its datum lies within the traverse-range cuboid. You can view the position of the active datum within the traverse range by pressing the "Show workpiece datum" soft key (2nd soft-key row).

For a test run it normally does not matter where the workpiece blank is located within the working space. However, if you test programs that contain movements with M91 or M92, you must graphically shift the workpiece blank to prevent contour damage. Use the soft keys shown in the following table.















If you want to perform a graphical collision test (software option), you may need to graphically shift the reference point in such a manner that no collision warnings are generated.

Press the "Show the workpiece datum in the working space" soft key to see the position of the workpiece blank in the machine coordinate system. You must then place your workpiece at these coordinates on the machine table in order to ensure the same conditions during machining as during the collision test.







17.9 Showing the Workpiece in the Working Space

You can also activate the working-space monitor for the Test Run mode in order to test the program with the current datum and the active traverse ranges (see table below, last line).

Function	Soft key
Move workpiece blank to the left	
Move workpiece blank to the right	
Move workpiece blank forward	
Move workpiece blank backward	
Move workpiece blank upward	
Move workpiece blank downward	
Show workpiece blank referenced to the set datum	
Show the entire traversing range referenced to the displayed workpiece blank	
Show the machine datum in the working space	
Show a position determined by the machine tool builder (e.g. tool change position) in the working space	
Show the workpiece datum in the working space	
Enable (ON) or disable (OFF) working-space monitoring during test run	

Rotate the entire image

The third soft-key row provides functions with which you can rotate and tilt the entire image:

Function	Soft keys
Rotate the image about the vertical axis	 
Tilt the image about the horizontal axis	 

17.10 Position Display Types

Application

In the Manual Operation mode and in the Program Run modes of operation, you can select the type of coordinates to be displayed.

The figure at right shows the different tool positions:


- Starting position
- Target position of the tool
- Workpiece datum
- Machine datum

The TNC position displays can show the following coordinates:

Function	Display
Actual position; current tool position	ACTL.
Reference position; the actual position relative to the machine datum	REF
Servo lag; difference between nominal and actual positions (following error)	LAG
Nominal position: the value presently commanded by the TNC	NOML
Distance remaining to the programmed position in the machine coordinate system; difference between actual and target positions	DIST.
Distance remaining to the programmed position in the active (tilted, where appropriate) coordinate system; difference between actual and target positions	DG 3D
Traverses that were carried out with handwheel superimpositioning (M118) (only Position display 2)	M118

With the MOD function Position display 1, you can select the position display in the status display.

With Position display 2, you can select the position display in the additional status display.



17.11 Unit of Measurement

Application

This MOD function determines whether the coordinates are displayed in millimeters (metric system) or inches.

- To select the metric system (e.g. $X = 15.789$ mm), set the Change mm/inches function to mm. The value is displayed to 3 decimal places.
- To select the inch system (e.g. $X = 0.6216$ inches), set the Change mm/inches function to inches. The value is displayed to 4 decimal places.

If you would like to activate the inch display, the TNC shows the feed rate in inch/min. In an inch program you must enter the feed rate larger by a factor of 10.



17.12 Selecting the Programming Language for \$MDI

Application

The Program input MOD function lets you decide whether to program the \$MDI file in HEIDENHAIN conversational dialog or in ISO format.

- To program the \$MDI.H file in conversational dialog, set the Program input function to HEIDENHAIN
- To program the \$MDI.I file according to ISO, set the Program input function to ISO



17.13 Selecting the Axes for Generating G01 Blocks

Application

The axis selection input field enables you to define the current tool position coordinates that are transferred to the **G01** block. To generate a separate **G01** block, press the ACTUAL POSITION CAPTURE key. The axes are selected by bit-oriented definition similar to programming the machine parameters:

Axis selection %11111: Transfer the X, Y, Z, IV, and V axes

Axis selection %01111: Transfer the X, Y, Z, and IV axes

Axis selection %00111: Transfer the X, Y and Z axes

Axis selection %00011: Transfer the X and Y axes

Axis selection %00001: Transfer the X axis




17.14 Entering the Axis Traverse Limits, Datum Display

Application

The AXIS LIMIT MOD function allows you to set limits to axis traverse within the machine's actual working envelope.

Possible application: Protecting an indexing fixture against tool collision.

The maximum range of traverse of the machine tool is defined by software limit switches. This range can be additionally limited through the TRAVERSE RANGE MOD function. With this function, you can enter the maximum and minimum traverse positions for each axis, referenced to the machine datum. If several traverse ranges are possible on your machine, you can set the limits for each range separately using the soft keys TRAVERSE RANGE (1) to TRAVERSE RANGE (3).



Working without additional traverse limits

To allow a machine axis to use its full range of traverse, enter the maximum traverse of the TNC (+/- 99 999 mm) as the TRAVERSE RANGE.

Find and enter the maximum traverse


- ▶ Set the Position display MOD function to REF.
- ▶ Move the spindle to the positive and negative end positions of the X, Y and Z axes
- ▶ Write down the values, including the algebraic sign
- ▶ To select the MOD functions, press the MOD key.

- ▶ Enter the limits for axis traverse: Press the TRAVERSE RANGE soft key and enter the values that you wrote down as limits in the corresponding axes
- ▶ To exit the MOD function, press the END soft key.



Active tool radius compensations are not taken into account in the axis traverse limit values.

The traverse range limits and software limit switches become active as soon as the reference points are traversed.



Datum display

The values shown at the top right of the screen define the currently active datum. The datum can have been set manually or can have been activated from the preset table. The datum cannot be changed in the screen menu.



The displayed values depend on your machine configuration. Refer to the notes in Chapter 2 (see “Explanation of values saved in the preset table” on page 470).



17.15 Displaying HELP Files

Application

Help files can aid you in situations in which you need clear instructions before you can continue (for example, to retract the tool after an interruption of power). The miscellaneous functions may also be explained in a help file. The figure at right shows the screen display of a help file.




HELP files are not provided on every machine. Your machine tool builder can provide you with further information on this feature.

Selecting HELP files

- ▶ Press the MOD key to select the MOD function.



- ▶ To select the last active HELP file, press the HELP soft key.
- ▶ Call the file manager (PGM MGT key) and select a different help file, if necessary.



17.16 Displaying Operating Times

Application


The MACHINE TIME soft key enables you to see various types of operating times:

Operating time	Meaning
Control on	Operating time of the control since being put into service
Machine on	Operating time of the machine tool since being put into service
Program run	Duration of controlled operation since being put into service



The machine tool builder can provide further operating time displays. Refer to your machine tool manual.

At the bottom of the screen you can enter a code number to have the TNC reset the displayed times. The machine tool builder defines exactly which times the TNC resets, so refer to your machine manual for more information.



17.17 Checking the Data Carrier

Application

Press the CHECK THE FILE SYSTEM soft key to check the TNC and PLC partitions on the hard disk, and have them automatically be repaired if necessary.



The TNC's system partition is automatically checked each time the control is started. If any errors are found on the system partition, the TNC reports this with an error message.

Performing the data carrier check



Danger of collision!

Before starting the data carrier check, put the machine in the EMERGENCY STOP condition. The TNC restarts the software before performing the check!

- ▶ Press the MOD key to select the MOD function.



- ▶ To select the diagnostic functions, press the DIAGNOSIS soft key



- ▶ To start the data carrier test, press the CHECK THE FILE SYSTEM soft key
- ▶ Press the YES soft key again to confirm that the check should be started. This function shuts down the TNC software and starts checking the data carrier. This check can take some time, depending on the number and size of the files that you have stored on the hard disk
- ▶ At the end of the test the TNC displays a window with the results of the test. The TNC also writes the results to the system log
- ▶ In order to restart the TNC software, press the ENT key



17.18 Setting the System Time

Application

You can set the time zone, the date and the system time with the SET DATE/TIME soft key.


Selecting appropriate settings



The TNC must be reset after you change the time zone, date or system time. In such cases the TNC displays a warning when the window closes.

- ▶ Press the MOD key to select the MOD function.
- ▶ Scroll through the soft-key row.
 - ▶ To display the time zone window, press the SET TIME ZONE soft key.
 - ▶ In the right side under "time zone," click your correct time zone.
 - ▶ In the left side of the pop-up window, use the mouse to set the year, month and date.
 - ▶ If required, edit the time of day through the keyboard.
 - ▶ To save the settings, click the **OK** button.
 - ▶ To discard the changes and cancel the dialog, click the **Cancel** button.

SET
DATE/
TIME



17.19 TeleService

Application



The TeleService functions are enabled and adapted by the machine tool builder. Refer to your machine tool manual for more information.

The TNC provides two soft keys for TeleService, making it possible to configure two different service agencies.

The TNC allows you to carry out TeleService. To be able to use this feature, your TNC should be equipped with an Ethernet card which achieves a higher data transfer rate than the serial RS232-C interface.

With the HEIDENHAIN TeleService software, your machine tool builder can then establish a connection to the TNC via an ISDN modem and carry out diagnostics. The following functions are available:


- On-line screen transfer
- Polling of machine states
- Data transfer
- Remote control of the TNC

Calling/exiting TeleService

- ▶ Select any machine mode of operation
- ▶ Press the MOD key to select the MOD function.



- ▶ Establish a connection to the service agency: Set the SERVICE or SUPPORT soft key to ON. The TNC breaks the connection automatically if no new data have been transferred for a time set by the machine tool builder (default: 15 min)
- ▶ To break the connection to the service agency: Set the SERVICE or SUPPORT soft key to OFF. The TNC terminates the connection after approx. one minute



17.20 External Access

Application



The machine tool builder can configure teleservice settings with the LSV-2 interface. Refer to your machine tool manual for more information.

The soft key SERVICE can be used to grant or restrict access through the LSV-2 interface.

With an entry in the configuration file TNC.SYS you can protect a directory and its subdirectories with a password. The password is requested when data from this directory is accessed from the LSV-2 interface. Enter the path and password for external access in the configuration file TNC.SYS.



The TNC.SYS file must be stored in the root directory TNC:\.

If you only supply one entry for the password, then the entire drive TNC:\ is protected.

You should use the updated versions of the HEIDENHAIN software TNCremo or TNCremoNT to transfer the data.

Entries in TNC.SYS	Meaning
REMOTE.PERMISSION=	Permit LSV-2 access only for defined computers. Define the list of computer names.
REMOTE.TNCPASSWORD=	Password for LSV-2 access
REMOTE.TNCPRIVATEPATH=	Path to be protected



Example of TNC.SYS

```
REMOTE.PERMISSION=PC2225;PC3547
```

```
REMOTE.TNCPASSWORD=KR1402
```

```
REMOTE.TNCPRIVATEPATH=TNC:\RK
```

Permitting/Restricting external access

- ▶ Select any machine mode of operation
- ▶ Press the MOD key to select the MOD function.



- ▶ Permit a connection to the TNC: Set the EXTERNAL ACCESS soft key to ON. The TNC will then permit data access through the LSV-2 interface. The password is requested when a directory that was entered in the configuration file TNC.SYS is accessed
- ▶ Block connections to the TNC: Set the EXTERNAL ACCESS soft key to OFF. The TNC will then block access through the LSV-2 interface



17.21 Configuring the HR 550 FS Wireless Handwheel

Application

Press the SET UP WIRELESS HANDWHEEL soft key to configure the HR 550 FS wireless handwheel. The following functions are available:


- Assigning the handwheel to a specific handwheel holder
- Setting the transmission channel
- Analyzing the frequency spectrum for determining the optimum transmission channel
- Selecting the transmitter power
- Statistical information on the transmission quality

Assigning the handwheel to a specific handwheel holder

- ▶ Make sure that the handwheel holder is connected to the control hardware.
- ▶ Place the wireless handwheel you want to assign to the handwheel holder in the handwheel holder
- ▶ Press the MOD key to select the MOD function.
- ▶ Scroll through the soft-key row.

SET UP
WIRELESS
HANDWHEEL

- ▶ Select the configuration menu for the wireless handwheel: Press the SET UP WIRELESS HANDWHEEL soft key.
- ▶ Click the **Connect HR** button: The TNC saves the serial number of the wireless handwheel located in the handwheel holder and shows it in the configuration window to the left of the **Connect HR** button.
- ▶ To save the configuration and exit the configuration menu, press the **END** button.





Setting the transmission channel

If the wireless handwheel is started automatically, the TNC tries to select the transmission channel supplying the best transmission signal. If you want to set the transmission channel manually, proceed as follows:

- ▶ Press the MOD key to select the MOD function.
- ▶ Scroll through the soft-key row.

SET UP
WIRELESS
HANDWHEEL

- ▶ Select the configuration menu for the wireless handwheel: Press the SET UP WIRELESS HANDWHEEL soft key.
- ▶ Click the **Frequency spectrum** tab.
- ▶ Click the **Stop HR** button: The TNC stops the connection to the wireless handwheel and determines the current frequency spectrum for all of the 16 available channels.
- ▶ Memorize the number of the channel with the least amount of radio traffic (smallest bar)
- ▶ Click the **Start handwheel** button to reactivate the wireless handwheel.
- ▶ Click the **Properties** tab.
- ▶ Click the **Select channel** button: The TNC shows all available channel numbers. Click the channel number for which the TNC determined the least amount of radio traffic.
- ▶ To save the configuration and exit the configuration menu, press the **END** button.



Selecting the transmitter power



Please keep in mind that the transmission range of the wireless handwheel decreases when the transmitter power is reduced.

- ▶ Press the MOD key to select the MOD function.
- ▶ Scroll through the soft-key row.

SET UP
WIRELESS
HANDWHEEL

- ▶ Select the configuration menu for the wireless handwheel: Press the SET UP WIRELESS HANDWHEEL soft key.
- ▶ Click the **Set power** button: The TNC shows the three available power settings. Click the desired setting.
- ▶ To save the configuration and exit the configuration menu, press the **END** button.

Statistics

Under **Statistics**, the TNC displays information about the transmission quality.

If the reception quality is poor so that a proper and safe stop of the axes cannot be ensured anymore, an emergency-stop reaction of the wireless handwheel is triggered.

The displayed value **Max. successive lost** indicates whether reception quality is poor. If the TNC repeatedly displays values greater than 2 during normal operation of the wireless handwheel within the desired range of use, then there is a risk of an undesired disconnection. This can be corrected by increasing the transmitter power or by changing to another channel with less radio traffic.



If this occurs, try to improve the transmission quality by selecting another channel (see "Setting the transmission channel" on page 581) or by increasing the transmitter power (see "Selecting the transmitter power" on page 582).

To display the statistical data, proceed as follows:

- ▶ Press the MOD key to select the MOD function.
- ▶ Scroll through the soft-key row.

SET UP
WIRELESS
HANDWHEEL

- ▶ To select the configuration menu for the wireless handwheel, press the SET UP WIRELESS HANDWHEEL soft key: The TNC displays the configuration menu with the statistical data.



e editieren

	F1	Vc2	F2
	0,016	55	0,020
	0,016	55	0,020
	0,200	130	0,250
	0,025	45	0,030
	0,016	55	0,020
	0,200	130	0,250
	0,016	55	0,020
	0,016	55	0,020
	0,200	130	0,250
	0,016	55	0,020
	0,016	55	0,020
	0,200	130	0,250
	0,016	55	0,020
	0,016	55	0,020
	0,200	130	0,250
	0,040	45	0,020
	0,040	35	0,020
	0,040	100	0,020
	0,040	35	0,020
	0,040	25	0,020

18

Tables and Overviews



18.1 General User Parameters

General user parameters are machine parameters affecting TNC settings that the user may want to change in accordance with his requirements.

Some examples of user parameters are:

- Dialog language
- Interface behavior
- Traversing speeds
- Sequence of machining
- Effect of overrides

Input possibilities for machine parameters

Machine parameters can be programmed as

- **Decimal numbers**
Enter only the number
- **Pure binary numbers**
Enter a percent sign (%) before the number
- **Hexadecimal numbers**
Enter a dollar sign (\$) before the number

Example:

Instead of the decimal number 27 you can also enter the binary number %11011 or the hexadecimal number \$1B.

The individual machine parameters can be entered in the different number systems.

Some machine parameters have more than one function. The input value for these machine parameters is the sum of the individual values. For these machine parameters the individual values are preceded by a plus sign.

Selecting general user parameters

General user parameters are selected with code number 123 in the MOD functions.



The MOD functions also include machine-specific user parameters.



List of general user parameters

External data transfer

Adjusting TNC interfaces EXT1 (5020.0) and EXT2 (5020.1) to an external device

MP5020.x

7 data bits (ASCII code, 8th bit = parity): **Bit 0 = 0**8 data bits (ASCII code, 9th bit = parity): **Bit 0 = 1**Block Check Character (BCC) any: **Bit 1 = 0**Block Check Character (BCC) control character not permitted: **Bit 1 = 1**Transmission stop through RTS active: **Bit 2 = 1**Transmission stop through RTS inactive: **Bit 2 = 0**Transmission stop through DC3 active: **Bit 3 = 1**Transmission stop through DC3 inactive: **Bit 3 = 0**Character parity even: **Bit 4 = 0**Character parity odd: **Bit 4 = 1**Character parity undesired: **Bit 5 = 0**Character parity desired: **Bit 5 = 1**

Number of stop bits that are transmitted at the end of a character:

1 stop bit: **Bit 6 = 0**2 stop bits: **Bit 6 = 1**1 stop bit: **Bit 7 = 1**1 stop bit: **Bit 7 = 0**

Example:

Use the following setting to adjust the TNC interface EXT2 (MP 5020.1) to an external non-HEIDENHAIN device:

8 data bits, any BCC, transmission stop through DC3, even character parity, character parity desired, 2 stop bits

Input for **MP 5020.1: %01101001**

Interface type for EXT1 (5030.0) and EXT2 (5030.1)

MP5030.x

Standard transmission: **0**Interface for blockwise transfer: **1**

3-D touch probes

Select signal transmission

MP6010

Touch probe with cable transmission: **0**Touch probe with infrared transmission: **1**

Probing feed rate for triggering touch probes

MP6120

1 to **3 000** [mm/min]

Maximum traverse to first touch point

MP6130

0.001 to **99 999.9999** [mm]

Safety clearance to probing point during automatic measurement

MP6140

0.001 to **99 999.9999** [mm]

3-D touch probes	
Rapid traverse for triggering touch probes	MP6150 1 to 300 000 [mm/min]
Pre-position at rapid traverse	MP6151 Pre-position with speed from MP6150: 0 Pre-position at rapid traverse: 1
Measure center misalignment of the stylus when calibrating a triggering touch probe	MP6160 No 180° rotation of the 3-D touch probe during calibration: 0 M function for 180° rotation of the touch probe during calibration: 1 to 999
M function for orienting the infrared sensor before each measuring cycle	MP6161 Function inactive: 0 Orientation directly through the NC: -1 M function for orienting the touch probe: 1 to 999
Angle of orientation for the infrared sensor	MP6162 0 to 359.9999 [°]
Difference between the current angle of orientation and the angle of orientation set in MP 6162; when the entered difference is reached, an oriented spindle stop is to be carried out.	MP6163 0 to 3.0000 [°]
Automatic operation: Automatically orient the infrared sensor before probing to the programmed probing direction	MP6165 Function inactive: 0 Orient infrared sensor: 1
Manual operation: Compensate the probe direction taking an active basic rotation into account	MP6166 Function inactive: 0 Take basic rotation into account: 1
Multiple measurement for programmable probe function	MP6170 1 to 3
Confidence range for multiple measurement	MP6171 0.001 to 0.999 [mm]
Automatic calibration cycle: Center of the calibration ring in the X axis referenced to the machine datum	MP6180.0 (traverse range 1) to MP6180.2 (traverse range 3) 0 to 99 999.9999 [mm]
Automatic calibration cycle: Center of the calibration ring in the Y axis referenced to the machine datum	MP6181.x (traverse range 1) to MP6181.2 (traverse range 3) 0 to 99 999.9999 [mm]
Automatic calibration cycle: Upper edge of the calibration ring in the Z axis referenced to the machine datum	MP6182.x (traverse range 1) to MP6182.2 (traverse range 3) 0 to 99 999.9999 [mm]
Automatic calibration cycle: Distance below the upper edge of the ring where the calibration is carried out by the TNC	MP6185.x (traverse range 1) to MP6185.2 (traverse range 3) 0.1 to 99 999.9999 [mm]



3-D touch probes	
Radius measurement with the TT 130 touch probe: Probing direction	MP6505.0 (traverse range 1) to 6505.2 (traverse range 3) Positive probing direction in the angle reference axis (0° axis): 0 Positive probing direction in the +90° axis: 1 Negative probing direction in the angle reference axis (0° axis): 2 Negative probing direction in the +90° axis: 3
Probing feed rate for second measurement with TT 130, stylus shape, corrections in TOOL.T	MP6507 Calculate feed rate for second measurement with TT 130, with constant tolerance: Bit 0 = 0 Calculate feed rate for second measurement with TT 130, with variable tolerance: Bit 0 = 1 Constant feed rate for second measurement with TT 130: Bit 1 = 1
Maximum permissible measuring error with TT 130 during measurement with rotating tool Required for calculating the probing feed rate in connection with MP6570	MP6510.0 0.001 to 0.999 [mm] (recommended input value: 0.005 mm) MP6510.1 0.001 to 0.999 [mm] (recommended input value: 0.01 mm)
Feed rate for probing a stationary tool with the TT 130	MP6520 1 to 3 000 [mm/min]
Radius measurement with the TT 130: Distance from lower edge of tool to upper edge of stylus	MP6530.0 (traverse range 1) to MP6530.2 (traverse range 3) 0.001 to 99.9999 [mm]
Set-up clearance in the tool axis above the stylus of the TT 130 for pre-positioning	MP6540.0 0.001 to 30 000.000 [mm]
Clearance zone in the machining plane around the stylus of the TT 130 for pre-positioning	MP6540.1 0.001 to 30 000.000 [mm]
Rapid traverse for TT 130 in the probe cycle	MP6550 10 to 10 000 [mm/min]
M function for spindle orientation during individual tooth measurement	MP6560 0 to 999 -1: Function inactive
Measuring rotating tools: Permissible rotational speed at the circumference of the milling tool Required for calculating rpm and probe feed rate	MP6570 1.000 to 120.000 [m/min]
Measuring rotating tools: Permissible rotational rpm	MP6572 0.000 to 1000.000 [rpm] If you enter 0, the speed is limited to 1000 rpm



3-D touch probes	
Coordinates of the TT 120 stylus center relative to the machine datum	MP6580.0 (traverse range 1) X axis
	MP6580.1 (traverse range 1) Y axis
	MP6580.2 (traverse range 1) Z axis
	MP6581.0 (traverse range 2) X axis
	MP6581.1 (traverse range 2) Y axis
	MP6581.2 (traverse range 2) Z axis
	MP6582.0 (traverse range 3) X axis
	MP6582.1 (traverse range 3) Y axis
	MP6582.2 (traverse range 3) Z axis
Monitoring the position of rotary axes and parallel axes	MP6585 Function inactive: 0 Monitor axis positions, definable bit-coded for each axis: 1
Defining the rotary axes and parallel axes to be monitored	MP6586.0 Do not monitor the position of the A axis: 0 Monitor the position of the A axis: 1
	MP6586.1 Do not monitor the position of the B axis: 0 Monitor the position of the B axis: 1
	MP6586.2 Do not monitor the position of the C axis: 0 Monitor the position of the C axis: 1
	MP6586.3 Do not monitor the position of the U axis: 0 Monitor the position of the U axis: 1
	MP6586.4 Do not monitor the position of the V axis: 0 Monitor the position of the V axis: 1
	MP6586.5 Do not monitor the position of the W axis: 0 Monitor the position of the W axis: 1
KinematicsOpt: Tolerance limit for error message in Optimization mode	MP6600 0.001 to 0.999



3-D touch probes

KinematicsOpt: Maximum permitted deviation from entered calibration sphere radius **MP6601**
0.01 to 0.1

KinematicsOpt: M function for positioning rotary axes **MP6602**
 Function inactive: **-1**
 Position the rotary axis with a defined miscellaneous function: **0 to 9999**

TNC displays, TNC editor

Cycles 17, 18 and 207: Oriented spindle stop at beginning of cycle **MP7160**
 Oriented spindle stop: **0**
 No oriented spindle stop: **1**

Programming station **MP7210**
 TNC with machine: **0**
 TNC as programming station with active PLC: **1**
 TNC as programming station with inactive PLC: **2**

Acknowledgment of POWER INTERRUPTED after switch-on **MP7212**
 Acknowledge with key: **0**
 Acknowledge automatically: **1**

ISO programming: Set the block number increment **MP7220**
0 to 150

Disabling the selection of file types **MP7224.0**
 All file types selectable via soft key: **%0000000**
 Disable selection of HEIDENHAIN programs (soft key SHOW .H): **Bit 0 = 1**
 Disable selection of DIN/ISO programs (soft key SHOW .I): **Bit 1 = 1**
 Disable selection of tool tables (soft key SHOW .T): **Bit 2 = 1**
 Disable selection of datum tables (soft key SHOW .D): **Bit 3 = 1**
 Disable selection of pallet tables (soft key SHOW .P): **Bit 4 = 1**
 Disable selection of text files (soft key SHOW .A): **Bit 5 = 1**
 Disable selection of point tables (soft key SHOW .PNT): **Bit 6 = 1**

Disabling the editor for certain file types **MP7224.1**
 Do not disable editor: **%0000000**
 Disable editor for

Note:

If a particular file type is inhibited, the TNC will erase all files of this type.

- HEIDENHAIN programs: **Bit 0 = 1**
- ISO programs: **Bit 1 = 1**
- Tool tables: **Bit 2 = 1**
- Datum tables: **Bit 3 = 1**
- Pallet tables: **Bit 4 = 1**
- Text files: **Bit 5 = 1**
- Point tables: **Bit 6 = 1**



TNC displays, TNC editor

Locking soft key for tables	<p>MP7224.2 Do not lock the EDITING ON/OFF soft key: %0000000 Lock the EDITING ON/OFF soft key for</p> <ul style="list-style-type: none"> ■ Without function: Bit 0 = 1 ■ Without function: Bit 1 = 1 ■ Tool tables: Bit 2 = 1 ■ Datum tables: Bit 3 = 1 ■ Pallet tables: Bit 4 = 1 ■ Without function: Bit 5 = 1 ■ Point tables: Bit 6 = 1
Configure pallet files	<p>MP7226.0 Pallet table inactive: 0 Number of pallets per pallet table: 1 to 255</p>
Configure datum files	<p>MP7226.1 Datum table inactive: 0 Number of datums per datum table: 1 to 255</p>
Program length up to which the LBL numbers are checked	<p>MP7229.0 Blocks 100 to 9999</p>
Program length up to which FK blocks are checked	<p>MP7229.1 Blocks 100 to 9999</p>
Dialog language	<p>MP7230.0 to MP7230.3 English: 0 German: 1 Czech: 2 French: 3 Italian: 4 Spanish: 5 Portuguese: 6 Swedish: 7 Danish: 8 Finnish: 9 Dutch: 10 Polish: 11 Hungarian: 12 Reserved: 13 Russian (Cyrillic character set): 14 (only on the MC 422 B) Chinese (simplified): 15 (only on the MC 422 B) Chinese (traditional): 16 (only on the MC 422 B) Slovenian: 17 (only as of MC 422 B, software option) Norwegian: 18 (only as of MC 422 B, software option) Slovak: 19 (only as of MC 422 B, software option) Latvian: 20 (only as of MC 422 B, software option) Korean: 21 (only as of MC 422 B, software option) Estonian: 22 (only as of MC 422 B, software option) Turkish: 23 (only as of MC 422 B, software option) Romanian: 24 (only as of MC 422 B, software option) Lithuanian: 25 (only as of MC 422 B, software option)</p>



TNC displays, TNC editor

Configure tool tables

MP7260Inactive: **0**

Number of tools generated by the TNC when a new tool table is opened:

1 to 254

If you require more than 254 tools, you can expand the tool table with the function APPEND N LINES see "Tool Data", page 164

Configure pocket tables

MP7261.0 (magazine 1)**MP7261.1 (magazine 2)****MP7261.2 (magazine 3)****MP7261.3 (magazine 4)****MP7261.4 (magazine 5)****MP7261.5 (magazine 6)****MP7261.6 (magazine 7)****MP7261.7 (magazine 8)**Inactive: **0**Number of pockets in the tool magazine: **1 to 9999**

If the value 0 is entered in MP7261.1 through MP7261.7, the TNC uses only one tool magazine.

Index tool numbers in order to be able to assign different compensation data to each tool number

MP7262Do not index: **0**Number of permissible indices: **1 to 9**

Configuration of tool table and pocket table

MP7263Configuration settings for tool table and pocket table: **%0000**

- Show the POCKET TABLE soft key in the tool table: **Bit 0 = 0**
- Do not show the POCKET TABLE soft key in the tool table: **Bit 0 = 1**
- External data transmission: Only transmit displayed columns: **Bit 1 = 0**
- External data transmission: Transmit all columns: **Bit 1 = 1**
- Show the EDIT ON/OFF soft key in the pocket table: **Bit 2 = 0**
- Do not show the EDIT ON/OFF soft key in the pocket table: **Bit 2 = 1**
- RESET COLUMN T and RESET POCKET TABLE soft keys active: **Bit 3 = 0**
- RESET COLUMN T and RESET POCKET TABLE soft keys not active: **Bit 3 = 1**
- Do not allow the deletion of tools if they are contained in the pocket table: **Bit 4 = 0**
- Allow the deletion of tools if they are contained in the pocket table, deletion must be confirmed by the user: **Bit 4 = 1**
- Deletion of tools contained in the pocket table is possible with confirmation: **Bit 5 = 0**
- Deletion of tools contained in the pocket table is possible without confirmation: **Bit 5 = 1**
- Delete indexed tools without confirmation: **Bit 6 = 0**
- Delete indexed tools with confirmation: **Bit 6 = 1**



TNC displays, TNC editor

Configure tool table
(To omit from the
table: enter 0); Column
number in the tool
table for

MP7266.0

Tool name – NAME: **0** to **42**; column width: 16 characters

MP7266.1

Tool length – L: **0** to **42**; column width: 11 characters

MP7266.2

Tool radius – R: **0** to **42**; column width: 11 characters

MP7266.3

Tool radius 2 – R2: **0** to **42**; column width: 11 characters

MP7266.4

Oversize length – DL: **0** to **42**; column width: 8 characters

MP7266.5

Oversize radius – DR: **0** to **42**; column width: 8 characters

MP7266.6

Oversize radius 2 – DR2: **0** to **42**; column width: 8 characters

MP7266.7

Tool locked – TL: **0** to **42**; column width: 2 characters

MP7266.8

Replacement tool – RT: **0** to **42**; column width: 3 characters

MP7266.9

Maximum tool life – TIME1: **0** to **42**; column width: 5 characters

MP7266.10

Maximum tool life for TOOL CALL – TIME2: **0** to **42**; column width: 5 characters

MP7266.11

Current tool life – CUR. TIME: **0** to **42**; column width: 8 characters

MP7266.12

Tool comment – DOC: **0** to **42**; column width: 16 characters

MP7266.13

Number of teeth – CUT.: **0** to **42**; column width: 4 characters

MP7266.14

Tolerance for wear detection in tool length – LTOL: **0** to **42**; column width: 6 characters

MP7266.15

Tolerance for wear detection in tool radius – RTOL: **0** to **42**; column width: 6 characters

MP7266.16

Cutting direction – DIRECT.: **0** to **42**; column width: 7 characters

MP7266.17

PLC status – PLC: **0** to **42**; column width: 9 characters

MP7266.18

Offset of the tool in the tool axis in addition to MP6530 – TT:L-OFFS: **0** to **42**
column width: 11 characters

MP7266.19

Offset of the tool between stylus center and tool center – TT:R-OFFS: **0** to **42**
column width: 11 characters



TNC displays, TNC editor

**Configure tool table
(To omit from the
table: enter 0); Column
number in the tool
table for**

MP7266.20

Tolerance for break detection in tool length – LBREAK: **0 to 42**; column width: 6 characters

MP7266.21

Tolerance for break detection in tool radius – RBREAK: **0 to 42**; column width: 6 characters

MP7266.22

Tooth length (Cycle 22) – LCUTS: **0 to 42**; column width: 11 characters

MP7266.23

Maximum plunge angle (Cycle 22) – ANGLE.: **0 to 42**; column width: 7 characters

MP7266.24

Tool type –TYP: **0 to 42**; column width: 5 characters

MP7266.25

Tool material – TMAT: **0 to 42**; column width: 16 characters

MP7266.26

Cutting data table – CDT: **0 to 42**; column width: 16 characters

MP7266.27

PLC value – PLC-VAL: **0 to 42**; column width: 11 characters

MP7266.28

Center misalignment in reference axis – CAL-OFF1: **0 to 42**; column width: 11 characters

MP7266.29

Center misalignment in minor axis – CAL-OFF2: **0 to 42**; column width: 11 characters

MP7266.30

Spindle angle for calibration – CALL-ANG: **0 to 42**; column width: 11 characters

MP7266.31

Tool type for the pocket table–PTYP: **0 to 42**; column width: 2 characters

MP7266.32

Limitation of spindle speed – NMAX: **0 to 42**; Column width: 6 characters

MP7266.33

Retraction at NC stop – LIFTOFF: **0 to 42**; column width is 1 character

MP7266.34

Machine-dependent function – P1: **0 to 42**; column width: 10 characters

MP7266.35

Machine-dependent function – P2: **0 to 42**; column width: 10 characters

MP7266.36

Machine-dependent function – P3: **0 to 42**; column width: 10 characters

MP7266.37

Tool-specific kinematics description – KINEMATIC: **0 to 42**; column width: 16 characters

MP7266.38

Point angle – T_ANGLE: **0 to 42**; column width: 9 characters

MP7266.39

Thread pitch PITCH: **0 to 42**; column width: 10 characters

MP7266.40

Adaptive feed control – AFC: **0 to 42**; column width: 10 characters

MP7266.41

Tolerance for wear detection in tool radius 2 – R2TOL: **0 to 42**; column width: 6 characters

MP7266.42

Name of the compensation-value table for 3-D tool radius compensation depending on the tool's contact angle

MP7266.43

Date/Time of the last tool call



TNC displays, TNC editor

Configure tool pocket table (to omit from the table: enter 0); Column number in the pocket table for

MP7267.0
Tool number – T: **0 to 20**

MP7267.1
Special tool – ST: **0 to 20**

MP7267.2
Fixed pocket – F: **0 to 20**

MP7267.3
Pocket locked – L: **0 to 20**

MP7267.4
PLC status – PLC: **0 to 20**

MP7267.5
Tool name from tool table – TNAME: **0 to 20**

MP7267.6
Comment from tool table – DOC: **0 to 20**

MP7267.7
Tool type – PTYP: **0 to 20**

MP7267.8
Value for PLC – P1: **0 to 20**

MP7267.9
Value for PLC – P2: **0 to 20**

MP7267.10
Value for PLC – P3: **0 to 20**

MP7267.11
Value for PLC – P4: **0 to 20**

MP7267.12
Value for PLC – P5: **0 to 20**

MP7267.13
Reserved pocket – RSV: **0 to 20**

MP7267.14
Pocket above locked – LOCKED_ABOVE: **0 to 20**

MP7267.15
Pocket below locked – LOCKED_BELOW: **0 to 20**

MP7267.16
Pocket at left locked – LOCKED_LEFT: **0 to 20**

MP7267.17
Pocket at right locked – LOCKED_RIGHT: **0 to 20**

MP7267.18
S1 value for PLC – P6: **0 to 20**

MP7267.19
S2 value for PLC – P7: **0 to 20**

Manual Operation mode: Display of feed rate

MP7270
Display feed rate F only if an axis direction button is pressed: **0**
Display feed rate F even if no axis direction button is pressed (feed rate defined via soft key F or feed rate of the “slowest” axis): **1**

Decimal character

MP7280
The decimal character is a comma: **0**
The decimal character is a point: **1**

Position display in the tool axis

MP7285
Display is referenced to the tool datum: **0**
Display in the tool axis is referenced to the tool face: **1**



TNC displays, TNC editor

Display step for the spindle position **MP7289**
 0.1 °: **0**
 0.05 °: **1**
 0.01 °: **2**
 0.005 °: **3**
 0.001 °: **4**
 0.0005 °: **5**
 0.0001 °: **6**

Display step **MP7290.0 (X axis) to MP7290.13 (14th axis)**
 0.1 mm: **0**
 0.05 mm: **1**
 0.01 mm: **2**
 0.005 mm: **3**
 0.001 mm: **4**
 0.0005 mm: **5**
 0.0001 mm: **6**

Disable datum setting in the preset table **MP7294**
 Do not disable datum setting: **%00000000000000**
 Disable datum setting in the X axis: **Bit 0 = 1**
 Disable datum setting in the Y axis: **Bit 1 = 1**
 Disable datum setting in the Z axis: **Bit 2 = 1**
 Disable datum setting in the IVth axis: **Bit 3 = 1**
 Disable datum setting in the Vth axis: **Bit 4 = 1**
 Disable datum setting in the 6th axis: **Bit 5 = 1**
 Disable datum setting in the 7th axis: **Bit 6 = 1**
 Disable datum setting in the 8th axis: **Bit 7 = 1**
 Disable datum setting in the 9th axis: **Bit 8 = 1**
 Disable datum setting in the 10th axis: **Bit 9 = 1**
 Disable datum setting in the 11th axis: **Bit 10 = 1**
 Disable datum setting in the 12th axis: **Bit 11 = 1**
 Disable datum setting in the 13th axis: **Bit 12 = 1**
 Disable datum setting in the 14th axis: **Bit 13 = 1**

Disable datum setting **MP7295**
 Do not disable datum setting: **%00000000000000**
 Disable datum setting in the X axis: **Bit 0 = 1**
 Disable datum setting in the Y axis: **Bit 1 = 1**
 Disable datum setting in the Z axis: **Bit 2 = 1**
 Disable datum setting in the IVth axis: **Bit 3 = 1**
 Disable datum setting in the Vth axis: **Bit 4 = 1**
 Disable datum setting in the 6th axis: **Bit 5 = 1**
 Disable datum setting in the 7th axis: **Bit 6 = 1**
 Disable datum setting in the 8th axis: **Bit 7 = 1**
 Disable datum setting in the 9th axis: **Bit 8 = 1**
 Disable datum setting in the 10th axis: **Bit 9 = 1**
 Disable datum setting in the 11th axis: **Bit 10 = 1**
 Disable datum setting in the 12th axis: **Bit 11 = 1**
 Disable datum setting in the 13th axis: **Bit 12 = 1**
 Disable datum setting in the 14th axis: **Bit 13 = 1**

Disable datum setting with the orange axis keys **MP7296**
 Do not disable datum setting: **0**
 Disable datum setting with the orange axis keys: **1**



TNC displays, TNC editor	
Reset status display, Q parameters, tool data and machining time	<p>MP7300 Reset all when a program is selected: 0 Reset all when a program is selected and with M2, M30, END PGM: 1 Reset only status display and tool data when a program is selected: 2 Reset only status display, machining time and tool data when a program is selected and with M2, M30, END PGM: 3 Reset status display, machining time and Q parameters when a program is selected: 4 Reset status display, machining time, and Q parameters when a program is selected and with M2, M30, END PGM: 5 Reset status display and machining time when a program is selected: 6 Reset status display and machining time when a program is selected and with M2, M30, END PGM: 7</p>
Graphic display mode	<p>MP7310 Projection in three planes according to ISO 128, projection method 1: Bit 0 = 0 Projection in three planes according to ISO 128, projection method 2: Bit 0 = 1 Display new BLK FORM in Cycle 7 DATUM SHIFT referenced to the old datum: Bit 2 = 0 Display new BLK FORM in Cycle 7 DATUM SHIFT referenced to the new datum: Bit 2 = 1 Do not show cursor position during projection in three planes: Bit 4 = 0 Show cursor position during projection in three planes: Bit 4 = 1 Software functions of the new 3-D graphics active: Bit 5 = 0 Software functions of the new 3-D graphics not active: Bit 5 = 1</p>
Limitation of a tool's tooth length to be simulated. Only effective if LCUTS is not defined.	<p>MP7312 0 to 99 999.9999 [mm] Factor by which the tool diameter is multiplied in order to increase the simulation speed. If 0 is entered, the TNC assumes an infinitely long tooth length, which significantly increases the time required for the simulation.</p>
Graphic simulation without programmed tool axis: Tool radius	<p>MP7315 0 to 99 999.9999 [mm]</p>
Graphic simulation without programmed tool axis: Penetration depth	<p>MP7316 0 to 99 999.9999 [mm]</p>
Graphic simulation without programmed tool axis: M function for start	<p>MP7317.0 0 to 88 (0: Function inactive)</p>
Graphic simulation without programmed tool axis: M function for end	<p>MP7317.1 0 to 88 (0: Function inactive)</p>
Screen saver	<p>MP7392.0 0 to 99 [min] Time in minutes until the screen saver switches on (0: Function not active)</p> <p>MP7392.1 No screen saver is active: 0 Standard screensaver of the X server: 1 3-D line pattern: 2</p>



Machining and program run	
Effect of Cycle 11 SCALING FACTOR	MP7410 SCALING FACTOR effective in 3 axes: 0 SCALING FACTOR effective in the working plane only: 1
Manage tool data/calibration data	MP7411 The TNC saves the calibrated data for the 3-D touch probe internally: +0 The TNC uses the compensation values for the touch probe from the tool table as calibration data for the 3-D touch probe: +1
SL cycles	MP7420 The following applies to Cycles 21, 22, 23, 24: Mill channel around the contour—clockwise for islands and counterclockwise for pockets: Bit 0 = 0 Mill channel around the contour—clockwise for pockets and counterclockwise for islands: Bit 0 = 1 First mill the channel, then rough out the contour: Bit 1 = 0 Rough out the contour, then mill the channel: Bit 1 = 1 Combine compensated contours: Bit 2 = 0 Combine uncompensated contours: Bit 2 = 1 Rough out to each pocket depth: Bit 3 = 0 Mill pocket and rough-out for each infeed depth before continuing to the next depth: Bit 3 = 1 The following applies to Cycles 6, 15, 16, 21, 22, 23, and 24: At the end of the cycle, move the tool to the position that was last programmed before the cycle call: Bit 4 = 0 At the end of the cycle, retract the tool in the spindle axis only: Bit 4 = 1
Cycle 4 POCKET MILLING and Cycle 5 CIRCULAR POCKET MILLING: Overlap factor	MP7430 0.1 to 1.414
Permissible deviation of circle radius between circle end point and circle starting point	MP7431 0.0001 to 0.016 [mm]
Limit switch tolerance for M140 and M150	MP7432 Function inactive: 0 Tolerance for the distance by which the software limit switch may be exceeded with M140/M150: 0.0001 to 1.0000



Machining and program run	
<p>Operation of various miscellaneous functions M</p> <p>Note:</p> <p>The k_V factors for position loop gain are set by the machine tool builder. Refer to your machine tool manual.</p>	<p>MP7440</p> <p>Program stop with M6: Bit 0 = 0 No program stop with M6: Bit 0 = 1 No cycle call with M89: Bit 1 = 0 Cycle call with M89: Bit 1 = 1 Program stop with M functions: Bit 2 = 0 No program stop with M functions: Bit 2 = 1 k_V factors cannot be switched through M105 and M106: Bit 3 = 0 k_V factors can be switched through M105 and M106: Bit 3 = 1 Reduce the feed rate in the tool axis with M103 F.. Function inactive: Bit 4 = 0 Reduce the feed rate in the tool axis with M103 F.. Function active: Bit 4 = 1 Reserved: Bit 5 Exact stop for positioning with rotary axes inactive: Bit 6 = 0 Exact stop for positioning with rotary axes active: Bit 6 = 1</p>
<p>Error message during cycle call</p>	<p>MP7441</p> <p>Display error message if M3/M4 not active: Bit 0 = 0 Suppress error message if M3/M4 not active: Bit 0 = 1 Reserved: Bit 1 Suppress error message if positive depth programmed: Bit 2 = 0 Display error message if positive depth programmed: Bit 2 = 1</p>
<p>M function for spindle orientation in the fixed cycles</p>	<p>MP7442</p> <p>Function inactive: 0 Orientation directly through the NC: -1 M function for orienting the spindle: 1 to 999</p>
<p>Maximum contouring speed at feed rate override setting of 100% in the Program Run modes</p>	<p>MP7470</p> <p>0 to 99 999 [mm/min]</p>
<p>Feed rate for rotary-axis compensation movements</p>	<p>MP7471</p> <p>0 to 99 999 [mm/min]</p>
<p>Compatibility machine parameters for datum tables</p>	<p>MP7475</p> <p>Datum shifts are referenced to the workpiece datum: 0 If the value 1 was entered in older TNC controls or in controls with software 340 420-xx, datum shifts were referenced to the machine datum. This function is no longer available. You must now use the preset table instead of datum tables referenced to REF (see "Datum management with the preset table" on page 466).</p>
<p>Time to be added when calculating the tool usage time</p>	<p>MP7485</p> <p>0 to 100 [%]</p>



18.2 Pin Layouts and Connecting Cables for the Data Interfaces

RS-232-C/V.24 interface for HEIDENHAIN devices



The interface complies with the requirements of EN 50 178 for "low voltage electrical separation."

Please note that pins 6 and 8 of the connecting cable 274 545 are bridged.

When using the 25-pin adapter block:

TNC		Connecting cable 365 725-xx			Adapter block 310 085-01		Connecting cable 274 545-xx		
Male	Assignment	Female	Color	Female	Male	Female	Male	Color	Female
1	Do not assign	1		1	1	1	1	White/Brown	1
2	RXD	2	Yellow	3	3	3	3	Yellow	2
3	TXD	3	Green	2	2	2	2	Green	3
4	DTR	4	Brown	20	20	20	20	Brown	8
5	Signal GND	5	Red	7	7	7	7	Red	7
6	DSR	6	Blue	6	6	6	6		6
7	RTS	7	Gray	4	4	4	4	Gray	5
8	CTS	8	Pink	5	5	5	5	Pink	4
9	Do not assign	9					8	Violet	20
Hsg.	Ext. shield	Hsg.	Ext. shield	Hsg.	Hsg.	Hsg.	Hsg.	Ext. shield	Hsg.



When using the 9-pin adapter block:

TNC		Connecting cable 355 484-xx			Adapter block 363 987-02		Connecting cable 366 964-xx		
Male	Assignment	Female	Color	Male	Female	Male	Female	Color	Female
1	Do not assign	1	Red	1	1	1	1	Red	1
2	RXD	2	Yellow	2	2	2	2	Yellow	3
3	TXD	3	White	3	3	3	3	White	2
4	DTR	4	Brown	4	4	4	4	Brown	6
5	Signal GND	5	Black	5	5	5	5	Black	5
6	DSR	6	Violet	6	6	6	6	Violet	4
7	RTS	7	Gray	7	7	7	7	Gray	8
8	CTS	8	White/Green	8	8	8	8	White/Green	7
9	Do not assign	9	Green	9	9	9	9	Green	9
Hsg.	Ext. shield	Hsg.	Ext. shield	Hsg.	Hsg.	Hsg.	Hsg.	Ext. shield	Hsg.

Non-HEIDENHAIN devices

The connector layout of a non-HEIDENHAIN device may substantially differ from the connector layout of a HEIDENHAIN device.

It depends on the unit and the type of data transfer. The table below shows the connector pin layout on the adapter block.

Adapter block 363 987-02		Connecting cable 366 964-xx		
Female	Male	Female	Color	Female
1	1	1	Red	1
2	2	2	Yellow	3
3	3	3	White	2
4	4	4	Brown	6
5	5	5	Black	5
6	6	6	Violet	4
7	7	7	Gray	8
8	8	8	White/Green	7
9	9	9	Green	9
Hsg.	Hsg.	Hsg.	Ext. shield	Hsg.



RS-422/V.11 interface

Only non-HEIDENHAIN devices are connected to the RS-422 interface.



The interface complies with the requirements of EN 50 178 for "low voltage electrical separation."

The pin layouts on the TNC logic unit (X28) and on the adapter block are identical.

TNC		Connecting cable 355 484-xx			Adapter block 363 987-01	
Female	Pin layout	Male	Color	Female	Male	Female
1	RTS	1	Red	1	1	1
2	DTR	2	Yellow	2	2	2
3	$\overline{\text{RXD}}$	3	White	3	3	3
4	$\overline{\text{TXD}}$	4	Brown	4	4	4
5	Signal GND	5	Black	5	5	5
6	CTS	6	Violet	6	6	6
7	DSR	7	Gray	7	7	7
8	RXD	8	White/ Green	8	8	8
9	TXD	9	Green	9	9	9
Hsg.	Ext. shield	Hsg.	External shield	Hsg.	Hsg.	Hsg.

Ethernet interface RJ45 socket

Maximum cable length:

- Unshielded: 100 m
- Shielded: 400 m

Pin	Signal	Description
1	TX+	Transmit Data
2	TX-	Transmit Data
3	REC+	Receive Data
4	Vacant	
5	Vacant	
6	REC-	Receive Data
7	Vacant	
8	Vacant	



18.3 Technical Information

Explanation of symbols

- Standard
- Axis option
- ◆ Software option 1
- Software option 2

User functions

Short description	<ul style="list-style-type: none"> ■ Basic version: 3 axes plus spindle ■ Fourth NC axis plus auxiliary axis or □ 8 additional axes or 7 additional axes plus 2nd spindle ■ Digital current and shaft speed control
Program entry	HEIDENHAIN conversational format, with smarT.NC and as per ISO
Position data	<ul style="list-style-type: none"> ■ Nominal positions for lines and arcs in Cartesian coordinates or polar coordinates ■ Incremental or absolute dimensions ■ Display and entry in mm or inches ■ Display of the handwheel path during machining with handwheel superimpositioning
Tool compensation	<ul style="list-style-type: none"> ■ Tool radius in the working plane and tool length ■ Radius compensated contour look ahead for up to 99 blocks (M120) ● Three-dimensional tool-radius compensation for subsequent changing of tool data without having to recalculate the program
Tool tables	Multiple tool tables with up to 30 000 tools
Cutting-data tables	Cutting data tables for automatic calculation of spindle speed and feed rate from tool-specific data (cutting speed, feed per tooth)
Constant contour speed	<ul style="list-style-type: none"> ■ With respect to the path of the tool center ■ With respect to the cutting edge
Parallel operation	Creating a program with graphical support while another program is being run
3-D machining (software option 2)	<ul style="list-style-type: none"> ● Motion control with minimum jerk ● 3-D compensation through surface normal vectors ● Using the electronic handwheel to change the angle of the swivel head during program run without affecting the position of the tool point (TCPM = Tool Center Point Management) ● Keeping the tool normal to the contour ● Tool radius compensation normal to the direction of traverse and the tool direction ● Spline interpolation
Rotary table machining (software option 1)	<ul style="list-style-type: none"> ◆ Programming of cylindrical contours as if in two axes ◆ Feed rate in distance per minute



User functions	
Contour elements	<ul style="list-style-type: none"> ■ Straight line ■ Chamfer ■ Circular path ■ Circle center point ■ Circle radius ■ Tangentially connected arc ■ Corner rounding
Approaching and departing the contour	<ul style="list-style-type: none"> ■ Via straight line: tangential or perpendicular ■ Via circular arc
FK free contour programming	<ul style="list-style-type: none"> ■ FK free contour programming in HEIDENHAIN conversational format with graphic support for workpiece drawings not dimensioned for NC
Program jumps	<ul style="list-style-type: none"> ■ Subroutines ■ Program-section repeat ■ Any desired program as subroutine
Fixed cycles	<ul style="list-style-type: none"> ■ Drilling cycles for drilling, pecking, reaming, boring, tapping with a floating tap holder, rigid tapping ■ Cycles for milling internal and external threads ■ Milling and finishing rectangular and circular pockets ■ Cycles for clearing level and inclined surfaces ■ Cycles for milling linear and circular slots ■ Linear and circular point patterns ■ Contour pockets—also with contour-parallel machining ■ Contour train ■ OEM cycles (special cycles developed by the machine tool builder) can also be integrated
Coordinate transformation	<ul style="list-style-type: none"> ■ Datum shift, rotation, mirroring ■ Scaling factor (axis-specific) ◆ Tilting the working plane (software option 1)
Q parameters Programming with variables	<ul style="list-style-type: none"> ■ Mathematical functions =, +, -, *, /, sin α, cos α ■ Logical comparisons (=, ≠, <, >) ■ Calculating with parentheses ■ tan α, arc sin, arc cos, arc tan, a^n, e^n, ln, log, absolute value of a number, the constant π, negation, truncation of digits before or after the decimal point ■ Functions for calculation of circles ■ String parameters
Programming aids	<ul style="list-style-type: none"> ■ Calculator ■ Context-sensitive help function for error messages ■ The context-sensitive help system TNCguide (FCL 3 function) ■ Graphic support for the programming of cycles ■ Comment blocks in the NC program



User functions	
Actual position capture	<ul style="list-style-type: none"> ■ Actual positions can be transferred directly into the NC program
Program verification graphics Display modes	<p>Graphic simulation before program run, even while another program is being run</p> <ul style="list-style-type: none"> ■ Plan view / projection in 3 planes / 3-D view ■ Magnification of details
Programming graphics	<ul style="list-style-type: none"> ■ In the Programming and Editing mode, the contours of the NC blocks are drawn on screen while they are being entered (2-D pencil-trace graphics), even while another program is running
Program Run graphics Display modes	<ul style="list-style-type: none"> ■ Graphic simulation of real-time machining in plan view / projection in 3 planes / 3-D view
Machining time	<ul style="list-style-type: none"> ■ Calculating the machining time in the Test Run mode of operation ■ Display of the current machining time in the Program Run modes
Returning to the contour	<ul style="list-style-type: none"> ■ Mid-program startup in any block in the program, returning the tool to the calculated nominal position to continue machining ■ Program interruption, contour departure and return
Datum tables	<ul style="list-style-type: none"> ■ Multiple datum tables
Pallet tables	<ul style="list-style-type: none"> ■ Pallet tables (with as many entries as desired for the selection of pallets, NC programs and datums) can be machined workpiece by workpiece or tool by tool
Touch probe cycles	<ul style="list-style-type: none"> ■ Calibrate touch probe ■ Compensation of workpiece misalignment, manual or automatic ■ Datum setting, manual or automatic ■ Automatic workpiece measurement ■ Cycles for automatic tool measurement ■ Cycles for automatic kinematics measurement
Specifications	
Components	<ul style="list-style-type: none"> ■ MC 420 or MC 422 C main computer ■ CC 422 or CC 424 controller unit ■ Keyboard ■ 15.1-inch
Program memory	At least 21 GB , for the dual-processor system at least 13 GB
Input resolution and display step	<ul style="list-style-type: none"> ■ Up to 0.1 μm for linear axes ■ Up to 0.0001° for angular axes
Input range	<ul style="list-style-type: none"> ■ Maximum 99 999.999 mm (3.937 inches) or 99 999.999°



Specifications	
Interpolation	<ul style="list-style-type: none"> ■ Linear in 4 axes ◆ Linear in 5 axes (subject to export permit) (software option 1) ■ Circular in 2 axes ◆ Circular in 3 axes with tilted working plane (software option 1) ■ Helix: Combination of circular and linear motion ■ Spline: Execution of splines (3rd degree polynomials)
Block processing time 3-D straight line without radius compensation	<ul style="list-style-type: none"> ■ 3.6 ms ● 0.5 ms (software option 2)
Axis feedback control	<ul style="list-style-type: none"> ■ Position loop resolution: Signal period of the position encoder/1024 ■ Cycle time of position controller: 1.8 ms ■ Cycle time of speed controller: 600 µs ■ Cycle time of current controller: minimum 100 µs
Range of traverse	<ul style="list-style-type: none"> ■ Maximum 100 m (3937 inches)
Spindle speed	<ul style="list-style-type: none"> ■ Maximum 40 000 rpm (with 2 pole pairs)
Error compensation	<ul style="list-style-type: none"> ■ Linear and nonlinear axis error, backlash, reversal peaks during circular movements, thermal expansion ■ Stick-slip friction
Data interfaces	<ul style="list-style-type: none"> ■ One each RS-232-C / V.24 and RS-422 / V.11 max. 115 kilobaud ■ Expanded interface with LSV-2 protocol for external operation of the TNC over the interface with HEIDENHAIN software TNCremo. ■ Ethernet interface 100BaseT Approx. 2 to 5 megabaud (depending on file type and network load) ■ USB 1.1 interface For pointing (mouse) devices and block devices (memory sticks, hard disks, CD-ROM drives)
Surrounding temperature	<ul style="list-style-type: none"> ■ Operation: 0 °C to +45 °C ■ Storage: -30 °C to +70 °C



Accessories**Electronic handwheels**

- One **HR 550 FS** portable wireless handwheel with display or
- One **HR 520** portable handwheel with display, or
- One **HR 420** portable handwheel with display, or
- One **HR 410** portable handwheel, or
- One **HR 130** panel-mounted handwheel, or
- Up to three **HR 150** panel-mounted handwheels via HRA 110 handwheel adapter

Touch probes

- **TS 220**: 3-D touch trigger probe with cable connection, or
- **TS 440**: 3-D touch trigger probe with infrared transmission
- **TS 444**: Battery-free 3-D touch trigger probe with infrared transmission
- **TS 640**: 3-D touch trigger probe with infrared transmission
- **TS 740**: High-precision 3-D touch trigger probe with infrared transmission
- **TT 140**: 3-D touch trigger probe for tool measurement



Software option 1

Rotary table machining ◆ Programming of cylindrical contours as if in two axes
◆ Feed rate in distance per minute

Coordinate transformation ◆ Tilting the working plane

Interpolation ◆ Circle in 3 axes with tilted working plane

Software option 2

3-D machining

- Motion control with minimum jerk
- 3-D tool compensation through surface normal vectors
- Using the electronic handwheel to change the angle of the swivel head during program run without affecting the position of the tool point (TCPM = **T**ool **C**enter **P**oint **M**anagement)
- Keeping the tool normal to the contour
- Tool radius compensation normal to the direction of traverse and the tool direction
- Spline interpolation

Interpolation ● Linear in 5 axes (subject to export permit)

Block processing time ● 0.5 ms

DXF Converter software option

Extracting contour programs and machining positions from DXF data

- Format supported: AC1009 (AutoCAD R12)
- For plain-language and smarT.NC
- Simple and convenient specification of reference points

Dynamic Collision Monitoring (DCM) software option

Collision monitoring in all machine operating modes

- The machine manufacturer defines objects to be monitored
- Fixture monitoring is also possible
- Three warning levels in manual operation
- Program interrupt during automatic operation
- Includes monitoring of 5-axis movements
- Program simulation before machining for possible collisions

Additional conversational language software option

Additional conversational languages

- Slovenian
- Norwegian
- Slovak
- Latvian
- Korean
- Estonian
- Turkish
- Romanian
- Lithuanian



Global Program Settings software option

Function for superimposing coordinate transformations in the Program Run modes

- Swapping axes
- Superimposed datum shift
- Superimposed mirroring
- Axis locking
- Handwheel superimposition
- Superimposed basic rotation and datum-based rotation
- Feed rate factor

Adaptive Feed Control software option (AFC)

Function for adaptive feed-rate control for optimizing the machining conditions during series production

- Recording the actual spindle power by means of a teach-in cut
- Defining the limits of automatic feed rate control
- Fully automatic feed control during program run

KinematicsOpt software option

Touch-probe cycles for automatic testing and optimization of the machine kinematics

- Backup/restore active kinematics
- Test active kinematics
- Optimize active kinematics

3D-ToolComp software option

3-D tool radius compensation depending on the tool's contact angle

- Compensate the delta radius of the tool depending on the tool's contact angle at the workpiece
- Prerequisite: LN blocks
- Compensation values can be defined in a separate table

FCL 2 upgrade functions

Enabling of significant improvements

- Virtual tool axis
- Touch probe cycle 441, Rapid Probing
- Offline CAD point filter
- 3-D line graphics
- Contour pocket: Assign a separate depth to each subcontour
- smarT.NC: Coordinate transformation
- smarT.NC: **PLANE** function
- smarT.NC: Graphically supported block scan
- Expanded USB functionality
- Network attachment via DHCP and DNS



FCL 3 upgrade functions**Enabling of significant improvements**

- Touch probe cycle for 3-D probing
- Touch Probe Cycles 408 and 409 (Units 408 and 409 in smarT.NC) for setting a reference point in the center of a slot or a ridge
- PLANE function: Axis angle input
- User documentation as context-sensitive help right on the TNC
- Feed-rate reduction for the machining of contour pockets with the tool being in full contact with the workpiece
- smarT.NC: Contour pocket on pattern
- smarT.NC: Parallel programming is possible
- smarT.NC: Preview of contour programs in the file manager
- smarT.NC: Positioning strategy for machining point patterns

FCL 4 upgrade functions**Enabling of significant improvements**

- Graphical depiction of the protected space when DCM collision monitoring is active
- Handwheel superimposition in stopped condition when DCM collision monitoring is active
- 3-D basic rotation (set-up compensation, must be adapted by the machine tool builder)



Input format and unit of TNC functions	
Positions, coordinates, circle radii, chamfer lengths	-99 999.9999 to +99 999.9999 (5.4: places before and after the decimal point) [mm]
Circle radii	-99 999.9999 to +99 999.9999 if values are entered directly, radii up to 210 m possible via Q parameter programming (5.4: places before and after the decimal point) [mm]
Tool numbers	0 to 32 767.9 (5.1)
Tool names	16 characters, enclosed by quotation marks with TOOL CALL. Permitted special characters: #, \$, %, &, -
Delta values for tool compensation	-99.9999 to +99.9999 (2.4) [mm]
Spindle speeds	0 to 99 999.999 (5.3) [rpm]
Feed rates	0 to 99 999.999 (5.3) [mm/min] or [mm/tooth] or [mm/rev]
Dwell time in Cycle 9	0 to 3600.000 (4.3) [s]
Thread pitch in various cycles	-99.9999 to +99.9999 (2.4) [mm]
Angle of spindle orientation	0 to 360.0000 (3.4) [°]
Angle for polar coordinates, rotation, tilting the working plane	-360.0000 to +360.0000 (3.4) [°]
Polar coordinate angle for helical interpolation (CP)	-99 999.9999 to +99 999.9999 (5.4) [°]
Datum numbers in Cycle 7	0 to 2999 (4.0)
Scaling factor in Cycles 11 and 26	0.000 001 to 99.999 999 (2.6)
Miscellaneous functions M	0 to 999 (3.0)
Q parameter numbers	0 to 1999 (4.0)
Q parameter values	-999 999 999 to +999 999 999 (9 digits, floating point)
Labels (LBL) for program jumps	0 to 999 (3.0)
Labels (LBL) for program jumps	Any text string in quotes (" ")
Number of program section repeats REP	1 to 65 534 (5.0)
Error number with Q parameter function FN14	0 to 1099 (4.0)
Spline parameter K	-9.999 9999 to +9.999 9999 (1.7)
Exponent for spline parameter	-255 to 255 (3.0)
Surface-normal vectors N and T with 3-D compensation	-9.9999999 to +9.9999999 (1.7)



18.4 Exchanging the Buffer Battery

A buffer battery supplies the TNC with current to prevent the data in RAM memory from being lost when the TNC is switched off.

If the TNC displays the error message **Exchange buffer battery**, then you must replace the battery:




Caution: Danger of life!

To exchange the buffer battery, first switch off the TNC!

The buffer battery must be exchanged only by trained service personnel.

Battery type: 1 Lithium battery, type CR 2450N (Renata) ID 315 878-01

- 1 The backup battery is at the back of the MC 422 C
- 2 Exchange the battery. The battery contact accepts a new battery only in the correct orientation



18.4 Exchanging the Buffer Battery





19

**iTNC 530 with
Windows XP (Option)**



19.1 Introduction

End User License Agreement (EULA) for Windows XP



Please pay attention to the Microsoft End User License Agreement (EULA), which is included with your machine documentation.

General



The special features of the iTNC 530 with Windows XP are described in this chapter. For the Windows XP system functions, please refer to the Windows documentation.

TNC controls from HEIDENHAIN have always been user friendly: Thanks to their simple programming in HEIDENHAIN conversational language, field-proven cycles, unambiguous function keys, and clear and vivid graphic functions they now count among the most popular shop-floor programmable controls.

The standard Windows operating system is now also provided as a user interface. The new and highly efficient HEIDENHAIN hardware with two processors is the basis for the iTNC 530 with Windows XP.

The first processor handles real-time jobs and the HEIDENHAIN operating system, whereas the second processor is available only to the standard Windows operating system and thus provides the user access to the world of information technology.

Here, too, ease of use is the highest priority:

- The operating panel comprises a complete PC keyboard with touchpad
- The 15-inch high-resolution color flat-panel monitor displays both the iTNC interface and the Windows applications
- Standard PC equipment such as a mouse or drives can easily be connected to the control through USB interfaces.



Changes in the pre-installed Windows system

If changes are made to the pre-installed Windows system, HEIDENHAIN does not guarantee that this will have no negative effects on the function of the control software, and therefore on the quality of the parts produced.

Changes to the system settings, installation of updates or installation of additional software in particular can have a lasting effect on the control software. HEIDENHAIN has tested important Windows security updates from Microsoft and integrated them, as far as possible, in the pre-installed Windows system. All other modifications are the responsibility of the machine tool builder or the user.

To minimize the probability of adverse effects on the machine control operation or on the quality of the parts manufactured with it, HEIDENHAIN recommends observing the following rules regarding such modifications and, in particular, the operation of the Windows system.



Before you do any extensive work, always put the machine in EMERGENCY STOP condition. See also the information on the installation of additional software (see "Logging on as a local administrator" on page 617). Even the change or modification of shared components (DLL, Registry settings, etc.) can lead to undesired impairments at completely unexpected locations.

Never do any extensive work on the Windows system while machining parts! This includes in particular operations that require a considerable portion of operating-system resources (computing time, RAM, accesses to the hard disk, network traffic, etc.).

Do not run any automatic updates, neither of Windows nor of any other software, as the implemented changes can impair the overall system both during the update itself and during further operation.

Do not start any additional software during start-up! This applies in particular to services such as the real-time scan components of virus scanners.

Network connections to non-existing drives can lead to an increased system load under Windows. Do not connect network drives automatically but only if required!



Specifications

Specifications	iTNC 530 with Windows XP
Description	Dual-processor control with <ul style="list-style-type: none"> ■ HEROS real-time operating system for controlling the machine ■ Windows XP PC operating system as user interface
Memory	<ul style="list-style-type: none"> ■ RAM memory: <ul style="list-style-type: none"> ■ 512 MB for control applications ■ 512 MB for Windows applications ■ Hard disk <ul style="list-style-type: none"> ■ 13 GB for TNC files ■ 13 GB for Windows files, of which approx. 13 GB are available for applications
Data interfaces	<ul style="list-style-type: none"> ■ Ethernet 10/100BaseT (up to 100 Mbps depending on network utilization) ■ RS-232-C/V.24 (max. 115 200 bps) ■ RS-422/V.11 (max. 115 200 bps) ■ 2 x USB ■ 2 x PS/2



19.2 Starting an iTNC 530 Application

Logging on to Windows

After you have switched on the power supply, the iTNC 530 starts booting automatically. When the input dialog for logging on to Windows appears, there are two possibilities for logging on:

- Logging on as a TNC user
- Logging on as a local administrator


Logging on as a TNC user

- ▶ Enter the user name "TNC" in the **User name** input box. Leave the **Password** input box blank and press the OK button.
- ▶ The TNC software is automatically started. The status message **Starting, please wait...** appears in the iTNC Control Panel.



Do not open or use any other Windows programs as long as the iTNC Control Panel is displayed (see figure). When the iTNC software has successfully started, the Control Panel minimizes itself to a HEIDENHAIN symbol on the task bar.

This user identification permits very limited access to the Windows operating system. You are neither allowed to change the network settings, nor are you allowed to install new software.



Logging on as a local administrator



Please contact your machine tool builder for the user name and the password.

As a local administrator, you are allowed to install software and change the network settings.



HEIDENHAIN does not assist you in installing Windows applications and offers no guarantee for the function of the applications you installed.

HEIDENHAIN is not liable for faulty hard disk contents caused by installing updates to non-HEIDENHAIN software or additional application software.

If HEIDENHAIN is required to render service after programs or data have been changed, HEIDENHAIN will charge you for the service costs incurred.



In order to guarantee the trouble-free function of the iTNC application, the Windows XP system must at all times have sufficient

- CPU power
- free hard disk memory on the C drive
- RAM
- bandwidth for the hard drive interface

available.

By sufficiently buffering the TNC data, the control can compensate brief interruptions (up to one second at a block cycle time of 0.5 ms) to the data transfer from the Windows PC. However, if the data transfer from the Windows PC is interrupted for a longer time period, problems can occur with the feed rate during program run, resulting in damage to the workpiece.



Keep in mind the following requirements for software installations:

The program to be installed must not overburden the computing power of the Windows PC (512 MB RAM, Pentium M with 1.8 GHz clock frequency).

Programs executed under Windows with the priority levels **above normal, high** or **real time** (e.g. games), must not be installed.

You should use virus scanners only when the TNC is not running an NC program. HEIDENHAIN recommends using virus scanners either just after switching the control on or just before switching it off.



19.3 Switching Off the iTNC 530

Fundamentals

To prevent data from being lost at switch-off, you must shut down the iTNC 530 properly. The following sections describe the various possibilities for doing so.



Inappropriate switch-off of the iTNC 530 can lead to data loss.

Exit the iTNC 530 application before exiting Windows.

Logging a user off

You can log a user off of Windows at any time without adversely influencing the iTNC software. However, the iTNC screen is not visible during the log-off process, and you cannot make any entries during this time.



Note that machine-specific keys (such as NC Start or the axis direction keys) remain active.

After a new user has logged on, the iTNC screen reappears.



Exiting the iTNC application



Warning!

Before you exit the iTNC application, you absolutely must press the Emergency Stop key. Otherwise you could lose data or the machine could become damaged.

There are two possibilities for exiting the iTNC application:

- Internal exiting via the Manual operating mode; simultaneously exits Windows
- External exiting via the iTNC Control Panel; only exits the iTNC application

Internal exiting via the Manual operating mode

- ▶ Select the Manual operating mode.
- ▶ Shift the soft-key row until the soft key for shutting down the iTNC application appears.



- ▶ Select the function for shutting down and confirm the following dialog prompt again with the YES soft key.
- ▶ When the message **It is now safe to turn off your computer** appears on the iTNC screen, you may switch off the power supply to the iTNC 530.

External exiting via the iTNC Control Panel



- ▶ Press the Windows key on the ASCII keyboard to minimize the iTNC application and display the Task Bar.
- ▶ Double-click the green HEIDENHAIN symbol to the lower right in the Task Bar for the iTNC Control Panel to appear (see figure).



- ▶ Select the function for exiting the iTNC 530 application: Press the **Stop iTNC** button.
- ▶ After you have pressed the Emergency Stop button, acknowledge the iTNC message with the **Yes** screen button. The iTNC application is stopped.
- ▶ The iTNC Control Panel remains active. To restart the iTNC 530, press the **Restart iTNC** button.

To exit Windows, select

- ▶ the **Start** button
- ▶ the menu item **Shut down...**
- ▶ again the menu item **Shut down...**
- ▶ and confirm with **OK**.



Shutting down Windows

If you try to shut down Windows while the iTNC software is still active, the control displays a warning (see figure).



Warning!



Before you confirm with OK, you absolutely must press the Emergency Stop button. Otherwise you could lose data or the machine could become damaged.

If you confirm with OK, the iTNC software is exited and Windows is shut down.



Warning!

After several seconds Windows displays its own warning, covering the iTNC warning (see figure). Never confirm the warning with End Now, since you could lose data or the machine could become damaged.



19.4 Network Settings

Prerequisite



You must log on as a local administrator to be able to change the network settings. Please contact your machine tool builder for the required user name and password.

The network should be configured only by network specialists.

Adjusting the network settings

The iTNC 530 is shipped with two network connections: The **Local Area Connection** and the **iTNC Internal Connection** (see figure).


The **Local Area Connection** is the iTNC's connection to its network. You may adjust all familiar Windows XP settings to your network (also see the Windows XP network description).



The **iTNC Internal Connection** is exactly that: an internal iTNC connection. The configuration of this connection must not be changed. Changes might cause the iTNC to stop functioning.

This internal network address has a default setting of **192.168.252.253** and must not collide with your company network, meaning that the subnet **192.168.254.xxx** cannot already exist in your network. If necessary, contact HEIDENHAIN if you are having address conflicts.

The option **Obtain IP address automatically** must be inactive.



Controlling access

Administrators have access to the TNC drives D, E and F. Please note that some of the data in these partitions is binary encoded, and write-accesses might lead to undefined behavior of the iTNC.

The user groups **SYSTEM** and **Administrators** have access rights to the partitions D, E and F. The **SYSTEM** group ensures that the Windows service that starts the control has access. The **Administrators** group ensures that the real-time processor of the iTNC receives a network connection via the **iTNC Internal Connection**.



You may not restrict access by these groups, nor may you add groups and prohibit certain accesses by these groups (in Windows, access restrictions have priority over access rights).



19.5 Specifics About File Management

The iTNC drive

When you call the iTNC file manager, the left window shows all available drives. For example:

- **C:**: Windows partition of the built-in hard disk
- **RS232:**: Serial interface 1
- **RS422:**: Serial interface 2
- **TNC:**: Data partition of the iTNC

There might also be other networks available if you have connected them with Windows Explorer.




Please note that the data drive of the iTNC appears in the file manager with the name **TNC:**. In Windows Explorer, this drive (partition) appears with the letter **D**.

Subdirectories on the TNC drive (e.g. **RECYCLER** and **SYSTEM VOLUME IDENTIFIER**) are created by Windows XP and may not be deleted.

With MP7225 you can define letters of drives that should not be shown in the file management of the TNC.

If you connect a new network drive with Windows Explorer, you may have to update the iTNC's display of available drives:

- ▶ Press the PGM MGT key to call the file manager.
- ▶ Move the highlight to the drive window at left.
- ▶ Switch to the second level of the soft-key row.
- ▶ To update the drive overview, press the UPDATE TREE soft key.



Data transfer to the iTNC 530



Before you can initiate data transfer on the iTNC, the network drive must have been connected with Windows Explorer. Access to UNC network names (e.g. \\PC0815\DIR1) is not possible.

TNC-specific files

After integrating the iTNC 530 into your network, you can access any computer and transfer files to it from the iTNC. However, certain file types may only be transferred if data transfer was initiated by the iTNC. The reason is that these files must be converted into binary format during data transfer to the iTNC.



Simply copying the file types listed below to the D drive using Windows Explorer is both prohibited and useless.

File types that may not be copied using Windows Explorer:

- Conversational dialog programs (extension **.H**)
- smarT.NC unit programs (extension **.HU**)
- smarT.NC contour programs (extension **.HC**)
- smarT.NC point tables (extension **.HP**)
- ISO programs (extension **.I**)
- Tool tables (extension **.T**)
- Pocket tables (extension **.TCH**)
- Pallet tables (extension **.P**)
- Datum tables (extension **.D**)
- Point tables (extension **.PNT**)
- Cutting data tables (extension **.CDT**)
- Freely definable tables (extension **.TAB**)

Procedure for data transfer: See "Data transfer to or from an external data medium" on page 134.

ASCII files

There are no limitations regarding the direct copying of ASCII files (files with the extension **.A**) with Windows Explorer.



Please note that all the files you want to use on the TNC must be stored on drive D.





SYMBOLE

- 3-D compensation
 - Peripheral milling ... 423
- 3-D touch probes
 - Calibrating
 - Triggering ... 478
 - Managing more than one block of calibration data ... 480
- 3-D view ... 514

A

- Accessories ... 94
- Actual position capture ... 107
- Adaptive feed control ... 366
- AFC ... 366
- Animation, PLANE function ... 393
- ASCII files ... 377
- Automatic cutting data calculation ... 171, 382
- Automatic program start ... 537
- Automatic tool measurement ... 169

B

- Backup ... 115
- Basic rotation
 - Measuring in the Manual Operation mode ... 483, 485, 486
- Baud rate, setting the ... 547
- Block
 - Deleting ... 109
 - Inserting, editing ... 109
- Blocks
- Buffer battery exchange ... 611

C

- Calculating with parentheses ... 281
- Calculator ... 143
- Chamfer ... 206
- Circle center point ... 208
- Circular path ... 209, 210, 212, 219, 220
- Code numbers ... 545
- Collision monitoring ... 337
- Comments, adding ... 140
- Compensating workpiece misalignment
 - By measuring two points of a line ... 481
 - Over two holes ... 482, 491
 - Over two studs ... 485, 491

C

- Constant contouring speed M90 ... 315
- Context-sensitive help ... 154
- Contour approach ... 200
- Contour departure ... 200
- Contour, selecting from DXF ... 233
- Conversational programming ... 106
- Copying program sections ... 111
- Corner rounding ... 207
- Cutting data calculation ... 382
- Cutting-data table ... 382
- Cylinder ... 304

D

- Data carrier, checking ... 575
- Data interface
 - Assigning ... 548
 - Pin layout ... 599
 - setting ... 547
- Data transfer rate ... 547
- Data transfer software ... 549
- Datum management ... 466
- Datum setting ... 464
 - without a 3-D touch probe ... 464
- Datum setting, manual
 - Center line as datum ... 490
 - Circle center as datum ... 489
 - Corner as datum ... 488
 - In any axis ... 487
 - Using holes/studs ... 491
- Datum table
 - Confirming probed values ... 475
- Datum, setting the ... 102
- DCM ... 337
- Dependent files ... 563
- Dialog ... 106
- Directory ... 116, 122
 - Copying ... 126
 - Creating ... 122
 - Deleting ... 127
- DXF data, processing ... 226
 - Basic settings ... 228
 - Contour selection ... 233
 - Filter for hole positions ... 240
 - Layer settings ... 230
 - Machining positions, selecting ... 236
 - Selecting hole positions
 - Diameter input ... 239
 - Individual selection ... 237
 - Mouse over ... 238
 - Workpiece presetting ... 231

D

- Dynamic Collision Monitoring ... 337
 - Test Run ... 342
 - Tool holders ... 174

E

- Ellipse ... 302
- Error list ... 150
- Error messages ... 149, 150
 - Help with ... 149
- Ethernet interface
 - Configuring ... 554
 - Connecting and disconnecting network drives ... 136
 - Connection possibilities ... 551
 - Introduction ... 551
- External access ... 578
- External data transfer
 - iTNC 530 ... 134
 - iTNC 530 with Windows XP ... 624

F

- FCL ... 544
- FCL function ... 10
- Feature content level ... 10
- Feed control, automatic ... 366
- Feed rate ... 462
 - Changing ... 463
 - for rotary axes, M116 ... 414
- Feed rate factor for plunging movements M103 ... 320
- Feed rate in millimeters per spindle revolution M136 ... 321
- File
 - Creating ... 122

- F**
- File management ... 116
 - Calling ... 118
 - Configuring with MOD ... 562
 - Copying a file ... 123
 - Copying a table ... 125
 - Deleting a file ... 127
 - Dependent files ... 563
 - Directories ... 116
 - Copying ... 126
 - Creating ... 122
 - External data transfer ... 134
 - File
 - Creating ... 122
 - File name ... 115
 - File selection ... 119
 - File type ... 114
 - Marking files ... 128
 - Overview of functions ... 117
 - Overwriting files ... 124
 - Protecting a file ... 131
 - Renaming a file ... 130
 - Shortcuts ... 133
 - File status ... 118
 - Filter for hole positions during DXF data transfer ... 240
 - Fixture monitoring ... 343
 - Fixture placement ... 346
 - Fixture position, checking ... 348
 - Fixture templates ... 344, 352
 - Fixture Wizard ... 353
 - Fixtures, editing ... 347
 - Fixtures, removing ... 347
 - FixtureWizard ... 344
 - FN14: ERROR: Displaying error messages ... 275
 - FN15: PRINT: Unformatted output of texts ... 279
 - FN19: PLC: Transfer values to the PLC ... 280
 - Full circle ... 209
 - Fundamentals ... 98
- G**
- G01 block generation ... 570
 - Global program settings ... 355
 - GOTO during program interruption ... 529
 - Graphic simulation ... 518
 - Tool, displaying the ... 518
 - Graphics
 - Display modes ... 512
 - During programming ... 144, 146
 - Detail enlargement ... 145
 - Magnification of details ... 517
- H**
- Handwheel ... 452
 - Hard disk ... 114
 - Hard disk, checking ... 575
 - Helical interpolation ... 221
 - Helix ... 221
 - Help files, displaying ... 573
 - Help files, downloading ... 159
 - Help system ... 154
 - Help with error messages ... 149
- I**
- Inclined-tool machining in a tilted plane ... 413
 - Indexed tools ... 173
 - Information on formats ... 610
 - Interrupt machining ... 529
 - iTNC 530 ... 76
 - with Windows XP ... 614
- K**
- Keyboard ... 79
- L**
- Laser cutting machines, miscellaneous functions ... 331
 - List of error messages ... 150
 - Local Q parameters, defining ... 265
 - Look-ahead ... 323
- M**
- M functions
 - See "Miscellaneous functions"
 - M91, M92 ... 312
 - Machine axes, moving the ... 450
 - In increments ... 451
 - With the machine axis direction buttons ... 450
 - Machine parameters
 - For 3-D touch probes ... 585
 - For external data transfer ... 585
 - For machining and program run ... 597
 - For TNC displays and TNC editor ... 589
 - Machining time, measuring the... ... 519
 - Manage fixtures ... 350
 - Mid-program startup ... 533
 - After power failure ... 533
 - Miscellaneous Functions
 - Miscellaneous functions
 - Entering ... 310
 - For contouring behavior ... 315
 - For coordinate data ... 312
 - For laser cutting machines ... 331
 - For program run control ... 311
 - for Rotary Axes ... 414
 - For spindle and coolant ... 311
 - MOD function
 - Exiting ... 542
 - Overview ... 543
 - Select ... 542
 - Monitoring
 - Collision ... 337
 - Monitoring for tool breakage ... 376
- N**
- NC error messages ... 149, 150
 - Nesting ... 250
 - Network connection ... 136
 - Network connection, testing ... 561
 - Network settings ... 554
 - iTNC 530 with Windows XP ... 622
 - Nonvolatile Q parameters, defining ... 265
 - Normal vector ... 401



- O**
- Open contour corners M98 ... 319
 - Operating modes ... 80
 - Operating times ... 574
 - Option number ... 544
- P**
- Pallet datum ... 429
 - Pallet preset ... 429
 - Pallet table
 - Application ... 426, 432
 - Entering coordinates ... 427, 433
 - Executing ... 431, 443
 - Selecting and leaving ... 428, 437
 - Parametric programming: See Q parameter programming
 - Part families ... 266
 - Path ... 116
 - Path contours
 - Cartesian coordinates
 - Circular arc with tangential connection ... 212
 - Circular path around circle center CC ... 209
 - Circular path with defined radius ... 210
 - Overview ... 204
 - Straight line ... 205
 - Polar coordinates
 - Circular arc with tangential connection ... 220
 - Circular path around pole CC ... 219
 - Overview ... 217
 - Straight line ... 218
 - Path functions
 - Fundamentals ... 196
 - Circles and circular arcs ... 198
 - Pre-position ... 199
 - Pin layout for data interfaces ... 599
 - Ping ... 561
 - Plan view ... 512
- P**
- PLANE function ... 391
 - Animation ... 393
 - Automatic positioning ... 408
 - Axis angle definition ... 406
 - Euler angle definition ... 399
 - Inclined-tool machining ... 413
 - Incremental definition ... 405
 - Points definition ... 403
 - Positioning behavior ... 408
 - Projection angle definition ... 397
 - Reset ... 394
 - Selection of possible solutions ... 411
 - Space-angle definition ... 395
 - Vector definition ... 401
 - Pocket table ... 176
 - Polar coordinates
 - Fundamentals ... 100
 - Programming ... 217
 - Positioning
 - With a tilted working plane ... 314, 422
 - with manual data input (MDI) ... 504
 - Positions, selecting from DXF ... 236
 - Preset table ... 466
 - Confirming probed values ... 476
 - For pallets ... 429
 - Principal axes ... 99
 - Probe cycles
 - See User's Manual for Touch Probe Cycles
 - Probing cycles
 - Program
 - Editing ... 108
 - Open new ... 104
 - Structure ... 103
 - Structuring ... 142
 - Program call
 - Any desired program as subroutine ... 248
 - Program defaults ... 335
 - Program jumps with GOTO ... 529
 - Program management: see File management
 - Program name: See File management, File name
- P**
- Program Run
 - Global program settings ... 355
 - Interrupting ... 529
 - Program run
 - Executing ... 528
 - Mid-program startup ... 533
 - Optional block skip ... 538
 - Overview ... 527
 - Resuming after an interruption ... 532
 - Program sections, copying ... 111
 - Programming tool movements ... 106
 - Program-section repeat ... 247
 - Projection in three planes ... 513
- Q**
- Q parameter programming ... 262, 285
 - Additional functions ... 274
 - Basic arithmetic (assign, add, subtract, multiply, divide, square root) ... 267
 - If/then decisions ... 271
 - Programming notes ... 264, 287, 288, 289, 293, 295
 - Trigonometric functions ... 269
 - Q parameters
 - Checking ... 273
 - Local QL parameters ... 262
 - Nonvolatile QR parameters ... 262
 - Preassigned ... 296
 - Transferring values to the PLC ... 280
 - Unformatted output ... 279
- R**
- Radius compensation ... 191
 - Input ... 193
 - Outside corners, inside corners ... 194
 - Rapid traverse ... 162
 - Reference points, crossing over ... 446
 - Reference system ... 99
 - Replacing texts ... 113
 - Retraction from the contour ... 326
 - Returning to the contour ... 536
 - Rotary axis
 - Reducing display M94 ... 416
 - Shorter-path traverse: M126 ... 415



- S**
- Screen ... 77
 - Screen layout ... 78
 - Search function ... 112
 - Secondary axes ... 99
 - Service pack, installing a ... 546
 - Software number ... 544
 - Software options ... 607
 - Software update ... 546
 - SPEC FCT ... 334
 - Special functions ... 334
 - Specifications ... 602
 - iTNC 530 with Windows XP ... 616
 - Sphere ... 306
 - Spindle load monitoring ... 376
 - Spindle speed, changing the ... 463
 - Spindle speed, entering ... 179
 - Status display ... 83
 - Additional ... 85
 - General ... 83
 - Straight line ... 205, 218
 - String parameters ... 285
 - Structuring programs ... 142
 - Subprogram ... 245
 - Superimposed transformations ... 355
 - Superimposing handwheel positioning
 - M118 ... 325
 - Swapping axes ... 361
 - Switch between upper and lower case
 - letters ... 378
 - Switch-off ... 449
 - Switch-on ... 446
 - Swivel axes ... 417, 418
 - System time, reading the... 290
 - System time, setting ... 576
- T**
- Teach in ... 107, 205
 - Teach-in cut ... 370
 - TeleService ... 577
 - Test Run
 - Overview ... 520
 - Test run
 - Executing ... 523
 - Speed setting ... 511
 - Up to a certain block ... 524
 - Text file
 - Delete functions ... 379
 - Editing functions ... 378
 - Opening and exiting ... 377
 - Text sections, finding ... 381
 - Text variables ... 285
 - Tilting the working plane ... 391, 496
 - Manually ... 496
 - Time zone, setting the... 576
 - TNC software, updating the ... 546
 - TNCguide ... 154
 - TNCremo ... 549
 - TNCremoNT ... 549
 - Tool change ... 181
 - Tool compensation
 - Length ... 190
 - Radius ... 191
 - Tool data
 - Calling ... 179
 - Delta values ... 165
 - Entering into tables ... 166
 - Entering them into the
 - program ... 165
 - Indexing ... 173
 - Tool length ... 164
 - Tool management ... 186
 - Tool material ... 171, 384
 - Tool measurement ... 169
 - Tool name ... 164
 - Tool number ... 164
 - Tool radius ... 164
 - Tool table
 - Editing functions ... 172, 188, 189
 - Editing, exiting ... 172
 - Input possibilities ... 166
 - Tool type, selecting ... 171
 - Tool usage file ... 183
 - Tool usage test ... 183
 - Tool-carrier kinematics ... 174
 - Touch probe cycles
 - Manual Operation mode ... 473
- T**
- Touch probe functions, use with
 - mechanical probes or dial
 - gauges ... 495
 - Touch probe monitoring ... 327
 - Traversing machine axes
 - with the handwheel ... 452
 - Trigonometric functions ... 269
 - Trigonometry ... 269
- U**
- Unit of measure, selection ... 104
 - USB devices,
 - connecting/removing ... 137
 - USB interface ... 614
 - User parameters ... 584
 - General
 - For 3-D touch probes ... 585
 - For external data transfer ... 585
 - For machining and program
 - run ... 597
 - For TNC displays, TNC
 - editor ... 589
 - Machine-specific ... 564
- V**
- Version numbers ... 545
- W**
- Windows XP ... 614
 - Windows, logging on ... 617
 - Wireless handwheel ... 455
 - Configuring ... 580
 - Handwheel holder, assigning
 - ... 580
 - Statistical data ... 582
 - Transmission channel,
 - setting... 581
 - Transmitter power,
 - selecting... 582
 - WMAT.TAB ... 383
 - Workpiece blank, defining a ... 104
 - Workpiece material, defining ... 383
 - Workpiece measurement ... 492
 - Workpiece positions
 - Absolute ... 101
 - Incremental ... 101
 - Workspace monitoring ... 523, 565
 - Writing probed values in datum
 - tables ... 475
 - Writing probed values in preset
 - table ... 476



Overview Tables

Machining cycles

Cycle number	Cycle designation	DEF active	CALL active
7	Datum shift	■	
8	Mirror image	■	
9	Dwell time	■	
10	Rotation	■	
11	Scaling factor	■	
12	Program call	■	
13	Oriented spindle stop	■	
14	Contour definition	■	
19	Tilting the working plane	■	
20	SL II contour data	■	
21	SL II pilot drilling		■
22	SL II rough out		■
23	Floor finishing SL II		■
24	Side finishing SL II		■
25	Contour train		■
26	Axis-specific scaling	■	
27	Cylinder surface		■
28	Cylindrical surface slot		■
29	Cylinder surface ridge		■
30	Run 3-D data		■
32	Tolerance	■	
39	Cylinder surface external contour		■
200	Drilling		■
201	Reaming		■
202	Boring		■
203	Universal drilling		■



Cycle number	Cycle designation	DEF active	CALL active
204	Back boring		■
205	Universal pecking		■
206	Tapping with a floating tap holder, new		■
207	Rigid tapping, new		■
208	Bore milling		■
209	Tapping with chip breaking		■
220	Circular point pattern	■	
221	Linear point pattern	■	
230	Multipass milling		■
231	Ruled surface		■
232	Face milling		■
240	Centering		■
241	Single-fluted deep-hole drilling		■
247	Datum setting	■	
251	Rectangular pocket (complete machining)		■
252	Circular pocket (complete machining)		■
253	Slot milling		■
254	Circular slot		■
256	Rectangular stud (complete machining)		■
257	Circular stud (complete machining)		■
262	Thread milling		■
263	Thread milling/countersinking		■
264	Thread drilling/milling		■
265	Helical thread drilling/milling		■
267	Outside thread milling		■
270	Contour train data	■	
275	Trochoidal slot		■



Miscellaneous functions

M	Effect	Effective at block...	Start	End	Page
M0	Program run STOP/Spindle STOP/Coolant OFF			■	Page 311
M1	Optional program STOP/Spindle STOP/Coolant OFF (machine-dependent)			■	Page 539
M2	Program run STOP/Spindle STOP/Coolant OFF/Clear status display (depending on machine parameter)/Go to block 1			■	Page 311
M3	Spindle ON clockwise		■		Page 311
M4	Spindle ON counterclockwise		■		
M5	Spindle STOP			■	
M6	Tool change/Stop program run (depending on machine parameter)/Spindle STOP			■	Page 311
M8	Coolant ON		■		Page 311
M9	Coolant OFF			■	
M13	Spindle ON clockwise/Coolant ON		■		Page 311
M14	Spindle ON counterclockwise/Coolant ON		■		
M30	Same function as M2			■	Page 311
M89	Vacant miscellaneous function or Cycle call, modally effective (depending on machine parameter)		■	■	Cycles Manual
M90	Only in lag mode: Constant contouring speed at corners			■	Page 315
M91	Within the positioning block: Coordinates are referenced to machine datum		■		Page 312
M92	Within the positioning block: Coordinates are referenced to position defined by machine tool builder, such as tool change position		■		Page 312
M94	Reduce the rotary axis display to a value below 360°		■		Page 416
M97	Machine small contour steps			■	Page 317
M98	Machine open contours completely			■	Page 319
M99	Blockwise cycle call			■	Cycles Manual
M101	Automatic tool change with replacement tool if maximum tool life has expired			■	Page 182
M102	Reset M101			■	
M103	Reduce feed rate during plunging to factor F (percentage)		■		Page 320
M104	Reactivate the datum as last defined		■		Page 314
M105	Machining with second k_v factor		■		Page 584
M106	Machining with first k_v factor		■		
M107	Suppress error message for replacement tools with oversize		■		Page 182
M108	Reset M107			■	



M	Effect	Effective at block...	Start	End	Page
M109	Constant contouring speed at tool cutting edge (increase and decrease feed rate)		■		Page 322
M110	Constant contouring speed at tool cutting edge (feed rate decrease only)		■		
M111	Reset M109/M110			■	
M114	Automatic compensation of machine geometry when working with tilted axes		■		Page 417
M115	Reset M114			■	
M116	Feed rate for rotary axes in mm/min		■		Page 414
M117	Reset M116			■	
M118	Superimpose handwheel positioning during program run		■		Page 325
M120	Pre-calculate radius-compensated contour (LOOK AHEAD)		■		Page 323
M124	Do not include points when executing non-compensated line blocks		■		Page 316
M126	Shortest-path traverse of rotary axes		■		Page 415
M127	Reset M126			■	
M128	Retain position of tool tip when positioning tilting axes (TCPM)		■		Page 418
M129	Reset M128			■	
M130	Moving to position in an untilted coordinate system with a tilted working plane		■		Page 314
M134	Exact stop at nontangential contour transitions when positioning with rotary axes		■		Page 421
M135	Reset M134			■	
M136	Feed rate F in millimeters per spindle revolution		■		Page 321
M137	Reset M136			■	
M138	Selection of tilted axes		■		Page 421
M140	Retraction from the contour in the tool-axis direction		■		Page 326
M141	Suppress touch probe monitoring		■		Page 327
M142	Delete modal program information		■		Page 328
M143	Delete basic rotation		■		Page 328
M144	Compensating the machine's kinematics configuration for ACTUAL/NOMINAL positions at end of block		■		Page 422
M145	Reset M144			■	
M148	Retract the tool automatically from the contour at NC stop		■		Page 329
M149	Reset M148			■	
M150	Suppress limit switch message (function effective blockwise)		■		Page 330
M200	Laser cutting: Output programmed voltage directly		■		Page 331
M201	Laser cutting: Output of voltage as a function of distance		■		
M202	Laser cutting: Output of voltage as a function of speed		■		
M203	Laser cutting: Output of voltage as a function of time (ramp)		■		
M204	Laser cutting: Output voltage as a function of time (pulse)		■		



Overview of DIN/ISO Functions of the iTNC 530

M Functions	
M00	Program STOP/Spindle STOP/Coolant OFF
M01	Optional program STOP
M02	STOP program run/Spindle STOP/Coolant OFF/CLEAR status display (depending on machine parameter)/Go to block 1
M03	Spindle ON clockwise
M04	Spindle ON counterclockwise
M05	Spindle STOP
M06	Tool change/STOP program run (depending on machine parameter)/Spindle STOP
M08	Coolant ON
M09	Coolant OFF
M13	Spindle ON clockwise/Coolant ON
M14	Spindle ON counterclockwise/Coolant ON
M30	Same function as M02
M89	Vacant miscellaneous function or Cycle call, modally effective (depending on machine parameter)
M90	Only in lag mode: Constant contouring speed at corners
M99	Blockwise cycle call
M91	Within the positioning block: Coordinates are referenced to machine datum
M92	Within the positioning block: Coordinates are referenced to position defined by machine tool builder, such as tool change position
M94	Reduce the rotary axis display to a value below 360°
M97	Machine small contour steps
M98	Machine open contours completely
M101	Automatic tool change with replacement tool if maximum tool life has expired
M102	Reset M101
M103	Reduce feed rate during plunging to factor F (percentage)
M104	Reactivate most recently set datum
M105	Machining with second kv factor
M106	Machining with first kv factor
M107	Suppress error message for replacement tools with oversize
M108	Reset M107

M Functions	
M109	Constant contouring speed at tool cutting edge (increase and decrease feed rate)
M110	Constant contouring speed at tool cutting edge (feed rate decrease only)
M111	Reset M109/M110
M114	Automatic compensation of machine geometry when working with tilted axes:
M115	Reset M114
M116	Feed rate for rotary axes in mm/min
M117	Reset M116
M118	Superimpose handwheel positioning during program run
M120	Pre-calculate radius-compensated contour (LOOK AHEAD)
M124	Do not include points when executing non-compensated line blocks
M126	Shortest-path traverse of rotary axes
M127	Reset M126
M128	Retain position of tool tip when positioning tilting axes (TCPM)
M129	Reset M128
M130	Within the positioning block: Points are referenced to the untilted coordinate system
M134	Exact stop at nontangential contour transitions when positioning with rotary axes
M135	Reset M134
M136	Feed rate F in millimeters per spindle revolution
M137	Cancel M136
M138	Selection of tilted axes
M142	Delete modal program information
M143	Delete basic rotation
M144	Compensating the machine's kinematics configuration for ACTUAL/NOMINAL positions at end of block
M145	Reset M144
M150	Suppress limit switch message

M Functions

M200	Laser cutting: Direct output of the programmed voltage
M201	Laser cutting: Output voltage as a function of distance
M202	Laser cutting: Output voltage as a function of speed
M203	Laser cutting: Output voltage as a function of time (ramp)
M204	Laser cutting: Output voltage as a function of time (pulse)

G Functions

Tool movements

G00	Straight-line interpolation, Cartesian coordinates, rapid traverse
G01	Straight-line interpolation, Cartesian coordinates
G02	Circular interpolation, Cartesian coordinates, clockwise
G03	Circular interpolation, Cartesian coordinates, counterclockwise
G05	Circular interpolation, Cartesian coordinates, without indication of direction
G06	Circular interpolation, Cartesian coordinates, tangential contour approach
G07*	Paraxial positioning block
G10	Straight-line interpolation, polar coordinates, rapid traverse
G11	Straight-line interpolation, polar coordinates
G12	Circular interpolation, polar coordinates, clockwise
G13	Circular interpolation, polar coordinates, counterclockwise
G15	Circular interpolation, polar coordinates, without indication of direction
G16	Circular interpolation, polar coordinates, tangential contour approach

Chamfer/Rounding/Approach contour/Depart contour

G24*	Chamfer with length R
G25*	Corner rounding with radius R
G26*	Tangential contour approach with radius R
G27*	Tangential contour approach with radius R

Tool definition

G99*	With tool number T, length L, radius R
------	--

Tool radius compensation

G40	No tool radius compensation
G41	Tool radius compensation, left of the contour
G42	Tool radius compensation, right of the contour
G43	Paraxial compensation for G07, lengthening
G44	Paraxial compensation for G07, shortening

Blank form definition for graphics

G30	(G17/G18/G19) min. point
G31	(G90/G91) max. point

G Functions

Cycles for drilling, tapping and thread milling

G240	Centering
G200	Drilling
G201	Reaming
G202	Boring
G203	Universal drilling
G204	Back boring
G205	Universal pecking
G206	Tapping with a floating tap holder
G207	Rigid tapping
G208	Bore milling
G209	Tapping with chip breaking
G241	Single-fluted deep-hole drilling

Cycles for drilling, tapping and thread milling

G262	Thread milling
G263	Thread milling/countersinking
G264	Thread drilling/milling
G265	Helical thread drilling/milling
G267	External thread milling

Cycles for milling pockets, studs and slots

G251	Rectangular pocket, complete
G252	Circular pocket, complete
G253	Slot, complete
G254	Circular slot, complete
G256	Rectangular stud
G257	Circular stud

Cycles for creating point patterns

G220	Circular point pattern
G221	Point patterns on lines

SL cycles, group 2

G37	Contour geometry, list of subcontour program numbers
G120	Contour data (applies to G121 to G124)
G121	Pilot drilling
G122	Rough-out
G123	Floor finishing
G124	Side finishing
G125	Contour train (machining open contour)
G127	Cylinder surface
G128	Cylindrical surface slot
G275	Trochoidal slot

Coordinate transformation

G53	Datum shift in datum table
G54	Datum shift in program
G28	Mirror image
G73	Rotation of the coordinate system
G72	Scaling factor (reduce or enlarge contour)
G80	Tilting the working plane
G247	Datum setting

G Functions

Cycles for multipass milling

G60	Run 3-D data
G230	Multipass milling of plane surfaces
G231	Multipass milling of tilted surfaces

*) Non-modal function

Touch probe cycles for measuring workpiece misalignment

G400	Basic rotation using two points
G401	Basic rotation from two holes
G402	Basic rotation from two studs
G403	Compensate a basic rotation via a rotary axis
G404	Set basic rotation
G405	Compensating misalignment with the C axis

Touch probe cycles for datum setting

G408	Slot center reference point
G409	Reference point at center of hole
G410	Datum from inside of rectangle
G411	Datum from outside of rectangle
G412	Datum from inside of circle
G413	Datum from outside of circle
G414	Datum in outside corner
G415	Datum in inside corner
G416	Datum circle center
G417	Datum in touch probe axis
G418	Datum in center of 4 holes
G419	Reference point in selectable axis

Touch probe cycles for workpiece measurement

G55	Measure any coordinate
G420	Measure any angle
G421	Measure hole
G422	Measure cylindrical stud
G423	Measure rectangular pocket
G424	Measure rectangular stud
G425	Measure slot
G426	Measure ridge
G427	Measure any coordinate
G430	Measure circle center
G431	Measure any plane

Touch probe cycles for kinematic measurement

G450	Calibrate the TT
G481	Measure tool length
G482	Measure tool radius
G483	Measure tool length and tool radius

Touch probe cycles for tool measurement

G480	Calibrating the TT
G481	Measure tool length
G482	Measure tool radius
G483	Measure tool length and tool radius
G484	Calibrate infrared TT

G Functions

Special cycles

G04*	Dwell time with F seconds
G36	Spindle orientation
G39*	Program call
G62	Tolerance deviation for fast contour milling
G440	Measure axis shift
G441	Fast probing

Define machining plane

G17	Working plane X/Y, tool axis Z
G18	Working plane Z/X, tool axis Y
G19	Working plane Y/Z, tool axis X
G20	Tool axis IV

Dimensions

G90	Absolute dimensions
G91	Incremental dimensions

Unit of measure

G70	Inches (set at start of program)
G71	Millimeters (set at start of program)

Other G functions

G29	Transfer the last nominal position value as a pole (circle center)
G38	STOP program run
G51*	Next tool number (with central tool file)
G79*	Cycle call
G98*	Set label number

*) Non-modal function

Addresses

%	Program beginning
%	Program call

Datum number with G53

A	Rotation about X axis
B	Rotation about Y axis
C	Rotation about Z axis

D Q-parameter definitions

DL	Length wear compensation with T
DR	Radius wear compensation with T

E Tolerance with M112 and M124

F	Feed rate
F	Dwell time with G04
F	Scaling factor with G72
F	Factor for feed-rate reduction F with M103

G G Functions

Addresses

H	Polar coordinate angle
H	Rotation angle with G73
H	Tolerance angle with M112
I	X coordinate of the circle center/pole
J	Y coordinate of the circle center/pole
K	Z coordinate of the circle center/pole
L	Set a label number with G98
L	Jump to a label number
L	Tool length with G99
M	M functions
N	Block number
P	Cycle parameters in machining cycles
P	Value or Q parameter in Q-parameter definition
Q	Q parameter
R	Polar coordinate radius
R	Circular radius with G02/G03/G05
R	Rounding radius with G25/G26/G27
R	Tool radius with G99
S	Spindle speed
S	Oriented spindle stop with G36
T	Tool definition with G99
T	Tool call
T	Next tool with G51
U	Axis parallel to X axis
V	Axis parallel to Y axis
W	Axis parallel to Z axis
X	X axis
Y	Y axis
Z	Z axis
*	End of block

Contour cycles**Sequence of Program Steps for Machining with Several Tools**

List of subcontour programs	G37 P01 ...
Define contour data	G120 Q1 ...
Define/Call drill Contour cycle: pilot drilling Cycle call	G121 Q10 ...
Define/Call roughing mill Contour cycle: rough-out Cycle call	G122 Q10 ...
Define/Call finishing mill Contour cycle: floor finishing Cycle call	G123 Q11 ...
Define/Call finishing mill Contour cycle: side finishing Cycle call	G124 Q11 ...
End of main program, return	M02
Contour subprograms	G98 ... G98 L0

Radius compensation of the contour subprograms

Contour	Programming Sequence of the Contour Elements	Radius Compensation
Internal (pocket)	Clockwise (CW)	G42 (RR)
	Counterclockwise (CCW)	G41 (RL)
External (island)	Clockwise (CW)	G41 (RL)
	Counterclockwise (CCW)	G42 (RR)

Coordinate transformation

Coordinate transformation	Activate	Cancelation
Datum shift	G54 X+20 Y+30 Z+10	G54 X0 Y0 Z0
Mirror image	G28 X	G28
Rotation	G73 H+45	G73 H+0
Scaling factor	G72 F 0.8	G72 F1
Working plane	G80 A+10 B+10 C+15	G80
Working plane	PLANE ...	PLANE RESET

Q-parameter definitions

D	Function
00	Assignment
01	Addition
02	Subtraction
03	Multiplication
04	Division
05	Root
06	Sine
07	Cosine
08	Root sum of squares $c = \sqrt{a^2+b^2}$
09	If equal, go to label number
10	If not equal, go to label number
11	If greater than, go to label number
12	If less than, go to label number
13	Angle from c sin a and c cos a
14	Error number
15	Print
19	Assignment PLC

HEIDENHAIN

DR. JOHANNES HEIDENHAIN GmbH

Dr.-Johannes-Heidenhain-Straße 5

83301 Traunreut, Germany

☎ +49 8669 31-0

FAX +49 8669 5061

E-mail: info@heidenhain.de

Technical support FAX +49 8669 32-1000

Measuring systems ☎ +49 8669 31-3104

E-mail: service.ms-support@heidenhain.de

TNC support ☎ +49 8669 31-3101

E-mail: service.nc-support@heidenhain.de

NC programming ☎ +49 8669 31-3103

E-mail: service.nc-pgm@heidenhain.de

PLC programming ☎ +49 8669 31-3102

E-mail: service.plc@heidenhain.de

Lathe controls ☎ +49 8669 31-3105

E-mail: service.lathe-support@heidenhain.de

www.heidenhain.de

3-D Touch Probe Systems from HEIDENHAIN

help you to reduce non-cutting time:

For example in

- workpiece alignment
- datum setting
- workpiece measurement
- digitizing 3-D surfaces

with the workpiece touch probes

TS 220 with cable

TS 640 with infrared transmission



- tool measurement
- wear monitoring
- tool breakage monitoring

with the tool touch probe

TT 140

